

# 2021 OWNER'S MANUAL AND MAINTENANCE INFORMATION



For your safety, read carefully and keep in this vehicle

# CALIFORNIA PROPOSITION 65 WARNING

# **WARNING**

Operating, servicing and maintaining a passenger vehicle or off-highway motor vehicle can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle in a well-ventilated area and wear gloves or wash your hands frequently when servicing your vehicle. For more information go to www.P65Warnings.ca. gov/passenger-vehicle.

#### **FOREWORD**

This manual was prepared to help you understand the operation and maintenance of your vehicle so that you may enjoy many miles (kilometers) of driving pleasure. Please read through this manual before operating your vehicle.

A separate Warranty Information Booklet contains the warranties covering your vehicle (whose terms have control over this Owner's Manual or any other document or representation regarding warranty coverage).

Additionally, a separate Customer Care/ Lemon Law Booklet (U.S. only) will explain how to resolve any concerns you may have with your vehicle, as well as clarify your rights under your state's lemon law.

In addition to factory installed options, your vehicle may also be equipped with additional accessories installed by NISSAN or your GT-R certified NISSAN dealer prior to delivery. It is important that you familiarize yourself with all disclosures, warnings, cautions and instructions concerning proper use of such accessories prior to operating the vehicle and/or accessory. It is recommended you see a GT-R certified NISSAN dealer for details concerning the particular accessories with which your vehicle is equipped.

Your GT-R certified NISSAN dealer knows your vehicle best. When you require any service or have any questions, they will be glad to assist you with the extensive resources available to them.

## **READ FIRST — THEN DRIVE SAFELY**

Before driving your vehicle, please read this Owner's Manual carefully. This will ensure familiarity with controls and maintenance requirements, assisting you in the safe operation of your vehicle.



# IMPORTANT SAFETY INFORMATION REMINDERS!

Follow these important driving rules to help ensure a safe and comfortable trip for you and your passengers!

- NEVER drive under the influence of alcohol or drugs.
- ALWAYS observe posted speed limits and never drive too fast for conditions.
- ALWAYS give your full attention to driving and avoid using vehicle features or taking other actions that could distract you.

- ALWAYS use your seat belts and appropriate child restraint systems. Pre-teen children should be seated in the rear seat.
- ALWAYS provide information about the proper use of vehicle safety features to all occupants of the vehicle.
- ALWAYS review this Owner's Manual for important safety information.

#### **MODIFICATION OF YOUR VEHICLE**

This vehicle should not be modified. Modification could affect its performance, safety or durability, and may even violate governmental regulations. See the 2021 NISSAN GT-R Warranty Information Booklet for details including applicable exclusions.

# **WARNING**

Installing an aftermarket On-Board Diagnostic (OBD) plug-in device that uses the port during normal driving, for example remote insurance company monitoring, remote vehicle diagnostics, telematics or engine reprogramming, may cause interfer-

ence or damage to vehicle systems. We do not recommend or endorse the use of any aftermarket OBD plug-in devices, unless specifically approved by NISSAN. The vehicle warranty may not cover damage caused by any aftermarket plug-in device.

## WHEN READING THE MANUAL

This manual includes information for all features and equipment available on this model. Features and equipment in your vehicle may vary depending on model, trim level, options selected, order, date of production, region or availability. Therefore, you may find information about features or equipment that are not included or installed on your vehicle.

All information, specifications and illustrations in this manual are those in effect at the time of printing. NISSAN reserves the right to change specifications, performance, design or component suppliers without notice and without obligation. From time to time, NISSAN may update or revise this manual to provide owners with the most accurate information currently available. Please carefully read and

retain with this manual all revision updates sent to you by NISSAN to ensure you have access to accurate and up-todate information regarding your vehicle. Current versions of vehicle Owner's Manuals and any updates can also be found in the Owner section of the NISSAN website at https://owners.nissanusa.com/nowners/navigation/manualsGuide. If you have questions concerning any information in your Owner's Manual, contact NISSAN Consumer Affairs. See the NISSAN CUSTOMER CARE PROGRAM page in this Owner's Manual for contact information.

# IMPORTANT INFORMATION ABOUT THIS MANUAL

You will see various symbols in this manual. They are used in the following ways:

# **WARNING**


This is used to indicate a hazard that could cause death or serious personal injury. To avoid or reduce the risk, follow the information and instructions exactly.

# **A** CAUTION

This is used to indicate a hazard that could cause minor or moderate personal injury. To avoid or reduce the risk, follow the information and instructions carefully.

# **NOTICE**

This is used to indicate a hazard that could cause damage to property or your vehicle. To avoid or reduce the risk, follow the information and instructions.



If you see the symbol above, it means "Do not do this" or "Do not let this happen".





If you see a symbol similar to those above in an illustration, it means the arrow points to the front of the vehicle.









Arrows in an illustration that are similar to those above indicate movement or action.









Arrows in an illustration that are similar to those above call attention to an item in the illustration.



This indicates the title and reference page.

# CALIFORNIA PERCHLORATE ADVI-SORY

Some vehicle parts, such as lithium batteries, may contain perchlorate material. The following advisory is provided: "Perchlorate Material - special handling may apply, See www.dtsc.ca. gov/hazardouswaste/perchlorate."

© 2020 NISSAN MOTOR CO., LTD.

All rights reserved. No part of this Owner's Manual may be reproduced or stored in a retrieval system, or transmitted in any form, or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of NISSAN Motor Co., Ltd.

#### NISSAN CUSTOMER CARE PROGRAM

#### NISSAN CARES ...

Both NISSAN and your GT-R certified NISSAN dealer are dedicated to serving all your automotive needs. Your satisfaction with your vehicle and your GT-R certified NISSAN dealer are our primary concerns. Your GT-R certified NISSAN dealer is always available to assist you with all your automobile sales and service needs.

However, if there is something that your GT-R certified NISSAN dealer cannot assist you with or you would like to provide NISSAN directly with comments or questions, please contact the NISSAN Consumer Affairs Department using our toll-free number:

For U.S. customers 1-866-668-1GTR (1-866-668-1487) For Canadian customers 1-800-387-0122 The Consumer Affairs Department will ask for the following information:

- Your name, address, and telephone number
- Vehicle identification number (attached to the top of the instrument panel on the driver's side)
- Date of purchase
- Current odometer reading
- Your NISSAN dealer's name
- Your comments or questions

OR

You can write to NISSAN with the information on the left at:

For U.S. customers
NISSAN North America, Inc.
Consumer Affairs Department
P.O. Box 685003
Franklin, TN 37068-5003
or via e-mail at:
nnaconsumeraffairs@nissan-usa.

com
For Canadian customers
NISSAN Canada Inc.
5290 Orbitor Drive
Mississauga, Ontario L4W 4Z5
or via e-mail at:
information.centre@nissancana-da.com

If you prefer, visit us at:

www.nissanusa.com (for U.S. customers) or www.nissan.ca (for Canadian customers)

We appreciate your interest in NISSAN and thank you for buying a quality NISSAN vehicle.

# Table of Contents

GT-R Overview	GTR
Illustrated table of contents	0
Safety — Seats, seat belts and supplemental restraint system	1
Instruments and controls	2
Pre-driving checks and adjustments	3
Display screen, heater, air conditioner and audio systems	4
Starting and driving	5
In case of emergency	6
Appearance and care	7
Do-it-yourself	8
Maintenance and schedules	9
Technical and consumer information	10
Index	11

# **GT-R Overview**

G٦	-R specific information	GTR-3	Pred	cautions before driving	GTR-1
	Warranty information	GTR-3	\	/ehicle Dynamic Control (VDC)	
	Maintenance information	GTR-3	(	OFF mode	GTR-1
G٦	-R special specification parts	GTR-4	5	Summer tires	GTR-1
	Engine oil	GTR-4	A	All-season tires	GTR-1
	Transmission oil	GTR-4	A	Avoiding body damage	GTR-1
	Differential oil (front and rear)	GTR-5		Fuel	
	Brake fluid	GTR-5	E	Body repair	GTR-1
GΤ	-R special precautions			Driving after replacing tires	
	Tires and road wheels	GTR-5	Add	itional maintenance items	GTR-1
	Brake pad and disc rotor	GTR-6	F	Precautions on performance driving	GTR-1
	NCCB (NISSAN Carbon Ceramic Brake) (if			nspection and adjustments	
	so equipped)	GTR-6		pefore driving	GTR-1
	Exhaust muffler and trunk carpet	GTR-7		nspection and adjustments	
	Titanium muffler and trunk carpet (if			after driving	
	so equipped)	GTR-7	GT-I	R specific vehicle characteristics	GTR-2
	Dry carbon fiber parts (if so equipped)	GTR-8	F	Refueling precautions	GTR-2
	Engine start and stop	GTR-8	(	Gasoline smell	GTR-2
GΤ	-R performance optimization services	GTR-8	(	Outside temperature display indicates	
	Wheel alignment inspection and		ŀ	nigher temperature	GTR-2
	adjustment (if necessary) (including tire		- 1	dle speed is not steady	GTR-2
	pressure adjustment)	GTR-9	E	Engine speed is restricted	GTR-2
	Transmission settings	GTR-9	E	Engine output	GTR-2
Br	eak-in schedule	GTR-10	ι	Jneven wear of tires	GTR-2
	Wheel alignment	GTR-10	1	Noises are heard while driving	GTR-2

Brake system information	GTR-28	Exhaust gas is not emitted from left
Change of surface color of titanium		exhaust pipe during idling/when engine
muffler (if so equipped)	GTR-30	speed is low (if so equipped) GTR-30
The color tone of the titanium muffler		Dry carbon fiber parts (if so equipped) GTR-30
finisher might be different from others		Dual clutch transmission GTR-30
(if so equipped)	GTR-30	Transmission
Sound heard around titanium muffler		operation characteristics GTR-32
(if so equipped)	GTR-30	

# **GT-R SPECIFIC INFORMATION**

The GT-R is NISSAN's first supercar category vehicle. The GT-R is equipped with special systems. These systems are different than those used on conventional vehicles to allow for the high performance driving characteristics of this vehicle. It is recommended that your vehicle be maintained by a GT-R certified NISSAN dealer. Special skills, knowledge and equipment are necessary to properly maintain your GT-R.

#### WARRANTY INFORMATION

Please read this Owner's Manual carefully, together with your Warranty Information Booklet which describes a number of express limitations, exclusions and ways to void your warranty for failing to follow the instructions contained in this Owner's Manual, including, but not limited to:

- Failure to use proper parts, fuel and fluids.
- Driving with the VDC off,
- Racing,
- Any competitive driving of any sort whatsoever,
- Use on a track or driving on any airstrip,
- Modifications, including adding/replacing, reprogramming, attempting to

reprogram, altering, disconnecting any computer, control unit or electronic modules,

- Deleting any or all stored information in any computer, control unit or electronic module including VSDR,
- Failure to have required GT-R Performance Optimization Services performed.

In addition, see your tire warranty for specific limitations or exclusions for operating summer tires below  $-4^{\circ}F$  ( $-20^{\circ}C$ ).

#### MAINTENANCE INFORMATION

- Special skills, knowledge and equipment are necessary to properly inspect and adjust the GT-R engine, transmission, suspension and brakes to maintain performance. A GT-R certified NISSAN dealer has the GT-R certified technical staff and the special equipment to properly maintain your GT-R.
- NISSAN recommends maintenance items that require the replacement of parts, engine oil, oil filters and air filters be performed by a GT-R certified NISSAN dealer. Make sure the recommended fluids and parts are used when the maintenance is performed. NISSAN also recommends the replace-

ment of parts such as brakes should be performed by a GT-R certified NISSAN dealer.

# **NOTICE**

It is recommended that you only use the following specified fluids and parts in the GT-R to avoid possible vehicle damage.

## **ENGINE OIL**

# Mobil 1 (0W-40) (100% synthetic oil) or equivalent

Mobil 1 (0W-40) (100% synthetic) is the factory fill oil. The VR38 engine with its plasma-sprayed bores was developed using this oil. NISSAN cannot ensure proper engine operation and durability if other non-equivalent synthetic oil is used. If Mobil 1 (0W-40) or equivalent is not available, Mobil 1 (10W-40) (100% synthetic) or equivalent may be used; however, some performance loss may be noticed.

Furthermore, replacement of the engine oil with MOTUL NISMO COMPETITION OIL type 2193E(5W40) is recommended for the frequent high performance driving opportunities.

NISSAN cannot ensure proper engine operation and durability if other non-equivalent synthetic oil is used.

# The use of additives, chemical materials or abrasive compounds is prohibited.

The use of additives, chemical materials, abrasive compounds or other high performance engine oils may cause internal engine damage.

# **Engine oil maintenance**

- When the vehicle is delivered, the engine oil level is 0.39 in (10 mm) below the H mark on the engine oil dipstick for optimum high performance driving. The engine oil can be filled up to the H mark if not engaging in performance driving.
- Because of the high performance characteristics of the GT-R engine, more frequent oil level inspections are necessary. Check the oil level every 1,800 miles (3,000 km) and adjust as necessary. Also, change the engine oil based on the driving conditions. For the information regarding oil replacement intervals, refer to the "9. Maintenance and schedules" section of this manual.
- Some amount of oil is consumed by your engine under normal operating conditions, and oil consumption by itself does not necessarily indicate any malfunction. If your rate of oil

- consumption increases suddenly or without explanation, NISSAN recommends that you have your vehicle inspected by a GT-R certified NISSAN dealer.

Make sure to replace the oil filter when the engine oil is changed.

## TRANSMISSION OIL

## Genuine NISSAN Transmission Oil R35 Special (100% synthetic oil) or equivalent

The GT-R uses a multiple-disc dual wet clutch transmission. The specially developed transmission oil maximizes the friction characteristics of the clutch and the lubrication of the gear bearings.

# The use of additives is not recommended.

The use of additives or other transmission oil may cause internal transmission or clutch damage.

# DIFFERENTIAL OIL (front and rear) Differential Oil R35 COMPETITION type 2189E or equivalent

Use Differential Oil R35 COMPETITION type 2189E or equivalent that can keep the oil temperature low in order to protect all parts of the differential and maximize the performance of the Limited Slip Differential (LSD).

## The use of additives is not recommended.

Using additives or any other than the specified differential oil may cause the oil temperature to increase and the final drive to be damaged. Also it may cause vibration and adversely the vehicle handling characteristics.

#### **BRAKE FLUID**

# Genuine NISSAN Brake Fluid R35 Special II or equivalent

Genuine NISSAN Brake Fluid R35 Special II is the factory fill brake fluid. The Vehicle Dynamic Control (VDC) unit and other related parts were specially designed for this brake fluid. NISSAN cannot ensure proper operation of the vehicle if other non-equivalent brake fluid is used.

# **GT-R SPECIAL PRECAUTIONS**

## **TIRES AND ROAD WHEELS**

## **Tires**

The GT-R uses specially designed run-flat tires and matching road wheels. Use of these specially developed tires and wheels provides the greatest potential for maximum performance.

- Using non-genuine GT-R tires may cause powertrain system damage if the vehicle is driven in a flat tire situation, even if run-flat tires are used. This may also prevent the vehicle from being stopped safely.
- Using non-genuine GT-R tires may also cause tire failure due to excessive heat buildup caused by tire distortion while driving.
- Using non-genuine GT-R tires may affect the operation of the VDC system.

# Tire replacement:

When tire replacement is required, replacing tires as a set of four with new tires is recommended. However, if a tire is punctured or damaged, it may be possible to replace only the damaged tire. Determining whether one tire or a complete set of tires should be replaced is based on a number of factors including tire wear and condition. Your GT-R certified NISSAN dealer can recommend if an individual tire or a complete set should be replaced.

- The GT-R uses specially designed runflat tires which have a rigid side wall. Special equipment and procedures are required when replacing these tires. NISSAN recommends that tire replacement be performed at a GT-R certified NISSAN dealer.
- Specific tire changing equipment must be used to remove the GT-R tires from the wheel and to install the GT-R tires onto the wheel. It is only possible to reuse the tires when they have no cracks and/or deformations on the bead portion of the tire. If the incorrect equipment is used to remove the GT-R tires from the wheel and to install the GT-R tires onto the wheel, cracks and deformation may occur on the bead portion of the tires meaning that the tires cannot be reused. We recommend contacting a GT-R certified NISSAN dealer if the tires need to be removed from the wheels.
- When reusing tires, it is recommended you contact a GT-R certified NISSAN

dealer.

## Road wheels

Using non-genuine GT-R wheels may cause the following:

- vehicle vibration
- the tire coming loose from the wheel during a flat tire
- · reduced wheel lug nut tightness

## **BRAKE PAD AND DISC ROTOR**

This vehicle is equipped with cross-drilled floating rotors and radial-mounted six-piston monoblock calipers. This helps to achieve excellent stopping performance and fade-resistance.

Using non-genuine GT-R brake pads or rotors can affect vehicle braking performance and the operation of the ABS and VDC system.

# Replacement of brake pads and disc rotors

# For models without NCCB (NISSAN Carbon Ceramic Brake) package:

NISSAN generally recommends to replace all four sets of brake pads and disc rotors at the same time to maintain maximum brake performance. However, replacing only the brake pads may be allowed in some cases (four wheels or only front wheels depending on the conditions). A GT-R certified technician must inspect the vehicle and determine that only the brake pads need to be replaced. In this case, replacing all brake pads and disc rotors as a set is not necessary.

Note that the replacement of brake pads and the disc rotors as a set on all four wheels should be performed when a GT-R certified technician determines that this is the correct repair.

If the inside of the disc rotors are cold during the winter and the surface becomes hot due to a heavy force being applied repeatedly to the brakes, cracks may occur near the coolant hole on the surface of the disc rotor. Cracks may also occur due to a heavy force being repeatedly applied to the brakes during high performance driving. In these cases it may be necessary to replace the disc rotors or brake pads depending on the condition of the crack. We recommend contacting a GT-R certified NISSAN dealer for replacement.

# NCCB (NISSAN Carbon Ceramic Brake) (if so equipped)

In order to enjoy the high performance braking sensation as well as the sporty driving and flexibility offered by the GT-R, NCCB (NISSAN Carbon Ceramic Brake) is available, NCCB (NISSAN Carbon Ceramic Brake) is specially designed brake system. Conventional carbon ceramic brakes have weaknesses in braking performance when driving in the rain, at a low temperature or at low speeds. However, NCCB (NISSAN Carbon Ceramic Brake) achieves both a stable brake force at high temperatures during high performance driving and braking performance under such driving conditions. NISSAN recommends that you have the NCCB (NISSAN Carbon Ceramic Brake) and the related parts maintained by a GT-R certified NISSAN dealer. Otherwise, the braking performance may not be delivered across all situations and the brake system may be damaged, which could result in a serious accident

# Replacement of brake pads and disc rotors

When replacing brake pads and brake disc rotors, NISSAN recommends replacing two sets of them at the same time. However, the brake pads can be separately replaced only when a GT-R certified technician judges that the brake disc rotors are reusable, based on a measured weight and a check for scratches and cracks.

# EXHAUST MUFFLER AND TRUNK CARPET

The GT-R exhaust system is designed to provide the maximum vehicle performance and to protect the vehicle from high exhaust gas temperatures.

If non-genuine GT-R exhaust system parts are used it is possible that the muffler or other exhaust system parts will deform and cause damage to the underbody. Non-genuine GT-R exhaust system parts can also affect vehicle performance and possibly lead to turbocharger, engine or power train related parts including transmission, damage.

Also, do not remove the trunk carpet from the vehicle for any reason. The carpet insulates the vehicle interior from the heat of the muffler and from the noise of the transmission.

# TITANIUM MUFFLER AND TRUNK CARPET (if so equipped)

If a non-genuine titanium muffler is used. the muffler may become deformed and damage the underbody due to the high performance engine reaching high exhaust gas temperatures (1,832°F (1.000°C) or more). The highest-class titanium alloy is used for genuine parts to ensure the resistance strength and creeping characteristics against high exhaust gas temperature. In addition, further cooling effects are secured by taking in air through the duct on the undercover, to cool the area around the muffler, and by applying partial plate thickness reduction. Since genuine titanium mufflers are made of titanium allov. the surface color will change depending on the driving conditions, which is not unusual. Prior to shipping from factory, all vehicles receive balance aligning for engine, transmission, and clutch, as well as quench driving of brake pads and rotors. As a result, the muffler surface color may differ depending on the vehicle.

Never remove the trunk carpet from the vehicle for any reason. The carpet insulates the vehicle interior from the heat of the muffler and from the noise of the transmission.

# Never Allow Oil or Grease to Adhere to the Titanium Muffler.

If the muffler is heated when oil or grease adhere to the muffler surface, the color of this area will be different from that of the surrounding area. To remove the oil or grease, check that the surface temperature of the muffler has cooled, wash the area with a neutral detergent, wipe it with a brake cleaner-sprayed clean shop cloth and gently tap it with a dry shop cloth to dry. Be careful not to allow the brake cleaner to splatter on rubber parts, bumper, etc.

# NOTICE

Never allow polishes with compounds, because there is a possibility that the titanium muffler finisher coloring will be changed.

# DRY CARBON FIBER PARTS (if so equipped)

Because of the characteristics of the material, the dry carbon fiber parts may turn yellow due to exposure to ultraviolet rays. The surfaces of dry carbon fiber parts are coated with a special ultraviolet protection paint. To maintain the appearance of these parts, it is important to take proper care of them.

## **NOTICE**

- Do not use compound agents on clear-coated dry carbon fiber parts (such as the NISMO model's bumper, side sill protector, rear spoiler, roof, hood duct, front fender duct, etc.).
- Do not use any chemical agents (wax, coating agent, compound agent, etc.) on matte-painted dry carbon fiber parts (such as the rear diffuser, a rear spoiler that is of specifications other than NISMO. etc.).
- When dry carbon fiber parts become dirty, prepare a dilute cleaning solution by mixing one capful of mild detergent in a

bucket of water, and use that mixture to clean the parts.

#### NOTE:

The surfaces of the dry carbon fiber parts are lightly coated like a race car so that you can feel the proper texture of real carbon, which may feel rough. This is normal.

## **ENGINE START AND STOP**

This vehicle includes spark plugs that are designed for high performance. For this reason, if the engine is repeatedly started and stopped over a short time, the spark plugs may become fouled, making the engine difficult to start. To prevent diminished starting performance, avoid starting and stopping the engine repeatedly during a short period of time.

# GT-R PERFORMANCE OPTIMIZATION SERVICES

In addition to the regular maintenance recommended by NISSAN, the GT-R requires the following special inspections:

- Wheel alignment inspection and adjustment (if necessary) (including tire pressure adjustment)
- Transmission settings

These inspections are required at the following intervals:

- 1,000 miles
- 12 months
- 24 months
- 36 months

## NOTE:

- These inspections will be performed free of charge for labor at a GT-R certified NISSAN dealer only. Inspections thereafter are recommended every 12 months or 12,000 miles (whichever comes first) at the customer's expense. See the 2021 NISSAN GT-R Warranty Information Booklet for details.
- Repairs and adjustments involving parts replacement, etc. determined to be necessary as a result of these inspections are performed at the customer's expense.

- See the 2021 NISSAN GT-R Warranty Information Booklet for significant limitations, exclusions and possible voiding of your warranty resulting from failure to have these necessary inspections, repairs and/or adjustments performed.
- See the "9. Maintenance and schedules" section of this manual for a detailed explanation of the GT-R Performance Optimization Services.

# WHEEL ALIGNMENT INSPECTION AND ADJUSTMENT (if necessary) (including tire pressure adjustment)

This vehicle is equipped with a high performance suspension. The vehicle's wheel alignment should be measured and adjusted (if necessary) as necessary as the vehicle is driven and the suspension parts break-in. It is recommended that you see a GT-R certified NISSAN dealer to perform these services.

The wheel alignment can be adjusted by a GT-R certified NISSAN dealer in accordance with specifications for city driving to high performance driving.

The tires on the GT-R may have different wear rates and wear patterns in compar-

ison to conventional passenger vehicles. It is recommended you contact a GT-R certified NISSAN dealer to confirm that the alignment is within specifications.

## Preventing toe-out:

Toe-out can cause uneven tire wear or damage to areas inside the tires due to high heat. Be sure to have the wheel alignment toe-in setting checked and adjusted. It is recommended you contact a GT-R certified NISSAN dealer before any performance driving on closed circuit tracks. Obey all traffic laws when on public roads.

Toe-in specification		
Front	≤ 0.059 in (1.5 mm)	
Rear	≤ 0.079 in (2.0 mm)	

## TRANSMISSION SETTINGS

The design of the clutch and transmission requires inspection and adjustment of the clutch and shift forks. It is recommended you contact a GT-R certified NISSAN dealer at the recommended intervals. If the transmission setting is not complete, excessive loads may be applied to the transmission and power train system parts during starting and shifting, which may result in a malfunction or damage. Depending on the driving conditions,

more frequent adjustments may be necessary to help maximize vehicle performance.

### **BREAK-IN SCHEDULE**

## **NOTICE**

Follow these recommendations to obtain maximum engine performance and ensure the future reliability and economy of your new vehicle. Failure to follow these recommendations may result in shortened engine life and reduced vehicle performance.

Please observe the following types of driving until the mileage shown below has been reached.

Until 300 miles (500 km):

- Do not depress the accelerator pedal more than halfway and avoid rapid acceleration.
- Drive with the engine speed kept at less than 3,500 RPM.
- Avoid unnecessary quick steering, abrupt braking and driving on poor roads.

300 to 600 miles (500 to 1,000 km):

 Avoid rapid acceleration in a low gear (1st to 3rd gears) with the accelerator pedal fully depressed. Depress the pedal slowly.

- Avoid unnecessary quick steering and abrupt braking.
- Drive with the suspension setup switch in the COMF mode to allow more suspension stroke.

600 to 1,200 miles (1,000 to 2,000 km):

- Drive with the engine speed kept relatively high with the shift lever in the position. Shifting is recommended between 1st and 4th gears.
- Avoid unnecessary quick steering and abrupt braking.
- Drive with the suspension setup switch in the COMF mode to allow more suspension stroke.

Even though the mileage reaches over 1,200 miles (2,000 km), the clutch may take longer to properly engage if the vehicle is mainly driven in town at a low speed. NISSAN recommends breaking in the clutch at a GT-R certified NISSAN dealer. Always perform the transmission setting after breaking in the clutch. If the transmission setting is not complete, excessive loads may be applied to the transmission and power train system parts during starting and shifting, which may result in a malfunction or damage.

#### WHEEL ALIGNMENT

Do not adjust the wheel alignment until the mileage reaches 1,000 miles (1,600 km). Until then, the suspension may not engage enough and the height may be higher.

However, make sure to adjust the alignment after 1,000 miles (1,600 km).

The wheel alignment can be adjusted by a GT-R certified NISSAN dealer in accordance with specifications for city driving to high performance driving.

The tires on the GT-R may have different wear rates and wear patterns in comparison to conventional passenger vehicles. It is recommended you contact a GT-R certified NISSAN dealer to confirm that the alignment is within specifications.

# PRECAUTIONS BEFORE DRIVING

# VEHICLE DYNAMIC CONTROL (VDC) OFF MODE

Always make sure the VDC is ON before driving the vehicle by checking that the VDC OFF indicator lights on the meter and the VDC set-up switch are not illuminated. The GT-R is a high performance vehicle and the VDC must be on/activated to provide proper powertrain operation and intended drivability.

# **WARNING**

- The VDC OFF mode should ONLY be used briefly to help free the vehicle if stuck in snow or mud by temporarily stopping operation of the VDC to maintain wheel torque.
- Driving the GT-R with the VDC off may lead to handling issues related to steering maneuvers, acceleration, or deceleration. Moreover, driving with the VDC off can result in an inoperative vehicle by causing serious damage to the powertrain, including damage to the Transaxle Assembly including Transfer, Clutch, Gears, Transaxle case and all of

its components and other drivetrain component(s) by overheating or excessive force.

 Damage to the powertrain or any drivetrain component(s) that occurs when there is a record in the Vehicle Status Data Recorder (VSDR) that the vehicle was driven with VDC off during the period when the damage was incurred is excluded from warranty coverage.

See your 2021 Warranty Information Booklet for important related information and warranty coverage exclusions. See also section 2 ( \*\*Transmission warning light" page 2-33) and section 5 ( \*\*Tvehicle Dynamic Control (VDC) system" page 5-54) of this Owner's Manual, "Transmission Clutch Temperature High" and "Vehicle Dynamic Control (VDC) System" for important additional related information

# **SUMMER TIRES**


The GT-R summer tires are made from a specially formulated rubber to maximize the vehicle's performance capabilities. Performance of summer tires is substantially reduced when temperatures are less than 32°F (0°C) so you must drive carefully. NISSAN recommends the use of winter or all-season tires on all four wheels if you plan to operate your vehicle in snowy or icy conditions when temperatures are less than 32°F (0°C).

# **WARNING**

Never use summer tires when the temperature is below -4°F (-20°C) to prevent permanent tread deformation which may cause tire damage or tire failure. This may cause a loss of vehicle control which can result in serious personal injury or death.

## **ALL-SEASON TIRES**

Do not exceed the speed rating of the tire that is installed on the vehicle.



## **AVOIDING BODY DAMAGE**

The GT-R bumper, fascia, side sills and undercarriage are close to the ground. Drive slowly on rough or uneven roads to avoid damaging these parts. Pay careful attention to wheel blocks and curbs. If the front bumper contacts a wheel block, curb, etc., the bumper and underlying parts may be damaged or cracked. Be careful not to damage the front spoiler that is installed below the engine room.

#### **FUEL**

NISSAN recommends using fuels that contain no alcohol. However, fuels containing up to 10% alcohol may be used, if necessary. Do not use E-15 or E-85 in your vehicle. ( \*\*Truel information\*\* page 10-4)

# **NOTICE**

To avoid serious engine damage due to increased cylinder temperatures, do not use fuels that contain more alcohol than indicated in "Gasoline containing oxygenates" page 10-5. Also, do not use fuel additives, fuel stabilizers or fuel deicers that contain alcohol.

# **BODY REPAIR**

The body of the GT-R has been manufactured on special fixtures utilizing a hybrid structure with aluminum die cast parts for the frame work. Special skills, information and equipment are required to correctly repair the body. It is recommended you contact a GT-R certified NISSAN dealer if the vehicle is damaged, such as in a collision, and they will recommend an appropriate body shop.

Only certified body shops using CELETTE® advanced collision repair equipment are approved by NISSAN for repairing structural body damage. It is recommended you contact a GT-R certified NISSAN dealer or NISSAN Consumer Affairs for a referral or list of certified body shops.

# **DRIVING AFTER REPLACING TIRES**

Avoid the driving conditions listed under "Additional maintenance items" in this section for 48 hours after tires are installed on the wheels ( [32] "Additional maintenance items" page GTR-13). The tire may slip on the wheel if the vehicle is driven in these conditions before 48 hours have passed. If the tire slips on the wheel, the wheel/tire assembly will be out of balance and will require rebalancing.

# **ADDITIONAL MAINTENANCE ITEMS**

The information and specifications in this section apply only when engaging in performance driving.

The following information applies only if you engage in performance driving such as driving your GT-R for extended periods under the following conditions.

- Higher-RPM (approaching redline) operation
- Frequent high pedal force braking from moderate and higher speeds
- Frequent throttle activation
- Fast revving throughout the RPM range

In such cases, the following additional maintenance guidelines apply.

However, you should also carefully read your 2021 NISSAN GT-R Warranty Information Booklet for important information concerning warranty coverage, limitations and exclusions.

We recommend that all GT-R maintenance be performed at a GT-R certified NISSAN dealer. NISSAN will only pay for GT-R Performance Optimization Services performed at a GT-R certified NISSAN dealer

# PRECAUTIONS ON PERFORMANCE DRIVING

The information and specifications in this section apply only when engaging in performance driving.

# Checking the temperature of the coolant and oils on the touch screen display

When the temperatures of the engine coolant and oil, and the oil pressure exceed the normal range, the color of the multi function meter on the touch screen display changes to red to warn the driver. When engaging in high performance driving, switch the display to the multi function meter to display the temperature of the engine coolant and oil, and the oil pressure. When the color of the meter display changes to red, perform cool down driving. When the values of the temperature and pressure return to the normal range, the color of the multi function meter will turn back to white.

Warning temperature:

 Engine coolant temperature is 230°F (110°C) or higher:

If the engine coolant temperature increases above  $230^{\circ}F$  ( $110^{\circ}C$ ), the

color of the multi function meter on the touch screen display changes to red to warn of a possible overheat condition and engine output is reduced.

 Engine oil temperature is 275°F (135°C) or higher:

If the engine oil temperature is higher than 275°F (135°C), the meter display changes to red, maximum engine speed is automatically limited to 4,000 rpm, and the transmission automatically changes from the position to the position.

 Transmission oil temperature is 284°F (140°C) or higher:

If the transmission oil temperature increases to over 284°F (140°C), the color of the meter display changes to red. However, the vehicle can continue to be driven until the temperature reaches 295°F (146°C). If the oil temperature exceeds 284°F (140°C) while driving (the color of the meter displayed in red), change both the transmission oil and the differential oil after driving because these fluids have deteriorated because of the heat.

## Cool down

The information and specifications in this section apply only when engaging in performance driving.

Cool down the vehicle to help extend the life of the vehicle if coolant temperatures are extremely high. Drive the vehicle at 37 to 50 MPH (60 to 80 km/h), in 5th or 6th gear for 2 to 3 miles (3 to 5 km) and then stop the engine.

# **Refueling precautions**

# **WARNING**

Do not attempt to top off the fuel tank after the fuel pump nozzle shuts off automatically. Continued refueling may cause fuel overflow, resulting in fuel spray and possibly a fire. The fuel tank is full at the first automatic shutoff.

To maximize vehicle performance, the fuel tank is located as low as possible to lower the vehicle center of gravity. The tank is also divided into two parts. This fuel tank design causes higher pressures inside the tank than other vehicles so fuel spillage is possible by trying to top off the

fuel tank after automatic shutoff.

The fuel tank pressure is higher when the vehicle is hot, especially if the tank is more than half full. If the cap is opened when the vehicle is hot, it may cause fuel spray and there may be a hissing noise. Open the cap slowly, releasing the pressure from the tank gradually. Also, if the vehicle is refueled when the vehicle is hot, the fuel pump may automatically shut off before the tank is full. This does not indicate that there is a malfunction. Refuel slowly or refuel after the vehicle has cooled.


# INSPECTION AND ADJUSTMENTS BEFORE DRIVING

The information and specifications in this section apply only when engaging in performance driving.


## **Fluids**

- Check the engine, transmission, differential and under vehicle surfaces for oil and coolant leaks.
- Check the fluid levels and adjust as necessary using the specified fluid as described under the conditions listed in this section. ( \*\* "Recommended fluids and maintenance interval" page

GTR-20) If you do not drive under the conditions listed, refer to the "9. Maintenance and schedules" section of this manual.



your engine under normal operating conditions, and oil consumption by itself does not necessarily indicate any malfunction. If your rate of oil consumption increases suddenly or without explanation, NISSAN recommends that you have your vehicle inspected by a GT-R certified NISSAN dealer.



NISSAN recommends to adjust the engine oil level ① to be 0.39 in (10 mm) (1/8 gal (0.5 liters)) ② below the H mark on the engine oil dipstick. (③ range is 1.18 in (30 mm).) Before checking the oil level, run the engine until it reaches operating temperature and wait at least 5 minutes after turning off the engine. Make sure the oil level always remains above the L mark.

When the vehicle is delivered, the engine oil is set to "H- 0.39 in (10 mm)" for optimal high performance driving.

Some amount of oil is consumed by

 Adjust the power steering fluid level to the R mark ⑤ on the power steering dipstick when the fluid temperature is hot or ⑥ when the fluid temperature is cold.

Fluid temperature:

Hot: 122 to 176°F (50 to 80°C): between 1 and 5

Cold: 32 to  $86^{\circ}$ F (0 to  $30^{\circ}$ C): between 3 and 6

# Coolant level and mixture ratio

The information and specifications in this section apply only when engaging in performance driving. Check the coolant level in the pressurized coolant reservoir. Adjust the level so that the fluid is between the MAX and MIN markings. For the coolant, use genuine NISSAN Long Life coolant or equivalent. (On delivery of new vehicle, the reservoir is filled to the MIN level. Be sure to replenish approximately 3/8 US quart (0.3 to 0.4 liter) of coolant.)

## **NOTICE**

Do not overfill the coolant. This may increase the pressure in the cooling system and cause coolant leaks.

To maximize vehicle performance, the coolant mixture ratio should be a combination of 30% coolant antifreeze and 70% demineralized or distilled water for maximum cooling system performance reaardless of ambient temperatures.

If ambient temperatures are anticipated below 5°F (-15°C), make sure a proper mixture ratio of 50% antifreeze and 50% demineralized or distilled water mix is used

# **Engine and powertrain**

The information and specifications in this section apply only when engaging

## in performance driving.

- Check the engine, transmission, differential and under the vehicle for oil and coolant leaks.
- Inspect the areas surrounding of the catalytic converter for heat deterioration.
- Always perform the transmission setting. After that, adjust the clutch clearance so that the clearance is less. than the clearance used for daily driving. Your GT-R certified NISSAN dealer has the necessary information and equipment to set the clutch clearance to the correct specification. The clearance used for daily driving increases clutch heat generated during Performance Driving. This leads to an increase in temperature of the transmission oil. In addition, a more direct shifting feel can be obtained by reducing the clutch clearance for Performance Driving. The clutch clearance should be reset to the daily driving specification after Performance Driving. It is recommended vou see a GT-R certified NISSAN dealer for information

# **NOTICE**

Failure to have the clutch properly adjusted before performance driving may cause the transmission oil temperature to increase which may cause transmission damage.

- Inspect and confirm the clearance between the exhaust finisher and rear bumper is more than 0.24 in (6 mm) (up/down) and more than 0.20 in (5 mm) (left/right).
- Inspect the dust boot of the drive shaft universal joint for cracks or damage.

# Suspension and wheel alignment The information and specifications in this section apply only when engaging in performance driving.

- Check the steering and suspension system and other links for loose and/ or damaged parts.
- Measure and adjust the wheel alignment. ( ) "Wheel alignment" page GTR-10) It is recommended you contact a GT-R certified NISSAN dealer to adjust the wheel alignment to the recommended setting for high perfor-

GTR-16 GT-R Overview

mance driving.

# Preventing toe-out:

Toe-out can cause uneven tire wear or damage to areas inside the tires due to high heat. Be sure to have the wheel alignment toe-in setting checked and adjusted. It is recommended you contact a GT-R certified NISSAN dealer before any performance driving on closed circuit tracks. Obey all traffic laws when on public roads.


Toe-in specification		
Front	≤ 0.059 in (1.5 mm)	
Rear	≤ 0.079 in (2.0 mm)	

## Wheels and tires

The information and specifications in this section apply only when engaging in performance driving.

- · Check tire wear and cracking.
- Inspect the tire side wall for damage.
- Check the tire pressure and adjust the pressure as necessary when the tires are cold. ( \*\*TWheels and tires" page 8-29)

The tire pressure changes depending on the outside temperature or altitude. Check the tire pressure regularly and when the climate conditions change. \* The following chart indicates how the tire pressure will decrease as outside air temperature decreases.




# **WARNING**

Keep your tires inflated to the correct tire pressure. Driving with low tire pressure can damage some powertrain systems and affect the operation of the ABS and VDC systems. Low Tire pressure may also cause tire failure and result in serious personal injury or death.

 Make sure the tire valve stem cap is installed and that the valve stem is tight. When installing the cap, make sure to tighten the cap by hand. If a tool is used to tighten the cap, the cap may be damaged.

- Make sure the wheel nuts are tight.
   ( pg "Wheels and tires" page 8-29)
- Make sure the drive shaft nuts are tight.
- Make sure to replace the grommet seal, the valve core and the valve cap of the Tire Pressure Monitoring System (TPMS) sensor attached to the wheel every 3 years for performance driving use. Replace them every 5 years even when not engaging in performance driving. A dirty grommet seal will cause the air leak from the tire
- Make sure that the nuts and valves that are attached to the TPMS sensor are tight and there is no nitrogen leak.
- Use only a NISSAN genuine valve cap or equivalent.
- Check wheel hub run out and that the wheel rotates smoothly without any friction. Check these with the tires removed whenever an inspection is performed with the vehicle jacked up.
- Secure road wheel balance weights with aluminum tape.
- · Check that the wheel nuts are not

stripped.



- Make sure the tire has not slipped on the wheel causing the assembly to be out of balance. The reference marks on the tire and wheel should be aligned. If the reference marks are not aligned, the tire has slipped on the wheel. Have the wheels/tires rebalanced. Make sure the old reference marks are erased and new reference marks are applied to the wheel and tire. When installing new tires on the wheels, make sure new reference marks are applied to the wheels and tires
- Avoid the driving conditions listed under "Additional maintenance items"

in this section for 48 hours after tires are installed on the wheels. The tire may slip on the wheel if the vehicle is driven in these conditions before 48 hours have passed. If the tire slips on the wheel, the wheel/tire assembly will be out of balance and will require rebalancing.

# **Brakes**

The information and specifications in this section apply only when engaging in performance driving.

- Check for the heat deterioration of the brakes and parts around the brakes.
- It is recommended that you remove air from the brake system after any of the following:
  - When engaging in high performance driving for the first time after purchasing a new vehicle.
  - After replacing the brake fluid.
  - When engaging in high performance driving for a sustained period of time. It is recommended that bleeding the brake be performed when the brake calipers are hot (about 212°F (100°C)).

# Brake pad break-in procedure:

NISSAN recommends that a special brake pad break-in procedure be performed before engaging in performance driving. It is recommended you contact a GT-R certified NISSAN dealer for details.

# INSPECTION AND ADJUSTMENTS AFTER DRIVING

The information and specifications in this section apply only when engaging in performance driving.

## NOTICE

At the completion of performance driving, all fluid and other adjustments should be returned to the normal fluid specifications as shown in the "8. Do-it-yourself" section of this manual.

# **Fluids**

The information and specifications in this section apply only when engaging in performance driving.

Check the engine, transmission, differential and under the vehicle for oil and coolant leaks.

- Check the fluid levels and adjust as necessary using the specified fluid as described under the conditions listed in this section. ( Recommended fluids and maintenance interval" page GTR-20) If you do not drive under the conditions listed, refer to the "9. Maintenance and schedules" section of this manual.
- When changing fluids, be sure to use the specified fluids as described in this Owner's manual. ( Capacities and recommended fluids/lubricants" page 10-2)

# Recommended fluids and maintenance interval

The information and specifications in this section apply only when engaging in performance driving.

ITEMS	Engine Oil		
GT-R SPECIFIED FLUIDS	Mobil 1 (OW-40)*1 or equivalent		
	When the oil temperature stays below 230°F (110°C) while driving	Change engine oil and engine oil filter at the same interval as Schedule 1 and 2 in the "9. Maintenance and schedules" section of this manual.	
MAINTENANCE INTERVAL	When the oil temperature reaches between 230°F (110°C) and 266°F (130°C) while driving	Change engine oil and engine oil filter every 3,000 miles (5,000 km).	
	When the oil temperature exceeds 266°F (130°C) while driving	Change engine oil and engine oil filter immediately after stopping.	

<sup>\*1:</sup> Mobil 1 (0W-40) (100% synthetic) is the factory fill oil. The VR38 engine with its plasma-sprayed bores was developed using this oil. NISSAN cannot ensure proper engine operation and durability if other 0W-40 non-equivalent synthetic oil is used. If Mobil 1 (0W-40) or equivalent is not available, Mobil 1 (10W-40) (100% synthetic) or equivalent may be used; however, some performance loss may be noticed.

ITEMS	Transmission Oil		
GT-R SPECIFIED FLUIDS	Genuine NISSAN Transmission Oil R35 Special or equivalent		
	When the oil temperature stays below 248°F (120°C) while driving	Change transmission oil at the same interval as Schedule 1 and 2 in the "9. Maintenance and schedules" section of this manual.	
MAINTENANCE INTERVAL	When the oil temperature reaches between 248°F (120°C) and 284°F (140°C) while driving	Change transmission oil every 3,000 miles (5,000 km).	
	When the oil temperature exceeds 284°F (140°C) while driving	Change both transmission oil and differential oil immediately after stopping. Differential oil temperature usually increases concurrently.	

ITEMS	Differential Oil (front and rear)		
GT-R SPECIFIED FLUIDS	Differential Oil R35 COMPETITION type 2189E*2 or equivalent		
	When the oil temperature stays below 248°F (120°C) while driving	Change differential oil at the same interval as Schedule 1 and 2 in the "9. Maintenance and schedules" section of this manual.	
MAINTENANCE INTERVAL	When the oil temperature reaches between 248°F (120°C) and 284°F (140°C) while driving	Change differential oil every 3,000 miles (5,000 km).	
	When the oil temperature exceeds 284°F (140°C) while driving	Change both transmission oil and differential oil immediately after stopping. Differential oil temperature usually increases concurrently as the transmission oil temperature.	

<sup>\*2:</sup> The differential oil temperature cannot be displayed on the multi function meter on the touch screen display. The differential oil temperature can be checked with the transmission oil temperature since both usually increases or decrease concurrently.

ITEMS	Brake Fluid
GT-R SPECIFIED FLUIDS	Genuine NISSAN Brake Fluid R35 Special II*3 or equivalent
MAINTENANCE INTERVAL	Change brake fluid every 3,000 miles (5,000 km).

\*3: Genuine NISSAN Brake Fluid R35 Special II is the factory fill brake fluid. The Vehicle Dynamic Control (VDC) unit and other related parts were specially designed for this brake fluid and NISSAN cannot ensure the best performance and proper operation of the vehicle if other non-equivalent brake fluid is used.

# Suspension and wheel alignment

- Check the steering and suspension system and other links for loose and/ or damaged parts.
- Measure and adjust the wheel alignment. It is recommended you contact
  a GT-R certified NISSAN dealer to
  adjust the wheel alignment to the
  recommended setting for normal driving.

## Wheels and tires

- Check tire wear and cracking.
- Inspect the tire side wall for damage.
- Check the tire pressure and adjust the pressure as necessary when the tires are cold. ( ) "Wheels and tires" page GTR-17) If you do not drive under the conditions listed in this section, see
   "Wheels and tires" page 8-29.
- Check that the wheel nuts are not stripped. Check if there is no deformation on the contact surface of the wheel nuts.
- Make sure the wheel nuts are tight.
   ( property "Wheels and tires" page 8-29)
- Make sure the drive shaft nuts are tight.

- Check wheel hub run out and that the wheel rotates smoothly without any friction. Check these with the tires removed whenever an inspection is performed with the vehicle jacked up.
- Make sure that the TPMS sensor installation nuts and the sensor valve are tight and there is no nitrogen leak.


# **Brakes**

- Check for the heat deterioration of the brakes and parts around the brakes.
- Check the condition of the brake pads and disc rotors and replace them as necessary.

 Apply MOLYKOTE® 7439 or equivalent to the top and bottom of the front brake pads. (See next page for illustration).

# Front disc brake pad:

BRAKE PAD: Exploded View (GT-R certified NISSAN dealer)



Apply MOLYKOTE 7439 or equivalent to the match face (a) of the brake pad (1)

Molykote is a registered trademark of Dow Coming Corporation.

- sensor)

4. Cross spring

Apply MOLYKOTE 7439 or equivalent

# **Engine and powertrain**

- Check the engine, transmission, differential and under the vehicle for oil and coolant leaks.
- Inspect the area surrounding the catalytic converter for heat deterioration.
- Inspect and confirm the clearance between the exhaust finisher and rear bumper is more than 0.24 in (6 mm) (up/down) and more than 0.20 in (5 mm) (left/right).
- The clutch clearance and shift fork position may need to be adjusted.
- Inspect the dust boot of the drive shaft universal joint for cracks or damage.
- Check that there is no abnormal noise, vibrations or warning lights illuminated when making tight turns at slow speed (for tight corner braking phenomenon).

# **GT-R SPECIFIC VEHICLE CHARACTERISTICS**

# **REFUELING PRECAUTIONS**

# **WARNING**

Do not attempt to top off the fuel tank after the fuel pump nozzle shuts off automatically. Continued refueling may cause fuel overflow, resulting in fuel spray and possibly a fire. The fuel tank is full at the first automatic shutoff.

To maximize vehicle performance, the fuel tank is located as low as possible to lower the vehicle center of gravity. The tank is also divided into two parts. This fuel tank design causes higher pressures inside the tank than other vehicles so fuel spillage is possible by trying to top off the fuel tank after automatic shutoff.

The fuel tank pressure is higher when the vehicle is hot, especially if the tank is more than half full. If the cap is opened when the vehicle is hot, it may cause fuel spray and there may be a hissing noise. Open the cap slowly, releasing the pressure from the tank gradually. Also, if the vehicle is refueled when the vehicle is hot, the fuel pump may automatically shut off before the tank is full. This does not indicate that there is a malfunction

Refuel slowly or refuel after the vehicle has cooled.

## **GASOLINE SMELL**

The fuel temperature is higher when the vehicle is hot. This may cause a gasoline smell from the vehicle. This does not indicate that there is a malfunction. The smell will go away when the fuel temperature has cooled.

# OUTSIDE TEMPERATURE DISPLAY INDICATES HIGHER TEMPERATURE

Heat from the engine compartment, radiator and intercoolers can affect the outside temperature display. The outside temperature display may indicate a higher than actual temperature while driving or stopped. This is normal.

#### **IDLE SPEED IS NOT STEADY**

The idle speed may not be steady when the engine compartment is extremely hot. This is normal. The engine speed will be steady when the engine cools down. In this case, the Malfunction Indicator Light (MIL) may come on. After a few driving trips, the MIL should turn off. If the light remains on after a few driving trips, it is recommended you have the vehicle inspected by a GT-R certified NISSAN dealer.

#### **ENGINE SPEED IS RESTRICTED**

To help protect the engine, the maximum engine speed is automatically controlled in the following conditions:

- Revving the engine with the shift lever in the or no position: The maximum engine speed is 4,300 RPM
- Revving the engine when the engine oil is at a low (below 32°F (0°C)) or extremely high (over 275°F (135°C)) temperature: The maximum engine speed is 4,000 RPM (The M position will automatically change to the A position.)

## **ENGINE OUTPUT**

# High altitude

To protect the engine, engine output is controlled so that it does not increase at altitude of approximately 3,281 ft (1,000 m) or higher.

# Engine output according to the coolant temperature

The engine output is controlled at a low level when the engine coolant temperature is lower than approximately 158°F (70°C) or higher than 230°F (110°C). This is not a malfunction.

If the temperature is lower than approximately 158°F (70°C), drive the vehicle until it reaches normal operating temperature. If the temperature is higher than 230°F (110°C), perform cool-down driving procedure. ( [25] "Cool down" page GTR-14) When the temperature of the engine coolant is between 158°F (70°C) and 230°F (110°C), the engine output returns to normal.

## **UNEVEN WEAR OF TIRES**

The GT-R is equipped with high performance, low profile, run-flat tires that are optimized for performance and handling. The life of these tires will be less than those of tires installed on a typical vehicle, and you are likely to experience uneven tire wear and tire noise regardless of the type of tire used.

# NOISES ARE HEARD WHILE DRIV-ING

 The GT-R brake pads use material that provides a high amount of braking power even in high temperatures. This material can cause an intermittent screeching noise just before the vehicle comes to a stop when the brakes are gently applied. The noise decreases as the brake pads wear. However, the additional brake pad breakin or replacing the cross spring may decrease the noise. It is recommended you contact a GT-R certified NISSAN dealer.

- A screeching noise may be heard when the brake pedal is depressed:
  - When driving the vehicle for the first time in the morning,
  - After leaving the vehicle parked for extended periods of time, or
  - When the vehicle is damp following rain showers or washing the vehicle.

These sounds are normal. The noise is caused when the brake pads absorb moisture, and the noise stops after the brake is applied several times.

- A screeching noise may also be heard when the brake pedal is depressed:
  - When repeatedly applying gentle braking, especially on a curve at a low speed, or
  - When the brake rotors have circular scores with the brake temperature high.

For models without NCCB (NISSAN Carbon Ceramic Brake) package:

# **WARNING**

Follow the instructions below when parking the vehicle to help prevent the brake rotor and brake pads from rusting together. Failure to follow the instructions could cause the rotor and pads to rust together. If the rotor and pads rust together. If the rotor and pads rust together, there may be a popping noise and some vibration when the vehicle is driven, a wheel may not roll correctly, or the brake pads could be damaged. If the pads are damaged, this may reduce the effectiveness of the brake system which could cause a collision, serious personal injury or death.

 The GT-R uses brake pad materials that have high metallic content. The brake pad material helps maintain braking performance in a wide range of weather and driving conditions.
 For the first 3,000-6,000 miles (5,000-10,000 km) of the vehicle's service life, and for the first 3,000-6,000 miles (5,000-10,000 km) after a brake replacement, the brake pad to brake rotor clearance is very small. When parking, apply the parking brake and move the shift lever to the position. Idle the engine for more than 20 seconds without depressing the brake pedal. This allows the brake pads to move away from the rotor so the pad does not contact the rotor.

Additionally, the brakes must be dry before parking the vehicle after driving on wet roads or after washing the vehicle. If the roads are wet, lightly apply the brakes for a short distance before parking the vehicle to dry the brakes. After washing the vehicle, dry the brakes by driving on a dry road for a few miles and apply the brakes normally based on traffic and road conditions.

The metallic brake pads and brake disc rotor may rust together when the brakes are not applied:

- If the vehicle is not idled for 20 seconds without the brakes applied, or if the brakes are applied when the vehicle is shut off, the rotor and pads can rust together, even when the brake pads are dry.
- If the brakes are wet when the vehicle is parked and the parking brake is applied for a long time.

 The hill start assist system can apply the brakes even if the brake pedal is not depressed. The brake pads and rotors can rust together if the parking procedure previously described is not followed.

It is recommended you contact a GT-R certified NISSAN dealer if the brake pads and brake rotor have rusted together.

# **NOTICE**

To help reduce the possibility of the rotors and brake pads rusting:

Have the brake pads and/or rotors quenched when the brake pads are replaced. For detailed information about quenching, contact a GT-R certified NISSAN dealer.

After quenching the brake pads and/ or rotors, apply a brake of 0.5G to stop the vehicle 6-7 times at least once a week in a safe location. Gforce can be checked on the multi function meter on the touch screen display. Refer to the separate Multi Function Display Owner's Manual.


- To maintain steady braking performance in both extremely high and low temperatures, the gap between the brake pad and caliper is larger than normal and large-size brake pads are used. When driving over a bump, a light rattling sound may be heard from the brake pad. This does not indicate that there is a malfunction.
- When the brake disc rotor undergoes thermal expansion, a ticking noise may be heard from the engaging portion of the wheel and the brake disc rotor. This does not indicate that there is a malfunction. The noise will reduce when the temperature decreases.
- In addition to noise resulting from uneven tire wear discussed in the previous section, the GT-R tires are more rigid than a typical passenger car tire and are made from a specially formulated rubber to maximize the vehicle's performance capabilities. These characteristics cause the GT-R tires to have more road noise than a typical passenger car tire. This road noise is normal
- Due to the performance capabilities and requirements of the GT-R, the

sequential 6-speed dual clutch transmission is unlike a typical automatic transmission. You will likely hear mechanical sounds from the transmission, particularly at slow speeds and at idle. This condition is normal.

## **BRAKE SYSTEM INFORMATION**

# Cracks on brake pad

The friction material of the GT-R disc brake pad is bonded to the pad backing plate more strongly than conventional brake pads to withstand the high brake temperatures. The friction material and backing plate expand due to heat at different rates. Some cracks may be on the surface of the friction material due to the differences in expansion rates and the strong bond between the friction material and backing plate. The cracks do not indicate the brake pads need to be replaced. However, depending on the condition of the cracks, the pads may need to be replaced. It is recommended you contact a GT-R certified NISSAN dealer.



# Cracks on the disc rotors (models without NCCB (NISSAN Carbon Ceramic Brake) package)

When the brake is repeatedly applied at high loads during the cold season, small cracks of approximately 0.12 in (3 mm) long may appear around the cross drilled holes (a). This is due to the temperature differential that occurs because the surfaces of the disc rotors become hot while the inside of the rotor is still cold. However, this poses no problem in terms of brake performance, and does not indicate a malfunction. The brakes do not need to

be replaced.

However, if the cracks extend to 0.16 in (4 mm) or longer after repeated application of the brakes at high loads during high performance driving, or through the continued use of the brakes, the disc rotors must be replaced.

#### **Brake dust**

This vehicle is equipped with high performance brakes, and the characteristics of the brake pad material may cause more brake dust than other vehicles. NISSAN recommends a wheel coating that helps prevent the brake dust from sticking to the wheels. It is recommended you contact a GT-R certified NISSAN dealer for more details.

## Sound heard from brake system (models with NCCB (NISSAN Carbon Ceramic Brake) package) Rattles from brake pads and creaks during braking

The high performance brake system of vehicles equipped with the NCCB (NISSAN Carbon Ceramic Brake) has more clearance between its brake pad and brake caliper than regular vehicles, and it uses a large brake pad to ensure stable braking

performance under a wide range of driving conditions such as extremely high temperature areas or low temperature areas like snow-covered roads. Accordingly, you may hear light rattles from the brake pad area when driving over a step, which is not a malfunction. In addition, you will hear creaks because of the characteristics of the material for the disc rotor. These creaks reduce with time and wear.

## Never park your vehicle for a long time with the brake system wet.

The materials used for the brake disc rotor and brake pads for specified NCCB (NISSAN Carbon Ceramic Brake) are different from those used for the standard brake system in GT-R. The rotor and pads will be protected from adhesion caused by rusting. However, never park your vehicle for a long time with the brake system wet. This helps maintain the brake disc rotor and brake pads for a long time and prevents an influence on the material composition of the carbon ceramic rotor and deterioration in the joint of brake disc rotor's full floating structure. Especially during winter, be sure to park your vehicle with the brake disc rotor and pads dry to prevent them from being frozen and damaged in below freezing temperature conditions. The carbon ceramic brake for

GT-R includes air bubbles in the rotor and pads. Note that leaving them in the wet condition tends to cause adhesion due to freezing.

- A screeching noise may be heard when the brake pedal is depressed:
  - When driving the vehicle for the first time in the morning,
  - After leaving the vehicle parked for extended periods of time, or
  - When the vehicle is damp following rain showers or washing the vehicle.

These sounds are normal. The noise is caused when the brake pads absorb moisture, and the noise stops after the brake is applied several times.

- A screeching noise may also be heard when the brake pedal is depressed:
  - When repeatedly applying gentle braking, especially on a curve at a low speed, or
  - When the brake rotors have circular scores with the brake temperature high.
- The NCCB (NISSAN Carbon Ceramic Brake) causes more screeching noise in cold weather conditions than in normal weather conditions.

# CHANGE OF SURFACE COLOR OF TITANIUM MUFFLER (if so equipped)

Genuine titanium mufflers are made of titanium alloy. The surface color will change depending on the driving conditions, which is not unusual. Prior to shipping from factory, all vehicles receive balance aligning for engine, transmission, and clutch, as well as quench driving of brake pads and rotors. As a result, the muffler surface color may differ depending on the vehicle.

## THE COLOR TONE OF THE TITA-NIUM MUFFLER FINISHER MIGHT BE DIFFERENT FROM OTHERS (if so equipped)

The titanium muffler finisher color tone is hand-made, so it may differ depending on the finisher.

## SOUND HEARD AROUND TITANIUM MUFFLER (if so equipped)

When stopping the engine (rapid cooling), you may hear a metal-rubbing sound or unusual ticking sound because of the differential thermal expansion between the inner and outer pipes of the muffler. This is not a malfunction. The sound will

decrease when the temperature lowers.

## EXHAUST GAS IS NOT EMITTED FROM LEFT EXHAUST PIPE DURING IDLING/WHEN ENGINE SPEED IS LOW (if so equipped)

The titanium muffler for vehicles with the exhaust sound control system is equipped with a control valve installed on the left-side exhaust pipe. When the exhaust sound control switch is ON or the engine speed is low, exhaust sound silencing is enhanced by closing the valve. Exhaust gas is not emitted from the left-side exhaust pipe when the control valve is closed. This is not a malfunction. ( This is not a malfunction. ( Exhaust sound control system" page 5-59)

## DRY CARBON FIBER PARTS (if so equipped)

## Roughness or uneven surfaces of dry carbon fiber parts and fiber twists

The surfaces of the dry carbon fiber parts are lightly coated like a race car so that you can feel the proper texture of real carbon, which may feel rough. This is normal.

### **DUAL CLUTCH TRANSMISSION**

The GT-R dual clutch transmission is a newly-developed system that uses an electronically controlled multiple-disc wet clutch attached to the highly efficient manual transmission. This transmission has two driving modes.

- A position (Automatic gearshift): allows automatic shifting of the manual transmission.
- M position (Manual gearshift): allows quick shifting of the manual transmission.

#### NOTE:

When starting or driving on a steep uphill grade, shift to the \( \mathbb{M} \) position and operate the paddle shifter to shift down to 1st gear similar to a manual transmission vehicle.

The GT-R dual clutch transmission was developed specifically to maximize vehicle performance and driving enjoyment. The GT-R transmission components were designed using different engineering standards than typical passenger car transmissions. Because of this, the GT-R has different operating characteristics, and various rattle noises may be heard during some driving conditions because of the following items:

- Gear clearances
- Ultralight flywheel
- Dry sump lubrication

These noises do not indicate that there is a malfunction.

## TRANSMISSION OPERATION CHARACTERISTICS

Mechanism	Operation characteristics
Base Manual transmission	<ul> <li>The GT-R transmission design is different from transmissions used in conventional passenger cars. The GT-R uses a transmission gear design, light flywheel and a dry sump lubrication system to provide maximum vehicle performance. Because the GT-R Transmission design is different, noises may be louder. When the transmission temperature is high, rattling, shaking and jarring noises may be heard.</li> <li>Clattering noises may be heard while shifting.</li> <li>Appropriate gaps are provided between gears to achieve smooth gear rotation and steady tooth surface lubrication under the high-load driving condition. However, this causes a rattling noise.</li> <li>If the shift lever is moved from  to  → Dosition, or  → Dosition before the vehicle stops, you may not be able to shift gear or it may take longer to shift gear. Make sure to depress the brake pedal and check that the vehicle has stopped before shifting.</li> </ul>
Multiple-disc wet clutch	<ul> <li>When stopping the vehicle with the shift lever in the  or  A→M position, be sure to firmly depress the brake pedal. The vehicle may slowly move if the brake pedal is not depressed.</li> <li>Avoid depressing the brake and accelerator pedals at the same time. Depressing the brake and accelerator pedals at the same time could cause the clutch to overheat and accelerate deterioration.</li> <li>When the vehicle is stopped on a hill, do not hold the vehicle in place by depressing the accelerator pedal. Doing so may cause the clutch to overheat and result in transmission damage. Use the brakes to prevent the vehicle from moving.</li> </ul>
Electronic oil pressure control	<ul> <li>The following conditions are caused due to changes in fluid viscosity as a result of temperature changes.</li> <li>When the transmission oil is extremely cold or extremely hot, the transmission may feel like it is slipping during shifts or there may be hard shifts. This is normal. Transmission shifting should return to normal when the transmission oil returns to normal operating temperatures.</li> <li>When the transmission oil temperature is extremely cold, the time required to run a system check may increase. During the system check, the shift lever must stay in the position. Move the shift lever after turning off the system check display. Also, it is normal to hear clicking noises during the transmission systems check.</li> </ul>
Changing modes	<ul> <li>The higher shift speeds in the  position may result in shift shock and jerkiness when starting or shifting.</li> <li>The quickest shifting in the R mode with the transmission in the  position is available when the engine speed is high. However, the transmission may shift more slowly when the engine speed is low.</li> </ul>
Mechanical Limited Slip Differential (LSD)	If the vehicle accelerates from a stop with the steering wheel turned half a turn in cold temperatures, the inner wheel tire may slip and some noise or vibration may be heard. This phenomenon occurs because the viscosity of the differential oil becomes thicker and the Limited Slip Differential (LSD) operates with increasing load. When the steering wheel is returned to the straight ahead position or the differential oil warms up, the noise and vibration decrease.

Mechanism	Operation characteristics
Electronically-con- trolled All-Wheel Drive (AWD)	If the vehicle accelerates from a stop with the steering wheel turned half a turn in cold temperatures, it may be hard to move the vehicle when the accelerator pedal is depressed. This phenomenon is unique to AWD vehicles and is caused by the speed difference between the front and rear wheel. This is not a malfunction. Resolve the phenomenon by returning the steering wheel to the straight ahead position. This phenomenon can be reduced if certain conditions are met. ( **Tight corner braking phenomenon" page 5-44)
Ultralight flywheel	<ul> <li>An ultralight flywheel is provided to achieve rapid engine response to the accelerator pedal operation. The engine rotation fluctuations become larger than conventional vehicles. Rattling, shaking or jarring noises may be heard when idling or driving at a low speed.</li> <li>Rattling noises may be heard when the engine is started or stopped.</li> </ul>


### MEMO

## O Illustrated table of contents

Seats, seat belts and Supplemental Restraint	
System (SRS)	0-2
Front	0-2
Rear	0-3
Exterior front	0-4
Exterior rear	0-6

Passenger compartment	. 0-7
Cockpit	. 0-8
nstrument panel	. 0-9
Meters and gauges	0-10
Engine compartment	0-11
Warning and indicator lights	0-12

## SEATS, SEAT BELTS AND SUPPLEMENTAL RESTRAINT SYSTEM (SRS)



8. Front seats (P.1-3)

### **FRONT**


- 1. Seat belt (Page 1-6)
- 2. Rear seat walk-in lever (P.1-5)
- Roof-mounted curtain side-impact and rollover supplemental air bag system (P.1-34)
- 4. Supplemental front-impact air bags (P.1-34)
- 5. Seat belt pretensioner (P.1-46)
- Front seat-mounted side-impact supplemental air bag system (P.1-34)
- Occupant classification sensor (pattern sensor) (P.1-40)



#### **REAR**

- Rear seats
  - Child restraint installation (P.1-15)
- 2. Child restraint anchor points (for top tether strap child restraint) (P.1-19)
- 3. LATCH (Lower Anchors and Tethers for CHildren) system (P.1-17, P.1-26, P.1-30)

#### **EXTERIOR FRONT**



- 1. Hood (P.3-18)
- Windshield wiper and washer (P.2-51, P.8-18)
- 3. Doors (P.3-2, P.3-4, P.3-8)
- 4. Outside mirrors (P.3-28)
- 5. Power windows (P.2-67)

- 6. Corner sensors (P.5-48)
- 7. Center sensors (P.5-48)
- 3. Daytime running light (P.2-53)
- 9. Headlight and turn signal (P.2-53, P.8-27)
- Tires and wheels (P.5-4, P.6-3, P.8-29, P.10-10)

ITEMS	GENUINE PARTS
Road wheel	Genuine road wheel specific to GT-R
Tire*1	Genuine tire specific to GT-R
Brake pad*2	Genuine brake pad specific to GT-R
Brake disc ro- tor*2	Genuine brake disc rotor specific to GT-R


- \*1: When tire replacement is required, replacing tires as a set of four with new tires is recommended. However, if a tire is punctured or damaged, it may be possible to replace only the damaged tire. Determining whether one tire or a complete set of tires should be replaced is based on a number of factors including tire wear and condition. It is recommended you contact your GT-R certified NISSAN dealer. They can recommend if an individual tire or a complete set should be replaced.
- \*2: For models without NCCB (NISSAN Carbon Ceramic Brake) package: \*\* "Brake pad and disc rotor" page GTR-6

For models with NCCB (NISSAN Carbon Ceramic Brake) package: [五] "NCCB (NISSAN Carbon Ceramic Brake)" page GTR-6

Genuine NISSAN Brake Fluid R35 Special II is the factory fill brake fluid. The Vehicle Dynamic Control (VDC) unit and other related parts were specially designed for this brake fluid. NISSAN cannot ensure

proper operation of the vehicle if other non-equivalent brake fluid is used.

#### **EXTERIOR REAR**




- High-mounted stop light (P.8-27)
- 2. Trunk (P.3-8, P.3-20)
- Rear window defroster (P.2-52)
- Satellite antenna (P.4-14)
- Corner sensors (P.5-48)
- Center sensors (P.5-48)

- Rear view camera (P.4-2)
- Rear combination light (P.8-27)
- Fuel-filler door (P.3-24, P.10-4)
- A: Except for NISMO models
- (B): NISMO models

ITEMS	GT-R SPECIFIED FUEL
Fuel	Unleaded premium gasoline with an octane rating of at least 93 AKI (Anti-Knock Index) number (Re- search octane number 98)*1

Use unleaded premium gasoline with an octane rating of at least 93 AKI (Anti-Knock Index) number (Research octane number 98) to maximize vehicle performance. If 93 AKI number (Research octane number 98) premium gasoline is not available, you may use unleaded premium gasoline with an octane rating of at least 91 AKI number (Research octane number 96), but you may notice a decrease in performance.

#### PASSENGER COMPARTMENT




- Coat hooks (P.2-66)
- Inside lock knob (P.3-5)
- 3. Interior light control switch (P.2-69)
- Map lights (P.2-69)
- E-Call (SOS) button (P.2-61)
- Sun visors (P.3-27)

- Sunglasses holder (P.2-64)
- Inside mirror (P.2-71, P.3-27)
- Center console box (P.2-66)
  - Power outlet (P.2-60)
  - USB memory operation\*
  - iPod® player operation\*
  - Auxiliary input jack\*

- Cup holders (P.2-63)
- Power window switches (P.2-67)
- Window lock button (P.2-68)
- 13. Power door lock switch (P.3-5)
- Refer to the separate Multi Function Display Owner's Manual.

#### COCKPIT




- Headlight and turn signal switch (P.2-53)
- 2. Paddle shifters (P.5-15)
- Steering-wheel-mounted controls (left side)\*
- 4. Meters and gauges (P.2-6)
- Steering-wheel-mounted controls (right side)

- MRK (Mark) switch\*
- Cruise control (P.5-35)
- Wiper and washer switch (P.2-51)
- 7. VDC, transmission and suspension set up switches (P.5-25)
- 8. Trunk lid release switch (P.3-20)

- 9. Hood release handle (P.3-18)
- 10. Intelligent Key port (P.5-12)
- 11. Sonar system OFF switch (P.5-50)
- Tilting/telescopic steering wheel lever (P.3-26)
- 13. Horn (P.2-58)
- Exhaust sound control switch (if so equipped) (P.5-59)
- 15. Push-button ignition switch (P.5-10)
- 16. Shift lever (P.5-15)
- 17. Parking brake (P.5-34, P.5-46)
- \*: Refer to the separate Multi Function Display Owner's Manual.

#### **INSTRUMENT PANEL**



- Outside mirror control switch (P.3-28)
- Rear window defroster switch (P.2-52)
- 3. CD slot\*
- Heater and air conditioner (P.4-10)
- Touch screen display\*
- Glove box (P.2-65)

- Fuse box cover (P.8-22)
- Power outlet (P.2-60)
- Display Commander\*
- 10. Front passenger air bag status light (P.1-42)
- Hazard warning flasher switch (P.6-2)

- Trunk release power cancel switch (P.3-21)
- Refer to the separate Multi Function Display Owner's Manual.

#### **METERS AND GAUGES**



- Trip A/B reset switch (P.2-7)
- Speedometer (P.2-7)
- Tachometer (P.2-8)/Upshift indicator (P.2-10)
- Transmission position indicator (P.2-10)
- Engine coolant temperature gauge (P.2-8)

- ENTER switch (P.2-16)
- Instrument brightness control switch (P.2-12)
- 8. Vehicle information display (P.2-13)
- Odometer/twin trip odometer (P.2-7)
- Fuel gauge (P.2-9)
- NEXT switch (P.2-16)

#### NOTE:

- Meters and gauges will illuminate when the ignition switch is pushed to the ON position.
- The needle indicators may move slightly after the ignition switch is pushed to the OFF position. This does not indicate that there is a malfunction.

#### **ENGINE COMPARTMENT**



- Fuse/fusible link holder (P.8-22)
- Battery (P.8-13)
- Engine oil filler cap (P.8-9)
- Engine oil dipstick (P.8-9)
- Brake fluid reservoir (P.8-11)
- Air cleaner (P.8-17)

- Power steering fluid reservoir (P.8-11)
- Radiator filler cap (P.8-6)
- Coolant reservoir cap (pressure type) (P.8-6)
- 10. Coolant reservoir (P.8-6)
- Window washer fluid reservoir (P.8-12)

ITEMS	GT-R SPECIFIED FLUIDS
Engine oil	Mobil 1 (0W-40)*1 or equivalent
Transmission oil	Genuine NISSAN Transmission Oil R35 Special or equivalent
Differential oil (front and rear)	Differential Oil R35 COM- PETITION type 2189E or equivalent
Brake fluid	Genuine NISSAN Brake Fluid R35 Special II*2 or equivalent

- Mobil 1 (OW-40) (100% synthetic) is the factory fill oil. The VR38 engine with its plasma-sprayed bores was developed using this oil. NISSAN cannot ensure proper engine operation and durability if other OW-40 non-equivalent synthetic oil is used. If Mobil 1 (OW-40) or equivalent is not available. Mobil 1 (10W-40) (100% synthetic) or equivalent may be used; however, some performance loss may be noticed
- \*2: Genuine NISSAN Brake Fluid R35 Special II is the factory fill brake fluid. The Vehicle Dynamic Control (VDC) unit and other related parts were specially designed for this brake fluid and NISSAN cannot ensure proper operation of the vehicle if other non-equivalent brake fluid is used.

## **WARNING AND INDICATOR LIGHTS**

Red light	Name	Page
BRAKE	Brake warning light	2-26
1	Charge warning light	2-27
***	Engine oil pressure warning light	2-28
*	Seat belt warning light	2-28
*	Supplemental air bag warning light	2-28

Yellow light	Name	Page
AWD	All-Wheel Drive (AWD) warning light	2-29
ABS	Anti-lock Braking System (ABS) warning light	2-29
	Intelligent Key warning light	2-30
3	Low tire pressure warning light	2-30
SERVICE ENGINE 900N	Malfunction Indicator Light (MIL)	2-32
4	Master warning light	2-32
좕	Transmission warning light	2-33
<b>₩</b> \$	Vehicle Dynamic Control (VDC) off indicator light	2-33
93	Vehicle Dynamic Control (VDC) warning light	2-34

Other light	Name	Page
(SELECTE	Cruise main switch indicator light	2-34
<b>S</b>	Cruise set switch indicator light	2-34
<del>-</del> >0 <del>-</del>	Exterior light indicator	2-34
OFF See	Front passenger air bag status light	2-34
	High beam indicator light	2-34
4+	Turn signal/hazard indica- tor lights	2-34

## 1 Safety — Seats, seat belts and supplemental restraint system

Seats 1-2	Rear-fa
Front seats 1-3	the sea
Head restraints/headrests 1-5	Forwar
Seat belts 1-6	using L
Precautions on seat belt usage 1-6	Forwar
Pregnant women 1-9	using t
Injured persons 1-9	Booste
Three-point type seat belt with retractor 1-9	Suppleme
Seat belt extenders 1-12	Precau
Seat belt maintenance 1-12	restrair
Child safety 1-13	NISSAN (front s
Infants 1-13	Front s
Small children 1-14	supple
Larger children 1-14	curtain
Child restraints 1-15	supple
Precautions on child restraints 1-16	Seat be
Lower Anchors and Tethers for CHildren	(front s
System (LATCH) 1-17	Supple
Rear-facing child restraint installation	Supple
using LATCH 1-20	Repair

	icing child restraint installation using	1-21
	d-facing child restraint installation ATCH	1-24
	d-facing child restraint installation he seat belts	1-26
Booste	r seats	1-30
	, , , , , , , , , , , , , , , , , , , ,	1-34
restrair	tions on supplemental nt system	1-34
	l Advanced Air Bag System seats)	1-40
suppler	eat-mounted side-impact mental air bag and roof-mounted side-impact and rollover	
suppler	mental air bag systemselts with pretensioners	1-45
	eats)	1-46
	mental air bag warning labels	
Supplei	mental air bag warning light	1-48
Repair	and replacement procedure	1-49

#### **SEATS**





Sit upright and well back.

## **WARNING**

- Do not ride in a moving vehicle when the seatback is reclined. This can be dangerous. The shoulder belt will not be against your body. In an accident, you could be thrown into it and receive neck or other serious injuries. You could also slide under the lap belt and receive serious internal injuries.
- For the most effective protection when the vehicle is in motion, the seat should be upright. Always sit

well back and upright in the seat with both feet on the floor and adjust the seat properly. ( \*\*\text{?\*\*}\text{"Precautions on seat belt usage" page 1-6)

- After adjustment, gently rock in the seat to make sure it is securely locked.
- Do not leave children unattended inside the vehicle. They could unknowingly activate switches or controls. Unattended children could become involved in serious accidents.


- To help avoid risk of injury or death through unintended operation of the vehicle and/or its systems, do not leave children, people who require the assistance of others or pets unattended in your vehicle. Additionally, the temperature inside a closed vehicle on a warm day can quickly become high enough to cause a significant risk of injury or death to people and pets.
- The seatback should not be reclined any more than needed for comfort. Seat belts are most effective when the passenger sits with their back straight up and contacting the seat. If the seatback is reclined, the risk of sliding under the lap belt and being injured is increased.

## **A** CAUTION

When adjusting the seat positions, be sure not to contact any moving parts to avoid possible injuries or damage.

#### NOTICE

Make sure the front seatback does not contact the rear seat when reclining the seat. When the front seat is reclined to the rearmost position, it may contact the rear seat. This may cause an indentation in the seatback.



#### FRONT SEATS

## Front power seat adjustment

Operating tips

- The power seat motor has an autoreset overload protection circuit. If the motor stops during operation, wait 30 seconds, then reactivate the switch.
- Do not operate the power seat switch for a long period of time when the engine is off. This will discharge the battery.

Seat Adjustment	Switch	Operation	Location
Forward and back- ward		Move the switch (a) forward or backward until the desired seat position is obtained.	Driver's and
Reclining	®	Turn the switch (a) forward and backward until the desired seatback angle is obtained.  The reclining feature allows adjustment of the seatback for occupants of different sizes for added comfort and to help obtain proper seat belt fit. ( **) "Precautions on seat belt usage" page 1-6)  Also, the seatback can be reclined to allow occupants to rest when the vehicle is stopped and the transmission is in the ** position with the parking brake fully applied.	
Seat lifter (front)	®	Push the switch up or down ® to raise or lower the front portion of the seat.	· Driver's seat
Seat lifter (rear)	®	Move the switch (a) up or down to raise or lower the rear portion of the seat.	



### Rear seat walk-in

This feature makes it easier to get in and out of the rear seat. Use the following procedure when getting in and out of the rear seat.

- 1. Pull up the lever ①, hold the knob ②. and tilt the seatback forward.
- 2. Use the seat adjustment switch (A) to slide the seat forward to a position where it will be easier to enter or exit the rear seats. Fold the shoulder belt guide for easier access to the rear seat.

To return the seatback to its original position, hold the knob (2), raise the seat-

back, and use the seat adjustment switch A to adjust the seat position.

## **A** CAUTION

- When returning the seat to its original position, confirm that the seat and seatback are locked properly.
- Be careful not to pinch your hand or foot or bump your head when operating the walk-in seat.

### NOTICE

Do not place any objects near the seatback of the front seats. They may be pinched and damaged.

### **HEAD RESTRAINTS/HEADRESTS**

## **WARNING**

Head restraints/headrests supplement the other vehicle safety systems. They may provide additional protection against injury in certain rear end collisions.


Head restraints/headrests must be adjusted properly, as specified in this section. Check the adjustment after someone else uses the seat. Failure to follow these instructions can reduce the effectiveness of the head restraints/headrests. This may increase the risk of serious injury or death in a collision.



## PRECAUTIONS ON SEAT BELT USAGE

If you are wearing your seat belt properly adjusted, and you are sitting upright and well back in your seat with both feet on the floor, your chances of being injured or killed in an accident and/or the severity of injury may be greatly reduced. NISSAN strongly encourages you and all of your passengers to buckle up every time you drive, even if your seating position includes a supplemental air bag.

Most U.S. states and Canadian provinces or territories specify that seat belts be worn at all times when a vehicle is being driven.



The illustration shows the seating positions equipped with head restraint/headrest.

- ▲ Indicates the seating position is equipped with a head restraint.
- + Indicates the seating position is not equipped with a head restraint or headrest.

Your vehicle is equipped with integrated head restraints/headrests

Proper adjustment:

Properly position the head restraint by adjusting the front seat so that the top of the seat is as upright as possible.



## **WARNING**

- Every person who drives or rides in this vehicle should use a seat belt at all times. Children should be properly restrained in the rear seat and, if appropriate, in a child restraint.
- The seat belt should be properly adjusted to a snug fit. Failure to do so may reduce the effectiveness of the entire restraint system and increase the chance or severity of injury in an accident. Serious injury or death can occur if the seat belt is not worn properly.
- Always route the shoulder belt over your shoulder and across your chest. Never put the belt behind your back, under your arm or across your neck. The belt should be away from your face and neck, but not falling off your shoulder.
- Position the lap belt as low and snug as possible AROUND THE HIPS, NOT THE WAIST. A lap belt worn too high could increase the risk of internal injuries in an

accident.

- Be sure the seat belt tongue is securely fastened to the proper buckle.
- Do not wear the seat belt inside out or twisted. Doing so may reduce its effectiveness.
- Do not allow more than one person to use the same seat belt.
- Never carry more people in the vehicle than there are seat belts.
- If the seat belt warning light glows continuously while the ignition is turned ON with all doors closed and all seat belts fastened, it may indicate a malfunction in the system. It is recommended you have the system checked by a GT-R certified NISSAN dealer.
- No changes should be made to the seat belt system. For example, do not modify the seat belt, add material, or install devices that may change the seat belt routing or tension. Doing so may affect the operation of the seat belt system. Modifying or tampering with the seat belt system may result in serious personal

injury.

- Once a seat belt pretensioner has activated, it cannot be reused and must be replaced together with the retractor. It is recommended you see a GT-R certified NISSAN dealer.
- Removal and installation of the pretensioner system components should be done by a GT-R certified NISSAN dealer.
- All seat belt assemblies, including retractors and attaching hardware, should be inspected after any collision by a GT-R certified NISSAN dealer. NISSAN recommends that all seat belt assemblies in use during a collision be replaced unless the collision was minor and the belts show no damage and continue to operate properly. Seat belt assemblies not in use during a collision should also be inspected and replaced if either damage or improper operation is noted.
- All child restraints and attaching hardware should be inspected after any collision. Always follow the restraint manufacturer's in-

spection instructions and replacement recommendations. The child restraints should be replaced if they are damaged.





#### PREGNANT WOMEN

NISSAN recommends that pregnant women use seat belts. The seat belt should be worn snug, and always position the lap belt as low as possible around the hips, not the waist. Place the shoulder belt over your shoulder and across your chest. Never run the lap/shoulder belt over your abdominal area. Contact your doctor for specific recommendations.

### INJURED PERSONS

NISSAN recommends that injured persons use seat belts. Check with your doctor for specific recommendations.

## THREE-POINT TYPE SEAT BELT WITH RETRACTOR

## **WARNING**

- Every person who drives or rides in this vehicle should use a seat belt at all times.
- Do not ride in a moving vehicle when the seatback is reclined. This can be dangerous. The shoulder belt will not be against your body. In an accident, you could be thrown into it and receive neck or other serious inju-

- ries. You could also slide under the lap belt and receive serious internal injuries.
- For the most effective protection when the vehicle is in motion, the seat should be upright. Always sit well back and upright in the seat with both feet on the floor and adjust the seat belt properly.
- Do not allow children to play with the seat belts. Most seating positions are equipped with Automatic Locking Retractor (ALR) mode seat belts. If the seat belt becomes wrapped around a child's neck with the ALR mode activated, the child can be seriously injured or killed if the seat belt retracts and becomes tight. This can occur even if the vehicle is parked. Unbuckle the seat belt to release the child. If the seat belt cannot be unbuckled or is already unbuckled, release the child by cutting the seat belt with a suitable tool (such as a knife or scissors) to release the seat belt.



Then smoothly pull the belt out of the retractor.



## Fastening the seat belts

- 1. Adjust the seat. ( 🏋 "Seats" page 1-2)
- Slowly pull the seat belt out of the retractor and insert the tongue into the buckle until you hear and feel the latch engage.
  - The retractor is designed to lock during a sudden stop or on impact. A slow pulling motion permits the belt to move, and allows you some freedom of movement in the seat.
  - If the seat belt cannot be pulled from its fully retracted position, firmly pull the belt and release it.

- Position the lap belt portion low and snug on the hips as shown.
- Pull the shoulder belt portion toward the retractor to take up extra slack. Be sure the shoulder belt is routed over your shoulder and across your chest.

The three-point type seat belts for the front passenger and rear seats have two modes of operation:

- Emergency Locking Retractor (ELR)
- Automatic Locking Retractor (ALR)

The Emergency Locking Retractor (ELR) mode allows the seat belt to extend and retract to allow the driver and passengers some freedom of movement in the seat.

The FLR locks the seat belt when the vehicle slows down rapidly or during impacts.

The Automatic Locking Retractor (ALR) mode or child restraint mode locks the seat belt for child restraint installation.

When the ALR mode is activated the seat belt cannot be extended again until the seat belt tongue is detached from the buckle and fully retracted. The seat belt returns to the FLR mode after the seat belt is fully retracted.

(译 "Child restraints" page 1-15)

The ALR mode should be used only for child restraint installation. During normal seat belt use by an occupant, the ALR mode should not be activated. If it is activated it may cause uncomfortable seat belt tension. It can also change the operation of the front passenger air bag. ( Front passenger air bag and status light" page 1-42)

## **WARNING**

When fastening the seat belts, be certain that seatbacks are completely secured in the latched position. If they are not completely secured, passengers may be injured in an accident or sudden stop.



## Unfastening the seat belts

To unfasten the seat belt, push the button on the buckle. The seat belt automatically retracts.

## Checking seat belt operation

Seat belt retractors are designed to lock seat belt movement by two separate methods.

- When the belt is pulled quickly from the retractor.
- When the vehicle slows down rapidly. To increase your confidence in the seat belts, check the operation as follows:
- Grasp the shoulder belt and pull forward quickly. The retractor should lock and restrict further belt movement.

If the retractor does not lock during this check or if you have any question about seat belt operation, see a GT-R certified NISSAN dealer



## Shoulder belt arm (for front seats)

Before fastening the seat belt, adjust the shoulder belt arm to the lock position where the belt fits snugly on the shoulder. The arm can also be folded down to allow rear seat passengers easier access.

Pulling the arm forward will allow an easy access to the belt.

#### SEAT BELT EXTENDERS

If, because of body size or driving position, it is not possible to properly fit the lapshoulder belt and fasten it, an extender that is compatible with the installed seat belts is available that can be purchased. The extender adds approximately 8 in (200 mm) of length and may be used for either the driver or front passenger seating position. It is recommended you see a GT-R certified NISSAN dealer for assistance with purchasing an extender if an extender is required.

## **WARNING**

- It is recommended that only NISSAN seat belt extenders, made by the same company which made the original equipment seat belts, be used with the NISSAN seat belts.
- Adults and children who can use the standard seat belt should not use an extender. Such unnecessary use could result in serious personal injury in the event of an accident.
- Never use seat belt extenders to install child restraints. If the child restraint is not secured properly,

the child could be seriously iniured or killed in a collision or a sudden stop.

### **SEAT BELT MAINTENANCE**

- To clean the seat belt webbing, apply a mild soap solution or any solution recommended for cleaning upholstery or carpets. Then, wipe with a cloth and allow the seat belts to dry in the shade. Do not allow the seat belts to retract until they are completely dry.
- If dirt builds up in the shoulder belt quide of the seat belt anchors, the seat belts may retract slowly. Wipe the shoulder belt guide with a clean, dry cloth
- Periodically check to see that the seat belt and the metal components such as buckles, tongues, retractors, flexible wires and anchors work properly. If loose parts, deterioration, cuts or other damage on the webbing is found, the entire seat belt assembly should be replaced.

## **WARNING**

Do not allow children to play with the seat belts. Most seating positions are equipped with Automatic Locking Retractor (ALR) mode seat belts. If the seat belt becomes wrapped around a child's neck with the ALR mode activated, the child can be seriously injured or killed if the seat belt retracts and becomes tight. This can occur even if the vehicle is parked. Unbuckle the seat belt to release the child. If the seat belt cannot be unbuckled or is already unbuckled, release the child by cutting the seat belt with a suitable tool (such as a knife or scissors) to release the seat belt.

#### Children need adults to help protect them. They need to be properly restrained.

In addition to the general information in this manual, child safety information is available from many other sources, including doctors, teachers, government traffic safety offices, and community organizations. Every child is different, so be sure to learn the best way to transport vour child.

There are three basic types of child restraint systems:

- Rear-facing child restraint
- Forward-facing child restraint
- Booster seat

The proper restraint depends on the child's size. Generally, infants (up to about 1 year and less than 20 lb (9 kg)) should be placed in rear- facing child restraints. Forward-facing child restraints are available for children who outgrow rear-facing child restraints and are at least 1 year old. Booster seats are used to help position a vehicle lap/shoulder belt on a child who can no longer use a forward-facing child restraint

## **WARNING**

Infants and children need special protection. The vehicle's seat belts may not fit them properly. The shoulder belt may come too close to the face or neck. The lap belt may not fit over their small hip bones. In an accident, an improperly fitting seat belt could cause serious or fatal injury. Always use appropriate child restraints.

All U.S. states and Canadian provinces or territories require the use of approved child restraints for infants and small children. ( 128 "Child restraints" page 1-15)

A child restraint may be secured in the vehicle by using either the LATCH (Lower Anchor and Tethers for CHildren) system or with the vehicle seat belt. ( \*\* "Child restraints" page 1-15)

NISSAN recommends that all pre-teens and children be restrained in the rear seat. According to accident statistics, children are safer when properly restrained in the rear seat than in the front seat.

This is especially important because your vehicle has a supplemental restraint system (air bag system) for the front passenger. ( \*\*\mathscr{P}

#### **INFANTS**

Infants up to at least one year old should be placed in a rear-facing child restraint. NISSAN recommends that infants be placed in child restraints that comply with Federal Motor Vehicle Safety Standards or Canadian Motor Vehicle Safety Standards. You should choose a child restraint which fits your vehicle and always follow the manufacturer's instructions for instal-

lation and use.

#### **SMALL CHILDREN**

Children that are over 1 year old and weigh at least 20 lb (9 kg) should remain in a rear-facing child restraint as long as possible up to the height or weight limit of the child restraint. Children who outgrow the height or weight limit of the rear-facing child restraint and are at least 1 year old should be secured in a forwardfacing child restraint with a harness. Refer to the manufacturer's instructions for minimum and maximum weight and height recommendations. NISSAN recommends that small children be placed in child restraints that comply with Federal Motor Vehicle Safety Standards or Canadian Motor Vehicle Safety Standards. You should choose a child restraint that fits your vehicle and always follow the manufacturer's instructions for installation and use.

#### LARGER CHILDREN

Children should remain in a forwardfacing child restraint with a harness until they reach the maximum height or weight limit allowed by the child restraint manufacturer.

Once a child outgrows the height or weight limit of the harness-equipped forward-facing child restraint, NISSAN recommends that the child be placed in a commercially available booster seat to obtain proper seat belt fit. For a seat belt to fit properly, the booster seat should raise the child so that the shoulder belt is properly positioned across the chest and the top, middle portion of the shoulder. The shoulder belt should not cross the neck or face and should not fall off the shoulder. The lap belt should lie snugly across the lower hips or upper thighs, not the abdomen

A booster seat can only be used in seating positions that have a three-point type seat belt. The booster seat should fit the vehicle seat and have a label certifying that it complies with Federal Motor Vehicle Safety Standards or Canadian Motor Vehicle Safety Standards.

A booster seat should be used until the child can pass the seat belt fit test below:

- Are the child's back and hips against the vehicle seatback?
- Is the child able to sit without slouching?
- Do the child's knees bend easily over the front edge of the seat with feet flat on the floor?
- Can the child safely wear the seat belt (lap belt low and snug across the hips and shoulder belt across mid-chest and shoulder)?
- Is the child able to use the properly adjusted head restraint/headrest?
- Will the child be able to stay in position for the entire ride?



If you answered no to any of these questions, the child should remain in a booster seat using a three-point type seat belt.

### NOTE:

Laws in some communities may follow different guidelines. Check local and state regulations to confirm your child is using the correct restraint system before traveling.

## **WARNING**

Never let a child stand or kneel on any seat and do not allow a child in the cargo areas while the vehicle is moving. The child could be seriously injured or killed in an accident or sudden stop.

### **CHILD RESTRAINTS**





## PRECAUTIONS ON CHILD RE-

## **WARNING**

- Failure to follow the warnings and instructions for proper use and installation of child restraints could result in serious injury or death of a child or other passengers in a sudden stop or collision:
  - The child restraint must be used and installed properly.
     Always follow all of the child restraint manufacturer's instructions for installation and use.
  - Infants and children should never be held on anyone's lap. Even the strongest adult cannot resist the forces of a collision.
  - Do not put a seat belt around both a child and another passenger.
  - NISSAN recommends that all child restraints be installed in the rear seat. Studies show that children are safer when properly restrained in the rear

seat than in the front seat. If you must install a forward-facing child restraint in the front seat. ( \*\*\security\*\* "Forward-facing child restraint installation using the seat belts" page 1-26)

- Even with the NISSAN Advanced Air Bag System, never install a rear-facing child restraint in the front seat. An inflating air bag could seriously injure or kill a child. A rear-facing child restraint must only be used in the rear seat.
- Be sure to purchase a child restraint that will fit the child and vehicle. Some child restraints may not fit properly in your vehicle.
- Child restraint anchor points are designed to withstand loads from child restraints that are properly fitted.
- Never use the anchor points for adult seat belts or harnesses.
- A child restraint with a top tether strap should not be

used in the front passenger seat.

- Keep seatbacks as upright as possible after fitting the child restraint.
- Infants and children should always be placed in an appropriate child restraint while in the vehicle.
- When the child restraint is not in use, keep it secured with the LATCH system or a seat belt. In a sudden stop or collision, loose objects can injure occupants or damage the vehicle.

## **A** CAUTION

A child restraint in a closed vehicle can become very hot. Check the seating surface and buckles before placing a child in the child restraint.

This vehicle is equipped with a universal child restraint anchor system, referred to as the LATCH (Lower Anchors and Tethers for CHildren) system. Some child restraints include rigid or webbingmounted attachments that can be con-

nected to these anchors. (See TAP "Lower Anchors and Tethers for CHildren System (LATCH)" page 1-17.)

If you do not have a LATCH compatible child restraint, the vehicle seat belts can be used.

Several manufacturers offer child restraints for infants and small children of various sizes. When selecting any child restraint, keep the following points in mind:

- Choose only a restraint with a label certifying that it complies with Federal Motor Vehicle Safety Standard 213 or Canadian Motor Vehicle Safety Standard 213.
- Check the child restraint in your vehicle to be sure it is compatible with the vehicle's seat and seat belt system.
- If the child restraint is compatible with your vehicle, place your child in the child restraint and check the various adjustments to be sure the child restraint is compatible with your child. Choose a child restraint that is designed for your child's height and weight. Always follow all recommended procedures.
- If the combined weight of the child

and child restraint is less than 65 lbs (29.5 kg), you may use either the LATCH anchors or the seat belt to install the child restraint (not both at the same time).

- If the combined weight of the child and child restraint is greater than 65 lbs (29.5 kg), use the vehicle's seat belt (not the lower anchors) to install the child restraint.
- Be sure to follow the child restraint manufacturer's instructions for installation.

All U.S. states and Canadian provinces or territories require that infants and small children be restrained in an approved child restraint at all times while the vehicle is being operated. Canadian law requires the top tether strap on forward-facing child restraints be secured to the designated anchor point on the vehicle.



LATCH label location

## Lower Anchors and Tethers for CHildren System (LATCH)

Your vehicle is equipped with special anchor points that are used with the LATCH (Lower Anchors and Tethers for CHildren) system compatible child restraints. This system may also be referred to as the ISOFIX or ISOFIX compatible system. With this system, you do not have to use a vehicle seat belt to secure the child restraint unless the combined weight of the child and child restraint exceeds 65 lbs (29.5 kg). If the combined weight of the child and child restraint is greater than 65 lbs (29.5 kg), use the

vehicle's seat belt (not the lower anchors) to install the child restraint. Be sure to follow the child restraint manufacturer's instructions for installation.

#### LATCH lower anchor

## **WARNING**

Failure to follow the warnings and instructions for proper use and installation of child restraints could result in serious injury or death of a child or other passengers in a sudden stop or collision:

- Attach LATCH system compatible child restraints only at the locations shown in the illustration.
- Inspect the lower anchors by inserting your fingers into the lower anchor area. Feel to make sure there are no obstructions over the anchors such as seat belt webbing or seat cushion material. The child restraint will not be secured properly if the lower anchors are obstructed.

Child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances

are they to be used to attach adult seat belts, or other items or equipment to the vehicle. Doing so could damage the child restraint anchorages. The child restraint will not be properly installed using the damaged anchorage, and a child could be seriously injured or killed in a collision.




LATCH lower anchor location

#### LATCH lower anchor location

The LATCH lower anchors are located at the rear of the seat cushion near the seatback. A label is attached to the seatback to help you locate the LATCH anchors.

## **WARNING**


The GT-R has seats and seat belts for four occupants, two in the front seats and two in the rear seats. Never use the rear console as a seating position or for a child restraint.






#### Installing child restraint LATCH lower anchor attachments

LATCH compatible child restraints include two rigid or webbing-mounted attachments that can be connected to two anchors located at certain seating positions in your vehicle. With this system, you do not have to use a vehicle seat belt to secure the child restraint. Check your child restraint for a label stating that it is compatible with LATCH. This information may also be in the instructions provided by the child restraint manufacturer.



LATCH rigid-mounted attachment

When installing a child restraint, carefully read and follow the instructions in this manual and those supplied with the child restraint.



# Top tether anchor point locations

Anchor points are located on the rear parcel shelf.

If you have any questions when installing a top tether strap child restraint on the rear seat, it is recommended you see a GT-R certified NISSAN dealer for this service.

# **WARNING**

Child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used to attach adult seat belts, or other items or equipment to the vehicle. Doing so could damage the child restraint anchorages. The child restraint will not be properly installed using the damaged anchorage, and a child could be seriously injured or killed in a collision.

#### REAR-FACING CHILD RESTRAINT INSTALLATION USING LATCH

Refer to all Warnings and Cautions in the "Child safety" and "Child restraints" sections before installing a child restraint.

Do not use the lower anchors if the combined weight of the child and the child restraint exceeds 65 lbs (29.5 kg). If the combined weight of the child and the child restraint is greater than 65 lbs (29.5 ka), use the vehicle's seat belt (not the lower anchors) to install the child restraint. Be sure to follow the child restraint manufacturer's instructions for installation.

Follow these steps to install a rear-facing child restraint using the LATCH system:

 Position the child restraint on the seat. Always follow the child restraint manufacturer's instructions.



Rear-facing web-mounted - step 2

2. Secure the child restraint anchor attachments to the LATCH lower anchors. Check to make sure the LATCH attachment is properly attached to the lower anchors



Rear-facing rigid-mounted - step 2



Rear-facing - step 3

3. For child restraints that are equipped with webbing-mounted attachments, remove any additional slack from the anchor attachments. Press downward and rearward firmly in the center of the child restraint with your hand to compress the vehicle seat cushion and seatback while tightening the webbing of the anchor attachments.



Rear-facing - step 4

4. After attaching the child restraint, test it before you place the child in it. Push it from side to side while holding the child restraint near the LATCH attachment path. The child restraint should not move more than 1 inch (25 mm). from side to side. Try to tug it forward and check to see if the LATCH attachment holds the restraint in place. If the restraint is not secure, tighten the LATCH attachment as necessary, or put the restraint in another seat and test it again. You may need to try a different child restraint or try installing by using the vehicle seat belt (if applicable). Not all child restraints fit

- in all types of vehicles.
- 5. Check to make sure the child restraint is properly secured prior to each use. If the child restraint is loose, repeat steps 1 through 4.

#### REAR-FACING CHILD RESTRAINT INSTALLATION USING THE SEAT **BELTS**

# **WARNING**

The three-point seat belt with Automatic Locking Retractor (ALR) must be used when installing a child restraint. Failure to use the ALR mode will result in the child restraint not being properly secured. The restraint could tip over or be loose and cause injury to a child in a sudden stop or collision. Also, it can change the operation of the front passenger air bag. See "Front passenger air bag and status light" later in this section.



 Child restraints for infants must be used in the rear-facing direction and therefore must not be used in the front seat. Position the child restraint on the seat. Always follow the restraint manufacturer's instructions.



Rear-facing — step 2

 Route the seat belt tongue through the child restraint and insert it into the buckle until you hear and feel the latch engage. Be sure to follow the child restraint manufacturer's instructions for belt routing.

Rear-facing - step 1

Refer to all Warnings and Cautions in "Child safety" and "Child restraints" before installing a child restraint.

Do not use the lower anchors if the combined weight of the child and the child restraint exceeds 65 lbs (29.5 kg). If the combined weight of the child and the child restraint is greater than 65 lbs (29.5 kg), use the vehicle's seat belt (not the lower anchors) to install the child restraint. Be sure to follow the child restraint manufacturer's instructions for installation.

Follow these steps to install a rear-facing child restraint using the vehicle seat belts in the rear seats:



Rear-facing - step 3

3. Pull the shoulder belt until the belt is fully extended. At this time, the seat belt retractor is in the Automatic Locking Retractor (ALR) mode (child restraint mode). It reverts to the Emergency Locking Retractor (ELR) mode when the seat belt is fully retracted



Rear-facing - step 4

4. Allow the seat belt to retract. Pull up on the shoulder belt to remove any slack in the belt.



Rear-facing - step 5

5. Remove any additional slack from the seat belt; press downward and rearward firmly in the center of the child restraint to compress the vehicle seat cushion and seatback while pulling up on the seat belt.



Rear-facing — step 6

- 6. After attaching the child restraint, test it before you place the child in it. Push it from side to side while holding the child restraint near the seat belt path. The child restraint should not move more than 1 inch (25 mm), from side to side. Try to tug it forward and check to see if the belt holds the restraint in place. If the restraint is not secure, tighten the seat belt as necessary, or put the restraint in another seat and test it again. You may need to try a different child restraint. Not all child restraints fit in all types of vehicles.
- 7. Check to make sure that the child restraint is properly secured prior to

each use. If the seat belt is not locked. repeat steps 1 through 6.

After the child restraint is removed and the seat belt fully retracted, the ALR mode (child restraint mode) is canceled.

#### FORWARD-FACING CHILD RE-STRAINT INSTALLATION USING LATCH

Refer to all Warnings and Cautions in the "Child safety" and "Child restraints" sections before installing a child restraint. Do not use the lower anchors if the combined weight of the child and the child restraint exceeds 65 lbs (29.5 kg). If the combined weight of the child and the child restraint is greater than 65 lbs (29.5 kg), use the vehicle's seat belt (not the lower anchors) to install the child restraint. Be sure to follow the child restraint manufacturer's instructions for installation.

Follow these steps to install a forwardfacing child restraint using the LATCH svstem:

1. Position the child restraint on the seat. Always follow the child restraint manufacturer's instructions.



#### Forward-facing web-mounted - step 2

2. Secure the child restraint anchor attachments to the LATCH lower anchors. Check to make sure the LATCH attachment is properly attached to the lower anchors.

If the child restraint is equipped with a top tether strap, route the top tether strap and secure the tether strap to the tether anchor point. See 'Installing top tether strap" page 1-26. Do not install child restraints that require the use of a top tether strap in seating positions that do not have a top tether anchor.



Forward-facing rigid-mounted - step 2

- 3. The back of the child restraint should be secured against the vehicle seatback.
  - If the seating position is interfering with the proper child restraint fit, try another seating position or a different child restraint.



Forward-facing - step 4


- For child restraints that are equipped with webbing-mounted attachments, remove any additional slack from the anchor attachments. Press downward and rearward firmly in the center of the child restraint with your knee to compress the vehicle seat cushion and seatback while tightening the webbing of the anchor attachments.
- 5. Tighten the tether strap according to the manufacturer's instructions to remove any slack.



Forward-facing — step 6

6. After attaching the child restraint, test it before you place the child in it. Push it from side to side while holding the child restraint near the LATCH attachment path. The child restraint should not move more than 1 inch (25 mm). from side to side. Try to tug it forward and check to see if the LATCH attachment holds the restraint in place. If the restraint is not secure, tighten the LATCH attachment as necessary, or put the restraint in another seat and test it again. You may need to try a different child restraint. Not all child restraints fit in all types of vehicles.

Check to make sure the child restraint. is properly secured prior to each use. If the child restraint is loose, repeat steps 1 through 6.



#### Installing top tether strap

The child restraint top tether strap must be used when installing the child restraint with the LATCH lower anchor attachments

First, secure the child restraint with the LATCH lower anchors (rear outboard seat positions only).

- 1. Flip up the anchor cover from the anchor point which is located directly behind the child restraint.
- 2. Position the top tether strap over the top of the seatback.
- 3. Secure the tether strap to the tether anchor point on the rear parcel shelf.

4. Refer to the appropriate child restraint installation procedure steps earlier in this section before tightening the tether strap.

If you have any questions when installing a top tether strap, consult a GT-R certified NISSAN dealer for details.

#### FORWARD-FACING CHILD RE-STRAINT INSTALLATION USING THE **SEAT BELTS**

## **WARNING**

The three-point seat belt with Automatic Locking Retractor (ALR) must be used when installing a child restraint. Failure to use the ALR mode will result in the child restraint not being properly secured. The restraint could tip over or be loose and cause injury to a child in a sudden stop or collision. Also, it can change the operation of the front passenger air bag. See "Front passenger air bag and status light" later in this section.



Forward-facing (front passenger seat) — step 1 Refer to all Warnings and Cautions in the "Child safety" and "Child restraints" sections before installing a child restraint.

Do not use the lower anchors if the combined weight of the child and the child restraint exceeds 65 lbs (29.5 kg). If the combined weight of the child and the child restraint is greater than 65 lbs (29.5 ka), use the vehicle's seat belt (not the lower anchors) to install the child restraint. Be sure to follow the child restraint manufacturer's instructions for installation.

Follow these steps to install a forwardfacing child restraint using the vehicle seat belt in the rear seats or in the front passenger seat:

- If you must install a child restraint in the front seat, it should be placed in a forward-facing direction only. Move the seat to the rearmost position. Child restraints for infants must be used in the rear-facing direction and, therefore, must not be used in the front seat.
- Position the child restraint on the seat. Always follow the child restraint manufacturer's instructions.

The back of the child restraint should be secured against the vehicle seatback.

If the seating position is interfering with the proper child restraint fit, try another seating position or a different child restraint.



#### Forward-facing - step 3

3. Route the seat belt tongue through the child restraint and insert it into the buckle until vou hear and feel the latch engage. Be sure to follow the child restraint manufacturer's instructions for belt routing.

If the child restraint is equipped with a top tether strap, route the top tether strap and secure the tether strap to the tether anchor point. ( 译 "Installing top tether strap" page 1-30) Do not install child restraints that require the use of a top tether strap in seating positions that do not have a top tether anchor.



Forward-facing — step 4

4. Pull the shoulder belt until the belt is fully extended. At this time, the seat belt retractor is in the Automatic Locking Retractor (ALR) mode (child restraint mode). It reverts to Emergency Locking Retractor (ELR) mode when the seat belt is fully retracted.



Forward-facing — step 5

Allow the seat belt to retract. Pull up on the shoulder belt to remove any slack in the belt.



Forward-facing - step 6

- Remove any additional slack from the seat belt; press downward and rearward firmly in the center of the child restraint with your knee to compress the vehicle seat cushion and seatback while pulling up on the seat belt.
- 7. Tighten the tether strap according to the manufacturer's instructions to remove any slack.



Forward-facing — step 8

- 8. After attaching the child restraint, test it before you place the child in it. Push it from side to side while holding the child restraint near the seat belt path. The child restraint should not move more than 1 inch (25 mm), from side to side. Try to tug it forward and check to see if the belt holds the restraint in place. If the restraint is not secure, tighten the seat belt as necessary, or put the restraint in another seat and test it again. You may need to try a different child restraint. Not all child restraints fit in all types of vehicles.
- Check to make sure the child restraint is properly secured prior to each use. If

the seat belt is not locked, repeat steps 2 through 8.



Forward-facing - step 10

10. If the child restraint is installed in the front passenger seat, place the ignition switch in the ON position. The front passenger air bag status light should illuminate. If this light is not illuminated, see "Front passenger air bag and status light" in this section. Move the child restraint to another seating position. It is recommended you have the system checked by a GT-R certified NISSAN dealer.

After the child restraint is removed and the seat belt is fully retracted, the ALR mode (child restraint mode) is canceled.



#### Installing top tether strap

The child restraint top tether strap must be used when installing the child restraint with the seat belts.

First, secure the child restraint with the seat belt.

- Flip up the anchor cover from the anchor point which is located directly behind the child restraint.
- 2. Position the top tether strap over the top of the seatback.
- Secure the tether strap to the tether anchor point on the rear parcel shelf.
- Refer to the appropriate child restraint installation procedure steps earlier in

this section before tightening the tether strap.

If you have any questions when installing a top tether strap, it is recommended you consult a GT-R certified NISSAN dealer for details.

#### **BOOSTER SEATS**

#### Precautions on booster seats

# **WARNING**

If a booster seat and seat belt are not used properly, the risk of a child being injured in a sudden stop or collision greatly increases:

- Make sure the shoulder portion of the belt is away from the child's face and neck and the lap portion of the belt does not cross the stomach.
- Make sure the shoulder belt is not behind the child or under the child's arm.
- A booster seat must only be installed in a seating position that has a lap/shoulder belt.



Booster seats of various sizes are offered by several manufacturers. When selecting any booster seat, keep the following points in mind:

- Choose only a booster seat with a label certifying that it complies with Federal Motor Vehicle Safety Standard 213 or Canadian Motor Vehicle Safety Standard 213.
- Check the booster seat in your vehicle to be sure it is compatible with the vehicle's seat and seat belt system.



Always follow all recommended procedures.



- Make sure the child's head will be properly supported by the booster seat or vehicle seat. The seatback must be at or above the center of the child's ears. For example, if a low back booster seat (1) is chosen, the vehicle seatback must be at or above the center of the child's ears. If the seatback is lower than the center of the child's ears, a high back booster seat ② should be used.
- If the booster seat is compatible with your vehicle, place your child in the booster seat and check the various adjustments to be sure the booster seat is compatible with your child.

All U.S. states and Canadian provinces or territories require that infants and small children be restrained in an approved child restraint at all times while the vehicle is being operated.

The instructions in this section apply to booster seat installation in the rear seats or the front passenger seat.

#### **Booster seat installation**

# **WARNING**

To avoid injury to child, do not use the lap/shoulder belt Automatic Locking Retractor (ALR) mode when using a booster seat with the seat belts.

Refer to all Warnings and Cautions in the "Child safety", "Child restraints" and "Booster seats" sections earlier in this section before installing a child restraint.

Follow these steps to install a booster seat in the rear seat or in the front passenger seat:



- 1. If you must install a booster seat in the front seat, move the seat to the rearmost position.
- 2. Position the booster seat on the seat. Only place it in a forward-facing direction. Always follow the booster seat manufacturer's instructions.



#### Outboard position

- 3. The booster seat should be positioned on the vehicle seat so that it is stable. If the seating position is interfering with the proper booster seat fit, try another seating position or a different booster seat.
- 4. Position the lap portion of the seat belt low and snug on the child's hips. Be sure to follow the booster seat manufacturer's instructions for adjusting the belt routing.
- 5. Pull the shoulder belt portion of the seat belt toward the retractor to take up extra slack. Be sure the shoulder belt is positioned across the top, middle portion of the child's shoulder.

Be sure to follow the booster seat manufacturer's instructions for adjusting the belt routing.



Front seat

6. Follow the warnings, cautions and instructions for properly fastening a seat belt. ( 译 "Three-point type seat belt with retractor" page 1-9)



7. If the booster seat is installed in the front passenger seat, push the ignition switch to the ON position. The front passenger air bag status light may or may not illuminate depending on the size of the child and the type of booster seat used. (译 "Front passenger air bag and status light" page 1-42)

#### SUPPLEMENTAL RESTRAINT SYSTEM

#### PRECAUTIONS ON SUPPLEMENTAL RESTRAINT SYSTEM

This Supplemental Restraint System (SRS) section contains important information concerning the following systems:

- Driver and passenger supplemental front-impact air bag (NISSAN Advanced Air Bag System)
- Front seat-mounted side-impact supplemental air bag
- Roof-mounted curtain side-impact and rollover supplemental air bag
- Seat belt pretensioner

Supplemental front-impact air bag system: The NISSAN Advanced Air Bag System can help cushion the impact force to the head and chest of the driver and front passenger in certain frontal collisions.

Front seat-mounted side-impact sup-

plemental air bag system: This system

can help cushion the impact force to the chest area of the driver and front passenger in certain side impact collisions. The side air bags are designed to inflate on the side where the vehicle is impacted. Roof-mounted curtain side-impact and rollover supplemental air bag system: This system can help cushion the impact force to the head of occupants in the front seating positions in certain side impact or rollover collisions. In a side impact, the curtain air bags are designed to inflate on the side where the vehicle is impacted. In a rollover, curtain air bags on both sides are designed to inflate and remain inflated for a short time.

Curtain air bags are also designed to inflate in certain types of rollover collisions or near rollovers. As a result, certain vehicle movements may cause the curtain air bags to inflate.

These supplemental restraint systems are designed to supplement the crash protection provided by the driver and passenger seat belts and are not a substitute for them. Seat belts should always be correctly worn and the occupant seated a suitable distance away from the steering wheel, instrument panel and door finishers. ( FF "Seat belts" page 1-6)

The supplemental air bags operate only when the ignition switch is in the ON position.

After pushing the ignition switch to the ON position, the supplemental air bag warning light illuminates. The supplemental air bag warning light will turn off after about 7 seconds if the systems are operational.





Sit upright and well back.





Sit upright and well back.

# **WARNING**

- The front air bags ordinarily will not inflate in the event of a side impact, rear impact, rollover, or lower severity frontal collision. Always wear your seat belts to help reduce the risk or severity of injury in various kinds of accidents.
- The front passenger air bag will not inflate if the passenger air bag status light is lit or if the front passenger seat is unoccupied.
   "Front passenger air bag and status light" page 1-42)
- The seat belts and the front air bags are most effective when you are sitting well back and upright in the seat. The front air bags inflate with great force. Even with the NISSAN Advanced Air Bag System, if you are unrestrained, leaning forward, sitting sideways or out of position in any way, you are at greater risk of injury or death in a crash. You may also receive serious or fatal injuries from the front air bag if you are up against it when it inflates. Always sit back against the seat-

back and as far-away as practical from the steering wheel or instrument panel. Always use the seat belts.

- The driver and front passenger seat belt buckles are equipped with sensors that detect if the seat belts are fastened. The Advanced Air Bag System monitors the severity of a collision and seat belt usage then inflates the air bags as needed. Failure to properly wear seat belts can increase the risk or severity of injury in an accident.
- The front passenger seat is equipped with an occupant classification sensor (pattern sensor) that turns the front passenger air bag OFF under some conditions. This sensor is only used in this seat. Failure to be properly seated and wearing the seat belt can increase the risk or severity of injury in an accident.
   Front passenger air bag and status light" page 1-42)
- Keep hands on the outside of the steering wheel. Placing them inside the steering wheel rim could increase the risk of hand injury if

the supplemental front air bag inflates.













# **WARNING**

- Never let children ride unrestrained or extend their hands or face out of the window. Do not attempt to hold them in your lap or arms. Some examples of dangerous riding positions are shown in the illustrations.
- Children may be severely injured or killed when the front air bags, side air bags or curtain air bags inflate if they are not properly restrained. Pre-teens and children should be properly restrained in the rear seat, if possible.
- Even with the NISSAN Advanced Air Bag System, never install a rear- facing child restraint in the front seat. An inflating supplemental front air bag could seriously injure or kill your child. ( property "Child restraints" page 1-15)



Do not lean against doors or windows.





Do not lean against doors or windows.




#### **WARNING**

Front seat-mounted side-impact supplemental air bags and roofmounted curtain side-impact and rollover supplemental air bags:

- The side air bags ordinarily will not inflate in the event of a front impact, rear impact, rollover, or lower severity side collision. Always wear your seat belts to help reduce the risk or severity of injury in various kinds of accidents.
- The curtain air bags ordinarily will not inflate in the event of a front impact, rear impact, or lower severity side collision. Always wear your seat belts to help reduce the risk or severity of injury in various kinds of accidents.
- The seat belts, side air bags and curtain air bags are most effective when you are sitting well back and upright in the seat. The side air bags and curtain air bags inflate with great force. Do not allow anyone to place their hand, leg or face near the side air bag

on the side of the seatback of the front seat or near the side roof rails. Do not allow anyone sitting in the front seat to extend their hand out of the window or lean against the door. Some examples of dangerous riding positions are shown in the previous illustrations.

- · When sitting in the rear seat, do not hold onto the seatback of the front seat. If the supplemental side air bag inflates, you may be seriously injured. Be especially careful with children, who should always be properly restrained. Some examples of dangerous riding positions are shown in the illustrations.
- Do not use seat covers on the front seatbacks. They may interfere with side air bag inflation.



- Crash zone sensor
- Supplemental front-impact air bag modules (NISSAN Advanced Air Bag System)
- Front seat-mounted side-impact supplemental air bags
- Roof-mounted curtain side-impact and rollover supplemental air bags
- Roof-mounted curtain side-impact and rollover supplemental air bag inflators
- 6. Pressure sensors in door
- 7. Occupant classification sensor (pattern sensor)
  - Occupant classification system control unit

- Satellite sensors
- 10. Seat belt pretensioners
- 11. Air bag Control Unit (ACU)

# NISSAN ADVANCED AIR BAG SYSTEM (front seats)

This vehicle is equipped with the NISSAN Advanced Air Bag System for the driver and front passenger seats. This system is designed to meet certification requirements under U.S. regulations. It is also permitted in Canada. All of the information, cautions and warnings in this manual apply and must be followed.

The driver supplemental front-impact air bag is located in the center of the steering wheel. The front passenger supplemental front-impact air bag is mounted in the instrument panel above the glove box. The front air bags are designed to inflate in higher severity frontal collisions, although they may inflate if the forces in another type of collision are similar to those of a higher severity frontal impact. They may not inflate in certain frontal collisions. Vehicle damage (or lack of it) is not always an indication of proper front air bag operation.

The NISSAN Advanced Air Bag System has dual stage air bag inflators. The system monitors information from the Air bag

Control Unit (ACU), seat belt buckle sensors and the occupant classification sensor (pattern sensor). Inflator operation is based on the severity of a collision and seat belt usage for the driver. For the front passenger, the occupant classification sensor is also monitored. Based on information from the sensors, only one front air bag may inflate in a crash, depending on the crash severity and whether the front occupants are belted or unbelted. Additionally, the front passenger air bag may be automatically turned OFF under some conditions, depending on the information provided by the occupant classification sensor. If the front passenger air bag is OFF, the passenger air bag status light will be illuminated (if the seat is unoccupied, the light will not be illuminated, but the air bag will be off). One front air bag inflating does not indicate improper performance of the system. ( pr "Front passenger air bag and status light" page 1-42)

If you have any questions about your air bag system, it is recommended you contact NISSAN or a GT-R certified NISSAN dealer. If you are considering modification of your vehicle due to a disability, you may also contact NISSAN. Contact information is contained in the front of this Owner's Manual.

When a front air bag inflates, a fairly loud noise may be heard, followed by release of smoke. This smoke is not harmful and does not indicate a fire. Care should be taken not to inhale it, as it may cause irritation and choking. Those with a history of a breathing condition should get fresh air promptly.

Front air bags, along with the use of seat belts, help to cushion the impact force on the head and chest of the front occupants. They can help save lives and reduce serious injuries. However, an inflating front air bag may cause facial abrasions or other injuries. Front air bags do not provide restraint to the lower bodv.

Even with NISSAN advanced air bags, seat belts should be correctly worn and the driver and passenger seated upright as far as practical away from the steering wheel or instrument panel. The front air bags inflate quickly in order to help protect the front occupants. Because of this, the force of the front air bag inflating can increase the risk of injury if the occupant is too close to, or is against, the air bag module during inflation.

The front air bags deflate quickly after a collision.

The front air bags operate only when the ignition switch is in the ON position. After pushing the ignition switch to the ON position, the supplemental air bag warning light illuminates. The supplemental air bag warning light will turn off after about 7 seconds if the system is operational.



Front passenger air bag status light

# Front passenger air bag and status liaht

# **WARNING**

The front passenger air bag is designed to automatically turn OFF under some conditions. Read this section carefully to learn how it operates. Proper use of the seat, seat belt and child restraints is necessary for most effective protection. Failure to follow all instructions in this manual concerning the use of seats, seat belts and child restraints can increase the risk or severity of injury in an accident.

#### Status light:

The front passenger air bag status light is located on the center instrument panel. After the ignition switch is placed in the ON position, the front passenger air bag status light on the instrument panel illuminates for about 7 seconds and then turns off or illuminates depending on the front passenger seat occupied status. The light operates as follows:

- Unoccupied passenger seat: The light is OFF and the front passenger air bag is OFF and will not inflate in a crash.
- Passenger seat occupied by a small adult, child or child restraint as outlined in this section: The light illuminates to indicate that the front passenger air bag is OFF and will not inflate in a crash.
- Occupied passenger seat and the passenger meets the conditions outlined in this section: The light is OFF to indicate that the front passenger air bag is operational.

#### Front passenger air bag:

The front passenger air bag is designed to automatically turn OFF when the vehicle is operated under some conditions as described below as permitted by U.S. regulations. If the front passenger air bag is OFF, it will not inflate in a crash. The driver air bag and other air bags in your vehicle are not part of this system.

The purpose of the regulation is to help reduce the risk of injury or death from an inflating air bag to certain front passenger seat occupants, such as children, by requiring the air bag to be automatically turned OFF.

The occupant classification sensor (pattern sensor) is in the front passenger seat cushion and is designed to detect an occupant and objects on the seat. For example, if a child is in the front passenger seat, the Advanced Air Bag System is designed to turn the passenger air bag OFF in accordance with the regulations. Also, if a child restraint of the type specified in the regulations is on the seat, the occupant classification sensor can detect it and cause the air bag to turn OFF.

Front passenger seat adult occupants who are properly seated and using the seat belt as outlined in this manual should not cause the passenger air bag

to be automatically turned OFF. For small adults it may be turned OFF, however, if the occupant does not sit in the seat properly (for example, by not sitting upright, by sitting on an edge of the seat, or by otherwise being out of position), this could cause the sensor to turn the air bag OFF. Always be sure to be seated and wearing the seat belt properly for the most effective protection by the seat belt and supplemental air bag.

NISSAN recommends that pre-teens and children be properly restrained in a rear seat. NISSAN also recommends that appropriate child restraints and booster seats be properly installed in a rear seat. If this is not possible, the occupant classification sensor is designed to operate as described above to turn the front passenger air bag OFF for specified child restraints. Failing to properly secure child restraints and to use the Automatic Locking Retractor (ALR) mode (child restraint mode) may allow the restraint to tip or move in an accident or sudden stop. This can also result in the passenger air bag inflating in a crash instead of being OFF. ( Tag "Child restraints" page 1-15)

If the front passenger seat is not occupied, the passenger air bag is designed not to inflate in a crash. However, heavy objects placed on the seat could result in

air bag inflation, because of the object being detected by the occupant classification sensor. Other conditions could also result in air bag inflation, such as if a child is standing on the seat, or if two children are on the seat, contrary to the instructions in this manual. Always be sure that you and all vehicle occupants are seated and restrained properly.

Using the passenger air bag status light, you can monitor when the front passenger air bag is automatically turned OFF with the seat occupied. The light will not illuminate when the front passenger seat is unoccupied.

If an adult occupant is in the seat but the passenger air bag status light is illuminated (indicating that the air bag is OFF), it could be that the person is a small adult, or is not sitting on the seat properly.

If a child restraint must be used in the front seat, the passenger air bag status light may or may not be illuminated, depending on the size of the child and the type of child restraint being used. If the passenger air bag status light is not illuminated (indicating that the air bag might inflate in a crash), it could be that the child restraint or seat belt is not being used properly. Make sure that the child restraint is installed properly, the seat belt is used properly and the occupant is positioned properly. If the passenger air bag status light is still not illuminated, reposition the occupant or child restraint in a rear seat.

If the passenger air bag status light will not illuminate even though you believe that the child restraint, the seat belts and the occupant are properly positioned, the system may be sensing an unoccupied seat (in which case the air bag is OFF). Your GT-R certified NISSAN dealer can check that the system is OFF by using a special tool. However, until you have confirmed with your dealer that your air bag is working properly, reposition the occupant or child restraint in a rear seat. The NISSAN Advanced Air Bag System and passenger air bag status light will take a few seconds to register a change in the passenger seat status. However, if the seat becomes unoccupied, the air bag status light will remain off.

If a malfunction occurs in the front passenger air bag system, the supplemental air bag warning light 🧩 , located in the meter and gauges area will blink. It is recommended you have the system checked by a GT-R certified NISSAN dealer.

## Other supplemental front air bag precautions

#### **WARNING**

- Do not place any objects on the steering wheel pad or on the instrument panel. Also, do not place any objects between any occupant and the steering wheel or instrument panel. Such objects may become dangerous projectiles and cause injury if the front air bag inflates.
- Do not place objects with sharp edges on the seat. Also, do not place heavy objects on the seat that will leave permanent impressions in the seat. Such objects can damage the seat or occupant classification sensor (pattern sensor). This can affect the operation of the air bag system and result in serious personal injury.
- Do not use water or acidic cleaners (hot steam cleaners) on the seat. This can damage the seat or occupant classification sensor. This can also affect the operation of the air bag system and result in

serious personal injury.

- Immediately after inflation, several front air bag system components will be hot. Do not touch them; you may severely burn vourself.
- No unauthorized changes should be made to any components or wiring of the supplemental air bag system. This is to prevent accidental inflation of the supplemental air bag or damage to the supplemental air bag system.
- Do not make unauthorized changes to your vehicle's electrical system, suspension system or front end structure. This could affect proper operation of the front air bag system.
- Tampering with the supplemental air bag system may result in serious personal injury. Tampering includes changes to the steering wheel and the instrument panel assembly by placing material over the steering wheel pad and above the instrument panel or by installing additional trim material around the air bag system.

- Modifying or tampering with the front passenger seat may result in serious personal injury. For example, do not change the front seats by placing material on the seat cushion or by installing additional trim material, such as seat covers, on the seat that is not specifically designed to assure proper air bag operation. Additionally, do not stow any objects under the front passenger seat or the seat cushion and seatback. Such objects may interfere with the proper operation of the occupant classification sensor.
- No unauthorized changes should be made to any components or wiring of the seat belt system. This may affect the front air bag system. Tampering with the seat belt system may result in serious personal injury.
- Work on and around the front air bag system should be done by a GT-R certified NISSAN dealer. Installation of electrical equipment should also be done by a GT-R certified NISSAN dealer. The Supplemental Restraint System (SRS)

wiring harnesses' should not be modified or disconnected. Unauthorized electrical test equipment and probing devices should not be used on the air bag system.

 A cracked windshield should be replaced immediately by a qualified repair facility. A cracked windshield could affect the function of the supplemental air bag system.

# \* The SRS wiring harness connectors are yellow and orange for easy identification.

When selling your vehicle, we request that you inform the buyer about the front air bag system and guide the buyer to the appropriate sections in this Owner's Manual.



## FRONT SEAT-MOUNTED SIDE-IM-PACT SUPPLEMENTAL AIR BAG AND ROOF-MOUNTED CURTAIN SIDE-IMPACT AND ROLLOVER SUPPLEMENTAL AIR BAG SYSTEMS

The front side air bags are located in the outside of the seatback of the front seats. The curtain air bags are located in the side roof rails. All of the information, cautions and warnings in this manual apply and must be followed. The side air bags and curtain air bags are designed to inflate in higher severity side collisions, although they may inflate if the forces in another type of collision are similar to

those of a higher severity side impact. They are designed to inflate on the side where the vehicle is impacted. They may not inflate in certain side collisions.

Curtain air bags are also designed to inflate in certain types of rollover collisions or near rollovers. As a result, certain vehicle movements may cause the curtain air bags to inflate.

Vehicle damage (or lack of it) is not always an indication of proper side air bag and curtain air bag operation.

When the side air bags and curtain air bags inflate, a fairly loud noise may be heard, followed by release of smoke. This smoke is not harmful and does not indicate a fire. Care should be taken not to inhale it, as it may cause irritation and choking. Those with a history of a breathing condition should get fresh air promptly.

Front side air bags, along with the use of seat belts, help to cushion the impact force on the chest of the front occupants. Curtain air bags help to cushion the impact force to the head of occupants in the front seating positions. They can help save lives and reduce serious injuries. However, an inflating side air bag and curtain air bag may cause abrasions or other injuries. Side air bags and curtain air bags do not provide restraint to the lower

body.

The seat belts should be correctly worn and the driver and passenger seated upright as far as practical away from the side air bags. The side air bags and curtain air bags inflate quickly in order to help protect occupants. Because of this, the force of the side air bags and curtain air bags inflating can increase the risk of injury if the occupant is too close to, or is against, these air bag modules during inflation. In a rollover, the curtain air bags on both sides are designed to inflate. Under both side-impact situations, the curtain air bags will remain inflated for a short period of time.

The side air bags and curtain air bags operate only when the ignition switch is in the ON position.

After placing the ignition switch in the ON position, the supplemental air bag warning light illuminates. The air bag warning light will turn off after about 7 seconds if the systems are operational.

# **WARNING**

 Do not place any objects near the seatback of the front seats. Also, do not place any objects (an umbrella, bag, etc.) between the door finisher and the front seat. Such objects may become dangerous projectiles and cause injury if a side air bag inflates.

- Right after inflation, several side air bag and curtain air bag system components will be hot. Do not touch them; you may severely burn yourself.
- No unauthorized changes should be made to any components or wiring of the side air bags and curtain air bags. This is to prevent damage to or accidental inflation of the side air bag and curtain air bag systems.
- Do not make unauthorized changes to your vehicle's electrical system, suspension system or side panel. This could affect proper operation of the side air bag and curtain air bag systems.
- Tampering with the side air bag system may result in serious personal injury. For example, do not change the front seat by placing material near the seatback or by installing additional trim material, such as seat covers, around the side air bags.
- Work around and on the side air

bag and curtain air bag systems should be done by a GT-R certified NISSAN dealer. Installation of electrical equipment should also be done by a GT-R certified NISSAN dealer. The SRS wiring harnesses' should not be modified or disconnected. Unauthorized electrical test equipment and probing devices should not be used on the side air bag and curtain air bag systems.

\* The SRS wiring harness connectors are yellow and orange for easy identification.

When selling your vehicle, we request that you inform the buyer about the side air bag and curtain air bag systems and guide the buyer to the appropriate sections in this Owner's Manual.

#### SEAT BELTS WITH PRETEN-SIONERS (front seats)

# **MARNING**

 The pretensioners cannot be reused after activation. They must be replaced together with the retractor and buckle as a unit.

- If the vehicle becomes involved in a collision but the pretensioner is not activated, it is recommended to have the pretensioner system checked and, if necessary, replaced by a GT-R certified NISSAN dealer.
- No unauthorized changes should be made to any components or wiring of the pretensioners. This is to prevent damage to or accidental activation of the pretensioners. Tampering with the pretensioner system may result in serious personal injury.
- Work around and on the pretensioners should be done by a GT-R certified NISSAN dealer. Installation of electrical equipment should also be done by a GT-R certified NISSAN dealer. Unauthorized electrical test equipment and probing devices should not be used on the pretensioners.
- If you need to dispose of a pretensioner or scrap the vehicle, it is recommended you contact a GT-R certified NISSAN dealer. Incorrect disposal procedures could cause personal injury.

The pretensioner system may activate with the supplemental air bag system in certain types of collisions. Working with the seat belt retractor, it helps tighten the seat belt when the vehicle becomes involved in certain types of collisions, helping to restrain front seat occupants.

The pretensioner is encased with the seat belt retractor. These seat belts are used the same way as conventional seat belts. When a pretensioner activates, smoke is released and a loud noise may be heard. The smoke is not harmful, and it does not indicate a fire. Care should be taken not to inhale it as it may cause irritation and choking. Those with a history of a breathing condition should get fresh air promptly.

After pretensioner activation, load limiters allow the seat belt to release webbing (if necessary) to reduce forces against the chest.

The supplemental air bag warning light is used to indicate malfunctions in the pretensioner system. (See Supplemental air bag warning light page 1-48 for more details.) If the operation of the supplemental air bag warning light indicates there is a malfunction, it is recommended you have the system checked by a GT-R certified NISSAN dealer.

When selling your vehicle, we request that you inform the buyer about the pretensioner system and guide the buyer to the appropriate sections in this Owner's Manual.



# **WARNING**

Do not use a rear-facing child restraint on a seat protected by an air bag in front of it. If the air bag deploys, it may cause serious injury or death.



#### SUPPLEMENTAL AIR BAG WARNING **LABELS**

Warning labels about the supplemental front-impact air bag are placed in the vehicle as shown in the illustration.

#### 1) SRS air bag

The warning labels are located on the surface of the sun visors.

#### SUPPLEMENTAL AIR BAG WARNING LIGHT

The supplemental air bag warning light, displaying 🐉 in the meter, monitors the circuits for the air bag systems, pretensioners and all related wirings.

When the ignition switch is in the ON position, the supplemental air bag warning light illuminates for about 7 seconds and then turns off. This means the SRS air. bag systems are operational.

If any of the following conditions occur, the air bag and/or pretensioner systems need servicina:

- The supplemental air bag warning light remains on after approximately 7 seconds.
- The supplemental air bag warning light flashes intermittently.
- The supplemental air bag warning light does not come on at all.

Under these conditions, the air bag and/ or pretensioner systems may not operate properly. They must be checked and repaired. It is recommended you take your vehicle to the nearest GT-R certified NISSAN dealer.

# **WARNING**

If the supplemental air bag warning light is on, it could mean that the front air bag, side air bag, curtain air bag and/or pretensioners will not operate in an accident. To help avoid injury to yourself or others, have your vehicle checked by a dealer as soon as possible.

#### REPAIR AND REPLACEMENT PRO-CEDURE

The front air bags, side air bags, curtain air bags and pretensioners are designed to activate on a one-time-only basis. As a reminder, unless it is damaged, the supplemental air bag warning light will remain illuminated after inflation has occurred. Repair and replacement of these systems should be done only by a GT-R certified NISSAN dealer.

When maintenance work is required on the vehicle, the front air bags, side air bags, curtain air bags, pretensioners and related parts should be pointed out to the person conducting the maintenance. The ignition switch should always be in the LOCK position when working under the hood or inside the vehicle.

# **MARNING**

 Once a front air bag, side air bag, or curtain air bag has inflated, the air bag module will not function again and must be replaced. Additionally, the activated pretensioners must also be replaced. The air bag module and pretensioners should be replaced by a GT-R certified NISSAN dealer. The

- air bag module and pretensioners cannot be repaired.
- The front air bag, side air bag, curtain air bag and the pretensioner should be inspected by a GT-R certified NISSAN dealer if there is any damage to the front end or side portion of the vehicle.
- If you need to dispose of a supplemental air bag or a pretensioner or scrap the vehicle, contact a GT-R certified NISSAN dealer. Incorrect disposal procedures could cause personal injury.

#### **MEMO**

# 2 Instruments and controls

Cockpit	2-4	Warning lights, indicator lights and	
Instrument panel	2-5	audible reminders	2-26
Meters and gauges	2-6	Checking lights	
Speedometer		Warning/indicator lights (red)	2-26
Odometer/twin trip odometer	2-7	Warning/indicator lights (yellow)	2-29
Tachometer	2-8	Warning/indicator lights (other)	2-34
Engine coolant temperature gauge	2-8	Audible reminders	2-34
Fuel gauge	2-9	Warning display	2-36
Transmission position indicator		Engine oil low pressure warning	2-37
Upshift indicator		Engine system warning	2-37
Instrument brightness control	2-12	Shift lever position warning	2-37
Vehicle information display	2-13	Reverse warning	
Engine oil level display	2-13	Transmission system warning	2-38
Transmission system check display	2-15	Transmission oil high	
Drive computer	2-16	temperature warning	2-38
Current fuel consumption	2-16	Transmission clutch high	2.70
Vehicle speed	2-17	temperature warning	
Cruise control	2-17	Parking brake release warning	
Average fuel consumption and speed	2-17	Low brake fluid warning	
Elapsed time and trip odometer	2-18	Anti-lock Braking System (ABS) warning Vehicle Dynamic Control (VDC)	2-40
Distance to empty	2-18	system warning	2-40
Outside air temperature	2-19	AWD clutch high temperature warning	
Setting (drive computer)		Front/rear tire size discrepancy warning	
Warning (drive computer)	2-24	AWD system warning	
		AVV System Warring	1


Low tire pressure warning 2-42	2 Turn signal switch	2-57
Run-flat tire warning 2-42		
Tire Pressure Monitoring System	Heated seats	2-58
(TPMS) warning 2-42	Turning on the heaters	2-58
Cruise control system warning 2-43		
Low fuel warning 2-43	Sonar system off switch	2-59
Door/trunk open warning 2-44	Exhaust sound control switch (if	
Headlight system warning 2-44	so equipped)	2-59
Low washer fluid warning 2-44	4 Power outlets	2-60
No key warning 2-45	E-Call (SOS) Button	2-61
Operation displays 2-45		2-61
Engine start operation indicator 2-46	Storage	2-63
Shift "P" warning 2-46	Cup holders	2-63
"PUSH" warning 2-46	Sunglasses holder	2-64
Steering lock release	Door pocket	2-65
malfunction indicator 2-47		
Intelligent Key insertion indicator 2-47		
Intelligent Key removal indicator 2-47	7 Coat hooks	2-66
Intelligent Key battery	Windows	2-67
discharge indicator 2-48	Power windows	2-67
Security systems 2-48	Interior lights	2-69
Vehicle security system 2-48		
NISSAN Vehicle Immobilizer System 2-50	Interior light control switch	
Wiper and washer switch 2-51	1 Vanity mirror lights	
Using the wipers 2-51	1 HomeLink® Universal Transceiver	
Using the washer 2-52	Programming HomeLink®	2-72

Rear window defroster switch ...... 2-52

Operating the HomeLink® Universal	
Transceiver	2-74
Programming troubleshooting	2-74
Clearing the programmed information	2-74

Reprogramming a single	
HomeLink® button	2-74
f your vehicle is stolen	2-75

#### COCKPIT




- Headlight and turn signal switch (P.2-53)
- 2. Paddle shifters (P.5-15)
- Steering-wheel-mounted controls (left side)\*
- 4. Meters and gauges (P.2-6)
- Steering-wheel-mounted controls (right side)

- MRK (Mark) switch\*
- Cruise control (P.5-35)
- . Wiper and washer switch (P.2-51)
- 7. VDC, transmission and suspension set up switches (P.5-25)
- 8. Trunk lid release switch (P.3-20)

- 9. Hood release handle (P.3-18)
- 10. Intelligent Key port (P.5-12)
- 11. Sonar system OFF switch (P.5-50)
- 12. Tilting/telescopic steering wheel lever (P.3-26)
- 13. Horn (P.2-58)
- 14. Exhaust sound control switch (if so equipped) (P.5-59)
- 15. Push-button ignition switch (P.5-10)
- 16. Shift lever (P.5-15)
- 17. Parking brake (P.5-34, P.5-46)
- \*: Refer to the separate Multi Function Display Owner's Manual.

#### 2-4 Instruments and controls

#### **INSTRUMENT PANEL**



- Outside mirror control switch (P.3-28)
- Rear window defroster switch (P.2-52)
- 3. CD slot\*
- Heater and air conditioner (P.4-10)
- Touch screen display\*
- Glove box (P.2-65)

- Fuse box cover (P.8-22)
- Power outlet (P.2-60)
- Display Commander\*
- 10. Front passenger air bag status light (P.1-42)
- Hazard warning flasher switch (P.6-2)

- Trunk release power cancel switch (P.3-21)
- Refer to the separate Multi Function Display Owner's Manual.

#### **METERS AND GAUGES**



- 1. Trip A/B reset switch (P.2-7)
- 2. Speedometer (P.2-7)
- 3. Tachometer (P.2-8)/Upshift indicator (P.2-10)
- 4. Transmission position indicator (P.2-10)
- 5. Engine coolant temperature gauge (P.2-8)

- 6. ENTER switch (P.2-16)
- Instrument brightness control switch (P.2-12)
- 8. Vehicle information display (P.2-13)
- 9. Odometer/twin trip odometer (P.2-7)
- 10. Fuel gauge (P.2-9)
- 11. NEXT switch (P.2-16)

#### NOTE:

- Meters and gauges will illuminate when the ignition switch is pushed to the ON position.
- The needle indicators may move slightly after the ignition switch is pushed to the OFF position. This does not indicate that there is a malfunction.



liquid may cause the system to malfunction.



#### **SPEEDOMETER**

The speedometer indicates the vehicle speed.

### **A** CAUTION

- For cleaning, use a soft cloth, dampened with water. Never use a rough cloth, alcohol, benzine, thinner or any kind of solvent or paper towel with a chemical cleaning agent. They will scratch or cause discoloration to the lens.
- Do not spray any liquid such as water on the meter lens. Spraying

### ODOMETER/TWIN TRIP OD-OMETER

The odometer ① indicates the total distance that the vehicle has been driven. The twin trip odometer ② indicates the distance of individual trips.

### Changing the display

Push the TRIP A/B RESET switch to change between trips  $\overline{\bf A}$  and  $\overline{\bf B}.$ 

### Resetting the trip odometer

To reset a trip, display the trip that you want to reset to zero, then push and hold the TRIP A/B RESET switch for more than

1 second.

#### NOTE:

When the battery is disconnected, the memory for trips A and B is erased, and both return to zero.



#### **TACHOMETER**

The tachometer indicates the engine speed in revolutions per minute (rpm). Do not rev the engine into the red zone ①.

### **NOTICE**

When engine speed approaches the red zone, shift to a higher gear or reduce engine speed. Operating the engine in the red zone may cause serious engine damage.



### **ENGINE COOLANT TEMPERATURE GAUGE**

The gauge indicates the engine coolant temperature.

The engine coolant temperature is within the normal range when the gauge needle points within the zone (1) shown in the illustration

The engine coolant temperature varies with the outside air temperature and driving conditions.

#### **NOTICE**

If the gauge indicates engine coolant temperature near the hot (H) end of the normal range, reduce vehicle speed to decrease temperature. If gauge is over the normal range, stop the vehicle as soon as safely possible. If the engine is overheated, continued operation of the vehicle may seriously damage the engine. ( ) "If your vehicle overheats" page 6-8)



#### **FUEL GAUGE**

The gauge indicates the approximate fuel level in the tank

The gauge may move slightly during braking, turning, acceleration, or going up or down hills.

The gauge needle returns to E (Empty) after the ignition switch is pushed to the LOCK position.

### Refill the fuel tank before the gauge registers "E" (Empty).

The low fuel warning will be indicated on the vehicle information display when the fuel tank is getting low. Refuel as soon as it is convenient, preferably before the gauge reaches "E". There will be a small reserve of fuel in the tank when the fuel gauge needle reaches "E". ( >> "Low fuel warning" page 2-43)

The indicates that the fuel-filler door is located on the passenger's side of the vehicle. ( Fruel-filler door" page 3-24)

#### NOTE:

If the vehicle runs out of fuel, the ENGINE Malfunction Indicator Light (MIL) may come on. Refuel as soon as possible. After a few driving trips, the ENGLE light should turn off. If the light remains on after a few driving trips, it is recommended you have the vehicle inspected by a GT-R certified NISSAN dealer.

( To "Malfunction Indicator Light (MIL)" page 2-32)





### TRANSMISSION POSITION INDICA-TOR

The transmission position indicator indicates the gear positions.

The indicator blinks if it is not possible to shift the gear when in the M position.


- Upshift indicator (green)
- Upshift indicator (yellow)
- Upshift indicator (red)

#### **UPSHIFT INDICATOR**

When the upshift indicator is set to on, the indicators on the tachometer will illuminate to help upshift at a constant engine speed from any gear or to warn the driver of over-revving.

The upshift indicator operates only when the shift lever is in the M position. This function consists of two modes that can be selected on the vehicle information display: AUTO setting and MANUAL setting.

MODE	INDICATOR	COLOR	CONDITIONS	
	A CONTRACTOR OF THE PARTY OF TH	No color	Light is off at all times.	
AUTO setting	P. T.	Yellow	Light comes on about 700 RPM before the red zone.	
	E The	Red	Light comes on immediately before the red zone.	
		Green	Light blinks about 500 RPM before the set RPM and comes on at the set RPM.	
MANUAL setting	E Jan	Yellow	Light comes on about 700 RPM before the red zone.	
	E JAS	Red	Light comes on immediately before the red zone.	



### Setting

Push the ignition switch to the ON position. Use the ENTER switch 🔲 and toggle the vehicle information display to show the SETTING screen.

Use the NEXT switch and ENTER

switch to go to ALERT > UPSHIFT. The current status of the upshift indicator will be shown on the UPSHIFT screen. Note that the function is set to AUTO as the factory default setting.

To change the upshift indicator mode, choose SETTING on the UPSHIFT screen. Set one of the following modes by pushing the NEXT switch  $\bigcirc$ , and then push ENTER  $\square$  to complete.

- AUTO
- 3,000 to 6,300 RPM (MANUAL)
- OFF

The number will increase by 100 RPM. To increase the number by 500 RPM, push and hold the NEXT switch 

.

### Example

## When the maximum engine speed is desired:

Set the upshift indicator to AUTO. The yellow indicator illuminates approximately 700 RPM before the red zone, and the red indicator illuminates just before the red zone.

## When the maximum engine torque is desired:

Set the figure at 6,000 RPM. The green indicator starts flashing from approxi-


mately 5,500 RPM and illuminates at 6.000 RPM.

#### When breaking-in the vehicle:

To help avoid high engine speeds during break-in, set the upshift indicator to less than 3,500 RPM. The green indicator starts flashing approximately 500 RPM before the set figure and illuminates from the set figure. ( \*\* "Break-in schedule" page 5-40)

#### NOTE:

- There may be a slight difference between the timing of the upshift indicator illumination and the tachometer indication.
- When the battery terminal is disconnected, the set memory will be erased and the mode returns to the default.



# INSTRUMENT BRIGHTNESS CONTROL

The instrument brightness can be adjusted when the ignition switch is in the ON position. Push the switch to adjust the brightness up ① or down ②. The brightness level is shown on the vehicle information display.

When the headlights are on, the brightness of the interior switches is also adjusted at the same time.

#### NOTE:

- The instrument brightness can be adjusted separately for daytime and nighttime conditions. The adjusted settings are automatically stored.
- When the battery terminal is disconnected, the set memory will be erased and the setting returns to the default.

#### VEHICLE INFORMATION DISPLAY

The vehicle information display can display the following information.

Engine oil level display

page 2-12)

- Transmission system check display
- Instrument brightness control level display (译 "Instrument brightness control"
- Drive computer ( ) Tap "Drive computer" page 2-16)
- Warning display ( \*\* "Warning display" page 2-36)
- Operation display ( 下写 "Operation displays" page 2-45)
- Cruise control display ( TSF "Cruise control" page 5-35)



#### **ENGINE OIL LEVEL DISPLAY**

When the ignition switch is pushed to the ON position, the engine oil status before starting the engine is indicated as illustrated.

#### When the oil level is normal

"OIL LEVEL OK" is displayed. Push the displayed LEVEL switch 
to check the oil level





#### NOTE:

The engine oil level can be displayed after the "OIL LEVEL OK" display turns off or while the engine is started and running. ( Maintenance page 2-21)

#### When the oil level is low

If the message shown above is displayed, the engine oil level is low.

Warm up the engine in a level location. After at least 5 minutes have passed since engine stop, use the engine oil dipstick to check the oil level. ( 738 "Engine oil" page 8-9)

If the oil level is low, it is recommended you have additional engine oil added, or the oil changed, at a GT-R certified NISSAN dealer.

#### **NOTICE**

If the vehicle is in a location that is not level, accurate measurement of the oil level may not be possible. If "OIL LEVEL LOW" is displayed, but the level shown by the oil dipstick is normal, move the vehicle to a level location and stop the engine. After at least 5 minutes have passed, open the driver's door and push the ignition switch back to ON. If the "OIL LEVEL LOW" message appears again, have engine oil added or the oil changed.





### When the oil level sensor malfunction occurs

If the message shown above is displayed, the engine oil level sensor may be malfunctioning.

It is recommended you contact a GT-R certified NISSAN dealer immediately.

## TRANSMISSION SYSTEM CHECK DISPLAY

This is displayed after the engine is started while the transmission system is being checked. It turns off after a few seconds


#### NOTE:

- During the system check, the shift lever cannot be moved out of the position. Operate the shift lever after the system check indicator turns off.
- The shift lever cannot be moved if the shift lever button is pushed while the system check is being

performed, even after the system check is finished. Release the button and push it again to operate the shift lever.

 During winter or at other times when the temperature is extremely low, changes in the hydraulic response characteristics may increase the amount of time that is required for the system check. During the system check, a thudding operating noise may occur or the engine speed may decrease, however this does not indicate that there is a malfunction.

#### **DRIVE COMPUTER**



- 1. ENTER switch 🔲
- . NEXT switch
- 3. Vehicle information display

The drive computer displays the following information:


- Current fuel consumption
- Vehicle speed
- Cruise control
- Average fuel consumption and speed
- Elapsed time and trip computer
- Distance to empty
- Outside air temperature
- Setting

Warning

The vehicle information display ③ can be changed when the ignition switch is in the ON position. Push the ENTER switch ① to change the display.

#### NOTE:

- The cruise control display is shown if cruise control is set. ( procedure "Cruise control" page 5-35)
- The warning display is not shown if there are no conditions to warn the driver.
- Depending on the driving conditions and other factors, the displayed values may differ from the actual values.
- The position of the speedometer needle and the speed shown in the vehicle information display may slightly differ.



#### **CURRENT FUEL CONSUMPTION**

The current fuel economy is displayed when driving.

#### 2-16 Instruments and controls

55 MPH

CRUISE

19.0 MPG 55.0 MPH

#### **VEHICLE SPEED**

This displays the vehicle speed while driving.

#### **CRUISE CONTROL**

This displays the set cruise control status.

### NOTE:

The cruise control display is shown if cruise control is set. ( The "Cruise control" page 5-35)

### **AVERAGE FUEL CONSUMPTION AND SPEED**

This displays the average fuel economy and average vehicle speed beginning from the time when the display was last reset.

To reset the display, push and hold the NEXT switch for more than 1 second. (The average fuel economy and average vehicle speed are reset at the same time.)

#### NOTE:

- "----" is displayed during the first 1/3 mile (500 m) or the first 30 seconds after a reset.
- The values are updated approximately every 30 seconds.

1:00 TIME MILES 34.5

RANGE 123 MILES

### **ELAPSED TIME AND TRIP OD-OMETER**

This displays the elapsed time and trip odometer beginning from the time when the display was last reset.

To reset the display, push and hold the NEXT switch for more than 1 second. (The elapsed time and trip odometer are reset at the same time.)

#### **DISTANCE TO EMPTY**

This displays the approximate distance that the vehicle can be driven based on the amount of fuel remaining in the fuel tank and the actual fuel consumption.

#### NOTE:

- If the fuel level is low, the low fuel warning will be displayed. ( 🎏 "Low fuel warning" page 2-43)
- If the vehicle is not refueled after the low fuel warning appears, the display will change to "----". This change timing may become earlier depending on the driving conditions. This does not indicate that there is a

malfunction.

The values are updated approximately every 30 seconds.



• When the outside air temperature is lower than 37°F (3°C), the low outside temperature warning will be displayed and "ICY" is indicated on the outside air temperature display. ( P "Alert" page 2-20)

#### **OUTSIDE AIR TEMPERATURE**

This displays the outside air temperature.

#### NOTE:

- The outside air temperature may not be displayed correctly in the following cases.
  - The outside air temperature is lower than -22°F (-30°C) or is higher than 131°F (55°C).
  - The vehicle is stopped or is driving at a low speed (less than approximately 12 MPH (20 km/h)).
  - The temperature in the engine compartment is high.



#### NOTE:

- When the battery terminal is disconnected, the set memory will be erased and the settings return to the default.
- Setting is not possible in the following cases.
  - The vehicle is being driven.
  - A warning display is active.
  - The instrument brightness control level display is active.
  - The cruise control status is displayed.



### **SETTING** (drive computer)

This is used to set the alert, maintenance and optional settings.

Use the NEXT switch to select an item, then confirm with the ENTER switch to change to the corresponding setting screen.

To return to the initial setting screen, push and hold the ENTER switch of for more than 1 second.

#### Alert

This function can be used to make settings for the upshift indicator, "time to rest" indicator and low outside temperature warning.

#### **Upshift indicator:**

For details concerning the upshift indicator, refer to the following section. ( \*\*Tupshift indicator\* page 2-10)







#### "TIMER" indicator:

This alert informs the driver that the set driving time has elapsed.

On the TIMER screen, push the NEXT switch to change the time. Push and hold the switch to increase the number every 1 hour. A maximum of 6 hours can be set.

### NOTE:

The default setting is OFF.

#### Low outside temperature warning:

This alert informs the driver when the outside air temperature is lower than  $37^{\circ}F$  ( $3^{\circ}C$ ).

On the ICY screen, push the NEXT switch to turn this warning ON/OFF.

### NOTE:

The default setting is ON.

#### Maintenance

This function can be used to set the various maintenance intervals and to check the engine oil level. The reminders shown below are used to notify the driver of the maintenance intervals.

#### NOTE:

Because these are displayed based on the mileage driven, they do not indicate the actual conditions of the vehicle. Use these functions only as a reference.

Input the maintenance distance using the following items:

• On each setting screen, push the

NEXT switch 

to change the mileage. Push and hold the switch to increase the number every 600 miles (1,000 km).

- Set to "—" to set no reminders.
- To reset the accumulated mileage to zero, go to the RESET screen, then push the NEXT switch and confirm with the ENTER switch .

#### NOTE:

- To restore the mileage to the original figure after resetting, push the NEXT switch again.
- When the battery terminal is disconnected, the set mileage will be erased and the settings will return to their default settings.





#### **Engine oil level:**

This can be used to check the pre-start oil level while the engine is running. Select SETTING > MAINTENANCE > OII > ENGINE OII > I FVFI

If the low level reminder appears, check the level using the engine oil dipstick. ( 译 "Checking engine oil level" page 8-9)

#### **Enaine oil:**

When the customer set mileage approaches, the reminder will appear on the display and the remaining distance is displayed at regular intervals. Select SETTING > MAINTENANCE > OIL > ENGINE OIL to set or reset the mileage for the engine oil change.

#### NOTE:

The default setting is 9,500 miles (15,000 km). The maximum mileage that can be set is 9,500 miles (15,000 km).







#### **Engine oil filter:**

The reminder is displayed when the customer set mileage is exceeded. Select SETTING > MAINTENANCE > FILTER to set or reset the mileage for the engine oil filter change.

#### NOTE:

The default setting is 9,500 miles (15,000 km). The maximum mileage that can be set is 9,500 miles (15,000 km).

#### Transmission oil:

The reminder is displayed when the customer set mileage is exceeded. Select SETTING > MAINTENANCE > OIL > T/M OIL to set or reset the mileage for the transmission oil change.

### NOTE:

The default setting is 37,000 miles (60,000 km). The maximum mileage that can be set is 55,500 miles (90,000 km).


#### Tires:

This reminder appears when the customer set distance comes for maintaining tires. You can set or reset the distance for maintaining tires. ( \*\*Setting\*\* (drive computer)\*\* page 2-20)

## **MARNING**

The tire maintenance indicator is not a substitute for regular tire checks, including tire pressure checks. See "Changing wheels and tires" in the "8. Do-it-yourself" section. Many factors including tire inflation, alignment, driving habits and road conditions

affect tire wear and when tires should be replaced. Setting the tire maintenance reminder for a certain driving distance does not mean your tires will last that long. Use the tire maintenance reminder as a quide only and always perform regular tire checks. Failure to perform regular tire checks, including tire pressure checks could result in tire failure. Serious vehicle damage could occur and may lead to a collision, which could result in serious personal injury or death.





#### NOTE:

The default setting is OFF.

### **Options**

This function can be used to make settings for language and unit.

#### Language:

Select ENGLISH or FRANCAIS for use in the vehicle information display.

#### Unit:

Select METRIC or US for use in the vehicle information display.

### **WARNING** (drive computer)

Warning information is displayed on the vehicle information display.

Push the ENTER switch while a warning display is active to return to the original display.

It is also possible to check any warnings that have not been corrected. ( \*\* Warning display" page 2-36)

### Checking the warnings

Use the NEXT switch 

to select "DE-TAIL", then confirm with the ENTER switch 

When there are multiple warnings, push

display among them.

To return to the initial warning, push and hold the ENTER switch [ ] for more than 1 second.

#### NOTE:

If there are no warnings to display, only "SKIP" can be selected.

## WARNING LIGHTS, INDICATOR LIGHTS AND AUDIBLE REMINDERS

	Warning/indicator light (red)		Warning/indicator light (yellow)		Warning/indicator light (other)	
BRAKE	Port of the Port	AWD	All-Wheel Drive (AWD) warning light	CRITISE	Cruise main switch indicator light	
<b>(D)</b>	Brake warning light	ABS	Anti-lock Braking System (ABS) warn-		Cruise set switch indicator light	
益	Charge warning light		ing light	-00-	Exterior light indicator	
150	Engine oil pressure warning light	KEY	Intelligent Key warning light	OFF ⊗ 2	Front passenger air bag status light	
#	Seat belt warning light	(!)	Low tire pressure warning light		High beam indicator light	
<b>₹</b>	Supplemental air bag warning light	SERVICE ENGINE SOON	Malfunction Indicator Light (MIL)	**	Turn signal/hazard indicator lights	
		A	Master warning light			
		李玉	Transmission warning light			
		Ş. OFF	Vehicle Dynamic Control (VDC) off indicator light			
		悬	Vehicle Dynamic Control (VDC) warn- ing light			

#### **CHECKING LIGHTS**

With all doors closed, apply the parking brake, fasten the seat belts and place the ignition switch in the ON position without starting the engine. The following lights (if so equipped) will come on:

The following lights (if so equipped) will

come on briefly and then go off:

※, ABS or (๑), 本至, 克, 豪, (⑴), 區 If any light does not come on or operates in a way other than described, it may indicate a burned-out bulb and/or a system malfunction. It is recommended you have the system checked by a GT-R certified NISSAN dealer.

#### WARNING/INDICATOR LIGHTS (red)

See \*\*Twarning display" page 2-36 and \*\*Twarning display" page 2-36 and \*\*Twarning display" page 2-13.

Brake warning light

This light functions for both the parking brake and the foot brake systems.

### Parking brake indicator:

When the ignition switch is in the ON position, the light comes on when the parking brake is applied.

#### Low brake fluid warning light:

When the ignition switch is in the ON position, the light warns of a low brake fluid level. If the light comes on while the engine is running with the parking brake not applied, stop the vehicle and perform the following:

- Check the brake fluid level. Add brake fluid as necessary. ( Prake fluid" page 8-11)
- 2. If the brake fluid level is correct, it is recommended you have the warning system checked by a GT-R certified NISSAN dealer.

#### Anti-lock Braking System (ABS) warning indicator:

When the parking brake is released and the brake fluid level is sufficient, if both the brake warning light and the Anti-lock Braking System (ABS) warning light illuminate, it may indicate the ABS is not functioning properly. It is recommended vou have the brake system checked, and if necessary repaired, by a GT-R certified NISSAN dealer promptly. (译字"Anti-lock Braking System (ABS) warning light" page 2-29)

### Brake pad wear warning indicator (models with NCCB (NISSAN Carbon Ceramic Brake) package):

When the brake warning light illuminates. it may indicate that there is brake pad wear. Have the brake system checked and brake pads replaced as soon as possible. It is recommended you contact a GT-R certified NISSAN dealer for this service



### **CAUTION**

Never drive for a long period of time when the brake warning light illuminates for brake pad wear warning indicator is illuminated. Otherwise. the brake may not function properly due to brake pad wear.

### **WARNING**

 Your brake system may not be working properly if the warning light is on. Driving could be dangerous. If you judge it to be safe, drive carefully to the nearest service station for repairs. Otherwise, have your vehicle towed

because driving it could be dangerous.

- Pressing the brake pedal with the engine stopped and/or low brake fluid level may increase your stopping distance and braking will require greater pedal effort as well as pedal travel.
- If the brake fluid level is below the minimum or MIN mark on the brake fluid reservoir, do not drive until the brake system has been checked. It is recommended you contact a GT-R certified NISSAN dealer.

### **Charge warning light**

If the light comes on while the engine is running, it may indicate the charging system is not functioning properly. Turn the engine off and check the alternator belt. If the belt is loose, broken, missing or if the light remains on, it is recommended vou see a GT-R certified NISSAN dealer immediately.

#### **NOTICE**

Do not continue driving if the alternator belt is loose, broken or missing.

### Engine oil pressure warning light

This light warns of low engine oil pressure. If the light flickers or comes on during normal driving, pull off the road in a safe area and stop the engine immediately. It is recommended you call a GT-R certified NISSAN dealer.

The engine oil pressure warning light is not designed to indicate a low oil level. Check the vehicle information display or use the dipstick to check the oil level. ( 下 "Engine oil level display" page 2-13) ( 下字 "Checking engine oil level" page 8-9)

#### **NOTICE**

Running the engine with the engine oil pressure warning light on could cause serious damage to the engine almost immediately. Turn off the engine as soon as it is safe to do so.

### Seat belt warning light and chime

The light and chime remind you to fasten seat belts. The light illuminates whenever the ignition switch is placed in the ON position, and will remain illuminated until the driver's seat belt is fastened. At the same time, the chime will sound for about 6 seconds unless the driver's seat belt is securely fastened.

The seat belt warning light for the front passenger will illuminate if the seat belt is not fastened when the front passenger's seat is occupied. For approximately 5 seconds after the ignition switch is placed in the ON position, the system does not activate the warning light for the front passenger. ( 'Seat belts' page 1-6)

## Supplemental air bag warnina liaht

After pushing the ignition switch to the ON position, the supplemental air bag warning light will illuminate for about 7 seconds and then turn off. This means the system is operational.

If any of the following conditions occur, the front air bag, side air bag, curtain air bag and pretensioner systems need servicing and it is recommended your vehicle be taken to a GT-R certified NISSAN deal-

- The supplemental air bag warning light remains on after approximately 7 seconds.
- The supplemental air bag warning light flashes intermittently.
- The supplemental air bag warning light does not come on at all.

Unless checked and repaired, the supplemental restraint system (air bag system) and/or the pretensioners may not function properly. ( Par "Supplemental restraint system" page 1-34)

## **WARNING**

If the supplemental air bag warning light is on, it could mean that the front air bag, side air bag, curtain air bag and/or pretensioner systems will not operate in an accident. To help avoid injury to yourself or others, have your vehicle checked. It is recommended you visit a GT-R certified NISSAN dealer for this service.

### WARNING/INDICATOR LIGHTS (vellow)

See 'Warning display" page 2-36 and "Vehicle information display" page 2-13.

### AMD All-Wheel Drive (AWD) warning light

The AWD warning light comes on when the ignition switch is pushed to ON. It turns off soon after the engine is started.

If the AWD system malfunctions, the warning light will either remain illuminated or blink. ( ) "All-Wheel Drive (AWD)" page 5-42)

### **A** CAUTION

- If the warning light comes on while driving there may be a malfunction in the AWD system. Reduce the vehicle speed and have your vehicle checked as soon as possible. It is recommended vou have the vehicle checked by a GT-R certified NISSAN dealer.
- If the AWD warning light blinks on when you are driving:

- blinks rapidly (about twice a second): Pull off the road in a safe area. and idle the engine. The driving mode will change to RWD to prevent the AWD system from malfunctioning. If the warning light turns off, you can drive again. This does not indicate that there is a malfunction.
- blinks slowly (about once every 2 seconds): Pull off the road in a safe area. and idle the engine. Check that all tire sizes are the same as that specified on the Tire and Loading Information label located in the driver's door opening, tire pressure is correct and tires are not worn. ( The "Tire and loading information label" page 10-14) If the tire pressure is insufficient, fill with nitrogen gas. It is recommended you contact a GT-R certified NISSAN dealer about filling with nitrogen gas. If nitrogen gas is not available, compressed air may be safely used under normal driving conditions.

- However, NISSAN recommends refilling with nitrogen gas for maximum tire performance.
- If the warning light is still on after the above operations, have your vehicle checked as soon as possible. It is recommended you have the vehicle checked by a GT-R certified NISSAN dealer.

## ABS or Marking Anti-lock Braking System (ABS) warning light

When the ignition switch is in the ON position, the Anti-lock Braking System (ABS) warning light illuminates and then turns off. This indicates the ABS is operational.

If the ABS warning light illuminates while the engine is running, or while driving, it may indicate the ABS is not functioning properly. It is recommended you have the system checked by a GT-R certified NISSAN dealer.

If an ABS malfunction occurs, the antilock function is turned off. The brake system then operates normally, but without anti-lock assistance. ( ) "Brake system" page 5-52)

### Intelligent Key warning light

After the ignition switch is pushed to the ON position, this light comes on for about 2 seconds and then turns off.

This light warns of a malfunction with the electrical steering lock system or the Intelligent Key system.

If the light comes on while the engine is stopped, it may be impossible to free the steering lock or to start the engine. If the light comes on while the engine is running, you can drive the vehicle. However in these cases, it is recommended you contact a GT-R certified NISSAN dealer for repair as soon as possible.

### Low tire pressure warning light

Your vehicle is equipped with a Tire Pressure Monitoring System (TPMS) that monitors the tire pressure of all tires.

The low tire pressure warning light warns of low tire pressure and flat tire, or indicates that the TPMS is not functioning properly.

After the ignition switch is pushed to the ON position, the warning light illuminates for about 1 second and turns off.

### Low tire pressure warning:

If the vehicle is being driven with low tire pressure, the warning light will illuminate. When the low tire pressure warning light illuminates, you should stop and adjust the tire pressure of all 4 wheels to the recommended COLD tire pressure shown on the Tire and Loading Information label located in the driver's door opening.

The low tire pressure warning light does not automatically turn off when the tire pressure is adjusted. After the tire is inflated to the recommended pressure, the vehicle must be driven at speeds above 16 MPH (25 km/h) to activate the TPMS and turn off the low tire pressure warning light. Use a tire pressure gauge to check the tire pressure. ( Fig "Tire Pressure Monitoring System (TPMS)" page 5-4) ( FF "Tire Pressure Monitoring System (TPMS)" page 6-3)

### Run-flat tire warning:

The run-flat tire warning warns of a flat tire.

If the vehicle is being driven with one or more flat tires, the warning light will illuminate continuously and a chime will sound for 10 seconds.

The chime will only sound at the first indication of a flat tire and the warning

light will illuminate continuously. When the flat tire warning is activated, it is recommended you have the system reset and the tire checked and replaced if necessary by a GT-R certified NISSAN dealer. Even if the tire is inflated to the specified COLD tire pressure, the warning light will continue to illuminate until the system is reset.

If you select the tire pressure information in the touch screen display, the warning screen will be displayed. The tire pressure for each tire will also be displayed. Refer to the separate Multi Function Display Owner's Manual

Your vehicle can be driven for a limited time on a flat tire. ( ) "Run-flat tires" page 6-4) ( Run-flat tires" page 8-36)

#### TPMS malfunction:

If the TPMS is not functioning properly, the low tire pressure warning light will flash for approximately 1 minute when the ignition switch is pushed to the ON position. The light will remain on after the 1 minute. It is recommended you have the system checked by a GT-R certified NISSAN dealer. ( Tre Pressure Monitoring System (TPMS)" page 5-4) ( 字 "Tire pressure" page 8-30)

### **WARNING**

- If the light does not illuminate with the ignition switch pushed to the ON position, it is recommended vou have the vehicle checked by a GT-R certified NISSAN dealer as soon as possible.
- If the light illuminates while driving, avoid sudden steering maneuvers or abrupt braking, reduce vehicle speed, pull off the road to a safe location and stop the vehicle as soon as possible. Driving with under-inflated tires may permanently damage the tires and increase the likelihood of tire failure. Serious vehicle damage could occur and may lead to an accident and could result in serious personal injury. Check the tire pressure for all four tires. Adjust the tire pressure to the recommended COLD tire pressure shown on the Tire and Loading Information label located in the driver's door opening to turn the low tire pressure warning light off. If the light still illuminates while driving after adjusting the

tire pressure, a tire may be flat ( FF "Run-flat tires" page 6-4) or the TPMS may be malfunctioning. If no tire is flat and all tires are properly inflated, it is recommended you have the vehicle checked by a GT-R certified NISSAN dealer.

- Although you can continue driving with a punctured run-flat tire, remember that vehicle handling stability is reduced, which could lead to an accident and personal injury. Also, driving a long distance at high speeds may damage the tires.
- Do not drive at speeds above 50 MPH (80 km/h) and do not drive more than 50 miles (80 km) with a punctured run-flat tire. The actual distance the vehicle can be driven on a flat tire depends on outside temperature, vehicle load, road conditions and other factors.
- If you detect any unusual sounds or vibrations while driving with a punctured run-flat tire, pull off the road to a safe location and stop the vehicle as soon as possible. The tire may be seriously damaged and need to be re-

placed.

- When a wheel is replaced, the TPMS will not function and the low tire pressure warning light will flash for approximately 1 minute. The light will remain on after the 1 minute. It is recommended vou contact a GT-R certified NISSAN dealer as soon as possible for tire replacement and/or system resetting.
- · Replacing tires with those not originally specified by NISSAN could affect the proper operation of the TPMS.

### **A** CAUTION

- The TPMS is not a substitute for the regular tire pressure check. Be sure to check the tire pressure regularly.
- Be sure to install the specified size of tires on the four wheels.

#### NOTE:

- If the vehicle is being driven at speeds of less than 16 MPH (25 km/h), the TPMS may not operate correctly.
- The tires of this vehicle are filled with nitrogen gas. When the tire pressure is low, fill the tires with nitrogen gas. It is recommended you contact a GT-R certified NISSAN dealer for information on filling the tires with nitrogen gas.

# Malfunction Indicator Light (MIL)

If the malfunction indicator light comes on steady or blinks while the engine is running, it may indicate a potential emission control or the muffler with electronic control valve (if so equipped) malfunction. The malfunction indicator light may also come on steady if the fuel-filler cap is loose or missing, or if the vehicle runs out of fuel. Check to make sure the fuel-filler cap is installed and closed tightly, and that the vehicle has at least 3 US gallons (12 liters) of fuel in the fuel tank.

After a few driving trips, the light should turn off if no other potential emission control system malfunction exists.

If this indicator light remains on for 20 seconds and then blinks for 10 seconds when the engine is not running, it indicates that the vehicle is not ready for an emission control system inspection/maintenance test. ( \*\* "Readiness for Inspection/Maintenance (I/M) test (US only)" page 10-22)

#### Operation:

The malfunction indicator light will come on in one of two ways:

- Malfunction indicator light on steady
   An emission control system malfunction has been detected. Check the fuel-filler cap. If the fuel-filler cap is loose or missing, tighten or install the cap and continue to drive the vehicle. The light should turn off after a few driving trips. If the light does not turn off after a few driving trips, it is recommended you have the vehicle inspected by a GT-R certified NISSAN dealer. You do not need to have your vehicle towed to the dealer.
- Malfunction indicator light blinking An engine misfire has been detected which may damage the emission control system.

To reduce or avoid emission control system damage:

- Do not drive at speeds above 45 MPH (72 km/h).
- Avoid hard acceleration or deceleration.
- 3) Avoid steep uphill grades.
- If possible, reduce the amount of cargo being hauled or towed.

The malfunction indicator light may stop blinking and remain on.

It is recommended you have the vehicle inspected by a GT-R certified NISSAN dealer. You do not need to have your vehicle towed to the dealer.

#### NOTICE

Continued vehicle operation without having the emission control system checked and repaired as necessary could lead to poor driveability, reduced fuel economy, and possible damage to the emission control system.

### A

### Master warning light

When the ignition switch is in the ON position, the master warning light illuminates if any of the warning displays appear on the vehicle information display. ( \*\*Tarriam of the control of the control



### Transmission warning light

This light warns of the following malfunctions.

#### Transmission system malfunction:

The light blinks if a malfunction in the transmission system occurs. If the light blinks, certain gear positions may become unusable, so that the vehicle may become undrivable. It is recommended you have the system inspected promptly by a GT-R certified NISSAN dealer.

#### Transmission oil temperature high:

The light illuminates if the transmission oil temperature becomes unusually high. If the light illuminates, avoid driving at high speed or at high engine speed until the light turns off. The light will turn off after a short period of time and the vehicle can then be driven normally. If the light illuminates frequently, it is recommended vou contact a GT-R certified NISSAN dealer.

### **NOTICE**

If the light continues to illuminate, the engine output may be reduced to prevent transmission damage.

### Transmission clutch temperature high:

The light illuminates if clutch temperature becomes unusually high. If the light illuminates, pull off the road in a safe area and idle the engine. When the light turns off, driving can be resumed. If the light illuminates frequently, it is recommended you contact a GT-R certified NISSAN dealer.

#### NOTICE

- Continuing to drive with the light on could cause serious damage to the transmission.
- If the light continues to illuminate, the vehicle cannot be driven because the engine output may be reduced and the clutch may be reduced to keep the clutch disengaged.

#### R mode start function:

If the R mode start function is used 4 times continuously, the function may be disabled and cannot be turned on for protection. While the function is disabled. the warning light illuminates. When the warning light goes off, the function can be used again. ( PF "R mode start function" page 5-33)

When the warning light illuminates, perform cool down driving (driving 1.3 mile (2 km) in 5th or 6th gear at a speed of approximately 37 - 50 MPH (60 - 80 km/h) while checking the temperature of the transmission oil until the warning light goes off.

#### NOTICE

While the warning light is illuminated, the engine output is controlled so that it does not increase.

### Wehicle Dynamic Control (VDC) off indicator light

When the ignition switch is in the ON position, the Vehicle Dynamic Control (VDC) off indicator light illuminates and then turns off.

The light comes on when the VDC set up switch is pushed to OFF for more than 1 second. ( Transmission and suspension setup switches" page 5-25)


This indicates that the vehicle dynamic control system and traction control system are not operating. ( ) "Vehicle Dynamic Control (VDC) system" page 5-54)

### Wehicle Dynamic Control (VDC) warning light

The light will blink when the VDC system or the traction control system is operating, thus alerting the driver that the vehicle is nearing its traction limits. The road surface may be slippery.

If the VDC warning light illuminates when the VDC system is turned on, this light alerts the driver to the fact that the VDC system's fail-safe mode is operating, for example the VDC or hill start assist system may not be functioning properly. It is recommended you have the system checked by a GT-R certified NISSAN dealer. If a malfunction occurs in the system, the VDC system function will be canceled but the vehicle is still driveable. ( ) "Vehicle Dynamic Control (VDC) system" page 5-54)

### WARNING/INDICATOR LIGHTS (other)



The light comes on when the cruise control is pushed. The light turns off when the main switch is pushed again. While the cruise control system main

switch indicator light is on, the cruise control system is operational.

### Cruise set switch indicator liaht

The light comes on while the vehicle speed is controlled by the cruise control system. If the light blinks while the engine is running, it may indicate the cruise control system is not functioning properly. It is recommended you have the system checked by a GT-R certified NISSAN dealer.

### **Exterior light indicator**

This indicator illuminates when the headlight switch is turned to the AUTO, and or position and the front parking lights, instrument panel lights, rear combination lights, license plate lights or headlights are on. The indicator turns off when these lights are turned off.

### Front passenger air bag status light

The front passenger air bag status light ( ) will be lit and the passenger front air bag will be OFF depending on how the front passenger seat is being used. ( 下写 "NISSAN Advanced Air Bag System

(front seats)" page 1-40)

### High beam indicator light

This light comes on when the headlight high beam is on and goes out when the low beam is selected.

### Turn signal/hazard indicator lights

The light flashes when the turn signal switch lever or hazard switch is turned on.

#### **AUDIBLE REMINDERS**

### Door lock warning chime

When the buzzer sounds, be sure to check both the vehicle and the Intelligent Key. See "Troubleshooting guide" (P.3-17).

### Light reminder chime

A chime will sound when the driver side door is opened with the headlight switch in the spas or position and the ignition switch in the ACC, OFF or LOCK position. Turn the headlight switch to the OFF (if so equipped) or AUTO position when you leave the vehicle.

### Parking brake reminder chime

A chime will sound if the vehicle speed is above 4 MPH (7 km/h) with the parking brake applied. Stop the vehicle and release the parking brake.

all the time even if the brake pedal is not depressed. Have the brakes checked as soon as possible if the warning sound is heard.

### Reverse warning chime

The chime will sound inside the vehicle if any of the following conditions occurs.


- The driver's door is opened while the shift lever is in the R position and the ignition switch is in the ON position.
- The shift lever is in the R position and 5 minutes have passed while the ignition switch is in the ON position.

Be sure to move the shift lever out of the R position after driving in reverse.

### Brake pad wear warning (models without NCCB (NISSAN Carbon Ceramic Brake) package)

The disc brake pads have audible wear warnings. When a brake pad requires replacement, it will make a high pitched scraping sound when the vehicle is in motion. This scraping sound will first occur only when the brake pedal is depressed. After the wear of the brake pad is increased, the sound will be heard

#### **WARNING DISPLAY**



### **WARNING**

When the warning light illuminates or blinks and a warning is displayed, promptly take the appropriate action. Ignoring the warning may result in malfunctions and accidents.

When the items mentioned below are detected the master warning light ① illuminates and the warning is displayed on the vehicle information display 2. A chime also sounds.

If there are multiple warnings, the warning lights remain lit or continue to blink and the warnings displayed in the vehicle information display are switched at regular intervals. The warnings displayed in the vehicle information display can be switched voluntarily by pushing the ENTER switch .







### **ENGINE OIL LOW PRESSURE** WARNING

This will appear if the engine oil pressure is low. ( ) "Engine oil pressure warning light" page 2-28)

#### **ENGINE SYSTEM WARNING**

This will appear if a potential emission control or the muffler with electronic control valve (if so equipped) malfunction is detected, the fuel-filler cap is loose or missing, or the vehicle runs out of fuel. ( ) "Malfunction Indicator Light (MIL)" page 2-32)


#### SHIFT LEVER POSITION WARNING

This will appear if the system cannot detect the shift lever position.

Stop the vehicle in a safe location. Depress the brake pedal and move this shift lever to another position then move the lever back to the desired position. If the warning is still displayed after the above operation is performed, it is recommended you have the system checked by a GT-R certified NISSAN dealer. (声 "Driving the vehicle" page 5-15)







#### **REVERSE WARNING**

This will appear (and a chime will sound) if the shift lever is in the R position for more than 5 minutes, or when the driver's door is opened while the shift lever is in the R position.

#### TRANSMISSION SYSTEM WARNING

This will appear if a transmission system malfunction occurs. ( pr "Transmission warning light" page 2-33)

### TRANSMISSION OIL HIGH TEM-**PERATURE WARNING**

This will appear if the transmission oil temperature becomes unusually high. ( 🍞 "Transmission warning light" page 2-33)







### TRANSMISSION CLUTCH HIGH **TEMPERATURE WARNING**

This will appear if the transmission clutch temperature becomes unusually high. ( 译 "Transmission warning light" page 2-33)

### PARKING BRAKE RELEASE WARN-ING

This will appear if the vehicle speed is above 4 MPH (7 km/h) with the parking brake applied. ( Prake warning light" page 2-26) ( Parking brake reminder chime" page 2-35)

### LOW BRAKE FLUID WARNING

This will appear if the brake fluid level becomes low. ( ) "Brake warning light" page 2-26)







### ANTI-LOCK BRAKING SYSTEM (ABS) WARNING

This will appear if the Anti-lock Braking System (ABS) is not functioning properly. (译 "Anti-lock Braking System (ABS) warning light" page 2-29) ( FF "Brake warning light" page 2-26)

### **VEHICLE DYNAMIC CONTROL (VDC)** SYSTEM WARNING

This will appear if the Vehicle Dynamic Control (VDC) system or the hill start assist system is not functioning properly. (译 "Vehicle Dynamic Control (VDC) warning light" page 2-34) ( The "Vehicle Dynamic Control (VDC) off indicator light" page 2-33)

### AWD CLUTCH HIGH TEMPERATURE WARNING

This will appear if the temperature of the AWD clutch becomes unusually high. ( Tar "All-Wheel Drive (AWD) warning light" page 2-29)

#### NOTE:

If the vehicle is driven in a way which causes the rear wheels to slip, the AWD clutch temperature will increase and the warning indicator may flash. Continuing to drive in way that causes the warning light to flash may cause the clutch to reach excessive temperatures

that could result in damage to the vehicle.





# FRONT/REAR TIRE SIZE DISCRE-**PANCY WARNING**

This will appear if the diameter of the front and the rear wheels are different. (译 "All-Wheel Drive (AWD) warning light" page 2-29)

# AWD SYSTEM WARNING

This will appear if the AWD system is not functioning properly while the engine is running. ( \*\* All-Wheel Drive (AWD) warning light" page 2-29)







#### LOW TIRE PRESSURE WARNING

This will appear if the vehicle is being driven with low tire pressure. ( ) "Low tire pressure warning light" page 2-30)

#### **RUN-FLAT TIRE WARNING**

This will appear and a chime will sound if the vehicle is being driven with one or more flat tires. ( Fr "Low tire pressure warning light" page 2-30)

# TIRE PRESSURE MONITORING SYSTEM (TPMS) WARNING

This will appear if the Tire Pressure Monitoring System (TPMS) is not functioning properly. ( The "Low tire pressure warning light" page 2-30)





- The timing of the low fuel warning display may change depending on braking, turning, acceleration, or going up or down hills.
- If the vehicle is not refueled after the low fuel warning appears, the display will change to "----". This change timing may become earlier depending on the driving conditions. This does not indicate that there is a malfunction.

# CRUISE CONTROL SYSTEM WARN-ING

This will appear if the cruise control system is not functioning properly. (译 "Cruise set switch indicator light" page 2-34)

# LOW FUEL WARNING

This will appear when the fuel level in the tank is getting low. Refuel as soon as it is convenient, preferably before the fuel gauge reaches the empty (E) position.

This displays the approximate distance that the vehicle can be driven based on the amount of fuel remaining in the fuel tank and the actual fuel consumption.

#### NOTE:

• The low fuel warning will appear when the amount of fuel remaining in the tank decreases to approximately 3 US gallons (12 liters).







#### DOOR/TRUNK OPEN WARNING

This will appear if any of the doors and/or trunk lid are open or not closed securely. The vehicle icon indicates which door or the trunk lid is open.

#### **HEADLIGHT SYSTEM WARNING**

This will appear if the LED headlight system is not functioning properly. It is recommended you have the system checked by a GT-R certified NISSAN dealer.

#### LOW WASHER FLUID WARNING

This will appear when the washer tank fluid is at a low level. Add washer fluid as necessary. ( Pr "Window washer fluid" page 8-12)

WARNING
NO KEY

nized by the system. You cannot start the engine with an unregistered Intelligent Key.

( pg "Intelligent Key system" page 3-8)

# **OPERATION DISPLAYS**

These displays appear when an appropriate operation is required in starting or stopping the engine.

#### **NO KEY WARNING**

This will appear in either of the following conditions.

# No key inside the vehicle

The warning appears when the door is closed with the Intelligent Key left outside the vehicle and the ignition switch in the ACC or ON position. Make sure that the Intelligent Key is inside the vehicle.

# **Unregistered Intelligent Key**

The warning appears when the ignition switch is pushed from the LOCK position and the Intelligent Key cannot be recog-







# **ENGINE START OPERATION INDI-CATOR**

This indicator appears when the shift lever is in the position.

This indicator means that the engine will start by pushing the ignition switch with the brake pedal depressed.

#### SHIFT "P" WARNING

This warning appears and an inside warning chime sounds when the ignition switch is pushed to stop the engine with the shift lever in any position except the P position.

If this warning appears, move the shift lever to the **P** position. This warning will also turn off when pushing the ignition switch to the ON position.

#### "PUSH" WARNING

This warning appears when the shift lever is moved to the position with the ignition switch in the ACC position after the SHIFT **P** warning appears.

If this warning appears, push the ignition switch to the OFF position.







# STEERING LOCK RELEASE MAL-**FUNCTION INDICATOR**

This indicator appears when the steering wheel lock cannot be released from the LOCK position. If this indicator appears. push the ignition switch while lightly turning the steering wheel right and left.

# INTELLIGENT KEY INSERTION INDI-CATOR

This indicator appears when the Intelligent Key needs to be inserted into the Intelligent Key port (for example, the Intelligent Key battery is discharged). If this indicator appears, insert the Intelligent Key into the Intelligent Key port in the correct direction. ( The "Intelligent Key battery discharge" page 5-12)

# INTELLIGENT KEY REMOVAL INDI-CATOR

This indicator appears when the driver's door is opened with the ignition switch in the OFF or LOCK position and the Intelligent Key placed in the Intelligent Key port. A key reminder chime also sounds.


If this indicator appears, remove the Intelligent Key from the Intelligent Key port and take it with you when leaving the vehicle

#### **SECURITY SYSTEMS**





This indicator appears when the Intelligent Key battery is running out of power. If this indicator appears, replace the battery with a new one. ( pr "Intelligent Key battery replacement" page 8-25)



Your vehicle has two types of security systems, as follows:


- Vehicle security system
- NISSAN Vehicle Immobilizer System The security condition will be shown by the security indicator light.

#### **VEHICLE SECURITY SYSTEM**

The vehicle security system provides visual and audio alarm signals if someone opens the doors, hood, or trunk lid when the system is armed. It is not, however, a motion detection type system that activates when a vehicle is moved or when a vibration occurs.

The system helps deter vehicle theft but cannot prevent it, nor can it prevent the theft of interior or exterior vehicle components in all situations. Always secure your vehicle even if parking for a brief period. Never leave your Intelligent Key(s) in the vehicle, and always lock it when unattended. Be aware of your surroundings, and park in secure, well-lit areas whenever possible.

Many devices offering additional protection, such as component locks, identification markers, and tracking systems, are available at auto supply stores and specialty shops. Your GT-R certified NISSAN dealer may also offer such equipment. Check with your insurance company to see if you may be eligible for discounts for various theft protection features.



# How to arm the vehicle security system

- 1. Close all windows.
  - The system can be armed even if the windows are open.
- Push the ignition switch to the OFF or LOCK position.
- Remove the Intelligent Key from the vehicle.
- Close all doors, hood and trunk. Lock all doors. The doors can be locked with the Intelligent Key, door handle request switch or power door lock switch. The power door lock switch

- should be operated while the door is open, and then closed.
- 5. Confirm that the security indicator light comes on. The security indicator light stays on for about 30 seconds. The vehicle security system is now pre-armed. After about 30 seconds the vehicle security system automatically shifts into the armed phase. The security light begins to flash once every approximately 3 seconds. If, during this 30-second pre-arm time period, the door is unlocked, or the ignition switch is pushed to ACC or ON, the system will not arm.

Even when the driver and/or passengers are in the vehicle, the system will activate with all doors, hood, and trunk lid locked with the ignition switch in the LOCK position. When pushing the ignition switch to the ACC or ON position, the system will be released.

# Vehicle security system activation

The vehicle security system will give the following alarm:

- The headlights blink and the horn sounds intermittently.
- The alarm automatically turns off after approximately 1 minute. However, the alarm reactivates if the

vehicle is tampered with again.

The alarm is activated by:

- Opening the door or the trunk lid without using the button on the Intelligent Key, the door handle request switch or the mechanical key. (Even if the door is opened by releasing the door inside lock knob, the alarm will activate.)
- Opening the hood.

# How to stop an activated alarm

The alarm will stop by:

- Unlocking a door by pushing the UNLOCK button on the Intelligent Key.
- Unlocking a door by pushing the door handle request switch.
- Pushing the ignition switch to the ACC or ON position.

If the system does not operate as described above, it is recommended you have it checked by a GT-R certified NISSAN dealer.

# NISSAN VEHICLE IMMOBILIZER SYSTEM

The NISSAN Vehicle Immobilizer System will not allow the engine to start without the use of the registered Intelligent Key. **Never leave these keys in the vehicle.** 

#### FCC Notice:


#### For USA:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### For Canada:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.



engine will not start, it is recommended you see a GT-R certified NISSAN dealer for NISSAN Vehicle Immobilizer System service as soon as possible. Please bring all Intelligent Keys that you have when visiting a GT-R certified NISSAN dealer for service.

# Security indicator light

The security indicator light is located on the instrument panel. It indicates the status of the NISSAN Vehicle Immobilizer System.

The light blinks whenever the ignition switch is in the ACC, OFF or LOCK position. This function indicates the security systems equipped on the vehicle are operational.

If the NISSAN Vehicle Immobilizer System is malfunctioning, this light will remain on while the ignition switch is in the ON position.

If the light still remains on and/or the

#### WIPER AND WASHER SWITCH

# **WARNING**

In freezing temperatures the washer solution may freeze on the windshield and obscure your vision which may lead to an accident. Warm windshield with the defroster before you wash the windshield.

# NOTICE

- Do not operate the washer continuously for more than 30 seconds.
- Do not operate the washer if the reservoir tank is empty.
- Do not fill the window washer reservoir tank with washer fluid concentrates at full strength. Some methyl alcohol based washer fluid concentrates may permanently stain the grille if spilled while filling the window washer reservoir tank.
- Pre-mix washer fluid concentrates with water to the manufacturer's recommended levels before pouring the fluid into the window washer reservoir tank. Do

not use the window washer reservoir tank to mix the washer fluid concentrate and water.

The windshield wiper and washer operates when the ignition switch is in the ON position.



- INT (Intermittent) intermittent operation can be adjusted by turning the knob toward (Slower) or (B) (Faster).
- Low continuous low speed operation
- High continuous high speed operation

#### **USING THE WIPERS**

Push the lever down to operate the wiper at the following speed:

Push the lever up 4 to have one sweep operation of the wiper.

#### NOTE:

- In the MIST position, the wipers operate while the lever is lifted up. When the lever is released, it automatically returns to the OFF position and the wipers stop.
- When the speed sensing wiper interval function is turned on, the intermittent operation speed varies in accordance with the vehicle speed. (For example, when the vehicle speed is high, the intermittent operation speed will be faster.) To turn this function on and off, see the separate Multi Function Display Owner's Manual.
- If the wiper operation is interrupted by snow or ice, the wiper may stop moving to protect its motor. If this occurs, turn the wiper switch to the OFF position and remove the snow or ice on and around the wiper arms. In approximately 1 minute, turn the switch on again to operate the wiper.




#### **USING THE WASHER**

Pull the lever toward you to operate the washer. Then the wiper will also operate several times.

#### NOTE:

When the level of washer fluid is low, a warning display appears on the vehicle information display. ( >> "Low washer fluid warning" page 2-44)

### **REAR WINDOW DEFROSTER SWITCH**



To defog/defrost the rear window, start the engine and push the switch on. The indicator light on the switch will come on. Push the switch again to turn the defroster off.

It will automatically turn off in approximately 15 minutes.

#### NOTE:

When the rear window defroster switch is pressed, the heated outside mirrors also operate at the same time. ( > "Outside mirrors" page 3-28)

# **HEADLIGHT AND TURN SIGNAL SWITCH**

#### **NOTICE**

When cleaning the inner side of the rear window, be careful not to scratch or damage the rear window defroster.



the daytime running light will remain on. Turning the switch to the position: Headlights will come on and all the other lights remain on. The daytime running light will turn off.

#### **HEADLIGHT SWITCH**

# Lighting

#### For USA:

The parking, tail and license plate lights will turn on after the engine is started regardless of the position of the headlight switch. The lights will turn off when the engine is turned off.

The daytime running lights will also turn on when the engine is started.

# Turning the switch to the position:

The parking, side marker, tail, license plate and instrument lights will come on and



The autolight system will also be set in this position.

Turning the switch to the position: Headlights will come on and all the other lights remain on. The daytime running light will turn off.



#### For Canada:

The parking, tail and license plate lights will turn on after the engine is started regardless of the position of the headlight switch. The lights will turn off when the engine is turned off while the headlight switch is in the AUTO position.

The daytime running lights will also turn on when the engine is started while the headlights are off.

# Turning the switch to the spas position:

The parking, side marker, tail, license plate and instrument lights will come on and the daytime running light will remain on if the headlights are off.

# Autolight system

#### For USA:

The autolight system allows the headlights to be set so they turn on and off automatically.

To set the autolight system:

- Make sure the headlight switch is in the AUTO position ①.
- 2. Push the ignition switch to the ON position.
- 3. The autolight system automatically turns the headlights on and off.

To turn the autolight system off, turn the switch to the OFF, and or position.

The autolight system can turn on the headlights automatically when it is dark and turn off the headlights when it is light.

If the ignition switch is pushed to the OFF position and one of the doors is opened, the headlights remain on for 45 seconds.



#### For Canada:

The autolight system allows the headlights to be set so they turn on and off automatically.

To set the autolight system:

- 1. Make sure the headlight switch is in the AUTO or EDGE position 1.
- 2. Push the ignition switch to the ON position.
- 3. The autolight system automatically turns the headlights on and off.


To turn the autolight system off, turn the switch to the position.

The autolight system can turn on the headlights automatically when it is dark and turn off the headlights when it is light.

If the ignition switch is pushed to the ON position when the parking brake is applied, the headlights remain off.

With the position selected, the headlights turn off when the ignition switch is pushed to the OFF position, the shift lever is placed in the **P** position or the parking brake is applied. (The parking, side marker, tail, license plate, and instrument lights are on.)

With the AUTO position selected (headlights are on), the headlights will remain on for 45 seconds when the ignition switch is placed in the OFF position and one of the doors is opened.



# Headlight beam select

When the headlights are on, push the lever to the front of the vehicle (1) to switch to the high beams. The high-beam indicator light illuminates. (128 "High beam indicator light" page 2-34)

Pull the lever to the neutral position 2 to switch to the low beams.

Pulling the lever toward you 3 will flash the headlight high beam regardless of the position of the headlight switch.

# **CAUTION**

Use low beams when there are cars approaching from the opposite direction, during city driving and at similar times.

# Battery saver system

A chime will sound when the driver side door is opened with the headlight switch in the sods or position and the ignition switch in the ACC, OFF or LOCK position. (译 "Light reminder chime" page 2-34) When the headlight switch is in the and or position while the ignition switch is in the ON position, the lights will automatically turn off after a period of time when the ignition switch has been pushed to the OFF position.

When the headlight switch remains in the edge or position after the lights automatically turn off, the lights will turn on when the ignition switch is pushed to the ON position.

# NOTICE

- Be sure to turn the headlight switch to the OFF (if so equipped) or AUTO position when you leave the vehicle for extended periods of time, otherwise the battery will be discharged.
- Never leave the headlight switch on when the engine is not running for extended periods of time even if the headlights turn off automatically.

# Daytime running light system

#### For USA:

The davtime running lights automatically illuminate when the engine is started with the parking brake released. The daytime running lights operate with the headlight switch in the AUTO position. Turn the headlight switch to the position for full illumination when driving at night.

If the parking brake is applied before the engine is started, the daytime running lights do not illuminate. The daytime running lights illuminate once the parking brake is released. The daytime running lights will remain on until the ignition


switch is pushed to the OFF position.

# **WARNING**

When the daytime running light system is active, tail lights on your vehicle are not on. It is necessary at dusk to turn on your headlights. Failure to do so could cause an accident injuring yourself and others.

#### For Canada:

The daytime running lights automatically illuminate when the engine is started with the parking brake released. The daytime running lights operate with the headlight switch in the AUTO position or in the apple position, the headlight must be off. Turn the headlight switch to the position for full illumination when driving at night. If the parking brake is applied before the engine is started, the daytime running lights do not illuminate. The davtime running lights illuminate once the parking brake is released. The daytime running lights will remain on until the ignition switch is pushed to the OFF position or the headlights turn on.



turn signal begins to flash, but the lever does not latch, and release the lever. The turn signal will automatically flash three times.

Choose the appropriate method to signal a lane change based on road and traffic conditions.

#### **TURN SIGNAL SWITCH**

# 1 Turn signal

Move the lever up or down to signal the turning direction. When the turn is completed, the turn signals cancel automatically.

# ② Lane change signal

- Move the lever up or down until the turn signal begins to flash, but the lever does not latch, to signal a lane change. Hold the lever until the lane change is completed.
- Move the lever up or down until the

#### **HEATED SEATS**





To sound the horn, push the center pad area of the steering wheel.

# **WARNING**

Do not disassemble the horn. Doing so could affect proper operation of the supplemental front air bag system. Tampering with the supplemental front air bag system may result in serious personal injury.

The seat heaters can be used when the ignition switch is in the ON position. The front seats are warmed by the built-in heaters.

#### **TURNING ON THE HEATERS**

Push the "HI" or "LO" side of the switch to activate the heaters. The switch indicator illuminates

Switch posi- tion	Function
HI	To heat the seat quickly
LO	To keep the seat warm

#### **TURNING OFF THE HEATERS**

Move the switch to the level position. The switch indicator turns off.

# **WARNING**

Do not use or allow occupants to use the seat heater if you or the occupants cannot monitor elevated seat temperatures or have an inability to feel pain in those body parts in contact with the seat. Use of the seat heater by such people could result in serious injury.

# **A** CAUTION


- Do not put anything on the seat which insulates heat, such as a blanket, cushion, seat cover, etc. Otherwise, the seat may become overheated.
- Do not place anything hard or heavy on the seat or pierce it with a pin or similar object. This may result in damage to the heater.
- Any liquid spilled on the heated seat should be removed immediately with a dry cloth.

If any malfunctions are found or the heated seat does not operate. turn the switch off and it is recommended you have the system checked by a GT-R certified NISSAN dealer.

#### **NOTICE**

- The battery could run down if the seat heater is operated while the engine is not running.
- Do not use the seat heater for extended periods or when no one is using the seat.
- When cleaning the seat, never use gasoline, thinner, or any similar materials.


# SONAR SYSTEM OFF SWITCH



The sonar system OFF switch on the lower side of the instrument panel allows the driver to turn the sonar system on and off. To turn the sonar system on and off, the ignition switch must be in the ON position. The indicator light (1) on the switch will turn off when the system is turned off. If the indicator light flashes it may indicate a malfunction in the sonar svstem.

( 字 "Sonar system" page 5-48 )

# EXHAUST SOUND CONTROL **SWITCH** (if so equipped)



The exhaust sound control switch on the lower side of the instrument panel allows the driver to turn the exhaust sound control system on and off.

To close the electronic control valve, push the exhaust sound control switch to the ON side

To open the electronic control valve, push the exhaust sound control switch to the OFF side.

(译 "Exhaust sound control system" page 5-59)

#### **POWER OUTLETS**


# **A** CAUTION

- The outlet and plug may be hot during or immediately after use.
- Do not use with accessories that exceed a 12 volt, 120W (10A) power draw. Do not use double adapters or more than one electrical accessory.
- This power outlet is not designed for use with a cigarette lighter unit.
- Before inserting or disconnecting a plug, be sure the electrical accessory being used is turned OFF.
- When not in use, be sure to close the cap. Do not allow water to contact the outlet.

# **NOTICE**

- Use power outlet with the engine running to avoid discharging the vehicle battery.
- Avoid using power outlet when the air conditioner, headlights or rear window defroster is on.

Push the plug in as far as it will go. If good contact is not made, the plug may overheat or the internal temperature fuse may open.



Next to the steering wheel
Pull out the cap to use the outlet.
Replace the cap after use.



Inside the console box
Open the cap to use the outlet.
Close the cap after use.

# **E-CALL (SOS) BUTTON**

#### **EMERGENCY SUPPORT**

NissanConnect® Services provides various services to support dealing with emergencies of the subscribed vehicle and the driver.

For example, in case of an illness or serious injury, you can seek support by pushing the in-vehicle E-Call\* (SOS) button and connecting to NissanConnect® Services. NissanConnect® Services can specify the location of the vehicle via GPS, and the information will be sent to the police or other agencies as needed.
\*: "E-Call" is an abbreviation for the "Emergency Call".

For information about other NissanConnect® Services emergency support related services, refer to the NissanConnect® Services website or contact the NissanConnect® Services support line

#### NissanConnect® Services website:

For U.S.
www.nissanusa.com/connect
For Canada
www.nissan.ca/nissanconnect (English)
www.nissan.ca/nissanconnect/fr (French)
NissanConnect® Services support line:
1-855-426-6628

# **WARNING**

- Please note that the Automatic Collision Notification service (For details of the Automatic Collision Notification service, refer to the separate Multi Function Display Owner's Manual.) and Emergency Call function cannot be used in the following conditions:
  - Emergency functions and services will not be available without a paid subscription to NissanConnect® Services.
  - The NissanConnect® Services network system is disabled.
  - The vehicle moves outside the service area where the TCU (Telematics Control Unit) is connected to the system.
  - The vehicle is outside the area where the cellular network service is receivable.
  - The vehicle is in a location with poor signal reception such as tunnels, underground parking garages, behind buildings or in mountainous areas.

- The line is busy.
- The TCU (Telematics Control Unit) or other systems of your vehicle are not working properly.
- It may not be possible to make an emergency call depending on the severity of a collision and/or emergency.
- Park the vehicle in a safe location and set the parking brake before operating the E-Call (SOS) button.
- Only use this service in case of an emergency. There may be a penalty for inappropriate use of the service.
- Radio waves could adversely affect electric medical equipment. Individuals who use a pacemaker should contact the device manufacturer regarding any possible effects before using the system.
- The TCU (Telematics Control Unit) antenna is installed inside the upper central part of the instrument panel. An occupant should not get any closer to the antenna than specified by the pacemaker manufacturer. The radio waves

from the TCU antenna may adversely affect the operation of the pacemaker while using the NissanConnect® Services.



# Making an emergency call

The E-Call (SOS) button is located near the map light.

- 1. Push the E-Call (SOS) button.
- 2. When the line is connected, speak to the Response Specialist.



# INFO:

 After the E-Call (SOS) button is pushed, it may take some time until the system initiates connection, depending on the technical environment and whether the TCU (Telematics Control Unit) is being used by other

# **STORAGE**

services

- An indicator light on the E-Call (SOS) button shows the readiness of the emergency support system. If the indicator light is not illuminated, pushing the E-Call (SOS) button does not connect your vehicle to the Response Specialist.
  - The indicator light blinks while connected to the NissanConnect® Services Response Center.
- Even when the indicator light is illuminated, connection to the Nissan-Connect® Services Response Center may not be possible. If this occurs in an emergency situation, contact the authorities by other means.
- To avoid disconnecting the line, keep the engine running during an emergency call, if it is safe to do so.

# **CUP HOLDERS**


# **A** CAUTION


- Avoid abrupt starting and braking when the cup holder is being used to prevent spilling the drink. If the liquid is hot, it can scald you or your passenger.
- Use only soft cups in the cup holder. Hard objects can injure you in an accident.

#### Front

Slide the cover toward the rear of the vehicle to open.

To close, slide the cover back toward the front of the vehicle.





# **A** CAUTION

- Do not use for anything other than glasses.
- Do not leave glasses in the sunglasses holder while parking in direct sunlight. The heat may damage the glasses.

# Rear

# NOTE:


Cup holder (A) is wider and shallower than cup holders (B) and (C). Small-size cups are likely to tip over in cup holder (A). Use cup holders (B) and (C).

# **SUNGLASSES HOLDER**

To open the sunglasses holder, push ①.

# **WARNING**

Keep the sunglasses holder closed while driving to avoid obstructing the driver's view and to help prevent an accident.




# DOOR POCKET

Door pockets are located inside the driver's side and passenger's side doors.

# **NOTICE**

Do not grasp the door pockets to open and close the doors. Doing so may damage the pockets.




#### **GLOVE BOX**

# **WARNING**

Keep glove box lid closed while driving to help prevent injury in an accident or a sudden stop.

Pull the knob toward you to open the glove box.

To close the glove box, press the lid forward until it locks in place.



Use the mechanical key to lock 1 and unlock ② the glove box. ( 🌠 "Mechanical key" page 3-3)

The mechanical key stops when it is inserted approximately halfway in.



#### **CONSOLE BOX**


Lift up the lock knob ① to open the lid. To close the center console box, press on the lid until it locks in place.

# NOTE:

The console box contains a power outlet.

# **A** CAUTION

Do not leave the console box open. The open lid may suddenly close when the vehicle stops.



#### **COAT HOOKS**

To use the coat hook, push the upper side of the hook to release it.

# **A** CAUTION

Do not hang any objects with sharp edges on the coat hangers. These items may be knocked off if the SRS air bag deploys, possibly causing injury.

### NOTICE

Do not place items that are more than 2 lb (1 kg) on the hook.


#### **WINDOWS**

#### **POWER WINDOWS**

# **WARNING**


- Make sure that all passengers have their hands, etc. inside the vehicle while it is in motion and before closing the windows. Use the window lock switch to prevent unexpected use of the power windows.
- To help avoid risk of injury or death through unintended operation of the vehicle and or its systems, including entrapment in windows or inadvertent door lock activation, do not leave children, people who require the assistance of others or pets unattended in your vehicle. Additionally, the temperature inside a closed vehicle on a warm day can quickly become high enough to cause a significant risk of injury or death to people and pets.

The power windows operate when the ignition switch is in the ON position or for about 45 seconds after the ignition switch is pushed to the LOCK position. If the driver's or front passenger's door is opened during this period of about 45 seconds, power to the windows is canceled.



#### Driver's side

- Window lock button
- Driver's window switch
- Front passenger's window switch



Front passenger's side
4. Front passenger's window switch

# Main power window switch (driver's side)

To open or close the window, push down or pull up the switch and hold it. The main switch (driver's side switches) will open or close all the windows.

# Locking passengers' windows

When the window lock button is pushed in, only the driver's side window can be opened or closed. Push it in again to cancel

# Passenger's side power window switch

The passenger side switch will open or close only the corresponding window. To open close the window, push down or pull up the switch and hold it.

# **Automatic operation**

To fully open or close the window, completely push down or pull up the switch and release it; it does not need to be held. The window will automatically open or close all the way. To stop the window, just push or lift the switch in the opposite direction.

A light push or pull on the switch will cause the window to open or close until the switch is released.

#### **Auto reverse function**

If the control unit detects something caught in the window as it is closing, the window will be immediately lowered.

The auto reverse function can be activated when the window is closed by automatic operation when the ignition switch is in the ON position or for 45 seconds after the ignition switch is pushed to the OFF position.

Depending on the environment or driving

conditions, the auto reverse function may be activated if an impact or load similar to something being caught in the window occurs.

# **WARNING**

There are some small distances immediately before the closed position which cannot be detected. Make sure that all passengers have their hands, etc., inside the vehicle before closing the window.

# **Automatic adjusting function**

# **A** CAUTION

When the battery cable is removed from the battery terminal, do not close either of the front doors. The automatic window adjusting function will not work and the side roof panel may be damaged.

The power window has an automatic adjusting function. When the door is being opened, the window is automatically lowered slightly to avoid contact between the window and the side roof

panel. When the door is closed, the window is automatically raised slightly. While the automatic adjusting function does not work, the window will be controlled as follows:

- When the door is opened, the window lowers for approximately 2 seconds.
- While the door is open, the window cannot be raised.

# If the windows do not close automatically

If the power window automatic function (closing only) does not operate properly. perform the following procedure to initialize the power window system.


- 1. Push the ignition switch to start the engine.
- 2. Close the door.
- 3. After starting the engine, open the window completely by operating the power window switch.
- 4. Pull the power window switch and hold it to close the driver side window. and then hold the switch more than 3 seconds after the window is closed completely.
- 5. Release the power window switch. Operate the window by the automatic function to confirm the initialization is

complete.

6. Perform steps 2 through 5 above for the passenger side window by operating either driver's or passenger's side switch.


If the power window automatic function does not operate properly after performing the procedure above, it is recommended you have your vehicle checked by a GT-R certified NISSAN dealer.

# **INTERIOR LIGHTS**



#### MAP LIGHTS

Push the button as illustrated to turn the light on or off.



#### INTERIOR LIGHT CONTROL SWITCH

The interior light control switch has three positions: ON 1, DOOR 2 and OFF 3.

# ON position

When the switch is in the ON position ①, the map lights will illuminate.

# **NOTICE**

Do not use the light for extended periods of time with the engine stopped. This could result in a discharged battery.

#### NOTE:

The lights will also turn off after a period of time when the lights remain illuminated after the ignition switch has been pushed to the OFF or LOCK position to prevent the battery from becoming discharged.

# **DOOR** position

When the switch is in the DOOR position ②, the map lights will turn on when the door is opened and turn off when the door is closed. The map lights will turn off approximately 15 seconds after the door is closed with the ignition switch in the OFF or LOCK position.

#### NOTE:

When the interior light control switch is in the DOOR position and the door is open, the light will remain on even when the map light switch is pressed to turn off.

# Key-linked interior light control system:

The map lights will turn on and off linked with the locking and unlocking of the door.

This function operates when the interior light control switch is in the DOOR position.

#### • When entering the vehicle

When the driver's seat door is unlocked, the map light illuminates for approximately 15 seconds, then it turns off.

While the map light is on, if the ignition switch is pushed to the ACC or ON position, or if the driver's side door is locked, the light turns off.

#### • When exiting the vehicle

When the ignition switch is pushed to the OFF or LOCK position, the map lights turn on for approximately 15 seconds, then it turns off.

If the driver's side door is locked while the map lights are on, the light turns off.


#### NOTE:

It is possible to cancel the key-linked interior light control system setting. See the separate Multi Function Display Owner's Manual.

# **OFF** position

When the switch is in the OFF position ③, the map lights will not illuminate, regardless of any condition.

#### **VANITY MIRROR LIGHTS**



There is an illuminated vanity mirror on the reverse side of the sun visor.

# **HomeLink® UNIVERSAL TRANSCEIVER**

The HomeLink® Universal Transceiver provides a convenient way to consolidate the functions of up to three individual hand-held transmitters into one built-in device.

HomeLink® Universal Transceiver:

- Will operate most Radio Frequency (RF) devices such as garage doors, gates, home and office lighting, entry door locks and security systems.
- Is powered by your vehicle's battery. No separate batteries are required. If the vehicle's battery is discharged or is disconnected, HomeLink® will retain all programming.

When the HomeLink® Universal Transceiver is programmed, retain the original transmitter for future programming procedures (Example: new vehicle purchases). Upon sale of the vehicle, the programmed HomeLink® Universal Transceiver buttons should be erased for security purposes. For additional in formation, refer to programming HomeLink®" page 2-72.

# **MARNING**

- Do not use the HomeLink® Universal Transceiver with any garage door opener that lacks safety stop and reverse features as required by federal safety standards. (These standards became effective for opener models manufactured after April 1, 1982.) A garage door opener which cannot detect an object in the path of a closing garage door and then automatically stop and reverse, does not meet current federal safety standards. Using a garage door opener without these features increases the risk of serious injury or death.
- During the programming procedure your garage door or security gate will open and close (if the transmitter is within range). Make sure that people or objects are clear of the garage door, gate, etc. that you are programming.
- Your vehicle's engine should be turned off while programming the HomeLink® Universal Transceiver. Do not breathe exhaust gases; they contain colorless

and odorless carbon monoxide. Carbon monoxide is dangerous. It can cause unconsciousness or death.


### PROGRAMMING HomeLink®

If you have any questions or are having difficulty programming your HomeLink® buttons, refer to the HomeLink® web site at: www.homelink.com or call 1-800-355-3515.

#### NOTE:

It is also recommended that a new battery be placed in the hand-held transmitter of the device being programmed to HomeLink® for guicker programming and accurate transmission of the radio-frequency.


1. Position the end of your hand-held transmitter 1-3 in (26-76 mm) away from the HomeLink® surface, keeping the HomeLink® indicator light 1) in view



2. Using both hands, simultaneously press and hold the desired HomeLink® button and handheld transmitter button. DO NOT release until the HomeLink® indicator light ① flashes slowly and then rapidly. When the indicator light flashes rapidly, both buttons may be released. (The rapid flashing indicates successful programming.)

#### NOTE:

Some devices to be programmed may require you to replace Step 2 with the cycling procedure noted in the 'Programming HomeLink® for Canadian customers and gate openers" page 2-73.



- Press and hold the programmed HomeLink® button and observe the indicator light.
  - If the indicator light ① is solid/ continuous, programming is complete and your device should activate when the HomeLink® button is pressed and released.
  - If the indicator light ① blinks rapidly for two seconds and then turns to a solid/continuous light, continue with Steps 4-6 for a rolling code device. A second person may make the following steps easier. Use a ladder or other device. Do not stand on your vehicle to perform the next steps.

- 4. At the receiver located on the garage door opener motor in the garage, locate the "learn" or "smart" button (the name and color of the button may vary by manufacturer but it is usually located near where the hanging antenna wire is attached to the unit). If there is difficulty locating the button, reference the garage door opener's manual.
- 5. Press and release the "learn" or "smart" button.

#### NOTE:

Once the button is pressed, you have approximately 30 seconds to initiate the next step.

- 6. Return to the vehicle and firmly press and hold the programmed HomeLink® button for two seconds and release. Repeat the "press/hold/release" sequence up to 3 times to complete the programming process. HomeLink® should now activate your rolling code equipped device.
- If you have any questions or are having difficulty programming your HomeLink® buttons, refer to the HomeLink® web site at: www. homelink.com or call 1-800-355-3515.

# PROGRAMMING HomeLink® FOR CANADIAN CUSTOMERS AND GATE OPENERS

Canadian radio-frequency laws require transmitter signals to "time-out" (or quit) after several seconds of transmission – which may not be long enough for HomeLink® to pick up the signal during programming. Similar to this Canadian law, some U.S. gate operators are designed to "time-out" in the same manner.

If you live in Canada or you are having difficulties programming a gate operator or garage door opener by using the "Programming HomeLink®" procedures, replace "Programming HomeLink®" Step 2 with the following:

### NOTE:

When programming a garage door opener, etc., unplug the device during the "cycling" process to prevent possible damage to the garage door opener components.

Step 2: Using both hands, simultaneously press and hold the desired HomeLink® button and the hand-held transmitter button. During programming, your hand-held transmitter may automatically stop transmitting. Continue to press and hold the desired HomeLink® button while you

press and re-press ("cycle") your handheld transmitter every two seconds until the frequency signal has been learned. The HomeLink® indicator light will flash slowly and then rapidly after several seconds upon successful programming. DO NOT release until the HomeLink® indicator light flashes slowly and then rapidly. When the indicator light flashes rapidly, both buttons may be released. The rapid flashing indicates successful programming.

Proceed with "Programming HomeLink®" step 3 to complete.

Remember to plug the device back in when programming is completed.

# **OPERATING THE HomeLink® UNI-VERSAL TRANSCEIVER**

The HomeLink® Universal Transceiver. after it is programmed, can be used to activate the programmed device. To operate, simply press and release the appropriate programmed HomeLink® Universal Transceiver button. The amber indicator light will illuminate while the signal is being transmitted.

For convenience, the hand-held transmitter of the device may also be used at any time.

# PROGRAMMING TROUBLESHOOT-ING

If the HomeLink® does not quickly learn the hand-held transmitter information:

- replace the hand-held transmitter batteries with new batteries.
- position the hand-held transmitter with its battery area facing away from the HomeLink® surface.
- press and hold both the HomeLink® and hand-held transmitter buttons without interruption.
- position the hand-held transmitter 1-3 in (26-76 mm) away from the HomeLink® surface. Hold the transmitter in that position for up to 15 seconds. If HomeLink® is not programmed within that time, try holding the transmitter in another position keeping the indicator light in view at all times.

If you have any questions or are having difficulty programming your HomeLink® buttons, refer to the HomeLink® web site at: www.homelink.com or 1-800-355-3515.

# CLEARING THE PROGRAMMED IN-**FORMATION**

The following procedure clears the programmed information from both buttons. Individual buttons cannot be cleared. However, individual buttons can be reprogrammed, see 'Reprogramming a single HomeLink® button" page 2-74.

# To clear all programming

- 1. Press and hold the two outer HomeLink® buttons until the indicator light begins to flash in approximately 10 seconds. Do not hold for longer than 20 seconds.
- Release both buttons.

HomeLink® is now in the programming mode and can be programmed at any time beginning with "Programming HomeLink®" - Step 1.

# REPROGRAMMING A SINGLE **HomeLink® BUTTON**

To reprogram a HomeLink® Universal Transceiver button, complete the followina.

- Press and hold the desired Homel ink® button. Do not release the button.
- 2. The indicator light will begin to flash after 20 seconds. Without releasing

the HomeLink® button, proceed with "Programming HomeLink®" - Step 1.

For questions or comments, contact HomeLink® at: www.homelink.com or 1-800-355-3515.

The HomeLink® Universal Transceiver button has now been reprogrammed. The new device can be activated by pushing the HomeLink® button that was just programmed. This procedure will not affect any other programmed HomeLink® buttons.

# IF YOUR VEHICLE IS STOLEN

If your vehicle is stolen, you should change the codes of any non-rolling code device that has been programmed into HomeLink®. Consult the Owner's Manual of each device or call the manufacturer or dealer of those devices for additional information.

When your vehicle is recovered, you will need to reprogram the HomeLink® Universal Transceiver with your new transmitter information.

**FCC Notice:** 

For USA:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device

may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### NOTE:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### For Canada:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

# MEMO

## 3 Pre-driving checks and adjustments

Keys	3-2
Intelligent Key	3-2
Doors	3-4
Locking with inside lock knob	3-5
Locking with power door lock switch	3-5
Automatic door lock system	3-5
Locking with mechanical key	3-6
Opening the doors	3-7
Intelligent Key system	3-8
Intelligent Key functions	3-9
Remote keyless entry system	3-12
Setting hazard indicator and horn mode	3-14
Warning signals	3-16
Troubleshooting guide	3-17
Hood	3-18
Opening the hood	3-18
Closing the hood	3-19

Frunk	3-20
Trunk open request switch	3-20
Trunk lid release switch	3-20
Trunk release power cancel switch	3-21
Opening and closing the trunk	3-22
Emergency trunk lid release	3-22
Fuel-filler door	3-24
Opening the fuel-filler door	3-25
Closing the fuel-filler door	3-25
Steering wheel	3-26
Tilt/telescopic steering column	3-26
Sun visors	3-27
Mirrors	3-27
Inside mirror	3-27
Outside mirrors	3-28
Vanity mirror	3-29

#### **KEYS**

A key number plate is supplied with your keys. Record the key number and keep it in a safe place (such as your wallet), not in the vehicle. If you lose your keys, it is recommended you see a GT-R certified NISSAN dealer for duplicates by using the kev number. NISSAN does not record any key numbers so it is very important to keep track of your key number plate.

A key number is only necessary when you have lost all keys and do not have one to duplicate from. If you still have a key, this key can be duplicated by a GT-R certified NISSAN dealer.



- Intelligent Key (2 sets)
- 2. Mechanical key (inside Intelligent Keys) (2 sets)
- 3. Kev number plate (1 set)

#### INTELLIGENT KEY

Your vehicle can only be driven with the Intelligent Keys which are registered to your vehicle's Intelligent Key system components and NISSAN Vehicle Immobilizer System components. As many as 4 Intelligent Keys can be registered and used with one vehicle. The new keys must be registered by a GT-R certified NISSAN dealer prior to use with the Intelligent Key system and NISSAN Vehicle Immobilizer System of your vehicle. Since the registration process requires erasing all memory in the Intelligent Key components when registering new keys, be sure to take all Intelligent Keys that you have to a GT-R certified NISSAN dealer.

## **NOTICE**

- Be sure to carry the Intelligent Key with you when driving. The Intelligent Key is a precision device with a built-in transmitter. To avoid damaging it, please note the following.
  - The Intelligent Kev is water resistant; however, wetting may damage the Intelligent Key. If the Intelligent Key gets wet, immediately wipe until it is completely dry.
  - Do not bend, drop or strike it against another object.
  - Do not place the Intelligent Key for an extended period in a place where temperatures exceed 140°F (60°C).
  - If the outside temperature is below 14°F (-10°C), the battery of the Intelligent Key may not

function properly.

- Do not change or modify the Intelligent Key.
- Do not use a magnet key holder.
- Do not place the Intelligent Key near an electric appliance such as a television set, personal computer or cellular phone.
- Do not allow the Intelligent Key to come into contact with water or salt water, and do not wash it in a washing machine. This could affect the system function.
- If an Intelligent Key is lost or stolen, NISSAN recommends erasing the ID code of that Intelligent Key. This will prevent the Intelligent Key from unauthorized use to unlock the vehicle. For information regarding the erasing procedure, please contact a GT-R certified NISSAN dealer.



## Mechanical key

To remove the mechanical key, release the lock knob at the back of the Intelliaent Kev.

To install the mechanical key, firmly insert it into the Intelligent Key until the lock knob returns to the lock position.

Use the mechanical key to lock or unlock the doors and the glove box. ( The "Locking with mechanical kev" page 3-6) ( 字 "Glove box" page 2-65)

## **A** CAUTION

Always carry the mechanical key installed in the Intelligent Key.

#### Valet hand-off

When you have to leave a key with a valet, give them the Intelligent Key itself and keep the mechanical key with you to protect your belongings.

To prevent the glove box and the trunk from being opened during valet hand-off. follow the procedures below.

- 1. Push the trunk release power cancel switch to the OFF side. ( ) "Trunk release power cancel switch" page 3-21)
- 2. Remove the mechanical key from the Intelligent Key.
- 3. Lock the glove box with the mechanical key. ( Fig "Glove box" page 2-65)
- 4. Hand the Intelligent Key to the valet, keeping the mechanical key in your pocket or bag for insertion into the Intelligent Key when you retrieve your vehicle.

## **WARNING**

- Always have the doors locked while driving. Along with the use of seat belts, this provides greater safety in the event of an accident by helping to prevent persons from being thrown from the vehicle. This also helps keep children and others from unintentionally opening the doors, and will help keep out intruders.
- Before opening any door, always look for and avoid oncoming traffic.
- To help avoid risk of injury or death through unintended operation of the vehicle and or its systems, including entrapment in windows or inadvertent door lock activation, do not leave children, people who require the assistance of others or pets unattended in your vehicle. Additionally, the temperature inside a closed vehicle on a warm day can quickly become high enough to cause a significant risk of injury or death to people and pets.

## **CAUTION**

To prevent theft or accidents, be sure to stop the engine and lock the doors before stepping away from the vehicle.

## **NOTICE**

When the battery cable is removed from the battery terminal, do not close either of the front doors. The automatic window adjusting function will not work, and the side roof panel may be damaged. ( > "Automatic adjusting function" page 2-68)

## NOTE:

 The doors of this vehicle are somewhat harder to close than those of an ordinary vehicle (especially when the vehicle is new). This is because the stiffness of the rubber has been increased to improve the airtightness of the vehicle interior during situations such as higher speed driving. This does not indicate that there is a malfunction.

When the driver's door is locked or unlocked, the fuel-filler door is automatically locked or unlocked at the same time.

When the door is being opened, the window is automatically lowered slightly to avoid contact between the window and the side roof panel. When the door is closed, the window is automatically raised slightly. ( Pr "Automatic adjusting function" page 2-68)





## LOCKING WITH INSIDE LOCK KNOB

To lock a door individually, push down the inside lock knob to the lock position ① then close the door.

To unlock, lift up the inside lock knob to the unlock position 2.

#### NOTE:

When locking the door without an Intelligent Key, be sure not to leave the Intelligent Key inside the vehicle.

## LOCKING WITH POWER DOOR LOCK **SWITCH**

Operating the power door lock switch will lock or unlock all the doors. The switches are located on the driver's and front passenger's door armrests.

To lock the doors, push the power door lock switch to the lock position ① with the driver's or front passenger's door open, then close the door.

#### NOTE:

When locking the door this way, be sure not to leave the Intelligent Key inside the vehicle.

To unlock the doors, push the power door lock switch to the unlock position (2).

## **Lockout protection**

When the power door lock switch (driver or front passenger) is moved to the lock position with the Intelligent Kev left in the key port and any door open, all doors will lock and unlock automatically.

When the power door lock switch (driver or front passenger) is moved to the lock position with the Intelligent Key left in the vehicle (not in the Intelligent Key port) and any door open, all doors will unlock automatically and a chime will sound after the door is closed.

These functions help to prevent the Intelligent Key from being accidentally locked inside the vehicle.


#### **AUTOMATIC DOOR LOCK SYSTEM**

- All doors lock automatically when the vehicle speed reaches 15 MPH (24 km/h).
- All doors unlock automatically when the ignition switch is placed in the OFF position.

The automatic unlock function can be deactivated or activated. To deactivate or activate the automatic door unlock system, perform the following procedure:

- Close all doors.
- 2. Place the ignition switch in the ON position.
- 3. Within 20 seconds of performing Step 2, push and hold the power door lock switch to the a position (UNLOCK) for more than 5 seconds.
- 4. When activated, the hazard indicator will flash twice. When deactivated, the hazard indicator will flash once.
- 5. The ignition switch must be placed in the OFF and ON position again between each setting change.


When the automatic door unlock system is deactivated, the doors do not unlock when the ignition switch is placed in the OFF position. To unlock the door manually, use the inside lock knob or the power door lock switch (driver's or front passenger's side).



## LOCKING WITH MECHANICAL KEY

The driver's door will be locked or unlocked using the mechanical key.

1. Press the rear end of the driver's outside door handle (1) to lift up the front end ②.




2. With the outside door handle lifted up, use the mechanical key and turn the key cylinder cap (A) counterclockwise to remove.



## NOTE:

- Do not pull too hard on the door handle when locking or unlocking the doors. Pulling too hard will prevent the mechanical key from turning, making it impossible to lock or unlock the doors
- Unlocking the driver's door using the mechanical key will not unlock the fuel-filler door.



- 3. Turning the door key cylinder to the front of the vehicle 1 will lock the driver's door, and turning to the rear of the vehicle (2) will unlock the driver's door.
- 4. Replace the key cylinder cap in the reverse order.

#### **NOTICE**

Do not drive with the cap removed. Water that enters through the keyhole may cause a malfunction.

#### **OPENING THE DOORS**

## Opening from outside the vehicle

- 1. Press the rear end of the outside door handle (1) to lift up the front end of the handle.
- 2. Pull the front end of the outside door handle 2 toward you.

## Opening from inside the vehicle

Lift up the inside door handle to open a door from inside the vehicle.

## **NOTICE**

Do not grasp the door pockets to open and close the doors. Doing so may damage the pockets.

#### INTELLIGENT KEY SYSTEM

## **WARNING**

- Radio waves could adversely affect electric medical equipment. Those who use a pacemaker should contact the electric medical equipment manufacturer for the possible influences before use.
- The Intelligent Key transmits radio waves when the buttons are pushed. The Federal Aviation Agency (FAA) advises the radio waves may affect aircraft navigation and communication systems. Do not operate the Intelligent Key while on an airplane. Make sure the buttons are not operated unintentionally when the unit is stored for a flight.

The Intelligent Key system can operate all the door locks using the remote controller function or pushing the request switch on the vehicle without taking the key out from a pocket or purse. The operating environment and/or conditions may affect the Intelligent Key system operation. Be sure to read the following before using

the Intelligent Kev system.

## **A** CAUTION

- Be sure to carry the Intelligent Key with you when operating the vehicle.
- Never leave the Intelligent Key in the vehicle when you leave the vehicle.
- The Intelligent Kev is always communicating with the vehicle as it receives radio waves. The Intelligent Kev system transmits weak radio waves. Environmental conditions may interfere with the operation of the Intelligent Key system under the following operating conditions. In such cases, correct the operating conditions before using the Intelligent Key function or use the mechanical key.
  - When operating near a location where strong radio waves are transmitted, such as a TV tower, power station and broadcasting station.
  - When in possession of wireless equipment, such as a cellular telephone, transceiver, and CB radio.

- When the Intelligent Key is in contact with or covered by metallic materials.
- When any type of radio wave remote control is used nearby.
- When the Intelligent Key is placed near an electric appliance such as a personal computer.
- When the vehicle is parked near a parking meter.
- Although the life of the battery varies depending on the operating conditions, the battery's life is approximately 2 years. If the battery is discharged, replace it with a new one. ( ) Intelligent Key battery replacement" page 8-25)
- Since the Intelligent Kev is continuously receiving radio waves, if the key is left near equipment which transmits strong radio waves, such as signals from a TV and personal computer, the battery life may become shorter.
- Because the steering wheel is locked electrically, unlocking the steering wheel with the ignition switch in the LOCK position is impossible when the vehicle battery is completely discharged. Pay special attention that the vehicle battery is not completely discharged.

- Do not push the door handle request switch with the Intelligent Key held in your hand. The close distance to the door handle will cause the Intelligent Key system to have difficulty recognizing that the Intelligent Key is outside the vehicle.
- After locking the doors, check that the doors are securely locked by testing them.
- To prevent the Intelligent Key from being left inside the vehicle, make sure you carry the key with you and then lock the doors
- To prevent the Intelligent Key from being left inside the trunk, make sure you carry the key with you and then close the trunk.
- Do not pull the door handle before pushing the door handle request switch. The door will be unlocked but will not open. Release the door handle once and pull it again to open the door.

#### INTELLIGENT KEY FUNCTIONS

It is possible to lock/unlock all doors, fuelfiller door and trunk lid by pushing the request switch on the outside door handles and the trunk lid.



- If the Intelligent Key is too close to the door glass, handle or rear bumper, the request switches may not function.
- When the Intelligent Key is within the operating range, it is possible for anyone who does not carry the Intelligent Key to push the request switch to lock/unlock the doors.



## Intelligent Key operating range

The Intelligent Key functions can only be used when the Intelligent Key is within the specified operating range from the request switch. The operating range is within 31.50 in (80 cm) from each request switch.

#### NOTE:

 When the Intelligent Key battery is discharged or strong radio waves are present near the operating location, the Intelligent Key system's operating range becomes narrower, and the Intelligent Key may not function properly.

## **Intelligent Key operation**

You can lock or unlock the doors without taking the key out from your pocket or bag.



When you carry the Intelligent Key with you, you can lock or unlock all doors by pushing the door handle request switch (A) within the range of operation.

#### NOTE:

- When the driver's door is locked or unlocked, the fuel-filler door is automatically locked or unlocked at the same time.
- When you lock or unlock the doors or the trunk lid, the hazard indicator will flash and the horn (or the outside chime) will sound as a confirmation. ( > "Setting hazard indicator and horn mode" page 3-14)

## Locking doors:

- 1. Move the shift lever to the **P** position, push the ignition switch to the OFF position and make sure you carry the Intelligent Key with you.
- Close all the doors.
- 3. Push the driver's or front passenger's door handle request switch while carrying the Intelligent Key with you.
- 4. All the doors will lock.
- 5. The hazard indicator flashes twice and the outside chime sounds twice.

#### NOTE:

- Doors will lock with the Intelligent Key while the ignition switch is in the ACC or ON position.
- Doors will not lock with the Intelligent Key while any door is open.
- Doors will not lock by pushing the door handle request switch with the Intelligent Key inside the vehicle. However, when an Intelligent Key is inside the vehicle, doors can be locked with another registered Intelligent Key.

#### Unlocking doors:

Push the driver's or front passenger's door handle request switch once while carrying the Intelligent Key with

#### vou.

- The hazard indicator flashes once and outside chime sounds once. The corresponding door will unlock.
- 3. Push the door handle request switch again within 1 minute.
- 4. The hazard indicator flashes once and outside chime sounds once again. All the doors will unlock.

#### NOTE:

All doors will be locked automatically unless one of the following operations is performed within 1 minute after pushing the request switch while the doors are locked. If during this 1-minute time period, the request switch is pushed, all doors will be locked automatically after another 1 minute.

- Opening any door
- Pushing the ignition switch





#### Opening trunk lid:

- 1. Push the trunk open request switch (A) for more than 1 second.
- 2. The trunk will unlatch. An outside chime will sound four times.
- 3. Raise the trunk lid to open the trunk.

#### NOTE:

- To prevent the Intelligent Key from being accidentally locked in the trunk, lockout protection is equipped with the Intelligent Key system.
- When the trunk lid is closed with the Intelligent Key inside the trunk, the outside buzzer will sound and the trunk will open.

### **Battery saver system**

When all the following conditions are met for a period of time, the battery saver system will cut off the power supply to prevent battery discharge.

- The ignition switch is in the ACC position, and
- All doors are closed, and
- The shift lever is in the **P** position.

#### REMOTE KEYLESS ENTRY SYSTEM

It is possible to lock/unlock all doors, fuelfiller door, and activate the panic alarm by pushing the buttons on the Intelligent Key.


#### NOTE:

Before locking the doors, make sure the Intelligent Key is not left in the vehicle.

## Remote keyless entry operating range

The LOCK/UNLOCK button on the Intelligent Key can operate at a distance of approximately 33 ft (10 m) from the vehicle. (The effective distance depends upon the conditions around the vehicle.) The lock and unlock buttons on the Intelligent Key will not operate when:

- the distance between the Intelligent Key and the vehicle is over 33 ft (10 m).
- the Intelligent Key battery runs down. The LOCK/UNLOCK operating range varies depending on the environment. To securely operate the lock and unlock buttons, approach the vehicle to about 3 ft (1 m) from the door.



## Remote keyless entry operation

#### NOTE:

- When the driver's door is locked or unlocked, the fuel-filler door is automatically locked or unlocked at the same time.
- When you lock or unlock the doors or the trunk lid, the hazard indicator will flash and the horn (or the outside chime) will sound as a confirmation. ( "Setting hazard indicator and horn mode" page 3-14)

## **Locking doors:**

- Move the shift lever to the position, push the ignition switch to the OFF position, and make sure you carry the Intelligent Key with you.
- 2. Close all the doors.
- 3. Push the LOCK ♠ button ① on the Intelligent Key.
- 4. All the doors will lock.
- 5. The hazard indicator flashes twice and the horn chirps once.

#### NOTE:

- Doors will lock with the Intelligent Key while the ignition switch is in the ACC or ON position.
- Doors will not lock with the Intelligent Key while any door is open.

## **Unlocking doors:**

- 1. Push the UNLOCK abutton ② on the Intelligent Key once.
- The hazard indicator flashes once. The driver's door will unlock.
- Push the UNLOCK button ② on the Intelligent Key again within 60 seconds.
- 4. The hazard indicator flashes once again. All the doors will unlock.

All doors will be locked automatically unless one of the following operations is

performed within 1 minute after pushing the UNLOCK button on the Intelligent Key while the doors are locked. If during this 1minute time period, the UNLOCK button on the Intelligent Key is pushed, all doors will be locked automatically after another 1 minute.

- Opening any door
- Pushing the ignition switch

## Opening trunk lid:

- Push the TRUNK button 3 on the Intelligent Key for more than 1 second.
- 2. The trunk will unlatch.
- 3. Raise the trunk lid to open the trunk.

## Using panic alarm:

If you are near your vehicle and feel threatened, you may activate the alarm to call attention as follows:

- Push the PANIC Double button @ on the Intelligent Key for more than 1 second.
- The theft warning alarm and headlights will stay on for 25 seconds.
- 3. The panic alarm stops when:
  - It has run for 25 seconds, or
  - Any of the buttons on the Intelligent Key are pushed. (Note: the panic button should be pushed for more than 1 second to turn the

panic alarm off.)

## SETTING HAZARD INDICATOR AND **HORN MODE**

This vehicle is set in hazard indicator and horn mode when you first receive the vehicle.

When you lock/unlock the doors, the hazard indicator will flash and the horn (or the outside chime) will sound as a confirmation.

The following descriptions show how the hazard indicator and horn will activate when locking/unlocking the doors and how the horn feature can be deactivated.

## Hazard indicator and horn mode

	DOOR LOCK	DOOR UNLOCK	TRUNK UNLOCK
Intelligent Key system (Using door handle request switch or trunk open re- quest switch)	HAZARD - <b>twice</b> OUTSIDE CHIME - <b>twice</b>	HAZARD - once OUTSIDE CHIME - once	HAZARD - none OUTSIDE CHIME - 4 times
Remote keyless entry system (Using 🔒 , 🝙 or	HAZARD - <b>twice</b> HORN - <b>once</b>	HAZARD - <b>once</b> HORN - none	HAZARD - none HORN - none


#### Hazard indicator mode

	DOOR LOCK	DOOR UNLOCK	TRUNK UNLOCK
Intelligent Key system (Using door handle request switch or trunk open re- quest switch)	HAZARD - <b>twice</b>	HAZARD - none	HAZARD - none
Remote keyless entry system (Using 🔒 , 🝙 or	HAZARD - <b>twice</b>	HAZARD - none	HAZARD - none

## Switching procedure

The horn beep feature can be deactivated with the following procedures.

- 1. Push the LOCK 🔒 and UNLOCK 🔒 buttons simultaneously for more than 2 seconds.
- 2. The hazard indicator flashes 3 times.
- 3. The horn beep feature will be deactivated (Hazard indicator mode).
- 4. To reactivate the horn beep feature (Hazard indicator and horn mode), push the buttons once more. The hazard indicator flashes once and the horn beeps once.



#### WARNING SIGNALS


To help prevent the vehicle from moving unexpectedly due to an erroneous operation of the Intelligent Key listed on the following chart or to help prevent the vehicle from being stolen, a chime or beep sounds inside and outside the vehicle and a warning displays in the vehicle information display. (京軍"Warning display" page 2-36) (译 "Operation displays" page 2-45)

When a chime or beep sounds or a warning displays, be sure to check the vehicle and the Intelligent Key.

## TROUBLESHOOTING GUIDE


	Symptom	Possible cause	Action to take
When pushing the ignition switch to stop the engine	The SHIFT P warning appears on the display and the inside warning chime sounds continuously.	The shift lever is not in the position.	Shift the shift lever to the position.
When opening the driver's	The inside warning chime sounds continu-	The ignition switch is in the ACC position.	Push the ignition switch to the OFF position.
door to get out of the vehi- cle	ously.	The Intelligent Key is in the Intelligent Key port.	Remove the Intelligent Key from the Intelligent Key port.
When closing the door after	The NO KEY warning appears on the display, the outside chime sounds 3 times and the inside warning chime sounds for approximately 3 seconds.	The ignition switch is in the ACC or ON position.	Push the ignition switch to the OFF position.
getting out of the vehicle	The SHIFT P warning appears on the display and the outside chime sounds continuously.	The ignition switch is in the ACC or OFF position and the shift lever is not in the position.	Move the shift lever to the position and push the ignition switch to the OFF position.
When closing the door with the inside lock knob turned to LOCK	The outside chime sounds for approximately 3 seconds and all the doors unlock.	The Intelligent Key is inside the vehicle or trunk.	Carry the Intelligent Key with you.
When pushing the door		The Intelligent Key is inside the vehicle or trunk.	Carry the Intelligent Key with you.
handle request switch to	2 Seconds.	A door is not closed securely.	Close the door securely.
lock the door		The door handle request switch is pushed before the door is closed.	Push the door handle request switch after the door is closed.
When closing the trunk lid	The outside chime sounds for approximately 10 seconds and the trunk lid opens.	The Intelligent Key is inside the trunk.	Carry the Intelligent Key with you.

## HOOD




## **OPENING THE HOOD**

1. Pull the hood lock release handle (1) located below the instrument panel. The hood will then spring up slightly.



2. Pull the lever ② at the front of the hood with your fingertips and raise the hood.



3. Grasp the insulated part of the stay ③ and release it from the hook, then securely insert it into the hood hole @.

## **WARNING**

If you see steam or smoke coming from the engine compartment, do not open the hood. Doing so could cause injury.

## **CAUTION**

- Do not insert hands, clothing, tools or other items into the engine compartment while the engine is running.
- Do not touch the exhaust system parts, radiator or other hot parts until the engine and the parts have cooled.

### **NOTICE**

Do not open the hood while the wiper arms are lifted away from the windshield. The hood and wipers will be damaged.



#### **CLOSING THE HOOD**

- 1. While supporting the hood, store the stay to the original position.
- 2. Slowly lower the hood. When it is at a height of 1 ft (30 cm) or higher, drop the hood and make sure that both sides of the hood securely lock in place.

## **WARNING**

 Make sure the hood is completely closed and latched before driving. Failure to do so could cause the hood to open and result in an

#### accident.

Be sure to check that the hood is securely closed before driving. If both sides of the hood are not locked in place, the hood may open during driving, possibly causing an accident.

## **CAUTION**

When closing the hood, lower it slowly so that hands or other items do not get caught.

#### NOTE:

Because the hood of this vehicle reguires more force to close than that for other vehicles, the hood will be difficult to close if you lower it all the way and then attempt to press it closed. Be sure to drop the hood from a height of approximately 1 ft (30 cm) and be sure that both sides securely lock in place.

## **WARNING**

- Do not drive with the trunk lid open. This could allow dangerous exhaust gases to be drawn into the vehicle. ( > "Exhaust gas (carbon monoxide)" page 5-3)
- Closely supervise children when they are around cars to prevent them from playing and becoming locked in the trunk where they could be seriously injured. Keep the car locked, with the trunk closed, when not in use, and prevent children's access to Intelligent Keys.




#### TRUNK OPEN REQUEST SWITCH

The trunk lid can be opened by pushing the trunk open request switch (A) when the Intelligent Key is within the operating range of the trunk lock/unlock function regardless of the inside lock knob position. ( ) "Intelligent Key system" page 3-8)



#### TRUNK LID RELEASE SWITCH

Press the trunk lid release switch to unlock the trunk.



valet and keep the mechanical key with you. ( \*\* "Valet hand-off" page 3-3) To connect the power to the trunk lid, push the switch to the ON position 2.



Except for carbon trunk lid models

## TRUNK RELEASE POWER CANCEL **SWITCH**

When the switch located inside the glove box is in the OFF position (1), the power to the trunk lid will be canceled and the trunk lid cannot be opened by the trunk lid release switch, the trunk open request switch or the TRUNK button on the Intelligent Key.

When you have to leave the vehicle with a valet and want to keep your belongings safe in the glove box and the trunk, push this switch to OFF and lock the glove box with the mechanical key. Then leave the vehicle and the Intelligent Key with the



For carbon trunk lid models

## **OPENING AND CLOSING THE TRUNK**

When opening the trunk, first unlock it then lift up the trunk lid so that it is fully open.

When closing the trunk, lower the trunk lid and press it until it is securely locked in place. The strap (A) (except for carbon trunk lid models) or the handle (B) (for carbon trunk lid models) can be used when the trunk lid is dirtv.


## **NOTICE**

- Open and close the trunk without grasping the rear spoiler. Grasping the rear spoiler to open or close the trunk may damage the spoiler.
- Do not leave the key inside the trunk.

#### NOTE:

• To prevent the Intelligent Key from being accidentally locked in the trunk, lockout protection is equipped with the Intelligent Kev system. When the trunk lid is closed with the Intelligent Key inside the trunk, the outside buzzer will sound and the trunk will open.

The trunk of this vehicle is slightly more difficult to close than an ordinary vehicle (particularly when the vehicle is new). This is because the trunk rigidity has been increased to handle the high load on the rear spoiler during vehicle operation. This does not indicate that there is a malfunction. Check that the trunk is securely locked.



#### **EMERGENCY TRUNK LID RELEASE**

## **WARNING**

Closely supervise children when they are around cars to prevent them from playing and becoming locked in the trunk where they could be seriously injured. Keep the car locked, with the trunk lid securely latched, when not in use, and prevent children's access to Intelligent Kevs.


The emergency trunk lid release mechan-

ism allows opening of the trunk lid in the event that people become locked inside the trunk or in the event of the loss of electrical power such as a discharged battery.

#### Inside the trunk

To open the trunk lid from the inside, pull the release handle ① until the lock releases and push up on the trunk lid. The release lever is made of a material that glows in the dark after a brief exposure to ambient light.

The handle is located on the back of the trunk lid as illustrated.



## From the passenger compartment

The trunk can be opened with the emergency trunk lid opener located on the floor in front of the passenger's seat.

Remove the board located on the floor in front of the passenger's seat.



2. Insert the mechanical key into the emergency trunk lid opener and turn it clockwise until it stops.

#### NOTE:

Because the trunk rigidity has been increased to handle the high load on the rear spoiler during vehicle operation, more force is required to operate the mechanical key (particularly when the vehicle is new). Be sure to turn the key clockwise until it stops.

#### **FUEL-FILLER DOOR**

The fuel-filler door is located on the right and rear side of the vehicle.

## **WARNING**

- Gasoline is extremely flammable and highly explosive under certain conditions. You could be burned or seriously injured if it is misused or mishandled. Always stop engine and do not smoke or allow open flames or sparks near the vehicle when refueling.
- Do not attempt to top off the fuel tank after the fuel pump nozzle shuts off automatically. Continued refueling may cause fuel overflow, resulting in fuel spray and possibly a fire.
- Use only an original equipment type fuel-filler cap as a replacement. It has a built-in safety valve needed for proper operation of the fuel system and emission control system. An incorrect cap can result in a serious malfunction and possible injury. It could also cause the malfunction indicator light to come on.
- Never pour fuel into the throttle body to attempt to start your

vehicle.

- Do not fill a portable fuel container in the vehicle or trailer. Static electricity can cause an explosion of flammable liquid, vapor or gas in any vehicle or trailer. To reduce the risk of serious injury or death when filling portable fuel containers:
  - Always place the container on the ground when filling.
  - Do not use electronic devices when filling.
  - Keep the pump nozzle in contact with the container while you are filling it.
  - Use only approved portable fuel containers for flammable liquid.

#### NOTICE

- If fuel is spilled on the vehicle body, flush it away with water to avoid paint damage.
- Insert the cap straight into the fuel-filler tube, then tighten until the fuel-filler cap clicks. Failure to

tighten the fuel-filler cap properly may cause the Malfunction Indicator Light (MIL) to illuminate. If the light illuminates because the fuel-filler cap is loose or missing, tighten or install the cap and continue to drive the vehicle. The light should turn off after a few driving trips. If the light does not turn off after a few driving trips, it is recommended you have the vehicle inspected by a GT-R certified NISSAN dealer.


( \*\*Malfunction Indicator Light (MIL)" page 2-32)

 This vehicle includes a system that can supply fuel even during high-G (gravity) turns. The fuel tank pressure is higher when the vehicle is hot. If the vehicle is refueled when the vehicle is hot, the fuel pump may automatically shut off before the tank is full. This does not indicate that there is a malfunction.

#### **OPENING THE FUEL-FILLER DOOR**

- 1. Unlock the fuel-filler door by using one of the following operations.
  - · Push the door handle request switch with the Intelligent Key carried with you.
  - · Push the UNLOCK button on the Intelligent Key.
  - Push the power door lock switch to the UNLOCK position.







3. Turn the cap ① slowly counterclockwise to remove it.

During refueling, place the cap on the inside of the door 2.

## **CLOSING THE FUEL-FILLER DOOR**

- 1. Turn the cap clockwise until a single click sound is heard.
- 2. Close the door. Lock the fuel-filler door by using one of the following operations.
- Push the door handle request switch with the Intelligent Key carried with you.
- Push the LOCK button on the Intelli-

aent Kev.

 Push the power door lock switch to the LOCK position.

#### NOTE:

After a single click is heard and the cap is released it may move slightly. This is not a malfunction.

#### STEERING WHEEL

## **WARNING**

- Do not adjust the steering wheel while driving. You could lose control of your vehicle and cause an accident.
- Do not adjust the steering wheel any closer to you than is necessary for proper steering operation and comfort. The driver's air bag inflates with great force. If you are unrestrained, leaning forward, sitting sideways or out of position in any way, you are at greater risk of injury or death in a crash. You may also receive serious or fatal injuries from the air bag if you are up against it when it inflates. Always sit back against the seatback and as far away as practical from the steering wheel. Always use the seat belts.




## TILT/TELESCOPIC STEERING COL-UMN

## Tilt adjustment


This adjusts up/down the position of the steering wheel.

- 1. Press lever (A) down (1).
- 2. Move the steering wheel up/down ② and stop it in an appropriate position.
- 3. Lift up lever (A) to lock the steering wheel in position 3.

#### **SUN VISORS**



#### **MIRRORS**



## Telescopic adjustment

This adjusts the forward/backward position of the steering wheel.

- 1. Press lever ® down ①.
- Move the steering wheel forward/ backward ② and stop it in an appropriate position.
- 3. Lift up lever ® to lock the steering wheel in position ③.

Lower the sun visor to block sunlight coming from the forward direction.

To block sunlight coming from the side, lower the sun visor, then unclip it from the hook and move it to the side.

## **INSIDE MIRROR**

The inside mirror is designed so that it automatically changes reflection according to the intensity of the headlights of the following vehicle.

The anti-glare system will be automatically turned on when the ignition switch is pushed to the ON position.


When the anti-glare system is turned on, the indicator light (a) will illuminate and excessive glare from the headlights of the vehicle behind you will be reduced.

Push the " $\bigcirc$ " switch  $\bigcirc$  to make the inside rearview mirror operate normally. The indicator light will turn off. Push the "I"

switch (1) to turn the system on.

#### **NOTICE**

Do not allow any object to cover the sensors (E) or apply glass cleaner on them. Doing so will reduce the sensitivity of the sensor, resulting in improper operation.



#### **OUTSIDE MIRRORS**

## **WARNING**

Objects viewed in the outside mirror on the passenger side are closer than they appear. Be careful when moving to the right. Using only this mirror could cause an accident. Use the inside mirror or glance over your shoulder to properly judge distances to other objects.


The outside mirror will operate only when the ignition switch is in the ACC or ON position.

## Adjusting the outside mirrors

- 1. Turn the switch right or left to select the right or left side mirror 1).
- 2. Operate the control switch ② to adjust the mirror angle.

## **WARNING**

Adjust the mirrors before starting to drive. Adjusting the mirrors during driving is dangerous as it reduces the driver's attention to the forward direction.



## Folding the outside mirrors

Push the switch down 2 to fold the outside mirrors.

Push the switch up 1) to unfold the mirrors before driving.

## **CAUTION**

- Do not touch the mirrors while they are moving. Your hand may be pinched, and the mirror may malfunction.
- Do not drive with the mirrors stored. You will be unable to see

behind the vehicle.

If the mirrors were folded or unfolded by hand, there is a chance that the mirror will move forward or backward during driving. If the mirrors were folded or unfolded by hand, be sure to adjust them again electrically before driving.

#### NOTE:

- If the switch is operated continuously, the mirror may stop before movement is completed. This does not indicate that there is a malfunction. Wait a few moments, then operate the switch again.
- If the mirrors were folded or unfolded by hand, the mirrors may start moving when the ignition switch is set to the ACC or ON position.
- When the ignition switch is in the ON position, operating the rear window defroster will also remove frost and fog from the outside mirrors. ( The "Rear window defroster switch"

page 2-52)



## **VANITY MIRROR**

To use the front vanity mirror, pull down the sun visor and pull up the cover.

## **MEMO**

# 4 Display screen, heater, air conditioner and audio systems

Multi Function Display Owner's Manual	4-2	Ventilators
RearView Monitor	4-2	Center vent
RearView Monitor system operation	4-3	Side ventilat
How to read the displayed lines	4-3	Heater and air
Difference between predictive and		Automatic a
actual distances	4-3	Operating ti
How to park with predictive course lines	4-5	In-cabin mid
Adjusting the screen	4-6	Servicing air
How to turn on and off predictive		Antenna
course lines	4-7	Window ant
Sonar indicator	4-7	Satellite ant
RearView Monitor system limitations	4-7	Car phone or C
System Maintenance	4-8	

/entilators	4-9
Center ventilators	4-9
Side ventilators	4-9
Heater and air conditioner	4-10
Automatic air conditioner	4-11
Operating tips	4-13
In-cabin microfilter	4-13
Servicing air conditioner	4-14
Antenna	4-14
Window antenna	4-14
Satellite antenna	4-15
Car phone or CB radio	4-15

## **MULTI FUNCTION DISPLAY** OWNER'S MANUAL

Refer to the separate Multi Function Display Owner's Manual that includes the following information.

- Multi function display system
- Settings
- Audio system
- Bluetooth® Hands-Free Phone System
- NissanConnect® Services powered by SiriusXM®
- SiriusXM® Travel Link
- SiriusXM Traffic<sup>TM</sup>
- Apple CarPlav®
- Navigation
- Voice recognition
- Multi function meter

#### **REARVIEW MONITOR**

## **WARNING**

Failure to follow the warnings and instructions for proper use of the RearView Monitor system could result in serious injury or death.


- The RearView Monitor is a convenience but it is not a substitute for proper backing. Always turn and look out the windows, and check mirrors to be sure that it is safe to move before operating the vehicle. Always back up slowly.
- The system is designed as an aid to the driver in showing large stationary objects directly behind the vehicle, to help avoid damaging the vehicle.
- The distance guide line and the vehicle width line should be used as a reference only when the vehicle is on a level paved surface. The distance viewed on the monitor is for reference only and may be different than the actual distance between the vehicle and displayed objects.

## **CAUTION**

Do not scratch the camera lens when cleaning dirt or snow from the front of the camera.

The RearView Monitor system automatically shows a rear view of the vehicle when the shift lever is placed in the R position.


The radio can still be heard while the RearView Monitor is active.



To display the rear view, the RearView Monitor system uses a camera (1) located just above the vehicle's license plate.

## **REARVIEW MONITOR SYSTEM OP-ERATION**

With the ignition switch in the ON position, move the shift lever to the R position to operate the RearView Monitor.



## **HOW TO READ THE DISPLAYED** LINES

Guiding lines which indicate the vehicle width and distances to objects with reference to the bumper line (A) are displayed on the monitor.

## Distance guide lines:

Indicate distances from the bumper.

- Red line ①: approx. 1.5 ft (0.5 m)
- Yellow line (2): approx. 3 ft (1 m)
- Green line 3: approx. 7 ft (2 m)
- Green line (4) (if so equipped): approx. 10 ft (3 m)

## Vehicle width quide lines (5):

Indicates the approximate vehicle width.

#### Predictive course lines @:

Indicate the predictive course when backing up. The predictive course lines will be displayed on the monitor when the shift lever is in the R position and the steering wheel is turned. The predictive course lines will move depending on how much the steering wheel is turned and will not be displayed while the steering wheel is in the neutral position.

The vehicle width guide lines and the width of the predictive course lines are wider than the actual width and course.

## **DIFFERENCE BETWEEN PREDIC-TIVE AND ACTUAL DISTANCES**


The displayed guide lines and their locations on the ground are for approximate reference only. Objects on uphill or downhill surfaces or projecting objects will be actually located at distances different from those displayed in the monitor relative to the guide lines (refer to illustrations). When in doubt, turn around and view the objects as you are backing up, or park and exit the vehicle to view the positioning of objects behind the vehicle.











## Backing up on a steep uphill

When backing up the vehicle up a hill, the distance guide lines and the vehicle width guide lines are shown closer than the actual distance. Note that any object on the hill is further than it appears on the monitor.


## Backing up on a steep downhill

When backing up the vehicle down a hill, the distance guide lines and the vehicle width guide lines are shown further than the actual distance. Note that any object on the hill is closer than it appears on the monitor.

# Backing up near a projecting object

The predictive course lines (a) do not touch the object in the display. However, the vehicle may hit the object if it projects over the actual backing up course.

4-4 Display screen, heater, air conditioner and audio systems




position (A) if the object projects over the actual backing up course.

## HOW TO PARK WITH PREDICTIVE **COURSE LINES**

## **WARNING**

- If the tires are replaced with different sized tires, the predictive course line may not be displayed correctly.
- On a snow-covered or slipperv road, there may be a difference between the predictive course line and the actual course line.







- 1. Visually check that the parking space is safe before parking your vehicle.
- 2. The rear view of the vehicle is displayed on the screen (a) when the shift lever is moved to the R position.

## Backing up behind a projecting object

The position © is shown further than the position (B) in the display. However, the position © is actually at the same distance as the position (A). The vehicle may hit the object when backing up to the





to the predictive course lines.

When the vehicle is parked in the space completely, move the shift lever in an appropriate gear and apply the parking brake.



#### **ADJUSTING THE SCREEN**

- While on a RearView Monitor screen, touch the touch screen display. The Camera Settings screen will come up.
- 2. Touch the "Display Settings" key.
- 3. Touch the "Brightness", "Contrast", "Tint", "Color" or "Black Level" key.
- Adjust the item by touching the "+" or "—" key on the touch screen display.

#### NOTE:

Do not adjust any of the display settings of the RearView Monitor while the vehicle is moving. Make sure the parking brake is firmly applied.

#### 4-6 Display screen, heater, air conditioner and audio systems

# HOW TO TURN ON AND OFF PREDICTIVE COURSE LINES

If the RearView Monitor is in operation and the rear view is displayed, turn on and off the predictive course line setting according to the following procedure.

- 1. Touch the touch screen display.
- 2. Touch the "Predictive Course Lines" key to turn the feature on or off.



If the RearView Monitor is not in operation, change the setting according to the following procedure.

- Touch the "Settings" key on the Launch Bar (a) on the touch screen display.
- 2. Touch the "Camera" key.
- Touch the "Predictive Course Lines" key. The indicator illuminates when the item is turned on.

#### SONAR INDICATOR

The sonar indicator will appear in the RearView Monitor display. ( \*\*Sonar system" page 5-48)

### REARVIEW MONITOR SYSTEM LIM-ITATIONS

## **A** WARNING

Listed below are the system limitations for RearView Monitor. Failure to operate the vehicle in accordance with these system limitations could result in serious injury or death.


- The system cannot completely eliminate blind spots and may not show every object.
- Underneath the bumper and the corner areas of the bumper cannot be viewed on the RearView Monitor because of its monitoring range limitation. The system will not show small objects below the bumper, and may not show objects close to the bumper or on the ground.
- Objects viewed in the RearView Monitor differ from actual distance because a wide-angle lens

is used.

- Objects in the RearView Monitor will appear visually opposite compared to when viewed in the rearview and outside mirrors.
- Use the displayed lines as a reference. The lines are highly affected by the number of occupants, fuel level, vehicle position, road conditions and road grade.
- Make sure that the trunk lid is securely closed when backing up.
- Do not put anything on the rearview camera. The rearview camera is installed above the license plate.
- When washing the vehicle with high-pressure water, be sure not to spray it around the camera. Otherwise, water may enter the camera unit causing water condensation on the lens, a malfunction, fire or an electric shock.
- Do not strike the camera. It is a precision instrument. Otherwise, it may malfunction or cause damage resulting in a fire or an electric shock.

The following are operating limitations and do not represent a system malfunction:

- When the temperature is extremely high or low, the screen may not clearly display objects.
- When strong light is directly coming on the camera, objects may not be displayed clearly.
- Vertical lines may be seen in objects on the screen. This is due to strong reflected light from the bumper.
- The screen may flicker under fluorescent light.
- The colors of objects on the RearView Monitor may differ somewhat from the actual color of objects.
- Objects on the monitor may not be clear in a dark environment.
- There may be a delay when switching to the RearView Monitor screen.
- If dirt, rain or snow accumulates on the camera, the RearView Monitor may not display objects clearly. Clean the camera.
- Do not use wax on the camera window. Wipe off any wax with a clean cloth dampened with mild detergent diluted with water.




### SYSTEM MAINTENANCE

# **A** CAUTION

- Do not use alcohol, benzine or thinner to clean the camera. This will cause discoloration. To clean the camera, wipe with a cloth dampened with diluted mild cleaning agent and then wipe with a dry cloth.
- Do not damage the camera as the monitor screen may be adversely affected.

### If dirt, rain or snow accumulates on the camera ①, the RearView Monitor may not display objects clearly. Clean the camera by wiping it with a cloth dampened with a diluted mild cleaning agent and then wiping it with a dry cloth.

### **VENTILATORS**





### **CENTER VENTILATORS**

Adjust the air flow direction of the ventilators by moving the center knob (up/ down, left/right) until the desired position is achieved

### SIDE VENTILATORS

Turning the center knob clockwise or counterclockwise will close or open the ventilators.

Adjust the air flow direction by moving the ventilators until the desired position is achieved.

### **HEATER AND AIR CONDITIONER**

# **WARNING**

- The air conditioner cooling function operates only when the engine is running.
- Do not leave children or adults who would normally require the support of others alone in your vehicle. Pets should not be left alone either. On hot, sunny days, temperatures in a closed vehicle could quickly become high enough to cause severe or possibly fatal injuries to people or animals.
- Do not use the recirculation mode for long periods as it may cause the interior air to become stale and the windows to fog up.


Start the engine and operate the heater and air conditioner system.

#### NOTE:

- Odors from inside and outside the vehicle can build up in the air conditioner unit. Odor can enter the passenger compartment through the vents.
- When parking, set the heater and air conditioner controls to turn off air

recirculation to allow fresh air into the passenger compartment. This should help reduce odors inside the vehicle.

4-10 Display screen, heater, air conditioner and audio systems



- 1. front defroster button
- Temperature control dial (driver's side)/ AUTO (automatic) button
- 3. Display screen
- Temperature control dial (passenger's side)/DUAL zone control button
- 5. So outside air circulation button
- 6. [[] rear window defroster button ( 文章 "Rear window defroster switch" page 2-52)
- 7. ON-OFF button
- 8. 🐉 fan speed control button
- 9. MODE (manual air flow control) button
- 10. A/C (air conditioner) button
- 11. ( air recirculation button

### **AUTOMATIC AIR CONDITIONER**

# **Automatic operation**

# Cooling and/or dehumidified heating (AUTO):

This mode may be used all year round as the system automatically works to keep a constant temperature. Air flow distribution and fan speed are also controlled automatically.

- Push the AUTO button on. (The indicator light on the button will illuminate.)
- 2. Turn the temperature control dial on the driver's side to the left or right to

set the desired temperature.

- The temperature of the passenger compartment will be maintained automatically. Air flow distribution and fan speed are also controlled automatically.
- A visible mist may be seen coming from the vents in hot, humid conditions as the air is cooled rapidly. This does not indicate a malfunction
- 3. You can individually set driver's and front passenger's side temperature using each temperature control dial. When the DUAL zone control button is pushed or the passenger's side temperature control dial is turned, the indicator light on the DUAL zone control button will come on. To turn off the passenger's side temperature control, push the DUAL zone control button.

### Heating (A/C OFF):

The air conditioner does not activate in this mode. Only use this mode when you need to heat the vehicle.

- Push the AUTO button on. (The indicator light on the button will illuminate.)
- 2. If the indicator light on the A/C button

is turned on, push the A/C button. (The indicator light will turn off.)

- Turn the temperature control dial on the driver's side to set the desired temperature.
  - The temperature of the passenger compartment will be maintained automatically. Air flow distribution and fan speed are also controlled automatically.
  - Do not set the temperature lower than the outside air temperature or the system may not work properly.
  - Not recommended if windows fog up.
- 4. You can individually set driver's and front passenger's side temperature using each temperature control dial. When the DUAL zone control button is pushed or passenger's side temperature control dial is turned, the DUAL indicator light will come on. To turn off the passenger's side temperature control, push the DUAL zone control button.

### Dehumidified defrosting or defogging:

- Push the front defroster button on. (The indicator light on the button will come on.)
- 2. Turn the temperature control dial on

the driver's side to set the desired temperature.

- To quickly remove ice from the outside of the windows, use the fan speed control button to set the fan speed to maximum.
- As soon as possible after the windshield is clean, push the AUTO button to return to the automatic mode.

When the  $\ \varpi$  front defroster button is pushed, the air conditioner will automatically be turned on at outside temperatures above 36°F (2°C) to defrost the windshield, and the air recirculation mode will automatically be turned off. Outside air is drawn into the passenger compartment to improve the defrosting performance.

### Manual operation

### Fan speed control:

Push the 🐓 fan speed control button to manually control the fan speed.

Push the AUTO button to return to automatic control of the fan speed.

#### Air intake control:

Push the 
 air recirculation button
to recirculate interior air inside the
vehicle. The 
 indicator light on the

button will come on.

- Push the so outside air circulation button to draw outside air into the passenger compartment. The so indicator light on the button will come on
- To switch to automatic control mode, push and hold the so air recirculation button or the so outside air circulation button (whichever one with an indicator light illuminated) for about 2 seconds. The indicator lights (both air recirculation and outside air circulation buttons) will flash twice, and then the air intake will be controlled automatically.

#### Air flow control:

Push the MODE button repeatedly to change the air flow mode.


: Air flows from the center and side ventilators

Air flows from the center and side ventilators and the foot outlets.

Air flows mainly from the foot outlets.

Air flows from the defroster and foot outlets.

# Turning the system on/off Push the ON-OFF button.





air flow from the foot outlets may not operate. However, this is not a malfunction. After the coolant temperature warms up, the air flow from the foot outlets will operate normally.

The sensors (A) and (B) located on the instrument panel help maintain a constant temperature. Do not put anything on or around the sensors.

#### **IN-CABIN MICROFILTER**

The air conditioning system is equipped with an in-cabin microfilter which collects dirt, dust, etc. To make sure the air conditioner heats, defogs, and ventilates efficiently, replace the filter in accordance with the maintenance schedule in the "9. Maintenance and schedules" section of this manual. It is recommended to see a NISSAN dealer or GT-R certified NISSAN dealer to replace the filter.

The filter should be replaced if air flow is extremely decreased or when windows fog up easily when operating heater or air conditioning system.

### **OPERATING TIPS**

When the engine coolant temperature and outside air temperature are low, the

### **ANTENNA**

#### SERVICING AIR CONDITIONER

The air conditioning system in your NISSAN is charged with a refrigerant designed with the environment in mind. This refrigerant will not harm the earth's ozone layer. However, special charging equipment and lubricant are required when servicing your NISSAN air conditioner. Using improper refrigerants or lubricants will cause severe damage to your air conditioning system. ( Tapacities and recommended fluids/lubricants" page 10-2)

Your NISSAN dealer or GT-R certified NISSAN dealer will be able to service your environmentally friendly air conditioning system.

# **WARNING**

The system contains refrigerant under high pressure. To avoid personal injury, any air conditioner service should be done only by an experienced technician with the proper equipment.



# WINDOW ANTENNA

The antenna pattern (a) is printed inside the rear window.

# **A** CAUTION

- Do not place metalized film near the rear window glass or attach any metal parts to it. This may cause poor reception or noise.
- When cleaning the inside of the rear window, be careful not to scratch or damage the rear window antenna. Lightly wipe along the antenna with a dampened

soft cloth.



### SATELLITE ANTENNA

The satellite antenna (A) is located on the rear part of the vehicle roof.

### CAR PHONE OR CB RADIO

When installing a car phone or a CB radio in your vehicle, be sure to observe the following cautions, otherwise the new equipment may adversely affect the electronic control modules and electronic control system harness.

# **WARNING**

- A cellular phone should not be used for any purpose while driving so full attention may be given to vehicle operation. Some jurisdictions prohibit the use of cellular phones while driving.
- If you must make a call while your vehicle is in motion, the handsfree cellular phone operational mode (if so equipped) is highly recommended. Exercise extreme caution at all times so full attention may be given to vehicle operation.
- If you are unable to devote full attention to vehicle operation while talking on the phone, pull off the road to a safe location and stop your vehicle.

# **A** CAUTION

- Keep the antenna as far away as possible from the electronic control modules.
- Keep the antenna wire more than 8 in (20 cm) away from the electronic control system harness. Do not route the antenna wire next to any harness.
- Adjust the antenna standingwave ratio as recommended by the manufacturer.
- Connect the ground wire from the CB radio chassis to the body.
- For details, it is recommended vou visit a NISSAN dealer or GT-R certified NISSAN dealer.

# **MEMO**

# 5 Starting and driving

Precautions when starting and driving 5-3	Features of each mode	5-28
Exhaust gas (carbon monoxide) 5-3	Turbocharger system	5-32
Three-way catalyst 5-3	R mode start function	5-33
Tire Pressure Monitoring System (TPMS) 5-4	How to use R mode start function	5-34
Avoiding collision and rollover 5-7	Parking brake	5-34
Off-road recovery 5-8	Cruise control	5-35
Rapid air pressure loss 5-8	Precautions on cruise control	5-35
Drinking alcohol/drugs and driving 5-9	Steering-wheel-mounted controls	5-36
All-Wheel Drive (AWD) driving	Indicators and display	
safety precautions 5-9	Cruise control operations	5-37
Push-button ignition switch 5-10	Hill Start Assist System	5-39
Operating range for engine start 5-10		5-40
Ignition switch operation 5-11		5-40
Ignition switch positions 5-11		5-41
Emergency engine shut off 5-12	Increasing fuel economy	5-42
Intelligent Key battery discharge 5-12	All-Wheel Drive (AWD)	
Before starting the engine 5-13		5-42
Starting the engine 5-14		5-44
Driving the vehicle 5-15	Tires	
Dual clutch transmission 5-15	AWD system characteristics	5-44
Driving tips 5-21	Limited Slip Differential (LSD)	5-45
VDC, transmission and suspension	Parking/parking on hills	5-46
setup switches 5-25		5-48
Usage of each mode 5-25		5-49
How to switch the modes 5-26	Sonar system OFF switch	5-50

Sonar system setting5	5-50	Draining of coolant water	5-57
Power steering 5	5-51	Tire equipment	5-57
Brake system5	5-52	Special winter equipment	5-57
Braking precautions5	5-52	Driving on snow or ice	5-57
Parking brake break-in 5	5-52	Engine block heater (if so equipped)	5-58
Brake assist 5	5-53 E	xhaust sound control system (if	
Anti-lock Braking System (ABS) 5	5-53 S	o equipped)	5-59
Vehicle Dynamic Control (VDC) system 5		ctive noise cancellation (if so equipped)/	
Cold weather driving 5	5-57 A	ctive sound enhancement (if so equipped)	
Freeing a frozen door lock 5	5-57	Active noise cancellation	
Anti-freeze5	5-57	Active sound enhancement	5-60
Battery 5	5-57		

# **WARNING**

- Do not leave children or adults who would normally require the support of others alone in your vehicle. Pets should not be left alone either. They could accidentally injure themselves or others through inadvertent operation of the vehicle. Also, on hot, sunny days, temperatures in a closed vehicle could quickly become high enough to cause severe or possibly fatal injuries to people or animals.
- Closely supervise children when they are around cars to prevent them from playing and becoming locked in the trunk where they could be seriously injured. Keep the car locked, with the rear seatback and trunk lid securely latched when not in use, and prevent children's access to car keys.

### **EXHAUST GAS (carbon monoxide)**

# **WARNING**

- Do not breathe exhaust gases: they contain colorless and odorless carbon monoxide. Carbon monoxide is dangerous. It can cause unconsciousness or death.
- If you suspect that exhaust fumes are entering the vehicle, drive with all windows fully open, and have the vehicle inspected immediately.
- Do not run the engine in closed spaces such as a garage.
- Do not park the vehicle with the engine running for any extended length of time.
- Keep the trunk lid closed while driving, otherwise exhaust gases could be drawn into the passenger compartment. If you must drive with the trunk lid open. follow these precautions:
  - a. Open all the windows.
  - b. Set the ( air recirculation to off and the fan control to high to circulate the air.

- The exhaust system and body should be inspected by a qualified mechanic whenever:
  - The vehicle is raised for service.
  - You suspect that exhaust fumes are entering into the passenger compartment.
  - You notice a change in the sound of the exhaust system.
  - You have had an accident involving damage to the exhaust system, underbody, or rear of the vehicle.

### THREE-WAY CATALYST

The three-way catalyst is an emission control device installed in the exhaust system. Exhaust gases in the three-way catalyst are burned at high temperatures to help reduce pollutants.

# **WARNING**

The exhaust gas and the exhaust system are very hot. Keep people, animals or flammable materials away from the exhaust system components.

Do not stop or park the vehicle over flammable materials such as dry grass, waste paper or rags. They may ignite and cause a fire.

### **NOTICE**

- Do not use leaded gasoline. Deposits from leaded gasoline seriously reduce the three-way catalyst's ability to help reduce exhaust pollutants.
- Keep your engine tuned up. Malfunctions in the ignition, fuel injection, or electrical systems can cause overrich fuel flow into the three-way catalyst, causing it to overheat. Do not keep driving if the engine misfires, or if noticeable loss of performance or other unusual operating conditions are detected. It is recommended you have the vehicle inspected promptly by a GT-R certified NISSAN dealer.
- Avoid driving with an extremely low fuel level. Running out of fuel could cause the engine to misfire. damaging the three-way catalyst.

- Do not race the engine while warming it up.
- Do not push or tow your vehicle to start the engine.

# TIRE PRESSURE MONITORING SYSTEM (TPMS)

Each tire should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label. (If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label, you should determine the proper tire inflation pressure for those tires)

As an added safety feature, your vehicle has been equipped with a Tire Pressure Monitoring System (TPMS) that illuminates a low tire pressure telltale when one or more of your tires is significantly under-inflated. Accordingly, when the low tire pressure telltale illuminates, vou should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability.

If the vehicle is being driven with one or more flat tires, the low tire pressure warning light will illuminate continuously and a chime will sound for 10 seconds. The chime will only sound at the first indication of a flat tire, and the warning light will illuminate continuously. When the flat tire warning is activated, it is recommended you have the system reset and the tire checked and replaced if necessary by a GT-R certified NISSAN dealer. Even if the tire is inflated to the specified COLD tire pressure, the warning light will continue to illuminate until the system is reset. Your vehicle can be driven for a limited time on a flat tire. ( PR "Runflat tires" page 8-36)

Please note that the TPMS is not a substitute for proper tire maintenance. and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale.

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure tell-

tale. When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly. Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

### Additional information

- The TPMS will activate only when the vehicle is driven at speeds above 16 MPH (25 km/h). Also, this system may not detect a sudden drop in tire pressure (for example a flat tire while driving).
- The low tire pressure warning light does not automatically turn off when the tire pressure is adjusted. After the tire is inflated to the recommended

- pressure, the vehicle must be driven at speeds above 16 MPH (25 km/h) to activate the TPMS and turn off the low tire pressure warning light. Use a tire pressure gauge to check the tire pressure.
- The "TIRE LOW PRESSURE VISIT DEALER" warning appears in the vehicle information display when the low tire pressure warning light is illuminated and low tire pressure is detected. The "TIRE LOW PRESSURE -VISIT DEALER" warning turns off when the low tire pressure warning light turns off.

The "TIRE LOW PRESSURE - VISIT DEALER" warning appears each time the ignition switch is placed in the "ON" position as long as the low tire pressure warning light remains illuminated

The "TIRE LOW PRESSURE - VISIT DEALER" warning does not appear if the low tire pressure warning light illuminates to indicate a TPMS malfunction.

 The "FLAT TIRE - VISIT DEALER" warning appears in the vehicle information display when the low tire pressure warning light is illuminated and one or more flat tires are detected.

- on the heat caused by the vehicle's operation and the outside temperature. Do not reduce the tire pressure after driving because the tire pressure rises after driving. Low outside temperature can lower the temperature of the air inside the tire which can cause a lower tire inflation pressure. Altitude can also affect tire pressure warning light to illuminate. If the warning light illuminates, check the tire pressure for all four tires.
- GT-R vehicles are delivered from the factory with nitrogen-filled tires. For best performance, NISSAN recommends that GT-R owners maintain their vehicles by using nitrogen for tire inflation. Because nitrogen is more stable than compressed air, it is less prone to pressure fluctuation resulting from temperature variations. If nitrogen is not available, compressed air may be safely used under normal driving conditions. However, NISSAN recommends refilling with Nitrogen for maximum tire performance.
- The Tire and Loading Information label (also referred to as the vehicle placard or tire inflation pressure label) is located in the driver's door opening.

- You can also check the pressure of all tires on the touch screen display. Refer to the separate Multi Function Display Owner's Manual.
- The tire pressure sensor should be reset anytime the wheels or tires are removed or replaced.
- If the tire is removed in order to replace the tire pressure sensor battery, it may not be possible to reuse the removed tire from the wheel. To replace the tire pressure sensor battery, it is recommended you contact a GT-R certified NISSAN dealer

# **WARNING**

If the low tire pressure warning light illuminates while driving, avoid sudden steering maneuvers or abrupt braking, reduce vehicle speed, pull off the road to a safe location and stop the vehicle as soon as possible. Driving with under-inflated tires may permanently damage the tires and increase the likelihood of tire failure. Serious vehicle damage could occur and may lead to an accident and could result in serious personal injury. Check the tire pressure for all four tires. Adjust the tire pressure to the recommended COLD tire pressure shown on the Tire and Loading Information label to turn the low tire pressure warning light off. If the light still illuminates while driving after adjusting the tire pressure, a tire may be flat ( Run-flat tires" page 6-4) or the TPMS may be malfunctioning. If no tire is flat and all tires are properly inflated, have the vehicle checked. It is recommended you have the vehicle checked by a GT-R certified NISSAN dealer.

- Although you can continue driving with a punctured run-flat tire, remember that vehicle handling stability is reduced, which could lead to an accident and personal injury. Also, driving a long distance at high speeds may damage the tires.
- Do not drive at speeds above 50 MPH (80 km/h) and do not drive more than 50 miles (80 km) with a punctured run-flat tire. The actual distance the vehicle can be driven on a flat tire depends on outside temperature, vehicle load, road

conditions and other factors.

- When a wheel is replaced, the TPMS will not function and the low tire pressure warning light will flash for approximately 1 minute. The light will remain on after 1 minute. It is recommended vou contact vour GT-R certified NISSAN dealer as soon as possible for tire replacement and/or system resetting.
- Replacing tires with those not originally specified by NISSAN could affect the proper operation of the TPMS.
- Do not inject any tire liquid or aerosol tire sealant into the tires. as this may cause a malfunction of the tire pressure sensors.

### NOTICE

- The TPMS may not function properly when the wheels are equipped with tire chains or the wheels are buried in snow.
- The TPMS may not function properly if the TPMS sensor is not reset and when wheels/tires from

another GT-R are installed on vour vehicle.

- The TPMS will not function properly if non-GT-R wheels are installed on the vehicle.
- Do not place metalized film or any metal parts (antenna, etc.) on the windows. This may cause poor reception of the signals from the tire pressure sensors, and the TPMS will not function properly.

Some devices and transmitters may temporarily interfere with the operation of the TPMS and cause the low tire pressure warning light to illuminate. Some examples are:

- Facilities or electric devices using similar radio frequencies are near the vehicle
- If a transmitter set to similar frequencies is being used in or near the vehicle.
- If a computer (or similar equipment) or a DC/AC converter is being used in or near the vehicle.

Low tire pressure warning light may illuminate in the following cases.

- If the vehicle is equipped with a wheel and tire without TPMS.
- If the TPMS has been replaced and the ID has not been registered.
- If the wheel is not originally specified by NISSAN.

#### **FCC Notice:**

#### For USA:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### For Canada:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

### AVOIDING COLLISION AND ROLL-**OVER**

# **WARNING**

Failure to operate this vehicle in a safe and prudent manner may result in loss of control or an accident.

Be alert and drive defensively at all times. Obey all traffic regulations. Avoid excessive speed, high speed cornering, or sudden steering maneuvers, because these driving practices could cause you to lose control of your vehicle. As with any vehicle, a loss of control could result in a collision with other vehicles or objects, or cause the vehicle to rollover, particularly if the loss of control causes the vehicle to slide sideways. Be attentive at all times, and avoid driving when tired. Never drive when under the influence of alcohol or drugs (including prescription or over-the-counter drugs which may cause drowsiness). Always wear your seat belt as outlined in this manual, and also instruct your passengers to do so. ( Seat belts" page 1-6) Seat belts help reduce the risk of injury in collisions and rollovers. In a rollover crash, an unbelted or improperly belted

person is significantly more likely to be injured or killed than a person properly wearing a seat belt.

#### OFF-ROAD RECOVERY

While driving, the right side or left side wheels may unintentionally leave the road surface. If this occurs, maintain control of the vehicle by following the procedure below. Please note that this procedure is only a general guide. The vehicle must be driven as appropriate based on the conditions of the vehicle. road and traffic

- 1. Remain calm and do not overreact.
- 2. Do not apply the brakes.
- 3. Maintain a firm grip on the steering wheel with both hands and try to hold a straight course.
- 4. When appropriate, slowly release the accelerator pedal to gradually slow the vehicle.
- 5. If there is nothing in the way, steer the vehicle to follow the road while the vehicle speed is reduced. Do not attempt to drive the vehicle back onto the road surface until vehicle speed is reduced.
- 6. When it is safe to do so, gradually turn the steering wheel until both tires return to the road surface. When all

tires are on the road surface, steer the vehicle to stay in the appropriate driving lane.

 If you decide that it is not safe to return the vehicle to the road surface based on vehicle, road or traffic conditions, gradually slow the vehicle to a stop in a safe place off the road.

### **RAPID AIR PRESSURE LOSS**

Rapid air pressure loss or a "blow-out" can occur if the tire is punctured or is damaged due to hitting a curb or pothole. Rapid air pressure loss can also be caused by driving on under-inflated tires.

Rapid air pressure loss can affect the handling and stability of the vehicle. especially at highway speeds.

Help prevent rapid air pressure loss by maintaining the correct air pressure and visually inspect the tires for wear and damage. ( Pr "Wheels and tires" page 8-29)

If a tire rapidly loses air pressure or "blows-out" while driving maintain control of the vehicle by following the procedure below. Please note that this procedure is only a general guide. The vehicle must be driven as appropriate based on the conditions of the vehicle, road and traffic.

# **WARNING**

The following actions can increase the chance of losing control of the vehicle if there is a sudden loss of tire air pressure. Losing control of the vehicle may cause a collision and result in personal injury.

- The vehicle generally moves or pulls in the direction of the flat tire.
- Do not rapidly apply the brakes.
- Do not rapidly release the accelerator pedal.
- Do not rapidly turn the steering wheel.
- Remain calm and do not overreact.
- 2. Maintain a firm grip on the steering wheel with both hands and try to hold a straight course.
- 3. When appropriate, slowly release the accelerator pedal to gradually slow the vehicle.
- 4. Gradually steer the vehicle to a safe location off the road and away from traffic if possible.
- 5. Lightly apply the brake pedal to gra-

- dually stop the vehicle.
- 6. Turn on the hazard warning flashers and contact a roadside emergency service to change the tire.

## DRINKING ALCOHOL/DRUGS AND DRIVING

# **WARNING**

Never drive under the influence of alcohol or drugs. Alcohol in the bloodstream reduces coordination. delays reaction time and impairs iudgement. Driving after drinking alcohol increases the likelihood of being involved in an accident injuring vourself and others. Additionally, if vou are injured in an accident, alcohol can increase the severity of the iniurv.

NISSAN is committed to safe driving. However, you must choose not to drive under the influence of alcohol. Every year thousands of people are injured or killed in alcohol-related accidents. Although the local laws vary on what is considered to be legally intoxicated, the fact is that alcohol affects all people differently and most people underestimate the effects of

#### alcohol.

Remember, drinking and driving don't mix! And that is true for drugs, too (overthe-counter, prescription, and illegal drugs). Don't drive if your ability to operate your vehicle is impaired by alcohol. drugs, or some other physical condition.

### ALL-WHEEL DRIVE (AWD) DRIVING **SAFETY PRECAUTIONS**

# **WARNING**

- Do not drive beyond the performance capability of the tires. even with AWD engaged. Accelerating quickly, sharp steering maneuvers or sudden braking may cause loss of control.
- Always use the specified tires on all four wheels. Install tire chains on the rear wheels when driving on slippery roads and drive carefully.
- This vehicle is not designed for offroad (rough road) use. Do not drive on sandy or muddy roads that tires may get stuck in.
- Do not attempt to raise two wheels off the ground and shift

the transmission to any A↔M or position with the engine running. Doing so may result in drivetrain damage or unexpected vehicle movement which could result in serious vehicle damage or personal injury.

- Do not attempt to test an AWD equipped vehicle on a 2-wheel dynamometer, (such as the dynamometers used by some states for emissions testing), or similar equipment even if the other two wheels are raised off the ground. Make sure you inform test facility personnel that your vehicle is equipped with AWD before it is placed on a dynamometer. Using the wrong test equipment may result in drivetrain damage or unexpected vehicle movement which could result in serious vehicle damage or personal injury.
- When a wheel is off the ground due to an unlevel surface, do not spin the wheel excessively.

### **PUSH-BUTTON IGNITION SWITCH**

# **WARNING**

Do not operate the push-button ignition switch while driving the vehicle except in an emergency. (The engine will stop when the ignition switch is pushed three consecutive times or the ignition switch is pushed and held for more than 2 seconds.) If the engine stops while the vehicle is being driven, this could lead to a crash and serious injury.

Before operating the push-button ignition switch, be sure to move the shift lever to the position.




be possible to start the engine.

### **OPERATING RANGE FOR ENGINE START**

The operating range for starting the engine inside the vehicle is shown in the illustration.

- If the Intelligent Key is on the instrument panel, rear parcel shelf, inside the glove box, door pocket, cup holders or console box, or the corner of the passenger compartment, it may not be possible to start the engine. Carry the Intelligent-Key and try to start the engine again.
- If the Intelligent Key is near the door or door glass outside the vehicle, it may



#### **IGNITION SWITCH OPERATION**

When the Intelligent Kev is carried with you and the ignition switch is pushed without depressing the brake pedal, the ignition switch position will change as follows:

- Push center once to change to ACC.
- Push center two times to change to ON.
- Push center three times to change to OFF. (No position illuminates.)
- Push center four times to return to ACC.

 Open or close any door to return to LOCK during the OFF position.

### **IGNITION SWITCH POSITIONS**

# LOCK (Normal parking position)

The ignition switch can only be locked in this position.

The ignition switch will be unlocked when it is pushed to the ACC position while carrying the Intelligent Key or with the Intelligent Key inserted in the port.

## **ACC (Accessories)**

This position activates electrical accessories such as the radio, when the engine is not running.

### ON (Normal operating position)

This position turns on the ignition system and electrical accessories.

### OFF

The engine can be turned off without locking the steering wheel.

The ignition lock is designed so that the ignition switch cannot be switched to the LOCK position until the shift lever is moved to the P position.

#### NOTE:

- If the steering lock release malfunction indicator appears on the vehicle information display when the ignition switch is pressed, press the ignition switch again while gently turning the steering wheel left and right. ( > "Steering lock release malfunction indicator" page 2-47)
- If the shift **P** warning appears on the vehicle information display when the ignition switch is pushed, the shift lever is in any position except the position. Move the shift lever to the position. ( Fr "Shift "P" warning" page 2-46)
- If the Intelligent Key battery discharge indicator appears on the vehicle information display, the Intelligent Key battery is discharged and the ignition switch will not operate. Insert the Intelligent Key into the key port to operate the ignition switch. ( 🎏 "Intelligent Key battery discharge indicator" page 2-48)
- When all of the following conditions are met for 60 minutes, the battery saver system will cut off the power supply to prevent battery discharge.
  - The ignition switch is in the ACC


position, and

- All doors are closed, and
- The shift lever is in the □ position.
- Do not leave the vehicle with the ignition switch in the ACC or ON position when the engine is not running for an extended period of time. This can discharge the battery.

### **EMERGENCY ENGINE SHUT OFF**

To shut off the engine in an emergency situation while driving, perform the following procedure:

- Rapidly push the push-button ignition switch 3 consecutive times in less than 1.5 seconds, or
- Push and hold the push button ignition switch for more than 2 seconds.



### INTELLIGENT KEY BATTERY DIS-CHARGE

If the battery of the Intelligent Key is almost discharged, the guide light (1) of the Intelligent Key port blinks and the indicator appears on the vehicle information display. ( 译 "Intelligent Key insertion indicator" page 2-47)


In this case, inserting the Intelligent Kev into the port allows you to start the engine. Make sure that the mechanical kev side faces backward as illustrated. Insert the Intelligent Key in the port until it is latched and secured

To remove the Intelligent Key from the

port, push the ignition switch to the OFF position and pull the Intelligent Key out of the port.

### NOTICE

Never place anything except the Intelligent Key in the Intelligent Key port. Doing so may cause damage to the equipment.



replacement" page 8-25)

#### NOTE:

- Make sure the Intelligent Kev is in the correct direction when inserting it into the Intelligent Key port. The engine may not start if it is in the incorrect direction.
- Remove the Intelligent Key from the Intelligent Key port after the ignition switch is pushed to the OFF position.
- The Intelligent Key port does not charge the Intelligent Key battery. If you see the low battery indicator in the vehicle information display, replace the battery as soon as possible. ( The "Intelligent Key battery

### BEFORE STARTING THE ENGINE

- Make sure the area around the vehicle is clear.
- · Check fluid levels such as engine oil, coolant, brake fluid and window washer fluid as frequently as possible, or at least whenever you refuel.
- Check that all windows and lights are clean.
- Visually inspect tires for their appearance and condition. Also check tires for proper inflation.
- Lock all doors
- Position seat.
- Adjust inside and outside mirrors.
- Fasten seat belts and ask all passengers to do likewise.
- Check the operation of warning lights when the ignition switch is pushed to the ON position. ( Fig "Warning lights, indicator lights and audible reminders" page 2-26)

### STARTING THE ENGINE

#### NOTE:

- This vehicle includes spark plugs that are designed for maximum performance. If the start time becomes longer, the plugs may be fouled, making the engine difficult to start. If this occurs, start the engine using the procedure described in this section.
- · A click sound may be heard when the brake pedal is depressed and released. This is normal.
- A low rattling operating sound may occur when the engine is started or stopped. This is because of the transmission gear design, light flywheel and dry sump lubrication system used in this transmission. This does not indicate that there is a malfunction. This sound is likely to occur in particular if the engine is stopped when the temperature of the transmission oil is high.



- Check the positions of the accelerator pedal ① and brake pedal ②. Adjust the steering wheel and seat positions so that the correct driving posture is achieved. ( ) "Front seats" page 1-3)
- 2. Check that the parking brake is engaged.
- 3. Check that the shift lever is in the **P** or N position. (P is recommended.)
- 4. Firmly depress the brake pedal. Without depressing the accelerator pedal, push the ignition switch once to start the engine.
- 5. To stop the engine, move the shift lever to the **P** position, and push the ignition switch to the OFF position.

#### NOTE:

- Care should be taken to avoid situations that can lead to potential battery discharge and potential nostart conditions such as:
  - a. Installation or extended use of electronic accessories that consume battery power when the engine is not running (Phone chargers, GPS, DVD players, etc.)
  - b. Vehicle is not driven regularly and/or only driven short distances.

In these cases, the battery may need to be charged to maintain battery health.

- If the engine is difficult to start, depress the accelerator pedal all the way to the floor and hold it. Push the ignition switch with the brake pedal depressed to start cranking the engine. After 5 or 6 seconds, stop cranking by pushing the ignition switch to the OFF position, and then release the accelerator pedal. Then perform steps 1 to 5 to start the engine. If the engine starts, but fails to run, repeat this procedure.
- Starting and stopping the engine over a short period of time may

make the vehicle more difficult to start. If this occurs, wait for more than 3 minutes, and then push the ignition switch again to start the engine.

- To maintain high performance over a long period of time, the engine speed is limited to 4,300 rpm when the engine is revved with the shift lever in the 
  ☐ or ☐ position, and to 4,000 rpm when the engine oil or coolant temperature is low or higher than normal.
- If the ignition switch is pushed before the shift lever is moved to the position, the ignition switch will not change to the OFF position. If this occurs, the SHIFT warning display appears on the vehicle information display. When stopping the engine, be sure to move the shift lever to the position and then push the ignition switch. Failure to do so may result in discharge of the battery. ( "Shift "P" warning" page 2-46)
- If the shift lever was in the △→□ or □ position when the engine was stopped, then be sure to move the shift lever to the □ position before starting the engine the next time. If

the engine is started with the shift lever in the \( \) position, then it may not be possible to drive the vehicle even when the shift lever is moved to the \( \) \( \) or \( \) position. If this occurs, the SHIFT \( \) warning appears on the vehicle information display. ( \( \) "Shift "P" warning" page 2-46)

# **A** CAUTION

If the engine was stopped soon when the engine is hot, the cooling fan may operate for approximately 2 minutes after the engine was stopped to cool the components in the engine compartment. When the cooling fan is operating, be sure that hands or other items do not get caught in it.

### **DRIVING THE VEHICLE**

### **DUAL CLUTCH TRANSMISSION**

The GT-R dual clutch transmission is a newly-developed system that uses an electronically controlled multiple-disc wet clutch attached to the highly efficient manual transmission. This transmission has two driving modes.

- A position (Automatic gearshift): allows automatic shifting of the manual transmission.
- M position (Manual gearshift): allows quick shifting of the manual transmission.

#### NOTE:

When starting or driving on a steep uphill grade, shift to the  $\square$  position and operate the paddle shifter to shift down to 1st gear similar to a manual transmission vehicle.

The GT-R dual clutch transmission was developed specifically to maximize vehicle performance and driving enjoyment. The GT-R transmission components were designed using different engineering standards than typical passenger car transmissions. Because of this, the GT-R has different operating characteristics, and various rattle noises may be heard during some driving conditions because

of the following items:

- Gear clearances
- Ultralight flywheel
- Dry sump lubrication

These noises do not indicate that there is a malfunction.

# **WARNING**

- Do not depress the accelerator pedal while shifting from the ☐ or ☐ position to the ☐ or ☐ → ☐ position. Always depress the brake pedal until shifting is completed. Failure to do so could cause loss of control and an accident.
- Cold engine idle speed is high, so use caution when shifting into a forward or reverse gear before the engine has warmed up.
- Never shift to either the ☑ or ☒ position while the vehicle is moving forward and ☒ or ☒→☒ position while the vehicle is reversing. This could cause an accident or damage the transmission.
- The shift lever contains a powerful magnet. Do not place electro-


- nic medical devices or other electronic products that are susceptible to magnetic force close to the shift lever.
- Do not downshift abruptly on slippery roads. This may cause a loss of control.
- If the shift lever is moved from 
   to △→ ☐ position, or △→ ☐ to ☐
   position before the vehicle stops,
   you may not be able to shift gear
   or it may take longer to shift gear.
   Make sure to depress the brake
   pedal and check that the vehicle
   has stopped before shifting.

# **A** CAUTION

 Because the vehicle includes a dual clutch transmission that automatically controls the clutch and shifting operation of the manual transmission, whenever the shift lever is in a position other than 2 or 1, the vehicle will begin to move slowly, in the same way as when the clutch in a manual transmission vehicle is partially engaged. Keep the brake pedal firmly depressed when the vehicle is stopped. In some circumstances the vehicle may not start moving on its own, however this does not indicate that there is a malfunction.

### **NOTICE**

- To avoid possible damage to your vehicle; when stopping the vehicle on an uphill grade, do not hold the vehicle in place by depressing the accelerator pedal. Doing so may cause the clutch to overheat and result in transmission damage. Use the brakes to prevent the vehicle from moving.
- The GT-R dual clutch transmission is provided with a dry sump lubrication system that improves efficiency and ensures reliability under high g-force conditions. When oil viscosity is high at low temperatures, it takes longer for all components to be sufficiently lubricated. Thus, when the transmission temperature is low (approximately 104°F (40°C), do not accelerate rapidly or run the engine faster than 4,000 rpm.



# Operating the shift lever

After starting the engine, fully depress the brake pedal and move the shift lever from the  $\mathbf{P}$  position to the  $\mathbf{R}$ ,  $\mathbf{N}$ , or  $\mathbf{A} \leftrightarrow \mathbf{M}$ position. Push the button to shift into the P or R position. All other positions can be selected without pushing the button.

Shift lever operation		
1	Push the button while depressing the brake pedal.	
	Push the button.	
	Just move the shift lever.	
	Automatically returns.	

### position:

Use this position for parking and starting the engine. The ignition switch will be changed to the OFF or LOCK position.

# **A** CAUTION

Use the position only when the vehicle is completely stopped.

## R position:

Use this position for driving in reverse. A chime will sound inside the vehicle and a warning will appear in the vehicle information display if the shift lever is in the R position for more than 5 minutes, or when the driver's door is opened while the shift lever is in the R position.

### N position:

Neither forward nor reverse gear is engaged.

### A↔M position:

Use this position for all normal forward driving. The shift lever can be moved between A and M to alternately change each other. The position indicator indicates the gear position with the indication of "A" or "M"

- A position: Use this position for ordinary driving, with the gears shifted automatically from first gear to sixth gear according to the speed and driving conditions.
- M position: Operate the paddle shifter to drive in first gear to sixth gear as desired
- The position indicator blinks if it is not possible to shift the gear. ( 译 "Transmission position indicator" page 2-10)





# A CAUTION

- Grip the shift lever correctly when operating it. Failure to do so may cause a finger or other items to be trapped between the lever and gate, possibly causing an accident.
- Because rolling resistance is reduced in the GT-R, the vehicle can move when on a road with a slight gradient, even when in the N position. Be sure to depress the brake pedal.

### **NOTICE**


- Be sure to observe the following precautions. Failure to do so may result in shift lever malfunction.
  - Do not spill water, beverages or other liquids on the shift lever.
  - Do not allow sand or similar substances to contact the shift lever.
- When the vehicle is hot, the area around the shift lever may be hot or may produce an unusual sound, however this does not indicate that there is a malfunction.
- Avoid depressing the brake and accelerator pedals at the same time. Depressing both pedals at the same time could cause the clutch to overheat and accelerate

#### deterioration.

#### NOTE:

- When moving the shift lever out of the position, it may not be possible to move the shift lever if the button is pressed before the brake pedal is depressed. Press the button only after depressing the brake pedal.
- Do not place coins or other small objects in the area around the shift lever. These objects may get stuck in the shift gate and prevent the shift lever from moving into a position. Sometimes, you may not be able to retrieve these objects.
- Immediately after a cold start, while
  the transmission system check display ("T/M SYSTEM CHECK IN PROCESS") appears on the vehicle
  information display, the shift lever
  cannot be moved out of the position. This is because a check of
  the transmission system is in progress. This does not indicate that
  there is a malfunction. Move the
  shift lever after the message on the
  vehicle information display turns off.
- The shift lever knob and console-

mounted shift indicator have a genuine leather finish that requires proper care and maintenance. ( \*\* "Cleaning interior" page 7-5)



### Shift lock release

If the battery charge is low or discharged, the shift lever may not be moved from the position even with the brake pedal depressed and the shift lever button pushed.

To move the shift lever, perform the following procedure.

- 1. Push the ignition switch to the OFF or LOCK position.
- 2. Apply the parking brake.
- 3. Remove the shift lock cover using a suitable tool wrapped with a cloth.
- 4. Push down the shift lock as illustrated.

5. Push the shift lever button and move the shift lever to the \( \mathbb{\manh}\mt\anha\mt\m{\mathbb{\mathbb{\mathba\\\\\\\\\\\\\\\\\\\\\\\\\

Push the ignition switch to the ON position to unlock the steering wheel. Now the vehicle may be moved to the desired location.

If the battery is discharged completely, the steering wheel cannot be unlocked. Do not move the vehicle with the steering wheel locked.

### **NOTICE**

If the shift lever cannot be moved out of the position after performing the shift lock release procedure, it is recommended you immediately have the vehicle inspected by a GT-R certified NISSAN dealer.

# Adaptive shift control

The adaptive shift control system automatically operates when the transmission is in the A position and selects an appropriate gear depending on the road conditions such as uphill, downhill or curving roads.

### Control on uphill and curving roads:

A low gear is maintained that suits the degree of the slope or curve to allow smooth driving with a small number of shifts.

### Control on downhill roads:

The adaptive shift control system shifts to a low gear that suits the degree of the slope, and uses the engine brake to reduce the number of times that the foot brake must be used.

### Control on winding roads:

A low gear is maintained on continuous curves that involve repeated acceleration and deceleration, so that smooth acceleration is available instantly when the accelerator pedal is depressed.

### NOTE:

Adaptive shift control may not operate when the transmission oil temperature is low immediately after the start of driving or when it is very hot. If this occurs, switch to the M position and downshift if necessary.

### M position

### Changing to the M position:

To change to the M position from the A position, either move the shift lever to the M side or operate the paddle shifter. The position indicator indicates the gear position with the indication of "M".

If the paddle shifter is used, in one operation the A position changes to the M position and the gear position shifts (except for downshifting from 2nd gear to 1st gear). For the downshift operation from the 2nd gear to the 1st gear, the first paddle shifter operation changes the A position to the M position, and the second operation changes the gear position.

To return to the A position, either move the shift lever to the M side again or pull the right side (up sift side) paddle shifter for approximately 2 seconds. The position indicator indicates the gear position with the indication of "A".




### Changing gears using paddle shifters:

#### NOTE:

The vehicle cannot be accelerated from a stop condition while the gear is in the 2nd to 6th position. When accelerating the vehicle from a stop condition, use the 1st gear position.

To shift up, pull the paddle shifter on the right side (1) toward you.

To shift down, pull the paddle shifter on the left side (2) toward you.



### First gear:

Use this position when accelerating from a stop, climbing a steep hill slowly or engine braking at low speeds.

#### Second gear:

Use this position when accelerating or engine braking at mid-low speeds.

### Third gear:

Use this position when accelerating or gently engine braking at middle speeds.

### Fourth gear:

Use this position when accelerating or gently engine braking at mid-high

speeds.

### Fifth gear:

Use this position for all normal forward driving at highway speeds. Engine braking is weaker in this position.

### Sixth gear:

Use this position for all normal forward driving at highway speeds. Engine braking is weakest in this position.

# Suggested maximum speed in each gear:

Downshift to a lower gear if the engine is not running smoothly, or if you need to accelerate.

Do not exceed the maximum suggested speed (shown below) in any gear. For level road driving, use the highest gear suggested for that speed. Always observe posted speed limits, and drive according to the road conditions that will ensure safe operation. Do not over-rev the engine when shifting to a lower gear as it may cause engine damage or loss of vehicle control

MPH (km/h)
36 (58)
63 (102)
91 (148)
- 1
- 1
ı

### **DRIVING TIPS**

After starting the engine, fully depress the foot brake pedal and push the shift lever button before shifting the shift lever from the position to the N or A→M position. Be sure the vehicle is fully stopped before attempting to shift the shift lever.

The transmission is designed so that the foot brake pedal must be depressed before shifting from 
to any other position.

The shift lever cannot be moved out of the position and into any other position with the ignition switch other in the LOCK, OFF or ACC position.

# When accelerating from a stop

Keep the foot brake pedal depressed and push the shift lever button to shift into a driving gear as following:

- To drive forward, move the shift lever to the A→M position.
- To back up, move the shift lever to the position.

### Starting on level ground or an uphill:

- Check the shift lever position indicator on the meter to confirm that the driving gear is selected.
- 2. Release the parking brake.
- Release the foot brake pedal gradually, then slowly depress the accelerator pedal to start the vehicle in motion.

( present the start function page 5-33)

#### NOTE:

- To prevent the clutch from overheating when the parking brake is applied, engine output is limited when the accelerator pedal is depressed. In particular, the vehicle may not start smoothly when the accelerator pedal is depressed with the parking brake applied on an uphill grade. To enable smooth starting, release the parking brake before moving the vehicle.
- The hill start assist system operates when the vehicle is accelerating from a stop on an uphill. ( \*\* "Hill Start Assist System" page 5-39)

## When driving the vehicle

# **WARNING**

Do not move the shift lever to the D position while driving. Doing so may result in an accident due to loss of engine braking. It may also damage the transmission.

### Normal driving:

Drive with the shift lever in the A position. The appropriate gear will be automatically shifted according to the position of the accelerator pedal, the driving speed and driving conditions.

# Passing:

A position:

Fully depress the accelerator pedal to the floor. This shifts the transmission down into a lower gear depending on the vehicle speed. Then depress the accelerator pedal as needed to adjust vehicle speed.

M position:

Use the paddle shifter to down shift, then fully depress the accelerator pedal to the floor. Then depress the accelerator pedal as needed to adjust vehicle speed.

### Hill climbing:

- When the vehicle speed decreases, depress the accelerator pedal to the floor with the shift lever in the position. This automatically shifts the transmission into a lower gear and maintains this position depending on the gradient of the hill.
- The system may down shift according to the accelerator pedal position and the vehicle speed.
- If the transmission is frequently changing gears while driving, switch to the position and select the appropriate gear for the driving conditions.

### Driving on a downhill:

• A position:

The system shifts down according to the degree of downhills to increase the effectiveness of the engine brake.

M position:

When driving on a long slope, selecting the  $\[Mathbb{M}\]$  position and 4th or 3rd gear will provide gentle engine braking.

When driving on a steep downhill, selecting the  $\square$  position and 2nd or 1st gear will provide powerful engine braking.

# **WARNING**

- When the shift lever is in the position, the adaptive shift control system will stay in a low gear in order to maintain the effectiveness of the engine brake. However if the vehicle is traveling too fast depending on the degree of the slope, you should shift to the M position and use the paddle shifter to shift down. If you continue to use only the foot brake, a high load will be applied to the brake, which may overheat, reducing its effectiveness. Be sure to use the engine brake together with the foot brake. ( > "Adaptive shift control" page 5-19)
- Do not downshift abruptly on slippery roads. This may cause a loss of control.

### **NOTICE**

When driving in the A position, gearshifting will be performed automatically with the adaptive shift control system ( The "Adaptive shift control" page 5-19) even on road conditions with continuous and sudden hills or curves. However, when the transmission oil temperature is low immediately after starting the vehicle or high when engaging in high performance driving, there may be some cases where the system cannot control shifting. When this occurs, switch to the M position and select a lower gear, depending on the gradient of the hill.

### When stopping the vehicle

Leave the shift lever in the  $A \leftrightarrow M$  or Rposition and firmly depress the foot brake pedal.

If the vehicle will be stopped for a long period of time, apply the parking brake and move the shift lever to the P or N position as necessary.

# **WARNING**

- Do not race the engine while the vehicle is stopped. Doing so may accelerate the vehicle suddenly and cause an accident when shifting to a driving gear.
- While the engine is running, the propeller shaft that transmits torque from the engine to the transmission is turning at all times. Crawling or reaching under the vehicle while the engine is running may result in serious injury.

### NOTICE

When the vehicle is stopped on a hill, do not hold the vehicle in place by depressing the accelerator pedal. Doing so may cause the clutch to overheat and result in transmission damage. Use the brakes to prevent the vehicle from moving.

## When parking the vehicle

# **WARNING**

Before exiting the vehicle, be sure to move the shift lever to the position and stop the engine. If the engine is running and the shift lever is not in the position, the vehicle may start moving due to partial engagement of the clutch or to the effects of gravity on a slope, or the vehicle may suddenly accelerate due to accidental operation of the accelerator pedal, possibly causing an accident.

For models without NCCB (NISSAN Carbon Ceramic Brake) package:

# **WARNING**

Follow the instructions below when parking the vehicle to help prevent the brake rotor and brake pads from rusting together. Failure to follow the instructions could cause the rotor and pads to rust together. If the rotor and pads rust together, there may be a popping noise and some vibration when the vehicle is driven, a wheel may not roll correctly,

or the brake pads could be damaged. If the pads are damaged, this may reduce the effectiveness of the brake system which could cause a collision, serious personal injury or death.

The GT-R uses brake pad materials that have high metallic content. The brake pad material helps maintain braking performance in a wide range of weather and driving conditions.

For the first 3,000 miles (5,000 km) of the vehicle's service life, and for the first 3,000 miles (5,000km) after a brake replacement, the brake pad to brake rotor clearance is very small. When parking, apply the parking brake and move the shift lever to the position. Idle the engine for more than 20 seconds without depressing the brake pedal. This allows the brake pads to move away from the rotor so the pad does not contact the rotor.

Additionally, the brakes must be dry before parking the vehicle after driving on wet roads or after washing the vehicle. If the roads are wet, lightly apply the brakes for a short distance before parking the vehicle to dry the brakes. After washing the vehicle, dry the brakes by driving on a dry road for a few miles and apply

the brakes normally based on traffic and road conditions.

The metallic brake pads and brake disc rotor may rust together when the brakes are not applied:

- If the vehicle is not idled for 20 seconds without the brakes applied, or if the brakes are applied when the vehicle is shut off, the rotor and pads can rust together, even when the brake pads are dry.
- If the brakes are wet when the vehicle is parked and the parking brake is applied for a long time.


It is recommended you contact a GT-R certified NISSAN dealer if the brake pads and brake rotor have rusted together.

- 1. Bring the vehicle to a complete stop.
- 2. With the foot brake pedal depressed, apply the parking brake.
- 3. Move the shift lever to the **P** position.
- Check the shift lever position indicator on the meter to confirm that the position is selected.
- 5. Push the ignition switch to stop the engine.

# For models with NCCB (NISSAN Carbon Ceramic Brake) package:

( 译 "NCCB (NISSAN Carbon Ceramic Brake)" page 8-20)

### **VDC, TRANSMISSION AND** SUSPENSION SETUP SWITCHES



The control of the dual clutch transmission, Bilstein DampTronic® electronically controlled shock absorbers and Vehicle Dynamic Control (VDC) can be changed to the desired modes by operating the setup switches. Select the desired mode best suited to the driving conditions.

#### NOTE:

Bilstein DampTronic® is a registered trademark of ThyssenKrupp Bilstein Suspension GmbH.

#### **USAGE OF EACH MODE**

### R mode

This mode enables optimum GT-R high performance during performance or high-speed driving.

If the gear is shifted or the accelerator pedal is quickly operated when the transmission setup switch is in R mode and the engine warmed up, a sound effect is output to enhance the sense of sportiness. (译 "Active sound enhancement" page 5-60)

### Normal mode

This mode is suitable for normal driving or performance driving. When the engine is started again, all modes will return to the normal mode.

### Other modes for each switch

#### Transmission: SAVE mode:


This mode improves the fuel economy for long distance driving and reduce fatigue by enabling easy acceleration pedal operation.

### Suspension: COMF mode:

This mode is suitable for normal driving.

#### VDC: OFF mode:


This mode is an emergency mode that can be used to free the vehicle from slush and deep snow, etc.



- 1. Transmission setup switch
- 2. Suspension setup switch
- Vehicle Dynamic Control (VDC) setup switch

### **HOW TO SWITCH THE MODES**

Each time the engine is started, all switches are set to the normal mode. The normal mode is recommended for normal driving. Move the VDC, transmission and suspension setup switches up or down to change the mode when the engine is running.



Push and hold the switch for longer than approximately 1 second

->: Push the switch

\* The selected mode is maintained even if the shift lever is moved between A and D position.

### **NOTICE**

- "ESC (Electronic Stability Control)
   OFF" indicated on the VDC setup
   switch stands for "VDC OFF".
- When the ignition switch is

pushed to the "ON" position, the indicators on the setup switches may illuminate briefly, however this is not a malfunction.

## **FEATURES OF EACH MODE**

## **Transmission**

The transmission mode differs depending on the shift lever position,  ${\color{red} \Delta}$  or  ${\color{red} \underline{M}}$ A position:

Cat up made	Features
Set up mode	
E	<ul> <li>In addition to the normal mode functions, this mode allows you to achieve higher engine speed, greater powertrain torque and engine braking.</li> <li>With the VDC switch in R mode, the R mode start function can be used. (</li></ul>
Normal (light is off)	<ul> <li>For everyday and performance driving, an appropriate gear position is automatically selected.</li> </ul>
SAVE	<ul> <li>For long distance driving, this mode helps improve fuel economy by reducing engine output compared to the normal mode.</li> <li>The engine response to accelerator operation changes to be less sensitive to pedal movement than the normal mode. The engine speed does not change as quickly for small accelerator pedal position changes.</li> <li>This mode controls powertrain torque on snowy roads and slippery surfaces making starting and driving easier.</li> <li>When the SAVE mode is selected, the maximum speed is lower than the one in the normal mode.</li> </ul>

## M position:

Set up mode	Features
<b>=</b>	<ul> <li>This mode allows you to shift gears quickly and directly.</li> <li>This mode will not allow the transmission to automatically upshift even when the engine speed reaches the red zone. Do not rev the engine into the red zone.</li> <li>With the VDC switch in R mode, the R mode start function can be used. ( R mode start function page 5-33)</li> </ul>
Normal (light is off)	<ul> <li>For everyday and performance driving, any gear position can be selected.</li> <li>This mode will allow the transmission to automatically upshift even when the engine speed is about to reach the red zone.</li> </ul>
SAVE	<ul> <li>For long distance highway driving, this mode improves fuel economy by reducing engine output compared to the normal mode.</li> <li>The engine response to accelerator operation changes to be less sensitive to pedal movement than the normal mode. The engine speed does not change as quickly for small accelerator pedal position changes.</li> <li>This mode controls powertrain torque on snowy roads and slippery surfaces making starting and driving easier.</li> <li>This mode allows the transmission to automatically upshift even when the engine speed is about to reach the red zone.</li> <li>When the SAVE mode is selected, the maximum speed is lower than the one in the normal mode.</li> </ul>

# **NOTICE**

- When the engine speed approaches the red zone, shift to a higher gear or reduce the engine speed. Operating the engine in the red zone may cause serious engine damage.
- Quickest shifting in the R mode with the transmission in the M position is available when the engine speed is high. However, the transmission may shift more slowly when the engine speed is low.

# Suspension

Set up mode	Features
	<ul> <li>The damping force of the shock absorbers is set for maximum vehicle performance.</li> <li>Riding comfort becomes harder.</li> </ul>
Normal (light is off)	<ul> <li>The damping force of the shock absorbers is variably adjusted for everyday driving or maximum vehicle performance.</li> </ul>
COMF	<ul> <li>The damping force of the shock absorbers is variably adjusted for more comfortable driving. Movement of the vehicle body is larger than the normal and R modes.</li> </ul>

# **NOTICE**

While maximizing vehicle performance, shock absorber control may automatically be returned to the normal mode. If the R mode or the COMF mode is selected in the case above, the suspension setup switch indicator may turn off. Operate the suspension setup switch to the R mode or the COMF mode and check to make sure the indicator illuminates. If the indicator does not illuminate, it is recommended you have the system checked by a GT-R certified NISSAN dealer.

## Vehicle Dynamic Control (VDC)

Set up mode	Features
	<ul> <li>In addition to the normal mode function, this mode adjusts front and rear wheel power distribution to improve handling.</li> <li>With the transmission switch in R mode, the R mode start function can be used. (  R mode start function page 5-33)</li> </ul>
Normal (light is off)	<ul> <li>This mode is for use in a broad range of driving conditions, for routine driving during fair to rainy weather, as well as for driving on road surfaces that are slippery due to snow or ice.</li> <li>Make sure to use this mode for everyday driving.</li> </ul>
OFF	<ul> <li>Temporary mode that can be used to free if it is stuck in snow or mud Also place transmission setup switch in SAVE mode when freeing a stuck vehicle.</li> </ul>

#### NOTE:

Always make sure the VDC is ON before driving the vehicle by checking that the VDC OFF indicator lights on the meter and the VDC set-up switch are not illuminated. The GT-R is a high performance vehicle and the VDC must be on/activated to provide proper powertrain operation and intended drivability.

# **WARNING**

- The VDC OFF mode should ONLY be used briefly to help free the vehicle if stuck in snow or mud by temporarily stopping operation of the VDC to maintain wheel torque.
- Driving the GT-R with the VDC off may lead to handling issues re-

lated to steering maneuvers, acceleration, or deceleration. Moreover, driving with the VDC off can result in an inoperative vehicle by causing serious damage to the powertrain, including damage to the Transaxle Assembly including Transfer, Clutch, Gears, Transaxle case and all of its components and other drivetrain component(s) by overheating or excessive force.

Damage to the powertrain or any drivetrain component(s) that occurs when there is a record in the Vehicle Status Data Recorder (VSDR) that the vehicle was driven with VDC off during the period when the damage was incurred is excluded from warranty coverage.

See your 2021 Warranty Information Booklet for important related information and warranty coverage exclusions. See also section 2 ( Transmission warning light" page 2-33) and section 5 ( ) Yehicle Dynamic Control (VDC) system" page 5-54) of this Owner's Manual. "Transmission Clutch Temperature High" and "Vehicle Dynamic Control (VDC) System" for important additional related information

#### TURBOCHARGER SYSTEM

The turbocharger system uses engine oil for lubrication and cooling of its rotating components. The turbocharger turbine turns at extremely high speeds and it can get very hot. It is essential to maintain a supply of oil flowing through the turbocharger system. Therefore, a sudden interruption of oil supply may cause a malfunction in the turbocharger.

To ensure prolonged life and performance of the turbocharger, it is essential to perform the following maintenance procedure:

- Change your engine oil according to the recommended intervals shown in the "9. Maintenance and schedules" section of this manual. Use only the recommended engine oil.
- If the engine had been operating at high engine speed for an extended period of time, let it idle for a few minutes prior to shutdown.
- Do not accelerate your engine to high engine speed immediately after start.

## **NOTICE**

This vehicle includes spark plugs that are designed for high performance. For this reason, if the engine is repeatedly started and stopped over a short time, the spark plugs may become fouled, making the engine difficult to start. To prevent diminished starting performance, avoid starting and stopping the engine repeatedly during a short period of time.

#### NOTE:

- When the vehicle is delivered, the engine oil level is 0.39 in (10 mm) below the H mark on the engine oil dipstick for optimum high performance driving. The engine oil can be filled up to the H mark if not engaging in performance driving.
- Because of the high performance characteristics of the GT-R engine. more frequent oil level inspections are necessary. Check the oil level every 1,800 miles (3,000km) and adjust as necessary. Also, change the engine oil based on the driving conditions. For the information re-

- garding oil replacement intervals, refer to the "9. Maintenance and schedules" section of this manual.
- Some amount of oil is consumed by vour engine under normal operating conditions, and oil consumption by itself does not necessarily indicate any malfunction. If your rate of oil consumption increases suddenly or without explanation, NISSAN recommends that you have your vehicle inspected by a GT-R certified NISSAN dealer.

#### **R MODE START FUNCTION**

This function enables the driver to start acceleration from a stop by selecting R mode with the VDC and transmission setup switch. The engine output will be maintained at approximately 4,100 rpm. When using the R mode or the R mode start function, always use proper seating position and follow the safety instructions in Section 1 of this manual

# **WARNING**

- Failure to follow the warnings and instruction for the use of this feature may cause a loss of vehicle control or a collision which may lead to serious personal injury or death:
- Make sure to drive carefully within legal limits.
- Only use this function when you can guarantee that it is safe to do so, based on the surrounding traffic conditions.
- Do not use this function on slippery or wet roads. This may cause loss of vehicle control and could result in an accident.
- The R mode start function has been developed not only for con-

trolling the engine, transmission and VDC system, but also the settings of the suspension and tires. Therefore, any modification of the vehicle may disrupt the vehicle's balance. This will not only reduce the optimum performance of the vehicle but may also cause damage to powertrain components, including the transmission.

### **NOTICE**

- When the temperature of the engine coolant and transmission oil is high or low, the function cannot be used. The temperature range in which the R mode start function can be used:
  - Engine coolant: 140°F 212°F (60°C - 100°C)
  - Transmission oil: 140°F 266°F (60°C - 130°C)
- If the R mode start function is used 4 times consecutively, the function may be disabled and cannot be turned on to protect the vehicle system. While the

function is disabled, the warning light illuminates. When the warning light illuminates, perform cool down driving. ( [25] "Cool down" page GTR-14) When the warning light turns off, the function can be used again.

- The performance of start may vary depending on the amount of wheel spin ,or increase and decrease of the engine output in response to the outside temperature. (This vehicle was set up according to the road surface conditions of the straight sections of the Sendai Highland Raceway course in Japan at 59°F (15°C).)
- For safety reasons, VDC control may activate automatically when driving on a slippery road surface, such as a wet road, in order to apply the brakes or limit the engine output.
- Frequent use of the R mode start function increases the load on the powertrain related parts such as the clutch and transmission compared to normal driving. In particular, the clutch will wear out

## more quickly.

## HOW TO USE R MODE START **FUNCTION**

- 1. Move the shift lever to the A or M position.
- 2. Select the R mode with the transmission setup switch. ( ) "VDC, transmission and suspension setup switches" page 5-25)
- 3. Select the R mode with the VDC setup switch.
- 4. Depress the brake pedal firmly with your left foot and keep depressing the brake pedal.
- 5. Depress the accelerator pedal quickly to the floor with your right foot while the brake pedal is depressed. The engine speed will increase to approximately 4,100 rpm and will be maintained
- 6. Within 3 seconds after depressing the accelerator pedal, release the brake pedal.

### **PARKING BRAKE**



# **WARNING**

- Be sure the parking brake is fully released before driving. Failure to do so can cause brake failure and lead to an accident.
- Do not release the parking brake from outside the vehicle.
- Do not use the shift lever in place of the parking brake. When parking, be sure the parking brake is fully engaged.
- To help avoid risk of injury or death through unintended opera-

tion of the vehicle and/or its systems, do not leave children, people who require the assistance of others or pets unattended in vour vehicle. Additionally, the temperature inside a closed vehicle on a warm day can quickly become high enough to cause a significant risk of injury or death to people and pets.

To apply: Pull the parking brake lever up. To release:

- Firmly apply the foot brake.
- While pulling up on the parking brake lever slightly, push the button (A) and lower the lever completely.
- 3. Before driving, be sure the brake warning light goes out.

#### **CRUISE CONTROL**

The cruise control allows driving at speeds above 25 MPH (40 km/h) without keeping your foot on the accelerator pedal.

# **WARNING**

Do not use the cruise control when driving under the following conditions. Doing so could cause a loss of vehicle control and result in an accident.

- When it is not possible to keep the vehicle at a set speed.
- In heavy traffic or in traffic that varies in speed.
- On winding or hilly roads.
- On slippery roads (rain, snow, ice, etc.).
- In very windy areas.

#### NOTE:

 When the SAVE mode is selected with the transmission setup switch, the acceleration and deceleration can be controlled smoothly. When the SAVE mode is selected, the maximum setting speed is lower than the one in the normal mode. When the vehicle approaches a gentle uphill, there may be a slight delay as the vehicle returns to the preset speed. However, the vehicle will gradually accelerate and return to the preset speed.




# PRECAUTIONS ON CRUISE CONTROL

- If the cruise control system malfunctions, it will cancel automatically. The SET indicator will blink and the cruise control system warning will appear to warn the driver. ( "Cruise control system warning" page 2-43)
- If the engine coolant temperature becomes excessively high, the cruise control system will be canceled automatically.
- If the SET indicator blinks, turn the cruise control main switch off and it is recommended you contact a GT-R


certified NISSAN dealer.

The SET indicator may sometimes blink when the cruise control main switch is turned on while pushing the RESUME/ACCELERATE, SET/COAST or CANCEL switch. To properly set the cruise control system, perform the steps below in the order indicated.



# STEERING-WHEEL-MOUNTED **CONTROLS**

- MAIN switch Turns cruise control ON/OFF.
- 2. SET/COAST switch (pressed down) Lowers the set vehicle speed.
- 3. RESUME/ACCELERATE switch (pressed up)
  - Raises the set vehicle speed.
- 4. CANCEL switch Cancels cruise control.



#### INDICATORS AND DISPLAY

- CRUISE display Displays the set vehicle speed.
- 2. CRUISE indicator Informs the driver that the MAIN switch is ON.
- SET indicator Informs the driver that the vehicle is driving at the set speed.





#### **CRUISE CONTROL OPERATIONS**

# **Constant-speed driving**

To set the cruising speed, perform the following procedure.

Push the MAIN switch on. The CRUISE indicator will come on.

 Accelerate your vehicle to the desired speed, push the SET/COAST switch and release it. (The SET indicator will illuminate in the meter.) Take your foot off the accelerator pedal. Your vehicle will maintain the set speed.

#### NOTE:

If the vehicle speed reaches approximately 3 MPH (5 km/h) over the set speed, the set speed on the vehicle information display blinks.

# Passing another vehicle

To pass another vehicle, depress the accelerator pedal. When you release the pedal, the vehicle will return to the pre-

viously set speed.

# Increasing the set vehicle speed

To reset at a faster cruising speed, use one of the following methods:

- Depress the accelerator pedal. When the vehicle attains the desired speed, push and release the SET/COAST switch.
- Push and hold the RESUME/ACCELER-ATE switch. When the vehicle attains the speed you desire, release the switch.
- Push and then quickly release the RESUME/ACCELERATE switch. Each time you do this, the set speed will increase by about 1 MPH or 1 km/h.

# Decreasing the set vehicle speed


To reset at a slower cruising speed, use one of the following methods:

- Lightly tap the brake pedal. When the vehicle attains the desired speed, push and release the SET/COAST switch.
- Push and hold the SET/COAST switch.
   Release the switch when the vehicle slows down to the desired speed.
- Push and then quickly release the

SET/COAST switch. Each time you do this, the set speed will decrease by about 1 MPH or 1 km/h.

## Resuming the preset speed

To resume the preset speed, push and release the RESUME/ACCELERATE switch. The vehicle will resume the last set cruising speed when the vehicle speed is over 25 MPH (40 km/h).



# Canceling the preset speed

To cancel the preset speed, use one of the following methods:

- Push the CANCEL switch ① The SET indicator will turn off.
- Tap the brake pedal 3. The SET indicator will turn off.
- Turn the MAIN switch ② off. Both the CRUISE indicator and SET indicator will turn off.

#### NOTE:

- If cruise control was canceled by pressing the cancel switch or by depressing the brake pedal, the system changes to standby status.
- If you depress the brake pedal while pushing the RESUME/ACCELERATE or SET/COAST switch and reset at the cruising speed, the cruise control will be deactivated. Turn the MAIN switch off once and then turn it on again.

Under the following conditions, cruise control will be automatically canceled.

- Vehicle speed drops to below approximately 19 MPH (30 km/h).
- Vehicle speed drops to more than approximately 8 MPH (13 km/h) below the set vehicle speed.
- The shift lever is moved to a position other than  $\triangle \leftrightarrow M$
- VDC operates.
- A tire is spinning.
- There is a malfunction in the cruise control system.

#### HILL START ASSIST SYSTEM

# **A** WARNING

- Never rely solely on the hill start assist system to prevent the vehicle from moving backward on a hill. Always drive carefully and attentively. Depress the brake pedal when the vehicle is stopped on a steep hill. Be especially careful when stopped on a hill on frozen or muddy roads. Failure to prevent the vehicle from rolling backwards may result in a loss of control of the vehicle and possible serious injury or death.
- The hill start assist system is not designed to hold the vehicle at a standstill on a hill. Depress the brake pedal when the vehicle is stopped on a steep hill. Failure to do so may cause the vehicle to roll backwards and may result in a collision or serious personal injury.
- The hill start assist may not prevent the vehicle from rolling backwards on a hill under all load or road conditions. Always be prepared to depress the brake pedal to prevent the vehicle from

rolling backwards. Failure to do so may result in a collision or serious personal injury.

# **NOTICE**

When the vehicle is stopped on a hill, do not hold the vehicle in place by depressing the accelerator pedal. Doing so may cause the clutch to overheat and result in transmission damage. Use the brakes to prevent the vehicle from moving.

The hill start assist system automatically keeps the brakes applied to help prevent the vehicle from rolling backwards in the time it takes the driver to release the brake pedal and apply the accelerator when the vehicle is stopped on a hill. Hill start assist will operate automatically

Hill start assist will operate automatic under the following conditions:

- The shift lever is moved to a forward or reverse position.
- The vehicle is stopped completely on a hill by applying the brake.

The maximum holding time is 2 seconds. After 2 seconds the vehicle will begin to roll back and hill start assist will stop operating completely.

#### NOTE:

This system does not function when the Vehicle Dynamic Control VDC) system warning appears on the vehicle information display located in the tachometer. ( \*\*Tehnicle Dynamic Control (VDC) system warning" page 2-40)

#### **BREAK-IN SCHEDULE**

#### **NOTICE**

Follow these recommendations to obtain maximum engine performance and ensure the future reliability and economy of your new vehicle. Failure to follow these recommendations may result in shortened engine life and reduced vehicle performance.

Please observe the following types of driving until the mileage shown below has been reached.

Until 300 miles (500 km):

- Do not depress the accelerator pedal more than halfway and avoid rapid acceleration.
- Drive with the engine speed kept at less than 3.500 RPM.
- Avoid unnecessary quick steering, abrupt braking and driving on poor roads.

300 to 600 miles (500 to 1,000 km):

 Avoid rapid acceleration in a low gear (1st to 3rd gears) with the accelerator pedal fully depressed. Depress the pedal slowly.

- Avoid unnecessary quick steering and abrupt braking.
- Drive with the suspension setup switch in the COMF mode to allow more suspension stroke.

600 to 1,200 miles (1,000 to 2,000 km):

- Drive with the engine speed kept relatively high with the shift lever in the position. Shifting is recommended between 1st and 4th gears.
- Avoid unnecessary quick steering and abrupt braking.
- Drive with the suspension setup switch in the COMF mode to allow more suspension stroke.

Even though the mileage reaches over 1,200 miles (2,000 km), the clutch may take longer to properly engage if the vehicle is mainly driven in town at a low speed. NISSAN recommends breaking in the clutch at a GT-R certified NISSAN dealer

## WHEEL ALIGNMENT

Do not adjust the wheel alignment until the mileage reaches 1,000 miles (1,600 km). Until then, the suspension may not engage enough and the height may be higher.

However, make sure to adjust the align-

ment after 1,000 miles (1,600 km).

The wheel alignment can be adjusted by a GT-R certified NISSAN dealer in accordance with specifications for city driving to high performance driving.

The tires on the GT-R may have different wear rates and wear patterns in comparison to conventional passenger vehicles. It is recommended you contact a GT-R certified NISSAN dealer to confirm that the alignment is within specifications.

### **FUEL EFFICIENT DRIVING TIPS**

Follow these easy-to-use Fuel Efficient Driving Tips to help you achieve the most fuel economy from your vehicle.

- Use smooth accelerator and brake pedal application.
  - · Avoid rapid starts and stops.
  - Use smooth, gentle accelerator and brake application whenever possible.
  - Maintain constant speed while commuting and coast whenever possible.
- 2. Maintain constant speed.
  - Look ahead to try and anticipate and minimize stops.
  - Synchronizing your speed with traffic lights allows you to reduce your number of stops.
  - Maintaining a steady speed can minimize red light stops and improve fuel efficiency.
- Use air conditioning (A/C) at higher vehicle speeds.
  - Below 40 MPH (64 km/h), it is more efficient to open windows to cool the vehicle due to reduced engine load.
  - Above 40 MPH (64 km/h), it is more efficient to use A/C to cool the vehicle due to increased aerodynamic drag.

- Recirculating the cool air in the cabin when the A/C is on reduces cooling load.
- Drive at economical speeds and distances.
  - Observing the speed limit and not exceeding 60 MPH (97 km/h) (where legally allowed) can improve fuel efficiency due to reduced aerodynamic drag.
  - Maintaining a safe following distance behind other vehicles reduces unnecessary braking.
  - Safely monitoring traffic to anticipate changes in speed permits reduced braking and smooth acceleration changes.
  - Select a gear range suitable to road conditions.
- Use cruise control.
  - Using cruise control during highway driving helps maintain a steady speed.
  - Cruise control is particularly effective in providing fuel savings when driving on flat terrains.
- 6. Plan for the shortest route.
  - Utilize a map or navigation system to determine the best route to save time.


- 7. Avoid idling.
  - Shutting off your engine when safe for stops exceeding 30-60 seconds saves fuel and reduces emissions.
- 8. Buy an automated pass for toll roads.
  - Automated passes permit drivers to use special lanes to maintain cruising speed through the toll and avoid stopping and starting.
- 9. Winter warm up.
  - Limit idling time to minimize impact to fuel economy.
  - Vehicles typically need no more than 30 seconds of idling at startup to effectively circulate the engine oil before driving.
  - Your vehicle will reach its ideal operating temperature more quickly while driving versus idling.
- 10. Keeping your vehicle cool.
  - Park your vehicle in a covered parking area or in the shade whenever possible.
  - When entering a hot vehicle, opening the windows will help to reduce the inside temperature faster, resulting in reduced demand on your A/C system.
- 11. Use the SAVE mode.
  - It is recommended that you select

the SAVE mode with the transmission setup switch while driving, except engaging in high performance driving. Doing so will enable improved fuel economy. ( Pr "VDC, transmission and suspension setup switches" page 5-25)

## **INCREASING FUEL ECONOMY**

- Keep your engine tuned up.
- Follow the recommended scheduled maintenance.
- Keep the tires inflated to the correct pressure. Low tire pressure increases tire wear and lowers fuel economy.
- Keep the wheels in correct alignment. Improper alignment increases tire wear and lowers fuel economy.
- Use the recommended viscosity engine oil. ( > "Oil viscosity" page 10-7)

# **ALL-WHEEL DRIVE (AWD)**



#### AWD WARNING LIGHT

The AWD warning light is located in the meter.

The AWD warning light comes on when the ignition switch is pushed to the ON position. It turns off soon after the engine

is started.

If any malfunction occurs in the AWD system while the engine is running, the warning light will come on.

The warning light may blink rapidly (about twice per second) while trying to free a stuck vehicle due to high AWD clutch temperature. The driving mode may change to two-wheel drive. If the warning light blinks rapidly during operation, stop the vehicle with the engine idling in a safe place immediately. Then if the light goes off after a while, you can continue drivina.

A large difference between the diameters of front and rear wheels will make the warning light blink slowly (about once per two seconds). Pull off the road in a safe area, and idle the engine. Check that all tire sizes are the same, tire pressure is correct and tires are not worn and winter tires are not installed on the front or rear wheels only.

If the warning light is blinking after the above operation, it is recommended you have your vehicle checked by a GT-R certified NISSAN dealer as soon as possible.

If non-genuine GT-R tires are used, the warning light may illuminate. ( 译 "GT-R special precautions" page GTR-5)

# **WARNING**

- Do not attempt to raise two wheels off the ground and shift the transmission to any drive or reverse position with the engine running. Doing so may result in drivetrain damage or unexpected vehicle movement which could result in serious vehicle damage or personal injury.
- Do not attempt to test an AWD equipped vehicle on a 2-wheel dynamometer (such as the dynamometers used by some states for emissions testing) or similar equipment even if the other two wheels are raised off the ground. Make sure that you inform the test facility personnel that your vehicle is equipped with AWD before it is placed on a dynamometer. Using the wrong test equipment may result in drivetrain damage or unexpected vehicle movement which could result in serious vehicle damage or personal injury.

## NOTICE

- If the warning light comes on while driving there may be a malfunction in the AWD system. Reduce the vehicle speed and it is recommended you have your vehicle checked by a GT-R certified NISSAN dealer as soon as possible.
- If the warning light remains on after the above operation, it is recommended you have your vehicle checked by a GT-R certified NISSAN dealer as soon as possible.
- The powertrain may be damaged if you continue driving with the warning light blinking.
- Do not spin the rear wheels while driving. Spinning the rear wheels may increase the temperatures of the AWD clutch system and damage the system. Adjust the accelerator pedal position to stop wheel spin.

## TIGHT CORNER BRAKING PHE-NOMENON

If the steering wheel is turned more than half a turn when the vehicle is started when it is cold, it may be harder to move the vehicle forward and backward. This phenomenon is known as the "tight corner braking phenomenon".

This phenomenon is unique to AWD vehicles, and occurs due to a difference in speeds between the front and rear wheels while the vehicle is turning. This does not indicate that there is a malfunction.

#### NOTE:

If the tight corner braking phenomenon occurs, a slipping sound may be heard from the tires, or a squeaking sound may be heard from the drive system.

# Reducing tight corner braking phenomenon

The tight corner braking phenomenon can be reduced if the following three conditions are met:

- Transmission setup switch is set to Normal mode.
- Vehicle speed is low (less than approximately 6 MPH (10 km/h)).

 The steering wheel is turned more than 1/2 turn.

#### **TIRES**

This vehicle is equipped with special tires. When changing the tires, install the designated special tires. Replacing tires as a set of four with new ones is recommended. However, if a tire is punctured or damaged, it may be possible to replace only the damaged tire. Determining whether one tire or a complete set of tires should be replaced is based on a number of factors including tire wear and condition. Contact your GT-R certified NISSAN dealer. They can recommend if an individual tire or a complete set should be replaced.

#### **NOTICE**

If tires other than the designated tires, tires with large differences in wear or tires of different sizes are installed, the AWD performance will be degraded and the drive mechanism may be damaged.

#### AWD SYSTEM CHARACTERISTICS

The AWD system automatically distributes the optimal torque to the front and rear wheels. This provides both the superior turning performance of a rear wheel drive vehicle and the traction of a AWD vehicle.

Electronic control continuously distributes torque to the front and rear wheels in the range from 0:100 (rear-wheel drive mode) to 50:50 (all-wheel drive mode) to match the driving conditions and road conditions. This allows the engine output (torque) to be effectively transmitted to the road surface.

## LIMITED SLIP DIFFERENTIAL (LSD)

The rear final drive of this vehicle is equipped with a 1.5-way mechanical Limited Slip Differential (LSD).

# **MARNING**

Sudden operation of the accelerator pedal can result in fishtailing or sideslip, possibly causing an accident. Use particular caution when driving in rainy weather or on slippery roads.

#### **NOTICE**


Use the designated differential gear oil. If any oil other than the designated oil is used, the LSD may not operate correctly, and noise and vibration may occur, possibly resulting in a malfunction.

#### NOTE:

 If the vehicle accelerates from a stop with the steering wheel turned in cold temperatures, the inner wheel tire may slip and some noise or vibration may be heard. This phenomenon is unique to vehicles equipped with the LSD. This does not indicate that there is a malfunction.

- The LSD controls the speed difference between the left and right wheels, and optimally allocates torque to the wheels.
- The 1.5-way mechanical LSD in the rear final drive of this vehicle is characterized by its asymmetrical LSD effects when the accelerator pedal is ON and when it is OFF. This allows the appropriate amount of torque for the driving environment to be transmitted to the road surface.

## **PARKING/PARKING ON HILLS**



# **WARNING**

- Do not stop or park the vehicle over flammable materials such as dry grass, waste paper or rags.
   They may ignite and cause a fire.
- Never leave the engine running while the vehicle is unattended.
- Do not leave children unattended inside the vehicle. They could unknowingly activate switches or controls. Unattended children could become involved in serious accidents.
- To help avoid risk of injury or death through unintended operation of the vehicle and/or its systems, do not leave children, people who require the assistance of others or pets unattended in your vehicle. Additionally, the temperature inside a closed vehicle on a warm day can quickly become high enough to cause a significant risk of injury or death to people and pets.
- Safe parking procedures require that both the parking brake be

- applied and the transmission placed into the position. Failure to do so could cause the vehicle to move unexpectedly or roll away and result in an accident.
- Make sure the shift lever has been pushed as far forward as it can go and cannot be moved without depressing the foot brake pedal.
- Follow the instructions below when parking the vehicle to help prevent the brake rotor and brake pads from rusting together. Failure to follow the instructions could cause the rotor and pads to rust together. If the rotor and pads rust together. there may be a popping noise and some vibration when the vehicle is driven, a wheel may not roll correctly, or the brake pads could be damaged. If the pads are damaged, this may reduce the effectiveness of the brake system which could cause a collision, serious personal injury or death. (for models without NCCB (NISSAN Carbon Ceramic Brake) package)

- Firmly apply the parking brake.
- 2. Move the shift lever to the **P** position.
- To help prevent the vehicle from rolling into the street when parked on a sloping drive way, it is a good practice to turn the wheels as illustrated.
  - HEADED DOWNHILL WITH CURB: ①
     Turn the wheels into the curb and move the vehicle forward until the curb side wheel gently touches the curb.
  - HEADED UPHILL WITH CURB: ②
     Turn the wheels away from the curb and move the vehicle back until the curb side wheel gently touches the curb.
  - HEADED UPHILL OR DOWNHILL, NO CURB: ③

Turn the wheels toward the side of the road so the vehicle will move away from the center of the road if it moves.

4. Push the ignition switch to the LOCK position.

# For models without NCCB (NISSAN Carbon Ceramic Brake) package:

The GT-R uses brake pad materials that have high metallic content. The brake pad material helps maintain braking performance in a wide range of weather and

driving conditions.

For the first 3,000 - 6,000 miles (5,000 - 10,000 km) of the vehicle's service life, and for the first 3,000 - 6,000 miles (5,000 - 10,000 km) after a brake replacement, the brake pad to brake rotor clearance is very small. When parking, apply the parking brake and move the shift lever to the position. Idle the engine for more than 20 seconds without depressing the brake pedal. This allows the brake pads to move away from the rotor so the pad does not contact the rotor.

Additionally, the brakes must be dry before parking the vehicle after driving on wet roads or after washing the vehicle. If the roads are wet, lightly apply the brakes for a short distance before parking the vehicle to dry the brakes. After washing the vehicle, dry the brakes by driving on a dry road for a few miles and apply the brakes normally based on traffic and road conditions.

The metallic brake pads and brake disc rotor may rust together when the brakes are not applied:


 If the vehicle is not idled for 20 seconds without the brakes applied, or if the brakes are applied when the vehicle is shut off, the rotor and pads can rust together, even when the brake pads are dry.

 If the brakes are wet when the vehicle is parked and the parking brake is applied for a long time.

It is recommended you contact a GT-R certified NISSAN dealer if the brake pads and brake rotor have rusted together.

# For models with NCCB (NISSAN Carbon Ceramic Brake) package:

( Procedure (NISSAN Carbon Ceramic Brake)" page 8-20)



# **WARNING**

- The sonar system is a convenience but it is not a substitute for proper parking. Always look around and check that it is safe to do so before parking. Always move slowly.
- Read and understand the limitations of the sonar system as contained in this section. Inclement weather may affect the function of the sonar system; this may include reduced performance or a false activation.

- This system is not designed to prevent contact with small or moving objects.
- The system is designed as an aid to the driver in detecting large stationary objects to help avoid damaging the vehicle. The system will not detect small objects below the bumper, and may not detect objects that are too close to the bumper or on the ground.
- If your vehicle sustains damage to the bumper fascia, leaving it misaligned or bent, the sensing zone may be altered causing in-

accurate measurement of obstacles or false alarms.

# **A** CAUTION

- Keep the interior of the vehicle as quiet as possible to hear the tone clearly. Excessive noise (such as audio system volume or an open vehicle window) will interfere with the tone and it may not be heard.
- Keep the sonar (located on the bumper fascia) free from snow, ice and large accumulations of dirt (do not clean the sonar with sharp objects). If the sonar is covered, it will affect the accuracy of the sonar system.
- The sonar system may not operate correctly if a license plate cover is installed.

The sonar system sounds a tone to warn the driver of obstacles near the bumper. The sonar indicator will also appear in the touch screen display. ( ☞ "Sonar indicator" page 5-49.) The system detects front obstacles when the shift lever is in the □ position or □ position and both front and

rear obstacles when the shift lever is in the  $\mathbf{R}$  position.


The system may not detect objects at speeds above 6 MPH (10 km/h) and may not detect certain angular or moving objects.

Refer to the illustration for approximate zone coverage areas. As you move closer to the obstacle, the rate of the tone increases. When you move even closer to the obstacle, the tone will sound continuously.

The sensitivity level of the sonar can be adjusted (higher or lower) in the sonar setting display. ( \*\*Sonar system setting" page 5-50)

The intermittent tone will stop in 3 seconds when an obstacle is detected by only the corner sensor and the distance does not change.





- Sonar display
- A Corner sonar indicator
- Center sonar indicator
- RearView Monitor display

### **SONAR INDICATOR**

With the "Automatic Display with Sonar" key ON in the touch screen display, when the front sonar detects obstacles near the bumper, a tone will sound and the sonar indicator will appear in the touch screen display ①. When the RearView Monitor is displayed, the sonar indicator will appear in the upper corner of the display ②.

The sonar indicators A and B indicate the position of the object and the distance to the object with its color and rate of blinking.

When an object is detected, the indicator (green) appears and blinks (the tone sounds intermittently). When the vehicle moves closer to the object, the color of the indicator turns yellow and the rate of blinking increases (the rate of the tone increases). When the vehicle moves even closer to the object, the indicator stops blinking and turns red (the tone sounds continuously).

When the RearView Monitor is displayed, the colors of the sonar indicator and the distance guide lines in the rear view indicate different distance to the object.



- When vehicle speed decreases below approximately 6 MPH (10 km/h).
- When the ignition switch is placed in the OFF position and turned back to the ON position again.



#### SONAR SYSTEM OFF SWITCH

The sonar system OFF switch on the lower side of the instrument panel allows the driver to turn the sonar system on and off. To turn the sonar system on and off, the ignition switch must be in the ON position. The indicator light ① on the switch will turn off when the system is turned off. If the indicator light flashes it may indicate a malfunction in the sonar system.

The sonar system will turn on automatically under the following conditions.

When the shift lever is placed in the position.

#### SONAR SYSTEM SETTING

Sonar settings can be adjusted.

- Touch the "Settings" key on the Launch Bar in the touch screen display.
- 2. Select the "Sonar" key.

Select a menu item to change from the following options.

- Sonar
- Only FR Sensor Use
- Automatic Display with Sonar
- Sonar Sensitivity
- Volume

#### 5-50 Starting and driving



#### Sonar

When this item is turned ON, the front and rear sonar is activated. When this item is turned to OFF (indicator turns off), the front and rear sonar is deactivated.

ON (default) - OFF

# Only FR Sensor Use

When this item is turned on, only the rear sonar is turned off. The amber markers are displayed at the rear corners of the vehicle icon

ON - OFF (default)

# **Automatic Display with Sonar**

Automatically shows the sonar view on the touch screen display when the sonar is activated

ON (default) - OFF

## **Sonar Sensitivity**

Adjust the sensitivity level of the sonar. higher (right) - lower (left)

## Volume

Adjust the volume of the tone. higher (right) - lower (left)

## **POWER STEERING**

# **WARNING**

If the engine is not running or is turned off while driving, the power assist for the steering will not work. Steering will be harder to operate.

The power assisted steering uses a hydraulic pump, driven by the engine, to assist steering.

If the engine stops or the drive belt breaks, you will still have control of the vehicle. However, much greater steering effort is needed, especially in sharp turns and at low speeds.

#### **BRAKE SYSTEM**

#### **BRAKING PRECAUTIONS**

The brake system has two separate hydraulic circuits. If one circuit malfunctions, you will still have braking at two wheels.

You may feel a small click and hear a sound when the brake pedal is fully depressed slowly. This is not a malfunction and indicates that the brake assist mechanism is operating properly.

### Vacuum assisted brakes

The brake booster aids braking by using engine vacuum. If the engine stops, you can stop the vehicle by depressing the brake pedal. However, greater foot pressure on the brake pedal will be required to stop the vehicle and the stopping distance will be longer.

#### Wet brakes

When the vehicle is washed or driven through water, the brakes may get wet. As a result, your braking distance will be longer and the vehicle may pull to one side during braking.

To dry brakes, drive the vehicle at a safe speed while lightly tapping the brake pedal to heat-up the brakes. Do this until the brakes return to normal. Avoid driving

the vehicle at high speeds until the brakes function correctly.

## Using the brakes

Avoid resting your foot on the brake pedal while driving. This will cause overheating of the brakes, wearing out the brake and pads faster and reduce gas mileage.

To help reduce brake wear and to prevent the brakes from overheating, reduce speed and downshift to a lower gear before going down a slope or long grade. Overheated brakes may reduce braking performance and could result in loss of vehicle control.

# **WARNING**

- While driving on a slippery surface, be careful when braking, accelerating or downshifting. Abrupt braking or accelerating could cause the wheels to skid and result in an accident.
- If the engine is not running or is turned off while driving, the power assist for the brakes will not work. Braking will be harder.

#### PARKING BRAKE BREAK-IN

Break in the parking brake shoes whenever the stopping effect of the parking brake is weakened or whenever the parking brake shoes and/or drums/rotors are replaced, in order to assure the best braking performance.

This procedure is described in the vehicle service manual and can be performed by a GT-R certified NISSAN dealer.

# ANTI-LOCK BRAKING SYSTEM (ABS)

# **WARNING**

- The Anti-lock Braking System (ABS) is a sophisticated device, but it cannot prevent accidents resulting from careless or dangerous driving techniques. It can help maintain vehicle control during braking on slippery surfaces. Remember that stopping distances on slipperv surfaces will be longer than on normal surfaces even with ABS. Stopping distances may also be longer on rough, gravel or snow covered roads, or if you are using tire chains. Always maintain a safe distance from the vehicle in front of you. Ultimately, the driver is responsible for safety.
- Tire type and condition may also affect braking effectiveness.
   When replacing tires, install the specified size of tires on all four wheels.

The Anti-lock Braking System (ABS) con-

trols the brakes so the wheels do not lock during hard braking or when braking on slippery surfaces. The system detects the rotation speed at each wheel and varies the brake fluid pressure to prevent each wheel from locking and sliding. By preventing each wheel from locking, the system helps the driver maintain steering control and helps to minimize swerving and spinning on slippery surfaces.

## Using the system

Depress the brake pedal and hold it down. Depress the brake pedal with firm steady pressure, but do not pump the brakes. The ABS will operate to prevent the wheels from locking up. Steer the vehicle to avoid obstacles.

# **MARNING**

Do not pump the brake pedal. Doing so may result in increased stopping distances.

## **Self-test feature**

The ABS includes electronic sensors, electric pumps, hydraulic solenoids and a computer. The computer has a built-in diagnostic feature that tests the system

each time you start the engine and move the vehicle at a low speed in forward or reverse. When the self-test occurs, you may hear a "clunk" noise and/or feel a pulsation in the brake pedal. This does not indicate that there is a malfunction. If the computer senses a malfunction, it switches the ABS off and illuminates the ABS warning light on the meter. The brake system then operates normally, but without anti-lock assistance.

If the ABS warning light illuminates during the self-test or while driving, it is recommended you have the vehicle checked by a GT-R certified NISSAN dealer.

## Normal operation

The ABS operates at speeds above 3 to 6 MPH (5 to 10 km/h). The speed varies according to road conditions.

When the ABS senses that one or more wheels are close to locking up, the actuator rapidly applies and releases hydraulic pressure. This action is similar to pumping the brakes very quickly. You may feel a pulsation in the brake pedal and hear a noise from under the hood or feel a vibration from the actuator when it is operating. This is normal and indicates that the ABS is operating properly. However, the pulsation may indicate that road

## VEHICLE DYNAMIC CONTROL (VDC) SYSTEM

conditions are hazardous and extra care is required while driving.

The Vehicle Dynamic Control (VDC) system uses various sensors to monitor driver inputs and vehicle motion. Under certain driving conditions, the VDC system helps to perform the following functions.

- Controls brake pressure to reduce wheel slip on one slipping drive wheel so power is transferred to a non slipping drive wheel on the same axle.
- Controls brake pressure and engine output to reduce drive wheel slip based on vehicle speed (traction control function).
- Controls brake pressure at individual wheels and engine output to help the driver maintain control of the vehicle in the following conditions:
  - understeer (vehicle tends to not follow the steered path despite increased steering input)
  - oversteer (vehicle tends to spin due to certain road or driving conditions).

The VDC system can help the driver to maintain control of the vehicle, but it cannot prevent loss of vehicle control in all driving situations.

When the VDC system operates, the VDC warning light 🕏 in the meter flashes so

note the following:

- The road may be slippery or the system may determine some action is required to help keep the vehicle on the steered path.
- You may feel a pulsation in the brake pedal and hear a noise or vibration from under the hood. This is normal and indicates that the VDC system is working properly.
- Adjust your speed and driving to the road conditions
- The VDC mode can be changed using the VDC setup switch. ( Fr "VDC, transmission and suspension setup switches" page 5-25)

( ) TSP "Vehicle Dynamic Control (VDC) warning light" page 2-34, Fr "Vehicle Dynamic Control (VDC) off indicator light" page 2-33)

If a malfunction occurs in the system, the VDC warning light \( \mathbb{B} \) illuminates in the meter. The VDC system automatically turns off.

The VDC setup switch is used to turn off the VDC system. The VDC off indicator illuminates to indicate the VDC system is off.

When the VDC setup switch is used to turn off the system, the VDC system still operates to prevent one drive wheel from slipping by transferring power to a non slipping drive wheel. The VDC warning light \$\mathbb{R}\$ flashes if this occurs. All other VDC functions are off and the VDC warning light \$\mathbb{R}\$ will not flash. The VDC system is automatically reset to on when the ignition switch is placed in the off position then back to the on position.

( 深 "Vehicle Dynamic Control (VDC) warning light" page 2-34, 深 "Vehicle Dynamic Control (VDC) off indicator light" page 2-33)

The computer has a built-in diagnostic feature that tests the system each time you start the engine and move the vehicle forward or in reverse at a slow speed. When the self-test occurs, you may hear a "clunk" noise and/or feel a pulsation in the brake pedal. This is normal and is not an indication of a malfunction.

# **MARNING**

 The VDC system is designed to help the driver maintain stability but does not prevent accidents due to abrupt steering operation at high speeds or by careless or dangerous driving techniques. Reduce vehicle speed and be especially careful when driving and cornering on slippery surfaces and always drive carefully.

- Do not modify the vehicle's suspension. If suspension parts such as shock absorbers, struts, springs, stabilizer bars, bushings and wheels are not NISSAN approved or are extremely deteriorated, the VDC system may not operate properly. This could adversely affect vehicle handling performance, and the VDC warning light \$\mathcal{B}\$ may illuminate.
- If brake related parts such as brake pads, rotors and calipers are not standard equipment or are extremely deteriorated, the VDC system may not operate properly and the VDC warning light 9 may illuminate.
- If engine control related parts are not standard equipment or are extremely deteriorated, the VDC warning light \$\mathcal{B}\$ may illuminate.
- When driving on extremely inclined surfaces such as higher banked corners, the VDC system may not operate properly and the VDC warning light \$\mathcal{D}\$ may illuminate. Do not drive on these types

of roads.

- When driving on an unstable surface such as a turntable, ferry, elevator or ramp, the VDC warning light may illuminate. This is not a malfunction. Restart the engine after driving onto a stable surface.
- If wheels or tires other than the those recommended are used, the VDC system may not operate properly and the VDC warning light \$\mathcal{B}\$ may illuminate.
- The VDC system is not a substitute for winter tires or tire chains on a snow covered road.

#### NOTE:

 Always make sure the VDC is ON before driving the vehicle by checking that the VDC OFF indicator lights on the meter and the VDC set-up switch are not illuminated.

The GT-R is a high performance vehicle and the VDC must be on/ activated to provide proper power-train operation and intended drivability.

# **MARNING**

- The VDC OFF mode should ONLY be used briefly to help free the vehicle if stuck in snow or mud by temporarily stopping operation of the VDC to maintain wheel torque.
- Driving the GT-R with the VDC off may lead to handling issues related to steering maneuvers, acceleration, or deceleration. Moreover, driving with the VDC off can result in an inoperative vehicle by causing serious damage to the powertrain, including damage to the Transaxle Assembly including Transfer, Clutch, Gears, Transaxle case and all of its components and other drivetrain component(s) by overheating or excessive force.
- Damage to the powertrain or any drivetrain component(s) that occurs when there is a record in the Vehicle Status Data Recorder (VSDR) that the vehicle was driven with VDC off during the period when the damage was incurred is excluded from warranty cover-

age.

See your 2021 Warranty Information Booklet for important related information and warranty coverage exclusions. See also section 2 ( \*\*Transmission warning light" page 2-33) and section 5 ( \*\*Tvehicle Dynamic Control (VDC) system" page 5-54) of this Owner's Manual, "Transmission Clutch Temperature High" and "Vehicle Dynamic Control (VDC) System" for important additional related information.

- Except for the emergency cases above, any issues related to driving stability (e.g., steering maneuvers and maneuvers during acceleration and deceleration) and any damages to drivetrain components (e.g., transfer, clutch, a sort of gear, transaxle case) will not be covered by warranty if there is a record in the Vehicle Status Data Recorder (VSDR) that the vehicle was driven with VDC off.
- When attempting to free the vehicle from mud or fresh snow, the VDC will detect the tire slipping, and the engine speed may not increase even when the accelerator pedal is depressed. To raise the engine speed,

use the VDC set up switch to turn the VDC system OFF and select SAVE mode with the transmission switch. ( \*\*\text{12"} "VDC, transmission and suspension setup switches" page 5-25)

 When the VDC system is turned OFF, all VDC functions (including traction control), except for the ABS functions, are deactivated.

#### **COLD WEATHER DRIVING**

#### FREEING A FROZEN DOOR LOCK

To prevent a door lock from freezing, apply deicer through the key hole. If the lock becomes frozen, heat the key before inserting it into the key hole or use the Intelligent Key system.

#### **ANTI-FREEZE**

In the winter when it is anticipated that the outside temperature will drop below 32°F (0°C), check antifreeze to assure proper winter protection. ( "Engine cooling system" page 8-6)

#### **BATTERY**

If the battery is not fully charged during extremely cold weather conditions, the battery fluid may freeze and damage the battery. To maintain maximum efficiency, the battery should be checked regularly. ( The "Battery" page 8-13)

#### DRAINING OF COOLANT WATER

If the vehicle is to be left outside without antifreeze, drain the cooling system, including the engine block. Refill before operating the vehicle. For details, it is recommended you contact a GT-R certified NISSAN dealer.

#### TIRE EQUIPMENT

The GT-R summer tires are made from a specially formulated rubber to maximize the vehicle's performance capabilities. Performance of summer tires is substantially reduced when temperatures are less than 32°F (0°C) so you must drive carefully. NISSAN recommends the use of winter or all-season tires on all four wheels if you plan to operate your vehicle in snowy or icy conditions when temperatures are less than 32°F (0°C).

# **WARNING**

Never use summer tires when the temperature is below -4°F (-20°C) to prevent permanent tread deformation which may cause tire damage or tire failure. This may cause a loss of vehicle control which can result in serious personal injury or death.

Tire chains may be used. (  $\nearrow$  "Tire chains" page 8-38)

If you install tires, they must also be the specified size, brand, construction and tread pattern on all four wheels.

#### SPECIAL WINTER EQUIPMENT

It is recommended that the following items be carried in the vehicle during winter:

- A scraper and stiff-bristled brush to remove ice and snow from the windows and wiper blades.
- A sturdy, flat board to be placed under the jack to give it firm support.
- A shovel to dig the vehicle out of snowdrifts.
- Extra window washer fluid to refill the reservoir tank.

#### **DRIVING ON SNOW OR ICE**

# **WARNING**

- Wet ice (32°F, 0°C and freezing rain), very cold snow or ice can be slick and very hard to drive on. The vehicle will have much less traction or "grip" under these conditions. Try to avoid driving on wet ice until the road is salted or sanded.
- Whatever the condition, drive with caution. Accelerate and slow down with care. If accelerating or downshifting too fast, the drive

wheels will lose even more traction.

- Allow more stopping distance under these conditions. Braking should be started sooner than on dry pavement.
- Allow greater following distances on slippery roads.
- Watch for slippery spots (glare ice). These may appear on an otherwise clear road in shaded areas. If a patch of ice is seen ahead, brake before reaching it. Try not to brake while on the ice, and avoid any sudden steering maneuvers.
- Do not use the cruise control on slippery roads.
- Snow can trap dangerous exhaust gases under your vehicle.
   Keep snow clear of the exhaust pipe and from around your vehicle.

#### NOTE:

When driving on snow, select the SAVE mode with the setup switch. By selecting the SAVE mode, the engine output is controlled appropriately for snow or

slippery road surfaces. This enables the vehicle to start or accelerate smoothly.

# ENGINE BLOCK HEATER (if so equipped)

Engine block heaters are used to assist with cold temperature starting.

The engine block heater should be used when the outside temperature is  $20^{\circ}F$  (-7°C) or lower.

# To use the engine block heater

- 1. Turn the engine off.
- Plug the engine block heater cord into a grounded 3-wire, 3-pronged extension cord.
- Plug the extension cord into a Ground Fault Interrupt (GFI) protected, grounded 110-volt AC (VAC) outlet.
- 4. The engine block heater must be plugged in for at least 2 - 4 hours, depending on outside temperatures, to properly warm the engine coolant. Use an appropriate timer to turn the engine block heater on.
- Before starting the engine, unplug and properly store the cord to keep it away from moving parts.


# **WARNING**

- Do not use your engine block heater with an ungrounded electrical system or a 2-pronged adapter. You can be seriously injured by an electrical shock if you use an ungrounded connection.
- Disconnect and properly store the engine block heater cord before starting the engine. Damage to the cord could result in an electrical shock and can cause serious injury.
- Use a heavy-duty 3-wire, 3pronged extension cord rated for at least 10A. Plug the extension cord into a Ground Fault Interrupt (GFI) protected, grounded 110-VAC outlet.

Failure to use the proper extension cord or a grounded outlet can result in a fire or electrical shock and cause serious personal injury.

# **EXHAUST SOUND CONTROL** SYSTEM (if so equipped)

This system enhances exhaust sound silencing by closing the electronic control valve while starting the engine, and while idling after starting the engine.



To close the electronic control valve, push the exhaust sound control switch to the ON side.

To open the electronic control valve, push the exhaust sound control switch to the OFF side.

#### NOTE:

Do not disconnect the electronic control valve connector. If the connector is not plugged in, the system will detect this as a malfunction and engine output will be limited.

# **ACTIVE NOISE CANCELLATION (if** so equipped)/ACTIVE SOUND **ENHANCEMENT** (if so equipped)





#### NOTE:

To operate the active noise cancellation and active sound enhancement system properly:

- Do not cover the speakers or woofer.
- Do not cover the microphones.
- Do not change or modify speakers including the woofer and any audio related parts such as the amplifier.
- Do not make any modification including sound deadening or modifications around the microphones, speakers or woofer.

#### **ACTIVE NOISE CANCELLATION**

The active noise cancellation uses the front and rear microphones ① to detect engine booming noise. The system then automatically generates a noise cancelling sound through the speakers (2) and woofer 3 to reduce engine booming noise

The front and rear microphones (1) are located inside of the roof.

The front speakers are located on the doors and the woofer is located in between the rear seats.

#### **ACTIVE SOUND ENHANCEMENT**

The active sound enhancement generates sounds according to engine speed and driving modes selected by the Vehicle Dynamic Control (VDC) system, transmission and suspension setup switches through the speakers (2) and woofer (3) to enhance the quality of the engine sound.


In addition, if the gear is shifted or the accelerator pedal is quickly operated when the transmission setup switch is in R mode and the engine warmed up, a sound effect is output to enhance the sense of sportiness. ( >> "R mode" page 5-25)

# 6 In case of emergency

Hazard warning flasher switch		Jun
Roadside assistance program	6-2	Pus
Emergency engine shut off	6-3	If yo
Flat tire		Tov
Tire Pressure Monitoring System (TPMS)	6-3	
Run-flat tires	6-4	

Jump starting	6-5
Push starting	6-8
If your vehicle overheats	6-8
Towing your vehicle	6-9
Towing recommended by NISSAN 6	5-10
Vehicle recovery (freeing a stuck vehicle) 6	5-10

### HAZARD WARNING FLASHER SWITCH



Push the switch on to warn other drivers when you must stop or park under emergency conditions. All turn signal lights will flash.

The flasher can be actuated with the ignition switch in any position.

Some state laws may prohibit the use of the hazard warning flasher switch while driving.

# **WARNING**

- If stopping for an emergency, be sure to move the vehicle well off the road.
- Do not use the hazard warning flashers while moving on the highway unless unusual circumstances force you to drive so slowly that your vehicle might become a hazard to other traffic.
- Turn signals do not work when the hazard warning flasher lights are on.

## ROADSIDE ASSISTANCE PROGRAM

In the event of a roadside emergency, Roadside Assistance Service is available to you. Please refer to your Warranty Information Booklet (U.S.) or Warranty & Roadside Assistance Information Booklet (Canada) for details.

#### **EMERGENCY ENGINE SHUT OFF**

To shut off the engine in an emergency situation while driving, perform the following procedure:

- Rapidly push the push-button ignition switch 3 consecutive times in less than 1.5 seconds, or
- Push and hold the push-button ignition switch for more than 2 seconds.

#### **FLAT TIRE**

## TIRE PRESSURE MONITORING SYSTEM (TPMS)

This vehicle is equipped with the Tire Pressure Monitoring System (TPMS). It monitors tire pressure of all tires. When the low tire pressure warning light is lit, one or more of your tires is significantly under-inflated. If the vehicle is being driven with low tire pressure, the TPMS will activate and warn you of it by the low tire pressure warning light (in the meter) or the warning message (on the display). This system will activate only when the vehicle is driven at speeds above 16 MPH (25 km/h). ( \*\* "Low tire pressure warning light" page 2-30) ( \*\* "Tire Pressure Monitoring System (TPMS)" page 5-4)

## **WARNING**

 If the low tire pressure warning light illuminates while driving, avoid sudden steering maneuvers or abrupt braking, reduce vehicle speed, pull off the road to a safe location and stop the vehicle as soon as possible. Driving with under-inflated tires may permanently damage the tires and increase the likelihood of tire failure. Serious vehicle damage could occur and may lead to an accident and could result in serious personal iniury. Check the tire pressure for all four tires. Adjust the tire pressure to the recommended COLD tire pressure shown on the Tire and Loading Information label to turn the low tire pressure warning light off. If the light still illuminates while driving after adjusting the tire pressure, a tire may be flat ( Run-flat tires" page 6-4) or the TPMS may be malfunctioning. If no tire is flat and all tires are properly inflated, it is recommended you have the vehicle checked by a GT-R certified NISSAN dealer.

- When a wheel is replaced, the TPMS will not function and the low tire pressure warning light will flash for approximately 1 minute. The light will remain on after 1 minute. It is recommended you contact a GT-R certified NISSAN dealer as soon as possible for tire replacement and/or system resetting.
- Replacing tires with those not originally specified by NISSAN

- could affect the proper operation of the TPMS.
- Do not inject any tire liquid or aerosol tire sealant into the tires. as this may cause a malfunction of the tire pressure sensors.

#### NOTE:

- You can check the pressure of all four tires on the touch screen display. See the separate Multi Function Display Owner's Manual.
- The tires of this vehicle are filled with nitrogen gas. When the tire pressure is low, fill the tires with nitrogen. It is recommended you contact a GT-R certified NISSAN dealer for information on filling the tires with nitrogen.
- If nitrogen is not available, compressed air may be safely used under normal driving conditions. However, NISSAN recommends refilling with nitrogen for maximum tire performance.

#### **RUN-FLAT TIRES**

Run-flat tires are those tires that can be used temporarily if they are punctured. ( Pragramma "Run-flat tires" page 8-36)

Also, see the tire safety information in the Warranty Information Booklet.

### **WARNING**

- Although you can continue driving with a punctured run-flat tire, remember that vehicle handling stability is reduced, which could lead to an accident and personal iniury. Also, driving a long distance at high speeds may damage the tires.
- Do not drive at speeds above 50 MPH (80 km/h) and do not drive more than 50 miles (80 km) with a punctured run-flat tire. The actual distance the vehicle can be driven on a flat tire depends on outside temperature, vehicle load, road conditions and other factors.
- Drive safely at reduced speeds. Avoid hard cornering or braking, which may cause you to lose control of the vehicle.

#### NOTICE

- Never install tire chains on a punctured run-flat tire, as this could damage your vehicle.
- Avoid driving over any projection or pothole, as the clearance between the vehicle and the ground is smaller than normal.
- Do not enter an automated car wash with a punctured run-flat tire.
- It is recommended you have the punctured tire replaced by your GT-R certified NISSAN dealer as soon as possible, as the tire's performance capability is reduced.

If you have a flat tire and have to stop the vehicle, follow the instructions below.

- 1. Safely move the vehicle off the road and away from traffic.
- 2. Turn on the hazard warning flashers.
- 3. Park on a level surface and apply the parking brake. Move the shift lever to the P position.
- 4. Turn off the engine.
- 5. Raise the hood to warn other traffic.

- and to signal professional road assistance personnel that you need assistance.
- Have all passengers get out of the vehicle and stand in a safe place, away from traffic and clear of the vehicle.

For the tire removing procedure, see the following section. ( \*\*\sum\_ "Jacking vehicle and removing wheels" page 8-41)

#### **JUMP STARTING**

The following circumstances indicate that the battery is discharged.

- The starter motor does not turn or it turns weakly and the engine does not start.
- The vehicle lights are much dimmer than usual.
- The sound of the horn is weak. The horn makes no sound.

#### **NOTICE**

When the battery is discharged, do not close either of the front doors. The automatic window adjusting function will not work, and the side roof panel may be damaged.

To start your engine with a booster battery, the instructions and precautions below must be followed.


For the battery maintenance information, see the following section. ( \*\*\overline{Lag} "Battery" page 8-13)

### **MARNING**

- If done incorrectly, jump starting can lead to a battery explosion, resulting in severe injury or death. It could also damage your vehicle.
- Explosive hydrogen gas is always present in the vicinity of the battery. Keep all sparks and flames away from the battery.
- Do not allow battery fluid to come into contact with eyes, skin, clothing or painted surfaces. Battery fluid is a corrosive sulphuric acid solution which can cause severe burns. If the fluid should come into contact with anything, immediately flush the contacted area with water.
- Keep the battery out of the reach of children.
- The booster battery must be rated at 12 volts. Use of an improperly rated battery can damage your vehicle.
- Whenever working on or near a battery, always wear suitable eye protectors (for example, goggles or industrial safety spectacles)

and remove rings, metal bands, or any other jewelry. Do not lean over the battery when jump starting.

- Do not attempt to jump start a frozen battery. It could explode and cause serious injury.
- Your vehicle has an automatic engine cooling fan. It could come on at any time. Keep hands and other objects away from it.



### **WARNING**

Always follow the instructions below. Failure to do so could result in damage to the charging system and cause personal injury.

- If the booster battery is in another vehicle (A) position the two vehicles (A) and (B) to bring their batteries into close proximity to each other. Do not allow the two vehicles to touch.
- 2. Apply parking brake. Move the shift lever to the P position. Switch off all

- unnecessary electrical systems (light, heater, air conditioner, etc.).
- 3. Remove the battery cover. Cover the battery with a firmly wrung out moist cloth to reduce explosion hazard.
- 4. Connect jumper cables in the seguence as illustrated (1)  $\rightarrow$  (2)  $\rightarrow$  (3)  $\rightarrow$ (4)).

If the battery is disconnected or discharged, the steering wheel will lock and cannot be turned. Supply power using jumper cables before pushing the ignition switch and disengaging the steering lock.

### **A** CAUTION

- Always connect positive (+) to positive (+) and negative (-) to body ground (as illustrated), not to the battery.
- Make sure that the jumper cables do not touch moving parts in the engine compartment and that clamps do not contact any other metal.
- 5. Start the engine of the booster vehicle A and let it run for a few minutes.
- 6. Keep the engine speed of the booster

vehicle (A) at about 2,000 rpm, and start the engine of the vehicle being jump started (B).

#### NOTE:

Do not keep the starter motor engaged for more than 10 seconds. If the engine does not start right away. push the ignition switch to the OFF position and wait 10 seconds before trving again.

- 7. After starting your engine, carefully disconnect the negative cable and then the positive cable ( $4 \rightarrow 3 \rightarrow 2$ )  $\rightarrow$  (1)).
- 8. Be sure to dispose of the cloth used to cover the vent holes as it may be contaminated with corrosive acid.
- 9. Put the battery cover on.

#### NOTE:

If the clamp clip is difficult to connect to the battery terminal, remove the cowl top cover to make it easier. ( Removing the cowl top cover" page 8-5)

#### **PUSH STARTING**

Do not attempt to start the engine by pushing.

#### **NOTICE**

Your NISSAN cannot be push-started or tow-started. Attempting to do so may cause transmission damage.

#### IF YOUR VEHICLE OVERHEATS

### **WARNING**

- Do not continue to drive if your vehicle overheats. Doing so could cause engine damage or a vehicle fire.
- To avoid the danger of being scalded, never remove the radiator filler cap and the coolant reservoir cap while the engine is still hot. When the cap is removed, pressurized hot water will spurt out, possibly causing serious injury.
- Do not open the hood if steam is coming out.

If your vehicle is overheating (indicated by an extremely high temperature gauge reading), or if you feel a lack of engine power, detect unusual noise, etc., take the following steps:

1. Move the vehicle safely off the road, apply the parking brake and move the shift lever to the position.

#### Do not stop the engine.

2. Turn off the air conditioner. Open all the windows, move the temperature control to maximum hot and fan

control to high speed.

- 3. If engine overheating is caused by climbing a long hill on a hot day, run the engine at a fast idle (approximately 1.500 rpm) until the temperature gauge indication returns to normal
- 4. Get out of the vehicle. Look and listen for steam or coolant escaping from the radiator before opening the hood. (If steam or coolant is escaping, turn off the engine.) Do not open the hood further until no steam or coolant can be seen.
- 5. Open the engine hood.

### **WARNING**

If steam or water is coming from the engine, stand clear to prevent getting burned.

6. Visually check drive belts for damage or looseness. Also check if the cooling fan is running. The radiator hoses and radiator should not leak water. If coolant is leaking, the drive belts are missing or loose, or the cooling fan does not run, stop the engine.

### **WARNING**

Be careful not to allow your hands. hair, jewelry or clothing to come into contact with, or get caught in, engine belts or the engine cooling fan. The engine cooling fan can start at anv time.

- 7. When the coolant temperature gauge goes down to the midpoint, stop the engine and wait until the gauge goes down further to "C" (cold).
- 8. After the engine cools down, check the coolant level in the reservoir tank. Add coolant to the reservoir, if necessary, after opening the coolant reservoir cap with a heavy cloth covering it. ( F) "Engine cooling system" page 8-6)
- 9. It is recommended you have your vehicle repaired at the nearest GT-R certified NISSAN dealer.

#### **TOWING YOUR VEHICLE**


When towing your vehicle, all State (Provincial in Canada) and local regulations for towing must be followed. Incorrect towing equipment could damage your vehicle. Towing instructions are available from a GT-R certified NISSAN dealer. Local service operators are familiar with the applicable laws and procedures for towing. To assure proper towing and to prevent accidental damage to your vehicle. NISSAN recommends that you have a service operator tow your vehicle. It is advisable to have the service operator carefully read the following precautions.

## **WARNING**

- Never ride in a vehicle that is being towed.
- Never get under your vehicle after it has been lifted by a tow truck.

## **A** CAUTION

Always attach safety chains before towing.



#### **TOWING RECOMMENDED BY** NISSAN

NISSAN recommends that towing dollies be used when towing your vehicle or the vehicle be placed on a flat bed truck as illustrated

#### NOTICE

Never tow the vehicle with any of the wheels on the ground as this may cause serious and expensive damage to the powertrain.

### **VEHICLE RECOVERY (freeing a** stuck vehicle)

### **WARNING**

To avoid vehicle damage, serious personal injury or death when recovering a stuck vehicle:

- Contact a professional towing service to recover the vehicle if you have any questions regarding the recovery procedure.
- Tow chains or cables must be attached only to main structural members of the vehicle.
- Do not use the vehicle tie-downs to tow or free a stuck vehicle.
- Only use devices specifically designed for vehicle recovery and follow the manufacturer's instructions.
- Always pull the recovery device straight out from the front of the vehicle. Never pull at an angle.
- Route recovery devices so they do not touch any part of the vehicle except the attachment point.

If your vehicle is stuck in sand, snow, mud. etc., use a tow strap or other device designed specifically for vehicle recovery. Always follow the manufacturer's instructions for the recovery device.

### Rocking a stuck vehicle

If your vehicle is stuck in sand, snow, mud, etc., use the following procedure:

- 1. Turn off the Vehicle Dynamic Control (VDC) system and select SAVE mode with the transmission setup switch. ( 기공 "VDC, transmission and suspension setup switches" page 5-25)
- 2. Make sure the area in front and behind the vehicle is clear of obstructions.
- 3. Turn the steering wheel right and left to clear an area around the front tires.
- 4. Slowly rock the vehicle forward and backward.
  - Shift back and forth between the R and A↔M positions.
  - Apply the accelerator as little as possible to maintain the rocking motion.
  - Release the accelerator pedal before shifting between the R and A↔M positions.
  - Do not spin the tires above 35 MPH

(55 km/h).

- 5. Turn on the Vehicle Dynamic Control (VDC) system.
- 6. If the vehicle cannot be freed after a few tries, contact a professional towing service to remove the vehicle.

### **WARNING**

- Stand clear of a stuck vehicle.
- Do not spin your tires at high speed. This could cause them to explode and result in serious iniury. Parts of your vehicle could also overheat and be damaged.

### **MEMO**

# 7 Appearance and care

Cleaning exterior	7-2
Washing	
Waxing	7-3
Removing spots	7-3
Underbody	7-3
Glass	7-3
Wheels	7-4
Chrome parts	7-4
Front grille	7-4
Outside door handles	7-4
Tire dressing	7-4
Dry carbon fiber parts (if so equipped)	7-5

Cleaning interior	7-5
Air fresheners	7-6
Floor mats	7-6
Seat belts	7-8
Corrosion protection	7-9
Most common factors contributing to	
vehicle corrosion	7-9
Environmental factors influence the rate	
of corrosion	7-9
To protect your vehicle from corrosion	7-9

#### **CLEANING EXTERIOR**

In order to maintain the appearance of your vehicle, it is important to take proper care of it.

To protect the paint surfaces, wash your vehicle as soon as you can:

- after a rainfall to prevent possible damage from acid rain
- after driving on coastal roads
- when contaminants such as soot, bird droppings, tree sap, metal particles or bugs get on the paint surface
- when dust or mud builds up on the surface

Whenever possible, store or park your vehicle inside a garage or in a covered area.

When it is necessary to park outside, park in a shady area or protect the vehicle with a body cover.

Be careful not to scratch the paint surface when putting on or removing the body cover.

#### WASHING

Wash dirt off the vehicle with a wet sponge and plenty of water. Clean the vehicle thoroughly using a mild soap, a special vehicle soap or general purpose dishwashing liquid mixed with clean, lukewarm (never hot) water.

#### NOTICE

- Do not use an automatic car wash. The rear spoiler may be damaged.
- Do not use car washes that use acid in the detergent. Some car washes, especially brushless ones, use some acid for cleaning. The acid may react with some plastic vehicle components, causing them to crack. This could affect their appearance, and also could cause them not to function properly. Always check with your car wash to confirm that acid is not used.
- Do not wash the vehicle with strong household soap, strong chemical detergents, gasoline or solvents.
- Do not wash the vehicle in direct

sunlight or while the vehicle body is hot, as the surface may become water-spotted.

- Avoid using tight-napped or rough cloths, such as washing mitts. Care must be taken when removing caked-on dirt or other foreign substances so the paint surface is not scratched or damaged.
- For models with decorative sticker and/or protection film on front fender and rear bumper, observe the following:
  - Wash dirt off the vehicle with a wet sponge and plenty of water. Then wipe the vehicle gently using a soft cloth.
  - Do not apply direct water pressure, such as high-pressure sprayer, on the vehicle body around the sticker and/ or protection film. This may cause the sticker and/or protection film edges to peel away or come off from the vehicle.

Rinse the vehicle thoroughly with plenty of clean water.

Inside flanges, seams and folds on the doors, hatches and hood are particularly vulnerable to the effects of road salt. Therefore, these areas must be regularly cleaned. Take care that the drain holes in the lower edge of the door are open. Spray water under the body and in the wheel wells to loosen the dirt and wash away road salt.

Avoid leaving water spots on the paint surface by using a damp chamois to dry the vehicle.

#### WAXING

Regular waxing protects the paint surface and helps retain new vehicle appearance. Polishing is recommended to remove built-up wax residue and to avoid a weathered appearance before reapplying wax.

A GT-R certified NISSAN dealer can assist you in choosing the proper product.

- Wax your vehicle only after a thorough washing. Follow the instructions supplied with the wax.
- Do not use a wax containing any abrasives, cutting compounds or cleaners that may damage the vehicle finish.

Machine compound or aggressive polishing on a base coat/clear coat paint finish may dull the finish or leave swirl marks.

### **WARNING**

Do not use wax on the glass, rubber or plastic parts around the glass or door. This may prevent the window operation or cause poor visibility and the wax cannot be coated uniformly.

#### NOTICE

- Do not use compound agents on clear-coated dry carbon fiber parts (such as the NISMO model's bumper, side sill protector, rear spoiler, roof, hood duct, front fender duct. etc.).
- Do not use any chemical agents (wax, coating agent, compound agent, etc.) on matte-painted dry carbon fiber parts (such as the rear diffuser, a rear spoiler that is of specifications other than NISMO, etc.).

#### REMOVING SPOTS

Remove tar and oil spots, industrial dust, insects, and tree sap as quickly as possible from the paint surface to avoid lasting damage or staining. Special cleaning products are available at a GT-R certified NISSAN dealer or any automotive accessory stores.

#### **UNDERBODY**

In areas where road salt is used in winter. the underbody must be cleaned regularly. This will prevent dirt and salt from building up and causing the acceleration of corrosion on the underbody and suspension. Before the winter period and again in the spring, the underseal must be checked and, if necessary, re-treated.

#### GLASS

Use glass cleaner to remove smoke and dust film from the glass surfaces. It is normal for glass to become coated with a film after the vehicle is parked in the hot sun. Glass cleaner and a soft cloth will easily remove this film.

#### **NOTICE**

When cleaning the inside of the windows, do not use sharp-edged tools, abrasive cleaners or chlorinebased disinfectant cleaners. They could damage the electrical conductors, radio antenna elements or rear window defroster elements.

#### WHFFIS

Wash the wheels when washing the vehicle to maintain their appearance.

- Clean the inner side of the wheels when the wheel is changed or the underside of the vehicle is washed.
- Inspect wheel rims regularly for dents or corrosion. Such damage may cause loss of pressure or poor seal at the tire bead.
- NISSAN recommends that the road wheels be waxed to protect against road salt in areas where it is used during winter.

### **CAUTION**

Do not use abrasive cleaners when washing the wheels.

#### Aluminum alloy wheels

Wash regularly with a sponge dampened in a mild soap solution, especially during winter months in areas where road salt is used. Salt could discolor the wheels if not removed.

It may discolor to black depending on storage conditions. If only one wheel is changed, it may be different color with other wheels. If the wheel is changed, It is recommended you consult with a GT-R certified NISSAN dealer.

#### **NOTICE**

Follow the directions below to avoid staining or discoloring the wheels:

- Do not use a cleaner that uses strong acid or alkali contents to clean the wheels.
- Do not apply wheel cleaners to the wheels when they are hot. The wheel temperature should be the same as ambient tempera-

ture.

Rinse the wheel to completely remove the cleaner within 15 minutes after the cleaner is applied.

#### CHROME PARTS

Clean chrome parts regularly with a nonabrasive chrome polish to maintain the finish.

#### FRONT GRILLE

Use alcohol (IPA), such as ethanol, to remove dirt, tar and oil spots, etc. that adheres to the surface of plated parts.

#### **OUTSIDE DOOR HANDLES**

After driving on a road where salt is used in winter, immediately wash and clean the outside door handles that are provided with a special coating. This will keep the beautiful finish longer.

#### TIRE DRESSING

NISSAN does not recommend the use of tire dressings. Tire manufacturers apply a coating to the tires to help reduce discoloration of the rubber. If a tire dressing is applied to the tires, it may react with the coating and form a compound. This compound may come off the tire while driving and stain the vehicle paint. If you choose to use a tire dressing, take the following precautions:

- Use a water-based tire dressing. The coating on the tire dissolves more easily with an oil-based tire dressing.
- Apply a light coat of tire dressing to help prevent it from entering the tire tread/grooves (where it would be difficult to remove).
- Wipe off excess tire dressing using a dry towel. Make sure the tire dressing is completely removed from the tire tread/grooves.
- Allow the tire dressing to dry as recommended by tire dressing manufacturer.

### DRY CARBON FIBER PARTS (if so equipped)

Because of the characteristics of the material, the dry carbon fiber parts may turn vellow due to exposure to ultraviolet rays. The surfaces of dry carbon fiber parts are coated with a special ultraviolet protection paint. To maintain the appearance of these parts, it is important to take proper care of them.

#### **NOTICE**

- Do not use compound agents on clear-coated dry carbon fiber parts (such as the NISMO model's bumper, side sill protector, rear spoiler, roof, hood duct, front fender duct. etc.).
- Do not use any chemical agents (wax, coating agent, compound agent, etc.) on matte-painted dry carbon fiber parts (such as the rear diffuser, a rear spoiler that is of specifications other than NISMO, etc.).
- When dry carbon fiber parts become dirty, prepare a dilute cleaning solution by mixing one capful of mild detergent in a bucket of water, and use that mixture to clean the parts.

#### NOTE:

The surfaces of the dry carbon fiber parts are lightly coated like a race car so that you can feel the proper texture of real carbon, which may feel rough. This is normal.

#### **CLEANING INTERIOR**

Occasionally remove loose dust from the interior trim, plastic parts and seats using a vacuum cleaner or soft bristled brush. Wipe the vinyl and leather surfaces with a clean, soft cloth dampened in mild soap solution, then wipe clean with a dry soft cloth

Regular care and cleaning is required in order to maintain the appearance of the leather.

Before using any fabric protector, read the manufacturer's recommendations. Some fabric protectors contain chemicals that may stain or bleach the seat material.

Use a cloth dampened only with water, to clean the meter and gauge lens.

### **WARNING**

Do not use water or acidic cleaners (hot steam cleaners) on the seat. This can damage the seat or occupant classification sensor. This can also affect the operation of the air bag system and result in serious personal injury.

### **A** CAUTION

- Never use benzine, thinner, or any similar material.
- For cleaning, use a soft cloth, dampened with water. Never use a rough cloth, alcohol, benzine, thinner or any kind of solvent or paper towel with a chemical cleaning agent. They will scratch or cause discoloration to the lens.
- Do not spray any liquid such as water on the meter lens. Spraying liquid may cause the system to malfunction.

#### **NOTICE**

- Small dirt particles can be abrasive and damaging to the leather surfaces and should be removed promptly. Do not use saddle soap, car waxes, polishes, oils, cleaning fluids, solvents, detergents or ammonia-based cleaners as they may damage the leather's natural finish.
- Never use fabric protectors unless recommended by the manu-

#### facturer.

 Do not use glass or plastic cleaner on meter or gauge lens covers. It may damage the lens cover.

#### **AIR FRESHENERS**

Most air fresheners use a solvent that could affect the vehicle interior. If an air freshener is used, take the following precautions:

- Hanging-type air fresheners can cause permanent discoloration when they contact vehicle interior surfaces.
   Place the air freshener in a location that allows it to hang free and not contact an interior surface.
- Liquid-type air fresheners typically clip on the vents. These products can cause immediate damage and discoloration when spilled on interior surfaces.

Carefully read and follow the manufacturer's instructions before using air fresheners.


#### **FLOOR MATS**

### **WARNING**

To avoid potential pedal interference that may result in a collision, injury or death:

- NEVER place a floor mat on top of another floor mat in the driver front position or install them upside down or backwards.
- Use only genuine NISSAN floor mats or equivalent floor mats that are specifically designed for use in your vehicle model and model year.
- Properly position the mats in the floorwell using the floor mat positioning hooks. ( \*\* "Floor mat installation" page 7-7)
- Make sure the floor mat does not interfere with pedal operation.
- Periodically check the floor mats to make sure they are properly installed.
- After cleaning the vehicle interior, check the floor mats to make sure they are properly installed.

The use of genuine NISSAN floor mats can extend the life of your vehicle carpet and make it easier to clean the interior. Mats should be maintained with regular cleaning and replaced if they become excessively worn.



#### Floor mat installation

Your vehicle is equipped with floor mat positioning hook(s). The number and shape of the floor mat positioning hooks for each seating position varies depending on the vehicle.

When installing genuine NISSAN floor mats, follow the installation instructions provided with the floor mat and the followina:

- 1. Position the floor mat in the floorwell. so that the mat grommet holes are aligned with the hook(s).
- 2. Secure the grommet holes into the hook(s) and ensure that the floor mat

- is properly positioned.
- 3. Make sure the floor mat does not interfere with pedal operation. With the ignition in the OFF position and the shift lever in the P (Park) position, fully apply and release all pedals. The floor mat must not interfere with pedal operation or prevent the pedal from returning to its normal position. It is recommended you see a GT-R certified NISSAN dealer for details about installing the floor mats in your vehicle.



### **WARNING**

Do not allow wet seat belts to roll up in the retractor. NEVER use bleach, dye, or chemical solvents to clean the seat belts, since these materials may severely weaken the seat belt webbing.



#### Positioning hooks

The illustration shows the location of the floor mat positioning hooks.

#### **SEAT BELTS**

The seat belts can be cleaned by wiping them with a sponge dampened in a mild soap solution. Allow the belts to dry completely in the shade before using them. ( \*\*Seat belt maintenance\*\* page 1-12)

### Cleaning the power window finisher

Moisten a soft cloth with neutral detergent and wipe off the dirt on the power window finisher ①.

After wiping off the dirt, soak a cloth with water and wring it out thoroughly, then wipe off the neutral detergent.

#### **NOTICE**

Some cleaners may cause the paint to peel or cause spots to occur. If using a cleaner, it is recommended you consult with a GT-R certified NISSAN dealer.

#### **CORROSION PROTECTION**

### MOST COMMON FACTORS CON-TRIBUTING TO VEHICLE CORRO-SION

- The accumulation of moisture-retaining dirt and debris in body panel sections, cavities, and other areas.
- Damage to paint and other protective coatings caused by gravel and stone chips or minor traffic accidents.

### ENVIRONMENTAL FACTORS IN-FLUENCE THE RATE OF CORRO-SION

#### Moisture

Accumulation of sand, dirt and water on the vehicle body underside can accelerate corrosion. Wet floor coverings will not dry completely inside the vehicle, and should be removed for drying to avoid floor panel corrosion.

### Relative humidity

Corrosion will be accelerated in areas of high relative humidity, especially those areas where the temperatures stay above freezing where atmospheric pollution exists, or where road salt is used.

#### **Temperature**

A temperature increase will accelerate the rate of corrosion to those parts which are not well ventilated.

### Air pollution

Industrial pollution, the presence of salt in the air in coastal areas, or heavy road salt use will accelerate the corrosion process. Road salt will also accelerate the disintegration of paint surfaces.

### TO PROTECT YOUR VEHICLE FROM CORROSION

- Wash and wax vour vehicle often to keep the vehicle clean.
- Always check for minor damage to the paint and repair it as soon as possible.
- Keep drain holes at the bottom of the doors open to avoid water accumulation.
- Check the underbody for accumulation of sand, dirt or salt. If present, wash with water as soon as possible.

### **A** CAUTION

- NEVER remove dirt, sand or other debris from the passenger compartment by washing it out with a hose. Remove dirt with a vacuum cleaner.
- Never allow water or other liquids to come in contact with electronic components inside the vehicle as this may damage them.

Chemicals used for road surface deicing are extremely corrosive. They accelerate corrosion and deterioration of underbody components such as the exhaust system, fuel and brake lines, brake cables, floor pan and fenders.

In winter, the underbody must be cleaned periodically.

For additional protection against rust and corrosion, which may be required in some areas, it is recommended you consult a GT-R certified NISSAN dealer.

# 8 Do-it-yourself

Maintenance precautions	8-3	Brakes	8-19
Engine compartment check locations	8-4	Self-adjusting brakes	8-19
Removing the cowl top cover	8-5	Brake pad wear warning (models without	
Engine cooling system	8-6	NCCB (NISSAN Carbon Ceramic	
Checking engine coolant level	8-8	Brake) package)	8-19
Changing engine coolant	8-8	High performance brake system (models	
Engine oil	8-9	without NCCB (NISSAN Carbon Ceramic Brake) package)	0_10
Checking engine oil level	8-9	Replacing the brake pads (models without	
Changing engine oil and filter	8-10	NCCB (NISSAN Carbon Ceramic	
Transmission oil		Brake) package)	8-20
Power steering fluid	8-11	NCCB (NISSAN Carbon Ceramic Brake) (if	
Brake fluid	8-11	so equipped)	8-20
Window washer fluid	8-12	Replacing brake pads and brake	
Battery	8-13	disc rotors	8-21
Precautions	8-14	Fuses	8-22
Fluid level check	8-14	Engine compartment	8-22
Jump starting	8-15	Passenger compartment	
Drive belts	8-16	Intelligent Key battery replacement	8-25
Spark plugs	8-16	Lights	8-27
Replacing spark plugs	8-17	Headlights	8-27
Air cleaner	8-17	Exterior and interior lights	8-28
Windshield wiper blades	8-18	Wheels and tires	
Cleaning	8-18	Tire pressure	8-30
Replacing the wiper blades	8-18	Tire and loading information label	8-32

Checking the tire pressure	8-33	Changing wheels and tires	8-38
Tire labeling	8-34	Jacking vehicle and removing wheels	8-41
Types of tires	8-36	Wheel lock nuts (if so equipped)	8-46
Tire chains	8-38		

#### **MAINTENANCE PRECAUTIONS**

When performing any inspection or maintenance work on your vehicle, always take care to prevent serious accidental injury to yourself or damage to the vehicle. The following are general precautions which should be closely observed.

### **WARNING**

- Park the vehicle on a level surface, apply the parking brake securely and block the wheels to prevent the vehicle from moving.
   Move the shift lever to the position.
- Be sure the ignition switch is in the OFF or LOCK position when performing any parts replacement or repairs.
- If you must work with the engine running, keep your hands, clothing, hair and tools away from moving fans, belts and any other moving parts.
- It is advisable to secure or remove any loose clothing and remove any jewelry, such as rings, watches, etc. before working on your vehicle.
- Always wear eve protection

- whenever you work on your vehicle.
- If you must run the engine in an enclosed space such as a garage, be sure there is proper ventilation for exhaust gases to escape.
- Never get under the vehicle while it is supported only by a jack. If it is necessary to work under the vehicle, support it with safety stands.
- Keep smoking materials, flame and sparks away from fuel tank and the battery.
- Your vehicle is equipped with an automatic engine cooling fan. It may come on at any time without warning, even if the ignition key is in the OFF position and the engine is not running. To avoid injury, always disconnect the negative battery cable before working near the fan.
- The fuel filter or fuel lines should be serviced by a GT-R certified NISSAN dealer because the fuel lines are under high pressure even when the engine is off.

### **A** CAUTION

- Do not work under the hood while the engine is hot. Turn the engine off and wait until it cools down.
- Avoid direct contact with used engine oil and coolant. Improperly disposed engine oil, coolant, and/or other vehicle fluids can damage the environment. Always conform to local regulations for disposal of vehicle fluid.

### **NOTICE**

- Never connect or disconnect the battery or any transistorized component while the ignition switch is in the ON position.
- Never leave the engine or transmission related component harnesses disconnected while the ignition switch is in the ON position.

This "8. Do-it-yourself" section gives instructions regarding only those items which are relatively easy for an owner to perform.

### **ENGINE COMPARTMENT CHECK LOCATIONS**

A genuine NISSAN Service Manual is also available. ( ) "Owner's Manual/Service Manual order information" page 10-24) You should be aware that incomplete or improper servicing may result in operating difficulties or excessive emissions. If in doubt about any servicing, we recommend that it be done by a GT-R certified NISSAN dealer.





- Fuse/fusible link holder
- Batterv
- Engine oil filler cap
- Engine oil dipstick
- Brake fluid reservoir
- Air cleaner

- Power steering fluid reservoir
- Radiator filler cap
- Coolant reservoir cap (pressure type)
- Coolant reservoir
- Window washer fluid reservoir

#### **NOTICE**

The coolant reservoir is equipped with a pressure type cap, and the radiator is equipped with a nonpressure type cap. Do not switch the radiator filler cap and the coolant reservoir cap. Doing so will cause substandard cooling performance and overheating.






#### REMOVING THE COWL TOP COVER

Remove the cowl top cover if necessary.

1. Remove the battery cover.

2. Unfasten the 5 clips and remove the cowl top cover (a) by pulling it up.



3. Unfasten the 3 clips and remove the cowl top cover ® by pulling it towards the front of the vehicle.

#### **ENGINE COOLING SYSTEM**

The engine cooling system is filled at the factory with a pre-diluted mixture of 50% Genuine NISSAN Long Life Antifreeze/ Coolant (blue) and 50% water to provide year-round anti-freeze and coolant protection. The anti-freeze solution contains rust and corrosion inhibitors. Additional engine cooling system additives are not necessary.


### **WARNING**

- Never remove the radiator or coolant reservoir cap when the engine is hot. Wait until the engine and radiator cool down. Serious burns could be caused by high pressure fluid escaping from the radiator. ( ) "If your vehicle overheats" page 6-8)
- The radiator is equipped with a pressure type radiator cap. To prevent engine damage, use only a genuine NISSAN radiator cap.


### **CAUTION**

- Never use any cooling system additives such as radiator sealer. Additives may clog the cooling system and cause damage to the engine, transmission and/or cooling system.
- When adding or replacing coolant, be sure to use only Genuine NISSAN Long Life Antifreeze/ Coolant (blue) or equivalent. Genuine NISSAN Long Life Antifreeze/ Coolant (blue) is pre-diluted to provide antifreeze protection to -34°F (-37°C). If additional freeze protection is needed due to weather where you operate your vehicle, add Genuine NISSAN Long Life Antifreeze/ Coolant (blue) concentrate following the directions on the container. If an equivalent coolant other than Genuine NISSAN Long Life Antifreeze/ Coolant (blue) is used, follow the coolant manufacture's instructions to maintain minimum antifreeze protection to -34°F (-37°C). The use of other types of coolant solutions other than Genuine NISSAN Long Life

- Antifreeze/ Coolant (blue) or equivalent may damage the engine cooling system.
- The life expectancy of the factory-fill coolant is 24,000 miles (38,400 km) or 2 years. Mixing any other type of coolant other than Genuine NISSAN Long Life Antifreeze/Coolant (blue) (or equivalent coolant), including Genuine NISSAN Long Life Antifreeze/Coolant (green), or the use of nondistilled water may reduce the life expectancy of the factoryfill coolant. Refer to the "9. Maintenance and schedules" section of this manual for more details.



**Except for NISMO models** 



NISMO models

- MAX line
- MIN line
- Between MAX and MIN lines (except for NISMO models)



### CHECKING ENGINE COOLANT LE-**VEL**

Check the coolant level in the reservoir when the engine is cold. If the coolant level is below the MIN level 2, open the reservoir cap (pressure type) (B) and add coolant up to between the MAX (1) and MIN (2) level. If the reservoir is empty, open the radiator filler cap (A) and check the coolant level in the radiator when the engine is cold. If there is insufficient coolant in the radiator, fill the radiator with coolant up to the filler opening and also add it to the reservoir up to between the MAX (1) and MIN (2) level.

This vehicle contains Genuine NISSAN Long Life Antifreeze/Coolant (blue). The life expectancy of the factory-fill coolant is 24,000 miles (38,400 km) or 2 years. Mixing any other type of coolant or the use of non-distilled water will reduce the life expectancy of the factory-fill coolant. Refer to the "9. Maintenance and schedules" section of this manual for more details.

If the cooling system frequently requires coolant, it is recommended you have it checked by a GT-R certified NISSAN dealer.

Check that the level of coolant is between MAX and MIN on the pressurized radiator reservoir. If the level is below the midpoint, the amount of coolant circulating may be insufficient for maximum vehicle performance, possibly causing engine overheating or other trouble.

For the coolant level and mixture ratio when engaging in performance driving, see 'S "Coolant level and mixture ratio" page GTR-15.

#### **Except for NISMO models:**

If it is difficult to determine the midpoint between MAX and MIN, remove the coolant reservoir cap and look inside through the opening to check that the coolant level is above the divider 3 between the top half and bottom half of the pressurized coolant reservoir.

#### **NOTICE**

- The coolant reservoir is equipped with a pressure type cap, and the radiator is equipped with a nonpressure type cap. Do not switch the radiator filler cap and the coolant reservoir cap. Doing so will cause substandard cooling performance and overheating.
- If you have added only water as the coolant in an emergency, change it to a coolant mixture ratio specified as soon as possible.

#### CHANGING ENGINE COOLANT

If major cooling system repairs are reguired, it is recommended you contact a GT-R certified NISSAN dealer. The service procedures can be found in the appropriate NISSAN Service Manual.


Improper servicing can result in reduced heater performance and engine overheating.

### **WARNING**

- To avoid the danger of being scalded, never change the coolant when the engine is hot.
- Never remove the radiator filler cap and the coolant reservoir cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator and reservoir.
- Avoid direct skin contact with used coolant. If skin contact is made, wash thoroughly with soap or hand cleaner as soon as possible.
- Keep coolant out of reach of children and pets.

Engine coolant must be disposed of properly. Check your local regulations.

#### **ENGINE OIL**



#### **CHECKING ENGINE OIL LEVEL**

- Park the vehicle on a level surface and apply the parking brake.
- 2. Run the engine until it reaches operating temperature.
- Turn off the engine. Wait at least 5 minutes for the oil to drain back into the oil pan before checking the oil.
- Remove the dipstick and wipe it clean. Reinsert it all the way.
- Remove the dipstick again and check the oil level. It should be within the range ①. If the oil level is below ②, remove the oil filler cap and pour recommended oil through the open-

ing. Do not overfill 3.

6. Recheck oil level with the dipstick.

#### NOTE:

- It is normal to add some oil between oil maintenance intervals or during the break-in period, depending on the severity of operating conditions. More engine oil is consumed by frequent acceleration/deceleration especially when the engine rpm is high. If your rate of oil consumption increases suddenly or without explanation, NISSAN recommends that you have your vehicle inspected by a GT-R certified NISSAN dealer.
- When the vehicle is delivered, the engine oil is set to 0.39 in (10 mm) below the H mark for optimal high performance driving. The engine oil can be filled up to the H mark if performance driving is not engaged.

#### **NOTICE**

 Mobil 1 (0W-40) (100% synthetic) is the factory fill oil. The VR38 engine with its plasma-sprayed bores was developed using this oil. NISSAN cannot ensure proper engine operation and durability if other OW-40 non-equivalent synthetic oil is used. If Mobil 1 (OW-40) or equivalent is not available, Mobil 1 (10W-40) (100% synthetic) or equivalent may be used; however, some performance loss may be noticed.

 Oil level should be checked regularly. Operating the engine with an insufficient amount of oil can damage the engine. See the 2021 NISSAN GT-R Warranty Information Booklet for details including applicable exclusions.

#### **CHANGING ENGINE OIL AND FILTER**

#### NOTE:

When replacement is required, it is recommended you contact a GT-R certified NISSAN dealer for servicing.

### **WARNING**

- Prolonged and repeated contact with used engine oil may cause skin cancer.
- Try to avoid direct skin contact with used oil. If skin contact is made, wash thoroughly with soap or hand cleaner as soon as pos-

#### sible.

 Keep used engine oil out of reach of children.

#### TRANSMISSION OIL


#### NOTE:

When checking or replacement is required, it is recommended you contact a GT-R certified NISSAN dealer for servicing.

#### **NOTICE**

- It is recommended that you use only Genuine NISSAN Transmission Oil R35 Special or equivalent.
   Do not mix with other fluids.
- Using transmission oil other than Genuine NISSAN Transmission Oil R35 Special or equivalent may cause deterioration in driveability and transmission durability, and may damage the transmission. See the 2021 NISSAN GT-R Warranty Information Booklet for details including applicable exclusions.

#### **POWER STEERING FLUID**



Check the fluid level in the reservoir. Remove the cap that is attached with a gauge inside.

The fluid level should be checked using the front side of the gauge marked "HOT" (①: HOT MIN., ②: HOT MAX.) at fluid temperatures of 122 to 176°F (50 to 80°C) or using the reverse side of the gauge marked "COLD" (③: COLD MIN., ④: COLD MAX.) at fluid temperatures of 32 to 86°F (0 to 30°C).

If the fluid is below the MIN line, add Genuine NISSAN PSF II or equivalent. Remove the cap and fill through the opening.

#### NOTE:

For maximum steering system performance, adjust the fluid level at the line (§) at the hot fluid temperature or (§) at the cold fluid temperature. We recommend contacting a GT-R certified NISSAN dealer when precise fluid level adjustment is required.

#### **NOTICE**

- Do not overfill.
- Use Genuine NISSAN PSF II or equivalent.

#### **BRAKE FLUID**

For further brake fluid information, see the following section. ( The "Capacities and recommended fluids/lubricants" page 10-2)

### **WARNING**


- Use only new fluid from a sealed container. Old, inferior or contaminated fluid may damage the brake system. The use of improper fluids can damage the brake system and affect the vehicle's stopping ability.
- Clean the filler cap before removing.
- Brake fluid is poisonous and should be stored carefully in marked containers out of the reach of children.

### **A** CAUTION

Genuine NISSAN Brake Fluid R35 Special II is the factory fill brake fluid. The Vehicle Dynamic Control (VDC) unit and other related parts were specially designed for this brake fluid and NISSAN cannot ensure proper operation of the vehicle if other non-equivalent brake fluid is used.


#### **NOTICE**

Do not spill the fluid on any painted surfaces. This will damage the paint. If fluid is spilled, wash the surface with water.



Check the fluid level in the reservoir. If the fluid is below the MIN line ① or the brake warning light comes on, add Genuine NISSAN Brake Fluid R35 Special II fluid (or equivalent) up to the MAX line (2). If fluid must be added frequently, the system should be checked. It is recommended you contact a GT-R certified NISSAN dealer.

#### WINDOW WASHER FLUID



### **WARNING**

Antifreeze is poisonous and should be stored carefully in marked containers out of the reach of children.

Fill the window washer fluid reservoir periodically. Add window washer fluid when the low washer fluid warning appears on the vehicle information display. ( Tow washer fluid warning" page 2-44)

To fill the window washer fluid reservoir, lift the cap off the reservoir tank and pour the window washer fluid into the tank

#### opening.

Add a washer solvent to the washer for better cleaning. In the winter season, add a windshield washer antifreeze. Follow the manufacturer's instructions for the mixture ratio.

Refill the reservoir more frequently when driving conditions require an increased amount of window washer fluid

#### **NOTICE**

- Do not substitute engine antifreeze coolant for window washer solution. This may result in damage to the paint.
- Do not fill the window washer reservoir tank with washer fluid concentrates at full strength.
   Some methyl alcohol based washer fluid concentrates may permanently stain the grille if spilled while filling the window washer reservoir tank.

#### NOTE:

Pre-mix washer fluid concentrates with water to the manufacturer's recommended levels before pouring the fluid into the window washer reservoir. Do not use the window washer reservoir to mix the washer fluid concentrate and water.

#### **BATTERY**

- Keep the battery surface clean and dry. Clean the battery with a solution of baking soda and water.
- Make certain the terminal connections are clean and securely tightened.
- If the vehicle is not to be used for 30 days or longer, disconnect the negative (-) battery terminal cable to prevent discharging it.

#### NOTE:

Care should be taken to avoid situations that can lead to potential battery discharge and potential no-start conditions such as:

- Installation or extended use of electronic accessories that consume battery power when the engine is not running (Phone chargers, GPS, DVD players, etc.)
- Vehicle is not driven regularly and/ or only driven short distances.

In these cases, the battery may need to be charged to maintain battery health.

#### **PRECAUTIONS**

#### **NOTICE**

When the battery cable is removed from the battery terminal, do not close either of the front doors. The automatic window adjusting function will not work, and the side roof panel may be damaged.

To disconnect the negative (-) battery terminal, perform the procedure in the following order. Otherwise, the window and the side roof panel may contact and be damaged.

- 1. Close the windows.
- 2. Open the hood.
- 3. Close and lock all the doors.
- Disconnect the negative (-) battery terminal.
- 5. Securely close the hood.

To connect the negative (-) battery terminal, perform the procedure in the following order. Otherwise, the window and the side roof panel may contact and be damaged.

- Unlock and open the driver side door.
   Do not close the door.
- 2. Open the hood.


- 3. Connect the negative (-) battery terminal. Then close the hood.
- Fully open the driver side door window.
- Close the driver side door and the window.


#### **FLUID LEVEL CHECK**

### **WARNING**

- Do not expose the battery to flames or electrical sparks. Hydrogen gas generated by the battery is explosive. Do not allow battery fluid to contact your skin, eyes, fabrics, or painted surfaces. After touching a battery or battery cap, do not touch or rub your eyes. Thoroughly wash your hands. If the acid contacts your eyes, skin or clothing, immediately flush with water for at least 15 minutes and seek medical attention.
- Do not operate the vehicle if the fluid in the battery is low. Low battery fluid can cause a higher load on the battery which can generate heat, reduce battery life, and in some cases lead to an explosion.

- When working on or near a battery, always wear suitable eye protection and remove all jewelry.
- Battery posts, terminals and related accessories contain lead and lead compounds. Wash hands after handling.
- Keep the battery out of the reach of children.





#### **JUMP STARTING**

If jump starting is necessary, see the following section. ( ) Jump starting" page 6-5)

If the engine does not start by jump starting, the battery may have to be replaced. It is recommended you contact a GT-R certified NISSAN dealer.

Check the fluid level in each cell (Remove the battery cover if it is necessary). It should be between the UPPER LEVEL (1) and LOWER LEVEL (2) lines.

If it is necessary to add fluid, add only distilled water to bring the level to the indicator in each filler opening. Do not overfill.


- Remove the cell plugs (A).
- 2. Add distilled water up to the UPPER LEVEL 1 line.

If the side of the battery is not clear. check the distilled water level by looking directly above the cell; the condition (1) indicates OK and the conditions 2 needs more to be added.

3. Tighten cell plugs (A).

Vehicles operated in high temperatures or under severe conditions require frequent checks of the battery fluid level.

#### **DRIVE BELTS**



- Power steering fluid pump
- Alternator
- Crankshaft pulley
- Air conditioner compressor
- Drive belt auto-tensioner

#### **WARNING**

Be sure the ignition switch is in the OFF or LOCK position before servicing drive belts. The engine could rotate unexpectedly.

Visually inspect each belt for signs of unusual wear, cuts, fraying or loosen-

#### ess. If the belt is in poor condition or loose, have it replaced or adjusted. It is recommended you contact a GT-R certified NISSAN dealer.

2. Have the belts checked regularly for condition and tension in accordance with the maintenance schedule shown in the "9. Maintenance and schedules" section.


#### **SPARK PLUGS**

### **WARNING**

Be sure the engine and the ignition switch are off and that the parking brake is engaged securely.

#### NOTICE

Be sure to use the correct socket to remove the spark plugs. An incorrect socket can damage the spark plugs.




### REPLACING SPARK PLUGS


If replacement is required, it is recommended you see a GT-R certified NISSAN dealer for servicing.

### Iridium-tipped spark plugs

It is not necessary to replace the iridiumtipped spark plugs as frequently as the conventional type spark plugs since they will last much longer. Follow the maintenance schedule shown in the "9. Maintenance and schedules" section, but do not reuse them by cleaning or regapping. Always replace spark plugs with recommended or equivalent ones.

#### **AIR CLEANER**





Remove the retainers (1) as illustrated and pull out the filter element (2).

The filter element should not be cleaned and reused. Replace it according to the maintenance intervals. See the "9. Maintenance and schedules" section for maintenance intervals. When replacing the filter, wipe the inside of the air cleaner housing and the cover with a damp cloth.

# **WARNING**

- Operating the engine with the air cleaner removed can cause you or others to be burned. The air cleaner not only cleans the air, it stops flame if the engine backfires. If it isn't there, and the engine backfires, you could be burned. Do not drive with the air cleaner removed, and be careful when working on the engine with the air cleaner removed.
- Never pour fuel into the throttle body or attempt to start the engine with the air cleaner removed. Doing so could result in serious injury.

#### WINDSHIELD WIPER BLADES

#### **CLEANING**


If your windshield is not clear after using the windshield washer or if a wiper blade chatters when running, wax or other material may be on the blade or windshield.

Clean the outside of the windshield with a washer solution or a mild detergent. Your windshield is clean if beads do not form when rinsing with clear water.

Clean each blade by wiping it with a cloth soaked in a washer solution or a mild detergent. Then rinse the blade with clear water. If your windshield is still not clear after cleaning the blades and using the wiper, replace the blades.

# **A** CAUTION

Worn windshield wiper blades can damage the windshield and impair driver vision.



#### REPLACING THE WIPER BLADES


Replace the wiper blades if they are worn.

- 1. Pull the wiper arm.
- 2. Push the release tab (A), and then move the wiper blade down the wiper arm (1) while pushing the release tab to remove.
- 3. Insert the new wiper blade onto the wiper arm until a click sounds.
- 4. Rotate the wiper blade so the dimple is in the aroove.

# **NOTICE**

- After wiper blade replacement, return the wiper arm to its original position; otherwise it may be damaged when the hood is opened.
- Make sure the wiper blades contact the glass; otherwise the arm may be damaged from wind pressure.





Be careful not to clog the washer nozzle ⓐ. This may cause improper windshield washer operation. If the nozzle is clogged, remove any objects with a needle or small pin ⑤. Be careful not to damage the nozzle.

#### **BRAKES**

If the brakes do not operate properly, have the brakes checked. It is recommended you contact a GT-R certified NISSAN dealer.

#### **SELF-ADJUSTING BRAKES**

Your vehicle is equipped with self-adjusting brakes.

The disc-type brakes self-adjust every time the brake pedal is applied.

# **WARNING**

We strongly recommend seeing a GT-R certified NISSAN dealer for a brake system check if the brake pedal height does not return to normal.

# BRAKE PAD WEAR WARNING (models without NCCB (NISSAN Carbon Ceramic Brake) package)

The disc brake pads have audible wear warnings. When a brake pad requires replacement, it will make a high pitched scraping sound when the vehicle is in motion. This scraping sound will first occur only when the brake pedal is depressed. After more wear of the brake pad, the sound will always be heard even

if the brake pedal is not depressed. Have the brakes checked as soon as possible if the wear warning sound is heard.

Under some driving or climate conditions, occasional brake squeak, squeal or other noise may be heard. Occasional brake noise during light to moderate stops is normal and does not affect the function or performance of the brake system.

**Proper brake inspection intervals should be followed.** For additional information, see the maintenance schedule shown in the "9. Maintenance and schedules" section.

# HIGH PERFORMANCE BRAKE SYSTEM (models without NCCB (NISSAN Carbon Ceramic Brake) package)

This vehicle is equipped with high performance brake pads that provide appropriate braking force in a broad range of driving environments. Due to the material used for the brake pads, the road wheels may become more easily covered by brake dust, however this does not indicate that there is a malfunction.

The GT-R brake pads use material that contains a lot of iron to maintain steady braking performance even in high and low temperatures. However, if the brake

system is wet and the parking brake is applied for a long time, the iron in this material may get rusty and the brake pad and disc rotor may be fixed together. This may cause noise and vibration while driving. Before parking the vehicle, dry the brake by driving on a dry road, especially after washing the vehicle or driving in rain. It is recommended you contact a GT-R certified NISSAN dealer if the noise and vibration continue.

Frequent hard braking may cause scorching of the brake pads. This will require the brake pads to be replaced, even if the wear limit has not been reached. Have the brake pads and disc rotors inspected at the regular vehicle inspections.

For more details, it is recommended you contact a GT-R certified NISSAN dealer.

# REPLACING THE BRAKE PADS (models without NCCB (NISSAN Carbon Ceramic Brake) package)

NISSAN generally recommends to replace all four sets of brake pads and disc rotors at the same time to maintain maximum brake performance.

However, replacing only the brake pads may be allowed in some cases (four wheels or only front wheels depending on the conditions). A GT-R certified technician must inspect the vehicle and determine that only the brake pads need to be replaced. In this case, replacing all brake pads and disc rotors as a set is not necessary.

Note that the replacement of brake pads and the disc rotors as a set on all four wheels should be performed when a GT-R certified technician determines that this is the correct repair.

If the inside of the disc rotors are cold during the winter and the surface becomes hot due to a heavy force being applied repeatedly to the brakes, cracks may occur near the coolant hole on the surface of the disc rotor. Cracks may also occur due to a heavy force being repeatedly applied to the brakes during high performance driving. In these cases it may be necessary to replace the disc rotors or brake pads depending on the condition of the crack. It is recommended you contact a GT-R certified NISSAN dealer for replacement.

# NCCB (NISSAN Carbon Ceramic Brake) (if so equipped)

#### NOTE:

- In order to enjoy the high performance braking sensation as well as
  the sporty driving and flexibility
  offered by the GT-R, NCCB (NISSAN
  Carbon Ceramic Brake) is available.
  In addition, NCCB (NISSAN Carbon
  Ceramic Brake) has excellent durability during normal driving and its
  light weight allows the reduction of
  the unsprung weight to improve the
  road holding grip performance.
- After high performance driving or extreme use of the brake, the composition of the brake disc rotor will change due to brake pad wear or high temperature friction heat. Even if the brake disc rotor looks normal, it may need to be replaced.
- NCCB (NISSAN Carbon Ceramic Brake) has the same full floating structure as the standard brake system in GT-R. Therefore, the joint of the full floating structure of the disc rotor may not rust depending on the status of use. In case of rust on the joint, have NCCB (NISSAN Carbon Ceramic Brake) and the related parts inspected. It is recommended you have the vehicle inspected by a GT-R certified NISSAN

dealer.

 The materials used for the brake disc rotor and brake pads for NCCB (NISSAN Carbon Ceramic Brake) are different from those used for the standard brake system in GT-R. The rotor and pads will be protected from adhesion caused by rusting. However, never park your vehicle for a long time with the brake system wet. This helps maintain the brake disc rotor and brake pads for a long time and prevents an influence on the material composition of the carbon ceramic rotor and deterioration in the joint of brake disc rotor's full floating structure. Especially during winter, be sure to park your vehicle with the brake disc rotor and pads dry to prevent them from being frozen and damaged in below freezing temperature conditions. The carbon ceramic brake includes air bubbles in the rotor and pads. Note that leaving them in the wet condition tends to cause adhesion due to freezing.

# **WARNING**

After an impact to the underbody or when the brake disc rotor has chipping or cracks, have your vehicle inspected. It is recommended you have the vehicle inspected by a GT-R certified NISSAN dealer. Otherwise, the brake disc rotor may be damaged, which may result in a serious accident.

#### NOTICE

- Never use brake cleaner or any chemical agent on the brake disc rotor. Using brake cleaner or any chemical agent on the brake disc rotor may cause a decrease in durability of the brake disc rotor.
- After driving on a gravel road, such as an evacuation route, have your vehicle checked for damage to the brake disc rotor. It is recommended you contact a GT-R certified NISSAN dealer for this service.
- Since the carbon ceramic brake disc rotor is very hard, do not

subject it to a strong impact. When removing the tires, be careful not to allow the tire to interfere with the brake disc rotor.

# REPLACING BRAKE PADS AND BRAKE DISC ROTORS

- When replacing brake pads and brake disc rotors, NISSAN recommends replacing two sets of them at the same time. However, the brake pads can be separately replaced only when a GT-R certified technician judges that the brake disc rotors are reusable, based on a measured weight and a check for scratches and cracks.
- It is recommended that maintenance and inspection on your vehicle should be performed at a GT-R certified NISSAN dealer after engaging in high performance driving. Otherwise, the peripheral parts of the brake may be damaged due to the generation of special radiant heat because of the characteristics of the material in addition to brake pad wear and the deterioration in durability of the brake disc rotor.

### **Brake pad**

When the brake warning light illuminates to indicate brake pad wear, have the brake system checked and brake pads replaced as soon as possible. It is recommended you contact a GT-R certified NISSAN dealer for this service.

# **A** CAUTION

Never drive for a long period of time when the warning light is illuminated. Otherwise, the brake may not function properly due to brake pad wear.

#### Brake disc rotor

Under the following conditions, the immediate replacement of the brake disc rotor may be necessary. Even if it looks normal, have your vehicle inspected immediately. It is recommended you contact a GT-R certified NISSAN dealer for this service.

- Extremely decreased braking force
- Chipping or cracks on the brake disc rotor
- After an impact to tires or the periph-

ery of the wheels

- Parts around the brake may have contacted with the brake disc rotor or brake caliper due to wear.
- The metal plate of a brake pad has contacted with the surface of a brake disc rotor because the brake pad replacement period was exceeded.
- Interference between the wheel and brake disc rotor during tire installation or removal.

# **WARNING**

When a GT-R certified technician judges that a brake disc rotor should be replaced, have the disc rotor replaced.

#### **FUSES**



#### **ENGINE COMPARTMENT**


# **WARNING**


Never use a fuse of a higher or lower amperage rating than that specified on the fuse box cover. This could damage the electrical system or electronic control units or cause a fire.

If any electrical equipment does not operate, check for an open fuse.

 Be sure the ignition switch is pushed to the OFF or LOCK position and the

- headlights are turned off.
- 2. Open the engine hood and remove the cover on the battery and the fuse/ fusible link holder.
- 3. Remove the fuse/fusible link holder cover
- 4. Remove the fuse with the fuse puller that is located in the engine compartment fuse box.





- 5. If the fuse is open (A), replace it with a new fuses ®. Spare fuses are stored in the passenger compartment fuse box.
- 6. If a new fuse also opens, have the electrical system checked and repaired. It is recommended you contact a GT-R certified NISSAN dealer.

#### **Fusible links**

If any electrical equipment does not operate and fuses are in good condition, check the fusible links. If any of these fusible links are melted, replace only with genuine NISSAN parts.

#### PASSENGER COMPARTMENT


#### **WARNING**

Never use a fuse of a higher or lower amperage rating than that specified on the fuse box cover. This could damage the electrical system or electronic control units or cause a fire.

If any electrical equipment does not operate, check for an open fuse.

1. Be sure the ignition switch is pushed to the OFF or LOCK position and the headlights are turned off.

2. Open the fuse box lid.



- 3. Remove the fuse with the fuse puller
- 4. If the fuse is open, replace it with a new fuse.
- 5. If a new fuse also opens, have the electrical system checked and repaired. It is recommended you contact a GT-R certified NISSAN dealer.

# Extended storage fuse switch (if so equipped)


To reduce battery drain, the extended storage fuse switch comes from the factory switched off. Prior to delivery of your vehicle, the switch is pushed in (switched on) and should always remain on.


If any electrical equipment does not operate, remove the extended storage fuse switch and check for an open fuse.

#### NOTE:

If the extended storage fuse switch malfunctions, or if the fuse is open, it is not necessary to replace the switch. In this case, remove the extended storage fuse switch and replace it with a new fuse of the same rating.

#### INTELLIGENT KEY BATTERY REPLACEMENT





- To remove the extended storage fuse switch, be sure the ignition switch is in the OFF or LOCK position.
- 2. Be sure the headlights are turned off.
- 3. Remove the fuse box cover.
- Pinch the locking tabs ① found on each side of the extended storage fuse switch.
- 5. Pull the extended storage fuse switch straight out from the fuse box ② .



# **WARNING**

Be careful that batteries and other removed components are not swallowed by children.

#### **NOTICE**

There is the possibility that the key may be damaged when the battery is replaced. It is recommended that you have the battery replaced by a GT-R certified NISSAN dealer.


Recommended battery: Lithium battery CR2032 or an equivalent.

- 1. Disengage the lock on the reverse side of the Intelligent Key while pulling out the mechanical key.
- Insert a flat-bladed screwdriver ①
   wrapped with a cloth into the slit ②
   and twist it to separate the case into
   the upper and lower parts.

#### **NOTICE**

Because there is the risk of scratching the key, wrap a cloth or similar item around the screwdriver when separating the parts. If the screwdriver is inserted too far into the key, it may damage the internal circuit board.





#### **NOTICE**

- Be sure that the + and sides of the battery are facing in the correct directions when the battery is inserted.
- Do not touch the internal circuits or electronic terminals. Doing so may damage them.



4. Reconnect the upper and lower parts of the Intelligent Key.

See a GT-R certified NISSAN dealer if you need any assistance for replacement.

#### NOTE:

After replacing the battery, be sure to check and check that all Intelligent Key system functions operate correctly.

**FCC Notice:** 

#### For USA:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference,


and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### For Canada:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

#### LIGHTS



- Headlight (High beam)
- 2. Front parking light
- 3. Front turn signal light
- 4. Daytime running light
- 5. Headlight (Low beam)
- 6. Front side marker light

- 7. High-mounted stop light
- 8. License plate light
- Rear combination light (rear turn signal/ tail/stop/back-up)
- 10. Rear side marker light
- A: Except for NISMO models
- (B): NISMO models

#### **HEADLIGHTS**

Fog may temporarily form inside the lens of the exterior lights in the rain or in a car wash. A temperature difference between the inside and the outside of the lens causes the fog. This does not indicate that there is a malfunction. If large drops of water collect inside the lens, it is recommended you contact a GT-R certified NISSAN dealer.

# Replacing

# LED headlight:

If replacement is necessary, it is recommended you see a GT-R certified NISSAN dealer.

#### **EXTERIOR AND INTERIOR LIGHTS**


Item	Wattage (W)	Bulb No.
Headlight assembly		
low-beam*	LED	_
high-beam*	LED	_
Front turn signal light*	28/8	7444NA
Front parking light*	LED	_
Daytime running light*	LED	_
Front side marker light*	3.8	T10
Rear combination light*		
back-up	16	W16W
turn signal	21	WY21W
stop/tail	LED	_
Rear side marker light*	LED	_
License plate light*	LED	_
Map light	8	_
Vanity mirror light*	2	_
Step light*	2.7	_
Trunk light*	3.4	_
High-mounted stop light*	LED	_


<sup>\*:</sup> It is recommended you see a GT-R certified NISSAN dealer for replacement.

It is recommended you always check with the Parts Department at a GT-R certified NISSAN dealer for the latest parts information.

# Replacement procedures

All other lights are either type A, B, C, D, E or F. When replacing a bulb, first remove the lens and/or cover.





#### WHEELS AND TIRES

If you have a flat tire, see the following section. ( \*\* "Flat tire" page 6-3)

# **A** CAUTION

A GT-R certified NISSAN dealer should perform a tire change. It will be necessary to reset the tire pressure sensors. To change the tires, it is recommended you contact a GT-R certified NISSAN dealer.

Be sure to use the tires and wheels together as a set that are designated for use with this vehicle.

When tire replacement is required, replacing the tires as a set of four with new tires is recommended. However, if a tire is punctured or damaged, it may be possible to replace only the damaged tire. Determining whether one tire or a complete set of tires should be replaced is based on a number of factors including tire wear and condition. It is recommended you contact your GT-R certified NISSAN dealer. They can recommend if an individual tire or a complete set should be replaced.

#### **NOTICE**

Make sure the tire valve stem cap is installed and that the valve stem is tight. When installing the cap, make sure to tighten the cap by hand. If a tool is used to tighten the cap, the cap may be damaged.

#### **TIRE PRESSURE**

# Tire Pressure Monitoring System (TPMS)

This vehicle is equipped with the Tire Pressure Monitoring System (TPMS). It monitors tire pressure of all tires. When the low tire pressure warning light is lit, one or more of your tires is significantly under-inflated. The system also displays pressure of all tires on the touch screen display by sending a signal from a sensor that is installed in each wheel.

The TPMS will activate only when the vehicle is driven at speeds above 16 MPH (25 km/h). Also, this system may not detect a sudden drop in tire pressure. ( \*\*\subseteq\*\* "Low tire pressure warning light" page 2-30) ( \*\subseteq\*\* "Tire Pressure Monitoring System (TPMS)" page 5-4) ( \*\subseteq\*\* "Flat tire" page 6-3)

### Tire inflation pressure

Check the tire pressure often and always prior to long distance trips. The recommended tire pressure specifications are shown on the F. M.V.S.S./C.M.V.S.S. label or the Tire and Loading Information label (if so equipped) under the "Cold Tire Pressure" heading. The Tire and Loading Information label is affixed to the driver side door end. Tire pressures should be checked regularly because:

- Most tires naturally lose air over time.
- Tires can lose air suddenly when driven over potholes or other objects or if the vehicle strikes a curb while parking.

#### NOTE:

- You can check the pressure of all four tires on the touch screen display. See the separate Multi Function Display Owner's Manual.
- The tires of this vehicle are filled with nitrogen gas. When the tire pressure is low, fill the tires with

- nitrogen. It is recommended you contact a GT-R certified NISSAN dealer for information on filling the tires with nitrogen.
- If nitrogen is not available, compressed air may be safely used under normal driving conditions.
   However, NISSAN recommends refilling with nitrogen for maximum tire performance.

The tire pressures should be checked when the tires are cold. The tires are considered COLD after the vehicle has been parked for 3 or more hours, or driven less than 1 mile (1.6 km) at moderate speeds.

Incorrect tire pressure, including under inflation, may adversely affect tire life and vehicle handling.

# **MARNING**

- Improperly inflated tires can fail suddenly and cause an accident.
- The Gross Vehicle Weight rating (GVWR) is located on

the F.M.V.S.S./C.M.V.S.S. certification label. The vehicle weight capacity is indicated on the Tire and Loading Information label (if so equipped). Do not load vour vehicle beyond this capacity. Overloading your vehicle may result in reduced tire life, unsafe operating conditions due to premature tire failure, or unfavorable handling characteristics and could also lead to a serious accident. Loading beyond the specified capacity may also result in failure of other vehicle components.


- Before taking a long trip, or whenever you heavily load your vehicle, use a tire pressure gauge to ensure that the tire pressures are at the specified level.
- For additional information regarding tires, refer to "Important Tire Safety Informa-

tion" (US) or "Tire Safety Information" (Canada) in the Warranty Information Booklet.

#### NOTE:

- Use only genuine GT-R tires and road wheels.
  - The GT-R uses specially designed run-flat tires and matching road wheels. Use of these specially developed tires and wheels provides the greatest potential for maximum performance.
  - Genuine GT-R tires and road wheels help achieve maximum cornering and braking performance.
  - Genuine GT-R tires and road wheels help achieve maximum tire durability during acceleration.
  - Genuine GT-R tires and road wheels help achieve maximum handling capability during performance driving.
  - Genuine GT-R tires and road wheels help provide road holding in the event of decreasing tire pressure and punctures.

- Genuine GT-R tires and road wheels help prevent the decrease of straight-running stability caused by uneven tire wear due to high rigidity wheels and wide tires.
- The GT-R uses specially designed run-flat tires which feature an extremely rigid side wall. Special techniques and equipment are therefore required when replacing these tires.
   NISSAN recommends that tire replacement be performed at a GT-R certified NISSAN dealer.
- Specific tire changing equipment must be used to remove the GT-R tires from the wheel and to install the GT-R tires onto the wheel. It is only possible to reuse the tires when they have no cracks and/or deformations on the bead portion of the tire. If the incorrect equipment is used to remove the GT-R tires from the wheel and to install the GT-R tires onto the wheel, cracks and deformation may occur on the bead portion of the tires meaning that the tires cannot be reused. It is recommended you contact a GT-R certified NISSAN dealer if the tires need to be removed from the wheels.



# TIRE AND LOADING INFORMATION LABEL

- Seating capacity: The maximum number of occupants that can be seated in the vehicle.
- ② Vehicle load limit: See the following section. (☆ "Vehicle loading information" page 10-16)
- 3 Original size: The size of the tires originally installed on the vehicle at the factory.

- Cold tire pressure: Inflate the tires to this pressure when the tires are cold. Tires are considered COLD after the vehicle has been parked for 3 or more hours, or driven less than 1 mile (1.6 km) at moderate speeds. The recommended cold tire inflation is set by the manufacturer to provide the best balance of tire wear, vehicle handling, driveability, tire noise, etc., up to the vehicle's GVWR.
- ⑤ Tire size see the following section. ( ) "Tire labeling" page 8-34)
- Spare tire size or compact spare tire size (if so equipped)



#### **CHECKING THE TIRE PRESSURE**

- 1. Remove the valve stem cap from the tire.
- Press the pressure gauge squarely onto the valve stem. Do not press too hard or force the valve stem sideways, or air will escape. If the hissing sound of air escaping from the tire is heard while checking the pressure, reposition the gauge to eliminate this leakage.
- 3. Remove the gauge.

- Read the tire pressure on the gauge stem and compare it to the specification shown on the Tire and Loading Information label.
- Add air to the tire as needed. If too much air is added, press the core of the valve stem briefly with the tip of the gauge stem to release pressure. Recheck the pressure and add or release air as needed.
- 6. Install the valve stem cap.
- Check the pressure of all other tires.

#### NOTE:

- You can check the pressure of all four tires on the touch screen display. See the separate Multi Function Display Owner's Manual.
- The tires of this vehicle are filled with nitrogen gas. When the tire pressure is low, fill the tires with nitrogen. It is recommended you contact a GT-R certified NISSAN dealer for in-

- formation on filling the tires with nitrogen.
- If nitrogen is not available, compressed air may be safely used under normal driving conditions. However, NISSAN recommends refilling with nitrogen for maximum tire performance.

### Summer tires:

	SIZE	COLD TIRE INFLATION PRESSURE
FRONT ORIGINAL TIRE	255/40ZR- F20 (97Y)	30 PSI (210 kPa) *1 32 PSI (220 kPa) *2
REAR ORI- GINAL TIRE	285/35ZR- F20 (100Y)	29 PSI (200 kPa)

- \*1: Except for NISMO and Track edition engineered by nismo models
- \*2: NISMO and Track edition engineered by nismo models

#### All-season tires:


	SIZE	COLD TIRE INFLATION PRESSURE
FRONT ORIGINAL TIRE	255/40R- F20 97W	32 PSI (220 kPa)
REAR ORI- GINAL TIRE	285/35R- F20 100W	30 PSI (210 kPa)



Example

#### TIRE LABELING


Federal law requires tire manufacturers to place standardized information on the sidewall of all tires This information identifies and describes the fundamental characteristics of the tire and also provides the tire identification number (TIN) for safety standard certification. The TIN can be used to identify the tire in case of a recall.



#### Example

- ① Tire size (example: P215/60R16 94H)
- 1. P: The "P" indicates the tire is designed for passenger vehicles. (Not all tires have this information.)
- 2. Three-digit number (215): This number gives the width in millimeters of the tire from sidewall edge to sidewall edge.
- 3. Two-digit number (65): This number, known as the aspect ratio, gives the tire's ratio of height to width.

- R: The "R" stands for radial.
   F: The "F" after "R" indicates Self-Supporting type run-flat tire.
- Two-digit number (15): This number is the wheel or rim diameter in inches.
- 6. Two- or three-digit number (95): This number is the tire's load index. It is a measurement of how much weight each tire can support. You may not find this information on all tires because it is not required by law.
- H: Tire speed rating. You should not drive the vehicle faster than the tire speed rating.



#### Example

- ② TIN (Tire Identification Number) for a new tire (example: DOT XX XX XXX XXXX)
- DOT: Abbreviation for the "Department of Transportation".
   The symbol can be placed above, below or to the left or right of the Tire Identification Number.
- 2. Two-digit code: Manufacturer's identification mark
- 3. Two-digit code: Tire size
- 4. Three-digit code: Tire type code (Optional)

- Four numbers represent the week and year the tire was built.
   For example, the numbers 3103 means the 31st week of 2003. If these numbers are missing, then look on the other sidewall of the tire.
- ③ Tire ply composition and material The number of layers or plies of rubber-coated fabric in the tire. Tire manufacturers also must indicate the materials in the tire, which include steel, nylon, polyester, and others.
- Maximum permissible inflation pressure

This number is the greatest amount of air pressure that should be put in the tire. Do not exceed the maximum permissible inflation pressure.

S Maximum load rating

This number indicates the maximum load in kilograms and pounds that can be carried by the tire. When replacing the tires on the vehicle, always use a tire that has

the same load rating as the factory installed tire.

- ⑥ Term of "tubeless" or "tube type" Indicates whether the tire requires an inner tube ("tube type") or not ("tubeless").
- 7) The word "radial"

The word "radial" is shown, if the tire has radial structure.

® Manufacturer or brand name Manufacturer or brand name is shown.

# Other tire-related terminology:

In addition to the many terms that are defined throughout this section, Intended Outboard Sidewall is (1) the sidewall that contains a whitewall, bears white lettering or bears manufacturer, brand and/or model name molding that is higher or deeper than the same molding on the other sidewall of the tire, or (2) the outward facing sidewall of an asymmetrical tire that has a particular side that must always face outward when mounted on a

vehicle.

#### **TYPES OF TIRES**

# **A** WARNING

- When changing or replacing tires, be sure all four tires are of the same type (Examples: Summer or All Season) and construction. A GT-R certified NISSAN dealer may be able to help you with information about tire type, size, speed rating and availability.
- Replacing tires with those not originally specified by NISSAN could affect the proper operation of the TPMS.
- For additional information regarding tires, refer to "Important Tire Safety Information" (US) or "Tire Safety Information" (Canada) in the Warranty Information Booklet.

#### All-season tires

NISSAN specifies all-season tires on some models to provide good performance for use all year around, including snowy and icy road conditions. All-season tires are identified by ALL SEASON on the tire sidewall.

#### **Summer tires**

The GT-R summer tires are made from a specially formulated rubber to maximize the vehicle's performance capabilities. Performance of summer tires is substantially reduced when temperatures are less than 32°F (0°C) so you must drive carefully. NISSAN recommends the use of winter or all-season tires on all four wheels if you plan to operate your vehicle in snowy or icy conditions when temperatures are less than 32°F (0°C).

# **A** WARNING

Never use summer tires when the temperature is below -4°F (-20°C) to prevent permanent tread deformation which may cause tire damage or tire failure. This may cause a loss of vehicle control which can result in serious personal injury or death.

#### **Run-flat tires**

Your vehicle is equipped with run-flat tires. You can continue driving to a safe location even if they are punctured. Always use run-flat tires of the specified size on all four wheels. Mixing tire sizes or construction may reduce vehicle handling stability. If necessary, contact a GT-R certified NISSAN dealer for assistance.

Frequently check the tire pressure information on the touch screen display and adjust pressure of each tire properly. See the separate Multi Function Display Owner's Manual.

It can be difficult to tell if a run-flat tire is under-inflated or flat. Check the tire pressures as described earlier in this section. If the tire becomes under-inflated while driving, the low tire pressure warning light will come on. If the tire becomes flat while driving, the low tire pressure warning light and the run-flat tire warning display will come on.

#### Low tire pressure:

If the vehicle is being driven with low tire pressure, the low tire pressure warning light will illuminate and the low tire pressure warning will appear in the vehicle information display.

#### Flat tire:

If the vehicle is being driven with one or more flat tires, the low tire pressure warning light will illuminate continuously and a chime will sound for 10 seconds. The run-flat tire warning also appears in the vehicle information display.

The chime will only sound at the first indication of a flat tire and the run-flat tire warning display will illuminate continuously. When the flat tire warning is activated, it is recommended you have the system reset and the tire checked and replaced if necessary by a GT-R certified NISSAN dealer. Even if the tire inflated to the specified COLD tire pressure, the warning light will continue to illuminate until the system is reset.

If the low tire pressure and the run-flat tire warning appears on the vehicle information display:

- Do not exceed 50 MPH (80 km/h).
- Increase your following distance to allow for increased stopping distances.
- Avoid sudden maneuvers, hard cornering and hard braking.

# **WARNING**

Although you can continue driving with a punctured run-flat tire, remember that vehicle handling stability is reduced, which could lead to an accident and personal injury. Also, driving a long distance at high speeds may da-

mage the tire.

- Do not drive at speeds above 50 MPH (80 km/h) and do not drive more than 50 miles (80 km) with a punctured run-flat tire. The actual distance the vehicle can be driven on a flat tire depends on outside temperature, vehicle load, road conditions and other factors.
- Drive safely at reduced speeds.
   Avoid hard cornering or braking,
   which may cause you to lose control of the vehicle.

#### **NOTICE**

- Never install tire chains on a punctured run-flat tire, as this could damage your vehicle.
- Avoid driving over any projection or pothole, as the clearance between the vehicle and the ground is smaller than normal.
- Do not enter an automated car wash with a punctured run-flat tire.
- It is recommended you have the punctured tire replaced by a GT-R certified NISSAN dealer as soon

as possible, as the tire's performance capability is reduced.

#### Tires for All-Wheel Drive (AWD)

If excessive tire wear is found, it is recommended that all four tires be replaced with tires of the specified size, brand, construction and tread pattern. The tire pressure and wheel alignment should also be checked and corrected as necessary. It is recommended you contact a GT-R certified NISSAN dealer.

#### **TIRE CHAINS**

Use of tire chains may be prohibited according to location. Check the local laws before installing tire chains. When installing tire chains, make sure they are of proper size for the tires on your vehicle and are installed according to the chain manufacturer instructions. Use only SAE class S chains. Class "S" chains are used on vehicles with restricted tire to vehicle clearance. Vehicles that can use Class "S" chains are designed to meet the SAE standard minimum clearances between the tire and the closest vehicle suspension or body component required to accommodate the use of a winter traction device (tire chains or cables). The minimum clearances are determined using the factory equipped tire size. Other types may damage your vehicle. Use chain tensioners when recommended by the tire chain manufacturer to ensure a tight fit. Loose end links of the tire chain must be secured or removed to prevent the possibility of whipping action damage to the fenders or undercarriage. If possible, avoid fully loading your vehicle when using tire chains. In addition, drive at a reduced speed. Otherwise, your vehicle may be damaged and/or vehicle handling and performance may be adversely affected.

#### NOTE:

Tire chains must be installed only on the rear wheels and not on the front wheels.

# **A** CAUTION

Do not use tire chains on dry roads.

#### **NOTICE**

Never install tire chains on a punctured run-flat tire, as this could damage your vehicle. Do not drive with tire chains on paved roads that are clear of snow. Driving with chains in such conditions can cause damage to the various mechanisms of the vehicle due to some overstress.

#### **CHANGING WHEELS AND TIRES**

#### Tire rotation

Tires cannot be rotated because your vehicle is equipped with different sized tires in the front and rear.



- 1. Wear indicator
- Wear indicator location marks. The locations are shown by " ∆ ", "TWI", etc. depending on tire types.

# Tire wear and damage

# **WARNING**

 Tires should be periodically inspected for wear, cracking, bulging or objects caught in the tread. If excessive wear, cracks, bulging or deep cuts are found, the tire(s) should be replaced.

- The original tires have builtin tread wear indicators.
   When the wear indicators are visible, the tire(s) should be replaced.
- Tires degrade with age and use. Have tires, over 6 years old checked by a qualified technician because some tire damage may not be obvious. Replace the tires as necessary to prevent tire failure and possible personal injury.
- For additional information regarding tires, refer to "Important Tire Safety Information" (US) or "Tire Safety Information" (Canada) in the Warranty Information Booklet.

# Replacing wheels and tires

When tire replacement is required, replacing tires as a set of four with new tires is

recommended. However, if a tire is punctured or damaged, it may be possible to replace only the damaged tire. Determining whether one tire or a complete set of tires should be replaced is based on a number of factors including tire wear and condition. It is recommended you contact your GT-R certified NISSAN dealer. They can recommend if an individual tire or a complete set should be replaced.

When replacing a tire, use the specified size, speed rating and load carrying capacity as originally equipped. ( \*\*The Two times of the specified size of

#### NOTICE

- When you replace the GT-R tires, it is recommended that you replace all the tires at the same time.
- The GT-R uses specially designed run-flat tires which feature an extremely rigid side wall. Special techniques and equipment are therefore required when replacing these tires. NISSAN recommends that tire replacement be performed at a GT-R certified NISSAN dealer.
- When tires are reinstalled after

being uninstalled from the wheels, use equipment such as a leverless automatic tire changer. It is only possible to reuse the tires when they have no cracks and/or deformations on the bead portion. However, if you use a lever-type tire changer, cracks and deformation may occur on the bead portion of the tires meaning that the tires cannot be reused.

 Make sure the tire valve stem cap is installed and that the valve stem is tight. When installing the cap, make sure to tighten the cap by hand. If a tool is used to tighten the cap, the cap may be damaged.

# **A** WARNING

 The use of tires other than those specified or the mixed use of tires of different brands, construction (bias, bias-belted, radial or runflat), or tread patterns can adversely affect the ride, braking, VDC system, handling, ground clearance, body-to-tire clearance,

- tire chain clearance, speedometer calibration, headlight aim and bumper height. Some of these effects may lead to accidents and could result in serious personal injury.
- If the wheels are changed for any reason, always replace with wheels which have the same offset dimension. Wheels of a different off-set could cause premature tire wear, degrade vehicle handling characteristics, affect the VDC system and/or cause interference with the brake discs. Such interference can lead to decreased braking efficiency and/or early brake pad wear.
   ( ) "Wheels and tires" page 10-10)
- When a wheel is replaced, tire pressure will not be indicated, the TPMS will not function and the low tire pressure warning light will flash for approximately 1 minute and remain on after the 1 minute. It is recommended you contact a GT-R certified NISSAN dealer as soon as possible for tire replacement and/or system resetting.

- Replacing tires with those not originally specified by NISSAN could affect the proper operation of the TPMS.
- The TPMS sensor may be damaged if it is not handled correctly. Be careful when handling the TPMS sensor.
- When replacing the TPMS sensor, the ID registration may be required. Contact a GT-R certified NISSAN dealer for ID registration.
- Do not use a valve stem cap that is not specified by NISSAN. The valve stem cap may become stuck.
- Be sure that the valve stem caps are correctly fitted. Otherwise the valve may be clogged up with dirt and cause a malfunction or loss of pressure.
- Do not install a damaged or deformed wheel or tire even if it has been repaired. Such wheels or tires could have structural damage and could fail without warning.
- Never use retread tires.
- For additional information re-

garding tires, refer to "Important Tire Safety Information" (US) or "Tire Safety Information" (Canada) in the Warranty Information Booklet.

 Always use tires of the specified type, size, brand, construction (bias, bias-belted, radial or runflat), and tread pattern on all four wheels. Failure to do so may result in a circumference difference between tires on the front and rear axles which will cause excessive tire wear and may damage the transmission, transfer case and differential gears.

#### Wheel balance

Unbalanced wheels may affect vehicle handling and tire life. Even with regular use, wheels can get out of balance. Therefore, they should be balanced as required.

Wheel balance service should be performed with the wheels off the vehicle. Spin balancing the rear wheels on the vehicle could lead to mechanical damage. For additional information regarding tires, refer to "Important Tire Safety Information" (US) or "Tire Safety Information" (Canada) in the Warranty Information Booklet.


#### Care of wheels

( Transport ( Cleaning exterior page 7-2)

# JACKING VEHICLE AND REMOVING WHEELS

# **WARNING**

- Make sure the parking brake is securely applied and the transmission is shifted into the position.
- Never change tires when the vehicle is on a slope, ice or slippery areas. This is hazardous.
- Never change tires if oncoming traffic is close to your vehicle.
   Wait for professional road assistance.




# **Blocking wheels**

Place suitable blocks ① at both the front and back of the wheel diagonally opposite the flat tire to prevent the vehicle from moving when it is jacked up.

# **MARNING**

Be sure to block the wheel as the vehicle may move and result in personal injury.



# Getting the tools

#### NOTE:

A jack, jack lever and rod are not equipped as standard with this vehicle. These parts are dealer options. It is recommended you contact a GT-R certified NISSAN dealer about acquiring a jack, jack lever and rod. You can store a jack, jack lever and rod in the floor in front of the passenger's seat.

# **CAUTION**

After using the tools, put them back in their original places. An accident may occur if you leave them in the car unsecured.

Jacking up the vehicle and removing the tire


# **WARNING**

- Never get under the vehicle while it is supported only by the jack. If it is necessary to work under the vehicle, support it with safety stands.
- Use the correct jack-up points. Never use any other part of the vehicle for jack support.
- Never jack up the vehicle more than necessary.
- Never use blocks on or under the jack.
- Do not start or run the engine while vehicle is on the jack, as it may cause the vehicle to move. This is especially true for vehicles

with limited slip differentials.


Do not allow passengers to stay in the vehicle while it is on the iack.

Carefully read the caution label attached to the jack body and the following instructions.




Jack-up point

1. Place the jack directly under the jackup point as illustrated so the top of the jack contacts the vehicle at the jack-up point. The jack should be used on level firm ground.




- 2. Fit the jack head into the recess (A) of the jack-up point by turning the jackscrew clockwise with your fingers.
- 3. Loosen each wheel nut one or two turns by turning counterclockwise with the wheel nut wrench. Do not remove the wheel nuts until the tire is off the ground.



4. Carefully raise the vehicle until the tire clears the ground. To lift the vehicle, securely hold the jack lever and rod with both hands as shown above.







5. Remove the wheel nuts and then remove the wheel.

#### NOTE:

When putting a wheel on the ground, put it down with the outer side of the wheel facing up to prevent scratching of the wheel surface. 6. Clean any mud or dirt from the surface between the brake disc rotor ① and wheel 2).





- - When replacing a front wheel, make sure the hole in the wheel is aligned with the pin on the brake disc rotor.
- 8. With the wheel nut wrench, tighten wheel nuts alternately and evenly in the sequence illustrated (①, ②, ③, ④, ⑤) until they are tight.
- Lower the vehicle slowly until the tire touches the ground. Then, with the wheel nut wrench, tighten the wheel nuts securely in the sequence as illustrated. Lower the vehicle completely.

# **WARNING**

- Incorrect wheel nuts or improperly tightened wheel nuts can cause the wheel to become loose or come off. This could cause an accident.
- Do not use oil or grease on the wheel studs or nuts. This could cause the nuts to become loose.
- Retighten the wheel nuts when the vehicle has been driven for 600 miles (1,000 km).

# **MARNING**

If the road wheels are hot, allow them to cool sufficiently before tightening the wheel nuts. Otherwise, the wheel nuts cannot be tightened to specification.

#### NOTE:

- As soon as possible, tighten the wheel nuts to the specified torque with a torque wrench.
  - Wheel nut tightening torque:

Except for NISMO and Track edition engineered by nismo models 97 ft-lb (132 N·m)

NISMO and Track edition engineered by nismo models 114 ft-lb (155 N·m)


The wheel nuts must be kept tightened to specification at all times. It is recommended that wheel nuts be tightened to specifications at each lubrication interval.

Adjust tire pressure to the COLD pressure.

COLD pressure: After the vehicle has been parked for three hours or more or driven less than 1 mile (1.6 km).

COLD tire pressures are shown on the Tire and Loading Information label affixed to the driver's door opening.

10. Securely store the jacking equipment in the vehicle.





# WHEEL LOCK NUTS (if so equipped)

In order to prevent theft, the specially designed wheel lock nut (1) is installed on each wheel. The wheel lock nut cannot be removed with commonly used tools.

When removing tires, use the lock key (2) provided with your vehicle.

# Removing the wheel lock nut

To remove the wheel lock nut, use the lock key stored under the passenger's side floor.

- 1. Insert the lock key to the wheel lock nut.
- 2. To remove the wheel lock nut, turn the lock key counterclockwise using the wheel nut wrench.

# **CAUTION**

- Do not use a power tool to remove the wheel lock nuts.
- Tighten the wheel lock nuts to the same tightening torque as the normal wheel nuts. ( >> "Jacking" up the vehicle and removing the tire" page 8-42)

#### NOTE:

- The wheel lock nut has an individual code. A lock key which does not match the individual code cannot remove the wheel lock nut. If you lose the wheel lock key, it is recommended you contact a GT-R certified NISSAN dealer immediately.
- Keep the key code card ③ in a safe place. To purchase a lock key, contact a GT-R certified NISSAN dealer with your original code ④ on the key code card.
- When you ask for a service at a GT-R certified NISSAN dealer, make sure to keep the lock key in the vehicle. Otherwise, tires cannot be removed and any service requiring the removal of the wheels cannot be performed.

# **MEMO**

# 9 Maintenance and schedules

Maintenance requirement	9-2
Scheduled maintenance	9-2
General maintenance	9-2
Where to go for service	9-2
Determining the proper maintenance interval	9-3
General maintenance	9-3
Explanation of maintenance items	9-3
Explanation of scheduled maintenance items	9-6
Emission control system maintenance	9-6

Chassis and body maintenance	9-7
Additional maintenance items	9-8
Setting guide of wheel alignment depending	0 21
on the customer's driving	
Tire replacement record	9-23
Transmission assembly/parts	
replacement record	9-26
Maintenance log and records	9-28

#### MAINTENANCE REQUIREMENT

Some day-to-day and regular maintenance is essential to maintain your vehicle good mechanical condition, as well as its emission and engine performance.

It is the owner's responsibility to make sure that the scheduled maintenance, as well as general maintenance, is performed.

As the vehicle owner, you are the only one who can ensure that your vehicle receives the proper maintenance care. You are a vital link in the maintenance chain.

#### SCHEDULED MAINTENANCE

For your convenience, both required and optional scheduled maintenance items are described and listed in this section. You must refer to that guide to ensure that necessary maintenance is performed on your vehicle at regular intervals.

#### **GENERAL MAINTENANCE**

General maintenance includes those items which should be checked during normal day-to-day operation. They are essential for proper vehicle operation. It is your responsibility to perform these procedures regularly as prescribed.

Performing general maintenance checks requires minimal mechanical skill and only a few general automotive tools.

These checks or inspections can be done by yourself, a qualified technician or, if you prefer, a GT-R certified NISSAN dealer.

#### WHERE TO GO FOR SERVICE

GT-R certified NISSAN dealers are reguired to have additional training and equipment and are the only NISSAN dealers authorized to perform warranty work on key vehicle performance systems such as engine, transmission, suspension and brakes

If maintenance service is required or your vehicle appears to malfunction, it is recommended that you have the systems checked and serviced by a GT-R certified NISSAN dealer.

NISSAN technicians are well-trained specialists and are kept up to date with the latest service information through technical bulletins, service tips, and in-dealer information systems. They are completely qualified to work on NISSAN vehicles before work begins.

If your vehicle is involved in a collision, it is recommended that you ask your NISSAN dealer where the nearest NISSAN Certified Collision Center is located, or go to http:// collision nissanusa.com

You can be confident that a GT-R certified NISSAN dealer's service department performs the best job to meet the maintenance requirements on your vehicle.

To find a GT-R certified NISSAN dealer near you, call 1-866-668-1GTR in the US or 1-800-387-0122 in Canada, or go to www. atrnissan.com/.

#### **DETERMINING THE PROPER** MAINTENANCE INTERVAL

Depending on your driving habits and local conditions, you should follow one of the two maintenance schedules listed below for scheduled maintenance. In addition to Schedule 1 maintenance, additional maintenance must be performed for optimum performance. Use these guidelines to determine which maintenance schedule to use:

#### Schedule 1 (Every 6,000 miles (10,000 km) or 6 months, whichever comes first)

Schedule 1 features 6,000-mile (10,000 km) service intervals. Use Schedule 1 if you primarily operate your vehicle under any of these conditions:

- Repeated short trips of less than 5 miles (8 km) in normal temperatures or less than 10 miles (16 km) in freezing temperatures
- Stop-and-go traffic in hot weather or lowspeed driving for long distances
- · Driving in dusty conditions or on rough, muddy, or salt-spread roads

#### Schedule 2 (Every 6,000 miles (10,000 km) or 6 months, whichever comes first)

Schedule 2 features 6.000-mile (10.000 km) service intervals: with Schedule 2 fewer maintenance items are regularly checked or replaced than with Schedule 1.

Generally, Schedule 2 applies only to

highway driving in temperate conditions. Use Schedule 2 only if you primarily operate your vehicle under conditions other than those listed in Schedule 1.

#### **GENERAL MAINTENANCE**

During the normal day-to-day operation of the vehicle, general maintenance should be performed regularly as prescribed in this section. If you detect any unusual sounds, vibrations or smell, be sure to check for the cause and have it checked promptly. In addition, it is recommended you notify a GT-R certified NISSAN dealer if you think that repairs are required. ( A "Maintenance precautions" page 8-3)

# **EXPLANATION OF MAINTENANCE ITEMS**

Additional information on the following items with "\*" is found later in the "8. Doit-vourself" section of this manual.

#### Outside the vehicle

The maintenance items listed here should be performed from time to time, unless otherwise specified.

Doors and engine hood: Check that all doors and the engine hood, operate properly. Also ensure that all latches lock securely. Lubricate hinges, latches, latch pins, rollers and links if necessary. Make sure that the secondary latch keeps the hood from opening when the primary latch is released.

When driving in areas using road salt or

other corrosive materials, check lubrication frequently.

**Lights\*:** Clean the headlights on a regular basis. Make sure that the headlights, stop lights, tail lights, turn signal lights, and other lights are all operating properly and installed securely. Also check headlight aim.

Road wheel nuts (lug nuts)\*: When checking the tires, make sure no wheel nuts are missing, and check for any loose wheel nuts. Tighten if necessary.

**Tire rotation\*:** Tires cannot be rotated because your vehicle is equipped with different sized tires in the front and rear.

Tires\*: Check the pressure with a gauge often and always prior to long distance trips. If necessary, adjust the pressure in all tires to the pressure specified. Check carefully for damage, cuts or excessive wear

#### NOTE:

- You can check the pressure of all four tires on the touch screen display. See the separate Multi Function Display Owner's Manual.
- The tires of this vehicle are filled with nitrogen gas. When the tire pressure is low, fill the tires with nitrogen. It is recommended you

- contact a GT-R certified NISSAN dealer for information on filling the tires with nitrogen.
- If nitrogen is not available, compressed air may be safely used under normal driving conditions.
   However, NISSAN recommends refilling with nitrogen for maximum tire performance.

**Tire Pressure Monitoring System (TPMS) transmitter components:** Replace grommet seal of transmitter in TPMS, when replacing each tire by reaching the wear limit.

Tire, wheel alignment and balance: If the vehicle should pull to either side while driving on a straight and level road, or if you detect uneven or abnormal tire wear, there may be a need for wheel alignment.

If the steering wheel or seat vibrates at normal highway speeds, wheel balancing may be needed.

For additional information regarding tires, refer to "Important Tire Safety Information" (US) or "Tire Safety Information" (Canada) in the Warranty Information Booklet.

**Windshield:** Clean the windshield on a regular basis. Check the windshield at least every six months for cracks or other

damage. Have a damaged windshield repaired by a qualified repair facility.

It is recommended that you have a damaged windshield repaired by a GT-R certified NISSAN dealer, or a NISSAN Certified Collision Center. To locate a collision center in your area, refer to http://collision.nissanusa.com.

**Windshield wiper blades\*:** Check for cracks or wear if they do not wipe properly.

#### Inside the vehicle

The maintenance items listed here should be checked on a regular basis, such as when performing scheduled maintenance, cleaning the vehicle, etc.

**Accelerator pedal:** Check the pedal for smooth operation and make sure the pedal does not catch or require uneven effort. Keep the floor mat away from the pedal.

**Transmission** mechanism: On a fairly steep hill, check that your vehicle is held securely with the shift lever in the position without applying any brakes.

**Brake pedal:** Check the pedal for smooth operation. If the brake pedal suddenly goes down further than normal, the pedal feels spongy or the vehicle seems to take longer to stop, it is recommended you see

a GT-R certified NISSAN dealer immediately. Keep the floor mat away from the pedal.

Brakes: Check that the brakes do not pull the vehicle to one side when applied.

Parking brake: Check the parking brake operation regularly. The vehicle should be securely held on a fairly steep hill with only the parking brake applied. If the parking brake needs to be adjusted, it is recommended you see a GT-R certified NISSAN dealer.

Seat belts: Check that all parts of the seat belt system (for example, buckles, anchors, adjuster and retractors) operate properly and smoothly, and are installed securely. Check the belt webbing for cuts, fraving, wear or damage.

Seats: Check seat position controls such as seat adjusters, seatback recliner, etc. to ensure they operate smoothly and that all latches lock securely in every position.

Steering wheel: Check for changes in the steering conditions, such as excessive free play, hard steering or strange noises.

Warning lights and chimes: Make sure that all warning lights and chimes are operating properly.

Windshield defroster: Check that the air comes out of the defroster outlets properly and in sufficient quantity when operating the heater or air conditioner.

Windshield wiper and washer\*: Check that the wipers and washer operate properly and that the wipers do not streak.

#### Under the hood and vehicle

The maintenance items listed here should be checked periodically (for example, each time you check the engine oil or refuel).

Battery\*: Check the fluid level in each cell. It should be between the MAX and MIN lines. Vehicles operated in high temperatures or under severe condition require frequent checks of the battery fluid level.

#### NOTE:

Care should be taken to avoid situations that can lead to potential battery discharge and potential no-start conditions such as:

- 1 Installation or extended use of electronic accessories that consume battery power when the engine is not running (Phone chargers, GPS, DVD players, etc.)
- 2. Vehicle is not driven regularly and/ or only driven short distances.

In these cases, the battery may need to

be charged to maintain battery health.

Brake fluid level\*: Make sure that the brake fluid level is between the MAX and MIN lines on the reservoir.

Engine coolant level\*: Check the coolant level when the engine is cold.

Engine drive belts\*: Make sure that no belt is frayed, worn, cracked or oily.

Engine oil level\*: Check the level after parking the vehicle on a level spot and turning off the engine. Wait at least 5 minutes for the oil to drain back into the oil pan before checking the oil.

Exhaust system: Make sure there are no loose supports, cracks or holes. If the sound of the exhaust seems unusual or there is a smell of exhaust fumes in the engine compartment, it is recommended you immediately have the exhaust system inspected. It is recommended you contact a GT-R certified NISSAN dealer. ( 下至 "Exhaust gas (carbon monoxide)" page 5-3)

Fluid leaks: Check under the vehicle for fuel, oil, water or other fluid leaks after the vehicle has been parked for a while. Water dripping from the air conditioner after use is normal. If you should notice any leaks or if gasoline fumes are evident, check for the cause and have it corrected immediatelv.

Power steering fluid level\* and lines: Check the level when the fluid is cold, with the engine off. Check the lines for proper attachment, leaks, cracks, etc.

Radiator and hoses: Check the front of the radiator and clean off any dirt, insects. leaves, etc., that may have accumulated. Make sure the hoses have no cracks. deformation, rot or loose connections.

**Underbody:** The underbody is frequently exposed to corrosive substances such as those used on icv roads or to control dust. It is very important to remove these substances, otherwise rust will form on the floor pan, frame, fuel lines and around the exhaust system. At the end of winter. the underbody should be thoroughly flushed with plain water, being careful to clean those areas where mud and dirt may accumulate. ( >> "Underbody" page 7-3)

Windshield washer fluid\*: Check that there is adequate fluid in the reservoir.

### **EXPLANATION OF SCHEDULED** MAINTENANCE ITEMS

The following descriptions are provided to give you a better understanding of the scheduled maintenance items that should be regularly checked or replaced. The maintenance log indicates at which mileage/time intervals each item requires service

In addition to scheduled maintenance. your vehicle requires that some items be checked during normal day-to-day operation. Refer to programme "General maintenance" page 9-3.

Maintenance items and intervals marked with "\*" are recommended by NISSAN for reliable vehicle operation. You are not required to perform such maintenance in order to maintain the emission warranty or manufacturer recall liability.

When applicable, additional information can be found in the "8. Do-it-yourself" section of this manual.

#### NOTE:

NISSAN does not advocate the use of non-OEM approved aftermarket flushing systems and strongly advises against performing these services on a NISSAN product. Many of the aftermarket flushing systems use non-OEM approved chemicals or solvents, the use of which has not been validated by

#### NISSAN.

For recommended fuel, lubricants, fluids, grease, and refrigerant, refer to াক্ত "Capacities and recommended fluids/lubricants" page 10-2 of this manual.

# **EMISSION CONTROL SYSTEM MAINTENANCE**

#### Drive belts\*:

Check engine drive belts for wear, fraying or cracking. Replace any damaged drive helts

# Engine air filter:

Replace at specified intervals. When driving for prolonged periods in dusty conditions, check/replace the filter more frequently.

## **Engine coolant\*:**

Replace coolant at the specified interval. When adding or replacing coolant, be sure to use only Genuine NISSAN Long Life Antifreeze/Coolant (blue) or equivalent with the proper mixture. (Refer to 下 "Engine cooling system" page 8-6 to determine the proper mixture for your area.)

#### NOTE:

Mixing any other type of coolant or the use of non-distilled water may reduce the recommended service interval of the coolant.

### Engine oil and oil filter:

Replace engine oil and oil filter at the specified intervals. Check engine oil level every 1,800 miles (3,000 km) and add as needed. For recommended oil grade and viscosity refer to process and recommended fluids/lubricants" page 10-2.

## Engine valve clearance\*:

Inspect only if valve noise increases. Adjust valve clearance if necessary.

#### Evaporative emissions control vapor lines\*:

Check vapor lines for leaks or looseness. Tighten connections or replace parts as necessary.

#### **Fuel filter**

Maintenance-free item.

#### Fuel lines\*:

Check the fuel hoses, piping and connections for leaks, looseness, or deterioration. Tighten connections or replace parts as necessary.

## Throttle chamber deposits\*:

Visually inspect the throttle chamber for deposits and clean as necessary.

#### Spark plugs:

Replace at specified intervals. Install new plugs of the same type as originally equipped.

# **CHASSIS AND BODY MAINTENANCE**

#### Brake lines and cables:

Visually inspect for proper installation. Check for chafing, cracks, deterioration, and signs of leaking. Replace any deteriorated or damaged parts immediately.

#### Brake pads and rotors:

Check for wear, deterioration and fluid leaks. Replace any deteriorated or damaged parts immediately. Replace all four sets of brake pads and disc rotors at the same time to maintain maximum brake performance.

#### Exhaust system:

Visually inspect the exhaust pipes, muffler and hangers for leaks, cracks, deterioration, and damage. Tighten connections or replace parts as necessary.

#### In-cabin microfilter:

Replace at specified intervals. When driving for prolonged periods in dusty conditions, replace the filter more frequently.

### Measurement and adjustment of wheel alignment:

Manage the wheel alignment by measuring and adjusting at specified intervals.

## Propeller shaft(s):

Check for damage, looseness, and grease leakage.

### Steering gear and linkage, axle and suspension parts, drive shaft boots:

Check for damage, looseness, and leakage of oil or grease. Under severe driving conditions, inspect more frequently.

#### Tire rotation:

Tires cannot be rotated as front tires are different size from rear tires.

# Transmission oil, differential oil:

Replace fluid at specified intervals. Visually inspect for signs of leakage at specified intervals.

### Transmission settings:

To keep the best condition for transmission, this inspection allows learning of the clutch touch point and the engaged gear position and neutral position for each gear.

# **ADDITIONAL MAINTENANCE ITEMS**

Additional maintenance items for performance driving - 2021 GT-R maintenance record list (Inspection before and after driving)

Inspection Key:		
N/A: Normal N Replace: X Tighten T Clean C Adjust: A Repair: Disassemble: D Lubricate: L Skip Step S	Wheel and Tire  B A Apply aluminum tape over the wheel balance weight	Brake System  B A  Inspect brake piping and hoses for leakages
Fluids and Lubricants   B A (B. Before A. After)   Inspect underbody for leakage and smears of oil, fluid and coolant   Adjust/inspect engine oil level (record temperature, document leakage and smears)   Adjust engine coolant level and mixture ratio in the pressurized radiator reservoir tank   Inspect power steering fluid level and check for leakage   Inspect brake fluid level   Inspect transmission and differential gear oil, record oil temperature and document leakage and smears   Engine   B A   Inspect area around the catalytic converter for heat deterioration   Inspect exhaust finishers and (only for vehicles with GT-R genuine exhaust) rear bumper clearance   Inspect and adjust clearance between the exhaust and it's surrounding parts	Inspect the wheel nut and the wheel nut lock nut for looseness Tighten the wheel nut with the standard torque Inspect the wheel bearing (hub) for backlash and the wheel for rotation Align the reference marks on the tire and the inner wheel Inspect the tire and the wheel for direction of rotation devaluon (rim deviation) Inspect and adjust the tire pressure Inspect the air valve and nut of the tire for looseness Inspect the tire for nitrogen leakage Inspect the tor for uneven and abnormal wear	Inspect brake pads for wear, color/temperature indication, damage and cracks Inspect brake disc rotors for wear, damage and cracks Inspect brake master cylinder and the calipers for fluid leak: Bleed any air from brake fluid Inspect the parts and area surrounding the brake rotors for hid deterioration Remove the grease on the front brake pads Apply the grease to the front brake pads Steering B A Inspect rods and arms of the steering system for looseness backlash and damage Inspect steering gear box for looseness at mounting points Suspension B A Inspect shock absorbers for damage and oil leakage
Transmission  B A Adjust clutch clearance (clutch gear learning) Inspect whether tight corner braking phenomenon does not become extremely strong	Driveshaft  B A Inspect driveshaft universal joint dust boots for cracks and damage	Inspect suspension for looseness at mounting points connection, backlash and damage  Measure and adjust wheel adjustment  Other Maintenance Items and Replaced Parts
Mileage	Memo:	

inspection key:			
	ghten: T Clean C pricate: L Skip Step: S	Wheel and Tire  B A Apply aluminum tape over the wheel balance weight	Brake System  B A  Inspect brake piping and hoses for leakages
Fluids and Lubricants   8 A (8: Before A: After)	cord temperature, document nixture ratio in the pressurized and check for leakage	Inspect the wheel nuts for deformation	Inspect brake pads for wear, color/temperature indication, damage and cracks Inspect brake disc rotors for wear, damage and cracks Inspect brake master cylinder and the calipers for fluid leak Bleed any air from brake fluid Inspect the parts and area surrounding the brake rotors for heterioration Remove the grease on the front brake pads Apply the grease to the front brake pads
Inspect transmission and differen temperature and document leaks Engine  B A Inspect area around the catalytic Inspect exhaust finishers and (on	age and smears c converter for heat deterioration	Inspect the tire for uneven and abnormal wear	Steering  B A  Inspect rods and arms of the steering system for looseness backlash and damage  Inspect steering gear box for looseness at mounting point.
exhaust) rear bumper clearance Inspect and adjust clearance bets surrounding parts  Transmission	ween the exhaust and it's	<b>—</b> '	Suspension  B A  Inspect shock absorbers for damage and oil leakage Inspect suspension for looseness at mounting points
B A Adjust clutch clearance (clutch ge Inspect whether tight corner brail become extremely strong		B A Inspect driveshaft universal joint dust boots for cracks and damage	connection, backlash and damage Measure and adjust wheel adjustment Other Maintenance Items and Replaced Parts
	fleage:  T-R Dealer Name:	Memo:	
	ste: schnician Name:		

ection Key:					
A.   Normal N Replace   Ist: A Repair: Disassemble: It   Is and Lubricants   (B: Before A: After)		E		Brake B A	Inspect brake piping and hoses for leakages Inspect brake pads for wear, color/temperature indication, damage and cracks
Adjust/inspect engine oil led leakage and smears) Adjust engine coolant level a radiator reservoir tank Inspect power steering fluid	vel (record temperature, document and mixture ratio in the pressurized	F	Inspect the wheel nut and the wheel hub lock nut for looseness Tighten the wheel nut with the standard torque Inspect the wheel bearing (hub) for backlash and the wheel for rotation Align the reference marks on the tire and the inner wheel Inspect the tire and the wheel for direction of rotation		Inspect brake disc rotors for wear, damage and cracks Inspect brake master cylinder and the calipers for fluid leaki Bleed any air from brake fluid Inspect the parts and area surrounding the brake rotors for hi deterioration Remove the grease on the front brake pads Apply the grease to the front brake pads
Inspect transmission and di temperature and document ne inspect area around the cal inspect exhaust finishers ar	t leakage and smears  Lalytic converter for heat deterioration of the converter for he		oeviation (rim deviation) Inspect and adjust the tire pressure Inspect the air valve and nut of the tire for looseness Inspect the tire for nitrogen leakage Inspect the groove of the tire Inspect the tire for uneven and abnormal wear Inspect the tire for uneven and abnormal wear	Steel B A	ring
Inspect and adjust clearance surrounding parts smission	e between the exhaust and it's		A Inspect driveshaft universal joint dust boots for cracks and	Suspe B A	ension  Inspect shock absorbers for damage and oil leakage Inspect suspension for looseness at mounting points connection, backlash and damage  Measure and adjust wheel adjustment
become extremely strong	Mileage:	Memo:	aanage		Other Maintenance Items and Replaced Parts
Address:	Date: Technician Name:				
	A Normal N Replace st A Repair Disassemble  A (8: Before A: After) Inspect underbody for leaks A (8: Before A: After) Inspect underbody for leaks A (8: Before A: After) Inspect pospect engine oil level leakeage and smears) Adjust engine coolant level radiator reservoir tank Inspect power steering fluid Inspect transmission and di temperature and document inspect transmission and di temperature and document inspect area around the cal inspect shaust finishers are exhaust) rear bumper clear inspect and adjust clearance surrounding parts ssmission  Adjust clutch clearance (clu Inspect whether tight com-	A (Be en an analyse of the second of the sec	Normat   Name   Name	Wheel and Tire   Normat   No	Wheel and Tire    A paper   Name   Na

Inspection Key:		
N/A:         Normal:         N         Replace:         X         Tighten:         T         Clean:         C           Adjust:         A         Repair:         Disassemble:         D         Lubricate:         L         Skip Step:         S	<u>Wheel and Tîre</u> B A	Brake System B A
Fluids and Lubricants B A (B: Before A: After) Inspect underbody for leakage and smears of oil, fluid a Adjust/inspect engine oil level (record temperature, dorleakage and smears) Adjust claim and adjust/inspect engine coloant level and mixture ratio in the pre radiator reservoir tank Inspect power steering fluid level and check for leakage inspect brake fluid level Inspect transmission and differential gear oil, record oil temperature and document leakage and smears  Engine B A Inspect area around the catalytic converter for heat de inspect exhaust finishers and (only for vehicles with GT exhaust) rear bumper clearance inspect and adjust clearance between the exhaust and surrounding parts  Transmission B A Adjust clutch clearance (clutch gear learning) Inspect whether tight corner braking phenomenon do	Apply aluminum tape over the wheel balance weight Inspect the wheel nuts for deformation Inspect the wheel nuts for deformation Inspect the mounting point of the wheel nut for deformation Inspect the mounting point of the wheel nut for deformation Inspect the wheel nut and the wheel nut for dosenes Tighten the wheel nut with the standard torque Inspect the wheel bearing (hub) for backlash and the wheel for rotation Align the reference marks on the tire and the inner wheel Inspect the tire and the wheel for direction of rotation deviation (in the wheel for direction of rotation deviation) Inspect and adjust the tire pressure Inspect the tire for nitrogen leakage Inspect the tire for ritrogen leakage Inspect the tire for uneven and abnormal wear Inspect the tire for damage and cracks Inspect the tire for damage and cracks Inspect the tire side wall for damage     Driveshaft   B A	Inspect brake piping and hoses for leakages Inspect brake pads for wear, color/temperature indication, damage and cracks Inspect brake disc rotors for wear, damage and cracks Inspect brake master cylinder and the calipers for fluid leakage
become extremely strong		Other Maintenance Items and Replaced Parts
Customer Name:  Mileage  GT-R Debler Name:  Address:  Date:  Technician Name:	Memo:	

Inspection Key:		
N/A: Normal N Replace: X Tighten T Clean C Adjust: A Repair: Disassemble: D Lubricate: L Skip Step S	Wheel and Tire  B A Apply aluminum tape over the wheel balance weight	Brake System B A Inspect brake piping and hoses for leakages
Fluids and Lubricants B A (R: Before A: After)	Inspect the wheel nuts for deformation and coolant Inspect the mounting point of the wheel nut for deformation Inspect the wheel nut and the wheel hub lock nut for looseness Tighten the wheel nut with the standard torque Inspect the wheel bearing (hub) for backlash and the wheel for rotation Align the reference marks on the tire and the inner wheel Inspect the tire and the wheel for direction of rotation deviation (rim deviation)	Inspect brake pads for wear, color/temperature indication, damage and cracks
Engine  B A Inspect area around the catalytic converter for heat of inspect exhaust finishers and (only for vehicles with of exhaust) rear bumper clearance inspect and adjust clearance between the exhaust are surrounding parts	Inspect the tire for nitrogen leakage Inspect the groove of the tire Inspect the tire for uneven and abnormal wear T-R genuine Inspect the tire for damage and cracks Inspect the tire side wall for damage	Inspect rods and arms of the steering system for looseness backlash and damage Inspect steering gear box for looseness at mounting points  Suspension  B A Inspect shock absorbers for damage and oil leakage
Transmission  B A  Adjust clutch clearance (clutch gear learning) Inspect whether tight corner braking phenomenon decome extremely strong  Customer Name.  Mileage.	B A Inspect driveshaft universal joint dust boots for cracks and	Inspect suspension for looseness at mounting points connection, backlash and damage Measure and adjust wheel adjustment  Other Maintenance items and Replaced Parts
COscilina name:  GT-R Dealer Nome:  Date:  Technician Name:		

inspection key:			
	ghten: T Clean C pricate: L Skip Step: S	Wheel and Tire  B A Apply aluminum tape over the wheel balance weight	Brake System  B A  Inspect brake piping and hoses for leakages
Fluids and Lubricants   8 A (8: Before A: After)	cord temperature, document nixture ratio in the pressurized and check for leakage	Inspect the wheel nuts for deformation	Inspect brake pads for wear, color/temperature indication, damage and cracks Inspect brake disc rotors for wear, damage and cracks Inspect brake master cylinder and the calipers for fluid leak Bleed any air from brake fluid Inspect the parts and area surrounding the brake rotors for heterioration Remove the grease on the front brake pads Apply the grease to the front brake pads
Inspect transmission and differen temperature and document leaks Engine  B A Inspect area around the catalytic Inspect exhaust finishers and (on	age and smears c converter for heat deterioration	Inspect the tire for uneven and abnormal wear	Steering  B A  Inspect rods and arms of the steering system for looseness backlash and damage  Inspect steering gear box for looseness at mounting point.
exhaust) rear bumper clearance Inspect and adjust clearance bets surrounding parts  Transmission	ween the exhaust and it's	<b>—</b> '	Suspension  B A  Inspect shock absorbers for damage and oil leakage Inspect suspension for looseness at mounting points
B A Adjust clutch clearance (clutch ge Inspect whether tight corner brail become extremely strong		B A Inspect driveshaft universal joint dust boots for cracks and damage	connection, backlash and damage Measure and adjust wheel adjustment Other Maintenance Items and Replaced Parts
	fleage:  T-R Dealer Name:	Memo:	
	ste: schnician Name:		

inspection key:			
NA	ge and smears of oil, fluid and cools el (record temperature, document and mixture ratio in the pressurized level and check for leakage	inspect the wheel nut and the wheel nub lock nut for looseness Tighten the wheel nut with the standard torque inspect the wheel bearing (hub) for backlash and the wheel for rotation Align the reference marks on the tire and the inner wheel inspect the tire and the wheel for direction of rotation deviation (rim deviation)	Inspect brake disc rotors for wear, damage and cracks Inspect brake master cylinder and the calipers for fluid leak: Bleed any air from brake fluid Inspect the parts and area surrounding the brake rotors for h deterioration Remove the grease on the front brake pads Apply the grease to the front brake pads
temperature and document  Engine B A Inspect area around the cations proceed exhaust finishers an exhaust) rear bumper cleara inspect and adjust clearance surrounding parts  Transmission B A Adjust clutch clearance (clut	leakage and smears alytic converter for heat deteriorati d (only for vehicles with GT-R genui nce e between the exhaust and it's	Inspect the tire for uneven and abnormal wear	Steering  B A  Inspect rods and arms of the steering system for looseness backlash and damage Inspect steering gear box for looseness at mounting points  Suspension  B A  Inspect shock absorbers for damage and oil leakage inspect suspension for looseness at mounting points connection, backlash and damage  Measure and adjust wheel adjustment  Other Maintenance items and Replaced Parts
Customer Name:  Address:	Mileage:  GT-R Debler Name:  Date:  Technician Name:	Memo:	

Inspection Key:			
N/A: Normal: N Replace: X Adjust: A Repair: Disassemble: D L	Tighten: T Clean C .ubricate: L Skip Step: S	Wheel and Tire B A	Brake System B A
Adjust/inspect engine oil level (in leakage and smears)	I mixture ratio in the pressurized rel and check for leakage ential gear oil, record oil ikage and smears tic converter for heat deterioration only for vehicles with GT-R genuine	Inspect the wheel nut and the wheel hub lock nut for loosenes Tighten the wheel nut with the standard torque Inspect the wheel bearing (hub) for backlash and the wheel for rotation Align the reference marks on the tire and the inner wheel Inspect the tire and the wheel for direction of rotation deviation (rim deviation) Inspect and adjust the tire pressure Inspect the air valve and nut of the tire for looseness Inspect the tire for nitrogen leakage Inspect the groove of the tire Inspect the for uneven and abnormal wear	Inspect brake disc rotors for wear, damage and cracks Inspect brake master cylinder and the calipers for fluid leak
exhaust) rear bumper clearance Inspect and adjust clearance be surrounding parts		Inspect the tire side wall for damage	Suspension  B A  Inspect shock absorbers for damage and oil leakage
Transmission  B A  Adjust clutch clearance (clutch Inspect whether tight corner be become extremely strong		Driveshaft B A Inspect driveshaft universal joint dust boots for cracks and damage	Inspect suspension for looseness at mounting points connection, backlash and damage Measure and adjust wheel adjustment  Other Maintenance items and Replaced Parts
Address:	Mileage: GT-R Dealer Nome: Date: Technician Name:	Memo:	

Inspection Key:			
N/A:         Normal:         N         Replace:         X           Adjust:         A         Repair:         Disassemble:         D	Tighten: T Clean C Lubricate: L Skip Step: S	Wheel and Tire  B A Apply aluminum tape over the wheel balance weight	B A  Inspect brake piping and hoses for leakages
Adjust/inspect engine oil level leakage and smears)	rential gear oil, record oil	Inspect the wheel nuts for deformation	Inspect brake pads for wear, color/temperature indication, damage and cracks
		Inspect the tire for nitrogen leakage Inspect the groove of the tire Inspect the tire for uneven and abnormal wear	Inspect rods and arms of the steering system for looseness, backlash and damage Inspect steering gear box for looseness at mounting points  Suspension  B A Inspect shock absorbers for damage and oil leakage
Transmission  B A  Adjust clutch clearance (clutch linspect whether tight corner become extremely strong	n gear learning) oraking phenomenon does not	Driveshaft  B A  Inspect driveshaft universal joint dust boots for cracks and damage	Inspect suspension for looseness at mounting points connection, backlash and damage Measure and adjust wheel adjustment  Other Maintenance Items and Replaced Parts
Customer Name.  Address:	Mileage: GT-R Dealer Name: Date: Technician Name:	Memo:	

inspection key:		
N/A:         Normal:         N         Replace:         X         Tighten:         T         Clean:         C           Adjust:         A         Repair:         Disassemble:         D         Lubricate:         L         Skip Step:         S	Wheel and Tire B A	Brake System
Eluids and Lubricants B A (B: Before A: After) Inspect underbody for leakage and smears of oil. fluid and coolant Adjust/inspect engine oil level (record temperature, document leakage and smears) Adjust engine coolant level and mixture ratio in the pressurized radiator reservoir tank Inspect power steering fluid level and check for leakage Inspect brake fluid level Inspect transmission and differential gear oil, record oil temperature and document leakage and smears  Engine B A Inspect exhaust finishers and (only for vehicles with GT-R genuine exhaust) rear bumper clearance inspect and adjust clearance between the exhaust and it's surrounding parts  Transmission  B A Adjust clutch clearance (clutch gear learning) Inspect whether tight corner braking phenomenon does not become extremely strong	Inspect the wheel nut and the wheel hub lock nut for looseness Tighten the wheel nut with the standard torque Inspect the wheel bearing (hub) for backlash and the wheel for rotation  Align the reference marks on the tire and the inner wheel Inspect the tire and the wheel for direction of rotation deviation (in deviation)  Inspect and adjust the tire pressure Inspect the air valve and nut of the tire for looseness Inspect the groove of the tire Inspect the groove of the tire Inspect the tire for nitrogen leakage Inspect the tire for uneven and abnormal wear	Inspect brake pipling and hoses for leakages Inspect brake pads for wear, color/temperature indication, damage and cracks Inspect brake disc rotors for wear, damage and cracks Inspect brake disc rotors for wear, damage and cracks Inspect brake master cylinder and the calipers for fluid leakage Bleed any air from brake fluid Inspect the parts and area surrounding the brake rotors for heat deterioration Remove the grease on the front brake pads  Steering B A Inspect rods and arms of the steering system for looseness, back-ash and damage Inspect steering gear box for looseness at mounting points  Suspension B A Inspect shock absorbers for damage and oil leakage Inspect suspension for looseness at mounting points connection, backlash and damage Measure and adjust wheel adjustment
Customer Name:    Mileage	Merno:	Other Maintenance Items and Replaced Parts


Inspection Key:		
N/A: Normal N Replace: X Tighten T Clean C Adjust: A Repair: Disassemble: D Lubricate: L Skip Step S	Wheel and Tire  B A Apply aluminum tape over the wheel balance weight	Brake System  B A  Inspect brake piping and hoses for leakages
Fluids and Lubricants   B A (B. Before A. After)   Inspect underbody for leakage and smears of oil, fluid and coolant   Adjust/inspect engine oil level (record temperature, document leakage and smears)   Adjust engine coolant level and mixture ratio in the pressurized radiator reservoir tank   Inspect power steering fluid level and check for leakage   Inspect brake fluid level   Inspect transmission and differential gear oil, record oil temperature and document leakage and smears   Engine   B A   Inspect area around the catalytic converter for heat deterioration   Inspect exhaust finishers and (only for vehicles with GT-R genuine exhaust) rear bumper clearance   Inspect and adjust clearance between the exhaust and it's surrounding parts	Inspect the wheel nut and the wheel nut lock nut for looseness Tighten the wheel nut with the standard torque Inspect the wheel bearing (hub) for backlash and the wheel for rotation Align the reference marks on the tire and the inner wheel Inspect the tire and the wheel for direction of rotation devaluon (rim deviation) Inspect and adjust the tire pressure Inspect the air valve and nut of the tire for looseness Inspect the tire for nitrogen leakage Inspect the tor for uneven and abnormal wear	Inspect brake pads for wear, color/temperature indication, damage and cracks Inspect brake disc rotors for wear, damage and cracks Inspect brake master cylinder and the calipers for fluid leak: Bleed any air from brake fluid Inspect the parts and area surrounding the brake rotors for hid deterioration Remove the grease on the front brake pads Apply the grease to the front brake pads Steering B A Inspect rods and arms of the steering system for looseness backlash and damage Inspect steering gear box for looseness at mounting points Suspension B A Inspect shock absorbers for damage and oil leakage
Transmission  B A Adjust clutch clearance (clutch gear learning) Inspect whether tight corner braking phenomenon does not become extremely strong	Driveshaft  B A Inspect driveshaft universal joint dust boots for cracks and damage	Inspect suspension for looseness at mounting points connection, backlash and damage  Measure and adjust wheel adjustment  Other Maintenance Items and Replaced Parts
Mileage	Memo:	

inspection key:		
N/A:         Normal:         N         Replace:         X         Tighten:         T         Clean:         C           Adjust:         A         Repair:         Disassemble:         D         Lubricate:         L         Skip Step:         S	Wheel and Tire B A	Brake System
Eluids and Lubricants B A (B: Before A: After) Inspect underbody for leakage and smears of oil. fluid and coolant Adjust/inspect engine oil level (record temperature, document leakage and smears) Adjust engine coolant level and mixture ratio in the pressurized radiator reservoir tank Inspect power steering fluid level and check for leakage Inspect brake fluid level Inspect transmission and differential gear oil, record oil temperature and document leakage and smears  Engine B A Inspect exhaust finishers and (only for vehicles with GT-R genuine exhaust) rear bumper clearance inspect and adjust clearance between the exhaust and it's surrounding parts  Transmission  B A Adjust clutch clearance (clutch gear learning) Inspect whether tight corner braking phenomenon does not become extremely strong	Inspect the wheel nut and the wheel hub lock nut for looseness Tighten the wheel nut with the standard torque Inspect the wheel bearing (hub) for backlash and the wheel for rotation  Align the reference marks on the tire and the inner wheel Inspect the tire and the wheel for direction of rotation deviation (in deviation)  Inspect and adjust the tire pressure Inspect the air valve and nut of the tire for looseness Inspect the groove of the tire Inspect the groove of the tire Inspect the tire for nitrogen leakage Inspect the tire for uneven and abnormal wear	Inspect brake pipling and hoses for leakages Inspect brake pads for wear, color/temperature indication, damage and cracks Inspect brake disc rotors for wear, damage and cracks Inspect brake disc rotors for wear, damage and cracks Inspect brake master cylinder and the calipers for fluid leakage Bleed any air from brake fluid Inspect the parts and area surrounding the brake rotors for heat deterioration Remove the grease on the front brake pads  Steering B A Inspect rods and arms of the steering system for looseness, back-ash and damage Inspect steering gear box for looseness at mounting points  Suspension B A Inspect shock absorbers for damage and oil leakage Inspect suspension for looseness at mounting points connection, backlash and damage Measure and adjust wheel adjustment
Customer Name:    Mileage	Merno:	Other Maintenance Items and Replaced Parts

## SETTING GUIDE OF WHEEL ALIGNMENT **DEPENDING ON THE CUSTOMER'S DRIVING**


#### Except For NISMO and Track edition engineered by nismo models

The wheel alignment can be adjusted. We recommend that you contact a GT-R certified NISSAN dealer for further details.



- Toe-out can cause uneven tire wear or damage to areas inside the tires due to high heat. Be sure to have the wheel alignment toe-in setting checked and adjusted. We recommend that you contact your GT-R certified NISSAN dealer for this service
- The toe changes, depending on vehicle attitude changes or the permanent set of bushings. Accordingly, the state of the front wheels change to toe-out and the rear wheels, toe in.
- For the above reasons, be sure to adjust to toe-in when engaging in high performance driving on a racetrack. (Toe-out is not covered by the warranty.)

## For NISMO and Track edition engineered by nismo models



 Toe-out can cause uneven tire wear or damage to areas inside the tires due to high heat. Be sure to have the wheel alignment toe-in setting checked and adjusted by your GT-R certified NISSAN dealer before any performance driving on closed circuit tracks. Obey all traffic laws when on public roads.

## Toe-in specification

Front:  $\leq$  0.059 in (1.5 mm) Rear:  $\leq$  0.079 in (2.0 mm)

- The toe changes, depending on vehicle attitude changes or the permanent set of bushings. Accordingly, the state of the front wheels change to toe-out and the rear wheels, toe in.
- For the above reasons, be sure to adjust to toe-in when engaging in high performance driving on a racetrack. (Toe-out is not covered by the warranty.)

#### TIRE REPLACEMENT RECORD

The GT-R uses specially designed run-flat tires and matching road wheels. Use of these specially developed tires and wheels provides the greatest potential for maximum performance.

#### NOTICE

- When you replace the GT-R tires, it is recommended that you replace all the tires at the same time.
- The GT-R uses specially designed run-flat tires which feature an extremely rigid side wall. Special techniques and equipment are therefore required when replacing these tires. NISSAN recommends that tire replacement be performed at a GT-R certified NISSAN dealer.

Da	tte			Mile	age at r	eplace	ment	Part numb		Pron	ts:		
-						mile	es (km)	replacem tire	ens i	Rear			
	Tire pri	essure (	nitroge	n filling)		Iristali	ed bala	nce weight	(g) / F	Residua	unbaland	e weight	(9)
Left	Front	kPa	Ripht	Front	кРа	Left	Front	9/	g	erceier.	Front	g/	9
	Rear	KPa	HIGHE	Rear	kPa	Lient	Rear	9/	9	Right	Rear	g/	9

Da	te			Mile	age at r	eplace	ment	Part nun		From	t		
						mile	es (km)	réplace		Rear			
	Tire pre	essure (	nitroge	en filling)		Install	ed bala	nce weigh	it (g) / i	esidu	unbalano	ce weight	(g)
Left	Front	kPa	District.	Front	kPa	Left	Front	9/	g	Right	Front	9/	9
LEIL	Rear	KPa	Hognit	Rear	KPa	Cert	Rear	q/	- 0	RIGHE	Rear	9/	c

Da	te			Mile	age at	eplace	ment	Part numb		Fron	t		
						mile	es (km)	replacem		Rear			
	Tire pre	essure (	nitroge	n filling)		instali	ed pala	nce weight	(g) / I	Residua	al unbaland	e weigh	(g)
Left	Front.	kPa	Right	Front	kPa	Left	Front	9/	ġ	Right	Front	9/	9
Lest	Rear	kPa	U. J. 46	Rear	кра	Leit	Rear	9/	9	ragni	Rear	g/	9

Da	ite			Mile	age at r	eplace	ment	Part num		Fran	t		-
						mile	15 (km)	replacer		Rear			
	Tire pr	essure (	nitroge	in filling)		install	ed bala	nce weigh	(g) / s	Residua	il unbalano	e weight	(g)
Left	Frant	kPa	Right	Front	kPa	Left	Front	9/	9	Right	Front	g/	9
	Rear	KPa	ragint	Rear	kPa	Cert	Rear	9/		Right	Rear	97	q

Da	te			Mile	eage at r	eplace	ment	Part number o	f From	it		- 1
						mile	es (Km)	Tion	Rea	il.		
	Tire pr	essure (	iltroge	en filling)		instali	ed bala	nce weight (g)	Residu	al unbalan	ce weight	(g)
Left	From	kPa	Right	Front	kPa	Left	Frant	g/ !	Right	Front	g/	g
CET	Rear	KPa	Right	Rear	KPa	Cert	Rear	g/ 1	- rouge co	Rear	g/	g

Da	te			Mile	age at i	eplace	ment	Part numb	0.00	Fran	t		-
				4		mile	s (km)	replacem	enc	Rear			
	Tire pre	essure (	nitroge	in filling)		install	ed bala	nce weight	(g) / s	Residua	il unbalan	e weight	(g)
Left	Front	kPa	2/44	Frant	kPa	San.	Front	g/	g	81.6	Front	9/	9
Lerc	Rear	kPa	Right	Rear	kPa	Left	Rear	g/	g	Right	Rear	g/	9

Da	te			Mile	age at r	replace	ment	Part numb		Pron	ts:		
						mile	es (km)	tire	tent	Rear			
	Tire pro	essure (	nitroge	en filling)		Instali	ed bala	nce weight	(g) / F	Residua	ol unbaland	e weight	(9)
Left	Front	KPa	Right	Front	kPa	Left	Front	9/	g	Right	Front	g/	- 5
PRINT.	Rear	KPa	HILITIE	Rear	kPa	Ligit	Rear	9/	'n	rogni	Rear	q/	5

Da	te			Mile	age at r	eplace	ment	Part num		Fron	t		
4						mile	es (km)	réplacer		Rear	SUE.		
	Tire pre	essure (	nitroge	n filling)		Install	ed bala	nce weigh	(g) / s	Pesidua	l unbaland	e weight	(g)
Left	Front	kPa	Diabe	Front	kPa	Left	Front	9/	g	Right	Front	9/	9
PRIT.	alia.	KPa	Ragnit	Rear	KPa	Cert	Reac	9/	- 9	RIGHE	Rear	9/	6

Da	ite			Mile	age at	replace	ment	Part numi		Fron	t		
						mile	es (km)	ting		Rear			
	Tire pre	essure (	nitroge	en filling)		instali	ed pala	nce weight	(g) / I	Residua	al unbaland	e weigh	t (g)
Left	Front.	kPa	Right	Front	kPa	Left	Front	9/	g	Right	Front	9/	. 0
Leit	Rear	kPa		Rear	KPa	Light	Rear	9/	9	ragin	Rear	g/	9

Da	ite			Mile	age at i	eplace	ment	Part numi		Fran	t		-
						mile	es (km)	tire	ner ne	Rear			
	Tine pre	essure (	nitroge	in filling)		install	ed bala	nce weight	(g) / s	Residua	il unbalani	e weight	(g)
Left	Frant	kPa		Front	kPa	Left	Front	9/	9	Right	Front	g/	9
Lett	Rear	KPa	Right	Rear	kPa	Cert	Rear	9/	9	Right	Rear	97	g

Da	te			Mile	age at r	eplace	ment	Part numbe replaceme		Fron	t		_
						mile	es (Km)	Fire	W.	Rear			
	Tire pr	essure (	nitrage	en filling)		instali	ed bala	nce Weight (	9)/6	Residue	unbalana	se weight	(g)
Left	From	kPa	Ni dia	Front	kPa	Left	Frant	<b>a</b> /	9	Right	Front	g/	g
CELL	Rear	kPa.	Right	Rear	kPa.	Cert	Rear	g/	g	RIGHT	Rear	9/	g

Da	ite			Mile	age at r	eplace	ment	Part numb		Fran	i i		-
						mile	s (km)	tire	enc	Rear			
	Tire pre	essure (	nitroge	in filling)	-	install	ed bala	nce weight	(g) / s	Residua	il unbalan	e weight	(g)
Left	Front	kPa	2/44	Frant	kPa	San.	Front	g/	g	Right	Front	g/	9
reir	Rear	kPa	Right	Rear	kPa	Left	Rear	g/	g	Kiğut	Briac	g/	

## TRANSMISSION ASSEMBLY/PARTS REPLACEMENT RECORD

When replacing the transmission assembly, be sure to record the new serial number in the space provided.

· When replacing the transmission assembly

Transmission Serial No.	Dealer name or signature	Transmission Serial No.	Dealer name or signature
Date:		Date:	
Mileage at replacement:		Mileage at replacement:	
Miles (km)		Miles (km)	
Transmission Serial No.	Dealer name or signature	Transmission Serial No.  Date:	Déaler name or signature

# $\cdot$ When replacing the transmission parts

Transmission Serial No.	Date:	Transmission Serial No.	Date
Replacement parts and Serial No. Clutch pack	Mileage at replacement: Miles (km)	Replacement parts and Serial No.	Mileage at replacement:
☐ Front control module	Dealer name or signature	☐ Front control module	Dealer name or signature
Actuator control module		Actuator control module	
Transmission Serial No.	Date:		
Replacement parts and Serial No.			
Clutch pack	Mileage at replacement. Miles (km)		
Front control module	Dealer name or signature		
☐ Actuator control module			

Miles (km)

### MAINTENANCE LOG AND RECORDS

The following Maintenance Log has been compiled by NISSAN to assist you in performing the recommended maintenance services and keeping appropriate records of services performed. The maintenance log is composed of the log for GT-R special inspections and the log for scheduled maintenance. Along with the related repair invoices, receipts, and other such records, a properly documented maintenance history could enhance the value of your vehicle should you ever wish to sell it. The services listed represent the minimal NISSAN recommended requirements for each time/ mileage interval, up to 96,000 miles (160,000 km) / 96 months.

#### Abbreviations


[]: Performed based on the mileage only.

<>: Performed based on the number of months only.

# GT-R Complimentary Performance Optimization Services\*

\*Necessary repairs discovered during inspections may incur service charges.

# 1,000 MILES (1,600 KILOMETERS)



Refer to the appropriate Schedule 1 or Schedule 2, recommended maintenance schedule for additional maintenance items


# GT-R Performance Optimization Service Log Record of Service Details

otal Toe-In			Transmission Settings				
		in/mm	Measured Values				
Camber	LH	Deg/min (Dec/Deg)	Engine Speed rpm			Address	
Camper	RH	Deg/min (Dec/Deg)	Trans. Oil Temp.		F(C)	Hadross	
Caster	LH	Deg/min (Dec/Deg)		-1-			
Caster	RH	Deg/min (Dec/Deg)					
otal Toe-In		in/mm					
Deg/min (Dec/Deg)							
Camber	RH	Deg/min (Dec/Deg)	Status of Transmission S	Status of Transmission Setting			
			L (4) L (8)	Previous L	earned Value	1	
			Clutch Gear Learning	4.00	2011/2010/2010	Mileage	Miles/km
ljusted Values				Dealer Name			
otal Toe-in	-	in/mm	entire the sectings as ac	average to the C	ostotne.		
Combas	LH	Deg/min (Dec/Deg)	Clutch A touch point sett	ing value			
Camber	RH	Deg/min (Dec/Deg)	Clutch B touch point setting value				
Castor	LH	Deg/min (Dec/Deg)	Adjust clutch A capacity	setting value			
Coate	RH	Deg/min (Dec/Deg)	Adjust clutch B capacity	setting value			
otal Toe-In	-	in/mm				Technician Name	
Combas	LH	Deg/min (Dec/Deg)					
Camper	AH	Deg/min (Dec/Deg)					
0	Camber I Values otal Toe-in Camber Caster otal Toe-in	tal Toe-In  Camber RH  I Values  Stal Toe-In  Camber RH  Camber RH  Caster RH  RH  Caster RH	Values	Caster	Caster LH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) In/mm LH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) Status of Transmission Setting Current Le Curre	Caster	Caster LH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) Status of Transmission Setting  Status of Transmission Setting  Status of Transmission Setting  Current Learned Value Current Learned Value Current Learned Value Circle the settings as delivered to the Customer  Camber LH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) Caster LH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) Adjust clutch A capacity setting value Date Tachnician Name

# GT-R Complimentary Performance Optimization Services\*

\*Necessary repairs discovered during inspections may incur service charges.

# 12 MONTHS



Refer to the appropriate Schedule 1 or Schedule 2, recommended maintenance schedule for additional maintenance items


# GT-R Performance Optimization Service Log Record of Service Details

otal Toe-In			Transmission Settings				
		in/mm	Measured Values				
Camber	LH	Deg/min (Dec/Deg)	Engine Speed rpm			Address	
Camper	RH	Deg/min (Dec/Deg)	Trans. Oil Temp.		F(C)	Hadross	
Caster	LH	Deg/min (Dec/Deg)		-1-			
Caster	RH	Deg/min (Dec/Deg)					
otal Toe-In		in/mm					
Deg/min (Dec/Deg)							
Camber	RH	Deg/min (Dec/Deg)	Status of Transmission S	Status of Transmission Setting			
			L (4) L (8)	Previous L	earned Value	1	
			Clutch Gear Learning	4.00	2011/2010/2010	Mileage	Miles/km
ljusted Values				Dealer Name			
otal Toe-in	-	in/mm	entire the sectings as ac	average to the C	ostotne.		
Combas	LH	Deg/min (Dec/Deg)	Clutch A touch point sett	ing value			
Camber	RH	Deg/min (Dec/Deg)	Clutch B touch point setting value				
Castor	LH	Deg/min (Dec/Deg)	Adjust clutch A capacity	setting value			
Coate	RH	Deg/min (Dec/Deg)	Adjust clutch B capacity	setting value			
otal Toe-In	-	in/mm				Technician Name	
Combas	LH	Deg/min (Dec/Deg)					
Camper	AH	Deg/min (Dec/Deg)					
0	Camber I Values otal Toe-in Camber Caster otal Toe-in	tal Toe-In  Camber RH  I Values  Stal Toe-In  Camber RH  Camber RH  Caster RH  RH  Caster RH	Values	Caster	Caster LH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) In/mm LH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) Status of Transmission Setting Current Le Curre	Caster	Caster LH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) Status of Transmission Setting  Status of Transmission Setting  Status of Transmission Setting  Current Learned Value Current Learned Value Current Learned Value Circle the settings as delivered to the Customer  Camber LH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) Caster LH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) Adjust clutch A capacity setting value Date Tachnician Name

# GT-R Complimentary Performance Optimization Services\*

\*Necessary repairs discovered during inspections may incur service charges.

# 24 MONTHS



Refer to the appropriate Schedule 1 or Schedule 2, recommended maintenance schedule for additional maintenance items


# GT-R Performance Optimization Service Log Record of Service Details

	dell'ent alla l	ujustriieni	of wheel alignment				Customer Name	
east	red Values			Transmission Settings				
	Total Toe-In		in/mm	Measured Values				
- 1	Camber	LH	Deg/min (Dec/Deg)	Engine Speed rpm			Address	
FR	Camper	RH	RH Deg/min (Dec/Deg) Trans. Oil Temp. F (*C)			"F ("C)	1.00.7-5	
Caster	LH	Deg/min (Dec/Deg)		-				
	A. 4500 a. 1	RH	Deg/min (Dec/Deg)					
	Total Toe-In		in/mm					
RR	R Camber LH Deg/min (Dec/Deg)		Deg/min (Dec/Deg)					
	Carricia	RH	Deg/min (Dec/Deg)	Status of Transmission S	Status of Transmission Setting			
					Previous L	earned Value		
	Transcription			Clutch Gear Learning	Current Le	arned Value	Mileage	Miles/km
djust	djusted Values		'Circle the settings as de	*Circle the settings as delivered to the Customer		Dealer Name		
	Total Toe-in		in/mm	ACT IN THE FOLIA CONTRACTOR	TO DESTRUCT	56,111,556		
- 1	Camber	TH	Deg/min (Dec/Deg)	Clutch A touch point sett	ing value			
FR.	comou	RH	Deg/min (Dec/Deg)	Clutch B touch point sett	ing value			
	Caster	CH	Deg/min (Dec/Deg)	Adjust clutch A capacity	setting value		5.00	
	225/4	RH	Deg/min (Dec/Deg)	Adjust clutch B capacity	setting value		Date	
	Total Toe-In	-	in/mm				Technician Name	
RR	Camber	LH	Deg/min (Dec/Deg)					
234	Comper	RH	Deg/min (Dec/Deg)					

# GT-R Complimentary Performance Optimization Services\*

\*Necessary repairs discovered during inspections may incur service charges.

# **36 MONTHS**



Refer to the appropriate Schedule 1 or Schedule 2, recommended maintenance schedule for additional maintenance items

# GT-R Performance Optimization Service Log Record of Service Details


otal Toe-In			Transmission Settings				
		in/mm	Measured Values				
Camber	LH	Deg/min (Dec/Deg)	Engine Speed rpm			Address	
Camper	RH	Deg/min (Dec/Deg)	Trans. Oil Temp.		F(C)	Hadross	
Caster	LH	Deg/min (Dec/Deg)		-1-			
Caster	RH	Deg/min (Dec/Deg)					
otal Toe-In		in/mm					
Deg/min (Dec/Deg)							
Camber	RH	Deg/min (Dec/Deg)	Status of Transmission S	Status of Transmission Setting			
			L (4) L (8)	Previous L	earned Value	1	
			Clutch Gear Learning	4.00	2011/2010/2010	Mileage	Miles/km
ljusted Values				Dealer Name			
otal Toe-in	-	in/mm	entire the sectings as ac	average to the C	ostotne.		
Combas	LH	Deg/min (Dec/Deg)	Clutch A touch point sett	ing value			
Camber	RH	Deg/min (Dec/Deg)	Clutch B touch point setting value				
Castor	LH	Deg/min (Dec/Deg)	Adjust clutch A capacity	setting value			
Coate	RH	Deg/min (Dec/Deg)	Adjust clutch B capacity	setting value			
otal Toe-In	-	in/mm				Technician Name	
Combas	LH	Deg/min (Dec/Deg)					
Camper	AH	Deg/min (Dec/Deg)					
0	Camber I Values otal Toe-in Camber Caster otal Toe-in	tal Toe-In  Camber RH  I Values  Stal Toe-In  Camber RH  Camber RH  Caster RH  RH  Caster RH	Values	Caster	Caster LH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) In/mm LH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) Status of Transmission Setting Current Le Curre	Caster	Caster LH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) Status of Transmission Setting  Status of Transmission Setting  Status of Transmission Setting  Current Learned Value Current Learned Value Current Learned Value Circle the settings as delivered to the Customer  Camber LH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) Caster LH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) RH Deg/min (Dec/Deg) Adjust clutch A capacity setting value Date Tachnician Name

# 6,000 MILES (10,000 KILOMETERS) OR 6 MONTHS





# 12,000 MILES (20,000 KILOMETERS) OR 12 MONTHS





<>: Performed based on the number of service months only.

Refer to the appropriate GT-R Performance Optimization Services section for additional maintenance items.

# 18,000 MILES (30,000 KILOMETERS) OR 18 MONTHS





>: Performed based on the number of service months only.


# 24,000 MILES (40,000 KILOMETERS) OR 24 MONTHS

SCHEDULE 1 MAINTENANCE	SCHEDULE 2 MAINTENANCE
☐ Replace engine oil and filter ☐ Replace engine coolant ☐ Replace in-cabin microfilter ☐ <replace brake="" fluid=""> ☐ Inspect the following:</replace>	☐ Replace engine oil and filter☐ Replace engine coolant☐ Replace in-cabin microfilter☐ <replace brake="" fluid="">☐ Inspect the following:</replace>
<engine abnormal="" and="" sound="" startability=""> <driving accelerating="" and="" at="" low="" performance="" speed=""> <throttle chamber="" deposits=""> Axle &amp; suspension parts Brake lines &amp; cables Brake place &amp; coors Differential oil (front &amp; rear) Engine drive belts Drive shaft boots Exhaust system Fuel lines/conr Fuel tank vapo system hoses Transmission of propeller shaft Steering gear at linkage Steering linkage joints</throttle></driving></engine>	abnormal sound> Front suspension ball   Spriving performance   Joints   Speed> Fuel lines/connection   Speed> Fuel tank vapor vent   System hoses   System hoses   Seake lines & Cables   Propeller shaft   Strake pads & rotors   Steering gear and   Differential oil (front & linkage   Inkage   Inkage

<>: Performed based on the number of service months only.
Refer to the appropriate GT-R Performance Optimization Services section for additional maintenance items.


# 30,000 MILES (50,000 KILOMETERS) OR 30 MONTHS






1 Replace spark plug when the spark plug gap reaches 0.9 mm (0.035 in) or more, even if within specified periodic replacement mileage []: Performed based on the mileage only.

## 36,000 MILES (60,000 KILOMETERS) OR 36 MONTHS





[]: Performed based on the mileage only.

<>: Performed based on the number of service months only.


Refer to the appropriate GT-R Performance Optimization Services section for additional maintenance items.

# 42,000 MILES (70,000 KILOMETERS) OR 42 MONTHS





## 48,000 MILES (80,000 KILOMETERS) OR 48 MONTHS




If the performance optimization services at 36 months (free of charge) including this inspection have not been finished yet, this inspection is not necessary.

<sup>&</sup>lt;>: Performed based on the number of service months only.

# GT-R Performance Optimization Service Log Record of Service Details

Values al Toe-In amber Caster	LH RH LH	in/mm Deg/min (Dec/Deg) Deg/min (Dec/Deg)	Transmission Settings Measured Values Engine Speed Trans. Oil Temp.		rpm	Customer Name	
al Toe-In amber	RH	Deg/min (Dec/Deg) Deg/min (Dec/Deg)	Measured Values Engine Speed		rpm		
amber	RH	Deg/min (Dec/Deg) Deg/min (Dec/Deg)	Engine Speed		rpm		
amber	RH	Deg/min (Dec/Deg) Deg/min (Dec/Deg)	7 19 2 C 1 1 2 C 1 1 L		rpm	factors and	
Car Do.	RH	Deg/min (Dec/Deg)	Trans, Oil Temp.			Address	
Caster	LH	1 main to 1 m 1 m 1 m 1 m 1 m 1 m 1 m 1 m 1 m 1			F(C)	Address	
aster		Deg/min (Dec/Deg)	77-00-00-00-00-00-00-00-00-00-00-00-00-0				
	RH	Deg/min (Dec/Deg)					
al Toe-in	17	in/mm					
which are	LH	Deg/min (Dec/Deg)					
amber.	RH	Deg/min (Dec/Deg)	Status of Transmission Setting				
			TOTAL DESIGNATION	Drawinus V	earnert Value	1	
			Clutch Gear Learning	4.00	2011/2010/2010	Mileage	Miles/km
/alues				1.		Dealer Name	
al Toe-in	-	in/mm	circle the settings as de	ivered to the C	uscumer	1	
ambat	LH	Deg/min (Dec/Deg)	Clutch A touch point sett	ing value			
amber	RH	Deg/min (Dec/Deg)					
astor	LH	Deg/min (Dec/Deg)	Adjust clutch A capacity	setting value		-	
	RH	Deg/min (Dec/Deg)	Adjust clutch B capacity	setting value			
al Toe-In	-	in/mm				Technician Name	
	LH	Deg/min (Dec/Deg)				11	
amper	AH	Deg/min (Dec/Deg)					
al al	Toe-in mber aster	I Toe-In Life RH			Deg/min (Dec/Deg)   Status of Transmission Setting   Previous L	Deg/min (Dec/Deg)   Status of Transmission Setting   Previous Learned Value   Current Learned Value	Status of Transmission Setting   Previous Learned Value   Cutch Gear Learning   Cutch

## 54,000 MILES (90,000 KILOMETERS) OR 54 MONTHS



[]: Performed based on the mileage only.

<>: Performed based on the number of service months only.

## 60,000 MILES (100,000 KILOMETERS) OR 60 MONTHS

SCHEDULE 1	MAINTENANCE	SCHEDULE 2 MAINTENANCE
Replace engine oil and filte Replace in-cabin microfilte Replace in-cabin microfilte Replace engine air filter Replace spark plugs excep Replace spark plugs for Ni Replace spark plugs for Ni Replace brake hoses> Inspect the following: Engine startability and abnormal sound> Driving performance at low and accelerating speed> Throttle chamber deposits> Transmission settings' Measurement and adjustment of wheel alignment' Axile & suspension parts Brake lines & cables Brake lines & cables Brake pads & rotors	ot NISMO] <sup>2</sup>	□ Replace engine oil and filter     □ Replace in-cabin microfilter     □ [Replace engine air filter]     □ [Replace spark plugs except NISMO]²     □ Replace spark plugs for NISMO]³     □ Replace brake hoses     □ Inspect the following:     □ <engine abnormal="" and="" sound="" startability="">     □ <inving accelerating="" and="" at="" low="" performance="" speed="">     □ <throttle chamber="" deposits="">     □ Transmission settings¹     □ Measurement and adjustment of wheel alignment¹     □ Brake lines &amp; cables     □ Brake pads &amp; rotors     □ Differential oil (front &amp; rear)     □ Drive shaft boots     □ Engine drive belts     □ Transmission oil     □ Propeller shaft</throttle></inving></engine>

<sup>1</sup> if the performance optimization services at 36 months (free of charge) including this inspection have not been finished yet, this inspection is

<sup>2</sup> Replace spark plug when the spark plug gap reaches 1.0 mm (0.039 in) or more, even if within specified periodic replacement mileage. 3 Replace spark plug when the spark plug gap reaches 0.9 mm (0.035 in) or more, even if within specified periodic replacement mileage.

<sup>[]:</sup> Performed based on the mileage only.


<sup>&</sup>lt;>: Performed based on the number of service months only.

# GT-R Performance Optimization Service Log Record of Service Details

aster	EH RH LH RH	in/mm Deg/min (Dec/Deg) Deg/min (Dec/Deg) Deg/min (Dec/Deg) Deg/min (Dec/Deg)	Measured Values Engine Speed Trans. Oil Temp.		rpm °F (°C)	Address	
aster	RH LH	Deg/min (Dec/Deg) Deg/min (Dec/Deg)	- Sec. 11. 12. 11. 11. 11. 11. 11. 11. 11. 11		1.00	Address	
aster al Toe-In	LH	Deg/min (Dec/Deg)	Trans. Oil Temp.		"F ("C)	1000000	
al Toe-in				-			
al Toe-in	RH	Deg/min (Dec/Deg)					
1000							
3-3-5		in/mm					
	LH	Deg/min (Dec/Deg)					
amber	RH	Deg/min (Dec/Deg)	Status of Transmission S	etting			
				Pravious Le	arned Value	1	
			Clutch Gear Learning	4.00	24102 2000	Mileage	Miles/km
niues						Dealer Name	
al Toe-in	-	in/mm	entre the settings as ac	WEIGHT TO DIE CO	Stating		
ombat	LIR	Deg/min (Dec/Deg)	Clutch A touch point sett	ing value			
amoer	RH	Deg/min (Dec/Deg)	Clutch B touch point sett				
aster	CR	Deg/min (Dec/Deg)	Adjust clutch A capacity	setting value		-	
3	RH	Deg/min (Dec/Deg)	Adjust clutch B capacity	setting value			
Toe-In		in/mm				Technician Name	
ambar I	LH	Deg/min (Dec/Deg)					
amper	RH	Deg/min (Dec/Deg)					
al	Toe-in mber aster	Toe-in  The Lift RH  Seter LH  RH  Toe-in	Toe-In   in/mm   in/mm	Clutch Gear Learning  Clutch Gear Learning  Circle the settings as del  Clutch A touch point sett  Deg/min (Dec/Deg)  Deg/min (Dec/Deg)  Adjust clutch A capacity:  Troe-In in/mm	Previous Let	Clutch Gear Learning   Current Learned Value	Clutch Gear Learning Current Learned Value C

## 66,000 MILES (110,000 KILOMETERS) OR 66 MONTHS





## 72,000 MILES (120,000 KILOMETERS) OR 72 MONTHS

SCHEDULE 1 MAINTENANCE	SCHEDULE 2 MAINTENANCE
Replace engine oil and filter	Replace engine oil and filter Replace engine coolant Replace transmission oil] Replace differential oil (front & rear)) Replace in-cabin microfilter Replace brake fluid> Inspect the following: Sengine startability and Exhaust system
<engine abnormal="" and="" sound="" startability=""> Engine drive belts     <priving accelerating="" and="" at="" low="" performance="" speed=""> Front suspension ball joints     </priving></engine>	abnormal sound> <pre></pre>

1 if the performance optimization services at 36 months (free of charge) including this inspection have not been finished yet, this inspection is not necessary.

[]: Performed based on the mileage only.

<>: Performed based on the number of service months only.

# GT-R Performance Optimization Service Log Record of Service Details


Values al Toe-In amber Caster	LH RH LH	in/mm Deg/min (Dec/Deg) Deg/min (Dec/Deg)	Transmission Settings Measured Values Engine Speed Trans. Oil Temp.		rpm	Customer Name	
al Toe-In amber	RH	Deg/min (Dec/Deg) Deg/min (Dec/Deg)	Measured Values Engine Speed		rpm		
amber	RH	Deg/min (Dec/Deg) Deg/min (Dec/Deg)	Engine Speed		rpm		
amber	RH	Deg/min (Dec/Deg) Deg/min (Dec/Deg)	7 19 2 C 1 1 2 C 1 1 L		rpm	factors and	
Car Do.	RH	Deg/min (Dec/Deg)	Trans, Oil Temp.			Address	
Caster	LH	1 main to 1 m 1 m 1 m 1 m 1 m 1 m 1 m 1 m 1 m 1			F(C)	Address	
aster		Deg/min (Dec/Deg)	77-00-00-00-00-00-00-00-00-00-00-00-00-0				
	RH	Deg/min (Dec/Deg)					
al Toe-in	17	in/mm					
which are	LH	Deg/min (Dec/Deg)					
amber.	RH	Deg/min (Dec/Deg)	Status of Transmission Setting				
			TOTAL DESIGNATION	Drawinus V	earnert Value	1	
			Clutch Gear Learning	4.00	2011/2010/2010	Mileage	Miles/km
/alues				1.		Dealer Name	
al Toe-in	-	in/mm	circle the settings as de	ivered to the C	uscumer	1	
ambat	LH	Deg/min (Dec/Deg)	Clutch A touch point sett	ing value			
amber	RH	Deg/min (Dec/Deg)					
astor	LH	Deg/min (Dec/Deg)	Adjust clutch A capacity	setting value		-	
	RH	Deg/min (Dec/Deg)	Adjust clutch B capacity	setting value			
al Toe-In	-	in/mm				Technician Name	
	LH	Deg/min (Dec/Deg)				11	
amper	AH	Deg/min (Dec/Deg)					
al al	Toe-in mber aster	I Toe-In Life RH			Deg/min (Dec/Deg)   Status of Transmission Setting   Previous L	Deg/min (Dec/Deg)   Status of Transmission Setting   Previous Learned Value   Current Learned Value	Status of Transmission Setting   Previous Learned Value   Cutch Gear Learning   Cutch


## 78,000 MILES (130,000 KILOMETERS) OR 78 MONTHS





## 84,000 MILES (140,000 KILOMETERS) OR 84 MONTHS





1 If the performance optimization services at 36 months (free of charge) including this inspection have not been finished yet, this inspection is not necessary.

<>: Performed based on the number of service months only.

# GT-R Performance Optimization Service Log Record of Service Details

otal Toe-in			Transmission Settings				
		in/mm	Measured Values				
Camber-	LH	Deg/min (Dec/Deg)	Engine Speed		rpm	Address	
Camper	RH	Deg/min (Dec/Deg)	Trans. Oil Temp.		'F ('C)	Hadross	
Caster	LH	Deg/min (Dec/Deg)		-1-			
Caster	RH	Deg/min (Dec/Deg)					
otal Toe-In		in/mm					
-	LH	Deg/min (Dec/Deg)					
Camber	RH	Deg/min (Dec/Deg)	Status of Transmission S	etting			
				Previous L	earned Value		
			Clutch Gear Learning	Current Les	arned Value	Mileage	Miles/km
d Values			'Circle the settings as de	ivered to the C	ustomer	Dealer Name	
otal Toe-in	-	in/mm	101101W100000	110000111100-14	30111308		
Cambat	LH	Deg/min (Dec/Deg)	Clutch A touch point sett	ing value			
Carriogi	RH	Deg/min (Dec/Deg)	Clutch B touch point sett	Clutch B touch point setting value			
Caster	CR	Deg/min (Dec/Deg)	Adjust clutch A capacity :	setting value			
30374	RH	Deg/min (Dec/Deg)	Adjust clutch B capacity	setting value			
otal Toe-In	-	in/mm				Technician Name	
Camber	LH	Deg/min (Dec/Deg)					
Camper	RH	Deg/min (Dec/Deg)					
0	Camber  I Values  otal Toe-in  Camber  Caster  otal Toe-in	total Toe-In  Camber RH  I Values  otal Toe-In  Camber RH  Camber RH  Caster RH  RH  Caster CH  RH	RH   Deg/min (Dec/Deg)     Stal Toe-in   In/mm     Camber	Deg/min (Dec/Deg)   Deg/min (Dec/Deg)     Deg/min (Dec/Deg)	Deg/min (Dec/Deg)	Deg/min (Dec/Deg)   In/mm   Deg/min (Dec/Deg)   Status of Transmission Setting     Values	Deg/min (Dec/Deg)   Deg/min (Dec/Deg)     Deg/min (Dec/Deg)     Deg/min (Dec/Deg)     Deg/min (Dec/Deg)     Deg/min (Dec/Deg)     Ualues

## 90,000 MILES (150,000 KILOMETERS) OR 90 MONTHS





1 Replace spark plug when the spark plug gap reaches 0.9 mm (0.035 in) or more, even if within specified periodic replacement mileage

[]: Performed based on the mileage only.

> Performed based on the number of service months only.

# 96,000 MILES (160,000 KILOMETERS) OR 96 MONTHS

SCHEDULE 1	MAINTENANCE
Replace engine oil and filte Replace engine coolant Replace in-cabin microfilte <replace brake="" fluid=""> Inspect the following:</replace>	
<pre><engine abnormal="" and="" sound="" startability=""> <driving accelerating="" and="" at="" low="" performance="" speed=""> <throttle chamber="" deposits=""> Axle &amp; suspension parts Brake lines &amp; cables Brake pads &amp; rotors Transmission oil Differential oil (front &amp; rear) Drive shaft boots Engine drive belts</throttle></driving></engine></pre>	Transmission settings' Measurement and adjustment of wheel alignment' Exhaust system Front suspension ball joints Fuel lines/connections Fuel tank vapor vent system hoses Propeller shaft Steering gear and linkage Steering linkage ball joints

SCHEDULE 2	MAINTENANCE
□ Replace engine oil and filte     □ Replace engine coolant     □ Replace in-cabin microfilte     □ <replace brake="" fluid="">     □ inspect the following:</replace>	
<engine abnormal="" and="" sound="" startability=""> <driving accelerating="" and="" at="" low="" performance="" speed=""> <throttle chamber="" deposits=""> Axle &amp; suspension parts Brake lines &amp; cables Brake pads &amp; rotors Transmission oll Differential oil (front &amp; rear) Drive shaft boots Engine drive belts Transmission settlings!</throttle></driving></engine>	Measurement and adjustment of wheel alignment! Exhaust system Front suspension ball joints Fuel lines/connections Fuel tank vapor vent system hoses Propeller shaft Steering gear and linkage Steering linkage ball joints

If the performance optimization services at 36 months (free of charge) including this inspection have not been finished yet, this inspection is not necessary.

>: Performed based on the number of service months only.

# GT-R Performance Optimization Service Log Record of Service Details

	-	7	Transmission Settings				
Total Toe-In		in/mm	Measured Values				
Camber	LH	Deg/min (Dec/Deg)	Engine Speed				
ACCOUNT DUTY			Trans. Oil Temp.		"F ("C)		
Caster							
7.000	RH	Deg/min (Dec/Deg)					
Total Toe-In		in/mm					
Camber	LH Deg/min (Dec/Deg)						
Contract	RH	Deg/min (Dec/Deg)	Status of Transmission S	etting			
				Previous L	earned Value		
DATE OF THE PARTY OF			Clutch Gear Learning	Current Le	arned Value	Mileage	Miles/km
d Values			'Circle the settings as de	livered to the C	ustomer	Dealer Name	
Total Toe-in		in/mm	ACT LE INTERPORTE DE LE	TO DESTRUCT	3011130		
Combas LH De		Deg/min (Dec/Deg)	Clutch A touch point setting value				
carride	RH	Deg/min (Dec/Deg)	Clutch B touch point setting value				
Castor	CR	Deg/min (Dec/Deg)	Adjust clutch A capacity	Adjust clutch A capacity setting value			
Coate	RH	Deg/min (Dec/Deg)	Adjust clutch B capacity				
Total Toe-In	-	in/mm				Technician Name	
en-to-	LH	Deg/min (Dec/Deg)					
Te	Caster otal Toe-In Camber d Values otal Toe-In Camber Caster otal Toe-In	Caster RH Camber RH Camber RH Camber RH Camber RH Camber RH Caster RH	RH	Caster	Caster RH Deg/min (Dec/Deg)  IH Deg/min (Dec/Deg)  Otal Toe-In  Camber LH Deg/min (Dec/Deg)  RH Deg/min (Dec/Deg)  In/mm  Camber LH Deg/min (Dec/Deg)  Otal Toe-In  Camber LH Deg/min (Dec/Deg)  Camber RH Deg/min (Dec/Deg)  Camber LH Deg/min (Dec/Deg)  Camber RH Deg/min (Dec/Deg)  Camber RH Deg/min (Dec/Deg)  Camber LH Deg/min (Dec/Deg)  RH Deg/min (Dec/Deg)  Caster LH Deg/min (Dec/Deg)  Adjust clutch A capacity setting value on the Company of the Compan	Caster	Caster

#### MEMO

# 10 Technical and consumer information

Capacities and	Installing front license plate	10-1
recommended fluids/lubricants 10-2	Vehicle loading information	10-1
Fuel information 10-4	Terms	10-1
Engine oil and oil filter recommendation 10-6	Vehicle load capacity	10-1
Air conditioning system refrigerant and	Loading tips	10-1
oil recommendations 10-7	Measurement of weights	10-1
Specifications 10-9	Towing a trailer	10-1
Engine 10-9	Flat towing	
Wheels and tires 10-10	Uniform tire quality grading	10-2
Dimensions 10-11	Treadwear	10-2
When traveling or registering in	Traction AA, A, B and C	10-2
another country 10-12	Temperature A, B and C	10-2
Vehicle identification 10-12	Emission control system warranty	
Vehicle Identification Number (VIN) plate 10-12	Reporting safety defects	
Vehicle identification number	Readiness for Inspection/Maintenance (I/M)	
(chassis number)	test (US only)	10-2
Engine serial number 10-13	Event Data Recorders (EDR)	10-2
F.M.V.S.S./C.M.V.S.S. certification label 10-13	Vehicle status data recorder (VSDR)	10-2
Emission control information label 10-13	Handling of data	10-2
Tire and loading information label 10-14	Owner's Manual/Service Manual	
Air conditioner specification label 10-14	order information	10-2

### **CAPACITIES AND RECOMMENDED FLUIDS/LUBRICANTS**

The following are approximate capacities. The actual refill capacities may be a little different. When refilling, follow the procedure instructed in the "8. Do-it-yourself" section to determine the proper refill capacity.

			Cap	acity (approxim			
	Fluid type		Metric Measure	US Measure	Imperial Measure	Recommended Fluids/Lubricants	
Fuel			73.8 L	19-1/2 gal	16-1/4 gal	· ( 🏣 "Fuel information" page 10-4)	
Engine oil*  Drain and refill  *For additional infor- mation, see  **Changing en- gine oil and filter*		With oil filter change	5.0 L	5-1/4 qt	4-3/8 qt	Mobil 1 (0W-40) or equivalent     Mobil 1 (0W-40) (100% synthetic) is the factory fill oil. The VR38 engine with its plasma-sprayed bores was developed using this oil. NISSAN cannot ensure proper engine operation and durability if other 0W-40 non-equivalent synthetic oil is used. If Mobil 1 (0W-40) or equivalent is not available,	
page 8-10.		change  4.5 L 4-5/4 qt 4 qt used; howeve additional inf ( ) "Engire" ( ) The recomme L) below the additional inf		Mobil 1 (10W-40) (100% synthetic) or equivalent may be used; however, some performance loss may be noticed. For additional information, see the following section.  ( ) "Engine oil and oil filter recommendation" page 10-6)  The recommended oil capacity level is 0.39 in (10 mm) (0.5 L) below the H mark on the engine oil dipstick. For additional information, see the following section.  ( ) "Engine oil" page 8-9)			
Engine coolant	For NISMO models	With reservoir	11.7 L	12-3/8 qt	10-1/4 qt	Genuine NISSAN Long Life Antifreeze/Coolant (blue) or	
		Reservoir	1.8 L	1-7/8 qt	1-5/8 qt	equivalent  For additional information, see the following section.	
	Except for NISMO models	With reservoir	11.3 L	12 qt	10 qt	( 下層 "Engine cooling system" page 8-6)	
		Reservoir	1.4 L	1-1/2 qt	1-1/4 qt	3 ,	
Transmission oil (Drain and refill)		9.4 L	10 qt	8-1/4 qt	Genuine NISSAN Transmission Oil R35 Special or equivalent     The use of fluids and lubricants other than the specified may cause vehicle malfunctions and result in non-warranty vehicle repairs.     All of the fluid cannot be removed when servicing the transmission. The actual refill amount may be less than shown.		
Differential oil (Drain and refill)		Front	0.65 L	1-3/8 pt	1-1/8 pt	Genuine NISSAN Differential Oil R35 COMPETITION type 2189E or equivalent	
		Rear	1.35 L	2-7/8 pt	2-3/8 pt	<ul> <li>The use of fluids and lubricants other than the specified may cause vehicle malfunctions and result in non-warranty vehicle repairs.</li> </ul>	
Power steering fluid	(PSF)			oper oil level acc the "8. Do-it-you		<ul> <li>Genuine NISSAN PSF II or equivalent</li> <li>DEXRON<sup>TM</sup> VI type ATF or equivalent may also be used.</li> </ul>	

	Cap	acity (approxim	ate)		
Fluid type	Metric Measure	US Measure	Imperial Measure	Recommended Fluids/Lubricants	
Brake fluid	Refill to the proper oil level according to the instructions in the "8. Do-it-yourself" section.			<ul> <li>Genuine NISSAN Brake Fluid R35 Special II or equivalent</li> <li>Genuine NISSAN Brake Fluid R35 Special II is the factory fill brake fluid. The Vehicle Dynamic Control (VDC) unit and other related parts were specially designed for this brake fluid and NISSAN cannot ensure the best performance and proper operation of the vehicle if other non-equivalent brake fluid is used.</li> </ul>	
Multi-purpose grease	_	_	_	· NLGI No. 2 (Lithium soap base)	
Air conditioning system refrigerant	_	_	-	HFO-1234yf (R-1234yf)     For additional information, see the following section. (	
Air conditioning system oil	_	_	_	· NISSAN A/C System Oil VC100YF (PAG) or equivalent	
Window washer fluid	_	_	_	<ul> <li>Genuine NISSAN Windshield Washer Concentrate Cleaner &amp; Antifreeze or equivalent</li> </ul>	

#### **FUEL INFORMATION**

#### VR38 engine

Use unleaded premium gasoline with an octane rating of at least 93 AKI (Anti-Knock Index) number (Research octane number 98) to maximize vehicle performance.

If the premium gasoline specified above is not available, you may use unleaded premium gasoline with an octane rating of at least 91 AKI number (Research octane number 96), but you may notice a decrease in performance.

Do not use gasoline with an octane rating lower than 91 AKI (Research octane number 96).

#### NOTICE

- Using a fuel other than that specified could adversely affect the emission control system, and may also affect warranty coverage.
- Under no circumstances should a leaded gasoline be used, because this will damage the three-way catalyst.
- Do not use E-15 or E-85 fuel in

your vehicle. Your vehicle is not designed to run on E-15 or E-85 fuel. Using E-15 or E-85 fuel in a vehicle not specifically designed for E-15 or E-85 fuel can adversely affect the emission control devices and systems of the vehicle. Damage caused by such fuel is not covered by the NISSAN new vehicle limited warranty.

- Do not use fuel that contains the octane booster methylcyclopentadienyl manganese tricarbonyl (MMT). Using fuel containing MMT may adversely affect vehicle performance and vehicle emissions. Not all fuel dispensers are labeled to indicate MMT content, so you may have to consult your gasoline retailer for more details. Note that Federal and California laws prohibit the use of MMT in reformulated gasoline.
- U.S. government regulations require ethanol dispensing pumps to be identified by a small, square, orange and black label with the common abbreviation or the appropriate percentage for that region.
- NISSAN recommends using fuels

that contain no alcohol. However, fuels containing up to 10% alcohol may be used, if necessary. To avoid serious engine damage due to increased cylinder temperatures, do not use fuels that contain more alcohol than indicated in this section. Also, do not use fuel additives, fuel stabilizers or fuel deicers that contain alcohol.

## **Gasoline specifications**

NISSAN recommends using gasoline that meets the World-Wide Fuel Charter (WWFC) specifications where it is available. Many of the automobile manufacturers developed this specification to improve emission system and vehicle performance. Ask your service station manager if the gasoline meets the World-Wide Fuel Charter (WWFC) specifications.

### Reformulated gasoline

Some fuel suppliers are now producing reformulated gasolines. These gasolines are specially designed to reduce vehicle emissions. NISSAN supports efforts towards cleaner air and suggests that you use reformulated gasoline when avail-

able.

### **Gasoline containing oxygenates**

Some fuel suppliers sell gasoline containing oxygenates such as ethanol, MTBE and methanol with or without advertising their presence. NISSAN does not recommend the use of fuels of which the oxygenate content and the fuel compatibility for your NISSAN cannot be readily determined. If in doubt, ask your service station manager.

If you use oxygenate-blend gasoline, please take the following precautions as the usage of such fuels may cause vehicle performance problems and/or fuel system damage.

- The fuel should be unleaded and have an octane rating no lower than that recommended for unleaded gasoline.
- If an oxygenate-blend, excepting a methanol blend, is used, it should contain no more than 10% oxygenate. (MTBE may, however, be added up to 15%.)
- E-15 fuel contains more than 10% oxygenate. E-15 fuel will adversely affect the emission control devices and systems of the vehicle and should not be used. Damage caused

by such fuel is not covered under the NISSAN new vehicle limited warranty.

 If a methanol blend is used, it should contain no more than 5% methanol (methyl alcohol and wood alcohol). It should also contain a suitable amount of appropriate cosolvents and corrosion inhibitors. If not properly formulated with the appropriate cosolvents and corrosion inhibitors, such methanol blends may cause fuel system damage and/or vehicle performance malfunctions. At this time, sufficient data is not available to ensure that all methanol blends are suitable for use in NISSAN vehicles.

If any undesirable driveability problems such as engine stalling or hard hot starting are experienced after using oxygenate-blend fuels, immediately change to a non-oxygenate fuel or a fuel with a low blend of MTBF

### **NOTICE**

Take care not to spill gasoline during refueling. Gasoline containing oxygenates can cause paint damage.

#### E-15 fuel

E-15 fuel is a mixture of approximately 15% fuel ethanol and 85% unleaded gasoline. E-15 can only be used in vehicles designed to run on E-15 fuel. Do not use E-15 in your vehicle. U.S. government regulations require fuel ethanol dispensing pumps to be identified with small, square, orange and black label with the common abbreviation or the appropriate percentage for that region.

#### E-85 fuel

E-85 fuel is a mixture of approximately 85% fuel ethanol and 15% unleaded gasoline. E-85 can only be used in a Flexible Fuel Vehicle (FFV). Do not use E-85 fuel in your vehicle. U.S. government regulations require fuel ethanol dispensing pumps to be identified by a small, square, orange and black label with the common abbreviation or the appropriate percentage for that region.

## **Fuel containing MMT**

MMT, or methylcyclopentadienyl manganese tricarbonyl, is an octane boosting additive. NISSAN does not recommend the use of fuel containing MMT. Such fuel may adversely affect vehicle performance, including the emissions control system. Note that while some fuel pumps label MMT content, not all do, so you may have to consult your gasoline retailer for more details.

#### Aftermarket fuel additives

#### NOTICE

NISSAN does not recommend the use of any aftermarket fuel additives (Example: fuel injector cleaner, intake valve deposit removers, etc.) which are sold commercially. Many of these additives intended for gum, varnish or deposit removal may contain active solvent or similar ingredients that can be harmful to the fuel system and engine.

## Octane rating tips

Using unleaded gasoline with an octane rating lower than recommended above can cause persistent, heavy spark knock. (Spark knock is a metallic rapping noise.) If severe, this can lead to engine damage. If you detect a persistent heavy spark knock even when using gasoline of the stated octane rating, or if you hear steady spark knock while holding a steady speed on level

roads, it is recommended you have a GT-R certified NISSAN dealer correct the condition. Failure to correct the condition is misuse of the vehicle, for which NISSAN is not responsible.

Incorrect ignition timing will result in knocking, after-run or overheating. This in turn may cause excessive fuel consumption or damage to the engine. If any of the above symptoms are encountered, it is recommended you have your vehicle checked at a GT-R certified NISSAN dealer or other competent service facility.

However, now and then you may notice light spark knock for a short time while accelerating or driving up hills. This is no cause for concern, because you get the greatest fuel benefit when there is light spark knock for a short time under heavy engine load.

## ENGINE OIL AND OIL FILTER RE-COMMENDATION

### Selecting the correct oil

It is essential to choose the correct grade, quality, and viscosity engine oil to ensure satisfactory engine life and performance. ( \*\*Tapacities\*\* and recommended fluids/lubricants\*\* page 10-2)

Mobil 1 (0W-40) (100% synthetic) is the

factory fill oil. The VR38 engine with its plasma-sprayed bores was developed using this oil. NISSAN cannot ensure proper engine operation and durability if other OW-40 non-equivalent synthetic oil is used. If Mobil 1 (OW-40) or equivalent is not available, Mobil 1 (10W-40) (100% synthetic) or equivalent may be used; however, some performance loss may be noticed.

#### **NOTICE**

Using an engine oil other than that specified could adversely affect the engine. See the 2021 NISSAN GT-R Warranty Information Booklet for details and exclusions.

#### Oil additives

NISSAN does not recommend the use of oil additives. The use of an oil additive is not necessary when the proper oil type is used and maintenance intervals are followed.

Oil which may contain foreign matter or has been previously used should not be used.

### Oil viscosity

The engine oil viscosity or thickness changes with temperature. Because of this, it is important that the engine oil viscosity be selected based on the temperatures at which the vehicle will be operated before the next oil change. Choosing an oil viscosity other than that recommended could cause serious engine damage.

### Selecting the correct oil filter

Your new vehicle is equipped with a highquality genuine NISSAN oil filter. NISSAN recommends to use the genuine NISSAN oil filter for the reason described in change intervals.

### Change intervals

The oil and oil filter change intervals for your engine are based on the use of the specified quality oils and filters. Oil and filter other than the specified quality, or oil and filter change intervals longer than recommended could reduce engine life. Damage to engines caused by improper maintenance or use of incorrect oil and filter quality and/or viscosity is not covered by the NISSAN new vehicle limited warranties.

Your engine was filled with a high quality

engine oil when it was built. You do not have to change the oil before the first recommended change interval. Oil and filter change intervals depend upon how you use your vehicle. Operation under the following conditions may require more frequent oil and filter changes.

- repeated short distance driving at cold outside temperatures
- · driving in dusty conditions
- extensive idling
- stop and go "rush hour" traffic Refer to the "9. Maintenance and schedules" section of this manual for the maintenance schedule.

## AIR CONDITIONING SYSTEM RE-FRIGERANT AND OIL RECOMMEN-DATIONS

The air conditioner system in your NISSAN vehicle must be charged with the refrigerant HFO-1234yf (R-1234yf) and NISSAN A/C System Oil VC100YF (PAG) or the exact equivalents.

## **A** CAUTION

The use of any other refrigerant or oil will cause severe damage to the air conditioning system and will require the replacement of all air conditioner system components.


The refrigerant HFO-1234vf (R-1234vf) in your NISSAN vehicle does not harm the earth's ozone layer. Although this refrigerant does not affect the earth's atmosphere, certain government regulations require the recovery and recycling of any refrigerant during automotive air conditioner system service. Air conditioner system should only be serviced by trained and certified technicians to ensure proper and safe operation (SAE J2845). Your GT-R certified NISSAN dealer has the trained technicians and equipment needed to recover and recycle your air conditioner system refrigerant. Only new and SAEJ2842 certified evaporator(s) shall be used as replacement parts.

A damaged or leaking air conditioning evaporator shall never be repaired or replaced with one removed from a used or salvaged vehicle. To replace a damaged or leaking evaporator, use only new and SAE J2842 certified evaporator (s). It is recommended that you visit a GT-R certified NISSAN dealer when servicing your air conditioner system.

#### **SPECIFICATIONS**

#### **ENGINE**

Model		VR38
Type		Gasoline, 4-cycle
Cylinder arrangement		6-cylinder, V-slanted at 60°
Bore × Stroke	in (mm)	3.760 × 3.480 (95.5 × 88.4)
Displacement	cu in (cm³)	231.83 (3,799)
Firing order		1-2-3-4-5-6
Idle speed	rpm	No adjustment is necessary.
Ignition timing (B.T.D.C.)	degree/rpm	No adjustment is necessary.
Spark plug	Standard	DILKAR8A8
Spark plug gap (Normal)	in (mm)	0.031 (0.8)
Camshaft operation		Timing chain



This spark ignition system complies with the Canadian standard ICES-002.

#### WHEELS AND TIRES

#### Tire

Туре	Size		Pressure PSI (kPa) [Cold]
Summer	Front:	255/40ZRF20 (97Y)	30 (210)*1 32 (220)*2
	Rear:	285/35ZRF20 (100Y)	29 (200)
A.II	Front:	255/40RF20 97W	32 (220)
All-season	Rear:	285/35RF20 100W	30 (210)

<sup>\*1:</sup> Except for NISMO and Track edition engineered by nismo models

Make sure to use the tires for GT-R. See the 2021 Warranty Information Booklet for the applicable exclusions.

<sup>\*2:</sup> NISMO and Track edition engineered by nismo models

#### Road wheel

Type	Size		Offset in (mm)
Aluminum	Front:	20 × 9-1/2J*1 20 × 10J*2	1.77 (45)*1 1.61 (41)*2
	Rear:	20 × 10-1/2J	0.98 (25)

<sup>\*1:</sup> Except for NISMO and Track edition engineered by nismo models

Make sure to use the road wheels for GT-R. See the 2021 Warranty Information Booklet for the applicable exclusions.

#### **DIMENSIONS**

		in (mm)
	185.4 (4,710)*1 184.6 (4,690)*2	
Overall width	74.6 (1,895)	
Overall height	53.9 (1,370)	
	62.6 (1,590)*3 63.0 (1,600)*4	
Rear tread	63.0 (1,600)	
Wheelbase	109.4 (2,780)	•

<sup>\*1:</sup> Except for NISMO models

<sup>\*2:</sup> NISMO and Track edition engineered by nismo models

<sup>\*2:</sup> NISMO models

<sup>\*3:</sup> Except for NISMO models and Track edition engineered by nismo models

<sup>\*4:</sup> NISMO models and Track edition engineered by nismo models

#### WHEN TRAVELING OR REGISTERING IN ANOTHER COUNTRY

If you plan to travel in another country, you should first find out if the fuel available is suitable for your vehicle's engine.


Using fuel with too low an octane rating may cause engine damage. All gasoline vehicles must be operated with unleaded gasoline. Therefore, avoid taking your vehicle to areas where appropriate fuel is not available.

When transferring the registration of your vehicle to another country, state, province or district, it may be necessary to modify the vehicle to meet local laws and regulations.

The laws and regulations for motor vehicle emission control and safety standards vary according to the country, state, province or district; therefore, vehicle specifications may differ.


When any vehicle is to be taken into another country, state, province or district and registered, its modifications, transportation, and registration are the responsibility of the user. NISSAN is not responsible for any inconvenience that may result.

#### **VEHICLE IDENTIFICATION**




## **VEHICLE IDENTIFICATION NUMBER** (VIN) PLATE

The vehicle identification number plate is attached as shown. This number is the identification for your vehicle and is used in the vehicle registration.




## VEHICLE IDENTIFICATION NUMBER (chassis number)

The number is stamped as shown in the engine compartment.




**ENGINE SERIAL NUMBER** 

The number is stamped on the engine as shown.



F.M.V.S.S./C.M.V.S.S. CERTIFICA-**TION LABEL** 


The Federal/Canadian Motor Vehicle Safety Standards (F.M.V.S.S./C.M.V.S.S.) certification label is affixed as shown. This label contains valuable vehicle information, such as: Gross Vehicle Weight Ratings (GVWR), Gross Axle Weight Rating (GAWR), month and year of manufacture, Vehicle Identification Number (VIN), etc. Review it carefully.



**EMISSION CONTROL INFORMA-TION LABEL** 

The emission control information label is attached as shown.





## TIRE AND LOADING INFORMATION LABEL

The cold tire pressure is shown on the Tire and Loading Information label affixed to the door end as illustrated.

## **AIR CONDITIONER SPECIFICATION LABEL**

The air conditioner specification label is attached as shown.

Air conditioner specification label symbols:			
Symbol Name	Reference	Graphic	
Caution	ISO 7000 0434	A	
Air Conditioning System (MAC)	ISO 2575 D01	**	
MAC System Lubricant Type (PAG-POE)			
Requires Registered Technician to Service MAC System		<u></u>	
Flammable Refrigerant		*	

### INSTALLING FRONT LICENSE PLATE

#### **VEHICLE LOADING INFORMATION**





Make sure that the two POP® nuts as illustrated are enclosed in the plastic bag. They are used for front license plate installation.

To install the front license plate to your vehicle, it is recommended you contact a GT-R certified NISSAN dealer.

## **WARNING**

- It is extremely dangerous to ride in a cargo area inside the vehicle. In a collision, people riding in these areas are more likely to be seriously injured or killed.
- Do not allow people to ride in any area of vehicle that is not equipped with seats and seat belts.
- Be sure everyone in your vehicle is in a seat and using a seat belt properly.

### **TERMS**


It is important to familiarize yourself with the following terms before loading your vehicle:

Curb Weight (actual weight of vour vehicle) - vehicle weight including: standard and optional equipment, fluids or emergency tools. This weight does not include passengers and cargo.

- GVW (Gross Vehicle Weight) curb weight plus the combined weight of passengers and cargo.
- GVWR (Gross Vehicle Weight Rating) - maximum total combined weight of the unloaded vehicle. passengers, luggage, hitch, trailer tongue load and any other optional equipment. This information is located on the F.M.V.S. S./C.M.V.S.S. label.
- GAWR (Gross Axle Weight Rating) - maximum weight (load) limit specified for the front or rear axle. This information is located on the F.M.V.S.S./C.M.V.S.S. label.
- GCWR (Gross Combined Weight Rating) - The maximum total weight rating of the vehicle, passengers, cargo, and trailer.
- Vehicle Capacity Weight, Load limit, Total load capacity - maximum total weight limit specified of the load (passengers and cargo) for the vehicle. This is

the maximum combined weight of occupants and cargo that can be loaded into the vehicle. If the vehicle is used to tow a trailer, the trailer tongue weight must be included as part of the cargo load. This information is located on the Tire and Loading Information label.

Cargo capacity - permissible weight of cargo, the weight of total occupants weight subtracted from the load limit.



#### VEHICLE LOAD CAPACITY

Do not exceed the load limit of your vehicle shown as "The combined weight of occupants and cargo" on the Tire and Loading Information label. Do not exceed the number of occupants shown as "Seating Capacity" on the Tire and Loading Information label.

To get "the combined weight of occupants and cargo", add the weight of all occupants, then add the total luggage weight. Examples are shown in the illustration.

# Steps for determining correct load limit

- Locate the statement "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs" on your vehicle's placard.
- Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- 3. Subtract the combined weight

- of the driver and passengers from XXX kg or XXX lbs.
- 4. The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the XXX amount equals 1400 lbs. and there will be five 150 lb. passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs. (1400 750 (5 x 150) = 650 lbs) or 640 340 (5 x 70) = 300 kg.)
- Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in Step 4.
- If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load

capacity of your vehicle.

Before driving a loaded vehicle, confirm that you do not exceed the Gross Vehicle Weight Rating (GVWR) or the Gross Axle Weight Rating (GAWR) for your vehicle. ( \*\* "Measurement of weights" page 10-19)

Also check tires for proper inflation pressures. See the Tire and Loading Information label.

#### **LOADING TIPS**

- The GVW must not exceed GVWR or GAWR as specified on the F.M. V.S.S./C.M.V.S.S. certification label.
- Do not load the front and rear axle to the GAWR. Doing so will exceed the GVWR.

## **WARNING**

 Properly secure all cargo to help prevent it from sliding or shifting. Do not place cargo higher than the seat-

backs. In a sudden stop or collision, unsecured cargo could cause personal injury.

- Do not load your vehicle any heavier than the GVWR or the maximum front and rear GAWRs. If you do, parts of your vehicle can break, tire damage could occur, or it can change the way your vehicle handles. This could result in loss of control and cause personal injury.
- Overloading could not only shorten the life of your vehicle and the tires, but also could lead to hazardous vehicle handling and long braking distance. This may cause a premature tire malfunction, which could result in a serious accident and personal injury. Repairs due to overloading the vehicle are not covered by the vehicle's warranty. (See the 2021 **NISSAN GT-R Warranty Infor-**

# mation Booklet.)

# **MEASUREMENT OF WEIGHTS**

Secure loose items to prevent weight shifts that could affect the balance of your vehicle. When the vehicle is loaded, drive to a scale and weigh the front and the rear wheels separately to determine axle loads. Individual axle loads should not exceed either of the gross axle weight ratings (GAWR). The total of the axle loads should not exceed the gross vehicle weight rating (GVWR). These ratings are given on the vehicle certification label. If weight ratings are exceeded, move or remove items to bring all weights below the ratings.

# **TOWING A TRAILER**

Do not tow a trailer with your vehicle.

#### **FLAT TOWING**

Towing your vehicle with all four wheels on the ground is sometimes called flat towing. This method is sometimes used when towing a vehicle behind a recreational vehicle, such as a motor home.

DO NOT tow the GT-R with all four wheels on the ground (flat towing). Doing so WILL DAMAGE internal transmission parts. Tow the GT-R with all four wheels off the ground. ( ) "Towing your vehicle" page 6-9)

## UNIFORM TIRE QUALITY GRADING

DOT (Department Of Transportation) Quality Grades: All passenger car tires must conform to federal safety requirements in addition to these grades.

Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width. For example:

Treadwear 200 Traction AA Temperature A

#### **TREADWEAR**

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course. For example, a tire graded 150 would wear one and one-half (1 1/2) times as well on the government course as a tire graded 100. The relative performance of tires depends upon actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

## TRACTION AA, A, B AND C

The traction grades, from highest to lowest, are AA, A, B and C. Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.

# **WARNING**

The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hvdroplaning, or peak traction characteristics.

#### TEMPERATURE A. B AND C

The temperature grades A (the highest), B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

# **WARNING**

The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, under-inflation, or excessive loading, either separately or in combination, can cause heat build-up and possible tire failure.

# **EMISSION CONTROL SYSTEM WARRANTY**

Your NISSAN is covered by specific emission warranties:

For the United States, see the 2021 NISSAN GT-R Warranty Information Booklet.

For Canada, see the Warranty and Roadside Assistance Information Booklet.

If you did not receive a Warranty Information Booklet (Warranty and Roadside Assistance Information (Canada only)), or it has become lost, you may obtain a replacement by writing to:

- NISSAN Division
   NISSAN North America, Inc.
   Consumer Affairs Department
   P.O. Box 685003
   Franklin, TN 37068-5003
- NISSAN Canada Inc.
   5290 Orbitor Drive
   Mississauga, Ontario,
   14W 475

## **REPORTING SAFETY DEFECTS**

For USA

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying NISSAN.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or NISSAN.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to http://www.safercar.gov; or write to: Administrator, NHTSA, 400 Seventh Street, SW., Washington, D.C. 20590. You can also obtain other information about motor vehicle safety from http://www.safercar.gov.

Technical and consumer information 10-21

You may notify NISSAN by contacting our Consumer Affairs Department, toll-free, at 1-866-668-1GTR (1-866-668-1487).

## For Canada

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform Transport Canada in addition to notifying NISSAN

If Transport Canada receives complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may request that NISSAN conduct a recall campaign. However, Transport Canada cannot become involved in individual problems between you, your dealer, or NISSAN.

You may contact Transport Canada's Defect Investigations and Recalls Division toll free at 1-800-333-0510. You may also report safety defects online at:

https://wwwapps.tc.gc.ca/Saf-Sec-

Sur/7/PCDB-BDPP/fc-cp.aspx?lang=eng (English speakers) or

https://wwwapps.tc.gc.ca/Saf-Sec-Sur/7/PCDB-BDPP/fc-cp.aspx? lang=fra (French speakers).

Additional information concerning motor vehicle safety may be obtained from Transport Canada's Road Safety Information Centre at 1-800-333-0371 or online at www. tc.gc.ca/roadsafety (English speakers) or www.tc.gc.ca/securiteroutiere (French speakers).

To notify NISSAN of any safety concerns please contact our Consumer Information Centre toll free at 1-800-387-0122.

# READINESS FOR INSPECTION/ **MAINTENANCE (I/M) TEST (US only)**

A vehicle equipped with All-Wheel Drive (AWD) should never be tested using a two wheel dynamometer (such as the dynamometers used by some states for emissions testing), or similar equipment. Make sure you inform test facility personnel that your vehicle is equipped with AWD before it is placed on a dynamometer. Using the wrong test equipment may result in transmission damage or unexpected vehicle movement which could result in serious vehicle damage or personal injury.

Due to legal requirements in some states/ areas, your vehicle may be required to be in what is called the "ready condition" for an Inspection/Maintenance (I/M) test of the emission control system.

The vehicle is set to the "ready condition" when it is driven through certain driving patterns. Usually, the "ready condition" can be obtained by ordinary usage of the vehicle.

If a powertrain system component is repaired or the battery is disconnected, the vehicle may be reset to a "not ready condition". Before taking the I/M test, check the vehicle's inspection/maintenance test readiness condition. Push the ignition switch to the ON position without starting the engine. If the Malfunction

Indicator Light (MIL) comes on steady for 20 seconds and then blinks for 10 seconds, the I/M test condition is "not ready". If the MIL does not blink after 20 seconds, the I/M test condition is "ready".

It is recommended you contact a GT-R certified NISSAN dealer to set "ready condition" or to prepare the vehicle for testing.

# **EVENT DATA RECORDERS (EDR)**

This vehicle is equipped with an Event Data Recorder (EDR). The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less. The EDR in this vehicle is designed to record such data as:

- How various systems in vour vehicle were operating;
- Whether or not the driver and passenger safety belts were buckled/fastened:
- How far (if at all) the driver was depressing the accelerator and/or brake pedal; and.
- How fast the vehicle was traveling.
- Sounds are not recorded.

These data can help provide a better understanding of the circumstances in which crashes and injuries occur. NOTE: EDR data are recorded by your vehicle only if a nontrivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data (e.g. name, gender, age and crash

location) are recorded. However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acguired during a crash investigation.

To read data recorded by an EDR, special equipment is required and access to the vehicle or the FDR is needed. In addition to the vehicle manufacturer and NISSAN dealer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR. EDR data will only be accessed with the consent of the vehicle owner or lessee or as otherwise required or permitted by law.

# **VEHICLE STATUS DATA RECORDER (VSDR)**

The Vehicle Status Data Recorder (VSDR) is different from the Event Data Recorder described in "Event Data Recorder" in this section. The VSDR is not a crash-activated device, but it records and accumulates vehicle data while driving.

# Examples are:

- Vehicle operating information such as the wheel speeds of the front and rear wheels
- Engine control information such as the engine speed and boost pressure

The VSDR always records and stores vehicle operating data between periodic inspections, which can assist and be used for servicing, diagnosing and performing warranty repairs.

The VSDR does not record sounds, conversations or images.

To read data recorded by the VSDR, special equipment is required and access to the vehicle or the VSDR is needed.

#### HANDLING OF DATA

NISSAN and third parties affiliated with NISSAN can acquire and use the data recorded by the VSDR in order to confirm the part replacement history to improve the quality of NISSAN vehicles.

With the exception of the following cases,

neither NISSAN nor third parties affiliated with NISSAN, shall disclose or offer the acquired data to other non-affiliated third parties.

- With the agreement of the vehicle owner
- When legally required to, such as when ordered by a court of law, etc.
- When offering processed data so that neither the vehicle owner nor the vehicle is identified, to research centers for statistical analysis, etc.

# OWNER'S MANUAL/SERVICE MANUAL ORDER INFORMATION

Genuine NISSAN Service Manuals for this model year and prior can be purchased. A genuine NISSAN Service Manual is the best source of service and repair information for your vehicle. This manual is the same one used by the factory-trained technicians working at NISSAN dealer. Genuine NISSAN Owner's Manuals can also be purchased.

#### For USA:

For current pricing and availability of genuine NISSAN Service Manuals,

www.nissan-techinfo.com

For current pricing and availability of genuine **NISSAN Owner's Manuals**, contact:

1-800-247-5321

#### For Canada:

To purchase a copy of a genuine NISSAN Service Manual or Owner's Manual for this model year and prior, please contact a GT-R certified NISSAN dealer. For the phone number and location of a GT-R certified NISSAN dealer in your area call the NISSAN Information Center at 1-800-387-0122 and a bilingual NISSAN representative will assist you.

# 11 Index

Α
Active noise cancellation 5-60
Active sound enhancement 5-60
Additional maintenance items GTR-13
Maintenance record list 9-8
Air cleaner 8-17
Air conditioner 4-11
Air conditioner operation 4-10
Air conditioner specification label 10-14
Air conditioning system refrigerant
and oil recommendations 10-7
Air fresheners 7-6
All-season tires GTR-11
All-Wheel Drive 5-42
All-Wheel Drive driving
safety precautions 5-9
Anti-freeze 5-57
Anti-lock Braking System 5-53
Anti-lock Braking System warning 2-40
Audible reminders 2-34
Automatic
Automatic door lock system 3-5
Average fuel consumption and speed 2-17
Avoiding body damage GTR-12
Avoiding collision and rollover 5-7
AWD clutch high temperature warning 2-40
AWD system characteristics 5-44
AWD system warning 2-41
AWD warning light 5-42

В	
Battery 5-57,	8-13
Intelligent Key battery discharge	5-12
Intelligent Key battery	
discharge indicator	2-48
Intelligent Key battery replacement	8-25
Before starting the engine	5-13
Body repair G7	ΓR-12
Booster seats	1-30
Brake	
Brake assist	5-53
Brake fluid GTR-5,	8-11
Brake pad wear warning	8-19
Brake system	5-52
Brakes	8-19
High performance brake system	8-19
Low brake fluid warning	2-39
Parking brake	
Parking brake break-in	5-52
Parking brake release warning	2-39
Replacing the brake pads	
Self-adjusting brakes	
Brake disc rotor	
Brake dust G7	ΓR-29
Brake pad Gi	
Brake pad and disc rotor (	
Brake pad break-in procedure G	
Brake system information G7	
Brakes GTR-19, GT	
Braking precautions	5-52

reak-in scheduleGTR-10, 5-40
C
Capacities and
ecommended fluids/lubricants 10-2
Car phone or CB radio 4-15
Changing
Changing engine coolant 8-8
Changing engine oil and filter 8-10
Changing wheels and tires 8-38
Checking
Checking engine coolant level 8-8
Checking engine oil level 8-9
Checking lights 2-26
Checking the tire pressure 8-33
Child restraints 1-15
Child safety 1-13
Chrome parts 7-4
Cleaning 8-18
Cleaning exterior 7-2
Cleaning interior 7-5
Closing the fuel-filler door 3-25
Closing the hood 3-19
Coat hooks 2-66
Cockpit 2-4
Cold weather driving 5-57
Console box 2-66
Cool down GTR-14
Coolant
Changing engine coolant 8-8

Checking engine coolant level 8-8	Brake system (NCCB (NISSAN	Engine compartment check
Draining of coolant water 5-57	Carbon Ceramic Brake)) GTR-29, 8-20	locations 8-4
Engine coolant temperature gauge 2-8	Cold weather driving 5-57	Engine coolant temperature gauge 2-8
Coolant level and mixture ratio GTR-15	Drinking alcohol/drugs and driving 5-9	Engine cooling system 8-6
Corrosion protection 7-9	Driving on snow or ice 5-57	Engine oil GTR-4, 8-9
Cracks on brake pad GTR-28	Driving the vehicle 5-15	Engine oil and oil filter
Cracks on the disc rotors GTR-28	Driving tips 5-21	recommendation 10-6
Cruise control 2-17, 5-35	Precautions when starting	Engine oil level display 2-13
Cruise control operations 5-37	and driving 5-3	Engine oil low pressure warning 2-37
Cruise control system warning 2-43	Driving after replacing tires GTR-12	Engine serial number 10-13
Cup holders 2-63	Dry carbon fiber parts GTR-8, GTR-30, 7-5	Engine start operation indicator 2-46
Current fuel consumption 2-16	Dual clutch transmission GTR-30, 5-15	Engine system warning 2-37
		Operating range for engine start 5-10
D	E	Starting the engine 5-14
S. C.	5 C. II (COC) D. II	Engine and powertrain GTR-16, GTR-25
Determining the proper	E-Call (SOS) Button	Engine oil maintenance GTR-4
maintenance interval	Elapsed time and trip odometer 2-18	Engine output GTR-26
Differential oil	Emergency engine shut off 5-12, 6-3	Engine output according to the
Dimensions	Emergency trunk lid release	coolant temperature
Distance to empty 2-18	Emission control information label 10-13	Engine speed is restricted GTR-26
Door pocket	Emission control system warranty 10-21	Environmental factors influence the
Door/trunk open warning 2-44	Engine	rate of corrosion 7-9
Doors	Before starting the engine 5-13	Event Data Recorders (EDR) 10-23
Draining of coolant water 5-57	Changing engine coolant 8-8	Exhaust gas 5-3
Drinking alcohol/drugs and driving 5-9	Changing engine oil and filter 8-10	Exhaust muffler and trunk carpet GTR-7
Drive belts 8-16	Checking engine coolant level 8-8	Exhaust sound control switch 2-59
Drive computer 2-16	Checking engine oil level 8-9	Exhaust sound control system 5-59
Driving	Emergency engine shut off 5-12, 6-3	Explanation of maintenance items 9-3
All-Wheel Drive driving	Engine block heater 5-58	Explanation of scheduled
safety precautions 5-9	Engine compartment 8-22	maintenance items
		Extended storage fuse switch 8-24

Exterior and interior lights	8-28	Fuel	GTR-12	GT-R special specification parts	
F		Average fuel consumption		GT-R specific information	
F		and speed	2-17	GT-R specific vehicle characteristics	GTR-25
F.M.V.S.S./C.M.V.S.S. certification labe	el 10-13	Capacities and recommended fluids/lubricants	10.2	н	
Features of each mode	5-28	Closing the fuel-filler door			
Flat tire	6-3	Current fuel consumption		Handling of data	10-24
Flat towing	10-20	Fuel gauge		Hazard warning flasher switch	6-2
Floor mats	7-6	Fuel information		Head restraints/headrests	1-5
Fluid		Fuel-filler door		Headlight	
Brake fluid G	TR-5, 8-11	Increasing fuel economy		Headlight and turn signal switch	2-53
Fluid level check	8-14	Low fuel warning		Headlight switch	2-53
Low brake fluid warning	2-39	Opening the fuel-filler door		Headlights	8-27
Low washer fluid warning	2-44	Fuel Efficient Driving Tips		Heated seats	2-58
Power steering fluid	8-11	Fuses		Heater	
Window washer fluid	8-12	Fuses	6-22	Heater and air	
Fluids GTR-	14, GTR-19	G		conditioner operation	4-10
Forward-facing child restraint		_		High altitude	GTR-26
installation using LATCH	1-24	Garage door opener		High performance brake system	8-19
Forward-facing child restraint instal	lation	HomeLink® Universal Transceiver	2-71	Hill Start Assist System	5-39
using the seat belts	1-26	Gasoline smell	GTR-25	HomeLink® Universal Transceiver	2-71
Freeing a frozen door lock	5-57	Gauge		Hood	3-18
Front seat-mounted side-impact		Engine coolant temperature gau	ge 2-8	Horn	2-58
supplemental air bag and roof-mou	ınted	Fuel gauge	2-9	How to switch the modes	5-26
curtain side-impact and rollover		Meters and gauges	2-6	How to use R mode start function	5-34
supplemental air bag systems	1-45	General maintenance	9-2, 9-3		
Front seats	1-3	Glass	7-3	I	
Front/rear tire size		Glove box	2-65		
discrepancy warning	2-41	GT-R performance		Idle speed is not steady	
		optimization services	GTR-8	If your vehicle overheats	
		GT-R special precautions	GTR-5	Ignition switch operation	
				Ignition switch positions	5-11

In-cabin microfilter	4-13	К
Increasing fuel economy	5-42	
Indicators and display	5-36	Key
Infants	1-13	Intelligent Key
Injured persons	1-9	Intelligent Key battery d
Inside mirror	3-27	Intelligent Key battery
Inspection and adjustments		discharge indicator
after driving	GTR-19	Intelligent Key battery re
Inspection and adjustments		Intelligent Key functions
before driving	GTR-14	Intelligent Key insertion
Installing front license plate	10-16	Intelligent Key removal i
Installing top tether strap	1-26, 1-30	Intelligent Key system
Instrument brightness control	2-12	Keys
Instrument panel	2-5	Locking with mechanica
Intelligent Key	3-2	No key warning
Intelligent Key battery discharge	5-12	Remote keyless entry sy
Intelligent Key battery		
discharge indicator		Land to the second seco
discriarge irrarcator	2-48	
Intelligent Key battery replacement		
9	8-25	Larger children
Intelligent Key battery replacement	8-25 3-9	Larger children Light
Intelligent Key battery replacement Intelligent Key functions	8-25 3-9 2-47	Larger children Light AWD warning light
Intelligent Key battery replacement Intelligent Key functions Intelligent Key insertion indicator Intelligent Key removal indicator Intelligent Key system	8-25 3-9 2-47 2-47 3-8	Larger children Light AWD warning light Exterior and interior ligh
Intelligent Key battery replacement Intelligent Key functions Intelligent Key insertion indicator Intelligent Key removal indicator	8-25 3-9 2-47 2-47 3-8	Larger children Light AWD warning light Exterior and interior ligh Headlight and turn sign
Intelligent Key battery replacement Intelligent Key functions Intelligent Key insertion indicator Intelligent Key removal indicator Intelligent Key system	8-25 3-9 2-47 2-47 3-8 2-70	Larger children Light AWD warning light Exterior and interior ligh Headlight and turn sign Headlight switch
Intelligent Key battery replacement Intelligent Key functions Intelligent Key insertion indicator Intelligent Key removal indicator Intelligent Key system Interior light control switch Interior lights	8-25 3-9 2-47 2-47 3-8 2-70	Larger children Light AWD warning light Exterior and interior ligh Headlight and turn sign Headlight switch
Intelligent Key battery replacement Intelligent Key functions Intelligent Key insertion indicator Intelligent Key removal indicator Intelligent Key system Interior light control switch		Larger children
Intelligent Key battery replacement Intelligent Key functions Intelligent Key insertion indicator Intelligent Key removal indicator Intelligent Key system Interior light control switch Interior lights	8-25 3-9 2-47 2-47 3-8 2-70 2-69	Larger children
Intelligent Key battery replacement Intelligent Key functions Intelligent Key insertion indicator Intelligent Key removal indicator Intelligent Key system Interior light control switch Interior lights  J  Jacking vehicle and removing whee	8-25 3-9 2-47 2-47 3-8 2-70 2-69	Larger children
Intelligent Key battery replacement Intelligent Key functions Intelligent Key insertion indicator Intelligent Key removal indicator Intelligent Key system Interior light control switch Interior lights	8-25 3-9 2-47 2-47 3-8 2-70 2-69	Larger children

K	
v	
, Intelligent Key	3-2
Intelligent Key battery dischargeIntelligent Key battery	5-12
discharge indicator	2-48
Intelligent Key battery replacement	8-25
Intelligent Key functions	3-9
Intelligent Key insertion indicator	2-47
Intelligent Key removal indicator	2-47
Intelligent Key system	3-8
Keys	3-2
Locking with mechanical key	3-6
No key warning	2-45
Remote keyless entry system	3-12
L	
L rger childrenht	1-14
rger childrenht	
rger children	5-42
rger childrenht ht AWD warning light	5-42 8-28
rger childrenht ht AWD warning light Exterior and interior lights	5-42 8-28 2-53
rger children ht AWD warning light Exterior and interior lights Headlight and turn signal switch	5-42 8-28 2-53 2-53
rger children ht AWD warning light Exterior and interior lights Headlight and turn signal switch Headlight switch	5-42 8-28 2-53 2-53 8-27
rger children ht AWD warning light Exterior and interior lights Headlight and turn signal switch Headlight switch	5-42 8-28 2-53 2-53 8-27 2-70
rger children	5-42 8-28 2-53 2-53 8-27 2-70 2-69
rger children	5-42 8-28 2-53 2-53 8-27 2-70 2-69 8-27
rger children	5-42 8-28 2-53 2-53 8-27 2-70 2-69 8-27 2-69

Warning lights, indicator lights and audible reminders	2-34 2-26 2-29 5-45
Anti-lock Braking System	5-53
Anti-lock Braking System warning	
Automatic door lock system	
Freeing a frozen door lock	
Locking with inside lock knob	
Locking with mechanical key	
Locking with power door lock switch	
Steering lock release	
malfunction indicator	2-47
Wheel lock nuts	
ow brake fluid warning	
ow fuel warning	
ow tire pressure warning	
ow washer fluid warning	
ower anchors and tethers for	2-44
	1 17
hildren system	1-1/
M	
Naintenance	
Brake system (NCCB (NISSAN Carbon	0 20
Ceramic Brake))	8-20

Explanation of maintenance items ....... 9-3

General maintenance 9-2, 9-	Noises are heard while driving GTR-26	Overheat
Maintenance information GTR-	3 Normal mode 5-25	If your vehicle overheats 6-8
Maintenance precautions 8-	3	Owner's Manual/Service Manual
Maintenance requirement9-	2	order information 10-24
Readiness for		
Inspection/Maintenance test 10-2	Odometer/twin trip odometer	P
Scheduled maintenance 9-	Off-road recovery 5-8	
Seat belt maintenance 1-1	2 Oil	Parking
Maintenance log and records 9-2	Changing engine oil and filter 8-10	Parking brake 5-34
Map lights 2-6	Checking engine oil level 8-9	Parking brake break-in 5-52
Measurement of weights 10-1	o Differential oil GTR-5	Parking brake release warning 2-39
Meters and gauges 2-	6 Engine oil GTR-4, 8-9	Parking/parking on hills 5-40
Mirror	Engine oil and oil	Passenger compartment 8-23
Inside mirror 3-2	7 filter recommendation 10-6	Power
Mirrors 3-2	7 Engine oil level display 2-13	Locking with power door lock switch 3-
Outside mirrors 3-2	8 Engine oil low pressure warning 2-37	Power outlets 2-60
Vanity mirror 3-2	Transmission oil CTD-/ 9-10	Power steering 5-5
Vanity mirror lights 2-7	Transmission oil high	Power steering fluid 8-1
Most common factors contributing to	temperature warning 2-38	Power windows 2-6
vehicle corrosion	Opening and closing the trunk 3-22	Trunk release power cancel switch 3-2
Multi Function Display Owner's Manual 4-	Opening the deers 7-7	Precautions 8-14
Material Parecial Pispidy Owner's Manada	Opening the fuel-filler door 3-25	All-Wheel Drive driving
N	Opening the hood 3-18	safety precautions 5-9
	Operating range for engine start 5-10	Braking precautions 5-52
NCCB (NISSAN Carbon	Operation displays 2-45	Maintenance precautions 8-:
Ceramic Brake) GTR-6, 8-2	O Other modes for each switch 5-25	Precautions on child restraints 1-10
Replacing brake pads and brake	Outside air temperature 2-19	Precautions on cruise control 5-3!
disc rotors 8-2	1 Outside door handles 7-4	Precautions on seat belt usage 1-0
NISSAN Advanced Air Bag System 1-4	O Outside mirrors 3-28	Precautions on supplemental
NISSAN Vehicle Immobilizer System 2-5	O Outside temperature display indicates	restraint system 1-34
No key warning 2-4	5 higher temperature GTR-25	

Precautions when starting
and driving 5-3
Precautions before driving GTR-11
Precautions on performance driving GTR-13
Pregnant women 1-9
Push starting 6-8
"PUSH" warning 2-46
Push-button ignition switch 5-10
R
R mode 5-25
R mode start function 5-33
Rapid air pressure loss 5-8
Readiness for
Inspection/Maintenance test 10-22
Rear window defroster switch 2-52
Rear-facing child restraint installation
using LATCH 1-20
Rear-facing child restraint installation
using the seat belts 1-21
RearView Monitor 4-2
Recommended fluids and
maintenance interval GTR-20
Reducing tight corner
braking phenomenon
Refueling precautions GTR-14
Remote keyless entry system 3-12
Removing spots
Removing the cowl top cover
Repair and replacement procedure 1-49

Replacement of brake pads and disc rotorsReplacement of brake pads and disc rotors (NCCB (NISSAN Carbon	
Ceramic Brake))	
Replacing spark plugs	
Replacing the brake pads	
Replacing the wiper blades	
Reporting safety defects	
Reverse warning	
Roadside assistance program	
Run-flat tire warning	
Run-flat tires	6-4
S	
-	
Safety	
Safety All-Wheel Drive driving	
All-Wheel Drive driving	5-9
•	
All-Wheel Drive driving safety precautions	1-13
All-Wheel Drive driving safety precautions	1-13
All-Wheel Drive driving safety precautions Child safety Reporting safety defects	1-13 . 10-2
All-Wheel Drive driving safety precautions Child safety Reporting safety defects Safety — Seats, seat belts and	1-13 . 10-21
All-Wheel Drive driving safety precautions Child safety Reporting safety defects Safety — Seats, seat belts and supplemental restraint system	1-13 . 10-21
All-Wheel Drive driving safety precautions Child safety Reporting safety defects Safety — Seats, seat belts and supplemental restraint system Scheduled maintenance	1-13 . 10-2 1-1
All-Wheel Drive driving safety precautions Child safety Reporting safety defects Safety — Seats, seat belts and supplemental restraint system Scheduled maintenance Seat	1-13 . 10-2 1-1
All-Wheel Drive driving safety precautions Child safety Reporting safety defects Safety — Seats, seat belts and supplemental restraint system Scheduled maintenance Seat Booster seats	1-13 . 10-2 1-1 9-2 1-30

Front seat-mounted side-impact supplemental air bag and roof-mounted curtain side-impact and rollover supplemental air
bag systems 1-45
Front seats 1-3
Heated seats
NISSAN Advanced Air Bag System 1-40
Precautions on seat belt usage 1-6
Rear-facing child restraint installation
using the seat belts 1-21 Seat belt extenders 1-12
Seat belt maintenance
Seat belts 1-6, 7-8
Seat belts with pretensioners 1-46
Seats 1-2
Three-point type seat belt
with retractor1-9
Seat belt
Forward-facing child restraint
installation using the seat belts 1-26
Precautions on seat belt usage 1-6
Rear-facing child restraint installation
using the seat belts 1-21
Seat belt extenders 1-12
Seat belt maintenance 1-12
Seat belts 1-6, 7-8
Seat belts with pretensioners 1-46
Three-point type seat belt
with retractor 1-9
Security systems 2-48

Self-adjusting brakes	8-19
Servicing air conditioner	4-14
Setting (drive computer)	2-20
Setting guide of wheel alignment	
depending on the customer's driving	9-21
Setting hazard indicator and	
horn mode	3-14
Shift lever position warning	2-37
Shift "P" warning	2-46
Small children	1-14
Sonar system	5-48
Sonar system off switch	2-59
Sonar system setting	5-50
Spark plugs	8-16
Special winter equipment	5-57
Specifications	10-9
Speedometer	2-7
Starting	
Before starting the engine	5-13
Jump starting 6-5,	8-15
Precautions when starting	
and driving	5-3
Push starting	. 6-8
Starting the engine	5-14
Steering	
Power steering	5-51
Power steering fluid	8-11
Steering lock release	
malfunction indicator	2-47
Steering wheel	3-26
Steering-wheel-mounted controls	

Tilt/telescopic steering column	3-26
torage	2-63
ummer tires GT	rR-11
un visors	3-27
unglasses holder	2-64
upplemental air bag warning labels	1-48
upplemental air bag warning light	1-48
upplemental restraint system	1-34
uspension and	
heel alignmentGTR-16, GT	rR-23
witch	
Hazard warning flasher switch	6-2
Headlight and turn signal switch	2-53
Headlight switch	2-53
How to switch the modes	5-26
Ignition switch operation	5-11
Ignition switch positions	5-11
Interior light control switch	2-70
Locking with power door lock switch	3-5
Push-button ignition switch	5-10
Rear window defroster switch	2-52
Trunk lid release switch	3-20
Trunk open request switch	3-20
Trunk release power cancel switch	3-21
VDC, transmission and suspension	
setup switches	5-25
Wiper and washer switch	2-51

Т	
achometer2	-8
emperature A, B and C 10-2	
erms 10-1	
hree-point type seat belt	
ith retractor1	-9
hree-way catalyst5	-3
ght corner braking phenomenon 5-4	44
lt/telescopic steering column	26
re	
Changing wheels and tires 8-3	38
Checking the tire pressure 8-3	33
Flat tire 6	-3
Front/rear tire size	
discrepancy warning 2-4	41
Low tire pressure warning 2-4	42
Run-flat tire warning 2-4	42
Run-flat tires 6	-4
Tire and loading	
information label 8-32, 10-	14
Tire chains 8-3	38
Tire dressing 7	
Tire equipment 5-5	57
Tire labeling 8-3	34
Tire pressure 8-3	
Tire Pressure Monitoring System 5-4, 6	-3
Tire Pressure Monitoring	
System warning 2-4	
Tire replacement record 9-2	23

Tires ...... 5-44

Types of tires 8-36	Transmission assembly/parts		Vehicle Dynamic Control (VDC)	
Uniform tire quality grading 10-20	replacement record	9-26	OFF mode	GTR-1
Wheels and tires 8-29, 10-10	Transmission		Vehicle Dynamic Control (VDC)	
Tires and road wheels GTR-5	operation characteristics	GTR-32	warning light	2-34
Titanium muffler GTR-7	Transmission settings	GTR-9	Vehicle Dynamic Control system	5-54
Change of surface color of	Treadwear	10-20	Vehicle Dynamic Control	
titanium muffler GTR-30	Troubleshooting guide	3-17	system warning	2-40
Sound heard around	Trunk		Vehicle identification	10-12
titanium muffler GTR-30	Trunk lid release switch	3-20	Vehicle identification number	10-12
To protect your vehicle from corrosion 7-9	Trunk open request switch	3-20	Vehicle Identification	
Towing	Trunk release power cancel switch	3-21	Number plate	10-1
Flat towing 10-20	Turbocharger system	5-32	Vehicle information display	2-1
Towing a trailer 10-19	Turning off the heaters	2-58	Vehicle load capacity	10-18
Towing recommended by NISSAN 6-10	Turning on the heaters	2-58	Vehicle loading information	10-1
Towing your vehicle 6-9	Types of tires	8-36	Vehicle recovery	6-10
Traction AA, A, B and C 10-20			Vehicle security system	2-48
Transceiver	U		Vehicle speed	2-1
HomeLink® Universal Transceiver 2-71	Underbody	7 7	Vehicle status data recorder	10-24
Transmission	Uneven wear of tires		Ventilators	4-9
Dual clutch transmission 5-15	Uniform tire quality grading			
Transmission clutch high	Upshift indicator		W	
temperature warning 2-39	Using the washer		Warning	
Transmission oil GTR-4, 8-10	Using the washer		Anti-lock Braking System warning	2-40
Transmission oil high	Osing the wipers	2-31	AWD clutch high	2-41
temperature warning 2-38	V		temperature warning	2-40
Transmission position indicator 2-10	•		AWD system warning	
Transpission system shock display. 2.15				
Transmission system check display 2-15	Vanity mirror	3-29	,	
Transmission system warning 2-38	Vanity mirrorVanity mirror lights		AWD warning light	5-42
Transmission system warning			AWD warning lightBrake pad wear warning	5-4: 8-1:
Transmission system warning 2-38	Vanity mirror lights	2-71	AWD warning light	5-42 8-19 2-42

Engine oil low pressure warning	2-37
Engine system warning	2-37
Front/rear tire size	
discrepancy warning	2-41
Hazard warning flasher switch	6-2
Low brake fluid warning	2-39
Low fuel warning	2-43
Low tire pressure warning	2-42
Low washer fluid warning	2-44
No key warning	2-45
Parking brake release warning	2-39
"PUSH" warning	2-46
Reverse warning	2-38
Run-flat tire warning	2-42
Shift lever position warning	2-37
Shift "P" warning	2-46
Supplemental air bag	
warning labels	1-48
Supplemental air bag warning light	1-48
Tire Pressure Monitoring	
System warning	2-42
Transmission clutch high	
temperature warning	2-39
Transmission oil high	
temperature warning	2-38
Transmission system warning	2-38
Vehicle Dynamic Control	
system warning	2-40
Warning (drive computer)	2-24
Warning display	2-36

Warning lights, indicator lights and	
audible reminders2	-26
Warning signals 3	-16
Warning/indicator lights (red) 2	-26
Warning/indicator lights (other) 2-	-34
Warning/indicator lights (yellow) 2	-29
Warranty information GT	R-3
Washing	7-2
Waxing	7-3
Wheel alignment GTR-10, 5	-40
Wheel alignment inspection and	
adjustment (if necessary) (including tire	
pressure adjustment) GT	R-9
Wheel lock nuts8	-46
Wheels	7-4
Wheels and	
tires GTR-17, GTR-23, 8-29, 10	-10
When traveling or registering in	
another country10	
Where to go for service	
Window washer fluid8	
Windows 2	
Windshield wiper blades8	-18
Wiper	
Replacing the wiper blades 8-	
Using the wipers 2	
Windshield wiper blades 8-	
Wiper and washer switch2	
Wiper and washer switch 2-	-51

# **MEMO**

#### GAS STATION INFORMATION

#### **FUEL INFORMATION**

# **VR38** engine

Use unleaded premium gasoline with an octane rating of at least 93 AKI (Anti-Knock Index) number (Research octane number 98) to maximize vehicle performance.

If the premium gasoline specified above is not available, you may use unleaded premium gasoline with an octane rating of at least 91 AKI number (Research octane number 96), but you may notice a decrease in performance.

Do not use gasoline with a lower octane rating than 91 AKI (Research octane number 96).

### **NOTICE**

- Using a fuel other than that specified could adversely affect the emission control systems, and may also affect warranty coverage.
- Under no circumstances should a leaded gasoline be used, since this will damage the three way catalyst.

- Do not use E-15 or E-85 fuel in your vehicle. Your vehicle is not designed to run on E-15 or E-85 fuel. Using E-15 or E-85 fuel in a vehicle not specifically designed for E-15 or E-85 fuel can adversely affect the emission control devices and systems of the vehicle. Damage caused by such fuel is not covered by the NISSAN new vehicle limited warranty.
- U.S. government regulations require ethanol dispensing pumps to be identified by a small, square, orange and black label with the common abbreviation or the appropriate percentage for that region.
- NISSAN recommends using fuels that contain no alcohol. However, fuels containing up to 10% alcohol may be used, if necessary. To avoid serious engine damage due to increased cylinder temperature, do not use fuels that contain more alcohol than indicated in "Gasoline containing oxygenates" page 10-5. Also, do not use fuel additives, fuel stabilizers or fuel deicers that contain alcohol.

For additional information, see the following section. ( 🎢 "Capacities and recommended fluids/lubricants" page 10-2)

#### **ENGINE OIL RECOMMENDATION**

Mobil 1 (0W-40) (100% synthetic) is the factory fill oil. The VR38 engine with its plasma-sprayed bores was developed using this oil. NISSAN cannot ensure proper engine operation and durability if other OW-40 non-equivalent synthetic oil is used. If Mobil 1 (0W-40) or equivalent is not available, Mobil 1 (10W-40) (100% synthetic) or equivalent may be used; however, some performance loss may be noticed.

#### **COLD TIRE PRESSURES**

# NEW VEHICLE BREAK-IN PROCE-DURES RECOMMENDATION

Follow these recommendations for the future reliability and economy of your new vehicle.

During the first 1,200 miles (2,000 km) of vehicle use, follow the recommendations outlined in this Owner's Manual. (译 "Break-in schedule" page 5-40)



Printing : June 2020 Publication No.: OM21E0 0R35U0 Printed in the U.S.A.