


CONTENT

A-Z



---

**OWNER'S MANUAL.**  
**MINI COUNTRYMAN.**







## **WELCOME TO MINI.**

### **OWNER'S MANUAL.**

Thank you for choosing a MINI.

The more familiar you are with your vehicle, the better control you will have on the road. We therefore strongly suggest:

Read this Owner's Manual before starting off in your new MINI. Also use the Integrated Owner's Manual in your vehicle. It contains important notes on vehicle operation that will help you make full use of the technical features available in your MINI. The manual also contains information designed to enhance operating reliability and traffic safety, and to contribute to maintaining the value of your MINI.

Any updates made after the editorial deadline can be found in the appendix of the printed Owner's Manual for the vehicle.

Get started now. We wish you driving fun and inspiration with your MINI.

# TABLE OF CONTENTS

Navigation, Entertainment and Communication can be called up via the Integrated Owner's Manual in the vehicle.

## NOTES

Information.....	6
------------------	---

## QUICK REFERENCE

Getting in.....	16
Set-up and use.....	20
On the road.....	24

## AT A GLANCE

Dashboard.....	32
Central Information Display (CID).....	36
Voice activation system.....	44
General settings.....	47
Owner's Manual media.....	59

## CONTROLS

Opening and closing.....	62
Seats, mirrors and steering wheel.....	86
Transporting children safely.....	99
Driving.....	105
Displays.....	132
Lights.....	155
Safety.....	161
Driving stability control systems.....	186
Driving comfort.....	191
Climate control.....	212

Interior equipment.....	222
Storage compartments.....	233
Cargo area.....	236

## **DRIVING TIPS**

Things to remember when driving.....	244
Reducing fuel consumption.....	249

## **MOBILITY**

Refueling.....	256
Fuel.....	258
Wheels and tires.....	260
Engine compartment.....	281
Engine oil.....	284
Coolant.....	288
Maintenance.....	290
Replacing components.....	292
Breakdown Assistance.....	297
Vehicle Care.....	306

## **REFERENCE**

Technical data.....	312
Appendix.....	315
Everything from A to Z.....	316

# Information

## Using this Owner's Manual

### Orientation

The fastest way to find information on a particular topic is by using the index.

An initial overview of the vehicle is provided in the first chapter.

### Updates made after the editorial deadline

Due to updates after the editorial deadline, differences may exist between the printed Owner's Manual and the Integrated Owner's Manual in the vehicle.

Notes on updates can be found in the appendix of the printed Owner's Manual for the vehicle.

### Owner's Manual for Navigation, Entertainment, Communication

The Owner's Manual for Navigation, Entertainment, and Communication can be obtained as a printed book from the service center.

The topics are also discussed in the Integrated Owner's Manual in the vehicle.

## Additional sources of information

### Service center

A service center will be glad to answer questions at any time.

### Internet

Vehicle information and general information on MINI, e.g., on technology, are available on the Internet: [www.miniusa.com](http://www.miniusa.com).

### Integrated Owner's Manual in the vehicle

The Integrated Owner's Manual specifically describes features and functions found in the vehicle. The Integrated Owner's Manual can be displayed on the Control Display. Additional information, refer to page 59.

### MINI Motorer's Guide app



The app specifically describes features and functions found in the vehicle. The app can be displayed on smartphones and tablets.

### MINI Motorer's Guide Web

Driver's Guide Web shows the most suitable information for the selected vehicle. If possible, only equipment and functions that are actually installed in the vehicle will be explained. Driver's Guide Web can be displayed in any current browser.

## Symbols and displays

### Symbols in the Owner's Manual

Icon	Meaning
	Precautions that must be followed in order to avoid the possibility of injury to yourself and to others as well as serious damage to the vehicle.
	Measures that can be taken to help protect the environment.

Icon	Meaning
"..."	Control Display texts used to select individual functions.
>...<	Verbal instructions to use with the voice activation system.
>>...<<	Responses generated by the voice activation system.

## Action steps

Action steps to be carried out are presented as a numbered list. The steps must be carried out in the defined order.


1. First action step.
2. Second action step.

## Enumerations

Enumerations without mandatory order or alternative possibilities are presented as a list with bullet points.

- First possibility.
- Second possibility.

## Icons on vehicle components

 This symbol on a vehicle component indicates that further information on the component is available in the Owner's Manual.

## Vehicle equipment and options

This Owner's Manual describes all models and all standard, country-specific and optional equipment that is offered in the model series. Therefore, this Owner's Manual also describes and illustrates features and functions that are not available in a vehicle, for example because of the se-

lected optional equipment or the country-specific version.

This also applies to safety-related functions and systems.

When using these functions and systems, the applicable laws and regulations must be observed.

For any options and equipment not described in this Owner's Manual, refer to the Supplementary Owner's Manuals.

Your dealer's service center is happy to answer any questions that you may have about the features and options applicable to your vehicle.

## Status of the Owner's Manual

### Basic information

The manufacturer of your vehicle pursues a policy of constant development that is conceived to ensure that our vehicles continue to embody the highest quality and safety standards. In rare cases, therefore, the features described in this Owner's Manual may deviate from those in your vehicle.

### Updates made after the editorial deadline

Due to updates after the editorial deadline, differences may exist between the printed Owner's Manual and the Integrated Owner's Manual in the vehicle.

Notes on updates can be found in the appendix of the printed Owner's Manual for the vehicle.

## For Your Own Safety

### Manufacturer

The manufacturer of this MINI is Bayerische Motoren Werke Aktiengesellschaft, BMW AG.

### Intended use

Heed the following when using the vehicle:

- Owner's Manual.
- Information on the vehicle. Do not remove stickers.
- Technical vehicle data.
- The traffic, speed, and safety laws where the vehicle is driven.
- Vehicle documents and statutory documents.

### Warranty

Your vehicle is technically configured for the operating conditions and registration requirements applying in the country of first delivery, also known as homologation. If your vehicle is to be operated in a different country it might be necessary to adapt your vehicle to potentially differing operating conditions and registration requirements. Noncompliance with homologation requirements in a certain country may affect warranty coverage. Please consult the New Vehicle Limited Warranty Booklet for further information on warranty matters.

### Maintenance and repairs

Advanced technology, for instance the use of modern materials and high-performance electronics, requires suitable maintenance and repair work.

The manufacturer of your vehicle recommends that you entrust corresponding procedures to a MINI dealer's service center. If you choose to use another service facility,

the manufacturer of your vehicle recommends use of a facility that performs work, e.g., maintenance and repair, according to MINI specifications with properly trained personnel, referred to in the Owner's Manual as "another qualified service center or repair shop".

If work is performed improperly, for instance maintenance and repair, there is a risk of subsequent damage and related safety risks.

Improperly performed work on the vehicle paintwork can lead to a failure or fault of components, e.g., the radar sensors, and thereby result in a safety hazard.

### Parts and accessories

The manufacturer of your vehicle recommends the use of parts and accessory products approved by the manufacturer of the MINI.

Approved parts and accessories, and advice on their use and installation are available from a MINI dealer's service center.

MINI parts and accessories were tested by the manufacturer of the MINI for their safety and suitability in MINI vehicles.

The manufacturer of your vehicle warrants genuine MINI parts and accessories.

The manufacturer of your vehicle does not evaluate whether each individual product from another manufacturer can be used with MINI vehicles without presenting a safety hazard, even if a country-specific official approval was issued. The manufacturer of your vehicle does not evaluate whether these products are suitable for MINI vehicles under all usage conditions.

### California Proposition 65 Warning

For vehicles sold in California, the law requires vehicle manufacturers to provide the following warning:



**⚠ Warning**

Engine exhaust and a wide variety of Automobile components and parts, including components found in the interior furnishings in a vehicle, contain or emit chemicals known to the State of California to cause cancer and birth defects and reproductive harm. In addition, certain fluids contained in vehicles and certain products of component wear contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Battery posts, terminals and related accessories contain lead and lead compounds. Batteries also contain other chemicals known to the State of California to cause cancer. Wash your hands after handling. Used engine oil contains chemicals that have caused cancer in laboratory animals. Always protect your skin by washing thoroughly with soap and water. For more information go to [www.P65Warnings.ca.gov/passenger-vehicle](http://www.P65Warnings.ca.gov/passenger-vehicle).

**⚠ Warning**

Operating, servicing and maintaining a passenger vehicle or off-highway motor vehicle can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle in a well-ventilated area and wear gloves or wash your hands frequently when servicing your vehicle. For more information go to [www.P65Warnings.ca.gov/passenger-vehicle](http://www.P65Warnings.ca.gov/passenger-vehicle).

**Service and warranty**

We recommend that you read this publication thoroughly. Your vehicle is covered by the following warranties:

- New Vehicle Limited Warranty.
- Rust Perforation Limited Warranty.
- Federal Emissions System Defect Warranty.
- Federal Emissions Performance Warranty.
- California Emission Control System Limited Warranty.

Detailed information about these warranties is listed in the New Vehicle Limited Warranty Booklet.

Your vehicle has been specifically adapted and designed to meet the particular operating conditions and homologation requirements in your country and continental region in order to deliver the full driving pleasure while the vehicle is operated under those conditions. If you wish to operate your vehicle in another country or region, you may be required to adapt your vehicle to meet different prevailing operating conditions and homologation requirements. You should also be aware of any applicable warranty limitations or exclusions for such country or region. In such case, please contact Customer Relations for further information.

**Maintenance**

Maintain the vehicle regularly to sustain the road safety, operational reliability and the New Vehicle Limited Warranty.

Specifications for maintenance measures:

- MINI maintenance system

Maintenance, refer to page 290.

- Maintenance Booklet, available online and accessible via a QR code in the New Vehicle Limited Warranty Booklet.
- Warranty and Service Guide Booklet for Canadian models.

If the vehicle is not maintained or is improperly maintained, this could result in serious damage to the vehicle.

A failure to maintain your vehicle or improper maintenance may affect your warranty coverage. Please consult the New Vehicle Limited Warranty Booklet for further information on warranty matters.

Refer to section on engine oil change regarding recommended service intervals for oil changes.

## Data memory

### General information

Electronic control devices are installed in the vehicle. Electronic control units process data they receive from vehicle sensors, self-generate or exchange with each other. Some control units are necessary for the vehicle to function safely or provide assistance during driving, for instance driver assistance systems. Furthermore, control units facilitate comfort or infotainment functions.

Information about stored or exchanged data can be requested from the manufacturer of the vehicle, in a separate booklet, for example.

### Personal reference

Each vehicle is marked with a unique vehicle identification number. Depending on the country, the vehicle owner can be identified with the vehicle identification number, license plate and corresponding authorities. In addition, there are other options to track

data collected in the vehicle to the driver or vehicle owner, for instance via utilized services.

### Operating data in the vehicle

Control units process data to operate the vehicle.

For example, this includes:

- Status messages for the vehicle and its individual components, e.g., wheel RPM, wheel speed, deceleration, lateral acceleration, engaged seat belt indicator.
- Ambient conditions, e.g., temperature, rain sensor signals.

The processed data is only processed in the vehicle itself and generally volatile. The data is not stored beyond the operating period.

Electronic components, e.g. control units and vehicle keys, contain components for storing technical information. Information about the vehicle condition, component usage, maintenance recommendations, events or faults can be stored temporarily or permanently.

This information generally documents the state of a component, a module, a system, or the surrounding area, for instance:

- Operating states of system components, for instance, fill levels, tire pressure, battery status.
- Malfunctions and faults in important system components, for instance lights and brakes.
- Responses by the vehicle to special driving situations such as airbag deployment or engagement of the driving stability control systems.
- Information on vehicle-damaging events.

The data is required to perform the control unit functions. Furthermore, it also serves

to detect and correct malfunctions, and helps the vehicle manufacturer to optimize vehicle functions.

The majority of this data is stored temporarily and is only processed within the vehicle itself. In some circumstances the vehicle may store some data for an additional but limited period of time.

When servicing, for instance during repairs, service processes, warranty cases, and quality assurance measures, this technical information can be read out from the vehicle together with the vehicle identification number.

A dealer's service center or another qualified service center or repair shop can read out the information. The diagnostic socket required by law in the vehicle is used to read out data.

The data is collected, processed, and used by the relevant organizations in the service network. The data documents technical conditions of the vehicle, which can be used to determine vehicle maintenance status, and facilitate quality improvement.

Fault and event memories in the vehicle can be reset when a dealer's service center or another qualified service center or repair shop performs repair or servicing work.

## Data entry and data transfer into the vehicle

### General information

Depending on the vehicle equipment, comfort and individual settings can be stored in the vehicle and modified or reset at any time.

For example, this includes:

- Settings for the seat and steering wheel positions.
- Chassis and climate control settings.

If necessary, data can be transferred to the entertainment and communication system of the vehicle, for instance via smartphone.

This includes the following depending on the respective equipment:

- Multimedia data such as music, films or photos for playback in an integrated multimedia system.
- Address book data for use in conjunction with an integrated hands-free system or an integrated navigation system.
- Entered navigation destinations.
- Data on the use of Internet services.

This data can be stored locally in the vehicle or is found on a device that has been connected to the vehicle, e.g., a smartphone, USB stick or MP3 player. If this data is stored in the vehicle, it can be deleted at any time.

This data is only transmitted to third parties upon personal request as part of the use of online services. The transmission depends on the selected settings for the use of the services.

### Incorporation of mobile devices

Depending on the vehicle equipment, mobile devices connected to the vehicle, for instance smartphones, can be controlled via the vehicle control elements.

The sound and picture from the mobile devices can be played back and displayed through the multimedia system. Certain information is transferred to the mobile devices at the same time. Depending on the type of incorporation, this includes, for instance position data and other general vehicle information. This optimizes the way in which selected apps, for instance navigation or music playback, work.

There is no further interaction between the mobile device and the vehicle, such as active access to vehicle data.

How the data will be processed further is determined by the provider of the particular app being used. The extent of the possible settings depends on the respective app and the operating system of the mobile device.

## Services

### General information

If the vehicle has a wireless network connection, it will enable data to be exchanged between the vehicle and other systems. The wireless network connection is realized via an in-vehicle transmitter and receiver unit or via personal mobile devices brought into the vehicle, for instance smartphones. This wireless network connection enables 'online functions' to be used. These include online services and apps supplied by the vehicle manufacturer or by other providers.

### Services from the vehicle manufacturer

Where online services from the vehicle manufacturer are concerned, the corresponding functions are described in the appropriate place, for instance the Owner's Manual or manufacturer's web page. The relevant legal information pertaining to data protection may also be found on the manufacturer's website. Personal data may be used to perform online services. Data is exchanged over a secure connection, for instance with the IT systems of the vehicle manufacturer intended for this purpose.

Any collection, processing, and use of personal data above and beyond that needed to provide the services must always be based on a legal permission, contractual arrangement or consent. It is also possible to activate or deactivate the data connection as a whole. That is, with the exception of functions and services required by law such as Assist systems.

### Services from other providers

When using online services from other providers, these services are the responsibility of the relevant provider and subject to their data privacy conditions and terms of use. The vehicle manufacturer has no influence on the content exchanged during this process. Information on the way in which personal data is collected and used in relation to services from third parties, the scope of such data, and its purpose, can be obtained from the relevant service provider.

## Event Data Recorder EDR

This vehicle is equipped with an event data recorder EDR. The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less.

The EDR in this vehicle is designed to record such data as:

- How various systems in your vehicle were operating.
- Whether or not the driver and passenger seat belts were fastened.
- How far, if at all, the driver was depressing the accelerator and/or brake pedal.
- How fast the vehicle was traveling.

This data can help provide a better understanding of the circumstances in which crashes and injuries occur.

EDR data is recorded by your vehicle only if a nontrivial crash situation occurs; no data is recorded by the EDR under normal driving conditions and no personal data, for in-

stance name, gender, age, and crash location, are recorded.

However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.


To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR.

## Vehicle identification number

### General information

Depending on the national-market equipment, the vehicle identification number is located in different positions in the vehicle. This chapter describes all possible positions for the series.

### Engine compartment



The engraved vehicle identification number can be found in the engine compartment, on the right-hand side of the vehicle.

### Right nameplate

For 3-door models:



The vehicle identification number can be found on the nameplate, on the right-hand side of the vehicle.

For 5-door models:



The vehicle identification number can be found on the nameplate, on the right-hand side of the vehicle.

### Left nameplate

For 3-door models:



The vehicle identification number can be found on the nameplate, on the left-hand side of the vehicle.

For 5-door models:



The vehicle identification number can be found on the nameplate, on the left-hand side of the vehicle.

## Windshield



The vehicle identification number can also be found behind the windshield.

## Reporting safety defects

### For US customers

The following only applies to vehicles owned and operated in the US.

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration NHTSA, in addition to notifying MINI of North America, LLC, P.O. Box 1227, Westwood, New Jersey 07675-1227, Telephone 1-800-831-1117.

If NHTSA receives similar complaints, it may open an investigation, and if it finds

that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign.

However, NHTSA cannot become involved in individual problems between you, your dealer, or MINI of North America, LLC.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to <http://www.safercar.gov>; or write to: Administrator, NHTSA, 1200 New Jersey Avenue, SE., Washington, DC 20590. You can also obtain other information about motor vehicle safety from <http://www.safercar.gov>

### For Canadian customers


Canadian customers who wish to report a safety-related defect to Transport Canada, Defect Investigations and Recalls, may call the toll-free hotline 1-800-333-0510. You can also obtain other information about motor vehicle safety from <http://www.tc.gc.ca/roadsafety>.



# Getting in

## Opening and closing

### Buttons on the vehicle key




- 1 Unlocking
- 2 Locking
- 3 Unlocking the tailgate  
With automatic trunk lid actuation:  
open the tailgate
- 4 Panic mode

### Unlocking the vehicle

 Press the button on the vehicle key.

Depending on the settings, either only the driver's door or all vehicle access points are unlocked.

If only the driver's door is unlocked, press the button on the vehicle key again to unlock the other vehicle access points.

 Press and hold the button on the vehicle key after unlocking.

The windows and the glass sunroof are opened, as long as the button on the vehicle key is pressed.

### Locking the vehicle

 Press the button on the vehicle key.

All vehicle access points are locked.


### Buttons for the central locking system

#### Overview




Buttons for the central locking system.

#### Locking

 Pressing the button locks the vehicle if the front doors are closed.

#### Unlocking

 Pressing the button unlocks the vehicle.

#### Panic mode

You can trigger the alarm system if you find yourself in a dangerous situation.

 Press the button on the vehicle key and hold for at least 3 seconds.

To switch off the alarm: press any button.



## Comfort Access


### Principle

The vehicle can be accessed without operating the vehicle key.

Carrying the vehicle key with you, e.g., in your pants pocket, is sufficient.


The vehicle automatically detects the vehicle key when it is in close proximity or in the interior.

### Unlocking the vehicle



Press the button on the door handle of the driver's or front passenger door.

### Locking the vehicle



Press the button on the door handle of the driver's or front passenger door.

## Opening and closing the tailgate with no-touch activation

### Principle

The trunk can be opened and closed contactless using the vehicle key you are carrying.

### Performing the foot movement


1. Stand in the middle behind the vehicle at approx. one arm's length away from the rear of the vehicle.
2. Wave a foot under the vehicle in the driving direction and immediately pull it back.



## Tailgate

### Without automatic tailgate: Unlocking




- Unlock the vehicle and then press the button on the outer side of the tailgate.
-  Press and hold the button on the vehicle key for approx. 1 second.

Depending on the setting, the doors may also be unlocked.

### With automatic tailgate: Opening




- Unlock the vehicle and press the button on the tailgate.
-  Press and hold the button on the vehicle key for approx. 1 second.

Depending on the setting, the doors may also be unlocked.

### Without automatic tailgate: Closing

Closing the tailgate manually.

### With automatic tailgate: Closing



Press the button on the inside of the tailgate.

## Displays and control elements

### In the vicinity of the steering wheel



- 1 Low beams, fog lights
- 2 High beams, headlight flasher, turn signal
- 3 Instrument cluster
- 4 Window wiper system

### Indicator/warning lights

The indicator/warning lights can light up in a variety of combinations and colors.


Several of the lights are checked for proper functioning and light up temporarily when the engine is started or the ignition is switched on.

### Driver's door



- 1 Safety switch
- 2 Power windows
- 3 Exterior mirrors

## All around the selector lever









- 1 Selector lever
- 2 Controller with buttons
- 3 Parking brake



## Central Information Display (CID)

### Principle

The Central Information Display (CID) combines the functions of a multitude of switches. These functions can be operated via the Controller.

### Buttons on the Controller

Button	Function
	Press once: calls up the main menu. Press twice: displays all menu items of the main menu.
	Call up the Communication menu.
	Call up the Media/Radio menu.
	Call up the destination input menu for navigation.
	Call up the CarPlay menu.
	Call up the navigation map.


Button	Function
	Press once: opens the previous display. Press and hold: open the menus used last.
	Call up the Options menu.

## Voice control

### Activating the voice control system

 Press the button on the steering wheel.

Wait for the signal tone.  
Say the command.

 This icon indicates that the voice activation system is active.

If no other commands are available, operate the function via the Central Information Display (CID).

### Ending the voice control system

 Press the button on the steering wheel or >Cancel<.

# Set-up and use


## Seats, mirrors and steering wheel

### Manually adjustable seats



- 1 Longitudinal direction
- 2 Thigh support
- 3 Height
- 4 Backrest tilt


### Electrically adjustable seats



- 1 Memory function
- 2 Lumbar support
- 3 Backrest tilt
- 4 Forward/backward, height, seat tilt


### Adjusting the head restraint

#### Height



- To raise: push the head restraint up.
- To lower: press the button, arrow 1, and push the head restraint down.

### Adjusting the exterior mirrors



- 1 Adjusting
- 2 Selecting a mirror, Automatic Curb Monitor
- 3 Folding in and out

## Adjusting the steering wheel

### In four directions



1. Fold the lever down.
2. Move the steering wheel to the preferred height and angle to suit your seat position.
3. Fold the lever back up.


## Memory function

### Principle

The following settings can be stored and, if necessary, retrieved using the memory function:

- Seat position.
- Exterior mirror position.
- Height of the Head-up Display.

### Storing

1. Turn on the ignition.
2. Set the desired position.
3.  Press the button. The LED in the button lights up.
4. Press the desired button 1 or 2 on the seat while the LED is illuminated. The LED goes out.

### Calling up settings

The stored position is called up automatically.

Press the desired button 1 or 2.

The procedure stops when a seat setting switch or one of the memory buttons is pressed.






Once underway, adjustment of the seat position on the driver's side is disabled after a short while.

## Infotainment

### Radio

#### Buttons and functions



Depending on the country and equipment version, the radio has the following buttons.

Button	Function
	Press: turns sound output on/off. Turn: adjusts the volume.
	Change the entertainment source.
	Press once: changes the station/track. Press and hold: fast forward/rewind the track.
	Programmable memory buttons.
	Changeover of wave range/satellite radio.

### Navigation destination input

#### Entering a destination via address

##### State/province

1.  "Navigation"
2.  "Enter address"
3. "State/Province?"
4. Select the country from the list.



### Entering the address

The address can be entered in any order.

Example: entering the address via the town/city

1. "City/Postal code?"
2. Enter the town/city.  
The list is narrowed down further with each entry.
3. **OK** Select the icon.
4. Select a town/city from the list.
5. If necessary, enter the street.
6. Select the street as you would the town/city.
7. If necessary, enter a house number.
8. **OK** Select the icon.
9. Select a house number or range of house numbers from the list.

### Starting destination guidance

"Start guidance"

Destination guidance is started to the town/city center if no street is entered.

### Pairing the mobile phone

After the mobile phone is paired once with the vehicle, the mobile phone can be operated using the Central Information Display (CID), the steering wheel buttons and spoken instructions.

1.  "My MINI"
2. "System settings"
3. "Mobile devices"
4. "Connect new device"

The vehicle's Bluetooth name is displayed on the Control Display.

5. Select the functions for which the mobile phone is to be used.

6. To perform additional steps on the mobile phone, refer to the operating instructions for the mobile phone: for instance search for or connect the Bluetooth device or a new device.

The Bluetooth name of the vehicle appears on the mobile phone display. Select the Bluetooth name of the vehicle.

7. Depending on the mobile device, a control number is displayed or the control number must be entered.
  - Compare the control number displayed on the Control Display with the control number on the display of the device. Confirm the control number on the device and on the Control Display.
  - Enter and confirm the same control number on the device and via the Central Information Display (CID).

The device is connected and displayed in the device list.

### Using the telephone

#### Accepting a call

Incoming call can be accepted via the Central Information Display (CID) or the button on the steering wheel.

#### Via the Central Information Display (CID)

 "Accept"

#### Via the button on the steering wheel





Press the button.

#### Via the instrument cluster

Use the OK button on the steering wheel to select: "Accept"

## Dialing a number

1.  "Communication"
2. "Dial number"
3. Select the numbers individually.
4.  Select the icon.

Establish the connection via the additional telephone:

1.  Press the button.
2. "Call via"

## Apple CarPlay preparation

### Principle


CarPlay allows select functions of a compatible Apple iPhone to be used via Siri voice control and the on-board monitor.

### Functional requirements

- Compatible iPhone: iPhone 5 or later with iOS 7.1 or later.
- Corresponding mobile contract.
- Bluetooth, Wi-Fi, and Siri voice control are activated on the iPhone.
- If necessary, the setting for mobile data must be activated on the iPhone.
- Wi-Fi and Bluetooth are enabled in the vehicle.

### Turning on Bluetooth and CarPlay

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Mobile devices"
4. "Settings"
5. Select the following settings:
  - "Bluetooth®"
  - "Apple CarPlay"

## Pairing the iPhone with CarPlay

Pair iPhone via Bluetooth with the vehicle.

Select CarPlay as the function:

1.  "Apple CarPlay"

The iPhone is connected to the vehicle and displayed in the device list.

# On the road

## Driving

### Starting and stopping the engine

#### Ignition on/off



- On: press the Start/Stop button.

Most of the indicator/warning lights light up for a varied length of time.

- Off: press the Start/Stop button again. All indicator lights turn off.
- Radio-ready state: when the ignition is switched off, press the ON/OFF button on the radio or when the engine is running, press the Start/Stop button. Some electrical components remain ready for operation.

#### Start/stop engine

##### Steptronic transmission: starting

1. Depress the brake pedal.
2. Engage selector lever position P or N.
3. Press the Start/Stop button.

##### Manual transmission: starting

1. Depress the brake pedal.
2. Press on the clutch pedal and shift to Neutral.
3. Press the Start/Stop button.

##### Steptronic transmission: switching off

1. When the vehicle is stationary, apply the parking brake.
2. Engage selector lever position P.
3. Press the Start/Stop button.

##### Manual transmission: switching off

1. With the vehicle at a standstill, press the Start/Stop button.
2. Shift into first gear or reverse.
3. Set the parking brake.

##### Auto Start/Stop function

Steptronic transmission: switches the engine off automatically while stationary to save fuel. The engine starts automatically when the brake pedal is released.

Manual transmission: switches the engine off automatically while stationary to save fuel. As soon as the clutch pedal is depressed, the engine starts automatically.

### Parking brake

#### Set the electrical parking brake



Pull the switch when the vehicle is stationary.

The LED and indicator light up.

#### Releasing



Manual transmission: press the switch while the brake pedal is pressed.

Steptronic transmission: press the switch while the brake is pressed or selector lever position P is set.

The LED and indicator light turn off.

The parking brake is released.



## Manual transmission

### Shifting

When shifting into 5th or 6th gear, push the gearshift lever to the right in order to prevent inadvertent shifting into the 3rd or 4th gear.

### Reverse gear

Select only when the vehicle is stationary.

To overcome the resistance push the gearshift lever dynamically to the left and engage reverse gear with a forward shifting movement.

## Steptronic transmission

### Selector lever positions

Parking position P.

R is reverse.

Neutral N.

Gear position D.

Engage selector lever position P or R only when the vehicle is stationary.

To prevent the vehicle from creeping after you select a gear position or reverse, maintain pressure on the brake pedal until you are ready to drive off.

### Selector lever lock

A lock prevents an inadvertent change from selector lever position P to another selector lever position and, depending on the transmission version, inadvertent switching to selector lever position P or R.

To release the lock: with the brake pedal depressed, press the button on the front or side of the selector lever.

## Steptronic transmission, Sport and manual mode



Sport program:


Press the selector lever to the left from selector lever position D.

Manual mode:

- Downshifting: press the selector lever forward.
- Upshifting: pull the selector lever rearwards.

## Turn signal, high beams, headlight flasher, roadside parking lights

### Turn signal



- Blinking: press the lever past the resistance point.
- Triple turn signal activation: lightly tap the lever up or down.
- Brief blinking: press the lever to the resistance point and hold it there for as long as you want the turn signal to blink.


## High beams, headlight flasher



Press the lever forward or pull it backward.

- High beams on, arrow 1.  
The high beams light up when the low beams are switched on.
- High beams off/headlight flasher, arrow 2.

## Canada: roadside parking light









To illuminate the vehicle on one side.

- On: with the radio-ready state switched off, press the lever either up or down past the resistance point for approx. 2 seconds.
- Off: briefly press the lever to the resistance point in the opposite direction.

## Lights and lighting

### Lighting functions

Icon	Function
	Front fog lights.
	Automatic headlight control. Cornering light.
	Lights off. Daytime driving lights.
	Parking lights.
	Low beams.
	Instrument lighting.

## Window wiper system

### Turning the wipers on/off and flick wiper

#### Turning on



Press the lever up until the desired position is reached.

- Resting position of the wipers: position 0.
- Rain sensor: position 1.
- Normal wiper speed: position 2.
- Fast wiper speed: position 3.

### Turning off and flick wipe



Press the lever down.

- Switching off: press the lever down until it reaches its basic setting.
- Flick wipe: press the lever down from the basic setting.

### Rain sensor

#### Activate/deactivate



To activate: press the lever up once from its basic setting, arrow 1.

To deactivate: press the lever back into the basic setting.

### Set interval period or sensitivity of the rain sensor



Turn the thumbwheel on the wiper lever.

### Cleaning the windshield



Pull the lever.

### Canada: window wiper system

#### Turning the wipers on/off and flick wipe

##### Turning on



Tap up the lever or press it past the resistance point.

- Normal wiper speed: tap up once.
- Fast wiper speed: tap up twice or tap once beyond the resistance point.

**Turning off and flick wipe**



Press the lever down.

- To turn off fast wipe: press down twice.
- To turn off normal wipe: press down once.
- Flick wipe: press down once.

**Rain sensor**

**Activate/deactivate**



Press the button on the wiper lever.

**Set interval period or sensitivity of the rain sensor**



Turn the thumbwheel on the wiper lever.




**Cleaning the windshield**






Pull the lever.









**Climate control**



**Air conditioning system**

Button	Function
	Temperature.
	Air conditioning.
	Air recirculation mode.

Button	Function
	Adjusts the air flow, manual.
	Adjusts the air distribution manually.
	Heated windshield.

## Automatic climate control

Button	Function
	Temperature.
	Air conditioning.
	Maximum cooling.
	AUTO program.
	Automatic air recirculation control AUC/recirculated-air mode.
	Adjusts the air flow, manual.
	Air distribution, manual.
	Defrosts and defogs the windows.


Button	Function
	Heated windshield.
	Rear window defroster.

## Refueling stop

### Refueling

#### Fuel cap

1. To open the fuel filler flap, press on the rear edge, arrow. The fuel filler flap opens.



2. Turn the fuel cap counterclockwise.
3. Place the fuel cap in the bracket attached to the fuel filler flap.

#### Gasoline

For the best fuel efficiency, the gasoline should be sulfur-free or very low in sulfur content.

Refuel only with unleaded gasoline without metallic additives.

Information on the recommended gasoline quality can be found in the Owner's Manual.

## Wheels and tires

### Tire pressure specifications



The tire inflation pressure values can be found on the sign on the door pillar.

### Checking the tire pressure

Regularly check the tire inflation pressure and correct it as needed:

- At least twice a month.
- Before embarking on an extended trip.

### After correcting the tire pressure

Reinitialize the Flat Tire Monitor.  
Monitor the tire pressure.



## Electronic oil measurement

### Prerequisites

A current measured value is available after approx. 30 minutes of driving. During a shorter trip, the status of the last, sufficiently long trip is displayed.

### Displaying the engine oil level

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle status"
3.  "Engine oil level"


The engine oil level is displayed.

## Adding engine oil

### General information

Turn off the ignition and safely park the vehicle before engine oil is added.

### Adding engine oil



Only add engine oil when the message is displayed in the instrument cluster.

Observe the top-up quantity in the message. Take care not to add too much engine oil. Observe recommended engine oil types.

## Providing assistance

### Hazard warning flashers




The button is located above the Control Display.

## Breakdown Assistance

### MINI Roadside Assistance

This service can be reached around the clock in many countries.

1.  "MINI Connected"
2. "MINI Assist"
3. "MINI Roadside Assistance"

The contact to the MINI Roadside Assistance is established.

A telephone number is displayed, if needed. Select to dial the telephone number on a connected mobile phone.


# Dashboard

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available

in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## In the vicinity of the steering wheel



- 1 Power windows [82](#)
- 2 Exterior mirror adjustment button [95](#)
- 3 Buttons of the central locking system [67](#)
- 4 Lights



Front fog lights [158](#)



Light switch [155](#)



Lights off  
Daytime driving lights [157](#)































Parking lights [155](#)



Low beams [155](#)




- |   |  |   |  |
|---|--|---|--|
|    | Automatic headlight control <a href="#">156</a>        |    | Canada: roadside parking light <a href="#">156</a> |
|   | Cornering light <a href="#">157</a>                    |    | Trip computer <a href="#">145</a>                  |
|   | Automatic High Beam Assistant <a href="#">157</a>      |   |  |
|    | Instrument lighting <a href="#">159</a>                | 7   | Instrument cluster <a href="#">132</a>             |
| 5   | Steering wheel buttons, left                           | 8   | Pitman arm, right                                  |
|    | Camera-based cruise control on/off <a href="#">191</a> |    | Wipers <a href="#">113</a>                         |
|    | Cruise control on/off <a href="#">198</a>              |    | Wiper on Canadian models <a href="#">117</a>       |
|    | Speed Limiter <a href="#">182</a>                      |    | Rain sensor <a href="#">114</a>                    |
|    | Interrupting, continuing cruise control                |    | Rain sensor on Canadian models <a href="#">118</a> |
|    | Cruise control: increase speed                         |    | Cleaning windows <a href="#">115</a>               |
|    | Cruise control: reduce speed                           |    | Rear wiper in Canadian models <a href="#">116</a>  |
|    | Camera-based cruise control: reduce distance           |    | Rear wiper <a href="#">116</a>                     |
|   | Camera-based cruise control: increase distance         |    | Clean the rear window <a href="#">116</a>          |
| 6   | Pitman arm, left                                       | 9   | Steering wheel buttons, right                      |
|  | Turn signal <a href="#">113</a>                        |   | Voice control <a href="#">44</a>                   |
|  | High beams, headlight flasher <a href="#">113</a>      |  | Telephone  |
|  | Automatic High Beam Assistant <a href="#">157</a>      |  | Confirm the selection <a href="#">144</a>          |
|   |  |  | Move selection up <a href="#">144</a>              |
|   |  |  | Move selection down <a href="#">144</a>            |



Increase volume



Reduce volume



Horn, entire surface

11 Steering wheel heating 97

12 Adjusting the steering wheel 97

13 Unlocking the hood 282

14 Depending on the equipment: using tail-gate 72

## In the vicinity of the center console



Hazard warning system 297



Intelligent Safety 172

2 Control Display 36

3 Radio/Multimedia

4 Glove compartment 233

5 Climate control 212



PDC Park Distance Control 201

Rearview camera 204

Automatic Parking Assistant 207



Auto Start/Stop function 108



Start/stop the engine and switch the ignition on/off 105



Dynamic Stability Control [186](#)



MINI Driving Modes switch [188](#)

Manual transmission gearshift lever [122](#)

8 Controller with buttons [39](#)

9 Parking brake [111](#)

7 Steptronic transmission selector lever [123](#)

## In the vicinity of the headliner



1  Emergency Call, SOS [298](#)

4  Ambient light [159](#)

2  Indicator light, front passenger airbag [164](#)

5  Panoramic glass sunroof [84](#)

3  Reading lights [159](#)

6  Interior lights [159](#)

# Central Information Display (CID)

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## Principle

The Central Information Display (CID) combines the functions of a multitude of switches. These functions can be operated via the Controller.

## Safety information

### Warning


Operating the integrated information systems and communication devices while driving can distract from surrounding traffic. It is possible to lose control of the vehicle. There is a risk of accident. Only use the systems or devices when the traffic situation allows. As warranted, stop and use the systems and devices while the vehicle is stationary.

## Input and display

### Main menu

#### General information

The main menu is divided into two areas. The left area contains menu items that can be used to call up all functions from the on-board monitor. The menu items in the right area show dynamic contents that enable quick access to certain functions.



### Media/Radio

All functions of the entertainment system, for instance radio stations or pairing with external devices.

### Communication

Telephone and message function, e-mail and calendar and connecting and managing mobile devices, for instance smartphones.

### Navigation

Access to the navigation system, destination input and traffic bulletins. Configurable map views and other functions, such as points of interest.

## My MINI

Information on vehicle status and setting options for vehicle and on-board monitor. Access to the Integrated Owner's Manual.

## MINI Connected



Access to apps and vehicle functions. Additional apps and vehicle functions can be purchased from the MINI Connected Store.

## Notifications

Access to all incoming messages in the vehicle, for instance Check Control messages.

## Letters and numbers

Depending on the menu, you can switch between entering upper and lower case letters, numbers and characters:

Icon	Function
abc ABC	Change between capital and lower-case letters.
	Insert blank space.
	Use voice control.
OK	Confirm entry.

## Without navigation system

   Select the icon.

## Entry comparison

When entering names and addresses, the choice is narrowed down with every letter entered and letters may be added automatically.

Entries are continuously compared with data stored in the vehicle.

- Only those letters are offered during entry for which data is available.
- Destination search: place names can be entered in all languages that are available on the Control Display.

## Activating/deactivating the functions

Several menu items are preceded by a checkbox. The checkbox indicates whether the function is activated or deactivated. Selecting the menu item activates or deactivates the function.



- Function is activated.
- Function is deactivated.

## Status information








### General information



The status field can be found in the upper area of the Control Display. Status information is displayed in the form of symbols.

### Radio





Icon	Meaning
	HD Radio station is being received.
	Satellite radio is switched on.

### Telephone






Icon	Meaning
	Incoming or outgoing call.
	Missed call.
	Signal strength of mobile phone network. Symbol flashes: network search.
	Mobile phone network is not available.
	Roaming is active.
	SMS text message received.
	Message received.

Icon	Meaning
	Reminder.
	Sending not possible.

**Entertainment**

Icon	Meaning
	Bluetooth audio.
	USB audio interface.
	Mobile phone audio interface.
	Apple CarPlay.

**Other symbols**


Icon	Meaning
	Check Control message.
	The sound output has been switched off.
	Encrypted connection not active.
	Request for the current vehicle position.
	Checking the current vehicle position.

**Split screen**

**General information**

Additional information can be displayed on the right side of the split screen, for instance information from the trip computer. In the divided screen view, the so-called split screen, this information remains visible even when changing to another menu.

**Switching the split screen on/off**

-  Press the button.
- "Split screen"

**Selecting the display**

The display can be selected in menus which support the split screen function.

- Tilt the Controller to the right until the split screen is selected.
- Press the Controller.
- Select the desired setting.

**Specifying the number of displays**

It is possible to specify the number of displays.

- Tilt the Controller to the right until the split screen is selected.
- Press the Controller.
- "Personalize menu"
- Select the desired setting.
- Tilt the Controller to the left.

**Control elements**

**Overview**



- Control Display
- Controller

**Control Display**

**General information**

To clean the Control Display, follow the vehicle care instructions, refer to page 310.

In the case of very high temperatures on the Control Display, for instance due to intense solar radiation, the brightness may be reduced down to complete deactivation. Once the temperature is reduced, for instance through shade or air conditioning system, the normal functions are restored.

## Safety information

### NOTICE

Objects in the area in the front of the Control Display can slip and damage the Control Display. There is a risk of damage to property, among other potential damage. Do not place objects in the area in front of the Control Display.

## Switching on/off automatically

The Control Display is switched on automatically when the vehicle is unlocked or as soon as the Control Display is needed for operation.

In certain situations, the Control Display is switched off automatically, for instance if no operation is performed on the vehicle for several minutes.

## Switching on/off manually

The Control Display can also be switched off manually.

1.  Press the button.

2. "Turn off control display"

Press the Controller or any button on the Controller to switch it back on again.


## Controller

### General information


The buttons can be used to open the menus directly. The Controller can be used to select menu items and enter the settings.

### Operation


- Turn to switch between menu items, for example.




- Press to select a menu item, for example.



- With navigation system: tilt in four directions to switch between displays, for example.



- Without navigation system: tilt in two directions to switch between displays, for example.



### Buttons on the Controller


Button	Function
	Press once: calls up the main menu. Press twice: displays all menu items of the main menu.
	With navigation system: opens the Communication menu.
	With navigation system: opens the Media/Radio menu.
	Without navigation system: open the Audio menu.
	Without navigation system: opens the Telephone menu.
	With navigation system: opens destination input menu for navigation.
	Call up the CarPlay menu.

Button	Function
	With navigation system: opens navigation map. Without navigation system: call up the CarPlay map.
	Press once: opens the previous display. Press and hold: open the menus used last.
	Call up the Options menu.

## Operating via the Controller

### Opening the main menu

- Press the button.



The main menu is displayed.  
All Central Information Display (CID) functions can be called up via the main menu.

### Adjusting the main menu

- Press the button twice.  
All menu items of the main menu are displayed.
- Select a menu item.
- To move the menu item to the desired position, tilt the Controller to the right or left.



## Selecting menu items

Highlighted menu items can be selected.

1. Turn the Controller until the desired menu item is highlighted.
2. Press the Controller.

## Adjusting menu contents

The display of menus "Media/Radio", "Communication" and "MINI Connected" can be adjusted, for instance to remove the entries of functions that are not used from the menu.

Via the Central Information Display (CID):

1. Select the menu.
2. "Personalize menu"
3. Select desired menu contents to be displayed.

## Dynamic contents

You can display dynamic contents within the menu items. The contents of the menu items update automatically, e.g., the active destination guidance in the navigation.

Via the Central Information Display (CID):

1. "My MINI"
2. "Contents of main menu"

## Changing between displays

After a menu item is selected, for instance "System settings", a new display appears.

- Tilt the Controller to the left.

The current display closes and the previous display is shown.

-  Press the button.

The previous display re-opens.

- Tilt the Controller to the right.  
The new display opens.


An arrow indicates that additional displays can be opened.

## Opening recently used menus

The recently used menus can be displayed.

-  The recently used menus are displayed.

## Going to the Options menu

-  Press the button.

The "Options" menu is displayed.

The menu consists of various areas, for instance:



- "Split screen": screen settings.
- "Media/Radio": control options for the selected main menu.
- "Save station": if applicable, further control options for the selected menu.

## Entering letters and numbers

### Input

1. Turn the Controller: select letters or numbers.
2. **OK** : confirm entry.

### Deleting

Icon	Function
	Press the Controller: delete letters or number.
 or <b>ABC</b>	Hold the Controller down: delete all letters or numbers.

## Using alphabetical lists

For alphabetical lists with more than 30 entries, the letters for which there is an entry are displayed at the left edge.

1. Turn the Controller to the left or right quickly.  
All letters for which there are entries are displayed on the left edge.
2. Select the first letter of the desired entry.  
The first entry of the selected letter is displayed.

## Operation via touchscreen


### General information

Depending on the equipment version, the Control Display is equipped with a touchscreen.

Touch the touchscreen with your fingers. Do not use any objects.

### Opening the main menu

Tap on the icon.



The main menu is displayed.

All Central Information Display (CID) functions can be called up via the main menu.

## Adjusting the main menu

1. Tap on the icon.
2. Drag the menu item to the desired position on the right or left.

## Selecting menu items

Tap the desired menu item.

## Dynamic contents

You can display dynamic contents within the menu items. The contents of the menu items update automatically, e.g., the active destination guidance in the navigation.

Via the Central Information Display (CID):

1. "My MINI"
2. "Contents of main menu"

## Changing between displays

After a menu item is selected, a new display opens.

An arrow indicates that additional displays can be opened.

- Swipe to the left.
- Tap arrow.



The new display opens.

## Entering letters and numbers

### Input

1. Tap the icon on the touchscreen.  
A keyboard is displayed on the Control Display.
2. Enter desired letters and numbers.

## Deleting

Icon	Function
	Tapping the icon: deletes the letter or number.
	Tapping and holding the icon all letters: deletes all letters or numbers.

## Operating navigation map

The navigation map can be moved using the touchscreen.

Function	Operation
Enlarge/shrink map.	Drag in or out with the fingers.



## Programmable memory buttons

### General information



The Central Information Display (CID) functions can be stored on the programmable memory buttons and called up directly, for instance radio stations, navigation destinations, phone numbers and menu entries.

Settings are stored for the driver profile currently used.

### Storing a function

1. Select the function via the Central Information Display (CID).
2. ... Press and hold the desired button, until a signal sounds.

### Executing a function

1. ... Press the button.  
The function will work immediately. This means, for instance that the connec-

tion is established when a phone number is selected.

### Displaying the key assignment

Touch buttons with finger. Do not wear gloves or use objects.

The assignment of the buttons is displayed in the upper area of the Control Display.

### Deleting the button assignments

1. Press buttons 1 and 6 simultaneously for approx. 5 seconds.
2. "OK"

# Voice activation system

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## Principle

Most functions displayed on the Control Display can be operated by voice commands via the voice activation system. The system supports you with announcements during input.

## General information

- Functions that can only be used when the vehicle is stationary can only be operated via the voice activation system to a limited extent.
- The system uses a special microphone on the driver's side.
- >...< in the Owner's Manual denotes verbal instructions to use with the voice activation system.

## Functional requirements

- A language must be set via the Control Display that is supported by the voice

activation system. To set the language, refer to page 47.

- Always say commands in the language of the voice activation system.

## Using the voice activation system

### Activating the voice control system



Press the button on the steering wheel.

Wait for the signal tone.

Say the command.



This icon indicates that the voice activation system is active.

No other commands may be available. In this case, operate the function via the Central Information Display (CID).

### Ending the voice control system



Press the button on the steering wheel or >Cancel<.

## Possible commands

### General information


Most menu items on the Control Display can be spoken as commands.

Commands from other menus can also be spoken.

You can also select list entries such as phone list entries via the voice activation system. Read these list entries out loud exactly as they are shown in the respective list.

## Displaying possible commands

The following is displayed in the top area of the Control Display:


- Some possible commands for the current menu.
- Some possible commands from other menus.
- Status of the speech recognition.
-  Encrypted connection is not available.

## Help on the voice activation system

- >General information on voice control<: have information on the operating principle of the voice activation system read out loud.
- >Help<: have help for the current menu read out loud.

## Example: going to the sound settings

The commands of the menu items are spoken just as they are selected via the Controller.

1. Switch on the Entertainment sound output, if needed.
2.  Press the button on the steering wheel.
3. >Media and radio<
4. >Tone<


## Settings

### Setting the voice control

You can set the system to use standard dialog or a short version.

The short version of the voice control plays back short messages in abbreviated form.


Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Language"
4. "Speech mode:"
5. Select the desired setting.

## Activating speech recognition via the server

The speech recognition feature via the server provides a dictation function and a natural method of destination input while improving the quality of voice recognition. To use the functions, data is transmitted to a service provider via an encrypted connection and stored locally there.

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Language"
4. "Server speech recognition"

## Adjusting the volume

Turn the volume button during the voice guidance until the desired volume is set.

- The volume remains constant even if the volume of other audio sources is changed.
- The volume is stored for the profile currently used.

## Information on Emergency Requests

Do not use the voice activation system to initiate an Emergency Request. In stressful

situations, the voice and vocal pitch can change. This can unnecessarily delay the establishment of a telephone connection.

Instead, use the SOS button, refer to page 298, close to the interior mirror.



## System limits

- Certain noises can be detected and may lead to problems. Keep the doors, windows, and glass sunroof closed.
- Noises from the front passenger or the rear seat bench can impair the system. Avoid making other noise in the vehicle while speaking.
- Major language dialects can cause problems with the speech recognition feature. Speak loud and clear.

## Using the voice activation system of the smartphone

A smartphone connected to the vehicle can be used via voice control.

Activate voice command response on the smartphone for this purpose.

1.  Press and hold the button on the steering wheel for approx. 3 seconds.  
Voice command response is activated on the smartphone.
2.  Release the button.  
If activation is successful, a confirmation appears on the Control Display.

If it was not possible to activate voice command response, the list of Bluetooth devices appears on the Control Display.

# General settings


## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## Language

### Adjusting the language

Via the Central Information Display (CID):


1.  "My MINI"
2. "System settings"
3. If necessary, "Language"
4. "Language:"
5. Select the desired setting.

The setting is stored for the driver profile currently used.

## Time

### Setting the time zone


Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Date and time"
4. "Time zone:"
5. Select the desired setting.

The setting is stored for the driver profile currently used.


### Setting the time

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Date and time"
4. "Time:"
5. Turn the Controller until the desired hours are displayed.
6. Press the Controller.
7. Turn the Controller until the desired minutes are displayed.
8. Press the Controller.

### Setting the time format

Via the Central Information Display (CID):


1.  "My MINI"
2. "System settings"
3. "Date and time"
4. "Time format:"
5. Select the desired setting.

The setting is stored for the driver profile currently used.

## Date

### Setting the date


Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Date and time"

4. "Date:"
5. Turn the Controller until the desired day is displayed.
6. Press the Controller.
7. Make the settings for the month and year.

## Setting the date format

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Date and time"
4. "Date format:"
5. Select the desired setting.


The setting is stored for the driver profile currently used.

## Setting the units of measurement

---

You can set the units of measurement for some values, for example, consumption, distances and temperature.

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Units"
4. Select the desired menu item.
5. Select the desired setting.

The setting is stored for the driver profile currently used.

## Activating/deactivating the display of the current vehicle position


---

### Principle

If vehicle tracking has been activated, the current vehicle position can be displayed in the MINI app.

### Activating/deactivating

Via the Central Information Display (CID):


1.  "My MINI"
2. "Vehicle settings"
3. "Data privacy"
4. "Vehicle tracking"
5. Select the desired setting.

## Activating/deactivating pop-ups

---

For some functions, pop-ups are displayed automatically on the Control Display. Some of these pop-ups can be activated or deactivated.

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Pop-ups"
4. Select the desired setting.

The setting is stored for the driver profile currently used.




## Control Display

---

### Brightness

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Displays"
4. "Control display"
5. "Brightness at night"
6. Turn the Controller until the desired brightness is set.
7. Press the Controller.

The setting is stored for the driver profile currently used.

Depending on the light conditions, the brightness control may not be clearly visible.

## Instrument cluster with enhanced features: color world

---

### Principle

The display of the display content can be configured individually, for instance in a harmonic color style.

### General information

The setting of the color world effects the following display content:


- On-board monitor.
- Instrument cluster.
- Head-up Display.

Depending on the equipment, the color world can be applied as basic display for the LED ring on the central instrument.

LED ring on the central instrument cluster, refer to page [149](#).

## Setting the color world

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Displays"
4. "Color scheme"
5. Select the desired setting.

## Notifications

---

### Principle

The menu centrally displays all messages arriving in the vehicle in list form.

### General information


The following messages can be displayed:

- Traffic messages.
- Communication messages, for example e-mails, SMS text messages or reminders.
- Check Control messages.
- Messages on service notifications.
- Messages from the vehicle manufacturer.

Notifications are additionally displayed in the status field.

### Retrieving notifications

Via the Central Information Display (CID):

1.  "Notifications"
2. Select the desired notification.



The menu in which the notification is displayed will open.

### Deleting notifications

Notifications can be deleted from the list.

Sustained Check Control messages or messages from the vehicle manufacturer with important customer information are displayed as long as they are relevant.

Via the Central Information Display (CID):


1.  "Notifications"
2. Select the desired notification.
3.  Press the button.
4. "Delete this notification" or "Delete all notifications"

## Settings

The following settings can be adjusted:

- Select the applications, from which notifications will be permitted.
- Sort the notifications according to date or priority.

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Notifications"
4. Select the desired setting.

## Data protection

### Data transfer

#### Principle

The vehicle offers various functions which require data to be transferred to MINI or a service provider. The data transfer can be deactivated for some functions.

#### General information


With data transfer deactivated, the respective function cannot be used.

Only make these settings while stationary.

### Activate/deactivate

Follow the instructions on the Control Display.

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Data privacy"
4. Select the desired setting.

## Deleting personal data in the vehicle

### Principle

Depending on the usage, the vehicle stores personal data, such as stored radio stations. This personal data can be permanently deleted via the Central Information Display (CID).

### General information

Depending on the vehicle equipment, the following data is deleted:

- Driver profile settings.
- Stored radio stations.
- Stored programmable memory buttons.
- Travel and trip computer information.
- Music collection.
- Navigation, for instance stored destinations.
- Phone book.
- Office data, for instance voice memos.
- Login accounts.

Altogether, the deletion of the data can take up to 15 minutes.


### Functional requirement

Data can only be deleted while stationary.

## Deleting data

Note and follow the instructions on the Control Display.

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Data privacy"
4. "Delete personal data"
5. "Delete personal data"
6. "OK"
7. Exit and lock the vehicle.

The deletion process takes 15 minutes to complete.

If not all data was deleted, repeat the deletion.

## Canceling deletion

Start the engine to cancel deletion of the data.

## Connections

### Principle

Various connection types are available for using mobile devices in the vehicle. The connection type to select depends on the mobile device and the desired function.

### General information

The following overview shows possible functions and the suitable connection types for them. The range of functions depends on the mobile device.

Function	Connection type
Making calls via the hands-free system.	Bluetooth.
Using phone functions via the Central Information Display (CID).	
Using the smartphone Office functions.	
Playing music from the smartphone or the audio player.	Bluetooth or USB.
Using compatible apps via the Central Information Display (CID).	Bluetooth or USB.
USB storage device:	USB.
Exporting and importing driver profiles.	
Update the software.	
Playing music.	
Playing videos from the smartphone or the USB device.	USB.
Using Apple CarPlay apps via the Central Information Display (CID) and voice operation.	Bluetooth and Wi-Fi.

The following connection types require one-time pairing with the vehicle:

- Bluetooth.
- Apple CarPlay.

Paired devices are automatically recognized later on and connected to the vehicle.

## Safety information

### Warning

Operating the integrated information systems and communication devices while driving can distract from surrounding traffic. It is possible to lose control of the vehicle. There is a risk of accident. Only use the systems or devices when the traffic situation allows. As warranted, stop and use the systems and devices while the vehicle is stationary.

## Compatible devices

### General information

Information on compatible mobile devices is available as follows:


- On the MINI homepage.
- Via Hotline/Customer Support
- At a dealer's service center or another qualified service center or repair shop.

### Displaying the vehicle identification number and software part number

With a search for compatible devices, you may have to state the vehicle identification number and the software part number.

These numbers can be displayed in the vehicle.

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Mobile devices"
4. "Settings"
5. "Bluetooth® info"
6. "System information"

A software update, refer to page 57, can be performed.


## Bluetooth connection

### Functional requirements

- Compatible device, refer to page 52, with Bluetooth interface.
- The vehicle key is in the vehicle.
- The device is ready for operation.
- Bluetooth is activated on the device and in the vehicle, refer to page 52.
- Bluetooth presettings, such as visibility, may be required on the device; refer to the operating instructions of the device.

### Switching on Bluetooth


Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Mobile devices"
4. "Settings"
5. "Bluetooth®"

### Activating/deactivating telephone functions

To use all supported functions of a mobile phone, the following functions must be activated prior to pairing.

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Mobile devices"
4. "Settings"
5. Select the desired setting:
  - "Office"






Activate function to transmit short messages, e-mails, calendars, tasks, memos, and reminders to the vehi-

cle. Costs can be incurred by transmitting all data to the vehicle.

- "Contact images"  
Activate function to show the contact pictures.

## Pairing the mobile device with the vehicle

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Mobile devices"
4. "Connect new device"
5. Select the functions for which the device will be used:
  -  "Telephone"
  -  "Bluetooth® audio"
  -  "Apps"
  -  "Apple CarPlay"

The vehicle's Bluetooth name is displayed on the Control Display.
6. On the mobile device, search for Bluetooth® devices in the surrounding area.  
The Bluetooth name of the vehicle appears on the mobile device display.  
Select the Bluetooth name of the vehicle.
7. Depending on the mobile device, a control number is displayed or the control number must be entered.
  - Compare the control number displayed on the Control Display with the control number on the display of the device.  
Confirm the control number on the device and on the Control Display.
  - Enter and confirm the same control number on the device and via the Central Information Display (CID).

The device is connected and displayed in the device list.

If connection was not successful: Frequently Asked Questions, refer to page 53.

## Frequently Asked Questions

All prerequisites are met and all required steps were completed in the specified order. Despite that, the mobile device does not function as expected.

In this case, the following explanations can help:

Why could the mobile phone not be paired or connected?

- There are too many Bluetooth devices connected to the mobile phone or vehicle.  
Delete Bluetooth connections with other devices.  
Delete all known Bluetooth connections from the device list on the mobile phone and start a new device search.
- The mobile phone is in power-save mode or has only a limited remaining battery life.  
Charge the mobile phone.

Why does the mobile phone no longer react?

- The applications on the mobile phone do not function anymore.  
Switch the mobile phone off and on again.
- Possibly too high or too low ambient temperatures for mobile phone operation.  
Do not subject the mobile phone to extreme ambient temperatures.

Why can phone functions not be used via the Central Information Display (CID)?

- The mobile phone may not be properly configured, for instance as Bluetooth audio device.

Connect the mobile phone with the telephone or additional telephone function.

Why are no or not all telephone book entries displayed or why are they incomplete?

- Transmission of the telephone book entries is not yet complete.
- It is possible that only the telephone book entries of the mobile phone or the SIM card are transmitted.
- It may not be possible to display telephone book entries with special characters.
- It may not be possible to transmit contacts from social networks.
- The number of phone book entries to be stored is too high.
- Data volume of the contact too large, for instance due to stored information such as memos.

Reduce the data volume of the contact.

- A mobile phone is only connected as an audio source.

Reconfigure the mobile phone and connect it with the telephone or additional telephone function.

How can the telephone connection quality be improved?

- The strength of the Bluetooth signal on the mobile phone can be adjusted, depending on the mobile phone.
- Insert the mobile phone into the wireless charging tray.
- Adjust the volume of the microphone and loudspeakers separately.

If all points in this list have been checked and the required function is still not available, contact Customer Relations, a dealer's

service center or another qualified service center or repair shop.

## USB connection

### General information

The following mobile devices can be connected to the USB port:

- Mobile phones.
  - Audio devices with USB port, for instance MP3 players.
  - USB storage devices.
- Common file systems are supported. FAT32 and exFAT are the recommended formats.

A connected USB device will be supplied with charge current via the USB port if the device supports this. Follow the maximum charge current of the USB port.

The following uses are possible on USB ports with data transfer:

- Exporting and importing driver profiles, refer to page 75.
- Playing music files via USB audio.
- Playing videos via USB video.
- Loading of software updates, refer to page 57.

Follow the following when connecting:

- Do not use force when plugging the connector into the USB port.
- Use a flexible adapter cable.
- Protect the USB device against mechanical damage.
- Due to the large number of USB devices available on the market, it cannot be guaranteed that every device is operable on the vehicle.
- Do not expose USB devices to extreme environmental conditions, such as very high temperatures; refer to the operating instructions of the device.

- Due to the many different compression techniques, proper playback of the media stored on the USB device cannot be guaranteed in all cases.
- To ensure proper transmission of the stored data, do not charge a USB device via the onboard socket, when it is connected to the USB port.
- Depending on how the USB device is being used, settings may be required on the USB storage device, refer to the operating instructions of the device.

Not compatible USB devices:

- USB hard drives.
- USB hubs.
- USB memory card readers with multiple slots.
- HFS-formatted USB devices.
- Devices such as fans or bulbs.

### Functional requirement

Compatible device, refer to page 52, with USB port.

### Connecting the device

Connect the USB device using a suitable adapter cable to a USB port, refer to page 228.

The USB device is connected to the vehicle and displayed in the device list.

## Apple CarPlay preparation

### Principle

CarPlay allows select functions of a compatible Apple iPhone to be used via Siri voice control and the on-board monitor.


### Functional requirements

- Compatible iPhone, refer to page 52.

- iPhone 5 or later with iOS 7.1 or later.
- Corresponding mobile contract.
- Bluetooth, Wi-Fi, and Siri voice control are activated on the iPhone.
- Wi-Fi and Bluetooth are enabled in the vehicle.
- If necessary, the setting for mobile data must be activated on the iPhone.

### Turning on Bluetooth and CarPlay

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Mobile devices"
4. "Settings"
5. Select the following settings:
  - "Bluetooth®"
  - "Apple CarPlay"

### Pairing the iPhone with CarPlay

Pairing an iPhone with the vehicle, refer to page 53, via Bluetooth

Select CarPlay as the function:

 "Apple CarPlay"

The iPhone is connected to the vehicle and displayed in the device list, refer to page 56.

### Operation

For more information, refer to the Integrated Owner's Manual or the Owner's Manual for Navigation, Entertainment, Communication.

### Frequently Asked Questions

All prerequisites are met and all required steps were completed in the specified order. Despite that, the mobile device does not function as expected.

In this case, the following explanations can help:

The iPhone has already been paired with Apple CarPlay. When a new connection is set up, CarPlay can no longer be selected.

- Delete the iPhone concerned from the device list.
- On the iPhone, delete the vehicle concerned from the list of stored vehicles under Bluetooth and under Wi-Fi.
- Pair the iPhone as a new device.

If the steps listed have been carried out and the required function is still not available: contact Customer Relations, a dealer's service center or another qualified service center or repair shop.

## Managing mobile devices


### General information

- After one-time pairing, the devices are automatically recognized and reconnected when the ignition is switched on.
- The data stored on the SIM card or in the mobile phone is transferred to the vehicle after recognition.
- For some devices, certain settings may be necessary, for instance authorization, see operating instructions of the device.






### Displaying the device list

All devices paired and/or connected with the vehicle are displayed in the device list.

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Mobile devices"


An icon indicates, for which function a device is used.

Icon	Function
	"Telephone"
	"Additional telephone"
	"Bluetooth® audio"
	"Apps"
	"Apple CarPlay"

### Configuring the device

Functions can be activated or deactivated for paired and connected devices.

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Mobile devices"
4. Select the desired device.
5. Select the desired setting.


If a function is assigned to a device, the function will be deactivated where appropriate for a device that is already connected and the device will be disconnected.

### Disconnecting the device

The device's connection to the vehicle is disconnected.

The device remains paired and can be connected again, refer to page 56.

Via the Central Information Display (CID):


1.  "My MINI"
2. "System settings"
3. "Mobile devices"
4. Select device.
5. "Disconnect device"

### Connecting the device

A disconnected device can be reconnected.




Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Mobile devices"
4. Select device.
5. "Connect device"

The functions that were assigned to the device before disconnecting are assigned to the device when it is reconnected. The functions may be deactivated on a device already connected.

### Deleting the device

Via the Central Information Display (CID):


1.  "My MINI"
2. "System settings"
3. "Mobile devices"
4. Select device.
5. "Delete device"

The device is disconnected and removed from the device list.

### Swapping the telephone and additional telephone

If two mobile phones are connected to the vehicle, the functions of the telephone and additional telephone can be switched.

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Mobile devices"
4. "Settings"
5. "Swap telephone/additional tel."

## Software update

### General information


The vehicle supports a large number of mobile devices, for instance mobile phones and MP3 players. Software updates are available for many of the supported devices. The vehicle is kept up-to-date via regular vehicle software updates.

Contact a dealer's service center or another qualified service center or repair shop for information on available software updates.

### Displaying the version of the installed software

The software version installed in the vehicle is displayed.

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Software update"
4. "Show current version"

If an update has been carried out before, select the desired version to display additional information.

### Updating software via USB

The software may only be updated when the vehicle is stationary.

Via the Central Information Display (CID):

1. Store the file for the software update in the main folder of a USB device.
2. Connecting USB device to the USB port.
3.  "My MINI"
4. "System settings"
5. "Software update"
6. "Update software"
7. "USB"
8. "Install software"


9. "OK"
10. Wait for the update to complete.
11. Confirm system restart.

### Restoring the software version

You can restore the software to the version prior to the last update or to its factory settings.

The software may only be restored when the vehicle is stationary.

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Software update"
4. "Restore software"
5. – "Previous version"
  - The previous software version is restored.
  - "Default software settings"
    - The first software version is restored.
6. "Remove software"
7. "OK"
8. Wait for software restore.
9. Confirm system restart.

# Owner's Manual media

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## General information

You can use the following media formats to call up the content in the Owner's Manual:

- Printed Owner's Manual, refer to page 59.
- Integrated Owner's Manual in the vehicle, refer to page 59.

## Printed Owner's Manual

### Principle

The printed Owner's Manual describes all standard, country-specific, and optional equipment offered with the series.

### General information

The Owner's Manual for Navigation, Entertainment, and Communication can be obtained as a printed book from the service center.

## Supplementary Owner's Manuals



Also follow the Supplementary Owner's Manuals, which are included in addition to the onboard literature.

## Integrated Owner's Manual in the vehicle

### Principle

The Integrated Owner's Manual specifically describes features and functions found in the vehicle. The Integrated Owner's Manual can be displayed on the Control Display.

### Selecting the Owner's Manual

1.  Press the button.
2.  "My MINI"
3. "Owner's Manual"
4. Select the desired method of accessing the contents.

### Scrolling through the Owner's Manual

Turn the Controller, until the next or previous contents are displayed.

### Context help

### General information

The section of the Owner's Manual relating to the function that is currently selected can be displayed directly.

## Opening via Central Information Display (CID)

Change directly to the Options menu from the function on the Control Display:

1.  Press the button.
2. "Owner's Manual"




## Opening when a Check Control message is displayed

Directly from the Check Control message on the Control Display:

1.  "Owner's Manual"

## Changing between a function and the Owner's Manual

To switch from a function, for instance radio, to the Owner's Manual on the Control Display and to alternate between the two displays:

1.  Press the button.
2. "Owner's Manual"
3. Select the desired page in the Owner's Manual.
4.  Press the button again to return to the last displayed function.
5.  Press the button to return to the page of the Owner's Manual displayed last.

To alternate continuously between the last displayed function and the last displayed page of the Owner's Manual, repeat steps 4 & 5. Opens a new display every time.



# Opening and closing

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## Vehicle key

### General information

Two vehicle keys are included in the scope of delivery, each containing an integrated key.

Each vehicle key contains a replaceable battery, refer to page 65.

Depending on the equipment and country version, various settings, refer to page 78, can be configured for the button functions.

A personal driver profile, refer to page 75, for each vehicle key is stored in the vehicle.

To provide information on maintenance recommendations, the service data is stored in the vehicle key, refer to page 290.

To prevent possible locking in of the vehicle key, take the vehicle key with you when exiting the vehicle.

## Safety information

### Warning

The vehicle key has a button cell battery. Batteries or button cell batteries can be swallowed and lead to serious or fatal injuries within two hours, for example, due to internal burns or chemical burns. There is a risk of injury or danger to life. Keep the vehicle key and batteries out of reach of children. Immediately seek medical help if there is any suspicion that a battery or button cell battery has been swallowed or is located in any part of the body.

### Warning

People or animals in the vehicle can lock the doors from the inside and lock themselves in. In this case, the vehicle cannot be opened from the outside. There is a risk of injury. Take the vehicle key with you so that the vehicle can be opened from the outside.


### Warning

Unattended children or animals in the vehicle can cause the vehicle to move and endanger themselves and traffic, for instance due to the following actions:

- Pressing the Start/Stop button.
- Releasing the parking brake.
- Opening and closing the doors or windows.
- Engaging selector lever position N.
- Using vehicle equipment.

There is a risk of accidents or injuries. Do not leave children or animals unattended in the vehicle. Take the vehicle key with you when exiting and lock the vehicle.

## Overview



- 1 Unlocking
- 2 Locking
- 3 Unlocking the tailgate  
With automatic trunk lid actuation:  
open the tailgate
- 4 Panic mode

## Unlocking

 Press the button on the vehicle key.

Depending on the settings, refer to page 78, the following access points are unlocked.

- Driver's door and fuel filler flap.  
Press the button on the vehicle key again to unlock the other vehicle access points.
- All doors, tailgate, and fuel filler flap.

In addition, the following functions are executed:


- Unlocking is confirmed by the turn signals and the horn. This function must be

activated in the settings, refer to page 78.

- The settings stored in the driver profile, refer to page 75, are applied.
- The driver's seat is set to the last seat position saved in the driver profile. This function must be activated in the settings, refer to page 78.
- The interior lights, refer to page 159, and the MINI logo projection are switched on, provided that the interior lights were not switched off manually.
- Depending on the settings, the welcome light and pathway lighting, refer to page 156, are switched on.
- The alarm system, refer to page 79, is switched off.


The lighting functions may depend on the ambient brightness.

## Convenient opening

 Press and hold the button on the vehicle key after unlocking.

The windows and the glass sunroof are opened, as long as the button on the vehicle key is pressed.

## Locking

1. Close the driver's door.
2.  Press the button on the vehicle key.

The following functions are executed:

- All doors, the tailgate, and the fuel filler flap are locked.
- Locking is confirmed by the turn signals and the horn. This function must be activated in the settings, refer to page 78.
- The alarm system, refer to page 79, is switched on.

If the engine or ignition is still switched on when you lock the vehicle, the vehicle horn honks twice. In this case, the engine or ignition must be switched off by means of the Start/Stop button.

## With Comfort Access: convenient closing

### Safety information

#### Warning

With convenient closing, body parts can be jammed. There is a risk of injury. Make sure that the area of movement of the doors is clear during convenient closing.

### Closing



Press and hold the button on the vehicle key in close range to the vehicle.

The windows and the glass sunroof are closed, as long as the button on the vehicle key is pressed.

## Switch on interior lights and courtesy lights



Press the button on the vehicle key with the vehicle locked.

The MINI logo projection is also switched on.

These functions are not available if the interior lights were switched off manually.

The lighting functions may depend on the ambient brightness.

After locking, wait 10 seconds before pressing the button again.

## Tailgate

### General information

To avoid locking the vehicle key in the vehicle, do not place the vehicle key in the cargo area.

Depending on the equipment and country version, it is possible to specify whether the tailgate can be activated with the vehicle key and how the vehicle doors will respond to this. To perform settings, refer to page 78.

### Safety information

#### Warning

Body parts can be jammed when operating the tailgate. There is a risk of injury. Make sure that the travel path of the tailgate is clear during opening and closing.

#### Warning

The tailgate swings back and up when it opens. There is a risk of injury or risk of damage to property. Make sure that the travel path of the tailgate is clear during opening and closing.

#### NOTICE

Sharp-edged or pointed objects can hit the windows and heating elements while driving. There is a risk of damage to property, among other potential damage. Cover the edges and ensure that pointed objects do not hit the windows.

### Opening



Press and hold the button on the vehicle key for approx. 1 second.



Without automatic trunk lid actuation:


The tailgate is unlocked and can be swung upward.

With automatic trunk lid actuation:

The tailgate opens automatically.

## Panic mode

You can trigger the alarm system if you find yourself in a dangerous situation.

-  – Press the button on the vehicle key and hold for at least 3 seconds.
- Briefly press the button on the vehicle key three times in succession.


To switch off the alarm: press any button.

## Replacing the battery

### NOTICE

Improper batteries in a battery-operated device can damage the device. There is a risk of damage to property. Always replace the discharged battery with a battery with the same voltage, the same size and the same specification.


1. Remove the integrated key from the vehicle key, refer to page 67.
2. Slide the integrated key into the opening and raise the cover. The battery compartment is accessible.



3. Slide the integrated key in the cover of the battery compartment and raise the cover.



4. Push battery in arrow direction using a pointed object and lift it out.



5. Insert a type CR 2032 3V battery with the positive side facing up.
6. Insert lid and cover.
7. Push the integrated key into the vehicle key until it engages.



Have old batteries disposed of by a dealer's service center or another qualified service center or repair shop or take them to a collection point.

## Additional vehicle keys

Additional vehicle keys are available from a service center or another qualified service center or repair shop.

## Loss of vehicle keys

A lost vehicle key can be disabled and replaced by a dealer's service center or an-

other qualified service center or repair shop.

## Malfunction

### General information

A Check Control message is displayed.

Vehicle key detection by the vehicle may malfunction under the following circumstances:

- The battery of the vehicle key is discharged. For replacing the battery, refer to page 65.
- Fault of the radio link from transmission towers or other equipment with high transmitting power.
- Shielding of the vehicle key due to metal objects.

Do not transport the vehicle key together with metal objects.

- Fault of the radio link from mobile phones or other electronic devices in direct proximity to the vehicle key.

Do not carry the vehicle key in close proximity to other electronic devices.

- Fault of radio transmission by a charging process of mobile devices, for instance charging of a mobile phone.
- The vehicle key is in direct proximity of the wireless charging tray.

Place the vehicle key in a different location.

In the case of interference, the vehicle can be unlocked and locked from the outside with the integrated key, refer to page 67.

## Starting the engine via emergency detection of the Vehicle key



It is not possible to start the engine if the vehicle key has not been detected.

Proceed as follows in this case:

1. Hold the vehicle key against the mark on the steering column as shown. Pay attention to the display in the instrument cluster.
2. If the vehicle key is detected:  
Start the engine within 10 seconds.

If the vehicle key is not recognized, slightly change the position of the vehicle key and repeat the procedure.

## Frequently Asked Questions

What precautions can be taken to be able to open a vehicle with an accidentally locked in vehicle key?

- The options provided by the Remote Services of the MINI Connected app include the ability to lock and unlock a vehicle.

This requires an active MINI Connected contract and the MINI Connected app must be installed on a smartphone.

- Unlocking the vehicle can be requested via the MINI Connected Call Center.  
An active MINI Connected contract is required.

## Integrated key

### General information


The driver's door can be locked and unlocked without the vehicle key using the integrated key.

### Safety information

#### NOTICE

The door lock is permanently joined with the door. The door handle can be moved. When pulling the door handle with the integrated key inserted, paint or the integrated key can be damaged. There is a risk of damage to property, among other potential damage. Remove the integrated key before pulling the external door handle.

### Removing




Press the button, arrow 1, and pull out the integrated key, arrow 2.

### Locking/unlocking via the door lock

1. Remove cover cap on the door lock.

To do this, slide the integrated key into the opening to the stop from below and remove the cover cap.



2. Unlock or lock the door lock using the integrated key.

The other doors must be unlocked or locked from the inside.

### Alarm system

The alarm system is not switched on if the vehicle is locked with the integrated key.

The alarm system is triggered when the door is opened, if the vehicle has been unlocked via the door lock.

## Buttons for the central locking system

### General information


In the event of a severe accident, the vehicle is automatically unlocked. The hazard warning system and interior lights come on.

## Overview




Buttons for the central locking system.

## Locking


 Press the button with the front doors closed.

- The fuel filler flap remains unlocked.
- The vehicle is not secured against theft when locking.

## Unlocking

 Press the button.

## Opening

-  Press button to unlock the doors together, and then pull the door handle above the armrest.
- Front doors: pull the door handle on the door to open the door. The other doors remain locked.
- Back doors: pull twice on the door handle on the door to be opened; the first time unlocks the door, the second time opens it. The other doors remain locked.

## Comfort Access

### Principle

The vehicle can be accessed without operating the vehicle key.

Carrying the vehicle key with you, e.g., in your pants pocket, is sufficient.

The vehicle automatically detects the vehicle key when it is in close proximity or in the interior.

### General information

Comfort Access supports the following functions:

- Unlocking and locking the vehicle.
- Convenient closing.
- Open the tailgate.
- Contactless trunk opening/closing.


This function must be activated in the settings, refer to page 78.

This function is not available in vehicles with a trailer hitch or with a rear-mounted luggage rack preparation.

### Functional requirements

- To lock the vehicle, the vehicle key must be outside of the vehicle near the doors.
- The next unlocking and locking cycle is not possible until after approx. 2 seconds.

## Unlocking




Press the button on the external door handle of the driver's or front passenger door.

Depending on the settings, refer to page 78, only the driver's door and the fuel filler flap may be unlocked. Unlike when unlocking using the vehicle key, pressing the button on the external door handle again does not unlock the other vehicle access points. Rather, the vehicle is locked again.

If the vehicle was locked automatically after driving off or with the button of the central locking system from the inside, note the following: if a door on a locked vehicle is opened from the inside with the door opener, pressing the button on the external door handle will first lock the vehicle again. To unlock, the button on the external door handle must be pressed again.

## Locking



Press the button on the external door handle of the driver's or front passenger door.


## Convenient closing

### Safety information

#### Warning

With convenient closing, body parts can be jammed. There is a risk of injury. Make sure that the area of movement of the doors is clear during convenient closing.

### Closing



Press and hold down the button on the external door handle of the driver's or front passenger door.

In addition to locking, the windows and glass sunroof will be closed.

## To open the tailgate

### General information

If the tailgate is opened via Comfort Access, locked doors are not unlocked.

To avoid locking the vehicle key in the vehicle, do not place the vehicle key in the cargo area.

## Safety information

### **Warning**

Body parts can be jammed when operating the tailgate. There is a risk of injury. Make sure that the travel path of the tailgate is clear during opening and closing.

### **Warning**

The tailgate swings back and up when it opens. There is a risk of injury or risk of damage to property. Make sure that the travel path of the tailgate is clear during opening and closing.

### **NOTICE**

Sharp-edged or pointed objects can hit the windows and heating elements while driving. There is a risk of damage to property, among other potential damage. Cover the edges and ensure that pointed objects do not hit the windows.

## Opening



Press button next on tailgate.

Without automatic trunk lid actuation:

The tailgate is unlocked and can be swung upward.

With automatic trunk lid actuation:

The tailgate opens automatically.

## With automatic trunk lid actuation: touchless opening and closing of tailgate

### Principle

The trunk can be opened and closed contactless using the vehicle key you are carrying. Two sensors detect a forward-directed foot movement in the central rear area and the tailgate is opened or closed.

### General information

To avoid locking the vehicle key in the vehicle, do not place the vehicle key in the cargo area.

This function is not available in vehicles with a trailer hitch or with a rear-mounted luggage rack preparation.

If the vehicle key is in the sensor area, the tailgate may open or close inadvertently if you unintentionally move your foot or if a foot movement is detected.

The sensor has an approximate range of 5 ft/1.50 m extending from the rear area.

If the trunk is opened contactless, locked doors are not unlocked.

Contactless trunk opening and closing must be activated in the settings.

## Safety information

### **Warning**

During no-touch activation, vehicle parts may be touched, such as the hot exhaust system. There is a risk of injury. When moving your foot, make sure you have a firm stance and do not touch the vehicle.

**⚠ Warning**

Body parts can be jammed when operating the tailgate. There is a risk of injury. Make sure that the travel path of the tailgate is clear during opening and closing.

**⚠ Warning**

The tailgate swings back and up when it opens. There is a risk of injury or risk of damage to property. Make sure that the travel path of the tailgate is clear during opening and closing.

**Settings**

1. "My MINI"
2. "Vehicle settings"
3. "Doors/Key"
4. "Tailgate"
5. Select the desired setting:
  - "Open by foot movement"  
Contactless trunk opening is switched on or off.
  - "Close by foot movement"  
Contactless trunk closing is switched on or off.

**Performing the foot movement**

1. Stand in the middle behind the vehicle at approx. one arm's length away from the rear of the vehicle.
2. Wave a foot under the vehicle in the driving direction and immediately pull it

back. With this movement, the leg must pass through the ranges of both sensors.

**Opening**

Perform the foot movement described earlier.

Before the opening, the hazard warning system flashes.

If contactless closing is switched on:

Moving a foot again will stop the opening procedure.

The subsequent foot movement will close the tailgate again.

**Closing**

Perform the foot movement described earlier.

Before closing, the hazard warning system flashes and an acoustic signal sounds.

Moving a foot again will stop the closing process.

When the touchless opening is switched on: the subsequent foot movement will open the tailgate again.

**System limits**

The detection of the foot movement may be limited due to the following external conditions:

- Ice, snow or slush on the rear of the vehicle.
- Dirt or road salt on the rear of the vehicle.

Movement in the range of the sensors may cause unintended opening or closing of the cargo area, for instance due to water running own when cleaning the vehicle or with heavy rainfall. To prevent such unintended opening or closing of the cargo area in such cases, keep the vehicle key at a sufficient distance from the rear of the vehicle.

### Malfunction

Vehicle key detection by the vehicle may malfunction under the following circumstances:

- The battery of the vehicle key is discharged. For replacing the battery, refer to page 65.
- Fault of the radio link from transmission towers or other equipment with high transmitting power.
- Shielding of the vehicle key due to metal objects.  
Do not transport the vehicle key together with metal objects.
- Fault of the radio link from mobile phones or other electronic devices in direct proximity to the vehicle key.  
Do not carry the vehicle key in close proximity to other electronic devices.

Wet or snowy conditions may disrupt the locking request detection on the door handles.

In the case of a malfunction, unlock and lock the vehicle using the buttons of the vehicle key or use the integrated key, refer to page 67.

## Tailgate

### General information

To avoid locking the vehicle key in the vehicle, do not place the vehicle key in the cargo area.

Depending on the equipment and country version, it is possible to specify whether the tailgate can be activated with the vehicle key and how the vehicle doors will respond to this. To perform settings, refer to page 78.

### Safety information

#### Warning

Body parts can be jammed when operating the tailgate. There is a risk of injury. Make sure that the travel path of the tailgate is clear during opening and closing.

#### Warning

The tailgate swings back and up when it opens. There is a risk of injury or risk of damage to property. Make sure that the travel path of the tailgate is clear during opening and closing.

#### NOTICE


Sharp-edged or pointed objects can hit the windows and heating elements while driving. There is a risk of damage to property, among other potential damage. Cover the edges and ensure that pointed objects do not hit the windows.



## Without automatic trunk lid actuation

### Opening from the outside




- Without Comfort Access: unlock vehicle.  
With Comfort Access: unlock the vehicle or have the vehicle key with you.  
Press button next on tailgate.
-  Press and hold the button on the vehicle key for approx. 1 second.


Depending on the setting, the doors may also be unlocked. Unlocking using the vehicle key, refer to page 64.

The tailgate is unlocked and can be swung upward.

### Opening from the inside

 With Steptronic transmission:  
With the vehicle stationary, pull the button in the storage compartment of the driver's door upwards.

If the vehicle is locked, selector lever position P must be engaged first.

 With manual transmission:  
With the vehicle stationary, pull the button in the storage compartment of the driver's door upwards twice in quick succession.

## Closing



Recessed grips on the interior trim of the tailgate can be used to conveniently pull down the tailgate.

## With automatic trunk lid actuation


### Opening

#### Adjusting the opening height

You can set how far the tailgate should open.


When adjusting the opening height, ensure that there is a clearance of at least 4 in/10 cm above the tailgate.

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle settings"
3. "Doors/Key"
4. "Tailgate"
5. Monitor the tailgate and set the desired opening height.

### From the outside





- Without Comfort Access: unlock vehicle.  
With Comfort Access: unlock the vehicle or have the vehicle key with you.  
Press the button on the outer side of the tailgate.
-  Press and hold the button on the vehicle key for approx. 1 second.

Depending on the setting, the doors may also be unlocked. Unlocking using the vehicle key, refer to page 64.

If the vehicle is stationary, the tailgate opens automatically to the adjusted opening height.

### From the inside

-  With Steptronic transmission:  
Pull button in the storage compartment of the driver's door upward.  
If the vehicle is locked, selector lever position P must be engaged first.

-  With manual transmission:  
With the vehicle stationary, pull the button in the storage compartment of the driver's door upwards twice in quick succession.

If the vehicle is stationary, the tailgate opens automatically to the adjusted opening height.

### Interruption of the opening procedure

The opening procedure is interrupted in the following situations:

- When the vehicle starts moving.
- By pressing the button on the outer side of the tailgate. Pressing again closes the tailgate.
- By pressing the button on the inside of the tailgate. Pressing again closes the tailgate.
- By pressing the button on the vehicle key. Pressing again continues the opening procedure.
- By pressing or pulling the button in the storage compartment of the driver's door. Pulling again continues the opening procedure.

### Closing

#### From the outside

Press the button on the outer side of the tailgate.

#### From the inside


-  Press and hold the button in the storage compartment of the driver's door.

The vehicle key must be located in the interior for this function.

An acoustic signal sounds before the tailgate is closed.

#### From inside the tailgate

Without Comfort Access:



Press the button on the inside of the tailgate.

With Comfort Access:



- Press button on the inside of the tailgate, arrow 1.
  - Press button, arrow 2.
- The vehicle will be locked after closing the tailgate. The driver's door must be closed for this purpose and the vehicle key must be outside of the vehicle in the area of the tailgate.

### Interruption of the closing procedure

The closing procedure is interrupted in the following situations:

- If the vehicle drives off with a jerky movement.
- By pressing the button on the outer side of the tailgate. Pressing again closes the tailgate.

- By pressing the button on the inside of the tailgate. Pressing again closes the tailgate.
- By releasing the button in the storage compartment of the driver's door. Pressing again and holding continues the closing motion.

### Malfunction

### Safety information

#### Warning

With manual operation of a blocked tailgate, it can release itself unexpectedly from the blocking. There is a risk of injury or risk of damage to property. Do not operate the tailgate manually if it is blocked. Have it checked by a dealer's service center or another qualified service center or repair shop.

### Manual operation

Operate the unlocked tailgate manually with a slow and smooth motion.

To close the tailgate fully, press down lightly only. Closing occurs automatically.

## Driver profiles

### Principle

In the driver profiles, individual settings for several drivers can be stored and called up again when required.

### General information

There are three driver profiles with which personal vehicle settings can be stored. Every vehicle key has been assigned one of these driver profiles.

If the vehicle is unlocked using the vehicle key, the assigned personal driver profile will be activated. All settings stored in the driver profile are automatically applied.

If several drivers use their own vehicle keys, the vehicle will apply the personal settings as it is being unlocked. These settings are also restored, if the vehicle has been used in the meantime by a person with a different vehicle key.

Changes to the settings are automatically stored in the driver profile currently activated.

If another driver profile is selected via the Central Information Display (CID), the settings stored in it will be applied automatically. The new driver profile is assigned to the vehicle key that is currently in use.

There is an additional guest profile available that is not assigned to any vehicle key: it can be used to apply settings in the vehicle without changing the personal driver profiles.

## Functional requirements

For the system to be able to identify the driver profile associated to a particular driver, the detected vehicle key must be clearly allocated to the driver.

This is the case when:

- The driver is only carrying his or her own vehicle key.
- The driver unlocks the vehicle.
- The driver gets into the vehicle through the driver's door.

## Settings

The settings, for instance for the following systems and functions, are stored in the active profile. The scope of storable settings depends on country and equipment.

- Unlocking and locking.
- Lights.
- Radio.
- Instrument cluster.
- Programmable memory buttons.
- Volumes, sound.
- Control Display.
- Climate control.
- Navigation.
- Park Distance Control.
- Rearview camera.
- Head-up Display.
- MINI Driving Modes.
- Intelligent Safety.
- Driver's seat position, exterior mirror position.


Both the positions saved via the seat memory and the last position set are saved.

## Profile management

### Selecting a driver profile

Regardless of the vehicle key in use, a different driver profile may be activated. This allows you to call up personal vehicle settings, even if you did not unlock the vehicle with your own vehicle key.

Via the Central Information Display (CID):

1.  "My MINI"
2. "Driver profiles"
3. Select driver profile.
4. "OK"

- All settings stored in the selected driver profile are automatically applied.
- The called-up driver profile is assigned to the vehicle key being used at the time.
- If the driver profile is already assigned to a different vehicle key, this driver profile will be valid for both vehicle keys.

### Using a guest profile

The guest profile is for individual settings that are stored in none of the three personal driver profiles.

Via the Central Information Display (CID):



1.  "My MINI"
2. "Driver profiles"
3. "Drive off (guest)"
4. "OK"

The guest profile cannot be renamed. It is not assigned to the vehicle key currently in use.

### Renaming a driver profile

A personal name can be assigned to the active driver profile to avoid confusion between the driver profiles.



Via the Central Information Display (CID):

1.  "My MINI"
2. "Driver profiles"
3. Select driver profile.
  -  The driver profile marked with this icon can be renamed.
4. "Change driver profile name"
5. Enter profile name.
6. **OK** Select the icon.

### Resetting a driver profile

The settings of the driver profile currently in use are reset to their factory settings.

Via the Central Information Display (CID):


1.  "My MINI"
2. "Driver profiles"
3. Select driver profile.
  -  The driver profile marked with this icon can be reset.
4. "Reset driver profile"
5. "OK"

### Exporting driver profiles

Most settings of the active driver profile can be exported.

Exporting is helpful when storing and retrieving personal settings, for instance prior to a workshop visit. The stored driver profiles can be taken into another vehicle.

Via the Central Information Display (CID):

1.  "My MINI"
2. "Driver profiles"
3. Select driver profile.
  -  The driver profile marked with this icon can be exported.
4. "Export driver profile (USB)"
  - Select USB storage device as needed.

### Importing driver profiles

Profiles stored on a USB device can be imported via the USB port.

The existing settings of the active driver profile are overwritten with the settings of the imported driver profile.

Via the Central Information Display (CID):

1.  "My MINI"
2. "Driver profiles"
3. Select the driver profile to overwrite.


 The driver profile marked with this icon can be overwritten.

4. "Import driver profile (USB)"  
Select USB storage device as needed.
5. Select the driver profile to be imported.

### Displaying driver profiles during start

The driver profiles can be displayed at each startup to select the desired profile.

Via the Central Information Display (CID):

1.  "My MINI"
2. "Driver profiles"
3. "Show driver profiles at startup"

### System limits

A clear assignment between the vehicle key and driver may not be possible in the following cases, for example.

- The front passenger unlocks the vehicle with his or her own vehicle key, but another person is driving.
- The driver unlocks the vehicle via Comfort Access and has multiple vehicle keys with him or her.
- The driver changes, but the vehicle is not locked and unlocked.
- Multiple vehicle keys are located in the outer area of the vehicle.

## Settings

### General information


Depending on the package and country version, various settings are available for the vehicle key functions.

These settings are stored for the driver profile, refer to page 75, currently used.

## Unlocking



### Doors

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle settings"
3. "Doors/Key"
4. "Driver's door" or "All doors"
5. Select the desired setting:
  - "Driver's door only"  
Only the driver's door and the fuel filler flap are unlocked. Pressing again unlocks the entire vehicle.
  - "All doors"  
The entire vehicle is unlocked.

### Tailgate

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle settings"
3. "Doors/Key"
4.   
The text next to the icon indicates the current setting.
5. Select the desired setting:
  - "Tailgate"  
Depending on your vehicle's optional features, the tailgate is either unlocked or opened.
  - "Tailgate and door(s)"  
Depending on your vehicle's optional features, the tailgate is either unlocked or opened and the doors unlocked.
  - "Tailgate opens after unlocking"

The vehicle must be unlocked before the tailgate can be used with the vehicle key.



- "Button lock"

The operation of the tailgate via the vehicle key is disabled.

Depending on the vehicle equipment and country version, this setting may not be offered.

### Adjusting the last seat and mirror position

Via the Central Information Display (CID):


1.  "My MINI"
2. "Driver profiles"
3. Select driver profile.
  -  The setting can be made for the driver profile marked with this icon.
4. "Last seat position automatic"

When the vehicle is unlocked, the driver's seat and exterior mirrors resume their last set positions.

The most recent position is independent of the positions saved via the seat memory.

### Automatic locking

Via the Central Information Display (CID):


1.  "My MINI"
2. "Vehicle settings"
3. "Doors/Key"
4. Select the desired setting:
  - "Lock automatically"
 

The vehicle locks automatically after a while if no door is opened after unlocking.
  - "Lock after starting to drive"
 

The vehicle locks automatically after you drive off.

### Automatic unlocking


Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle settings"
3. "Doors/Key"
4. "Unlock at end of trip"

After the engine is switched off by pressing the Start/Stop button, the locked vehicle is automatically unlocked.

### Confirmation signals from the vehicle

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle settings"
3. "Doors/Key"
4. Deactivate or activate the desired confirmation signals.
  - "Flash for lock/unlock"
 

Unlocking is signaled by blinking twice, locking by blinking once.
  - With alarm system:
 

"Acoustic signal for lock/unlock"

Unlocking is signaled by one honk of the horn.

## Alarm system

### General information

When the vehicle is locked, the vehicle alarm system reacts to the following changes:

- Unauthorized opening of a door, the hood or the tailgate.
- Movements in the vehicle interior.


- Changes in the vehicle inclination, for instance, during attempts at stealing a wheel or when towing the vehicle.
- Disconnected battery voltage.
- Improper use of the socket for OBD on-board diagnostics.
- Locking the vehicle while a device is connected to the socket for the diagnostic socket. For socket for the OBD on-board diagnostics, refer to page 291.

The alarm system signals these changes visually and acoustically:


- Acoustic alarm:  
Depending on local regulations, the acoustic alarm may be suppressed.
- Optical alarm:  
By blinking of the hazard warning system and headlights, where required.

Do not modify the system to ensure function of the alarm system.

## Overview



Indicator light in the roof fin.



Indicator light on the interior mirror.

## Turning on/off

The alarm system is switched on or off as soon as the vehicle is locked with the vehicle key or unlocked or locked via Comfort Access.

## Opening the doors with the alarm system switched on

The alarm system is triggered when a door is opened if the door was unlocked using the integrated key in the door lock.

End alarm, refer to page 81.


## Opening the tailgate with the alarm system switched on

The tailgate can be opened even when the alarm system is switched on.

After the tailgate is closed, it is locked and monitored again provided the doors are locked. The hazard warning system flashes once.

## Panic mode

You can trigger the alarm system if you find yourself in a dangerous situation.

-  - Press the button on the vehicle key and hold for at least 3 seconds.
- Briefly press the button on the vehicle key three times in succession.



To switch off the alarm: press any button.

## Signals of the indicator lights

- The indicator light flashes briefly every 2 seconds:  
The alarm system is switched on.
- Indicator light flashes for approx. 10 seconds, then it flashes briefly every 2 seconds:

Interior motion sensor and tilt alarm sensor are not active, as doors, hood, or tailgate are not correctly closed. Correctly closed access points are secured.

Interior motion sensor and tilt alarm sensor are not active, as doors, hood, or trunk lid are not correctly closed. Correctly closed access points are secured.

When the still open access points are closed, the interior motion sensor and tilt alarm sensor will be switched on.

- The indicator light goes out after unlocking:  
The vehicle has not been tampered with.
- The indicator light flashes after unlocking until the engine ignition is switched on, but no longer than approx. 5 minutes:  
An alarm has been deployed.

## Tilt alarm sensor

The inclination of the vehicle is monitored. The alarm system responds in situations such as attempts to steal a wheel or when the vehicle is towed.

## Interior motion sensor

The windows and the glass sunroof must be closed for the system to function properly.

## Avoiding unintentional alarms

### General information

The tilt alarm sensor and interior motion sensor can trigger an alarm, although no unauthorized action occurred.

Possible situations for an unwanted alarm:

- In car washes.
- In duplex garages.
- During transport on trains carrying vehicles, at sea or on a trailer.
- With animals in the vehicle.
- When the vehicle is locked after start of refueling.

The tilt alarm sensor and the interior motion sensor can be switched off in such situations.

### Switching off the tilt alarm sensor and interior motion sensor



Press the button on the vehicle key within 10 seconds as soon as the vehicle is locked.

The indicator light lights up for approx. 2 seconds and then continues to flash.

The tilt alarm sensor and interior motion sensor are switched off until the vehicle is locked again.

### Ending the alarm

- Unlock the vehicle with the vehicle key.
- Unlock the vehicle with the integrated key and switch on the ignition using the emergency detection of the vehicle key, refer to page 66.
- With Comfort Access: if you have the vehicle key with you, unlock the vehicle using the button on the driver's side or front passenger side door.

## Power windows

### General information

If an accident of a certain severity occurs, the windows are automatically closed except a gap.

### Safety information

#### Warning

When operating the windows, body parts and objects can be jammed. There is a risk of injury or risk of damage to property. Make sure that the travel path of the windows is clear during opening and closing.



### Overview



 Power windows.

 Safety switch.



### Opening

-  Press the switch to the resistance point.  
The window opens while the switch is being held.
-  Press the switch beyond the resistance point.

The window opens automatically. Pressing the switch again stops the motion.

Convenient opening with the vehicle key, refer to page 63.

### Closing

-  Pull the switch to the resistance point.  
The window closes while the switch is being held.
-  Pull the switch beyond the resistance point.  
The window closes automatically if the door is closed. Pulling the switch again stops the motion.

Convenient closing with the vehicle key, refer to page 64.

Closing via Comfort Access, refer to page 69.

### Jam protection system

#### Principle

The jam protection prevents objects or body parts becoming jammed between the door frame and window while a window is being closed.

#### General information

If resistance or a blockage is detected while a window is being closed, the closing action is interrupted.


### Safety information

#### Warning


Accessories on the windows such as antennas can impact jam protection. There is a risk of injury. Do not install accessories in the area of movement of the windows.

## Closing without the jam protection system

In case of danger from the outside or if icing might prevent normal closing, proceed as follows:

1.  Pull the switch past the resistance point and hold it there.

The window closes with limited jam protection. If the closing force exceeds a specific threshold, closing is interrupted.

2.  Pull the switch past the resistance point again within approx. 4 seconds and hold it there.

The window closes without jam protection.

## Safety switch

### General information

The safety switch can be used to prevent children, for instance from opening and closing the rear windows using the switches in the rear.

If an accident of a certain severity occurs, the safety function is switched off automatically.

### Turning on/off

 Press the button.

The LED lights up if the safety function is switched on.

## Malfunction

### General information

In certain situations a window can only be operated to a limited extent.

- After a power interruption during the opening or closing process, the window

can only be operated to a limited extent. The system must be initialized in this case.

- The power window motors are equipped with overheating protection. If a window is opened and closed several times within a short period of time, the overheating protection switches the motor off temporarily. Depending on the degree of overheating, it may only be possible to close the window or it may not be possible to operate it at all.

In this case: allow the power window motor to cool down.



## Initializing the system

The system can be initialized when the vehicle is stationary and the engine is running.

During initialization, the affected window closes without jam protection.

### Warning

When operating the windows, body parts and objects can be jammed. There is a risk of injury or risk of damage to property. Make sure that the travel path of the windows is clear during opening and closing.

1. Open the affected window completely.
2.  Pull the switch to the resistance point and hold. The window closes.
3.  Continue holding the switch pulled to the resistance point. The window opens and closes once or twice after approx. 15 seconds, depending on the vehicle's equipment.
4. Release switch.

## Panoramic glass sunroof

### General information

In the event of a severe accident, the glass sunroof is automatically closed.

### Safety information

#### Warning

Body parts can be jammed when operating the glass sunroof. There is a risk of injury. Make sure that the area of movement of the glass sunroof is clear during opening and closing.

### Overview



### Tilting the glass sunroof



Press back the switch up to or beyond the resistance point and release it.

The glass sunroof is raised.

### Opening glass sunroof

#### When the glass sunroof is closed




Press the switch back beyond the resistance point and release it twice.

The glass sunroof is opened.

Pressing the switch again stops the motion.

### With the glass sunroof completely raised



– Slide switch back to the resistance point and hold.

The glass sunroof is opened as long as the switch is pressed.

– Press the switch back beyond the resistance point and release it.

The glass sunroof is opened.

Pressing the switch again stops the motion.


### Comfort position

In some models, the wind noises in the car's interior are lowest when the glass sunroof is not fully open. In these models, the automatic function initially only opens the glass sunroof up to this comfort position.

Pressing the switch again opens the glass sunroof fully.

### Closing glass sunroof

#### With the glass sunroof open



– Slide switch forward to the resistance point and hold.

The glass sunroof is closed as long as the switch is pressed and stops in the raised position.

– Press the switch forward beyond the resistance point and release it.

The glass sunroof is closed and stops in the raised position.

Pressing the switch again stops the motion.

– Press the switch forward beyond the resistance point and release it twice.

The glass sunroof is closed.

Pressing the switch again stops the motion.

### With the glass sunroof completely raised



Press the switch forward beyond the resistance point and release it.

The glass sunroof is closed.

### Opening/closing the sun protection



Use the handle to slide the sun protection into the desired position.

### Jam protection system

#### Principle

The jam protection prevents objects or body parts from becoming jammed between the roof frame and glass sunroof while the glass sunroof is closing.


#### General information

If resistance or a blockage is detected while the glass sunroof is being closed, the closing action is interrupted.

The glass sunroof opens slightly.

### Closing without the jam protection system

If there is an external danger, proceed as follows:



1. Push the switch forward past the resistance point and hold it.

The glass sunroof closes with limited jam protection. If the closing force exceeds a specific threshold, closing is interrupted.

2. Push the switch forward again past the resistance point and hold until the glass sunroof closes without jam protection. Make sure that the closing path is clear.

### Initializing after a power interruption

After a power interruption during the opening or closing process, the glass sunroof can only be operated to a limited extent. The system must be initialized in this case. MINI recommends having this work performed only by a dealer's service center or another qualified service center or repair shop.

# Seats, mirrors and steering wheel

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## Sitting safely

An ideal seat position that meets the needs of the occupants can make a vital contribution to relaxed, fatigue-free driving.

In the event of an accident, the correct seat position plays an important role. Follow the information in the following chapters:

- Seats, refer to page 86.
- Seat belts, refer to page 90.
- Head restraints, refer to page 92.
- Airbags, refer to page 161.

## Front seats

### Safety information

**⚠ Warning**

Seat setting while driving can lead to unexpected movements of the seat. Vehicle control could be lost. There is a risk of accident. Only adjust the seat on the driver's side when the vehicle is stationary.

**⚠ Warning**

With a backrest inclined too far to the rear, the protective effect of the seat belt can no longer be ensured. There is a risk of sliding under the seat belt in an accident. There is a risk of injury or danger to life. Adjust the seat prior to starting the trip. Adjust the backrest so that it is in the most upright position as possible and do not adjust again while driving.

**⚠ Warning**

There is a risk of jamming when moving the seats. There is a risk of injury or risk of damage to property. Make sure that the travel path of the seat is clear prior to any adjustment.

## Manually adjustable seats

### Overview



- 1 Longitudinal direction
- 2 Thigh support
- 3 Height
- 4 Backrest tilt

## Longitudinal direction


### Warning

Unexpected movements of the seat while driving may occur if the seat is unlocked. Vehicle control could be lost. There is a risk of accident. After adjusting, move the seat forward or back slightly, making sure the seat engages properly.



Pull the lever and slide the seat in the desired direction.

## Height



Pull the lever up or press it down as often as needed to reach the desired height.

## Backrest tilt



Pull the lever, and apply your weight to the backrest or lift it off, as necessary.

## Lumbar support

The curvature of the seat backrest can be adjusted in a way that it supports the lumbar region of the spine. The lower back and the spine are supported for upright sitting position.



Turn the wheel in order to increase or decrease the curvature.


## Electrically adjustable seats

### General information

The seat setting for the driver's seat is stored for the profile currently used. When the vehicle is unlocked via the vehicle key, the position is automatically retrieved if the function, refer to page 79, is activated for this purpose.

The current seat position can be stored using the memory function, refer to page 94.

## Overview



- 1 Memory function
- 2 Lumbar support
- 3 Backrest tilt
- 4 Forward/backward, height, seat tilt

## Longitudinal direction



Press switch forward or backward.

## Height



Press switch up or down.

## Seat tilt



Tilt switch up or down.

## Backrest tilt



Tilt switch forward or backward.

## Lumbar support

### Principle

The curvature of the seat backrest can be adjusted in a way that it supports the lumbar region of the spine. The lower back and the spine are supported for upright sitting position.

### Adjusting




- Press the front/rear section of the button:  
The curvature is increased/decreased.
- Press the upper/lower section of the button:



The curvature is shifted up/down.

## Thigh support



Pull the lever at the front of the seat and adjust the thigh support.


## Front seat heating

### Overview



 Seat heating

### Turning on


 Press the button once for each temperature level.

The maximum temperature is reached when three LEDs are lit.

If the trip is continued within approx. 15 minutes after a stop, seat heating is switched on automatically with the temperature selected last.

When GREEN Mode is activated, refer to page 250, the heater output is reduced.

### Turning off

 Press and hold the button until the LEDs turn off.

## Rear seats

### Safety information

#### Warning

There is a danger of jamming when folding down the center armrest in the rear. There is a risk of injury. Make sure that the area of movement of the center armrest is clear during folding down.

#### Warning

Unexpected movements of the rear seat backrest while driving may occur due to unintentional unlocking of the rear seat backrests by the loops. There is a risk of injury. Only use loops for releasing the rear seat backrests. Do not attach objects on the loops.

### Longitudinal direction

#### General information

The rear seat is divided at a ratio of 60 to 40. The left seat is connected to the center section.


## Adjusting



Pull the lever and slide the seat in the desired direction.

After releasing the lever, move the seat forward and back slightly, making sure it engages properly.

## Backrest tilt



Pull the loop and apply your weight to the backrest or lift it off, as necessary.

After the adjustment, move the backrest slightly forward or back to engage it correctly.

## Seat belts

### General information

The vehicle is fitted with five seat belts to ensure occupant safety. However, the seat belts can only offer protection when adjusted correctly.

Always make sure that seat belts are being worn by all occupants before driving off. Although airbags enhance safety by providing added protection, they do not replace seat belts.

If needed, detach the seat belt in the rear from the belt retainer on the side.

All belt fastening points are designed to achieve the best possible protective effect of the seat belts with proper use of the seat belts and correct seat setting. Follow notes on sitting safely, refer to page 86.

The two outer seat belt buckles of the rear seat are intended for the persons sitting on the left and right.

The center seat belt buckle of the rear seat is intended for the person sitting in the middle.

## Safety information

### Warning

Use of a seat belt to buckle more than one person will potentially defeat the ability of the seat belt to serve its protective function. There is a risk of injury or danger to life. Do not allow more than one person to fasten a single seat belt. Infants and children are not allowed on an occupant's lap, but must be transported and secured in designated child restraint systems.

### Warning

The protective effect of safety gear, including seat belts, can be limited or lost when seat belts are fastened incorrectly. An incorrectly fastened seat belt can cause additional injuries, for instance in the event of an accident, braking or evasive maneuvers. There is a risk of injury or danger to life. Make sure that all occupants are wearing seat belts correctly.

**⚠ Warning**

The protective effect of safety gear, including seat belts, may not be fully functional or fail in the following situations:

- The seat belts or seat belt buckles are damaged, soiled, or changed in any other way.
- Seat belt tensioners or roll-up mechanism were modified.

Seat belts can be imperceptibly damaged in the event of an accident. There is a risk of injury or danger to life. Do not modify seat belts, seat belt buckles, seat belt tensioners, roll-up mechanisms, or belt anchors and keep them clean. Have the seat belts checked after an accident at the dealer's service center or another qualified service center or repair shop.

**Correct use of seat belts**


- Wear the seat belt twist-free and tight to your body over your lap and shoulders.
- Wear the seat belt deep on your hips over your lap. The seat belt may not press on your stomach.
- Do not rub the seat belt against sharp edges, or guide it or jam it in across hard or fragile objects.
- Avoid thick clothing.
- Re-tighten the seat belt frequently upward around your upper body area.

**Buckling the seat belt**

1. Guide the seat belt slowly over shoulder and hip to put it on.
2. Insert the buckle tongue into the seat belt buckle. The seat belt buckle must engage audibly.

**Unbuckling the seat belt**

1. Hold down the seat belt firmly.
2. Press the red button in the belt buckle.
3. Guide the seat belt back into its roll-up mechanism.


**Middle seat belt in the rear****Buckling the seat belt**

1. Pull the buckle tongues out of the mounts in the roof.
2. Insert the lower buckle tongue in the belt buckle, arrow 1.
3. Insert the upper buckle tongue in the belt buckle, arrow 2.

Seat belt buckles must audibly click into place.

### Unbuckling the seat belt

1. Hold down the seat belt firmly.
2. Press the red button in the belt buckle.
3. Use the buckle tongue, arrow 1, to open the second seat belt buckle, arrow 2.



4. Guide the seat belt to the mount in the headliner.

### Seat belt reminder for driver's seat and passenger's seat

#### General information

The seat belt reminder is issued when the driver's side seat belt is not buckled.

The seat belt reminder is also active when the front passenger seat belt is not buckled or objects are on the front passenger seat.

The seat belt reminder is also activated when a passenger unbuckles a seat belt during the trip.

#### Display in the instrument cluster



The indicator light lights up and a signal sounds. Make sure that the seat belts are positioned correctly.

The seat belt reminder can also be activated if objects are placed on the front passenger seat.

## Front head restraints

### Safety information

#### **Warning**

Removal or incorrect adjustment of head restraints can cause injuries in the head and neck area. There is a risk of injury.

- Before driving, install the removed head restraints on the occupied seats.
- Adjust the head restraint so its center supports the back of the head at as close to eye level as possible.
- Adjust the distance so that the head restraint is as close as possible to the back of the head. Adjust the distance via the backrest tilt as needed.

#### **Warning**

Body parts can be jammed when moving the head restraint. There is a risk of injury. Make sure that the area of movement is clear when moving the head restraint.

#### **Warning**


Objects on the head restraint reduce the protective effect in the head and neck area. There is a risk of injury.

- Do not use seat or head restraint covers.
- Do not hang objects, for instance clothes hangers, directly on the head restraint.
- Only use accessories that have been determined to be safe for attachment to a head restraint.
- Do not use any accessories, for instance pillows, while driving.

## Adjusting the height: John Cooper Works sport seat

The height of the head restraints cannot be set.

### Adjusting the height




- To lower: press the button, arrow 1, and push the head restraint down.
  - To raise: push the head restraint up.
- After setting the height, make sure that the head restraint engages correctly.

## Removing: John Cooper Works sport seat

The head restraints cannot be removed.

### Removing

Only remove the head restraint if no one will be sitting in the seat in question.



1. If necessary, fold the rear seat backrest forward.
2. Pull head restraint up to the stop.
3. Press the button, arrow 1, and pull the head restraint out completely.

## Installing

Proceed in the reverse order to install the head restraint.

## Rear head restraints

### Safety information

#### Warning

Removal or incorrect adjustment of head restraints can cause injuries in the head and neck area. There is a risk of injury.

- Before driving, install the removed head restraints on the occupied seats.
- Adjust the head restraint so its center supports the back of the head at as close to eye level as possible.
- Adjust the distance so that the head restraint is as close as possible to the back of the head. Adjust the distance via the backrest tilt as needed.

#### Warning


Body parts can be jammed when moving the head restraint. There is a risk of injury. Make sure that the area of movement is clear when moving the head restraint.

#### Warning

Objects on the head restraint reduce the protective effect in the head and neck area. There is a risk of injury.

- Do not use seat or head restraint covers.
- Do not hang objects, for instance clothes hangers, directly on the head restraint.
- Only use accessories that have been determined to be safe for attachment to a head restraint.
- Do not use any accessories, for instance pillows, while driving.


### Adjusting the height



- To lower: press the button, arrow 1, and push the head restraint down.
- To raise: push the head restraint up.

After setting the height, make sure that the head restraint engages correctly.

### Fold down



- To fold down: press the button, arrow 1, and press down the head restraint, arrow 2.
- Forward: fold the head restraint toward the front as far as it will go. Make sure that the head restraint engages correctly.

### Removing

The head restraints cannot be removed.

## Memory function

### Principle

The following settings can be stored and, if necessary, retrieved using the memory function:

- Seat position.
- Exterior mirror position.
- Height of the Head-up Display.

### General information

Different settings can be assigned to two memory locations.

The setting of the lumbar support is not stored.

## Safety information

### Warning

There is a risk of jamming when moving the seats. There is a risk of injury or risk of damage to property. Make sure that the travel path of the seat is clear prior to any adjustment.

### Warning

Using the memory function while driving can lead to unexpected movements of the seat. Vehicle control could be lost. There is a risk of accident. Only retrieve the memory function when the vehicle is stationary.

Press the desired button 1 or 2.

The procedure stops when a seat setting switch or one of the memory buttons is pressed.

Once underway, adjustment of the seat position on the driver's side is disabled after a short while.

## Call up deactivated

After a brief period, calling up stored seat positions is deactivated to save battery power.


To reactivate calling up of a seat position:

- Open or close the door or tailgate.
- Press a button on the vehicle key.
- Press the Start/Stop button.

## Overview



## Storing

1. Turn on the ignition.
2. Set the desired position.
3.  Press the button. The LED in the button lights up.
4. Press the desired button 1 or 2 while the LED is lit. The LED goes out.

## Calling up settings

The stored position is called up automatically.

## Mirrors

### Exterior mirrors

#### General information

The front passenger's side exterior mirror is more curved than the driver's side mirror.

The mirror setting is stored for the driver profile currently in use. When the vehicle is unlocked via the vehicle key, the position is automatically retrieved if the function, refer to page 79, is activated for this purpose.

The current exterior mirror position can be stored using the memory function, refer to page 94.


### Safety information

#### Warning

Objects reflected in the mirror are closer than they appear. The distance to the road users behind could be incorrectly estimated, for instance while changing lanes. There is a risk of accident. Estimate the

distance to the traffic behind by looking over your shoulder.

**Overview**



- 1 Adjusting
- 2 Selecting a mirror, Automatic Curb Monitor
- 3 Folding in and out

**Selecting a mirror**



To change over to the other mirror: Slide the switch.

**Adjusting electrically**



Press the button. The mirror movement follows the button movement.

**Malfunction**

In case of an electrical malfunction, adjust the mirror by pressing the edges of the mirror glass.

**Automatic heating**

Both exterior mirrors are automatically heated as needed and when the ignition is switched on.

**Automatic dimming feature**

The exterior mirror on the driver's side is automatically dimmed. Photocells in the


car's interior mirror, refer to page 97, are used to control this.

**Automatic Curb Monitor**

**Principle**

If reverse gear is engaged, the mirror glass on the passenger's side is tilted downward. This improves your view of the curb and other low-lying obstacles when parking, for instance.

**Activating**


- 1.  slide the switch to the driver's side mirror position.
- 2. Engage selector lever position R.

**Deactivating**

Slide the switch to the front passenger's side exterior mirror position.

**Interior mirror, manually dimmable**


**Flip lever**



To reduce the blinding glare of the interior mirror, flip the lever forward.




## Turn button



Turn the button to reduce the blinding glare by the interior mirror.

## Interior mirror, automatic dimming feature

### Overview



Photocells are used for control:

- In the mirror glass.
- On the rear of the mirror.

### Functional requirements

- Keep the photocells clean.
- Do not cover the area between the interior mirror and the windshield.

## Steering wheel

### Safety information

#### Warning

Steering wheel adjustments while driving can lead to unexpected steering wheel movements. Vehicle control could be lost. There is a risk of accident. Adjust the steering wheel while the vehicle is stationary only.

### Adjusting



1. Fold the lever down.
2. Move the steering wheel to the preferred height and angle to suit your seat position.
3. Fold the lever back up.

### Steering wheel heating

#### Overview





Steering wheel heating

### Turning on/off



Press the button.

- On: the LED lights up.
- Off: the LED goes out.

If the trip is resumed within approx. 15 minutes after an intermediate stop, the steering wheel heating turns on automatically if the function was turned on at the completion of the last trip.

# Transporting children safely

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## The right place for children

### Safety information

#### Warning

Unattended children or animals in the vehicle can cause the vehicle to move and endanger themselves and traffic, for instance due to the following actions:

- Pressing the Start/Stop button.
- Releasing the parking brake.
- Opening and closing the doors or windows.
- Engaging selector lever position N.
- Using vehicle equipment.

There is a risk of accidents or injuries. Do not leave children or animals unattended in the vehicle. Take the vehicle key with you when exiting and lock the vehicle.

#### Warning

A heated vehicle may result in death to persons, especially children, or animals. There is a risk of injury or danger to life. Do not leave persons, especially children, or animals unattended in the vehicle.

#### Warning

Exposure to intense sunlight can cause child restraint systems and their components to become very hot. Persons may sustain burn injuries when touching the hot components. There is a risk of injury. Do not expose the child restraint system to direct sunlight or cover where necessary. If necessary, let the child restraint system cool down before transporting a child. Do not leave children unattended in the vehicle.

## Transport children in the rear seat

### General information

Accident research shows that the safest place for children is in the rear seat.

Children younger than 13 years of age or shorter than 5 ft/150 cm should be transported in the rear seat in suitable child restraint systems designed for the age, weight and size of the child. Children 13 years of age or older must wear a seat belt as soon as a suitable child restraint system can no longer be used due to their age, weight, or size.

## Safety information

### Warning

The seat belt cannot be fastened correctly on children shorter than 5 ft/150 cm without suitable additional child restraint systems. The protective effect of safety gear, including seat belts, can be limited or lost when seat belts are fastened incorrectly. An incorrectly fastened seat belt can cause additional injuries, for instance in the event of an accident, braking or evasive maneuvers. There is a risk of injury or danger to life. Secure children shorter than 5 ft/150 cm using suitable child restraint systems.

## Children on the front passenger seat

### General information

Before using a child restraint system on the front passenger seat, ensure that the front, knee, and side airbags on the passenger's side are deactivated. For automatic deactivation of front passenger airbags, refer to page 163.

### Safety information

#### Warning

Active front passenger airbags can injure a child in a child restraint system when the airbags are deployed. There is a risk of injury. Make sure that the front passenger airbags are deactivated and that the PASSENGER AIRBAG OFF indicator light lights up.

#### Warning

The stability of the child restraint system is limited or compromised with incorrect seat setting or improper installation of the child seat. There is a risk of injury or danger to life. Make sure that the child restraint system fits securely against the backrest. If possible, adjust the backrest tilt for all affected backrests and correctly adjust the seats. Make sure that seats and backrests are securely engaged or locked. If necessary, adjust the height of the head restraints or remove them.

## Installing child restraint systems

### General information

Pay attention to the specifications of the child restraint system manufacturer when selecting, installing, and using child restraint systems.

### Safety information

#### Warning

The protective effect of child restraint systems and their fastening systems which have been damaged or exposed to an accident can be limited or lost. A child cannot be properly restrained in the event of an accident, braking or evasive maneuvers. There is a risk of injury or danger to life.

Do not use child restraint systems which have been damaged or exposed to an accident.

If a child restraint system and its fastening system has been damaged or exposed to an accident, have these systems checked and replaced by a dealer's service

center or another qualified service center or repair shop.

### **Warning**

The stability of the child restraint system is limited or compromised with incorrect seat setting or improper installation of the child seat. There is a risk of injury or danger to life. Make sure that the child restraint system fits securely against the backrest. If possible, adjust the backrest tilt for all affected backrests and correctly adjust the seats. Make sure that seats and backrests are securely engaged or locked. If necessary, adjust the height of the head restraints or remove them.

### On the rear seats

If the vehicle is equipped with a sliding rear seat row: move the seats to the rearmost position before mounting a child restraint system.

### On the front passenger seat

#### Deactivating airbags

### **Warning**

Active front passenger airbags can injure a child in a child restraint system when the airbags are deployed. There is a risk of injury. Make sure that the front passenger airbags are deactivated and that the PASSENGER AIRBAG OFF indicator light lights up.

Before installing a child restraint system in the front passenger seat, make sure that the front, knee and side airbags on the passenger's side are deactivated.

Deactivate the front passenger airbags automatically, refer to page [163](#).

### Seat position and height

After installing a child restraint system, move the front passenger seat as far back as possible and adjust its height to the highest and thus best possible position for the belt and to offer optimal protection in the event of an accident.

If the upper attachment point of the seat belt is located in front of the belt guide of the child restraint seat, move the front passenger seat carefully forward until the best possible belt guide position is reached.

### Child seat security



The rear seat belts and the front passenger seat belt can be permanently locked to fasten child restraint systems.

#### Locking the seat belt

1. Pull out the belt strap completely.
2. Secure the child restraint system with the seat belt.
3. Allow the belt strap to be pulled in and pull it tight against the child restraint system. The seat belt is disabled.

#### Unlocking the seat belt

1. Unbuckle the seat belt buckle.
2. Remove the child restraint system.
3. Allow the belt strap to be pulled in completely.

In some cases it may be necessary to separate the lower belt attachment. Seat belts, refer to page 90.

## LATCH child seat mountings

### General information

LATCH: Lower Anchors and Tether for Children.

Pay attention to the operating and safety information from the child restraint system manufacturer when installing and using LATCH child restraint fixing systems.

### Mounts for the lower LATCH anchors

#### General information

The lower anchors may be used to attach the CRS to the vehicle seat up to a combined child and CRS weight of 65 lbs/ 30 kg when the child is restrained by the internal harnesses.

#### Safety information

**Warning**



If the lower mountings of the child restraint system are not correctly engaged, the protective effect of the child restraint system is limited. There is a risk of injury or danger to life. Make sure that the lower mountings are correctly engaged and that the child restraint system fits securely against the backrest.

**Warning**

The mounts for the lower mountings and attachment points of the child restraint system are intended for attaching child restraint systems only. If other objects are

attached, the mounts or attachment points can be damaged. There is a risk of injury or risk of damage to property. Attach child restraint systems only at the corresponding mounts for the lower mountings or attachment points.

### Position

Icon	Meaning
	The corresponding icon shows the mounts for the lower LATCH anchors.
	Seats equipped with lower mountings are marked with a pair, (2), of LATCH symbols.
	For vehicles equipped with a middle seat:
	It is not recommended to use the inner lower mountings of standard outer LATCH positions to fasten a child restraint system on the middle seat. Use the vehicle seat belt instead for the middle seat.

### Before installing LATCH child restraint systems

Pull the seat belt away from the area of the child seat mountings.

### Assembly of LATCH child restraint fixing systems

1. Mount child restraint system, see manufacturer's information.
2. Ensure that both LATCH anchors are properly engaged.

## Child restraint systems with tether strap

### Safety information

#### Warning

If the upper retaining strap is incorrectly used for the child restraint system, the protective effect is reduced. There is a risk of injury. Make sure that the upper retaining strap does not run over sharp edges and is not twisted as it passes the upper anchor.

#### Warning

If the rear seat backrest is not locked, the protective effect of the child restraint system is limited or there is none. In certain situations, for instance braking maneuvers or in case of an accident, the rear seat backrest can fold forward. There is a risk of injury or danger to life. Make sure that the rear seat backrests are locked.

#### Warning

The mounts for the lower mountings and attachment points of the child restraint system are intended for attaching child restraint systems only. If other objects are attached, the mounts or attachment points can be damaged. There is a risk of injury or risk of damage to property. Attach child restraint systems only at the corresponding mounts for the lower mountings or attachment points.


### Attachment points



The respective icon shows the attachment point for the upper retaining strap. Seats with an upper top

tether are marked with this icon. It can be found on the rear seat backrest or the rear shelf.

### Routing the retaining strap



- 1 Driving direction
- 2 Head restraint
- 3 Hook for upper retaining strap
- 4 Attachment point
- 5 Seat backrest
- 6 Upper retaining strap

### Attaching the upper retaining strap to the attachment point

1. Raise the head restraint, if needed.
2. On the rear seat: Guide the upper retaining strap between or along both sides of the supports of the head restraint to the anchor.
3. Attach the hook of the retaining strap to the anchor on the rear seat.
4. Tighten the retaining strap by pulling it down.

## Locking the doors and windows

### Doors



Push the locking lever on the rear doors up. The door can now be opened from the outside only.

### Safety switch for the rear



Press the button on the driver's door if children are being transported in the rear.

This disables various functions so that they cannot be operated from the rear: safety switch, refer to page [83](#).



# Driving

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## Start/Stop button

### Principle



Pressing the Start/Stop button switches the ignition on or off and starts the engine.

Steptronic transmission: the engine starts in selector lever position P or N with the brake pedal pressed when you press the Start/Stop button.

Manual transmission: the engine starts with the clutch pedal pressed when the Start/Stop button is pressed.

### Ignition on

Manual transmission: press the Start/Stop button without stepping on the clutch pedal.

Steptronic transmission: press the Start/Stop button, but do not press on the brake pedal at the same time.

All vehicle systems are ready for operation.

Most of the indicator/warning lights in the instrument cluster light up for a varied length of time.

To save battery power when the engine is off, switch off the ignition and any unnecessary electrical components.

### Ignition off

Manual transmission: press the Start/Stop button again without stepping on the clutch pedal.

Steptronic transmission: shift to selector lever position P, press the Start/Stop button again without stepping on the brake.

All indicator lights in the instrument cluster turn off.

To save battery power when the engine is off, switch off the ignition and any unnecessary electrical components.

### Safety precautions

The ignition is switched off automatically in the following situations while the vehicle is stationary and the engine is off:

- When locking the vehicle, even if the low beams are switched on.
- Shortly before the battery is discharged completely, so that the engine can still be started. This function is only available when the low beams are switched off.
- When opening or closing the driver's door, if the driver's seat belt is unbuckled and the low beams are switched off.
- While the driver's seat belt is unbuckled with driver's door open and low beams off.
- When the front doors are opened if there is no other person sitting in the front seats.
- The low beams switch to parking lights after some minutes of no use.



Steptronic transmission with a tap-operated selector lever, refer to page 123: when switching off the ignition, the selector lever position P is engaged automatically if the selector lever position R, D or M/S is engaged.

## Radio-ready state

### General information

In the radio-ready state, certain electrical components remain ready for operation.

### Activating

With the engine running, press the Start/Stop button.

If the engine is not running and the ignition is switched on: the system automatically activates radio-ready state when the door is opened if the lights are switched off or the daytime driving lights are switched on.

Radio-ready state remains active if, for instance the ignition is automatically switched off for the following reasons:

- Opening or closing the driver's door.
- Unfastening of the driver's seat belt.
- When automatically changing over from low beams to parking lights.

### Switching off automatically

The radio-ready state is switched off automatically in the following situations:

- If the driver's or front passenger door is opened when exiting the vehicle, with the engine switched off manually.
- If the ignition is switched off manually with the Start/Stop button.
- After approx. 8 minutes.

- When the vehicle is locked using the central locking system.
- Shortly before the battery is discharged completely, so that the engine can still be started.

## Starting the engine

### Safety information

#### DANGER

If the exhaust pipe is blocked or ventilation is insufficient, harmful exhaust gases can penetrate the vehicle. The exhaust gases contain pollutants which are colorless and odorless. In enclosed areas, exhaust gases can also accumulate outside of the vehicle. There is a danger to life. Keep the exhaust pipe free and ensure sufficient ventilation.

#### Warning

An unsecured vehicle can begin to move and possibly roll away. There is a risk of accident. Before leaving the vehicle, secure the vehicle against rolling away.

In order to ensure that the vehicle is secured against rolling away, follow the following:

- Set the parking brake.
- On uphill grades or on a downhill slope, turn the front wheels in the direction of the curb.
- On uphill grades or on a downhill slope, also secure the vehicle, for instance with a wheel chock.

**⚠ NOTICE**

Repeated attempts to start the vehicle or repeated starting of the vehicle in rapid succession can cause the starter to overheat. This also results in unburned or inadequately burned fuel, and can cause the catalytic converter to overheat. There is a risk of damage to property, among other potential damage. Avoid repeated starting of the vehicle, particularly repeated starting in rapid succession.

**Gasoline engine**

Depending on the motorization, the full drive power may not be available for approximately 30 seconds after starting the engine. In this case, the vehicle will not accelerate as usual.

**Steptronic transmission****Starting the engine**

1. Depress the brake pedal.
2. Engage selector lever position P or N.
3. Press the Start/Stop button.

The ignition is activated automatically for a brief time and is stopped as soon as the engine starts.

**Manual transmission****Starting the engine**

1. Depress the brake pedal.
2. Press on the clutch pedal and shift to Neutral.
3. Press the Start/Stop button.

The ignition is activated automatically for a brief time and is stopped as soon as the engine starts.

**Engine stop****Safety information****⚠ Warning**

Unattended children or animals in the vehicle can cause the vehicle to move and endanger themselves and traffic, for instance due to the following actions:

- Pressing the Start/Stop button.
- Releasing the parking brake.
- Opening and closing the doors or windows.
- Engaging selector lever position N.
- Using vehicle equipment.

There is a risk of accidents or injuries. Do not leave children or animals unattended in the vehicle. Take the vehicle key with you when exiting and lock the vehicle.

**⚠ Warning**

An unsecured vehicle can begin to move and possibly roll away. There is a risk of accident. Before leaving the vehicle, secure the vehicle against rolling away.

In order to ensure that the vehicle is secured against rolling away, follow the following:

- Set the parking brake.
- On uphill grades or on a downhill slope, turn the front wheels in the direction of the curb.
- On uphill grades or on a downhill slope, also secure the vehicle, for instance with a wheel chock.



## Steptronic transmission

### Switching off the engine

1. When the vehicle is stationary, apply the parking brake.
2. Engage selector lever position P.
3. Press the Start/Stop button.  
The engine is switched off.  
The radio-ready state is switched on.

## Manual transmission

### Switching off the engine

1. With the vehicle at a standstill, press the Start/Stop button.  
The engine is switched off.  
The radio-ready state is switched on.
2. Shift into first gear or reverse.
3. Set the parking brake.

## Auto Start/Stop function

### Principle

The Auto Start/Stop function helps save fuel. The system switches off the engine during a stop, for instance in traffic jam or at traffic lights. The ignition remains switched on. The engine starts automatically for driving off.

After each engine start using the Start/Stop button, the Auto Start/Stop function is ready and is activated at speeds faster than about 3 mph/5 km/h.

Depending on the selected driving mode, refer to page 188, the system is automatically activated or deactivated.

## Engine stop

### Functional requirements

The engine is switched off automatically during a stop under the following conditions:

Manual transmission:

- Neutral is engaged and the clutch pedal is not pressed.
- The driver's seat belt is buckled or the driver's door is closed.

Steptronic transmission:

- The selector lever is in selector lever position D.
- The brake pedal remains depressed while the vehicle is at a standstill.
- The driver's seat belt is buckled or the driver's door is closed.

In order to be able to release the brake pedal at a vehicle standstill, engage the selector lever in position P. The engine remains off.

To continue driving depress the brake pedal. When a gear is engaged, the engine starts automatically.

The air flow from the air conditioning system is reduced when the engine is switched off.

### Steptronic transmission: manual engine stop

Depending on the vehicle equipment and country version, the engine can be switched off manually, if the engine was not switched off automatically when the vehicle stopped:

- Depress the brake pedal forcefully again from the current pedal position.
- Engage selector lever position P.

If all functional preconditions are fulfilled, the engine switches off.

## Displays in the instrument cluster

### Instrument cluster without enhanced features: display



The display indicates that the Auto Start/Stop function is ready for an Automatic engine start.



The display indicates that the conditions for an automatic engine stop have not been met.

### Instrument cluster with enhanced features: display



The display indicates that the Auto Start/Stop function is ready for an Automatic engine start.



The display indicates that the conditions for an automatic engine stop have not been met.

## Functional limitations

The engine is not switched off automatically in the following situations:

- Outside temperature too low.
- The outside temperature is high and automatic climate control is running.
- The car's interior has not yet been heated or cooled to the required level.
- The engine is not yet at operating temperature.
- The wheels are at a sharp angle or the steering wheel is being turned.
- After driving in reverse.

- Window condensation when the automatic climate control is switched on.
- The vehicle battery charge is very low.
- At higher elevations.
- The hood is unlocked.
- The Automatic Parking Assistant is activated.
- Stop-and-go traffic.
- Selector lever in selector lever position R, N or M/S.

## Starting the engine

The engine starts automatically to drive off under the following conditions:

- Manual transmission: clutch pedal is pressed.
- Steptronic transmission: by releasing the brake pedal.

After the engine starts, accelerate as usual.

## Safety mode

After the engine switches off automatically, it will not start again automatically if any one of the following conditions are met:

- The driver's seat belt is unbuckled and the driver's door is open.
- The hood was unlocked.

Some indicator lights light up for a varied length of time.

The engine can only be started via the Start/Stop button.

## Functional limitations

Even if driving off was not intended, the deactivated engine starts up automatically in the following situations:

- Excessive heating up of the car's interior when air conditioning is switched on.
- With steering operation.

- Steptronic transmission: change from selector lever position D to R, N or M/S.
- Steptronic transmission: change from selector lever position P to R, N, D or M/S.
- The vehicle begins rolling.
- Window condensation when the automatic climate control is switched on.
- The vehicle battery charge is very low.
- Excessive cooling of the car's interior when the heating is switched on.
- Manual transmission: low brake vacuum pressure; this can occur, for instance if the brake pedal is depressed a number of times in succession.

### Additional Auto Start/Stop function

Depending on the vehicle equipment and country-specific version, the vehicle features a variety of sensors for assessing the traffic situation. The Auto Start/Stop function uses this information to adapt to various traffic situations in a proactive manner.

For instance, this applies to the following situations:

- When a situation is detected in which the stopping time is expected to be very short, the engine is not switched off automatically. A message appears on the Control Display, depending on the situation.
- When a situation is detected in which the vehicle needs to drive off immediately, the engine is started automatically.

The function may be restricted if the navigation data is invalid, outdated or not available, for example.

## Switching the system on/off

### Using the button



Press the button.

- LED comes on: Auto Start/Stop function is deactivated.  
The engine is started during an automatic engine stop.  
The engine can only be stopped or started via the Start/Stop button.
- LED goes out: Auto Start/Stop function is activated.

### Switching off the vehicle during an automatic engine stop

During an automatic engine stop, the vehicle can be switched off permanently, for instance when leaving it.

Steptronic transmission:

1. Engage selector lever position P.
2. Press the Start/Stop button. The ignition is switched off. The Auto Start/Stop function is deactivated.
3. Set the parking brake.

Manual transmission:

1. Press the Start/Stop button. The ignition is switched off. The Auto Start/Stop function is deactivated.
2. Shift into first gear or reverse.
3. Set the parking brake.

Engine start as usual via Start/Stop button.

## Automatic deactivation

In certain situations, the Auto Start/Stop function is deactivated automatically for safety reasons, for instance if no driver is detected.

## Malfunction

The Auto Start/Stop function no longer switches off the engine automatically. A Check Control message is displayed. It is possible to continue driving. Have the system checked by a dealer's service center or another qualified service center or repair shop.

## Parking brake, electric

### Principle

The parking brake is used to prevent the vehicle from rolling when it is parked.

### Safety information

#### Warning

An unsecured vehicle can begin to move and possibly roll away. There is a risk of accident. Before leaving the vehicle, secure the vehicle against rolling away.

In order to ensure that the vehicle is secured against rolling away, follow the following:

- Set the parking brake.
- On uphill grades or on a downhill slope, turn the front wheels in the direction of the curb.
- On uphill grades or on a downhill slope, also secure the vehicle, for instance with a wheel chock.

#### Warning

Unattended children or animals in the vehicle can cause the vehicle to move and endanger themselves and traffic, for instance due to the following actions:

- Pressing the Start/Stop button.
- Releasing the parking brake.
- Opening and closing the doors or windows.
- Engaging selector lever position N.
- Using vehicle equipment.

There is a risk of accidents or injuries. Do not leave children or animals unattended in the vehicle. Take the vehicle key with you when exiting and lock the vehicle.


### Overview




 Parking brake

### Setting the parking brake

#### With a stationary vehicle

 Pull the switch.  
The LED lights up.


 The indicator light lights up red. The parking brake is set.


Depending on the stopping situation, the parking brake is engaged automatically.

Steptronic transmission: in some parking situations, the parking brake is automatically engaged, when selector lever position P is engaged. In these cases, the parking brake is released automatically when you leave the selector lever position P.

### While driving

To use as emergency brake while driving:

-  Pull the switch and hold it. The vehicle brakes hard while the switch is being pulled.



-  The indicator lights light up red, a signal sounds, and the brake lights illuminate.

A Check Control message is displayed.

If the vehicle is decelerated to a complete stop, the parking brake is engaged.

### Releasing the parking brake

#### Releasing the parking brake manually

1. Turn on the ignition.
2.  Manual transmission: press the switch while the brake pedal is pressed.
-  Steptronic transmission: press the switch while the brake is pressed or selector lever position P is set.

The LED and the indicator light go out.

The parking brake is released.

#### Automatic release in cars with Steptronic transmission

For automatic release, step on the accelerator pedal.

The LED and the indicator light go out.

The parking brake is automatically released when you step on the accelerator pedal when the following prerequisites are met:

- Engine on.
- Gear position engaged.
- Driver buckled in and doors closed.

#### Automatic release in cars with manual transmission

Drive off as usual. The parking brake disengages when the clutch pedal is released.

The LED and the indicator light go out.

Under the following conditions, the parking brake is automatically released:

- Engine on.
- Gear engaged.
- Driver buckled in and doors closed.
- Engine power is sufficient to drive off.

### Malfunction


If the parking brake fails or in case of a fault, secure the vehicle against rolling away before exiting.

A Check Control message is displayed.


Secure the vehicle against rolling away, for instance with a wheel chock, after getting out of the vehicle.

### After a power interruption

#### Commissioning

1. Turn on the ignition.
2.  Press the switch while stepping on the brake pedal or selector lever position P is set.

Commissioning may take a few seconds. Some mechanical sounds associated with this process are normal.


-  The indicator light in the instrument cluster turns off as soon as the parking brake is ready for operation again.



## Turn signal, high beams, headlight flasher

### Turn signal

#### Blinking




Press the lever past the resistance point. Canada: the lever returns into its initial position after actuation. To switch off manually, slightly tap the lever to the resistance point.

#### Triple turn signal activation

Lightly tap the lever up or down.

The triple turn signal duration can be adjusted.

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle settings"
3. "Lighting"
4. "Exterior lighting"
5. "One-touch turn signal"
6. Select the desired setting.

Settings are stored for the profile currently used.

#### Brief blinking

Press the lever to the resistance point and hold it there for as long as you want the turn signal to flash.

### Malfunction

Unusually rapid blinking of the indicator light indicates that a turn signal bulb has failed.

### High beams, headlight flasher

Press the lever forward or pull it backward.



- High beams on, arrow 1.  
The high beams light up when the low beams are switched on.
- High beams off/headlight flasher, arrow 2.

## Window wiper system

### Safety information

#### Warning

If the wipers start moving in the folded away state, body parts can be jammed or damage may occur to parts of the vehicle. There is a risk of injury or risk of damage to property. Make sure that the vehicle is switched off when the wipers are in the folded away state and the wipers are folded in when switching on.

**⚠ NOTICE**

The wiper blades can wear out or become damaged prematurely when wiping on a dry window for a longer period of time. The wiper motor can overheat. There is a risk of damage to property, among other potential damage. Do not use the wipers when the window is dry.

**⚠ NOTICE**

If the wipers are frozen to the windshield, the wiper blades can be torn off and the wiper motor can overheat when switching on. There is a risk of damage to property, among other potential damage. Defrost the windshield prior to switching the wipers on.

**Turning on**



Press the lever up until the desired position is reached.

- Resting position of the wipers, position 0.
- Intermittent operation or rain sensor, position 1.
- Normal wiper speed, position 2.
- Fast wiper speed, position 3.

When the journey is interrupted with the window wiper system switched on: when travel continues, the wipers resume at their previous level.

**Turning off and flick wipe**



Press the lever down.

- Switching off: press the lever down until it reaches its basic setting.
- Flick wipe: press the lever down from the basic setting.  
The lever automatically returns to its basic setting when released.

**Intermittent operation or rain sensor**

**Principle**

The rain sensor automatically controls the wiper operation depending on the intensity of the rainfall.

**General information**

The sensor is located on the windshield, directly in front of the interior mirror. Without the rain sensor, the interval of the wiper operation is predefined.

**Safety information**

**⚠ NOTICE**

If the rain sensor is activated, the wipers can accidentally start moving in car washes. There is a risk of damage to property, among other potential damage. Deactivate the rain sensor in car washes.

## Activating



Press the lever up once from its basic setting, arrow 1.

Wiping operation is started.

The LED in the wiper lever is illuminated.

In frosty conditions, wiping operation may not start.

## Deactivating

Press the lever back into the basic setting.

## Setting the interval period or sensitivity of the rain sensor



Turn the thumbwheel.

With deactivated rain sensor: set the interval period.

With activated rain sensor: set the rain sensor sensitivity.

Up: short interval or high sensitivity of the rain sensor.

Down: long interval or low sensitivity of the rain sensor.

## Windshield washer system

### Safety information

#### Warning

The washer fluid can freeze onto the window at low temperatures and obstruct the view. There is a risk of accident. Only use the washer systems, if the washer fluid cannot freeze. Use washer fluid with anti-freeze, if needed.

#### NOTICE

When the washer fluid reservoir is empty, the washer pump cannot work as intended. There is a risk of damage to property, among other potential damage. Do not use the washer system when the washer fluid reservoir is empty.

## Cleaning the windshield



Pull the lever.

The washer fluid is sprayed on the windshield, and the wipers are turned on briefly.

## Windshield washer nozzles

The washer jets are automatically heated whenever the ignition is switched on.

## Rear wiper

### Switching on the rear wiper



Turn the outer switch upward.

- Resting position of the wiper, position 0.
- Intermittent operation, arrow 1. When reverse gear is engaged, the system switches to continuous operation.

### Clean the rear window

Turn the outer switch in the desired direction.

- In resting position: turn the switch downward, arrow 3. The switch automatically returns to its idle position when released.
- In intermittent operation: turn the switch further, arrow 2. The switch automatically returns to its interval position when released.

The function is deactivated if the washer fluid reservoir fill level is low.

## Fold-out position of the wipers

### Principle

The fold-out position enables the wipers to be folded out from the windshield.

### General information

Helpful when changing the wiper blades or under frosty conditions, for instance.

## Safety information

### ⚠ Warning

If the wipers start moving in the folded away state, body parts can be jammed or damage may occur to parts of the vehicle. There is a risk of injury or risk of damage to property. Make sure that the vehicle is switched off when the wipers are in the folded away state and the wipers are folded in when switching on.

### ⚠ NOTICE


If the wipers are frozen to the windshield, the wiper blades can be torn off and the wiper motor can overheat when switching on. There is a risk of damage to property, among other potential damage. Defrost the windshield prior to switching the wipers on.

## Folding out the wipers

1. Switch the ignition on and off again.
2. Press and hold the wiper lever down, until the wipers stop in a close to vertical position.



3. Fold the wipers all the way out from the windshield.



## Folding in the wipers

After the wipers are folded back down, the window wiper system must be reactivated.

1. Fold the wipers back in onto the windshield.
2. Turn on the ignition.
3. Push wiper lever down. Wipers return to their resting position and are ready again for operation.

## Canada: window wiper system

### Safety information

#### Warning

If the wipers start moving in the folded away state, body parts can be jammed or damage may occur to parts of the vehicle. There is a risk of injury or risk of damage to property. Make sure that the vehicle is switched off when the wipers are in the folded away state and the wipers are folded in when switching on.

#### NOTICE

The wiper blades can wear out or become damaged prematurely when wiping on a dry window for a longer period of time. The wiper motor can overheat. There is a risk of damage to property, among other potential damage. Do not use the wipers when the window is dry.

#### NOTICE

If the wipers are frozen to the windshield, the wiper blades can be torn off and the wiper motor can overheat when switching on. There is a risk of damage to property, among other potential damage. Defrost the windshield prior to switching the wipers on.

## Turning on



Tap up the lever or press it past the resistance point.

- Normal wiper speed: tap up once.
- Fast wiper speed: tap up twice or tap once beyond the resistance point.

The lever automatically returns to its basic setting when released.

## Turning off and flick wipe



Press the lever down.

- To switch off from fast wiper speed: press down twice.
- To switch off from normal wiper speed: press down once.
- Flick wipe: press down once.

The lever automatically returns to its basic setting when released.

## Intermittent operation or rain sensor

### Principle

The rain sensor automatically controls the wiper operation depending on the intensity of the rainfall.

### General information

The sensor is located on the windshield, directly in front of the interior mirror. Without the rain sensor, the interval of the wiper operation is predefined.

### Safety information

#### NOTICE

If the rain sensor is activated, the wipers can accidentally start moving in car washes. There is a risk of damage to property, among other potential damage. Deactivate the rain sensor in car washes.

### Activating/deactivating



Press the button on the wiper lever.

Wiping operation is started.

The LED in the wiper lever is illuminated.

In frosty conditions, wiping operation may not start.

If a journey is interrupted with the rain sensor switched on: if the trip is resumed

within approx. 15 minutes, the rain sensor is automatically activated again.

### Setting the interval period or sensitivity of the rain sensor



Turn the thumbwheel.

With deactivated rain sensor: set the interval period.

With activated rain sensor: set the rain sensor sensitivity.

Up: short interval or high sensitivity of the rain sensor.

Down: long interval or low sensitivity of the rain sensor.

## Windshield washer system

### Safety information

#### Warning

The washer fluid can freeze onto the window at low temperatures and obstruct the view. There is a risk of accident. Only use the washer systems, if the washer fluid cannot freeze. Use washer fluid with anti-freeze, if needed.

#### NOTICE

When the washer fluid reservoir is empty, the washer pump cannot work as intended. There is a risk of damage to property, among other potential damage. Do not use the washer system when the washer fluid reservoir is empty.

### Cleaning the windshield



Pull the lever.

The washer fluid is sprayed on the windshield, and the wipers are turned on briefly.

### Windshield washer nozzles

The washer jets are automatically heated whenever the ignition is switched on.

### Rear wiper

#### Switching on the rear wiper



Turn the outer switch upward.

- Resting position of the wiper, position 0.
- Intermittent operation, arrow 1. When reverse gear is engaged, the system switches to continuous operation.

**Clean the rear window**

Turn the outer switch in the desired direction.

- In resting position: turn the switch downward, arrow 3. The switch automatically returns to its idle position when released.
- In intermittent operation: turn the switch further, arrow 2. The switch automatically returns to its interval position when released.

The function is deactivated if the washer fluid reservoir fill level is low.

**Fold-out position of the wipers**

**Principle**

The fold-out position enables the wipers to be folded out from the windshield.

**General information**

Helpful when changing the wiper blades or under frosty conditions, for instance.

**Safety information**

**Warning**

If the wipers start moving in the folded away state, body parts can be jammed or damage may occur to parts of the vehicle. There is a risk of injury or risk of damage to property. Make sure that the vehicle is switched off when the wipers are in the folded away state and the wipers are folded in when switching on.

**NOTICE**


If the wipers are frozen to the windshield, the wiper blades can be torn off and the wiper motor can overheat when switching on. There is a risk of damage to property, among other potential damage. Defrost the windshield prior to switching the wipers on.

**Folding out the wipers**

1. Switch the ignition on and off again.
2. Press the wiper lever up past the point of resistance and hold it for approx. 3 seconds, until the wipers remain in a nearly vertical position.



3. Fold the wipers all the way out from the windshield.





## Folding in the wipers

After the wipers are folded back down, the window wiper system must be reactivated.

1. Fold the wipers back in onto the windshield.
2. Turn on the ignition.
3. Push wiper lever down. Wipers return to their resting position and are ready again for operation.

## Washer fluid

### General information

All windshield washer jets are supplied from one tank.

Use a mixture of tap water and windshield washer concentrate. If desired, a windshield washer concentrate containing antifreeze can be used.

Recommended minimum fill quantity:  
0.2 US gal/1 liter.

### Safety information

#### Warning

Some types of antifreeze can contain harmful substances and are flammable. There is a risk of fire and an injury hazard. Follow the instructions on the containers. Keep antifreeze away from ignition sources. Do not refill operating materials into different bottles. Store operating materials out of reach of children.

United States: the washer fluid mixture ratio is regulated by the U.S. EPA and many individual states; do not exceed the allowable washer fluid dilution ratio limits that apply. Follow the usage instructions on the washer fluid container.

Use of BMW's Windshield Washer Concentrate or the equivalent is recommended.

#### Warning

Washer fluid can ignite and catch fire on contact with hot engine parts. There is a risk of injury or risk of damage to property. Only add washer fluid when the engine is cooled down. Next, fully close the lid of the washer fluid reservoir.

#### NOTICE

Silicon-containing additives in the washer fluid for the water-repelling effect on the windows can lead to damage to the washing system. There is a risk of damage to property, among other potential damage. Do not add silicon-containing additives to the washer fluid.

#### NOTICE

Mixing different windshield washer fluid concentrates or antifreeze can damage the car wash. There is a risk of damage to property, among other potential damage. Do not mix different windshield washer fluid concentrates or antifreeze. Follow the information and mixture ratios provided on the containers.

## Overview



The washer fluid reservoir is located in the engine compartment.

## Malfunction

The use of undiluted windshield washer fluid concentrate or alcohol-based anti-freeze can lead to incorrect readings at temperatures below +5 °F/-15 °C.

## Manual transmission

### Safety information

#### Warning

An unsecured vehicle can begin to move and possibly roll away. There is a risk of accident. Before leaving the vehicle, secure the vehicle against rolling away.


In order to ensure that the vehicle is secured against rolling away, follow the following:

- Set the parking brake.
- On uphill grades or on a downhill slope, turn the front wheels in the direction of the curb.
- On uphill grades or on a downhill slope, also secure the vehicle, for instance with a wheel chock.

#### NOTICE

When shifting to a lower gear, excessive RPM can damage the engine. There is a risk of damage to property, among other potential damage. When shifting into 5th or 6th gear, press the gearshift lever to the right.

### Shift pattern



- 1-6: forward gears.
- R: reverse gear.

### Shifting

#### General information

Depending on the motorization, the RPM during a shifting operation is adjusted automatically as required for harmonious gear changing.

#### Reverse gear

Select only when the vehicle is stationary. To overcome the resistance push the gearshift lever dynamically to the left and engage reverse gear with a forward shifting movement.

## Rolling or pushing the vehicle

In some situations, the vehicle is to roll without its own power, for instance in a car wash, or be pushed.

1. Turn on the ignition.
2. Press on the clutch pedal and shift out of a forward gear or reverse.
3. Release the parking brake.

## Steptronic transmission

### Principle

The Steptronic transmission combines the functions of an automatic transmission with the possibility of manual shifting, if needed.

### Safety information

#### Warning

An unsecured vehicle can begin to move and possibly roll away. There is a risk of accident. Before leaving the vehicle, secure the vehicle against rolling away.

In order to ensure that the vehicle is secured against rolling away, follow the following:

- Set the parking brake.
- On uphill grades or on a downhill slope, turn the front wheels in the direction of the curb.
- On uphill grades or on a downhill slope, also secure the vehicle, for instance with a wheel chock.

### Selector lever version

#### General information

Depending on the vehicle equipment, a transmission with either a latching selector

lever or a tap-operated selector lever is installed.

### Transmission with a latching selector lever



The selector lever positions P, R, N, and D are selected by moving the selector lever into the respective selector lever position. The selector lever engages in the selector lever positions.

### Transmission with tap-operated selector lever



The selector lever positions R, N, and D are selected by tapping the selector lever forward or back. The selector lever automatically returns to the center position when released.

The selector lever position P is engaged by pressing the P button on the selector lever or, in certain situations, automatically, refer to page [124](#).



## Selector lever positions

### Gear position D

Selector lever position for normal driving. All gears for forward travel are activated automatically.

### R is reverse

Engage selector lever position R only when the vehicle is stationary.

### Neutral N

The vehicle may be pushed or roll without engine power in selector lever position N, for instance in vehicle washes, refer to page 126.

### Parking position P

#### General information

Selector lever position, for instance for parking the vehicle.

The transmission blocks the drive wheels in selector lever position P.

Engage selector lever position P only when the vehicle is stationary.

Before exiting the vehicle, make sure that selector lever position P is set. Otherwise, the vehicle may begin to move.

#### Automatic parking position for a transmissions with tap-operated selector lever

Selector lever position P is engaged automatically in situations such as the following:

- After the engine is switched off when the vehicle is in the radio-ready state, refer to page 106, or when the ignition is switched off, refer to page 105, while

selector lever position R, D or M/S is engaged.

- If the driver's seat belt is unbuckled, the driver's door is opened, and the brake pedal is not pressed while the vehicle is stationary and selector lever position D, M/S or R is engaged.
- After the ignition has been switched off while selector lever position N is engaged.

## Engaging selector lever positions: with a latching selector lever

### General information

To prevent the vehicle from creeping after you select a gear position, maintain pressure on the brake pedal until you are ready to drive off.

### Functional requirements

The selector lever can only be taken out of selector lever position P if the ignition is on or the engine is running.

### Engaging selector lever position D, N, R, or P

With the vehicle stationary, depress the brake pedal before shifting out of selector lever position P or N; otherwise, the gearshift block will not be deactivated and the gearshift request will not be executed.

A selector lever lock prevents the following incorrect operation:

- Unintentional shifting into selector lever position P or R.
- Unintentional shifting from selector lever position P into another selector lever position.

1. To release the selector lever lock: with the brake pedal depressed, press the button on the front of the selector lever.



2. Move the selector lever into the desired position.



## Engaging selector lever positions: with a tap-operated selector lever

### General information

To prevent the vehicle from creeping after you select a gear position, maintain pressure on the brake pedal until you are ready to drive off.

### Functional requirements

Only when the brake pedal is depressed is it possible to change from selector lever position P to another selector lever position.

Depending on the transmission version, the engine may have to be running too.

The selection lever position P cannot be changed until all technical prerequisites are met.

## Engaging selector lever position D, N, R

A selector lever lock prevents the following incorrect operation:

- Unintentional shifting into selector lever position R.
  - Unintentional shifting from selector lever position P into another selector lever position.
1. Press and hold the button to release the selector lever lock.



2. With the driver's seat belt fastened, briefly push the selector lever in the desired direction, past a resistance point, if needed. The selector lever automatically returns to the center position when released.



## Engaging selector lever position P



Press button P.

## Rolling or pushing the vehicle

### General information

In some situations, the vehicle is to roll without its own power for a short distance, for instance in a car wash, or be pushed.

### Engaging selector lever position N: with a latching selector lever

1. Turn on the ignition.
2. If necessary, release the parking brake.
3. Depress the brake pedal.
4. Touch the selector lever lock and engage selector lever position N.
5. Release brake.

The vehicle can roll.

If there is a malfunction, you may not be able to change the selector lever position.

Manually unlock the transmission lock, if needed, refer to page [129](#).

## Engaging selector lever position N: with a tap-operated selector lever

### ⚠ NOTICE

Selector lever position P is automatically engaged when the ignition is switched off. There is a risk of damage to property, among other potential damage. Do not switch ignition off in car washes.

1. Start the engine while pressing on the brake pedal.
2. If necessary, release the parking brake.
3. Depress the brake pedal.
4. Touch the selector lever lock and engage selector lever position N.
5. Switch the engine off.

In this way, the ignition remains switched on, and a Check Control message is displayed.

The vehicle can roll.

Irrespective of the ignition, the selector lever position P is automatically engaged after approx. 15 minutes.

If there is a malfunction, you may not be able to change the selector lever position.

Electronically unlock the transmission lock, if needed, refer to page [129](#).

## Kickdown

Kickdown is used to achieve maximum driving performance. Press down accelerator pedal beyond the resistance point.

## Sport program M/S

### Principle

The shifting points and shifting times in the Sport program are designed for sportier handling. The transmission, for instance

shifts up later and the shifting times are shorter.

### Activating the Sport program



Press the selector lever to the left from selector lever position D.

The engaged gear is displayed in the instrument cluster, for instance S1.

The sport program of the transmission is activated.

### Ending the Sport program

Press the selector lever to the right.

D is displayed in the instrument cluster.

## Manual mode M/S

### Principle

Manual gear-shifting is possible in manual mode.

### Activating manual mode

1. Press the selector lever to the left from selector lever position D, arrow 1.



2. Press the selector lever forward or pull it backward, arrows 2.

Manual mode M/S becomes active and the gear is changed.

The engaged gear is displayed in the instrument cluster, for instance M1.

### Shifting

- To downshift: press the selector lever forward.
- Upshifting: pull the selector lever rearwards.

The Steptronic transmission continues shifting automatically in certain situations, for instance when certain engine speed limits are reached.

With a tap-operated selector lever: when M2 is set manually while the vehicle is stationary, the transmission will no longer shift back to M1. This shift characteristic is retained until you engage M1 manually or exit M.

### Avoiding automatic upshifting

Once a particular engine speed is attained, M/S manual mode is automatically upshifted as needed.

John Cooper Works: once particular engine speeds are attained, upshifting is not automatically performed in M/S manual mode.

For vehicles with Steptronic Sport transmission, automatic shift operations are not performed if one of the following conditions is met:

- The Dynamic Stability Control is deactivated.
- TRACTION is activated.

In addition, there is no downshifting for kickdown.

With the appropriate transmission version, the lowest possible gear can be selected by simultaneously activating kickdown and operating the left shift paddles. This is not possible by switching briefly via the shift paddles from selector lever position D to manual mode M/S.

### Ending the manual mode

Press the selector lever to the right. D is displayed in the instrument cluster.

### Shift paddles for Steptronic Sport transmission

#### Principle

The shift paddles on the steering wheel allow you to shift gears quickly while keeping both hands on the steering wheel.

#### General information

##### Shifting

Gears will only be changed at appropriate engine and road speeds, for instance downshifting is not possible if the engine speed is too high.

##### Short-term manual mode

In selector lever position D, actuating a shift paddle switches into manual mode temporarily.

After conservative driving in manual mode without acceleration or shifting via the shift

paddles for a certain amount of time, the transmission switches back to automatic mode.


It is possible to switch into automatic mode as follows:

- Keep the right shift paddle pulled until D is displayed in the instrument cluster.
- In addition to the pulled right shift paddle, pull the left shift paddle.

#### Continuous manual mode

In selector lever position S, actuating a shift paddle switches into manual mode permanently.

#### Shifting



- Upshifting: pull the right shift paddle.
- Downshifting: pull left shift paddle.
- Downshifting to the lowest possible gear: keep the left shift paddle pulled.

The selected gear is briefly displayed in the instrument cluster, followed by the current gear.

#### Displays in the instrument cluster



The selector lever position is displayed, for example P.




## Releasing the transmission lock manually: with a latching selector lever

If the selector lever is locked in selector lever position **P** despite the ignition being switched on, the brake pedal being depressed and the button on the selector lever being pressed, the transmission lock can be unlocked manually:

Before unlocking the transmission lock manually, set the parking brake to prevent the vehicle from rolling away.

1. Loosen the selector lever sleeve, together with the lower retaining ring, from the center console. To do so, pull the retaining ring upward at the rear edge.



2. Lift the sleeve. Detach the cable connector, if needed.
3. Using the screwdriver from the onboard vehicle tool kit, refer to page 292, press the yellow release lever downward, see arrow.



4. Press the button on the front of the selector lever and move the selector lever back slightly.  
Release the release lever.
5. Bring the selector lever into the desired position.

For additional information, see the chapter on tow-starting and towing.

## Releasing the transmission lock electronically: with a tap-operated selector lever

### General information

Electronically unlock the transmission lock to maneuver vehicle from a hazardous area.

Before unlocking the transmission lock, set the parking brake to prevent the vehicle from rolling away.

### Engaging selector lever position **N**

Unlocking is possible, if the starter can crank the engine.

1. Press and hold down brake pedal.
2. Press the Start/Stop button. The starter must audibly start.
3. Press the button on the selector lever, arrow 1, and press and hold the selector lever into selector lever position **N**, arrow **N**, until selector lever position **N** is displayed in the instrument cluster.

A Check Control message is displayed.





4. Release the selector lever.
5. Release brake, as soon as the starter stops.
6. Maneuver the vehicle from the hazardous area and secure it against rolling away.

With some transmission versions, the procedure for unlocking is as follows:

1. Press the Start/Stop button three times in a row.
2. Press and hold down brake pedal.
3. Press the button on the selector lever, arrow 1, and press and hold the selector lever into selector lever position N, arrow N, until selector lever position N is displayed in the instrument cluster.  
A Check Control message is displayed.
4. Release the selector lever.
5. Release the brake.
6. Maneuver the vehicle from the hazardous area and secure it against rolling away.

For additional information, see the chapter on tow-starting and towing.

## Steptronic Sport transmission: Launch Control

### Principle

Launch Control enables optimum acceleration on roads with good traction under dry surrounding conditions.

### General information

The use of Launch Control causes premature component wear since this function represents a very heavy load for the vehicle.

Do not use Launch Control during the break-in, refer to page 244.

Do not turn the steering wheel when driving off with Launch Control.


## Functional requirements

Launch Control is available as soon as the engine and transmission are at operating temperature.

Depending on the outside temperature and driving style, the engine and transmission require an interrupted trip of up to 30 miles/50 km in order to reach the operating temperature needed for Launch Control.

## Start with launch control

While the engine is running:

1.  Press button and select SPORT with the MINI Driving Modes switch.  
The instrument cluster displays TRACTION in combination with SPORT. The DSC OFF indicator light lights up.
2. Engage selector lever position S.
3. With the left foot, forcefully press down on the brake.
4. Press and hold down the accelerator pedal beyond the resistance point, kick-down.

A destination flag is displayed in the instrument cluster.

5. The starting engine speed adjusts. Wait briefly until the engine speed is constant. Keep the accelerator pedal in this position.
6. Release the brake within 3 seconds after the destination flag illuminates.

The vehicle accelerates.

Upshifting occurs automatically as long as the destination flag is displayed and the accelerator pedal is not released.

## Repeated use during a trip

After Launch Control has been used, the transmission must cool down for approx.

5 minutes before Launch Control can be used again.

### **After using Launch Control**

To support driving stability, reactivate Dynamic Stability Control.

### **System limits**

An experienced driver may be able to achieve better acceleration values in DSC OFF mode.

# Displays


## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available

in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## Instrument cluster

### Instrument cluster without enhanced features: overview




- |                                  |  |
|----------------------------------|--|
| 1 Tachometer <a href="#">140</a> | 4 Fuel gauge <a href="#">139</a>               |
| 2 Indicator/warning lights       | 5 Display/reset kilometers <a href="#">140</a> |
| 3 Speedometer                    | 6 Electronic displays <a href="#">134</a>      |

## Instrument cluster with enhanced features: overview




- |   |                          |                     |   |                          |                     |
|---|--------------------------|---------------------|---|--------------------------|---------------------|
| 1 | Tachometer               | <a href="#">140</a> | 4 | Vehicle speed            |                     |
| 2 | Display/reset kilometers | <a href="#">140</a> | 5 | Indicator/warning lights |                     |
| 3 | Electronic displays      | <a href="#">135</a> | 6 | Fuel gauge               | <a href="#">139</a> |

Instrument cluster without additional functions: electronic displays



- |  |   |
|--|---|
| <p>1 Driver assistance systems<br/>         Messages, for instance Check Control<br/>         Time <a href="#">140</a><br/>         Outside temperature <a href="#">140</a><br/>         Selection lists <a href="#">144</a></p> | <p>Total kilometers/trip odometer <a href="#">140</a><br/>         Trip computer <a href="#">145</a></p> <p>2 Selector lever position <a href="#">123</a><br/>         Gear shift indicator <a href="#">142</a></p> <p>3 MINI Driving Modes switch status <a href="#">188</a></p> |
|--|---|

## Instrument cluster with enhanced features: electronic displays



- |  |  |
|--|--|
| <p>1 Selector lever position <a href="#">123</a><br/>Gear shift indicator <a href="#">142</a></p> <p>2 Time <a href="#">140</a><br/>MINI Driving Modes switch status <a href="#">188</a></p> <p>3 Driver assistance systems</p> <p>4 Outside temperature <a href="#">140</a></p> | <p>Range <a href="#">141</a></p> <p>5 Messages, for instance Check Control Selection lists <a href="#">144</a><br/>Navigation instructions</p> <p>6 Total kilometers/trip odometer <a href="#">140</a><br/>Trip computer <a href="#">145</a></p> |
|--|--|

## Check Control

### Principle

The Check Control system monitors functions in the vehicle and notifies you of faults in the monitored systems.

### General information

A Check Control message is displayed as a combination of indicator or warning lights and text messages in the instrument cluster and in the Head-up Display.

In addition, an acoustic signal may be output and a text message may appear on the Control Display.

### Indicator/warning lights


#### General information

The indicator/warning lights can light up in a variety of combinations and colors.


Several of the lights are checked for proper functioning and light up temporarily when the engine is started or the ignition is switched on.

## Red lights


### Seat belt reminder

 Indicator light flashes or is illuminated: seat belt on the driver or passenger's side is not buckled. The seat belt reminder can also be activated if objects are placed on the front passenger seat. Make sure that the seat belts are positioned correctly.


### Airbag system


 Airbag system and seat belt tensioner may not be working. Have the vehicle checked immediately by a dealer's service center or another qualified service center or repair shop.

### Parking brake, electric


 The parking brake is set. For releasing the parking brake, refer to page [112](#).

### Brake system

 Brake system fault. Continue to drive moderately. Have the vehicle checked immediately by a dealer's service center or another qualified service center or repair shop.

 BRAKE

### Forward Collision Warning

 Indicator light illuminates: prewarning is issued, for example when there is the impending risk of a collision or the distance to the vehicle ahead is too small.


Increase the distance.

Indicator light flashes: acute warning of the imminent risk of a collision when the vehi-

cle approaches another vehicle at a relatively high differential speed.


Intervene by braking or make an evasive maneuver.

### Pedestrian Warning

 If a collision with a detected person is imminent, the icon lights up and a signal sounds.


### Instrument cluster without enhanced features: orange lights

#### Active Cruise Control

 The number bars shows the selected distance from the vehicle driving ahead.

Camera-based cruise control, refer to page [191](#).


#### Vehicle detection, Active Cruise Control


 Indicator light illuminates: a vehicle has been detected ahead of you. Indicator light flashes: the conditions are not adequate for the system to work.

The system was deactivated but applies the brakes until the driver actively resumes control of the vehicle by pressing on the brake pedal or accelerator pedal.

## Yellow lights

### Anti-lock Braking System

 The Brake Assistant function may not activate. Avoid abrupt braking. Take the longer braking distance into account.

 ABS Have the system immediately checked by a dealer's service center



or another qualified service center or repair shop.

### Dynamic Stability Control



Indicator light blinks: Dynamic Stability Control controls the drive and brake forces. The vehicle is stabilized. Reduce speed and modify your driving style to the driving circumstances.

Indicator light illuminates: the Dynamic Stability Control has malfunctioned.

Have the system checked by a dealer's service center or another qualified service center or repair shop.

Dynamic Stability Control, refer to page [186](#).

### The Dynamic Stability Control deactivated or the Dynamic Traction Control activated



The Dynamic Stability Control is deactivated or the Dynamic Traction Control is activated.

Dynamic Stability Control, refer to page [186](#), and Dynamic Traction Control, refer to page [187](#).

### Flat Tire Monitor



The flat tire monitor reports a tire pressure loss in a tire.

Reduce your speed and stop cautiously. Avoid sudden braking and steering maneuvers.

Flat tire monitor, refer to page [170](#).

### Tire pressure monitor



The indicator light illuminates: the Tire Pressure Monitor reports a low tire pressure or a flat tire. Follow the information in the Check Control message.

The indicator light flashes and is then illuminated continuously: flat tires or tire pressure losses cannot be detected.

- Fault caused by systems or devices with the same radio frequency: after leaving the area of the interference, the system automatically becomes active again.
- The Tire Pressure Monitor could not complete the reset: reset the system again.
- A wheel without wheel electronics is mounted: have it checked by a dealer's service center or another qualified service center or repair shop as needed.
- Malfunction: have the system checked by a dealer's service center or another qualified service center or repair shop.

Tire pressure monitor, refer to page [165](#).

### Steering system



Steering system may be faulty.

Have the system checked by a dealer's service center or another qualified service center or repair shop.

### Emissions



- The warning light lights up: Emissions are deteriorating. Have the vehicle checked as soon as possible.

- The warning light flashes under certain circumstances:

This indicates that there is excessive misfiring in the engine.

Reduce the vehicle speed and have the system checked immediately; otherwise, serious engine misfiring within a brief period can seriously damage emission control components, in particular the catalytic converter.

Socket for OBD on-board diagnostics, refer to page 291.

### Green lights

#### Turn signal



Turn signal switched on.

Unusually rapid blinking of the indicator light indicates that a turn signal bulb has failed.

Turn signal, refer to page 113.

#### Parking lights, headlights



Parking lights or headlights are switched on.

Parking lights/low beams, headlight control, refer to page 155.

#### Front fog lights



Front fog lights are switched on.

Front fog lights, refer to page 158.

#### Automatic High Beam Assistant



Automatic High Beam Assistant is switched on.

High beams are switched on and off automatically depending on the traffic situation.

Automatic High Beam Assistant, refer to page 157.

#### Cruise control



The system is switched on. It maintains the speed that was predefined using the control elements on the steering wheel.

### Manual Speed Limiter



The indicator light illuminates: the system is switched on.

The indicator light flashes: the set speed limit has been exceeded. If this happens, a signal sounds.

Reduce speed or deactivate system.

### Lane departure warning



The indicator light lights up: the system is activated. At least one lane marking was detected and warnings can be issued.

Lane departure warning, refer to page 180.

### Blue lights


#### High beams



High beams are switched on.

High beams, refer to page 113.

### Hiding Check Control messages



Press the button on the turn signal lever.

### Continuous display

Some Check Control messages are displayed continuously and are not cleared until the fault is eliminated. If several faults occur at once, the messages are displayed consecutively.



The messages can be hidden for approx. 8 seconds. After this time, they are displayed again automatically.

### Temporary display

Some Check Control messages are hidden automatically after approx. 20 seconds. The Check Control messages are stored and can be displayed again later.

### Displaying stored Check Control messages

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle status"
3. Tilt the Controller to the left.
4.  "Check Control"
5. Select the text message.

### Display

#### Check Control



At least one Check Control message is displayed or stored.

#### Text messages

Text messages in combination with an icon in the instrument cluster explain a Check Control message and the meaning of the indicator/warning lights.



#### Supplementary text messages

Additional information, such as on the cause of an error or the required action, can be called up via Check Control.

With urgent messages the added text will be automatically displayed on the Control Display.

Depending on the Check Control message, further help can be selected.

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle status"
3. Tilt the Controller to the left.
4.  "Check Control"
5. Select the desired text message.
6. Select the desired setting.

### Messages after trip completion

Certain messages displayed while driving are displayed again after the ignition is switched off.

## Fuel gauge

### Principle

The current fill level of the fuel tank is displayed.

### General information

Vehicle inclination may cause the display to vary.

Information on refueling, refer to page [256](#).

### Instrument cluster without enhanced features: display



The arrow beside the fuel pump icon shows which side of the vehicle the fuel filler flap is on.

### Instrument cluster with enhanced features: display



The arrow beside the fuel pump icon shows which side of the vehicle the fuel filler flap is on.

## Indicator light in the instrument cluster



The yellow indicator light illuminates, once the fuel reserve is reached.

- The odometer is displayed when the ignition is switched off.
- When the ignition is switched on, the trip odometer is reset.

## Tachometer

Always avoid engine speeds in the red warning field. In this range, the fuel supply is reduced to protect the engine.

## Odometer and trip odometer

### Principle

The total kilometers driven and the kilometers driven since the last reset are displayed in the instrument cluster.

### Instrument cluster without additional functions: reset trip distance



Press the button.

- The odometer is displayed when the ignition is switched off.
- When the ignition is switched on, the trip odometer is reset.

### Instrument cluster with enhanced features: reset trip distance



Press the button.

## Outside temperature

### General information

If the indicator drops to +37 °F/+3 °C, a signal sounds.

A Check Control message is displayed.


There is an increased risk of ice on roads.

### Safety information

#### Warning


Even at temperatures above +37 °F/+3 °C there can be a risk of icy roads, for instance on bridges or shady sections of the road. There is a risk of accident. Modify your driving style to the weather conditions at low temperatures.

### Display



The outside temperature is displayed in the instrument cluster.

## Time



The time is displayed in the instrument cluster.

Set the time on the Central Information Display (CID), refer to page 47.

## Date



The date is displayed in the instrument cluster.

Set the date on the Central Information Display (CID), refer to page 47.

## Range

### General information

When the remaining range is low:

- A Check Control message is displayed briefly.
- The remaining range is shown on the trip computer.
- With a sporty driving style, for instance fast cornering, the engine function is not always ensured.

The Check Control message appears continuously below a range of approx. 30 miles/50 km.


### Safety information

#### NOTICE

With a range below 30 miles/50 km, the engine may no longer have sufficient fuel. Engine functions are not ensured anymore. There is a risk of damage to property, among other potential damage. Refuel promptly.

### Display

Display the current range in the on-board computer, refer to page 145.



Instrument cluster with extended functionality: The current range is permanently displayed in the instrument cluster.

## Current consumption

### Principle

Displays the current fuel consumption. Check whether you are currently driving in an efficient and environmentally-friendly manner.

### Display

The current consumption can be displayed on the on-board computer, refer to page 145.

## Service notifications

### Principle

The function displays the service notifications and the corresponding maintenance scopes.

### General information

After the ignition is switched on the instrument cluster briefly displays available distance travelled or time to the next scheduled maintenance.



A service advisor can read out the current service notifications from your vehicle key.

## Display




### Detailed information on service notifications

More information on the type of service required may be displayed on the Control Display.

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle status"
3. Tilt the Controller to the left.
4.  "Service required"  
Maintenance work and legally mandated inspections are displayed.
5. Select an entry to call up detailed information.

### Icons

Icons	Description
	No service is currently required.
	The time for recommended maintenance or a legally mandated inspection is approaching.
	Service interval is exceeded.


### Entering appointment dates

Enter the dates for the mandatory vehicle inspections.

Make sure that the vehicle's date and time are set correctly.

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle status"



3. Tilt the Controller to the left.
4.  "Service required"
5. "Vehicle inspection"
6. "Date:"
7. Select the desired setting.

### Automatic Service Request

Data regarding the service status or legally mandated vehicle inspections is automatically transmitted to your dealer's service center before your vehicle is due for service.

You can check when your dealer's service center was notified.

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle status"
3. Tilt the Controller to the left.
4.  "Teleservice Call"

## Gear shift indicator

### Principle




The system recommends the most efficient gear for the current driving situation.

### General information




Depending on the vehicle equipment and country version, the gear shift indicator is active in the manual mode of the Steptronic transmission and with manual transmission.

Suggestions to upshift or downshift are displayed in the instrument cluster.

## Manual transmission: displaying

Example	Description
	Efficient gear is set.
	Depending on the equipment version, shift to a more efficient gear.
	

## Steptronic transmission: displaying

Example	Description
	Efficient gear is set.
	Depending on the equipment version, shift to a more efficient gear.
	

## Speed Limit Info

### Speed Limit Info

#### Principle

Speed Limit Info shows the current maximum permitted speed in the instrument cluster.

#### General information

The camera at the base of the interior mirror detects traffic signs at the edge of the road as well as overhead sign posts. Traffic signs with extra symbols for wet road conditions, etc., are also detected and compared with the vehicle's onboard data, such as

from the rain sensor, and will be displayed depending on the situation.

With the navigation system, the system takes into account the information stored in the navigation data and also displays speed limits present on routes without signs.


## Safety information

### Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident. Adjust driving style to traffic conditions. Watch the surrounding traffic situation closely, be ready to take over steering and braking at any time, and actively intervene where appropriate.

## Overview

### Camera




The camera is installed near the interior mirror.

Keep the windshield in front of the interior mirror clean and clear.

### Display

Depending on the vehicle equipment, Speed Limit Info is displayed permanently in the instrument cluster or via the trip computer.



Press button on the turn signal lever several times, if needed.

Speed Limit Info is displayed in the instrument cluster.

### Speed Limit Info



The last speed limit detected.



With navigation system: Speed Limit Info is not available.

Speed Limit Info can also be displayed in the Head-up Display.

### System limits

The system function may be limited and may provide incorrect information in the following situations:

- In heavy fog, wet conditions, or snowfall.
- When traffic signs are fully or partially concealed by objects, stickers or paint.
- When driving very close to the vehicle in front of you.
- When driving toward bright lights or strong reflections.

- When the windshield in front of the interior mirror is fogged up, dirty or covered by a sticker, etc.
- In the event of incorrect detection by the camera.
- If the speed limits stored in the navigation system are incorrect.
- In areas not covered by the navigation system.
- When roads deviate from the navigation, such as due to changes in road layout.
- When passing buses or trucks with a speed sticker.
- If the traffic signs are non-conforming.
- When traffic signs that are valid for a parallel road are detected.
- During calibration of the camera immediately after vehicle delivery.

## Selection lists




### General information

Depending on the vehicle equipment, the buttons on the steering wheel and the display in the instrument cluster can be used to display or use the following:


- Current audio source.
- Phone redial.
- Turn on voice activation system.



## Activating a list and adjusting the setting

Button on the steering wheel	Function
	Move selection up.
	Move selection down.
	Confirm the selection.

### Instrument cluster without enhanced features: display



### Instrument cluster with enhanced features: display




## Trip computer

### Principle


The trip computer displays different vehicle data in the instrument cluster, such as average values.

### Calling up information



Press the button on the turn signal lever. Information is displayed in the instrument cluster.

### Information at a glance



Repeatedly pressing the button on the turn signal lever calls up the following information:

- Range.
- GREEN Info.  
When GREEN Mode is activated.
- Average consumption, fuel.
- Average consumption since delivery from the factory.
- Current consumption, fuel.
- Average speed.
- Date.
- Engine temperature display.
- With equipment version with Head-up Display and navigation:

Distance to destination.

When destination guidance is activated in the navigation system.

- With equipment version with Head-up Display and navigation:

Arrival time.

When destination guidance is activated in the navigation system.

- Instrument cluster without enhanced features:

Speed Limit Info.

- Vehicle speed.
- Trip odometer.


The unit of measurement of some information can be changed.

Setting units of measurement, refer to page 48.

## Selecting information

Depending on the vehicle equipment, you can select what information from the trip computer can be accessed in the instrument cluster.

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Displays"
4. "Instrument panel"
5. Select the desired setting.

Settings are stored for the profile currently used.

## Information in detail

### Range

Displays the estimated cruising range available with the remaining fuel.

The range is calculated based on your driving style over the last 20 miles/30 km.

### GREEN info

The achieved range extension may be displayed as a bonus range.

### Average fuel consumption


The average consumption is calculated for the period while the engine is running.

The average consumption is calculated for the distance traveled since the last reset by the trip computer.

### Average speed

Periods in which the vehicle is parked with the engine manually stopped are not included in the calculation of the average speed.

### Resetting average values



Press and hold the button on the turn signal lever.

### Engine temperature display

#### Principle

The current engine temperature, based on a combination of coolant and engine oil temperature is displayed. As soon as the optimum operating temperature has been attained, the indicator is in the center position.

### General information

If the engine oil or coolant, and thus the engine, become too hot, a Check Control message is displayed too.




When the engine temperature is too high, a red indicator light is displayed.




When the engine oil temperature is too high, a red indicator light is displayed.

To check the coolant level, refer to page 288.

### Instrument cluster without enhanced features: display



### Instrument cluster with enhanced features: display



### Distance to destination

Depending on the vehicle equipment, the distance remaining to the destination is displayed if a destination is entered in the navigation system before the trip is started.

The distance to the destination is adopted automatically.

### Arrival time

Depending on the vehicle equipment, the estimated arrival time is displayed if a destination is entered in the navigation system before the trip is started.

The prerequisite is that the time must be correctly set.

### Instrument cluster without additional functions: Speed Limit Info

Speed Limit Info shows the current maximum permitted speed in the instrument cluster.

### Trip computer on the Control Display

#### Principle

The trip computer displays different vehicle data on the Control Display, such as average values.


### General information

Two types of trip computers are available on the Control Display:

- "Onboard info": average values, such as the consumption, are displayed. The values can be reset individually.
- "Trip computer": the values deliver an overview of a specific distance covered and can be reset as often as necessary.

### Calling up the trip computer or onboard computer


Via the Central Information Display (CID):

1.  "My MINI"
2. "Driving information"
3. "Onboard info" or "Trip computer"






## Resetting the on-board computer

Via the Central Information Display (CID):

1.  "My MINI"
2. "Driving information"
3. "Onboard info"
4. "Consumption" or "Speed"
5. "OK"

## Resetting the trip computer

Via the Central Information Display (CID):

1.  "My MINI"
2. "Driving information"
3. "Trip computer"
4. Tilt the Controller to the left, if needed.
  -  "Reset": all values are reset.
  -  "Automatic reset": all values are reset approx. 4 hours after the vehicle has come to a standstill.
5. If necessary, "OK"

## Driving Excitement

### Principle

On the Control Display, sport instruments can be displayed, and the vehicle condition can be checked before the use of the SPORT program.



### Sport instruments

#### General information


On the Control Display, values for power and torque are displayed.

## Displaying sport instruments

Via the Central Information Display (CID):

1.  "My MINI"
2. "Technology in action"
3. "Sport displays"
4.  "Sports instruments"

Via MINI Driving Modes switch:

1. Activate SPORT.
2. "Sport displays"
3.  "Sports instruments"

## Vehicle condition

### General information



The following vehicle and surrounding area data is automatically checked and evaluated in succession:

- Range.
- Engine temperature.
- Outside temperature.
- SPORT program state.


Finally, a total evaluation of the vehicle condition is displayed.

### Checking vehicle condition

Via the Central Information Display (CID):

1.  "My MINI"
2. "Technology in action"
3. "Sport displays"
4.  "Vehicle and surroundings"

Via the MINI Driving Modes switch:

1. Activate SPORT.
2. "Sport displays"
3.  "Vehicle and surroundings"

## Speed warning

### Principle


The system can be used to set a speed limit. A warning will be issued when this speed limit is exceeded.

### General information

The warning is repeated if the vehicle speed exceeds the set speed limit again, after it has dropped below it by 3 mph/5 km/h.


### Adjusting

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle settings"
3. "Speed warning"
4. "Warning at:"
5. Turn the Controller until the desired speed is displayed.
6. Press the Controller.


### Activate/deactivate

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle settings"
3. "Speed warning"
4. "Speed warning"

### Accept current speed as the speed warning

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle settings"
3. "Speed warning"
4. "Select current speed"

## LED ring on the central instrument cluster

### Principle

The LED ring displays light animations to represent specific functions.

### Basic displays

Basic functions, for instance the tachometer, can be set to be displayed continually if so desired.

### Event displays


Functions that are only displayed temporarily, for instance the volume or temperature settings, can be set as event displays.

Several vehicle assistance functions can also be displayed on the LED ring. This display corresponds with the displays of the function in the respective display.

### Example: tachometer

Like the tachometer in the instrument cluster, the light animations of the tachometer's basic display show the current RPMs and the respective RPM warning thresholds.


### Display



- Arrow 1: current RPM.
- Arrow 2: Advance warning zone.
- Arrow 3: warning field.


## Switching on/off LED ring

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Displays"
4. "Center Instrument"
5. "Center Instrument"

## Adjusting the LED ring


Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Displays"
4. "Center Instrument"
5. "Basic display" or "Event display"
6. Select the desired setting.

## Setting the brightness

The brightness can be adjusted when night lighting is active in the instrument cluster.

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Displays"
4. "Center Instrument"
5. "Brightness at night"
6. Turn the Controller until the desired brightness is set.
7. Press the Controller.

The setting is stored for the driver profile currently used.

## Head-up Display

### Principle

This system projects important information into the driver's field of view, for instance the speed.

The driver can get information without averting his or her eyes from the road.

### General information

Follow the instructions for cleaning the Head-up Display. For additional information, see the chapter on care.

### Safety information

#### **Warning**

When extending and retracting the projection screen of the Head-up Display, body parts can be jammed. There is a risk of injury. Make sure that the area of movement of the projection screen is clear when extending and retracting.

#### **NOTICE**

The Head-up Display consists of sensitive components that can easily be scraped or damaged. There is a risk of damage to property, among other potential damage. Do not place any objects on the Head-up Display, attach to system components or plug into the system. Do not move the moving parts manually.

## Overview




The Head-up display is switched on.

## Switching the Head-up Display on/off

When switching on, the projection screen of the Head-up Display is extended. When switching off, the projection screen of the Head-up Display is retracted again.

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Displays"
4. "Head-Up Display"
5. "Head-Up Display"

## Display

### Overview

The following information is displayed on the Head-up Display:

- Vehicle speed.
- Navigation instructions.
- Check Control messages.
- Selection list from the instrument cluster.
- Driver assistance systems.

Some of this information is only displayed briefly as needed.

## Selecting displays in the Head-up Display

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Displays"
4. "Head-Up Display"
5. "Displayed information"
6. Select the desired displays in the Head-up Display.


Settings are stored for the driver profile currently used.

## Setting the brightness

The brightness is automatically adjusted to the ambient brightness.

The base setting can be adjusted manually.

Via the Central Information Display (CID):


1.  "My MINI"
2. "System settings"
3. "Displays"
4. "Head-Up Display"
5. "Brightness"
6. Turn the Controller until the desired brightness is set.
7. Press the Controller.

When the low beams are switched on, the brightness of the Head-up Display can be adjusted using the instrument lighting, refer to page 159.

The setting is stored for the driver profile currently used.

## Adjusting the height

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"

3. "Displays"
4. "Head-Up Display"
5. "Height"
6. Turn the Controller until the desired height is reached.
7. Press the Controller.


The setting is stored for the driver profile currently used.

The height of the Head-up Display can also be stored using the memory function, refer to page 94.

### Setting the rotation

The screen of the Head-up Display can be rotated around its own axis.

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Displays"
4. "Head-Up Display"
5. "Rotation"
6. Turn the Controller until the desired setting is selected.
7. Press the Controller.

The setting is stored for the driver profile currently used.

### Display visibility

The visibility of the displays in the Head-up Display is influenced by the following factors:

- Certain seat positions.
- Objects on the cover of the Head-up Display.
- Sunglasses with certain polarization filters.
- Wet road.
- Unfavorable light conditions.


## John Cooper Works: sport displays in the Head-up Display

### General information

The sport displays in the Head-up Display assist with a sporty driving style.


### Turning on

Via the Central Information Display (CID):

1.  "My MINI"
2. "System settings"
3. "Displays"
4. "Head-Up Display"
5. "Displayed information"
6. "Sport displays"

With navigation system: if the sport displays are switched on, no navigation content will be displayed on the Head-up Display.

### Display



- 1 Vehicle speed
- 2 Shift lights
- 3 Gear display
- 4 Current RPM
- 5 Warning field, speed



## Shift lights

### Principle

The Shift lights in the Head-up Display indicates the optimum shift point. Thus, with a sporty driving style, the best possible vehicle acceleration is achieved.

### Functional requirements

- Steptronic Sport transmission:
  - Manual mode M/S and, if necessary Dynamic Traction Control are activated.
- Press the accelerator pedal all the way down.

### Display

Successive gray illuminated fields indicate the upcoming shift point.

Upshift immediately when the red fields light up.

When the maximum RPM is reached, the entire display flashes red and the fuel supply is interrupted in order to protect the engine.

## Country timer

### Principle

The system provides information on how long and to what degree the vehicle was driven on inclined, uneven, unpaved or snow-covered roads, for example.

### General information

The system consists of the following two menus:

- Country Timer: display of the gradient and unevenness of the routes traveled.
- Country Timer Info: display of the best time and total time since the last reset.

Follow the notes on traveling on poor roads, refer to page 248.

### Call up the menu

Via the Central Information Display (CID):

1.  "My MINI"
2. "MINI Country Timer"
3. Select the desired setting.
  -  : display of the Country Timer.
  -  : display of the Country Timer Info.

### Display of the Country Timer

#### Overview



- Symbols for road gradient and unevenness, arrow 1.
- Category, arrow 2.
- Pulse value, arrow 3.

### Symbols, pulse deflection and pulse value

When the vehicle is being driven on inclined or uneven roads, the corresponding icon lights up, arrow 1. One or more pulse deflections are displayed and the pulse value increases, arrow 3.

### Categories

As the pulse value increases, the vehicle becomes larger and reaches various levels, arrow 2.

## Display of the Country Timer Info

### Best time


The shortest travel time necessary to reach the highest level.

### Total time

The total travel time that the vehicle was driven at the highest level.

### Resetting the Country Timer Info

Via the Central Information Display (CID):

1.  "My MINI"
2. "MINI Country Timer"
3.  "MINI Country Timer Info"
4. Select the desired setting:
  - "Reset record time and display": resetting the best time.
  - "Reset total time": resetting the total time.

## Vehicle status

### General information







The status can be displayed and actions performed for several systems.

### Going to the vehicle status

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle status"
3. Tilt the Controller to the left.

## Information at a glance

Icons	Description
	"Flat Tire Monitor": Status of the flat tire monitor, refer to page 170.
	"Tire Pressure Monitor": status of the Tire Pressure Monitor, refer to page 165.
	"Engine oil level": electronic oil-level check, refer to page 284.
	"Check Control": Check Control messages are stored in the background and can be displayed on the Control Display. Displaying stored Check Control messages, refer to page 139.
	"Service required": displaying service notifications, refer to page 141.
	"Teleservice Call"

# Lights

## Vehicle features and options




This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.




## Overview

### Switches in the vehicle






The light switch element is located next to the steering wheel.

Icon	Function
	Front fog lights.
	Automatic headlight control. Cornering light.
	Lights off. Daytime driving lights.

Icon	Function
	Parking lights.
	Low beams.
	Instrument lighting.

## Parking lights, low beams and roadside parking lights

### General information

Switch position:  ,  , 

If the driver's door is opened when the ignition is switched off, the exterior lighting is automatically switched off.

### Parking lights

Switch position: 

The vehicle is illuminated on all sides.

Do not use the parking lights for extended periods; otherwise, the battery may become discharged and it would then be impossible to start the engine.

Canada: when parking, switch on the one-sided roadside parking light, refer to page [156](#).

### Low beams

Switch position: 


The low beams light up when the ignition is switched on.

## Canada: roadside parking light

### Principle

The vehicle can be illuminated on one side.

### Turning on



With radio-ready state switched off, press the lever either up or down past the resistance point for approx. 2 seconds.

### Turning off

Briefly press the lever to the resistance point in the opposite direction.

## Welcome lights and pathway lighting

### Welcome lights

#### General information

Depending on the vehicle equipment and the ambient brightness, individual lighting functions may be switched on briefly when the vehicle is unlocked.

#### Activate/deactivate

Switch position:  , 

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle settings"

3. "Lighting"
4. "Exterior lighting"
5. "Welcome lights"

The setting is stored for the driver profile currently used.

### Pathway lighting


#### General information

The low beams stay illuminated for a particular time if the high beams are switched on after radio-ready state is switched off.

Canada: the low beams stay illuminated for a particular time if the headlight flasher is switched on after radio-ready state is switched off.

#### Setting the duration

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle settings"
3. "Lighting"
4. "Exterior lighting"
5. "Pathway lighting"
6. Set length of time.

The setting is stored for the driver profile currently used.

## Automatic headlight control

### Principle

The low beams are switched on and off automatically depending on the ambient brightness, for example in tunnels, in twilight or if there is precipitation.

#### General information

A blue sky with the sun low on the horizon can cause the lights to be turned on.

## Activating

Switch position: 

The indicator light in the instrument cluster is illuminated when the low beams are switched on.

## System limits




The automatic headlight control cannot replace your personal judgment of lighting conditions.

For example, the sensors are unable to detect fog or hazy weather. In these situations, turn the lights on manually.


## Daytime driving lights

### General information

Switch position:

-  , 
- Depending on the national-market version: 


The daytime driving lights light up when the ignition is switched on.

Depending on the national-market version: after switching off the ignition, the parking lights will illuminate in position  .

### Activate/deactivate

In some countries, daytime driving lights are mandatory, so it may not be possible to deactivate the daytime running lights.


Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle settings"
3. "Lighting"
4. "Exterior lighting"
5. Select the desired setting.

Settings are stored for the currently used vehicle key.

## Cornering light

### General information

Switch position: 

In tight curves, for instance on mountainous roads or when turning, an additional, cornering light is switched on that lights up the inside of the curve when the vehicle is moving below a certain speed.

The cornering light is automatically switched on depending on the steering-wheel angle or, where applicable, the use of turn signals.

When driving in reverse, the cornering lights may be automatically switched on regardless of the steering-wheel angle.

## Adaptive headlight range control

The adaptive headlight range control feature balances out acceleration and braking processes as well as the vehicle load conditions in order to avoid blinding oncoming traffic. Illumination of the road is optimized.

## Automatic High Beam Assistant

### Principle

The Automatic High Beam Assistant detects other road users early on and automatically switches the high beams on or off depending on the traffic situation.

### General information


The Automatic High Beam Assistant ensures that the high beams are switched on, whenever the traffic situation allows. In the

low speed range, the high beams are not switched on by the system.

The system responds to light from oncoming traffic and traffic driving ahead of you, and to ambient lighting, for instance in towns and cities.

The high beams can be switched on and off manually at any time.

### Activate/deactivate



Switch position, depending on the vehicle equipment:  , 

Press the button on the turn signal lever.



The indicator light in the instrument cluster is illuminated when the low beams are switched on.

The headlights are automatically changed between low beams and high beams.



The blue indicator light in the instrument cluster lights up when the system switches on the high beams.

The Automatic High Beam Assistant is deactivated when manually switching the high beams on and off, refer to page 113.

To reactivate the Automatic High Beam Assistant, press the button on the turn signal lever.

### System limits

The Automatic High Beam Assistant cannot replace the driver's personal judgment of when to use the high beams. In situation

that require this, therefore dimming manually.

The system is not fully functional in the following situations, and driver intervention may be necessary:

- In very unfavorable weather conditions, such as fog or heavy precipitation.
- When detecting poorly-lit road users such as pedestrians, cyclists, horseback riders and wagons; when driving close to train or ship traffic; or at animal crossings.
- In tight curves, on hilltops or in depressions, in crossing traffic or half-obscured oncoming traffic on highways.
- In poorly-lit towns and cities or in the presence of highly reflective signs.
- When the windshield in front of the interior mirror is fogged up, dirty or covered with stickers, etc.

## Fog lights

### Front fog lights

#### Principle

The front fog lights work alongside the low beams to illuminate a wider area of the roadway.

#### Functional requirement

- Low beams are switched on.

#### Turning on/off



Press the button.

The green indicator light lights up if the front fog lights are switched on.

If the automatic headlight control, refer to page 156, is activated, the low beams will come on automatically when you switch on the front fog lights.

When the high beams or headlight flasher are activated, the front fog lights are not switched on.

## Instrument lighting

### Functional requirement

The parking lights or low beams must be switched on to set the brightness.

### Adjusting



Adjust the brightness with the thumbwheel.

## Interior lights

### General information

Depending on the equipment, the interior lights, footwell lights, entry lights, and courtesy lights are controlled automatically.

The thumbwheel for the instrument lighting controls brightness of some of these features.

## Overview



- 1 Interior lights
- 2 Reading lights
- 3 Ambient light

### Switching the interior lights on/off



Press the button.

To switch off permanently: press the button and hold for approx. 3 seconds.

### Switching the reading lights on and off manually



Press the button.

The reading lights are located in the front next to the interior lights.


### Ambient light

#### General information

Depending on the equipment version, lighting can be adjusted for some lights in the car's interior.

#### Activating/deactivating

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle settings"
3. "Lighting"



4. "Interior lighting"
5. "Ambient lighting"
6. Select the desired setting.

Settings are stored for the profile currently used.

### Changing color



Push the switch forward or back: manual color change.




Press the switch forward or backward and hold for approx. 3 seconds until the Ambient Light

flashes several times: automatic color change. Push the switch again to end color changes.

### Setting the brightness

Depending on the equipment, the brightness of the ambient light can be adjusted via the thumbwheel for the instrument lighting or on the Control Display.

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle settings"
3. "Lighting"
4. "Interior lighting"
5. "Brightness"
6. Adjust the brightness.




# Safety

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available

in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## Airbags



- |                                 |               |
|---------------------------------|---------------|
| 1 Front airbag, driver          | 4 Side airbag |
| 2 Front airbag, front passenger | 5 Knee airbag |
| 3 Head airbag                   |               |

### Front airbags

Front airbags help protect the driver and the front passenger by responding to frontal impacts in which seat belts alone would not provide adequate protection.

### Side airbag

In the event of a side collision, the side airbag protects the side of the body in the chest and lap area.

## Head airbag

In the event of a side collision, the head airbag protects the head.

## Ejection Mitigation

The head airbag system is designed as an ejection mitigation countermeasure to reduce the likelihood of ejections of vehicle occupants through side windows during rollovers or side collision events.

## Knee airbag

Depending on the national-market version: The knee airbag protects the legs in the event of a frontal impact.

## Protective effect

Airbags are not deployed in every impact situation, for instance in less severe accidents or rear-end collisions.

## Information on optimum protective effect of the airbags

### Warning

If the seat position is incorrect or the deployment area of the airbags is impaired, the airbag system cannot provide protection as intended and may cause additional injuries due to deployment. There is a risk of injury or danger to life. Follow the information on achieving the optimum protective effect of the airbag system.

- Keep a distance from the airbags.
- Always grasp the steering wheel on the steering wheel rim. Hold your hands at the 3 o'clock and 9 o'clock positions, to keep the risk of injury to your hands or arms as low as possible when the airbag is deployed.
- Adjust seat and steering wheel so that hands can be crossed over the steering

wheel. Select the settings so that the shoulder rests against the backrest when crossing the hands and the upper body is as far back as possible while still maintaining a comfortable grip on the steering wheel.

- Make sure that the front passenger is sitting correctly, i.e., keeps his or her feet and legs in the footwell and does not support them on the dashboard.
- Make sure that occupants keep their heads away from the side airbag.
- There should be no additional persons, animals or objects between an airbag and a person.
- Dashboard and windshield on the passenger's side must stay clear - do not attach adhesive film or coverings and do not attach brackets or cables, for instance for navigation devices or mobile phones.
- Do not bond the airbag cover panels with adhesive, do not cover them or modify them in any way.
- Do not use the cover of the front airbag on the passenger's side as a storage area.
- Do not attach slip covers, seat cushions or other objects to the front seats that are not specifically suited for seats with integrated side airbags.
- Do not hang pieces of clothing, such as jackets, over the backrests.
- Never modify either the individual components or the wiring in the airbag system. This also applies to steering wheel covers, the dashboard, and the seats.
- Do not disassemble the airbag system.

Even when you follow all instructions very closely, injury from contact with the airbags cannot be fully ruled out in certain situations.

The ignition and inflation noise may lead to short-term and, in most cases, temporary hearing impairment in sensitive occupants. Vehicle modifications for a person with disabilities may affect the air bag system; contact MINI Customer Relations for further information.

Warnings and information on the airbags are also found on the sun visors.

## Operational readiness of the airbag system

### Safety information

#### Warning

Individual components can be hot after deployment of the airbag system. There is a risk of injury. Do not touch individual components.

#### Warning

Improperly executed work can lead to failure, malfunction or unintentional deployment of the airbag system. In the case of a malfunction, the airbag system might not deploy as intended despite the accident severity. There is a risk of injury or danger to life. Have the airbag system checked, repaired, disassembled and scrapped by a dealer's service center or another qualified service center or repair shop.

### Correct function



When the ignition is switched on, the warning light in the instrument cluster lights up briefly, thereby indicating the operational readiness of the entire airbag system and the seat belt tensioners.

## Airbag system fault

- Warning light does not come on when the ignition is switched on.
- The warning light lights up continuously.

## Automatic deactivation of the front passenger airbags

### Principle

The system reads if the front passenger seat is occupied by measuring the human body's resistance.

Front, knee, and side airbag on the front passenger's side are activated or deactivated.

### General information

Before transporting a child on the front passenger seat, refer to the safety information and instructions for children on the front passenger seat, see Children.

### Safety information

#### Warning

To ensure the front passenger airbag function, the system must be able to detect whether a person is sitting in the front passenger seat. The entire seat surface must be used for this purpose. There is a risk of injury or danger to life. Make sure that the front passenger keeps his or her feet in the footwell.

## Fault of the automatic deactivation system

When transporting older children and adults, the front passenger airbags may be deactivated in certain seat positions. In this case, the indicator light for the front passenger airbags lights up.

In this case, change the seat position so that the front passenger airbags are activated and the indicator light goes out.

If it is not possible to activate the airbags, have the person sit in the rear seat.

To enable accurate recognition of the occupied seat surface

- Do not attach covers, cushions, ball mats or other items to the front passenger seat unless they are specifically determined to be safe for use on the front passenger seat.
- Do not place any electronic devices on the front passenger seat if a child restraint system is to be installed on it.
- Do not place objects under the seat that could press against the seat from below.
- No moisture in or on the seat.

### Indicator light for the front passenger airbags



The indicator light for the front passenger airbags indicates the operating state of the front passenger airbags.

The light indicates whether the airbags are either activated or deactivated.



- The indicator light lights up when a child is properly seated in a child restraint system or when the seat is empty. The airbags on the

passenger's side are not activated.

- The indicator light does not light up when, for instance a correctly seated person of sufficient size is detected on the seat. The airbags on the passenger's side are activated.

### Detected child restraint systems

The system generally detects children seated in a child restraint system, particularly in child restraint systems required by NHTSA at the point in time when the vehicle was manufactured. After installing a child restraint system, make sure that the indicator light for the front passenger airbags lights up. This indicates that the child restraint system has been detected and the front passenger airbags are not activated.

### Strength of the driver's and front passenger airbag

The power that deploys the driver's/front passenger airbags depends on the position of the driver's/front passenger seat.

To maintain the accuracy of this function over the long-term, calibrate the front seats as soon as a relevant Check Control message is displayed. A message also appears on the Control Display.

### Calibrating the front seats

#### **Warning**

There is a risk of jamming when moving the seats. There is a risk of injury or risk of damage to property. Make sure that the travel path of the seat is clear prior to any adjustment.

An appropriate Check Control message is displayed.

1. Move the respective seat all the way forward.
2. Move the respective seat forward again. The seat moves forward briefly.
3. Readjust the seat to the desired seat position.

The calibration procedure is completed when the Check Control message disappears.

If the message continues to be displayed, repeat the calibration.

If the message does not disappear after a repeat calibration, have the system checked as soon as possible.

## Tire pressure monitor

### Principle

The system monitors tire pressure in the four mounted tires. The system warns you if there is a significant loss of pressure in one or more tires.

### General information

Sensors in the tire valves measure the tire inflation pressure and, depending on the model, the tire temperature.

Further information and instructions on using the system can also be found under Tire inflation pressure, refer to page 260.

### Functional requirements

The following prerequisites must be met for the system; otherwise, reliable message of a tire pressure loss is not assured:

- After a tire or wheel change, a reset was performed with the correct tire inflation pressure.
- After the tire inflation pressure was adjusted to a new value, a reset was performed.
- Wheels with TPM wheel electronics.

### Status display

#### Current status

The system status can be displayed on the Control Display, e.g., whether or not the system is active.

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle status"
3.  "Tire Pressure Monitor"

The current status is displayed.

### Tire conditions

#### General information

Tire and system status are indicated by the color of the wheels and a text message on the Control Display.

#### All wheels green

System is active and will issue a warning related to the tire inflation pressures stored during the last reset.

#### One to four yellow wheels

A flat tire or major tire pressure loss has occurred in the indicated tires.

#### Gray wheels

It may not be possible to identify tire pressure losses.

Possible causes:



- Malfunction.
- The system is being reset.

### Additional information

The status control display additionally shows the current tire inflation pressures. The values shown are instantaneous measurements and may vary depending on driving or weather conditions.

### Resetting the system

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle status"
3.  "Tire Pressure Monitor"
4. Start the engine but do not drive off.
5. Reset tire pressure: "Perform reset".
6. Drive away.

The wheels are displayed in gray and the following is displayed "Resetting Tire Pressure Monitor...".

After a travel time of several minutes, the set tire inflation pressures are accepted as reference values. The resetting process is completed automatically while driving.

After successful completion of the reset, the tires appear in green on the Control Display and "Tire Pressure Monitor active. See label for recommended pressures." is displayed.

You may interrupt this trip at any time. When you continue driving the reset resumes automatically.

### Messages

#### General information

A low tire inflation pressure may cause the DSC Dynamic Stability Control to be switched on.

### Safety information



#### Warning

A damaged regular tire with low or missing tire inflation pressure impacts handling, such as steering and braking response. Runflat tires can maintain limited stability. There is a risk of accident. Do not continue driving if the vehicle is equipped with normal tires. Follow the information on runflat tires and continued driving with these tires.

#### If a tire inflation pressure check is required

#### Message

An icon with a Check Control message appears on the Control Display.

Icon	Possible cause
	The system has detected a wheel change, but no reset was done. No reset was performed for the system. The system issues a warning based on the tire inflation pressures stored during the last reset. Inflation was not carried out according to specifications.
	The tire inflation pressure has fallen below the level of the last reset.

#### Measure

1. Check the tire pressure and correct as needed.
2. Reset the system.


## If the tire inflation pressure is too low

### Message



A yellow warning light is illuminated in the instrument cluster.

In addition, an icon with a Check Control message appears on the Control Display.

Icon	Possible cause
	<p>There is a tire pressure loss.</p> <p>No reset was performed for the system. The system issues a warning based on the tire inflation pressures stored during the last reset.</p>

### Measure

1. Reduce your speed and drive moderately. Do not exceed a speed of 80 mph/130 km/h.
2. At the next opportunity, for instance filling station, check and correct the tire inflation pressure in all four tires, if necessary.
3. Reset the system.


## If there is a significant tire pressure loss

### Message



A yellow warning light is illuminated in the instrument cluster.

In addition, an icon with the affected tire appears in a Check Control message on the Control Display.

Icon	Possible cause
	<p>There is a flat tire or a major tire pressure loss.</p> <p>No reset was performed for the system. The system issues a warning based on the tire inflation pressures stored during the last reset.</p>

### Measure

1. Reduce your speed and stop cautiously. Avoid sudden braking and steering maneuvers.
2. Check whether the vehicle is fitted with standard tires or runflat tires. Runflat tires, refer to page 269, are labeled with a circular icon containing the letters RSC marked on the tire sidewall.

## Actions in the event of a flat tire

### Standard tires

1. Identify the damaged tire.  
To do this, check the tire pressure in all four tires, for instance using the tire pressure display of a flat tire kit.

If the tire pressure in all four tires is correct, the Tire Pressure Monitor may not have been reset. In this case, perform the reset.

If the tire inflation pressure in all four tires is correct, the Flat Tire Monitor may not have been initialized. In this case, initialize the system.

If identification of flat tire damage is not possible, please contact a dealer's service center or another qualified service center or repair shop.

2. Repair the flat tire, e.g., with a flat tire kit or by changing the wheel.

Use of sealing compound, for instance from the flat tire kit, may damage the wheel elec-

tronics. In this case, have the electronics checked and replaced at the next opportunity.

## Runflat tires

### Safety information

#### **Warning**

The vehicle handles differently when a runflat tire has insufficient or no tire pressure; for instance, reduced directional stability when braking, braking distances are longer and the self-steering properties will change. There is a risk of accident. Drive moderately and do not exceed a speed of 50 mph/80 km/h.

### Maximum speed

You may continue driving with a damaged tire at speeds up to 50 mph/80 km/h.

### Continued driving with a flat tire

If continuing to drive with a damaged tire:

1. Avoid sudden braking and steering maneuvers.
2. Do not exceed a speed of 50 mph/80 km/h.
3. Check the tire inflation pressure in all four tires at the next opportunity.

If the tire pressure in all four tires is correct, the Tire Pressure Monitor may not have been reset. In this case, perform the reset.

### Possible distance travelled with a depressurized tire

The distance travelled for which it may be possible to drive safely varies depending on how the vehicle is loaded and used, e.g., speed, road conditions, outside temperature. The distance travelled may be less but may

also be more if an economical driving style is used.

If the vehicle is loaded with an average weight and used under favorable conditions, the distance travelled for which it may be safe to drive may be up to 50 miles/80 km.

### Vehicle handling with damaged tires

Vehicles driven with a damaged tire will handle differently, potentially leading to conditions such as the following:

- Greater likelihood of skidding of the vehicle.
- Longer braking distances.
- Changed self-steering properties.

Modify your driving style. Avoid abrupt steering maneuvers or driving over obstacles, for instance curbs or potholes.

### Final tire failure

Vibrations or loud noises while driving can indicate the final failure of a tire.

Reduce speed and stop; otherwise, pieces of the tire could come loose and cause an accident.

Do not continue driving. Contact a dealer's service center or another qualified service center or repair shop.

## System limits

### Temperature

The tire inflation pressure depends on the tire's temperature.

Driving or exposure to the sun will increase the tire temperature, thus increasing the tire inflation pressure.

The tire inflation pressure is reduced when the tire temperature falls again.

These circumstances may cause a warning when temperatures fall very sharply.



## Sudden tire pressure loss

The system cannot indicate sudden serious tire damage caused by external circumstances.

## Failure performing a reset

The system does not function properly if a reset has not been carried out, for instance a flat tire is reported though tire inflation pressures are correct.

## Malfunction



The yellow warning light flashes and is then illuminated continuously. A Check Control message is displayed.

It may not be possible to identify tire pressure losses.

Examples and recommendations in the following situations:

- A wheel without TPM wheel electronics, for instance an emergency wheel, is mounted: have it checked by a dealer's service center or another qualified service center or repair shop as needed.
- Malfunction: have system checked by a dealer's service center or another qualified service center or repair shop.
- The system was unable to complete the reset. Perform a system reset again.
- Fault caused by systems or devices with the same radio frequency: after leaving the area of the interference, the system automatically becomes active again.

## Declaration according to NHTSA/FMVSS 138 Tire Pressure Monitoring System

Each tire, including the spare (if provided) should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label. (If your vehicle has tires of a different

size than the size indicated on the vehicle placard or tire inflation pressure label, you should determine the proper tire inflation pressure for those tires.) As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale when one or more of your tires is significantly under-inflated. Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly under-inflated tire causes the tire to over-heat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability. Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale. Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly. Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires

and wheels allow the TPMS to continue to function properly.

## Flat Tire Monitor

### Principle

The system detects tire pressure loss on the basis of rotation speed differences between the individual wheels while driving.

In the event of a tire pressure loss, the diameter and therefore the rotational speed of the corresponding wheel changes. The difference will be detected and reported as a flat tire.

The system does not measure the actual inflation pressure in the tires.

### Functional requirements

The following prerequisites must be met for the system; otherwise, reliable message of a tire pressure loss is not assured:

- After a tire or wheel change, an initialization was performed with the correct tire inflation pressure.
- After the tire pressure was adjusted to a new value, an initialization was performed.

### Status display

The current status of the flat tire monitor can be displayed, e.g., whether the flat tire monitor is active.

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle status"
3.  "Flat Tire Monitor"

The status is displayed.

### Initialization required

An initialization must be performed in the following situations:



- After the tire inflation pressure has been adjusted.
- After a tire or wheel change.

### Performing initialization

When initializing, the set tire inflation pressures serve as reference values in order to detect a flat tire. Initialization is started by confirming the tire inflation pressures.

Do not initialize the system when driving with tire chains.

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle status"
3.  "Flat Tire Monitor"
4. Start the engine but do not drive off.
5. Start the initialization with: "Perform reset".
6. Drive away.

The initialization is completed while driving, which can be interrupted at any time. The initialization automatically continues when driving continues.

### Messages

#### General information

When a flat tire is indicated, DSC Dynamic Stability Control is switched on, if needed.

#### Safety information

##### Warning

A damaged regular tire with low or missing tire inflation pressure impacts handling, such as steering and braking response. Runflat tires can maintain limited


stability. There is a risk of accident. Do not continue driving if the vehicle is equipped with normal tires. Follow the information on runflat tires and continued driving with these tires.

### Indication of a flat tire



A yellow warning light is illuminated in the instrument cluster.

In addition, an icon with a Check Control message appears on the Control Display.

Icon	Possible cause
	There is a flat tire or a major tire pressure loss.

### Measure

1. Reduce your speed and stop cautiously. Avoid sudden braking and steering maneuvers.
2. Check whether the vehicle is fitted with standard tires or runflat tires.

Runflat tires, refer to page 269, are labeled with a circular icon containing the letters RSC marked on the tire sidewall.

### Actions in the event of a flat tire

#### Standard tires

1. Identify the damaged tire.  
To do this, check the tire pressure in all four tires, for instance using the tire pressure display of a flat tire kit.  
If the tire pressure in all four tires is correct, the Tire Pressure Monitor may not have been reset. In this case, perform the reset.  
If the tire inflation pressure in all four tires is correct, the Flat Tire Monitor may not have been initialized. In this case, initialize the system.

If identification of flat tire damage is not possible, please contact a dealer's service center or another qualified service center or repair shop.

2. Repair the flat tire, e.g., with a flat tire kit or by changing the wheel.

Use of sealing compound, for instance from the flat tire kit, may damage the wheel electronics. In this case, have the electronics checked and replaced at the next opportunity.

### Runflat tires

#### Safety information

##### Warning

The vehicle handles differently when a runflat tire has insufficient or no tire pressure; for instance, reduced directional stability when braking, braking distances are longer and the self-steering properties will change. There is a risk of accident. Drive moderately and do not exceed a speed of 50 mph/80 km/h.

#### Maximum speed

You may continue driving with a damaged tire at speeds up to 50 mph/80 km/h.

#### Continued driving with a flat tire

If continuing to drive with a damaged tire:

1. Avoid sudden braking and steering maneuvers.
2. Do not exceed a speed of 50 mph/80 km/h.
3. Check the tire inflation pressure in all four tires at the next opportunity.

If the tire inflation pressure in all four tires is correct, the Flat Tire Monitor may not have been initialized. In this case, initialize the system.



### Possible distance travelled with a depressurized tire

The distance travelled for which it may be possible to drive safely varies depending on how the vehicle is loaded and used, e.g., speed, road conditions, outside temperature. The distance travelled may be less but may also be more if an economical driving style is used.

If the vehicle is loaded with an average weight and used under favorable conditions, the distance travelled for which it may be safe to drive may be up to 50 miles/80 km.

### Vehicle handling with damaged tires

Vehicles driven with a damaged tire will handle differently, potentially leading to conditions such as the following:

- Greater likelihood of skidding of the vehicle.
- Longer braking distances.
- Changed self-steering properties.

Modify your driving style. Avoid abrupt steering maneuvers or driving over obstacles, for instance curbs or potholes.

### Final tire failure

Vibrations or loud noises while driving can indicate the final failure of a tire.

Reduce speed and stop; otherwise, pieces of the tire could come loose and cause an accident.

Do not continue driving. Contact a dealer's service center or another qualified service center or repair shop.

### System limits

The system could be delayed or malfunction in the following situations:

- A natural, even tire pressure loss in all four tires will not be recognized. There-

fore, check the tire inflation pressure regularly.

- Sudden serious tire damage caused by external circumstances cannot be recognized in advance.
- When the system has not been initialized.
- When driving on a snowy or slippery road.
- Sporty driving style: slip on traction wheels, high lateral acceleration (drifting).
- When driving with tire chains.

## Intelligent Safety

### Principle

Intelligent Safety enables central operation of the driver assistance systems.

The intelligent safety systems can help prevent an imminent collision.

- Forward Collision Warning with city collision mitigation, refer to page 173.
- Pedestrian Warning with City light braking function, refer to page 177.
- Lane departure warning, refer to page 180.

### Safety information

#### Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident. Adjust driving style to traffic conditions. Watch the surrounding traffic situation closely, be ready to take

over steering and braking at any time, and actively intervene where appropriate.

### Warning

Indicators and warnings cannot serve as a substitute for the driver's personal judgment. Due to its limits, the system may not issue warnings or reactions, or these may be issued late or in a manner that is not consistent with their normal use. There is a risk of accident. Adjust driving style to traffic conditions. Watch surrounding traffic closely and actively intervene where appropriate.

### Warning

Due to system limits, individual functions can malfunction during tow-starting/towing with the Intelligent Safety systems activated. There is a risk of accident. Switch all Intelligent Safety systems off prior to tow-starting/towing.

## Overview

### Button in the vehicle



Intelligent Safety button

## Turning on/off

Some Intelligent Safety systems are automatically active after every departure. Some Intelligent Safety systems activate according to the last setting.



Press button briefly:

- The menu for the Intelligent Safety system is displayed. The systems are individually switched off according to their respective settings.
- LED lights up orange or goes out respective to their individual settings.

Adjust the settings as needed. The individual settings are stored for the driver profile currently in use.



Press button again:

- All Intelligent Safety systems are switched on.
- The LED lights up green.



Hold down button:

- All Intelligent Safety systems are switched off.
- The LED goes out.

## Forward Collision Warning with city collision mitigation

### Principle

The system may prevent some accidents. In the event of an accident, the system may reduce impact speed.

The system sounds a warning for a possible risk of collision and activates brakes independently, if needed.

The automatic brake intervention occurs with limited force and duration.

A camera at the base of the interior mirror controls the system.

The Forward Collision Warning is available even if cruise control has been deactivated.

The driver's own driving behavior is taken into account in the reactions of the system, e.g., if you deliberately approach a vehicle, the Forward Collision Warning and the brake intervention will take place later.

### General information


The system issues a two-phase warning of an imminent risk of collision at speeds from approx. 3 mph/5 km/h. The timing of warnings may vary with the current driving situation.

If necessary, a brake intervention will occur. Depending on the equipment and national-market version, the brake intervention will occur up to approx.

35 mph/60 km/h or up to approx.

35 mph/60 km/h.

### Detection range



Objects that the system can detect are taken into account.

### Safety information

#### ⚠ Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident. Adjust driving style to traffic conditions. Watch the surrounding traffic situation closely, be ready to take over steering and braking at any time, and actively intervene where appropriate.

#### ⚠ Warning

Indicators and warnings cannot serve as a substitute for the driver's personal judgment. Due to its limits, the system may not issue warnings or reactions, or these may be issued late or in a manner that is not consistent with their normal use. There is a risk of accident. Adjust driving style to traffic conditions. Watch surrounding traffic closely and actively intervene where appropriate.

#### ⚠ Warning

Due to system limits, individual functions can malfunction during tow-starting/towing with the Intelligent Safety systems activated. There is a risk of accident. Switch all Intelligent Safety systems off prior to tow-starting/towing.


## Overview

### Button in the vehicle



 Intelligent Safety button

### Camera



The camera is installed near the interior mirror.


Keep the windshield in front of the interior mirror clean and clear.

## Turning on/off

### Turning on automatically

The system is automatically active when the vehicle is turned on.


### Switching on/off manually


-  Press button briefly:
- The menu for the Intelligent Safety system is displayed. The systems are individually

switched off according to their respective settings.

- LED lights up orange or goes out respective to their individual settings.


Adjust the settings as needed. The individual settings are stored for the driver profile currently in use.

-  Press button again:
- All Intelligent Safety systems are switched on.
  - The LED lights up green.

-  Hold down button:
- All Intelligent Safety systems are switched off.
  - The LED goes out.

## Setting the warning time

The warning time can be set via the Central Information Display (CID).



1.  "My MINI"
2. "Vehicle settings"
3. "Intelligent Safety"
4. "Warning time"
5. Select the desired setting.

The selected warning time is stored for the driver profile currently in use.

## Warning with light braking function

### Display

A warning symbol appears in the instrument cluster and in the Head-up Display if a collision with a detected vehicle is imminent.

Icon	Measure
	Icon lights up red: prewarning. Brake and increase distance.
	Symbol flashes red and an acoustic signal sounds: acute warning. Brake and make an evasive maneuver, if necessary.

### Prewarning

This prewarning is provided, for instance when there is impending risk of a collision or the distance to the vehicle ahead is too small.

If a prewarning is provided, respond by braking as warranted.

### Acute warning with light braking function

An acute warning is displayed when there is an imminent danger of collision due to the vehicle approaching another object at a high speed.

The driver must intervene actively when there is an acute warning. If necessary, the driver is assisted by a minor automatic brake intervention in a possible risk of collision.

Acute warnings may be provided even when there has been no prior warning.

### Brake intervention

The warning prompts the driver to intervene. When a warning occurs, the maximum braking force is used when the brake is applied. In order to activate the Brake Assistant function, you must apply the brakes quickly and forcefully. If there is a risk of collision, the system may assist with a minor brake intervention. When the vehicle is traveling at a low speed, the vehicle may come to a complete stop.

Manual transmission: during a brake intervention up to a complete stop, the engine may be shut down.

The brake intervention can be interrupted by stepping on the accelerator pedal or by actively moving the steering wheel.

The system's ability to detect objects may be limited in some circumstances. Refer to the information in this Owner's Manual regarding the limitations of the system and actively intervene as warranted.

### System limits

#### Safety information

#### Warning

The system is designed to operate in certain conditions and circumstances. Due to conditions or other factors, the system may not respond. There may be a risk of accident or risk of damage to property. Actively intervene as warranted. Refer to the information in this Owner's Manual regarding the scope of the system's operation and limitations.

### Detection range

The system's detection capability is limited. Thus, a system response might not come or might come late.

The following situations may not be detected, for example:

- Slow moving vehicles when you approach them at high speed.
- Vehicles that suddenly swerve in front of you, or strongly decelerating vehicles.
- Vehicles with an unusual rear view.
- Two-wheeled vehicles ahead of you.



## Functional limitations

The system may be limited in the following situations:

- In heavy fog, wet conditions, or snow-fall.
- In tight curves.
- If the camera field of view or the wind-shield is dirty or covered.
- If the driving stability control systems are deactivated, for instance DSC OFF.
- Up to 10 seconds after the start of the engine via the Start/Stop button.
- During calibration of the camera immediately after vehicle delivery.
- If there are constant blinding glares because of oncoming light, for instance from the sun low in the sky.

## Warning sensitivity

The more sensitive the warning settings are, the more warnings are displayed. Therefore, there may also be an excess of unwarranted warnings and responses.

## Pedestrian Warning with City light braking function

### Principle

The system may prevent some accidents with pedestrians.

When driving in the city speed range, the system will issue a warning if there is imminent risk of a collision with pedestrians, and support this with a light braking function.

The camera at the base of the interior mirror controls the system.


### General information

In sufficiently bright conditions, the system issues a warning of a possible risk of colli-

sion with pedestrians and assists with brake intervention just before a collision in the speed range from approx. 6 mph/10 km/h to approx. 35 mph/60 km/h.

The system reacts to people who are within the detection range of the system.

### Detection range



The detection range in front of the vehicle is divided into two areas:

- Central area, arrow 1, directly in front of the vehicle.
- Extended area, arrows 2, to the right and left of the central area.

A collision is imminent if pedestrians are located within the central area. A warning is issued about pedestrians who are located within the extended area only if they are moving in the direction of the central area.

### Safety information

#### Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident. Adjust driving style to traffic conditions. Watch the surrounding traffic situation closely, be ready to take over steering and braking at any time, and actively intervene where appropriate.

**Warning**

Indicators and warnings cannot serve as a substitute for the driver's personal judgment. Due to its limits, the system may not issue warnings or reactions, or these may be issued late or in a manner that is not consistent with their normal use. There is a risk of accident. Adjust driving style to traffic conditions. Watch surrounding traffic closely and actively intervene where appropriate.

**Warning**

Due to system limits, individual functions can malfunction during tow-starting/towing with the Intelligent Safety systems activated. There is a risk of accident. Switch all Intelligent Safety systems off prior to tow-starting/towing.


**Overview**

**Button in the vehicle**



 Intelligent Safety button

**Camera**



The camera is installed near the interior mirror.


Keep the windshield in front of the interior mirror clean and clear.


**Turning on/off**


**Turning on automatically**

The system is automatically active when the vehicle is turned on.

**Switching on/off manually**

-  Press button briefly:
  - The menu for the Intelligent Safety system is displayed. The systems are individually switched off according to their respective settings.
  - LED lights up orange or goes out respective to their individual settings.
- Adjust the settings as needed. The individual settings are stored for the driver profile currently in use.

-  Press button again:
  - All Intelligent Safety systems are switched on.
  - The LED lights up green.

-  Hold down button:

- All Intelligent Safety systems are switched off.
- The LED goes out.

## Warning with light braking function

### Display

If a collision with a detected person is imminent, a warning symbol appears on the instrument cluster and in the Head-up Display.



The red icon is displayed and a signal sounds.

Intervene immediately by braking or make an evasive maneuver.

### Brake intervention

The warning prompts the driver to intervene. When a warning occurs, the maximum braking force is used when the brake is applied. In order to activate the Brake Assistant function, you must apply the brakes quickly and forcefully. If there is a risk of collision, the system may assist with a minor brake intervention. When the vehicle is traveling at a low speed, the vehicle may come to a complete stop.

Manual transmission: during a brake intervention up to a complete stop, the engine may be shut down.

The brake intervention can be interrupted by stepping on the accelerator pedal or by actively moving the steering wheel.

The system's ability to detect objects may be limited in some circumstances. Refer to the information in this Owner's Manual regarding the limitations of the system and actively intervene as warranted.

## System limits

### Safety information

#### Warning

The system is designed to operate in certain conditions and circumstances. Due to conditions or other factors, the system may not respond. There may be a risk of accident or risk of damage to property. Actively intervene as warranted. Refer to the information in this Owner's Manual regarding the scope of the system's operation and limitations.

### Detection range

The detection capability of the camera is limited.

Thus, a warning might not be issued or be issued late.

The following situations may not be detected, for example:

- Partially covered pedestrians.
- Pedestrians that are not detected as such because of the viewing angle or contour.
- Pedestrians outside of the detection range.
- Pedestrians having a body size less than 32 in/80 cm.

### Functional limitations

The system may be limited or may not be available in the following situations:

- In heavy fog, wet conditions, or snowfall.
- In tight curves.
- If the camera field of view or the windshield is dirty or covered.
- If the driving stability control systems are deactivated, for instance DSC OFF.

- Up to 10 seconds after the start of the engine via the Start/Stop button.
- During calibration of the camera immediately after vehicle delivery.
- If there are constant blinding glares because of oncoming light, for instance from the sun low in the sky.
- When it is dark outside.

## Lane departure warning

### Principle

The lane departure warning alerts when the vehicle on roads with lane markings is about to leave the lane.

### General information

Depending on the country version, the system issues a warning at speeds between 35 mph/55 km/h and 45 mph/70 km/h.

Warnings are issued by means of a steering wheel vibration. The time of the warning may vary depending on the current driving situation.

The system does not provide a warning if the turn signal is set before exiting the lane.

### Safety information

#### Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing road and traffic situation. There is a risk of accident. Adjust driving style to traffic conditions. Watch surrounding traffic closely and actively intervene where appropriate. Do not jerk the steering wheel in response to a warning.

#### Warning

Indicators and warnings cannot serve as a substitute for the driver's personal judgment. Due to its limits, the system may not issue warnings or reactions, or these may be issued late or in a manner that is not consistent with their normal use. There is a risk of accident. Adjust driving style to traffic conditions. Watch surrounding traffic closely and actively intervene where appropriate.


## Overview

### Button in the vehicle



 Intelligent Safety button

### Camera



The camera is installed near the interior mirror.

Keep the windshield in front of the interior mirror clean and clear.

## Turning on/off

### Turning on automatically

The lane departure warning is automatically activated after departure, if the function was switched on the last time the engine was stopped.

### Switching on/off manually



Press button briefly:

- The menu for the Intelligent Safety system is displayed. The systems are individually switched off according to their respective settings.
- LED lights up orange or goes out respective to their individual settings.

Adjust the settings as needed. The individual settings are stored for the driver profile currently in use.



Press button again:

- All Intelligent Safety systems are switched on.
- The LED lights up green.



Hold down button:

- All Intelligent Safety systems are switched off.
- The LED goes out.

### Display in the instrument cluster



The icon illuminates green: at least one lane marking was detected and warnings can be issued.

## Output of warning

### If you leave the lane

If you leave the lane and if a lane marking has been detected, the steering wheel vibrates.

If the turn signal is switched on before changing the lane, a warning is not issued.

### End of warning

The warning is canceled in the following situations:

- Automatically after approx. 3 seconds.
- When returning to your own lane.
- When braking hard.
- When blinking.

## System limits

### Safety information

#### Warning

The system is designed to operate in certain conditions and circumstances. Due to conditions or other factors, the system may not respond. There may be a risk of accident or risk of damage to property. Actively intervene as warranted. Refer to the information in this Owner's Manual regarding the scope of the system's operation and limitations.

### Functional limitations

The system may be limited in the following situations:

- In heavy fog, wet conditions, or snowfall.
- In the event of missing, worn, poorly visible, merging, diverging, or multiple lane markings such as in construction areas.

- When lane markings are covered in snow, ice, dirt or water.
- In tight curves or on narrow roads.
- When lane markings are covered by objects.
- When driving very close to the vehicle in front of you.
- When driving toward bright lights.
- When the windshield in front of the interior mirror is fogged up, dirty or covered with stickers, etc.
- During calibration of the camera immediately after vehicle delivery.

## Manual Speed Limiter

### Principle

The system can be used to set a speed limit, for instance to prevent the vehicle from exceeding speed limits.

### General information

The system can limit the speed, starting at a value of 20 mph/30 km/h. The vehicle can be driven at any speed below the set speed limit.

### Exceeding the speed limit

In special situations, the speed limit can be exceeded by intentional acceleration.

When the vehicle speed exceeds the set speed limit, a warning is issued.




### No brake intervention

If the set speed limit is reached or unintentionally exceeded, such as when driving downhill, the vehicle is not actively braked.

When the speed limit is set during a trip to a value below the driving speed, the vehicle coasts until its driving speed drops below the set speed limit.

## Overview

### Steering wheel buttons, left

Button	Function
	System on/off.
	Increase the speed limit.
	Reduce the speed limit.

## Operation

### Turning on

 Press the button on the steering wheel.

The current speed is accepted as the speed limit.

If the system is switched on while the vehicle is stationary or driving at low speeds, 20 mph/30 km/h is set as the speed limit.

The set speed is displayed under the LIMIT or LIM indicator.

When the speed limit is activated, Dynamic Stability Control is switched on as necessary.

### Turning off



 Press the button on the steering wheel.





The system switches off automatically in the following situations, for example:

- When shifting into reverse gear.
- When the engine is switched off.
- When cruise control is switched on.
- When activating Dynamic Traction Control or deactivating Dynamic Stability Control.

The displays turn off.

### Changing the speed limit

 or  button: press up or down repeatedly until the desired speed limit is set.

-  or  button: each time it is pressed to the resistance point, the speed limit increases or decreases by 1 mph, 1 km/h.
-  or  button: each time it is pressed past the resistance point, the desired speed changes by a maximum of 5 mph/10 km/h.

When the speed limit is set during a trip to a value below the current speed, the vehicle coasts until it drops to the set speed limit.

### Exceeding the speed limit

The speed limit can be exceeded intentionally.

Press the accelerator pedal all the way down to intentionally exceed the set speed limit.

When the vehicle speed drops below the set speed limit, the limit is automatically reactivated.

### Warning when the speed limit is exceeded

#### Visual warning


If the set speed limit is exceeded, the LIMIT or LIM indicator flashes while the vehicle speed is greater than the speed limit.

#### Acoustic warning


- If the speed limit is exceeded unintentionally, a signal sounds.
- When the speed limit is reduced to below the vehicle speed while driving, a signal sounds after approx. 30 seconds.
- When the speed limit is intentionally exceeded by stepping on the accelerator

pedal all the way down, there is no signal.

### Displays in the instrument cluster

 Instrument cluster without enhanced features:

The desired speed is displayed under the LIMIT indicator.



Instrument cluster with enhanced features:

The desired speed is displayed under the LIM indicator.

- The indicator does not light up: the system is switched off.
- The indicator lights up green: the system is active.
- Display flashes green: set speed limit exceeded.

### Displays in the Head-up Display

The information from the Speed Limiter can also be displayed in the Head-up Display.

## Fatigue alert

### Principle

The system can detect decreasing alertness or fatigue of the driver during long, monotonous trips, for instance on highways. In this situation, it is recommended that the driver takes a break.

### Safety information

#### Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing one's physical state. An increasing lack of alertness or fatigue may not be de-



ected or not be detected in time. There is a risk of accident. Make sure that the driver is rested and alert. Adjust driving style to traffic conditions.

## Function

The system is switched on each time the engine is started and cannot be switched off. After start of the trip, the system monitors certain aspects of the driver's behavior, so that decreasing alertness or fatigue can be detected.

This procedure takes the following criteria into account:

- Personal driving style, for instance steering behavior.
- Driving conditions, for instance time, length of trip.

Starting at approximately 43 mph/70 km/h, the system is active and can display a break recommendation.

## Break recommendation

If the driver becomes less alert or fatigued, a message is displayed in the Control Display with the recommendation to take a break.

A break recommendation is displayed only once during an uninterrupted trip.

After a break, another break recommendation cannot be displayed until after approximately 45 minutes.

## System limits

The function may be limited in the following situations and may issue an incorrect warning or no warning at all:

- When the time is set incorrectly.
- When the vehicle speed is mainly below about 43 mph/70 km/h.

- With a sporty driving style, such as during rapid acceleration or when cornering fast.
- In active driving situations, such as when changing lanes frequently.
- When the road condition is poor.
- In the event of strong side winds.

The system is reset approx. 45 minutes after parking the vehicle, for instance in the case of a break during longer trips on highways.

## PostCrash – iBrake

### Principle

In the event of an accident, the system can bring the vehicle to a halt automatically without intervention by the driver in certain situations. This can reduce the risk of a further collision and the consequences thereof.

### At standstill

After coming to a halt, the brake is released automatically. Secure the vehicle against rolling away.

### Harder vehicle deceleration

In certain situations, it can be necessary to bring the vehicle to a halt more quickly than the Brake Assistant allows.

To do this, quickly apply extra force to the brake. For a brief period, the brake pressure will be higher than the brake pressure that is achieved by the automatic braking function. This interrupts automatic brake actuation.



## Canceling automatic braking

It can be necessary to interrupt automatic braking in certain situations, for instance for an evasive maneuver.

Canceling automatic braking:

- By pressing the brake pedal.
- By pressing the accelerator pedal.

# Driving stability control systems

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

### Anti-lock Braking System

The Antilock Braking System prevents locking of the wheels during braking.

The vehicle maintains its steerability even during emergency braking, which increases the active driving safety.

The Antilock Braking System is ready every time the drive readiness is turned on.

### Brake assistant

When you apply the brakes rapidly, this system automatically boosts the vehicle braking capability to the furthest possible extent. It reduces the braking distance to a minimum during emergency braking. This system utilizes all of the capabilities provided by the Antilock Brake System.

Do not reduce the pressure on the brake pedal for the duration of emergency braking.

## Dynamic Stability Control

### Principle

Within the physical limits, the system helps to keep the vehicle on a steady course by reducing engine power and by applying brake intervention to the individual wheels.

### General information

The Dynamic Stability Control will detect, e.g., the following unstable driving conditions:

- Skidding, which can lead to oversteering.
- Loss of adhesion of the front wheels, which can lead to understeering.

Dynamic Traction control, refer to page 187, is a version of the Dynamic Stability Control where drive power is optimized.

### Safety information

#### Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident. Adjust driving style to traffic conditions. Watch the surrounding traffic situation closely, be ready to take over steering and braking at any time, and actively intervene where appropriate.

**⚠ Warning**

When driving with a roof load, for instance with roof-mounted luggage rack, the vehicle's center of gravity is higher, which increases the risk of the vehicle tipping in critical driving situations. There may be a risk of accident or risk of damage to property. Driving with roof load only with activated Dynamic Stability Control.

**Indicator/warning lights**

Indicator light blinks: Dynamic Stability Control controls the drive and brake forces.

Indicator light illuminates: the Dynamic Stability Control has malfunctioned.

**Deactivate Dynamic Stability Control: DSC OFF****General information**

When Dynamic Stability Control is deactivated, driving stability is limited when accelerating and cornering.

To support driving stability, reactivate Dynamic Stability Control as soon as possible.

**Deactivating the system**

Press and hold this button but not longer than approx. 10 seconds, until the indicator light for DSC OFF lights up in the instrument cluster and displays DSC OFF.

Dynamic Stability Control is switched off.

**Activating the system**

Press the button. DSC OFF and the DSC OFF indicator light turn off.

**Indicator/warning lights**

If the Dynamic Stability Control is deactivated, DSC OFF is displayed in the instrument cluster.



Indicator light illuminates: Dynamic Stability Control is deactivated.

**Automatic activation**

If Dynamic Stability Control is deactivated, it is automatically activated in the following situations:

- The vehicle has a flat tire.
- When activating cruise control in the TRACTION or DSC OFF settings.

**Dynamic Traction Control****Principle**

The Dynamic Traction Control is a variant of the Driving Stability Control where the drive power is optimized.

The system ensures maximum drive power on unusual road conditions, for instance unplowed snow covered roads, or loose road surfaces, but with somewhat limited driving stability.

When the Dynamic Traction Control is activated, there is maximum traction. Driving stability is limited during acceleration and when cornering.

Drive carefully.

A brief activation of the Dynamic Traction Control may be useful in the following exceptional situations:

- When driving in slush or on uncleared, snow-covered roads.
- When driving off from deep snow or loose ground.
- When driving with tire chains.

## Activating/deactivating the Dynamic Traction Control

### Activating the system



Press the button.

TRACTION is displayed in the instrument cluster and the indicator light for DSC OFF lights up.

### Deactivating the system



Press the button again.

TRACTION and the DSC OFF indicator light turn off.

## Performance Control

Performance Control enhances the agility of the vehicle.

To increase maneuverability, wheels are braked individually when a sporty driving style is used.

## ALL4

ALL4 is the all-wheel-drive system of your vehicle. The ALL4 and Dynamic Stability Control work together to optimize the traction and driving dynamics. The ALL4 all-wheel-drive system variably distributes the driving forces to the front and rear axles as demanded by the driving situation and road condition.

## Adaptive suspension

### Principle

The setting of the chassis can be changed with the system.

The system offers several different programs.

The programs are selected via the MINI Driving Modes switch.

### Programs

#### MID/GREEN

Balanced setting of the shock absorbers for more comfort.

#### SPORT

Consistently sporty setting of the shock absorbers for greater driving agility.

## MINI Driving Modes switch

### Principle

The MINI Driving Modes switch helps to fine-tune the vehicle's settings and features. Choose between three different programs. Pressing the MINI Driving Modes switch will activate the particular program.

### Operating the programs

Switch	Program
	SPORT
	MID
	GREEN

### MID

MID provides a balanced setting.

With each starting procedure, MID is activated using the Start/Stop button.

## GREEN

### Principle

GREEN provides a consistent setting to maximize range.

### Activating GREEN

Press the MINI Driving Modes switch downward until GREEN is displayed in the instrument cluster.


### Configuring GREEN

#### Via MINI Driving Modes switch

1. Activate GREEN.
2. "Configure GREEN"
3. Configure the program.

This configuration is retrieved when GREEN is activated.

#### Via the Central Information Display (CID)

1.  "My MINI"
2. "Vehicle settings"
3. If necessary, "Driving mode"
4. "Configure GREEN"
5. Select the desired setting.

This configuration is retrieved when GREEN is activated.

## SPORT

### Principle

Consistently sporty setting of the drivetrain for greater driving agility.

Depending on the vehicle equipment, the setting of the chassis and suspension also changes and SPORT can be individually configured.


The configuration is stored for the driver profile currently in use.

### Activating SPORT

Press the MINI Driving Modes switch upward until SPORT is displayed in the instrument cluster.

### Configuring SPORT

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle settings"
3. If necessary, "Driving mode"
4. "Configure SPORT"
5. Select the desired setting.

This configuration is retrieved when SPORT is activated.


### Configuring driving program

Settings can be made for the following driving programs in Drive mode:


- GREEN, refer to page 189.
- SPORT, refer to page 189.

## Displays

### Program selection

 Pressing the MINI Driving Modes switch displays a list of programs, which can be selected.

### Selected program

 The instrument cluster displays the selected program.

## Drive-off assistant

---

### Principle

This system supports driving off on uphill grades. The parking brake is not required.

### Driving off with the drive-off assistant

1. Hold the vehicle in place with the foot brake.
2. Release the foot brake and drive off without delay.

After the foot brake is released, the vehicle is held in place for approx. 2 seconds.

## Servotronic

---

Servotronic is a speed-dependent power steering function.

The system provides the steering force with more support at low speeds than at higher ones. This makes it easier to park, for instance, and makes steering firmer when driving at faster speeds.

Furthermore, the steering force adapts according to the driving program, so that a firm, sporty feel or a comfortable steering response is conveyed.

# Driving comfort

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## Camera-based cruise control

### Principle

Using this system, a set speed and a distance to a vehicle ahead can be adjusted using the buttons on the steering wheel.

The system maintains the set speed on clear roads. The vehicle accelerates or brakes automatically.

If a vehicle is driving ahead of you, the system adjusts the speed of your vehicle so that the set distance to the vehicle ahead is maintained. The speed is adjusted as far as the given situation allows.

The distance can be adjusted at several levels. For safety reasons, it depends on the respective speed.

With the Stop&Go function for Steptronic transmissions: if the vehicle ahead of you brakes to a halt, and then proceeds to drive again shortly thereafter, the system is able to detect this within the given system limits.

## General information

A camera on the interior mirror is used to detect vehicles driving ahead.

Depending on the settings, the cruise control settings may change under certain conditions.

## Safety information

### Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident. Adjust driving style to traffic conditions. Watch the surrounding traffic situation closely, be ready to take over steering and braking at any time, and actively intervene where appropriate.

### Warning

The set speed can be incorrectly adjusted or called up by mistake. There is a risk of accident. Adjust the set speed to the traffic conditions. Watch surrounding traffic closely and actively intervene where appropriate.

### Warning

Risk of accident due to too high speed differences to other vehicles, for instance in the following situations:

- When fast approaching a slowly moving vehicle.
- Vehicle suddenly swerving into own lane.
- When fast approaching standing vehicles.

There is a risk of injury or danger to life. Watch surrounding traffic closely and actively intervene where appropriate.

**Warning**




An unsecured vehicle can begin to move and possibly roll away. There is a risk of accident. Before leaving the vehicle, secure the vehicle against rolling away.




In order to ensure that the vehicle is secured against rolling away, follow the following:

- Set the parking brake.
- On uphill grades or on a downhill slope, turn the front wheels in the direction of the curb.
- On uphill grades or on a downhill slope, also secure the vehicle, for instance with a wheel chock.

**Overview**


**Buttons on the steering wheel**

Button	Function
	Cruise control on/off, refer to page 193.
	Interrupt cruise control, refer to page 193. Continue cruise control with the last setting, refer to page 194.
	Reduce distance, refer to page 194.

Button	Function
	Increase the distance, refer to page 194.
	Increase speed, refer to page 193.
	Reduce speed, refer to page 193.

Buttons are arranged according to vehicle's series, optional features and country specifications.

**Camera**



The camera is installed near the interior mirror.

Keep the windshield in front of the interior mirror clean and clear.

**Functional requirements**

The system is best used on well-constructed roads.

The system is functional at speeds beginning at approx. 20 mph/30 km/h.

With the Stop&Go function for Steptronic transmissions: the system can also be activated while the vehicle is stationary.

The max. speed that can be set is 85 mph/140 km/h.

Manual transmission: Active Cruise Control is interrupted below a speed of approx. 20 mph/30 km/h. The system does not brake to a stop.



If distance control is switched off, refer to page 195, higher desired speeds can be selected as well.

## Turning on/off and interrupting cruise control

### Turning on



Press the button on the steering wheel.



Instrument cluster without enhanced features:

Display in the instrument cluster lights up.



Instrument cluster without enhanced features:

Display in the instrument cluster lights up. The current speed is adopted as desired speed and displayed with icon.



Instrument cluster with enhanced features:

Display in the instrument cluster lights up. The current speed is adopted as desired speed and displayed with icon.

Cruise control is active and maintains the set speed.

If necessary, the Dynamic Stability Control will be turned on.

### Turning off

With the Stop&Go function for Steptronic transmissions: when switching off while stationary, depress the brake pedal simultaneously.



Press the button on the steering wheel.

The displays turn off. The stored set speed is deleted.

### Interrupting manually



Press the button on the steering wheel.

With the Stop&Go function for Steptronic transmission: when interrupting while stationary, depress the brake pedal simultaneously.

### Interrupting automatically

The system is automatically interrupted in the following situations:

- When the driver applies the brakes.
- Manual transmission: when the clutch pedal is depressed for a few seconds or released while a gear is not engaged.
- If selector lever position N is set.
- When Dynamic Traction Control is activated or Dynamic Stability Control is deactivated.
- When the Dynamic Stability Control is adjusting.
- If the detection range of the camera is impaired, for instance by contamination, heavy precipitation or blinding glare from the sun.
- Manual transmission: if the vehicle in front decelerates below a speed of approx. 20 mph/30 km/h.
- With the Stop&Go function for Steptronic transmissions: following a stationary period of approx. 3 seconds, after the vehicle was braked to a stop by the system.

### Adjusting the speed

#### Maintaining/storing the speed


Press  or  button in the interrupted state.

When the system is switched on, the current speed is maintained and stored as the set speed.



Instrument cluster without enhanced features:

The stored speed is displayed by the icon in the Info Display of the instrument cluster.




Instrument cluster with enhanced features:





The stored speed is displayed.

If necessary, the Dynamic Stability Control will be turned on.

### Changing the speed

 or  button: press until the desired speed is set.

If active, the displayed speed is stored and the vehicle reaches the stored speed when the road is clear.

-  or  button: each time it is pressed to the point of resistance, the desired speed increases or decreases by approx. 1 mph/1 km/h.
-  or  button: each time it is pressed past the resistance point, the desired speed changes by a maximum of 5 mph/10 km/h.

 or  button: hold down to repeat the action.

### Adjusting the distance

#### Safety information

##### Warning

The system cannot serve as a substitute for the driver's personal judgment. Due to the system limits, deceleration can be late. There may be a risk of accident or risk of damage to property. Be aware to the surrounding traffic situation at all times. Adjust the distance to the traffic and weather

conditions and maintain the prescribed safety distance, possibly by braking.

### Reduce distance



Press the button repeatedly until the desired distance is set.



Instrument cluster without enhanced features:

The set distance is briefly displayed in the left part of the Info Display of the instrument cluster.

### Increase the distance



Press the button repeatedly until the desired distance is set.



Instrument cluster without enhanced features:

The set distance is briefly displayed in the left part of the Info Display of the instrument cluster.

### Continuing cruise control

#### General information


An interrupted cruise control can be continued by calling up the stored speed.

Make sure that the difference between current speed and stored speed is not too large before calling up the stored speed. Otherwise, unintentional deceleration or acceleration may occur.

In the following cases, the stored speed value is deleted and cannot be called up again:

- When the system is switched off.
- When the ignition is switched off.

## Calling up the stored speed and distance

 Press the button with the system interrupted. Cruise control is continued with the stored values. The instrument cluster briefly displays the selected distance.

## Switching distance control on/off

### Safety information

#### Warning

The system does not react to traffic driving ahead of you, but instead maintains the stored speed. There may be a risk of accident or risk of damage to property. Adjust the set speed to the traffic conditions and brake as needed.

### Switching distance control off

Distance control can be switched off and on when driving with cruise control activated.



Press and hold this button.

Or:



Press and hold this button.



The indicator light in the instrument cluster lights up.

To switch distance control back on, press one of the two buttons again briefly.

After changing over distance control, a Check Control message is displayed.

## Displays in the instrument cluster

### Set speed and stored speed



Instrument cluster without enhanced features:

In addition to the indicator light, the desired speed is displayed in the Info Display.

- Display lights up green: system is active, the display indicates the desired speed.
- Display lights up orange: system is interrupted, the display indicates the stored speed.
- No display: system is switched off.



Instrument cluster with enhanced features:

- Display lights up green: system is active, the display indicates the desired speed.
- Speed value is illuminated gray: system is interrupted.
- No display: system is switched off.

If no speed is indicated, it is possible that the conditions necessary for operation are not currently fulfilled.

### Distance to vehicle ahead of you

#### Distance display



Distance 1



Distance 2

### Distance display



Distance 3



Distance 4

This value is set automatically after the system is switched on.


Instrument clusters without enhanced features: selected distance from the vehicle driving ahead is briefly displayed in the left hand portion of the Info Display.

### Detected vehicle



Instrument cluster without enhanced features:

Icon lights up orange: a vehicle has been detected ahead of you.



Instrument cluster with enhanced features:

Vehicle symbol is displayed: a vehicle has been detected ahead of you.



With the Stop&Go function for Steptronic transmissions:

Rolling bars: the detected vehicle has driven away.

The system does not accelerate. To accelerate, activate the system as follows:

- By briefly pressing the accelerator pedal.
- By pressing the RES CNCL button.
- By pressing the  $\oplus$  or  $\ominus$  button.

### Indicator/warning lights



Instrument cluster without enhanced features:

Icon flashes orange.



Instrument cluster with enhanced features:

Vehicle symbol flashes.

The conditions are not adequate for the system to work.

The system was deactivated but applies the brakes until you actively resume control by pressing on the brake pedal or accelerator pedal.



Icon flashes red and a signal sounds: Brake and make an evasive maneuver, if necessary.



System interrupted without detected vehicle.




System interrupted with detected vehicle.

### Displays in the Head-up Display

The information from Active Cruise Control can also be displayed in the Head-up Display.

### System limits

#### Detection range



The detection capability of the system and the automatic braking performance are limited.


For instance, two-wheeled vehicles may not be detected.

## Deceleration

The system does not decelerate in the following situations:

- For pedestrians, cyclists or similarly slow-moving road users.
- For red traffic lights.
- For cross traffic.
- For oncoming traffic.
- Unlit vehicles or vehicles with faulty lighting at night.

## Merging vehicles



A vehicle driving in front of you is not detected until it is completely within the same lane as your vehicle.

If a vehicle driving ahead of you suddenly merges into your lane, the system may not be able to automatically restore the selected distance. It may not be possible to restore the selected distance in certain situations, including if you are driving significantly faster than vehicles driving ahead of you, for instance when rapidly approaching a truck. When a vehicle driving ahead of you is reliably detected, the system requests that the driver intervene by braking and carrying out evasive maneuvers, if needed.


## With Stop&Go function for Steptronic transmission: driving off

In some situations, the vehicle cannot drive off automatically; for example:

- On steep uphill grades.
- In front of bumps in the road.

In these cases, press on the accelerator pedal.

## Cornering



When the set speed is too high for a curve, the speed is reduced slightly. Because curves may not be anticipated in advance, drive into a curve at an appropriate speed.

The system has a limited detection range. Situations can arise in tight curves where a vehicle driving ahead will not be detected or will be detected very late.



When you approach a curve the system may briefly report vehicles in the next lane due to the bend of the curve. If the system decelerates you may compensate it by briefly accelerating. After releasing the accelerator pedal the system is reactivated and controls speed independently.



## Weather

The following restrictions can occur under unfavorable weather or light conditions:

- Poorer vehicle detection.
- Short-term interruptions for vehicles that are already recognized.

Examples of unfavorable weather or light conditions:

- Wet conditions.
- Snowfall.
- Slush.
- Fog.
- Glare.

Drive attentively, and react to the current surrounding traffic situation. If necessary, intervene actively, for instance by braking, steering or evading.

## Engine power

The desired speed may not be maintained on uphill grades if engine power is insufficient.

## Malfunction

A Check Control message is displayed if the system has malfunctioned or was automatically deactivated.

The system may be limited in the following situations:

- When an object was not correctly detected.
- In heavy fog, wet conditions, or snowfall.
- In tight curves.
- If the camera field of view or the windshield is dirty or covered.
- When driving toward bright lights.

- Up to 20 seconds after the start of the engine, via the Start/Stop button.
- During calibration of the camera immediately after vehicle delivery.

## Cruise control

### Principle

Using this system, a set speed can be adjusted using the buttons on the steering wheel. The system maintains the set speed. The system accelerates and brakes automatically as needed.

### General information

The system is functional at speeds beginning at approx. 20 mph/30 km/h.

Depending on the settings, the cruise control settings may change under certain conditions.

### Safety information

#### Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident. Adjust driving style to traffic conditions. Watch the surrounding traffic situation closely, be ready to take over steering and braking at any time, and actively intervene where appropriate.

#### Warning





The use of the system can lead to an increased risk of accidents in the following situations, for instance:

- On winding roads.
- With high traffic volume.
- On slippery roads, in fog, snow, or wet conditions, or on a loose road surface.

There may be a risk of accident or risk of damage to property. Only use the system if driving at constant speed is possible.

## Overview


### Buttons on the steering wheel

Button	Function
	Cruise control on/off, refer to page 199.
	Interrupt cruise control, refer to page 199. Continue cruise control with the last setting, refer to page 200.
	Increase speed, refer to page 200.
	Reduce speed, refer to page 200.

### Turning on/off and interrupting cruise control

#### Turning on

 Press the button on the steering wheel.

 Instrument cluster without enhanced features:  
The indicator light in the instrument cluster lights up.

 Instrument cluster without enhanced features:  
55

The current speed is adopted as the desired speed and is displayed with the symbol in the instrument cluster.



Instrument cluster with enhanced features:

Display in the instrument cluster lights up. The current speed is adopted as the speed

limit.

Cruise control is active and maintains the set speed.


If necessary, the Dynamic Stability Control will be turned on.

#### Turning off

 Press the button on the steering wheel.

The displays turn off. The stored set speed is deleted.

#### Interrupting manually

 When active, press the button on the steering wheel.

#### Interrupting automatically

The system is automatically interrupted in the following situations:

- When the driver applies the brakes.
- If the clutch pedal is depressed for a few seconds or released while a gear is not engaged.
- If the gear engaged is too high for the current speed.
- If selector lever position N is set.
- When Dynamic Traction Control is activated or Dynamic Stability Control is deactivated.
- When the Dynamic Stability Control is adjusting.

## Adjusting the speed

### Maintaining/storing the speed



Press  or  button in the interrupted state.

When the system is switched on, the current speed is maintained and stored as the set speed.







The stored speed is displayed in the instrument cluster.

If necessary, the Dynamic Stability Control will be turned on.

### Changing the speed

 or  button: press until the desired speed is set.

If active, the displayed speed is stored and the vehicle reaches the stored speed when the road is clear.

-  or  button: each time it is pressed to the point of resistance, the desired speed increases or decreases by approx. 1 mph/1 km/h.
-  or  button: each time it is pressed past the resistance point, the desired speed changes by a maximum of 5 mph/10 km/h.
-  or  button: press button to resistance point and hold. The vehicle accelerates or decelerates without pressure on the accelerator pedal. After the rocker switch is released, the vehicle maintains its final speed. Pressing the switch beyond the resistance point causes the vehicle to accelerate more rapidly.

## Continuing cruise control

### General information

An interrupted cruise control can be continued by calling up the stored speed.

Make sure that the difference between current speed and stored speed is not too large before calling up the stored speed. Otherwise, unintentional deceleration or acceleration may occur.

### Calling up the stored speed

 Press the button on the steering wheel.


The stored speed is reached again and maintained.

## Displays in the instrument cluster

### Indicator light

 Instrument cluster without enhanced features:

Depending on how the vehicle is equipped, the indicator light in the instrument cluster indicates whether the system is switched on.

 Instrument cluster with enhanced features:  
The indicator in the instrument cluster lights up: the system is switched on.

### Set speed and stored speed

 Instrument cluster without enhanced features:

- The desired speed is displayed together with the symbol.
- Display lights up green: system is active, the display indicates the desired speed.
  - Display lights up orange: system is interrupted, the display indicates the stored speed.
  - No display: system is switched off.





Instrument cluster with enhanced features:

The desired speed is displayed together with the symbol.

- Display lights up green: system is active, the display indicates the desired speed.
- Display lights up gray: system is interrupted, the display indicates the stored speed.
- No display: system is switched off.

Instrument cluster without enhanced features:

If no speed is indicated, it is possible that the conditions necessary for operation are not currently fulfilled.

## System limits

### Engine power

The set speed is also maintained downhill, but may not be maintained on uphill grades if engine power is insufficient.

## Park Distance Control

### Principle

Park Distance Control assists with parking. The system detects objects behind the vehicle. If equipped with Park Distance Control in the front, objects in front of the vehicle are also detected. Objects that you are approaching slowly are indicated by signal tones and a visual display.

### General information

The ultrasound sensors for measuring the distances are located in the bumpers.

The range, depending on obstacles and environmental conditions, is approx. 6 ft/2 m.

An acoustic warning is first given in the following situations:

- By the front middle sensors and the two corner sensors at approx. 24 in/60 cm from the object.
- By the rear middle sensors at approx. 5 ft/1.50 m from the object.
- When a collision is imminent.

## Safety information

### Warning


The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident. Adjust driving style to traffic conditions. Check surrounding traffic and vehicle's surroundings closely and actively intervene where appropriate.

### Warning

Due to high speeds when the Park Distance Control is activated, the warning can be delayed due to physical circumstances. There is a risk of injury or risk of damage to property. Avoid approaching an object too fast. Avoid driving off quickly while Park Distance Control is not yet active.


## Overview

### With front Park Distance Control: button in the vehicle



 Park assistance button

### Ultrasound sensors



Ultrasonic sensors of the Park Distance Control, in the bumpers, for example.

### Functional requirements

Ensure full operability:

- Do not cover sensors, for instance with stickers, bicycle racks or similar.
- Keep the sensors clean and free of ice.

### Turning on/off


#### Turning on automatically

The system switches on automatically in the following situations:

- If selector lever position R is engaged when the engine is running.  
The rearview camera also switches on.
- With front Park Distance Control: when obstacles are detected behind or in front of the vehicle by Park Distance Control

and the speed is slower than approx. 2.5 mph/4 km/h.

With front Park Distance Control: automatic activation when obstacles are detected can be switched off. Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle settings"
3. "Parking"
4. "Automatic PDC Activation": depending on the vehicle equipment.
5. "Automatic PDC Activation"

The setting is stored for the driver profile currently used.

### Automatic deactivation during forward travel

The system switches off when a certain driving distance or speed is exceeded. Switch the system back on, if needed.

### With front Park Distance Control: switch on/off manually

 Press the park assistance button.

- On: the LED lights up.
- Off: the LED goes out.

The rearview camera image is displayed if the reverse gear is engaged when pressing the park assistance button.

Depending on the equipment version, the system cannot be switched off manually if the reverse gear is engaged.

### Warning

#### Signal tones

An intermittent tone indicates when the vehicle is approaching an object. E.g., when an object is detected at the rear left of the ve-

hicle, a signal tone sounds from the rear left speaker.

The shorter the distance to the object, the shorter the intervals.


When the distance to a detected object is less than approx. 10 inches/25 cm, a continuous tone is sounded.

With front Park Distance Control: when objects are simultaneously located both in front of and behind the vehicle, an alternating continuous signal is sounded.

The signal tone is switched off, when selector lever position P is engaged on vehicles with Steptronic transmission.

## Volume

The ratio of the volume of the Park Distance Control signal tone to the entertainment volume can be adjusted.

1.  "My MINI"
2. "System settings"
3. "Tone"
4. "Volume settings"
5. "PDC"
6. Set the desired value.

The setting is stored for the driver profile currently used.

## Visual warning

The approach of the vehicle to an object can be shown on the Control Display. Objects that are farther away are already displayed on the Control Display before a signal sounds.

The display appears as soon as Park Distance Control is activated.

The detection range of the sensors is represented in colors: red, green and yellow.

When the image of the rearview camera is displayed, it is possible to switch to Park Distance Control:

 "Rear view camera"

## System limits

### Safety information

#### Warning

The system is designed to operate in certain conditions and circumstances. Due to conditions or other factors, the system may not respond. There may be a risk of accident or risk of damage to property. Actively intervene as warranted. Refer to the information in this Owner's Manual regarding the scope of the system's operation and limitations.

### Limits of ultrasonic measurement

The detection of objects with ultrasonic measurements can run into physical limits, for instance under the following conditions:

- For small children and animals.
- For persons with certain clothing, for instance jacket.
- With external fault of the ultrasound, for instance from passing vehicles or loud machines.
- When sensors are dirty, iced over, damaged or out of position.
- If cargo protrudes.
- Under certain weather conditions such as high moisture, wet conditions, snowfall, extreme heat, or strong wind.
- With tow bars and trailer couplings of other vehicles.
- With thin or wedge-shaped objects.
- With moving objects.
- With elevated, protruding objects such as ledges or cargo.
- With objects with corners and sharp edges.



- With objects with a fine surface structure such as fences.
- For objects with porous surfaces.
- Low objects already displayed, for instance curbs, can move into the blind area of the sensors before or after a continuous tone sounds.

## Unwarranted warnings

The system may issue a warning under the following conditions even though there is no obstacle within the detection range:

- In heavy rain.
- When sensors are very contaminated or covered with ice.
- When sensors are covered in snow.
- On rough road surfaces.
- On uneven surfaces, such as speed bumps.
- In large buildings with right angles and smooth walls, for instance in underground garages.
- In automatic car washes.
- Due to heavy exhaust.
- Due to other ultrasound sources, for instance sweeping machines, steam cleaners or neon lights.

The malfunction is signaled by a continuous tone alternating between the front and rear speakers. As soon as the malfunction due to other ultrasound sources is no longer present, the system is again fully functional.

With front Park Distance Control: to reduce unwarranted warnings, switch off automatic Park Distance Control activation on obstacle detection, for instance in car washes, see Switching on/off.

## Malfunction

A Check Control message is displayed in the instrument cluster.



Red icon is displayed, and the detection range of the sensors is dimmed on the Control Display.

Park Distance Control malfunction. Have the system checked by a dealer's service center or another qualified service center or repair shop.

## Rearview camera

### Principle

The rearview camera provides assistance in reverse parking and maneuvering. The area behind the vehicle is shown on the Control Display.


### Safety information


#### Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident. Adjust driving style to traffic conditions. Check surrounding traffic and vehicle's surroundings closely and actively intervene where appropriate.

## Overview

Depending on the vehicle equipment:  
button in the vehicle



 Park assistance button

## Camera



The camera lens is located in the handle of the tailgate.

The image quality may be impaired by dirt. If necessary, clean the camera lens.

## Turning on/off

### Turning on automatically

The system is switched on automatically if selector lever position R is engaged when the engine is running.

### Automatic deactivation during forward travel

The system switches off when a certain driving distance or speed is exceeded.

Switch the system back on, if needed.

### Depending on the vehicle equipment: switching on/off manually



Press the park assistance button.

- On: the LED lights up.
- Off: the LED goes out.

The parking assistance functions are shown on the Control Display.

### Switching the view via the Central Information Display (CID)

If the rearview camera view is not displayed, change the view via the Central Information Display (CID):

 "Rear view camera"

The rearview camera image is displayed.

## Display on the Control Display

### Functional requirements

- The rearview camera is switched on.
- The tailgate is fully closed.
- Keep the detection range of the camera open.

Protruding cargo or rear-mounted luggage racks and trailers that are not connected to a trailer power socket can lead to malfunctions.

### Activating assistance functions

More than one assistance function can be active at the same time.

- Parking aid lines

 "Parking aid lines"

Lanes and turning circle lines are indicated.


- Obstacle marking

 "Obstacle marking"

Obstacles are marked, depending on the vehicle equipment.

### Obstacle marking


### Pathway lines



Pathway lines can be superimposed on the image of the rearview camera.

Pathway lines help you to estimate the space required when parking and maneuvering on level roads.


Pathway lines depend on the current steering-wheel angle and are continuously adjusted to the steering wheel movements.



Depending on the vehicle equipment, obstacle markings can be faded into the image of the rearview camera.

The colored steps of the obstacle markings match the marks of the Park Distance Control.

### Turning circle lines




Turning circle lines can be superimposed on the image of the rearview camera.

Turning circle lines show the course of the smallest possible turning radius on a level road.


Only one turning circle line is displayed after the steering wheel is turned past a certain angle.

## Parking using lanes and turning circle lines

1. Position the vehicle so that the turning circle lines lead to within the limits of the parking space.




2. Turn the steering wheel to the point where the pathway line covers the corresponding turning circle line.



## Display settings


### Brightness

With the rearview camera switched on:

1.  Select the icon.
2. Turn the Controller until the desired setting is reached and press the Controller.

### Contrast

With the rearview camera switched on:

1.  Select the icon.
2. Turn the Controller until the desired setting is reached and press the Controller.

## System limits

### Detection of objects

Very low obstacles or high, protruding objects such as ledges may not be recognized by the system.


Depending on the equipment, some assistance functions also take into account data from the Park Distance Control.

Follow the notes in the Park Distance Control chapter.

The objects displayed on the Control Display may be closer than they appear. Therefore, do not estimate the distance from the objects on the display.

## Automatic Parking Assistant

### Principle



This system assists the driver in parking parallel to the road.

### General information

Automatic Parking Assistant handling is divided into three steps:

- Switching on and activating.
- Parking space search.
- Parking.

Ultrasound sensors measure parking spaces on both sides of the vehicle.

The Automatic Parking Assistant calculates the best possible parking line and takes control of steering during the parking operation.

System status and instructions on required actions are displayed on the Control Display.

A component of the Parking Assistant is Park Distance Control.

## Safety information

### Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident. Adjust driving style to traffic conditions. Check surrounding traffic and vehicle's surroundings closely and actively intervene where appropriate.

### NOTICE


The system can steer the vehicle over or onto curbs. There is a risk of damage to property, among other potential damage. Watch surrounding traffic closely and actively intervene where appropriate.

In addition, the safety instructions of the Park Distance Control apply.

## Overview

### Button in the vehicle



 Park assistance button

### Ultrasound sensors



The ultrasound sensors for measuring parking spaces are located on the wheel housing.

## Functional requirements

### Ultrasound sensors

Ensure full operability:

- Do not cover sensors, for instance with stickers.
- Keep the sensors clean and unobstructed.



## For the measurement of parking spaces

- Maximum speed while driving forward approx. 22 mph/35 km/h.
- Maximum distance to row of parked vehicles: 5 ft/1.5 m.

## Suitable parking space

- Gaps behind an object that has a min. length of 5 ft/1.5 m.
- Gap between two objects with a minimum length of approx. 5 ft/1.5 m.
- Minimum length of gap between two objects: own vehicle length plus approx. 3.3 ft/1.0 m.
- Minimum depth: approx. 5 ft/1.5 m.

## For the parking operation

- Doors and tailgate are closed.
- The parking brake is released.
- When parking in parking spaces on the driver's side, the corresponding turn signal must be switched on.


## Switching on and activating

### Switching on with the button



- Press the park assistance button. The LED lights up.


The current status of the parking space search is indicated on the Control Display.

-  Automatic Parking Assistant is activated automatically.

### Switching on with reverse gear



Shift into reverse.

The current status of the parking space search is indicated on the Control Display.


- To activate:  "Parking Assistant"

## Display on the Control Display


### System activated/deactivated

Icon	Meaning
	Gray: the system is not available. White: the system is available but not activated.
	The system is activated.

### Parking space search and system status





- Symbol P on the vehicle image: the Automatic Parking Assistant is activated and the parking space search is active.
- Control Display shows suitable parking spaces at the edge of the road next to the vehicle symbol. When the Automatic Parking Assistant is active, suitable parking spaces are highlighted.

-  The parking operation is active. The system takes over the steering.

- Parking space search is always active whenever the vehicle is moving forward slow and straight, even if the system is deactivated. When the system is deactivated, the displays on the Control Display are shown in gray.

## Parking using the Automatic Parking Assistant

### Parking

1.  Press the park assistance button or shift into reverse gear to switch on the Automatic Parking Assistant, refer to page 209. Activate the Automatic Parking Assistant, if needed.
  -  Automatic Parking Assistant is activated.
2. Pass the row of parked vehicles at a speed of up to approx. 22 mph/35 km/h and at a distance of maximum 5 ft/1.5 m.
 

The status of the parking space search and possible parking spaces are displayed on the Control Display, refer to page 209.
3. Follow the instructions on the Control Display.
 



The Automatic Parking Assistant takes control of steering during the parking operation. The driver takes over braking and accelerating.

The best possible parking position will come after gear change on the stationary vehicle - wait for the automatic steering operation.

The end of the parking operation is indicated on the Control Display.
4. Adjust the parking position yourself, if needed.

### Canceling manually

The Automatic Parking Assistant can be interrupted at any time:

-  Press the park assistance button.
-  "Parking Assistant"

### Canceling automatically

The system is interrupted automatically in the following situations:

- If the driver grasps the steering wheel or takes over steering.
- If a gear is selected that does not match the instruction on the Control Display.
- If the vehicle speed exceeds approx. 6 mph/10 km/h.
- Possibly on snow-covered or slippery road.
- If a maximum number of parking attempts or the time taken for parking is exceeded.
- If Park Distance Control displays clearances that are too small.
- When changing over to other functions of the radio.

A Check Control message is displayed.


### Resuming

An interrupted parking operation can be continued, if needed.

Reactivate the Automatic Parking Assistant, refer to page 209, and follow the instructions on the Control Display.

### Turning off

The system can be switched off as follows:

-  Press the park assistance button.
- Switching off the ignition.

## System limits

### Safety information

#### Warning

The system is designed to operate in certain conditions and circumstances. Due to conditions or other factors, the system may not respond. There may be a risk of accident or risk of damage to property. Actively intervene as warranted. Refer to the information in this Owner's Manual regarding the scope of the system's operation and limitations.

### No parking assistance

The Automatic Parking Assistant does not offer assistance in the following situations:

- In tight curves.

### Functional limitations

The system may be limited in the following situations:

- On bumpy road surfaces such as gravel roads.
- On slippery ground.
- With accumulations of leaves/snow in the parking space.
- With a mounted emergency wheel.
- With ditches or edges, for instance an edge of a port.

### Limits of ultrasonic measurement

The detection of objects with ultrasonic measurements can run into physical limits, for instance under the following conditions:

- For small children and animals.
- For persons with certain clothing, for instance jacket.

- With external fault of the ultrasound, for instance from passing vehicles or loud machines.
- When sensors are dirty, iced over, damaged or out of position.
- If cargo protrudes.
- Under certain weather conditions such as high moisture, wet conditions, snowfall, extreme heat, or strong wind.
- With tow bars and trailer couplings of other vehicles.
- With thin or wedge-shaped objects.
- With moving objects.
- With elevated, protruding objects such as ledges or cargo.
- With objects with corners and sharp edges.
- With objects with a fine surface structure such as fences.
- For objects with porous surfaces.
- Low objects already displayed, for instance curbs, can move into the blind area of the sensors before or after a continuous tone sounds.
- The parking assistant may identify parking spaces that are not suitable for parking.

### Tire size

The parking position may vary depending on the tire size.

### Malfunction

A Check Control message is displayed.

The Automatic Parking Assistant has malfunctioned. Have the system checked by a dealer's service center or another qualified service center or repair shop.



# Climate control

## Vehicle features and options

---

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

- Emission tested passenger compartment.
- Microfilter.
- Air conditioning system to control the temperature, air flow and recirculated-air mode.

Depending on the equipment specification:

- Microfilter/activated-charcoal filter.
- Automatic climate control.
- Pre-ventilation.

## Interior air quality

---

The air quality in the vehicle is improved by the following components:

## Air conditioning system



- |   |  |   |                                       |
|---|--|---|---------------------------------------|
| 1 | Air distribution settings              | 6 | Air recirculation mode                |
| 2 | Air flow                               | 7 | Rear window defroster                 |
| 3 | Temperature                            | 8 | Heated windshield                     |
| 4 | Seat heating, right <a href="#">89</a> | 9 | Seat heating, left <a href="#">89</a> |
| 5 | Air conditioning                       |   |                                       |

### Climate control functions in detail

#### Switching the system on/off

##### Turning on

Set any air flow.

##### Turning off



Turn the wheel for air flow all the way to the left.

#### Temperature

##### Principle

The system heats or cools, depending on the set temperature.

##### Adjusting



Turn the wheel to set the desired temperature.

## Air conditioning


### Principle

The air in the interior will be cooled and dehumidified and, depending on the temperature setting, warmed again.

### Functional requirement

The car's interior can only be cooled with the engine running.

### Turning on/off

 Press the button. The LED is illuminated with air conditioning switched on.

Depending on the weather, the windshield may fog up briefly when the engine is started.


The cooling mode produces condensation, refer to page 247, that will exit from below the vehicle.

## Air recirculation mode

### Principle

You may react to unpleasant odors or pollutants in the immediate environment by temporarily suspending the supply of outside air. The system then recirculates the interior air.

### Operation

 Press the button: The LED is illuminated when recirculated-air mode is switched on. The supply of outside air is shut off.

When recirculated-air mode is switched off, fresh air is directed into the vehicle's interior.

To prevent window condensation, recirculated-air mode switches off automatically af-

ter a certain amount of time, depending on the outside temperature.

With extended air recirculation mode, the air quality in the interior deteriorates and window fogging increases.

In case of window condensation, switch off air recirculation mode and increase the air flow, if needed.

## Air flow, manual

### Principle

The air flow for climate control can be adjusted manually.

### Adjusting



Turn the ring to set the desired air flow.

The higher the air flow, the more effective the heating or cooling power will be.

The air flow from the air conditioning system may be reduced to save vehicle battery power.

## Manual air distribution





### Principle

The air distribution for climate control can be adjusted manually.

### Adjusting



Turn the wheel to select the desired program or the desired intermediate setting.

-  Windows.
-  Upper body area.
-  Footwell.
-  Windows, upper body area and footwell.

## To defrost windows and remove condensation

Make the following settings to defrost the windows and remove condensation:

- Direct the air distribution onto the windows.
- Increasing the air flow.
- Increase the temperature.
- Switch on air conditioning if needed.

## Heated windshield



Press the button. The LED lights up.

The heated windshield switches off automatically after a certain period of time.

## Rear window defroster



Press the button. The LED lights up.

The rear window defroster switches off automatically after a certain period of time.

For permanent activation, press the button for longer than 3 seconds. To deactivate, press the button again.

The rear window defroster can only be activated continuously at an outside temperature below approx. 41 °F/5 °C.


When GREEN driving mode is activated, the heater output is reduced.

## Microfilter

In external and recirculated-air mode, the microfilter filters dust and pollen from the air.

Have this filter changed during vehicle maintenance, refer to page [290](#).

## Automatic climate control



- |   |  |
|---|--|
| <ul style="list-style-type: none"> <li>1 Temperature, left</li> <li>2 Display</li> <li>3 Air flow, AUTO intensity</li> <li>4 AUTO program</li> <li>5 Air distribution, manual</li> <li>6 Display</li> <li>7 Temperature, right</li> <li>8 Seat heating, right <a href="#">89</a></li> </ul> | <ul style="list-style-type: none"> <li>9 Maximum cooling</li> <li>10 Air conditioning</li> <li>11 Air recirculation mode</li> <li>12 Rear window defroster</li> <li>13 Heated windshield</li> <li>14 To defrost windows and remove condensation</li> <li>15 Seat heating, left <a href="#">89</a></li> </ul> |
|---|--|

## Climate control functions in detail

### Switching the system on/off

#### Turning on

Set any air flow.

#### Turning off



Turn wheel for air flow to the left until the control panel switches off.

## Temperature

### Principle

The automatic climate control achieves the set temperature as quickly as possible, if



necessary by using the maximum cooling or heater output, and then keeps it constant.

### Adjusting



Turn the wheel to set the desired temperature.

Do not rapidly change between different temperature settings. The automatic climate control will not have sufficient time to adjust the set temperature.

### Air conditioning

#### Principle

The air in the interior will be cooled and dehumidified and, depending on the temperature setting, warmed again.

#### Functional requirement

The car's interior can only be cooled with the engine running.

#### Turning on/off



Press the button.

The LED is illuminated with air conditioning switched on.

Depending on the weather, the windshield may fog up briefly when the engine is started.

Air conditioning is switched on automatically with the AUTO program.

The cooling mode produces condensation, refer to page 247, that will exit from below the vehicle.

### Maximum cooling

#### Principle

The system is set to the lowest temperature, maximum air flow and recirculated-air mode.

#### Functional requirement

The function is available at outside temperatures above approx. 32 °F/0 °C and with the engine running.

#### Turning on/off



Press the button.

The LED is illuminated with the system switched on.

Air flows out of the air vents to the upper body area. The air vents need to be open for this.

The air flow can be adjusted when maximum cooling is switched on.

### AUTO program

#### Principle

The AUTO program cools, ventilates or heats the car's interior automatically.

For this, the air flow, air distribution and temperature are regulated depending on the settings and the interior temperature.

#### Turning on/off



Press the button.

The LED is illuminated with the AUTO program switched on.

Depending on the selected temperature, AUTO intensity and outside influences, the air is directed to the windshield, side windows, upper body, and into the floor area.

Point the side air vents toward the side windows.

The following features are switched on automatically with the AUTO program:

- Air conditioning, refer to page 217.

To switch off the program: press the button again or manually adjust the air distribution.

### Adjusting the intensity of the air flow

With the AUTO program switched on, the intensity can be adjusted. This changes the automatic control for the air mass.



Turn the wheel to set the desired intensity from soft to intensive.

The set intensity is displayed via the position of the illuminated LED segment.

### Automatic recirculated-air control (AUC)/recirculated-air mode

#### Principle

The automatic recirculated-air control (AUC) recognizes pollutants in the outside air. The outside air supply is shut off and the interior air is recirculated.

#### General information

If the system is activated, a sensor detects pollutants in the outside air and controls the shut-off automatically.

If the system is deactivated, outside air continuously flows into the interior.

With constant air recirculation mode, the air quality in the interior deteriorates and window fogging increases.

You may react to unpleasant odors or pollutants in the immediate environment by temporarily suspending the supply of outside air. The system then recirculates the interior air.

### Turning on/off



Press button repeatedly to select an operating mode:

- LEDs off, outside air flows in continuously.
- Left LED on, automatic recirculated-air control: a sensor detects pollutants in the outside air and shuts off automatically.
- Right LED on, recirculated-air mode: the supply of outside air into the vehicle is permanently disabled.

To prevent window condensation, recirculated-air mode switches off automatically after a certain amount of time, depending on the outside temperature.

In case of window condensation, switch off the recirculating mode and press the AUTO button. Make sure that air can flow to the windshield.

### Air flow, manual

#### Principle

The air flow for climate control can be adjusted manually.

#### General information

To adjust the air flow manually switch off AUTO program first.

#### Adjusting



Turn the ring to set the desired air flow.

The manually adjusted air flow is displayed via illuminated LED segments.

The air flow of the automatic climate control may be reduced to save vehicle battery power.

## Manual air distribution

### Principle

The air distribution for climate control can be adjusted manually.

### Adjusting



Press the button repeatedly to select a program:

- Windows, upper body area, and footwell.
- Upper body area and footwell.
- Footwell.
- Windows and footwell.
- Windows.
- Windows and upper body area.
- Upper body area.

## To defrost windows and remove condensation

### Principle

Ice and condensation are quickly removed from the windshield and the front side windows.

### Turning on/off



Press the button.

The LED is illuminated with the system switched on.

The air flow can be adjusted with the program active.

If there is window condensation, switch on the air conditioning as well.

## Heated windshield



Press the button. The LED lights up.

The heated windshield switches off automatically after a certain period of time.

## Rear window defroster



Press the button. The LED lights up.

The rear window defroster switches off automatically after a certain period of time.

For permanent activation, press the button for longer than 3 seconds. To deactivate, press the button again.

The rear window defroster can only be activated continuously at an outside temperature below approx. 41 °F/5 °C.

When GREEN driving mode is activated, the heater output is reduced.

## Microfilter/activated-charcoal filter

In external and recirculated-air mode, the microfilter/activated-charcoal filter filters dust, pollen, and gaseous pollutants out of the air.

Have this filter changed during vehicle maintenance, refer to page [290](#).

## Ventilation


### Setting

The air flow directions can be individually adjusted:

- Direct ventilation:  
The air flow is directly pointed onto the person. The air flow heats or cools noticeably, depending on the adjusted temperature.
- Indirect ventilation:


If the air vents are fully or partly closed, the air is directly routed into the car's interior.

## Front ventilation



- Turn knob for continuous opening and closing of the air vents.
- Swivel the air vents to alter the airflow direction, arrows.

## Ventilation in the rear



- Lever for changing the airflow direction, arrow 1.
- Thumbwheel for variable opening and closing of the air vents, arrow 2.

## Pre-ventilation

### Principle

The pre-ventilation ventilates the interior and lowers its temperature, if needed.

### General information

The pre-ventilation can be switched on and off directly or by using two preset activa-

tion times. The system remains switched on for 30 minutes.

The pre-ventilation system is operated via the Central Information Display (CID).

### Functional requirements

- Direct operation: vehicle is in radio-ready state.
- Direct operation or preset activation time: does not depend on outside temperature.
- The vehicle battery is sufficiently charged.

If pre-ventilation is switched on, the vehicle battery will be discharged. Thus, limit the maximum activation time to save the vehicle battery. The system will be available again after the engine is started or after a short trip.

- Make sure that the vehicle's date and time are set correctly.
- Open the air vents of the ventilation to allow air to flow out.

### Switching on/off directly

Via the Central Information Display (CID):

1. "My MINI"
  2. "Vehicle settings"
  3. If necessary, "Climate functions"
  4. "Activate comfort ventilation now"
- The icon on the automatic climate control flashes if the system is switched on.

### Preselecting the activation time


Via the Central Information Display (CID):

1. "My MINI"
2. "Vehicle settings"
3. If necessary, "Climate functions"
4. "Comfort ventilation"


5. Select the desired activation time.
6. Set the desired time.


### Activating the activation time

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle settings"
3. If necessary, "Climate functions"
4. "For start time at:"

Activate the desired activation time.

 The icon on the automatic climate control lights up when the activation time is activated.

 The icon on the automatic climate control flashes when the system has been switched on.

The system will only be switched on within the next 24 hours. After that, it needs to be reactivated.

# Interior equipment

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## Integrated Universal Remote Control

### Principle

The integrated Universal Remote Control in the interior mirror can operate up to 3 functions of remote-controlled systems such as garage door drives, barriers, or lighting systems.

### General information

The Integrated Universal Remote Control replaces up to 3 different hand-held transmitters. To operate the remote control, the buttons on the interior mirror must be programmed with the desired functions. The hand-held transmitter for the particular system is required in order to program the remote control.

Before selling the vehicle, delete the stored functions for the sake of security.

If possible, do not install the antenna of the remote-controlled system, e.g. the garage door drive, near metal objects to ensure the best possible operation.

## Safety information

### Warning

The operation of remote-controlled systems with the integrated universal remote control, such as the garage door, may result in injury, for example, body parts becoming jammed in a garage door. There is a risk of injury or risk of damage to property. Make sure that the travel path of the respective system is clear during programming and operation. Also follow the safety information for the hand-held transmitter.

## Compatibility




If this symbol is printed on the packaging or in the operating instructions of the system to be controlled, the system is generally compatible with the integrated Universal Remote Control.

Additional questions are answered by:

- A dealer's service center or another qualified service center or repair shop.
- [www.homelink.com](http://www.homelink.com) on the Internet.

HomeLink is a registered trademark of Gen-tex Corporation.

## Overview



- 1 LED
- 2 Programmable keys
- 3 Hand-held transmitters of the system

## Programming

### General information

The battery of the hand-held transmitter must be fully charged at the time of programming to ensure an optimal range of the integrated universal remote control.

1. Turn on the ignition.
2. Initial commissioning:  
Press and hold the two outer buttons on the interior mirror simultaneously for approximately 10 seconds until the LED flashes green rapidly. This erases all programming of the buttons on the interior mirror.
3. Press the interior mirror button to be programmed. The LED on the interior mirror will slowly begin flashing orange.
4. Hold the hand-held transmitter for the system to be used approx. 1 to 12 in/2.5 to 30 cm away from the buttons on the interior mirror. The required distance depends on the hand-held transmitter.
5. Press and hold the button of the desired function on the hand-held transmitter.  
Canada: if programming with the hand-held transmitter was interrupted, hold

down the interior mirror button and repeatedly press and release the hand-held transmitter button for 2 seconds.

6.
  - The LED lights up green: programming completed.  
Release the button.
  - The LED flashes fast: programming is not complete.  
Press the button on the interior mirror for 2 seconds and release. Perform this procedure three times to complete the programming procedure.  
If the integrated universal remote control remains nonoperational, continue with the special features for change code wireless systems.
  - LED does not flash green after 60 seconds: programming not completed.  
Repeat steps 3 to 6.

To program other functions on other buttons, repeat steps 3 to 5.

### Special feature of the rolling code wireless system

If you are unable to operate the system after repeated programming, please check if the system to be controlled features a rolling code radio system.

Refer to the operating instructions for the system.

For systems with a rolling code radio system, the integrated Universal Remote Control and the system also have to be synchronized.

Please read the operating instructions to find out how to synchronize the system.

Synchronizing is easier with the aid of a second person.



Synchronizing the universal remote control with the system:

1. Park the vehicle within range of the remote-controlled system.
2. Program the relevant button on the interior mirror as described.
3. Locate and press the synchronizing button on the system being programmed, e.g. at the garage gate. You have approx. 30 seconds for the next step.
4. Hold down the programmed button on the interior mirror for approximately 3 seconds and then release it. If necessary, repeat this step up to three times in order to end synchronization. Once synchronization is complete, the programmed function will be carried out.

## Reprogramming individual buttons

1. Turn on the ignition.
2. Press and hold the interior mirror button to be programmed.
3. As soon as the LED on the interior mirror flashes orange after approx. 20 seconds, release the button.
4. Hold the hand-held transmitter for the system to be used approx. 1 to 12 in/2.5 to 30 cm away from the buttons on the interior mirror. The required distance depends on the hand-held transmitter.
5. Press and hold the button of the desired function on the hand-held transmitter.  
Canada: if programming with the hand-held transmitter was interrupted, hold down the interior mirror button and repeatedly press and release the hand-held transmitter button for 2 seconds.
6. The LED can light up in different ways.
  - The LED lights up green: the programming procedure is completed.

Release the button.

- The LED flashes fast: the hand-held transmitter was detected but programming is not complete.

Press the button on the interior mirror for 2 seconds and release. Perform this procedure three times to complete the programming procedure.

If the integrated universal remote control remains nonoperational, continue with the special features for change code wireless systems.

- LED does not flash green after 60 seconds: programming not completed.

Repeat steps 3 to 6.

If the programming procedure is not completed, the previous programming will remain unchanged.

## Operation

### Warning

The operation of remote-controlled systems with the integrated universal remote control, such as the garage door, may result in injury, for example, body parts becoming jammed in a garage door. There is a risk of injury or risk of damage to property. Make sure that the travel path of the respective system is clear during programming and operation. Also follow the safety information for the hand-held transmitter.

The system, such as the garage door, can be operated using the button on the interior mirror while the engine is running or when the ignition is started. To do this, hold down the button within receiving range of the system until the function is activated. The interior mirror LED stays lit while the wireless signal is being transmitted.



## Deleting stored functions

All stored functions will be deleted. The functions cannot be deleted individually.

Press and hold the two outer buttons on the interior mirror simultaneously for approximately 10 seconds until the LED on the interior mirror flashes green fast.

## Digital compass

### Overview



- 1 Adjustment knob
- 2 Mirror display

## Mirror display

The compass shows the current driving direction.

## Operating concept


Various functions can be called up by pressing the adjustment knob with a pointed object, such as the tip of a ballpoint pen or similar object. The following adjustment ranges are displayed in succession, depending on how long the adjustment knob is pressed:

- Pressed briefly: turns display on/off.
- 3 to 6 seconds: compass zone setting.
- 6 to 9 seconds: compass calibration.
- 9 to 12 seconds: left/right-hand drive setting.
- 12 to 15 seconds: language setting.

## Setting the compass zones

Sets the particular compass zones on the vehicle so that the compass operates correctly; refer to World map with compass zones.

## World map with magnetic zones



### Procedure

1. Press and hold the adjustment knob for approx. 3 to 4 seconds. The number of the set compass zone appears in the mirror.
2. To change the zone setting, press the adjustment knob quickly and repeatedly until the number of the compass zone that corresponds with your location appears in the mirror.

The set zone is stored automatically. The compass is ready for use again after approximately 10 seconds.

### Calibrating the digital compass

The digital compass must be calibrated in the event of the following:

- The wrong compass point is displayed.
- The point of the compass displayed does not change despite changing the driving direction.
- Not all points of the compass are displayed.

### Procedure

1. Make sure that there are no large metallic objects or overhead power lines near the vehicle and that there is sufficient room to drive around in a circle.
2. Set the currently valid compass zone.
3. Press and hold the adjustment knob for approx. 6 to 7 seconds so that "C" appears on the display. Next, drive in a complete circle at least once at a speed of no more than 4 mph/7 km/h. If calibration is successful, the "C" is replaced by the points of the compass.

## Left/right-hand drive vehicle

The digital compass is already set for right or left-hand drive vehicle at the factory.

## Adjusting the language

Press and hold the adjustment knob for approx. 12 to 13 seconds. Briefly press the adjustment knob again to switch between English "E" and German "O".

Settings are stored automatically after approximately 10 seconds.

## Sun visor

### Glare shield

To provide protection against glare, fold the sun visor down or pivot it to the side.

### Vanity mirror

A vanity mirror is located in the sun visor behind a cover.

When the cover is opened, the mirror lighting switches on.

## Ashtray/cigarette lighter

### Overview



The ashtray is located in one of the frontal cup holders, the cigarette lighter above it in the center console.

## Ashtray

In order to empty the ashtray, remove the ashtray from the cup holder.

## Cigarette lighter

### Safety information

#### Warning

Contact with the hot heating element or the hot socket of the cigarette lighter can cause burns. Flammable materials can ignite if the cigarette lighter falls down or is held against the objects. There is a risk of fire and an injury hazard. There is a risk of damage to property, among other potential damage. Take hold of the cigarette lighter by its handle. Make sure that children do not use the cigarette lighter.

#### NOTICE

If metal objects fall into the socket, they can cause a short circuit. There is a risk of damage to property, among other potential damage. Insert the cigarette lighter or socket cover again after using the socket.

### Operation



Push in the cigarette lighter. The cigarette lighter can be removed as soon as it pops back out.

## Sockets

### Principle

The socket can be used for electronic devices while the ignition is switched on or the engine is running.

## General information

The total load of all sockets must not exceed 140 watts at 12 volts.

Do not damage the socket by using unsuitable connectors.

## Safety information

### **Warning**

Devices and cables in the unfolding area of the airbags, such as portable navigation devices, can hinder the unfolding of the airbag or be thrown around in the car's interior during unfolding. There is a risk of injury. Make sure that devices and cables are not in the airbag's area of unfolding.

### **NOTICE**

Battery chargers that charge the vehicle battery via sockets or cigarette lighters in the vehicle may overload or damage the 12 V electrical system. There is a risk of damage to property, among other potential damage. Only connect battery chargers for the vehicle battery to the jump-start terminals in the engine compartment.

### **NOTICE**

If metal objects fall into the socket, they can cause a short circuit. There is a risk of damage to property, among other potential damage. Insert the cigarette lighter or socket cover again after using the socket.

## In the center console



Remove the cover or cigarette lighter.

## In the cargo area




The socket is located on the right side in the cargo area.

## USB port

### General information

Follow the information regarding the connection of mobile devices to the USB port in the section on USB connections, refer to page 54.

## In the front center console



The USB port is located in the front of the center console.

Properties:

- USB port Type A.
- For charging mobile devices and for data transfer.
- Charge current: max. 1.5 A.

## In the rear center console



One USB dual charge socket is located in the rear center console.

Properties:

- USB port Type C.
- For charging of mobile devices.
- Charge current: max. 3 A.

## Under the center armrest



The USB port is located under the center armrest.

Properties:

- USB port Type C.
- For charging of mobile devices.
- Charge current: max. 3 A.

## Wireless charging tray

### Principle

The wireless charging tray enables the following functions to be performed without cables:

- Charging the rechargeable battery of a mobile phone with Qi capability and of other mobile devices, which support the Qi standard.
- Connect the mobile phone to the external antenna.

Depending on the country, this provides for better network reception and a consistent reproduction quality.

### General information

When inserting the mobile phone, make sure there are no objects between it and the wireless charging tray.


During charging, the surface of the tray and the mobile phone may heat up. Higher temperatures may lead to a reduction in the

charge current through the mobile phone, and in isolated cases the charging process is paused temporarily. Follow the relevant instructions in the mobile phone owner's manual.

**NOTE**

This device has been tested for human exposure limits and found compliant at a minimum distance of 4 in/10 cm during operation.

Therefore, a distance of 4 in/10 cm must be maintained in every direction when operating the device.



Mounting position of the product.

**Safety information**

**Warning**

When charging a device that meets the Qi standard in the wireless charging tray, any metal objects located between the device and the tray can become very hot. Placing storage devices or electronic cards, such as chip cards, cards with magnetic strips or cards for signal transmission, between the device and the tray may impair the card function. There is a risk of injury and risk of damage to property. When charging mobile devices, make sure there are no objects between the device and the tray.

**NOTICE**


The tray is intended for mobile phones up to a particular size. Forceful inserting of the mobile phone into the tray can damage the tray or the mobile phone. There is a risk of damage to property, among other potential damage. Observe the maximum dimensions for mobile phones. Do not force the mobile phone into the tray.

**Functional requirements**

- Ignition or standby state is switched on.
- The mobile phone must compatibly support the required Qi standard. Compatible mobile phones, refer to page 52.  
If the mobile phone does not support the Qi standard, the mobile phone can be charged using a special Qi-compatible charging case.
- Use only protective sleeves and covers up to a maximum thickness of 0.07 in/2 mm. Otherwise, the charging function may be impaired.
- The mobile phone must not exceed the maximum size of approximately 5.9 x 3.07 x 0.62 in/150 x 78 x 16 mm.

**Overview**


The wireless charging tray is located in the center armrest.



- 1 Front holder with LED
- 2 Storage area
- 3 Movable retaining clip

### Inserting the mobile phone

1. Open the center armrest.
2. Push back the retaining clip.
3. Insert the mobile phone with the display facing upward in the direction of the front holder, arrow 1.



4. Place the mobile phone in the storage area, arrow 2.
5. Push the retaining clip forward and clip the mobile phone in the tray.
6. Close the center armrest.

### Removing the mobile phone

1. Open the center armrest.
2. Push the retaining clip back and remove the mobile phone.

### LED displays

Color	Meaning
Blue	The mobile phone is charging. Depending on the model, the blue LED is no longer illuminated once the inserted mobile phone with Qi capability is fully charged.
Orange	The mobile phone is not charging. Temperature on the mobile phone possibly too high or foreign object in the charging tray.
Red	The mobile phone is not charging. Contact a dealer's service center or another qualified service center or repair shop.

### System limits

At high temperatures on the mobile phone or in the vehicle, the charging functions of the mobile phone may be limited and some functions may no longer work.

### LTE-Compensator - Information and User Manual

Your car is equipped with a wireless charging tray (WCA) to charge your mobile phone and connect it to the mobile network. To ensure the best possible connection a signal booster (LTE-Compensator) is used in conjunction with the WCA. The following paragraphs refer to this booster:

This is a CONSUMER device.

BEFORE USE, you MUST REGISTER THIS DEVICE with your wireless provider and have your provider's consent. Most wireless providers consent to the use of Compensators. Some providers may not consent to the use of this device on their network. If you



are unsure, contact your provider. You **MUST** operate this device with approved antennas and cables as specified by the manufacturer. Antennas **MUST** be installed at least 20 cm (8 inches) from any person. You **MUST** cease operating this device immediately if requested by the FCC or a licensed wireless service provider. Warning E911 location information may not be provided or may be inaccurate for calls served by using this device.

Please observe additionally the following information

- Sprint Nextel will allow consumers to register their signal boosters by calling their toll-free number.
- T-Mobile online registration link: ([www.T-Mobile.com/BoosterRegistration](http://www.T-Mobile.com/BoosterRegistration)); (<https://saqat.t-mobile.com/sites/SignalBooster#>).
- Verizon's online registration link: (<http://www.verizonwireless.com/wcms/consumer/register-signal-booster.html>).
- AT&T online registration link (<https://securec45.securewebsession.com/attsignalbooster.com/>).
- U.S.Cellular online registration link (<http://www.uscellular.com/uscellular/support/fcc-booster-registration.jsp>).

Before use you must register your booster device with your wireless provider.

If you should be requested by the FCC to cease operating your booster, you are not allowed to insert your mobile phone in the charging tray anymore unless the booster is permanently deactivated by your local MINI dealer.

You must not remove the booster from the car nor use it with any other than the pre-installed coupling device or antenna. Any modification of the existing antenna or coupling device as well as the use of other an-

tennas or coupling devices will cause the cease of the booster's operating license.

The booster device fulfills the network protection standards as required by the FCC, such as intermodulation limits, oscillation detection and gain limits.

Booster Manufacturer: Kathrein Automotive

Model Number: LTECOMPB0

Part Number: 6803145-01

FCC-ID: 2ACC7LTECOMPB0



# Storage compartments

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## Safety information

### Warning

Devices connected to the vehicle via a cable, such as mobile phones or loose objects, can be thrown through the vehicle interior while driving such as in the event of an accident, braking or evasive maneuver. There is a risk of injury. Secure loose objects or devices that are connected to the vehicle via a cable.

### NOTICE

Anti-slip pads such as anti-slip mats can damage the dashboard. There is a risk of damage to property, among other potential damage. Do not use anti-slip pads.

- Glove compartment on the front passenger side.
- Compartments in the doors.
- Storage compartment in the center armrest.
- Storage compartment in front of the cup holders.
- Coat hooks
- Storage compartments in the cargo area.
- Storage tray in the center console.
- Pockets on the backrests of the front seats.

## Glove compartment

### Safety information

#### Warning

Folded open, the glove compartment protrudes in the car's interior. Objects in the glove compartment can be thrown into the car's interior while driving, for instance in the event of an accident, braking or evasive maneuvers. There is a risk of injury. Always close the glove compartment immediately after using it.

## Overview

The following storage compartments are available in the interior:

## Opening



Pull the handle.

The light in the glove compartment switches on.

## Closing

Fold up the lid.

## Compartments in the doors

### General information

There are storage compartments in the doors.

### Safety information

#### Warning

Breakable objects, such as glass bottles or glasses, can break in the event of an accident or a braking or evasive maneuver. Broken glass can be scattered in the car's interior. There is a risk of injury or risk of damage to property. Do not use any breakable objects while driving. Only stow breakable objects in closed storage compartments.

## Center armrest

### General information

The center armrest contains a storage compartment.

### Opening



Press button, arrow 1, and open center armrest upward, arrow 2.

### Set the incline

The center armrest can be adjusted at several inclination levels.

## Cup holders

### Safety information

#### Warning

Unsuitable containers in the cup holders may damage the cup holders or be thrown about the car's interior in the event of an accident, an evasive maneuver, or forceful braking. Spilled liquids can distract from the surrounding traffic conditions and lead to an accident. Hot drinks can damage the cup holder or lead to scalding. There is a risk of injury or risk of damage to property. Do not force objects into the cup holder. Use lightweight, shatterproof, and

sealable containers. Do not transport hot beverages.

## Front




In the center console.

## Back

### General information

The cup holder is located in the center armrest.



Pull the center armrest forward at the loop.

To open: press the button.

To close: push both covers back in, one after the other.

## Safety information

### NOTICE

With an open cup holder, the center armrest cannot be folded back up. There is a risk of damage to property, among other potential damage. Press back the covers before the center armrest is folded up.

## Coat hooks

### General information

The coat hooks are located above the rear doors.

### Safety information

#### Warning

Clothing articles on the coat hooks can obstruct the view while driving. There is a risk of accident. When suspending clothing articles from the coat hooks, ensure that they will not obstruct the driver's view.

#### Warning

Improper use of the coat hooks can lead to a risk of objects flying about during braking and evasive maneuvers. There is a risk of injury and risk of damage to property. Only hang lightweight objects, for instance clothing articles, from the coat hooks.

# Cargo area

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## Loading

### Safety information

 **Warning**

High gross vehicle weight can overheat the tires, damage them internally and cause a sudden tire pressure loss. Driving characteristics may be negatively impacted, reducing directional stability, lengthening the braking distances and changing the steering response. There is a risk of accident. Pay attention to the permitted load-carrying capacity of the tires and never exceed the permitted gross vehicle weight.

 **Warning**

Devices connected to the vehicle via a cable, such as mobile phones or loose objects, can be thrown through the vehicle interior while driving such as in the event of an accident, braking or evasive maneuver. There is a risk of injury. Secure loose

objects or devices that are connected to the vehicle via a cable.

 **Warning**

Improperly stowed objects can slip and be thrown into the car's interior, for instance in the event of an accident or during braking and evasive maneuver. Vehicle occupants can be hit and injured. There is a risk of injury. Stow and secure objects and cargo properly.

 **NOTICE**

Fluids in the cargo area can cause damage. There is a risk of damage to property, among other potential damage. Make sure that no fluids leak in the cargo area.

## Steps for Determining Correct Load Limit

1. Locate the statement “The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs” on your vehicle’s placard.
2. Determine the combined weight of the driver and passengers that will be riding in your vehicle.
3. Subtract the combined weight of the driver and passengers from XXX kg or XXX lbs
4. The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the “XXX” amount equals 1,400 lbs and there will be five 150 lbs passengers in your vehicle, the amount of available cargo and

- luggage load capacity is 650 lbs (1,400 - 750 (5 x 150) = 650 lbs)
- Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in Step 4.
  - If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle.
- Fold down the rear seat backrests completely to stow large cargo.
  - Do not stack cargo above the upper edge of the backrests.


## Lashing eyes in the cargo area



With storage compartment package: to secure the cargo there are four lashing eyes in the cargo area.

Attach auxiliary materials to secure the cargo, such as lashing straps, tensioning straps, draw straps or cargo nets, to the lashing eyes in the cargo area.

## Payload



The maximum payload is the sum of the weight of the occupants and the cargo.

The greater the weight of the occupants, the less cargo that can be transported.

## Stowing and securing cargo

- Cover sharp edges and corners on the cargo.
- Heavy cargo: stow as far forward as possible, directly behind and at the bottom of the rear seat backrests.
- Very heavy cargo: when the rear seat is not occupied, secure each of the outer seat belts in the opposite buckle.

## Cargo cover

### General information

When the tailgate is opened, the cargo cover is raised.

### Safety information

#### Warning


Devices connected to the vehicle via a cable, such as mobile phones or loose objects, can be thrown through the vehicle interior while driving such as in the event of an accident, braking or evasive maneuver. There is a risk of injury. Secure loose

objects or devices that are connected to the vehicle via a cable.

## Removing

For storing bulky objects the cargo cover can be removed.

1. Detach the left and right retaining straps at the tailgate.
2. Pull the cargo cover out of the brackets on the left and right.



## Installing

1. Slide the cargo cover forward horizontally into the two side brackets until it audibly engages.
2. Hook the left and right retaining straps at the tailgate.

## Storage compartments in the cargo area

### Storage compartment on the side

A storage compartment is located on the left side.

## Multifunction hook

### Warning

Improper use of the multifunction hooks can lead, e.g., to a risk of objects flying about during braking and evasive maneuvers. There is a risk of injury and risk of damage to property. Only hang lightweight objects from the multifunction hooks. Only transport heavy luggage in the cargo area if it has been appropriately secured.



There are two multifunction hooks in the cargo area.

## Enlarging the cargo area

### Principle

Depending on the equipment version, the cargo area can be enlarged as follows:

- The rear seat backrests can be folded down.
- The rear seat backrests can be moved into an upright loading position using the cargo setting.

### General information

The rear seat backrest is divided at a ratio of 40–20–40. The side rear seat backrests and the center section can be folded down separately.

The rear seat backrests can be folded down with the respective loops from the rear.

## Safety information

### Warning

There is a danger of jamming with folding down the rear seat backrests. There is a risk of injury or risk of damage to property. Make sure that the area of movement of the rear seat backrest and the of the head restraint is clear prior to folding down.

### Warning

If a rear seat backrest is not locked, unsecured cargo can be thrown about the car's interior; for instance, in the event of an accident, braking or an evasive maneuver. There is a risk of injury. Make sure that the rear seat backrest is locked after folding it back.

### Warning

Unexpected movements of the rear seat backrest while driving may occur due to unintentional unlocking of the rear seat backrests by the loops. There is a risk of injury. Only use loops for releasing the rear seat backrests. Do not attach objects on the loops.

### Warning


The stability of the child restraint system is limited or compromised with incorrect seat setting or improper installation of the child seat. There is a risk of injury or danger to life. Make sure that the child restraint system fits securely against the backrest. If possible, adjust the backrest

tilt for all affected backrests and correctly adjust the seats. Make sure that seats and backrests are securely engaged or locked. If necessary, adjust the height of the head restraints or remove them.

### Warning

Body parts can be jammed when moving the head restraint. There is a risk of injury. Make sure that the area of movement is clear when moving the head restraint.

## Folding down the rear seat backrest from the rear



Pull the loop. The rear seat backrest folds forward.


## Cargo position

### Principle

The rear seat backrests can be moved into an upright loading position individually. An adjustment in several tilt stages is possible as needed.

## Adjusting

1. Pull the loop.




2. Set the loading position of the rear seat backrest as required.
3. Engage the rear seat backrest.

## Folding back the backrest

Without a cargo position:


1. Pull the loop.



2. Return the rear seat backrest to the upright seat position and engage it.

With a cargo position:

1. Pull the loop.



2. Fold the rear seat backrest rearward. The rear seat backrest first engages in the loading position.
3. Pull the loop again.
4. Return the rear seat backrest to the upright seat position and engage it.

## Variable cargo area floor

### Principle

With the variable cargo area floor, the cargo area can be configured corresponding to transport requirements.

### General information

Follow instructions on securing cargo, refer to page [236](#).



## Removing the cargo floor panel


1. Fold down the rear seat backrest, refer to page 238.
2. Fold the rear part of the cargo floor panel upward.



3. Grasp the cargo floor panel in the rear and fold up above the locking point of the upper position, refer to page 241.
4. Pull the cargo floor panel backward from the brackets.

## Inserting the cargo floor panel

1. Push the cargo area floor into the supports at a shallow angle. The cargo area floor must engage noticeably.



2. Fold the cargo area floor over downward.

## Folded up position

### Safety information

#### Warning

Improper use of the cargo area floor can lead to a risk of objects flying about during braking and evasive maneuvers, for example. There is a risk of injury and risk of damage to property.

- Do not use the cargo area floor to separate the cargo area and vehicle interior in the sense of a luggage net.
- Only use the cargo area floor in the folded-up position when the rear seat backrests are folded up and locked.
- Fold down the cargo area floor before driving off.
- Always secure cargo against slipping, using straps, belts and lashing eyes, for instance.

## Fold up the cargo floor panel

Fold the rear part of the cargo floor panel upward.



Fold up the cargo area floor. You've reached the maximum cargo height.

## MINI Picnic Bench

### Principle

The MINI Picnic Bench provides a comfortable seating surface on the loading lip of the vehicle.

### General information

Only use the MINI Picnic Bench while the vehicle is parked and with the tailgate open. When the MINI Picnic Bench is not in use, fold it in to prevent contamination and damage.

In vehicles with a no-touch opening and closing tailgate:

If the vehicle key is in the sensor area, the tailgate may open or close inadvertently if you unintentionally move your foot or if a foot movement is detected.

The sensor has an approximate range of 5 ft/1.50 m extending from the rear area.

### Safety information

#### Warning


Body parts can be jammed when operating the tailgate. There is a risk of injury. Make sure that the travel path of the tailgate is clear during opening and closing.

### Overview


The MINI Picnic Bench is located on the underside of the cargo area floor.

### Mounting

1. Fold the rear part of the cargo floor panel upward.



2. Place the MINI Picnic Bench on the front part of the cargo floor panel and attach it to the rear part of the cargo floor panel using the four snaps.



3. Fold down the MINI Picnic Bench toward the rear. The MINI Picnic Bench is fastened with magnets.




4. Fold the rear part of the cargo area floor downward.

To disassemble the MINI Picnic Bench, proceed in reverse order.

## Folding down

1. Lift the rear part of the cargo area floor.



2. Grasp the MINI Picnic Bench in the middle and pull it back and up against the resistance of the magnets.



3. Fold the rear part of the cargo area floor downward and place the MINI Picnic Bench over the loading lip of the cargo area. Place a protective cloth over the bumper.



## Folding in

Fold rear part of the cargo area floor upward.

The MINI Picnic Bench swings against the underside of the cargo area floor and is fastened there with magnets.

# Things to remember when driving

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## Break-in

### General information

Moving parts need to begin working together smoothly.

The following instructions will help you to achieve a long vehicle life and good efficiency.

During break-in, do not use the Launch Control, refer to page 130.

### Safety information

#### Warning

Due to new parts and components, safety and driver assistance systems can react with a delay. There is a risk of accident. After installing new parts or with a new vehicle, drive conservatively and intervene early if necessary. Observe the break-in procedures of the respective parts and components.

## Engine, transmission, and axle drive

### Up to 1,200 miles/2,000 km

Do not exceed the maximum engine and road speed:

- For gasoline engine 4,500 rpm and 100 mph/160 km/h.

Avoid full throttle or kickdown under all circumstances.

### From 1,200 miles/2,000 km

The engine and vehicle speed can gradually be increased.

## Tires

Tire traction is not optimal due to manufacturing circumstances when tires are brand-new; they achieve their full traction potential after a break-in time.

Drive conservatively for the first 200 miles/300 km.

## Brake system

Brake disks and brake pads only reach their full effectiveness after approx. 300 miles/500 km. Drive moderately during this break-in period.

## Clutch

The function of the clutch reaches its optimal level only after a distance driven of approx. 300 miles/500 km. During this break-in period, engage the clutch gently.

## Following part replacement

The same break-in procedures should be observed if any of the components mentioned

above have to be renewed in the course of driving.

## General driving notes

### Closing the tailgate

#### Safety information

##### Warning

An open tailgate protrudes from the vehicle and can endanger occupants and other road users or damage the vehicle in the event of an accident, braking or evasive maneuvers. In addition, exhaust fumes may enter the vehicle interior. There is a risk of injury or risk of damage to property. Do not drive with the tailgate open.

#### Driving with the tailgate open

If driving with the tailgate open cannot be avoided:

- Close all windows and the glass sunroof.
- Greatly increase the blower output.
- Drive moderately.

### Hot exhaust system

##### Warning

High temperatures can occur underneath the body, for instance caused by the exhaust system, while driving. Contact with the exhaust system can cause burns. There is a risk of injury. Do not touch the hot exhaust system, including the exhaust pipe.

##### Warning

If combustible materials, such as leaves or grass, come in contact with hot parts of the exhaust system, these materials can ignite. There is a risk of fire and an injury hazard. Do not remove the heat shields installed and never apply undercoating to them. Make sure that no combustible materials can come in contact with hot vehicle parts while driving, in Neutral or during parking.

### Mobile radio in the vehicle

##### Warning

Vehicle electronics and mobile communication devices can influence one another. There is radiation due to the transmission operations of mobile communication devices. There is a risk of injury or risk of damage to property. If possible, in the car's interior use only mobile communication devices, such as mobile phones with direct connections to an external antenna in order to exclude mutual interference and deflect the radiation from the vehicle interior.

### Aquaplaning

On wet or slushy roads, a wedge of water can form between the tires and road surface.

This phenomenon is referred to as aquaplaning. It is characterized by a partial or complete loss of contact between the tires and the road surface, ultimately undermining your ability to steer and brake the vehicle.

## Driving through water

### General information

When driving through water, follow the following:

- Deactivate Auto Start/Stop function.
- Drive through calm water only.
- Drive through water only if it is not deeper than maximum 9.8 inches/25 cm.
- Drive through water at a maximum of walking speed, up to 3 mph/5 km/h.

### Safety information

#### NOTICE

When driving too quickly through deep water, the water can penetrate the engine compartment, the electrical system, or the transmission. There is a risk of damage to property, among other potential damage. When driving through water, do not exceed the maximum indicated water level and the maximum speed for driving through water.

## Braking safely

### General information

The vehicle is equipped with an Antilock Braking System as a standard feature.

Perform emergency braking in situations that require such.

Steering is still responsive. You can still avoid any obstacles with a minimum of steering movement.

The pulsation of the brake pedal and sounds from the hydraulic circuits indicate that the Antilock Braking System is in its active mode.

## Objects in the travel path of the pedals

#### Warning

Objects in the driver's footwell can limit the pedal travel or block a depressed pedal. There is a risk of accident. Stow objects in the vehicle such that they are secured and cannot enter into the driver's footwell. Use floor mats that are suitable for the vehicle and can be safely attached to the floor. Do not use loose floor mats and do not layer several floor mats. Make sure that there is sufficient clearance for the pedals. Ensure that the floor mats are securely fastened again after they were removed, for instance for cleaning.

### Driving in wet conditions

In case of wet roads, exposure to road salt, in heavy rain, gently press the brake pedal every few kilometers.

Ensure that this action does not endanger other road users.

The heat generated during braking dries brake disks and brake pads and protects them against corrosion.

In this way the brake force will be available when you need it.

### Hills

#### General information

Drive long or steep downhill gradients in the gear that requires least braking effort. Otherwise, the brake system may overheat and reduce braking effect.

You can increase the engine's braking effect by downshifting, going all the way to first gear, if needed.

## Safety information

### Warning

Light but consistent pressure on the brake pedal can lead to high temperatures, brake wear and possibly even brake system failure. There is a risk of accident. Avoid placing excessive stress on the brake system.

### Warning

In idle state or with the engine switched off, safety functions, for instance engine braking effect, braking assistance and steering assistance, may not be available. There is a risk of accident. Do not attempt to drive in idle state or with the engine switched off.

## Brake disk corrosion

Corrosion on the brake disks and contamination on the brake pads are increased by the following circumstances:

- Low mileage.
- Extended stationary periods.
- Infrequent use of the brakes.
- Aggressive, acidic, or alkaline cleaning agents.

Corrosion buildup on the brake disks will cause a pulsating effect on the brakes when braking slowly - generally this cannot be corrected.

## Condensation water under the parked vehicle

When using the automatic climate control, condensation water develops and collects underneath the vehicle.

## Ground clearance

### NOTICE

If the ground clearance is insufficient, e.g., curbs or underground garage entrances, contact with vehicle parts, e.g., spoiler, and the underbody may occur. There is a risk of damage to property, among other potential damage. Ensure that there is sufficient ground clearance available.

## Roof-mounted luggage rack

### General information

Installation only possible with roof rack.

Roof racks are available as optional accessories.

### Installation

Follow the assembly instructions of the roof rack.

### Loading

Because roof-mounted luggage racks raise the vehicle's center of gravity when loaded, they have a major effect on vehicle handling and steering response.

Therefore, note the following when loading and driving:

- Do not exceed the approved roof/axle weights and the approved gross vehicle weight.
- Be sure that adequate clearance is maintained for tilting and opening the glass sunroof.
- Distribute the roof load uniformly.
- The roof load should not extend past the loading area.

- Always place the heaviest pieces on the bottom.
- Secure the roof luggage firmly, for instance using luggage straps.
- Do not let objects project into the swiveling range of the tailgate.
- Drive cautiously and avoid driving off and braking with jerky movements or fast cornering.
- When driving on steep uphill or downhill grades: add engine oil and coolant up to near the maximum mark.
- Avoid body bottom coming in contact with the ground. The ground clearance may vary depending on the vehicle load status.
- When wheels continue to spin, depress the accelerator so that driving stability control systems can distribute the driving power to the wheels. If necessary, activate the Dynamic Traction Control.

## Driving on poor roads

### Principle

Because of its greater ground clearance, the vehicle can be driven on a variety of road types and qualities.

All-wheel drive can help improve drive power.

### Safety information

#### NOTICE

Objects in unpaved areas, for instance stones or branches, can damage the vehicle. There is a risk of damage to property, among other potential damage. Do not drive on unpaved terrain.

### When driving on poor roads

For your own safety, for the safety of passengers and of the vehicle, heed the following points:

- Familiarize yourself with the vehicle before driving.
- Do not take risks when driving.
- Adjust the speed to the road surface conditions. The steeper and more uneven the road surface, the slower the speed.

### After a trip on poor roads

Note the following to maintain driving safety:

- Clear heavy soiling from the body.
- Keep the wheels and tires free of mud, snow, ice, etc., and check them for damage.

## Driving on racetracks

#### Warning

The vehicle is not designed for use in M Sport or motor sport type competition. There is a risk of accident. Do not use the vehicle for M Sport or motor sport type competitions.

Higher mechanical and thermal loads during racetrack operation lead to increased wear. Use of the vehicle in M Sport or motor sport type competition is an improper use of the vehicle and may affect your warranty coverage. Please consult the “New Vehicle Limited Warranty” Booklet for further information on warranty matters.



# Reducing fuel consumption

## Vehicle features and options

---

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## General information

---

The vehicle contains advanced technologies for the reduction of consumption and emission values.

Fuel consumption depends on a number of different factors.

The implementation of certain measures, driving style and regular maintenance can influence fuel consumption and environmental pollution.

## Remove unnecessary cargo

---

Additional weight increases fuel consumption.

## Remove attached parts following use

---

Remove auxiliary mirrors, roof-mounted or rear carriers which are no longer required following use.

Attached parts on the vehicle impair the aerodynamics and increase the fuel consumption.

## Close the windows and glass sunroof

---

Driving with the glass sunroof and windows open results in increased drag and raises fuel consumption.

## Tires

---

### General information

Tires can affect consumption in various ways, for instance tire size may influence consumption.

### Check the tire pressure regularly

Check and, if needed, correct the tire inflation pressure at least twice a month and before starting on a long trip.

Low tire inflation pressure increases rolling resistance and thus raises fuel consumption and tire wear.

## Drive away without delay

---

Do not wait for the engine to warm-up while the vehicle remains stationary. Start driving right away, but at moderate RPM. This is the fastest way for the cold engine to reach its operating temperature.

## Anticipating driving

A smooth and anticipating driving style reduces fuel consumption.

Avoid unnecessary acceleration and braking.

By maintaining a suitable distance to the vehicle driving ahead of you.

## Avoid high RPM

Driving at low RPM lowers fuel consumption and reduces wear.

If necessary, observe the vehicle's gear shift indicator, refer to page 142.

## Using coasting/overrun mode

When approaching a red traffic light, take your foot off the accelerator and let the vehicle coast to a halt.

For going downhill take your foot off the accelerator and let the vehicle roll.

The fuel supply is interrupted in coasting/overrun mode.

## Switch off the engine during longer stops

### Switching off the engine

Switch off the engine during longer stops, for instance at traffic lights, railroad crossings or in traffic jam.

### Auto Start/Stop function

The Auto Start/Stop function of the vehicle automatically switches off the engine during a stop.

If the engine is switched off and then re-started rather than leaving the engine running constantly, fuel consumption and emissions are reduced. Savings can begin within a few seconds of an engine stop.

In addition, fuel consumption is also determined by other factors, such as driving style, road conditions, maintenance or environmental factors.

## Switch off any functions that are not currently needed

Functions such as seat heating and the rear window defroster require a lot of energy and consume additional fuel, especially in city traffic and with stop-and-go driving.

Switch off these functions if they are not needed.

## Have maintenance carried out

Have the vehicle maintained regularly to achieve optimal vehicle efficiency and service life. MINI recommends that maintenance work be performed by a MINI service center.

Additional information:

MINI maintenance system, refer to page 290.

## GREEN Mode

### Principle

GREEN Mode supports a driving style that saves on consumption. For this purpose, the engine control and comfort features, for instance the climate control output, are adjusted.

For Steptronic transmission:

When certain prerequisites are met the engine is automatically decoupled from the transmission in the D selector lever position. The vehicle continues traveling in Neutral to reduce consumption. The D selector lever position remains engaged.

In addition, context-sensitive instructions are displayed to assist with an efficient driving style.

The achieved extended range is displayed in the instrument cluster as bonus range.

## General information

The system includes the following MINIMALISM functions and MINIMALISM displays:

- GREEN Limit, refer to page 251
- GREEN climate control, refer to page 251.
- GREEN bonus range, refer to page 252.
- GREEN tip, driving instruction, refer to page 252.
- Coasting mode, refer to page 253.
- MINIMALISM analyzer, refer to page 255.

## Activating GREEN Mode




Press the MINI Driving Modes switch downward until GREEN is displayed in the instrument cluster.

## Configuring GREEN

### Via MINI Driving Modes switch

1. Activating GREEN Mode.
2. "Configure GREEN"
3. Select the desired setting.

### Via the Central Information Display (CID)

1.  "My MINI"
2. "Vehicle settings"
3. "Configure GREEN"
4. Select the desired setting.

### Activating/deactivating the functions

The following functions can be activated/deactivated:

- "GREEN speed warning"
- "GREEN climate control"
- "Coasting"

Settings are stored for the driver profile currently used.

### GREEN Limit

- "GREEN speed warning": GREEN Limit is activated.

A GREEN tip is displayed if the speed of the set GREEN Limit is exceeded.

- "Tip at:"

Set the desired speed for the GREEN Limit.

### GREEN climate control

Climate control is set to be efficient.

A minor deviation to the set temperature and adjusting the rate of heating or cooling down of the car's interior consumption can be economized.

The power output to the seat heating and exterior mirror heating is reduced.

### Coasting

Efficiency can be optimized by disengaging the engine and coasting, refer to page 253, in Neutral.

This function is only available in GREEN driving mode.


Deactivate the function to use the braking effect of the engine when traveling downhill.

### GREEN potential savings

Shows potential savings with the current configuration in percentages.

### Display in the instrument cluster

#### GREEN bonus range




A modified driving style helps you extend your driving range. The range extension can be displayed as the bonus range in the instrument cluster.

The bonus range is shown in the range display.

The bonus range is automatically reset every time the vehicle is refueled.

- Green display: efficient driving style.
- Gray display: modify driving style, for instance by backing off the accelerator pedal.

#### Efficiency display



A bar display in the instrument cluster indicates your current driving efficiency.

Mark in the left area, arrow 1: display for energy recovered by coasting or when braking.

Mark in the right area, arrow 2: display when accelerating.

The efficiency of your driving style is shown by the position of the mark:


- Mark inside the green range: efficient driving style.
- Mark outside the green range: modify driving style, for example by backing off the accelerator.

### GREEN tip, driving instruction


#### General information

The GREEN tip indicates that your driving style can be modified to be more efficient, for example by reducing the speed.

#### Instrument cluster without enhanced features: display



#### Instrument cluster with enhanced features: display








#### Activating/deactivating the display

Activate information relating to the driving style and GREEN tips in the instrument cluster using the Central Information Display (CID):

1. "My MINI"
2. "System settings"
3. "Displays"
4. "Instrument panel"
5. "GREEN info"

## GREEN tip, symbols

An additional icon and text instructions are displayed.


Icon	Measure
	For an efficient driving style, look well ahead when driving, accelerate conservatively, and delay accelerating.
	Reduce speed to the selected GREEN speed.
	Steptronic transmission: Switch from M/S to D and avoid manual shift interventions.
	Manual transmission: Follow the shift instructions.
	Manual transmission: Engage Neutral for an engine stop.

## Indications on the Control Display

### Displaying MINIMALISM information

The current operating principle of the functions in GREEN driving mode can be displayed on the Control Display.

Via the Central Information Display (CID):

1.  "My MINI"
2. "Technology in action"
3. "MINIMALISM"

Information is shown on the following functions:

- Auto Start/Stop function.
- Energy recovery.
- Coasting.

### Displaying the MINIMALISM analyzer

Via the Central Information Display (CID):

1.  "My MINI"
2. "Technology in action"
3. "MINIMALISM Analyser"

Further information on the MINIMALISM analyzer, refer to page [255](#).

## Coasting

### Principle

The function helps to conserve fuel.

To do this, under certain conditions the engine is automatically decoupled from the transmission when selector lever position D is set. The vehicle continues traveling in Neutral to reduce consumption. Selector lever position D remains engaged.

This driving condition is referred to as coasting.

As soon as you step on the brake or accelerator pedal, the engine is automatically coupled again.

### General information

A proactive driving style helps the driver to use the function often and supports the efficient effect of coasting.

### Functional requirements

The function is available in the speed range from approx. 15 mph/25 km/h up to 100 mph/160 km/h.

- Accelerator pedal and brake pedal are not operated.
- The selector lever is in selector lever position D.

- Engine and transmission are at operating temperature.
- With a camera in the area of the interior mirror: the system does not detect any vehicles ahead of you.

### Operation via shift paddles

#### Principle


Depending on your vehicle's equipment, the Coasting mode can be influenced with the shift paddles.

#### Activating/deactivating coasting via shift paddles

1. Shift to the highest gear by pulling the right shift paddle.
  2. To activate Coasting mode, actuate the right shift paddle again.
- To deactivate, actuate the left shift paddle.


### Display

#### Instrument cluster without enhanced features



The bar display below the tachometer is filled in green and the mark appears at the zero point. The tachometer indicates idle speed.

#### Instrument cluster with enhanced features



The bar display below the tachometer is filled in green and the mark appears at the zero point. The tachometer indicates idle speed.

#### Indications on the Control Display

The Coasting mode is displayed in the MINIMALISM Info while driving.

The distance traveled in Coasting mode is indicated by a counter.

#### Displaying MINIMALISM information

Via the Central Information Display (CID):

1. "My MINI"
2. "Technology in action"
3. "MINIMALISM"

#### System limits

The function is not available if one of the following conditions applies:

- DSC OFF and TRACTION are activated.
- Cruise control is activated.
- If driving in the dynamic limit range.
- If driving on steep uphill or downhill grades.
- The battery charge state is temporarily too low.
- The vehicle electrical system is drawing excessive current.

## MINIMALISM analyzer

### Principle

The function helps develop an especially efficient driving style and to conserve fuel.

For this purpose, the driving style is analyzed. The assessment is done in various categories and is displayed on the Control Display.

This display will help you adjust your driving style and save some fuel.

The range of the vehicle can be extended by adopting an efficient driving style. This gain in range is displayed as a bonus range in the instrument cluster and on the Control Display.

### Functional requirement

This function is available in GREEN driving mode.

### Displaying the MINIMALISM analyzer

Via the Central Information Display (CID):

1.  "My MINI"
2. "Technology in action"
3. "MINIMALISM Analyser"

### Display on the Control Display

The display of the MINIMALISM analyzer consists of a fish in a water glass, a table of values and the display of the achieved bonus range.

The fish and the movements of the water in the bowl symbolize the efficiency of the driving style.

Depending on the equipment, the fish is shown with efficient and inefficient driving style or only with inefficient driving style.

The more efficient the driving style, the less the water sloshes around in the bowl and the better is the fish's mood. If the driving style is inefficient, the water oscillates, the

fish's mood worsens, and a reduced number of stars is displayed.

The table of values contains stars and evaluates the driving style in different categories. The more efficient the driving style, the more stars are displayed in the table.

The bonus range achieved by a driving style that minimizes consumption is displayed below the table of values. The more efficient the driving style, the faster the bonus range increases.

To support an efficient driving style, GREEN tips are displayed while driving.

Tips for an energy-saving driving style, Saving fuel, refer to page [249](#).

# Refueling

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## General information

Follow the fuel recommendation, refer to page 258, prior to refueling.

## Safety information


### NOTICE

With a range below 30 miles/50 km, the engine may no longer have sufficient fuel. Engine functions are not ensured anymore. There is a risk of damage to property, among other potential damage. Refuel promptly.

## Fuel cap

### Opening

1. To open the fuel filler flap, press on the rear edge, arrow. The fuel filler flap opens.



2. Turn the fuel cap counterclockwise.



3. Place the fuel cap in the bracket attached to the fuel filler flap.





## Closing

### Warning

The retaining strap of the fuel cap can be jammed and crushed during closing. The cap cannot be correctly closed. Fuel or fuel vapors can escape. There is a risk of injury or risk of damage to property. Pay attention that the retaining strap is not jammed or crushed when closing the cap.

1. Fit the cap and turn it clockwise until you clearly hear a click.
2. Press on the fuel filler flap until it engages.

## Emergency unlocking

It may be necessary in certain situations to unlock the fuel filler flap manually, for instance with an electrical malfunction.

Have fuel filler flap unlocked by a dealer's service center or another qualified service center or repair shop.

## Follow the following when refueling

### General information

When refueling, hook the filler nozzle completely into the filler pipe. Lifting up the filler nozzle during refueling causes:

- Premature switching off.
- Reduced return of the fuel vapors.

The fuel tank is full when the filler nozzle clicks off the first time.

Make sure that the fuel cap is closed properly after refueling, otherwise the emissions warning light may light up.

Follow safety regulations posted at the filling station.

## Safety information

### NOTICE

Fuels are toxic and aggressive. Overfilling of the fuel tank can damage the fuel system. Painted surfaces may be damaged by contact with fuel. Escaping fuel can harm the environment. There is a risk of damage to property, among other potential damage. Avoid overfilling.

# Fuel

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## Fuel recommendation

### General information

Depending on the region, many filling stations sell fuel that has been customized to winter or summer conditions. Fuel that is available in winter, for instance helps make a cold start easier.

### Gasoline

#### General information

For the best fuel efficiency, the gasoline should be sulfur-free or very low in sulfur content.

Fuels that are marked on the gas pump as containing metal must not be used.

Fuels with a maximum ethanol content of 25 %, i. e. E10 or E25, may be used for refueling.

To achieve nominal values for mileage and consumption, follow the specified fuel quality in the sales literature.



Ethanol should meet the following quality standards:

US: ASTM 4806-xx

CAN: CGSB-3.511-xx

xx: comply with the current valid standard in each case.

The use of fuels of minimum quality has no influence on the service life of the engine.

## Safety information

### NOTICE

Even small quantities of the wrong fuel or wrong fuel additives can damage the fuel system and engine. Furthermore, the catalytic converter is permanently damaged. There is a risk of damage to property, among other potential damage. Do not refuel or add the following in the case of gasoline engines:

- Leaded gasoline.
- Metallic additives, for instance manganese or iron.

Do not press the Start/Stop button after refueling with the wrong fuel. Contact a dealer's service center or another qualified service center or repair shop.

**⚠ NOTICE**

Incorrect fuels can damage the fuel system and the engine. There is a risk of damage to property, among other potential damage. Do not use fuels with a higher ethanol content than recommended. Do not refuel with fuels containing methanol, e.g. M5 to M100.

**⚠ NOTICE**

Fuel that does not comply with the minimum quality can compromise engine function or cause engine damage. There is a risk of damage to property, among other potential damage. Do not fill with fuel that does not comply with the minimum quality.

**⚠ CAUTION**

The use of poor-quality fuels may result in harmful engine deposits or damage. Additionally, problems relating to drivability, starting and stalling, especially under certain environmental conditions such as high ambient temperature and high altitude, may occur.

If drivability problems are encountered, we recommend switching to a high quality gasoline brand and a higher octane grade — AKI number — for a few tank fills. To avoid harmful engine deposits, it is highly recommended to purchase gasoline from Top Tier retailers.

Failure to comply with these recommendations may result in the need for additional maintenance.

MINI recommends AKI 93.

**Minimum fuel grade**

MINI recommends AKI 87.

John Cooper Works:

MINI recommends AKI 91.

If you use gasoline with this minimum AKI Rating, the engine may produce knocking sounds when starting at high external temperatures. This has no effect on the engine life.

**Recommended gas quality**

MINI recommends AKI 91.

John Cooper Works:

# Wheels and tires

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## Tire pressure

### General information

The tire condition and tire pressure influence the following:

- The service life of the tires.
- Driving safety.
- Driving comfort.
- Fuel consumption.

### Safety information

#### Warning

A tire with too little or no tire inflation pressure may heat up significantly and sustain damage. This will have a negative impact on aspects of handling, such as steering and braking response. There is a risk of accident. Regularly check the tire inflation pressure, and correct it as needed, for instance twice a month and before a long trip.

## Tire pressure specifications

### In the tire inflation pressure table

The tire inflation pressure table, refer to page 261, contains all tire inflation pressure specifications for the specified tire sizes at the ambient temperature. The tire inflation pressure values apply to tire sizes approved by the manufacturer of the vehicle for the vehicle type.

To identify the correct tire inflation pressure, please note the following:

- Tire sizes of your vehicle.
- Maximum speed for driving.

## Checking the tire pressure

### General information

Tires heat up while driving. The tire pressure increases with the tire temperature.

Tires have a natural, consistent tire pressure loss.

The displays of inflation devices may under-read by up to 0.1 bar/2 psi.

### Checking using tire inflation pressure specifications in the tire inflation pressure table

The tire inflation pressure specifications in the tire inflation pressure table only relate to cold tires or tires at the same temperature as the ambient temperature.

Only check the tire inflation pressure levels when the tires are cold, i.e.:

- Distance travelled of max. 1.25 miles/2 km has not been exceeded.
- If the vehicle has not moved again for at least 2 hours after a trip.

1. Determine the intended tire inflation pressure levels for the mounted tires.
2. Check the tire inflation pressure in all four tires, using a pressure gage, for example.
3. Correct the tire inflation pressure if the actual tire inflation pressure deviates from the intended tire inflation pressure.
4. Check whether all valve caps are screwed onto the tire valves.

### After correcting the tire pressure

For flat tire monitor: reinitialize flat tire monitor.

For Tire Pressure Monitor: reset the Tire Pressure Monitor.

### Checking the tire inflation pressure of the emergency wheel

Also check the tire inflation pressure of the emergency wheel in the cargo area regularly, and correct it as needed.

### Tire pressures up to 100 mph/160 km/h

For speeds of up to 100 mph/160 km/h and for optimum driving comfort, note the pressure values in the tire pressure table, refer to page 261, and adjust as necessary.




These pressure values can also be found on the tire pressure label on the driver's door pillar.

Do not exceed a speed of 100 mph/160 km/h.

### Tire pressure values up to 100 mph/160 km/h


#### COOPER, COOPER ALL4

Tire size	Pressure specifications in bar/PSI	
Specifications in bar/PSI with cold tires		
225/55 R 17 97 H A/S	2.2 / 32	2.2 / 32
225/55 R 17 97 W		
225/55 R 17 97 H M+S		
225/50 R 18 95 V A/S	2.3 / 33	2.3 / 33
225/50 R 18 95 W		
225/50 R 18 99 W XL		
205/65 R 16 95 H M+S		
225/50 R 18 95 H M+S		


Tire size	Pressure specifications in bar/PSI	
225/45 R 19 96 W XL	2.6 / 38	2.6 / 38
225/45 R 19 96 Y XL		
205/60 R 17 93 H M+S		
205/55 R 18 96 H XL M+S		
Emergency wheel	Speed up to a max. of 50 mph / 80 km/h	
T 115/95 R 17 95 M	4.2 / 60	

Tire size	Pressure specifications in bar/PSI	
225/45 R 19 96 W XL	2.6 / 38	2.6 / 38
225/45 R 19 96 Y XL		
205/60 R 17 93 H M+S		
205/55 R 18 96 H XL M+S		
Emergency wheel	Speed up to a max. of 50 mph / 80 km/h	
T 115/95 R 17 95 M	4.2 / 60	

### COOPER S, COOPER S ALL4

Tire size	Pressure specifications in bar/PSI	
Specifications in bar/PSI with cold tires		
225/55 R 17 97 H A/S	2.4 / 35	2.4 / 35
225/50 R 18 95 V A/S		
225/55 R 17 97 W		
225/50 R 18 95 W		
225/55 R 17 97 H M+S		
225/50 R 18 95 H M+S		

### JOHN COOPER WORKS

Tire size	Pressure specifications in bar/PSI	
Specifications in bar/PSI with cold tires		
225/50 R 18 95 V A/S	2.4 / 35	2.4 / 35
225/50 R 18 95 W		
225/50 R 18 95 H M+S		
225/45 R 19 96 W XL	2.7 / 39	2.7 / 39
205/55 R 18 96 H XL M+S		

## Tire inflation pressures at max. speeds above 100 mph/160 km/h


### Warning

In order to drive at maximum speeds in excess of 100 mph/160 km/h, please observe, and, if necessary, adjust tire pressures for speeds exceeding 100 mph/160 km/h from the relevant table on the following pages. Otherwise, tire damage and accidents could occur.


For speeds over 100 mph/160 km/h and for optimum driving comfort, note the pressure values in the tire pressure table, refer to page 263, and adjust as necessary.

## Tire pressure values over 100 mph/160 km/h


### COOPER, COOPER ALL4

Tire size	Pressure specifications in bar/PSI	
Specifications in bar/PSI with cold tires		
225/55 R 17 97 H A/S	2.4 / 35	2.4 / 35
225/55 R 17 97 W		
225/55 R 17 97 H M+S		
225/50 R 18 95 V A/S	2.6 / 38	2.6 / 38
225/50 R 18 95 W		
225/50 R 18 99 W XL		
205/65 R 16 95 H M+S		
225/50 R 18 95 H M+S		
225/45 R 19 96 W XL	2.8 / 41	2.8 / 41
225/45 R 19 96 Y XL		
205/60 R 17 93 H M+S		
205/55 R 18 96 H XL M+S		
Emergency wheel	Speed up to a max. of 50 mph / 80 km/h	
T 115/95 R 17 95 M	4.2 / 60	

**COOPER S, COOPER S ALL4**

Tire size	Pressure specifications in bar/PSI	
Specifications in bar/PSI with cold tires		
225/55 R 17 97 H A/S	3.0 / 44	3.0 / 44
225/50 R 18 95 V A/S		
225/55 R 17 97 W		
225/50 R 18 95 W		
225/55 R 17 97 H M+S		
225/50 R 18 95 H M+S		
225/45 R 19 96 W XL	3.2 / 46	3.2 / 46
225/45 R 19 96 Y XL		
205/60 R 17 93 H M+S		
205/55 R 18 96 H XL M+S		
Emergency wheel	Speed up to a max. of 50 mph / 80 km/h	
T 115/95 R 17 95 M	4.2 / 60	

**JOHN COOPER WORKS**

Tire size	Pressure specifications in bar/PSI	
Specifications in bar/PSI with cold tires		
225/50 R 18 95 V A/S	3.0 / 44	3.0 / 44
225/50 R 18 95 W		
225/50 R 18 95 H M+S		
225/45 R 19 96 W XL	3.2 / 46	3.2 / 46
205/55 R 18 96 H XL M+S		

**Tire marking**
**Tire size**

205/45 R 17 84 V

205: nominal width in mm

45: cross-sectional relationship in %

R: radial tire code

17: rim diameter in inches

84: load bearing capacity

V: speed code letter

ZR tires: reinforced radial tire for speeds exceeding 150 mph/240 km/h

**Maximum tire load**

Maximum tire load is the maximum permissible weight for which the tire is approved.

Locate the maximum tire load on the tire sidewall and the Gross Axle Weight Rating – GAWR – on the certification label on the driver's door pillar. Divide the tire load by



1.1. It must be greater than one-half of the vehicle's Gross Axle Weight Rating – GAWR. Note, front vs. rear GAWR and tire loads, respectively.

## Speed letter

Designation	Maximum speed
Q	up to 100 mph/160 km/h
R	up to 106 mph/170 km/h
S	up to 112 mph/180 km/h
T	up to 118 mph/190 km/h
H	up to 131 mph/210 km/h
V	up to 150 mph/240 km/h
W	up to 167 mph/270 km/h
Y	up to 186 mph/300 km/h

## Tire Identification Number

DOT code: DOT xxxx xxx 0122

xxxx: manufacturer code for the tire brand

xxx: tire size and tire design

0122: tire age

Tires with DOT codes meet the guidelines of the U.S. Department of Transportation.

## Tire age

### Recommendation

Regardless of the tire tread depth, replace tires at least every 6 years.

### Manufacture date

You can find the manufacture date of the tire on the tire sidewall.

Designation	Manufacture date
DOT ... 0122	1st week 2022

## Uniform Tire Quality Grading

Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width.

E.g.: Treadwear 200; Traction AA; Temperature A

## DOT Quality Grades

Treadwear

Traction AA A B C

Temperature A B C

All passenger vehicle tires must conform to Federal Safety Requirements in addition to these grades.

## Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course. E.g., a tire graded 150 would wear one and one-half, 1 g, times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

## Traction

The traction grades, from highest to lowest, are AA, A, B, and C.

Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.

The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration,

cornering, hydroplaning, or peak traction characteristics.

## Temperature

The temperature grades are A, the highest, B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades Band A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

### Warning

The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure.

## Runflat tires

Runflat tires, refer to page 269, are labeled with a circular icon containing the letters RSC marked on the tire sidewall.

## M+S

Winter and all-season tires with better cold weather performance than summer tires.

## Tire tread


### Summer tires

Do not drive with a tire tread depth of less than 0.12 in/3 mm, otherwise there is an increased risk of aquaplaning.

### Winter tires

Do not drive with a tire tread depth of less than 0.16 in/4 mm, as such tires are less suitable for winter driving conditions.

### Minimum tread depth



Distributed over the tire circumference are the tire manufacturer's wear indicators with a height of at least 0.06 in/1.6 mm, which serve as an indicator of tire tread wear.

The positions of the wear indicators are marked on the tire sidewall with TWI, Tread Wear Indicator.

Irrespective of the wear indicators, observe the statutory regulations on the minimum tread depth.

## Tire damage

### General information

Check your tires regularly for damage, foreign bodies lodged in the tread, and tread wear.

Driving over rough or damaged road surfaces, as well as debris, curbs and other obstacles can cause serious damage to wheels, tires and suspension parts. This is more likely to occur with low-profile tires, which provide less cushioning between the wheel and the road. Be careful to avoid road hazards and reduce your speed, especially if your vehicle is equipped with low-profile tires.

Indications of tire damage or other vehicle malfunctions:

- Unusual vibrations.
- Unusual tire or running noises.
- Unusual handling such as a strong tendency to pull to the left or right.
- Uneven wear pattern, e.g., increased wear in the area of the tire shoulder.

Damage can be caused by the following situations, for instance:

- Driving over curbs.
- Road damage.
- Tire pressure too low.
- Vehicle overloading.
- Incorrect tire storage.

## Safety information

### Warning

Damaged tires can lose tire inflation pressure, which can lead to loss of vehicle control. There is a risk of accident. If tire damage is suspected while driving, immediately reduce speed and stop. Have wheels and tires checked. For this purpose, drive carefully to the nearest dealer's service center or another qualified service center or repair shop. Have vehicle towed or transported as needed. Do not repair damaged tires, but have them replaced.

### Warning

Tires can become damaged by driving over obstacles, e.g., curbs or road damage, at high speed. Larger wheels have a smaller tire cross-section. The smaller the tire cross-section, the higher the risk of tire damage. There may be a risk of accidents and risk of damage to property. If possible, avoid driving over objects or road conditions that may damage tires, or drive over them slowly and carefully.

## Exchanging wheels and tires

### Mounting and wheel balancing

Have mounting and tire and wheel balancing carried out by a dealer's service center or another qualified service center or repair shop.

### Approved wheels and tires

#### General information

The following properties are recommended and approved by the manufacturer of the vehicle for the approved wheels and tires per vehicle type and special equipment:

- Wheel and tire combinations.
- Rim designs.
- Tire sizes.
- Tire brands.

You can ask a dealer's service center or another qualified service center or repair shop about the approved wheels and tires for the vehicle and the special equipment.

## Safety information

### Warning

Wheels and tires which are not suitable for your vehicle can damage parts of the vehicle, for instance due to contact with the body due to tolerances despite the same official size rating. There is a risk of an accident. The manufacturer of your vehicle strongly suggests that you use wheels and tires that have been recommended by the vehicle manufacturer for your vehicle type.

### Warning

Incorrect wheel/tire combinations will impair the vehicle's handling characteristics and a variety of system functions, such as the Antilock Braking System or Dynamic Stability Control. There is a risk of accident. To maintain good handling and vehicle response, use only tires with a single tread configuration from a single manufacturer. The manufacturer of the vehicle recommends that you use wheels and tires that have been recommended by the vehicle manufacturer for your vehicle type. Following tire damage, have the original wheel/tire combination remounted on the vehicle as soon as possible.

## Recommended tire brands



For each tire size, the manufacturer of the vehicle recommends certain tire brands. The tire brands can be identified by a star on the tire sidewall.

## New tires

Tire traction is not optimal due to manufacturing circumstances when tires are brand-new; they achieve their full traction potential after a break-in time.

Drive conservatively for the first 200 miles/300 km.

## Retreaded tires

### Warning

Retreaded tires can have different tire casing structures. With advanced age the service life can be limited. There is a risk of accident. The manufacturer of the vehicle does not recommend the use of re-treaded tires.

## Winter tires



Winter tires are recommended for operating on winter roads.

Winter tires can be identified by the symbol with mountain and snowflake, as well as the M+S marking on the tire sidewall.

So-called all-season tires with M+S designation, but without symbol with mountain and snowflake, have better winter characteristics than summer tires but generally do not achieve the performance of winter tires.

### Maximum speed of winter tires

If the maximum speed of the vehicle is higher than the permissible speed for the winter tires, then attach a sign showing the permissible maximum speed in the field of vision. The sign is available from a dealer's service center or another qualified service center or repair shop.

With winter tires mounted, observe and do not exceed the permissible maximum speed.

## Changing runflat tires

When changing from runflat tires to standard tires, it must be ensured that the vehicle contains an emergency wheel or tire mobility kit. Further information is available from a dealer's service center or another qualified service center or repair shop.

## Wheel change between axles

Different abrasion patterns can occur on the front and rear axles depending on individual driving conditions. The tires can be rotated in pairs between the axles to achieve even abrasion. Further information is available from a dealer's service center or another qualified service center or repair shop. After changing, check the tire pressure and correct, if needed.

## Storing tires

### Tire pressure

Do not exceed the maximum tire inflation pressure indicated on the tire sidewall.

### Storage

Store wheels and tires in a cool, dry and dark place.

Always protect tires against all contact with oil, grease, and solvents.

Do not leave tires in plastic bags.

Remove dirt from wheels or tires.

## Runflat tires

### Principle

Runflat tires permit continued driving under limited conditions even in the event of a complete tire pressure loss.

### General information

The wheels are composed of tires that are self-supporting to a limited degree.

The reinforcement of the sidewall allows the tire to remain drivable to a limited degree in the event of a tire pressure loss.

Follow the instructions for continued driving with a flat tire.

## Safety information

### Warning

The vehicle handles differently when a runflat tire has insufficient or no tire pressure; for instance, reduced directional stability when braking, braking distances are longer and the self-steering properties will change. There is a risk of accident. Drive moderately and do not exceed a speed of 50 mph/80 km/h.

## Identification



Runflat tires are labeled with a circular icon containing the letters RSC marked on the tire sidewall.

## Repairing a flat tire

### Safety precautions

- Park the vehicle as far away as possible from passing traffic and on solid ground.
- Turn on the hazard warning system.
- Secure the vehicle against rolling away by setting the parking brake.
- Turn the steering wheel until the front wheels are in the straight-ahead position and engage the steering wheel lock.
- Have all vehicle occupants get out of the vehicle and ensure that they remain out-

side the hazardous area in a safe place, such as behind a guardrail.

- If necessary, set up a warning triangle at an appropriate distance.

## Tire repair set

### Principle

With the tire repair set, minor tire damage can be sealed temporarily to enable continued driving. To accomplish this, sealing compound is pumped into the tires, which hardens and seals the damage from the inside.

### General information


- Follow the instructions on using the tire repair set found on the compressor and sealant bottle.
- Use of the tire repair set may be ineffective if the tire puncture measures approx. 4 mm or more.
- Contact a dealer's service center or another qualified service center or repair shop if the tire cannot be made drivable.
- Do not remove foreign objects that have penetrated the tire. Only remove foreign bodies if they are visibly protruding from the tire.
- Pull the speed limit sticker off the sealant bottle and apply it to the steering wheel.
- The use of a sealing compound can damage the TPM wheel electronics. In this case, have the TPM wheel electronics replaced at the next opportunity.
- The compressor can be used to check the tire inflation pressure.

## Overview

### Storage

The tire repair set is located in a bag on the right side trim panel in the cargo area.


### Sealant bottle



- Sealant bottle, arrow 1.
- Filler hose, arrow 2.

Observe expiration date on the sealant bottle.

### Compressor



- 1 Sealant bottle unlocking
- 2 Sealant bottle mount
- 3 Tire pressure display
- 4 Reduce tire inflation pressure button
- 5 On/off switch
- 6 Compressor
- 7 Connector/cable for socket
- 8 Connection hose

## Safety precautions

- Park the vehicle as far away as possible from passing traffic and on solid ground.
- Turn on the hazard warning system.
- Secure the vehicle against rolling away by setting the parking brake.
- Turn the steering wheel until the front wheels are in the straight-ahead position and engage the steering wheel lock.
- Have all vehicle occupants get out of the vehicle and ensure that they remain outside the hazardous area in a safe place, such as behind a guardrail.
- If necessary, set up a warning triangle at an appropriate distance.

## Filling the tire with sealing compound

### Safety information

#### DANGER


If the exhaust pipe is blocked or ventilation is insufficient, harmful exhaust gases can penetrate the vehicle. The exhaust gases contain pollutants which are colorless and odorless. In enclosed areas, exhaust gases can also accumulate outside of the vehicle. There is a danger to life. Keep the exhaust pipe free and ensure sufficient ventilation.

#### NOTICE


The compressor can overheat during extended operation. There is a risk of damage to property, among other potential damage. Do not run the compressor for more than 10 minutes.

## Filling


1. Shake the sealant bottle.



2. Pull filler hose completely out of the cover of the sealant bottle. Do not kink the hose.



3. Slide the sealant bottle into the mount on the compressor housing, ensuring that it engages audibly.




4. Screw the filler hose of the sealant bottle onto the tire valve of the faulty wheel.



5. With the compressor switched off, insert the connector into the power socket in the vehicle interior.



6. With the ignition switched on or the engine running, switch on the compressor.



Let the compressor run for max. 10 minutes to fill the tire with sealing compound and achieve a tire inflation pressure of approx. 2.5 bar.

While the tire is being filled with sealing compound, the tire inflation pressure may



sporadically reach approx. 5 bar. Do not switch off the compressor in this phase.

## Checking and adjusting the tire inflation pressure

### Checking

1. Switch off the compressor.
2. Read the tire pressure on the tire pressure display.

To continue the trip, a tire inflation pressure of at least 2 bar must be reached.


### Removing and stowing the sealant bottle

1. Unscrew the filler hose of the sealant bottle from the tire valve.
2. Press the red unlocking device.
3. Remove the sealant bottle from the compressor.
4. Wrap and store the sealant bottle in suitable material to avoid contamination of the cargo area.


### Minimum tire inflation pressure is not reached

1. Pull the connector out of the power socket in the vehicle interior.
2. Drive 33 ft/10 m forward and back to distribute the sealing compound in the tire.

3. Screw the connection hose of the compressor directly onto the tire valve stem.



4. Insert the connector into the power socket in the vehicle interior.



5. With the ignition turned on or the engine running, turn on the compressor and let it run for a maximum of 10 minutes.

If a tire inflation pressure of at least 2 bar cannot be reached, contact a dealer's service center or another qualified service center or repair shop.

If a tire inflation pressure of at least 2 bar is reached, see Minimum tire inflation pressure is reached.

6. Unscrew the connection hose of the compressor from the tire valve.
7. Pull the connector out of the power socket in the vehicle interior.
8. Stow the tire repair set in the vehicle.

### Minimum tire inflation pressure is reached


1. Unscrew the connection hose of the compressor from the tire valve.
2. Pull the connector out of the power socket in the vehicle interior.
3. Stow the tire repair set in the vehicle.
4. Immediately drive approx. 5 miles/10 km to ensure that the sealing compound is evenly distributed in the tire.

Do not exceed a speed of 50 mph/80 km/h.


If possible, do not drive at speeds less than 12 mph/20 km/h.

### Adjustment

1. Stop at a suitable location.
2. Screw the connection hose of the compressor directly onto the tire valve stem.



3. Insert the connector into the power socket in the vehicle interior.



4. Correct the tire inflation pressure to at least 2.0 bar.
  - Increase tire pressure: with the ignition turned on or the engine running, turn on the compressor and let it run for a maximum of 10 minutes.
  - Reduce tire inflation pressure: press the button on the compressor.
5. Unscrew the connection hose of the compressor from the tire valve.
6. Pull the connector out of the power socket in the vehicle interior.
7. Stow the tire repair set in the vehicle.

### Continuing the trip

Do not exceed the permissible maximum speed of 50 mph/80 km/h.

Reinitialize the Flat Tire Monitor, refer to page 170.

Reset the Tire Pressure Monitor, refer to page 165.

Replace the faulty tire and the sealant bottle of the tire repair set promptly.

## Tire chains

### General information

The manufacturer of the vehicle has determined certain wheels and tires to be suitable for operation on the vehicle.

Follow the tire chain manufacturer's instructions.

Do not initialize the flat tire monitor after mounting tire chains, as doing so may result in incorrect readings.

Do not reset the Tire Pressure Monitor after mounting tire chains, as doing so may result in incorrect readings.

When driving with tire chains, briefly activate Dynamic Traction Control, if needed.

## Safety information

### Warning

With the mounting of tire chains on unsuitable tires, the tire chains can come into contact with vehicle parts. There may be a risk of accident or risk of damage to property. Only mount tire chains on tires that are designated by their manufacturer as suitable for the use of tire chains.

### Warning

Insufficiently tight tire chains may damage tires and vehicle components. There may be a risk of accident or risk of damage to property. Make sure that the tire chains are always sufficiently tight. Re-tighten as needed according to the tire chain manufacturer's instructions.

## Fine-link tire chains

The manufacturer of the vehicle recommends the use of fine-link tire chains. Certain types of fine-link tire chains have been tested by the manufacturer of the vehicle and recommended as road-safe and suitable. Information regarding suitable tire chains is available from a dealer's service center or another qualified service center or repair shop.

## Use

Use only in pairs on the front wheels, equipped with the tires of the following size:

- 205/65 R 16.
- 205/60 R 17.
- 205/55 R 18.

John Cooper Works:

- 205/60 R 17.
- 205/55 R 18.

## Maximum speed with tire chains

Do not exceed a speed of 30 mph/50 km/h when using tire chains.

## Changing wheels/tires

### General information

When using runflat tires or a flat tire kit, a wheel does not always need to be changed immediately in case of a breakdown when there is a tire pressure loss due to a flat tire.

If needed, the appropriate tool for a wheel change, e.g., a jack, is available as an accessory from a dealer's service center, another qualified service center or a repair shop.

## Safety information

### DANGER

The jack is only provided for short-term lifting of the vehicle for wheel changes. Even if all safety precautions are observed, there is a risk of the raised vehicle falling, if the jack tips over. There is a risk of injury or danger to life. If the vehicle is raised with the jack, do not lie under the vehicle and do not start the engine.

### Warning

Supports such as wooden blocks under the jack reduce the load-carrying capacity of the jack to bear weight. The load-carrying capacity of the wooden blocks may be exceeded and the vehicle may tip over. There is a risk of injury or danger to life. Do not place supports under the jack.

**⚠ Warning**

The jack, issued by the vehicle manufacturer, is provided in order to perform a wheel change in the event of a breakdown. The jack is not designed for frequent use; for example, changing from summer to winter tires. Using the jack frequently may cause it to become jammed or damaged. There is a risk of injury and risk of damage to property. Only use the jack to change an emergency or spare wheel in the event of a breakdown.

**⚠ Warning**

On soft, uneven or slippery ground, for example snow, ice, tiles, etc., the jack can slip away. There is a risk of injury. If possible, change the wheel on a flat, solid, and slip-resistant surface.

**⚠ Warning**

The jack is optimized for lifting the vehicle and for the jacking points on the vehicle only. There is a risk of injury. Do not lift any other vehicle or cargo using the jack.

**⚠ Warning**

When the jack is not inserted into the jacking point provided for this purpose, the vehicle may be damaged or the jack may slip when it is being cranked up. There is a risk of injury or risk of damage to property. When cranking up the jack, ensure that it is inserted in the jacking point next to the wheel well.

**⚠ Warning**

A vehicle that is raised on a jack may fall off of the jack if lateral forces are exerted on it. There is a risk of injury and risk of damage to property. While the vehicle is raised, do not exert lateral effort on the vehicle or pull abruptly on the vehicle. Have a stuck wheel removed by a dealer's service center or another qualified service center or repair shop.

## Securing the vehicle against rolling away

### General information


The vehicle manufacturer recommends to additionally secure the vehicle against rolling away when changing a wheel.

### On a level surface



Place wheel chocks or other suitable objects in front and behind the wheel that is diagonal to the wheel to be changed.

## On a slight downhill gradient




If you need to change a wheel on a slight downhill grade, place chocks and other suitable objects, for instance rocks, under the wheels of both the front and rear axles against the rolling direction.

## Preparing the vehicle

- Park the vehicle on solid and non-slip ground at a safe distance from road traffic.
- Turn on the hazard warning system.
- Set the parking brake.
- Engage a gear or move the selector lever to position P.
- As soon as permitted by the traffic flow, have all vehicle occupants get out of the vehicle and ensure that they remain outside the hazardous area in a safe place, such as behind a guardrail.
- Depending on the vehicle equipment, get wheel change tools and, if necessary, the emergency wheel from the vehicle.
- If necessary, set up a warning triangle or portable hazard warning light at an appropriate distance.
- Secure the vehicle additionally against rolling away.
- Loosen the lug bolts a half turn.

## Jacking points




The jacking points for the vehicle jack are located at the marked positions.

## Jacking up the vehicle


### Warning

Hands and fingers can be jammed when using the jack. There is a risk of injury. Comply with the described hand position and do not change this position while using the jack.


1. Hold the vehicle jack with one hand, arrow 1, and grasp the jack crank handle or lever with your other hand, arrow 2.



2. Insert the jack into the rectangular recess of the jacking point closest to the wheel to be changed.




3. Extend the jack by turning the jack crank handle or lever clockwise.




4. Take your hand away from the jack as soon as the jack is under load and continue turning the jack crank handle or lever with one hand.

5. Make sure that the car jack foot stands vertically and at a right angle beneath the jacking point.



6. Make sure that the car jack foot stands vertically and perpendicularly beneath the jacking point after extending the vehicle jack.



7. Crank the vehicle up, until the vehicle jack is with the entire surface on the ground and the relevant wheel is maximum 1.2 inches/3 cm above ground.

## Mounting a wheel

Mount one emergency wheel only, as required.

1. Unscrew the lug bolts.
2. Remove the wheel.
3. Put the new wheel or emergency wheel on and screw in at least two lug bolts in a crosswise pattern until hand-tight.

If non-original light-alloy wheels of the vehicle manufacturer are mounted, the accompanying lug bolts may have to be used as well.

4. Hand-tighten the remaining lug bolts and tighten all lug bolts well in a cross-wise pattern.
5. Turn the jack crank handle counter-clockwise to retract the jack and lower the vehicle.
6. Remove the jack and stow it securely.

## After the wheel change

1. Tighten the lug bolts crosswise. The tightening torque is 101 lbs ft/140 Nm.
2. Stow the faulty wheel in the cargo area, if necessary.  
The faulty wheel cannot be stored under the cargo area floor because of its size.
3. Check tire inflation pressure at the next opportunity and correct as needed.
4. Reinitialize the Flat Tire Monitor.  
Reset the Tire Pressure Monitor again.
5. Check to make sure the lug bolts are tight with a calibrated torque wrench.
6. Have the damaged tire renewed at the nearest dealer's service center or another qualified service center or repair shop.

## Emergency wheel

### Principle

In the event of a flat tire, the emergency wheel can be used in place of the wheel with the faulty tire. The emergency wheel is only intended for temporary use until the faulty tire/wheel has been replaced.

### General information

Mount one emergency wheel only.

Also check the tire inflation pressure of the emergency wheel in the cargo area regularly, and correct it as needed.

## Safety information

### Warning

The emergency wheel has particular dimensions. When driving with an emergency wheel, changed driving properties may occur, for instance reduced directional stability when braking, longer braking distance, and changed self-steering properties in the limit range. There is a risk of accident. Drive moderately and do not exceed a speed of 50 mph/80 km/h.

## Overview



The emergency wheel and the wheel change tools are located in the cargo area under the cargo area floor.

## Removing the emergency wheel

1. Pull up and remove the cargo area floor.
2. Unscrew the wing screw.
3. Remove the retaining plate or the cover.
4. Where applicable, remove the holder and the trailer hitch.

5. Remove the jacking point and the tool holder on the left next to the emergency wheel.
6. Slide the emergency wheel to the left and remove it.

### Inserting the emergency wheel

1. Insert the emergency wheel on the left and slide it to the right.
2. Where applicable, mount the holder and the trailer hitch.
3. Attach the retaining plate or the cover.
4. Screw on and tighten the wing screw.
5. Insert and secure the jacking point and the tool holder on the left next to the emergency wheel.
6. Insert the cargo area floor.




# Engine compartment

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available

in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## Overview



- |   |                               |   |                                  |
|---|-------------------------------|---|----------------------------------|
| 1 | Filler neck for washer fluid  | 4 | Jump-starting, positive terminal |
| 2 | Vehicle identification number | 5 | Jump-starting, negative terminal |
| 3 | Oil filler neck               | 6 | Coolant reservoir                |

## Hood

### Safety information

#### **Warning**

Improperly executed work in the engine compartment can damage vehicle components and impair vehicle functions. There is a risk of an accident and damage to property. Have work in the engine compartment performed by a dealer's service center or another qualified service center or repair shop.

#### **Warning**

The engine compartment accommodates moving components. Certain components in the engine compartment can also move with the vehicle switched off, for instance the radiator fan. There is a risk of injury. Do not reach into the area of moving parts. Keep articles of clothing and hair away from moving parts.

#### **Warning**

There are protruding parts, for instance locking hooks, on the inside of the hood. There is a risk of injury. If the hood is open, pay attention to protruding parts and keep clear of these areas.

#### **Warning**

An incorrectly locked hood can open while driving and restrict the view. There is a risk of accident. Stop immediately and correctly close the hood.

#### **Warning**

Body parts can be jammed when opening and closing the hood. There is a risk of injury. Make sure that the travel path of the hood is clear during opening and closing.

#### **NOTICE**

Folded-away wipers can be jammed when the hood is opened. There is a risk of damage to property, among other potential damage. Make sure that the wipers with the wiper blades mounted are folded down onto the windshield before opening the hood.

#### **NOTICE**

When the hood is closed, it must engage on both sides. Pressing again can damage the hood. There is a risk of damage to property, among other potential damage. Open the hood again and then close it energetically. Avoid pressing again.

### Opening the hood

1. Pull lever, arrow 1.  
Hood is unlocked.



2. After the lever is released, pull the lever again, arrow 2.  
Hood can be opened.

## Indicator/warning lights

When the hood is opened, a Check Control message is displayed.

## Closing the hood



Energetically close the hood from approx. 20 in/50 cm.

The hood must engage on both sides.

# Engine oil

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## General information

The engine oil consumption is dependent on your driving style and driving conditions. Therefore, regularly check the engine oil level after refueling by taking a detailed measurement.

The engine oil consumption can increase in the following situations, for instance:

- Sporty driving style.
- Break-in of the engine.
- Idle operation of the engine.
- With use of engine oil types that are classified as not suitable.

Different Check Control messages appear, depending on the engine oil level.

The vehicle manufacturer recommends that you have a dealer's service center or another qualified service center or repair shop change the engine oil.

## Safety information

### NOTICE

An engine oil level that is too low causes engine damage. There is a risk of damage to property, among other potential damage. Immediately add engine oil.

### NOTICE

Too much engine oil can damage the engine or the catalytic converter. There is a risk of damage to property, among other potential damage. Do not add too much engine oil. When too much engine oil is added, have the engine oil level corrected by a dealer's service center or another qualified service center or repair shop.

### NOTICE

Engine oil that is not changed in timely fashion can cause increased engine wear and thus engine damage. There is a risk of damage to property. It is recommended that you do not exceed the service intervals indicated in the vehicle.

## Electronic oil measurement

### General information

The electronic oil measurement has two measuring principles:

- Monitoring.
- Detailed measurement.

When making frequent short-distance trips or using a dynamic driving style, for instance when cornering aggressively, regularly perform a detailed measurement.

## Monitoring

### Principle

The engine oil level is monitored electronically while driving and can be shown on the Control Display.



If the engine oil level is outside its permissible operating range, a Check Control message is displayed.

### Functional requirements

A current measured value is available after approx. 30 minutes of normal driving.

### Displaying the engine oil level

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle status"
3.  "Engine oil level"

The engine oil level is displayed.

### System limits

When making frequent short-distance trips or using a dynamic driving style, it may not be possible to calculate a measured value. In this case, the measured value for the last, sufficiently long trip is displayed.

## Detailed measurement

### Principle

The engine oil level is checked when the vehicle is stationary and displayed via a scale.

If the engine oil level is outside its permissible operating range, a Check Control message is displayed.

## General information



During the measurement, the idle speed is increased somewhat.

### Functional requirements

- Vehicle is parked in a horizontal position.
- Manual transmission: gearshift lever in idle position, clutch and accelerator pedals not depressed.
- Steptronic transmission: selector lever in selector lever position N or P and accelerator pedal not depressed.
- Engine is running and is at operating temperature.

### Performing a detailed measurement

Via the Central Information Display (CID):

1.  "My MINI"
2. "Vehicle status"
3.  "Engine oil level"
4. "Measure engine oil level"
5. "Start measurement"

The engine oil level is checked and displayed via a scale.

## Adding engine oil

### General information

Only add engine oil when the message is displayed in the instrument cluster. The top-up quantity is indicated in the message displayed in the instrument cluster.

Only add suitable types of engine oil, refer to page 287.

Safely park the vehicle and switch off the ignition before adding engine oil.

Take care not to add too much engine oil.

## Safety information

### Warning

Operating materials, for instance oils, greases, coolants, fuels, can contain harmful ingredients. There is a risk of injury or danger to life. Follow the instructions on the containers. Avoid the contact of articles of clothing, skin or eyes with operating materials. Do not refill operating materials into different bottles. Store operating materials out of reach of children.

### NOTICE

An engine oil level that is too low causes engine damage. There is a risk of damage to property, among other potential damage. Immediately add engine oil.

### NOTICE


Too much engine oil can damage the engine or the catalytic converter. There is a risk of damage to property, among other potential damage. Do not add too much engine oil. When too much engine oil is added, have the engine oil level corrected by a dealer's service center or another qualified service center or repair shop.

## Overview

The oil filler neck is located in the engine compartment, refer to page 281.

## Adding engine oil

1. Open the hood, refer to page 282.
2. Open the lid counterclockwise.



3. Add engine oil.
4. Close the lid.

## Engine oil types to add

### General information

The engine oil grade is critical for the service life of the engine.

Only add with the types of engine oil which are listed.

### Safety information

#### NOTICE

Oil additives can damage the engine. There is a risk of damage to property, among other potential damage. Do not use oil additives.

#### NOTICE

Incorrect engine oil can cause malfunctions in the engine or damage it. There is a risk of damage to property, among other potential damage. When selecting an engine oil, make sure that the engine oil has the correct oil specification.

## Suitable engine oil types

Up to 1 US quart/liter of an engine oil with the following oil specification can be topped up:

### Gasoline engine

BMW Longlife-14 FE+.

BMW Longlife-17 FE+.

MINI recommends  
**MINI Original Engine Oil.**

## Alternative engine oil types

If an engine oil suitable for continuous use is not available, up to 1 US quart/liter of an engine oil with the following oil rating can be added:

### Oil specification

API SL.

API SM.

API SN.

## Viscosity grades

When selecting an engine oil, make sure that the engine oil has a suitable viscosity grade. The suitable viscosity grade is indicated on a sign in the engine compartment.

### Viscosity grades

SAE 0W-20.

More information about suitable oil specifications and viscosity grades of engine oils can be requested from a dealer's service center or another qualified service center or repair shop.

# Coolant

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems.

When using these functions and systems, the applicable laws and regulations must be observed.

## General information

Coolant consists of water and coolant additive.

Not all commercially available additives are suitable for the vehicle. The vehicle manufacturer recommends using coolant with the BMW LC-18 specification. Do not mix additives of different colors. Observe the water-additive mixture ratio of 50:50. Information about suitable additives is available from a dealer's service center or another qualified service center or repair shop.

## Safety information

### Warning

With the engine hot and the cooling system open, coolant can escape and lead to scalding. There is a risk of injury. Only open the cooling system with the engine cooled down.

### Warning


Additives are harmful and incorrect additives can damage the engine. There is a risk of injury and risk of damage to property. Do not allow additives to come into contact with skin, eyes or articles of clothing. Use suitable additives only.

## Coolant level

### Checking

There are yellow minimum and maximum marks in the coolant reservoir.


1. Let the engine cool down.
2. Open the hood, refer to page [282](#).
3. Turn the lid of the coolant reservoir slightly counterclockwise to allow any excess pressure to dissipate, then open it.



4. Open the coolant reservoir lid.




- The coolant level is correct if it lies between the minimum and maximum marks in the filler neck.



- Close the lid.

## Adding coolant

- Let the engine cool down.
- Open the hood, refer to page [282](#).
- Turn the lid of the coolant reservoir slightly counterclockwise to allow any excess pressure to dissipate, then open it.



- Open the coolant reservoir lid.
- If the coolant is low, slowly add coolant up to the specified fill level; do not overfill.
- Close the lid.
- Have the cause of the coolant loss eliminated as soon as possible.

## Disposal



Comply with the relevant environmental protection regulations when disposing of coolant and coolant additives.

# Maintenance

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## MINI maintenance system

The maintenance system provides service notifications and thereby provides support in maintaining road safety and the operational reliability of the vehicle.

In some cases, scopes and intervals of the maintenance system may vary according to the country version. Replacement work, spare parts, fuels and lubricants, and wear materials are calculated separately. Further information is available from a dealer's service center or another qualified service center or repair shop.

## Condition Based Service

### Principle

Condition Based Service determines the maintenance recommendation using sensors and special algorithms that take into account the operating conditions of the vehicle.

The system makes it possible to adapt the amount of maintenance corresponding to your user profile.

### General information

Information on service notifications, refer to page 141, can be displayed on the Control Display.

### Service data in the vehicle key

Information on the service notifications is continuously stored in the vehicle key. The service center can read this data out and suggest a maintenance scope for the vehicle.

Therefore, hand the service advisor the vehicle key with which the vehicle was driven most recently.

### Stationary periods

Stationary periods during which the vehicle battery was disconnected are not taken into account.

If this occurs, have a dealer's service center or another qualified service center or repair shop update the time-dependent maintenance procedures, such as checking brake fluid and, if necessary, changing the engine oil and the microfilter/activated-charcoal filter.

## Maintenance Booklet for US Models

Please consult your Maintenance Booklet for additional information on the performance of service and maintenance work.

The manufacturer of your vehicle recommends that maintenance and repair be per-

formed by a service center or another qualified service center or repair shop. Records of regular maintenance and repair work should be retained.

## Diagnostic socket

### General information

Devices connected to the diagnostic socket will trigger the alarm system after locking the vehicle. Remove devices connected to the diagnostic socket before locking the vehicle.

### Safety information

#### NOTICE

The socket for Onboard Diagnosis is an intricate component intended to be used in conjunction with specialized equipment to check the vehicle's primary emissions system. Improper use of the socket for Onboard Diagnosis, or contact with the socket for Onboard Diagnosis for other than its intended purpose, can cause vehicle malfunctions and creates risks of personal and property damage. Given the foregoing, the manufacture of your vehicle strongly recommends that access to the socket for Onboard Diagnosis be limited to a dealer's service center or another qualified service center or repair shop or other persons that have the specialized training and equipment for purposes of properly utilizing the socket for Onboard Diagnosis.

### Position



On the driver's side, there is a socket for onboard diagnosis to check components that are relevant for the vehicle's emission mix.

### Emissions




- The warning light lights up:  
Emissions are deteriorating.  
Have the vehicle checked as soon as possible.
- The warning light flashes under certain circumstances:  
This indicates that there is excessive misfiring in the engine.  
Reduce the vehicle speed and have the system checked immediately; otherwise, serious engine misfiring within a brief period can seriously damage emission control components, in particular the catalytic converter.

# Replacing components

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## Onboard vehicle tool kit



The bag containing the onboard vehicle tool kit is located beneath the cargo floor panel.

After use, secure the bag with the onboard vehicle tool kit on a lashing eye again.

## Wiper blades

### Safety information

#### NOTICE

The window may sustain damage if the wiper falls onto it without the wiper blade installed. There is a risk of damage to property, among other potential damage. Hold the wiper firmly when changing the wiper blade. Do not fold in or switch on the wiper without a wiper blade installed.


#### NOTICE

Folded-away wipers can be jammed when the hood is opened. There is a risk of damage to property, among other potential damage. Make sure that the wipers with the wiper blades mounted are folded down onto the windshield before opening the hood.

### Replacing the front wiper blades

1. To change the wiper blades, bring wipers into fold-out position.
2. Fold up and hold the wiper arm firmly.


- Press the button, arrow 1, and swing out the wiper blade, arrow 2.



- Attach a new wiper blade. The wiper blade must engage audibly.
- Fold in the wiper arm.

### Rear wiper blade

- Fold up and hold the wiper arm firmly.
- Pull the wiper blade out of the wiper arm.



- Attach a new wiper blade. The wiper blade must engage audibly.
- Fold in the wiper arm.

## Light and bulb replacement

### General information

#### Lights and bulbs

Lights and bulbs make an essential contribution to driving safety.

Except for the side turn signal lamps, all headlights and lights are designed in LED technology.

The manufacturer of the vehicle recommends that you have appropriate work performed by a dealer's service center or another qualified service center or repair shop if you are unfamiliar with it or if it has not been described here.

A replacement bulb set is available from a dealer's service center or another qualified service center or repair shop.

Follow the safety information, refer to page 293.

### Light-emitting diodes (LEDs)

Some items of equipment use light-emitting diodes installed behind a cover as a light source. These light-emitting diodes are related to conventional lasers and are officially designated as Class 1 light-emitting diodes.

Follow the safety information, refer to page 293.

### Safety information

#### Warning

Intensive brightness can irritate or damage the retina of the eye. There is a risk of injury. Do not look directly into the headlights or other light sources. Do not remove the LED covers.

### Headlight glass

The inside of the headlight glass can fog up in cool or humid weather. When driving with the lights switched on, the condensation evaporates after a short time. The headlight glass does not need to be changed.

If despite driving with the headlights switched on, increasing moisture forms, for


instance water droplets in the light, have the headlights checked.

## Side turn signal lamps, bulb exchange

Follow the general instructions on lights and bulbs, refer to page 293.

Bulb: WY5W.

1. Push the side turn signal forward in the driving direction, arrow 1, and swing it outward, arrow 2.



2.
  - On the left facing the driving direction: turn the bulb holder clockwise and remove.
  - On the right facing the driving direction: turn the bulb holder counter-clockwise and remove.
3. Replace the bulb.
4. Insert the bulb holder.
5. Insert the rear side turn signal, arrow 1, and swing it forward, arrow 2.



## Vehicle battery

### General information

The battery is maintenance-free.

More information about the battery can be requested from a dealer's service center or another qualified service center or repair shop.

### Safety information

#### **⚠ DANGER**

Contact with live components can lead to an electric shock. There is a risk of injury or danger to life. Do not touch any components that are under voltage.

#### **⚠ Warning**

Vehicle batteries that are not compatible can damage vehicle systems and impair vehicle functions. There is a risk of an accident and damage to property. Only vehicle batteries that are compatible with your vehicle type should be installed in your vehicle. Information on compatible vehicle batteries is available at your dealer's service center.

### Register the battery to the vehicle

The manufacturer of the vehicle recommends that you have a dealer's service center or another qualified service center or repair shop register the vehicle battery to the vehicle after the battery has been changed. Once the battery has been registered again, all comfort features will be available without limitation and any Check Control messages displayed which relate to comfort features will disappear.

## Charging the battery

### General information

Make sure that the battery is always sufficiently charged to guarantee that the battery remains usable for its full service life.



A discharged battery is indicated by a red indicator light.

Charge the battery when acceleration is insufficient.

The following circumstances can have a negative effect on the performance of the battery:

- Frequent short-distance drives.
- Stationary periods of more than one month.

### Safety information

#### NOTICE

Battery chargers that charge the vehicle battery via sockets or cigarette lighters in the vehicle may overload or damage the 12 V electrical system. There is a risk of damage to property, among other potential damage. Only connect battery chargers for the vehicle battery to the jump-start terminals in the engine compartment.

### Charging the battery

Charge the battery only when the engine is off and via the jump-start terminals, refer to page 300, in the engine compartment.

### Power interruption

After a power interruption, some equipment needs to be newly initialized or individual settings updated, for example:

- Memory function: store the positions again.
- Time: update.
- Date: update.
- Glass sunroof: initialize the system.

### Disposing of old batteries



Have old batteries disposed of by a dealer's service center or another qualified service center or repair shop or take them to a collection point.

Maintain the filled battery in an upright position for transport and storage. Secure the battery so that it does not tip over during transport.

## Fuses

### Safety information

#### Warning

Incorrect and repaired fuses can overload electrical lines and components. There is a risk of fire. Never attempt to repair a blown fuse. Do not replace a nonworking fuse with a substitute of another color or amperage rating.

## Accessing the fuses

The fuses are located in the glove compartment.

1. Open the glove compartment.
2. Swing the cover down, arrow.



Information on the fuse layout, as well as the positions of any other fuse boxes, is available on the Internet: [www.mini.com/fusecard](http://www.mini.com/fusecard).

Where applicable, information on the fuse layout is also found on a separate sheet in the fuse box.

## Replacing fuses

The vehicle manufacturer recommends that you have a dealer's service center or another qualified service center or repair shop replace the fuses.



# Breakdown Assistance

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## Hazard warning flashers



The button is located above the Control Display.

The red light in the button flashes when the hazard warning flashers are activated.

## Warning triangle



The warning triangle is located in the tailgate. To remove, loosen the brackets.

## First-aid kit

### General information

Depending on the vehicle equipment and country-specific version, the vehicle is equipped with a first-aid kit.

Some of the articles have a limited service life.

Check the expiration dates of the contents regularly and replace any expired items promptly.

### Storage

Storage for the first-aid kit is provided in the cargo area.

## MINI Roadside Assistance

### Principle

MINI Roadside Assistance can be contacted if assistance is needed in the event of a breakdown.

## General information

In the event of a breakdown, data on the vehicle's condition is sent to the vehicle manufacturer.

There are various ways of making contact.

- Via a Check Control message, refer to page 135.
- Calling with a mobile phone.


## Prerequisites

- Active MINI Connected contract or equipment version with intelligent emergency call.
- Cellular network reception.
- The ignition is switched on.

## Starting

If the vehicle is equipped with Teleservices, support is offered through Teleservice Diagnosis.

Via the Central Information Display (CID):

1.  "MINI Connected"
2. "MINI Assist"
3. "MINI Roadside Assistance"

The contact to Roadside Assistance is established.

A telephone number is displayed, if needed. Select to dial the telephone number on a connected mobile phone.

## Teleservice Diagnosis

Teleservice Diagnosis enables the wireless transmission of detailed vehicle data that is important for vehicle diagnosis. This data is transmitted automatically.

## Teleservice Help

Depending on the country, the Teleservice Help enables a more in-depth diagnosis of the vehicle via wireless transmission.

You can launch Teleservice Help by requesting it through the Service Specialist.

1. Park the vehicle in a safe place.
2. Set the parking brake.
3. Control Display is switched on.
4. Confirm Teleservice Help.

The driving ability of the vehicle can be restored for specific functions.

If this is not possible, further measures will be initiated, for instance Mobile Assistance vehicle will be informed.

## Emergency Call

### Intelligent emergency call

#### Principle

In case of an emergency, an emergency call can be triggered automatically by the system or manually.

#### General information

Depending on vehicle equipment and national-market version, the vehicle is equipped with an Assist system.

Only press the SOS button in an emergency.

The Intelligent Assist system establishes a connection with the MINI Response Center.

For technical reasons, the Emergency Call cannot be guaranteed under unfavorable conditions.

## Overview



SOS button in the headliner

### Functional requirements

- The ignition is switched on.
- The Assist system is functional.
- If the vehicle is equipped with intelligent emergency call: the integrated SIM card in the vehicle has been activated.

### Automatic triggering

Under certain conditions, for instance if the airbags deploy, an emergency call is automatically initiated immediately after an accident of corresponding severity. Automatic Collision Notification is not affected by pressing the SOS button.

### Manual triggering

1. Press the cover flap briefly to open it.
  2. Press the SOS button until the LED at the button lights up green.
- The LED is illuminated green when an emergency call has been initiated.  
If the situation allows, wait in your vehicle until the voice connection has been established.
  - The LED flashes green when a connection to the MINI Response Center has been established.

The MINI Response Center then makes contact with you and takes further steps to help you.

Even if you are unable to respond, the MINI Response Center can take further steps to help you under certain circumstances.

For this purpose, data that serves to determine the necessary rescue measures, for instance the current position of the vehicle when it can be determined, is transmitted to the MINI Response Center.

If you can no longer hear the MINI Response Center through the loudspeakers, the hands-free system, for instance, may be broken. However, the MINI Response Center may still be able to hear you.

The MINI Response Center ends the emergency call.

## Jump-starting

### General information

If the battery is discharged, the engine can be started using the battery of another vehicle and two jumper cables. Only use jumper cables with fully insulated clamp handles.

### Safety information

#### DANGER

Contact with live components can lead to an electric shock. There is a risk of injury or danger to life. Do not touch any components that are under voltage.

**⚠ Warning**

If the jumper cables are connected in the incorrect order, spark formation may occur. There is a risk of injury. Pay attention to the correct order during connection.

**⚠ NOTICE**

In the case of body contact between the two vehicles, a short circuit can occur during jump-starting. There is a risk of damage to property, among other potential damage. Make sure that no body contact occurs.

## Preparation

1. Check whether the battery of the other vehicle has a voltage of 12 volts. The voltage information can be found on the battery.
2. Switch off the engine of the assisting vehicle.
3. Switch off any electrical components in both vehicles.

## Jump-start terminals

The jump-start terminal in the engine compartment, refer to page 281, acts as the positive battery terminal.

Open the lid of the jump-start terminal.

A special connection on the body in the engine compartment, refer to page 281, acts as the negative battery terminal.

## Connecting the cables

To prevent personal injury or damage to both vehicles, adhere strictly to the following procedure.

1. Pull off the cover cap of the jump-start terminal.
2. Attach one terminal clamp of the positive jumper cable to the positive battery terminal, or to the corresponding jump-start terminal of the vehicle providing assistance.
3. Attach the terminal clamp on the other end of the cable to the positive battery terminal, or to the corresponding jump-start terminal of the vehicle to be started.
4. Attach one terminal clamp of the negative jumper cable to the negative battery terminal, or to the corresponding engine or body ground of assisting vehicle.
5. Attach the second terminal clamp to the negative battery terminal, or to the corresponding engine or body ground of the vehicle to be started.

## Starting the engine

Never use spray fluids to start the engine.

1. Start the engine of the assisting vehicle and let it run for several minutes at an increased idle speed.
2. Start the engine of the vehicle that is to be started in the usual way.

If the first attempt to start the engine is not successful, wait a few minutes before making another attempt in order to allow the discharged battery to recharge.

3. Let both engines run for several minutes.
4. Disconnect the jumper cables in the reverse order.

Check the battery and recharge, if needed.

## Tow-starting and towing

### Safety information

#### Warning

Due to system limits, individual functions can malfunction during tow-starting/towing with the Intelligent Safety systems activated. There is a risk of accident. Switch all Intelligent Safety systems off prior to tow-starting/towing.

### Steptronic transmission with driven front axle: transporting the vehicle

#### General information

The vehicle must not be towed if the front wheels are touching the ground.

### Safety information

#### NOTICE

The vehicle can be damaged when towing the vehicle with a lifted rear axle. There is a risk of damage to property, among other potential damage. Have vehicle towed only with lifted front axle or on a loading platform.

#### NOTICE

The vehicle can become damaged when lifting and securing it. There is a risk of damage to property, among other potential damage.


- Lift the vehicle using suitable means.
- Do not lift or secure the vehicle by its tow fitting, body parts, or suspension parts.

### Pushing the vehicle

To remove a broken-down vehicle from the hazardous area, it can be pushed for a short distance.

For rolling or pushing the vehicle, refer to page 126.

### Tow truck



Your vehicle should be transported with a tow truck with a so-called spectacle lift or on a loading platform.

### Steptronic transmission with ALL4: transporting the vehicle

#### General information

The vehicle is not permitted to be towed.

### Pushing the vehicle

To remove a broken-down vehicle from the hazardous area, it can be pushed for a short distance.

For rolling or pushing the vehicle, refer to page 126.


## Tow truck

### ⚠ NOTICE

The vehicle can become damaged when lifting and securing it.

There is a risk of damage to property, among other potential damage.

- Lift the vehicle using suitable means.
- Do not lift or secure the vehicle by its tow fitting, body parts, or suspension parts.



The vehicle should only be transported on a loading platform.

## Manual transmission

### Towing or pushing the vehicle

A broken-down vehicle can be towed or pushed.

For rolling or pushing the vehicle, refer to page 123.

### ⚠ NOTICE


If manual unlocking of the parking brake is not possible, the vehicle cannot be moved or towed. There is a risk of damage to property, among other potential damage. The vehicle should only be transported on a loading platform.

Follow the following instructions:

- Make sure that the ignition is switched on; otherwise, the low beams, tail lights, turn signals, and wipers may be unavailable.
- Do not tow the vehicle with the rear axle tilted, as the front wheels could turn.
- When the engine is stopped, there is no power assistance. Consequently, more effort needs to be applied when braking and steering.
- Larger steering wheel movements are required.
- The towing vehicle must not be lighter than the vehicle being towed; otherwise, it will not be possible to control handling.
- Do not exceed a towing speed of 30 mph/50 km/h.
- Do not exceed a towing distance of 30 miles/50 km.

## Tow truck

### With driven front axle




Your vehicle should be transported with a tow truck with a so-called spectacle lift or on a loading platform.

## With ALL4

### NOTICE

The vehicle can be damaged when towing the vehicle with a single lifted axle. There is a risk of damage to property, among other potential damage. The vehicle should only be transported on a loading platform.



Have your vehicle transported on a loading platform only

## Towing other vehicles

### General information

Switch on the hazard warning system, depending on local regulations.

If the electrical system has failed, clearly identify the vehicle being towed by placing a sign or a warning triangle in the rear window.

### Safety information

#### Warning

If the approved gross vehicle weight of the towing vehicle is lighter than the vehicle to be towed, the tow fitting can tear off or it will not be possible to control handling. There is a risk of accident. Make sure that the gross vehicle weight of the towing vehicle is heavier than the vehicle to be towed.

#### NOTICE

If the tow bar or tow rope is attached incorrectly, damage to other vehicle parts can occur. There is a risk of damage to property, among other potential damage. Correctly attach the tow bar or tow rope to the tow fitting.

### Tow bar

The tow fittings used should be on the same side on both vehicles.

If it is impossible to avoid mounting the tow bar at an inclination, note the following:

- Free movement is limited when cornering.
- The tow bar will generate lateral forces if it is secured with an inclination.


### Tow rope

Observe the following notes when using the tow rope:

- Use nylon ropes or straps, which will enable the vehicle to be towed without jerking.
- Make sure the tow rope is not twisted when fastening.
- Check the attachment of the tow fitting and tow rope in regular intervals.
- Do not exceed a towing speed of 30 mph/50 km/h.
- Do not exceed a towing distance of 3 miles/5 km.
- When driving off to tow the vehicle, make sure that the tow rope is taut.

## Tow fitting

### General information



The screw-in tow fitting should always be carried in the vehicle.

The tow fitting can be screwed in at the front or rear of the vehicle.

The tow fitting and the onboard vehicle tool kit, refer to page 292, are together in the cargo area.

Use of the tow fitting:

- Use only the tow fitting provided with the vehicle and screw it in to the stop.
- Use the tow fitting for towing on paved roads only.
- Avoid lateral loading of the tow fitting, for instance do not lift the vehicle by the tow fitting.
- Check the attachment of the tow fitting in regular intervals.

### Safety information

#### NOTICE

If the tow fitting is not used as intended, there may be damage to the vehicle or to the tow fitting. There is a risk of damage to property, among other potential damage. Follow the notes on using the tow fitting.

## Screw thread for tow fitting



Threaded holes for the tow fitting are located in the front and rear of the vehicle on the right side with respect to the driving direction.

Press on the mark on the edge of the cover to push it out.

## Tow-starting

### Steptronic transmission

Do not tow-start the vehicle.

Tow-starting the engine is not possible due to the Steptronic transmission.

Have the cause of the starting difficulties corrected by a dealer's service center or another qualified service center or repair shop.

### Manual transmission

If possible, do not tow-start the vehicle but start the engine by jump-starting, refer to page 299. If the vehicle is equipped with a catalytic converter, only tow-start while the engine is cold.

1. Switch on the hazard warning system and comply with local regulations.
2. Switch on the ignition, refer to page 105.
3. Engage third gear.
4. Have the vehicle tow-started with the clutch pedal pressed and slowly release



the pedal. After the engine starts, immediately press on the clutch pedal again.

5. Stop at a suitable location, remove the tow bar or tow rope, and switch off the hazard warning system.
6. Have the vehicle checked by a dealer's service center or another qualified service center or repair shop.

# Vehicle Care

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## Washing the vehicle

### General information

Regularly remove foreign bodies such as leaves in the area below the windshield when the hood is raised.

Wash your vehicle frequently, particularly in winter. Intense contamination and road salt can damage the vehicle.

### Safety information

#### NOTICE

When washing with an open fuel filler flap, damage may occur. There is a risk of damage to property, among other potential damage. Close the fuel filler flap before washing. Clean dirt behind the fuel filler flap with a cloth.

## Steam cleaners or high pressure cleaners

### Safety information

#### NOTICE

When cleaning with high pressure cleaners, components can be damaged due to the pressure or temperatures being too high. There is a risk of damage to property, among other potential damage. Maintain sufficient distance and do not spray too long continuously. Follow the operating instructions for the high pressure cleaners.

### Distances and temperature

- Maximum temperature: 140 °F/60 °C.
- Minimum distance from sensors, cameras, seals and lights: 12 inches/30 cm.
- Minimum distance from glass sunroof: 31.5 in/80 cm.

## Automatic car washes or car washes

### Safety information

#### NOTICE

Improper use of automatic car washes can cause damage to the vehicle. There is a risk of damage to property, among other potential damage. Follow the following instructions:

- Give preference to cloth car washes or those that use soft brushes in order to avoid paint damage.
- Do not drive through a car wash with guide rails higher than 4 in/10 cm to avoid damage to the body.
- Observe the tire width of the guide rail to avoid damage to tires and rims.
- Fold in exterior mirrors to avoid damage to the exterior mirrors.
- With rod antenna: unscrew the rod antenna to avoid rod antenna breakage.
- Deactivate the wiper and, if necessary, rain sensor to avoid damage to the window wiper system.

### Driving into a car wash with a manual transmission

In car washes, the vehicle must be able to roll freely.

Rolling or pushing the vehicle, refer to page [123](#).

### Driving into a car wash with a Steptronic transmission

In car washes, the vehicle must be able to roll freely.

Rolling or pushing the vehicle, refer to page [126](#).

Some car washes do not permit persons in the vehicle. The vehicle cannot be locked from the outside when in selector lever position N. A signal is sounded when an attempt is made to lock the vehicle.

### Driving out of a car wash

Ensure that the vehicle key is in the car.

Start the engine, refer to page [106](#).

## Lights

Do not rub wet lights dry and do not use abrasive or acidic cleaning agents or cleaning agents containing alcohol.

Soak areas that have been dirtied, for instance from insects, with auto shampoo and wash off with water.

Thaw ice with de-icing spray; do not use an ice scraper.

## After washing the vehicle

After washing the vehicle, apply the brakes briefly to dry them; otherwise, braking effect can be reduced. The heat generated during braking dries brake disks and brake pads and protects them against corrosion.

Completely remove all residues on the windows, to minimize loss of visibility due to smearing and to reduce wiper noises and wiper blade wear.

## Vehicle care

### Vehicle care products

#### General information

MINI recommends using vehicle care and cleaning agents from MINI. Suitable vehicle care products are available from a dealer's service center or another qualified service center or repair shop.

#### Safety information

##### Warning

Cleaning agents can contain substances that are dangerous and harmful to your health. There is a risk of injury. When cleaning the interior, open the doors or windows. Only use products intended for

cleaning vehicles. Follow the instructions on the packaging.

## Vehicle paintwork

### General information

Regular vehicle care contributes to driving safety and value retention. Environmental influences in areas with elevated air pollution or natural contaminants, such as tree resin or pollen can affect the vehicle paintwork. Tailor the frequency and extent of your vehicle care to these influences.

Corrosive substances such as spilled fuel, oil, grease or bird droppings, must be removed immediately to prevent the finish from being altered or discolored.

### Matte paintwork

Only use cleaning and care products suitable for vehicles with matte paintwork.

### Leather care

Remove dust from the leather regularly, using a cloth or vacuum cleaner.

Otherwise, particles of dust and road grime chafe in pores and folds, and lead to heavy abrasion and premature degradation of the leather surface.

To guard against discoloration, such as from clothing, clean leather and provide leather care roughly every two months.

Clean light-colored leather more frequently because contamination on such surfaces is substantially more visible.

Use leather care products; otherwise, dirt and grease will gradually break down the protective coating of the leather surface.

### Synthetic leather care

Clean synthetic leather regularly with a damp microfiber cloth or vacuum cleaner.

Otherwise, dust and road grime particles will rub into pores and folds, causing significant abrasion and premature degradation of the surface.

In case of major soiling, use a moist soft sponge or microfiber cloth with suitable interior cleaners.

Immediately remove aggressive substances such as sunscreen to prevent the synthetic leather from being altered or discolored.

## Upholstery material care

### General information

Vacuum the cushions regularly with a vacuum cleaner.

If upholstery is very contaminated, for instance with beverage stains, use a soft sponge or microfiber cloth with a suitable interior cleaner.

Clean the cushions down to the seams using large sweeping motions. Avoid rubbing the material vigorously.

### Safety information

#### NOTICE

Open hook and loop fasteners on articles of clothing can damage the seat covers and other cloth upholstery in the vehicle. There is a risk of damage to property, among other potential damage. Ensure that any Velcro® fasteners are closed.

## Caring for special components

### Light-alloy wheels

When cleaning the vehicle, use only neutral rim cleaners having a pH value from 5 to 9. Do not use abrasive cleaning agents or steam cleaners above 140 °F/60 °C. Follow the manufacturer's instructions.

Aggressive, acidic or alkaline cleaning agents can destroy the protective coating of adjacent components, such as the brake disk.

After cleaning, apply the brakes shortly to dry them. The heat generated during braking dries brake disks and brake pads and protects them against corrosion.

### Chrome surfaces

Carefully clean components such as the radiator grille or door handles with plenty of water, if necessary, with auto shampoo added, particularly when they have been exposed to road salt.

### Rubber components

Environmental influences can cause surface contamination of rubber parts and a loss of gloss. Use only water and suitable cleaning agents for cleaning.

Treat especially worn rubber parts with rubber care products at regular intervals. When cleaning rubber seals, do not use any silicon-containing vehicle care products in order to avoid damage or noises.

### Wiper blades

The wiper blades are cleaned by using the washer system.

Avoid cleaning the wiper blades manually, as this may reduce wiper performance.

### Fine wood parts

Clean fine wood facing and fine wood components only with a moist rag. Then dry with a soft cloth.

## Plastic components

### NOTICE

Solvent cleaners that contain alcohol or solvents, such as lacquer thinners, cold cleaning agents, fuel and such, can damage plastic parts. There is a risk of damage to property, among other potential damage. Clean with a microfiber cloth. Dampen the cloth lightly with water, if needed.

Clean with a microfiber cloth.

Dampen the cloth lightly with water, if needed.

Do not soak the headliner.

## Seat belts

### Warning

Chemical solvent cleaners can destroy the seat belt fabric. Missing protective effect of the seat belts. There is a risk of injury or danger to life. Use only a mild soap solution for cleaning the seat belts.

Dirty belt straps impede the reeling action and thus have a negative impact on safety.

Use only a mild soap solution, with the seat belts clipped into their buckles.

Seat belts should only be allowed to retract if they are dry.

## Carpets and floor mats

### Warning

Objects in the driver's footwell can limit the pedal travel or block a depressed pedal. There is a risk of accident. Stow objects in the vehicle such that they are secured and cannot enter into the driver's footwell. Use floor mats that are suitable for the vehicle and can be safely attached to the floor. Do

not use loose floor mats and do not layer several floor mats. Make sure that there is sufficient clearance for the pedals. Ensure that the floor mats are securely fastened again after they were removed, for instance for cleaning.

Floor mats can be removed from the car's interior for cleaning.

If the floor carpets are very contaminated, clean with a microfiber cloth and water or a textile cleaner. To prevent matting of the carpet, rub back and forth in the driving direction only.

### Sensor/camera lenses

To clean sensors and camera lenses, use a cloth moistened with a small amount of glass detergent.

### Displays/Screens/Projection screen

#### NOTICE

Chemical solvent cleaners, moisture or fluids of any kind can damage the surface of displays and screens. There is a risk of damage to property, among other potential damage. Clean with a clean, antistatic microfiber cloth.

#### NOTICE

The surface of displays can be damaged with improper cleaning. There is a risk of damage to property, among other potential damage. Avoid pressure that is too high and do not use any scratching materials.

Use a dry, clean antistatic microfiber cloth.

For stubborn soiling on the projection screen of the Head-up Display, dampen the microfiber cloth with ethyl alcohol. Projection screen, refer to page [150](#).

### Taking the vehicle out of service

When the vehicle is shut down for longer than three months, special measures must be taken. Further information is available from a dealer's service center or another qualified service center or repair shop.



# Technical data

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available

in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## General information

The technical data and specifications in the Owner's Manual are used as guidance values. Vehicle-specific data may deviate from this, for instance due to the optional equipment chosen, national-market version, or country-specific measuring process. De-

tailed values can be found in the approval documents, on signs on the vehicle or can be obtained from a dealer's service center or another qualified service center or repair shop.

## Dimensions

The dimensions can vary depending on the model version, equipment version or country-specific measurement procedure.

The height of the vehicle can also differ, e.g., due to tires and vehicle load.

### MINI Countryman

Width with mirrors	in/mm	78.8/2,001
Width without mirrors	in/mm	71.7/1,822
Height	in/mm	61.3/1,557
Length	in/mm	169.7/4,310
Wheelbase	in/mm	105.1/2,670
Smallest turning radius diam.	ft/m	37.4/11.4



## Weights

MINI Cooper Countryman		
Approved gross vehicle weight	lbs/kg	4,376/1,985
Payload	lbs/kg	820/372
Approved front axle weight	lbs/kg	2,326/1,055
Approved rear axle weight	lbs/kg	2,183/990

MINI Cooper S Countryman		
Approved gross vehicle weight	lbs/kg	4,542/2,060
Payload	lbs/kg	924/419
Approved front axle weight	lbs/kg	2,403/1,090
Approved rear axle weight	lbs/kg	2,260/1,025

MINI Cooper Countryman ALL4		
Approved gross vehicle weight	lbs/kg	4,564/2,070
Payload	lbs/kg	805/365
Approved front axle weight	lbs/kg	2,403/1,090
Approved rear axle weight	lbs/kg	2,293/1,040

MINI Cooper S Countryman ALL4		
Approved gross vehicle weight	lbs/kg	4,696/2,130
Payload	lbs/kg	855/388
Approved front axle weight	lbs/kg	2,469/1,120
Approved rear axle weight	lbs/kg	2,337/1,060

MINI John Cooper Works Countryman ALL4		
Approved gross vehicle weight	lbs/kg	4,696/2,130
Payload	lbs/kg	858/389

**MINI John Cooper Works Countryman ALL4**

Approved front axle weight	lbs/kg	2,502/1,135
Approved rear axle weight	lbs/kg	2,337/1,060

**Filling capacities**

**MINI Countryman**

Fuel tank, approx.	US gal/liters	16.1/61.0
--------------------	---------------	-----------

Observe further information on fuel quality, refer to page [258](#).

# Appendix

Any updates to the Owner's Manual of the vehicle are listed here.

## Updates made after the editorial deadline

The following chapters were updated in the printed version of the Owner's Manual after the editorial deadline for the Integrated Owner's Manual in the vehicle had closed:

- Overview: Central Information Display (CID): operating elements: overview.
- Overview: Central Information Display (CID): operation via touchscreen: general.
- Operation: driving: wiper system: safety instructions.
- Operation: displays: range: display.
- Operation: displays: current consumption: display.
- Operation: displays: Speed Limit Info: safety instructions.
- Operation: safety: Intelligent Safety: safety instructions.
- Operation: safety: Forward Collision Warning with city collision mitigation.
- Operation: safety: Pedestrian Warning with city collision mitigation: safety instructions.
- Operation: driving stability control systems: Dynamic Stability Control: safety instructions.
- Operation: driving comfort: camera-based cruise control: safety instructions.
- Operation: driving comfort: cruise control: safety instructions.

- Operation: driving comfort: Park Distance Control: safety instructions.
- Operation: driving comfort: Automatic Parking Assistant: safety instructions.

In contrast to the description in the Integrated Owner's Manual in the vehicle, the MINI FindMate equipment is not available.

# Everything from A to Z

## Index

### A

ABS, see Antilock Braking System 186  
 Acceleration Assistant, see Launch Control 130  
 Accessories and parts 8  
 ACC, see Cruise Control with Distance Control 191  
 Activated charcoal filter 219  
 Activation times, pre-ventilation 220  
 Active Cruise Control 191  
 Active Guard, see Intelligent Safety 172  
 Adaptive chassis 188  
 Adaptive suspension 188  
 Adding engine oil types 286  
 Additives, engine oil types 286  
 Adjusting menu contents, Central Information Display (CID) 41  
 Adjustments, steering wheel 97  
 Airbags 161  
 Airbags, indicator and warning light 163  
 Air circulation, see Recirculated-air mode 214  
 air conditioning, climate 217  
 Air conditioning system 213  
 Air distribution, manual 214, 219  
 Air drying, see air conditioning 217  
 Air flow, air conditioning system 214  
 Air flow, automatic climate control 218  
 Air outlets, see Ventilation 219  
 Air pressure, tires 260  
 Air vent, see Ventilation 219  
 Alarm activation 79  
 Alarm system 79  
 Alarm triggering 79  
 Alarm, unintentional 81  
 ALL4 188  
 All-season tires, see Winter tires 269  
 All-wheel drive, see ALL4 188  
 Antifreeze, see Washer fluid 121

Antilock Braking System 186  
 Apps, see Owner's Manual for Navigation, Entertainment, Communication 6  
 Aquaplaning 245  
 Arrival time 147  
 Ashtray 227  
 Assistance when driving off, see Drive-off assistant 190  
 Assistance with breakdown 297  
 Audio, see Owner's Manual for Navigation, Entertainment and Communication 6  
 Automatic climate control 216  
 Automatic control, headlight 156  
 Automatic Curb Monitor, exterior mirror 96  
 Automatic deactivation, front-seat passenger airbags 163  
 Automatic dimming, see Automatic High Beam Assistant 157  
 Automatic headlight control 156  
 Automatic High Beam Assistant 157  
 Automatic locking 79  
 Automatic Parking Assistant 207  
 Automatic program, automatic climate control 217  
 Automatic Recirculating Air Control 218  
 Automatic transmission, see Steptronic transmission 123  
 Automatic unlocking 79  
 AUTO program, automatic climate control 217  
 AUTO program, intensity 218  
 Auto Start/Stop function 108  
 Average consumption 146  
 Average speed 146  
 Axle loads, approved 313

**B**

Backrest curvature, see Lumbar support 87, 88  
Backrest, seats 86  
Bad road trips 248  
Battery, disposing of 295  
Battery, vehicle 294  
Being towed, see Tow-starting and towing 301  
Belts, see Seat belts 90  
Beverage holder, see Cup holders 234  
Blocking, power window, see Safety switch 83  
Blower 214, 218  
Bluetooth connection 52  
Bonus range, GREEN Mode 252  
Bottle holder, see Cup holders 234  
Brake assistant 186  
Brake disks, breaking in 244  
Brake disks, see Brake system 244  
Brake pads, breaking in 244  
Brake pads, see Brake system 244  
Brake system 244  
Braking, information 246  
Breakdown assistance 297  
Breaking in 244  
Brightness, Control Display 49  
Bulb replacement 293  
Bulb replacement, side 294  
Bulbs and lights 293  
Buttons on the steering wheel 32  
Button, SOS, see Intelligent emergency call 298  
Button, Start/Stop 105  
Bypassing, see Jump-starting 299

**C**

Calendar day, see Date 47  
California Proposition 65 Warning 8  
Calling up mirror adjustment 79  
Camera-based assistance systems, see Intelligent Safety 172  
Camera lenses, care 310

Camera, rearview camera 204  
Can holder, see Cup holders 234  
Care 306  
Care, displays, screens 310  
Care, light-alloy wheels 308  
Care, vehicle 307  
Cargo 236  
Cargo area 236  
Cargo area, adapting size 240  
Cargo area, enlarging 238  
Cargo area lid 72  
Cargo area, seating surface 242  
Cargo area, storage compartments 238  
Cargo cover 237  
Cargo position, rear seat backrest 238  
Cargo, stowing and securing 236  
Cargo straps 237  
Car key, see Vehicle key 62  
Carpet, care 309  
Car wash 306  
Car wash, automatic 306  
Catalytic converter, see Hot exhaust gas system 245  
CBS, see Condition Based Service 290  
Cell phone, see Owner's Manual for Navigation, Entertainment and Communication 6  
Center armrest 234  
Center console 34  
Central Information Display (CID) 36  
Central Information Display (CID), see Control Display 38  
Central instrument cluster, LED ring 149  
Central locking system, unlocking, from inside 67  
Central screen, see Control Display 38  
Changes, technical, see For Your Own Safety 8  
Change, wheels and tires 267  
Changing parts 292  
Changing wheels 275  
Charging cradle 229  
Charging smartphone, see Wireless charging tray 229  
Charging tray for smartphones, see Wireless charging tray 229

- Chassis number, see Vehicle identification number 13
- Check Control 135
- Checking the engine oil level electronically 284
- Children, seating position 99
- Children, transporting safely 99
- Child restraint seats 99
- Child restraint system 99
- Child restraint systems, mounting 100
- Child safety latch 104
- Child safety locks 104
- Child seat installation 100
- Child seat, mounting 100
- Child seat mountings LATCH 102
- Child seats 99
- Chrome parts, care 309
- Cigarette lighter 227
- City light braking function 177
- Cleaning, displays, screens 310
- Clearance, water 246
- Climate control 213, 216
- Clothes hooks 235
- Coasting 253
- Coasting with idling engine 253
- Coat hooks 235
- Combination switch, see Turn signals 113
- Combination switch, see Washer/wiper system 113, 117
- Comfort Access 68
- Compartments in the doors 234
- Compass 225
- Compatible devices, see Suitable devices 52
- Compatible mobile phones 52
- Computer, see Trip computer 145
- Condensation under the vehicle 247
- Condensation, windows 215, 219
- Condition Based Service 290
- Confirmation signal from the vehicle 79
- Connection, electrical devices, see Sockets 227
- Connections 51
- Consumption display, average consumption 146
- Consumption, see Current consumption 141
- Contactless trunk closing 70
- Contactless trunk opening 70
- Contacts, see Owner's Manual for Navigation, Entertainment, Communication 6
- Continued driving with a flat tire, see Tire Pressure Monitor 165
- Continued driving with flat tire, see Flat tire monitor 170
- Control Display 38
- Control Display, brightness 49
- Controller 39
- Control systems, driving stability 186
- Convenient closing, vehicle key 64
- Convenient opening, vehicle key 63
- Cooling, maximum 217
- Cornering light 157
- Corrosion, brake disks 247
- Cosmetic mirror 227
- Country timer 153
- Coupling, see Pairing 51
- Courtesy lights during unlocking 63
- Courtesy lights, locked vehicle 64
- Cruise Control, see Cruise Control with Distance Control 191
- Cruise Control with Distance Control 191
- Cruise Control without Distance Control 198
- Cruising range 141
- Cup holder 234
- Current consumption 141
- Customer service, see Owner's Manual for Navigation, Entertainment, Communication 6
- Customer Support 6
- ## D
- Damage, tires 266
- Dashboard 32
- Dashboard, see Instrument cluster 132
- Data memory 10
- Data protection, settings 50
- Data, see Personal data, deleting 50
- Data, technical 312

- Date 47
  - Date, display 141
  - Daytime driving lights 157
  - Daytime running lights 157
  - DCC, see Cruise Control without Distance Control 198
  - Defrosting, see Windows, defrosting 215, 219
  - Defrosting, windows 215, 219
  - Deleting, personal data 50
  - Departure schedule, see Pre-ventilation 220
  - Destination distance 147
  - Destination input 6
  - Device, connecting 51
  - Device list 51
  - Device, registering 51
  - Devices, suitable 52
  - Diagnostic connection 291
  - Diagnostic socket 291
  - Digital clock 140
  - Digital compass 225
  - Dimensions 312
  - Dimmable exterior mirrors 96
  - Dimmable interior mirror 97
  - Direction indicator, see Turn signals 113
  - Display, date 141
  - Display, electronic, instrument cluster 134, 135
  - Display, engine temperature 146
  - Display, GREEN Mode 250
  - Display, iDrive 36
  - Display in instrument cluster 147
  - Display in the windshield, see Head-up Display 150
  - Display lighting, see Instrument lighting 159
  - Display panel, see Instrument cluster 132
  - Displays 132
  - Display, speed limiting function, see Speed Limit Info 143
  - Disposal, coolant 289
  - Disposal, vehicle battery 295
  - Distance control, see Cruise Control 191
  - Distance to destination 147
  - Distance warning, see Park Distance Control 201
  - Divided screen view, split screen 38
  - Drive-off assistant 190
  - Drive-off assistant, see Dynamic Stability Control 186
  - Driver assistance, see Intelligent Safety 172
  - Driver profiles 75
  - Driver profiles, exporting profiles 77
  - Driver profiles, importing profiles 77
  - Driving Dynamics Control, see MINI Driving Modes switch 188
  - Driving Excitement 148
  - Driving mode, GREEN 250
  - Driving mode, GREEN Driving style analysis 255
  - Driving modes 188
  - Driving notes, breaking in 244
  - Driving notes, general 245
  - Driving notes, things to remember when driving 244
  - Driving on bad roads 248
  - Driving on racetracks 248
  - Driving program, configuring 189
  - Driving stability control systems 186
  - Driving, Start/Stop button 105
  - Driving style analysis 255
  - Driving through water 246
  - Driving tip, GREEN tip 252
  - Driving tips, see General driving notes 245
  - DSC, see Dynamic Stability Control 186
  - DTC, see Dynamic Traction Control 187
  - DVD, video, see Owner's Manual for Navigation, Entertainment, Communication 6
  - Dynamic damping, see Adaptive chassis 188
  - Dynamic Stability Control 186
  - Dynamic Traction Control 187
- ## E
- Easy Opener 70
  - Electronic displays, instrument cluster 134, 135

Electronic oil measurement 284  
 Electronic Stability Program ESP, see Dynamic Stability Control 186  
 E-mail, see Owner's Manual for Navigation, Entertainment, Communication 6  
 Emergency braking, see PostCrash – iBrake 184  
 Emergency call 298  
 Emergency service, see MINI Roadside Assistance 297  
 Emergency unlocking, fuel filler flap 257  
 Emergency unlocking, transmission lock 129  
 Emergency wheel, compact wheel, see Emergency wheel 279  
 Energy control 141  
 Engine, automatic Start/Stop function 108  
 Engine compartment 281  
 Engine coolant 288  
 Engine idling when driving, see Coasting 253  
 Engine oil 284  
 Engine oil filler neck 285  
 Engine oil, topping up 285  
 Engine oil types to add 286  
 Engine start, see Jump-starting 299  
 Engine start, see Starting the engine 106  
 Engine stop 107  
 Engine temperature, display 146  
 Entering a destination, see Owner's Manual for Navigation, Entertainment, Communication 6  
 Entering an address, navigation, see Owner's Manual for Navigation, Entertainment and Communication 6  
 Entertainment, see Owner's Manual for Navigation, Entertainment and Communication 6  
 Equipment, interior 222  
 ESP Electronic Stability Program, see Dynamic Stability Control 186  
 Exchange, wheels and tires 267  
 Exhaust gas system 245  
 Exhaust, see Exhaust gas system 245  
 Exterior mirror 95

Exterior mirror, Automatic Curb Monitor 96  
 Exterior mirror, automatic dimming 96  
 Exterior mirrors, malfunction 96  
 External start, see Jump-starting 299  
 External temperature display 140  
 External temperature warning 140  
 Eyes for securing cargo 237

## F

Failure message, see Check Control 135  
 Fan, see Air flow 214, 218  
 Fastening seat belts, see Seat belts 90  
 Fatigue Alert 183  
 Fatigue warner, see Fatigue Alert 183  
 Fault indications, see Check Control 135  
 Filler neck for engine oil 285  
 Filter, see Microfilter 215  
 Fine wood, care 309  
 Fine wood parts, care 309  
 First-aid kit 297  
 Fish, MINIMALISM display 255  
 Flat tire, changing wheels 275  
 Flat tire, continued driving, see Flat tire monitor 170  
 Flat tire, continued driving, see Tire Pressure Monitor 165  
 Flat tire message, see Flat tire monitor 170  
 Flat tire message, see Tire Pressure Monitor 166  
 Flat tire monitor 170  
 Flat tire, repairing 270  
 Flat tire, see Flat tire monitor 170  
 Flat tire, see Tire Pressure Monitor 165  
 Flat tire warning light, see Flat tire monitor 170  
 Flat tire warning light, see Tire Pressure Monitor 166  
 Flooding, driving through 246  
 Floor carpet, care 309  
 Floor mats, care 309  
 Fold-away position, windshield wipers 116, 120  
 Fold-out position 116, 120



Foot brake 246  
Forward Collision Warning with city collision mitigation 173  
Forward Collision Warning with City light braking function 173  
Forward Collision Warning with collision mitigation 173  
For Your Own Safety 8  
Front airbags 161  
Front fog lights 158  
Front passenger's side exterior mirror, tilting down, see Automatic Curb Monitor 96  
Front passenger airbags, automatic deactivation 163  
Front-seat passenger airbags, indicator light 164  
Front seats 86  
Fuel 258  
Fuel cap 256  
Fuel filler flap 256  
Fuel filler flap, emergency unlocking 257  
Fuel gauge 139  
Fuel quality 258  
Fuel recommendation 258  
Fuel, saving 249  
Fuel tank, see Filling capacity 314  
Fuses 295

## G

Garage door opener, see Integrated Universal Remote Control 222  
Gasoline 258  
Gasoline quality 259  
Gear shift indicator 142  
General driving notes 245  
General settings 47  
Glare shield, see Sun visor 227  
Glass sunroof, initialize the system 85  
Glass sunroof, see Panoramic glass sunroof 84  
Global Positioning System geolocation 48  
Global Positioning System, navigation 6  
Glove compartment 233  
GPS geolocation, vehicle position 48

GPS, navigation, see Owner's Manual for Navigation, Entertainment, Communication 6  
GREEN bonus range 252  
GREEN Mode 250  
GREEN - program, driving dynamics 189  
GREEN tip, driving tip 252  
Gross vehicle weight, approved 313  
Ground clearance 247

## H

Handbrake, electric, see Parking brake, electric 111  
Hand-held transmitter, alternating code 223  
Hands-free device, see Owner's Manual for Navigation, Entertainment, Communication 6  
Hands-free system 6  
Hazard warning system 297  
Head airbag 162  
Headlight control, automatic 156  
Headlight flasher 113  
Headlight glass 293  
Headlights, care 307  
Headlights, turning up, dimming, see Automatic High Beam Assistant 157  
Headliner 35  
Head restraints and seats 86  
Head restraints, front 92  
Head restraints, rear 93  
Head-up Display 150  
Head-up display, position, saving see Memory function 94  
Head-up Display, shift point indicator 153  
Head-up Display, sport displays 152  
Head-up Display, standard view 151  
Heated steering wheel 97  
Heated windshield 215, 219  
Heavy cargo, stowing 236  
Height, vehicle 312  
High beams 113  
Hills 246  
Hill start assistant, see Drive-off assistant 190

Holder for beverages, see Cup holders 234  
 HomeLink, see Integrated Universal Remote Control 222  
 Homepage, see Internet 6  
 Hood 282  
 Horn 32  
 Hot exhaust gas system 245  
 Hour, see Time 47  
 Humidity in the headlight, see Headlight glass 293

## I

iBrake – PostCrash 184  
 Ice warning, see External temperature warning 140  
 Icy roads, see External temperature warning 140  
 Identification marks, tires 264  
 Identification number, see Vehicle identification number 13  
 ID transmitter, see Vehicle key 62  
 Ignition key, see Vehicle key 62  
 Ignition off 105  
 Ignition on 105  
 Illuminated ring, central instrument cluster 149  
 Indicator and warning lights, see Check Control 135  
 Indicator light, front-seat passenger airbags 164  
 Indicator light, see Check Control 135  
 Individual air distribution 214, 219  
 Individual settings, see Driver profiles 75  
 Inductive charging, smartphone, see Wireless charging tray 229  
 Info Display 134  
 Information 6  
 Initialization, see flat tire monitor 170  
 Input, iDrive 36  
 Installation of child restraining systems 100  
 Instrument cluster 132  
 Instrument cluster, electronic displays 134, 135  
 Instrument lighting 159

Instrument panel, see Instrument cluster 132  
 Integrated key 67  
 Integrated Owner's Manual in the vehicle 59  
 Integrated Universal Remote Control 222  
 Intelligent emergency call 298  
 Intelligent Safety 172  
 Intended use 8  
 Intensity, AUTO program 218  
 Interior equipment 222  
 Interior lights 159  
 Interior lights during unlocking 63  
 Interior lights, locked vehicle 64  
 Interior mirror 95  
 Interior mirror, automatic dimming feature 97  
 Interior mirror, compass 225  
 Interior mirror, manually dimmable 96  
 Interior motion sensor 81  
 Intermittent operation 114, 118  
 Interval display, service notifications 141  
 Interval indicator, service notifications 141  
 Interval mode 114, 118  
 In the vicinity of the center console 34  
 In the vicinity of the roofliner 35

## J

Jack 277  
 Jacking points 277  
 Jacking points for the vehicle jack 277  
 Jam protection system, glass sunroof 85  
 Jam protection system, windows 82  
 Jump-starting 299  
 Jump-starting terminals 300  
 Jump-start terminals 300

## K

Keyless Go, see Comfort Access 68  
 Key, see Integrated key 67  
 Key, see Vehicle key 62  
 Kickdown, Steptronic transmission 126

Knee airbag 162

## L

Labeling 264

Label on recommended tires 268

Lane boundary 180

Lane departure warning 180

Lane threshold, warning 180

Language, setting 47

Lashing eyes 237

LATCH child seat mountings 102

Launch Control 130

Leather care 308

LED headlights 293

LED ring, central instrument cluster 149

LEDs, light-emitting diodes 293

Length, vehicle 312

Letters and numbers, entering 37

Light-alloy wheels, care 308

Light-emitting diodes, LEDs 293

Lighter 227

Lighting 155

Light replacement 293

Light replacement, side 294

Lights 155

Lights and bulbs 293

Lights, care 307

Light switch 155

LIM button, see Manual Speed Limiter 182

List, instrument cluster, see Selection lists 144

List, notifications, see Notifications 49

Load 237

Loading 236

Loading position 238

Loading the cargo area, see Stowing cargo 236

Local time, see Time 47

Location, vehicle position 48

Locking, automatic 79

Locking, from inside 67

Locking, settings 78

Low beams, operation 155

Lower back support, see Lumbar support 87, 88

Luggage rack, see Roof-mounted luggage rack 247

Luggage straps 237

Lumbar support 87, 88

## M

Maintenance 290

Maintenance requirement, see Condition Based Service 290

Maintenance, service notifications 141

Maintenance system, MINI 290

Make-up mirror 227

Malfunction displays, see Check Control 135

Malfunction, vehicle key 66

Manual air flow 214

Manual brake, electric, see Parking brake, electric 111

Manual control, air distribution 214, 219

Manual control, air flow 218

Manual mode, transmission 127

Manual operation, PDC Park Distance Control 202

Manual operation, rearview camera 205

Manual Speed Limiter 182

Manual transmission 122

Manufacturer of the MINI 8

Map update, see Owner's Manual for Navigation, Entertainment, Communication 6

Matte paintwork 308

Matt paint, care 308

Maximum cooling 217

Maximum speed, display, see Speed Limit Info 143

Maximum speed, winter tires 269

Mechanical key 67

Media of the Owner's Manual 59

Medical supplies, see First-aid kit 297

Memory function 94

Menus, Central Information Display (CID) 40

Messages, see Check Control 135

Meters, see Instrument cluster 132

Microfilter 215, 219  
 MID - program, driving dynamics 188  
 MINI Connected, see Owner's Manual for Navigation, Entertainment, Communication 6  
 MINI driving modes 188  
 MINI logo projection during unlocking 63  
 MINI maintenance system 290  
 MINIMALISM analyzer 255  
 Minimum tread, tires 266  
 MINI Picnic Bench 242  
 MINI Roadside Assistance 297  
 Mirror position, saving, see Memory function 94  
 Mirrors 95  
 Mobile phone, connecting 51  
 Mobile phone, see Owner's Manual for Navigation, Entertainment and Communication 6  
 Mobile phones, suitable 52  
 Mobile radio in the vehicle 245  
 Mobile Service, see MINI Roadside Assistance 297  
 Mobility System, see Tire repair set 270  
 Modifications, technical, see For Your Own Safety 8  
 Moisture 293  
 Monitor, see Control Display 38  
 Mounting of child restraint systems 100  
 MP3 player, see Owner's Manual for Navigation, Entertainment, Communication 6  
 Multi-function steering wheel 32  
 Multifunction steering wheel, buttons 32  
 Multimedia, see Owner's Manual for Navigation, Entertainment and Communication 6

## N

Navigation, see Owner's Manual for Navigation, Entertainment and Communication 6  
 Neck restraints, front, see Head restraints, front 92  
 Neck restraints, rear, see Head restraints, rear 93

Neutral cleaner, see Light-alloy wheels, care 308  
 Notifications 49  
 No-touch closing of the tailgate 70  
 No-touch opening of the tailgate 70

## O

OBD, see On-board diagnosis 291  
 Obstacle marking, rearview camera 206  
 Octane number, see Gasoline quality 259  
 Odometer 140  
 Oil 284  
 Oil filler neck 285  
 Oil level, checking electronically 284  
 Oil service interval, service notifications 141  
 Oil, topping up 285  
 Oil types to add, engine 286  
 Old battery 295  
 On-board diagnosis 291  
 Onboard literature, printed 59  
 Onboard vehicle tool kit 292  
 On-call service, see MINI Roadside Assistance 297  
 Opening and closing 62  
 Opening, from inside 67  
 Operate tailgate with vehicle key 64  
 Operating concept Central Information Display (CID) operating concept 36  
 Operating menus, Central Information Display (CID) 36  
 Operation via the Controller 40  
 Operation via touchscreen 42  
 Operation via voice 44  
 Optional equipment, see Vehicle equipment 7  
 Outside air, see Automatic Recirculating Air Control 218  
 Outside temperature display 140  
 Overwintering, see Long-term vehicle storage 310  
 Owner's Manual, printed 59

**P**

Paint, vehicle care 308  
Paintwork 308  
Pairing 51  
Panic alarm, see Panic mode 80  
Panic mode 80  
Panoramic glass sunroof 84  
Park Distance Control 201  
Parked vehicle, condensation 247  
Parking assistance, see Park Distance Control 201  
Parking assistant 207  
Parking brake, electric 111  
Parking lights 155  
Parts and accessories 8  
Pathway lighting 156  
Pathway lines, rearview camera 206  
Payload 237  
Payload, technical data 313  
PDC, see Park Distance Control 201  
Pedestrian Collision Warning with City Collision Mitigation 177  
Pedestrian Warning with City Collision Mitigation 177  
Performance Control 188  
Personal data, deleting 50  
Personal profile, see Driver profiles 75  
Physical units, see Units of measurement, setting 48  
Picnic Bench 242  
Plastic, care 309  
Plastic parts, care 309  
PostCrash - iBrake 184  
Power failure 295  
Power interruption 295  
Power windows 82  
Pressure monitor, tire, see Tire Pressure Monitor 165  
Pressure, tires 260  
Pressure warning, see Flat tire monitor 170  
Pressure warning, see Tire Pressure Monitor 165  
Pre-ventilation 220  
Printed onboard literature 59

Profiles, see Driver profiles 75  
Programmable memory buttons, Central Information Display (CID) 43  
Protective function, glass sunroof, see Jam protection system 85  
Protective function, windows, see Jam protection system 82  
Push-and-turn reel, see Controller 39

**R**

Racetrack operation 248  
Radio-ready state 106  
Radio, see Owner's Manual for Navigation, Entertainment and Communication 6  
Rain sensor 114, 118  
Ratchet straps 237  
Rear seat backrests, folding down 238  
Rear seats 89  
Rearview camera 204  
Rear-view mirror, exterior 95  
Rear window defroster 215, 219  
Rear window wiper, operation 116, 119  
Rear wiper 116, 119  
Recirculated-air filter, see Microfilter/activated-charcoal filter 219  
Recirculated-air mode 214  
Recommended tire brands 268  
Refueling 256  
Remote control, see Vehicle key 62  
Remote control, universal 222  
Remote services, app, see Owner's Manual for Navigation, Entertainment, Communication 6  
Renewal, wheels and tires 267  
Replace battery, vehicle key 65  
Replacement, wheels and tires 267  
Replacing parts 292  
Reporting safety malfunctions 14  
RES CNCL button, camera-based cruise control 191  
RES CNCL button, cruise control 198  
Reserve warning, see Range 141  
Resetting, Tire Pressure Monitor 166  
Reset, Tire Pressure Monitor 166  
Retreaded tires 268

Roadside parking lights 156  
 Rolling code hand-held transmitter 223  
 Rolling to a stop with engine decoupled, see Coasting 253  
 RON, see gasoline quality 259  
 Roofliner 35  
 Roof-mounted luggage rack 247  
 Route, navigation, see Owner's Manual for Navigation, Entertainment, Communication 6  
 RTTI, see Owner's Manual for Navigation, Entertainment, Communication 6  
 Rubber components, care 309  
 Runflat tires 269

**S**

Safe braking 246  
 Safety locks, doors, and windows 104  
 Safety switch, windows 83  
 Safety systems, see Airbags 161  
 Screen, see Control Display 38  
 Screwdriver, see Onboard vehicle tool kit 292  
 Sealing compound, see Tire repair set 270  
 Seat belt reminder for driver and front passenger seat, see Seat belts 92  
 Seat belts 90  
 Seat belts, care 309  
 Seat heating, front 89  
 Seating position for children 99  
 Seat position, saving, see Memory function 94  
 Seats and head restraints 86  
 Seat setting, calling up 79  
 Seats, front 86  
 Seats, rear 89  
 Securing, cargo 236  
 Selection list on the instrument cluster 144  
 Sensors, care 310  
 Service and warranty 9  
 Service Center, see MINI Roadside Assistance 297  
 Service notifications, display 141

Service notifications, see Condition Based Service 290  
 Servotronic 190  
 SET button, camera-based cruise control 191  
 SET button, cruise control 198  
 Set clock 47  
 Set day, see Date 47  
 Set time, see Time 47  
 Setting, Control Display 49  
 Settings, general 47  
 Settings, locking/unlocking 78  
 Settings, mirrors 95  
 Settings, seats and head restraints 86  
 Shifting 122  
 Shift lights 153  
 Shift paddles on the steering wheel 128  
 Shift point indicator, Head-up Display 153  
 Side airbag 161  
 Signaling, horn 32  
 Signals when unlocking, see Confirmation signals from the vehicle 79  
 Sitting safely 86  
 Slide/tilt glass roof 84  
 Smallest turning circle, vehicle 312  
 Smartphone, connecting 51  
 Smartphone, see Owner's Manual for Navigation, Entertainment and Communication 6  
 Smartphone, using via voice control 46  
 Sockets, electrical devices 227  
 Software update 57  
 Software, updating 57  
 SOS button, see Intelligent emergency call 298  
 Sound 6  
 Sound output, see Owner's Manual for Navigation, Entertainment, Communication 6  
 Spare tire, see Emergency wheel 279  
 Speech recognition 44  
 Speed Limit Device, see Speed Limiter 182  
 Speed limit, display, see Speed Limit Info 143  
 Speed Limiter 182  
 Speed Limit Info 143

- Speed Limit Info, trip computer 147  
Speed limit, see Speed Limiter 182  
Speed, see Average speed 146  
Speed warning 149  
Split screen 38  
Sport displays, Head-up Display 152  
Sport displays, see Driving Excitement 148  
SPORT program, driving dynamics 189  
Sport program, transmission 126  
Stability control systems 186  
Standard equipment, see Vehicle equipment 7  
Standard view, Head-up Display 151  
Stars, MINIMALISM display 255  
Start/stop, automatic function 108  
Start/Stop button 105  
Starting aid terminals 300  
Starting the engine 106  
Stations, AM/FM, see Owner's Manual for Navigation, Entertainment, Communication 6  
Status control display, tires 165  
Status information, Central Information Display (CID) 37  
Status of Owner's Manual 7  
Status, vehicle 154  
Steering column adjustment 97  
Steering support, see Servotronic 190  
Steering wheel, adjusting 97  
Steering wheel, buttons 32  
Steering wheel heating 97  
Steptronic Sport transmission, see Steptronic transmission 123  
Steptronic Sport transmission with double clutch, see Steptronic transmission 123  
Steptronic transmission 123  
Steptronic transmission with double clutch, see Steptronic transmission 123  
Stopping the engine 107  
Storage compartments 233  
Storage, tires 269  
Storing the vehicle 310  
Stowing, cargo 236  
Suitable devices 52  
Suitable mobile phones 52  
Summer tires, tread 266  
Sun visor 227  
Supplementary Owner's Handbooks 59  
Supplementary Owner's Manuals 59  
Switches, see Dashboard 32  
Switch for driving dynamics 188  
Symbols 6  
System language, setting, see Language, setting 47  
System settings, see General settings 47
- ## T
- Tachometer 140  
Tailgate 72  
Tailgate, closing with no-touch activation 70  
Tailgate, opening with no-touch activation 70  
Taking the vehicle out of service 310  
Tank capacity 314  
Technical changes, see For Your Own Safety 8  
Technical data 312  
Telephone, see Owner's Manual for Navigation, Entertainment and Communication 6  
Teleservices, see Owner's Manual for Navigation, Entertainment, Communication 6  
Temperature, air conditioning system 213  
Temperature, automatic climate control 216  
Temperature display for external temperature 140  
Temperature, engine 146  
Text message, Check Control 135  
Theft alarm system, see Alarm system 79  
Thigh support 89  
Tilt alarm sensor 81  
Tilting down, front passenger's side exterior mirror, see Automatic Curb Monitor 96  
Time 47  
Time of day, see Time 47  
Tire brands, recommended 268  
Tire chains 274  
Tire change 267

Tire damage 266  
 Tire identification marks 264  
 Tire inflation pressure 260  
 Tire marking 264  
 Tire pressure 260  
 Tire Pressure Monitor 165  
 Tire pressure monitoring, see Flat tire monitor 170  
 Tire Pressure Monitor, reset 166  
 Tire Pressure Monitor, resetting 166  
 Tire pressure, tires 260  
 Tire pressure warning, see Flat tire monitor 170  
 Tire repair set 270  
 Tires 260  
 Tire sealant, see Tire repair set 270  
 Tires, run-flat 269  
 Tire tread 266  
 Tone, see Owner's Manual for Navigation, Entertainment and Communication 6  
 Tool 292  
 Touchscreen 42  
 Towing 301  
 Tow-starting 301  
 Traction Control 187  
 Traction control system, see Dynamic Stability Control 186  
 TRACTION, see Dynamic Traction Control 187  
 Traffic bulletins, see Owner's Manual for Navigation, Entertainment, Communication 6  
 Transmission lock, electronic unlocking 129  
 Transmission lock, releasing manually 129  
 Transmission, manual transmission 122  
 Transmission, see Steptronic transmission 123  
 Transporting children safely 99  
 Tread, tires 266  
 Trip computer 145, 147  
 Triple turn signal activation 113  
 Trip odometer 140  
 Trip recorder, see Trip odometer 140  
 Trunk, see Cargo area 236  
 Turning circle lines, rearview camera 206

Turning circle, vehicle 312  
 Turn signal, indicator light 138  
 Turn signal, side 294  
 Turn signals, operation 113

## U

Unintentional alarm, avoiding 81  
 Units of measurement, setting 48  
 Units, see Units of measurement, setting 48  
 Universal remote control 222  
 Unlocking, automatic 79  
 Unlocking, settings 78  
 Unpaved roads, cross-country trips 248  
 Updates made after the editorial deadline 7  
 Updating, software 57  
 Upholstery care 308  
 Upper retaining strap, top tether 103  
 USB connection 54  
 USB port, position in vehicle 228  
 Used battery, disposing of 295  
 Use, intended 8

## V

Vanity mirror 227  
 Vehicle battery 294  
 Vehicle breakdown, see Breakdown assistance 297  
 Vehicle, breaking in 244  
 Vehicle care 307  
 Vehicle care products 307  
 Vehicle equipment 7  
 Vehicle identification number 13  
 Vehicle issues 297  
 Vehicle jack 277  
 Vehicle key 62  
 Vehicle key, additional 65  
 Vehicle key, loss 65  
 Vehicle key, malfunction 66  
 Vehicle key, replace battery 65  
 Vehicle paint, care 308  
 Vehicle paintwork 308



Vehicle position, vehicle location 48  
Vehicle status 154  
Vehicle storage 310  
Vehicle tracking 48  
Ventilation 219  
Ventilation, see Pre-ventilation 220  
Venting, see Ventilation 219  
VIN, see Vehicle identification number 13  
Voice activation system 44  
Voice command response 44  
Voice control 44  
Voice control system 44

## W

Warning and indicator lights, see Check Control 135  
Warning displays, see Check Control 135  
Warning messages, see Check Control 135  
Warning triangle 297  
Warranty 8  
Warranty Booklet, see Warranty 8  
Washer fluid 121  
Washer nozzles, windshield 115, 119  
Washer system 113, 117  
Washing the vehicle 306  
Washing, vehicle 306  
Water on roads 246  
Website 6  
Weights 313  
Welcome lights 156  
Welcome lights during unlocking 63  
Wheelbase 312  
Wheel base, vehicle 312  
Wheel change 275  
Wheels 260  
Wheels and tires, exchange 267  
Width, vehicle 312  
Windows, powered 82  
Windshield defroster 215, 219  
Windshield washer fluid, see Washer fluid 121  
Windshield washer nozzles 115, 119  
Windshield wiper, see Wiper system 113, 117  
Windshield wipers, fold-away position 116, 120  
Winter storage, see Long-term vehicle storage 310  
Winter tires, suitable tires 269  
Winter tires, tread 266  
Wiper blades, changing 292  
Wiper fluid, see Washer fluid 121  
Wiper, see Washer/wiper system 113, 117  
Wiper system 113, 117  
Wireless charging, smartphone, see Wireless charging tray 229  
Wireless charging tray for smartphones 229  
Wood, care 309  
Wordmatch principle 37  
Word match principle, navigation 37  
Working in, engine compartment 282  
Wrench, see Onboard vehicle tool kit 292

---

01405A541E1 ue



# California Proposition 65 Warning

---

For vehicles sold in California:

## California Proposition 65 Warning



### **WARNING**

Operating, servicing and maintaining a passenger vehicle or off-highway motor vehicle can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle in a well-ventilated area and wear gloves or wash your hands frequently when servicing your vehicle. For more information go to [www.P65Warnings.ca.gov/passenger-vehicle](http://www.P65Warnings.ca.gov/passenger-vehicle).

# MINI MOTORER'S GUIDE APP.

## YOUR DIGITAL VEHICLE INFORMATION.

The MINI Motorer's Guide app explains the equipment of your vehicle and offers further scopes and functions:



All information surrounding navigation, entertainment and communication

Photorealistic animations for various vehicle functions

Keyword search

360° view: Explore your vehicle interactively inside and out

Smart Scan for Apple iPhone: Icon and optical character recognition on the buttons in the vehicle

Available in more than 30 languages



Can be used offline after download



01405A541E1 ue