## **OWNER'S MANUAL**

Operation Maintenance Specifications

All information in this Owner's Manual is current at the time of publication. However, HYUNDAI reserves the right to make changes at any time so that our policy of continual product improvement may be carried out.

This manual applies to all HYUNDAI models and includes descriptions and explanations of optional as well as standard equipment. As a result, you may find material in this manual that does not apply to your specific vehicle.

#### **CAUTION: MODIFICATIONS TO YOUR HYUNDAI**

Your HYUNDAI should not be modified in any way. Such modifications may adversely affect the performance, safety or durability of your HYUNDAI and may, in addition, violate conditions of the limited warranties covering the vehicle. Certain modifications may also be in violation of regulations established by the U.S. Department of Transportation and other federal or state agencies.

## TWO-WAY RADIO OR CELLULAR TELEPHONE INSTALLATION

Your vehicle is equipped with a Tire Pressure Monitoring System, Passenger Occupant Classification System and other CAN bus systems. It is possible for an improperly installed/adjusted high powered two-way radio to adversely affect electronic systems. For this reason, we recommend that you carefully follow the radio manufacturer's instructions if you choose to install one of these devices.

#### SAFETY AND VEHICLE DAMAGE WARNING

This manual includes information titled as DANGER, WARNING, CAUTION and NOTICE.

These titles indicate the following:



DANGER indicates a hazardous situation that, if not avoided, will result in death or serious injury.



WARNING indicates a hazardous situation that, if not avoided, could result in death or serious injury.



CAUTION indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

## NOTICE

NOTICE indicates a situation that, if not avoided, could result in vehicle damage.

#### **HYUNDAI VEHICLE OWNER PRIVACY POLICY**

Your Hyundai vehicle may be equipped with technologies and services that use information collected, generated, recorded or stored by the vehicle. Hyundai has created a Vehicle Owner Privacy Policy to explain how these technologies and services collect use and share this information.

You may read our Vehicle Owner Privacy Policy on the Hyundaiusa.com website at: https://www.hyundaiusa.com/owner-privacy-policy.aspx


If you would like to receive a hard copy of our Vehicle Owner Privacy Policy, please contact the Hyundai Customer Care Center at:

Hyundai Customer Care P.O. Box 20850 Fountain Valley, CA 92728 800-633-5151 consumeraffairs@hmausa.com

Hyundai's Customer Care Center representatives are available Monday through Friday,

between the hours of 6:00 AM and 5:00 PM PST and Saturday between 6:30 AM and 3:00 PM PST (English).

For Customer Care assistance in Spanish or Korean, representatives are available Monday through Friday between 6:30 AM and 3:00 PM PST.



## **Table of Contents**

Foreword	1
Vehicle Information, Consumer Information and Reporting Safety Defects	2
Seats & Safety System	3
Instrument Cluster	4
Convenience Features	5
Driving Your Vehicle	6
Driver Assistance System	7
Emergency Situations	8
Maintenance	9
Index	1

# 1. Foreword

Introduction	1-2
HYUNDAI Motor America	1-2
Guide to HYUNDAI Genuine Parts	1-3
How to Use This Manual1	1-4
Safety Messages1	1-4
Fuel Requirements1	
Gasoline containing alcohol or methanol	
Using Fuel Additives (except Detergent Fuel Additives)	
Gasoline containing MMT	
Detergent Fuel Additives	
Operation in foreign countries	1-7
Vehicle Modifications	1-7
Vehicle Break-in Process	1-7
Vehicle Data Collection and Event Data Recorders 1	1-8

#### INTRODUCTION

Congratulations, and thank you for choosing HYUNDAI. We are pleased to welcome you to the growing number of discerning people who drive HYUNDAIs. We are very proud of the advanced engineering and high-quality construction of each HYUNDAI we build.

Your Owner's Manual will introduce you to the features and operation of your new HYUNDAI. To become familiar with your new HYUNDAI, so that you can fully enjoy it, read this Owner's Manual carefully before driving your new vehicle.

This manual contains important safety information and instructions intended to familiarize you with your vehicle's controls and safety features so you can safely operate your vehicle.

This manual also contains information on maintenance designed to enhance safe operation of the vehicle. It is recommended that all service and maintenance on your car be performed by an authorized HYUNDAI dealer. HYUNDAI dealers are prepared to provide high-quality service, maintenance and any other assistance that may be required.

This Owner's Manual should be considered a permanent part of your vehicle, and should be kept in the vehicle so you can refer to it at any time. The manual should stay with the vehicle if you sell it to provide the next owner with important operating, safety and maintenance information.

### HYUNDAI MOTOR AMERICA



## **CAUTION**

Severe engine and transmission damage may result from the use of poor quality fuels and lubricants that do not meet HYUNDAI specifications. You must always use high quality fuels and lubricants that meet the specifications listed on Page 2-12 in the Vehicle Specifications section of the Owner's Manual.

Copyright 2025 HYUNDAI Motor America. All rights reserved. No part of this publication may be reproduced, stored in any retrieval system or transmitted in any form or by any means without the prior written permission of HYUNDAI Motor America

### **GUIDE TO HYUNDAI GENUINE PARTS**

#### 1. What are HYUNDAI Genuine Parts?

HYUNDAI Genuine Parts are the same parts used by HYUNDAI Motor Company to manufacture vehicles. They are designed and tested for the optimum safety, performance, and reliability for our customers.



Genuine Parts



### 2. Why Hyundai Genuine Parts?

HYUNDAI Genuine Parts are engineered and built to meet rigid manufacturing requirements.

Damage caused by using imitation, counterfeit or used salvage parts is not covered under the HYUNDAI New Vehicle Limited Warranty or any other HYUNDAI warranty.

In addition, any damage to or failure of HYUNDAI Genuine Parts caused by the installation or failure of an imitation, counterfeit or used salvage part is not covered by any HYUNDAI Warranty.



## 3. How can you tell if you are purchasing HYUNDAI Genuine Parts?

Look for the HYUNDAI Genuine Parts Logo on the package (see below).

HYUNDAI Genuine Parts exported to the U.S. are packaged with labels written only in English.

HYUNDAI Genuine Parts are only sold through authorized HYUNDAI Dealerships.



### **HOW TO USE THIS MANUAL**

We want to help you get the greatest possible driving pleasure from your vehicle. Your Owner's Manual can assist you in many ways. To gain an overview of the contents of your Owner's Manual, use the Table of Contents in the front of the manual. The first page of each Chapter includes a detailed Table of Contents of the topics in that Chapter.

To quickly locate information about your vehicle, use the Index in the back of the manual. It is an alphabetical list of what is in this manual and the page number where it can be found.

For your convenience, we have incorporated tabs on the right-hand page edges. These tabs are coded with the Chapter titles to assist you with navigating through the manual.

#### **SAFETY MESSAGES**

Your safety, and the safety of others, is very important. This Owner's Manual provides you with many safety precautions and operating procedures. This information alerts you to potential hazards that may hurt you or others, as well as cause damage to your vehicle.

Safety messages found on vehicle labels and in this manual describe these hazards and what to do to avoid or reduce the risks.

Warnings and instructions contained in this manual are for your safety. Failure to follow safety warnings and instructions can lead to serious injury or death. Throughout this manual DANGER, WARNING, CAUTION, NOTICE and the SAFETY ALERT SYMBOL will be used.



This is the safety alert symbol. It is used to alert you to potential physical injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death. The safety alert symbol precedes the signal words DANGER, WARNING and CAUTION.



#### **DANGER**

DANGER indicates a hazardous situation that, if not avoided, will result in death or serious injury.



### **WARNING**

WARNING indicates a hazardous situation that, if not avoided, could result in death or serious injury.



#### CAUTION

CAUTION indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

## NOTICE

NOTICE indicates a situation that, if not avoided, could result in vehicle damage.

### **FUEL REQUIREMENTS**

Your new vehicle is designed to obtain maximum performance with UNLEADED FUEL, as well as minimize exhaust emissions and spark plug fouling.

Your new vehicle is designed to perform optimally using unleaded fuel having an octane number ((R+M)/2) of 87 (Research Octane Number 91) or higher. For improved vehicle performance, premium unleaded fuel with an octane number ((R+M)/2) of 91 (Research Octane Number 95) or higher is recommended. (Do not use methanol blended fuels.)

## **NOTICE**

Using unleaded gasoline that is lower than octane number ((R+M)/2) of 91 (Research Octane Number 95) could result in reduced engine power and increased fuel consumption.



## **CAUTION**

To prevent damage to the engine and engine components, never add any fuel system cleaning agents to the fuel tank other than what has been specified.

Consult an authorized HYUNDAI dealer for additional information.



### WARNING

- Do not "top off" after the nozzle automatically shuts off when refueling.
- Always check that the fuel cap is installed securely to prevent fuel spillage in the event of an accident.

## Gasoline containing alcohol or methanol

Gasohol, a mixture of gasoline and ethanol (also known as grain alcohol) are being marketed along with or instead of leaded or unleaded gasoline. For example, "E15" is a gasohol comprised of 15% ethanol and 85% gasoline.

Do not use gasohol containing more than 15% ethanol, and do not use gasoline or gasohol containing any methanol. Either of these fuels may cause drivability problems and damage to the fuel system, engine control system and emission control system.

Discontinue using gasohol of any kind if drivability problems occur.

"E85" fuel is an alternative fuel comprised of 85 percent ethanol and 15 percent gasoline, and is manufactured exclusively for use in Flexible Fuel Vehicles. "E85" is not compatible with your vehicle. Use of "E85" may result in poor engine performance and damage to your vehicle's engine and fuel system. HYUNDAI recommends that customers do not use fuel with an ethanol content exceeding 15 percent.

## NOTICE

To prevent damage to your vehicle's engine and fuel system:

- Never use gasohol which contains methanol.
- Never use gasohol containing more than 15% ethanol.
- Never use leaded fuel or leaded gasohol.
- · Never use "E85" fuel.

Your New Vehicle Limited Warranty does not cover damage to the fuel system or any performance problems caused by the use of "E85" fuel.

### Using Fuel Additives (except Detergent Fuel Additives)

Using fuel additives such as:

- Silicone fuel additive
- Ferrocene (iron-based) fuel additive
- Other metallic-based fuel additives may result in cylinder misfire, poor acceleration, engine stalling, damage to the catalyst, or abnormal corrosion, and may cause damage to the engine resulting in a reduction in the overall life of the powertrain.
  - The Malfunction Indicator Lamp (MIL) may illuminate.

### NOTICE

Damage to the fuel system or performance problem caused by the use of these fuels or fuel additives may not be covered by your New Vehicle Limited Warranty.

### Gasoline containing MMT

Some gasoline contains harmful manganese-based fuel additives such as MMT (Methylcyclopentadienyl Manganese Tricarbonyl).

HYUNDAI does not recommend the use of gasoline containing MMT.

This type of fuel can reduce vehicle performance and affect your emission control system.

The malfunction indicator lamp on the cluster may come on.

#### **Detergent Fuel Additives**

HYUNDAI recommends that you use good quality gasolines treated with detergent additives such as TOP TIER Detergent Gasoline, which help prevent deposit formation in the engine. These gasolines will help the engine run cleaner and enhance performance of the Emission Control System. For more information on TOP TIER Detergent Gasoline, please go to the website (www. toptiergas.com).

For customers who do not use TOP Tier Detergent Gasoline regularly, and have problems starting or the engine does not run smoothly, detergent-based fuel additives that you can purchase separately may be added to the gasoline. If TOP TIER Detergent Gasoline is not available, one bottle of additive added to the fuel tank according to the maintenance schedule is recommended (refer to the Maintenance Schedule in chapter 9).

Additives are available from your authorized HYUNDAI dealer along with information on how to use them. Do not mix other additives.

## Operation in foreign countries

If you are going to drive your vehicle in another country, be sure to:

- Observe all regulations regarding registration and insurance.
- Determine that acceptable fuel is available.

#### **VEHICLE MODIFICATIONS**

- This vehicle should not be modified. Modification of your vehicle could affect its performance, safety or durability and may even violate governmental safety and emissions regulations.
  - In addition, damage or performance problems resulting from any modification may not be covered under warranty.
- If you use unauthorized electronic devices, it may cause the vehicle to operate abnormally, wire damage, battery discharge and fire. For your safety, do not use unauthorized electronic devices.

# VEHICLE BREAK-IN PROCESS

By following a few simple precautions for the first 600 miles (1,000 km) you may add to the performance, economy and life of your vehicle.

- · Do not race the engine.
- While driving, avoid sudden acceleration.
- Do not maintain a single speed for long periods of time, either fast or slow. Varying engine speed is needed to properly break-in the engine.
- Fuel economy and engine performance may vary depending on vehicle break-in process and be stabilized after 4,000 miles (6,000 km). New engines may consume more oil during the vehicle break-in period.
- Avoid hard stops, except in emergencies, to allow the brakes to seat properly.

## WARNING

#### **CALIFORNIA PROPOSITION 65** WARNING

Items contained in motor vehicles or emitted from them are known to the State of California to cause cancer and birth defects or reproductive harm.

#### These include:

- Gasoline and its vapors
- · Engine exhaust
- · Used engine oil
- Interior passenger compartment components and materials
- · Component parts which are subject to heat and wear

In addition, battery posts, terminals and related accessories contain lead, lead compounds and other chemicals known to the State of California to cause cancer and reproductive harm.

For more information go to https://www.p65warnings.ca.gov/ passenger-vehicle

## VEHICLE DATA COLLECTION AND EVENT DATA **RECORDERS**

This vehicle is equipped with an event data recorder (EDR). The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less. The EDR in this vehicle is designed to record such data as:

- How various systems in your vehicle were operating:
- Whether or not the driver and passenger safety belts were buckled/ fastened:
- · How far (if at all) the driver was depressing the accelerator and/or brake pedal; and.
- How fast the vehicle was traveling.

These data can help provide a better understanding of the circumstances in which crashes and injuries occur. NOTE: EDR data is recorded by your vehicle only if a non-trivial crash situation occurs: no data are recorded by the EDR under normal driving conditions and no personal data (for example, name, gender, age, and crash location) are recorded. However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

To read data recorded by an EDR. special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the FDR.

# 2. Vehicle Information, Consumer Information and Reporting Safety Defects

Exterior Overview (Front View)	2-2
Exterior Overview (Rear View)	2-3
Interior Overview	2-4
Center Console Overview	2-5
Instrument Panel Overview	2-6
Engine Compartment	2-7
Dimensions	2-8
Engine Specification	2-8
Bulb Wattage	2-9
Tires and Wheels	2-10
Air Conditioning System	2-11
Volume and Weight	2-11
Recommended Lubricants and Capacities	2-12 2-13
Vehicle Identification Number (VIN)	
Vehicle Certification Label	
Tire Specification and Pressure Label	2-14
Engine Number	
Air Conditioner Compressor Label	
Air Conditioning Refrigerant Label	
Open Source Software Notice	
Consumer Information	
Reporting Safety Defects	


## **EXTERIOR OVERVIEW (FRONT VIEW)**



OCN	7NIO	120	O1N


1.	Hood	5-53	5.	Sunroof	5-49
2.	Headlight	9-59	6.	Front windshield wiper blades	9-28
3.	Tires and wheels	9-33	7.	Windows	5-44
4	Side view mirror	5-42			

## **EXTERIOR OVERVIEW (REAR VIEW)**



8. Door5-22	12. Defroster / Glass antenna 5-102/ 5-111
9. Fuel filler door5-60	13. High mounted stop light9-61
10. Rear combination lamp9-59	14. Antenna 5-111
11. Trunk 5-55	15. Wide-rear view camera7-61

## **INTERIOR OVERVIEW**




The actual shape may differ from the illustration.

OCN7N013010N

1.	Inside door handle5	-23
2.	Side view mirror control switch5	-43
3.	Central door lock switch5	-24
4.	Power window switches5	-44
5.	Power window lock switch 5	-47
6.	Steering wheel tilt/telescopic lever 5	-30
7.	Steering wheel5	-29

В.	Instrument panel illumination control	
	switch	. 4-5
9.	ESC OFF button	6-33
10.	Fuel filler door opener lever	5-60
11.	Trunk release lever	5-55
12.	Hood release lever	5-53
13.	Seat adjusting lever	. 3-5


## **CENTER CONSOLE OVERVIEW**



1.	Instrument cluster4-4
2.	Driver's front air bag 3-33
3.	Engine Start/Stop button6-5
4.	Infotainment system 4-33
5.	Hazard warning flasher button 8-2
6.	Climate control system 5-75/ 5-86

7.	Passenger's front air bag 3-33
8.	Glove box5-104
9.	Manual transmission/Dual clutch
	transmission 6-12/ 6-18
10.	Drive mode button 6-1
11.	Parking/View button 7-63
12.	Parking Safety button7-77

## **INSTRUMENT PANEL OVERVIEW**




1.	Lighting control lever5-62
2.	Wiper and washer control lever5-73
3.	Voice recognition button5-113
4.	Bluetooth wireless technology hands-free button5-113
5.	Steering wheel audio controls5-112

6.	N1 button6-42
7.	Cluster display control 4-25
8.	Driving Assist button7-38/ 7-53
9.	Lane Driving Assist button7-15/ 7-58
10.	N2 button6-42
11.	Dual Clutch Transmission :
	NGS (N Grin Shift)6-48
	Manual Transmission: Rev Matching 6-15

OCN7N013005N

## **ENGINE COMPARTMENT**

■ Gasoline 2.0 T-GDi



The actual engine compartment in the vehicle may differ from the illustration.

OCN7N093001CN

1.	Engine coolant reservoir9-19	6.	Windshield washer fluid reservoir 9-24
2.	Brake/clutch fluid reservoir 9-23	7.	Fuse box9-48
3.	Air cleaner 9-25	8.	Battery9-31
4.	Engine oil dipstick9-16	9.	Engine coolant cap9-20
5.	Engine oil filler cap9-16		

## **DIMENSIONS**

Ite	ems	in. (mm)
Overall length		185.43 (4,710)
Overall width		71.85 (1,825)
Overall height		55.71 (1,415)
Front tread	245/35 ZR19	62.36 (1,584)
Rear tread 245/35 ZR19		62.17 (1,579)
Wheelbase		107.09 (2,720)

## **ENGINE SPECIFICATION**

Item	2.0 T-GDi
Displacement cu. in. (cc)	121.9 (1,998)
Bore x Stroke in. (mm)	3.39 X 3.39 (86.0 X 86.0)
Firing order	1-3-4-2
No. of cylinders	4, in-line

## **BULB WATTAGE**

	Light bulb		Bulb type	Wattage	
	Headlight	High Low	LED	LED	
Front	Daytime running I Position light	ight (DRL)/	LED	LED	
Front	Side marker		LED	LED	
	Turn signal light		LED	LED	
	Side repeater light (Side view mirror)	t	LED	LED	
	Stop light		LED	LED	
	Tail light		LED	LED	
	Side marker		LED	LED	
Rear	Turn signal light		PY21W	21	
	License plate light	t	W5W	5	
	Reverse light		W16W	16	
	High mounted sto	p light	P21W	21	
	Map lamp		W10W	10	
lusta ui a u	Room lamp		FESTOON	8	
Interior	Vanity mirror lamp	)	FESTOON	5	
	Trunk room lamp		FESTOON	5	

#### TIRES AND WHEELS

					Inflation pressure psi (kPa)						
Items	Trans- mission	Tire size	Wheel size	(less than 100mph or		High-speed driving (over 100mph or 160km/h) *1		driving Track or driving *2		Wheel nut torque Ibf·ft (kgf·m, N·m,)	
				Front	Rear	Front	Rear	Front	Rear		
Full size tire	MT/DCT	245/35 ZR19	8.0Jx19	36 (250)	34 (235)	42 (290)	40 (275)	37 (255)	37 (255)	79-94 (11-13, 107- 127)	

MT : Manual Transmission
DCT : Dual Clutch Transmission

\*1: Must drive only where the speed is legal

\*2: Refers to the recommended inflation pressure for the hot tire condition (state when the tire temperature is increased). Limited number of passengers is 2 with no luggage. After the track driving is complete, change to the appropriate tire inflation recommended for the normal road driving condition.

### NOTICE

- Ambient temperature affects the tire pressure (about 1psi (7kPa)) for every 12°F (7°C) change). If colder temperatures are anticipated, it is permissible to increase cold tire inflation pressure by up to 3psi (20kPa) over the specification. If extreme temperature changes are expected, be sure to check and adjust tire pressure accordingly.
- Tire inflation pressure decreases with higher elevation, and increases with lower elevation (about 2.4psi (10kPa) for every mile (or kilometer) elevation change).
   Be sure to check and adjust tire pressure accordingly when driving through changing elevations.
- Do not exceed the maximum inflation pressure, as found on the sidewall of the tire(s).



### **CAUTION**

When replacing tires, ALWAYS use the same size, type, brand, construction and tread pattern supplied with the vehicle. If not, it can damage the related parts or make it work irregularly.

## **AIR CONDITIONING SYSTEM**

Items	Weight of volume	Classification
Refrigerant oz. (g)	17.6±0.9 (500±25)	R-1234yf
Compressor lubricant oz. (g)	3.4 ± 0.3 (100 ± 10)	PAG (FD46XG)

Contact an authorized HYUNDAI dealer for more details.

## **VOLUME AND WEIGHT**

lanne	2.0 T-GDi				
Items	MT	DCT			
Gross vehicle weight lbs. (kg)	4,167 (1,890)	4,255 (1,930)			
Luggage volume (SAE) cu ft ( $\ell$ )	14.2 (402)				

MT : Manual Transmission DCT : Dual Clutch Transmission

### RECOMMENDED LUBRICANTS AND CAPACITIES

To help achieve proper engine and powertrain performance and durability, use only lubricants of the proper quality. The correct lubricants also help promote engine efficiency that results in improved fuel economy.

These lubricants and fluids are recommended for use in your vehicle.

Lubri	cant	Volume	
Engine oil *1*2 (drain and refill) F	Recommends	5.49 US qt. (5.2 ℓ)	SAE OW-30 API SN PLUS/SP or ILSAC GF-6 *3
Manual transmi	ssion fluid	1.9 ~ 2.0 US qt. (1.8 ~ 1.9 ℓ)	HK SYN MTF 70W (SK) SPIRAX S6 GHME 70W MTF (H.K.SHELL) GS MTF HD 70W (GS CALTEX) (API GL-4, SAE 70W, TGO-9)
Dual clutch	Gear oil	3.4 ~ 3.6 US qt. (3.3 ~ 3.4 l)	GS WDCTF HD G (WET DCT FLUID)
transmission fluid	Control oil	2.58 ~ 2.64 US qt. (2.45 ~ 2.5 l)	GS WDCTF HD H (WET DCT HYDRAULIC CONTROL OIL)
Coolant		7.93 US qt. (7.5 ℓ)	Mixture of antifreeze and water (Phosphate-based Ethylene glycol coolant for aluminum radiator)
Brake/clutch flu	iid *4	0.74 ~ 0.85 US qt. (0.7 ~ 0.8 l)	DOT-4
Fuel		12.42 US gal. (47 ℓ)	Refer to "Fuel requirements" in chapter 1.

<sup>\*1:</sup> Refer to the recommended SAE viscosity numbers on the next page.

<sup>\*2:</sup> Engine oils labeled Energy Conserving Oil are now available. Along with other additional benefits, they contribute to fuel economy by reducing the amount of fuel necessary to overcome engine friction. Often, these improvements are difficult to measure in everyday driving, but in a year's time, they can offer significant cost and energy savings.

<sup>\*3:</sup> Requires < API SN PLUS (or above) Full synthetic> grade engine oil. If a lower grade engine oil (mineral oil including Semi-synthetic) is used, then the engine oil and engine oil filter must be replaced as indicated severe maintenance condition.

<sup>\*4:</sup> For the best performance of braking and ABS/ESC functions, you should use genuine brake fluid that conform to standards. (Standards: SAE J1704 DOT-4 LV, ISO4925 CLASS-6 and FMVSS116 DOT-4)

## **Recommended SAE viscosity number**

## NOTICE

- Always be sure to clean the area around any filler plug, drain plug, or dipstick before checking or draining any lubricant. This is especially important in dusty or sandy areas and when the vehicle is used on unpaved roads. Cleaning the plug and dipstick areas will prevent dirt and grit from entering the engine and other mechanisms that could be damaged.
- Never add any additives to the engine oil. Engine oil additives can change the properties of engine oil and may cause serious engine failure.

Engine oil viscosity (thickness) has an effect on fuel economy and cold weather operating (engine start and engine oil flowability). Lower viscosity engine oils can provide better fuel economy and cold weather performance, however, higher viscosity engine oils are required for satisfactory lubrication in hot weather. Using oils of any viscosity other than those recommended could result in engine damage.

When choosing an oil, consider the range of temperature your vehicle will be operated in before the next oil change.

Proceed to select the recommended oil viscosity from the chart.

Temperature Range for SAE Viscosity Numbers												
Tomonoroturo	°F	-30	-20		-10	0	10	)	20	30	40	50
Temperature	(°C)	-	-10	0	20		40	60		80	100	120
Gasoline 2.0 T-	-GDi *1						0W-30					

\*1: Requires < API SN PLUS (or above) Full synthetic> grade engine oil. If a lower grade engine oil (mineral oil including Semi-synthetic) is used, then the engine oil and engine oil filter must be replaced as indicated severe maintenance condition.



An engine oil displaying this American Petroleum Institute (API) Certification Mark conforms to the International Lubricant Specification Advisory Committee (ILSAC). It is recommended to only use engine oils that uphold this API Certification Mark.

# VEHICLE IDENTIFICATION NUMBER (VIN)



The vehicle identification number (VIN) is the number used in registering your vehicle and in all legal matters pertaining to its ownership, etc.

The VIN is on a plate attached to the top of the dashboard. The number on the plate can easily be seen through the windshield from outside.

# VEHICLE CERTIFICATION LABEL



The vehicle certification label attached on the driver's (or front passenger's) side center pillar gives the vehicle identification number (VIN).

# TIRE SPECIFICATION AND PRESSURE LABEL



The tires supplied on your new vehicle are chosen to provide the best performance for normal driving.

The tire label located on the driver's side center pillar gives the tire pressures recommended for your vehicle.

### **ENGINE NUMBER**



The engine number is stamped on the engine block as shown in the drawing.

# AIR CONDITIONER COMPRESSOR LABEL



A compressor label informs you the type of compressor your vehicle is equipped with such as model, supplier part number, production number, refrigerant (1) and refrigerant oil (2).

# AIR CONDITIONING REFRIGERANT LABEL



The refrigerant label provides information such as refrigerant type and amount. (R-1234yf)

# OPEN SOURCE SOFTWARE NOTICE

This vehicle contains software with open source licenses. Open source software information including the source code, copyright notices and referred license terms may be obtained on the website. https://www.hyundai.com/worldwide/opensource

HYUNDAI Motor Company will provide the open source code to you in storage medium such as CD-ROM for minimum charge covering the cost of performing source distribution upon email request to opensource@hyundai.com within a period of 3 years from the date of product purchase.

#### **CONSUMER INFORMATION**

This consumer information has been prepared in accordance with regulations issued by the National Highway Traffic Safety Administration of the U.S. Department of Transportation. Your HYUNDAI dealer will help answer any questions you may have as you read this information.

HYUNDAI motor vehicles are designed and manufactured to meet or exceed all applicable safety standards.

For your safety, however, we strongly urge you to read and follow all directions in this Owner's Manual, particularly the information under the headings "NOTICE", "CAUTION" and "WARNING".

If, after reading this manual, you have any questions regarding the operation of your vehicle, please contact the Hyundai Customer Care Center.

Hyundai Customer Care P.O. Box 20850 Fountain Valley, CA 92728 800-633-5151 consumeraffairs@hmausa.com

Hyundai's Customer Care Center representatives are available Monday through Friday, between the hours of  $6:00~\mathrm{AM}$  and  $5:00~\mathrm{PM}$  PST

and Saturday between 6:30 AM and 3:00 PM PST (English).

For Customer Care Center assistance in Spanish or Korean, representatives are available Monday through Friday between 6:30 AM and 3:00 PM PST.

### REPORTING SAFETY DEFECTS

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying HYUNDAI MOTOR AMERICA.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153);

go to http://www.safercar.gov;

download the SaferCar mobile application;

or write to: Administrator, NHTSA

1200 New Jersey Ave, SE,

West Building Washington, D.C. 20590.

You can also obtain other information about motor vehicle safety from http://www.safercar.gov.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or HYUNDAI MOTOR AMERICA.

# 3. Seats & Safety System

This chapter provides you with important information about how to protect yourself and your passengers. It explains how to properly use your seats and seat belts, and how your air bags work. Additionally, this chapter explains how to properly restrain infants and children in your vehicle.

Important Safety Precautions	3-2
Always Wear Your Seat Belt	
Restrain All Children	
Air Bag Hazards	
Driver Distraction	
Control Your Speed	
Keep Your Vehicle in Safe Condition	3-2
Seats	3-3
Safety Precautions	
Front Seats	
Rear seats	3-7
Head Restraints	3-9
Seat Warmers	3-11
Seat Belts	3-13
Seat Belt Safety Precautions	
Seat Belt Warning Light	
Seat Belt Restraint System	
Additional Seat Belt Safety Precautions	3-19
Care of Seat Belts	
Child Restraint System (CRS)	3-22
Children Always in the Rear	3-22
Selecting a Child Restraint System (CRS)	
Installing a Child Restraint System (CRS)	
Air Bag - Advanced Supplemental Restraint System	
Where Are the Air Bags?	
How Does the Air Bag System Operate?	
What to Expect After an Air Bag Inflates	
Occupant Classification System (OCS)	
Why Didn't My Air Bag Go Off in a Collision?	
SRS Care	
Additional Safety Precautions	
Air Bag Warning Labels	

#### IMPORTANT SAFETY PRECAUTIONS

You will find many safety precautions and recommendations throughout this section, and throughout this manual. The safety precautions in this section are among the most important.

## **Always Wear Your Seat Belt**

A seat belt is your best protection in all types of accidents. Air bags are designed to supplement seat belts, not replace them. So even though your vehicle is equipped with air bags, ALWAYS make sure you and your passengers wear your seat belts, and wear them properly.

#### **Restrain All Children**

All children under age 13 should ride in your vehicle properly restrained in a rear seat, not the front seat. Infants and small children should be restrained in an appropriate child restraint. Larger children should use a booster seat with the lap/shoulder belt until they can use the seat belt properly without a booster seat.

## **Air Bag Hazards**

While air bags can save lives, they can also cause serious or fatal injuries to occupants who sit too close to them, or who are not properly restrained. Infants, young children, and shorter adults are at the greatest risk of being injured by an inflating air bag. Follow all instructions and warnings in this manual.

#### **Driver Distraction**

Driver distraction presents a serious and potentially deadly danger, especially for inexperienced drivers. Safety should be the first concern when behind the wheel, and drivers need to be aware of the wide array of potential distractions, such as drowsiness, reaching for objects, eating, personal grooming, other passengers, and using cellular phones.

Drivers can become distracted when they take their eyes and attention off the road or their hands off the wheel to focus on activities other than driving. To reduce your risk of distraction or getting into an accident:

- ALWAYS set up your mobile devices (for example, MP3 players, phones, navigation units, etc.) when your vehicle is parked or safely stopped.
- ONLY use your mobile device when allowed by laws and when conditions permit safe use. NEVER text or email while driving. Most states have laws prohibiting drivers from texting. Some states and cities also prohibit drivers from using handheld phones.
- NEVER let the use of a mobile device distract you from driving. You have a responsibility to your passengers and others on the road to always drive safely, with your hands on the wheel as well as your eyes and attention on the road.


## **Control Your Speed**

Excessive speed is a major factor in crash injuries and deaths. Generally, the higher the speed, the greater the risk, but serious injuries can also occur at lower speeds. Never drive faster than is safe for current conditions, regardless of the maximum speed posted.

## **Keep Your Vehicle in Safe Condition**

Having a tire blowout or a mechanical failure can be extremely hazardous. To reduce the possibility of such problems, check your tire pressures and condition frequently, and perform all regularly scheduled maintenance.

## **SEATS**



#### Driver's seat

- (1) Forward and rearward
- (2) Seatback angle
- (3) Seat height

## Front passenger's seat

- (1) Forward and rearward
- (2) Seatback angle

### **Safety Precautions**

Adjusting the seats so that you are sitting in a safe, comfortable position plays an important role in driver and passenger safety together with the seat belts and air bags in an accident.



## **WARNING**

Do not use a cushion that reduces friction between the seat and the passenger. The passenger's hips may slide under the lap portion of the seat belt during an accident or a sudden stop. Serious or fatal internal injuries could result because the seat belt cannot operate properly.

#### Air bags

You can take steps to reduce the risk of being injured by an inflating air bag. Sitting too close to an air bag greatly increases the risk of injury in the event the air bag inflates.

The National Highway Traffic Safety Administration (NHTSA) recommends that drivers allow at least 10 inches (25) cm) between the center of the steering wheel and their chest.



## ! WARNING

To reduce the risk of serious injury or death from an inflating air bag, take the following precautions:

- Adjust the driver's seat as far to the rear as possible while maintaining the ability to maintain full control of the vehicle.
- · Adjust the front passenger seat as far to the rear as possible.
- Hold the steering wheel by the rim with your hands at the 9 o'clock and 3 o'clock positions to minimize the risk of injuries to your hands and arms.

- NEVER place anything or anyone between the steering wheel and the air bag.
- Do not allow the front passenger to place feet or legs on the dashboard to minimize the risk of leg injuries.

#### Seat belts

Always fasten your seat belt before starting any trip.

At all times, passengers should sit upright and be properly restrained. Infants and small children must be restrained in appropriate child restraint systems. Adults and children who have outgrown a booster seat must be restrained using the seat belts.



### WARNING

Take the following precautions when adjusting your seat belt:

- NEVER use one seat belt for more than one occupant.
- Always position the seatback upright with the lap portion of the seat belt snug and low across the hips.
- NEVER allow children or small infants to ride on a passenger's lap.
- · Do not route the seat belt across your neck, across sharp edges, or reroute the shoulder strap away from your body.
- Do not allow the seat belt to become caught or jammed.

#### **Front Seats**



## WARNING

Take the following precautions when adjusting your seat:

- NEVER attempt to adjust the seat while the vehicle is moving. The seat could respond with unexpected movement and may cause loss of vehicle control resulting in an accident.
- Do not place anything under the front seats. Loose objects in the driver's foot area could interfere with the operation of the foot pedals, causing an accident.
- Do not allow anything to interfere with the normal position and proper locking of the seatback.
- Do not place a cigarette lighter on the floor or seat. When you operate the seat, gas may exit out of the lighter causing a fire.
- Use extreme caution when picking up small objects trapped under the seats or between the seat and the center console. Your hands might be cut or injured by the sharp edges of the seat mechanism.
- If there are occupants in the rear seats, be careful while adjusting the front seat position.
- Make sure that the seat is locked in place after the adjustment. If not, the seat might move unexpectedly resulting in an accident.



#### CAUTION

To prevent injury:

- Do not adjust your seat while wearing your seat belt. Moving the seat cushion forward may cause strong pressure on your abdomen.
- Do not allow your hands or fingers to get caught in the seat mechanisms while the seat is moving.

#### Manual adjustment


The front seat can be adjusted by using the levers located on the outside of the seat cushion. Before driving, adjust the seat to the proper position so that you can easily control the steering wheel, foot pedals and controls on the instrument panel.



Forward and rearward adjustment

To move the seat forward or rearward:

- Pull up the seat slide adjustment lever and hold it.
- 2. Slide the seat to the position you desire.
- Release the lever and make sure the seat is locked in place. Move forward and rearward without using the lever. If the seat moves, it is not locked properly.



#### Seatback angle

To recline the seatback:

- Lean forward slightly and lift up the seatback lever.
- Carefully lean back on the seat and adjust the seatback to the position you desire.
- Release the lever and make sure the seatback is locked in place. (The lever MUST return to its original position for the seatback to lock.)

#### **Reclining seatback**

Sitting in a reclined position when the vehicle is in motion can be dangerous. Even when buckled up, the protection of your restraint system (seat belts and air bags) is greatly reduced by reclining your seatback.



### WARNING


NEVER ride with a reclined seatback when the vehicle is moving.

Riding with a reclined seatback increases your chance of serious or fatal injuries in the event of a collision or sudden stop.

Drivers and passengers should ALWAYS sit well back in their seats, properly belted, and with the seatbacks upright.

Seat belts must be snug against your hips and chest to work properly. When the seatback is reclined, the shoulder belt cannot do its job because it will not be snug against your chest. Instead, it will be in front of you. During an accident, you could be thrown into the seat belt, causing neck or other injuries.

The more the seatback is reclined, the greater chance the passenger's hips will slide under the lap belt or the passenger's neck will strike the shoulder helt



Seat cushion height (for driver's seat, if equipped)

To change the height of the seat cushion:

- Push down on the lever several times, to lower the seat cushion.
- Pull up on the lever several times, to raise the seat cushion.

#### **Rear seats**



Take the following precautions:

- · Adjusting the seats
  - NEVER attempt to adjust the seat while the vehicle is moving. The seat may suddenly move and may injure the passenger.
  - Make sure that the seat is locked in place after the adjustment. If not, the seat might move unexpectedly resulting in an accident.
- · Folding the seats
  - Do not fold the seatback when the seat is occupied (for example, passenger, pets or luggage). It may injure the passenger or pet, or damage the luggage.
  - Never allow passengers to sit on top of the folded down seatback while the vehicle is moving. This is not a proper seating position and no seat belts are available for use. This could result in serious injury or death in case of an accident or sudden stop.
  - Objects carried on the folded down seatback should not extend higher than the top of the front seatbacks. This could allow cargo to slide forward and cause injury or damage during sudden stops.

- When returning the rear seatback from a folded to an upright position, hold the seatback and return it slowly. Ensure that the seatback is completely locked into its upright position by pushing on the top of the seatback. In an accident or sudden stop, the unlocked seatback could allow cargo to move forward with great force and enter the passenger compartment, which could result in serious injury or death.
- Loading cargo
  - Make sure the engine is off, the gear is in R (Reverse) or 1st gear (for manual transmission vehicle) or in P (Park, for dual clutch transmission vehicle), and the parking brake is securely applied whenever loading or unloading cargo. Failure to take these steps may allow the vehicle to move if the shift lever is inadvertently moved to another position.
  - When cargo is loaded through the rear passenger seats, ensure the cargo is properly secured to prevent it from moving while driving.
- Do not place objects in the rear seats, since they cannot be properly secured and may hit vehicle occupants in a collision causing serious injury or death.



## **CAUTION**

Do not allow your hands or fingers to get caught in the seat mechanisms while adjusting the seats.

## NOTICE

To prevent damage to the vehicle:

· Rear seat belts


Before folding the seatback, insert the seat belt buckle in the holder between the seatback and cushion. And insert the seat belt webbing in the guide to prevent the seat belt from being damaged.

· Cargo

Be careful when loading cargo through the rear passenger seats to prevent damage to the vehicle interior.

## Folding the rear seat

The rear seatbacks can be folded to facilitate carrying long items or to increase the luggage capacity of the vehicle.



To fold down the rear seatback:

- Set the front seatback to the upright position and if necessary, slide the front seat forward
- 2. Lower the rear head restraint to the lowest position.



Route the seat belt webbing through the rear seat belt guides to prevent the belts from being trapped behind or under the seats.



4. Pull on the seatback folding lever (1) located in the trunk.



- 5. Fold the seatback toward the front of the vehicle.
- 6. To use the rear seat, lift and pull the seatback rearward. Pull the seatback firmly until it clicks into place. Make sure the seatback is locked in place.

#### **Head Restraints**


The vehicle's rear seats have adjustable head restraints. The headrests provide comfort for passengers, but more importantly they are designed to help protect passengers from whiplash and other neck and spinal injuries during an accident, especially in a rear impact collision.



## WARNING

To help reduce the risk of serious injury or death in an accident, take the following precautions when adjusting your head restraints:

- Always properly adjust the head restraints for all passengers BEFORE starting the vehicle.
- NEVER let anyone ride in a seat with the head restraint removed or reversed.



- Adjust the head restraints so the middle of the head restraints is at the same height as the height of the top of the eyes.
- Adjust the head restraint as close to the passenger's head as possible. Do not use a seat cushion that holds the body away from the seatback.
- Make sure the head restraint locks into position after adjusting it.

## NOTICE

To prevent damage, NEVER hit or pull on the head restraints.



## **CAUTION**

When there is no occupant in the rear seats, adjust the height of the head restraint to the lowest position. The rear seat head restraint can reduce the visibility of the rear area.


#### Front seat headrests

## **NOTICE**




If you recline the seatback towards the front with the head restraint and seat cushion raised, the head restraint may come in contact with the sunvisor or other parts of the vehicle.

#### Rear seat head restraints



The rear seats are equipped with headrests in all the seating positions for the passenger's safety and comfort.



Adjusting the height up and down To raise the headrest:

1. Pull it up to the desired position (1).

#### To lower the headrest:

- 1. Push and hold the release button (2) on the headrest support.
- 2. Lower the headrest to the desired position (3).

#### **Seat Warmers**

#### Front seat warmers

Seat warmers are provided to warm the seats during cold weather.



## WARNING

The seat warmers can cause a SERIOUS BURN, even at low temperatures and especially if used for long periods of time.

Passengers must be able to feel if the seat is becoming too warm so they can turn it off, if needed.

People who cannot detect temperature change or pain to the skin should use extreme caution, especially the following types of passengers:

- Infants, children, elderly or disabled persons, or hospital outpatients.
- People with sensitive skin or who burn easily.
- · Fatigued individuals.
- · Intoxicated individuals.
- People taking medication that can cause drowsiness or sleepiness.



## WARNING

NEVER place anything on the seat that insulates against heat when the seat warmer is in operation, such as a blanket or seat cushion. This may cause the seat warmer to overheat, causing a burn or damage to the seat.

## NOTICE

To prevent damage to the seat warmers and seats:

- Never use a solvent such as paint thinner, benzene, alcohol or gasoline to clean the seats.
- Do not place heavy or sharp objects on seats equipped with seat warmers.
- Do not change the seat cover. It may damage the seat warmer or air ventilation system.



While the engine is running, push either of the switches to warm the driver's seat or front passenger's seat.

During mild weather or under conditions where the operation of the seat warmer is not needed, keep the switches in the OFF position.

- Manual temperature control
   Each time you push the switch, the temperature setting of the seat is changed as follows:
  - Front seat



- Automatic temperature control
   The seat warmer starts to
   automatically control the seat
   temperature in order to prevent
   low-temperature burns after being
   manually turned ON.
  - Front seat

You may manually press the switch to decrease seat temperature. However, it soon returns the automatic mode again.

- When pressing the switch for more than 1.5 seconds with the seat warmer operating, the seat warmer will turn OFF.
- The seat warmer defaults to the OFF position whenever the Engine Start/ Stop button is pressed to the ON position. However, if the Auto Comfort Control function is ON, the driver's seat warmer will turn on and off depending on the ambient temperature.
- Auto Comfort Control (for driver's seat, if equipped)

The seat warmer automatically controls the seat temperature depending on the ambient temperature when the engine is running. If the seat warmer switch is pushed, the seat warmer will have to be controlled manually. To use this function, it must be activated from the Settings menu in the infotainment system.



## Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

#### **SEAT BELTS**

This section describes how to use the seat belts properly. It also describes some of the things to avoid when using seat belts.

### **Seat Belt Safety Precautions**

Always fasten your seat belt and make sure all passengers have fastened their seat belts before starting any trip. Air bags are designed to supplement the seat belt as an additional safety device, but they are not a substitute. Most states require all occupants of a vehicle to wear seat belts.

## A

#### WARNING

Seat belts must be used by ALL passengers whenever the vehicle is moving. Take the following precautions when adjusting and wearing seat belts:

- ALWAYS properly restrain children under age 13 in the rear seats.
- NEVER allow children to ride in the front passenger seat. If a child age 13 or older must be seated in the front seat, move the seat as far back as possible. And the child must always be restrained in the seat properly.
- NEVER allow an infant or child to be carried on an occupant's lap.
- NEVER ride with the seatback reclined when the vehicle is moving.
- Do not allow children to share a seat or seat helt.
- Do not wear the shoulder belt under your arm or behind your back.
- Always wear both the shoulder portion and lap portion of the lap/ shoulder belt.
- Do not use the seat belt if it is twisted. A twisted seat belt will not protect you properly in an accident.
- Do not use a seat belt if the webbing or hardware is damaged.

- Do not latch the seat belt into the buckles of other seats.
- NEVER unfasten the seat belt while driving. This may cause loss of vehicle control resulting in an accident.
- Make sure there is nothing in the buckle interfering with the seat belt latch mechanism, because any materials in the buckle can cause the seat belt not to be fastened securely.
- No modifications or additions should be made by the user which will either prevent the seat belt adjusting devices from operating to remove slack, or prevent the seat belt assembly from being adjusted to remove slack.



## WARNING

Damaged seat belts and seat belt assemblies will not operate properly. Always replace:

- Frayed, contaminated, or damaged webbing
- Damaged hardware
- The entire seat belt assembly after it has been worn in an accident, even if damage to webbing or assembly is not apparent

## **Seat Belt Warning Light**

#### Seat belt warning



Driver's and Passenger's front seat belt warning

As a reminder, the seat belt warning light will illuminate for about 6 seconds each time you set the Engine Start/Stop button ON regardless of belt fastening. If the seatbelt is not fastened, the warning chime will sound for about 6 seconds.

If you start to drive without the seat belt fastened over about 5 mph (9 km/h) and less than about 12 mph (20 km/h), the corresponding warning light will illuminate. The warning light will turn off when the vehicle speed drops below about 5 mph (9 km/h).

If you start to drive without the seat belt fastened or you unfasten the seat belt when you drive about 12 mph (20 km/h) and faster, the warning light will blink and warning chime will sound for about 100 seconds.

When the seat belt is unfastened during driving, the warning light will illuminate when the speed is over about 5 mph (9 km/h) and less than about 12 mph (20 km/h). When the speed is about 12 mph (20 km/h) and faster, the warning light will blink and warning chime will sound for about 100 seconds.

### **Seat Belt Restraint System**



## **WARNING**

Improperly positioned seat belts may increase the risk of serious injury in an accident. Take the following precautions when adjusting the seat belt:

- Position the lap portion of the seat belt as low as possible across your hips, not on your waist, so that it fits snugly.
- Position one arm under the shoulder belt and the other over the belt, as shown in the illustration.
- Always position the shoulder belt anchor into the locked position at the appropriate height.
- NEVER position the shoulder belt across your neck or face.

# Seat Belt-Driver's 3-point system with emergency locking retractor



#### To fasten your seat belt:

Pull the seat belt out of the retractor and insert the metal tab (1) into the buckle (2). There will be an audible "click" when the tab locks into the buckle.



You should place the lap belt (1) portion across your hips and the shoulder belt (2) portion across your chest.

The seat belt automatically adjusts to the proper length after the lap belt portion is adjusted manually so that it fits snugly around your hips. If you lean forward in a slow, easy motion, the belt will extend and move with you.


If there is a sudden stop or impact, the belt will lock into position. It will also lock if you try to lean forward too quickly.

### **NOTICE**

If you are not able to smoothly pull enough of the seat belt out from the retractor, firmly pull the seat belt out and release it. After release, you will be able to pull the belt out smoothly.

### Height adjustment

You can adjust the height of the shoulder belt anchor to one of the three different positions for maximum comfort and safety. The shoulder portion should be adjusted so it lies across your chest and midway over your shoulder nearest the door, not over your neck. To adjust the height of the seat belt anchor, lower or raise the height adjuster into an appropriate position.



To raise the height adjuster, pull it up (1). To lower it, push it down (3) while pressing the height adjuster button (2). Release the button to lock the anchor into position. Try sliding the height adjuster to make sure that it has locked into position.



To release your seat belt:

Press the release button (1) in the locking buckle.

When it is released, the belt should automatically draw back into the retractor. If this does not happen, check the belt to be sure it is not twisted, then try again.

#### Rear Seat Belt – Passenger's 3-point system with convertible locking retractor

This type of seat belt combines the features of both an emergency locking retractor seat belt and an automatic locking retractor seat belt. Convertible retractor type seat belts are installed in the rear seat positions to help accommodate the installation of child restraint systems. Although a convertible retractor is also installed in the front passenger seat position, NEVER place any infant/child restraint system in the front seat of the vehicle.

#### To fasten your seat belt:

Pull the seat belt out of the retractor and insert the metal tab into the buckle. There will be an audible "click" when the tab locks into the buckle. When not securing a child restraint, the seat belt operates in the same way as the driver's seat belt (Emergency Locking Retractor Type). It automatically adjusts to the proper length only after the lap belt portion of the seat belt is adjusted manually so that it fits snugly across your hips.

When the seat belt is fully extended from the retractor to allow the installation of a child restraint system, the seat belt operation changes to allow the belt to retract, but not to extend (Automatic Locking Retractor Type). Refer to the "Using a Child Restraint System" section in this chapter.

## NOTICE

Although the seat belt retractor provides the same level of protection for seated passengers in either emergency or automatic locking modes, the emergency locking mode allows seated passengers to move freely in their seat while keeping some tension on the belt. During a collision or sudden stop, the retractor automatically locks the belt to help restrain your body.

To deactivate the automatic locking mode, unbuckle the seat belt and allow the belt to fully retract.

#### Rear center seat belt



When using the rear center seat belt, the buckle with the "CENTER" mark must be used



## ! WARNING

Make sure that the seatback is locked in place when using the rear center seat belt.

If not, the seatback may move when there is a sudden stop or collision, which could result in serious injury.

#### Pre-tensioner seat belt



Your vehicle is equipped with driver's and front passenger's and rear passenger's Pre-tensioner Seat Belts (Retractor Pre-tensioner). The purpose of the pretensioner is to make sure the seat belts fit tightly against the occupant's body in certain frontal or side collision(s).

When the vehicle stops suddenly, or if the occupant tries to lean forward too quickly, the seat belt retractor will lock into position. In certain frontal or side collision(s), the pre-tensioner will activate and pull the seat belt into tighter contact against the occupant's body.


If the system senses excessive tension on the driver or passenger's seat belt when the pre-tensioner system activates, the load limiter inside the retractor pre-tensioner will release some of the pressure on the affected seat belt.

## **WARNING**

- Always wear your seat belt and sit properly in your seat.
- Do not use the seat belt if it is loose or twisted. A loose or twisted seat belt will not protect you properly in an accident.
- Do not place anything near the buckle. This may adversely affect the buckle and cause it to function improperly.
- Always replace your pre-tensioners after activation or an accident.
- NEVER inspect, service, repair or replace the pre-tensioners by yourself. This must be done by an authorized HYUNDAI dealer.
- Do not hit the seat belt assemblies.



Do not touch the pre-tensioner seat belt assemblies for several minutes after they have been activated. When the pre-tensioner seat belt mechanism deploys during a collision, the pretensioners become hot and can burn you.





The Pre-Tensioner Seat Belt System consists mainly of the following components. Their locations are shown in the illustration above:

- 1. SRS air bag warning light
- 2. Retractor pre-tensioner (front)
- 3. SRS control module
- 4. Retractor pre-tensioner (rear)

## NOTICE

The sensor that activates the SRS air bag is connected with the pre-tensioner seat belts. The SRS air bag warning light on the instrument panel will illuminate for about 6 seconds after the Engine Start/ Stop button is in the ON position, and then it should turn off.

If the pre-tensioner is not working properly, the warning light will illuminate even if the SRS air bag is not malfunctioning. If the warning light does not illuminate, stays illuminated or illuminates when the vehicle is being driven, have an authorized HYUNDAI dealer inspect the pre-tensioner seat belts and SRS air bags as soon as possible.

## NOTICE

- The pre-tensioner seat belts may be activated in certain frontal or side collisions or rollovers.
- When the pre-tensioner seat belts are activated, a loud noise may be heard and fine dust, which may appear to be smoke, may be visible in the passenger compartment. These are normal operating conditions and are not hazardous.
- Although it is non-toxic, the fine dust may cause skin irritation and should not be inhaled for prolonged periods. Wash all exposed skin areas thoroughly after an accident in which the pre-tensioner seat belts were activated.

## **MARNING**

- Fasten your seat belt while sitting properly in an upright position to maximize the effectiveness of the pre-tensioner seat belt system.
- A pre-tensioner seat belt system is designed to activate only once.
   Replace the pre-tensioner seat belt system, if it was activated in an accident.

## Additional Seat Belt Safety Precautions

### Seat belt use during pregnancy

The seat belt should always be used during pregnancy. The best way to protect your unborn child is to protect yourself by always wearing the seat belt.

Pregnant women should always wear a lap-shoulder seat belt. Place the shoulder belt across your chest, routed between your breasts and away from your neck. Place the lap belt line so that it fits snugly and as low as possible across the hips, not across the abdomen.

## **!** WARNING

- Pregnant women and patients are more vulnerable to any impacts on the abdomen during an abrupt stop or accident. If you are in an accident while pregnant, consult your doctor.
- To reduce the risk of serious injury or death to an unborn child during an accident, pregnant women should NEVER place the lap portion of the seat belt above or over the area of the abdomen where the unborn child is located.

#### Seat belt use and children

#### Infant and small children

All 50 states have child restraint laws which require children to travel in approved child restraint devices, including booster seats. The age at which seat belts can be used instead of child restraints differs among states, so you should be aware of the specific requirements in your state, and where you are travelling. Infant and child restraints must be properly placed and installed in a rear seat. For more information refer to the "Child Restraint Systems" section in this chapter.



## WARNING

ALWAYS properly restrain infants and small children in a child restraint appropriate for the child's height and weight.

To reduce the risk of serious injury or death to a child and other passengers, NEVER hold a child in your lap or arms when the vehicle is moving. The violent forces created during an accident will tear the child from your arms and throw the child against the interior of the vehicle.

Small children are best protected from injury in an accident when properly restrained in the rear seat by a child restraint system that meets the requirements of the Federal Motor Vehicle Safety Standards. Before buying any child restraint system, make sure that it has a label certifying that it meets Federal Motor Vehicle Safety Standard FMVSS 213. The restraint must be appropriate for your child's height and weight. Check the label on the child restraint for this information. Refer to the "Child Restraint Systems" section in this chapter.

#### Larger children

Children under age 13 and who are too large for a booster seat must always occupy the rear seat and use the available lap/shoulder belts. A seat belt should lie across the upper thighs and be snug across the shoulder and chest to restrain the child safely. Check belt fit periodically. Children are afforded the most safety in the event of an accident when they are restrained by a proper restraint system and/or seat belts in the rear seat. Always have the LATCH system inspected by your authorized HYUNDAL dealer after an accident. An accident can damage the LATCH system and may not properly secure the child restraint.

If a larger child over age 13 must be seated in the front seat, the child must be securely restrained by the available lap/shoulder belt and the seat should be placed in the rearmost position.

If the shoulder belt portion slightly touches the child's neck or face, try placing the child closer to the center of the vehicle. If the shoulder belt still touches their face or neck, they need to be returned to an appropriate booster seat in the rear seat.



## WARNING

- Always make sure children are wearing their seat belts and that they are properly adjusted before driving.
- NEVER allow the shoulder belt to contact the child's neck or face.
- Do not allow more than one child to use a single seat belt.

### Transporting an injured person

A seat belt should be used when an injured person is being transported. Consult a physician for specific recommendations.

#### One person per belt

Two people (including children) should never attempt to use a single seat belt. This could increase the severity of injuries in case of an accident.

#### Do not lie down

Sitting in a reclined position when the vehicle is in motion can be dangerous. Even when buckled up, the protections of your restraint system (seat belts and air bags) is greatly reduced by reclining your seatback.

To reduce the chance of injuries in the event of an accident and to achieve the maximum effectiveness of the restraint system, all passengers should be sitting up and the front and rear seats should be in an upright position when the car is moving.

A seat belt cannot provide proper protection if the person is lying down in the rear seat or if the front or rear seats are in a reclined position.

## **⚠** WARNING

- NEVER ride with a reclined seatback when the vehicle is moving.
- Riding with a reclined seatback increases your chance of serious or fatal injuries in the event of a collision or sudden stop.
- Driver and passengers should always sit well back in their seats with the seatbacks upright and should be belted properly.

#### **Care of Seat Belts**

Seat belt systems should never be disassembled or modified. In addition, care should be taken to assure that seat belts and belt hardware are not damaged by seat hinges, doors or other abuse.

#### Periodic inspection

All seat belts should be inspected periodically for wear or damage of any kind. Any damaged parts should be replaced as soon as possible by an authorized HYUNDAI dealer.

### Keep belts clean and dry

Seat belts should be kept clean and dry. If belts become dirty, they can be cleaned by using a mild soap solution and warm water. Bleach, dye, strong detergents or abrasives should not be used because they may damage and weaken the fabric.

## When to replace seat belts

The entire seat belt assembly or assemblies should be replaced if the vehicle has been involved in an accident. This should be done even if no damage is visible. Additional questions concerning seat belt operation should be directed to an authorized HYUNDAI dealer.

### **CHILD RESTRAINT SYSTEM (CRS)**

## **Children Always in the Rear**



## **WARNING**

Always properly restrain children in the rear seats of the vehicle.

Children of all ages are safer when restrained in the rear seat. A child riding in the front passenger seat can be forcefully struck by an inflating air bag resulting in SERIOUS INJURY or DEATH.

Children under age 13 must always ride in the rear seats and must always be properly restrained to minimize the risk of injury in an accident, sudden stop or sudden maneuver. According to accident statistics, children are safer when properly restrained in the rear seats than in the front seat. **Even with air bags, children can be seriously injured or killed.** Children too large for a child restraint must use the seat belts provided.

All 50 states have child restraint laws which require children to travel in approved child restraint devices. The laws governing the age or height/weight restrictions at which seat belts can be used instead of child restraints differs among states, so you should be aware of the specific requirements in your state, and where you are travelling.

Child restraint systems must be properly placed and installed in the rear seat. You must use a commercially available child restraint system that meets the requirements of the Federal Motor Vehicle Safety Standards (FMVSS 213).

Child restraint systems are generally designed to be secured in a vehicle seat by lap belt portion of a lap/shoulder belt, or by a LATCH system in the rear seats of the vehicle.

### Child restraint system (CRS)

Infants and younger children must be restrained in an appropriate rear-facing or forward-facing CRS that has first been properly secured to the rear seat of the vehicle. Read and comply with the instructions for installation and use provided by the manufacturer of the child restraint.



### WARNING

An improperly secured child restraint can increase the risk of SERIOUS INJURY or DEATH in an accident. Always take the following precautions when using a child restraint system:

- NEVER install a child or infant restraint in the front passenger's seat.
- Always properly secure the child restraint to a rear seat of the vehicle.
- Always follow the child restraint system manufacturer's instructions for installation and use.
- Always properly restrain your child in the child restraint.
- If the vehicle head restraint prevents proper installation of a child seat (as described in the child restraint system manual), the head restraint of the respective seating position shall be readjusted or entirely removed.
- Do not use an infant carrier or a child safety seat that "hooks" over a seatback, it may not provide adequate protection in an accident.
- After an accident, have a HYUNDAI dealer check the child restraint system, seat belts, tether anchors and lower anchors.

## Selecting a Child Restraint System (CRS)

When selecting a CRS for your child, always:

- Make sure the CRS has a label certifying that it meets applicable Federal Motor Vehicle Safety Standards (FMVSS 213).
- Select a child restraint based on your child's height and weight. The required label or the instructions for use typically provide this information.
- Select a child restraint that fits the vehicle seating position where it will be used.
- Read and comply with the warnings and instructions for installation and use provided with the child restraint system.

#### Child restraint system types

There are three main types of child restraint systems: rear-facing seats, forward-facing seats, and booster seats. They are classified according to the child's age, height and weight.

Rear-facing child seats



### WARNING

NEVER install a child or infant restraint in the front passenger's seat.

Placing a rear-facing child restraint in the front seat can result in SERIOUS INJURY or DEATH if the child restraint is struck by an inflating air bag.



A rear-facing child seat provides restraint with the seating surface against the back of the child. The harness system holds the child in place, and in an accident, acts to keep the child positioned in the seat and reduce the stress to the neck and spinal cord.

All children under age one must always ride in a rear-facing infant child restraint.

Convertible and 3-in-1 child seats typically have higher height and weight limits for the rear-facing position, allowing you to keep your child rearfacing for a longer period of time.

Continue to use a rear-facing child seat for as long as your child will fit within the height and weight limits allowed by the child seat manufacturer. It's the best way to keep them safe. Once your child has outgrown the rear-facing child restraint, your child is ready for a forward-facing child restraint with a harness.



#### Forward-facing child restraints

A forward-facing child seat provides restraint for the child's body with a harness. Keep children in a forward-facing child seat with a harness until they reach the top height or weight limit allowed by your child restraint's manufacturer.

Once your child outgrows the forwardfacing child restraint, your child is ready for a booster seat.

#### **Booster seats**

A booster seat is a Child Restraint System designed to improve the fit of the vehicle's seat belt system. A booster seat positions the seat belt so that it fits properly over the stronger parts of your child's body. Keep your children in booster seats until they are big enough to fit in a seat belt properly. For a seat belt to fit properly, the lap belt must lie comfortable across the upper thighs, not the stomach. The shoulder belt should lie comfortable across the shoulder and chest and not across the neck or face. Children under age 13 must always be properly restrained to minimize the risk of injury in an accident, sudden stop or sudden maneuver

# Installing a Child Restraint System (CRS)



### **WARNING**

Before installing your child restraint system always:

- Read and follow the instructions provided by the manufacturer of the child restraint.
- Read and follow the instructions regarding child restraint systems in this manual.

Failure to follow all warnings and instructions could increase the risk of the SERIOUS INJURY or DEATH if an accident occurs.



## WARNING

If the vehicle head restraint prevents proper installation of a child seat as described in the child seat system manual, the head restraint of the respective seating position shall be readjusted or entirely removed.

After selecting a proper child seat for your child, check to make sure it fits properly in your vehicle. Follow the instructions provided by the manufacturer when installing the child seat. Note these general steps when installing the seat to your vehicle:

- Properly secure the child restraint to the vehicle. All child restraints must be secured to the vehicle with the lap part of a lap/shoulder belt or with the LATCH system.
- · Make sure the child restraint is firmly secured. After installing a child restraint to the vehicle, push and pull the seat forward-and-back and side-to-side to verify that it is securely attached to the seat. A child restraint secured with a seat belt should be installed as firmly as possible. However, some side-to-side movement can be expected. When installing a Child Restraint System, adjust the vehicle seat and seatback (up and down, forward and rearward) so that your child fits in the Child Restraint System in a comfortable manner.
- Secure the child in the child restraint. Make sure the child is properly strapped in the child restraint according to the manufacturer instructions.



## ! CAUTION

A child restraint in a closed vehicle can become very hot. To prevent burns, check the seating surface and buckles before placing your child in the child restraint.


### Lower Anchors and Tether for Children (LATCH System)

The LATCH system holds a child restraint during driving and in an accident. This system is designed to make installation of the child restraint easier and reduce the possibility of improperly installing your child restraint. The LATCH system uses anchors in the vehicle and attachments on the child restraint. The LATCH system eliminates the need to use seat belts to secure the child restraint to the rear seats

Lower anchors are metal bars built into the vehicle. There are two lower anchors for each LATCH seating position that will accommodate a child restraint with lower attachments.

To use the LATCH system in your vehicle. you must have a child restraint with I ATCH attachments

The child seat manufacturer will provide you with instructions on how to use the child seat with its attachments for the LATCH lower anchors.



LATCH anchors have been provided in the left and right outboard rear seating positions. Their locations are shown in the illustration. There are no LATCH anchors provided for the center rear seating position.




## ! WARNING

Do not attempt to install a child restraint system using LATCH anchors in the rear center seating position. There are no LATCH anchors provided for this seat. Using the outboard seat anchors can damage the anchors which may break or fail in a collision resulting in serious injury or death.



### WARNING

Before installing the Child Restraint System, make sure that there are no objects (for example, toy, pen, wire) around the lower anchor area. Those objects may damage either the seat belt system or the Child Restraint System during the installment procedure. If necessary, have the vehicle inspected by an authorized HYUNDAI dealer.



[A]: Lower Anchor Position Indicator [B]: Lower Anchor

The lower anchor position indicator symbols are located on the left and right rear seat backs to identify the position of the lower anchors in your vehicle (see arrows in illustration).

The LATCH anchors are located between the seatback and the seat cushion of the rear seat left and right outboard seating positions.

#### Securing a child restraint with the LATCH anchors system

To install a LATCH-compatible child restraint in either of the rear outboard seating positions:

- 1. Move the seat belt buckle away from the lower anchors.
- 2. Move any other objects away from the anchors that could prevent a secure connection between the child restraint and the lower anchors.
- 3. Place the child restraint on the vehicle seat, then attach the seat to the lower anchors according to the instructions provided by the child restraint manufacturer.
- 4. Follow the child restraint instructions for properly adjusting and tightening the lower attachments on the child restraint to the lower anchors.

Take the following precautions when using the LATCH system:

- Read and follow all installation instructions provided with your child restraint system.
- To prevent the child from reaching and taking hold of unretracted seat belts, buckle all unused rear seat belts and retract the seat belt webbing behind the child. Children can be strangled if a shoulder belt becomes wrapped around their neck and the seat belt tightens.
- NEVER attach more than one child restraint to a single anchor. This could cause the anchor or attachment to come loose or break.
- Always have the LATCH system inspected by your authorized HYUNDAI dealer after an accident. An accident can damage the LATCH system and may not properly secure the child restraint.

## NOTICE

The recommended weight for the LATCH system is under 65 lb (30 kg).

How to determine an appropriate child restraint weight:

Child weight + Child restraint weight < 65 lb (30kg)

### Securing a child restraint seat with "Tether Anchor" system



First secure the child restraint with the LATCH lower anchors or the seat belt. If the child restraint manufacturer recommends that the top tether strap be attached, attach and tighten the top tether strap to the top tether strap anchor

Child restraint hook holders are located on the rear of the seatbacks.



#### **WARNING**

Take the following precautions when installing the tether strap:

- Read and follow all installation instructions provided with your child restraint system.
- NEVER attach more than one child restraint to a single tether anchor. This could cause the anchor or attachment to come loose or break.
- Do not attach the tether strap to anything other than the correct tether anchor. It may not work properly if attached to something else.
- Child Restraint System anchors are designed to withstand only those loads imposed by correctly fitted Child Restraint System.
- Do not use them for adult seat belts, harnesses, or for attaching other items or equipment to the vehicle.



To install the tether anchor:

- Route the child restraint tether strap over the child restraint seatback. Route the tether strap under the head restraint and between the head restraint posts, or route the tether strap over the top of the vehicle seatback. Make sure the strap is not twisted.
- Connect the tether strap hook to the tether anchor, then tighten the tether strap according to the child seat manufacturer's instructions to firmly secure the child restraint to the seat.
- Check that the child restraint is securely attached to the seat by pushing and pulling the seat forwardand-back and side-to-side.

### Securing a child restraint with lap/ shoulder belt

When not using the LATCH system, all child restraints must be secured to a vehicle rear seat with the lap part of a lap/shoulder belt.



ALWAYS place a rear-facing child restraint in the rear seat of the vehicle.

Placing a rear-facing child restraint in the front seat can result in serious injury or death if the child restraint is struck by an inflating air bag.



### Automatic locking mode

Since all passenger seat belts move freely under normal conditions and only lock under extreme or emergency conditions (emergency locking mode), you must manually pull the seat belt all the way out to shift the retractor to the "Automatic Locking" mode to secure a child restraint.

The "Automatic Locking" mode will help prevent the normal movement of the child in the vehicle from causing the seat belt to loosen and compromise the child restraint system. To secure a child restraint system, use the following procedure.

To install a child restraint system on the rear seats, do the following:

 Place the child restraint system on a rear seat and route the lap/ shoulder belt around or through the child restraint, following the restraint manufacturer's instructions. Be sure the seat belt webbing is not twisted.

## *i* Information

When using the rear center seat belt, you should also refer to the "Rear Seat Belt – Passenger's 3-point system" section in this chapter.



Fasten the lap/shoulder belt latch into the buckle. Listen for the distinct "click" sound.

## *i* Information

Position the release button so that it is easy to access in case of an emergency.



 Pull the shoulder portion of the seat belt all the way out. When the shoulder portion of the seat belt is fully extended, it will shift the retractor to the "Automatic Locking" (child restraint) mode.



- 4. Slowly allow the shoulder portion of the seat belt to retract and listen for an audible "clicking" or "ratcheting" sound. This indicates that the retractor is in the "Automatic Locking" mode. If no distinct sound is heard, repeat steps 3 and 4.
- Remove as much slack from the belt as possible by pushing down on the child restraint system while feeding the shoulder belt back into the retractor.
- Push and pull on the child restraint system to confirm that the seat belt is holding it firmly in place. If it is not, release the seat belt and repeat steps 2 through 6.
- Double check that the retractor is in the "Automatic Locking" mode by attempting to pull more of the seat belt out of the retractor. If you cannot, the retractor is in the "Automatic Locking" mode.

If your CRS (child restraint system) manufacturer instructs or recommends you to use a tether anchor with the lap/shoulder belt, refer to the previous pages for more information.

## *i* Information


When the seat belt is allowed to retract to its fully stowed position, the retractor will automatically switch from the "Automatic Locking" mode to the emergency lock mode for normal adult usage.

## **MARNING**

If the retractor is not in the "Automatic Locking" mode, the child restraint can move when your vehicle turns or stops suddenly. A child can be seriously injured or killed if the child restraint is not properly anchored in the car, including manually pulling the seat belt all the way out to shift the rectractor to the "Automatic Locking" mode.

To remove the child restraint, press the release button on the buckle and then pull the lap/shoulder belt out of the restraint and allow the seat belt to retract fully.

## **AIR BAG - ADVANCED SUPPLEMENTAL RESTRAINT SYSTEM**



- 1. Driver's front air bag
- 2. Passenger's front air bag
- 3. Front side air bag
- 4. Rear side air bag
- 5. Curtain air bag

This vehicle is equipped with an Advanced Supplemental Air Bag System for the driver's seat and front passenger's seats.

The front air bags are designed to supplement the three-point seat belts. For these air bags to provide protection, the seat belts must be worn at all times when driving.

You can be severely injured or killed in an accident if you are not wearing a seat belt. Air bags are designed to supplement seat belts, but do not replace them. Also, air bags are not designed to deploy in every collision. In some accidents, the seat belts are the only restraint protecting you.



#### AIR BAG SAFETY PRECAUTIONS

ALWAYS use seat belts and child restraints - every trip, every time, everyone! Even with air bags, you can be seriously injured or killed in a collision if you are improperly belted or not wearing your seat belt when the air bag inflates.

NEVER place a child in any child restraint or booster seat in the front passenger seat. An inflating air bag could forcefully strike the infant or child causing serious or fatal injuries.

ABC - Always Buckle Children under age 13 in the back seat. It is the safest place for children of any age to ride. If a child age 13 or older must be seated in the front seat, he or she must be properly belted and the seat should be moved as far back as possible.

All occupants should sit upright with the seatback in an upright position, centered on the seat cushion with their seat belt on, legs comfortably extended and their feet on the floor until the vehicle is parked and is turned off. If an occupant is out of position during an accident, the rapidly deploying air bag may forcefully contact the occupant causing serious or fatal injuries.

You and your passengers should never sit or lean unnecessarily close to the air bags or lean against the door or center console.

Move your seat as far back as possible from front air bags, while still maintaining control of the vehicle. The U.S. National Highway Traffic Safety Administration (NHTSA) recommends that drivers allow at least 10 inches (25 cm) between the center of the steering wheel and the chest.

## Where Are the Air Bags?

## Driver's and passenger's front air bags

Your vehicle is equipped with an Advanced Supplemental Restraint System (SRS) and lap/shoulder belts at both the driver and passenger seating positions.

The SRS consists of air bags which are located in the center of the steering wheel, in the driver's side lower crash pad below the steering wheel column and the passenger's side front panel pad above the glove box.

The air bags are labeled with the letters "AIR BAG" embossed on the pad covers.





The purpose of the SRS is to provide the vehicle's driver and front passengers with additional protection than that offered by the seat belt system alone. The SRS uses sensors to gather information about the driver's and front passenger's seat belt usage and impact severity. The seat belt buckle sensors determine if the driver and front passenger's seat belts are fastened. These sensors provide the ability to control the SRS deployment based on whether or not the seat belts are fastened, and how severe the impact is. The advanced SRS offers the ability to control the air bag inflation within two levels. A first stage level is provided for moderate-severity impacts. A second stage level is provided for more severe impacts. According to the impact severity, and seat belt usage, the SRS Control Module (SRSCM) controls the air bag inflation. Failure to properly wear seat belts can increase the risk or severity of injury in an accident.

To reduce the risk of serious injury or death from inflating front air bags, take the following precautions:

- Seat belts must be worn at all times to help keep occupants positioned properly.
- Move your seat as far back as possible from front air bags, while still maintaining control of the vehicle.
- Never lean against the door or center console.
- Do not allow the front passenger to place their feet or legs on the dashboard.
- No objects (such as crash pad cover, cellular phone holder, cup holder, air fresheners or stickers) should be placed over or near the air bag modules on the steering wheel, instrument panel, windshield glass, and the front passenger's panel above the glove box. Such objects could cause harm if the vehicle is in a crash severe enough to cause the air bags to deploy.
- Do not attach any objects on the front windshield and inside mirror.

### Side air bags







Your vehicle is equipped with a side air bag in each front and outboard second row seat. The purpose of the air bag is to provide the vehicle's additional protection than that offered by the seat belt alone.


The side air bags are designed to deploy only during certain side impact collisions, depending on the crash severity. The side and curtain air bags on both sides of the vehicle may deploy if a rollover or possible rollover is detected. For vehicles equipped with a rollover sensor the side air bags and pre-tensioners on both sides of the vehicle may deploy if a rollover or possible rollover is detected. However, the side air bags are not designed to deploy in all side impact or rollover situations.

To reduce the risk of serious injury or death from an inflating side air bag, take the following precautions:

- Seat belts must be worn at all times to help keep occupants positioned properly.
- Do not allow passengers to lean their heads or bodies onto doors, put their arms on the doors, stretch their arms out of the window, or place objects between the doors and seats.
- Hold the steering wheel at the 9
  o'clock and 3 o'clock positions, to
  minimize the risk of injuries to your
  hands and arms.
- Do not use any accessory seat covers. This could reduce or prevent the effectiveness of the system.
- Do not place any objects over the air bag or between the air bag and yourself. Also, do not attach any objects around the area the air bag inflates such as the door, side door glass, front and rear pillar.
- Do not place any objects between the door and the seat. They may become dangerous projectiles if the side air bag inflates.
- Do not install any accessories on the side or near the side air bags.
- Do not put any objects between the side airbag label and seat cushion. It could cause harm if the vehicle is in a crash severe enough to cause the air bags to deploy.
- Do not cause impact to the doors when the Engine Start/ Stop button is in the ON position as this may cause the side air bags to inflate.
- If the seat or seat cover is damaged, have the vehicle checked and repaired by an authorized HYUNDAI dealer.

### Curtain air bags





Curtain air bags are located along both sides of the roof rails above the front and rear doors.

They are designed to help protect the heads of the front seat occupants and the rear outboard seat occupants in certain side impact collisions.

The curtain air bags are designed to deploy during certain side impact collisions, depending on the crash severity.


The side and curtain air bags on both sides of the vehicle may deploy if a rollover or possible rollover is detected.

The curtain air bags are not designed to deploy in all side impact or rollover situations.

To reduce the risk of serious injury or death from an inflating curtain air bag, take the following precautions:

- All seat occupants must wear seat belts at all times to help keep occupants positioned properly.
- Properly secure child restraints as far away from the door as possible.
- Do not hang or place any objects over the air bag. Also, do not attach any objects around the area the air bag inflates such as the door, side door glass, front and rear pillar, roof side rail.
- Do not hang other objects except clothes, especially hard or breakable objects. In an accident, it may cause vehicle damage or personal injury.
- Do not allow passengers to lean their heads or bodies onto doors, put their arms on the doors, stretch their arms out of the window, or place objects between the doors and seats.
- Do not attempt to open or repair the side curtain air bags yourself. If necessary, have the air bag inspected by an authorized HYUNDAI dealer.

# How Does the Air Bag System Operate?



The SRS consists of the following components:

- (1) Driver's front air bag module
- (2) Passenger's front air bag module
- (3) Side air bag modules
- (4) Side airbag modules (rear)
- (5) Curtain air bag modules
- (6) Retractor pre-tensioner assemblies
- (7) Air bag warning light
- (8) SRS control module (SRSCM)
- (9) Front impact sensors
- (10) Side impact sensors (acceleration)
- (11) Side impact sensors (pressure)
- (12) Occupant classification system
- (13) Driver's and front passenger's seat belt buckle sensors

The SRSCM (Supplemental Restraint System Control Module) continually monitors all SRS components while the Engine Start/Stop button is in the ON position or about within 3 minutes after the ignition is off to determine if a crash impact is severe enough to require air bag deployment or pre-tensioner seat belt deployment.



### SRS warning light

The SRS (Supplement Restraint System) air bag warning light on the instrument panel displays the air bag symbol depicted in the illustration. The system checks the air bag electrical system for malfunctions. The light indicates that there is a potential malfunction with your air bag system, which could include your side and curtain air bags used for rollover protection.

## ! WARNING

If your SRS malfunctions, the air bag may not inflate properly during an accident, increasing the risk of serious injury or death.

If any of the following conditions occur. your SRS is malfunctioning:

- The light does not turn on for about three to six seconds when the Engine Start/Stop button is in the ON position.
- The light stays on after illuminating for about three to six seconds.
- The light comes on while the vehicle is in motion.
- · The light blinks when the engine is running.

Have an authorized HYUNDAI dealer inspect the SRS as soon as possible if any of these conditions occur.

The front air bags help protect the driver and front passenger by responding to frontal impacts in which seat belts alone cannot provide adequate restraint. When needed, the side air bags help provide protection in the event of a side impact or rollover by supporting the side upper body area.

- Air bags are activated (able to inflate if necessary) when the Engine Start/ Stop button is in the ON position or about within 3 minutes after ignition off.
- Air bags inflate in the event of certain frontal or side collisions to help protect the occupants from serious physical injury.
- There is no single speed at which the air bags will inflate. Generally, air bags are designed to inflate based upon the severity of a collision and its direction. These two factors determine whether the sensors produce an electronic deployment/inflation signal.
- · The front air bags will completely inflate and deflate in an instant. It is virtually impossible for you to see the air bags inflate during an accident. It is much more likely that you will simply see the deflated air bags hanging out of their storage compartments after the collision.
- In addition to inflating in certain side collisions, vehicles equipped with a rollover sensor, side and curtain air bags will inflate if the sensing system detects a rollover.

When a rollover is detected, side and curtain air bags will remain inflated longer to help provide protection from ejection, especially when used in conjunction with the seat belts.

- To help provide protection, the air bags must inflate rapidly. The speed of air bag inflation is a consequence of extremely short time in which to inflate the air bag between the occupant and the vehicle structures before the occupant impacts those structures. This speed of inflation reduces the risk of serious or lifethreatening injuries and is thus a necessary part of air bag design.
   However, the rapid air bag inflation can also cause injuries which can
- There are even circumstances under which contact with the air bag can cause fatal injuries, especially if the occupant is positioned excessively close to the air bag.

include facial abrasions, bruises and

broken bones because the inflation

speed also causes the air bags to

expand with a great deal of force.

You can take steps to help reduce the risk of being injured by an inflating air bag. The greatest risk is sitting too close to the air bag. An air bag needs about 10 inches (25 cm) of space to inflate. NHTSA recommends that drivers allow at least 10 inches (25 cm) between the center of the steering wheel and the chest.



### WARNING

To reduce the risk of serious injury or death from an inflating air bag, take the following precautions:

- NEVER place a child restraint in the front passenger seat.
  - Always properly restrain children under age 13 in the rear seats of the vehicle.
- Adjust the front passenger's and driver's seats as far to the rear as possible while maintaining you to maintain full control of the vehicle.
- Hold the steering wheel with hands at the 9 o'clock and 3 o'clock positions.
- NEVER place anything or anyone between the air bag and the seat occupant.
- Do not allow the front passenger to place their feet or legs on the dashboard.



When the SRSCM detects a sufficiently severe impact to the front of the vehicle, it will automatically deploy the front air bags.



Upon deployment, tear seams molded directly into the pad covers will separate under pressure from the expansion of the air bags. Further opening of the covers allows full inflation of the air bags.

A fully inflated air bag, in combination with a properly worn seat belt, slows the driver or the front passenger forward motion, reducing the risk of head and chest injury.





After complete inflation, the air bag immediately starts deflating, enabling the driver to maintain forward visibility and the ability to steer or operate other controls.



## WARNING

To prevent objects from becoming dangerous projectiles when the passenger's air bag inflates:

- Do not install or place any objects (drink holder, CD holder, stickers, etc.) on the front passenger's panel above the glove box where the passenger's air bag is located.
- Do not install a container of liquid air freshener near the instrument cluster or on the instrument panel surface.

### What to Expect After an Air Bag Inflates

After a frontal or side air bag inflates, it will deflate very quickly. Air bag inflation will not prevent the driver from seeing out of the windshield or being able to steer. Curtain air bags may remain partially inflated for some time after they deploy.

## ! WARNING

After an air bag inflates, take the following precautions:


- Open your windows and doors as soon as possible after impact to reduce prolonged exposure to the smoke and powder released by the inflating air bag.
- Do not touch the air bag storage area's internal components immediately after an air bag has inflated. The parts that come into contact with an inflating air bag may be very hot.
- Always wash exposed skin areas thoroughly with cold water and mild soap.
- Always have an authorized HYUNDAI dealer replace the air bag immediately after deployment. Air bags are designed to be used only once.

## Noise and smoke from inflating air

When the air bags inflate, they make a loud noise and may produce smoke and powder in the air inside of the vehicle. This is normal and is a result of the ignition of the air bag inflator. After the air bag inflates, you may feel substantial discomfort in breathing because of the contact of your chest with both the seat belt and the air bag, as well as from breathing the smoke and powder. The powder may aggravate asthma for some people. If you experience breathing problems after an air bag deployment, seek medical attention immediately.

Though the smoke and powder are nontoxic, they may cause irritation to the skin, eyes, nose, throat, etc. If this is the case, wash and rinse with cold water. immediately and seek medical attention if the symptoms persist.

# Occupant Classification System (OCS)





Your vehicle is equipped with an Occupant Classification System (OCS) in the front passenger's seat.

## Main components of the Occupant Classification System

- A detection device located within the front passenger seat cushion.
- Electronic system to help determine whether the passenger air bag systems should be activated or deactivated.
- An indicator light located on the overhead console which illuminates the words "PASSENGER AIR BAG OFF" indicating the front passenger air bag system is deactivated.
- The overhead console air bag indicator light is interconnected with the OCS.

The OCS is designed to help detect the presence of a properly-seated front passenger and determine if the passenger's front air bag should be enabled (may inflate) or not.

The purpose is to help reduce the risk of injury or death from an inflating air bag to certain front passenger seat occupants, such as children, by requiring the air bag to be automatically turned OFF.

For example, if a child restraint of the type specified in the regulations is on the seat, the occupant classification sensor can detect it and cause the air bag to turn OFF.

Front passenger seat adult occupants who are properly seated and wearing the seat belt properly, should not cause the passenger air bag to be automatically turned OFF. For small adults it may be turned OFF, however, if the occupant does not sit in the seat properly (for example, by not sitting upright, by sitting on the edge of the seat, or by otherwise being out of position), this could cause the sensor to turn the air bag OFF.

You will find the "PASSENGER AIR BAG OFF" indicator on the overhead console. This system detects the conditions 1-4 in the following table and activates or deactivates the front passenger air bag based on these conditions.

Always be sure that you and all vehicle occupants are seated properly and wearing the seat belt properly for the most effective protection by the air bag and the seat belt.

Never install a Child Restraint System in the front passenger's seat. If you should install a CRS (Child Restraint System) inevitably, use a forward-facing CRS with 3-point ALR safety seat belt and adjust the front passenger's seat as far to the rear as possible. If the PASSENGER AIR BAG "OFF" indicator is OFF after a CRS (Child Restraint System) is equipped, the front passenger's airbag is operating so you should install the CRS in the rear seats of the vehicle immediately.

The OCS may not function properly if the passenger takes actions which can affect the classification system. These include:

- · Failing to sit in an upright position.
- Leaning against the door or center console.
- Sitting towards the sides of the front of the seat.
- Putting their legs on the dashboard or resting them on other locations which reduce the passenger weight on the front seat.
- · Wearing the seat belt improperly.
- Reclining the seatback.
- Wearing a thick cloth like ski wear or hip protection wear.
- Putting an additional thick cushion on the seat.
- Putting electrical devices (for example, notebook, satellite radio) on the seat with inverter charging.

#### Condition and operation in the front passenger Occupant Classification System

	Indicator/Warning light		Devices
Condition detected by the occupant classification system	"PASSENGER AIR BAG OFF" indicator light	SRS warning light	Front passenger air bag
1. Adult *1	Off	Off	Activated
2. Infant *2 or child restraint system with 12 months old *3 *4	On	Off	Deactivated
3. Unoccupied	On	Off	Deactivated
4. Malfunction in the system	Off	On	Activated

- \*1: The system judges a person of adult size as an adult. When a smaller adult sits in the front passenger seat, the system may recognize him/her as a child depending on his/her physique and posture.
- \*2: Do not allow children to ride in the front passenger seat. When a larger child who has outgrown a child restraint system sits in the front passenger seat, the system may recognize him/her as an adult depending upon his/her physique or sitting position.
- \*3: Never install a child restraint system on the front passenger seat.
- \*4: The PASSENGER AIR BAG "OFF" indicator may turn on or off when a child above 12 months to 12 years old (with or without child restraint system) sits in the front passenger seat. This is a normal condition.

### **MARNING**

Riding in an improper position or placing weight on the front passenger's seat when it is unoccupied by a passenger adversely affects the OCS. To reduce the risk of serious injury or death:



 NEVER put a heavy load in the front seat or seatback pocket, or hang any items on the front passenger seat.



 NEVER place your feet on the front passenger seatback.



NEVER sit with your hips shifted towards the front of the seat.



 NEVER ride with the seatback reclined when the vehicle is moving.



NEVER place your feet or legs on the dashboard.



 NEVER lean on the door or center console or sit on one side of the front passenger seat.



Do not sit on the passenger seat wearing heavily padded clothes such as ski wear and hip protector.



Do not use car seat accessories such as thick blankets and cushions which cover up the car seat surface.



- Do not place electronic devices such as laptops, DVD player, or conductive materials such as water bottles on the passenger seat.
- Do not use electronic devices such as laptops and satellite radios which use inverter chargers.



 If large amount of liquid has been spilled on the passenger seat, the air bag warning light may illuminate or malfunction.

Therefore, make sure the seat has been completely dried before driving the vehicle.

- Do not place sharp objects on the front passenger seat. These may damage the occupant detection system, if they puncture the seat cushion.
- · Do not place any items under the front passenger seat.
- When changing or replacing the seat or seat cover, use original items only.
   The OCS has been developed based on using original HYUNDAI car seats only.
   Altering or changing the authentic parts may result in system malfunction and increase risk of injury when in collision. Any of the above could interfere with the proper operation of the OCS sensor thereby increasing the risk of an injury in an accident.



Proper seated position for OCS If the "PASSENGER AIR BAG OFF" indicator is on when an adult is seated in the front passenger seat, place the Engine Start/Stop button in the OFF position and ask the passenger to sit properly (sitting upright with the seat back in an upright position, centered on the seat cushion with their seat belt on, legs comfortably extended and their feet on the floor). Restart the engine and have the person remain in that position. This will allow the system to detect the person and to enable the passenger air bag. If the "PASSENGER AIR BAG OFF" indicator is still on, ask the passenger to move to the rear seat.

### **MARNING**

NEVER allow an adult passenger to ride in the front passenger seat when the "PASSENGER AIR BAG OFF" indicator is illuminated. During a collision, the air bag will not inflate if the indicator is illuminated. Have your passenger reposition themselves in the seat. If the "PASSENGER AIR BAG OFF" indicator remains illuminated after the passenger repositions themselves properly and the vehicle is restarted, have the passenger move to the rear seat because the air bag will not inflate.

#### NOTICE

The "PASSENGER AIR BAG OFF" indicator generally illuminates for about 4 seconds after the Engine Start/Stop button is in the ON position or after the engine is started. However, if the Engine Start/Stop button is turned to the ON position within 3 minutes after ignition OFF, the indicator does not illuminate. If the front passenger seat is occupied, the OCS will then classify the front passenger after several more seconds.

## Do Not Install a Child Restraint in the Front Passenger's Seat



Even though your vehicle is equipped with the OCS, never install a child restraint in the front passenger's seat. An inflating air bag can forcefully strike a child or child restraint resulting in serious or fatal injury.

### ! WARNING

- NEVER place a rear-facing or frontfacing child restraint in the front passenger's seat of the vehicle.
- An inflating frontal air bag could forcefully strike a child resulting in serious injury or death.
- Always properly restrain children in an appropriate child restraint in the rear seat of the vehicle.

## Why Didn't My Air Bag Go Off in a Collision?

Air bags are not designed to inflate in every collision. There are certain types of accidents in which the air bag would not be expected to provide additional protection. These include rear impacts, second or third collisions in multiple impact accidents, as well as low speed impacts. Damage to the vehicle indicates a collision energy absorption, and is not an indicator of whether or not an air bag should have inflated.

### 1 V

#### WARNING

To reduce the risk of an air bag deploying unexpectedly and causing serious injury or death:

- Do not hit or allow any objects to impact the locations where air bags or sensors are installed.
- Do not perform maintenance on or around the air bag sensors. If the location or angle of the sensors is altered, the air bags may deploy when they should not or may not deploy when they should.
- Do not install bumper guards or replace the bumper with a nongenuine HYUNDAI parts. This may adversely affect the collision and air bag deployment performance.
- Press the Engine Start/Stop button to the OFF or ACC position, when the vehicle is being towed to prevent inadvertent air bag deployment.
- Have all air bag repairs performed by an authorized HYUNDAI dealer.

### Air bag collision sensors



- 1. SRS control module / Rollover sensor
- 2. Front impact sensor
- 3. Side impact sensor (Acceleration) (B-PILLAR)
- 4. Side impact sensor (Pressure) (FR DOOR)


#### Air bag inflation conditions



#### Front air bags

Front air bags are designed to inflate in a frontal collision depending on the severity of impact of the front collision.





#### Side and curtain air bags

Side and curtain air bags are designed to inflate when an impact is detected by side collision sensors depending on the severity, speed or angles of impact resulting from a side impact collision.

Although the driver's and front passenger's air bags are designed to inflate in frontal collisions, they also may inflate in other types of collisions if the front impact sensors detect a sufficient impact. Side and curtain air bags are designed to inflate in side impact collisions, but they may inflate in other collisions if the side impact sensors detect a sufficient impact.

Also, the side and curtain air bags are designed to inflate when a rollover is detected by a rollover sensor. (if equipped with rollover sensor)

If the vehicle chassis is impacted by bumps or objects on unimproved roads, the air bags may deploy. Drive carefully on unimproved roads or on surfaces not designed for vehicle traffic to prevent unintended air bag deployment.


#### Air bag non-inflation conditions



In certain low-speed collisions the air bags may not deploy. The air bags are designed not to deploy in such cases because they may not provide benefits beyond the protection of the seat belts.




Front air bags are not designed to inflate in rear collisions, because occupants are moved backward by the force of the impact. In this case, inflated air bags would not provide any additional benefit.




Front air bags may not inflate in side impact collisions, because occupants move in the direction of the collision, and thus in side impacts, front air bag deployment would not provide additional occupant protection.

However, side and curtain air bags may inflate depending on the severity of impact.




In an angled collision, the force of impact may direct the occupants in a direction where the air bags would not be able to provide any additional benefit, and thus the sensors may not deploy any air bags.



Just before impact, drivers often brake heavily. Such heavy braking lowers the front portion of the vehicle causing it to "ride" under a vehicle with a higher ground clearance. Air bags may not inflate in this "underride" situation because deceleration forces that are detected by sensors may be significantly reduced by such "underride" collisions.



Air bags may not inflate if the vehicle collides with objects such as utility poles or trees, where the point of impact is concentrated and the collision energy is absorbed by the vehicle structure.



Front air bags may not inflate in rollover accidents because front air bag deployment would not provide additional occupant protection.

However, the side and curtain air bags may inflate in a rollover situation, when it is detected by the rollover sensor.

#### **SRS Care**

The SRS is virtually maintenance-free and there are no parts you can safely service by yourself. If the SRS air bag warning light does not illuminate when the Engine Start/Stop button is in the ON position, or continuously remains on, have your vehicle immediately inspected by an authorized HYUNDAI dealer.

Any work on the SRS system, such as removing, installing, repairing, or any work on the steering wheel, the front passenger's panel, front seats and roof rails must be performed by an authorized HYUNDAI dealer. Improper handling of the SRS system may result in serious personal injury.



To reduce the risk of serious injury or death take the following precautions:

- Do not attempt to modify or disconnect the SRS components or wiring, including the addition of any kind of badges to the pad covers or modifications to the body structure.
- Do not place objects over or near the air bag modules on the steering wheel, instrument panel, and the front passenger's panel above the glove box.
- Clean the air bag pad covers with a soft cloth moistened with plain water. Solvents or cleaners could adversely affect the air bag covers and proper deployment of the system.
- Always have inflated air bags replaced by an authorized HYUNDAI dealer.
- If components of the air bag system must be discarded, or if the vehicle must be scrapped, certain safety precautions must be observed.
   Consult an authorized HYUNDAI dealer for the necessary information.
   Failure to follow these precautions could increase the risk of personal injury.

#### **Additional Safety Precautions**

Passengers should not move out of or change seats while the vehicle is moving. A passenger who is not wearing a seat belt during a crash or emergency stop can be thrown against the inside of the vehicle, against other occupants, or be ejected from the vehicle.

Do not use any accessories on seat belts. Devices claiming to improve occupant comfort or reposition the seat belt can reduce the protection provided by the seat belt and increase the chance of serious injury in a crash.

#### Do not modify the front seats.

Modification of the front seats could interfere with the operation of the supplemental restraint system sensing components or side air bags.

Do not place items under the front seats. Placing items under the front seats could interfere with the operation of the supplemental restraint system sensing components and wiring harnesses.

Do not cause impact to the doors. Impact to the doors when the Engine Start/Stop button is in the ON or START position may cause the air bags to inflate.

Modifications to accommodate disabilities. If you require modification to your vehicle to accommodate a disability, contact the HYUNDAI Customer Connect Center at 800-633-5151.

#### Adding equipment to or modifying your air bag equipped vehicle

If you modify your vehicle by changing your vehicle's frame, bumper system, front end or side sheet metal or ride height, this may affect the operation of your vehicle's air bag system.

#### Air Bag Warning Labels



OCN7N031135N

Air bag warning labels, required by the U.S. National Highway Traffic Safety Administration (NHTSA), are attached to alert the driver and passengers of potential risks of the air bag system. Be sure to read all of the information about the air bags that are installed on your vehicle in this Owners Manual.

# **4.Instrument Cluster**

Instrument Cluster	4-4
Instrument Cluster Control	4-5
Instrument panel illumination	4-5
Gauges and Meters	4-5
Speedometer	4-5
Tachometer	4-6
Engine Coolant Temperature Gauge	4-6
Fuel Gauge	
Outside Temperature Gauge	4-8
Odometer	
Distance to empty	4-9
Fuel economy (Normal mode)	4-9
CUSTOM mode settings	
Transmission Shift Indicator	4-10
Dual clutch transmission indicator	4-10
Manual transmission indicator	
Warning and Indicator Lights	4-11
Air Bag Warning Light	4-11
Seat Belt Warning Light	
Parking Brake & Brake Fluid Warning Light	4-11
Anti-lock Brake System (ABS) warning light	4-12
Electronic Brake Force Distribution System Warning Light	4-12
Malfunction Indicator Lamp (MIL)	4-13
Charging System Warning Light	4-14
Engine Oil Level Warning Light	
Engine Oil Pressure Warning Light	
Low Fuel Level Warning Light	4-15
Master Warning Light	
Low Tire Pressure Warning Light	
Electronic Stability Control (ESC) Indicator Light	
Electronic Stability Control (ESC) OFF Indicator Light	
Immobilizer Indicator Light (with smart key)	
Turn Signal Indicator Light	
Exterior Light Warning Light	
LED headlight warning light	
High Beam Indicator Light	
Light ON Indicator Light	
Low Beam Indicator Light	
High Beam Assist indicator light	
Forward Safety Warning Light	
Lane Safety Indicator Light	
Driver Attention Warning light	4-19

Intelligent Speed Limit Assist indicator light	4-19
Cruise Indicator Light	4-19
SPORT Mode Indicator Light	4-20
ECO Mode Indicator Light	
N Mode Indicator Light	4-20
CUSTOM Mode Indicator Light	4-20
REV (Rev Matching) Indicator Light	4-20
Icy Road Warning Light	4-20
Cluster Display Messages	
Key not in vehicle	
Key not detected	
Press START button with key	
Press START button again	
Low Key Battery	
Shift to P (for dual clutch transmission)	
Press brake pedal to start engine (for dual clutch transmission)	
Press clutch pedal to start engine (for manual transmission)	
Press START button again	
Check BRAKE SWITCH fuse (for dual clutch transmission)	
Shift to P or N to start engine (for dual clutch transmission)	
Battery discharging due to external electrical devices	
Door, Hood, Trunk open indicator	4-22
Sunroof open indicator	
Lights mode	
Wiper mode	
Low pressure	
Heated Steering Wheel turned off	
Low washer fluid	
Low fuel	
Engine Overheated	
Check headlight (High)	
Check headlight (Low)	
Check turn signal	
Check brake light	
Check daytime running light	
Check high mounted brake light	
Check headlight LED	

# **4.Instrument Cluster**

Cluster Display	4-25
Cluster Display Control	4-25
View Modes	4-26
Driving Assist mode	4-27
Sport view	
Trip computer mode	
Turn By Turn (TBT) mode	
Master warning mode	
Trip Computer	4-31
Trip modes	4-31
Digital speedometer	
Vehicle Settings (Infotainment System)	4-33
Setting Your Vehicle	4-33

### **INSTRUMENT CLUSTER**

■ Normal mode (Type A)



■ N mode (Type B)



The actual cluster in the vehicle may differ from the illustration. For more details, refer to the "Gauges and Meters" in this chapter.

OCN7N043091N/OCN7N041130N

- 1. Tachometer
- 2. Speedometer
- 3. Engine coolant temperature gauge
- 4. Fuel gauge
- 5. Shift light

# **Instrument Cluster Control** *Instrument panel illumination*



OUS4041035L

When the vehicle's parking lights or headlights are on, press the illumination control switch to adjust the brightness of the instrument panel illumination.

When pressing the illumination control switch, the interior switch illumination intensity also adjusted.

You can adjust the brightness of the instrument panel illumination from the Settings menu in the infotainment system. Select:

 Setup > Vehicle > Cluster > Illumination

When the vehicle's parking lights or headlights are on, interior switch illumination intensity and mood lamps are also adjusted.

### *i* Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

### **WARNING**

Never adjust the instrument cluster while driving. This could result in loss of control and lead to an accident that may cause death, serious injury, or vehicle damage.

- The brightness of the instrument panel illumination is displayed.
- If the brightness reaches the maximum or minimum level, a chime will sound.

#### **Gauges and Meters**

#### Speedometer





The speedometer indicates the speed of the vehicle and is calibrated in miles per hour (MPH) and/or kilometers per hour (km/h).

#### **Tachometer**





The tachometer indicates the approximate number of engine revolutions per minute (RPM).

Use the tachometer to select the correct shift points and to prevent lugging and/ or over-revving the engine.

### NOTICE

Do not operate the engine within the tachometer's RED ZONE. This may cause severe engine damage.

#### **Engine Coolant Temperature Gauge**



OCN7040009



This gauge indicates the temperature of the engine coolant when the Engine Start/Stop button is in the ON position.

### NOTICE

If the gauge pointer moves beyond the normal range area toward the "H" position, it indicates overheating that may damage the engine.

Do not continue driving with an overheated engine. If your vehicle overheats, refer to "If the Engine Overheats" in chapter 8.



Never remove the radiator cap when the engine is hot. The engine coolant is under pressure and could cause severe burns. Wait until the engine is cool before adding coolant to the reservoir.

#### Fuel Gauge





This gauge indicates the approximate amount of fuel remaining in the fuel tank.

### Information

- · The fuel tank capacity is given in chapter 2.
- More than 1.5 US gal. (6 liters) of fuel should be added to the vehicle for the fuel gauge to increase.
- The fuel gauge is supplemented by a low fuel warning light, which will illuminate when the fuel tank is nearly empty.
- On inclines or curves, the fuel gauge pointer may fluctuate or the low fuel warning light may come on earlier than usual due to the movement of fuel in the tank.



#### ! CAUTION

If the shift gear is not in P (Park) or N (Neutral) during refueling, the refueling may not be recognized and the fuel amount and distance to empty may be displayed abnormally. (for dual clutch transmission)



#### WARNING

Running out of fuel can expose vehicle occupants to danger.

You must stop and obtain additional fuel as soon as possible after the warning light comes on or when the gauge indicator comes close to the "E (Empty)" level.

#### NOTICE

Avoid driving with an extremely low fuel level. Running out of fuel could cause the engine to misfire damaging the catalytic converter.

#### **Outside Temperature Gauge**



This gauge indicates the current outside air temperatures either in Celsius (°C) or Fahrenheit.

 Temperature range: -40°F ~ 140°F (-40°C ~ 60°C)


The outside temperature on the display may not immediately change like a general thermometer not to distract the driver.

The temperature unit (from °F to °C or from °C to °F) can be changed by:

- Settings menu in the infotainment system screen: Setup → General Settings → Unit → Temperature Unit → °F/°C
- Automatic climate control system:
   While pressing the OFF button, press
   the AUTO button for 3 seconds or
   more

The temperature unit of the instrument cluster and climate control system will change at once.

#### **Odometer**



The odometer indicates the total distance that the vehicle has been driven and should be used to determine when periodic maintenance should be performed.

#### Distance to empty



- The distance to empty is the estimated distance the vehicle can be driven with the remaining fuel.
- If the estimated distance is below 1 mi. (1 km), the trip computer will display "---" as distance to empty.




If the shift gear is not P (Park) or N (Neutral) during refueling, the refueling may not be recognized and the fuel amount and distance to empty may be displayed abnormally. (for dual clutch transmission)

### *i* Information

- If the vehicle is not on level ground or the battery power has been interrupted, the fuel amount and range function may not operate correctly.
- The distance to empty may differ from the actual driving distance as it is an estimate of the available driving distance.
- The distance to empty and fuel amount increases when refueling more than 1.5 US gal. (6 liters).
- The distance to empty may vary significantly based on driving conditions, driving habits, and condition of the vehicle.

#### Fuel economy (Normal mode)



OCN7N041114N

The average fuel economy (1) and instant fuel economy (2) is displayed at the bottom of the cluster.

#### **Automatic reset**

To automatically reset the average fuel economy, select between "After Ignition" or "After Refueling" from the Settings menu in the infotainment system screen.

#### **CUSTOM** mode settings



OCN7N041136N


The main settings of CUSTOM mode is displayed at the bottom of the cluster. The CUSTOM mode can be set on the infotainment system.

### Information

For more details on the CUSTOM mode, refer to "Drive Mode Integrated Control System" section in chapter 6.

#### **Transmission Shift Indicator**

#### **Dual clutch transmission indicator**





This indicator displays which shift lever position is selected.

Park: PReverse: RNeutral: N

• Drive: D1, D2, D3, D4, D5, D6, D7, D8

• Manual shift mode: 1, 2, 3, 4, 5, 6, 7, 8

#### Manual transmission indicator





- 1. Current shift lever position
- 2. Transmission shift indicator

This indicator informs which gear is recommended while driving, to save fuel.

- Shifting up : ▲2, ▲3, ▲4, ▲5, ▲6
- Shifting down: ▼1, ▼2, ▼3, ▼4, ▼5
   For example
- : Indicates that shifting up to the 3rd gear is recommended (currently the shift lever is in the 2nd or 1st gear).
- : Indicates that shifting down to the 3rd gear is recommended (currently the shift lever is in the 4th, 5th, or 6th gear).

When the system is not working properly, the indicator is not displayed.

#### **Warning and Indicator Lights**



#### *i* Information

Make sure that all warning lights are OFF after starting the engine. If any light is still ON, this indicates a situation that needs attention.

#### Air Bag Warning Light



This warning light illuminates:

- When you set the Engine Start/Stop button to the ON position.
  - The air bag warning light illuminates for about 6 seconds and then turns off when all checks have been performed
- The air bag warning light will remain illuminated if there is a malfunction with the Safety Restraint System (SRS) air bag operation.

In this case, have the vehicle inspected by an authorized HYUNDAI dealer.

#### Seat Belt Warning Light



This warning light informs the driver that the seat belt is not fastened.

For more information, refer to "Seat Belts" in chapter 3.

#### Parking Brake & Brake Fluid Warning Light



This warning light illuminates:

- When you set the Engine Start/Stop button to the ON position.
  - The parking brake light illuminates for about 3 seconds and will then turn off once the parking brake is released.
- Whenever the parking brake is applied.
- Whenever the brake fluid level in the reservoir is low.
  - If the warning light illuminates with the parking brake released, it indicates that the brake fluid level in the reservoir is low.

If the brake fluid level in the reservoir is low:

- 1. Drive carefully to the nearest safe location and stop your vehicle.
- 2. With the engine stopped, check the brake fluid level immediately and add fluid as required (For more information, refer to "Brake Fluid" in chapter 9). After adding brake fluid, check all brake components for fluid leaks. If a brake fluid leak is found, or if the warning light remains on, or if the brakes do not operate properly, do not drive the vehicle. Have the vehicle inspected by an authorized HYUNDAI dealer.

#### **Dual-diagonal braking system**

Your vehicle is equipped with dualdiagonal braking systems. This means you still have braking on two wheels even if one of the dual systems should fail.

With only one of the dual systems working, more than normal pedal travel and greater pedal pressure are required to stop the vehicle.

Also, the vehicle will not stop in as short a distance with only a portion of the brake system working.

If the brakes fail while you are driving, shift to a lower gear for additional engine braking and stop the vehicle as soon as it is safe to do so.



#### WARNING

Parking Brake & Brake Fluid Warning Light

Driving the vehicle with a warning light ON is dangerous. If the Parking Brake & Brake Fluid Warning Light illuminates with the parking brake released, it indicates that the brake fluid level is low.

In this case, have the vehicle inspected by an authorized HYUNDAI dealer.

#### Anti-lock Brake System (ABS) warning light



This warning light illuminates:

- When you set the Engine Start/Stop button to the ON position.
  - It illuminates for approximately 3 seconds and then goes off.
- When there is a malfunction with the ABS (The normal braking system will still be operational without the assistance of the anti-lock brake system).

In this case, have the vehicle inspected by an authorized HYUNDAI dealer.

Electronic Brake Force Distribution System Warning Light





These two warning lights illuminate at the same time while driving:

 When the ABS and regular brake system may not work normally.

In this case, have the vehicle inspected by an authorized HYUNDAI dealer

### **⚠** WARNING

Electronic Brake Force Distribution System Warning Light

When both ABS and Parking Brake & Brake Fluid Warning Lights are on, the brake system will not work normally and you may experience an unexpected and dangerous situation during sudden braking.

In this case, avoid high speed driving and abrupt braking.

Have the vehicle inspected by an authorized HYUNDAI dealer as soon as possible.

### Information

**Electronic Brake Force Distribution System Warning Light** 

When the ABS Warning Light is on or both ABS and Parking Brake & Brake Fluid Warning Lights are on, the speedometer, odometer, or tripmeter may not work. Also, the MDPS Warning Light may illuminate and the steering effort may increase or decrease.

In this case, have the vehicle inspected by an authorized HYUNDAI dealer as soon as possible.

## Malfunction Indicator Lamp (MIL)



This warning light illuminates:

- When you set the Engine Start/Stop button to the ON position.
  - The malfunction indicator light illuminates for about 3 seconds and then goes off.
- Whenever there is a malfunction with either the emission control system or the engine or the vehicle powertrain.
   If this occurs, have the vehicle inspected by an authorized HYUNDAI dealer.

#### NOTICE

Driving with the Malfunction Indicator Lamp (MIL) on may cause damage to the emission control system which could affect drivability and/or fuel economy.

#### **NOTICE**

If the Malfunction Indicator Lamp (MIL) illuminates, potential catalytic converter damage is possible which could result in loss of engine power.

In this case, have the vehicle inspected by an authorized HYUNDAI dealer as soon as possible.

#### Charging System Warning Light



This warning light illuminates:

 When there is a malfunction with either the alternator or electrical charging system

If there is a malfunction with either the alternator or electrical charging system:

- 1. Drive carefully to the nearest safe location and stop your vehicle.
- Turn the engine off and check the alternator drive belt for looseness or breakage.

If the belt is adjusted properly, there may be a problem in the electrical charging system.

In this case, have the vehicle inspected by an authorized HYUNDAI dealer as soon as possible.

#### Engine Oil Level Warning Light



The engine oil level warning light illuminates when the engine oil level should be checked.

If the warning light comes on, check the engine oil level as soon as possible and add engine oil as required.

Slowly pour the recommended oil little by little into a funnel. (Oil refill capacity : approximately  $0.6 \sim 1.0 \ \ell$ )

Use only the specified engine oil. (Refer to "Recommended lubricants and capacities" in chapter 2.)

Do not overfill the engine oil. Make sure the oil level is not above F (Full) mark on the dipstick.

### i

#### Information

- If you travel about 30 ~ 60 miles (50 km ~100 km) after the engine warms up, after adding the engine oil, the warning light will go off.
- Cycle the ignition from OFF to ON 3 times within 10 seconds, the warning light will go off immediately. However, when you turn off the warning light without adding the engine oil, the light will come on again after traveling approximately 30 ~ 60 miles (50 ~ 100 km) after the engine warms up.

#### NOTICE

If the light comes on continuously after adding the engine oil and travelling about 30 ~ 60 miles (50~100 km) after the engine warms up, have the system checked by an authorized HYUNDAI dealer.

Even if this light doesn't come on after the engine has started, the engine oil level should be periodically checked and topped up if required.

#### Engine Oil Pressure Warning Light



This warning light illuminates: When the engine oil pressure is low.

If the engine oil pressure is low:

- 1. Drive carefully to the nearest safe location and stop your vehicle.
- Turn the engine off and check the engine oil level (For more information, refer to "Engine Oil" in chapter 9). If the level is low, add oil as required.
   If the warning light remains on after adding oil or if oil is not available, have the vehicle inspected by an authorized HYUNDAI dealer as soon as possible. Continued driving with the warning light on may cause engine failure.

#### NOTICE

If the engine is not turned OFF immediately after the Engine Oil Pressure Warning Light is illuminated, severe damage could occur.

#### Low Fuel Level Warning Light



This warning light illuminates:
When the fuel tank is nearly empty. Add fuel as soon as possible.

#### NOTICE

Driving with the Low Fuel Level warning light on or with the fuel level below "E(Empty)" can cause the engine to misfire and damage the catalytic converter (if equipped).

#### Master Warning Light



This warning light illuminates:

When there is a malfunction in operation in any of the following systems:

- Forward Collision-Avoidance Assist system malfunction (if equipped)
- Blind-Spot Collision-Avoidance Assist malfunction (if equipped)
- Blind-Spot Collision-Avoidance Assist radar blocked (if equipped)
- High Beam Assist malfunction
- Lamp malfunction (if equipped)
- Tire Pressure Monitoring System (TPMS) malfunction
- LED head light malfunction (if equipped)

To identify the details of the warning, look at the cluster display.

#### Low Tire Pressure Warning Light



This warning light illuminates:

- When you set the Engine Start/Stop button to the ON position.
  - It illuminates for approximately 3 seconds and then goes off.
- When one or more of your tires are significantly underinflated. (The location of the underinflated tires is displayed on the cluster display.)

For more information, refer to "Tire Pressure Monitoring System (TPMS)" in chapter 8.

This warning light remains ON after blinking for about 60 seconds, or repeatedly blinks ON and OFF in 3 second intervals

When there is a malfunction with the TPMS.

In this case, have the vehicle inspected by an authorized HYUNDAI dealer as soon as possible.

For more information, refer to "Tire Pressure Monitoring System (TPMS)" in chapter 8.



#### WARNING

#### Safe Stopping

- The TPMS cannot alert you to severe and sudden tire damage caused by external factors.
- · If you notice any vehicle instability, immediately take your foot off the accelerator pedal, apply the brakes gradually with light force, and slowly move to a safe position off the road.

#### **Electronic Stability Control** (ESC) Indicator Light



This indicator light illuminates:

- When you set the Engine Start/Stop button to the ON position.
  - The Electronic Stability Control indicator light illuminates for about 3 seconds and then goes off.
- Whenever there is a malfunction with the ESC system.

If this occurs, have the vehicle inspected by an authorized HYUNDAI dealer

This indicator light blinks:

While the ESC is operating.

For more information, refer to "Electronic Stability Control (ESC)" in chapter 6.

#### **Electronic Stability Control** (ESC) OFF Indicator Light



This indicator light illuminates:

- When you set the Engine Start/Stop button to the ON position.
  - It illuminates for approximately 3 seconds and then goes off.
- · When you deactivate the ESC system by pressing the ESC OFF button.

For more information, refer to "Electronic Stability Control (ESC)" in chapter 6.

#### Immobilizer Indicator Light (with smart key) (if equipped)



This indicator light illuminates for up to 30 seconds:

When the vehicle detects the smart key in the vehicle with the Engine Start/Stop button in the ACC or ON position.

- Once the smart key is detected, you can start the engine.
- The indicator light goes off after starting the engine.

This indicator light blinks for a few seconds: When the smart key is not in the vehicle.

- If the smart key is not detected, you cannot start the engine.

### This indicator light illuminates for 2 seconds and goes off:

If the smart key is in the vehicle and the Engine Start/Stop button is ON, but the vehicle cannot detect the smart key.

In this case, have the vehicle inspected by an authorized HYUNDAI dealer.

#### This indicator light blinks:

When there is a malfunction with the immobilizer system.

In this case, have the vehicle inspected by an authorized HYUNDAI dealer.

#### Turn Signal Indicator Light



This indicator light blinks:

When you operate the turn signal indicator stalk.

If any of the following occur, there may be a malfunction with the turn signal system.

- The turn signal indicator light illuminates but does not blink
- The turn signal indicator light blinks rapidly
- The turn signal indicator light does not illuminate at all

If any of these conditions occur, have your vehicle inspected by an authorized HYUNDAI dealer.

## Exterior Light Warning Light (if equipped)



This warning light illuminates:

 When one of the exterior bulbs (headlight, DRL, turn signal light, stop light, etc) is not operating properly.
 One of the bulbs may need to be replaced.

### *i* Information

Make sure to replace the burned out bulb with a new one of the same wattage rating.

## LED headlight warning light (if equipped)



This warning light illuminates:

- When you set the Engine Start/Stop button to the ON position.
  - The LED headlight warning light illuminates for approximately 3 seconds and then goes off.
- Whenever there is a malfunction with the LED headlight.

If this occurs, have your vehicle inspected by an authorized HYUNDAI dealer.

#### NOTICE

Continuous driving with the LED Headlight warning light on or blinking can reduce LED headlight life.

#### High Beam Indicator Light



This indicator light illuminates:

- When the headlights are on and in the high beam position.
- When the turn signal lever is pulled into the Flash-to-Pass position.

#### Light ON Indicator Light



This indicator light illuminates: When the tail lights or headlights are on.

## Low Beam Indicator Light (if equipped)



This indicator light illuminates:

When the headlights are on.

#### High Beam Assist indicator light



This indicator light illuminates:

When the High Beam is on with the light switch in the AUTO light position.

- White: When High Beam Assis is ready to operate.
- Green: When High Beam Assist is operating.

If your vehicle detects oncoming or preceding vehicles, High Beam Assist will switch the high beam to low beam automatically.

For more information, refer to "High Beam Assist (HBA)" in chapter 5.

#### Forward Safety Warning Light



The warning light illuminates:

- When the Engine Start/Stop button is in the ON position. It illuminates for about 3 seconds and then goes off.
- Yellow: When Forward Safety of Forward Collision-Avoidance Assist is deselected, disabled, or a malfunction is detected.
  - If the yellow warning light remains on after the sensor has been uncovered or unblocked when Forward Safety is set, have your vehicle inspected by an authorized HYUNDAI dealer.

This warning light blinks:

Red: When Forward Safety function is operating.

For more information, refer to "Forward Collision-Avoidance Assist (FCA)" in chapter 7.

#### Lane Safety Indicator Light



#### This indicator light illuminates:

- When the Engine Start/Stop button is in the ON position. It illuminates for about 3 seconds and then goes off.
- Gray: When Lane Keeping Assist operating conditions are not satisfied.
- Green: When Lane Keeping Assist operating conditions are satisfied.
- Yellow: When Lane Safety is disabled or a malfunction is detected.
  - If the yellow warning light remains on after the sensor has been uncovered or unblocked when Lane Safety is set, have your vehicle inspected by an authorized HYUNDAI dealer.

#### The indicator light blinks:

Green: When Lane Keeping Assist is operating.

In this case, have your vehicle inspected by an authorized HYUNDAI dealer.

For more information, refer to "Lane Keeping Assist (LKA)" in chapter 7.

#### Inattentive Driving Driver Attention Warning light



#### This indicator light illuminates:

- When the Engine Start/Stop button is in the ON position. It illuminates for about 3 seconds and then goes off.
- Yellow: When Driver Attention Warning is disabled or a malfunction is detected.

If the yellow indicator light remains on after the front view camera has been uncovered or unblocked, have your vehicle inspected by an authorized HYUNDAI dealer.

#### This indicator light blinks:

Yellow: Driver Attention Warning recommends to take a break.

For more details, refer to "Driver Attention Warning (DAW)" in chapter 7.

## Intelligent Speed Limit Assist indicator light



#### This indicator light illuminates:

- When the Engine Start/Stop button is in the ON position. It illuminates for about 3 seconds and then goes off.
- Yellow: When Intelligent Speed Limit Assist is disabled or a malfunction is detected. If the yellow indicator light remains on after the front view camera has been uncovered or unblocked, have your vehicle inspected by an authorized HYUNDAI dealer.

#### Cruise Indicator Light

**€** CRUISE

This indicator light illuminates:

• When Cruise Control is enabled. For more details, refer to "Cruise Control (CC)" in chapter 7.

## SPORT Mode Indicator Light (if equipped)

SPORT

This indicator light illuminates:

 When you select "SPORT" mode as drive mode.

For more details, refer to "Drive Mode Integrated Control System" in chapter 6.

## ECO Mode Indicator Light (if equipped)

ECO

This indicator light illuminates:

 When you select "ECO" mode as drive mode.

For more details, refer to "Drive Mode Integrated Control System" in chapter 6.

#### N Mode Indicator Light



This indicator light illuminates:

When you select "N" mode as drive mode

For more details, refer to "Drive Mode Integrated Control System" in chapter 6.

#### CUSTOM Mode Indicator Light

сиѕтом

This indicator light illuminates:

 When you select "CUSTOM" mode as drive mode.

For more details, refer to "Drive Mode Integrated Control System" in chapter 6.

#### REV (Rev Matching) Indicator Light (if equipped)

**REV** 

This indicator light illuminates:

- [White] When Rev Matching is turn on in NORMAL mode.
- [Yellow] When Rev Matching is turned on in SPORT mode.
- [Red] When Rev Matching is turned on in N mode.

For more details, refer to "Rev Matching" in chapter 6.

## Icy Road Warning Light (if equipped)



This indicator light illuminates:

This warning light is to warn the driver the road may be icy.

When the temperature on the outside temperature gauge is approximately below 40°F (4°C), the Icy Road Warning Light and Outside Temperature Gauge blinks and then illuminates. Also, the warning chime sounds 1 time.

You can activate or deactivate lcy Road Warning function from the Settings menu in the infotainment system screen.

### i

#### Information

If the icy road warning light appears while driving, you should drive more attentively and safely, refraining from over-speeding, rapid acceleration, sudden braking or sharp turning, etc.

#### **Cluster Display Messages**

#### Key not in vehicle

This warning message is displayed if the smart key is not in the vehicle when you open or close door in the ACC position or ON position. The warning sound is heard when you close door without a smart key in vehicle.

When attempting to start the vehicle always have the smart key with you.

#### Key not detected

This warning message is displayed if the smart key is not detected when you press the Engine Start/Stop button.

#### Press START button with key

This warning message is displayed if you press the Engine Start/Stop button while the warning message "Key not detected" is displayed.

At this time, the immobilizer indicator light blinks.

#### Press START button again

This message is displayed if you were unable to start the vehicle when the Engine Start/Stop button was pressed.

If this occurs, attempt to start the engine by pressing the Engine Start/Stop button again.

If the warning message appears each time you press the Engine Start/Stop button, have your vehicle inspected by an authorized HYUNDAI dealer.

#### Low Key Battery

This warning message is displayed if the battery of the smart key is discharged while changing the Engine Start/Stop button to the OFF position.

## Shift to P (for dual clutch transmission)

This warning message is displayed if you try to turn off the engine without the shift lever in P (Park) position.

At this time, the Engine Start/Stop button turns to the ACC position (If you press the Engine Start/Stop button once more, it will turn to the ON position).

## Press brake pedal to start engine (for dual clutch transmission)

This warning message is displayed if the Engine Start/Stop button changes to the ACC position twice by pressing the button repeatedly without depressing the brake pedal.

You can start the vehicle by depressing the brake pedal.

## Press clutch pedal to start engine (for manual transmission)

This warning message is displayed if the Engine Start/Stop button is in the ACC position twice by pressing the button repeatedly without depressing the clutch pedal.

Depress the clutch pedal to start the engine.

#### Press START button again

This message is displayed if you were unable to start the vehicle when the Engine Start/Stop button was pressed.

If this occurs, attempt to start the engine by pressing the Engine Start/ Stop button again.

If the warning message appears each time you press the Engine Start/Stop button, have your vehicle inspected by an authorized HYUNDAI dealer.

## Check BRAKE SWITCH fuse (for dual clutch transmission)

This warning message is displayed if the brake switch fuse is disconnected.

You need to replace the fuse with a new one. If that is not possible, you can start the engine by pressing the Engine Start/Stop button for 10 seconds in the ACC position.

## Shift to P or N to start engine (for dual clutch transmission)

This warning message is displayed if you try to start the engine with the shift lever not in the P (Park) or N (Neutral) position.



You can start the engine with the shift lever in the N (Neutral) position. But, for your safety, we recommend that you start the engine with the shift lever in the P (Park) position.

## Battery discharging due to external electrical devices (if equipped)

This message is displayed if the battery voltage is weak due to any non-factory electrical accessories (ex. dashboard camera) while parking. Be careful that the battery is not discharged.

If the warning message appears after removing the non-factory electrical accessories, have the vehicle inspected by an authorized HYUNDAI dealer.

#### Door, Hood, Trunk open indicator



OCN7040017


This warning is displayed indicating which door, or hood, or trunk is open.



#### **CAUTION**

Before driving the vehicle, you should confirm that the door/ hood/trunk are fully closed. Also, check there is no door/hood/ trunk open warning light or message displayed on the instrument cluster.

#### Sunroof open indicator (if equipped)



OCN7040018

This warning is displayed if you turn off the engine when the sunroof is open. Close the sunroof securely when leaving your vehicle.

#### Lights mode



This indicator displays which exterior light is selected using the lighting control.

#### Wiper mode



This indicator displays which wiper speed is selected using the wiper control.

#### Low pressure



This warning message is displayed if the tire pressure is low. The corresponding tire on the vehicle will be illuminated.

For more details, refer to "Tire Pressure Monitoring System (TPMS)" in chapter 8.

#### Low washer fluid (if equipped)

This warning message is displayed if the washer fluid level in the reservoir is nearly empty.

Have the washer fluid reservoir refilled.

#### Low fuel

This warning message is displayed if the fuel tank is almost out of fuel.

When this message is displayed, the low fuel level warning light in the cluster will come on.

It is recommended to look for the nearest fueling station and refuel as soon as possible.

#### Engine Overheated (if equipped)

This warning message is displayed when the engine coolant temperature is above 248°F (120°C). This means that the engine is overheated and may be damaged.

If your vehicle is overheated, refer to "Overheating" in chapter 8.

#### Check headlight (High) (if equipped)

This warning message is displayed if the headlights are not operating properly.

In addition, if a specific light (turn signal light etc.) is not operating properly, the warning message according to a specific light (turn signal light etc.) is displayed. A corresponding bulb may need to be replaced.

Make sure to replace the burned out bulb with a new one of the same wattage rating.

#### Check headlight (Low) (if equipped)

This warning message is displayed if the headlight (Low) are not operating properly.

In addition, if a specific light (turn signal light etc.) is not operating properly, the warning message according to a specific light (turn signal light etc.) is displayed. A corresponding bulb may need to be replaced.

Make sure to replace the burned out bulb with a new one of the same wattage rating

#### Check turn signal (if equipped)

This warning message is displayed if the turn signal lights are not operating properly. A light may need to be replaced.

Make sure to replace the burned out bulb with a new one of the same wattage rating.

#### Check brake light (if equipped)

This warning message is displayed if the stop lights are not operating properly. A light may need to be replaced.

Make sure to replace the burned out bulb with a new one of the same wattage rating.

# Check daytime running light (if equipped)

This warning message is displayed if the daytime running lights are not operating properly. A light may need to be replaced.

Make sure to replace the burned out bulb with a new one of the same wattage rating.

## Check high mounted brake light (if equipped)

This warning message is displayed if the high mounted stop light are not operating properly. A light may need to be replaced.

Make sure to replace the burned out bulb with a new one of the same wattage rating.

#### Check headlight LED (if equipped)

This warning message is displayed if there is a problem with the LED headlight. Have the vehicle inspected by an authorized HYUNDAI dealer.

#### **CLUSTER DISPLAY**

## **Cluster Display Control**



The cluster display modes can be changed by using the control buttons.

Switch	Function	
自	MODE button for changing modes	
$\wedge$ , $\vee$	MOVE switch for changing items	
OK	SELECT/RESET button for setting or resetting the selected item	

#### **View Modes**

View modes	Symbol	Explanation
Driving Assist		This mode displays the state of: - Lane Keeping Assist - Blind-Spot Collision-Avoidance Assist For more information, refer to "Lane Keeping Assist (LKA)", "Blind-Spot Collision-Avoidance Assist (BCA)" in chapter 7.
Sport	132	The Sport menu displays Oil Temp./Engine Temp., Turbo/ Torque, Lap Timer and G-Force. For more details, refer to the following pages.
Trip Computer		This mode displays driving information such as the tripmeter, fuel economy, etc.  For more details, refer to "Trip Computer" in this chapter.
Turn By Turn (TBT)	t	This mode displays the state of the navigation.
Warning	<u> </u>	<ul><li>This mode displays warning messages related to the system malfunction, etc.</li><li>Tire pressure information</li></ul>

The information provided may differ depending on which functions are applicable to your vehicle.

#### **Driving Assist mode**



#### LKA/BCA

This mode displays the state of Lane Keeping Assist and Blind-Spot Collision-Avoidance Assist.

For more details, refer to each function information in chapter 7.

#### Sport view



Oil Temp./Engine Temp.

This mode displays information related to your engine such as oil temperature (1) and engine temperature (2).



OCN7N041137N

#### Turbo/Torque

This mode displays information related to your engine such as turbo (3) and torque (4).





OBC3N040027

#### Lap timer

- (1) Best lap
- (2) Current lap

#### To start (A)

Press the OK button shortly on the steering wheel. The lap timer will start counting the current lap (2).

#### To stop (B)

Press and hold the OK button for more than 1 second on the steering wheel while the lap timer is counting the current lap (2).



#### To reset (C):

Press and hold the OK button for more than 1 second on the steering wheel when the lap timer has stopped counting the current lap (2).

#### To save laps:

Press the OK button shortly on the steering wheel while the lap timer is counting the current lap (2).

From best lap (1) to No.4 lap (3) will be displayed.

Press the OK button for more than 1 second on the steering wheel to reset the lap. Then the driver can start a new lap.

## *i* Information

Lap timer can be activated regardless of the mode settings (Drive mode or N mode).

#### NOTICE

If the N1(N2) button is set to 'Start lap timer', the N2(N1) button is automatically set to 'Stop & Reset lap timer' from the infotainment system. Then the driver can operate lap timer using the N1/N2 buttons as the one pair.

## *i* Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.



#### **G-Force**

This mode displays the force delivered to the vehicle laterally while the vehicle is in motion.


#### Trip computer mode



OOSN041024N


The trip computer mode displays information related to vehicle driving parameters including fuel economy, tripmeter information and vehicle speed. For more information, refer to "Trip Computer" in this chapter.

#### Turn By Turn (TBT) mode



Turn-by-turn navigation, distance/time to destination information is displayed when Turn by Turn view is selected.

#### Master warning mode



This warning light informs the driver the following situations.

- Forward Collision-Avoidance Assist malfunction
- Blind-Spot Collision-Avoidance Assist malfunction (if equipped)
- Blind-Spot Collision-Avoidance Assist radar blocked (if equipped)
- LED headlight malfunction (if equipped)
- High Beam Assist malfunction
- Tire Pressure Monitoring System (TPMS) malfunction

The Master Warning Light illuminates if one or more of the above warning situations occur.

If the warning situation is solved, the master warning light will be turned off and the Master Warning icon will disappear.



**Tire Pressure** 

This mode displays information related to Tire Pressure.

For more details, refer to "Tire Pressure Monitoring System (TPMS)" in chapter 8.

#### **Trip Computer**

The trip computer is a microcomputercontrolled driver information system that displays information related to driving.



#### Information

Some driving information stored in the trip computer (for example Average Vehicle Speed) resets if the battery is disconnected.

#### Trip modes

# Current Trip Trip distance Total driving time Average Fuel Economy Since Refueling Trip distance Total driving time Average Fuel Economy Since Reset Trip distance Total driving time Average Fuel Economy

Digital speedometer



To change the trip mode, toggle the "\wedge, \widensighty" switch on the steering wheel.



#### **Current Trip**

Trip distance (1), average fuel economy (2), and total driving time (3) are displayed.

The information is combined for each ignition cycle. However, when the engine has been OFF for 3 minutes or longer the Current Trip screen will reset.

To reset manually, press the OK switch on the steering wheel for more than 1 second when 'Current Trip' is displayed.



#### Since refueling

Trip distance (1), total driving time (2), and average fuel economy (3) after the vehicle has been refueled are displayed.

To reset manually, press the OK switch on the steering wheel for more than 1 second when 'Since Refueling' is displayed.



#### Since Reset

Accumulated trip distance (1), total driving time (2), and average fuel economy (3) are displayed.

The information is accumulated starting from the last reset.

To reset manually, press the OK switch on the steering wheel for more than 1 second when 'Since Reset' is displayed.



### Information

The vehicle must be driven for a minimum of 0.19 miles (300 meters) since the last Engine Start/Stop button cycle before the average fuel economy will be recalculated.

#### Digital speedometer



This message shows the speed of the vehicle.

#### **VEHICLE SETTINGS (INFOTAINMENT SYSTEM)**

Vehicle Settings in the infotainment system provides user options for a variety of settings including door lock/ unlock features, convenience features, driver assistance settings, etc.



#### Vehicle Settings menu


- Driver Assistance
- Cluster
- Climate
- Light
- Door
- Convenience

The information provided may differ depending on which features are applicable to your vehicle.



Do not operate the Vehicle Settings while driving. This may cause distraction resulting in an accident.

#### **Setting Your Vehicle**



1. Press the SETUP button on the main keyboard.



2. Select 'Vehicle' to change the Vehicle Settings.

## *i* Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

# **5. Convenience Features**


Smart key	
Locking	5-4
Unlocking your vehicle (When the Two Press Unlock feature is off)	
Unlocking your vehicle (When the Two Press Unlock feature is on)	
Trunk Unlocking	
Panic Button	
Remotely Starting Vehicle	
Start-upMechanical Key	
Loss of a Smart Key	
Smart Key Precautions	
Battery Replacement	
Immobilizer System	
Hyundai Digital Key	
Digital Key (Smartphone)	
Digital Key (Card Key)	
Used Vehicle/Digital Key Maintenance	
Limitations of the System	
Door Locks	5-22
Operating Door Locks from Outside the Vehicle	
Operating Door Locks from Inside the Vehicle	5-23
Automatic Door Lock and Unlock Features	
Child-Protector Rear Door Locks	5-26
Rear Occupant Alert (ROA)	5-27
Rear Occupant Alert Operation	
Theft-Alarm System	5-28
Steering Wheel	5-29
Motor Driven Power Steering (MDPS)	
Tilt Steering / Telescope Steering	
Horn	5-30
Mirrors	5-31
Inside Rearview Mirror	
Side View Mirrors	
Windows	5-44
Power Windows	

Sunroof	
Sunshade	5-49
Tilt Open/Close	5-50
Slide Open/Close	5-50
Automatic Reversal	5-51
Resetting the Sunroof	5-52
Sunroof Open Warning	5-52
Hood	5-53
Trunk	5-55
Emergency Trunk Safety Release	5-56
Smart Trunk Release	5-57
Fuel filler door	5-60
Exterior Lights	5-62
Lighting Control	
High Beam Operation	
Turn Signals And Lane Change Signals	
Battery Saver Function	
Headlight Delay Function	5-65
High Beam Assist (HBA)	5-66
Detecting Sensor	
High Beam Assist Settings	5-66
High Beam Assist Operation	5-66
High Beam Assist Malfunction and Limitations	5-67
Interior Lamps	5-69
Interior Lamp AUTO Cut	5-69
Front Lamps	5-69
Mood lighting	5-70
Rear Lamp	5-70
Luggage Compartment Lamp	5-71
Vanity Mirror Lamp	5-71
Welcome System	
Wipers and Washers	5-73
Windshield wipers	5-73
Windshield Washers	5-74
Manual Climate Control System	
Heating and Air Conditioning	5-76
System Operation	
System Maintenance	5-84

# **5. Convenience Features**

Automatic Climate Control System	5-86
Automatic Heating and Air Conditioning	5-87
Manual Heating and Air Conditioning	
System Operation	
System Maintenance	5-96
Windshield defrosting and defogging	5-98
Manual Climate Control System	5-98
Automatic Climate Control System	
Defogging Logic	
Auto Defogging System (only for automatic climate control system)	
Defroster	
Climate control additional features	5-103
Sunroof Inside Air Recirculation	
Automatic Ventilation	5-103
Storage compartment	5-104
Center Console Storage	
Glove Box	5-104
Interior Features	5-105
Cup Holder	
Sunvisor	
Power Outlet	5-106
USB charger	5-107
Wireless Smartphone Charging System	5-107
Clock	
Coat Hook	5-110
Infotainment System	5-111
USB Port	
Antenna	
Steering Wheel Audio Control	
Infotainment System	
Voice Recognition	
Bluetooth® Wireless Technology Hands-free	
How Vehicle Radio Works	5-114

#### **SMART KEY**



Your HYUNDAI uses a smart key, which you can use to lock or unlock a door (and trunk) and even start the engine.

- 1. Door Lock
- 2. Door Unlock
- 3. Trunk unlock
- 4. Panic
- 5. Remote start (DCT models only)

#### Locking



#### To lock:

- 1. Close all doors, engine hood and trunk.
- 2. Carry the smart key.
- Either press the door handle button or press the Door Lock button (1) on the smart key.
- 4. The hazard warning lights will blink.
- 5. Make sure the doors are locked by pulling the door outside handle.

## *i* Information

The door handle button will only operate when the smart key is within  $28\sim40$  in.  $(0.7\sim1 \text{ m})$  from the outside door handle.


Even though you press the outside door handle button, the doors will not lock and the chime will sound for three seconds if any of the following occur:


- · The smart key is in the vehicle.
- The Engine Start/Stop button is in ACC or ON position.
- · Any door except the trunk is open.

## **WARNING**

Do not leave the smart key in your vehicle with unsupervised children. Unattended children could press the Engine Start/ Stop button and may operate power windows or other controls, or even make the vehicle move, which could result in serious injury or death.

#### Unlocking your vehicle (When the Two Press Unlock feature is off)





- 1. Make sure you have the smart key in your possession.
- 2. Press the Door Unlock button (2) on the smart key, press the button on the front door handle or touch the door unlock sensor inside of the front door handle to unlock the doors.
- All of the doors will unlock. When the doors unlock, the hazard warning lights will blink two times.
- The door handle button will only operate when the smart key is within 28~40 inches (0.7~1 m) from the outside door handle.
- If you do not open the door after unlocking within 30 seconds, it will return to the lock mode.
- If you unlocked the door with the door handle, the doors cannot be locked with the sensor for up to 2 seconds.

#### Unlocking your vehicle (When the Two Press Unlock feature is on)

- 1. Make sure you have the smart key in your possession.
- Press the Door Unlock button (2) on the smart key, press the button on the front door handle or touch the door unlock sensor inside of the front door handle to unlock the doors.
- 3. The driver's door will unlock.
- 4. If you press the button on the front door handle or touch the door unlock sensor inside of the front door handle to unlock the doors within 4 seconds, all of the doors unlock. When the doors unlock, the hazard warning lights will blink two times.
- The door handle button will only operate when the smart key is within 28~40 inches (0.7~1 m) from the outside door handle.
- If you do not open the door after unlocking within 30 seconds, it will return to the lock mode.
- The factory default setting is in off mode so you should set in the User's Settings mode.
- If you unlocked the door with the door handle, the doors cannot be locked with the sensor for up to 2 seconds.

#### Two Press Unlock Feature

The priority for unlocking the driver door only, or unlocking all the doors with one press may be adjusted in the Settings menu in the infotainment system.

The Two Press Unlock feature, when enabled, will require the user to press the door unlock button once for driver door only and twice for unlocking all the doors.

Select or Deselect the Two Press Unlock feature in the Settings menu in the infotainment system. The option can be found under the following menu:

Setup → Vehicle → Door → Two Press

## Information

If you press the front passenger outside door handle with the smart key in your possession, all the doors will unlock.

# Setting the door lock/unlock prevention feature (if equipped)

The doors may lock or unlock if the touch sensor of the outside door handle is recognized while washing your vehicle or due to heavy rain.

To prevent unintentional door lock or unlock:

Press the lock button on the smart key and immediately press the unlock button along with the lock button for more than 4 seconds. The hazard warning lights blink four times. At this time, the doors do not lock or unlock even though the touch sensor is touched on the outside door handle. To deactivate the function, press the door lock or unlock button on the smart key.

#### **Trunk Unlocking**

To unlock:

- 1. Carry the smart key.
- Either press inside the trunk emblem or press the Trunk Unlock button (4) on the smart key for more than one second.
- 3. The hazard warning lights will blink two times.

Once the trunk is opened and then closed, the trunk will lock automatically.

## Information

After unlocking the trunk, the trunk will lock automatically after 30 seconds unless the trunk is opened.

#### **Panic Button**

Press and hold the Panic button (5) for more than one second. The horn sounds and hazard warning lights blink for about 30 seconds. To cancel the panic mode, press any button on the Smart Key.

# Remotely Starting Vehicle (if equipped)

You can start the vehicle using the Remote Start button (3) on the smart key.

To start the vehicle remotely:

- Press the door lock button on the smart key within 32 feet (10 m) from the vehicle.
- 2. Press the Remote Start button (3) for more than 2 seconds within 4 seconds after pressing the door lock button.
- 3. Press the door lock button (1), and then the hazard warning lights blink once to alert you.
- To turn off the remote start function, press the Remote Start button (3) once.

## *i* Information

- The vehicle must be in P (Park) for the remote start function to start.
- The engine turns off if you get on the vehicle without a registered smart key.
- The engine turns off if you do not get on the vehicle within 10 minutes after remotely starting the vehicle.
- The Remote Start button (4) may not operate if the smart key is not within 32 feet (10 m).
- The vehicle will not remotely start if the engine hood or trunk is opened.
- Do not idle the engine for a long period.

#### Start-up

You can start the engine without inserting the key. For detailed information refer to the Engine Start/ Stop button in chapter 6.



If the smart key is not moved for some time, the detection function for smart key operation will pause. Lift the smart key to activate the detection again.

#### NOTICE

To prevent damaging the smart key:


- Keep the smart key away from water or any liquid and fire. If the inside of the smart key gets damp (due to drinks or moisture), or is heated, internal circuit may malfunction and may void the vehicle warranty.
- Avoid dropping or throwing the smart key.
- Protect the smart key from extreme temperatures.

#### NOTICE

Always have the smart key with you when leaving the vehicle. If the smart key is left near the vehicle, the vehicle battery may be discharged.

#### **Mechanical Key**

If the Smart Key does not operate normally, you can lock or unlock the door by using the mechanical key.



Turn the knob (2) of the mechanical key after removing the key protector (1). After using the mechanical key, turn the key knob (2) and insert the key protector (1).

#### Key cylinder (Driver door)

A key cylinder is located on the driver side door handle hidden behind a plastic cover.

For more information, refer to the "Door Locks" section in this chapter.

#### **Loss of a Smart Key**

A maximum of two smart keys can be registered to a single vehicle. If you happen to lose your smart key, it is recommended that you immediately take the vehicle and remaining key to your authorized HYUNDAI dealer or tow the vehicle, if necessary.

#### **Smart Key Precautions**

The smart key will not work if any of the following occur:

- The smart key is close to a radio transmitter such as a radio station or an airport which can interfere with normal operation of the smart key.
- The smart key is near a mobile two way radio system or a cellular phone.
- Another vehicle's smart key is being operated close to your vehicle.
- If your windows are tinted, especially with metallic window tint, it may cause frequency interference, reducing the smart key operating range.
- Make sure the smart key battery is inserted in the correct polarity before use. Using an improperly positioned battery may cause smart key failure or premature discharge of the battery.

When the smart key does not work correctly, open and close the door with the mechanical key. If you have a problem with the smart key, it is recommended that you contact an authorized HYUNDAI dealer.

If the smart key is in close proximity to your mobile phone, the signal could be blocked by your mobile phone's normal operational signals.

This is especially important when the phone is active such as making and receiving calls, text messaging, and/ or sending/receiving emails.

Avoid placing the smart key and your mobile phone in the same location and always try to maintain an adequate distance between the two devices.

## *i* Information

This device complies with Part 15 of the FCC rules.

Operation is subject to the following three conditions:

- 1. This device may not cause harmful interference.
- 2. This device must accept any interference received, including interference that may cause undesired operation.
- 3. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

## *i* Information

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. If the keyless entry system is inoperative due to changes or modifications not expressly approved by the party responsible for compliance, it will not be covered by your manufacturer's vehicle warranty.


#### NOTICE

Keep the smart key away from electromagnetic materials that blocks electromagnetic waves to the key surface.


#### **Battery Replacement**

Battery Type: CR2450 To replace the battery:

 Put the slim tool into the key hole
 (1) to pry open the rear cover of the smart key.



2. Remove the old battery and insert a new battery. Make sure the battery position is correct. An improperly positioned battery may discharge the battery, causing smart key failure.



3. Reinstall the rear cover of the smart key.

If you suspect your smart key might have sustained some damage or you feel your smart key is not working correctly, contact an authorized HYUNDAI dealer.

## *i* Information



An inappropriately disposed battery can be harmful to the environment and human health. Dispose of the battery according to your local law(s) and regulation.

## **MARNING**

## THIS PRODUCT CONTAINS A BUTTON BATTERY

If swallowed, a lithium button battery can cause severe or fatal injuries within 2 hours.

Keep batteries out of reach of children. If you think batteries may have been swallowed or placed inside any part of the body, seek immediate medical attention.

#### **Immobilizer System**

The immobilizer system helps protect your vehicle from theft. If an improperly coded key (or other device) is used, the engine's fuel system is disabled.

When the Engine Start/Stop button is pressed to the ON position, the immobilizer system indicator should come on briefly, then go off. If the indicator starts to blink, the system does not recognize the coding of the key.

Press the Engine Start/Stop button to the OFF position, then press the Engine Start/Stop button to the ON position again.

In some circumstances, the vehicle may not recognize your smart key if another smart key device is nearby or a metal object such as a key chain is causing interference with the smart key.

If this occurs, your vehicle may not start. Remove any metal objects or additional keys near the smart key before attempting to start the vehicle again.

If the system repeatedly does not recognize the coding of the key, contact your HYUNDAI dealer.

Do not attempt to alter this system or add other devices to it. Electrical problems could result that may make your vehicle inoperable.



#### WARNING

In order to prevent theft of your vehicle, do not leave spare keys anywhere in your vehicle. Your immobilizer password is a customer unique password and should be kept confidential.

#### NOTICE

The transponder in your key is an important part of the immobilizer system. It is designed to give years of trouble-free service, however you should avoid exposure to moisture, static electricity and rough handling. Immobilizer system malfunction could occur.



#### Information

This device complies with Part 15 of the FCC rules.

Operation is subject to the following three conditions:

- 1. This device may not cause harmful interference.
- 2. This device must accept any interference received, including interference that may cause undesired operation.
- 3. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device

#### **HYUNDAI DIGITAL KEY**

Hyundai digital key provides convenience to the driver, which the driver can use to lock or unlock the driver and passenger doors or the trunk and turn on the vehicle.

#### **Digital Key (Smartphone)**

## *i* Information

- Hyundai digital keys are only available on smartphone that support digital key functions, and digital key functions of smartphones are provide by smartphone manufacturers.
- Available smartphone models can be found on smartphone manufactures' website or HYUNDAI website.
- Depending on the availability of service on the vehicle, some functions may not operated.


#### Setting your smartphone

To use the digital key (smartphone), download the Bluelink App and sign up Hyundai account and service.

For more information about Bluelink, refer to the infotainment system guide.

# Registering your digital key (smartphone)

- Turn on the vehicle with a smart key and have your smart key with you in the vehicle.
- After selecting Digital Key > Set Up
  Digital Key from the My Hyundai App
  in the smartphone, register the digital
  key according to the guidance in the
  smartphone screen.



[A]: Wireless charging pad

- Place your smartphone on the vehicle authentication pad (wireless charging pad) with the screen facing up. (In case of Apple WATCH, the watch face must be on the pad).
- When the digital key (smartphone) is saved, a message appears on the infotainment system.

## *i* Information



- The NFC Antenna position on Samsung device can be found in the following path: Settings > Connections > NFC and contactless payments.
- The NFC Antenna position on Apple iPhone is located at the top of the rear and Apple WATCH is located at the center of the screen.
- Ensure that the NFC Antenna position on the smartphone is in contact with the vehicle authentication pad (wireless charging pad).
- The location of the NFC Antenna on the smartphone may vary by phone model, so please contact the smartphone manufacturer for details.
- NFC communication may not work for some smartphones depending on the internal structure of the smartphone.
   Move the smartphone to the left or right of the indoor authentication pad (wireless charging pad) to operate.

To register the digital key (smartphone) from the infotainment system



OCN7N053243N

If you cannot register the digital key (smartphone) with the My Hyundai app, try registering from the infotainment system.

- Turn off the vehicle, and then turn on the vehicle with a smart key and have your smart key with you in the vehicle.
- Put the gear in P (Park), from the infotainment system Settings menu, select Setup > Vehicle > Digital key > Smartphone key and press the Save button.
- Place your smartphone on the vehicle authentication pad (wireless charging pad) with the screen facing up. (In case of Apple WATCH, the watch face must be on the pad).
  - When the digital key (smartphone) is saved, a message appears on the infotainment system screen.

## **i** Information

- If you want to register a different digital key (smartphone), refer to the "Deleting your digital key (smartphone)" and delete the digital key (smartphone) before re-registering. An active Digital Key can be shared through the My Hyundai app with a different smartphone.
- During the digital key saving process, the process may cancel when:
  - The smartphone is removed from the vehicle authentication pad (wireless charging pad)
  - The infotainment system screen is changed
  - The engine is turned off
  - The gear is shifted
- The registering process does not start if a smart key is not in the vehicle.
- Some smartphones may not start the registering process depending on the internal structure. Move the smartphone to the left or right on the vehicle authentication pad (wireless charger pad) and try registering the smartphone.

#### Using the digital key (smartphone)

The driver can lock or unlock the door by placing the smartphone on the outside door handle, and the vehicle can be started by placing the smartphone on the vehicle authentication pad (wireless charging pad).



[A]: Door handle authentication pad [B]: NFC Antenna

## *i* Information

- The location of the NFC Antenna on the smartphone may vary by phone model, so please contact the smartphone manufacturer for details.
- The NFC Antenna position on Samsung device can be found in the following path: Setup > Connections > NFC and contactless payments.
- The NFC Antenna position on Google Pixel phone can be found in the following path: Settings > Connected devices > Connection preference > NFC.



The NFC Antenna position on Apple iPhone is located at the top of the rear [A] and Apple WATCH is located at the center of the screen [B].

 Touch the Door handle NFC Antenna position with the back of your smartphone. (In case of Apple WATCH, the watch face must be on the pad).

#### Locking/Unlocking the doors

- If the driver places the digital key (smartphone) NFC antenna to the driver's or passenger's door handle authentication pad (A) for more than 2 seconds, the door locks or unlocks.
- After unlocking the doors, the doors are automatically re-lock after 30 seconds unless a door is opened.
- If the smartphone digital key does not operate, try again after moving the smartphone away from the door handle authentication pad (more than 4 in. (0.1 m)).

## *i* Information

You cannot lock your vehicle using the digital key (smartphone) if any of the following occurs:

- · The smart key is in the vehicle.
- The Engine Start/Stop button is in the ACC or ON position.
- · Any of the doors are open.

#### Starting the vehicle

After placing your registered digital key (smartphone) on the vehicle authentication pad (wireless charging pad), depress the brake pedal and press the Engine Start/Stop button.

After starting the vehicle, the digital key (smartphone) may be removed from the vehicle authentication pad (wireless charging pad).

For more details on the basic way to start the vehicle, refer to the "Engine Start/ Stop Button" section in chapter 6.

## *i* Information

If a shared digital key (smartphone) is used for the first time, the activating time may take longer.

- Place the shared digital key (smartphone) on the door handle authentication pad until the vehicle door lock/unlock activates.
- If a shared digital key (smartphone) is first used on the vehicle authentication pad (wireless charger pad), the initial start of the vehicle may fail.
- If the door lock/unlock is activated once with the shared digital key (smartphone) or the vehicle is started with the digital key (smartphone) on the vehicle authentication pad, the digital key (smartphone) is registered in the vehicle.

## **MARNING**

The vehicle can be started when the registered smartphone is placed on the vehicle authentication pad (wireless charging pad). Therefore, do not leave unsupervised children or people who are not aware of the system since it can result in serious injury or death. In addition, always have the registered smartphone with you to prevent vehicle theft when leaving the vehicle.

# Deleting your digital key (smartphone)

Turn on the vehicle with a smart key. Have your smart key with you in the vehicle.



Deleting all registered digital key (smartphone)

To delete all the registered digital key (smartphone), from the Settings menu select Setup > Vehicle > Digital Keys > Smartphone key > Delete All in the infotainment system.

 The "Delete All" button is disabled if there is no registered digital key (smartphone).



Deleting my registered digital key (smartphone)

To delete only my registered digital key (smartphone), from the Settings menu select Setup > Vehicle > Digital Keys > Smartphone key > My Smartphone Key > Delete in the infotainment system.

- If a shared digital key (smartphone) is registered, it cannot be deleted.
- A new smartphone can be registered after deleting the existing digital key (smartphone) from "My Smartphone Key" menu.


## Information

- If the registered digital key (smartphone) is deleted, the digital key saved in the smartphone is also deleted.
- If the digital key is deleted from the smartphone, the digital key (smartphone) registered in the vehicle is also deleted.
- The shared digital key registered in the vehicle cannot be deleted individually.
- Even though the Blue Link® App is deleted from the smartphone, the digital key saved in the smartphone is not deleted.
- Management of the digital key saved in the smartphone is available from the Digital Key App provided by the smartphone manufacturer.

#### **Digital Key (Card Key)**

# How to register digital key (Card Key)

To use the card key as a digital key, follow the following procedure.







[A]: Vehicle authentication pad (Wireless charging pad)

- Have both of your smart keys with you in the vehicle.
- Select Setup > Vehicle > Digital Keys > NFC Card Key from the Settings menu, and check whether "Use" is selected in the infotainment system.
- Place your card key on the vehicle authentication pad (wireless charging pad) while the engine is on.
- Register your card key by selecting Setup > Vehicle > Digital Keys > NFC Card Key > Save from the Settings menu in the infotainment system.


## *i* Information

- Only one digital key (card key) can be registered to the vehicle. If it must be replaced, delete the existing card key before registering the new card key.
- To register a digital key (card key), both of your smart keys must be in the vehicle.
- Once a digital key (card key) is registered, it cannot be registered in another vehicle. It is possible to reregister it to the original vehicle.

#### Using the digital key (card key)

The driver can lock or unlock the door by placing the card key on the outside door handle, and the vehicle can be started by placing the card key on the vehicle authentication pad (wireless charging pad).

#### Locking/Unlocking the doors



[A]: Door handle authentication pad [B]: Card key NFC Antenna

If the driver places the digital key (card key) to the driver's or passenger's door handle authentication pad (A) for more than 2 seconds, the door locks or unlocks.

After unlocking the doors, the doors are automatically re-locked after 30 seconds unless a door is opened.

## *i* Information

You cannot lock your vehicle using the digital key (card key) if any of the following occurs:

- The smart key is in the vehicle.
- The Engine Start/Stop button is in the ACC or ON position.
- Any of the doors are open.

#### Starting the vehicle

After placing your registered digital key (card key) on the vehicle authentication pad (wireless charging pad), depress the brake pedal and press the Engine Start/Stop button.

For more information on the basic way to start the vehicle, refer to the "Engine Start/Stop Button" section in chapter 6.

## **MARNING**

The vehicle can be started when the registered card key is placed on the vehicle authentication pad (wireless charging pad). Therefore, do not leave unsupervised children or people who are not aware of the system since it can result in serious injury or death. In addition, always have the registered card key with you to prevent vehicle theft when leaving the vehicle.

## *i* Information

- The digital key (card key) may not work under the following conditions:
  - The digital key (card key) is not placed on the door handle authentication pad or vehicle authentication pad (wireless charging pad) correctly.
  - The digital key (card key) is near NFC-enabled cards such as credit cards or smartphones.
  - If the digital key (card key) does not work, try again after moving the digital key (card key) away from the door handle authentication pad (more than (4 in. (0.1 m)).
- The digital key (card key) can be damaged by impacts. If the digital key (card key) is damaged, replace the digital key (card key) with a new one and register it again.
- Long-time exposure to high temperature may cause the digital key (card key) to malfunction. Be careful not to expose the digital key (card key) to direct sunlight or high temperature.
- Leaving the digital key (card key)
   on the in-vehicle authentication pad
   (wireless charging pad) while driving
   may cause the digital key (card key)
   to malfunction. Remove the digital
   key (card key) from the in-vehicle
   authentication pad (wireless charging
   pad) after starting the vehicle.
- Keep the digital key (card key) away from the smartphone when charging the smartphone. If the digital key (card key) is placed between the smartphone and the in-vehicle authentication pad (wireless charging pad) while the smartphone is being charged, the digital key (card key) may malfunction. For example, when charging smartphone while the digital key (card key) is attached to the back of the smartphone case.

#### Deleting your digital key (card key)



- Turn on the engine with a smart key. Have your smart key with you in the vehicle.
- From the infotainment system settings menu, select Setup > Vehicle > Digital Keys > NFC Card Key > Delete.
  - The "Delete" button is disabled if there is no digital key (card key) registered.

# Personalized profile and vehicle settings

You can set the registered digital key (smartphone) profiles for Driver 1 and Driver 2. When you use the digital key (smartphone), the vehicle can be set to the user-defined personalized profile (includes items such as vehicle settings and audio preferences).

#### Linking/Unlinking profile

How to link user profile

- Select Setup > User Profile >
   Profile Settings > Link Digital Key
   (Smartphone) from the Settings menu in the infotainment system.
- Select "Link" to connect the registered smartphone's digital key and the user's profile.
- 3. Follow the instructions according to the message on the infotainment system screen.

How to unlink user profile

Select Setup > User Profile > Profile Settings, and then deselect "Link Digital Key (Smartphone)" from Settings menu in the infotainment system.

Unlinking is possible only when user profile is linked.

## *i* Information

- User profile cannot be linked to both Driver 1 and Driver 2 that are connected to single smartphone.
   Personalization operates with the recently linked user profile, and the previously linked user profile will be automatically canceled.
- User profile link works only when the digital key is registered to the vehicle.
- Digital key (card key) cannot be linked with a user profile.
- If the user profile linked digital key in the smartphone is deleted, the digital key should be re-registered and personalized by linking the user profile again.

#### Vehicle personalization operation

- The personalization function linked with digital key works when the profile linked smartphone is placed on the outside door handle authentication pad to lock or unlock the doors.
- The profile set by the digital key can be changed manually from the infotainment system.
- The personalization function using the digital key can be operated after linking the digital key in the infotainment system profile menu.
- The personalization function works only when the vehicle is OFF or when the
  vehicle is started remotely. If the vehicle is not started remotely, the personalization
  function does not work with the digital key.

## *i* Information

User profile operation according to door lock/unlock system is as follows:

Item	Personalization Operation
Initial value	Guest
Profile linked smartphone key	Linked profile
Profile unlinked smartphone key	
NFC card key	Recently activated profile
Smart key	

# Used Vehicle/Digital Key Maintenance

#### Purchasing used vehicle

If any of the digital key devices (smartphone key, card key) are registered in the vehicle, the "Digital key registered" message appears once on the infotainment system screen or instrument cluster when the Engine Start/Stop button is in the ON position after unlocking the doors. When purchasing a used vehicle, make sure to check the message and delete the smartphone key and card key registered by the previous user and inform the purchase of a used vehicle through Hyundai Customer Care Center.

If the card key comes with the vehicle, check whether it operates properly.

#### Digital key maintenance

If you need to repaired or replaced your Digital Key system, make sure your smartphone key is still active. You may have to pair your phone again using the HYUNDAI Digital Key app.

#### **Limitations of the System**

- HYUNDAI Digital Key app on the smartphone and card key may not work if:
  - Smartphone battery or the vehicle battery is discharged.
  - NFC or Bluetooth is turned off on the smartphone settings.
  - The card key is in a wallet or card holder, or overlapped with other cards.
  - If you use a smartphone cover that uses wireless communication or is made of metal, remove the smartphone cover.
- The vehicle may not be controlled by the smartphone if any of the following occurs:
  - Other smartphone functions (calls, urgent call, audio or NFC payment), apps, or wireless earphones are operating.
  - The digital key app function such as basic setting or app launching is limited by the prior policy according to the manufacturer.

#### **DOOR LOCKS**

#### Operating Door Locks from Outside the Vehicle

#### Mechanical key



- 1. Press the lever located under the cover with mechanical key. (1)
- While pushing the lever so that the mechanical key does not fall out of the cover hole, slowly push it towards the rear of the vehicle and remove the cover. (2)
- After removing the cover, only driver's door can be locked or unlocked by using mechanical key.
- 4. Turn the key toward the front of the vehicle to lock and toward the rear of the vehicle to unlock. (3)

If you lock/unlock the driver's door with a key, the driver's door will lock/ unlock automatically.

Once the door is unlocked, it may be opened by pulling the door handle.

Make sure that doors are closed securely.

## *i* Information

- Be careful when locking the door by mechanical key operation, only the driver's door can be locked/unlocked.
- Refer to Chapter 5 "Operating door locks from inside the vehicle" to lock from inside the vehicle.
- When all doors are locked with the mechanical key, lock all doors by using the central door lock switch inside the vehicle. Open the door using the driver's inner door handle, and then close the door and lock the driver's door with mechanical key operation.

## *i* Information

When removing the cover, be careful not to lose cover and any scratches.

When the key cover freezes and does not open, lightly tap or indirectly warm(hand temperature, etc.) it.

Do not apply excessive force to the door and door handle. It may be damaged.

#### Smart key



To lock the doors, press the button on the outside door handle while carrying the smart key with you or press the door lock button on the smart key.

To unlock the doors, press the button on the outside door handle while carrying the smart key with you or press the door unlock button on the smart key.

Once the doors are unlocked, they may be opened by pulling the door handle.

When closing the door, push the door by hand. Make sure that doors are closed securely.

## Information

- In cold and wet climates, door lock and door mechanisms may not work properly due to freezing conditions.
- If the door is locked/unlocked multiple times in rapid succession with either the vehicle key or door lock switch, the system may stop operating temporarily in order to protect the circuit and prevent damage to system components.
- Two press unlock setting can be changed in the User Settings mode on the cluster.

#### Operating Door Locks from Inside the Vehicle

#### With the door handle



#### Front door

If the inner door handle is pulled when the door is locked, the door will unlock and open.

#### Rear door

If the inner door handle is pulled once when the door is locked, the door will unlock. If the inner door handle is pulled once more, the door will open.

If any door is opened, the doors will not lock even though the central door lock switch is pressed.

## *i* Information

If a power door lock ever fails to function while you are in the vehicle try one or more of the following techniques to exit:

- Operate the door unlock feature repeatedly (both electronic and manual) while simultaneously pulling on the door handle.
- Operate the other door locks and handles, front and rear.
- Lower a front window and use the mechanical key to unlock the door from outside.

#### With the central door lock switch





- When pressing the (♠) portion (1) of the switch, all vehicle doors will lock.
  - If any door is opened, the doors will not lock even though the central door lock switch (1) is pressed.
- When pressing the (1) portion (2) of the switch, all vehicle doors will unlock.
- Doors indicating light (3)
   When all vehicle doors are locked, the indicating lights on the driver's door will turn off. If any door is unlocked, it would turn on.

#### NOTICE

If the smart key is in the vehicle and the front door is opened, the central door lock button (1) cannot lock the doors.

#### In case of an emergency



In case of emergency such as when the battery is discharged, the only way to lock the door(s) is with the mechanical key from the outside key hole.

Doors without an outside key hole can be locked as follows:

- 1. Open the door.
- Insert a small blade tool (for example, screwdriver or similar) into the emergency door lock hole and turn it counterclockwise for left side door, or turn it clockwise for right side door.
- 3. Close the door securely.

#### WARNING

- Always close and lock the doors while the vehicle is moving. If the doors are unlocked, the risk of being thrown from the vehicle in a collision increases.
- Do not pull the inner door handle of the driver's or passenger's door while the vehicle is moving.

## **MARNING**

Do not leave the elderly, children or animals unattended in your vehicle. An enclosed vehicle can become extremely hot, causing death or serious injury to the elderly, unattended children or animals who cannot escape from the vehicle. Children might operate features of the vehicle that could injure them, or they could encounter other harm, possibly from someone gaining entry to the vehicle.

## **MARNING**

Always secure your vehicle.

Leaving your vehicle unlocked increases the potential risk to you or others from someone hiding in your vehicle.

To secure your vehicle, while depressing the brake, move the shift lever to the P (Park) position, engage the parking brake, and set the Engine Start/Stop button in the OFF position, close all windows, lock all doors, and always take the key with you.

## ! WARNING

If you stay in the vehicle for a long time while the weather is very hot or cold, there are risks of injuries or danger to life. Do not lock the vehicle from the outside when someone is in the vehicle.

## **MARNING**

Opening a door when something is approaching may cause damage or injury. Be careful when opening doors and watch for vehicles, motorcycles, bicycles or pedestrians approaching the vehicle in the path of the door.

### Automatic Door Lock and Unlock Features

# Impact sensing door unlock system (if equipped)

All doors will be automatically unlocked when an impact causes the air bags to deploy.

# Speed sensing door lock system (if equipped)

All doors will be automatically locked when vehicle speed exceeds 9 mph (15 km/h).

You can activate or deactivate the Auto Door Lock/Unlock features from the infotainment system. Select:

Setup > Vehicle > Door > Auto Lock/ Auto Unlock

## *i* Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

#### Child-Protector Rear Door Locks



The child safety lock is provided to help prevent children seated in the rear from accidentally opening the rear doors.

The rear door safety locks should be used whenever children are in the vehicle.

The child safety lock is located on the edge of each rear door. When the child safety lock is in the lock position, the rear door will not open if the inner door handle is pulled.

To lock the child safety lock, insert a small flat blade tool (for example, screwdriver or similar) into the slot and turn it to the lock position as shown.

To allow a rear door to be opened from inside the vehicle, unlock the child safety lock.



## ! WARNING

If children accidently open the rear doors while the vehicle is in motion, they could fall out of the vehicle. The rear door safety locks should always be used whenever children are in the vehicle.

## **REAR OCCUPANT ALERT (ROA)**

Rear Occupant Alert helps prevent the driver from leaving a passenger in the rear seats.

#### System setting

To use Rear Occupant Alert, it can be enabled from the Settings menu in the infotainment system. Select:

Setup > Vehicle > Convenience > Rear **Occupant Alert** 

### **Rear Occupant Alert Operation**



When the driver turns off the engine and opens the driver's door after opening and closing a rear door, a warning message "Check rear seat for passengers and belongings" appears on the cluster.

## WARNING

**Rear Occupant Alert provides** information to the driver to check the rear seats but it does not detect whether there is an object or passenger. Always check the rear seats when leaving the vehicle.

## Information

The open and close history of the rear door is initialized if the driver turns off the engine and lock vehicle doors.

However, the alarm may sound again whenever the driver's door is opened if the previous history of the rear door is not initialized.

#### THEFT-ALARM SYSTEM

This system helps to protect your vehicle and valuables. The horn will sound and the hazard warning lights will blink continuously if any of the following occur:

- A door is opened without using the smart key.
- The trunk is opened without using the smart key.
- The engine hood is opened.

The alarm continues for 30 seconds, then the system resets. To turn off the alarm, unlock the doors with the smart key.

The Theft Alarm System automatically sets 30 seconds after you lock the doors and the trunk. For the system to activate, you must lock the doors and the trunk from outside the vehicle with the smart key or by pressing the button on the outside of the door handle with the smart key in your possession.

The hazard warning lights will blink and the chime will sound once to indicate the system is armed.

Once the security system is set, opening any door, the trunk, or the hood without using the smart key will cause the alarm to activate.

The Theft Alarm System will not set if the hood, the trunk, or any door is not fully closed. If the system will not set, check the hood, the trunk, or the doors are fully closed.

Do not attempt to alter this system or add other devices to it.

## *i* Information

- Do not lock the doors until all passengers have left the vehicle. If the remaining passenger leaves the vehicle when the system is armed, the alarm will be activated.
- If the vehicle is not disarmed with the smart key, open the doors by using the mechanical key and start the engine by directly pressing the Engine Start/Stop button with the smart key.
- If the system is disarmed by unlocking the vehicle, but neither a door or the trunk is opened within 30 seconds, the doors will relock and the system will rearm automatically.

#### STEERING WHEEL

# Motor Driven Power Steering (MDPS)

The system assists you with steering the vehicle. If the vehicle is turned off or if the power steering system becomes inoperative, you may still steer the vehicle, but it will require increased steering effort.

Also, the steering effort becomes heavier as the vehicle's speed increases and becomes lighter as the vehicle's speed decreases for better control of the steering wheel.

Should you notice any change in the effort required to steer during normal vehicle operation, have the system checked by an authorized HYUNDAI dealer.

## $\overline{\mathbb{A}}$

#### CAUTION

- If the Motor Driven Power Steering System does not operate normally, the warning light (♠!) will illuminate on the instrument cluster. You may steer the vehicle, but it will require increased steering efforts. Take your vehicle to an authorized HYUNDAI dealer and have the system checked as soon as possible.
- When an abnormality is detected in the Motor Driven Power Steering system, to prevent an accident, the steering assist function may become inoperative. At this time, the warning light turns on or blinks on the cluster. The steering wheel may become difficult to control or operate. Have your vehicle checked immediately, after moving the vehicle to a safe area.

# *i* Information

The following symptoms may occur during normal vehicle operation:

- The steering effort may be high immediately after setting the Engine Start/Stop button to the ON position.

  This happens as the system performs
  - This happens as the system performs the MDPS system diagnostics. When the diagnostics are completed, the steering wheel effort will return to its normal condition.
- When the battery voltage is low, you
  may have to put more steering effort.
  However, it is a temporary condition so
  that it will return to normal condition
  after charging the battery.
- A click noise may be heard from the MDPS relay after the Engine Start/Stop button is in the ON or OFF position.
- Motor noise may be heard when the vehicle is at a stop or at a low driving speed.
- When you operate the steering wheel in low temperatures, abnormal noise may occur. If the temperature rises, the noise will disappear. This is a normal condition.
- When an error is detected from the MDPS, the steering effort assist function may become inoperative in order to prevent fatal accidents. Instrument cluster warning lights may be on or the steering effort may be high. If these symptoms occur, drive the vehicle to a safe area as soon as it is safe to do so. Have the system checked by an authorized HYUNDAI dealer as soon as possible.

## **Tilt Steering / Telescope Steering**

When adjusting the steering wheel to a comfortable position, adjust the steering wheel so that it points toward your chest. not toward your face. Make sure you can see the instrument cluster warning lights and gauges. After locking the lever, push the steering wheel both up and down to be certain it is locked in position. Always adjust the position of the steering wheel before driving.



### WARNING

NEVER adjust the steering wheel while driving. This may cause loss of vehicle control resulting in an accident.



To adjust the steering wheel angle and height:

- 1. Pull down the lock-release lever (1).
- 2. Adjust the steering wheel to the desired angle (2) and height (3, if equipped). Move the steering wheel, so it points toward your chest, not toward your face. Make sure you can see the instrument panel warning lights and gauges.
- 3. Pull up the lock-release lever to lock the steering wheel in place.

## Information

Sometimes the lock release lever may not engage completely. This may occur when the gears of the locking mechanism do not completely mesh. If this occurs, pull down on the lock release lever, readjust the steering wheel again, and then pull back up on the release lever to lock the steering wheel in place.



#### **CAUTION**

While adjusting the steering wheel height, please do not push or pull it hard since the fixture can be damaged.

#### Horn



To sound the horn, press the area indicated by the horn symbol on your steering wheel (see illustration). The horn will operate only when this area is pressed.

## NOTICE

Do not strike the horn severely to operate it, or hit it with your fist. Do not press on the horn with a sharp-pointed obiect.

#### **MIRRORS**

#### Inside Rearview Mirror

Before driving your vehicle, check to see that your inside rearview mirror is properly positioned. Adjust the rearview mirror so that the view through the rear window is properly centered.



## ! WARNING

Make sure your line of sight is not obstructed. Do not place objects in the rear seat, cargo area, or behind the rear head restraints which could interfere with your vision through the rear window.



### **WARNING**

To prevent serious injury during an accident or deployment of the air bag, do not modify the rearview mirror and do not install a wide mirror.



### WARNING

NEVER adjust the mirror while driving. This may cause loss of vehicle control resulting in an accident.

## NOTICE

When cleaning the mirror, use a paper towel or similar material dampened with glass cleaner. Do not spray glass cleaner directly on the mirror as this may cause the liquid cleaner to enter the mirror housing.

### Day/night rearview mirror (if equipped)



[A]: Lever, [B]: Day, [C]: Night

Make this adjustment before you start driving and while the day/night lever is in the day position.

Pull the day/night lever towards you to reduce glare from the headlights of the vehicles behind you during night driving.

Remember that you lose some rearview clarity in the night position.

# Electrochromic mirror (ECM) with HomeLink® system (if equipped)

Your vehicle may be equipped with a Gentex Automatic-Dimming Mirror with an Integrated HomeLink® Wireless Control System.

During nighttime driving, this feature will automatically detect and reduce rearview mirror glare. The HomeLink® Universal Transceiver allows you to activate your garage door(s), electric gate, home lighting, etc.



- (1) HomeLink Channel 1
- (2) HomeLink Channel 2
- (3) HomeLink Channel 3
- (4) Garage Door Opener Status Indicator: Closing or Closed
- (5) HomeLink Operation Indicator
- (6) Garage Door Opener Status Indicator: Opening or Opened
- (7) HomeLink User Interface Indicator

# Automatic-Dimming Night Vision Safety™ (NVS®) Mirror (if equipped)

The NVS® Mirror automatically reduces glare by monitoring light levels in the front and the rear of the vehicle. Any object that obstructs either light sensor will degrade the automatic dimming control feature.

For more information regarding NVS® mirrors and other applications, please refer to the Gentex website:

#### www.gentex.com

Your mirror will automatically dim upon detecting glare from the vehicles traveling behind you.

The mirror defaults to the ON position each time the vehicle is started.

# Integrated HomeLink® Wireless Control System

The HomeLink® Wireless Control System provides a convenient way to replace up to three hand held radio-frequency transmitters used to activate compatible devices such as gate operators, garage door openers, entry door locks, security systems, and home lighting.

## **NOTICE**

HomeLink® operates while the Engine Start/Stop button is in the ACC or ON position for safety reasons. It is to prevent unintentional security problems from happening when the vehicle is parked outside the garage.

## **⚠** WARNING

Before programming HomeLink® to a garage door opener or gate operator. make sure people and objects are out of the way of the device to prevent potential harm or damage. Do not use the HomeLink® with any garage door opener that lacks the safety stop and reverse features required by U.S. federal safety standards (this includes any garage door opener model manufactured before April 1, 1982). A garage door that cannot detect an object - signaling the door to stop and reverse - does not meet current U.S. federal safety standards. Using a garage door opener without these features increases the risk of serious injury or death.

For more information, contact HomeLink® at www.homelink.com, or call Home-Link customer support at 1-800-355-3515.

It is also recommended that a new battery be replaced in the handheld transmitter of the device being trained to HomeLink® for quicker training and accurate transmission of the radio frequency.

#### 1. Programming HomeLink®

The following steps show how to program HomeLink. If you have any questions or are having difficulty programming your HomeLink buttons, refer to the HomeLink website or call the HomeLink customer support toll-free number. Do this, before going back to the dealer who sold you the car.

- Visit the HomeLink website at: www. homelink.com. Then at the top of the page, choose your vehicle make. Then watch the You Tube video, and/or access additional website information.
- If you choose to access the website via your cell phone, scan the QR code.



 Or, call HomeLink customer support at 1-800-355-3515 (Please have the vehicle make/model AND the opener device make/model readily available.)

#### 1) Programming Preparation



- 1. When programming a garage door opener, it is advised to park the vehicle outside of the garage.
- It is recommended that a new battery be placed in the handheld transmitter of the device being programmed to HomeLink for quicker training and accurate transmission of the radiofrequency signal.
- 3. Set the Engine Start/Stop button to the ACC (Accessory) position for programming of HomeLink.

### 2) Programming a New HomeLink®




 Press and release the HomeLink button (1), (2) or (3), you would like to program. The HomeLink indicator light (7) will flash orange slowly (if not, perform the steps of "Erasing HomeLink Buttons" section, and start over).



 Position the garage door opener remote 1 – 3 inches (2 – 8cm) away from the HoleLink buttons.

- 3. While the HomeLink indicator light (7) is flashing orange, press and hold the hand-held remote button. Continue pressing the handheld remote button until the HomeLink indicator light (7) light changes from orange to green. You may now release the handheld remote button.
- Wait until your garage door comes to a complete stop, regardless of position, before proceeding to the next steps.
- 5. Press and release the HomeLink button you are programming and observe the indicator light.
  - If the indicator light remains solid green, your device should operate when the HomeLink button is pressed. At this point, if your device operates, programming is complete.
  - If the indicator light rapidly flashes green, firmly press, hold for two seconds and release the HomeLink button up to three times in a row slowly to complete the programming process. Do not press the HomeLink button rapidly. At this point if your device operates, programming is complete. If the device does not operate, continue with step 6.
- 6. At the garage door opener motor, (security gate motor, etc.) locate the "Learn", "Smart", "Set" or "Program" button. This can usually be found where the hanging antenna wire is attached to the motor-head unit (see the device's manual to identify this button). The name and color of the button may vary by manufacturer.



- \* A ladder and/or second person may simplify the following steps.
- 7. Firmly press and release the "Learn", "Smart", "Set" or "Program" button. You now have up to 30 seconds in which to complete the next step.
- 8. Return to the vehicle and firmly press, hold for two seconds and release, the HomeLink button up to three times in a row slowly. Do not press the HomeLink button rapidly. As soon as you see the garage door start to move, stop pressing any buttons until a few seconds after the garage door has come to a complete stop, regardless of position. At this point, programming is complete and your device should operate when the HomeLink button is pressed and released.

#### Two-Way Communication Programming (For select garage door openers)

If your garage door opener has the 'myQ' logo on its side, your opener likely has Two-Way Communication capability. HomeLink has the capability to establish Two-Way Communication with your garage door opener. HomeLink can receive and display "closing" or "opening" status messages from compatible garage door openers. At any time, Home-Link can also recall and display the last recorded status communicated by the garage door opener to indicate your garage door being "closed" or "opened".

To check if your garage door opener is compatible with this feature, refer to www.homelink.com/compatible/Twoway-Communication. If your garage door opener has this functionality, AND the Two-Way Communication indicators (4), (6) in the mirror appear while the garage door is opening/closing, then no further steps are needed. Two-Way Communication Programming is already complete. However, if your garage door opener has this functionality, AND the Two-Way Communication indicators (4). (6) in the mirror DO NOT appear while the garage door is opening/closing, use the following instructions to enable this functionality.

- 1. In your vehicle, press and hold the programmed HomeLink button for 2 seconds, then release. Confirm that the garage door is moving. AFTER it stops, you will have one minute to complete the following steps:
- \* A ladder and/or second person may simplify the following steps.

- 2. On your garage door opener in your garage, locate the "Learn" button (usually near where the hanging antenna wire is attached to the garage door opener). If there is difficulty locating this button, reference the device's owner's manual
- 3. Press and release the "Learn" button.
- A light on your garage door opener may flash, and your Two-Way Communication indicators (4), (6) in your vehicle may flash, confirming completion of the process.
- 5. Return to the vehicle and firmly press and release the programmed HomeLink button to activate your garage door. The Two-Way Communication indicators (4), (6) flash in orange when the door is moving. Do not make any additional button presses until AFTER the garage door has come to a complete stop.
- 6. Your Two-Way Communication programming is now complete.

## *i* Information

If your garage door opener has Two-Way Communication functionality, it is possible for HomeLink to stop functioning the garage door shortly after initial programming, IF the Two-Way Communication Programming wasn't properly completed. This usually happens after the first 10 times a programmed HomeLink button is pressed. If you experience this, completing the "Programming a New HomeLink Button" and "Two-Way Communication Programming" will restore door operation.

#### 4) Canadian Programming

Canadian radio-frequency laws require transmitter remote signals to "time-out" (or quit) after a couple seconds of transmission, which may not be long enough for HomeLink to pick up the signal during programming.

If you live in Canada or you are having difficulties programming a gate operator or garage door opener by using the programming procedures, replace "Programming a New HomeLink Button" step 3 with the following:

While the HomeLink indicator light (7) is flashing orange, press and release ("cycle") your device's handheld remote every two seconds until the HomeLink indicator light (7) changes from orange to green. You may now release the handheld remote button. Then proceed with "Programming a New HomeLink Button" step 4.

#### 2. Operating HomeLink®

#### 1) Operating HomeLink®



 Press and release the desired programmed HomeLink button (1, 2 or 3).

## *i* Information

The HomeLink indicator (7) should light green, solid or flashing, and your programmed device should operate.

If your device does not operate, the HomeLink programming was not successful, and you'll need to reprogram the button.

#### 2) Two-Way Communication Display Behavior



 Press and release one of the programmed HomeLink buttons (1, 2 or 3).



The indicator (4) and (6) operates as below, if your garage door opener has Two-Way Communication functionality.

- If the indicator (4) flashes in Orange, it indicates that the garage door is "Closing".
- The indicator (4) turns solid green once the garage door has closed.
- If the indicator (6) flashes in Orange, it indicates that the garage door is "Opening".
- The indicator (6) turns solid green once the garage door has fully opened.
- If the indicator (4) or (6) does not turn to green, it indicates that the last status of garage door was not received properly. The HomeLink mirror tries to receive the last known status of the garage door for a few seconds.

#### 3) Recalling Garage Door Status

HomeLink mirror with Two-Way Communication provides a way to view the last stored message from the garage door opener. In order to recall the last known status of the last activated device, press the buttons "1 and 2" OR "2 and 3" simultaneously.

- If the indicator (4) appears solid Green, it indicates that the last activated device was "closed" properly.
- If the indicator (6) appears solid Green, it indicates that the last activated device was "open" properly.

- 3. Erasing HomeLink® Buttons
- Erasing and Reprogramming a Single HomeLink® Button:
- Press and hold the desired HomeLink button you want to re-program. DO NOT release the button.
- The HomeLink indicator light (7) will illuminate solid green. Release the button as soon as the HomeLink indicator light (7) begins to flash orange, usually about 20 seconds.
- Proceed with the steps in the "Programming a New HomeLink Button" section.

## **i** Information

If you do not complete the reprogramming of a new device to the button, it will revert to the previously stored programming.  The following instructions will erase ALL HomeLink® programming from ALL buttons:



- 1. Press and hold the buttons (1) and (3) simultaneously.
- 2. The HomeLink indicator light (7) will illuminate solid Orange for about 10 seconds.
- 3. Release the buttons once the HomeLink indicator light (7) changes to Green and flashes rapidly.
- 4. Now all three HomeLink buttons (1), (2) and (3) are cleared of any programming.

## **1** Information

HomeLink® and the HomeLink® House logo are registered trademarks of Gentex Corporation.

The myQ logo is a registered trademark of The Chamberlain Group, Inc.

#### FCC (USA) and ISED (Canada)

This device complies with FCC rules part 15 and Innovation, Science, and Economic Development Canada RSS-210. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference that may be received including interference that may cause undesired operation. WARNING: The transmitter has been tested and complies with FCC and ISED rules. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

This equipment complies with FCC and ISED radiation exposure limits set forth for an uncontrolled environment. End Users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must be at least 20 cm from the user and must not be co-located or operating in conjunction with any other antenna or transmitter.

#### FCC (Htats-Unis) et ISED (Canada)


Cet appareil est conforme aux règlements de la FCC, section 15, et au CNR-210 d'Innovation, Sciences et Dhyeloppement économique Canada, Le fonctionnement est assuietti aux deux conditions suivantes: (1) cet appareil ne doit pas causer d'interférences nuisibles et (2) cet appareil doit accepter toute interférence reçue, y compris celle qui pourrait entraîner un dysfonctionnement. MISE EN GARDE : L'émetteur a subi des tests et est conforme aux règlements de la FCC et d'ISDE. Les changements ou modifications non approuvés explicitement par la partie responsable de la conformité pourraient rendre caduque l'autorisation de l'utilisateur de se servir du dispositif.

Cet appareil est conforme aux limites d'exposition aux radiations de la FCC et d'ISDE établies pour un environnement non contrôlé. Les utilisateurs finaux doivent respecter les instructions d'utilisation spécifiques pour satisfaire aux exigences de conformité aux expositions de RF. L'émetteur doit se trouver à 20 cm au minimum de l'utilisateur et ne doit pas être situé au même endroit que tout autre émetteur ou antenne ni fonctionner avec un autre émetteur ou antenne.

#### Méiico

La operación de este equipo está sujeta a las siguientes dos condiciones: (1) es posible que este equipo o dispositivo pueda no causar interferencia dañina, y (2) este dispositivo o dispositivos deben aceptar cualquier interferencia, que incluye la interferencia que puede causar su operación no deseada.

### **HomeLink 5 Programing Flow Chart**



#### **Side View Mirrors**



Make sure to adjust the side view mirrors to your desired position before you begin driving.

Your vehicle is equipped with both left-hand and right-hand side view mirrors. The mirrors can be adjusted remotely with the remote switch. The side view mirrors can be folded to help prevent damage when going through an automatic car wash or when passing through a narrow street.

The right side view mirror is convex. Objects seen in the mirror are closer than they appear.

Use the inside rear view mirror or look back directly to determine the actual distance of other vehicles prior to changing lanes.



## **WARNING**

Do not adjust or fold the side view mirrors while driving. This may cause loss of vehicle control resulting in an accident.

### NOTICE

- Do not scrape ice off the mirror face; this may damage the surface of the glass.
- If the mirror is jammed with ice, do not adjust the mirror by force. Use an approved de-icer (not radiator antifreeze) spray, or a sponge or soft cloth with very warm water, or move the vehicle to a warm place and allow the ice to melt.

#### Side View Mirror Adjustment



- Move either the L (left side) or R (right side) lever (1) to select the side view mirror you would like to adjust.
- 2. Use the mirror adjustment control (2) to position the selected mirror up, down, left or right.
- 3. After adjustment, put the lever into neutral (center) position to prevent inadvertent adjustment.

## NOTICE


- The mirrors stop moving when they reach the maximum adjusting angles, but the motor continues to operate while the switch is pressed.
   Do not press the switch longer than necessary, because this can damage the motor.
- Do not attempt to adjust the side view mirrors by hand, because this can damage the motor.

### Folding the side view mirrors



To fold the side view mirrors, grasp the housing of the mirror and then fold it inwards.

### **WINDOWS**



- (1) Driver's door power window switch
- (2) Front passenger's door power window switch
- (3) Rear door (left) power window switch
- (4) Rear door (right) power window switch
- (5) Window opening and closing
- (6) Automatic power window
- (7) Power window lock switch

#### **Power Windows**

The Engine Start/Stop button must be in the ON position to be able to raise or lower the windows. Each door has a Power Window switch to control that door's window. The driver has a Power Window Lock switch which can block the operation of rear passenger windows. The power windows will operate for approximately 3 minutes after the Engine Start/Stop button is in the ACC or OFF position. However, if the front doors are opened, the Power Windows will not operate even within the 3 minutes period.

## / WARNING

To avoid serious injury or death, do not extend your head, arms or body outside the windows while driving.

## *i* Information

- In cold and wet climates, power windows may not work properly due to freezing conditions.
- While driving with the rear windows down or with the sunroof (if equipped) opened (or partially opened), your vehicle may demonstrate a wind buffeting or pulsation noise. This noise is normal and can be reduced or eliminated by taking the following actions. If the noise occurs with one or both of the rear windows down, partially lower both front windows approximately one inch. If you experience the noise with the sunroof open, slightly close the sunroof.

#### Window opening and closing



#### To open:

Press the window switch down to the first detent position (5). Release the switch when you want the window to stop.

#### To close:

Pull the window switch up to the first detent position (5). Release the window switch when you want the window to stop.

## Auto down window (if equipped)

Pressing the power window switch down momentarily to the second detent position (6) completely lowers the window even when the switch is released. To stop the window at the desired position while the window is in operation, pull up or press down and release the switch.

## Auto up/down window (if equipped)

Pressing or pulling up the power window switch momentarily to the second detent position (6) completely lowers or lifts the window even when the switch is released. To stop the window at the desired position while the window is in operation, pull up or press down and release the switch.

#### To reset the power windows

If the power windows do not operate normally, the automatic power window system must be reset as follows:

- 1. Set the Engine Start/Stop button to the ON position.
- Close the window and continue pulling up on the power window switch for at least one second.


If the power windows do not operate properly after resetting, have the system checked by an authorized HYUNDAI dealer.



#### WARNING

The automatic reverse feature doesn't activate while resetting the power window system. Make sure body parts or other objects are safely out of the way before closing the windows to avoid injuries or vehicle damage.

#### Automatic reverse (if equipped)



If a window senses any obstacle while it is closing automatically, it will stop and lower approximately 12 inches (30 cm) to allow the object to be cleared.

If the window detects the resistance while the power window switch is pulled up continuously, the window will stop upward movement then lower approximately 1 inch (2.5 cm).

If the power window switch is pulled up continuously again within 5 seconds after the window is lowered by the automatic window reverse feature, the automatic window reverse will not operate.



### Information

The automatic reverse feature is only active when the "Auto Up" feature is used by fully pulling up the switch to the second detent.



## WARNING

Make sure body parts or other objects are safely out of the way before closing the windows to avoid injuries or vehicle damage.

Objects less than 0.16 inch (4 mm) in diameter caught between the window glass and the upper window channel may not be detected by the automatic reverse window and the window will not stop and reverse direction.

### NOTICE

Do not install any accessories on the windows. The automatic reverse feature may not operate.

#### Power window lock switch



The driver can disable the power window switches on the rear passenger doors by pressing the power window lock switch. When the power window lock switch is pressed:

- The rear passenger control will not be able to operate the rear passenger power window
- Note that the front passenger control is still able to operate the front passenger window, and that the driver master control can still operate all the power windows.

## NOTICE

- To prevent possible damage to the power window system, do not open or close two windows or more at the same time. This will also ensure the longevity of the fuse.
- Never try to operate the main switch on the driver's door and the individual door window switch in opposite directions at the same time. If this is done, the window will stop and cannot be opened or closed.

## **⚠** WARNING

- NEVER leave the keys in your vehicle with unsupervised children, when the engine is running.
- NEVER leave any child unattended in the vehicle. Even very young children may inadvertently cause the vehicle to move, entangle themselves in the windows, or otherwise injure themselves or others.
- Always double check to make sure arms, hands, head and other obstructions are safely out of the way before closing a window.
- Do not allow children to play with the power windows. Keep the driver's door power window lock switch in the LOCK position (pressed). Serious injury can result from unintentional window operation by the child.
- Do not extend your head, arms or body outside the windows while driving.

# Remote window opening function (if equipped)



Press and hold the Door Unlock (1) button on the smart key for more than 3 seconds and the front seat windows move down after the doors are unlocked. Window movement stops when you release the door unlock button.

### NOTICE

Do not leave the windows down when leaving the vehicle to prevent theft or damage from water entering the vehicle.



The remote window opening function may abruptly stop, when you move away from your vehicle during operation. Stay in close proximity from your vehicle, while monitoring the window movement.

The doors unlock when the windows are opened using the remote window opening function.

## **SUNROOF (IF EQUIPPED)**

If your vehicle is equipped with a sunroof, you can slide or tilt your sunroof with the sunroof switch located on the overhead console.



The sunroof can only be operated when the Engine Start/Stop button is in the ON position.

The sunroof can be operated for approximately 3 minutes after the the Engine Start/Stop button is in the ACC or OFF position. However, if the front door is open, the sunroof cannot be operated even within the 3 minute period.

## **WARNING**

- Never adjust the sunroof or sunshade while driving. This could result in loss of control and an accident that may cause injury, or property damage.
- Do not leave the engine running and the key in your vehicle with unsupervised children. Unattended children could operate the sunroof, which could result in serious injury.
- Do not sit on the top of the vehicle. It may cause injury or vehicle damage.

## NOTICE

Do not operate the sunroof when roof bars are installed on the vehicle or when there is luggage on the roof.

#### Sunshade



Use the sunshade to block direct sunlight coming through the sunroof glass.

Open or close the sunshade by hand.


## Information

The sunshade opens automatically when the sunroof glass is opened, but the sunshade does not close automatically when the sunroof glass is closed. Also, only the sunshade cannot be closed when the sunroof glass is opened.

## NOTICE

Do not pull the sunshade up or down, or apply excessive force as such action may damage the sunshade or cause it to malfunction.

### Tilt Open/Close



- Push the sunroof switch upward, the sunroof glass tilts open.
- Push the sunroof switch forward when the sunroof glass is tilt opened, the sunroof glass closes.

The sunroof glass tilts open or closes while the switch is pushed.

## *i* Information

The sunroof glass cannot slide open and tilt open at the same time. You cannot tilt the sunroof glass open while the sunroof glass is slide open. Also, you cannot slide the sunroof glass open while the sunroof is tilt open. Slide open or tilt open the sunroof glass when the sunroof glass is completely closed.

### Slide Open/Close



- Push the sunroof switch rearward, the sunshade and sunroof glass slide open.
  - Push the sunroof switch forward, only the sunroof glass closes.
- Push the sunroof switch forward or rearward to the first detent position, the sunroof glass moves until the switch is released.
- Push the sunroof switch forward or rearward to the second detent position, the sunroof glass operates automatically (auto slide feature). To stop the sunroof movement at any point, push the sunroof switch in any direction.
- The sunroof glass stops halfway (first detent position) before it is fully opened. To fully open the sunroof glass, push the sunroof switch rearward once more. At this time, the sunroof glass opens only while the switch is pushed.

To stop the sunroof movement at any point, push the sunroof switch in any direction.

# *i* Information

To reduce wind noise while driving, we recommend that you drive at the recommended position (first detent position) before the maximum slide open position.

#### **Automatic Reversal**



If the sunroof glass senses any obstacle while it is closing automatically, it will reverse direction then stop at a certain position.

The auto reverse function may not work if an object thin or soft is caught between the sliding sunroof glass and sunroof sash.

## **WARNING**

- Make sure heads, hands, arms or any other body parts or objects are out of the way before operating the sunroof. Body parts or objects may get caught causing injuries or vehicle damage.
- Never deliberately use your body parts to test the automatic reversal function. The sunroof glass may reverse direction, but there is a risk of injury.

### NOTICE

- Do not continue to push the sunroof switch after the sunroof is fully opened, closed, or tilted. Damage to the sunroof motor could occur.
- Continuous operations such as slide open/close, tilt open/close, etc. may cause the motor or sunroof system to malfunction.
- Regularly remove any accumulated dust on the sunroof rail.
- Dust accumulated between the sunroof and roof panel can make noise. Open the sunroof and remove dust regularly using a clean cloth.
- Do not try to open the sunroof when the temperature is below freezing or when the sunroof is covered with snow or ice. The sunroof may not work properly and may break if opened by force.
- Do not open or drive with the sunroof glass open immediately after rain or washing the vehicle. Water may wet the interior of the vehicle.
- Do not extend any luggage outside the sunroof while driving. Vehicle damage may occur if the vehicle suddenly stops.



Do not extend your head, arms, body parts or objects outside the sunroof while driving. Injuries may occur if the vehicle suddenly stops.

### **Resetting the Sunroof**



In some circumstances resetting the sunroof operation may need to be performed. Some instances where resetting the sunroof may be required include:

- · When the 12 V battery is either disconnected or discharged
- When the sunroof fuse is replaced
- If the sunroof one-touch AUTO OPEN/ CLOSE operation is not functioning properly

Sunroof resetting procedure:

- 1. It is recommended to perform the reset procedure with the vehicle engine running. Start the vehicle in P (Park).
- 2. Make sure the sunroof glass is in the fully closed position. If the sunroof glass is open, push the switch forward until the sunroof glass is fully closed.
- 3. Release the switch when the sunroof glass is fully closed.
- 4. Push the switch forward until the sunroof glass moves slightly. Then release the switch.

5. Once again push and hold the sunroof switch forward until the sunroof glass slides open and close. Do not release the switch until the operation is completed.

If you release the switch during operation, start the procedure again from step 2.

## Information

If the sunroof is not reset when the vehicle battery is disconnected or discharged, or the sunroof fuse is blown, the sunroof may not operate normally.

### **Sunroof Open Warning**



OCN7040018

If the driver turns off the engine when the sunroof is not fully closed, the warning chime will sound for several seconds and the sunroof open warning will appear on the cluster display.

Close the sunroof securely when leaving your vehicle.



### CAUTION

Make sure the sunroof is closed fully when leaving your vehicle.

If the sunroof is left open, rain or snow may wet the interior of the vehicle. Also, leaving the sunroof open when the vehicle is unattended may invite theft.

#### HOOD

#### Opening the hood



- 1. Park the vehicle and set the parking brake.
- 2. Pull the release lever to unlatch the hood. The hood should pop open slightly.



- 3. Go to the front of the vehicle, raise the hood slightly, push up the secondary hood release lever (1) inside of the hood center and lift the hood (2).
- 4. Pull out the support rod.



5. Hold the hood open with the support rod (3).



### ! WARNING

#### Support rod

- · After driving, the engine compartment and support rod will be hot. Grasp the support rod in the area wrapped in rubber to prevent burns.
- The support rod must be inserted completely into the hole provided whenever you inspect the engine compartment. This will prevent the hood from falling and possibly injuring you.

#### Closing the hood

- 1. Before closing the hood, check the following:
  - All filler caps in engine compartment must be correctly installed
  - Gloves, rags or any other combustible material must be removed from the engine compartment.
- 2. Return the support rod to its clip to prevent it from rattling.
- 3. Lower the hood halfway (lifted approximately 12 in. (30 cm) from the closed position) and push down to securely lock in place. Then double check to be sure the hood is secure. If the hood can be raised slightly, it is not securely locked. Open it again and close it with more force.

## **MARNING**

- Before closing the hood, ensure all obstructions are removed from around the hood opening.
- Always double check to be sure that the hood is firmly latched before driving away. Check there is no hood open warning light or message displayed on the instrument cluster. Driving with the hood opened may cause a total loss of visibility, which might result in an accident.
- Do not move the vehicle with the hood in the raised position, as vision is obstructed, which might result in an accident, and the hood could fall or be damaged.

#### **TRUNK**

#### Opening the trunk

 Make sure the shift lever is in P (Park, for Dual clutch transmission) or first gear or R (Reverse, for manual transmission) and set the parking brake.



- 2. Then do one of the following:
- Hold down the trunk unlock button located on your smart key for more than 1 second.
- Additionally, for vehicles equipped with smart key:
  - While all doors are unlocked, press the switch in the trunk to open the trunk with or without the smart key in your possession.
  - If any door is locked or all doors are locked, the switch can still be used to open the trunk, as long as the smart key is in your possession.



- Use the trunk release lever.
- 3. Lift the trunk lid up.

### Closing the trunk

Lower the trunk lid and press down until it locks. To be sure the trunk lid is securely fastened, always check by trying to pull it up again.



#### WARNING

Always keep the trunk lid completely closed while the vehicle is in motion. If it is left open or ajar, poisonous exhaust gases containing carbon monoxide (CO) may enter the vehicle and serious illness or death may result.



## Information

To prevent damage to the trunk lift cylinders and the attached hardware, always close the trunk before driving.

## NOTICE

In cold and wet climates, trunk lock and trunk mechanisms may not work properly due to freezing conditions.

### **Emergency Trunk Safety Release**



Your vehicle is equipped with an Emergency Trunk Safety Release lever located inside the trunk. When someone is inadvertently locked in the trunk, the trunk can be opened by moving the lever in the direction of the arrow and pushing the trunk open.

## **MARNING**

- You and your passengers must be aware of the location of the Emergency Trunk Safety Release lever in this vehicle and how to open the trunk in case you are accidentally locked in the trunk.
- NEVER allow anyone to occupy the trunk of the vehicle at any time. If the trunk is partially or totally latched and the person is unable to get out, serious injury or death could occur due to lack of ventilation, exhaust fumes and rapid heat build-up, or because of exposure to cold weather conditions. The trunk is also a highly dangerous location in the event of a crash because it is not a protected occupant space but is a part of the vehicle's crush zone.
- Your vehicle should be kept locked and the Smart Key should be kept out of the reach of children. Parents should teach their children about the dangers of playing in trunks.
- Use the release lever for emergencies only.

# **Smart Trunk Release** (if equipped)



On a vehicle equipped with a smart key, the trunk can be opened using the Smart Trunk release system.

#### How to use the Smart Trunk release

The trunk can be opened with no touch activation satisfying all the conditions below.

- After 15 seconds when all doors are closed and locked
- Positioned in the detecting area for more than 3 seconds

## *i* Information


The Smart Trunk release does not operate when:

- The smart key is detected within 15 seconds after the doors are closed and locked, and is continuously detected.
- The smart key is detected within 15 seconds after the doors are closed and locked, and 60 in. (1.5 m) from the front door handles. (for vehicles equipped with Welcome Light)
- · A door is not locked or closed.
- · The smart key is in the vehicle.

#### 1. Setting

To activate the Smart Trunk release, go to the Settings menu on the infotainment system and select smart trunk. Select:

- Setup > Vehicle > Door > Smart Trunk



#### 2. Detect and Alert

If you are positioned in the detecting area (20~40 in. (50~100 cm) behind the vehicle) carrying a smart key, the hazard warning lights will blink and chime will sound to alert you the smart key has been detected and the trunk will open.

## *i* Information

Do not approach the detecting area if you do not want the trunk to open. If you have unintentionally entered the detecting area and the hazard warning lights and chime starts to operate, leave the detecting area with the smart key. The trunk will stay closed.




### 3. Automatic opening

The hazard warning lights will blink and chime will sound 6 times and then the trunk will open.



- Make sure you close the trunk before driving your vehicle.
- Make sure there are no people or objects around the trunk before opening or closing the trunk.
- Make sure objects in the trunk do not come out when opening the trunk on a slope. It may cause serious injury.
- Make sure to deactivate the Smart Trunk when washing your vehicle. Otherwise, the trunk may open inadvertently.
- The key should be kept out of reach of children. Children may inadvertently open the Smart Trunk release while playing around the rear area of the vehicle.

# How to deactivate the Smart Trunk release function using the smart key



- 1. Door Lock
- 2. Door Unlock
- 3. Trunk unlock
- 4. Panic
- 5. Remote start (DCT models only)

If you press any button of the smart key during the Detect and Alert stage, the Smart Trunk release function will be deactivated.

Make sure to be aware of how to deactivate the Smart Trunk release function for emergency situations.

## *i* Information

- If you press the door unlock button (2), the Smart Trunk release function will be deactivated temporarily. But, if you do not open any door for 30 seconds, the smart trunk function will be activated again.
- If you press the trunk open button

   (4) for more than 1 second, the trunk opens.
- If you press the door lock button (1) or trunk open button (4) when the Smart Trunk release function is not in the Detect and Alert stage, the smart trunk function will not be deactivated.
- In case you have deactivated the Smart Trunk function by pressing the smart key button and opened a door, the Smart Trunk release function can be activated again by closing and locking all doors.

#### Detecting area



- The Smart Trunk release operates with a welcome alert if the smart key is detected within 20 ~ 40 inches (50 ~ 100 cm) from the trunk.
- The alert stops at once if the smart key is positioned outside the detecting area during the Detect and Alert stage.

## *i* Information

- The Smart Trunk release function will not work if any of the following occurs:
  - The smart key is close to a radio transmitter such as a radio station or an airport which can interfere with normal operation of the transmitter.
  - The smart key is near a mobile two way radio system or a cellular phone.
  - Another vehicle's smart key is being operated close to your vehicle.
- The detecting range may decrease or increase when:
  - One side of the tire is raised to replace a tire or to inspect the vehicle.
  - The vehicle is slantingly parked on a slope or unpaved road, etc.

#### **FUEL FILLER DOOR**

#### Opening the fuel filler door



The fuel filler door must be opened from inside the vehicle by pulling up the fuel filler door opener.

- 1. Turn the engine off.
- 2. Pull up the fuel filler door opener.



- 3. Pull the fuel filler door (1) out to fully open.
- 4. To remove the fuel tank cap (2), turn it counterclockwise. You may hear a hissing noise as the pressure inside the tank equalizes.
- 5. Place the cap on the fuel filler door



Open and close the reservoir cap by using the handle on the cap cover for safety.

## *i* Information

If the fuel filler door does not open because ice has formed around it, tap lightly or push on the door to break the ice and release the door. Do not pry on the door. If necessary, spray around the door with an approved de-icer fluid (do not use radiator anti-freeze) or move the vehicle to a warm place and allow the ice to melt.

### Closing the fuel filler door

- 1. To install the fuel tank cap, turn it clockwise until it "Clicks"
- 2. Close the fuel filler door until it is latched securely.

## **MARNING**

Gasoline is highly flammable and explosive. Failure to follow these guidelines may result in SERIOUS INJURY or DEATH:

- Read and follow all warnings posted at the gas station.
- Before refueling, note the location of the Emergency Gasoline Shut-Off, if available, at the gas station.
- Before touching the fuel nozzle, you should eliminate the potential buildup of static electricity by touching a metal part of the vehicle, a safe distance away from the fuel filler neck, nozzle, or other gas source, with your bare hand.
- Do not use cellular phones while refueling. Electric current and/or electronic interference from cellular phones can potentially ignite fuel vapors and cause a fire.

- Do not get back into a vehicle once you have begun refueling. You can generate a build-up of static electricity by touching, rubbing or sliding against any item or fabric capable of producing static electricity. Static electricity discharge can ignite fuel vapors causing a fire. If you must re-enter the vehicle, you should once again eliminate potentially dangerous static electricity discharge by touching a metal part of the vehicle. away from the fuel filler neck, nozzle or other gasoline source, with your hare hand.
- When refueling, always move the shift lever to the P (Park) position, set the parking brake, and set the Engine Start/Stop button to the OFF position.
- Sparks produced by electrical components related to the engine can ignite fuel vapors causing a fire.
- When using an approved portable fuel container, be sure to place the container on the ground prior to refueling. Static electricity discharge from the container can ignite fuel vapors causing a fire. Once refueling has begun, contact between your bare hand and the vehicle should be maintained until the filling is complete.
- Use only approved portable plastic fuel containers designed to carry and store gasoline.
- Do not use matches or a lighter and do not smoke or leave a lit cigarette in your vehicle while at a gas station, especially during refueling.

- Do not over-fill or top-off your vehicle tank, which can cause gasoline spillage.
- If a fire breaks out during refueling, leave the vicinity of the vehicle, and immediately contact the manager of the gas station and then contact the local fire department. Follow any safety instructions they provide.
- If pressurized fuel sprays out, it can cover your clothes or skin and thus subject you to the risk of fire and burns. Always remove the fuel cap carefully and slowly. If the cap is venting fuel or if you hear a hissing sound, wait until the condition stops before completely removing the cap.
- Always check that the fuel cap is installed securely to prevent fuel spillage in the event of an accident.

### *i* Information

Make sure to refuel your vehicle according to the "Fuel Requirements" suggested in the Introduction chapter.


#### NOTICE

- Do not spill fuel on the exterior surfaces of the vehicle. Any type of fuel spilled on painted surfaces may damage the paint.
- If the fuel filler cap requires replacement, use only a genuine HYUNDAI cap or the equivalent specified for your vehicle. An incorrect fuel filler cap can result in a serious malfunction of the fuel system or emission control system.

#### **EXTERIOR LIGHTS**

#### **Lighting Control**

To operate the lights, turn the knob at the end of the control lever to one of the following positions:




- 1. OFF
- 2. AUTO headlight
- 3. Parking light
- 4. Headlight

#### Daytime running light (DRL)

The Daytime Running Lights (DRL) can make it easier for others to see the front of your vehicle during the day, especially after dawn and before sunset.

The DRL system will turn the dedicated lamp OFF when:

- The headlights are ON.
- The parking lamps are ON.
- The vehicle is turned off.
- The parking brake is engaged.



#### **AUTO** headlight

The parking light and headlight will be turned ON or OFF automatically depending on the amount of daylight as measured by the ambient light sensor on the center dash (1).

Even with the AUTO headlight feature in operation, it is recommended to manually turn ON the headlights when driving at night or in a fog, driving in the rain, or when you enter dark areas, such as tunnels and parking facilities.

#### NOTICE

- Do not cover or spill anything on the sensor (1) located in front of the instrument panel.
- Do not clean the sensor using a window cleaner, the cleanser may leave a light film which could interfere with sensor operation.
- If your vehicle has window tint or other types of metallic coating on the front windshield, the AUTO headlight system may not work properly.



#### Parking light (-00-)

The parking light, license plate light and instrument panel light are turned ON.



#### Headlight (⟨□)

The headlight, parking light, license plate light and instrument panel light are turned ON.



#### Information

The Engine Start/Stop button must be in the ON position to turn on the headlight.

#### **High Beam Operation**



To turn on the high beam headlight, push the lever away from you. The lever will return to its original position.

The high beam indicator will light when the headlight high beams are switched on.

To turn off the high beam headlight, pull the lever towards you. The low beams will turn on.




#### WARNING

Do not use high beam when there are other vehicles approaching you. Using high beam could obstruct the other driver's vision.



To flash the high beam headlight, pull the lever towards you, then release the lever. The high beams will remain ON as long as you hold the lever towards you.

## **Turn Signals And Lane Change Signals**



To signal a turn, push down on the lever for a left turn or up for a right turn in position (A). To signal a lane change, move the turn signal lever slightly and hold it in position (B). The lever will return to the OFF position when released or when the turn is completed.

If an indicator stays on and does not flash or if it flashes abnormally, one of the turn signal bulbs may be burned out and will require replacement.

#### One touch turn signal function

To activate a one-touch turn signal function, move the turn signal lever slightly and then release it. The lane change signals will blink 3, 5 or 7 times.

You can activate or deactivate the One Touch Turn Signal function or choose the number of blinks (3, 5, or 7) from the infotainment system.



#### Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

#### **Battery Saver Function**

The purpose of this feature is to help prevent the battery from being discharged. The system automatically turns off the parking light when the driver turns the vehicle off and opens the driver-side door.

With this feature, the parking lights will turn off automatically if the driver parks on the side of road at night.

However, the position lights stay ON even when the driver-side door is opened if the headlight switch is turned to the position light or AUTO (if equipped) position after the engine is turned off.

If necessary, to keep the lights on turn the position lights OFF and ON again using the headlight switch on the steering column after the engine is turned off.

## Headlight Delay Function (if equipped)

If the Engine Start/Stop button is in the ACC parking or the OFF position with the headlights ON, the headlights (and/or parking lights) remain on for about 5 minutes. However, with the engine off if the driver's door is opened and closed, the headlights (and/or parking lights) are turned off after 15 seconds.

The headlights (and/or parking lights) can be turned off by pressing the lock button on the remote key or smart key twice or turning the light switch to the OFF or AUTO position. However, if you turn the light switch to the AUTO position when it is dark outside, the headlights will not be turned off.

You can activate or deactivate the Headlight Delay function from the infotainment system.

### *i* Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

#### NOTICE

If the driver exits the vehicle through another door besides the driver door, the battery saver function does not operate and the headlight delay function does not turn OFF automatically.

This may cause the battery to discharge. To avoid battery discharge, turn OFF the headlights manually from the headlight switch before exiting the vehicle.

#### **HIGH BEAM ASSIST (HBA)**



High Beam Assist will automatically adjust the headlight range (switches between high beam and low beam) depending on the brightness of detected vehicles and certain road conditions.

#### **Detecting Sensor**



[1]: Front view camera

The front view camera is used as a detecting sensor to help detect ambient light and brightness while driving.

Refer to the picture above for the detailed location of the detecting sensor.

#### NOTICE

- Always keep the front view camera in good condition to maintain optimal performance of High Beam Assist.
- For more details on the precautions of the front view camera, refer to "Forward Collision-Avoidance Assist (FCA)" section in chapter 7.

#### **High Beam Assist Settings**

#### Setting features

With the engine on, select 'Lights → High Beam Assist' from the Settings menu to turn on High Beam Assist and deselect to turn off the function.



### ⚠ W

#### WARNING

For your safety, only change the Settings after parking the vehicle at a safe location.

#### High Beam Assist Operation Display and control

- After selecting 'High Beam Assist' in the Settings menu, High Beam Assist will operate by following the procedure below.
  - Place the headlight switch in the AUTO position and push the headlight lever towards the instrument cluster. The High Beam Assist (♠) indicator light will illuminate on the cluster and High Beam Assist will be enabled.
  - When High Beam Assist is enabled, high beam will turn on when vehicle speed is above 20 mph (30 km/h). When vehicle speed is below 12 mph (20 km/h), high beam will turn off.
  - The High Beam ( ) indicator light will illuminate on the cluster when high beam is on.

- When High Beam Assist is operating, if the headlight lever or switch is used, High Beam Assist operates as follow:
  - If the headlight lever is pulled towards you when the high beam is off, the high beam will turn on without High Beam Assist canceled. When you let go of the headlight lever, the lever will move to the middle and the high beam will turn off.
  - If the headlight lever is pulled towards you when the high beam is on by High Beam Assist, low beam will turn on and High Beam Assist will turn off.
  - If the headlight switch is placed from AUTO to another position (headlight/position/off), High Beam Assist will turn off and the corresponding light will turn on.
- When High Beam Assist is operating, high beam switches to low beam if any of the following conditions occur:
  - When the headlight of an oncoming vehicle is detected.
  - When the tail light of a vehicle in front is detected.
  - When the headlight or tail light of a motorcycle or a bicycle is detected.
  - When the surrounding ambient light is bright enough that high beams are not required.
  - When streetlights or other lights are detected.

### *i* Information

The images and colors in the cluster may differ depending on the cluster type or theme selected from the cluster.

## **High Beam Assist Malfunction** and Limitations

#### High Beam Assist malfunction



B0179EU04

When High Beam Assist is not working properly, the 'Check High Beam Assist system' warning message will appear and \( \uldet\) warning light will illuminate on the cluster. Have the vehicle inspected by an authorized HYUNDAI dealer.

#### Limitations of High Beam Assist

High Beam Assist may not work properly in the following situations:

- Light from an oncoming or front vehicle is not detected because of lamp damage, or because it is hidden from sight, etc.
- Headlight of an oncoming or front vehicle is covered with dust, snow or water.
- A front vehicle's headlights are off, but the fog lights are on, etc.
- There is a lamp that has a similar shape as a vehicle's lamp.
- Headlights have been damaged or not repaired properly.
- · Headlights are not aimed properly.
- Driving on a narrow-curved road, rough road, uphill or downhill.
- Vehicle in front is partially visible on a crossroad or curved road.
- There is a traffic light, reflecting sign, flashing sign or mirror ahead.
- There is a temporary reflector or flash ahead (construction area).
- The road conditions are bad such as being wet, iced or covered with snow.
- A vehicle suddenly appears from a curve.
- The vehicle is tilted from a flat tire or is being towed.
- Light from an oncoming or front vehicle is not detected due to obstacles in the air such as exhaust fume, smoke, fog, snow, or water spay or blizzard on the road, or fogging in the lamp, etc.

### *i* Information

For more details on the limitations of the front view camera, refer to "Forward Collision-Avoidance Assist (FCA)" section in chapter 7.

### **MARNING**

- At times, High Beam Assist may not work properly High Beam Assist is for your convenience only. It is the responsibility of the driver for safe driving practices and always check the road conditions for your safety.
- When High Beam Assist does not operate properly, change the headlight position manually between high beam and low beam.

#### **INTERIOR LAMPS**



#### ! WARNING

Do not use the interior lamps when driving in the dark. The interior lamps may obscure your view and cause an accident.

#### NOTICE

Do not use the interior lamps for extended periods when the vehicle is turned off or the battery will discharge.

#### **Interior Lamp AUTO Cut**

The interior lamps will automatically go off approximately 20 minutes after the engine is turned off and the doors are closed. If a door is opened, the lamp will go off 40 minutes after the engine is turned off. If the doors are locked by the smart key and the vehicle enters the armed stage of the theft alarm system, the lamps will go off five seconds later.

#### **Front Lamps**



- (1) Front Map Lamp
- (2) Front Door Lamp
- (3) Front Room Lamp ON
- (4) Front Room Lamp OFF

#### Front map lamp:

Press either of these lens to turn the map lamp on or off. This light produces a spot beam for convenient use as a map lamp at night or as a personal lamp for the driver and the front passenger.

#### Front Door Lamp ( 🚟 ):

The front or rear room lamps come on when the front or rear doors are opened if the engine is running or not. When doors are unlocked by the smart key. the front and rear lamps come on for approximately 30 seconds as long as any door is not opened. The front and rear room lamps go out gradually after approximately 30 seconds if the door is closed. However, if the Engine Start/ Stop button is in the ON position or all doors are locked, the front and rear lamps will turn off. If a door is opened with the Engine Start/Stop button in the ACC position or the OFF position, the front and rear lamps stay on for about 20 minutes.

#### Front room lamp

- Press the button to turn ON the room lamp for the front/rear seats.
- Press the button to turn OFF the room lamp for the front/rear seats.

#### **Mood lighting (if equipped)**



The lamp turns on when **Setup > Vehicle** > **Lights > Ambient Lighting** is selected from the infotainment system.

### Information

- The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.
- The color of the mood lamp may seem different under some conditions depending on the color of the interior and the set mood color.

#### **Rear Lamp**




#### Rear Room Lamp (স্কু):

Press this switch to turn the rear room lamp on and off.

#### NOTICE

Do not leave the lamp switches on for an extended period of time when the engine is turned off.

#### **Luggage Compartment Lamp**



The luggage compartment lamp comes on when the trunk is opened.

#### NOTICE

The luggage compartment lamp comes on as long as the trunk is open. To prevent unnecessary battery system drain, close the trunk securely after using the luggage compartment.

#### **Vanity Mirror Lamp (if equipped)**



Push the switch to turn the light on or off.

- The lamp will turn on if this button is pressed.
- O: The lamp will turn off if this button is pressed.

#### NOTICE

Always have the switch in the off position when the vanity mirror lamp is not in use. If the sunvisor is closed without the lamp off, it may discharge the battery or damage the sunvisor.

#### Welcome System (if equipped) Welcome light



#### Door handle lamp (if equipped)

When all the doors (and trunk) are closed and locked, the door handle lamp will come on for about 15 seconds if any of the below is performed.

- · When the door unlock button is pressed on the smart key.
- When the button of the outside door handle is pressed.
- When the vehicle is approached with the smart key in possession.

#### Headlight and parking light

When the headlight (light switch in the headlight or AUTO position) is on and all doors (and trunk) are locked and closed. the headlight and parking light will come on for 15 seconds if/or any of the below is performed.

· When the door unlock button is pressed on the smart key.

At this time, if you press the door lock or unlock button, the headlight and parking light will turn off immediately.

You can activate or deactivate the Welcome Light from the infotainment system.



#### Information

The infotainment system may change after software undates. For more information. refer to the user's manual provided in the infotainment system and the quick reference guide.


#### Interior lamp

When the interior lamp switch is in the DOOR position and all doors (and trunk) are closed and locked, the room lamp will come on for 30 seconds if any of the below is performed.

- · When the door unlock button is pressed on the smart key.
- · When the button of the outside door handle is pressed.

At this time, if you press the door lock or unlock button, the room lamp will turn off immediately.

#### **WIPERS AND WASHERS**



A. Wiper speed control

- MIST Single wipe
- OFF Off
- INT Intermittent wipe AUTO\* – Auto control wipe
- LO Low wiper speed
- HI High wiper speed
- \*: if equipped
- B. Intermittent wipe time adjustment/ Auto control wipe time adjustment\*
- C. Wash with brief wipes

#### Windshield wipers

Operates as follows when the Engine Start/Stop button is in the ON position.

MIST: For a single wiping cycle,

push the lever upward and release. The wipers will operate continuously if the lever is held in this position.

OFF: Wiper is not in operation.

INT: Wiper operates intermittently

at the same wiping intervals.To vary the speed setting, turn the

speed control knob.

AUTO The rain sensor located (if equipped): on the upper end of the

windshield glass senses the amount of rainfall and controls the wiping cycle for the proper interval. The more it rains, the faster the wiper operates. When the rain stops, the wiper stops. To vary the speed setting, turn the speed control knob.

LO: The wiper runs at a lower speed.
HI: The wiper runs at a higher speed.

### *i* Information

If there is heavy accumulation of snow or ice on the windshield, defrost the windshield for about 10 minutes, or until the snow and/or ice is removed before using the windshield wipers to ensure proper operation.

If you do not remove the snow and/or ice before using the wiper and washer, it may damage the wiper and washer system.

#### Windshield Washers



In the OFF position, pull the lever gently toward you to spray washer fluid on the windshield and to run the wipers 1-3 cycles. The spray and wiper operation will continue until you release the lever. If the washer does not work, you may need to add washer fluid to the washer fluid reservoir

### **MARNING**

When the outside temperature is below freezing, ALWAYS warm the windshield using the defroster to help prevent the washer fluid from freezing on the windshield and obscuring your vision which could result in an accident and serious injury or death.

#### NOTICE

- To prevent possible damage to the washer pump, do not operate the washer when the fluid reservoir is empty.
- To prevent possible damage to the wipers or windshield, do not operate the wipers when the windshield is dry.
- To prevent damage to the wiper arms and other components, do not attempt to move the wipers manually.
- To prevent possible damage to the wipers and washer system, use antifreezing washer fluids in the winter season or cold weather.

#### **MANUAL CLIMATE CONTROL SYSTEM (IF EQUIPPED)**





- 1. Fan speed control knob
- 2. Temperature control knob
- 3. Mode selection knob
- 4. Front windshield defroster position
- 5. Rear window defroster button
- 6. Air intake control button
- 7. A/C (Air conditioning) button


#### **Heating and Air Conditioning**

- 1. Start the engine.
- Set the mode to the desired position.
   To improve the effectiveness of heating and cooling, select the mode according to the following:
  - Heating: 🕶
  - Cooling: 🛪
- 3. Set the temperature control to the desired position.
- 4. Set the air intake control to fresh mode or recirculation mode position.
- 5. Set the fan speed control to the desired speed.
- 6. If air conditioning is desired, turn the air conditioning system on.

When starting the vehicle in cold weather a more efficient way to heat the passenger compartment is to do the following.

- Turn off or lower the blower, right after starting the engine.
  - Engine temperature is still low and the air flow from the heater is still cold.
- After a few minutes of engine warm up, turn on or set the fan to a higher level and adjust the temperature setting towards hot.

#### Mode selection






The mode selection knob controls the direction of the air flow through the ventilation system.


Air can be directed to the floor, dashboard outlets, or windshield. Five symbols are used to represent Face, Bi-Level, Floor, Floor-Defrost and Defrost air position.



Air flow is directed toward the upper body and face. Additionally, each outlet can be controlled to direct the air discharged from the outlet.



Air flow is directed towards the face and the floor.



Most of the air flow is directed to the floor, with a small amount of the air being directed to the windshield and side window defrosters.



• Floor & Defrost (A, C, D, E)

Most of the air flow is directed to the floor and the windshield with a small amount directed to the side window defrosters.



Defrost-Level (A, D)

Most of the air flow is directed to the windshield with a small amount of air directed to the side window defrosters.



MAX A/C-Level (B, D) (if equipped)
The MAX A/C mode is used to cool the inside of the vehicle faster. Air flow is directed toward the upper body and face.

In this mode, the air conditioning and the recirculated air position cannot be selected. Turn the fan speed mode to adjust.

#### Instrument panel vents



#### **Instrument panel vents**

The instrument panel vent air flow can be directed up/down or left/right using the vent adjustment lever.

To close the vent, push the air vent lever in the opposite direction of the passenger. To open the vent, push the air vent lever in the same direction of the passenger.


#### Temperature control



The temperature will increase by turning the knob to the right.

The temperature will decrease by turning the knob to the left.

#### Air intake control



The air intake control button is used to select either Fresh mode (outside air) or Recirculation mode (cabin air).

#### Recirculation mode



When Recirculation mode is selected, air from the passenger compartment will be recirculated through the system and heated or cooled according to the function selected.

#### Fresh mode

■ Type A



When Fresh mode is selected, air enters the vehicle from outside and is heated or cooled according to the function selected.

■ Type E



### Information

Operating the system primarily in Fresh mode is recommended. Use Recirculation mode temporarily only when needed.

Prolonged operation of the heater in Recirculation mode and without the A/C ON can cause fogging of the windshield.

In addition, prolonged use of the A/C ON in Recirculation mode may result in excessively dry, dehumidified air in the cabin and may promote formation of musty vent odor due to stagnant air.

### A

#### WARNING

- Continued use of the climate control system operation in Recirculation mode for a prolonged period of time may cause drowsiness to the occupants in the cabin. This may lead to loss of vehicle control which may lead to an accident.
- Continued use of the climate control system operation in Recirculation mode with the A/C OFF may allow humidity to increase inside the cabin. This may cause condensation to accumulate on the windshield and obscure visibility.
- Do not sleep in your vehicle or remain parked in your vehicle with the windows up and either the heater or the air conditioning ON for prolonged periods of time. Doing so may increase the levels of carbon dioxide in the cabin which may lead to serious injury or death.

#### Fan speed control



Turn the knob to the right to increase the fan speed and airflow. Turn the knob to the left to decrease fan speed and airflow.

Setting the fan speed control knob to the "0" position turns off the fan.

#### NOTICE

Operating the fan speed when the Engine Start/Stop button is in the ON position could cause the battery to discharge. Operate the fan speed when the engine is running.

#### Air conditioning (if equipped)



Press the A/C button to turn the air conditioning system on (indicator light will illuminate). Press the button again to turn the air conditioning system off.

#### **System Operation**

#### Ventilation

- 1. Select the Face Level mode.
- 2. Set the air intake control to fresh mode.
- 3. Set the temperature control to the desired position.
- 4. Set the fan speed control to the desired speed.

#### Heating

- 1. Select the Floor Level . i mode.
- 2. Set the air intake control to fresh mode.
- 3. Set the temperature control to the desired position.
- 4. Set the fan speed control to the desired speed.
- If desired, turn the air conditioning ON with the temperature control knob set to heat in order to dehumidify the air before it enters into the cabin.

If the windshield fogs up, select the Floor & Defrost in mode or rotate the mode selecting knob to the Defrost in mode.

#### **Operation Tips**

- To help keep dust or unpleasant fumes from entering the vehicle through the ventilation system, temporarily set the air intake control to the recirculation mode. Be sure to return the control to fresh mode position when the irritation has passed to keep fresh air in the vehicle. This will help keep the driver alert and comfortable.
- To help prevent interior fog on the windshield, set the air intake control to fresh mode and fan speed to the desired position, turn on the air conditioning system, and adjust the temperature control to desired temperature.

#### Air conditioning

HYUNDAI Air Conditioning Systems are filled with R-1234yf refrigerant.

- 1. Start the vehicle.
- 2. Push the air conditioning button
- 3. Select the Face Level if mode.
- 4. Set the air intake control to Recirculation mode temporarily to allow the cabin to cool quickly. When the desired temperature in the cabin is reached, change the air intake control back to Fresh mode.
- Adjust the fan speed control and temperature control to maintain maximum comfort.

#### NOTICE


- When using the air conditioning system, monitor the temperature gauge closely while driving up hills or in heavy traffic when outside temperatures are high. Air conditioning system operation may cause engine overheating. Continue to use the blower fan but turn the air conditioning system off if the temperature gauge indicates engine overheating.
- When opening the windows in humid weather, air conditioning may create water droplets inside the vehicle.
   Since excessive water droplets may cause damage to electrical equipment, air conditioning should only be used with the windows closed.

Air conditioning system operation tips

- If the vehicle has been parked in direct sunlight during hot weather, open the windows for a short time to let the hot air inside the vehicle escape.
- After sufficient cooling has been achieved, switch back from recirculation mode to fresh mode.
- To help reduce moisture inside of the windows on rainy or humid days, decrease the humidity inside the vehicle by operating the air conditioning system with the windows and sunroof closed.
- During air conditioning system operation, you may occasionally notice a slight change in engine speed as the air conditioning compressor cycles. This is a normal system operation characteristic.
- Use the air conditioning system every month only for a few minutes to ensure maximum system performance.
- When using the air conditioning system, you may notice clear water dripping (or even puddling) on the ground under the passenger side of the vehicle. This is a normal system operation characteristic.
- If you operate the air conditioner excessively, the difference between the temperature of the outside air and that of the windshield could cause the outer surface of the windshield to fog up, causing loss of visibility. In this case, set the mode selection button to the position and set the fan speed control knob to the lowest speed setting.

#### **System Maintenance**

#### Cabin air filter



[A]: Outside air, [B]: Recirculated air [C]: Cabin air filter, [D]: Blower [E]: Evaporator core, [F]: Heater core

The cabin air filter is installed behind the glove box. It filters the dust or other pollutants that enter the vehicle through the heating and air conditioning system.

Have the cabin air filter replaced by an authorized HYUNDAI dealer according to the maintenance schedule. If the vehicle is being driven in severe conditions such as dusty or rough roads, more frequent cabin air filter inspections and changes are required.

If the air flow rate suddenly decreases, the system should be checked at an authorized HYUNDAI dealer.

### *i* Information

- Replace the filter according to the Maintenance Schedule.
- If the car is being driven in severe conditions such as dusty, rough roads, more frequent cabin air filter inspections and changes are required.
- When the air flow rate suddenly decreases, have the system be checked by an authorized HYUNDAI dealer.

# Checking the amount of air conditioner refrigerant and compressor lubricant

When the amount of refrigerant is low, the performance of the air conditioning is reduced. Overfilling also reduces the performance of the air conditioning system.

Therefore, if abnormal operation is found, have the system inspected by an authorized HYUNDAI dealer.

#### NOTICE

It is important that the correct type and amount of oil and refrigerant are used. Otherwise, damage to the compressor and abnormal system operation may occur. To prevent damage, the air conditioning system in your vehicle should only be serviced by trained and certified technicians.

#### NOTICE

- The refrigerant system should only be serviced by trained and certified technicians to insure proper and safe operation.
- The refrigerant system should be serviced in a well-ventilated place.
- The air conditioning evaporator (cooling coil) shall never be repaired or replaced with one removed from a used or salvaged vehicle and new replacement MAC evaporators shall be certified (and labeled) as meeting SAE Standard J2842.

### **MARNING**

Vehicles equipped with R-1234yf






Since the refrigerant is mildly flammable and operated at high pressure, the air conditioning system should only be serviced by trained and certified technicians. It is important that the correct type and amount of oil and refrigerant are used.

All refrigerants should be reclaimed with proper equipment.

Venting refrigerants directly to the atmosphere is harmful to individuals and environment. Failure to heed these warnings can lead to serious injuries.



Air conditioning refrigerant label
You can find out which air conditioning refrigerant is applied to your vehicle on the label located inside of the hood.



Each symbols and specification on the air conditioning refrigerant label is represented as below:

- 1. Classification of refrigerant
- 2. Amount of refrigerant
- 3. Classification of Compressor lubricant
- 4. Caution
- 5. Flammable refrigerant
- 6. To require registered technician to service air conditioning system

#### **AUTOMATIC CLIMATE CONTROL SYSTEM (IF EQUIPPED)**




- 1. Driver's temperature control knob
- 2. Passenger's temperature control knob
- 3. AUTO (automatic control) button
- 4. SYNC button
- 5. OFF button
- 6. Front windshield defroster button
- 7. Air conditioning button
- 8. Air intake control button
- 9. Rear window defroster button
- 10. Fan speed control button
- 11. Mode selection button
- 12. Climate control information screen

## Automatic Heating and Air Conditioning



#### 1. Press the AUTO button

The modes, fan speeds, air intake and air-conditioning will be controlled automatically according to the temperature setting you select.




OCN7050113


You can control the blower strength in three stages by pushing the AUTO button during automatic operation.

- HIGH: Provide rapid air conditioning and heating with strong blower
- MEDIUM: Provide air conditioning and heating with medium strength blower
- LOW: Is suitable for drivers that prefer lower air speeds

When you select the temperature to HI or LO in AUTO mode, the fan speed is set to 'HIGH'.



- Turn the temperature control knob to set the desired temperature. If the temperature is set to the lowest setting (Lo), the air conditioning system will operate continuously.
- To turn the automatic operation off, select any button of the following:
  - Mode selection button
  - Front windshield defroster button (Press the button one more time to deselect the front windshield defroster function. The 'AUTO' sign will illuminate on the information screen once again.)
  - Fan speed control toggle switch
     The selected function will be controlled manually while other functions operate automatically.
- For your convenience and overall system efficiency, use the AUTO button and set the temperature to 72°F (22°C).



### *i* Information


Never place anything near the sensor to ensure better control of the heating and cooling system.


## Manual Heating and Air Conditioning

The heating and cooling system can be controlled manually by pushing buttons other than the AUTO button. In this case, the system works sequentially according to the order of buttons selected. When pressing any button except the AUTO button while using automatic operation, the functions not selected will be controlled automatically.

- 1. Start the engine.
- Set the mode to the desired position.
   To improve the effectiveness of heating and cooling, select the mode according to the following:
  - Heating: 🇸 🕻
  - Cooling: نرح
- 3. Set the temperature control to the desired position.
- 4. Set the air intake control to fresh mode.
- 5. Set the fan speed control to the desired speed.
- 6. If air conditioning is desired, turn the air conditioning system on.
- Press the AUTO button in order to convert to full automatic control of the system.

#### Mode selection






The mode selection switch controls the direction of the air flow through the ventilation system.

The air flow outlet direction is cycled as follows:




Face-level (B, D)

Air flow is directed toward the upper body and face. Additionally, each outlet can be controlled to direct the air discharged from the outlet.




Air flow is directed towards the face and the floor.



Most of the air flow is directed to the floor, with a small amount of the air being directed to the windshield and side window defrosters.



Most of the air flow is directed to the floor and the windshield with a small amount directed to the side window defrosters and side vents.



#### Defrost-Level (A, D)

Most of the air flow is directed to the windshield with a small amount of air directed to the side window defrosters and side vents.




#### **Instrument panel vents**

The instrument panel vent air flow can be directed up/down or left/right using the vent adjustment lever.

To close the vent, push the air vent lever in the opposite direction of the passenger. To open the vent, push the air vent lever in the same direction of the passenger.

#### Temperature control



The temperature will increase by turning the knob to the right.

The temperature will decrease by turning the knob to the left.

The temperature will increase or decrease by 1°F (0.5°C) for each incremental location. When set to the lowest temperature setting, the air conditioning will operate continuously.



Adjusting the driver and passenger side temperature equally

- Press the "SYNC" button to adjust the driver and passenger side temperature equally.
- The passenger side temperature will be set to the same temperature as the driver side temperature.
- Turn the driver side temperature control knob. The driver and passenger side temperature will be adjusted equally.
- If you rotate the passenger's temperature control knob, the SYNC button is off and the passenger side temperature can be operated individually.

Adjusting the driver and passenger side temperature individually

Press the "SYNC" button again to adjust the driver and passenger side temperature individually. The button indicator will turn off.

#### **Temperature conversion**

If the battery has been discharged or disconnected, the temperature mode display will reset to Centigrade.

To change the temperature unit from °C to °F or °F to °C:

- Press the AUTO button for 3 seconds while pressing the OFF button.
- Infotainment system

### Go to Setup > General > Units > Temperature Unit.

The temperature unit on both the cluster display and the climate control screen will change.

#### Air intake control

#### Recirculated air position



With the recirculated air position selected, air from the passenger compartment will be drawn through the heating system and heated or cooled according to the function selected.

#### Outside (fresh) air position



With the outside (fresh) air position selected, air enters the vehicle from outside and is heated or cooled according to the function selected.

### *i* Information

Operating the system primarily in Fresh mode is recommended. Use Recirculation mode temporarily only when needed.


Prolonged operation of the heater in Recirculation mode and without the A/C ON can cause fogging of the windshield.

In addition, prolonged use of the A/C ON in Recirculation mode may result in excessively dry, dehumidified air in the cabin and may promote formation of musty yent odor due to stagnant air.

### **⚠** WARNING

- Continued use of the climate control system operation in Recirculation mode for a prolonged period of time may cause drowsiness to the occupants in the cabin. This may lead to loss of vehicle control which may lead to an accident.
- Continued use of the climate control system operation in Recirculation mode with the A/C OFF may allow humidity to increase inside the cabin. This may cause condensation to accumulate on the windshield and obscure visibility.
- Do not sleep in your vehicle or remain parked in your vehicle with the windows up and either the heater or the air conditioning ON for prolonged periods of time. Doing so may increase the levels of carbon dioxide in the cabin which may lead to serious injury or death.

#### Fan speed control



The fan speed can be set to the desired speed by using the fan speed control switch.


More air is delivered with higher fan speeds.

Pressing the OFF button turns off the fan.

#### NOTICE

Operating the fan speed when the Engine Start/Stop button is in the ON position could cause the battery to discharge. Operate the fan speed when the engine is running.


#### Air conditioning



Push the A/C button to manually turn the air conditioning system on (indicator light will illuminate).

Push the button again to turn the air conditioning system off.

#### **OFF** mode



Push the OFF button of the front to turn off the air climate control system. However, you can still operate the mode and air intake buttons as long as the Engine Start/Stop button is in the ON position.

#### **System Operation**

#### Ventilation

- 1. Select the Face Level mode.
- 2. Set the air intake control to fresh mode.
- 3. Set the temperature control to the desired position.
- 4. Set the fan speed control to the desired speed.

#### Heating

- 2. Set the air intake control to fresh mode.
- 3. Set the temperature control to the desired position.
- 4. Set the fan speed control to the desired speed.
- If desired, turn the air conditioning ON with the temperature control knob set to heat in order to dehumidify the air before it enters into the cabin.

If the windshield fogs up, select the Front & Deforst (m) mode or press the Front Defrost (m) mode.

#### **Operation Tips**

- To help keep dust or unpleasant fumes from entering the vehicle through the ventilation system, temporarily set the air intake control to the recirculation mode. Be sure to return the control to fresh mode position when the irritation has passed to keep fresh air in the vehicle. This will help keep the driver alert and comfortable.
- To help prevent interior fog on the windshield, set the air intake control to fresh mode and fan speed to the desired position, turn on the air conditioning system, and adjust the temperature control to desired temperature.

#### Air conditioning

HYUNDAI Air Conditioning Systems are filled with R-1234yf refrigerant.

- 1. Start the vehicle.
- 2. Push the air conditioning button.
- 3. Select the Face Level if mode.
- 4. Set the air intake control to Recirculation mode temporarily to allow the cabin to cool quickly. When the desired temperature in the cabin is reached, change the air intake control back to Fresh mode.
- Adjust the fan speed control and temperature control to maintain maximum comfort.

#### NOTICE


- When using the air conditioning system, monitor the temperature gauge closely while driving up hills or in heavy traffic when outside temperatures are high. Air conditioning system operation may cause engine overheating. Continue to use the blower fan but turn the air conditioning system off if the temperature gauge indicates engine overheating.
- When opening the windows in humid weather, air conditioning may create water droplets inside the vehicle. Since excessive water droplets may cause damage to electrical equipment, air conditioning should only be used with the windows closed

Air conditioning system operation tips

- If the vehicle has been parked in direct sunlight during hot weather, open the windows for a short time to let the hot air inside the vehicle escape.
- After sufficient cooling has been achieved, switch back from recirculation mode to fresh mode.
- To help reduce moisture inside of the windows on rainy or humid days, decrease the humidity inside the vehicle by operating the air conditioning system with the windows and sunroof closed.
- During air conditioning system operation, you may occasionally notice a slight change in engine speed as the air conditioning compressor cycles. This is a normal system operation characteristic.
- Use the air conditioning system every month only for a few minutes to ensure maximum system performance.
- When using the air conditioning system, you may notice clear water dripping (or even puddling) on the ground under the passenger side of the vehicle. This is a normal system operation characteristic.
- If you operate the air conditioner excessively, the difference between the temperature of the outside air and that of the windshield could cause the outer surface of the windshield to fog up, causing loss of visibility. In this case, set the mode selection button to the position and set the fan speed control knob to the lowest speed setting.

#### **System Maintenance**

#### Cabin air filter



[A]: Outside air, [B]: Recirculated air [C]: Cabin air filter, [D]: Blower [E]: Evaporator core, [F]: Heater core

The cabin air filter is installed behind the glove box. It filters the dust or other pollutants that enter the vehicle through the heating and air conditioning system.

Have the cabin air filter replaced by an authorized HYUNDAI dealer according to the maintenance schedule. If the vehicle is being driven in severe conditions such as dusty or rough roads, more frequent cabin air filter inspections and changes are required.

If the air flow rate suddenly decreases, the system should be checked at an authorized HYUNDAI dealer.

### *i* Information

- Replace the filter according to the Maintenance Schedule.
- If the car is being driven in severe conditions such as dusty, rough roads, more frequent cabin air filter inspections and changes are required.
- When the air flow rate suddenly decreases, have the system be checked by an authorized HYUNDAI dealer.

# Checking the amount of air conditioner refrigerant and compressor lubricant

When the amount of refrigerant is low, the performance of the air conditioning is reduced. Overfilling also reduces the performance of the air conditioning system.

Therefore, if abnormal operation is found, have the system inspected by an authorized HYUNDAI dealer.

#### NOTICE

It is important that the correct type and amount of oil and refrigerant are used. Otherwise, damage to the compressor and abnormal system operation may occur. To prevent damage, the air conditioning system in your vehicle should only be serviced by trained and certified technicians.

#### NOTICE

- The refrigerant system should only be serviced by trained and certified technicians to insure proper and safe operation.
- The refrigerant system should be serviced in a well-ventilated place.
- The air conditioning evaporator (cooling coil) shall never be repaired or replaced with one removed from a used or salvaged vehicle and new replacement MAC evaporators shall be certified (and labeled) as meeting SAE Standard J2842.

# **MARNING**

Vehicles equipped with R-1234yf







Since the refrigerant is mildly flammable and operated at high pressure, the air conditioning system should only be serviced by trained and certified technicians. It is important that the correct type and amount of oil and refrigerant are used.

All refrigerants should be reclaimed with proper equipment.

Venting refrigerants directly to the atmosphere is harmful to individuals and environment. Failure to heed these warnings can lead to serious injuries.



Air conditioning refrigerant label
You can find out which air conditioning
refrigerant is applied to your vehicle on
the label located inside of the hood.



Each symbols and specification on the air conditioning refrigerant label is represented as below:

- 1. Classification of refrigerant
- 2. Amount of refrigerant
- 3. Classification of Compressor lubricant
- 4. Caution
- 5. Flammable refrigerant
- 6. To require registered technician to service air conditioning system

#### WINDSHIELD DEFROSTING AND DEFOGGING




#### Windshield heating

Do not use the () or () position during cooling operation in extremely humid weather. The difference between the temperature of the outside air and that of the windshield could cause the outer surface of the windshield to fog up, causing loss of visibility. In this case, set the mode selection knob or button to the () position and fan speed control knob or button to lower speed.

- For maximum defrost performance, set the temperature control knob to the highest temperature setting (rotated all the way to the right) and the fan speed control to the highest setting.
- If warm air to the floor is desired while defrosting or defogging, set the mode to the floor-defrost position.
- Before driving, clear all snow and ice from the windshield, rear window, side view mirrors, and all side windows.
- Clear all snow and ice from the hood and air inlet in the cowl grill to improve heater and defroster efficiency and to reduce the probability of fogging up inside of the windshield.

# Manual Climate Control System To defog inside windshield




[A]: Type A, [B]: Type B

- Select any fan speed except "0" position.
- 2. Select the desired temperature.
- 3. Select the 🍑 or 🗰 position.
- 4. Fresh mode air will be selected automatically. Additionally, the air conditioning (if equipped) will automatically operate if the mode is selected to the position.

If the air conditioning and fresh mode are not selected automatically, press the corresponding button manually.

#### To defrost outside windshield




[A]: Type A, [B]: Type B

- Set the fan speed to the highest setting (knob rotated all the way to the right).
- 2. Set the temperature control to the highest temperature setting.
- 3. Select the mp position.
- Fresh mode air and air conditioning (if equipped) will be selected automatically.

# **Automatic Climate Control System**

## To defog inside windshield



- 1. Select desired fan speed.
- 2. Select desired temperature.
- 3. Press the defroster button (\( \mathbb{M} \)).
- The air-conditioning will turn on according to the detected ambient temperature, fresh mode and higher fan speed will be selected automatically.

If the air-conditioning, fresh mode and higher fan speed are not selected automatically, adjust the corresponding button or knob manually.

If the position is selected, lower fan speed is controlled to higher fan speed.

#### To defrost outside windshield



- 1. Set fan speed to the highest position.
- 2. Set temperature to the extreme hot (HI) position.
- 3. Press the defroster button (\(\pi\)).
- The air-conditioning will turn on according to the detected ambient temperature and fresh mode will be selected automatically.

If the mospher position is selected, lower fan speed is controlled to higher fan speed.

## **Defogging Logic (if equipped)**

To help reduce the probability of fogging up the inside of the windshield, the air intake or air conditioning are controlled automatically according to certain conditions such as or position. To cancel or return the defogging logic, do the following

#### Manual climate control system

- 1. Press the Engine Start/Stop button to the ON position.
- Select defroster mode (\(\mathbb{M}\)).
- Press the air intake control button at least 5 times within 3 seconds. The process should be completed within 10 seconds after the defroster mode ( iii) is selected.

The LED indicator on the air intake button will blink 3 times to indicate that the defogging logic has been disabled. Repeat the steps again to re-enable the defogging logic.

If the battery has been discharged or disconnected, it resets to the defog logic status.

#### Automatic climate control system

- 1. Press the Engine Start/Stop button to the ON position.
- 2. Press the defroster button ().
- While pressing the air conditioning button (A/C), press the air intake control button at least 5 times within 3 seconds.

The automatic climate control information screen will blink 3 times to indicate that the defogging logic has been disabled.

Repeat the steps again to re-enable the defogging logic.

If the battery has been discharged or disconnected, it resets to the defog logic status.

## **Auto Defogging System (only** for automatic climate control system, if equipped)



Auto defogging helps reduce the possibility of fogging up the inside of the windshield by automatically sensing the moisture on inside the windshield.

The auto defogging system operates when the heater or air conditioning is on.



When the Auto Defogging System operates, the indicator AUTO will illuminate.

If a high amount of humidity is detected in the vehicle, the Auto Defogging System will be enabled.

The following steps will be performed automatically:

- Step 1) The A/C button will turn ON.
- Step 2) The air intake control will change to Fresh mode under low outside temperature.
- Step 3) The mode will be changed to defrost to direct airflow to the windshield.
- Step 4) The fan speed will be increased.

To cancel or reset the Auto Defogging System

Press the front windshield defroster button for 3 seconds when the Engine Start/Stop button is in the ON position.

When the Auto Defogging System is canceled, defrost button indicator will hlink 3 times

When the Auto Defogging System is reset, defrost button indicator will blink 6 times without a signal.

# Information

- When the air conditioning is turned on by Auto defogging system, if you try to turn off the air conditioning, the indicator will blink 3 times and the air conditioning will not be turned off.
- To maintain the effectiveness and efficiency of the Auto Defogging System, do not select Recirculation mode while the system is operating.
- When the Auto Defogging System is operating, the fan speed adjustment knob, the temperature adjustment knob, and the air intake control button are all disabled.

## NOTICE

Do not remove the sensor cover located on the upper end of the driver side windshield glass.

Damage to system parts could occur and may not be covered by your vehicle warrantv.

#### **Defroster**


## NOTICE

To prevent damage to the conductors bonded to the inside surface of the rear window, never use sharp instruments or window cleaners containing abrasives to clean the window.



If you want to defrost and defog the front windshield, refer to "Windshield Defrosting and Defogging" in this chapter.

#### Rear window defroster



The defroster heats the window to remove frost, fog and thin ice from the interior and exterior of the rear window, while engine is running.

- To activate the rear window defroster, press the rear window defroster button located in the center facia switch panel. The indicator on the rear window defroster button illuminates when the defroster is ON.
- To turn off the defroster, press the rear window defroster button again.

# *i* Information

- If there is heavy accumulation of snow on the rear window, brush it off before operating the rear defroster.
- The rear window defroster automatically turns off after approximately 20 minutes or when the Engine Start/Stop button is in the OFF position.

# Side view mirror defroster (if equipped)

If your vehicle is equipped with the side view mirror defrosters, they will operate at the same time you turn on the rear window defroster.

#### **CLIMATE CONTROL ADDITIONAL FEATURES**

# **Sunroof Inside Air Recirculation** (if equipped)

When the sunroof is opened, outside (fresh) air will be automatically selected. At this time, if you press the air intake control button, recirculated air position will be selected but will change back to outside (fresh) air after 3 minutes. When the sunroof is closed, the air intake position will return to the original position that was selected.

# Automatic Ventilation (if equipped)

The system automatically selects the fresh mode when the climate control system operates over a certain period of time (approximately 30 minutes) in low temperature with the recirculation mode selected.

#### To cancel or reactivate the Automatic Ventilation

When the air conditioning system is on, select Face Level immode and press the air recirculation mode button at least 5 times within 3 seconds while pressing the A/C button.

When the automatic ventilation is canceled, the indicator blinks 3 times. When the automatic ventilation is activated, the indicator blinks 6 times.

#### STORAGE COMPARTMENT



## WARNING

Never store cigarette lighters, propane cylinders, or other flammable/explosive materials in the vehicle. These items may catch fire and/or explode if the vehicle is exposed to hot temperatures for extended periods.



## ! WARNING

ALWAYS keep the storage compartment covers closed securely while driving. Items inside your vehicle are moving as fast as the vehicle. If you have to stop or turn quickly, or if there is a crash, the items may fly out of the compartment and may cause an injury if they strike the driver or a passenger.

## NOTICE

To avoid possible theft, do not leave valuables in the storage compartments.


## **Center Console Storage**



To open:

Grab and hold the latch on the armrest then lift the lid.

#### **Glove Box**



To open: Pull the lever (1).



## WARNING

ALWAYS close the glove box door after use.

An open glove box door can cause serious injury to the passenger in an accident, even if the passenger is wearing a seat belt.

#### **INTERIOR FEATURES**

### **Cup Holder**



## **!** WARNING

- Avoid abrupt starting and braking when the cup holder is in use to prevent spilling your drink. If hot liquid spills, you could be burned.
   Such a burn to the driver could cause loss of vehicle control resulting in an accident.
- Do not place uncovered or unsecured cups, bottles, cans, etc., in the cup holder containing hot liquid while the vehicle is in motion. Injuries may result in the event of a sudden stop or collision.
- Only use soft cups in the cup holders. Hard objects can injure you in an accident.


# **MARNING**

Keep cans or bottles out of direct sun light and do not put them in a hot vehicle. It may explode.

## NOTICE

- Keep your drinks sealed while driving to prevent spilling your drink. If liquid spills, it may get into the vehicle's electrical/electronic system and damage electrical/electronic parts.
- When cleaning spilled liquids do not use hot air to blow out or dry the cup holder. This may damage the interior.

#### Sunvisor



To use a sunvisor, pull it downward.

To use a sunvisor for a side window, pull it downward, unsnap it from the bracket (1) and swing it to the side (2).

To use the vanity mirror, pull down the sunvisor and slide the mirror cover (3).

Adjust the sunvisor forward or backward (4, if equipped) as needed.

Use the ticket holder (5) to hold tickets.

Close the vanity mirror cover securely and return the sunvisor to its original position after use.

## NOTICE

Close the vanity mirror cover securely and return the sunvisor to its original position after use.

# A


#### WARNING

For your safety, do not block your view when using the sunvisor.

## NOTICE

Do not put several tickets in the ticket holder at one time. This could cause damage to the ticket holder.

#### **Power Outlet**



The power outlet is designed to provide power for mobile telephones or other devices designed to operate with vehicle electrical systems. The devices should draw less than 180 W with the engine runnina.



## ! WARNING

Avoid electrical shocks. Do not place your fingers or foreign objects (pin. etc.) into a power outlet or touch the power outlet with a wet hand.


## NOTICE

To prevent damage to the Power **Outlets:** 

- Use the power outlet only when the engine is running and remove the accessory plug after use. Using the accessory plug for prolonged periods of time with the engine off could cause the battery to discharge.
- Only use 12 V electric accessories which are less than 180 W in electric capacity.
- Adjust the air-conditioner or heater to the lowest operating level when using the power outlet.
- Close the cover when not in use.
- Some electronic devices can cause electronic interference when plugged into a vehicle's power outlet. These devices may cause excessive audio static and malfunctions in other electronic systems or devices used in your vehicle.
- · Push the plug in as far as it will go. If good contact is not made, the plug may overheat and the fuse may open.
- Plug in battery equipped electrical/ electronic devices with reverse current protection. The current from the battery may flow into the vehicle's electrical/electronic system and cause system malfunction.

## **USB** charger






The USB charger is located inside the console box between the driver's seat and the front passenger's seat. Insert the USB charger into the USB port, and recharge a smartphone or a tablet PC.

- A charging status/charging completion message is displayed on a screen of a smartphone or a tablet PC.
- A smartphone or a tablet PC may get warmer during the re-charging process. It does not indicate any malfunction with the charging system.
- A smartphone or a tablet PC, which adopts a different re-charging method, may not be properly recharged. In this case, use an exclusive charger of your device.
- The charging terminal is only to recharge a device. Do not use the charging terminal either to turn ON an audio or to play media on the infotainment system.

# Wireless Smartphone Charging System (if equipped)



[A]: Charging indicator

There is a wireless smartphone charger inside the front console.

The system is available when all doors are closed, and when the Engine Start/Stop button is in the ON position.

#### Charging smartphone

The wireless smartphones charging system charges only the Qi-enabled smartphones (  $\dot{\mathbf{q}}$  ). Read the label on the smartphone accessory cover or visit your smartphone manufacturer's website to check whether your smartphone supports the Qi technology.

The wireless charging process starts when you put a Qi-enabled smartphone on the wireless charging unit.

- Remove other items, including the smart key, from the wireless charging unit. If not, the wireless charging process may be interrupted. Place the smartphone on the center of the charging pad.
- The indicator light is orange when the smartphone is charging. The indicator light turns green when phone charging is complete.
- You can turn ON or OFF the wireless charging function in the infotainment system. Select:

Setup > Vehicle > Convenience > Wireless charging system

If your smartphone is not charging:

- Move the smartphone on the charging pad.
- Make sure the indicator light is orange.

The indicator light blinks orange for 10 seconds if there is a malfunction in the wireless charging system.

The system warns you with a message on the cluster display if the smartphone is still on the wireless charging pad after the vehicle is turned OFF and the front door is opened.

# *i* Information

- For some manufacturers' smartphones, the system may not warn you even though the smartphone is left on the wireless charging unit. This is due to the particular characteristic of the smartphone and not a malfunction of the wireless charging.
- For flip type smartphones, when using wireless charging, place the smartphone folded with the device's back placed on the center of the wireless charging unit.
- The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

#### **NOTICE**

- The wireless smartphone charging system may not support certain smartphones, which are not verified for the Qi specification ( Qi ).
- When placing your smartphone on the charging mat, position the phone in the middle of the mat for optimal charging performance. If your smartphone is off to the side, the charging rate may be less and in some cases the smartphone may experience higher heat conduction.
- In some cases, the wireless charging may stop temporarily when the smart key is used, either when starting the vehicle or locking/ unlocking the doors, etc.
- The wireless charging process may temporarily stop, when temperature abnormally increases inside the wireless smartphone charging system. Stop the charging smartphone and wait until temperature falls to a certain level.

- The wireless charging process may temporarily stop when there is any metallic item, such as a coin, between the wireless smartphone charging system and the smartphone.
- When using a smartphone application, such as Android Auto, while charging, the charging process may be delayed or interrupted due to the smartphone overheating. This issue is not related to the wireless charging system but rather caused by the smartphone's selfheating. Therefore, disconnect the smartphone from the charging pad.
- If the smartphone has a thick cover, the wireless charging may not be possible.
- If the smartphone is not completely contacting the charging pad, wireless charging may not operate properly.
- Some magnetic items like credit cards, phone cards or rail tickets may be damaged if left with the smartphone during the charging process.
- When any smartphone without a wireless charging function or a metallic object is placed on the charging pad, a small noise may sound. This small sound is due to the vehicle discerning compatibility of the object placed on the charging pad. It does not affect your vehicle or the smartphone in any way.
- Some smartphones may not be able to charge depending on the internal structure of the smartphone. If this occurs, try charging the smartphone by moving it to the left or right side of the wireless charging pad. However, for some foldable smartphones that have magnets inside the smartphone, try charging the smartphone while holding it close to the left side of the wireless charging pad.

- During wireless charging, an internal fan operates to prevent overheating.
   Fan noise may sound.
- Wireless charging speed varies depending on the wireless charging policy and product specifications set by each smartphone manufacturer.
   You can check your smartphone's maximum wireless charging speed in the user manual provided by the smartphone manufacturer.
- It is normal for your smartphone to heat up during the charging process. When using Android Auto or Apple CarPlay, your smartphone may heat up more quickly, and the charging process may be slower.

# *i* Information

If the Engine Start/Stop button is in the OFF position, the charging also stops.

## *i* Information

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

#### Clock



## ! WARNING

Do not attempt to adjust the clock while driving. Doing so may result in distracted driving which may lead to an accident involving personal injury or death.



## *i* Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

#### Coat Hook



These hangers are not designed to hold large or heavy items.



## WARNING



Do not hang other objects such as hangers or hard objects except clothes. Also, do not put heavy, sharp or breakable objects in the clothes pockets. In an accident or when the curtain air bag is inflated, it may cause vehicle damage or personal injury.

#### INFOTAINMENT SYSTEM

# *i* Information

- If you install an aftermarket HID headlight, your vehicle's audio and electronic device may malfunction.
- Prevent chemicals such as perfume, cosmetic oil, sun cream, hand cleaner, and air freshener from contacting the interior parts because they may cause damage or discoloration.

#### **USB Port**




This is a convenient device that allows external sound devices such as MP3 and USB storage devices to be connected to the vehicle and played back through the vehicle infotainment system.

# *i* Information

When using a portable audio device connected to the power outlet, noise may occur during playback. If this happens, use the power source of the portable audio device.

#### **Antenna**



#### Shark fin antenna (1)

The shark fin antenna receives transmitted data. (for example: GPS)

#### Glass antenna (2)

Your vehicle uses a glass antenna to receive both AM and FM signals.

\* The signals which antenna can transmit and receive vary by the vehicle option.

## NOTICE

- To prevent damage to the rear glass antenna, never use sharp instruments or window cleaner containing abrasives to clean the window. Clean the inside surface of the rear glass window with a piece of soft cloth.
- When putting a sticker on the inside surface of the rear window, be careful not to damage to the rear glass antenna.
- Avoid adding metallic coatings such as Ni, Cd, etc.
- These can degrade the receiving AM and FM broadcast signals.
- Do not put sharp instruments nearby the rear glass antenna.
- Tinted rear window may affect the proper functioning of the antenna.

#### **Steering Wheel Audio Control**



OCN7N053203N

The steering wheel audio control switches are installed for your convenience.

## NOTICE

Do not operate audio remote control buttons simultaneously.

#### **VOLUME (VOL + / VOL -) (1)**

- Move the VOLUME toggle switch up to increase volume.
- Move the VOLUME toggle switch down to decrease volume.

# *i* Information

You can set the volume level of each source (FM, AM, SXM, USB, BT, etc.) individually by adjusting the VOLUME scroll.

Then the infotainment system saves the last volume level of each source in the system sound settings.

If you change the source, the volume will revert to the previously set volume for that source.

#### SEEK/PRESET ( $\wedge$ / $\vee$ ) (2)

If the SEEK/PRESET toggle switch is moved up or down and held for 0.8 second or more, it will function in the following modes.

- RADIO mode
   It will function as the AUTO SEEK select switch. It will SEEK until you release the switch.
- MEDIA mode
   It will function as the FF/REW switch.

If the SEEK/PRESET toggle switch is moved up or down, it will function in the following modes.

- RADIO mode
   It will function as the PRESET STATION UP/DOWN switch.
- MEDIA mode
   It will function as the TRACK UP/ DOWN switch.

## **MODE** ((○) (3)

Press the MODE button to select Audio Source.

## MUTE (或) (4)

- Press the button to mute the sound.
- Press the button again to activate the sound.

### Custom button (★) (5)

You can set the function to be executed by pressing the user button on the steering wheel. It is convenient to set frequently used functions as user button functions.

For detailed information, refer to the infotainment system manual separately supplied.

## **Infotainment System**



The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

## **Voice Recognition (if equipped)**



OCN7N073129N

Voice recognition allows you to command a variety of infotainment functions.

The Infotainment system may be changed by an system update. Please see additional information in supplied Infotainment Manual

# Bluetooth® Wireless Technology Hands-free (if equipped)



OCN7N053075N




You can use the phone wirelessly by using the Bluetooth® Wireless Technology.

- (1) Call / Answer button
- (2) Microphone 1
- (3) Microphone 2

For detailed information, refer to the infotainment system manual separately supplied.

# How Vehicle Radio Works FM reception



AM and FM radio signals are broadcast from transmitter towers located around your city. They are intercepted by the radio antenna on your vehicle. This signal is then received by the radio and sent to your vehicle speakers.

When a strong radio signal has reached your vehicle, the precise engineering of your audio system ensures the best possible quality reproduction. However, in some cases the signal coming to your vehicle may not be strong and clear.


This can be due to factors, such as the distance from the radio station, closeness of other strong radio stations or the presence of buildings, bridges or other large obstructions in the area.

#### AM (MW, LW) reception




AM broadcasts can be received at greater distances than FM broadcasts. This is because AM radio waves are transmitted at low frequencies. These long, low frequency radio waves can follow the curvature of the earth rather than travelling straight out into the atmosphere. In addition, they curve around obstructions so that they can provide better signal coverage.

#### FM radio station




FM broadcasts are transmitted at high frequencies and do not bend to follow the earth's surface. Because of this, FM broadcasts generally begin to fade at short distances from the station. Also, FM signals are easily affected by buildings, mountains, or other obstructions.

These can result in certain listening conditions which might lead you to believe a problem exists with your radio. The following conditions are normal and do not indicate radio trouble:



- Fading as your vehicle moves away from the radio station, the signal will weaken and sound will begin to fade. When this occurs, we suggest that you select another stronger station.
- Flutter/Static Weak FM signals or large obstructions between the transmitter and your radio can disturb the signal causing static or fluttering noises to occur. Reducing the treble level may lessen this effect until the disturbance clears.



- Station Swapping As a FM signal weakens, another more powerful signal near the same frequency may begin to play. This is because your radio is designed to lock onto the clearest signal. If this occurs, select another station with a stronger signal.
- Multi-Path Cancellation Radio signals being received from several directions can cause distortion or fluttering. This can be caused by a direct and reflected signal from the same station, or by signals from two stations with close frequencies. If this occurs, select another station until the condition has passed.

# Using a cellular phone or a twoway radio

When a cellular phone is used inside the vehicle, noise may be produced from the audio system. This does not mean that something is wrong with the audio equipment. In such a case, use the cellular phone at a place as far as possible from the audio equipment.

#### NOTICE

When using a communication system such as a cellular phone or a radio set inside the vehicle, a separate external antenna must be fitted. When a cellular phone or a radio set is used with an internal antenna alone, it may interfere with the vehicle's electrical system and adversely affect safe operation of the vehicle.



## WARNING

Do not use a cellular phone while driving. Stop at a safe location to use a cellular phone.

# **6.Driving Your Vehicle**

Before Driving	6-4
Before Entering the Vehicle	
Before Starting	6-4
Engine Start/Stop Button	6-5
Remote start	
Vehicle Auto-Shut Off	6-11
Operating Conditions	
Deactivating Conditions	
System Operation	6-11
Manual Transmission (MT)	6-12
Manual Transmission Operation	
Good Driving Practices	6-14
Rev Matching	6-15
Dual Clutch Transmission (DCT)	6-18
Dual Clutch Transmission Operation	
Cluster Display for Transmission Temperature and Warning Message	
Parking	
Paddle Shifter (Manual Shift Mode)	
Good Driving Practices	
Brake System	
Power Brakes	
Disc Brakes Wear IndicatorHigh Performance Brake	
Parking Brake	
Anti-lock Brake System (ABS)	
Electronic Stability Control (ESC)	
Vehicle Stability Management (VSM)	
Hill-Start Assist Control (HAC)	
Good Braking Practices	6-39
Electronic Control Suspension (ECS)	6-40
Electronic Limited Slip Differential	
Warning Messages	

N Button	6-42
Drive Mode Integrated Control System	6-44 6-46
Vehicle Characteristic	6-49
Performance Option	6-516-526-556-576-59
Special Driving Conditions  Hazardous Driving Conditions  Rocking the Vehicle  Smooth Cornering  Driving at Night  Driving in the Rain  Driving in Flooded Areas  Highway Driving	6-62 6-63 6-63 6-63 6-64
Winter Driving	6-65
Vehicle Load Limit	
Trailer Towing	6-73

# **MARNING**

# Carbon monoxide (CO) gas is toxic. Breathing CO can cause unconsciousness and death.

Engine exhaust contains carbon monoxide which cannot be seen or smelled.

#### Do not inhale engine exhaust.

If at any time you smell engine exhaust inside the vehicle, open the windows immediately. Exposure to CO can cause unconsciousness and death by asphyxiation.

#### Be sure the exhaust system does not leak.

The exhaust system should be checked whenever the vehicle is raised to change the oil or for any other purpose. If you hear a change in the sound of the exhaust or if you drive over something that strikes the underneath side of the vehicle, have the exhaust system checked as soon as possible by an authorized HYUNDAI dealer.

#### Do not run the engine in an enclosed area.

Letting the engine idle in your garage, even with the garage door open, is a hazardous practice. Run the engine only long enough to start the engine and to move the vehicle out of the garage.

#### Avoid idling the engine for prolonged periods with people inside the vehicle.

If it is necessary to idle the engine for a prolonged period with people inside the vehicle, be sure to do so only in an open area with the air intake set at "Fresh" and fan control set to high so fresh air is drawn into the interior.

#### Keep the air intakes clear.

To assure proper operation of the ventilation system, keep the ventilation air intakes located in front of the windshield clear of snow, ice, leaves, or other obstructions.

#### If you must drive with the trunk open:

Close all windows.

Open instrument panel air vents.

Set the air intake control at "Fresh", the air flow control at "Floor" or "Face", and the fan control set to high.



#### **CALIFORNIA PROPOSITION 65 WARNING**

Engine exhaust and a wide variety of automobile components including components found in the interior furnishings in a vehicle, contain or emit harmful chemicals known to the State of California to cause cancer and birth defects and reproductive harm. In addition, certain fluids contained in vehicles and certain products of components contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

#### **BEFORE DRIVING**

## **Before Entering the Vehicle**

- Be sure all windows, side view mirror(s), and outside lights are clean and unobstructed.
- · Remove frost, snow, or ice.
- Visually check the tires for uneven wear and damage.
- Check under the vehicle for any sign of leaks.
- Be sure there are no obstacles behind you if you intend to back up.

## **Before Starting**

- Make sure the hood, the trunk, and the doors are securely closed and locked
- Adjust the position of the seat and steering wheel.
- Adjust the inside and side view mirrors.
- · Verify all the lights work.
- Fasten your seatbelt. Check that all passengers have fastened their seatbelts.
- Check the gauges and indicators in the instrument cluster and the messages on the cluster display when the Engine Start/Stop button is in the ON position.
- Check that any items you are carrying are stored properly or fastened down securely.

# **⚠** WARNING

To reduce the risk of SERIOUS INJURY or DEATH, take the following precautions:

- ALWAYS wear your seat belt. All passengers must be properly belted whenever the vehicle is moving.
   For more information, refer to "Seat Belts" in chapter 3.
- Always drive defensively. Assume other drivers or pedestrians may be careless and make mistakes.
- Stay focused on the task of driving.
   Driver distraction can cause accidents.
- Leave plenty of space between you and the vehicle in front of you.

# **MARNING**

NEVER drink alcohol or take drugs and drive.

Drinking alcohol or taking drugs and driving is dangerous and may result in an accident and SERIOUS INJURY or DEATH.

Drunk driving is the number one contributor to the highway death toll each year. Even a small amount of alcohol will affect your reflexes, perceptions and judgment. Just one drink can reduce your ability to respond to changing conditions and emergencies and your reaction time gets worse with each additional drink.

Driving while under the influence of drugs is as dangerous or more dangerous than driving under the influence of alcohol.

You are much more likely to have a serious accident if you drink or take drugs and drive. If you are drinking or taking drugs, don't drive. Do not ride with a driver who has been drinking or taking drugs. Choose a designated driver or call a taxi.

#### **ENGINE START/STOP BUTTON**



Whenever the front door is opened, the Engine Start/Stop button will illuminate and will go off 30 seconds after the door is closed.



## WARNING

To reduce risk of serious injury or death, NEVER allow children or any person who is unfamiliar with the vehicle to touch the Engine Start/Stop button or related parts. Unexpected and sudden vehicle movement can occur.



#### WARNING

To turn the engine off in an emergency:
Press and hold the Engine Start/Stop
button for more than two seconds OR

rapidly press and release the Engine Start/Stop button three times (within three seconds).

If the vehicle is still moving, you can restart the engine without depressing the brake pedal by pressing the Engine Start/Stop button with the shift lever in the N (Neutral) position.



## WARNING

- NEVER press the Engine Start/Stop button while the vehicle is in motion except in an emergency. This will result in the engine turning off and loss of power assist for the steering and brake systems.
  - This may lead to loss of directional control and braking function, which could cause an accident.
- Before leaving the driver's seat, always make sure the shift lever is in the P (Park) position, set the parking brake, press the Engine Start/Stop button to the OFF position, and take the Smart Key with you. Unexpected vehicle movement may occur if these precautions are not followed.
- NEVER reach through the steering wheel for the Engine Start/Stop button or any other control while the vehicle is in motion. The presence of your hand or arm in this area may cause a loss of vehicle control resulting in an accident.

## **Engine Stop/Start button positions**

- Vehicle with manual transmission

Button Position	Action	Notes
OFF	To turn off the engine, stop the vehicle and then press the Engine Start/Stop button.	If the steering wheel is not locked properly when you open the driver's door, the warning chime will sound.
ACC	Press the Engine Start/Stop button when the button is in the OFF position without depressing the clutch pedal. Some of the electrical accessories are usable.  The steering wheel unlocks.	If you leave the Engine Start/Stop button in the ACC position for more than one hour, the battery power will turn off automatically to prevent the battery from discharging.  If the steering wheel doesn't unlock properly, the Engine Start/Stop button will not work.  Press the Engine Start/Stop button while turning the steering wheel right and left to release.
ON	Press the Engine Start/Stop button while it is in the ACC position without depressing the clutch pedal. The warning lights can be checked before the engine is started.	Do not leave the Engine Start/Stop button in the ON position when the engine is not running to prevent the battery from discharging.
START	To start the engine, depress the clutch and brake pedals and press the Engine Start/ Stop button with the shift lever in neutral.	If you press the Engine Start/Stop button without depressing the clutch pedal, the engine does not start and the Engine Start/Stop button changes as follows: OFF → ACC → ON → OFF or ACC

## **Engine Stop/Start button positions**

- Vehicle with dual clutch transmission

Button Position	Action	Notes
OFF	To turn off the engine, press the Engine Start/Stop button with the vehicle shifted to P (Park).  Note if the Engine Start/Stop button is pressed with the vehicle shifted to D (Drive) or R (Reverse), the gear will automatically shift to P (Park).  If the Engine Start/Stop button is pressed with the gear shifted to N (Neutral), the Engine Start/Stop button will change to the ACC position.	If the steering wheel is not locked properly when you open the driver's door, the warning chime will sound.
ACC	Press the Engine Start/Stop button when the button is in the OFF position without depressing the brake pedal. Some electrical accessories are usable.  The steering wheel unlocks.	If you leave the Engine Start/Stop button in the ACC position for more than one hour, the battery power will turn off automatically to prevent the battery from discharging.  If the steering wheel doesn't unlock properly, the Engine Start/Stop button will not work. Press the Engine Start/Stop button while turning the steering wheel right and left to release tension.
ON	Press the Engine Start/Stop button while it is in the ACC position without depressing the brake pedal. The warning lights can be checked before the engine is started.	Do not leave the Engine Start/Stop button in the ON position when the engine is not running to prevent the battery from discharging.
START	To start the engine, press the brake pedal and press the Engine Start/Stop button with the gear shifted to the P (Park) or the N (Neutral) position. For your safety, start the engine with the gear shifted to the P (Park) position.	If you press the Engine Start/Stop button without depressing the brake pedal, the engine does not start and the Engine Start/Stop button changes as follows: OFF → ACC → ON → OFF or ACC

#### Starting the engine

# **MARNING**

- Always wear appropriate shoes when operating your vehicle.
  - Unsuitable shoes, such as high heels, ski boots, sandals, flip-flops, etc., may interfere with your ability to use the brake and accelerator pedals.
- Do not start the vehicle with the accelerator pedal depressed. The vehicle can move and lead to an accident.
- Wait until the engine rpm is normal.
   The vehicle may suddenly move if the brake pedal is released when the rpm is high.

## *i* Information

- The engine will start by pressing the Engine Start/Stop button, only when the smart key is in the vehicle.
- Even if the smart key is in the vehicle, if it is far away from the driver, the engine may not start.
- When the Engine Start/Stop button is in the ACC or ON position, if any door is open, the system checks for the smart key. If the smart key is not in the vehicle, the "" indicator will blink and the warning "Key not in vehicle" will come on and if all doors are closed, the chime will also sound for about 5 seconds. Keep the smart key in the vehicle when using the ACC position or if the vehicle engine is ON.

Vehicle with manual transmission:

- 1. Always carry the smart key with you.
- 2. Make sure the parking brake is applied.
- 3. Make sure the shift lever is in neutral.
- 4. Depress the clutch and brake pedals.
- 5. Press the Engine Start/Stop button.

# *i* Information

Depress the brake pedal and clutch pedal until the engine starts.

Vehicle with dual clutch transmission:

- 1. Always carry the smart key with you.
- 2. Make sure the parking brake is applied.
- 3. Make sure the shift lever is in P (Park).
- 4. Depress the brake pedal.
- 5. Press the Engine Start/Stop button.

## *i* Information

- Do not wait for the engine to warm up while the vehicle remains stationary. Start driving at moderate engine speeds. (Aggressive accelerating and decelerating should be avoided.)
- Always start the vehicle with your foot on the brake pedal. Do not depress the accelerator while starting the vehicle. Do not rev the engine while warming it up.

## NOTICE

To prevent damage to the vehicle:

- If the engine stalls while you are in motion, do not attempt to move the shift lever to the P (Park) position.
   If traffic and road conditions permit, you may put the shift lever in the N (Neutral) position while the vehicle is still moving and press the Engine Start/Stop button in an attempt to restart the engine.
- Do not push or tow your vehicle to start the engine.

## NOTICE

To prevent damage to the vehicle:

When the stop light switch fuse is blown, you can't start the engine normally. Replace the fuse with a new one. If you are not able to replace the fuse, you can start the engine by pressing and holding the Engine Start/Stop button for 10 seconds with the Engine Start/Stop button in the ACC position.

Do not press the Engine Start/Stop button for more than 10 seconds except when the stop light switch fuse is blown.

For your safety always depress the brake pedal before starting the engine.

#### Emergency starting



If the smart key battery is weak or the smart key does not work correctly, you can start the engine by pressing the Engine Start/Stop button with the smart key in the direction of the picture above.

#### Turning off the engine

Vehicle with manual transmission:

- Stop the vehicle and depress the clutch and brake pedals at the same time.
- With the clutch and brake pedals depressed, put the shift lever in neutral.
- 3. Press the Engine Start/Stop button to the off position and apply the parking brake.

Vehicle with Dual clutch transmission:

- 1. Stop the vehicle and depress the brake pedal fully.
- 2. Make sure the gear is in P (Park).
- 3. Press the Engine Start/Stop button to the OFF position and apply the parking brake.

## Remote start (if equipped)



You can start the vehicle using the Remote Start button of the smart key.

To start the vehicle remotely:

- 1. Press the door lock button within 32 feet (10 m) from the vehicle.
- 2. Press the remote start ( ) button for over 2 seconds within 4 seconds after locking the doors. The hazard warning lights will blink.
- To turn off the remote start function, press the remote start ( ∩ ) button once.
- The remote start ( ) button may not operate if the smart key is not within 32 feet (10 m).
- The vehicle will not remotely start if the engine hood or trunk is opened.
- The vehicle must be in P (Park) for the remote start function to start.
- The engine turns off if you get in the vehicle without a registered smart key.
- The engine turns off if you do not get in the vehicle within 10 minutes after remotely starting the vehicle.
- Do not idle the engine for a long period.

## **VEHICLE AUTO-SHUT OFF (IF EQUIPPED)**

If your vehicle is parked and the engine is left on for a long period of time, the engine will turn off automatically to help reduce fuel consumption and prevent accidents caused by carbon dioxide poisoning.

## **Operating Conditions**

Vehicle Auto-Shut Off timer operates when all the following conditions are satisfied:


- Vehicle speed is below 1.8 mph (3) km/h), and the gear is shifted to P (Park)
- The brake pedal and accelerator pedal are not depressed
- · The driver's seat belt is unfastened
- The passenger seat is empty
- The infotainment system is not being updated

## **Deactivating Conditions**

Vehicle Auto-Shut Off timer turns off when one of the situation occur:

- Vehicle speed is above 1.8 mph (3) km/h)
- The gear is shifted to R (Reverse), D (Drive) or N (Neutral)
- The brake pedal or accelerator pedal is depressed
- The driver's seat belt is fastened
- · A passenger is in the passenger's seat

#### **System Operation**



OJK041087N

When all the conditions are satisfied, the Vehicle Auto-Shut Off operates and turns the engine off automatically after 60 minutes.

A timer appears on the instrument cluster 30 minutes before vehicle shut off

#### Resetting cluster timer

To reset the cluster timer, do one of following:


- Release the accelerator pedal or brake pedal after Vehicle Auto-Shut Off is complete.
- · Press the OK button on the steering wheel while the timer appears on the instrument cluster.



## CAUTION

Do not leave a passenger or a pet in the vehicle in hot weather since the air conditioning system turns off when the engine is off.

## **MANUAL TRANSMISSION (MT) (IF EQUIPPED)**



- The shift lever can be moved without pressing the button (1).
- The button (1) must be pressed while moving the shift lever.

## **Manual Transmission Operation**

The manual transmission has 6 forward gears. The transmission is fully synchronized in all forward gears so shifting to either a higher or a lower gear is easily accomplished.

# A

### WARNING

- Before leaving the driver's seat, always make sure the shift lever is in 1st gear when the vehicle is parked on a uphill and in R (Reverse) on a downhill, set the parking brake, and place the Engine Start/Stop button in the OFF position. Unexpected vehicle movement may occur if these precautions are not followed.
- When parking on an incline, block the wheels to prevent the vehicle from rolling down.

To shift to R (Reverse), make sure the vehicle has completely stopped, and then move the shift lever to neutral before moving into R (Reverse).

When you've come to a complete stop and it's hard to shift into 1st gear or R (Reverse):

- 1. Put the shift lever in neutral and release the clutch pedal.
- 2. Depress the clutch pedal, and then shift into first or R (Reverse) gear.



## Information

During cold weather, shifting may be difficult until the transmission lubricant has warmed up.

#### Using the clutch

The clutch pedal should be depressed all the way before:

- Starting the engine
   The engine will not start without depressing the clutch pedal.
- Shifting into gear, up shifting to the next higher gear, or down shifting to the next low gear.

When releasing the clutch pedal, release it slowly. The clutch pedal should always be fully released while driving.

#### NOTICE

To prevent unnecessary wear or damage to the clutch:

- Do not rest your foot on the clutch pedal while driving.
- Do not hold the vehicle with the clutch on an incline, while waiting for the traffic light, etc.
- Always depress the clutch pedal down fully to prevent noise or damage.
- Do not start with the 2nd (second) gear engaged except when you start on a slippery road.
- Do not drive with cargo loaded more than the recommended loading capacity.
- Make sure to depress the clutch pedal until the engine starts completely. If you release the clutch pedal before the engine starts completely, the engine may stop.

#### **Downshifting**

Down shift to a lower gear when slowing down in heavy traffic or driving up a steep hill to prevent high engine loads.

Also, downshifting reduces the chance of stalling and helps to reaccelerate the vehicle when you need to increase your speed.

When the vehicle is going downhill, downshifting helps maintain safe speed by providing a load from the engine and results in less wear on the brakes.

## **NOTICE**

To prevent damage to the engine, clutch and transmission:

- When downshifting from 5th gear to 4th gear, be careful not to inadvertently push the shift lever sideways engaging the 2nd gear.
   A drastic downshift may cause the engine speed to increase to the point the tachometer will enter the redzone and may cause engine damage.
- Do not downshift more than two gears at a time or downshift the gear when the engine is running at high speed (5,000 RPM or higher).
   Such downshifting may damage the engine, clutch and the transmission.

#### **Good Driving Practices**

- Never take the vehicle out of gear and coast down a hill. This is extremely dangerous.
- Don't "ride" the brakes. This can cause the brakes and related parts to overheat and malfunction.
- When you are driving down a long hill, slow down and shift to a lower gear.
   Engine braking will help slow down the vehicle.
- Slow down before shifting to a lower gear. This will help avoid over-revving the engine, which can cause damage.
- Slow down when you encounter cross winds. This gives you much better control of your vehicle.
- Be sure the vehicle is completely stopped before you shift into R (Reverse) to prevent damage to the transmission.
- Exercise extreme caution when driving on a slippery surface. Be especially careful when braking, accelerating or shifting gears. On a slippery surface, an abrupt change in vehicle speed can cause the drive wheels to lose traction and may cause loss of vehicle control resulting in an accident.

## 1

## **WARNING**

Do not use the engine brake (shifting from a higher gear to lower gear) rapidly on slippery roads. The vehicle may slip causing an accident.



### WARNING

To reduce the risk of SERIOUS INJURY or DEATH:

- ALWAYS wear your seat belt. In a collision, an unbelted occupant is significantly more likely to be seriously injured or killed than a properly belted occupant.
- Avoid high speeds when cornering or turning.
- Do not make quick steering wheel movements, such as sharp lane changes or fast, sharp turns.
- The risk of rollover is greatly increased if you lose control of your vehicle at highway speeds.
- Loss of control often occurs if two or more wheels drop off the roadway and the driver over steers to reenter the roadway.
- In the event your vehicle leaves the roadway, do not steer sharply. Instead, slow down before pulling back into the travel lanes.
- HYUNDAI recommends you follow all posted speed limits.

## **Rev Matching**

The Rev Matching system automatically helps synchronize engine rpm with the optimal speed of the gear about to be engaged which reduces the impact of clutch connection and improves gear shift response.

# *i* Information

- Fully depress the clutch pedal. Without the clutch pedal fully depressed, the system may not respond correctly.
- The system does not operate when backing up.
- Rev Matching controls the engine speed up to the rev limit, but the function cannot prevent over-revving caused by shifting mistake.


#### Rev Matching activation



#### 1. Press REV button (ON/OFF)

- Press the REV button to turn on the system. A message appears "Rev Matching On" with a REV indicator on the cluster display.
- Press the REV button again to turn off the system. A message appears "Rev Matching Off" and the REV indicator disappears.

#### 2. Select Drive Mode.





#### **DRIVE MODE button**

Use Rev Matching in normal driving conditions in below modes.

- · When FCO mode is selected:
  - Rev Matching cannot be activated even if the driver presses the REV button.
  - RFV indicator is off.
- · When NORMAL mode is selected:
  - Rev Matching activates if Rev Matching is turned on by the REV button.
  - White REV indicator illuminates.
  - Engine rpm response during gear shift is smooth.
- · When SPORT mode is selected:
  - Rev Matching activates if Rev Matching is turned on by the REV button.
  - Yellow REV indicator illuminates.
  - Engine rpm response is faster than NORMAL mode.

The system must be turned on by pressing the REV button whenever the engine is turned on.

## *i* Information

If N1 or N2 button is set to 'Drive mode' from the infotainment system, the drive mode can be selected by pressing N1 or N2 button.

# *i* Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.



■ N2 button



OCN7N061257N

# *i* Information

Set N1 or N2 button from the infotainment system, then N mode can be selected by pressing N1 or N2 button. For more details, please refer to the infotainment system manual separately supplied.

#### N button (N1/N2 button)

Use Rev Matching when driving on race tracks, etc. in N mode.

- When N mode (SPORT+) is selected:
  - REV Matching is turned on automatically. To turn off Rev Matching, press the REV button.
  - Red RFV indicator illuminates.
  - Engine speed is automatically adjusted to the shifted gear without the accelerator pedal depressed.
  - Engine RPM response is faster than SPORT mode when downshifting with heavy braking such as when driving on a race track.
- When CUSTOM mode (CUSTOM 1/ CUSTOM 2) is selected:
  - You may select the drive mode you prefer from the infotainment system screen Custom setting page. (OFF/ NORMAL/SPORT/ SPORT+).

# Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

#### Rev Matching operation

Engine speed is automatically synchronized with the next selected gear. The accelerator pedal does not have to be depressed to speed up the engine RPM.

- Clutch depressed with the gear engaged
  - At once, engine speed automatically decreases right after the clutch is disengaged, but the selected gear is fixed and then the engine RPM reverts to the selected gear's target speed. This operation method gives more comfortable feeling in public road drivina.
- Up shifting Engine speed will automatically decrease and stay at the target engine speed before the clutch is engaged.
- Down shifting Engine speed will automatically increase and stay at the target engine speed.

# Warning message




OCN7N061224I

Downshift Alert. Downshifting at high RPMs may result in engine damage.

If transmission input RPM is too high (over rev limit) due to shifting, a warning message will appear and a warning chime will sound.

# **DUAL CLUTCH TRANSMISSION (DCT) (IF EQUIPPED)**



[A]: Shift button [B]: Shift lever

- Depress the brake pedal and press the shift lever while moving the shift lever.
- Press the shift lever while moving the shift lever.
- □ The shift lever can freely operate.

# **Dual Clutch Transmission Operation**

The dual clutch transmission has 8 forward speeds and one reverse speed. The individual speeds are selected automatically in the D (Drive) position.

# **MARNING**

To reduce the risk of serious injury or death:

- ALWAYS check the surrounding areas near your vehicle for people, especially children, before shifting a vehicle into D (Drive) or R (Reverse).
- Before leaving the driver's seat, always make sure the shift lever is in the P (Park) position, then set the parking brake, and place the Engine Start/Stop button in the OFF position. Unexpected and sudden vehicle movement can occur if these precautions are not followed.
- When using Manual Shift Mode, do not use engine braking (shifting from a high gear to lower gear) rapidly on slippery roads. The vehicle may slip causing an accident.
- To avoid damage to your transaxle, do not try to accelerate in R (Reverse) or any forward gear position with the brakes on.
- When stopped on slope, do not hold the vehicle with accelerator pedal.
   Use the service brake or the parking brake.

- The dual clutch transmission gives the driving feel of a manual transmission, yet provides the ease of a fully automatic transmission. Unlike a traditional automatic transmission, the gear shifting can be felt (and heard) on the dual clutch transmission
  - Think of it as an automatically shifting manual transmission.
  - Shift into Drive range and get fully automatic shifting, similar to a conventional automatic transmission
- Dual clutch transmission adopts wettype dual clutch, which is different from torque converter of automatic transmission, and shows better acceleration performance during driving. But, initial launch might be little bit slower than automatic transmission
- Gear shifts are sometimes more noticeable than a conventional automatic transmission and a light vibration during launching can be felt as the transmission speed is matched with the engine speed. This is a normal condition of the dual clutch transmission.
- The wet-type clutch transfers torque and provides a direct driving feeling which may feel different from a conventional automatic transmission with a torque converter. This may be more noticeable when starting from a stop or low vehicle speed.
- When rapidly accelerating at low vehicle speed, engine could rev at high RPM depending on vehicle drive condition.

- For smooth launch uphill, press down the accelerator pedal smoothly depending on the current conditions.
- If you release your foot from the accelerator pedal at low vehicle speed, you may feel strong engine brake, which is similar to manual transmission.
- When driving downhill, you may use Manual Mode to downshift to a lower gear in order to control your speed without using the brake pedal excessively.
- When you turn the engine on and off, you may hear clicking sounds as the system goes through a self test. This is a normal sound for the Dual clutch transmission

# **MARNING**

Due to transmission failure, you may not continue to drive and the position indicator (D, R) on the cluster will blink. Contact an authorized HYUNDAI dealer and have the system checked.

# Cluster Display for Transmission Temperature and Warning Message

Transmission temperature gauge



OCN7N0612251


- Select trip computer mode on the cluster display and move to the transmission temperature screen to see the temperature of the dual clutch transmission.
- Try to drive so that the temperature gauge do not show high/overheat. When the transmission is overheated, the warning message will display on the cluster. Follow the displayed message.
- The transmission temperature is displayed in three colors (white, orange and red) as it increases. (if equipped with the cluster type B)
- Orange temperature gauge is displayed right before the warning message appears on the cluster display. (if equipped)



## CAUTION

- Increase (high temperature) of the transmission temperature gauge usually appears on an incline when the vehicle is stopped for a long time using accelerator pedal, without depressing the brake pedal.
- To maintain the optimal transmission performance, drive so that the white gauge is not exceeded. (if equipped)

#### **DCT** warning messages



OCN7N061226L

This warning message is displayed when vehicle is driven slowly on a grade and the vehicle detects that the brake pedal is not applied.

#### Steep grade

Driving up hills or on steep grades:

- To hold the vehicle on an incline use the foot brake or the parking brake.
- When in stop-and-go traffic on an incline, keep some distance ahead before moving the vehicle forward. Then hold the vehicle on the incline with the foot brake.
- If the vehicle is held on a hill by applying the accelerator pedal or by creeping with brake pedal disengaged, the clutch and transmission may overheat which can result in damage. At this time, a warning message will appear on the cluster display.
- If the cluster display warning is active, the foot brake must be applied.
- Ignoring the warnings can lead to damage to the transmission.



# Transmission high temperature

- Under certain conditions, such as repeated stop-and-go launches on steep grades, sudden take off or acceleration, or other harsh driving conditions, the transmission clutch temperatures will increase excessively. Finally the clutch in transmission could be overheated.
- When the clutch is overheated, the safe protection mode engages and the gear position indicator on the cluster blinks with a chime. At this time, "Transmission temperature is high! Stop safely" warning message will appear on the cluster display and driving may not be smooth.

- If this occurs, pull over to a safe location, stop the vehicle with the engine running, apply the brakes and shift the vehicle to P (Park), and allow the transmission to cool.
- If you ignore this warning, the driving condition may become worse.
   You may experience abrupt shifts, frequent shifts, or jerkiness. To return to the normal driving condition, stop the vehicle and apply the foot brake or shift into P (Park). Then allow the transmission to cool for a few minutes with engine on, before driving off.
- When possible, drive the vehicle smoothly.







#### Transmission overheated

- If the vehicle continues to be driven and the clutch temperatures reach the maximum temperature limit, the "Transmission hot! Park with engine On" warning will be displayed. When this occurs the clutch is disabled until the clutch cools to normal temperatures.
- The warning will display a time to wait for the transmission to cool.
- If this occurs, pull over to a safe location, stop the vehicle with the engine running, apply the brakes and shift the vehicle to P (Park), and allow the transmission to cool.
- When the message "Transmission cooled down. Resume driving" appears you can continue to drive your vehicle.
- When possible, drive the vehicle smoothly.

If any of the warning messages in the cluster display continue to blink, for your safety, contact an authorized HYUNDAI dealer and have the system checked.

## Transmission ranges

The indicator in the instrument cluster displays the shift lever position when the Engine Start/Stop button is in the ON position.

#### P (Park)

Always come to a complete stop before shifting into P (Park).

To shift from P (Park), you must depress firmly on the brake pedal and make sure your foot is off the accelerator pedal.

If you have done all of the above and still cannot shift the lever out of P (Park), see "Shift-Lock Release" in this chapter.

The shift lever must be in P (Park) before turning the engine off.

# **!** WARNING

- Shifting into P (Park) while the vehicle is in motion may cause you to lose control of the vehicle.
- After the vehicle has stopped, always make sure the shift lever is in P (Park), apply the parking brake, and turn the engine off.
- Do not use the P (Park) position in place of the parking brake.

#### R (Reverse)

Use this position to drive the vehicle backward.

## NOTICE

Always come to a complete stop before shifting into or out of R (Reverse); you may damage the transaxle if you shift into R (Reverse) while the vehicle is in motion.

#### N (Neutral)

The wheels and transaxle are not engaged.

Use N (Neutral) if you need to restart a stalled engine, or if it is necessary to stop with the engine ON. Shift into P (Park) if you need to leave your vehicle for any reason.

Always depress the brake pedal when you are shifting from N (Neutral) to another gear.

#### D (Drive)

This is the normal driving position. The transmission will automatically shift through a 8-gear sequence, providing the best fuel economy and power.

For extra power when passing another vehicle or driving uphill, depress the accelerator fully. The transmission will automatically downshift to the next lower gear (or gears, as appropriate).

The DRIVE MODE switch, located on the shift lever console, allows the driver to switch from NORMAL mode to ECO or SPORT mode.


For more information, refer to "Drive Mode Integrated Control System" section in this chapter.

#### ! WARNING

- Do not shift into gear unless your foot is firmly on the brake pedal. Shifting into gear when the engine is running at high speed can cause the vehicle to move very rapidly. You may lose control of the vehicle and cause accidents.
- Do not drive with the shift lever in N (Neutral). The engine brake will not work and may lead to an accident.

# NOTICE

Always make sure the vehicle is stationary, at a complete stop, before selecting D (Drive).



#### Manual shift mode

Whether the vehicle is stationary or in motion, sports mode is selected by pushing the shift lever from the D (Drive) position into the manual gate. To return to D (Drive) range operation, push the shift lever back into the main gate.

In manual shift mode, moving the shift lever backwards and forwards will allow you to select the desired range of gears for the current driving conditions.

Up (+): Pull the lever backwards once to shift up one gear.

Down (-): Push the lever forward once to shift down one gear.

# *i* Information

- Only the eight forward gears can be selected. To reverse or park the vehicle, move the shift lever to the R (Reverse) or P (Park) position as required.
- Downshifts are made automatically when the vehicle slows down. When the vehicle stops, 1st gear is automatically selected.
- When the engine RPM approaches the red zone the transmission will upshift automatically.
- If the driver presses the lever to + (Up) or (Down) position, the transmission may not make the requested gear change if the next gear is outside of the allowable engine RPM range.
   The driver must execute upshifts in accordance with road conditions, taking care to keep the engine RPM below the red zone.

## Shift-lock system

For your safety, the dual clutch transmission has a shift-lock system which prevents shifting the transmission from P (Park) into R (Reverse) unless the brake pedal is depressed.

To shift the transmission from P (Park) into R (Reverse):

- 1. Depress and hold the brake pedal.
- 2. Start the engine or place the Engine Start/Stop button in the ON position.
- 3. Move the shift lever.

#### Shift-lock release

If the shift lever cannot be moved from the P (Park) position into R (Reverse) position with the brake pedal depressed, continue depressing the brake, and then do the following:



- 1. Set the Engine Start/Stop button in the OFF position
- 2. Apply the parking brake.
- 3. Carefully remove the shift lever boots.
- 4. Move the shift lever while holding the release button (1) with a tool (for example, flathead screw-driver).

If you need to use the shift-lock release, have the system inspected by an authorized HYUNDAI dealer immediately.



## **CAUTION**

Be careful not to damage the trim beside of the shift lever while removing the shift lever boots.

## **Parking**

Always come to a complete stop and continue to depress the brake pedal. Move the shift lever into the P (Park) position, apply the parking brake, and set the Engine Start/Stop button to the OFF position. Take the Key with you when exiting the vehicle.

# $\Lambda$


#### WARNING

When you stay in the vehicle with the engine running, be careful not to depress the accelerator pedal for a long period of time. The engine or exhaust system may overheat and start a fire.

The exhaust gas and the exhaust system are very hot. Keep away from the exhaust system components.

Do not stop or park over flammable materials, such as dry grass, paper or leaves. They may ignite and cause a fire.

# Paddle Shifter (Manual Shift Mode) (if equipped)



The paddle shifter is available when the gear is in the D (Drive) position.

# With the shift lever in the D (Drive) position

The paddle shifter will operate when the vehicle speed is more than 6 mph (10km/h). Pull the [+] or [-] paddle shifter once to shift up or down one gear and the system changes from automatic mode to manual mode.

When the vehicle speed is lower than 6 mph (10km/h), if you depress the accelerator pedal for more than 5 seconds or if you move the shift lever from D (Drive) to manual shift mode and move it from manual shift mode to D (Drive) again, the system changes from manual mode to automatic mode.

When the engine reaches maximum RPM in manual shift mode by paddle shifting at shift lever D (Drive) position, the shift is automatically performed.

# With the shift lever in the manual shift mode

Pull the [+] or [-] paddle shifter once to shift up or down one gear. In the manual shift mode (+, -) position, even when the engine reaches full speed, it does not shift automatically.



## Information

If the [+] and [-] paddle shifters are pulled at the same time, gear shift may not occur.

## **Good Driving Practices**

- Never move the shift lever from P (Park) or N (Neutral) to any other position with the accelerator pedal depressed.
- Never move the shift lever into P (Park) when the vehicle is in motion.
- Be sure the vehicle is completely stopped before you attempt to shift into R (Reverse) or D (Drive).
- Do not move the shift lever to N (Neutral) when driving. Doing so may result in an accident because of a loss of engine braking and the transmission could be damaged.
- When driving uphill or downhill, always shift to D (Drive) for driving forward or shift to R (Reverse) for driving rearwards. After selecting D (Drive) or R (Reverse), check the gear position indicated on the cluster before driving. If the vehicle moves in the opposite direction of the selected gear, the engine may turn off and a serious accident might occur due to degraded brake performance.
- Do not drive with your foot resting on the brake pedal. Even light, but consistent pedal pressure can result in the brakes overheating, brake wear and possibly even brake failure.
- When driving in sports mode, slow down before shifting to a lower gear. Otherwise, the lower gear may not be engaged if the engine RPM is outside of the allowable range.
- Always apply the parking brake when leaving the vehicle. Do not depend on placing the transmission in P (Park) to keep the vehicle from moving.
- Exercise extreme caution when driving on a slippery surface. Be especially careful when braking, accelerating or shifting gears. On a slippery surface, an abrupt change in vehicle speed can cause the drive wheels to lose traction and may cause loss of vehicle control resulting in an accident.

 Optimum vehicle performance and economy is obtained by smoothly depressing and releasing the accelerator.



#### WARNING

To reduce the risk of SERIOUS INJURY or DEATH:

- ALWAYS wear your seatbelt. In a collision, an unbelted occupant is significantly more likely to be seriously injured or killed than a properly belted occupant.
- Avoid high speeds when cornering or turning.
- Do not make quick steering wheel movements, such as sharp lane changes or fast, sharp turns.
- The risk of rollover is greatly increased if you lose control of your vehicle at highway speeds.
- Loss of control often occurs if two or more wheels drop off the roadway and the driver over steers to reenter the roadway.
- In the event your vehicle leaves the roadway, do not steer sharply. Instead, slow down before pulling back into the travel lanes.
- HYUNDAI recommends you follow all posted speed limits.



#### ! WARNING

If your vehicle is stuck in snow, mud, sand, etc., you may attempt to free the vehicle by rocking it back and forth. Do not attempt this procedure if people or objects are anywhere near. Vehicle may suddenly move forward or backward as it becomes unstuck, causing injury or damage to nearby people or objects.

#### **BRAKE SYSTEM**

#### **Power Brakes**

Your vehicle has power-assisted brakes that adjust automatically through normal usage.

If the engine is not running or is turned off while driving, the power assist for the brakes will not work. You can still stop your vehicle by applying greater force to the brake pedal than typical. The stopping distance, however, will be longer than with power brakes.

When the engine is not running, the reserve brake power is partially depleted each time the brake pedal is applied. Do not pump the brake pedal when the power assist has been interrupted.

Only pump the brakes on slippery surfaces if the power assist has been interrupted to maintain steering control. Do not pump the brakes on slippery surfaces if the brakes are operating normally.

# *i* Information

- When the brake pedal is depressed under certain driving conditions or weather conditions, you may temporarily hear a noise. This is normal and does not indicate a problem with your brakes.
- If deicing chemicals get stuck on the brakes, abnormal wear and noise may occur on the brake discs and pads.
   Remove the deicing chemicals from the brake discs and pads while applying the brakes in a safe traffic condition.

# **MARNING**

Take the following precautions:

 Do not drive with your foot resting on the brake pedal. This will create abnormal high brake temperatures, excessive brake lining and pad wear, and increased stopping distances.

- When descending down a long or steep hill, move the gear shift lever to Manual Shift Mode and manually downshift to a lower gear in order to control your speed without using the brake pedal excessively. Applying the brakes continuously will cause the brakes to overheat and could result in a temporary loss of braking performance.
- The brake pressure (%) displayed on the infotainment screen may differ from the actual brake pressure.
- Wet brakes may impair the vehicle's ability to safely slow down; the vehicle may also pull to one side when the brakes are applied.
   Applying the brakes lightly will indicate whether they have been affected in this way. Always test your brakes in this fashion after driving through deep water. To dry the brakes, lightly tap the brake pedal to heat up the brakes while maintaining a safe forward speed until brake performance returns to normal.
   Avoid driving at high speeds until the brakes function correctly.

#### **Disc Brakes Wear Indicator**

When your brake pads are worn and new pads are required, you will hear a high pitched warning sound from your front or rear brakes. You may hear this sound come and go or it may occur whenever you depress the brake pedal.

# NOTICE

To avoid costly brake repairs, do not continue to drive with worn brake pads.



Always replace brake pads as complete front or rear axle sets.

# **High Performance Brake**

As this vehicles equipped with the High Performance Brake (applied with material having high coefficient of friction), noise such as a squeal, squeak or groan is generated while braking. This is normal and the friction may create circle patterns on the disc surface. This is also a normal situation which does not affect braking performance.

# NOTICE

- Occasional brake noise is normal. If a continuous grinding or continuous squeal sound is present, the brake lining may be worn-out. Have the vehicle checked by an authorized HYUNDAI dealer.
- If the vehicle has continuous vibration or shudder in the steering wheel while braking, have the vehicle checked by an authorized HYUNDAI dealer.



Frequent speeding and braking may deform components and wear the disc brake causing vibration when braking. Prevent brake damage by avoiding excessive braking. Brake wear, noise, vibration from excessive braking or deformation of the brakes caused by repeatedly braking in high speed, racing on tracks, etc., can be excluded from warranty coverage.

## **Parking Brake**

Applying the parking brake




Always set the parking brake before leaving the vehicle, to apply: Firmly depress the brake pedal. Pull up the parking brake lever as far as possible.



#### **WARNING**

To reduce the risk of SERIOUS INJURY or DEATH, do not operate the parking brake while the vehicle is moving except in an emergency situation. It could damage the brake system and lead to an accident.

#### Releasing the parking brake



To release:

Firmly depress the brake pedal.

While pressing the release button (1). slightly pull up on the parking brake lever then lower the parking brake lever (2).

# ! WARNING

- Whenever leaving the vehicle or parking, always come to a complete stop and continue to depress the brake pedal. Move the shift lever into the 1st gear (for manual transmission vehicle) or P (Park, for dual clutch transmission vehicle) position, then apply the parking brake, and Set the Engine Start/Stop button in the OFF position.
- Vehicles with the parking brake not fully engaged are at risk for moving inadvertently and causing injury to vourself or others.
- NEVER allow anyone who is unfamiliar with the vehicle to touch the parking brake. If the parking brake is released unintentionally, serious iniury may occur.
- Only release the parking brake when you are seated inside the vehicle with your foot firmly on the brake pedal.

#### NOTICE

- Do not apply the accelerator pedal while the parking brake is engaged. If you depress the accelerator pedal with the parking brake engaged, a warning will sound. Damage to the parking brake may occur.
- Driving with the parking brake on can overheat the braking system and cause premature wear or damage to brake parts. Make sure the parking brake is released and the Brake Warning Light is off before driving.



Check the Parking Brake
Warning Light by placing the BRAKE Engine Start/Stop button to the ON position (do not start the engine).

This light will be illuminated when the parking brake is applied with the Engine Start/Stop button in the START or ON position.

Before driving, be sure the parking brake is released and the Brake Warning Light is OFF.

If the Parking Brake Warning Light remains on after the parking brake is released while the engine is running, there may be a malfunction in the brake system. Immediate attention is necessary.

If at all possible, cease driving the vehicle immediately. If that is not possible, use extreme caution while operating the vehicle and only continue to drive the vehicle until you can reach a safe location.

## Anti-lock Brake System (ABS)



#### ! WARNING

An Anti-Lock Braking System (ABS) or an Electronic Stability Control (ESC) system will not prevent accidents due to improper or dangerous driving maneuvers. Even though vehicle control is improved during emergency braking, always maintain a safe distance between you and objects ahead of you. Vehicle speeds should always be reduced during extreme road conditions. The braking distance for cars equipped with ABS or ESC may be longer than for those without these systems in the following road conditions.

Drive your vehicle at reduced speeds during the following conditions:

- Rough, gravel or snow-covered roads
- On roads where the road surface is pitted or has different surface height.
- · Tire chains are installed on your vehicle.

The safety features of an ABS or ESC equipped vehicle should not be tested by high speed driving or cornering. This could endanger the safety of yourself or others.

ABS is an electronic braking system that helps prevent a braking skid. ABS allows the driver to steer and brake at the same time.

#### Using ABS

To obtain the maximum benefit from your ABS in an emergency situation. do not attempt to modulate your brake pressure and do not try to pump your brakes. Depress your brake pedal as hard as possible.

When you apply your brakes under conditions which may lock the wheels, you may hear sounds from the brakes, or feel a corresponding sensation in the brake pedal. This is normal and it means your ABS is active.

ABS does not reduce the time or distance it takes to stop the vehicle.

Always maintain a safe distance from the vehicle in front of you.

ABS will not prevent a skid that results from sudden changes in direction, such as trying to take a corner too fast or making a sudden lane change. Always drive at a safe speed for the road and weather conditions.

ABS cannot prevent a loss of stability. Always steer moderately when braking hard. Severe or sharp steering wheel movement can still cause your vehicle to veer into oncoming traffic or off the road.

On loose or uneven road surfaces, operation of the anti-lock brake system may result in a longer stopping distance than for vehicles equipped with a conventional brake system.

The ABS warning light ((ABS)) will stay on for several seconds after the Engine Start/Stop button is in the ON position. During that time, the ABS will go through self-diagnosis and the light will go off if everything is normal. If the light stays on, you may have a problem with your ABS. Contact an authorized HYUNDAI dealer as soon as possible.



# WARNING

If the ABS warning light ((ABS)) is on and stays on, you may have a problem with the ABS. Your power brakes will work normally. To reduce the risk of serious injury or death, contact your HYUNDAL dealer as soon as possible.



# ! CAUTION

When you drive on a road having poor traction, such as an icy road, and apply vour brakes continuously, the ABS will be active continuously and the ABS warning light (ABS) may illuminate. Pull your car over to a safe place and turn the engine off.

Restart the engine. If the ABS warning light is off, then your ABS system is normal.

Otherwise, you may have a problem with your ABS system. Contact an authorized HYUNDAI dealer as soon as possible.



## Information

When you jump start your vehicle because of a drained battery, the ABS warning light ((ABS)) may turn on at the same time. This happens because of the low battery voltage. It does not mean your ABS is malfunctioning. Have the battery recharged before driving the vehicle.

# **Electronic Stability Control (ESC)**

Electronic Stability Control (ESC) helps to stabilize the vehicle during cornering maneuvers. ESC checks where you are steering and where the vehicle is actually going, ESC applies braking pressure to any one of the vehicle's brakes and intervenes in the engine management system to assist the driver with keeping the vehicle on the intended path. It is not a substitute for safe driving practices. Always adjust your speed and driving to the road conditions.



## WARNING

Never drive too fast for the road conditions or too quickly when cornering. The ESC system will not prevent accidents.

Excessive speed in turns, abrupt maneuvers, and hydroplaning on wet surfaces can result in severe accidents.

#### ESC operation

**ESC ON condition** 

When the engine is turned off and then on again, ESC operation is enabled, and it is activated in the ESC operating mode (not in ESC Sport mode or ESC OFF mode) regardless of the ESC mode before turning off the engine.

You may select between the following state of ESC:

- ESC NORMAL activated (ESC ON)
- ESC SPORT activated (ESC SPORT indicator illuminates)
- ESC deactivated (ESC OFF indicator illuminates)

#### When operating



When the ESC is in operation, the ESC indicator light blinks:

- When you apply your brakes under conditions which may lock the wheels, you may hear sounds from the brakes, or feel a corresponding sensation in the brake pedal. This is normal and it means your ESC is active.
- When the ESC activates, the engine may not respond to the accelerator as it does under routine conditions.
- If Cruise Control was in use when the ESC activates, Cruise Control automatically disengages. Cruise Control can be reengaged when the road conditions allow. See "Cruise Control (CC)" in chapter 7.
- When moving out of the mud or driving on a slippery road, the engine RPM (revolutions per minute) may not increase even if you press the accelerator pedal deeply. This is to maintain the stability and traction of the vehicle and does not indicate a problem.

#### Deactivating / Activating ESC



You may select between the following state of ESC:

- ESC NORMAL activated
- ESC SPORT activated (ESC SPORT indicator illuminates)
- ESC deactivated (ESC OFF indicator illuminates)

Press the ESC OFF button shortly

ESC NORMAL ← → ESC SPORT

Press and hold the ESC OFF button for over 3 seconds

ESC NORMAL ESC OFF

Press the ESC OFF button shortly

ESC OFF ------ ESC NORMAL

# <u> </u> ∧

## WARNING

- If you deactivate ESC, ESC no longer stabilizes the vehicle. There is an increased risk of skidding and an accident.
- When ESC SPORT mode is activated, the stability support from ESC will be less than in "ESC ON mode", there is a greater risk of skidding and an accident.

Only deactivate ESC or activate ESC SPORT in the situations described in the following.

In the following situations, it may be better to activate ESC SPORT or deactivate ESC (ESC OFF):


- · When using snow chains
- · Driving in deep snow
- · Driving in sand or gravel
- Driving on specially designed roads where oversteering and understeering characteristics are desired

We recommend only qualified and experienced drivers to drive the vehicle with the ESC deactivated or ESC SPORT activated.



#### **CAUTION**

After the above situations are over, activate ESC immediately. If not, the vehicle can be unstable due to vehicle slip or wheel spin.



#### ESC SPORT

To activate ESC SPORT mode

 Press the ESC OFF button briefly. The ESC SPORT indicator light illuminates on the instrument cluster. In this state, ESC only stabilizes the vehicle to a limited degree.

When ESC SPORT mode is activated:

- ESC only improves driving stability to a limited degree.
- Traction control is still activated, but with less wheel control (more slip).
- Engine torque can partially be limited for the vehicle's stability and the driving wheel spin may be restricted for better traction.

To deactivate ESC SPORT mode

 Press the ESC OFF button briefly. The ESC SPORT indicator light will go off on the instrument cluster.

#### To deactivate ESC (ESC OFF)



Press and hold the ESC OFF button continuously for more than 3 seconds. The ESC OFF indicator light and message "Traction & Stability Control disabled" illuminates and a warning chime sounds. In this state, both the traction control function of ESC (engine management) and the brake control function of ESC (braking management) are disabled. To activate the ESC again, briefly press the ESC OFF button. The ESC OFF indicator light will go off

#### Indicator lights

■ ESC indicator light (blinks)



■ ESC OFF indicator light (comes on)



When the Engine Start/Stop button is in the ON position, the ESC indicator light illuminates, then goes off if the ESC system is operating normally.

The ESC indicator light blinks whenever the ESC is operating.

If the ESC indicator light stays on, your vehicle may have a malfunction with the ESC system. When this warning light illuminates, have the vehicle inspected by an authorized HYUNDAI dealer as soon as possible.

The ESC OFF indicator light comes on when the ESC is turned off with the button.



## WARNING

When the ESC is blinking, this indicates the ESC is active:

Drive slowly and NEVER attempt to accelerate. NEVER turn the ESC off while the ESC indicator light is blinking or you may lose control of the vehicle resulting in an accident.

## NOTICE

Driving with wheels and tires with different sizes may cause the ESC system to malfunction. Before replacing tires, make sure all four tires and wheels are the same size. Never drive the vehicle with different sized wheels and tires installed.



Don't use ESC SPORT mode or ESC OFF while using a minispare tire or a tire repair kit is in use!

#### ESC OFF usage

When Driving

The ESC OFF mode should only be used briefly to help free the vehicle if stuck in snow or mud, by temporarily stopping operation of the ESC, to maintain wheel torque.

To turn ESC off while driving, press the ESC OFF button while driving on a flat road surface.

# NOTICE

To prevent damage to the transmission:

- Do not allow wheel(s) of one axle to spin excessively while the ESC, ABS, and parking brake warning lights are displayed. The repairs would not be covered by the vehicle warranty. Reduce engine power and do not spin the wheel(s) excessively while these lights are displayed.
- When operating the vehicle on a dynamometer, make sure the ESC is turned off (ESC OFF light illuminated).



# Information

Turning the ESC off does not affect ABS or standard brake system operation.

#### Drive mode selection

When the ESC is on, the characteristic of ESC varies according to which drive mode is selected by pressing the DRIVE MODE or N1 or N2 button on the steering wheel

Mode button	Selected mode	Characteristic of ESC	
	ECO mode NORMAL		
DRIVE MODE button	NORMAL mode	NORMAL	
	SPORT mode	NORMAL	
N button	N mode	SPORT	
N button	N CUSTOM mode	NORMAL/ SPORT/OFF	

For more details, refer to "Drive Mode Integrated Control System" in this chapter.


#### CUSTOM mode

You may select the drive mode you prefer from the infotainment system.

- From the CUSTOM mode menu, select 'ESC → NORMAL / SPORT / OFF'.
- You may directly go to the CUSTOM mode menu by touching the infotainment system.

# *i* Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.



When N1 or N2 button is set to CUSTOM mode, you cannot turn CUSTOM mode on by pressing either N1 or N2 button if ESC OFF setting is saved within CUSTOM mode. If N1 or N2 button is pressed, a message "ESC disabled in CUSTOM 1 (or 2) mode settings. Hold the button again to acknowledge" appears on the cluster display. To turn on CUSTOM mode with ESC OFF setting, press and hold N1 or N2 button.

# Vehicle Stability Management (VSM)

The Vehicle Stability Management (VSM) is a function of the Electronic Stability Control (ESC) system. It helps ensure the vehicle stays stable when accelerating or braking suddenly on wet, slippery and rough roads where traction over the four tires can suddenly become uneven.

# A

## WARNING

Take the following precautions when using the Vehicle Stability Management (VSM):

- ALWAYS check the speed and the distance to the vehicle ahead. The VSM is not a substitute for safe driving practices.
- Never drive too fast for the road conditions. The VSM system will not prevent accidents. Excessive speed in bad weather, on slippery and uneven roads can result in severe accidents.

#### VSM operation

When operating

When you apply your brakes under conditions which may activate the ESC, you may hear sounds from the brakes, or feel a corresponding sensation in the brake pedal. This is normal and it means your VSM is active.



## Information

The VSM does not operate when:

system is available again.

- Driving through banked corners might result in a ESC system shut down, due to system self-diagnostics and an assumption of a sensor failure.
   In the next ignition cycle, the ESC
- Driving in reverse.
- · The ESC OFF indicator light is on.
- The MDPS (Motor Driven Power Steering) warning light (♠) is on or blinks.



## ! WARNING

If the ESC indicator light (📢) or MDPS warning light (🌖) stays illuminated or blinks, your vehicle may have a malfunction with the VSM system. When the warning light illuminates, have your vehicle checked by an authorized HYUNDAI dealer as soon as possible.

# NOTICE

Driving with wheels and tires with different sizes may cause the VSM system to malfunction. Before replacing tires, make sure all four tires and wheels are the same size. Never drive the vehicle with different sized tires and wheels installed.

## **Hill-Start Assist Control (HAC)**

Hill-Start Assist Control helps prevent the vehicle from rolling backwards when starting a vehicle from a stop on a hill. The system operates the brakes automatically for approximately 2 seconds (maximum of 5 seconds when the accelerator pedal is slightly depressed during HAC operation) and releases the brake after 2 seconds or when the accelerator pedal is depressed.



#### WARNING

Always be ready to depress the accelerator pedal when starting off an incline. Hill-Start Assist Control activates only for approximately 2 seconds (maximum of 5 seconds when the accelerator pedal is slightly depressed during HAC operation).

## NOTICE

- The HAC does not operate when the shift lever is in P (Park) or N (Neutral)
- The HAC activates even though the ESC (Electronic Stability Control) is off but does not activate when the ESC has malfunctioned.

## **Good Braking Practices**



#### WARNING

Whenever leaving the vehicle or parking, always come to a complete stop and continue to depress the brake pedal. Move the shift lever into P (Park) position, then apply the parking brake, and set the Engine Start/Stop button in the OFF position.

Vehicles parked with the parking brake not applied or not fully engaged may roll inadvertently and may cause injury to the driver and others. ALWAYS apply the parking brake before exiting the vehicle.

Wet brakes can be dangerous! The brakes may get wet if the vehicle is driven through standing water or if it is washed. Your vehicle will not stop as quickly if the brakes are wet. Wet brakes may cause the vehicle to pull to one side.

To dry the brakes, apply the brakes lightly until the braking action returns to normal, taking care to keep the vehicle under control at all times. If the braking action does not return to normal, stop as soon as it is safe to do so and call an authorized HYUNDAI dealer for assistance.

DO NOT drive with your foot resting on the brake pedal. Even light, but constant pedal pressure can result in the brakes overheating, brake wear, and possibly even brake failure.

If a tire goes flat while you are driving, apply the brakes gently and keep the vehicle pointed straight ahead while you slow down. When you are moving slowly enough for it to be safe to do so, pull off the road and stop in a safe location.

Keep your foot firmly on the brake pedal when the vehicle is stopped to prevent the vehicle from rolling forward.



# **CAUTION**

#### **Brake override system**

The system assists safe deceleration by reducing the engine power when the accelerator pedal is jammed or stuck and when you continue depressing the brake pedal.

However, the system is deactivated when ESC is OFF in N mode. (Gear shift lever should stay in manual position.) When the system is disabled, the brake distance may be longer than when the system is activated.

# **ELECTRONIC CONTROL SUSPENSION (ECS)**

The Electronic Control Suspension (ECS) controls the vehicle suspension automatically to maximize driving comfort by taking into account the driving conditions such as speed, surface of the road, cornering, stopping requirements and acceleration.

## System malfunction



**Check Electronic Suspension** 

When Electronic Control Suspension is not working properly, this warning message will appear on the cluster display. If this occurs, have the system inspected by an authorized HYUNDAI dealer.

#### **ELECTRONIC LIMITED SLIP DIFFERENTIAL**

Electronic Limited Slip Differential refers to a feature equipped with a mechanism that controls the differential functions of the wheels.

The Electronic Limited Slip Differential helps:

- Improve handling performance when circling at high speed.
- Improve launching performance.
- Prevent slipping on rainy or snowy roads due to dissimilar friction of the left and right wheels.

# / WARNING

Never run wheels with one of them lifted by the jack. It is extremely dangerous for a vehicle equipped with Electronic Limited Slip Differential.

#### Drive mode selection

The characteristic of e-LSD varies according to which drive mode is selected by pressing the DRIVE MODE or N1 or N2 button on the steering wheel.

Mode button	Selected mode	Characteristic of e-LSD	
	ECO mode	NORMAL	
DRIVE MODE button	NORMAL mode	NORMAL	
	SPORT mode	SPORT	
N button	N mode	SPORT	
	N CUSTOM mode	NORMAL/ SPORT	

For more details, refer to "Drive Mode Integrated Control System" in this chapter.

#### CUSTOM mode

You may select the drive mode you prefer from the infotainment system.


- From the CUSTOM mode menu, select 'e- LSD → NORMAL/SPORT'.
- You may directly go to the CUSTOM mode menu by touching the infotainment system.

# *i* Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

## **Warning Messages**


Electronic Limited Slip Differential disabled temporarily due to overheating



OOSN061013L

Overheating of related parts will temporarily disable e-LSD. Wait until the vehicle cools down.

# Tire size mismatch. Check all tire sizes



OOSN061014L

If your vehicle is equipped with different tires (size, type, etc.) on the front, the message will appear. To use the Electronic Limited Slip Differential, equip the vehicle with the same tires on the front.

#### Check limited slip differential



OOSN061015L

If the Electronic Limited Slip Differential warning message comes on, you may have a problem with the Electronic Limited Slip Differential system. Have the system checked by an authorized HYUNDAI dealer

#### **N BUTTON**

# **N1/N2 Button Settings**



OCN7N063208N



OCN7N073130N

N1 button: Left N button, N2 button: Right N button

The driver can set the N1/N2 button on the infotainment system screen by pressing the button approximately 0.8 seconds.

#### **Button settings**



■ N2 button



Each of the N1/N2 button can be set:

- 1. N
- 2. CUSTOM 1
- 3. CUSTOM 2
- 4. N ↔ CUSTOM 1
- 5. N ↔ CUSTOM 2
- 6. DRIVE MODE
- 7. Start/Record Lap Timer
- 8. End/Reset Lap Timer

# *i* Information

The same setting can be selected simultaneously on both N1 and N2 button. However, if the N1(N2) button is set to '(7) Start/Record Lap Timer', the N2(N1) button is automatically set to '(8) End/Reset Lap Timer'.

# *i* Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

#### **DRIVE MODE INTEGRATED CONTROL SYSTEM**

#### **Drive Mode**









If N1 or N2 button is set to 'Drive mode' from the infotainment system, the drive mode can be selected by pressing N1 or N2 button.


# *i* Information

The infotainment system may change after software updates. For more information, refer to user's the manual provided in the infotainment system and the quick reference guide.

The drive mode may be selected according to the driver's preference or road condition.

The system resets to be in the NORMAL mode, when the engine is restarted.

The mode changes, whenever the N1 or N2 button on the steering wheel or the Drive mode button is pressed.



When NORMAL mode is selected, it is not displayed on the instrument cluster.

#### ECO mode



When the Drive Mode is set to ECO mode, the engine and transmission control logic are changed to maximize fuel efficiency.

- · When the ECO mode is selected, the FCO indicator will illuminate.
- If the vehicle is set to ECO mode. when the engine is turned OFF and restarted, the Drive Mode setting will change to NORMAL mode.



# Information

Fuel efficiency depends on the driver's driving habit and road condition.

When ECO mode is activated:

- The acceleration response may be slightly reduced as the accelerator pedal is depressed moderately.
- The air conditioner performance may be limited.
- · The engine noise may get louder.

The above situations are normal conditions when ECO mode is activated, to improve fuel efficiency.

#### **Limitation of ECO mode operation:**

If the following conditions occur while ECO mode is operating, the system operation is limited even though there is no change in ECO indicator.

- When the coolant temperature is low: The system will be limited until engine performance becomes normal.
- When driving up a hill:
  - The system will be limited to gain power when driving uphill because engine torque is restricted.
  - The system will be limited due to the shift location.
- When the accelerator pedal is deeply depressed for a few seconds:
  - The system will be limited, judging that the driver wants to speed up.

#### SPORT mode



SPORT mode manages the driving dynamics by automatically adjusting the steering effort, the engine and transmission control logic for enhanced driving performance.

- When SPORT mode is selected by pressing the DRIVE MODE button, the SPORT indicator will illuminate.
- When SPORT mode is activated:
  - The engine RPM will tend to remain raised over a certain length of time even after releasing the accelerator
  - Upshifts are delayed when accelerating

# *i* Information

In SPORT mode, the fuel efficiency may decrease.

#### **N** Mode



OCN7N063208N



N mode may be selected by pressing the N1 or N2 button.

The system resets to be in the NORMAL mode, when the engine is restarted.



# Information

The driver can set the N1 or N2 button to N mode on the infotainment system. For more details on N1 or N2 button setup, refer to "N button" in this chapter.

#### N mode



N mode selects the proper driving mode among SPORT and SPORT+ for each components that will effect the performance of a highperformance vehicle.

- When N mode is selected, the N indicator will illuminate.
- N mode (SPORT/SPORT+) manages the driving dynamics by automatically adjusting the steering effort, and the engine and transmission control logic for enhanced driver performance.
- When N mode (SPORT/SPORT+) is activated:
  - The engine RPM will tend to remain raised over a certain length of time even after releasing the accelerator
  - Upshifts are delayed when accelerating

# *i* Information

In SPORT mode, the fuel efficiency may decrease.



#### **CAUTION**

N mode is for track use only and is not intended for use under any other driving conditions.

#### **CUSTOM** mode

The driver can set the two
types of CUSTOM mode
(CUSTOM 1/CUSTOM 2). In
CUSTOM mode, they can
select the drive mode for each
component they prefer on the
infotainment system screen.

- Engine: NORMAL/SPORT/ SPORT+
- Transmission: NORMAL/SPORT/ SPORT+ (For DCT)
  - CREEP START function\*1 ON/OFF
- E-LSD (Electronic Limited Slip Differential): NORMAL/SPORT
- Suspension : NORMAL/SPORT/ SPORT+
- Steering: NORMAL/SPORT/ SPORT+
- ESC (Electronic Stability Control): NORMAL/SPORT/OFF
- Exhaust sound : NORMAL/ SPORT/ SPORT+

\*1 CREEP START function (default setting ON): When OFF is set, vehicle will not start automatically even if the brake pedal is not pressed in D stop state.



# Information

The infotainment system may change after software updates. For more information, refer to user's the manual provided in the infotainment system and the quick reference guide.



#### **CAUTION**

SPORT+ mode is for track use only and is not intended for use under any other driving conditions.

## **NGS (N Grin Shift)**

Controls engine / transmission to maximum performance when pressing NGS button on the steering wheel remote control in situations where rapid acceleration is required.

#### Functional description and operating conditions



When NGS button is pressed:

- Automatically shifts to the lowest allowable gear (Automatic shifting is not performed in manual shift mode)
- Turbo is in overboost mode (number can be added as well)
- · N Grin Shift is available for 20 Seconds
- N Grin Shift can be reused 40 seconds later after using the function for 20 seconds

N Grin Shift will turn off during operation or will not operate when:

- · Changing Drive-mode during N Grin Shift operation
- Engine check light is on
- Transmission high temperature (overheating) lights on
- · Transmission malfunction
- Shift lever is in P (Park)/R (Reverse)/N (Neutral)
- · Using N Grin Shift within 40 seconds after using the function for 20 seconds





- The driver has the responsibility to safely drive and control the vehicle when using N Grin Shift.
- Do not attempt dangerous driving while using N Grin Shift.
- · It is recommended to use after vehicle break-in and continuous use of N Grin Shift can overload the vehicle components such as transmission, engine and drive shaft.

#### **Vehicle Characteristic**

The characteristic of each components varies according to which drive mode is selected by pressing the N1 or N2 button on the steering wheel or the DRIVE MODE button.

MT	Component	DRIVE MODE Button			
MT		ECO mode	NORMAL mode	SPORT mode	
Engine & Driving	Engine	ECO	NORMAL	SPORT	
	Rev matching	OFF	NORMAL	SPORT	
	e-LSD*1	NORMAL	NORMAL	SPORT	
Chassis	Suspension	NORMAL	NORMAL	SPORT	
	Steering	NORMAL	NORMAL	SPORT	
	ESC *2	NORMAL	NORMAL	NORMAL	
Sound	Exhaust sound *3	ECO	NORMAL	SPORT	

MT	Component	N mode		
MT		N mode	CUSTOM mode	
	Engine	SPORT+	NORMAL / SPORT / SPORT+	
Engine & Driving	Rev matching	SPORT+	OFF / NORMAL / SPORT / SPORT+	
	e-LSD*1	SPORT	NORMAL / SPORT	
	Suspension	SPORT+	NORMAL / SPORT / SPORT+	
Chassis	Steering	SPORT+	NORMAL / SPORT / SPORT+	
	ESC *2	SPORT	NORMAL / SPORT / OFF	
Sound	Exhaust sound *3	SPORT+	NORMAL / SPORT / SPORT+	

<sup>\*1:</sup> Electronic Limited Slip Differential

An exhaust crackle sound, to deliver emotional effect, is produced while driving when the accelerator pedal is released right after being depressed. This exhaust sound effect will be heard when SPORT+ is selected for the Sound component. To turn it off, select NORMAL or SPORT for the Engine component in CUSTOM mode.

Please be aware and be mindful when using exhaust sound system in SPORT+ mode as the pops and bangs can cause disturbance to your neighbors when using it in a crowded public area, closed parking spaces, and/or residential area. We strongly recommend to use it with consideration.

MT: Manual Transmission

<sup>\*2:</sup> Electronic Stability Control

<sup>\*3:</sup> The volume of the exhaust sound made by the exhaust gas flap (if equipped) changes according to the mode selected. [Quietest] ECO/NORMAL mode < SPORT mode < N mode [Loudest]

DCT	Component	DRIVE MODE Button			
DCI		ECO mode	NORMAL mode	SPORT mode	
Engine & Driving	Engine	ECO	NORMAL	SPORT	
	Transmission*4	ECO	NORMAL	SPORT	
	e-LSD*1	NORMAL	NORMAL	SPORT	
Chassis	Suspension	NORMAL	NORMAL	SPORT	
	Steering	NORMAL	NORMAL	SPORT	
	ESC *2	NORMAL	NORMAL	NORMAL	
Sound	Exhaust sound *3	ECO	NORMAL	SPORT	

DCT	Component		NGS Button		
DCI		N mode	CUSTOM mode	(N Grin Shift)	
F	Engine	SPORT+	NORMAL / SPORT / SPORT+	SPORT+	
Engine & Driving  Chassis	Transmission*4	SPORT+	NORMAL / SPORT / SPORT+	SPORT+	
	e-LSD*1	SPORT	NORMAL / SPORT		
	Suspension	SPORT+	NORMAL / SPORT / SPORT+	Maintain mode before entering NGS	
	Steering	SPORT+	NORMAL / SPORT / SPORT+		
	ESC *2	SPORT	NORMAL / SPORT / OFF	1105	
Sound	Exhaust sound	SPORT+	NORMAL / SPORT / SPORT+	SPORT+	

<sup>\*1:</sup> Electronic Limited Slip Differential

An exhaust crackle sound, to deliver emotional effect, is produced while driving when the accelerator pedal is released right after being depressed. This exhaust sound effect will be heard when SPORT+ is selected for the Sound component. To turn it off, select NORMAL or SPORT for the Engine component in CUSTOM mode.

Please be aware and be mindful when using exhaust sound system in SPORT+ mode as the pops and bangs can cause disturbance to your neighbors when using it in a crowded public area, closed parking spaces, and/or residential area. We strongly recommend to use it with consideration.

DCT: Dual Clutch Transmission

<sup>\*2:</sup> Electronic Stability Control

<sup>\*3:</sup> The volume of the exhaust sound made by the exhaust gas flap (if equipped) changes according to the mode selected. [Quietest] ECO/NORMAL mode < SPORT mode < N mode [Loudest]

<sup>\*4:</sup> Automatic creep start function can be turned ON / OFF in CUSTOM setup menu.

# **PERFORMANCE OPTION (IF EQUIPPED)**

# *i* Information

Using high performance exhaust sound in a crowded public area, closed parking spaces, and/or residential area can cause disturbance to your neighbors.

# **Performance Option Settings**



OCN7N061219N



 You can performance option function from the Settings menu in the infotainment system screen. : Touch the N mode (1)→Swipe the screen to left (2)



2. Touch the performance option (3).



Items of Performance option may differ depending on the transmission specification.

#### **Launch Control**

Launch Control provides maximum acceleration on dry asphalt roads. Launch Control not to be used on any other surface. Excessive slip might occur and harm your vehicle.

#### Prerequisite for activation

Launch Control gets ready to be activated, when the following prerequisites are satisfied.

- · All doors, hood and trunk are closed.
- · The vehicle is at a complete stop.
- No malfunction warning lights related to the engine and ESC (Electronic Stability Control) is in Sport or Off mode.

# NOTICE

- Launch Control is intended for use at a closed race track with dry road surface and not intended for use on public roads. It will not compensate for driver's who are inexperienced or lack familiarity with the race track.
- Do not use Launch Control during break-in period of the vehicle.
- Constant use of Launch Control can put enormous stress on the vehicle resulting in premature wear of related components.



OCN7N061232N

- 1. Press the 'Launch control' tab.
- Press the '< (Left)' or '> (Right)' to set the engine RPM for launch control.
- 3. Press 'Activate' to enter Launch Control ready state.
- Press 'Reset RPM' to reset engine RPM to default launch control engine speed.

# Launch control on and off (For Manual transmission)

- Select N mode with 'N' button (N mode indicator will illuminate on the cluster) or select SPORT+ for the engine mode in CUSTOM mode.
- Check that the ESC mode is ESC SPORT mode or ESC OFF. If not, press ESC OFF button to set the ESC mode to ESC SPORT mode or ESC OFF. (Electronic Stability Control (ESC) does not operate when ESC OFF.)
- Select 'Performance Options → Launch Control' to set engine RPM from the infotainment system screen. After setting RPM, press 'Activate'.
- 4. Align the steering wheel straight
- 5. Depress the clutch pedal.
- 6. Shift to 1st gear.
- 7. While depressing the clutch pedal with your left foot, quickly and fully depress the accelerator pedal with your right foot. Launch control will be in the ready state. The message 'Launch Control Ready' will appear on the cluster. If necessary, adjust engine RPM with +/- switch on the steering wheel.
- 8. A smooth, quick release of the clutch pedal within 8 seconds, while maintaining full depression of the accelerator pedal will initiate launching of the vehicle. The message 'Launch Control Active' will appear on the cluster.
- 9. Control will deactivate when the accelerator pedal is released.

# Launch control on and off (For Dual clutch transmission)

- Select N mode with 'N' button (N-mode indicator lights up on instrument cluster) or select SPORT+ for the engine mode in custom mode.
- Check that the ESC mode is ESC SPORT or ESC OFF. If not, press button to set the ESC mode to ESC SPORT or ESC OFF.(Indicator lights on the instrument cluster)(Vehicle dynamic control device does not operate when ESC OFF.)
- Put the transmission gear on 'D'(driving) or 'M' (manual mode) position.(driver must shift by yourself when manual mode is selected.)
- 4. In Launch Control tab of Navigation's Performance Options, select rpm and press 'Activate' button.(N mode → Performance Option → Launch Control) (button lights on when activated)
- 5. Align the steering wheel straight.
- 6. Press brake pedal to maximum with your left foot.
- 7. When you press the brake pedal with your left foot and quickly and fully depress and hold accelerator pedal with your right foot, you are ready for launch control. When it is ready, the text "Launch Control Ready" is displayed. RPM value can be adjusted with +/- switch on the steering wheel.
- 8. Release your foot gently off the brake pedal within 8 seconds to launch the vehicle, keeping accelerator pedal fully pressed. Launch Control is activated and the text" Launch Control Active" is displayed.
- 9. Launch control is deactivated when you release accelerator pedal.



#### ! CAUTION (For Manual transmission)

- If you press the clutch pedal and the accelerator pedal at the same time and then release the accelerator pedal, the launch control function is released.
- To use the Launch Control again, you must use the vehicle for at least 3 minutes (over 37 mph (60 km)) or for at least after 5 minutes of cooling.
- If you do not start after 8 seconds by stepping on the clutch pedal and the accelerator pedal, the launch control function is automatically released and can be reused after cooling down the vehicle



## ! CAUTION (For Dual clutch transmission)


- If you press the brake pedal and the accelerator pedal at the same time and then release the accelerator pedal, the launch control function is released.
- To use the Launch Control again, you must use the vehicle for at least 2 minutes (over 37 mph (60 km)) or for at least after 5 minutes of cooling.
- If you do not start after 8 seconds by stepping on the clutch pedal and the accelerator pedal ,the launch control function is automatically released and can be reused after cooling down the vehicle.



#### CAUTION

Launch performance when using launch control in vehicle is highly dependent on the clutch connection technology, tire friction and road conditions. In other words, the use of the launch control does not always guarantee maximum launch performance.

#### **Shift Light**






When engine is operating in a high RPM area, it is indicated on the cluster according to the corresponding engine RPM.

As the engine RPM approaches to the limit, each of shift lights on both sides, and when all lights blinks in red or alert alarm sound, it is time to perform upshift immediately.

In the "Shift light" tab of the performance option, you can set which mode displays shift light and select target shift RPM.

(N mode → Performance options → Shift light)

#### How to set shift light



OCN7N061241L

- 1. Press 'Shift light' tab in Performance options.
- Select drive mode to activate shift indicator. (ECO/NORMAL/SPORT/N/ CUSTOM)
- Set up target RPM by pressing '< (Left)' or '> (Right)'. (6000 RPM ~ 6700 RPM)
- 4. Check 'Alert sound' to choose whether or not to execute.
- 5. Press 'Reset RPM' to reset the target RPM speed.
- Engine speed change notification is sent before engine speed reaches to the set value to shift at set target RPM speed.

## Shift Light operation table


 $\bar{\ }$  Blinking of all 5 LEDs, works only in the fixed shift mode where manual upshift is required.

Shift lever position	Shift mode	LED step lighting	All LED blink (upshift shift notification)
	Automatic shift mode	X	X
D	N Grin Shift operation	0	X
	N Track Shift operation	0	X
	Temporary manual shift mode (enter D stage paddle shifter operation)	0	Х
М	Fixed shift mode (no automatic upshift)	0	0

# N Track Sense Shift (for dual clutch transmission)

N Track Sense Shift is automatically activated when dynamic driving condition with lots of cornering maneuver is detected. (for example, Race track driving). The program enables stress-free track driving by automatically shifting down at the entry of corner and maintains lower gear during cornering as if you are shifting manually in professional manner. N Track Sense Shift provides lower gear when level of driving aggression increases.

#### How to set N Track Sense Shift



OCN7N061242L

- Press 'N Mode → Performance
   Option → N Track Sense Shift' on the
   infotainment system home screen to
   enter the N Track Sense Shift setting
   screen.
- In N Track Sense Shift setup screen, press 'Activate' to select enable/ disable features.
- \* When the vehicle is released for the first time, function is activated.
- \* Active/Deactivated setting is saved even when the vehicle is restarted.

#### Operating condition

- N Track Sense Shift is enabled in the Performance Options settings
- Shift lever in D (Drive) position
- Transmission mode is SPORT or SPORT+ (Including SPORT or N mode)
- Vehicle speed is above 21 mph (35km/h)
- Cornering-oriented dynamic driving detection



\* When N Track Sense Shift is operating, a message is displayed in the cluster display as shown below.

#### Non-operating conditions

- N Track Sense Shift is disabled in Performance Options settings
- Shift lever position is in P (Park)/R (Reverse)/N (Neutral)
- Changing Transmission mode during operation (Transmission mode does not work in ECO, NORMAL or manual shift mode.)
- Cruise Control is operating
- Vehicle speed is below 21 mph (35 km/h)
- \* When N Track Sense Shift is deactivated, the displayed message will disappear from the cluster display.



#### ! CAUTION


Vehicle safety and control must be at your own discretion and do not attempt to drive dangerously to operate N Track Sense Shift.



#### WARNING

N Track Sense is activated only automatically when vehicle recognizes dynamic driving (longitudinal & lateral forces). Only operate in accordance with local road rules and in safe conditions. Driving the vehicle in certain circumstances or participating in certain driving activities can impact your new vehicle warranty. See your Service Warranty Passport for full warranty terms, conditions and exclusions.

# N Power Shift (for dual clutch transmission)



OCN7N061255N

When the driver depresses the accelerator pedal fully (100%) in N mode for faster acceleration, it controls by (up) shifting with minimal energy loss.

N Power Shift can be deactivated by pressing 'Activate' on the screen. When N Power Shift is deactivated, vehicle shifting is similar to normal shifting. However, it is activated when the engine is restarted.

#### **N Sound Equalizer**



#### Driving sound master volume



Tone equalizer



OCN7N063245

N Sound Equalizer provides a more exciting driving sound to the driver through the existing speakers installed in the vehicle.

# *i* Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

# *i* Information

It provides three special driving sounds of N vehicle's. Equalizer features are available to adjust the volume and tone in detail to suit your personal taste.

Sound	Mode	Custom	Function
CDODTV	SPORT	-	It matches well with the exhaust sound to
SPORTY	CUSTOM	0	provide a natural and linear sound.
HIGH	N STANDARD	-	It provides a sound with a sense of power
PERPORMANCE	CUSTOM	0	an1d dynamics even in the low RPM range.
TCR	CUSTOM	0	It plays the sound of a HYUNDAI TCR vehicle.

# Maximum Performance Driving (How to drive with Octane Number Learning)


- When the vehicle is refueled, ECU recognizes fueling conditions and determines the octane rating of the fuel.
- Maximum boost pressure is limited to protect the engine until the fuel is identified as premium fuel.
- After the vehicle is refueled with premium fuel, it is recommended to drive the vehicle in the below conditions for guick learning.

Driving conditions	Gear	Accelerator pedal	Vehicle speed	Driving time
When high and constant speed driving is possible (highway, expressway, freeway, etc.)	TOP gear fixed (MT: 6th gear) (DCT: 8th gear)	Constant speed control (Cruise control is possible)	68-99 mph	5 minutes or more
When high and constant speed driving is not possible (circuit, etc.)	4th gear or 5th gear fixed	40%-70%	25-75 mph Repeating slow acceleration within the area	5 minutes or more


The description (vehicle speed is above speed limit and acceleration and deceleration is repeated) in the table is based on the assumption that you are driving in a circuit.

## **!** WARNING

Follow the speed limit when driving with Octane Number Learning.



[Driving example] When high and constant speed driving is possible



[Driving example] When high and constant speed driving is not possible

#### SPECIAL DRIVING CONDITIONS

#### **Hazardous Driving Conditions**

When hazardous driving elements are encountered such as water, snow. ice, mud and sand, take the below suggestions:

- Drive cautiously and keep a longer braking distance.
- Avoid abrupt braking or steering.
- When your vehicle is stuck in snow, mud, or sand, use second gear. Accelerate slowly to avoid unnecessary wheel spin.
- Put sand, rock salt, tire chains or other non-slip materials under the wheels to provide additional traction while the vehicle becomes stuck in ice. snow. or mud.

# ! WARNING

Downshifting with an intelligent variable transmission while driving on slippery surfaces can cause an accident. The sudden change in tire speed could cause the tires to skid. Be careful when downshifting on slippery surfaces.

#### **Rocking the Vehicle**

If it is necessary to rock the vehicle to free it from snow, sand, or mud, first turn the steering wheel right and left to clear the area around your front wheels. Then, shift back and forth between R (Reverse) and a forward gear.

Try to avoid spinning the wheels, and do not race the engine.

To prevent transmission wear, wait until the wheels stop spinning before shifting gears. Release the accelerator pedal while shifting, and press lightly on the accelerator pedal while the transmission is in gear. Slowly spinning the wheels in forward and reverse directions causes a rocking motion that may free the vehicle.

## WARNING

If the vehicle is stuck and excessive wheel spin occurs, the temperature of the tires can increase very quickly. If the tires become damaged, a tire blow out or tire explosion can occur. This condition is dangerous - you and others may be injured. Do not attempt this procedure if people or objects are anywhere near the vehicle.

If you attempt to free the vehicle, the vehicle can overheat quickly, possibly causing an engine compartment fire or other damage. Try to avoid spinning the wheels as much as possible to prevent overheating of either the tires or the engine, DO NOT allow the vehicle to spin the wheels above 35 mph (56 km/h).

### Information

The ESC system must be turned OFF before rocking the vehicle.

#### NOTICE

If you are still stuck after rocking the vehicle a few times, have the vehicle pulled out by a tow vehicle to avoid engine overheating, possible damage to the transmission, and tire damage. Refer to "Towing" section in chapter 8.

#### **Smooth Cornering**

Avoid braking or gear changing in corners, especially when roads are wet. Ideally, corners should always be taken under gentle acceleration.

#### **Driving at Night**

Night driving presents more hazards than driving in the daylight. Here are some important tips to remember:

- Slow down and keep more distance between you and other vehicles, as it may be more difficult to see at night, especially in areas where there may not be any street lights.
- Adjust your mirrors to reduce the glare from other driver's headlights.
- Keep your headlights clean and properly aimed. Dirty or improperly aimed headlights will make it much more difficult to see at night.
- Avoid staring directly at the headlights of oncoming vehicles. You could be temporarily blinded, and it will take several seconds for your eyes to readjust to the darkness.

#### **Driving in the Rain**

Rain and wet roads can make driving dangerous. Here are a few things to consider when driving in the rain or on slick payement:

- Slow down and allow extra following distance. A heavy rainfall makes it harder to see and increases the distance needed to stop your vehicle.
- · Turn OFF your Cruise Control.
- Replace your windshield wiper blades when they show signs of streaking or missing areas on the windshield.
- Tires should be properly maintained with at least 2/32nds of an inch of tread depth. If your tires do not have enough tread, making a quick stop on wet pavement can cause a skid and possibly lead to an accident. Refer to "Tire replacement" section in chapter 9.
- Turn on your headlights to make it easier for others to see you.
- Driving too fast through large puddles can affect your brakes. If you must go through puddles, try to drive through them slowly.
- If you believe your brakes may be wet, apply them lightly while driving until normal braking operation returns.

#### Hydroplaning

If the road is wet enough and you are going fast enough, your vehicle may have little or no contact with the road surface and actually ride on the water. The best advice is SLOW DOWN when the road is wet.

The risk of hydroplaning increases as the depth of tire tread decreases, refer to "Tire Replacement" section in chapter 9.

#### **Driving in Flooded Areas**

Avoid driving through flooded areas unless you are sure the water is no higher than the bottom of the wheel hub. Drive through any water slowly. Allow adequate stopping distance because brake performance may be reduced.

After driving through water, dry the brakes by gently applying them several times while the vehicle is moving slowly.

#### **Highway Driving**

#### **Tires**

Adjust the tire inflation, as specified. Under-inflation may overheat or damage the tires.

Do not install worn-out or damaged tires, which may reduce traction or adversely affect vehicle handling. This could lead to sudden tire failure that may cause loss of vehicle control resulting in an accident.



Never over-inflate your tires above the maximum inflation pressure, as specified on your tires.

#### Fuel, engine coolant and engine oil

Driving at higher speeds on the highway consumes more fuel and is less efficient than driving at a slower, more moderate speed. Maintain a moderate speed in order to conserve fuel when driving on the highway.

Be sure to check both the engine coolant level and the engine oil before driving.

#### Drive helt

A loose or damaged drive belt may overheat the engine.

#### WINTER DRIVING

The severe weather conditions of winter quickly wear out tires and cause other problems. To minimize winter driving problems, you should take the following suggestions:

#### **Snow or Icy Conditions**

You need to keep sufficient distance between your vehicle and the vehicle in front of you.

Apply the brakes gently. Speeding, rapid acceleration, sudden brake applications, and sharp turns are potentially very hazardous practices. During deceleration, use engine braking to the fullest extent. Sudden brake applications on snowy or icy roads may cause the vehicle to skid.

To drive your vehicle in deep snow, it may be necessary to use snow tires or to install tire chains on your tires.

Always carry emergency equipment. Some of the items you may want to carry include tire chains, tow straps or chains, a flashlight, emergency flares, sand, a shovel, jumper cables, a window scraper, gloves, ground cloth, coveralls, a blanket, etc.

#### Snow tires



#### **⚠** WARNING

Snow tires should be equivalent in size and type to the vehicle's standard tires. Otherwise, the safety and handling of your vehicle may be adversely affected.

If you mount snow tires on your vehicle, make sure to use radial tires of the same size and load range as the original tires. Mount snow tires on all four wheels to balance your vehicle's handling in all weather conditions. The traction provided by snow tires on dry roads may not be as high as your vehicle's original equipment tires. Check with the tire dealer for maximum speed recommendations.



#### Information

Do not install studded tires without first checking local, state and municipal regulations for possible restrictions against their use.

#### Tire chains



Since the sidewalls of radial tires are thinner than other types of tires, they may be damaged by mounting some types of tire chains on them. Therefore the use of snow tires is preferred over the use of tire chains.

If the road and weather conditions require the use of tire chains, be sure to use tire chains that have been properly selected for the size of tire on your HYUNDAI vehicle.

Be sure to follow the guidelines and installation instructions provided from the tire chain manufacturer.

Damage to your vehicle caused by improper tire chain use is not covered by your vehicle manufacturer's warranty.

## **MARNING**

The use of AutoSock (fabric snow chain) may adversely affect vehicle handling:

- Drive less than 20 mph (30 km/h) or the chain manufacturer's recommended speed limit, whichever is lower.
- Drive carefully and avoid bumps, holes, sharp turns, and other road hazards, which may cause the vehicle to bounce.
- Avoid sharp turns or locked wheel braking.

## *i* Information

- Install AutoSock (fabric snow chain) only in pairs and on the front tires. It should be noted that installing AutoSock (fabric snow chain) on the tires will provide a greater driving force, but will not prevent side skids.
- Do not install studded tires without first checking local and municipal regulations for possible restrictions against their use.

#### Chain Installation

When installing AutoSock (fabric snow chain), follow the manufacturer's instructions and mount them as tightly as possible. Drive slowly (less than 20) mph (30 km/h)) with chains installed. If you hear the chains contacting the body or chassis, stop and tighten them. If they still make contact, slow down until the noise stops. Remove the AutoSock(fabric snow chain) as soon as you begin driving on cleared roads. When mounting AutoSock (fabric snow chain), park the vehicle on level ground away from traffic. Turn on the vehicle Hazard Warning Flasher and place a triangular emergency warning device behind the vehicle (if available). Always place the vehicle in P (Park), apply the parking brake and turn off the engine before installing tire chains.

#### NOTICE

When using AutoSock (fabric snow chain):

- Wrong size chains or improperly installed chains can damage your vehicle's brake lines, suspension, body and wheels.
- If you hear noise caused by chains contacting the body, retighten the chain to prevent contact with the vehicle body.
- To prevent body damage, retighten the chains after driving 0.3-0.6 miles (0.5-1.0 km).

#### **Winter Precautions**

# Use high quality ethylene glycol coolant

Your vehicle is delivered with high quality ethylene glycol coolant in the cooling system. It is the only type of coolant that should be used because it helps prevent corrosion in the cooling system, lubricates the water pump and prevents freezing. Be sure to replace or replenish your coolant in accordance with the maintenance schedule in chapter 9. Before winter, have your coolant tested to assure that its freezing point is sufficient for the temperatures anticipated during the winter.

# Change to "winter weight" oil if necessary

In some climates it is recommended that a lower viscosity "winter weight" oil be used during cold weather. See chapter 8 for recommendations. If you aren't sure what weight oil you should use, consult an authorized HYUNDAI dealer.

#### Check battery and cables

Winter puts additional burdens on the battery system. Visually inspect the battery and cables as described in chapter 8. The level of charge in your battery can be checked by an authorized HYUNDAL dealer or a service station.

# Check spark plugs and ignition system

Inspect your spark plugs as described in chapter 8 and replace them if necessary. Also check all ignition wiring and components to be sure they are not cracked, worn or damaged in any way.

#### Use approved window washer antifreeze in system

To keep the water in the window washer system from freezing, add an approved window washer anti-freeze solution in accordance with instructions on the container.

Window washer anti-freeze is available from an authorized HYUNDAI dealer and most auto parts outlets. Do not use engine coolant or other types of antifreeze as these may damage the paint finish.

#### Do not let your parking brake freeze

Under some conditions your parking brake can freeze in the engaged position. This is most likely to happen when there is an accumulation of snow or ice around or near the rear brakes or if the brakes are wet. If there is a risk the parking brake may freeze, apply it only temporarily while you put the gear selector lever in P and block the rear wheels so the car cannot roll. Then release the parking brake.

# Do not let ice and snow accumulate underneath

Under some conditions, snow and ice can build up under the fenders and interfere with the steering. When driving in severe winter conditions where this may happen, you should periodically check underneath the car to be sure the movement of the front wheels and the steering components is not obstructed.

#### Don't place foreign objects or materials in the engine compartment

Placement of foreign object or materials which prevent cooling of the engine, in the engine compartment, may cause a failure or combustion. The manufacturer is not responsible for the damage caused by such placement.

#### To keep locks from freezing

To keep the locks from freezing, squirt an approved de-icer fluid or glycerine into the key opening. If a lock is covered with ice, squirt it with an approved deicing fluid to remove the ice. If the lock is frozen internally, you may be able to thaw it out by using a heated key. Handle the heated key with care to avoid injury.

# Drive your vehicle when water vapor condenses and accumulates inside the exhaust pipes

When the vehicle is stopped for a long time in winter while the engine is running, water vapor may condense and accumulate inside the exhaust pipes. Water in the exhaust pipes may cause noise, etc., but it is drained driving at medium to high speed.

#### VEHICLE LOAD LIMIT

Two labels on your driver's door sill show how much weight your vehicle was designed to carry: the Tire and Loading Information Label and the Certification Label.

Before loading your vehicle, familiarize yourself with the following terms for determining your vehicle's weight ratings, from the vehicle's specifications and the Certification Label:

#### **Base Curb Weight**

This is the weight of the vehicle including a full tank of fuel and all standard equipment. It does not include passengers, cargo, or optional equipment.

#### **Vehicle Curb Weight**

This is the weight of your new vehicle when you picked it up from your dealer plus any aftermarket equipment.

#### **Cargo Weight**

This figure includes all weight added to the Base Curb Weight, including cargo and optional equipment.

#### **GAW (Gross Axle Weight)**

This is the total weight placed on each axle (front and rear) - including vehicle curb weight and all payload.

#### **GAWR (Gross Axle Weight Rating)**

This is the maximum allowable weight that can be carried by a single axle (front or rear). These numbers are shown on the Certification Label. The total load on each axle must never exceed its GAWR.

#### **GVW (Gross Vehicle Weight)**

This is the Base Curb Weight plus actual Cargo Weight plus passengers.

# GVWR (Gross Vehicle Weight Rating)

This is the maximum allowable weight of the fully loaded vehicle (including all options, equipment, passengers and cargo). The GVWR is shown on the Certification Label located on the driver's door sill.

#### **Tire Loading Information Label**



OCN7N063249N

The label located on the driver's door sill gives the original tire size, cold tire pressures recommended for your vehicle, the number of people that can be in your vehicle and vehicle capacity weight.

# Vehicle capacity weight 849 lbs. (385 kg)

Vehicle capacity weight is the maximum combined weight of occupants and cargo. If your vehicle is equipped with a trailer, the combined weight includes the tongue load.

#### Seating capacity

Total: 5 persons

(Front seat : 2 persons, Rear seat : 3 persons)

Seating capacity is the maximum number of occupants including a driver, your vehicle may carry. However, the seating capacity may be reduced based upon the weight of all of the occupants, and the weight of the cargo being carried or towed. Do not overload the vehicle as there is a limit to the total weight, or load limit including occupants and cargo, the vehicle can carry.

#### Towing capacity

We do not recommend using this vehicle for trailer towing.

#### Cargo capacity

The cargo capacity of your vehicle will increase or decrease depending on the weight and the number of occupants and the tongue load, if your vehicle is equipped with a trailer.

# Steps for determining correct load limit

- Locate the statement "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs." on your vehicle's placard.
- Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- Subtract the combined weight of the driver and passengers from XXX kg or XXX lbs.
- 4. The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the "XXX" amount equals 1400 lbs. and there will be five 150 lb. passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs. (1400 750 (5 x 150) = 650 lbs.)
- Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in Step 4.
- If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle.



#### ! WARNING

Do not overload the vehicle as there is a limit to the total weight, or load limit, including occupants and cargo, the vehicle can carry. Overloading can shorten the life of the vehicle. If the GVWR or the GAWR is exceeded, parts on the vehicle can be broken, and it can change the handling of your vehicle. These could cause you to lose control and result in an accident.

Example 1	Vehicle Capacity	≥	**	+	
	Maximum Load (1400 lbs.) (635 kg)		Passenger Weight (150 lbs. × 2 = 300 lbs.) (68 kg × 2 = 136 kg)		Cargo Weight (1100 lbs.) (499 kg)
Example 2	Vehicle Capacity	≥	<b>**</b> *	+	
	Maximum Load (1400 lbs.) (635 kg)		Passenger Weight (150 lbs. × 5 = 750 lbs.) (68 kg × 5 = 340 kg)		Cargo Weight (650 lbs.) (295 kg)
Example 3	Vehicle Capacity	≥	444 44	+	
	Maximum Load (1400 lbs.) (635 kg)		Passenger Weight (172 lbs. × 5 = 860 lbs.) (78 kg × 5 = 390 kg)		Cargo Weight (540 lbs.) (245 kg)

#### Certification label



The certification label is located on the driver's door sill at the center pillar and shows the maximum allowable weight of the fully loaded vehicle. This is called the GVWR (Gross Vehicle Weight Rating). The GVWR includes the weight of the vehicle, all occupants, fuel and cargo.

This label also tells you the maximum weight that can be supported by the front and rear axles, called Gross Axle Weight Rating (GAWR).

The total weight of the vehicle, including all occupants, accessories, cargo, and trailer tongue load must not exceed the Gross Vehicle Weight Rating (GVWR) or the Gross Axle Weight Rating (GAWR). To find out the actual loads on your front and rear axles, you need to go to a weigh station and weigh your vehicle. Be sure to spread out your load equally on both sides of the centerline.

## **⚠** WARNING

#### Overloading

 Never exceed the GVWR for your vehicle, the GAWR for either the front or rear axle and vehicle capacity weight. Exceeding these ratings can affect your vehicle's handling and braking ability, and cause an accident. Do not overload your vehicle.
 Overloading your vehicle can cause heat buildup in your vehicle's tires and possible tire failure, increased stopping distances and poor vehicle handling-all of which may result in a crash.

#### NOTICE

Overloading your vehicle may cause damage. Repairs would not be covered by your warranty. Do not overload your vehicle.



#### WARNING

If you carry items inside your vehicle (for example, suitcases, tools, packages, or anything else), they are moving as fast as the vehicle. If you have to stop or turn quickly, or if there is a crash, the items will keep going and can cause an injury if they strike the driver or a passenger.

- Put items in the cargo area of your vehicle. Try to spread the weight evenly.
- Do not stack items like suitcases inside the vehicle above the tops of the seats.
- Do not leave an unsecured child restraint in your vehicle.
- When you carry something inside the vehicle, secure it.

#### TRAILER TOWING


We do not recommend using this vehicle for trailer towing.

# 7. Driver Assistance System

Due to the infotainment software version, the description of each function of the driver assistance system may differ from the owner's manual.

Driving Safety	
Forward Collision-Avoidance Assist (FCA) (Front view camera only)	7-2
Lane Keeping Assist (LKA)	7-14
Blind-Spot Collision-Avoidance Assist (BCA)	
Safe Exit Warning (SEW)	
Manual Speed Limit Assist (MSLA)	
Intelligent Speed Limit Assist (ISLA)	
Driver Attention Warning (DAW)	
Driving Convenience	
Cruise Control (CC)	7-53
Lane Following Assist (LFA)	
Parking Safety	
Rear View Monitor (RVM)	7.6
· · ·	
Rear Cross-Traffic Collision-Avoidance Assist (RCCA)	
Forward/Reverse Parking Distance Warning (PDW)	
Declaration of Conformity	/-8

# FORWARD COLLISION-AVOIDANCE ASSIST (FCA) (FRONT VIEW CAMERA ONLY)



Forward Collision-Avoidance Assist helps detect a vehicle, a powered two-wheeler, a pedestrian, or a cyclist ahead on the road and may warn you of a possible collision with a warning message on the instrument cluster and a warning sound. Also, Forward Collision-Avoidance Assist may assist with braking your vehicle to help reduce collision speed or avoid a collision.

#### **Detecting sensor**



[1]: Front view camera

Refer to the illustration above for the detailed location of the detecting sensor.

## $\Lambda$

#### CAUTION

Take the following precautions to maintain optimal performance of the detecting sensor:

- Never disassemble the detecting sensor or sensor assembly, or cause any damage to it.
- If the detecting sensors have been replaced or repaired, have your vehicle inspected by an authorized HYUNDAI dealer.
- Never install any accessories or stickers on the front windshield, or tint the front windshield.
- Pay extreme caution to keep the front view camera dry.
- Never place any reflective objects (for example, white paper, mirror) over the dashboard.
- Do not place any objects near the front windshield or install any accessories on the front windshield. It can affect the performance of the defogging and defrosting function of the climate control system, which may prevent the Driver Assistance systems from operating.
- If a trailer, carrier, etc., is installed, it may adversely affect the performance of detecting sensor or Forward Collision-Avoidance Assist may not operate.

#### Forward Collision-Avoidance Assist Settings

#### Forward Safety



OCN7073151L

With the engine on, select **Setup** > **Vehicle** > **Driver Assistance** > **Driving Safety** from the settings menu in the infotainment system to set whether to use each function.

If Forward Safety is selected, Forward Collision-Avoidance Assist will warn you with a warning message and an audible warning depending on the collision risk levels. Braking assist will be applied depending on the collision risk levels.

 If Forward Safety is deselected, Forward Safety will turn off. The warning light ★ will illuminate on the instrument cluster.

The driver can monitor Forward Collision-Avoidance Assist ON/OFF status from the Settings menu. If the swarning light remains ON when Forward Collision-Avoidance Assist is ON, have the vehicle inspected by an authorized HYUNDAI dealer.

## **MARNING**

When the engine is restarted, Forward Collision-Avoidance Assist will always turn on. However, if 'Forward Safety' is deselected, the driver should always be aware of the surroundings and drive safely.

#### Forward Safety warning timing



With the engine on, select Setup > Vehicle > Driver Assistance > Driving Safety > Forward Safety Warning Timing settings menu in the infotainment system to change the initial warning activation time for Forward Collision-Avoidance Assist. The warning time can be set to either Standard or Late.

- Use Standard in normal driving conditions. If the Warning Timing seems sensitive, change it to Late.
- If Late is selected, Forward Collision-Avoidance Assist warns the driver more slowly.



#### **↑** CAUTION

- Even though 'Standard' is selected for Warning Timing, if the front vehicle suddenly stops, the warning may seem late.
- Select 'Late' for Warning Timing when traffic is light and when driving speed is slow.



#### Information

When the engine is restarted, the Warning Timing maintains its last setting.

#### Warning methods



OCN7073153L

The Warning Methods can be set with the engine on. Select **Setup** > **Vehicle** > **Driver Assistance** > **Warning Methods** from the settings menu in the infotainment system to change the following settings:

- Warning Volume: Adjusts the volume of the warning sound.
- Driving Safety Priority: Lowers all other audio volumes when the Driving Safety system sounds a warning.

## *i* Information

- If you change the Warning Methods, it can be applied to each function of the driver assistance system. Please check and change it in each function.
- If the vehicle is restarted, Warning Methods will maintain the last setting.
- The setting menu may not exist based on vehicle specification.

# Forward Collision-Avoidance Assist Operation

#### Warning and control

The basic function for Forward Collision-Avoidance Assist is to warn and help control the vehicle depending on the collision risk level:

- · Collision Warning
- · Emergency Braking
- Stopping vehicle and ending brake control



OCN7N071014L

#### **Collision Warning**

To warn the driver of a collision, Forward Safety waring light ♣ blinking, the 'Collision Warning' warning message will appear on the instrument cluster, an audible warning will sound.

- If a vehicle or powered two-wheeler is detected in front, the function will operate when your vehicle speed is about 6~112 mph (10~180 km/h).
- If a pedestrian or cyclist is detected in front, the function will operate when your vehicle speed is about 6~50 mph (10~80 km/h).



OCN7N071015L

#### **Emergency Braking**

To warn the driver that emergency braking will be assisted, Forward Safety waring light  $\stackrel{*}{\sim}$  blinking, the 'Emergency Braking' warning message will appear on the instrument cluster, an audible warning will sound.

In emergency braking situation, braking is assisted with strong braking power by the function to help prevent collision with the vehicle, powered two-wheeler, pedestrian or cyclist ahead.

- If a vehicle or powered two-wheeler is detected in front, the function will operate when your vehicle speed is about 6~37 mph (10~60 km/h).
- If a pedestrian or cyclist is detected in front, the function will operate when your vehicle speed is about 6~37 mph (10~60 km/h).



#### **CAUTION**

The function operation range may decrease due to the front traffic condition or the surroundings of the vehicle.



OCN7N071017L

Stopping vehicle and ending brake control

- When the vehicle is stopped due to emergency braking, the 'Drive carefully' warning message will appear on the instrument cluster.
   For your safety, the driver should depress the brake pedal immediately and check the surroundings.
- Brake control will end after the vehicle is stopped by emergency braking for about 2 seconds

## **MARNING**

Take the following precautions when using Forward Collision-Avoidance Assist:

- For your safety, only change the Settings after parking the vehicle at a safe location.
- The driver should hold the responsibility to control the vehicle. Do not solely depend on Forward Collision-Avoidance Assist. Rather, maintain a safe braking distance, and if necessary, depress the brake pedal to reduce driving speed or to stop the vehicle.
- Forward Collision-Avoidance Assist does not operate in all situations or cannot avoid all collisions.
- Depending on the road and driving conditions, Forward Collision-Avoidance Assist may warn the driver late or may not warn the driver.
- Never deliberately operate Forward Collision-Avoidance Assist on people, objects, etc. It may cause serious injury or death.
- Forward Collision-Avoidance
   Assist may not operate if the driver depresses the brake pedal to avoid collision.
- During Forward Collision-Avoidance Assist operation, the vehicle may stop suddenly injuring passengers and shifting loose objects. Always have the seat belt on and keep loose objects secured.
- If any other function's warning message is displayed or audible warning is generated, Forward Collision-Avoidance Assist warning message may not be displayed and audible warning may not be generated.

- You may not hear the warning sound of Forward Collision-Avoidance Assist if the surrounding is noisy.
- Even if there is a problem with Forward Collision-Avoidance Assist, the vehicle's basic braking performance will operate properly.
- During emergency braking, braking control by Forward Collision-Avoidance Assist will automatically cancel when the driver excessively depresses the accelerator pedal or sharply steers the vehicle.

## $\triangle$

#### ↑ CAUTION

- Depending on the condition of the vehicle, powered two-wheeler, pedestrian and cyclist in front and the surroundings, the speed range to operate Forward Collision-Avoidance Assist may reduce. Forward Collision Avoidance Assist may only warn the driver, or it may not operate.
- Forward Collision-Avoidance Assist will operate under certain conditions by judging the risk level based on the condition of the oncoming vehicle, driving direction, speed and surroundings.
- Forward Collision-Avoidance Assist may be limited or disabled if the vehicle speed is too high or the distance to the vehicle ahead is far.

## i

### *i* Information

- In a situation collision is imminent, braking may be assisted by Forward Collision-Avoidance Assist when braking is insufficient by the driver.
- The images and colors in the instrument cluster may differ depending on the cluster type or theme selected from the instrument cluster.

#### Forward Collision-Avoidance **Assist Malfunction and** Limitations

#### Forward Collision-Avoidance Assist malfunction



When Forward Collision-Avoidance Assist is not working properly, the 'Check Forward Safety systems' warning message will appear, and the / \( \) and \( \frac{\sqrt{\text{\tint{\text{\tin}\text{\te}\text{\texi}\text{\text{\text{\text{\texi}\text{\text{\text{\text{\text{\texi}\text{\text{\text{\texi}\text{\text{\texi}\tint{\text{\t lights will illuminate on the instrument cluster. Have the vehicle inspected by an authorized HYUNDAI dealer.

#### Forward Collision-Avoidance Assist disabled



OTM070093N

When the front windshield where the front view camera is located, sensor is covered with foreign material, such as snow or rain, it can reduce the detecting performance and temporarily limit or disable Forward Collision-Avoidance ∆ssist

If this occurs the 'Forward safety system' disabled. Camera obscured' warning message, and the A and the warning lights will illuminate on the instrument cluster.

Forward Collision-Avoidance Assist will operate properly when snow, rain or foreign matter is removed.

If Forward Collision-Avoidance Assist does not operate properly after it is removed, have the vehicle inspected by an authorized HYUNDAI dealer.

## **WARNING**

- Even though the warning message or warning light does not appear on the instrument cluster, Forward Collision-Avoidance Assist may not properly operate.
- Forward Collision-Avoidance Assist may not properly operate in an area (for example, open terrain), where any objects are not detected after turning ON the engine.
- If the vehicle is turned off and restarted while the camera is blocked or malfunctioned, the condition is maintained. Therefore, Forward Collision-Avoidance Assist may not operate properly.

#### Limitations of the Forward Collision-Avoidance Assist

Forward Collision-Avoidance Assist may not operate properly, or it may operate unexpectedly under the following circumstances:

- The detecting sensor or the surroundings are contaminated or damaged
- The temperature around the front view camera is high or low
- The camera lens is contaminated due to tinted, filmed or coated windshield, damaged glass, or stuck of foreign material (sticker, bug, etc.) on the glass
- Moisture is not removed or frozen on the windshield
- Washer fluid is continuously sprayed, or the wiper is on
- Driving in heavy rain or snow, or thick fog
- The field of view of the front view camera is obstructed by sun glare
- Street light or light from an oncoming vehicle is reflected on the wet road surface, such as a puddle on the road
- An object is placed on the dashboard

- · Your vehicle is being towed
- The surrounding is very bright
- The surrounding is very dark, such as in a tunnel, etc.
- The brightness changes suddenly, for example when entering or exiting a tunnel
- The brightness outside is low, and the headlights are not on or are not bright
- Only part of the vehicle, powered two-wheeler, pedestrian or cyclist is detected
- The vehicle in front is a bus, heavy truck, truck with an unusually shaped cargo, trailer, etc.
- The vehicle or powered two-wheeler in front has no tail lights, tail lights are located unusually, etc.
- The brightness outside is low, and the tail lamps of the front vehicle are turned off or are not bright.
- The rear of the front vehicle is small or the vehicle does not look normal, such as when the vehicle is tilted, overturned, or the side of the vehicle is visible, etc.
- The front vehicle's ground clearance is low or high
- A vehicle, powered two-wheeler, pedestrian or cyclist suddenly cuts in front
- The vehicle or powered two-wheeler in front is detected late
- The vehicle or powered two-wheeler in front is suddenly blocked by an obstacle
- The vehicle or powered two-wheeler in front suddenly changes lane or suddenly reduces speed
- The vehicle or powered two-wheeler in front is bent out of shape
- The vehicle in front is covered with snow

- You are departing or returning to the lane
- · Unstable driving
- You are on a roundabout and the vehicle in front is not detected
- · You are continuously driving in a circle
- The vehicle or powered two-wheeler in front has an unusual shape
- The vehicle or powered two-wheeler in front is driving uphill or downhill
- The pedestrian or cyclist in front is not fully detected, for example, if the pedestrian is leaning over or is not fully walking upright
- The pedestrian or cyclist in front is wearing clothing or equipment that makes it difficult to detect




The illustration above shows the image the front view camera will detect as a vehicle, a powered two-wheeler, a pedestrian or a cyclist.

- The pedestrian or cyclist in front is moving very quickly
- The pedestrian or cyclist in front is short or is posing a low posture
- The pedestrian or cyclist in front is moving intersected with the driving direction
- There is a group of pedestrians, cyclists or a large crowd in front
- The pedestrian or cyclist in front is wearing clothing that easily blends into the background, making it difficult to detect

- You are driving by a pedestrian, cyclist, traffic sign, structure, etc. near the intersection
- · When driving in the following places
  - Driving through steam, smoke or shadow
  - Driving through a tunnel or iron bridge
  - Driving in vast areas where there are few vehicles or structures (for example, desert, meadow, suburb, etc.)
  - Driving in a parking lot
  - Driving through a tollgate, construction area, unpaved road, partial paved road, uneven road, speed bumps, etc.
  - Driving near areas containing metal substances, such as a construction zone, railroad, etc.
  - Driving on an incline road, curved road, etc.
  - Driving through a roadside with trees or streetlights
  - Driving through a narrow road where trees or grass are overgrown
  - There is interference by electromagnetic waves, such as driving in an area with strong radio waves or electrical poise
- When the vehicle moves unstable or shakes violently
- When the height of the vehicle changes significantly due to abnormal tire pressure or overloading of the cargo compartment
- The vehicle is installed with a snow chain, spare tire or different size wheel.


# **MARNING**

· Driving on a curved road



Forward Collision-Avoidance Assist may not detect other vehicles, powered two-wheelers, pedestrians or cyclists in front of you on curved roads that adversely affect the performance of the sensors. This may result in no warning or braking assist when necessary.

When driving on a curve, you must maintain a safe braking distance, and if necessary, steer your vehicle and depress the brake pedal to reduce your driving speed in order to maintain a safe distance.



Forward Collision-Avoidance Assist may detect a vehicle, a powered two-wheeler, a pedestrian or a cyclist in the next lane or outside the lane when driving on a curved road. If this occurs, Forward Collision-Avoidance Assist may unnecessarily warn the driver and control the brake. Always check the traffic conditions around the vehicle.

#### · Driving on an inclined road



Forward Collision-Avoidance Assist may not detect a vehicle, a powered two-wheeler, a pedestrian or a cyclist in front of you while driving uphill or downhill adversely affecting the performance of the sensors.

This may result in unnecessary warning or braking assist, or no warning or braking assist when necessary.

Also, vehicle speed may rapidly decrease when a vehicle, a powered two-wheeler, a pedestrian or a cyclist ahead is suddenly detected.

Always have your eyes on the road while driving uphill or downhill and if necessary, steer your vehicle and depress the brake pedal to reduce your driving speed in order to maintain a safe distance.

#### · Changing lanes



[A]: Your vehicle,

[B]: Lane changing vehicle

When a vehicle moves into your lane from an adjacent lane, it cannot be detected by the sensor until it is in the sensor's detection range. Forward Collision-Avoidance Assist may not immediately detect the vehicle when the vehicle changes lanes abruptly. In this case, you must maintain a safe braking distance, and if necessary, steer your vehicle and depress the brake pedal to reduce your driving speed in order to maintain a safe distance.



[A]: Your vehicle,


[B]: Lane changing vehicle,

[C]: Same lane vehicle

When a vehicle in front of you merges out of the lane, Forward Collision-Avoidance Assist may not immediately detect the vehicle that is now in front of you.

In this case, you must maintain a safe braking distance, and if necessary, steer your vehicle and depress the brake pedal to reduce your driving speed in order to maintain a safe distance.

#### · Detecting vehicle



If the vehicle in front of you has cargo that extends rearward from the cab, or when the vehicle in front of you has higher ground clearance, additional special attention is required. Forward Collision-Avoidance Assist may not be able to detect the cargo extending from the vehicle. In these instances, you must maintain a safe braking distance from the rearmost object, and if necessary, steer your vehicle and depress the brake pedal to reduce your driving speed in order to maintain distance.

## **MARNING**

- When you are towing a trailer or another vehicle, turn off Forward Collision-Avoidance Assist for safety reasons.
- Forward Collision-Avoidance Assist may operate if objects that are similar in shape or characteristics to vehicles, powered two-wheelers, pedestrians or cyclists are detected.
- Forward Collision-Avoidance Assist does not operate on bicycles, motorcycles, or smaller wheeled objects, such as luggage bags, shopping carts, or strollers.
- Forward Collision-Avoidance
   Assist may not operate properly if interfered by strong electromagnetic waves.
- Forward Collision-Avoidance Assist may not operate for 15 seconds after the vehicle is started, or the front view camera is initialized.

#### LANE KEEPING ASSIST (LKA)

While driving over a certain speed, Lane Keeping Assist detects lane markings (or road edges) and may warn you if your vehicle leaves the lane without using the turn signal and may assist with steering to prevent your vehicle departing from its travel lane

#### **Detecting sensor**



[1]: Front view camera

The front view camera is used as a detecting sensor to detect lane markings (or road edges).

Refer to the illustration above for the detailed location of the detecting sensor.



#### **CAUTION**

For more information on the precautions of the front view camera. refer to "Forward Collision-Avoidance Assist (FCA)" section in this chapter.

#### **Lane Keeping Assist Settings** Lane Safety



OCN70731591

With the engine on, select Setup > Vehicle > Driver Assistance > Driving Safety > Lane Safety from the settings menu in the infotainment system to set whether to use each function.

If Lane safety is selected. Lane Keeping Assist will automatically assist the driver's steering when lane departure is detected to help prevent the vehicle from moving out of its lane. If Lane safety is deselected, Lane Keeping Assist turns off and the / indicator light turns off on the instrument cluster.



#### **WARNING**


- Lane Keeping Assist does not control the steering wheel when the vehicle is driven in the middle of the lane.
- The driver should always be aware of the surroundings. If 'Lane Safety' is deselected, Lane Keeping Assist cannot assist you.



## Information

When Lane Keeping Assist is turned off with the Lane Driving Assist button, Lane Safety settings will turn off.

### Warning Methods



OCN7073153L

The Warning Methods can be set with the engine on, Select Setup > Vehicle > Driver Assistance > Warning Methods from the settings menu in the infotainment system to change the following settings:

- Warning Volume: Adjusts the volume of the warning sound.
- **Driving Safety Priority**: Lowers all other audio volumes when the Driving Safety system sounds a warning.

### Information

- If you change the Warning Methods, it can be applied to each function of the driver assistance system. Please check and change it in each function.
- · If the vehicle is restarted, Warning Methods will maintain the last setting.
- The setting menu may not exist based on vehicle specification.

### **Lane Keeping Assist Operation** Turning Lane Keeping Assist ON/OFF



OCN7N073137N

With the vehicle on, press and hold the Lane Driving Assist 🔊 button located on the steering wheel to turn on and off. When Lane Keeping Assist is on, the grey or green / indicator is on.

## Information

- · When the engine is restarted, Lane Keeping Assist maintains its last setting.
- When Lane Keeping Assist is ready to operate, the grey (/ indicator is on.
- When Lane Keeping Assist is enabled, the green ( ) indicator is on.

### Warning and control

Lane Keeping Assist will warn and help control the vehicle with Lane Keeping Assist.

#### **Lane Departure Warning**

- To warn the driver that the vehicle is departing from the projected lane in front, the green (/ ) indicator light will blink on the instrument cluster, the lane line will blink on the instrument cluster depending on which direction the vehicle is veering. and an audible warning will sound.
- Lane Departure Warning will operate when your vehicle speed is about 40~120 mph (60~200 km/h).

### Lane Keeping Assist

- To warn the driver that the vehicle is departing from the projected lane in front, the green / indicator light will blink on the instrument cluster, and the steering wheel will make adjustments to keep vehicle inside the lane.
- Lane Keeping Assist will operate when your vehicle speed is about 40~120 mph (60~200 km/h).



OCN7N071095L

### Hands-off warning

If the driver takes their hands off the steering wheel for several seconds. the 'Keep hands on the steering wheel' warning message will appear on the instrument cluster, and an audible warning will sound in stages.



### WARNING

- The steering wheel may not be assisted if the steering wheel is held very tight or the steering wheel is steered over a certain degree.
- Lane Keeping Assist does not operate at all times. It is the responsibility of the driver to safely steer the vehicle and to maintain the vehicle in its lane.
- · The hands-off warning message may appear late depending on road conditions. Always have your hands on the steering wheel while driving.
- If the steering wheel is held very lightly, the hands-off warning message may appear because Lane Keeping Assist may not recognize that the driver has their hands on the steering wheel.
- · If you attach objects to the steering wheel, the hands-off warning may not work properly.

### *i* Information

- The status of the Lane Keeping Assist operation appears in Driving Assist mode on the instrument cluster. Refer to the "View modes" section in chapter 4.
- When lane markings (or road edges) are detected, the lane lines on the instrument cluster will change from grey to white and the green /=\ indicator light will illuminate.





OCN7N071023

■ Lane detected



OCN7N071022

- The images and colors in the instrument cluster may differ depending on the cluster type or theme selected from the instrument cluster.
- Even though the steering is assisted by Lane Keeping Assist, the driver may control the steering wheel.
- The steering wheel may feel heavier or lighter when the steering wheel is assisted by Lane Keeping Assist than when it is not.

## Lane Keeping Assist Malfunction and Limitations


### Lane Keeping Assist malfunction



B0317FU02

When Lane Keeping Assist is not working properly, the 'Check Lane Safety system' warning message will appear and the yellow indicator light will illuminate on the instrument cluster. If this occurs, have the vehicle inspected by an authorized HYUNDAI dealer.

#### Lane Keeping Assist disabled



OBC3073264E

When the front windshield where the front view camera is located, or sensor is covered with foreign material, such as snow or rain, it can reduce the detecting performance and temporarily limit or disable Lane Keeping Assist.

If this occurs, the 'Lane Safety system disabled. Camera obscured' warning message and master (1) light or Lane Keeping Assist warning light (1) will appear on the instrument cluster.

Lane Keeping Assist will operate properly when snow, rain or foreign material is removed.

If Lane Keeping Assist does not operate properly after it is removed, have the vehicle inspected by an authorized HYUNDAI dealer.

### A

### WARNING

- Even though the warning message or warning light does not appear on the instrument cluster, Lane Keeping Assist may not properly operate.
- If the vehicle is turned off and restarted while the camera is blocked or malfunctioned, the condition is maintained. Therefore, Lane Keeping Assist may not operate properly.

#### Limitations of Lane Keeping Assist

Lane Keeping Assist may not operate properly or may operate unexpectedly under the following circumstances:

- The lane is contaminated or difficult to detect because:
  - The lane markings (or road edge) is covered with rain, snow, dirt, oil, etc.
  - The color of the lane marking (or road edge) is not distinguishable from the road
  - There are markings (or road edges) on the road near the lane or the markings (or road edges) on the road looks similar to the lane markings (or road edge)
  - The lane marking (or road edge) is indistinct or damaged
  - The shadow is on the lane marking (or road edge) by a median strip, trees, quardrail, noise barriers, etc.
- There are more than two lane markings (or road edges) on the road
- The number of lanes change or the lanes merge
- The lane markings (or road edges) are complicated or a structure substitutes for the lines, such as a construction area
- There are road markings, such as zigzag lanes, crosswalk markings and road signs
- The lane suddenly disappears, such as at the intersection
- The lane (or road width) is very wide or narrow
- There is a road edge without a lane
- There is a boundary structure in the roadway, such as a tollgate, sidewalk, curb, etc.
- The distance to the front vehicle is extremely short or the vehicle in front is covering the lane marking (or road edge)

### *i* Information

For more information on the limitations of the front view camera, refer to "Forward Collision-Avoidance Assist (FCA)" section in this chapter.

### **MARNING**

Take the following precautions when using Lane Keeping Assist:


- The driver has the responsibility to safely drive and control the vehicle.
   Do not solely rely on Lane Keeping Assist and drive dangerously.
- The operation of Lane Keeping Assist can be cancelled or not work properly depending on road conditions and surroundings. Always be cautious while driving.
- Refer to "Limitations of Lane Keeping Assist" if the lane is not detected properly.
- When you are towing a trailer or another vehicle, we recommend that Lane Keeping Assist is turned off due to safety reasons.
- If the vehicle is driven at high speed, the steering wheel will not be controlled. The driver must always follow the speed limit when using Lane Keeping Assist.
- If any other function's warning message is displayed or audible warning is generated, Lane Keeping Assist warning message may not be displayed and audible warning may not be generated.

- You may not hear the warning sound of Lane Keeping Assist if the surrounding is noisy.
- If you attach objects to the steering wheel, steering may not be assisted properly.
- Lane Keeping Assist may not operate for 15 seconds after the vehicle is started, or the front view camera is initialized.
- Lane Keeping Assist will not operate when:
  - The turn signal or hazard warning flasher is turned on
  - The vehicle is not driven in the center of the lane when Lane Keeping Assist is turned on or right after changing a lane
  - ESC (Electronic Stability Control) or VSM (Vehicle Stability Management) is activated
  - The vehicle is driven on a sharp curve
  - Vehicle speed is below 35 mph (55 km/h) or above 130 mph (210 km/h)
  - The vehicle makes sudden lane changes
  - The vehicle brakes suddenly
- Loading in excess of the maximum load allowance or concentrated loading at one point in the cargo compartment can reduce the vehicle's driving stability, which can in turn reduce the effectiveness of Lane Keeping Assist.

### **BLIND-SPOT COLLISION-AVOIDANCE ASSIST (BCA) (IF EQUIPPED**)

Blind-Spot Collision-Avoidance Assist helps detect approaching vehicles in the driver's blind spot areas and warn you of a possible collision with a warning light and a warning sound.

If there is a collision risk when exiting a parallel space, Blind-Spot Collision-Avoidance Assist may assist with braking your vehicle to help avoid a collision.



Blind-Spot Collision-Avoidance Assist helps detect and inform the driver that a vehicle is in the blind spot.



### **CAUTION**

The detecting range may vary depending on the speed of your vehicle. Even if there is a vehicle in the blind spot area, Blind-Spot Collision-Avoidance Assist may not warn you when you pass by at high speeds.




Blind-Spot Collision-Avoidance Assist helps detect and inform the driver that a vehicle is approaching at high speed from the blind spot area.



### **↑** CAUTION

Warning timing may vary depending on the speed of the vehicle approaching at high speed.



When you are driving forward out of a parking space, if Blind-Spot Collision-Avoidance Assist judges that there is a collision risk with an approaching vehicle in the blind spot, Blind-Spot Collision-Avoidance Assist will help avoid collision by applying the brake.

### **Detecting sensor**



[1]: Rear corner radar

Refer to the illustration above for the detailed location of the detecting sensors.

### **!** CAUTION

Take the following precautions to maintain optimal performance of the detecting sensor:

- Never disassemble the rear corner radar or radar assembly, or cause any damage to it.
- If the rear corner radar or near the radar has been damaged or impacted in any way, even though the warning message does not appear on the instrument cluster, Blind-Spot Collision-Avoidance Assist may not operate properly. Have the vehicle inspected by an authorized HYUNDAI dealer.
- If the rear corner radars have been replaced or repaired, have the vehicle inspected by an authorized HYUNDAI dealer.
- **Blind-Spot Collision-Avoidance** Assist may not work properly if the bumper has been replaced, or the surroundings of the rear corner radar have been damaged or paint has been applied.

- Use only genuine parts to repair the rear bumper where the rear corner radar is located.
- Do not apply license plate frame or objects, such as a bumper sticker. film or a bumper guard near the rear corner radar.
- If a trailer, carrier, etc., is installed, it may adversely affect the performance of the rear corner radar or Blind-Spot Collision-Avoidance Assist may not operate.

### **Blind-Spot Collision-Avoidance Assist Settings**

Blind-Spot Safety



With the engine on, select Setup > Vehicle > Driver Assistance > Driving Safety > Blind-Spot Safety from the settings menu in the infotainment system. to set whether to use each function.

· If Blind-Spot Safety is selected, Blind-Spot Collision-Avoidance Assist will warn the driver with a warning message, an audible warning depending on the collision risk levels. Braking assist will be applied for parking exit depending on the collision risk levels



OTM070097N

When the engine is restarted with Blind-Spot Collision-Avoidance Assist off. the 'Blind-Spot Safety System is Off' message will appear on the instrument cluster.

If you select **Blind-spot safety**, warning light on the side view mirror will blink for three seconds. In addition, if the vehicle is turned on, when Blind-Spot Safety is selected, the warning light on the side view mirror will blink for three seconds.



### WARNING

The driver should always be aware of the surroundings and drive safely. If 'Blind-Spot Safety' is deselected, Blind-Spot Collision-Avoidance Assist cannot assist you.



### Information

If the engine is restarted, Blind-Spot Collision-Avoidance Assist will maintain the last setting.

### Warning Methods



OCN7073153L

The Warning Methods can be set with the engine on. Select **Setup** > **Vehicle** > **Driver Assistance** > **Warning Methods** from the settings menu in the infotainment system to change the following settings:

- Warning Volume: Adjusts the volume of the warning sound.
- Driving Safety Priority: Lowers all other audio volumes when the Driving Safety system sounds a warning.

### *i* Information

- If you change the Warning Methods, it can be applied to each function of the driver assistance system. Please check and change it in each function.
- If the vehicle is restarted, Warning Methods will maintain the last setting.
- The setting menu may not exist based on vehicle specification.

### Blind-Spot Collision-Avoidance Assist Operation

Blind-Spot Collision-Avoidance Assist warns and control you by the following actions:

- Collision warning
- Collision-Avoidance Assist

### **Collision-Warning**



To warn the driver a vehicle is detected, the warning light on the side view mirror will illuminate.

 Vehicle detection warning will operate when your vehicle speed is above 12 mph (20 km/h) and the speed of the vehicle in the blind spot area is above 6 mph (10 km/h).

Collision warning will operate when the turn signal is turned on in the direction of the detected vehicle.

- To warn the driver of a collision, the warning light on the side view mirror will illuminate, an audible warning may sound and the steering wheel will vibrate.
- When the turn signal is turned off, the collision warning will be canceled and Blind-Spot Collision-Avoidance Assist will return to vehicle detection state.

Collision warning may warn you under the following conditions:

- Your vehicle speed is above 25 mph (40 km/h).
- The speed of the vehicle in your blind spot area is above 6 mph (10 km/h).

### **MARNING**

- The detecting range of the rear corner radar is determined by a standard road width, therefore, on a narrow road, Blind-Spot Collision-Avoidance Assist may detect other vehicles two lanes over and warn you. In contrast, on a wide road, Blind-Spot Collision-Avoidance Assist may not be able to detect a vehicle driving in the next lane and may not warn you.
- When the hazard warning flasher is on, the collision warning by the turn signal will not operate.

## *i* Information

The images and colors in the instrument cluster may differ depending on the cluster type or theme selected from the instrument cluster.

## Collision-avoidance assist (while parallel parking exit)



- To warn the driver of a collision, the warning light on the side view mirror will blink and a warning message will appear on the instrument cluster. At the same time, an audible warning will sound.
- Emergency braking will be assisted to help prevent collision with the vehicle in the blind spot area.
- Blind-Spot Collision-Avoidance Assist will operate when your vehicle speed is below 2 mph (3 km/h) and the speed of the vehicle in the blind spot area is above 3 mph (5 km/h).



OCN7N071017L

- When the vehicle is stopped due to emergency braking, the 'Drive carefully' warning message will appear on the instrument cluster.
   For your safety, the driver should depress the brake pedal immediately and check the surroundings.
- Brake control will end after the vehicle is stopped by emergency braking for about 2 seconds.



### WARNING

Take the following precautions when using Blind-Spot Collision-Avoidance Assist:

- For your safety, only change the Settings after parking the vehicle at a safe location.
- If any other system's warning message is displayed or audible warning is generated, Blind-Spot Collision-Avoidance Assist's warning message may not be displayed and audible warning may not be generated.
- You may not hear the warning sound of Blind-Spot Collision-Avoidance Assist if the surrounding is noisy.
- Blind-Spot Collision-Avoidance
   Assist may not operate if the driver applies the brake pedal to avoid collision.
- When Blind-Spot Collision-Avoidance Assist is operating, braking control by the function will automatically cancel when the driver excessively depresses the accelerator pedal or sharply steers the vehicle.
- During Blind-Spot Collision-Avoidance Assist operation, the vehicle may stop suddenly injuring passengers and shifting loose objects. Always have the seat belt on and keep loose objects secured.
- Even if there is a problem with Blind-Spot Collision-Avoidance Assist, the vehicle's basic braking performance will operate properly.

- Blind-Spot Collision-Avoidance Assist does not operate in all situations or cannot avoid all collisions.
- Blind-Spot Collision-Avoidance
   Assist may warn the driver late or may not warn the driver depending on the road and driving conditions.
- Driver should maintain control of the vehicle at all times. Do not depend on Blind-Spot Collision-Avoidance Assist. Maintain a safe braking distance, and if necessary, depress the brake pedal to reduce driving speed or to stop the vehicle.
- Never operate Blind-Spot Collision-Avoidance Assist on people, animal, objects, etc. It may cause serious injury or death.

### **MARNING**

The brake control may not operate properly depending on the status of ESC (Electronic Stability Control).

There will only be a warning when:

- The ESC (Electronic Stability Control) warning light is on
- ESC (Electronic Stability Control) is engaged in a different function


### Blind-Spot Collision-Avoidance Assist Malfunction and Limitations

Blind-Spot Collision-Avoidance Assist malfunction



B0322EU01


When Blind-Spot Collision-Avoidance Assist is not working properly, the 'Check Blind-Spot Safety system' warning message will appear on the instrument cluster for several seconds, and the master ((\(\frac{\Lambda}{\Lambda}\)) warning light will illuminate on the instrument cluster. If this occurs, have the vehicle inspected by an authorized HYUNDAI dealer.



B0322EU02

When the side view mirror warning light is not working properly, the 'Check side view mirror warning light' warning message will appear on the instrument cluster for several seconds, and the master (A) warning light will illuminate on the instrument cluster. If this occurs, have the vehicle inspected by an authorized HYUNDAI dealer.

### Blind-Spot Collision-Avoidance Assist disabled



OCN7N071098L

When the rear bumper around the rear corner radar or sensor is covered with foreign material, such as snow or rain, or installing a trailer or carrier, it can reduce the detecting performance and temporarily limit or disable Blind-Spot Collision-Avoidance Assist.

If this occurs, the 'Blind-Spot Safety system disabled. Radar blocked' warning message will appear on the instrument cluster.

Blind-Spot Collision-Avoidance Assist will operate properly when such foreign material or trailer, etc., is removed, and then the engine is restarted.

If Blind-Spot Collision-Avoidance Assist does not operate properly after it is removed, have the vehicle inspected by an authorized HYUNDAI dealer.

### **WARNING**

- Even though the warning message does not appear on the instrument cluster, Blind-Spot Collision-Avoidance Assist may not properly operate.
- Blind-Spot Collision-Avoidance
   Assist may not properly operate in
   an area (for example, open terrain)
   where any objects are not detected
   right after the engine is turned on, or
   when the detecting sensor is blocked
   with foreign material right after the
   engine is turned on.



Turn off Blind-Spot Collision-Avoidance Assist to install or remove a trailer, carrier, or another attachment. Turn on Blind-Spot Collision-Avoidance Assist when finished.

#### Limitations of Blind-Spot Collision-Avoidance Assist

Blind-Spot Collision-Avoidance Assist may not operate properly, or it may operate unexpectedly under the following circumstances:

- There is inclement weather, such as heavy snow, heavy rain, etc.
- The rear corner radar is covered with snow, rain, dirt, etc.
- The temperature around the rear corner radar is high or low
- Driving on a highway (or motorway) ramp
- The road pavement (or the peripheral ground) abnormally contains metallic components (for example, possibly due to subway construction)
- There is a fixed object near the vehicle, such as sound barriers, guardrails, central dividers, entry barriers, street lamps, signs, tunnels, walls, etc. (including double structures)
- Driving through a narrow road where trees or grass are overgrown
- Driving in vast areas where there are few vehicles or structures (for example, desert, meadow, suburb, etc.)
- Driving on a wet road surface, such as a puddle on the road
- The other vehicle drives very close behind your vehicle, or the other vehicle passes by your vehicle in close proximity

- The speed of the other vehicle is very fast that it passes by your vehicle in a short time
- Your vehicle passes by the other vehicle
- · Your vehicle changes lane
- Your vehicle has started at the same time as the vehicle next to you and has accelerated
- The vehicle in the next lane moves two lanes away from you, or when the vehicle two lanes away moves to the next lane from you
- A trailer, carrier or other attachment is installed around the rear corner radar
- The bumper around the rear corner radar is covered with objects, such as a bumper sticker, bumper guard, bike rack, etc.
- The bumper around the rear corner radar is impacted, damaged or the radar is out of position
- Your vehicle height is low or high due to heavy loads, abnormal tire pressure, etc.

Blind-Spot Collision-Avoidance Assist may not operate properly, or it may operate unexpectedly when the following objects are detected:

- A motorcycle or bicycle is detected
- A vehicle such as a flat trailer is detected
- A big vehicle such as a bus or truck is detected
- A moving obstacle such as a pedestrian, animal, shopping cart or a baby stroller is detected
- A vehicle with low height such as a sports car is detected

Braking control may not work, driver's attention is required in the following circumstances:

- The vehicle severely vibrates while driving over a bumpy road, uneven road or concrete patch
- Driving on a slippery surface due to snow, water puddle, ice, etc.
- The tire pressure is low or a tire is damaged
- · The brake is tuned
- The vehicle makes abrupt lane changes

## **MARNING**

Driving on a curved road




Blind-Spot Collision-Avoidance Assist may not operate properly when driving on a curved road. Blind-Spot Collision-Avoidance Assist may not detect the vehicle in the next lane. Always pay attention to road and driving conditions while driving.



Blind-Spot Collision-Avoidance Assist may not operate properly when driving on a curved road. Blind-Spot Collision-Avoidance Assist may recognize a vehicle in the same lane.

Always pay attention to road and driving conditions while driving.


· Driving on an inclined road



Blind-Spot Collision-Avoidance Assist may not operate properly when driving on a slope. Blind-Spot Collision-Avoidance Assist may not detect the vehicle in the next lane or may incorrectly detect the ground or structure.

Always pay attention to road and driving conditions while driving.


 Driving where the road is merging/ dividing



Blind-Spot Collision-Avoidance Assist may not operate properly when driving where the road merges or divides. Blind-Spot Collision-Avoidance Assist may not detect the vehicle in the next lane.

Always pay attention to road and driving conditions while driving.

 Driving where the heights of the lanes are different



Blind-Spot Collision-Avoidance Assist may not operate properly when driving where the heights of the lanes are different. Blind-Spot Collision-Avoidance Assist may not detect the vehicle on a road with different lane heights (underpass joining section, grade separated intersections, etc.).

Always pay attention to road and driving conditions while driving.

### **WARNING**

- When you are towing a trailer or another vehicle, make sure that you turn off Blind-Spot Collision-Avoidance Assist.
- Blind-Spot Collision-Avoidance
   Assist may not operate properly if interfered by strong electromagnetic waves.
- Blind-Spot Collision-Avoidance
   Assist may not operate for 3 seconds after the vehicle is started, rear corner radars are initialized.

### *i* Information

This device complies with Part 15 of the FCC rules.

Operation is subject to the following three conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.
- 3. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

### *i* Information


Radio frequency radiation exposure information:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance of 8 in. (20 cm) between the radiator (antenna) and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

### SAFE EXIT WARNING (SEW) (IF EQUIPPED)



While your vehicle is stopped, and if Safe Exit Warning detects a vehicle approaching the rear corner of your vehicle and a passenger opens a door, Safe Exit Warning may warn you with a warning message and a warning sound to help avoid a collision.



### **CAUTION**

Warning timing may vary depending on the speed of the approaching vehicle.

### **Detecting sensor**



[1]: Rear corner radar

Refer to the illustration above for the detailed location of the detecting sensors.

### NOTICE

For more details on the precautions of the rear corner radars, refer to "Blind-Spot Collision-Avoidance Assist (BCA)" section in this chapter.

### Safe Exit Warning Settings Exit Safety



With the engine on, select Setup > Vehicle > Driver Assistance > Driving Safety > Exit Safety from the Settings menu in the infotainment system to turn on Safe Exit Warning and deselect to turn off the function.



### WARNING

The driver should always be aware that unexpected and sudden situations may occur. If 'Exit Safety' is deselected, Safe Exit Warning cannot assist you.



### Information

If the engine is restarted, Safe Exit Warning will maintain the last setting.

### Warning Methods



OCN7073153L

The Warning Methods can be set with the engine on. Select **Setup** > **Vehicle** > **Driver Assistance** > **Warning Methods** from the settings menu in the infotainment system to change the following settings:

- Warning Volume: Adjusts the volume of the warning sound.
- Driving Safety Priority: Lowers all other audio volumes when the Driving Safety system sounds a warning.

### *i* Information

- If you change the Warning Methods, it can be applied to each function of the driver assistance system. Please check and change it in each function.
- If the vehicle is restarted, Warning Methods will maintain the last setting.
- The setting menu may not exist based on vehicle specification.

## Safe Exit Warning Operation Safe Exit Warning





OCN7073166L

Collision warning when exiting vehicle

- When an approaching vehicle from the rear is detected at the moment a door is opened, the warning light on the side view mirror will blink and the 'Collision Warning' warning message will appear on the instrument cluster, and an audible warning will sound.
- Safe Exit Warning will warn the driver when your vehicle speed is below 2 mph (3 km/h), and the speed of the approaching vehicle from the rear is above 4 mph (6 km/h).

### **MARNING**

Take the following precautions when using Safe Exit Warning:

- For your safety, change the Settings after parking the vehicle at a safe location.
- If any other function's warning message is displayed or audible warning is generated, Safe Exit Warning warning message may not be displayed and audible warning may not be generated.
- You may not hear the warning sound of Safe Exit Warning if the surrounding is noisy.
- Safe Exit Warning does not operate in all situations and cannot prevent all collisions.
- Safe Exit Warning may warn the driver late or may not warn the driver depending on the road and driving conditions. Always check vehicle surroundings.
- The driver and passengers are responsible for accidents that occur while exiting the vehicle. Always check the surroundings before you exit the vehicle.
- Never deliberately operate Safe Exit Warning. Doing so may lead to serious injury or death.

### *i* Information

- After the engine is turned off, Safe Exit Warning operates about for 3 minutes, but turns off immediately if the doors are locked.
- The images and colors in the instrument cluster may differ depending on the instrument cluster type or theme selected from the settings menu.

## Safe Exit Warning Malfunction and Limitations

Safe Exit Warning malfunction



B0322FU01

When Safe Exit Warning is not working properly, the 'Check Blind-Spot Safety system' warning message will appear on the instrument cluster for several seconds, and the master (A) warning light will appear on the instrument cluster. If this occurs, have the vehicle inspected by an authorized HYUNDAI dealer.



B0322EU02

When the side view mirror warning light is not working properly, the 'Check side view mirror warning light' warning message will appear on the instrument cluster for several seconds, and the master (A) warning light will illuminate on the instrument cluster. If this occurs, have the vehicle inspected by an authorized HYUNDAI dealer.

### Safe Exit Warning disabled



OCN7N071098L

When the rear bumper around the rear corner radar or sensor is covered with foreign material, such as snow or rain, or installing a trailer or carrier, it can reduce the detecting performance and temporarily limit or disable Blind-Spot Collision-Avoidance Assist.

If this occurs, the 'Blind-Spot Safety system disabled. Radar blocked' warning message will appear on the instrument cluster.

Safe Exit Warning will operate properly when such foreign material or trailer, etc., is removed, and then the engine is restarted.

If Safe Exit Warning does not operate properly after it is removed, have the vehicle inspected by an authorized HYUNDAI dealer.

### **⚠** WARNING

- Even though the warning message does not appear on the cluster, Safe Exit Warning may not properly operate.
- Safe Exit Warning may not properly operate in an area (for example, open terrain) where any objects are not detected right after the engine is turned on, or when the detecting sensor is blocked with foreign material right after the engine is turned on.



### **CAUTION**

Turn off Safe Exit Warning to install or remove a trailer, carrier, or another attachment. Turn on Safe Exit Warning when finished.

#### Limitations of Safe Exit Warning

Safe Exit Warning may not operate properly, or Safe Exit Warning may operate unexpectedly under the following circumstances:

- Getting off the vehicle where trees or grass are overgrown
- Getting off the vehicle where the road is wet
- The approaching vehicle is very fast or very slow



For more information on the limitations of the rear corner radar, refer to the "Blind-Spot Collision-Avoidance Assist (BCA)" section in this chapter.



### WARNING

- Safe Exit Warning may not operate properly if interfered by strong electromagnetic waves.
- Safe Exit Warning may not operate for 3 seconds after the vehicle is started, or rear corner radars are initialized.
- If the vehicle is turned off and restarted while the rear corner radar is blocked or malfunctioned, the condition is maintained. Therefore, Safe Exit Warning may not operate properly.

### *i* Information

This device complies with Part 15 of the FCC rules.

Operation is subject to the following three conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.
- 3. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

### *i* Information

Radio frequency radiation exposure information:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance of 8 in. (20 cm) between the radiator (antenna) and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

### **MANUAL SPEED LIMIT ASSIST (MSLA)**



[1]: Manual Speed Limit Assist enabled indicator[2]: Set speedYou can set the speed limit when you do

not want to drive over a specific speed. If you drive over the preset speed limit, Manual Speed Limit Assist operates (set speed limit will blink and chime will sound) until the vehicle speed returns

within the speed limit.

# **Manual Speed Limit Assist Settings**

### Warning Methods



The Warning Methods can be set with the engine on. Select Setup > Vehicle > Driver Assistance > Warning Methods from the settings menu in the infotainment system to change the following settings:

• Warning Volume: Adjusts the volume of the warning sound.

## *i* Information

- If you change the Warning Methods, it can be applied to each function of the driver assistance system. Please check and change it in each function.
- If the vehicle is restarted, Warning Methods will maintain the last setting.
- The setting menu may not exist based on vehicle specification.

## Manual Speed Limit Assist Operation

#### Setting speed limit



Press and hold Driving Assist
 (♠) button at the desired speed.
 The Manual Speed Limit Assist
 (♠) LIMIT) indicator will illuminate on
 the instrument cluster.



OCN7N073132N

2. Push the + switch up or - switch down, and release it at the desired speed.

Push the + switch up or - switch down and hold it.

The speed will increase or decrease to the nearest multiple of five (multiple of ten in km/h) at first, and then increase or decrease by 5 mph (10 km/h).



3. The set speed limit will be displayed on the instrument cluster.

If you would like to drive over the preset speed limit, depress the accelerator pedal beyond the pressure point to activate the kickdown function.

The set speed limit will blink and chime will sound until you return the vehicle speed within the speed limit.

### *i* Information

- When the accelerator pedal is not depressed beyond the pressure point, vehicle speed will maintain within the speed limit.
- The maximum setting speed varies depending on the vehicle specifications.
   The set speed cannot be increased beyond the maximum set speed.

#### Temporarily pausing Manual Speed Limit Assist



Press the II S switch to temporarily pause the set speed limit. The set speed limit will turn off but the Manual Speed Limit Assist (© LIMIT) indicator will stay on.

### Resuming Manual Speed Limit Assist



OCN7N073136CN

To resume Manual Speed Limit Assist after the function was paused, operate the +, -, II S switch.

If you push the + switch up or – switch down, vehicle speed will be set to the current speed on the instrument cluster.

If you press the **II 3** switch, vehicle speed will resume to the preset speed.

#### Turning off Manual Speed Limit Assist



Press the Driving Assist ((\*\*)) button to turn Manual Speed Limit Assist off. The Manual Speed Limit Assist ((\*\*)\*LIMIT) indicator will go off.

Always press the Driving Assist (年) button to turn Manual Speed Limit Assist off when not in use.



### WARNING

Take the following precautions when using Manual Speed Limit Assist:

- Always set the vehicle speed under the speed limit in your area.
- Keep Manual Speed Limit Assist off when the function is not in use, to avoid inadvertently setting a speed. Check that the Manual Speed Limit Assist (© LIMIT) indicator is off.
- Manual Speed Limit Assist does not substitute for proper and safe driving. It is the responsibility of the driver to always drive safely and be aware of unexpected and sudden situations. Pay attention to the road conditions at all times.

### **INTELLIGENT SPEED LIMIT ASSIST (ISLA) (IF EQUIPPED)**

Intelligent Speed Limit Assist uses information from detected road signs and the navigation system to inform the driver of the speed limit of the current road, Also, Intelligent Speed Limit Assist helps the driver to remain within the speed limit of the road.

### ! CAUTION

- **Intelligent Speed Limit Assist may** not operate properly if the function is used in other countries.
- If a navigation is applied to your vehicle, the navigation needs to be regularly updated for Intelligent Speed Limit Assist to operate properly.
- The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

### **Detecting sensor**



[1]: Front view camera

Refer to the image above for the detailed location of the detecting sensor.




### CAUTION

For more details on the precautions of the front view camera, refer to "Forward Collision-Avoidance Assist (FCA) (front view camera only)" section in this chapter.

# **Intelligent Speed Limit Assist Settings**

### Speed Limit



OCN707316

With the engine on, select **Setup** > **Vehicle** > **Driver Assistance** > **Speed Limit** from the settings menu in the infotainment system to set whether to use each function.

- Speed Limit Offset: The Speed Limit Offset can be changed. Speed Limit Warning and Speed Limit Assist will operate by applying the Speed Limit Offset setting to the detected speed limit
- Speed Limit Assist: Intelligent Speed Limit Assist will inform the driver of speed limit and additional road signs. In addition, Intelligent Speed Limit Assist will inform the driver to change set speed of Manual Speed Limit Assist to help the driver stay within the speed limit.

- Speed Limit Warning: Intelligent Speed Limit Assist will inform the driver of speed limit. In addition, Intelligent Speed Limit Assist will warn the driver when the vehicle is driven faster than the speed limit.
- Off: Intelligent Speed Limit Assist will turn off.



### **! WARNING**

- For your safety, only change the Settings after parking the vehicle at a safe location.
- Intelligent Speed Limit Assist does not substitute for proper and safe driving. It is the driver's responsibility to always drive safely and be aware of unexpected and sudden situations. Pay attention to the road conditions at all times.

# **Intelligent Speed Limit Assist Operation**

#### Warning and control

Intelligent Speed Limit Assist will warn and control the vehicle by 'Displaying speed limit', 'Warning overspeed' and 'Changing set speed'.

## *i* Information

Intelligent Speed Limit operation is described based on the offset adjusted to "0". For more information on setting the offset, refer to "Intelligent Speed Limit Assist settings" in this section.

### Displaying speed limit



Speed limit information is displayed on the instrument cluster.

## *i* Information


- If speed limit information of the road cannot be recognised, '---' sign will be displayed. Please refer to "Limitations of Intelligent Speed Limit Assist" if the road signs are difficult to recognise.
- Intelligent Speed Limit Assist provides additional road sign information in addition to speed limit. The additional road sign information provided may vary according to your country.
- The images and colours in the instrument cluster may differ depending on the instrument cluster type or theme selected from the instrument cluster.

### Warning overspeed



When driving at a speed higher than the displayed speed limit, the speed limit appears in red.

### Changing set speed



If the speed limit of the road changes during the operation of Manual Speed Limit Assist an arrow in the direction of up or down is displayed to inform the driver that the set speed needs to be changed. At this time, the driver can change the set speed according to the speed limit by using the + or - switch on the steering wheel.

## **Set Speed Auto Change (Navigation equipped)**



Manual Speed Limit Assist assists the vehicle to adjust its speed according to the speed limit. When the cruising speed is set as same as the speed limit, the vehicle automatically adjusts its speed if the speed limit changes. The function operates on the road which has a speed limit of 44 mph (70 km/h) or higher. When the function is active, the set speed on the instrument cluster appears in green.

### **MARNING**

- If you want to drive below the speed limit, set the Speed Limit Offset under "0" or use the - switch on the steering wheel to lower the set speed. If the Speed Limit Offset is set over "0", the set speed changes to a speed higher than the limit for the road.
- Even after changing the set speed according to the speed limit of the road, the vehicle can still be driven over the speed limit. If necessary, press the brake pedal to reduce your driving speed.
- If the speed limit of the road is under 20 mph (30 km/h), the set speed change function will not work.
- Intelligent Speed Limit Assist operates using the speed units in the instrument cluster set by the driver. If the speed unit is not set to the speed unit used in your country, Intelligent Speed Limit Assist may not operate properly.

### *i* Information

For more details on Manual Speed Limit Assist operation, refer to "Manual Speed Limit Assist (MSLA)" section in this chapter.

## Intelligent Speed Limit Assist Malfunction and Limitations

Intelligent Speed Limit Assist malfunction



B0332EU01

When Intelligent Speed Limit Assist is not working properly, the 'Check Speed Limit system' warning message will appear on the instrument cluster for several seconds, and the master (1) warning light and (1) warning light will illuminate on the instrument cluster. If this occurs, have the vehicle inspected by an authorized HYUNDAI dealer.

## Intelligent Speed Limit Assist disabled



B0332EU02

If the area where the front view camera is located is covered with foreign material, such as snow or rain, it can reduce the detecting performance and temporarily limit or disable Intelligent Speed Limit Assist. If this occurs, the 'Speed Limit system disabled. Camera obscured' warning message and (—) warning light will appear on the instrument cluster.

Intelligent Speed Limit Assist will operate properly when snow, rain or foreign material is removed.

If Intelligent Speed Limit Assist does not operate properly after it is removed, have the vehicle inspected by an authorized HYUNDAI dealer.



### **WARNING**

Even though the warning message or warning light does not appear on the instrument cluster, Intelligent Speed Limit Assist may not operate properly.

#### Limitations of Intelligent Speed Limit Assist

Intelligent Speed Limit Assist may not operate properly, or it may operate unexpectedly under the following circumstances:

- The road sign is contaminated or indistinguishable
  - The road sign is difficult to see due to bad weather, such as rain, snow, fog, etc.
  - The road sign is not clear or damaged
  - The road sign is partially obscured by surrounding objects or shadow
- The road signs do not conform to the standard
  - The text or illustration on the road sign is different from the standard
  - The road sign is installed between the main line and the exit road or between diverging roads
  - There is no conditional road signs on the road sign located on the exit road
  - A sign is attached to another vehicle
- The distance between the vehicle and the road signs is too far
- The vehicle encounters illuminant road signs
- Intelligent Speed Limit Assist incorrectly recognizes numbers or illustrations in the street signs or other signs as the speed limit
- A road sign near the road you are driving is detected
- The other traffic sign or signboards are alongside the road sign
- Multiple signs are installed close together
- The minimum speed limit sign is misrecognised
- The minimum speed limit sign is on the road
- The light level changes suddenly, for example when entering or exiting a tunnel or passing under a bridge

- Headlights are not used or the brightness of the headlights are weak at night or in the tunnel
- Road signs are difficult to recognizes due to the reflection of sunlight, street lights, or oncoming vehicles
- The navigation information or GPS information contain errors.
- The driver does not follow the guide of the navigation.
- The driver is driving on a new road that is not in the navigation system
- The field of view of the front view camera is obstructed by sun glare
- Driving on a road that is sharply curved or continuously curved
- Driving through speed bumps, or driving up and down or left to right on steep inclines
- The vehicle is shaking heavily
- Driving on a newly opened road
- The navigation software is being updated whilst driving
- The navigation is restarted while drivina

### **!** WARNING

- Intelligent Speed Limit Assist is a supplemental function that helps the driver to comply with the speed limit on the road, and may not display the correct speed limit or control the driving speed properly.
- Always set the vehicle speed to the speed limit in your area.
- Intelligent Speed Limit Assist may not operate for 15 seconds after the vehicle is started, or the front camera is initialised.



#### Information

For more details on the limitations of the front view camera, refer to "Forward Collision-Avoidance Assist (FCA) (front view camera only)" section in this chapter.

### **DRIVER ATTENTION WARNING (DAW)**

### **Inattentive Driving Warning function**

Driver Attention Warning monitors your driving pattern while driving. When the driver's attention level is below a certain level, Driver Attention Warning recommends a break to help with safe driving.

## Leading vehicle departure alert function

Leading Vehicle Departure Alert function will inform the driver when a detected vehicle in front departs from a stop.

### **Detecting sensor**



[1]: Front view camera

The front view camera is used as a detecting sensor to detect driving patterns and front vehicle departure while vehicle is being driven.

Refer to the illustration above for the detailed location of the detecting sensor.

### **CAUTION**

- Always keep the front view camera in good condition to maintain optimal performance of Driver Attention Warning.
- For more information on the precautions of the front view camera, refer to "Forward Collision-Avoidance Assist (FCA)" section in this chapter.

## **Driver Attention Warning Settings**

### Leading Vehicle Departure Alert



With the engine on, select **Settings** > **Vehicle** > **Driver Assistance** > **Driver Attention Warning** from the settings menu in the infotainment system to set whether to use the function.

 If Leading Vehicle Departure Alert is selected, the function will inform the driver when a detected vehicle in front departs from a stop.

### **Driver Attention Warning Operation**

### Inattentive Driving Warning function

The basic function of Driver Attention Warning is to warn the driver 'Consider taking a break'.

#### Taking a break



OUS4071057L

- The 'Consider taking a break' message and Driver Attention Warning light ()) indicator will appear on the instrument cluster and an audible warning will sound to suggest that the driver take a break, when the driver's attention level is below 1.
- Driver Attention Warning will not suggest a break when the total driving time is shorter than 4 minutes or 4 minutes has not passed after the last break was suggested.

### WARNING

For your safety, only change the Settings after parking the vehicle at a safe location.



### **CAUTION**

- · Driver Attention Warning may suggest a break depending on the driver's driving pattern or habits. even if the driver doesn't feel fatique.
- · Driver Attention Warning is a supplemental function and may not be able to determine whether the driver is inattentive.
- The driver who feels fatigued should take a break at a safe location, even though there is no break suggestion by Driver Attention Warning.

## Leading Vehicle Departure Alert function



OCN7N071016L

When a detected vehicle in front departs from a stop, Leading Vehicle Departure Alert will inform the driver by displaying the 'Leading vehicle is driving away' message on the instrument cluster and an audible warning will sound.

## 1

### WARNING

- If any other system's warning message is displayed or audible warning is generated, Leading Vehicle Departure Alert's warning message may not be displayed and audible warning may not be generated.
- The driver should hold the responsibility to safely drive and control the vehicle.



### CAUTION ■

- Leading Vehicle Departure Alert is a supplemental function and may not alert the driver whenever the front vehicle departs from a stop.
- Always check the front of the vehicle and road conditions before departure.



### Information

The images and colors in the instrument cluster may differ depending on the instrument cluster type or theme selected from the settings.

# **Driver Attention Warning Malfunction and Limitations**


## Driver Attention Warning malfunction



B0337FU01

When Driver Attention Warning is not working properly, the 'Check Inattentive Driving Warning system' warning message will appear on the instrument cluster for several seconds, and the master (A) warning light and Driver Attention Warning light (b) will illuminate on the instrument cluster. If this occurs, have the vehicle inspected by an authorized HYUNDAI dealer.

#### **Driver Attention Warning disabled**



B0337EU02

When the front windshield where the front view camera is located is covered with foreign material, such as snow or rain, it can reduce the detecting performance and temporarily limit or disable Driver Attention Warning. If this occurs, the 'Inattentive Driving Warning disabled. Camera obscured' warning message, master (A) warning light and Driver Attention Warning light (B) will appear on the instrument cluster. Driver Attention Warning will operate properly when snow, rain or foreign material is removed.

If Driver Attention Warning does not operate properly after it is removed, have the vehicle inspected by an authorized HYUNDAI dealer.

### **⚠** WARNING

- Driver Attention Warning may not properly operate in an area (for example, open terrain) where any objects are not detected right after turning ON the vehicle.
- If the vehicle is turned off and restarted while the camera is blocked or malfunctioned, the condition is maintained. Therefore, Driver Attention Warning may not operate properly.


### Limitations of Driver Attention Warning

Driver Attention Warning may not work properly in the following situations:

- · The vehicle is driven violently
- The vehicle intentionally crosses over lanes frequently
- The vehicle is controlled by Driver Assistance system, such as Lane Keeping Assist

#### **Leading Vehicle Departure Alert function**

· When the vehicle cuts in



OADAS021SD




OADAS034SD

[A]: Your vehicle, [B]: Front vehicle

If a vehicle cuts in front of your vehicle, Leading Departure Alert may not operate properly.


· When the vehicle ahead sharply steers



[A]: Your vehicle, [B]: Front vehicle

If the vehicle in front makes a sharp turn, such as to turn left or right or make a Uturn, etc., Leading Vehicle Departure Alert may not operate properly.

When the vehicle ahead abruptly departures



OVDV80348B


If the vehicle in front abruptly departures, Leading Vehicle Departure Alert may not operate properly.

• When a pedestrian or bicycle is between you and the vehicle ahead




If there is a pedestrian(s) or bicycle(s) in between you and the vehicle in front, Leading Vehicle Departure Alert may not operate properly.

· When in a parking lot



If a vehicle parked in front drives away from you, Leading Vehicle Departure Alert may alert you that the parked vehicle is driving away.

• When driving at a tollgate or intersection, etc.



If you pass a tollgate or intersection with lots of vehicles or you drive where lanes are merged or divided frequently, Leading Vehicle Departure Alert may not operate properly.

## A

#### WARNING


Driver Attention Warning may not operate for 15 seconds after the vehicle is started, or the front view camera is initialized.



#### Information

For more information on the precautions of the front view camera, refer to "Forward Collision-Avoidance Assist (FCA)" section in this chapter.

#### **CRUISE CONTROL (CC)**



[1]: Cruise indicator [2]: Set speed

Cruise Control allows you to drive at speeds above 20 mph (30 km/h) without depressing the accelerator pedal.

#### **Cruise Control Operation**

#### Setting set speed

1. Accelerate to the desired speed, which must be more than 20 mph (30 km/h).



- 2. Press the Driving Assist ( ) button at the desired speed. The set speed and Cruise ('CCRUISE) indicator will illuminate on the instrument cluster.
- 3. Release the accelerator pedal. Vehicle speed will maintain the set speed even when the accelerator pedal is not depressed.

## Information

The vehicle may slightly slow down or speed up while driving uphill or downhill.

#### Increasing set speed



- Push the + switch up and release it immediately. The set speed will increase by 1 mph (1 km/h) each time the switch is operated in this manner.
- Push the + switch up and hold it while monitoring the set speed on the instrument cluster. The set speed will increase to the nearest multiple of five (multiple of ten in km/h) at first. and then increase by 5 mph (10 km/h) each time the switch is operated in this manner.

Release the switch when the desired speed is shown and the vehicle will accelerate to that speed.

## Information

The set speed may differ depending on the vehicle specifications. You may not increase the set speed above the maximum set speed.

#### Decreasing set speed



Push the - switch down and release

- it immediately. The set speed will decrease by 1 mph (1 km/h) each time the switch is operated in this manner.
- Push the switch down and hold it while monitoring the set speed on the instrument cluster. The set speed will decrease to the nearest multiple of five (multiple of ten in km/h) at first, and then decrease by 5 mph (10 km/h) each time the switch is operated in this manner.


Release the switch at the speed you want to maintain.

#### Accelerating temporarily

If you want to speed up temporarily when Cruise Control is on, depress the accelerator pedal. To return to the set speed, take your foot off the accelerator pedal.

If you push the + switch up or - switch down at increased speed, the set speed will be set to the current increased speed.

#### Temporarily pausing Cruise Control



Cruise Control will be paused when:


- · Depressing the brake pedal.
- Pushing the II switch.
- · Shifting the gear to N (Neutral).
- Decreasing vehicle speed to less than about 20 mph (30 km/h).
- · ESC (Electronic Stability Control) is operating.
- Downshifting to 2nd gear when in Manual Shift mode.

The set speed will turn off but the Cruise (CCRUISE) indicator will stay on.

#### NOTICE

If Cruise Control pauses during a situation that is not mentioned, have the vehicle inspected by an authorized HYUNDAI dealer.

#### Resuming Cruise Control



Operate the +, - switch or II button. If you push the + switch up or - switch down, vehicle speed will be set to the current speed on the instrument cluster.

If you press the **II 3** button, vehicle The vehicle will resume to the preset speed.

The vehicle speed must be above 20 mph (30 km/h) for Cruise Control to resume.



### ! WARNING

Check the driving condition before using the [[5] button. Driving speed may sharply increase or decrease when you press the [15] button.

#### **Turning off Cruise Control**



Press the Driving Assist () button to turn Cruise Control off. The Cruise () CRUISE) indicator will go off. Always press the Driving Assist () button to turn Cruise Control off when not in use.

## *i* Information

If your vehicle is equipped with Manual Speed Limit Assist, press and hold the Driving Assist ( ) button to turn off Cruise Control. However, Manual Speed Limit Assist will turn on.

## **MARNING**

Take the following precautions when using Cruise Control:

- Always set the vehicle speed under the speed limit in your area.
- Keep Cruise Control off when the function is not in use, to avoid inadvertently setting a speed. Check that the Cruise ( CRUISE) indicator is off.
- Cruise Control does not substitute for proper and safe driving. It is the responsibility of the driver to always drive safely and should always be aware of unexpected and sudden situations from occurring.
- Always drive cautiously to prevent unexpected and sudden situations from occurring. Pay attention to the road conditions at all times.
- Do not use Cruise Control when it may be unsafe to keep the vehicle at a constant speed:
  - When driving in heavy traffic, or when traffic conditions make it difficult to drive at a constant speed
  - When driving on rainy, icy, or snow-covered roads
  - When driving on hilly or windy roads
  - When driving in windy areas
  - When driving with limited view (possibly due to bad weather, such as fog, snow, rain and sandstorm)

#### LANE FOLLOWING ASSIST (LFA)

Lane Following Assist detects lane markings and/or a vehicle ahead on the road, and center your vehicle in the lane.

#### **Detecting sensor**



[1]: Front view camera

The front view camera is used as a detecting sensor to detect lane markings and front vehicles.

Refer to the illustration above for the detailed location of the detecting sensor.



#### CAUTION

For more information on the precautions of the front view camera, refer to "Forward Collision-Avoidance Assist (FCA)" section in this chapter.

## Lane Following Assist Settings Warning Methods



OCN7073153L

The Warning Methods can be set with the engine on. Select **Setup** > **Vehicle** > **Driver Assistance** > **Warning Methods** from the settings menu in the infotainment system to change the following settings:

- Warning Volume: Adjusts the volume of the warning sound.
- Driving Safety Priority: Lowers all other audio volumes when the Driving Safety system sounds a warning.

- If you change the Warning Methods, it can be applied to each function of the driver assistance system. Please check and change it in each function.
- If the vehicle is restarted, Warning Methods will maintain the last setting.
- The setting menu may not exist based on vehicle specification.

## Lane Following Assist Operation Turning Lane Following Assist On/ Off



With the engine on, short press the Lane Driving Assist button located on the steering wheel to turn on Lane Following Assist. The white or green  $\bigcirc$  indicator light will illuminate on the instrument cluster.

Press the button again to turn off the function.

#### Lane Following Assist



OCN7073210

If the vehicle ahead and/or both lane markings are detected and your vehicle speed is below 120 mph (200 km/h), the green indicator light will illuminate on the instrument cluster, and the function will help center the vehicle in the lane by assisting the steering wheel.



#### **CAUTION**

When the steering wheel is not assisted, the green  $\bigotimes$  indicator light will blink and change to white.


#### Hands-off warning



OCN7N071095L

If the driver takes their hands off the steering wheel for several seconds, the 'Keep hands on the steering wheel' warning message will appear and an audible warning will sound in stages.

First stage: Warning message Second stage: Warning message (red steering wheel) and audible warning



B0356EU01

If the driver still does not have their hands on the steering wheel after the hands-off warning, the 'Lane Following Assist deactivated' warning message will appear and Lane Following Assist will be automatically canceled.

## **⚠** WARNING

- The steering wheel may not be assisted if the steering wheel is held very tight or the steering wheel is steered over a certain degree.
- Lane Following Assist does not operate at all times. It is the responsibility of the driver to safely steer the vehicle and to maintain the vehicle in its lane.
- The hands-off warning message may appear late depending on road conditions. Always have your hands on the steering wheel while driving.
- If the steering wheel is held very lightly the hands-off warning message may appear because the function may not recognize that the driver has their hands on the steering wheel.
- If you attach objects to the steering wheel, the hands-off warning may not work properly.


- For more information on setting the functions in the infotainment system, refer to "Vehicle Settings" section in chapter 4.
- When both lane markings are detected, the lane lines on the instrument cluster will change from grey to white.





- The images and colors in the instrument cluster may differ depending on the instrument cluster type or theme selected from the settings menu.
- If lane markings are not detected, steering wheel control by Lane Following Assist can be limited depending on whether a vehicle is in front or the driving conditions of the vehicle.
- Even though the steering is assisted by Lane Following Assist, the driver may control the steering wheel.
- The steering wheel may feel heavier or lighter when the steering wheel is assisted by Lane Following Assist than when it is not.

# Lane Following Assist Malfunction and Limitations Lane Following Assist malfunction



B0357EU01

When Lane Following Assist is not working properly, the 'Check Lane Following Assist system' warning message will appear on the instrument cluster for several seconds, and the master (\(\hat{\Lambda}\)) warning light will illuminate on the instrument cluster. If this occurs, have the vehicle inspected by an authorized HYUNDAI dealer.

#### Limitations of Lane Following Assist

For more information on function limitations, refer to "Lane Keeping Assist (LKA)" section in this chapter.

## *i* Information

For more information on the function precautions, refer to "Lane Keeping Assist (LKA)" section in this chapter.

## **⚠** WARNING

 Loading in excess of the maximum load allowance or concentrated loading at one point in the cargo compartment can reduce the vehicle's driving stability, which can in turn reduce the effectiveness of Lane Following Assist.

#### **REAR VIEW MONITOR (RVM)**

Rear View Monitor displays the area behind your vehicle to help with safe parking.

#### **Detecting sensor**



[1]: Wide-rear view camera

Refer to the illustration above for the detailed location of the detecting sensor.

### **Rear View Monitor Settings**

#### Warning Methods



OCN7073184L

The Warning Methods can be set with the engine on. Select **Setup** > **Vehicle** > **Driver Assistance** > **Warning Methods** from the settings menu in the infotainment system to change the following settings:

 Parking Safety Priority: Lowers all other audio volumes when Rear View Monitor is operating.

- If you change the Warning Methods, it can be applied to each function of the driver assistance system. Please check and change it in each function.
- If the vehicle is restarted, Warning Methods will maintain the last setting.
- The setting menu may not exist based on vehicle specification.

#### **Camera Settings**



OCN7073186L

You can change Rear View Monitor
Display contents by touching the setup
icon ( ) on the screen while Rear
View Monitor is operating, or selecting
Setup > Vehicle > Driver Assistance >
Parking Safety > Camera Settings from
the Settings menu in the infotainment
system when the engine is on.

- Display Contents: You can change settings for rear view reference lines.
- Display settings: You can change the screen's brightness and contrast.

## *i* Information

There may be no Setting menu depending on the vehicle specification.

#### **Extended Rear View Monitor**

With the vehicle on, select Camera Settings > Display Contents > Extended Rear View Monitor from the Settings menu to turn on Extend rear camera use function and deselect to turn off the function

#### **Rear View Parking Lines**


If Rear View Parking Lines is selected, the rear view parking guide lines and rear top view guide lines will be displayed at the left side of the infotainment system.

- The horizontal guideline of the Rear View Parking Guidance shows the distance of 20 in (0.5 m), 40 in (1 m) and 91 in (2.3 m) from the vehicle.
- The horizontal guideline of the Rear Top View Parking Guidance shows the distance 20 in (0.5 m) and 60 in (1.5 m) from the vehicle.

#### **Rear View Monitor Operation**

#### Parking/View button





- Press the Parking/View button (1)
   while the gear is in P (Park) to turn on
   Rear View Monitor. Press the button
   again to turn off the function.
- Press the Parking/View button (1)
   while the gear is in D (Drive) or N
   (Neutral) to turn on Rear View Monitor
   while driving.

#### Rear View



#### **Operating conditions**

- Shift the gear to R (Reverse), the rear view will appear on the screen.
- Press the Parking/View button (1) while the gear is in P (Park), the rear view will appear on the screen.
- Touch the licon, the rear view will appear on the screen.

#### Off conditions

- Press the Parking/View button (1) again while the gear is in P (Park), the rear view will turn off.
- Shift the gear from R (Reverse) to P (Park), the rear view will turn off.

## *i* Information

When the gear is in R (Reverse), the rear view does not turn off.

#### Rear top view



When you touch the icon, the top view is displayed on the screen and shows the distance from the vehicle in the back of your vehicle while parking.

#### Extended Rear View Monitor

The rear view will maintain showing on the screen to help you when parking.

#### **Operating conditions**

- Shift the gear from R (Reverse) to N (Neutral) or D (Drive), the rear view will appear on the screen.
- Vehicle speed is 6 mph (10 km/h) or less, the rear view will appear on the screen.

#### Off conditions

- Vehicle speed is above 6 mph (10 km/h) the rear view will turn off.
- Press the Parking/View button (1), the rear view will turn off.
- Shift the gear to P (Park), the rear view will turn off.

## Rear View Monitor Malfunction and Limitations

#### Rear View Monitor malfunction

When Rear View Monitor is not working properly, or the screen flickers, or the camera image does not display properly, have the vehicle inspected by an authorized HYUNDAI dealer.

#### Limitations of Rear View Monitor

When the vehicle is stopped for a long time in winter or when the vehicle is parked in an indoor parking lot, the exhaust fumes may temporarily blur the image.




#### WARNING

- The rear view camera does not cover the complete area behind the vehicle. The driver should always check the rear area directly through the inside and side view mirror before parking or backing up.
- The image shown on the screen may differ from the actual distance of the object. Make sure to directly check the vehicle's surroundings for safety.
- Always keep the rear view camera lens clean. If the lens is covered with foreign material, it may adversely affect camera performance and Rear View Monitor may not operate properly. However, do not use chemical solvents such as strong detergents containing high alkaline or volatile organic solvents (gasoline, acetone, etc.). This may damage the camera lens.

## REAR CROSS-TRAFFIC COLLISION-AVOIDANCE ASSIST (RCCA) (IF EQUIPPED)

Rear Cross-Traffic Collision-Avoidance Assist detects vehicles approaching from the rear left or right while your vehicle is reversing and warns you of a possible collision with a warning message and a warning sound. Also, Rear Cross-Traffic Collision-Avoidance Assist may assist with braking your vehicle to help avoid a collision.



- [A]: Rear Cross-Traffic Collision Warning operating range.
- [B]: Rear Cross-Traffic Collision-Avoidance Assist operating range



Warning timing may vary depending on the speed of the approaching vehicle.

#### **Detecting sensor**



[1]: Rear corner radar

Refer to the illustration above for the detailed location of the detecting sensors.



For more information on the precautions of the rear corner radar, refer to "Blind-Spot Collision-Avoidance Assist (BCA)" section in this chapter.

#### Rear Cross-Traffic Collision Avoidance Assist Settings

Rear Cross-Traffic Safety



With the engine on, select Setup > Vehicle > Parking Safety > Rear Cross-Traffic Safety from the settings menu in the infotainment system to turn on Rear Cross-Traffic Collision-Avoidance Assist and deselect to turn off the function.



#### WARNING

When the engine is restarted, Rear Cross-Traffic Collision-Avoidance Assist will always turn on. However, if 'Rear Cross-Traffic Safety' is deselected after the engine is restarted, the driver should always be aware of the surroundings and drive safely.

#### Warning Methods



OCN7073199L

The Warning Methods can be set with the engine on. Select **Setup** > **Vehicle** > **Driver Assistance** > **Warning Methods** from the settings menu in the infotainment system to change the following settings:

• Warning Volume: Adjusts the volume of the warning sound.

## i

- If you change the Warning Methods, it can be applied to each function of the driver assistance system. Please check and change it in each function.
- If the vehicle is restarted, Warning Methods will maintain the last setting.
- The setting menu may not exist based on vehicle specification.

#### Rear Cross-Traffic Collision Avoidance Assist Operation

Rear Cross-Traffic Collision-Avoidance Assist will warn and control the vehicle depending on collision level: 'Collision Warning', 'Emergency Braking' and 'Stopping vehicle and ending brake control'.

#### **Collision Warning**





To warn the driver of an approaching vehicle from the rear left/right side of your vehicle, the warning light on the side view mirror will blink and a warning message will appear on the instrument cluster. At the same time, an audible warning will sound.

A warning will also appear on the infotainment system.

Rear Cross-Traffic Collision-Avoidance Assist will operate when all the following conditions are satisfied:

- The gear is shifted to R (Reverse) and your vehicle speed is below 5 mph (8 km/h).
- The approaching vehicle is detected within about 82 ft. (25 m) from the left or right of your vehicle.
- The speed of the vehicle approaching from the left or right is above 3 mph (5 km/h).

- If the operating conditions are satisfied, there will be a warning whenever the vehicle approaches from the left or right side even though your vehicle speed is 0 mph (0 km/h).
- The images and colors in the instrument cluster may differ depending on the instrument cluster type or theme selected from the instrument cluster.

#### **Emergency Braking**





To warn the driver of an approaching detected vehicle from the rear left/right side of your vehicle, the warning light on the side view mirror will blink and a warning message will appear on the instrument cluster. At the same time, an audible warning will sound.

A warning will also appear on the infotainment system.

Emergency braking will be assisted to help prevent collision with approaching vehicles from the left and right.

Rear Cross-Traffic Collision-Avoidance Assist will operate when all the following conditions are satisfied:

- The gear is shifted to R (Reverse) and your vehicle speed is below 5 mph (8 km/h).
- The approaching vehicle is detected within about 5 ft. (1.5 m) from the left or right of your vehicle.
- The speed of the vehicle approaching from the left or right is above 3 mph (5 km/h).



Brake control will end when:

- The approaching vehicle is out of the detecting range
- The approaching vehicle passes behind your vehicle
- The approaching vehicle does not drive toward your vehicle
- The approaching vehicle speed slows down
- The driver depresses the brake pedal with sufficient power

## Stopping vehicle and ending brake control



OCN7N071035L

When the vehicle is stopped due to emergency braking, the 'Drive carefully' warning message will appear on the instrument cluster.

For your safety, the driver should depress the brake pedal immediately and check the surroundings.

- Brake control will end after the vehicle is stopped by emergency braking for about 2 seconds.
- During emergency braking, braking control by Rear Cross-Traffic Collision-Avoidance Assist will automatically cancel when the driver excessively depresses the brake pedal.

## ۱

#### WARNING

Take the following precautions when using Rear Cross-Traffic Collision-Avoidance Assist:

- For your safety, only change the Settings after parking the vehicle at a safe location.
- If any other function's warning message is displayed or audible warning is generated, Rear Cross-Traffic Collision-Avoidance Assist warning message may not be displayed and audible warning may not be generated.
- You may not hear the warning sound of Rear Cross-Traffic Collision-Avoidance Assist if the surroundings are noisy.
- Rear Cross-Traffic Collision-Avoidance Assist may not operate if the driver applies the brake pedal to avoid collision.
- During Rear Cross-Traffic Collision-Avoidance Assist operation, the vehicle may stop suddenly injuring passengers and shifting loose objects. Always have the seat belt on and keep loose objects secured.
- Even if there is a problem with Rear Cross-Traffic Collision-Avoidance Assist, the vehicle's basic braking will function normally.
- When Rear Cross-Traffic Collision-Avoidance Assist is operating, braking control by the function will automatically cancel when the driver excessively depresses the accelerator pedal.
- Rear Cross-Traffic Collision-Avoidance Assist does not operate in all situations and cannot avoid all collisions.
- Rear Cross-Traffic Collision-Avoidance Assist may warn the driver late or may not warn the driver depending on the road and driving conditions.

- The driver has the responsibility to control the vehicle. Do not solely depend on Rear Cross-Traffic Collision-Avoidance Assist. Rather. maintain a safe braking distance, and if necessary, depress the brake pedal to reduce driving speed or to stop the vehicle.
- Never deliberately operate Rear **Cross-Traffic Collision-Avoidance** Assist on people, animal, objects, etc. It may cause serious injury or death.



#### **CAUTION**

The brake control may not operate properly depending on the status of ESC (Electronic Stability Control).

There will only be a warning when:

- The ESC (Electronic Stability Control) warning light is on
- ESC (Electronic Stability Control) is engaged in a different function

### Information

- · If braking is assisted by Rear Cross-Traffic Collision-Avoidance Assist. the driver must immediately depress the brake pedal and check vehicle surroundings.
  - Brake control will end when the driver depresses the brake pedal with sufficient power.
  - After shifting the gear to R (Reverse), braking control will operate once for left and right vehicle approach.

#### **Rear Cross-Traffic Collision** Avoidance Assist Malfunction and Limitations

Rear Cross-Traffic Collision-Avoidance Assist malfunction



B0373EU01

When Rear Cross-Traffic Collision-Avoidance Assist is not working properly, the 'Check Rear Cross-Traffic Safety system' warning message will appear on the instrument cluster for several seconds, and the master / warning light will illuminate on the instrument cluster. If this occurs, have the vehicle inspected by an authorized HYUNDAI dealer.



B0322EU02

When the side view mirror warning light is not working properly, the 'Check side view mirror warning light' warning message will appear on the instrument cluster for several seconds, and the master \( \frac{\Lambda}{\text{ warning light will illuminate}} \) on the instrument cluster. If this occurs, have the vehicle inspected by an authorized HYUNDAI dealer.

#### Rear Cross-Traffic Collision-Avoidance Assist disabled



OTM070124N

When the rear bumper around the rearside radar or sensor is covered with foreign material, such as snow or rain, or installing a trailer or carrier, it can reduce the detecting performance and temporarily limit or disable Rear Cross-Traffic Collision-Avoidance Assist.

If this occurs, the 'Rear Cross-Traffic Safety system disabled. Radar blocked' warning message will appear on the instrument cluster.

Rear Cross-Traffic Collision-Avoidance Assist will operate properly when such foreign material or trailer, etc., is removed.

If Rear Cross-Traffic Collision-Avoidance Assist does not operate properly after it is removed, have the vehicle inspected by an authorized HYUNDAI dealer.

## **MARNING**

- Even though the warning message does not appear on the instrument cluster, Rear Cross-Traffic Collision-Avoidance Assist may not operate properly.
- Rear Cross-Traffic Collision-Avoidance Assist may not operate properly in an area (for example, open terrain), where any substance are not detected after turning ON the engine.

## **CAUTION**

Turn off Rear Cross-Traffic Collision-Avoidance Assist to install or remove a trailer, carrier, or another attachment. Turn on Rear Cross-Traffic Collision-Avoidance Assist when finished.

## Limitations of Rear Cross-Traffic Collision-Avoidance Assist

Rear Cross-Traffic Collision-Avoidance Assist may not operate properly, or it may operate unexpectedly under the following circumstances:

- Departing from where trees or grass are overgrown
- · Departing from where roads are wet
- Speed of the approaching vehicle is fast or slow

Braking control may not work, driver's attention is required in the following circumstances:


- The vehicle severely vibrates while driving over a bumpy road, uneven road or concrete patch
- Driving on a slippery surface due to snow, water puddle, ice, etc.
- The tire pressure is low or a tire is damaged
- · The braking system has been modified



For more information on the limitations of the rear corner radar, refer to the "Blind-Spot Collision-Avoidance Assist (BCA)" section in this chapter.

### **MARNING**

· Driving near a vehicle or structure




[A]: Structure

Rear Cross-Traffic Collision-Avoidance Assist may be limited when driving near a vehicle or structure, and may not detect the vehicle approaching from the left or right. If this occurs, the function may not warn the driver or control the brakes when necessary.

Always check your surroundings while backing up.


When the vehicle is in a complex parking environment



Rear Cross-Traffic Collision-Avoidance Assist may detect vehicles which are parking or pulling out near your vehicle (for example, a vehicle leaving beside your vehicle, a vehicle parking or pulling out in the rear area, a vehicle approaching your vehicle making a turn, etc.). If this occurs, the function may unnecessarily warn the driver and control the brake.

Always check your surroundings while backing up.

When the vehicle is parked diagonally




[A]: Vehicle

Rear Cross-Traffic Collision-Avoidance Assist may be limited when backing up diagonally, and may not detect the vehicle approaching from the left or right. If this occurs, the function may not warn the driver or control the brakes when necessary.

Always check your surroundings while backing up.


When the vehicle is on or near a slope



Rear Cross-Traffic Collision-Avoidance Assist may be limited when the vehicle is on a uphill or downhill slope, or near it, and may not detect the vehicle approaching from the left or right. If this occurs, the function may not warn the driver or control the brakes when necessary.

Always check your surroundings while backing up.

 Pulling into the parking space where there is a structure




[A]: Structure, [B]: Wall

Rear Cross-Traffic Collision-Avoidance Assist may detect vehicles passing by in front of you when parking in reverse into a parking space with a wall or structure in the rear or side area. If this occurs, the function may unnecessarily warn the driver and control the brake.

Always check your surroundings while backing up.

When the vehicle is parked rearward



Rear Cross-Traffic Collision-Avoidance Assist may detect vehicles passing by behind you when parking in reverse into a parking space. If this occurs, the function may unnecessarily warn the driver and control the brake.

Always check your surroundings while backing up.

### **!** WARNING

- When you are towing a trailer or another vehicle, we recommend that Rear Cross-Traffic Collision-Avoidance Assist is turned off due to safety reasons.
- Rear Cross-Traffic Collision-Avoidance Assist may not operate properly if interfered by strong electromagnetic waves.
- Rear Cross-Traffic Collision-Avoidance Assist may not operate for 3 seconds after the vehicle is started, or the rear corner radars are initialized.

### *i* Information

This device complies with Part 15 of the FCC rules.

Operation is subject to the following three conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.
- 3. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

### *i* Information

Radio frequency radiation exposure information:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance of 8 in. (20 cm) between the radiator (antenna) and your body.


This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## FORWARD/REVERSE PARKING DISTANCE WARNING (PDW) (IF EQUIPPED)

Forward/Reverse Parking Distance Warning uses the front and rear ultrasonic sensors to detect and warns you if a person, animal, or object is within a certain distance when your vehicle is stopped or driving at low speed.

#### **Detecting sensor**





[1]: Front ultrasonic sensors [2]: Rear ultrasonic sensors

Refer to the illustration above for the detailed location of the detecting sensors.

## Forward/Reverse Parking Distance Warning Settings Warning Methods




OCN70731001

The Warning Methods can be set with the engine on. Select **Setup** > **Vehicle** > **Driver Assistance** > **Warning Methods** from the settings menu in the infotainment system to change the following settings:

• Warning Volume: Adjusts the volume of the warning sound.

- If you change the Warning Methods, it can be applied to each function of the driver assistance system. Please check and change it in each function.
- If the vehicle is restarted, Warning Methods will maintain the last setting.
- The setting menu may not exist based on vehicle specification.

# Forward/Reverse Parking Distance Warning Operation Parking Safety button



Press the Parking Safety button to turn on Forward/Reverse Parking Distance Warning. Press the button again to turn off the function.

When Forward/Reverse Parking
 Distance Warning is off (button
 indicator light off), if you shift the
 gear to R (Reverse), Forward/Reverse
 Parking Distance Warning will
 automatically turn on.

#### Forward Parking Distance Warning

- Forward Parking Distance Warning will operate when one of the condition is satisfied.
  - The gear is shifted from R (Reverse) to D (Drive) with Reverse Parking Distance Warning on
  - The gear is in D (Drive) and the Parking safety button indicator light is on
  - Parking Distance Warning Auto On is selected from the Settings menu and the gear is in D (Drive)
  - The gear is shifted to R (Reverse) (only front corner warning is on)

- Forward Parking Distance Warning will operate only when the vehicle's forward speed is below 6 mph (10 km/h).
- While the gear is in R (Reverse),
   Forward Parking Distance Warning
   operates only for the front outer side
   area.
- When 'Parking Distance Warning Auto on' is deselected, and the vehicle's forward speed is above 18 mph (30 km/h), the Parking Safety PM▲ button indicator will turn off. Although you drive below 6 mph (10 km/h), Forward Parking Distance Warning will not turn on.

Distance from object	Warning indicator	Warning sound	
24~40 in. (60~100 cm)		Buzzer beeps intermittently	
12~24 in. (30~60 cm)		Beeps more frequently	
Within 12 in. (30 cm)		Beeps continuously	

- The corresponding indicator will illuminate whenever each ultrasonic sensor detects a person, animal or object in its sensing range. Also an audible warning will sound.
- When more than two objects are detected at the same time, the closest one will be warned with an audible warning.
- The shape of the indicator in the illustration may differ from the actual vehicle.

#### Reverse Parking Distance Warning

Reverse Parking Distance Warning will operate under the following conditions.

• The gear is shifted to R (Reverse).

Distance from object	Warning indicator	Warning sound	
24~48 in. (60~120 cm)		Buzzer beeps intermittently	
12~24 in. (30~60 cm)		Beeps more frequently	
Within 12 in. (30 cm)		Beeps continuously	

- The corresponding indicator will illuminate whenever each ultrasonic sensor detects a person, animal or object in its sensing range. Also an audible warning will sound.
- When more than two objects are detected at the same time, the closest one will be warned with an audible warning.
- The shape of the indicator in the illustration may differ from the actual vehicle.

## Forward/Reverse Parking Distance Warning Malfunction and Limitations

## Forward/Reverse Parking Distance Warning malfunction

If the following occurs, first check whether the ultrasonic sensor is damaged or covered with foreign material. If it still does not work properly, have the vehicle inspected by and authorized HYUNDAI dealer.

The warning message appears on the instrument cluster.



B0377EU01

#### Parking Distance Warning disabled



B0377EU03

If this occurs the warning message appears on the instrument cluster.

Parking Distance Warning will operate properly when snow, rain or foreign material is removed. If Parking Distance Warning does not operate properly after obstruction (snow, rain, or foreign material) is removed (including trailer, carrier, etc., from the rear bumper), have the vehicle inspected by an authorized HYUNDAI dealer.

#### Limitations of Forward/Reverse Parking Distance Warning

- Forward/Reverse Parking Distance Warning may not operate properly when:
  - Moisture is frozen to the sensor
  - Sensor is covered with substance, such as snow or water (Forward/ Reverse Parking Distance Warning will operate properly when such substance is removed.)
  - The weather is extremely hot or cold
  - The sensor or sensor assembly is disassembled
  - The surface of the sensor is pressed hard or hit with a hard object
  - The surface of the sensor is scratched with a sharp object
  - The sensors or its surrounding area is directly sprayed with high pressure washer
- Forward/Reverse Parking Distance Warning may malfunction when:
  - Heavy rain or water spray is present
  - Water flows on the surface of the sensor
  - Affected by another vehicle's sensors
  - The sensor is covered with snow or ice
  - Driving on uneven road, gravel roads or bushes
  - Objects that generates ultrasonic waves are near the sensor
  - License plate is installed in a different spot from the original location
  - The vehicle bumper height or ultrasonic sensor installation has been modified
  - Attaching equipment or accessories next to the ultrasonic sensors

- The following objects may not be detected:
  - Sharp or slim objects, such as ropes, chains or small poles.
  - Narrow objects, such as corners of a square column
  - Objects, which tend to absorb sensor frequency, such as clothes, spongy material or snow.
  - Objects smaller than 40 in. (100 cm) in length and narrower than 6 in. (14 cm) in diameter.
  - Pedestrians, animals or objects that are very close to the ultrasonic sensors.

#### WARNING

- Parking Distance Warning is a supplemental function. The operation of Parking Distance Warning can be affected by several factors (including environmental conditions). It is the responsibility of the driver to always check the front and rear views before and while parking.
- Your new vehicle warranty does not cover any accidents or damage to the vehicle due to the malfunction of Parking Distance Warning.
- Pay close attention when driving near objects, pedestrians, and especially children. Some objects may not be detected by the ultrasonic sensors, due to the objects distance, size or material, all of which can limit the effectiveness of the sensor.
- Parking Distance Warning does not warn you in the order of detection. It varies depending on the speed of the vehicle or the shape of a person, animal, or object.
- If the Parking Distance Warning does not operate properly, have the vehicle inspected by an authorized HYUNDAI dealer.

#### **DECLARATION OF CONFORMITY**

The radio frequency components complies:

#### Rear Corner Radar (if equipped)

#### ■ For USA



The antenna(s) must be installed such that a minimum separation distance of at least 20 cm is maintained between the radiator (antenna) and all persons at all times, This device must not be co-located or operating in conjunction with any other antenna or transmitter,

OANATEL124

#### ■ For Canada

This device complies with Innovation, Science and Economic Development Canada's


- licence—
  exempt RSS standard(s). Operation is subject to the following two conditions:
  (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired
- operation of the device,
- Le prèsent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence, L'exploitation est autorisès
- aux deux conditions suivantes:
- (1) l'appareil ne doit pas produire de brouillage,
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement,

OANATEL123

## **8. Emergency Situations**

Hazard Warning Flasher	8-2
In Case of an Emergency While Driving	8-2 8-2
If the Engine Will not Start	8-3
Jump Starting	8-4
If the Engine Overheats	8-7
Tire Pressure Monitoring System (TPMS)  Check Tire Pressure  Tire Pressure Monitoring System  Low Tire Pressure Telltale  Low Tire Pressure Position and Tire Pressure Telltale  TPMS (Tire Pressure Monitoring System) Malfunction Indicator	8-9 8-9 8-10 8-11 8-13
Changing a Tire with TPMS	8-15 8-16 8-17 8-20
Towing  Towing Service  Emergency Towing  Removable Towing Hook  Fmergency Towing	8-22 8-23 8-23

#### **HAZARD WARNING FLASHER**



The hazard warning flasher serves as a warning to other drivers to exercise extreme caution when approaching, overtaking, or passing your vehicle.

It should be used whenever emergency repairs are being made or when the vehicle is stopped near the edge of a roadway.

To turn the hazard warning flasher on or off, press the hazard warning flasher button. The button is located in the center fascia panel. Both the left and right turn signal lights will flash simultaneously.

- The hazard warning flasher operates whether your vehicle is running or not.
- The turn signals do not work when the hazard flasher is on.

## IN CASE OF AN EMERGENCY WHILE DRIVING

#### If the Engine Stalls While Driving

- Reduce your speed gradually, keeping a straight line. Move cautiously off the road to a safe place.
- Turn on your hazard warning flasher.
- Try to start the engine again. If your vehicle will not start, contact an authorized HYUNDAI dealer or seek other qualified assistance.

## If the Engine Stalls at a Crossroad or Crossing

If the engine stalls at a crossroads or crossing, if safe to do so, move the shift lever to the N (Neutral) position and then push the vehicle to a safe location.

#### If you Have a Flat Tire While **Driving**

If a tire goes flat while you are driving:

- Take your foot off the accelerator pedal and let the vehicle slow down while driving straight ahead. Do not apply the brakes immediately or attempt to pull off the road as this may cause loss of vehicle control resulting in an accident. When the vehicle has slowed to such a speed that it is safe to do so, brake carefully and pull off the road. Drive off the road as far as possible and park on firm, level ground. If you are on a divided highway, do not park in the median area between the two traffic
- When the vehicle is stopped, press the hazard warning flasher button, move the shift lever into P (Park, for dual clutch transmission vehicle) or neutral (for manual transmission vehicle), and apply the parking brake, and set the Engine Start/Stop button in the OFF position.
- Have all passengers get out of the vehicle. Be sure they all get out on the side of the vehicle that is away from traffic
- When you have a flat tire, follow the Tire Mobility Kit instructions provided later in this chapter.

#### IF THE ENGINE WILL NOT **START**

#### If the Engine Doesn't Turn Over or Turns Over Slowly

- Be sure the shift lever is in N (Neutral) or P (Park). The engine starts only when the shift lever is in N (Neutral) or P (Park).
- Check the battery connections to be sure they are clean and tight.
- Turn on the interior light. If the light dims or goes out when you operate the starter, the battery is drained.

Do not push or pull the vehicle to start it. This could cause damage to your vehicle. Refer to "Jump Starting" section in this chapter.



#### ? CAUTION

Push or pull starting the vehicle may cause the catalytic converter to overload which can lead to damage to the emission control system.

#### If the Engine Turns Over Normally but Doesn't Start

Check the fuel level and add fuel if necessary.

If the engine still does not start, have your vehicle checked by an authorized HYUNDAI dealer.

#### **JUMP STARTING**

Jump starting can be dangerous if done incorrectly. Follow the jump starting procedure in this section to avoid serious injury or damage to your vehicle. If in doubt about how to properly jump start your vehicle, have a service technician or towing service do it for you.

## **MARNING**

To prevent SERIOUS INJURY or DEATH to you or bystanders, always follow these precautions when working near or handling the battery:



Always read and follow instructions carefully when handling a battery.



Wear eye protection designed to protect the eyes from acid splashes.



Keep all flames, sparks, or smoking materials away from the battery.



Hydrogen is always present in battery cells, is highly combustible, and may explode if ignited.



Keep batteries out of reach of children.



Batteries contain sulfuric acid which is highly corrosive. Do not allow acid to contact your eyes, skin or clothing. If acid gets into your eyes, flush your eyes with clean water for at least 15 minutes and get immediate medical attention. If acid gets on your skin, thoroughly wash the area. If you feel pain or a burning sensation, get medical attention immediately.

- When lifting a plastic-cased battery, excessive pressure on the case may cause battery acid to leak. Lift with a battery carrier or with your hands on opposite corners.
- Do not attempt to jump start your vehicle if your battery is frozen.
- NEVER attempt to recharge the battery when the vehicle's battery cables are connected to the battery.
- The electrical ignition system works with high voltage. NEVER touch these components with the engine running or when the Engine Start/ Stop button in the OFF position.

# Jump starting procedure

- 1. Position the vehicles close enough that the jumper cables will reach, but do not allow the vehicles to touch
- 2. Avoid fans or any moving parts in the engine compartment at all times, even when the vehicles are turned off
- 3. Turn off all electrical devices such as radios, lights, air conditioning, etc. Put the vehicle in P (Park), and set the parking brakes. Turn both vehicles OFF.



- 4. Open the engine hood.
- 5. Connect the jumper cables in the exact sequence shown in the illustration. First connect one jumper cable to the red, positive (+) jumper terminal of your vehicle (1).
- 6. Connect the other end of the jumper cable to the red, positive (+) battery/ jumper terminal of the assisting vehicle (2).
- 7. Connect the second jumper cable to the black, negative (-) battery/jumper terminal of the assisting vehicle (3).

8. Connect the other end of the second iumper cable to the black, negative (-) chassis ground of your vehicle (4). Do not allow the jumper cables to contact anything except the correct battery or jumper terminals or the correct ground. Do not lean over the battery when making connections.



# ! CAUTION

Before jump starting, make sure to correctly identify the positive (+) and negative (-) terminals to avoid reverse polarity connections.



## WARNING

Do not connect the jumper cable to the negative (-) jumper terminal of the discharged battery. A spark could cause the battery to explode and lead to a personal injury or vehicle damage.

9. Operate your vehicle for at least 30 minutes of driving or at least 60 minutes of engine running at idle before shutting off the engine. Without sufficient time to charge the battery, the vehicle will reoccur another no start. You can also visit your nearest dealer to request the battery be charged and tested.

If your vehicle will not start after a few attempts, it probably requires service. In this event please seek qualified assistance. If the cause of your battery discharging is not apparent, have your vehicle checked by an authorized HYUNDAI dealer.

Disconnect the jumper cables in the exact reverse order you connected them:

- Disconnect the jumper cable from the black, negative (-) chassis ground of your vehicle (4).
- Disconnect the other end of the jumper cable from the black, negative (-) battery/chassis ground of the assisting vehicle (3).
- 3. Disconnect the second jumper cable from the red, positive (+) battery/ jumper terminal of the assisting vehicle (2).
- 4. Disconnect the other end of the jumper cable from the red, positive (+) jumper terminal of your vehicle (1).

# **MARNING**

While jump starting your vehicle, avoid the positive (+) and negative (-) cables to come in contact. A spark could cause personal injury.

# *i* Information



An inappropriately disposed battery can be harmful to the environment and human health. Dispose of the battery according to your local law(s) or regulations.

# NOTICE

To prevent damage to your vehicle:

- Only use a 12 V power supply (battery or jumper system) to jump start your vehicle.
- Do not attempt to jump start your vehicle by push-starting.

# IF THE ENGINE OVERHEATS

If your temperature gauge indicates overheating, you experience a loss of power, or hear loud pinging or knocking. the engine may be overheating. If this happens, you should:

- 1. Pull off the road and stop as soon as it is safe to do so.
- 2. Place the shift lever in P (Park, for dual clutch transmission vehicle) or neutral (for manual transmission vehicle) and set the parking brake. If the air conditioning is ON, turn it OFF.
- 3. If engine coolant is running out under the vehicle or steam is coming out from the hood, stop the engine. Do not open the hood until the coolant has stopped running or the steaming has stopped. If there is no visible loss of engine coolant and no steam. leave the engine running and check to be sure the engine cooling fan is operating. If the fan is not running. turn the engine off.

# WARNING



While the engine is running, keep hands, clothing and tools away from the moving parts such as the cooling fan and drive belt to prevent serious injury.

- 4. Check to see if the water pump drive belt is missing.
- (1) If it is not missing, check to see that it is tight.
- (2) If the drive belt seems to be satisfactory, check for coolant leaking from the radiator, hoses or under the vehicle. (If the air conditioning had been in use, it is normal for cold water to be draining from it when you stop.)
- 5. If the water pump drive belt is broken or engine coolant is leaking out, stop the engine immediately and call an authorized HYUNDAI dealer for assistance.



# ! WARNING



**NEVER** remove the engine coolant cap or the drain plug while the engine and radiator are hot. Hot coolant and steam may blow out under pressure, causing serious injury.

Turn the engine off and wait until the engine cools down. Use extreme care when removing the engine coolant cap. Wrap a thick towel around it, and turn it counterclockwise slowly to the first stop. Step back while the pressure is released from the cooling system. When you are sure all the pressure has been released, press down on the cap, using a thick towel, and continue turning counterclockwise to remove it.

- If you cannot find the cause of the overheating, wait until the engine temperature has returned to normal. Then, if coolant has been lost, carefully add coolant to the reservoir to bring the fluid level in the reservoir up to the halfway mark.
- Proceed with caution, keeping alert for further signs of overheating. If overheating happens again, call an authorized HYUNDAI dealer for assistance.

# NOTICE

- Serious loss of coolant indicates a leak in the cooling system and have system be checked by an authorized HYUNDAI dealer.
- When the engine overheats from low engine coolant, suddenly adding engine coolant may cause cracks in the engine. To prevent damage, add engine coolant slowly in small quantities.

# **TIRE PRESSURE MONITORING SYSTEM (TPMS)**





OCN7N081055L

- (1) Low Tire Pressure Telltale/TPMS
  Malfunction Indicator
- (2) Low Tire Pressure Position Telltale and Tire Pressure Telltale (Shown on the cluster display)

### **Check Tire Pressure**



■ Type B

Tire Pressure

33 29

34 33

OCN7N041115L

- You can check the tire pressure in the View mode on the cluster display.
- Refer to the "View Modes" in chapter
   4.
- Tire pressure is displayed after a few minutes of driving after initial engine start up.
- If tire pressure is not displayed when the vehicle is stopped, "Drive to display" message will appear. After driving, check the tire pressure.
- The displayed tire pressure values may differ from those measured with a tire pressure gauge.
- You can change the tire pressure unit from the Settings menu in the infotainment system. Select:
  - Setup > General > Units > Tire Pressure Unit

# **Tire Pressure Monitoring System**



# ! WARNING

Over-inflation or under-inflation can reduce tire life, adversely affect vehicle handling, and lead to sudden tire failure that may cause loss of vehicle control resulting in an accident.

Each tire, including the spare, should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label. (If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label, you should determine the proper tire inflation pressure for those tires.)

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale when one or more of your tires is significantly under-inflated. Accordingly. when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly underinflated tire causes the tire to overheat and can lead to tire failure.

Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability.

Please note that the TPMS is not a substitute for proper tire maintenance. and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale.

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists

When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly.

Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

# NOTICE

If any of the below happens, have the system checked by an authorized HYUNDAI dealer.

- The Low Tire Pressure Telltale/ TPMS
   Malfunction Indicator does not
   illuminate for 3 seconds when the
   Engine Start/Stop button is set to
   the ON position or engine is running.
- 2. The TPMS Malfunction Indicator remains illuminated after blinking for approximately 1 minute.
- 3. The Low Tire Pressure Position Telltale remains illuminated.



# **Low Tire Pressure Telltale**

# Low Tire Pressure Position and Tire Pressure Telltale



OCN7080057L

When the tire pressure monitoring system warning indicators are illuminated and a warning message displayed on the cluster display, one or more of your tires is significantly under-inflated. The Low Tire Pressure Position Telltale will indicate which tire is significantly underinflated by illuminating the corresponding position light.

If either telltale illuminates, immediately reduce your speed, avoid hard cornering and anticipate increased stopping distances. You should stop and check your tires as soon as possible. Inflate the tires to the proper pressure as indicated on the vehicle's placard or tire inflation pressure label located on the driver's side center pillar outer panel.

If you cannot reach a service station or if the tire cannot hold the newly added air, replace the low pressure tire with the spare tire.

The Low Tire Pressure Telltale will remain on and the TPMS Malfunction Indicator may blink for one minute and then remain illuminated (when the vehicle is driven approximately 10 minutes at speed above 22mph (35km/h)) until you have the low pressure tire repaired and replaced on the vehicle.



The spare tire is not equipped with a tire pressure sensor.



# **CAUTION**

In winter or cold weather, the Low Tire Pressure Telltale may be illuminated if the tire pressure was adjusted to the recommended tire inflation pressure in warm weather. It does not mean your TPMS is malfunctioning because the decreased temperature leads to a proportional lowering of tire pressure.

When you drive your vehicle from a warm area to a cold area or from a cold area to a warm area, or the outside temperature is greatly higher or lower, you should check the tire inflation pressure and adjust the tires to the recommended tire inflation pressure.



# WARNING

Low pressure damage

Significantly low tire pressure makes the vehicle unstable and can contribute to loss of vehicle control and increased braking distances.

Continued driving on low pressure tires can cause the tires to overheat and fail.



The TPMS Malfunction Indicator will illuminate after it blinks for approximately one minute when there is a problem with the Tire Pressure Monitoring System.

Have the system be checked by an authorized HYUNDAI dealer.

# NOTICE

If there is a malfunction with the TPMS, the Low Tire Pressure Position Telltale will not be displayed even though the vehicle has an under-inflated tire.

# NOTICE

The TPMS Malfunction Indicator may illuminate after blinking for one minute if the vehicle is near electric power supply cables or radio transmitters such as police stations, government and public offices, broadcasting stations, military installations, airports, transmitting towers, etc.

Additionally, the TPMS Malfunction Indicator may illuminate if snow chains are used or electronic devices such as computers, chargers, remote starters, navigation, etc. This may interfere with normal operation of the TPMS.

# **Changing a Tire with TPMS**

If you have a flat tire, the Low Tire Pressure and Position telltales will come on. Have the flat tire be repaired by an authorized HYUNDAI dealer as soon as possible or replace the flat tire with the spare tire.

# NOTICE

It is recommended that you do not use a puncture-repairing agent not approved by a HYUNDAI dealer to repair and/or inflate a low pressure tire. Tire sealant not approved by a HYUNDAI dealer may damage the tire pressure sensor.

The spare tire (if equipped) does not come with a tire pressure monitoring sensor. When the low pressure tire or the flat tire is replaced with the spare tire, the Low Tire Pressure Telltale will remain on. Also, the TPMS Malfunction Indicator will illuminate after blinking for one minute if the vehicle is driven at speed above 22mph (35km/h) for approximately 10 minutes.

Once the original tire equipped with a tire pressure monitoring sensor is reinflated to the recommended pressure and reinstalled on the vehicle, the Low Tire Pressure Telltale and TPMS Malfunction Indicator will go off within a few minutes of driving.

If the indicators do not extinguish after a few minutes, please visit an authorized HYUNDAI dealer.

Each wheel is equipped with a tire pressure sensor mounted inside the tire behind the valve stem. You must use TPMS specific wheels. Always have your tires serviced by an authorized HYUNDAI dealer.

You may not be able to identify a tire with low pressure by simply looking at it. Always use a good quality tire pressure gauge to measure the tire's inflation pressure. Please note that a tire that is hot (from being driven) will have a higher pressure measurement than a tire that is cold.

A cold tire means the vehicle has been sitting for 3 hours and driven for less than 1 mile (1.6 km) in that 3 hour period. Allow the tire to cool before measuring the inflation pressure. Always be sure the tire is cold before inflating to the recommended pressure.



# **!** WARNING

- The TPMS cannot alert you to severe and sudden tire damage caused by external factors such as nails or road debris.
- If you feel any vehicle instability, immediately take your foot off the accelerator, apply the brakes gradually with light force, and slowly move to a safe position off the road.



# WARNING

Tampering with, modifying, or disabling the Tire Pressure Monitoring System (TPMS) components may interfere with the system's ability to warn the driver of low tire pressure conditions and/or TPMS malfunctions. Tampering with, modifying, or disabling the Tire Pressure Monitoring System (TPMS) components may void the warranty for that portion of the vehicle.



# Information

This device complies with Part 15 of the FCC rules.

Operation is subject to the following three conditions:

- 1. This device may not cause harmful interference.
- 2. This device must accept any interference received, including interference that may cause undesired operation.
- 3. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

# IF YOU HAVE A FLAT TIRE (WITH TIRE MOBILITY KIT)



For safe operation, carefully read and follow the instructions in this manual before use.

- (1) Compressor
- (2) Sealant bottle

The Tire Mobility Kit is a temporary fix to the tire and we recommend that the system be inspected by an authorized HYUNDAI dealer.



# CAUTION

When two or more tires are flat, do not use the tire mobility kit because the sealant provided with the Tire Mobility Kit must be used for only one flat tire.



### **WARNING**

Do not use the Tire Mobility Kit to repair punctures in the tire walls. This can result in an accident due to tire failure.



### WARNING

Have your tire repaired as soon as possible. The tire may loose air pressure at any time after inflating with the Tire Mobility Kit.

# Introduction

With the Tire Mobility Kit you stay mobile even after experiencing a tire puncture.

The system of compressor and sealing compound effectively and comfortably seals most punctures in a passenger car tire caused by nails or similar objects and reinflates the tire.

After you ensured that the tire is properly sealed you can drive cautiously on the tire (distance up to 120 miles (200 km/h)) at a max. speed of 50 mph (80 km/h) in order to reach a service station or tire dealer to have the tire replaced.

It is possible that some tires, especially with larger punctures or damage to the sidewall, cannot be sealed completely.

Air pressure loss in the tire may adversely affect tire performance.

For this reason, you should avoid abrupt steering or other driving maneuvers, especially if the vehicle is heavily loaded or if a trailer is in use.

The Tire Mobility Kit is not designed or intended as a permanent tire repair method and is to be used for one tire only. This instruction shows you step by step how to temporarily seal the puncture simply and reliably.

Read the section "Notes on the safe use of the Tire Mobility Kit".




### WARNING

Do not use the TMK if a tire is severely damaged by driving run flat or with insufficient air pressure.

Only punctured areas located within the tread region of the tire can be sealed using the TMK.

# **Components of the Tire Mobility Kit**



- 0. Speed-restriction label
- 1. Sealant bottle and label with speed restriction
- 2. Filling hose
- 3. Connectors and cable for the power outlet direct connection
- 4. Holder for the sealant bottle
- 5. Compressor
- 6. ON/OFF switch
- 7. Pressure gauge for displaying the tire inflation pressure
- 8. Button for reducing the tire inflation pressure

Connectors, cable and connection hose are stored in the compressor housing. Strictly follow the specified sequence, otherwise the sealant may escape under high pressure.

# ! WARNING

### **Expired sealant**

Do not use the Tire sealant after the sealant has expired (i.e. pasted the expiration date on the sealant container). This can increase the risk of tire failure.



### Sealant

- · Keep out of reach of children.
- Avoid contact with eyes.
- · Do not swallow.

# Using the Tire Mobility Kit when a Tire is Flat





Detach the speed restriction label (0) from the sealant bottle (1), and place it in a highly visible place inside the vehicle such as on the steering wheel to remind the driver not to drive too fast.



If only the tire pressure needs to be adjusted, refer to "How to Adjust Tire Pressure" in this chapter.

Before using the Tire Mobility Kit, be fully aware of the explanation on the sealant.

1 Shake the sealant bottle



- 2. Connect the filling hose (2) to the sealant bottle (1) in the direction of (A) and connect the sealant bottle to the compressor (5) in the direction of (B).
- 3. Ensure that the compressor is switched OFF.
- 4. Unscrew the valve cap from the valve of the defective wheel and screw the filling hose (2) of the sealant bottle onto the valve.





# ! CAUTION

Securely install the sealant filling hose to the valve. If not, sealant may flow backward, possibly clogging the filling hose.



5. Plug the compressor power cord (3) into the vehicle power outlet.

# NOTICE

Only use the front passenger side power outlet when connecting the power cord.

- 6. Set the Engine Start/Stop button to the ON position.
- 7. Switch on the compressor and let it run for approximately 5~7 minutes to fill the sealant up to proper pressure. (refer to the Tire and Wheels, chapter 2). The inflation pressure of the tire after filling is unimportant and will be checked/corrected later.

Be careful not to overinflate the tire and stay away from the tire when filling it.



# ! CAUTION

### Tire pressure

Do not attempt to drive your vehicle if the tire pressure is below 29 psi (200 kPa). This could result in an accident due to sudden tire failure.

- 8. Switch off the compressor.
- 9. Detach the hoses from the sealant bottle connector and from the tire valve.


Return the Tire Mobility Kit to its storage location in the vehicle.



# WARNING

### Carbon monoxide

Do not leave your vehicle running in a poorly ventilated area for extended periods of time. Carbon monoxide poisoning and suffocation can occur.




10. Immediately drive approximately 4~6 miles (7~10 km or, about 10min) to evenly distribute the sealant in the

Do not exceed a speed of 50 mph (80 km/h). If possible, do not fall below a speed of 12 mph (20 km/h).

While driving, if you experience any unusual vibration, ride disturbance or noise, reduce your speed and drive with caution until you can safely pull off of the side of the road.

Call for road side service or towing.





- After driving approximately 4~6 miles (7~10 km or, about 10min), stop at a safety location.
- 12. Connect the filling hose (2) of the compressor directly to the tire valve.
- 13. Plug the compressor power cord into the vehicle power outlet.
- 14. Adjust the tire inflation pressure to the recommended tire inflation.

With the Engine Start/Stop button in the ON position, proceed as follows.

- To increase the inflation pressure

   Switch on the compressor. To
   check the current inflation pressure
   setting, briefly switch off the
   compressor.
- To reduce the inflation pressure: Press the button (8) on the compressor.

# NOTICE

Do not let the compressor run for more than 10 minutes, otherwise the device will overheat and may be damaged.



# Information

The pressure gauge may show higher than actual reading when the compressor is running. To get an accurate tire reading, the compressor needs to be turned off.



# **CAUTION**

If the inflation pressure is not maintained, drive the vehicle a second time, refer to step 10.

Then repeat steps 11 to 14.

Use of the TMK may be ineffectual for tire damage larger than approximately 0.16 in (4 mm).

Please contact the nearest HYUNDAI dealership if the tire cannot be made roadworthy with the Tire Mobility Kit.



# **WARNING**

The tire inflation pressure must be at least 32 psi (220 kPa). If it is not, do not continue driving.

Call for road side service or towing.



### CAUTION

Tire pressure sensor

(if equipped with TPMS)

The sealant on the tire pressure sensor and wheel should be removed when you replace the tire with a new one and inspect the tire pressure sensors. We recommend that you get this done at an authorized HYUNDAI dealer.

# *i* Information

When reinstalling the repaired or replaced tire and wheel on the vehicle, tighten the wheel lug nut to 79~94 lbf·ft (11~13 kgf·m).

# **How to Adjust Tire Pressure**





- 1. Park your vehicle in a safe location.
- 2. Connect the filling hose (2) of the compressor directly to the tire valve.
- 3. Plug the compressor power cord into the vehicle power outlet.
- 4. Adjust the tire inflation pressure to the recomended tire inflation.

With the Engine Start/Stop button ON, proceed as follows.

- To increase the inflation pressure

   Switch on the compressor. To
   check the current inflation pressure
   setting, briefly switch off the
   compressor.
- To reduce the inflation pressure: Press the button (8) on the compressor.

# NOTICE

Do not let the compressor run for more than 10 minutes, otherwise the device will overheat and may be damaged.

# *i* Information

The pressure gauge may show higher than actual reading when the compressor is running. To get an accurate tire reading, the compressor needs to be turned off.

# **A** CAUTION

Do not use the sealant when the tire pressure only needs to be adjusted.

# **MARNING**

The tire inflation pressure must be at least 32 psi (220 kPa). If it is not, do not continue driving.

Call for road side service or towing.


# Notes on the Safe Use of the Tire Mobility Kit

- Park your car at the side of the road so that you can work with the Tire Mobility Kit away from moving traffic.
- To be sure your vehicle will not move, even when you're on fairly level ground, always set your parking brake.
- Only use the Tire Mobility Kit for sealing/inflation passenger car tires.
   Only punctured areas located within the tread region of the tire can be sealed using the tire mobility kit.
- Do not use on motorcycles, bicycles or any other type of tires.
- When the tire and wheel are damaged, do not use Tire Mobility Kit for your safety.
- Use of the Tire Mobility Kit may not be effective for tire damage larger than approximately 0.16 in (4 mm).
- Please contact the nearest HYUNDAI dealership if the tire cannot be made roadworthy with the Tire Mobility Kit.
- Do not use the Tire Mobility Kit if a tire is severely damaged by driving run flat or with insufficient air pressure.
- Do not remove any foreign objects such as nails or screws that have penetrated the tire.
- Provided the car is outdoors, leave the engine running. Otherwise operating the compressor may eventually drain the car battery.

- Never leave the Tire Mobility Kit unattended while it is being used.
- Do not leave the compressor running for more than 10 min. at a time or it may overheat.
- Do not use the Tire Mobility Kit if the ambient temperature is below -22°F (-30°C).
- In case of skin contact with the sealant, wash the area thoroughly with plenty of water. If the irritation persists, seek medical attention.
- In case of eye contact with the sealant, flush your eyes for at least 15 minutes. If the irritation persists, seek medical attention.
- In case of swallowing the sealant, rinse the mouth and drink plenty of water. However, never give anything to an unconscious person and seek medical attention immediately.
- Long time exposure to the sealant may cause damage to bodily tissue such as kidney, etc.

### **TOWING**

# **Towing Service**



If emergency towing is necessary, have it done by an authorized HYUNDAI dealer or a commercial tow-truck service.

Proper lifting and towing procedures are necessary to prevent damage to the vehicle. The use of wheel dollies or flatbed is recommended.

It is acceptable to tow the vehicle with the rear wheels on the ground (without dollies) and the front wheels off the ground.

If any of the loaded wheels or suspension components are damaged or the vehicle is being towed with the front wheels on the ground, use a towing dolly under the front wheels.

When being towed by a commercial tow truck and wheel dollies are not used, the front of the vehicle should always be lifted, not the rear.

# **A** CAUTION

 Do not tow the vehicle with the front wheels on the ground as this may cause damage to the vehicle.



 Do not tow with sling-type equipment. Use a wheel lift or flatbed equipment.



 Do not tow the vehicle with four wheels in contact with the ground if it is the vehicle equipped with dual clutch transmission.

Otherwise, the transmission will be seriously damaged. Also, make sure not to tow the vehicle connecting it with other vehicles including camper vans.



# **MARNING**

If your vehicle is equipped with a rollover sensor, set the Engine Start/ Stop button in the OFF or ACC position when the vehicle is being towed. The side impact and curtain air bag may deploy if the sensor detects the situation as a rollover.

When towing your vehicle in an emergency without wheel dollies:

- 1. Set the Engine Start/Stop button in the ACC position.
- 2. Place the shift lever in N (Neutral).
- 3. Release the parking brake.


# **CAUTION**

Failure to place the shift lever in N (Neutral) when being towed with the front wheels on the ground can cause internal damage to the transmission.

# **Emergency Towing**

If towing is necessary, have it done by an authorized HYUNDAI dealer or a commercial tow truck service.

# **Removable Towing Hook**



 Open the trunk, and remove the towing hook from the tool case.



- 2. Remove the hole cover by pressing the lower part of the cover on the bumper.
- Install the towing hook by turning it clockwise into the hole until it is fully secured.
- 4. Remove the towing hook and install the cover after use.

# **Emergency Towing**





If towing is necessary, have it done by an authorized HYUNDAI dealer or a commercial tow truck service.

If towing service is not available in an emergency, your vehicle may be temporarily towed using a cable or chain secured to the emergency towing hook at the front (or rear) of the vehicle.

Use extreme caution when towing the vehicle with a cable or chain. A driver must be in the vehicle to steer it and operate the brakes.

Towing in this manner may be done only on hard-surfaced roads for a short distance and at low speeds. Also, the wheels, axles, power train, steering and brakes must all be in good condition.


# $\triangle$

# CAUTION

The driver must be in the vehicle for steering and braking operations when the vehicle is being towed. Passengers other than the driver must not be in the vehicle.

Always follow these emergency towing precautions:

- Set the Engine Start/Stop button in the ACC position so the steering wheel is not locked.
- · Place the shift lever in N (Neutral).
- · Release the parking brake.
- Depress the brake pedal with more force than normal since you will have reduced braking performance.
- More steering effort will be required because the power steering system will be disabled.
- Use a vehicle heavier than your own to tow your vehicle.
- The drivers of both vehicles should communicate with each other frequently.
- Before emergency towing, check that the hook is not broken or damaged.
- Fasten the towing cable or chain securely to the hook.
- Do not jerk the hook. Apply steady and even force.



- Use a towing cable or chain less than 16 feet (5 m) long. Attach a white or red cloth (about 12 in. (30 cm) wide) in the middle of the cable or chain for easy visibility.
- Drive carefully so the towing cable or chain remains tight during towing.
- Before towing, check the dual clutch transmission for fluid leaks under your vehicle. If the dual clutch transmission fluid is leaking, flatbed equipment or a towing dolly must be used.

# NOTICE

Accelerate or decelerate the vehicle in a slow and gradual manner while maintaining tension on the tow rope or chain to start or drive the vehicle, otherwise tow hooks and the vehicle may be damaged.

# NOTICE

To avoid damage to your vehicle and vehicle components when towing:

- Always pull straight ahead when using the towing hooks. Do not pull from the side or at a vertical angle.
- Do not use the towing hooks to pull a vehicle out of mud, sand or other conditions from which the vehicle cannot be driven out under its own power.
- The vehicle should be towed at a speed of 15 mph (25 km/h) or less within the distance of 12 miles (20 km/h). (for manual transmission)
- The vehicle should be towed at a speed of 9 mph (15 km/h) or less within the distance of 0.9 miles (1.5 km/h), (for dual clutch transmission)


# 9. Maintenance

Engine Compartment Overview	9-3
Maintenance Services Owner's Responsibility Owner Maintenance Precautions	9-4
Owner Maintenance Owner Maintenance Schedule	9-5
Scheduled Maintenance Services	9-9
Explanation of Scheduled Maintenance Items	9-14
Engine Oil	9-16
Engine Coolant	9-19
Brake/Clutch Fluid	
Washer FluidChecking the Washer Fluid Level	
Parking Brake Checking the Parking Brake	
Air CleanerFilter Replacement	
Cabin Air FilterFilter InspectionFilter Replacement	9-27
Wiper Blades	9-28
Battery	9-30 9-3′ 9-3′ 9-32

Tires and Wheels	
Tire Care	9-34
Recommended Cold Tire Inflation Pressures	
Check Tire Inflation Pressure	
Tire Rotation	
Wheel Alignment and Tire Balance	
Tire Replacement	
Wheel Replacement	
Tire Traction	
Tire Maintenance	
Tire Sidewall Labeling	
Tire Terminology and Definitions	
All Season Tires	
Summer Tires	
Snow TiresRadial-Ply Tires	
Low Aspect Ratio Tires	
•	
Fuses	
Instrument Panel Fuse Replacement	
Engine Compartment Panel Fuse Replacement	
Fuse/Relay Panel Description	
Light Bulbs	
Headlight, Position Light, Turn Signal Light and Daytime Running Light Bulb	
Replacement	
Side Repeater Light Replacement	
Rear Combination Light Bulb Replacement	
High Mounted Stop Light Replacement	
License Plate Light Bulb Replacement	
Interior Light Bulb Replacement	9-62
Appearance care	9-64
Exterior Care	
Interior Care	
Emission Control System	0-72
Crankcase Emission Control System	
Evaporative Emission Control System Including Onboard Refueling Vapor	5 72
Recovery (ORVR)	9-72
Exhaust Emission Control System	
•	
California perchlorate notice	4-/5

# **ENGINE COMPARTMENT OVERVIEW**

■ Gasoline 2.0 T-GDi



The actual engine compartment in the vehicle may differ from the illustration.

OCN7N093001CN

- 1. Engine coolant reservoir
- 2. Brake/clutch fluid reservoir
- 3. Air cleaner
- 4. Engine oil dipstick

- 5. Engine oil filler cap
- 6. Windshield washer fluid reservoir
- 7. Fuse box
- 8. Battery
- 9. Engine coolant cap

# **MAINTENANCE SERVICES**

You should exercise the utmost care to prevent damage to your vehicle and injury to yourself whenever performing any maintenance or inspection procedures.

Have your vehicle maintained and repaired by an authorized HYUNDAI dealer. An authorized HYUNDAI dealer meets HYUNDAI's high service quality standards and receives technical support from HYUNDAI in order to provide you with a high level of service satisfaction.

# **Owner's Responsibility**

Maintenance service and record retention are the owner's responsibility.

You should retain documents that show proper maintenance has been performed on your vehicle in accordance with the scheduled maintenance service charts shown on the following pages. You need this information to establish your compliance with the servicing and maintenance requirements of your vehicle warranties.

Detailed warranty information is provided in your Owner's Handbook & Warranty Information booklet.

Repairs and adjustments required as a result of improper maintenance or a lack of required maintenance are not covered.

### **Owner Maintenance Precautions**

Inadequate, incomplete or insufficient servicing may result in operational problems with your vehicle that could lead to vehicle damage, an accident, or personal injury. This chapter provides instructions only for the maintenance items that are easy to perform. Several procedures can be done only by an authorized HYUNDAI dealer with special tools.

Your vehicle should not be modified in any way. Such modifications may adversely affect the performance, safety or durability of your vehicle and may, in addition, violate conditions of the limited warranties covering the vehicle.

Certain modifications may also be in violation of regulations established by the U.S. Department of Transportation and other federal or state agencies.

# NOTICE

Improper owner maintenance during the warranty period may affect warranty coverage. For details, read the separate Owner's Handbook & Warranty Information booklet provided with the vehicle. If you're unsure about any service or maintenance procedure, have it done by an authorized HYUNDAI dealer.

# **OWNER MAINTENANCE**



# WARNING

Performing maintenance work on a vehicle can be dangerous. If you lack sufficient knowledge and experience or the proper tools and equipment to do the work, have it done by an authorized HYUNDAI dealer.

**ALWAYS** follow these precautions for performing maintenance work:

- Park your vehicle on level ground. move the shift lever into the P (Park) position, set the Engine Start/Stop button to the OFF position.
- Block the tires (front and back) to prevent the vehicle from moving. Remove loose clothing or jewelry that can become entangled in moving parts.
- If you must run the engine during maintenance, do so in an outdoor area or in an area with plenty of ventilation.
- Keep flames, sparks, or smoking materials away from the battery and fuel-related parts.

The following lists are vehicle checks and inspections that should be performed by the owner or an authorized HYUNDAL dealer at the frequencies indicated to help ensure safe, dependable operation of your vehicle.

Any adverse conditions should be brought to the attention of your dealer as soon as possible.

These Owner Maintenance vehicle checks are generally not covered by warranties and you may be charged for labor, parts and lubricants used.

# **Owner Maintenance Schedule** When you stop for fuel:

- · Check the coolant level in the engine coolant reservoir.
- Check the windshield washer fluid. level
- Check the for low or under-inflated tires.



# ! WARNING

Be careful when checking your coolant level if the engine is hot. This may result in coolant being blown out of the opening and cause serious burns and other injuries.

# While operating your vehicle:

- Note any changes in the sound of the exhaust or any smell of exhaust fumes in the vehicle.
- Check for vibrations in the steering wheel. Notice if there is any increased steering effort or looseness in the steering wheel, or change in its straight-ahead position.
- Notice if your vehicle constantly turns slightly or "pulls" to one side when traveling on smooth, level road.
- When stopping, listen and check for unusual sounds, pulling to one side, increased brake pedal travel or "hardto-push" brake pedal.
- If any slipping or changes in the operation of your transmission occurs, check the transmission fluid level.
- Check the dual clutch transmission P (Park) function.
- · Check the parking brake.
- Check for fluid leaks under your vehicle (water dripping from the air conditioning system during or after use is normal).
- Check the manual transmission operation, including clutch operation.

# At least monthly:

- Check coolant level in the engine coolant reservoir.
- Check the operation of all exterior lights, including the brake lights, turn signals and hazard warning flashers.
- Check the inflation pressures of all tires including the spare for tires that are worn, show uneven wear, or are damaged.
- · Check for loose wheel lug nuts.

# At least twice a year: (for example, every Spring and Autumn)

- Check radiator, heater and air conditioning hoses for leaks or damage.
- Check windshield washer spray and wiper operation. Clean wiper blades with a clean cloth dampened with washer a fluid.
- · Check headlight alignment.
- Check muffler, exhaust pipes, shields and clamps.
- Check the seat belts for wear and function.

# At least once a year:

- Clean body and door drain holes.
- Lubricate door hinges and hood hinges.
- Lubricate door and hood locks and latches.
- Lubricate door rubber weather strips.
- · Lubricate door checker.
- · Check the air conditioning system.
- Inspect and lubricate dual clutch transmission linkage and controls.
- · Clean the battery and terminals.
- · Check the brake fluid level.

### SCHEDULED MAINTENANCE SERVICES

Follow Normal Maintenance Schedule if the vehicle is usually operated where none of the following conditions apply. If any of the following conditions apply, you must follow the Maintenance Under Severe Usage Conditions.

- Repeatedly driving short distance of less than 5 miles (8 km) in normal temperature of less than 10 miles (16 km) in freezing temperature.
- Extensive engine idling or low speed driving for long distances.
- Driving on rough, dusty, muddy, unpaved, graveled or salt- spread roads.
- Driving in areas using salt or other corrosive materials or in very cold weather.
- · Driving in heavy dust condition.
- · Driving in heavy traffic area.
- Driving on uphill, downhill, or mountain roads repeatedly.
- · Using for towing or camping, and driving with loads on the roof
- Driving as a patrol car, taxi, other commercial use of vehicle towing.
- Frequently driving under high speed or rapid acceleration/deceleration.
- Frequently driving in stop-and-go conditions.
- Engine oil usage which is not recommended(Mineral type, Semi-synthetic, Lower grade spec, etc.)

If your vehicle is operated under the above conditions, you should inspect, replace or refill more frequently than the following Normal Maintenance Schedule. After the periods or distance shown in the chart, continue to follow the prescribed maintenance intervals.

# NOTICE

After driving more than 10 years or 100,000 miles, use severe maintenance schedule.

# *i* Information

- As it is normal for engine oil to be consumed during driving, the engine oil level should be checked on regular basis.
- The engine oil change interval for normal operating conditions is based on the use of the recommended engine specification.
- The vehicle may be equipped with the Oil Life Management System that predicts
  engine oil life based on the driver's driving history and alerts the driver to change
  engine oil.
  - If the deterioration of the engine oil increases depending on the driver's driving severity, the remaining oil life alert appears on the instrument cluster before the normal engine oil replacement interval. Have the engine oil and filter changed by an authorized HYUNDAI dealer.
  - Oil Life Management System works when the recommended engine oil is used.
     So, if recommended engine oil is not used, replace the engine oil according to the maintenance schedule under severe usage condition.
    - Also, check the amount of engine oil regularly as this system assumes that the engine oil is being filled normally.
  - Always reset the remaining engine oil life whenever the engine oil is changed. Otherwise, the indication of remaining Oil life in the Oil Life Management System may not be accurate. To reset the Engine Oil Change Reminder, select 'RESET' from the infotainment system screen. Then, select 'Yes' when the message "Has the engine oil been changed? Press [Yes] to reset the oil life." appears on the screen.
  - If there is no alert until the maximum maintenance interval, have the vehicle checked by an authorized HYUNDAI dealer.

# Normal Maintenance Schedule

MAINTENANCE Months	Months	12	24	36	48	09	72	84	96	108	120
INTERVALS	Miles×1,000	9	12	18	24	30	36	42	48	54	09
ПЕМ	Km×1,000	9	20	30	40	20	09	70	80	06	100
Engine oil and engine oil filter *1*2			~	eplace	6,000 r	niles (10	),000 k	m) or 12	Replace 6,000 miles (10,000 km) or 12 months	S	
Fuel additives *3			Ad	d ever)	000,9	miles (7	10,000	km) or 1	Add every 6,000 miles (10,000 km) or 12 months	hs	
Air cleaner filter		_	_	_	~	_	_	_	~	_	_
Spark plugs				Repla	Replace every 42,000 miles (70,000 km)	y 42,00	0 miles	(70,00	0 km)		
Rotate Tires (includes tread wear inspection and tire pressure check)	nd tire pressure		Rot	ate eve	ry 6,00	0 miles	(10,000	km) or	Rotate every 6,000 miles (10,000 km) or 12 months	ıths	
Cabin air filter		_	~	_	~	_	~	_	~	_	~
Drive belts *4		Ä	At first fter tha	, Inspec t, Inspe	ct at 48,	,000 mi 7 6,000	ile (78,0 mile (10	000 km) 0,000 k	At first, Inspect at 48,000 mile (78,000 km) or 72 months After that, Inspect every 6,000 mile (10,000 km) or 12 months	onths month	SI
Intercooler in/out hose		Afi	At firs er that,	t, Inspe Inspec	ect at 6, et every	000 mi 18,000	le (10,0) mile (3	000,000 l	At first, Inspect at 6,000 mile (10,000 km) or 12 months After that, Inspect every 18,000 mile (30,000 km) or 24 months	onths 4 mont	hs
Valve clearance *5			lnspe	ct ever	у 60,00	00 mile	)0,06) s	00km) o	Inspect every 60,000 miles (90,000km) or 72 months	nths	

R: Replace or change.

I: Inspect and if necessary, adjust, correct, clean or replace.

- \*1: Requires API SN PLUS (or above) grade engine oil. If a lower grade engine oil is used, then the engine oil and engine oil filter must be replaced at every 3,000 miles (5,000 km) or 6 months as indicated for severe maintenance condition.
- \*2: Never add any additives to the engine oil. Engine oil additives can change the properties of engine oil and may cause serious \*3: If TOP TIER Detergent Gasoline is not available, one bottle of additive is recommended. Additives are available from your engine failure.
  - authorized HYUNDAI dealer along with information on how to use them. Do not mix other additives.
    - \*4: The drive belt should be replaced when cracks occur or tension is reduced excessively.
- \*5: Inspect for excessive valve noise and/or engine vibration and adjust if necessary. Have the system inspected by an authorized HYUNDAI dealer.

# Normal Maintenance Schedule (CONT)

MAINTENANCE	Months	12	24	36	48	09	72	84	96	108	120
INTERVALS	Miles×1,000	9	12	18	24	30	36	42	48	54	09
ITEM	Km×1,000	10	20	30	40	20	09	70	80	06	100
Vacuum hose		_	_	_	_	_	_	_	_	_	_
Engine coolant		Aft	t first, re er that,	splace a	at 120,0 every	At first, replace at 120,000 miles (200,000 km) or 120 months. After that, replace every 24,000 miles (40,000 km) or 24 months	s (200,0 miles (4	300 km 10,000	or 120 (km) or 2	month 24 mon	s. ths
Battery condition		_	-	_	_	ı	_	_	_	-	_
Brake lines, hoses and connections		_	_	_	_	_	_	_	_	_	_
Disc brakes and pads		_	_	_	_	1	_	_	_	_	_
Steering gear rack, linkage and boots / lower arm ball joint, upper arm ball joint	rm ball joint,	_	_	_	_	_	_	_	_	_	_
Drive axle shafts and boots		_	_	_	_	1	_	_	_	_	_
Suspension mounting bolts		_	_	_	-	ı	_	_	_	_	-
Air conditioner refrigerant		_	1	-	-	ı	_	_	-	-	-
Air conditioner compressor		_	1	-	-	ı	_	_	-	-	-
Exhaust pipe and muffler		_	_	-		ı	_	_	_	1	_
Manual transmission fluid (if equipped) *1				_	Jo Chec	No Check, No Service required	ervice	equire	-		
Dual clutch transmission fluid (if equipped) *1					_				_		

R: Replace or change. I: Inspect and if necessary, adjust, correct, clean or replace.

# Normal Maintenance Schedule (CONT)

MAINTENA	MAINTENANCE Months	12	24	36	12         24         36         48         60         72         84         96         108	09	72	84	96	108	120
MAINTENANCE	VALS Miles×1,000	9	12	18	24	30	36	24 30 36 42 48	48	54	09
ITEM	Km×1,000	10	20	30	30 40 50 60 70 80	20	09	70	80	06	100
Vapor hose, fuel filler cap and fuel tank			_		_		_		_		_
Fuel tank air filter *1			_		_		_		_		_
Fuel lines, hoses and connections			_		_		_		_		_
Parking brake			_		_		_		_		_
Brake fluid			Insp Repla	ect eve	Inspect every 6,000 miles (10,000km) or 12 months, Replace every 48,000 miles (80,000km) or 48 months	0 miles 00 miles	(10,000)	Jkm) or JOkm) o	12 mon r 48 mo	iths, onths	

R: Replace or change.

I: Inspect and if necessary, adjust, correct, clean or replace.

depends on fuel quality. If there are some important safety matters like fuel flow restriction, surging, loss of power, hard starting \*\*: The fuel filter is considered to be maintenance free but periodic inspection is recommended for this maintenance schedule problem etc, replace the fuel filter immediately regardless of maintenance schedule and consult an authorized HYUNDAI dealer for details.

# **Maintenance Under Severe Usage Conditions**

The following items must be serviced more frequently on cars mainly used under severe driving conditions. Refer to the chart below for the appropriate maintenance intervals.

R: Replace

I: Inspect and if necessary, adjust, correct, clean or replace

Maintenance item	Maintenance operation	Maintenance intervals	Driving condition
Engine oil and filter *1	R	Every 3,000 miles (5,000 km) or 6 months	D, H, I, L
Air cleaner filter	I	Inspect more frequently depending on the condition	C, E
Spark plugs	R	Replace more frequently depending on the condition	A, B, F, G, H, I, K
Steering gear rack, linkage and boots	I	Inspect more frequently depending on the condition	C, D, E, F, G
Disc brakes and pads, calipers and rotors	I	Inspect more frequently depending on the condition	C, D, E, G, H
Parking brake	I	Inspect more frequently depending on the condition	C, D, G, H
Drive axle shafts and boots	I	Inspect more frequently depending on the condition	C, D, E, F, G, H, I, J
Cabin air filter	R	Replace more frequently depending on the condition	C, E, G
Manual transmission fluid (if equipped)	R	Every 72,000 miles (120,000 km)	C, D, E, F, G, H, I, J
Dual clutch transmission fluid (if equipped)	R	Every 56,000 miles (91,000 km)	A, C, D, E, F, G, H, I, J, K

<sup>\*1:</sup> Requires <API SN PLUS (or above)> grade engine oil. If a lower grade engine oil (mineral oil) is used, then the engine oil and engine oil filter must be replaced as indicated for severe maintenance condition.

# Severe driving conditions

- A. Repeatedly driving short distance of less than 5 miles (8 km) in normal temperature of less than 10 miles (16 km) in freezing temperature.
- B. Extensive engine idling or low speed driving for long distances.
- C. Driving on rough, dusty, muddy, unpaved, graveled or salt- spread roads.
- D. Driving in areas using salt or other corrosive materials or in very cold weather.
- E. Driving in heavy dust condition.
- F. Driving in heavy traffic area.
- G. Driving on uphill, downhill, or mountain roads repeatedly.
- H. Using for towing or camping, and driving with loads on the roof
- I. Driving as a patrol car, taxi, other commercial use of vehicle towing.
- J. Frequently driving under high speed or rapid acceleration/deceleration.
- K. Frequently driving in stop-and-go conditions.
- L. Engine oil usage which is not recommended(Mineral type, Semi-synthetic, Lower grade spec, etc.)

### **EXPLANATION OF SCHEDULED MAINTENANCE ITEMS**

# **Engine Oil and Filter**

The engine oil and filter should be changed at the intervals specified in the maintenance schedule. If the vehicle is being driven in severe conditions, more frequent oil and filter changes are required.

### **Drive Belts**

Inspect all drive belts for evidence of cuts, cracks, excessive wear or oil saturation and replace if necessary. Drive belts should be checked periodically for proper tension and adjusted as necessary.



# Information

When you are inspecting the belt, turn the engine off.

# **Fuel Filter**

A clogged-up fuel filter may limit the vehicle driving speed, damage the emission system, and cause the hard starting. When a considerable amount of foreign substances are accumulated in the fuel tank, the fuel filter should be replaced.

Upon installing a new fuel filter, operate the engine for several minutes, and check the connections for any leakages. Fuel filters should be installed by an authorized HYUNDAI dealer.

# Fuel Lines, Fuel Hoses and Connections

Check the fuel lines, fuel hoses and connections for leakage and damage. Have an authorized HYUNDAI dealer replace any damaged or leaking parts immediately.

# **Vapor Hose and Fuel Filler Cap**

The vapor hose and fuel filler cap should be inspected at those intervals specified in the maintenance schedule. Make sure a new vapor hose or fuel filler cap is correctly replaced.

### Air Cleaner Filter

A genuine HYUNDAI air cleaner filter is recommended when the filter is replaced.

# **Spark Plugs**

Make sure to install new spark plugs of the correct heat range.

When assembling parts, be sure to wipe out foreign substances inside and outside of the boot bottom of the ignition coil and the insulator of the spark plug with a soft cloth to prevent contamination of the spark plug insulator.



# WARNING

Do not disconnect and inspect spark plugs when the engine is hot. You may burn yourself.

# **Cooling System**

Check cooling system components, such as radiator, coolant reservoir, hoses and connections for leakage and damage. Replace any damaged parts.

#### **Engine Coolant**

The coolant should be changed at the intervals specified in the maintenance schedule.

# Manual Transmission Fluid (if equipped)

Manual transmission fluid should not be checked under normal usage conditions. Have the manual transmission fluid changed by an authorized HYUNDAI dealer according to the maintenance schedule.

# Dual clutch transmission fluid (if equipped)

Dual clutch transmission fluid should not be checked under normal usage conditions.

Have the Dual clutch transmission fluid is changed by an authorized HYUNDAI dealer according to the maintenance schedule.

#### **Brake Hoses and Lines**

Visually check for proper installation, chafing, cracks, deterioration and any leakage. Replace any deteriorated or damaged parts immediately.

#### **Brake Fluid**

Check the brake fluid level in the brake fluid reservoir. The level should be between the MIN and the MAX marks on the side of the reservoir. Use only hydraulic brake fluid conforming to DOT 4 specification..

#### **Parking Brake**

Inspect the parking brake system including the parking brake pedal and cables.

# Brake Discs, Pads, Calipers and Rotors

Check the pads for excessive wear, discs for run out and wear, and calipers for fluid leakage.

#### **Suspension Mounting Bolts**

Check the suspension connections for looseness or damage. Retighten to the specified torque.

# Steering Gear Box, Linkage & Boots/Lower Arm Ball Joint

With the vehicle stopped and the engine off, check for excessive freeplay in the steering wheel. Check the linkage for bends or damage. Check the dust boots and ball joints for deterioration, cracks, or damage.

Replace any damaged parts.

#### **Drive Axle Shafts and Boots**

Check the drive axle shafts, boots and clamps for cracks, deterioration, or damage. Replace any damaged parts and, if necessary, repack the grease.

#### **Air Conditioning Refrigerant**

Check the air conditioning lines and connections for leakage and damage. Engine Oil


#### **ENGINE OIL**

#### **Checking the Engine Oil Level**

Engine oil is used for lubricating, cooling, and operating various hydraulic components in the engine. Engine oil consumption while driving is normal, and it is necessary to check and refill the engine oil regularly. Also, check and refill the oil level within the recommended maintenance schedule to prevent deterioration of oil performance.

Check the engine oil following the below procedure.

- 1. Follow all of the oil manufacturer's precautions.
- Be sure the vehicle is on the level ground in P (Park) with the parking brake set. If possible, block the wheels.
- 3. Turn the engine on and allow the engine to reach normal operating temperature.
- 4. Turn the engine off and wait about fifteen minutes for the oil to return to the oil pan.
- 5. Pull the dipstick out, wipe it clean, and re-insert it fully.





- Pull the dipstick out again and check the level. The level should be between F and L.
- 7. If the oil level is below L, add enough oil to bring the level to F.

Use only the specified engine oil. (refer to "Recommended Lubricants and Capacities" in chapter 2).

#### NOTICE

To prevent damage to your engine:

- Do not spill engine oil when adding or changing engine oil. Use a funnel to help prevent oil from being spilled on engine components. Wipe off spilled oil immediately.
- The engine oil consumption may increase while you break in a new vehicle and it will be stabilized after driving 4,000 miles (6,000 km).
- The engine oil consumption can be affected by driving habits, climate conditions, traffic conditions, oil quality, etc. Therefore, it is recommended that you inspect the engine oil level regularly and refill it if necessary.

# Checking the Engine Oil and Filter



- The lubrication, rust prevention, cooling, and cleaning effect of the engine oil will gradually degrade during its use. Have the engine oil and filter changed by an authorized HYUNDAI dealer according to the Oil Life Management System Instructions or the Maintenance Schedule at the beginning of this chapter.
- If the maintenance schedule to replace engine oil is exceeded, the engine oil performance may deteriorate, and the engine condition may be affected. Therefore, replace the engine oil according to the maintenance schedule.
- To keep the engine in optimal condition, use the recommended engine oil and filter. If the recommended engine oil and filter are not used, replace it according to the maintenance schedule under severe usage conditions.
- The purpose of the maintenance schedule for engine oil replacement is to prevent oil deterioration and it is irrelevant to oil consumption. Check and refill engine oil regularly.



### ! CAUTION

The engine oil is very hot immediately after the vehicle has been driven and can cause burns during replacement. Replace the engine oil after the engine oil has cooled down.



#### WARNING

# CALIFORNIA PROPOSITION 65 WARNING

Engine oil contains chemicals known to the State of California to cause cancer, birth defects and reproductive harm. Used engine oil may cause irritation or cancer of the skin if left in contact with the skin for prolonged periods of time. Always protect your skin by washing your hands thoroughly with soap and warm water as soon as possible after handling used oil.

#### NOTICE

Never add any additives to the engine oil. Engine oil additives can change the properties of engine oil and may cause serious engine failure.

#### **ENGINE COOLANT**

The high-pressure cooling system has a reservoir filled with year-round antifreeze coolant. The reservoir is filled at the factory.

Check the antifreeze protection and coolant level at least once a year, at the beginning of the winter season and before traveling to a colder climate.

#### NOTICE

- When the engine overheats from low engine coolant, suddenly adding engine coolant may cause cracks in the engine. To prevent damage, add engine coolant slowly in small quantities.
- Do not drive with no engine coolant. It may cause water pump failure and engine seizure, etc.

# **Checking the Engine Coolant Level**






Check the condition and connections of all cooling system hoses and heater hoses. Replace any swollen or deteriorated hoses.

The coolant level should be filled between MAX and MIN (or F (Full) and L (Low)) marks on the side of the coolant reservoir when the engine is cool.

If the coolant level is low, add enough distilled (deionized) water. Bring the level to MAX, (or F (Full)) but do not overfill.

## **MARNING**

Make sure the coolant cap is properly closed after refilling coolant. Otherwise the engine could be overheated while driving.



 Check if the coolant cap label is straight in front.



Make sure that the tiny protrusions inside the coolant cap are securely interlocked.

## **MARNING**



Never remove the engine coolant cap or the drain plug while the engine and radiator are hot. Hot coolant and steam may blow out under pressure, causing serious injury.

Turn the vehicle off and wait until the engine cools down. Use extreme care when removing the engine coolant cap. Wrap a thick towel around it, and turn it counterclockwise slowly. Step back while the pressure is released from the cooling system. When you are sure all the pressure has been released, using a thick towel, and continue turning counterclockwise to remove it.

### i

#### Information

The coolant level is influenced by the engine temperature. Before checking or refilling the coolant, turn the engine off.

#### Recommended engine coolant

- When adding coolant, use only distilled (deionized) water for your vehicle and never mix hard water in the coolant filled at the factory.
- An improper coolant mixture can result in severe malfunction or engine damage.
- The engine in your vehicle has aluminum engine parts and must be protected by an ethylene-glycol with phosphate based coolant to prevent corrosion and freezing.
- Do not use alcohol or methanol coolant or mix them with the specified coolant.
- Do not use a solution that contains more than 60% antifreeze or less than 35% antifreeze, which would reduce the effectiveness of the solution.

For mixing percentage, refer to the following table:

Ambient	Mixture Percentage (volume)	
Temperature	Antifreeze	Water
5°F (-15°C)	35	65
-13°F (-25°C)	40	60
-31°F (-35°C)	50	50
-49°F (-45°C)	60	40



#### Information

If in doubt about the mix ratio, a 50% water and 50% antifreeze mix is the easiest to mix together as it will be the same quantity of each. It is suitable to use for most temperature ranges of - 31°F and higher.







The electric motor for the cooling fan may continue to operate or start up when the engine is not running and can cause serious injury. Keep hands, clothing and tools away from the rotating fan blades of the cooling fan.

The electric motor for the cooling fan is controlled by engine coolant temperature, refrigerant pressure and vehicle speed. As the engine coolant temperature decreases, the electric motor will automatically shut off. This is a normal condition.

Always turn off the vehicle unless the vehicle has to be inspected with the engine on. Be cautious as the cooling fan may operate if the negative (-) battery terminal is not disconnected.

### **Changing Engine Coolant**

Have coolant changed by an authorized HYUNDAI dealer according to the Maintenance Schedule at the beginning of this chapter.

# **MARNING**

Do not use engine coolant or antifreeze in the washer fluid reservoir.

Engine coolant can severely obscure visibility when sprayed on the windshield and may cause loss of vehicle control resulting in an accident.

Engine coolant may also cause damage to paint and body trim.

#### NOTICE

To prevent damage to engine parts, put a thick towel around the radiator cap before refilling the coolant to prevent the coolant from overflowing into engine parts, such as the alternator.

#### **BRAKE/CLUTCH FLUID**

# Checking the Brake/Clutch Fluid Level



Check the fluid level in the reservoir periodically. The fluid level should be between MAX and MIN marks on the side of the reservoir.

Before removing the reservoir cap and adding brake fluid, clean the area around the reservoir cap thoroughly to prevent brake fluid contamination.

If the level is low, add fluid to the MAX level. The level will fall with accumulated mileage. This is a normal condition associated with the wear of the brake linings.

If the fluid level is excessively low, have the system be checked by an authorized HYUNDAI dealer.

## *i* Information

Use only the specified brake/clutch fluid. Refer to "Recommended lubricants and capacities" in chapter 2.

## *i* Information

Before removing the brake/clutch filler cap, read the warning on the cap.

# *i* Information

Clean the filler cap before removing. Use only DOT4 brake/clutch fluid from a sealed container.

## **⚠** WARNING

Do not let brake fluid enter into your eyes. If brake fluid gets in your eyes, flush your eyes with clean water for at least 15 minutes and get immediate medical attention.


#### NOTICE

- Do not allow brake/clutch fluid to contact the vehicle's body paint, as it will result in paint damage.
- NEVER use brake fluid which has been exposed to open air for an extended time, as its quality cannot be guaranteed. It should be disposed of properly.
- Don't put in the wrong type of fluid.
   A few drops of mineralbased oil, such as engine oil in your brake system can damage system parts.
- To maintain the best braking performance and ABS/ESC performance, have you use genuine brake/clutch fluid that conform to specifications.

(Standard: SAE J1704 DOT-4 LV, ISO4925 CLASS-6 and FMVSS 116 DOT-4)

#### **WASHER FLUID**

#### **Checking the Washer Fluid Level**



Check the fluid level in the washer fluid reservoir and add fluid if necessary. Plain water may be used if washer fluid is not available. However, use washer solvent with antifreeze characteristics in cold climates to prevent freezing.

# / WARNING

To prevent serious injury or death, take the following safety precautions when using washer fluid:

- Do not use engine coolant or antifreeze in the washer fluid
  - Engine coolant can severely obscure visibility when sprayed on the windshield and may cause loss of vehicle control resulting in an accident or damage to paint and body trim.
- Do not allow sparks or flames to contact the washer fluid or the washer fluid reservoir. Washer fluid may contain alcohol and can be flammable.
- Do not drink washer fluid and avoid contact with skin. Washer fluid is harmful to humans and animals.
- Keep washer fluid away from children and animals.

#### **PARKING BRAKE**

#### **Checking the Parking Brake**




Check the stroke of the parking brake by counting the number of "clicks" heard while fully applying it from the released position. Also, the parking brake alone should securely hold the vehicle on a fairly steep grade. If the stroke is more or less than specified, have the system serviced by an authorized HYUNDAI dealer.

Stroke: 5~7 "clicks" at a force of 44 lbs (20 kg, 196 N)

#### **AIR CLEANER**


#### **Filter Replacement**




The air cleaner filter can be cleaned for inspection using compressed air. Do not attempt to wash or to rinse it, as water will damage the filter. If soiled, the air cleaner filter must be replaced.




1. Loosen the air cleaner cover attaching clip (1) and open the cover.



2. Replace the air cleaner filter.





- 3. Insert the air cleaner cover in the hinge (2) and engage the clip (3) after closing the cover.
- 4. Check that the cover is firmly installed.

# *i* Information

If the vehicle is operated in extremely dusty or sandy areas, replace the element more often than the usual recommended intervals (refer to "Maintenance Under Severe Usage Conditions" in this chapter).

#### NOTICE

- Do not drive with the air cleaner filter removed. This will result in excessive engine wear.
- When removing the air cleaner filter, be careful that dust or dirt does not enter the air intake, or damage may result.
- Use HYUNDAI genuine parts or the equivalent specified for your vehicle.
   Use of parts without the matching quality could damage the air flow sensor.

#### **CABIN AIR FILTER**


#### **Filter Inspection**

The cabin air filter should be replaced according to the Maintenance Schedule. If the vehicle is operated in severely air-polluted cities or on dusty rough roads for a long period, it should be inspected more frequently and replaced earlier. When you replace the cabin air filter, replace it performing the following procedure, and be careful to avoid damaging other components.

#### **Filter Replacement**



 Push in both sides of the glove box as shown. This will ensure that the glove box stopper pins will get released from its holding location allowing the glove box to hang.



2. Remove the cabin air filter case while pressing the lock on the right side of the cover.



- 3. Replace the cabin air filter.
- 4. Reassemble in the reverse order of disassembly.

#### NOTICE

Install a new cabin air filter in the correct direction with the arrow symbol  $(\downarrow)$  facing downwards, otherwise, it may be noisy and the effectiveness of the filter may be reduced.

#### **WIPER BLADES**

#### **Blade Inspection**

Contamination of either the windshield or the wiper blades with foreign matter can reduce the effectiveness of the windshield wipers.

Common sources of contamination are insects, tree sap, and hot wax treatments used by some commercial car washes. If the blades are not wiping properly, clean both the window and the blades with a good cleaner or mild detergent, and rinse thoroughly with clean water.

#### NOTICE

To prevent damage to the wiper blades, arms or other components, do not:

- Use gasoline, kerosene, paint thinner, or other solvents on or near them.
- Attempt to move the wipers manually.
- Use non-specified wiper blades.

## *i* Information

Commercial hot waxes applied by automatic car washes have been known to make the windshield difficult to clean.

# *i* Information

Wiper blades are consumable items. Normal wear of the wipers may not be covered by your vehicle warranty.

#### **Blade Replacement**

When the wipers no longer clean adequately, the blades may be worn or cracked, and require replacement.

#### NOTICE

- In order to prevent damage to the hood and the wiper arms, the wiper arms should only be lifted when in the top wiping position.
- Always return the wiper arms to the windshield before driving.

#### NOTICE

The use of a non-specified wiper blade could result in wiper malfunction and failure


# Front windshield wiper service positions




This vehicle has a "hidden" wiper design which means that the wipers cannot be lifted when they are in their bottom resting position.

- Within 20 seconds of turning off the engine, lift and hold the wiper lever up to the MIST position for about 2 seconds until the wipers move to the top wipe position.
- 2. At this time you can lift the wipers off the windshield.
- 3. Gently put the wipers back down onto the windshield.
- 4. Turn the wipers to any ON position to return the wipers to the bottom resting position.

#### Blade replacement



1. Raise the wiper arm.



Lift up the wiper blade clip. Then pull down the blade assembly and remove it.



- 3. Install the new blade assembly.
- 4. Return the wiper arm on the windshield.

#### **BATTERY**



#### WARNING

To prevent SERIOUS INJURY or DEATH to you or bystanders, always follow these precautions when working near or handling the battery:



Always read and follow instructions carefully when handling a battery.



Wear eye protection designed to protect the eyes from acid splashes.



Keep all flames, sparks, or smoking materials away from the battery.



Hydrogen is always present in battery cells, is highly combustible, and may explode if ignited.



Keep batteries out of reach of children.



Batteries contain sulfuric acid which is highly corrosive. Do not allow acid to contact your eyes, skin or clothing. If acid gets into your eyes, flush your eyes with clean water for at least 15 minutes and get immediate medical attention. If acid gets on your skin, thoroughly wash the area. If you feel pain or a burning sensation, get medical attention immediately.

- When lifting a plastic-cased battery, excessive pressure on the case may cause battery acid to leak. Lift with a battery carrier or with your hands on opposite corners.
- Do not attempt to jump start your vehicle if your battery is frozen.
- NEVER attempt to recharge the battery when the vehicle's battery cables are connected to the battery.
- The electrical ignition system works with high voltage. NEVER touch these components with the engine running or when the Engine Start/ Stop button is in the ON position.
- Do not allow the (+) and (-) jumper cables to touch. It may cause sparks.
- The battery may rupture or explode when you jump start with a low or frozen battery.
- Leaked battery electrolyte due to repeated driving on sharp curves (for example, on circuits) may cause safety problem. Avoid repeated driving on sharp curves.



#### **WARNING**

#### CALIFORNIA PROPOSITION 65 WARNING


Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer, birth defects and reproductive harm. Batteries also contain other chemicals known to the State of California to cause cancer. Wash hands after handling.

#### NOTICE

Always follow these instructions when handling your vehicle's battery to prevent damage to your battery:

- When you do not use the vehicle for a long time in a low temperature area, disconnect the battery and keep it indoors.
- Always charge the battery fully to prevent battery case damage in low temperature areas.
- Prevent liquid from wetting the battery terminals. The performance of the battery may be degraded, and may cause injury. Be cautious when loading liquid in the trunk.
- · Do not tilt the battery.
- If you connect unauthorized electronic devices to the battery, the battery may be discharged. Never use unauthorized devices.

#### **For Best Battery Service**



- · Keep the battery securely mounted.
- · Keep the battery top clean and dry.
- Keep the terminals and connections clean, tight, and coated with petroleum jelly or terminal grease.
- Rinse any spilled acid from the battery immediately with a solution of water and baking soda.

#### **Battery Capacity Label**



- \* The actual battery label in the vehicle may differ from the illustration.
- 1. CMF60L-DIN: The HYUNDAI model name of battery
- 2. 12 V: The nominal voltage
- 3. 68 Ah (20HR): The nominal capacity (in Ampere hours)
- 4. RC 110 min: The nominal reserve capacity (in min.)
- 5. CCA 600: The cold-test current in amperes by SAE
- 6. 600 A: The cold-test current in amperes by EN

#### **Battery Recharging**

# **MARNING**

Always follow these instructions when recharging your vehicle's battery to avoid the risk of SERIOUS INJURY or DEATH from explosions or acid burns:

- Before performing maintenance or recharging the battery, turn off all accessories and press the Engine Start/Stop button to the OFF position.
- Keep all flames, sparks, or smoking materials away from the battery.
- Always work outdoors or in an area with plenty of ventilation.
- Wear eye protection when checking the battery during charging.
- The battery must be removed from the vehicle and placed in a well ventilated area.
- Watch the battery during charging, and stop or reduce the charging rate if the battery cells begin boiling violently.
- The negative battery cable must be removed first and installed last when the battery is disconnected. Disconnect the battery charger in the following order:
  - Turn off the battery charger main switch.
  - 2. Unhook the negative clamp from the negative battery terminal.
  - 3. Unhook the positive clamp from the positive battery terminal.
- Always use a genuine HYUNDAI approved battery when you replace the battery.

#### By jump starting

After a jump start from a good battery, drive the vehicle for 20-30 minutes before it is shutoff. The vehicle may not restart if you shut it off before the battery had a chance to adequately recharge. See "Jump Starting" in chapter 8 for more information on jump starting procedures.

### i

#### Information



An inappropriately disposed battery can be harmful to the environment and human health. Dispose of the battery according to your local law(s) or regulations.

#### **Reset Items**

Items should be reset after the battery has been discharged or the battery has been disconnected.

- Auto up/down window (See chapter 5)
- Sunroof (See chapter 5)
- Trip computer (See chapter 4)
- Climate control system (See chapter 5)

#### TIRES AND WHEELS



#### ! WARNING

Tire failure may cause loss of vehicle control resulting in an accident. To reduce risk of SERIOUS INJURY or DEATH, take the following precautions:

- Inspect your tires monthly for proper inflation as well as wear and damage.
- The recommended cold tire pressure for your vehicle can be found in this manual and on the tire label located on the driver's side center pillar. Always use a tire pressure gauge to measure tire pressure. Tires with too much or too little pressure wear unevenly causing poor handling.
- Check the pressure of the spare every time you check the pressure of the other tires on vour vehicle.
- Replace tires that are worn, show uneven wear, or are damaged. Worn tires can cause loss of braking effectiveness, steering control, or traction.
- ALWAYS replace tires with the same type, size, brand, construction and tread pattern as each tire that was originally supplied with this vehicle. Using tires and wheels other than the recommended sizes could cause unusual handling characteristics, poor vehicle control, or negatively affect your vehicle's Anti-Lock Brake System (ABS) resulting in a serious accident.

# Information - Power Hop

When fully accelerating the vehicle from standstill, a front tire oscillation called "Power Hop" of Elantra N may occur due to the high torque of engine and the characteristics of high performance tire. This may be affected by road condition and temperatures.

Additionally it is a normal phenome non in powerful front-wheel drive vehicles. Elantra N will act on this phenomenon with the traction control in all ESC modes with the main focus on high performance character.

#### **Tire Care**

For proper maintenance, safety, and maximum fuel economy, you must always maintain recommended tire inflation pressures and stay within the load limits and weight distribution recommended for your vehicle



All specifications (sizes and pressures) can be found on a label attached to the driver's side center. nillar.

#### **Recommended Cold Tire Inflation Pressures**

All tire pressures should be checked when the tires are cold. "Cold tires" means the vehicle has not been driven for at least three hours or has been driven for less than one mile (1.6 km).

Warm tires normally exceed recommended cold tire pressures by 4 to 6 psi (28 to 41 kPa). Do not release air from warm tires to adjust the pressure or the tires will be under-inflated. For recommended inflation pressure, refer to "Tire and Wheels" in chapter 2.



#### **!** WARNING

Recommended pressures must be maintained for the best ride, vehicle handling, and minimum tire wear.

Over-inflation or under-inflation can reduce tire life, adversely affect vehicle handling, and lead to sudden tire failure that could result in loss of vehicle control resulting in an accident.

Severe under-inflation can lead to severe heat build-up, causing blowouts, tread separation and other tire failures that can result in the loss of vehicle control resulting in an accident. This risk is much higher on hot days and when driving for long periods at high speeds.



#### **!** CAUTION

- Under-inflation results in excessive wear, poor handling and reduced fuel economy. Wheel deformation is also possible. Keep your tire pressures at the proper levels. If a tire frequently needs refilling, have it checked by an authorized HYUNDAI dealer.
- Over-inflation produces a harsh ride, excessive wear at the center of the tire tread, and a greater possibility of damage from road hazards.

#### **Check Tire Inflation Pressure**

Check your tires, including the spare tire, once a month or more.

#### How to check

Use a good quality tire pressure gauge to check tire pressure. You can not tell if your tires are properly inflated simply by looking at them. Radial tires may look properly inflated when they are underinflated.

Remove the valve cap from the tire valve stem. Press the tire gauge firmly onto the valve to get a pressure measurement. If the cold tire inflation pressure matches the recommended pressure on the tire label located on the driver's side center pillar or in this manual. No further adjustment is necessary. If the pressure is low, add air until you reach the recommended pressure. Make sure to put the valve caps back on the valve stems. Without the valve cap, dirt or moisture could get into the valve core and cause air leakage. If a valve cap is missing, install a new one as soon as possible.

If you overfill the tire, release air by pushing on the metal stem in the center of the tire valve. Recheck the tire pressure with the tire gauge. Be sure to put the valve caps back on the valve stems. Without the valve cap, dirt or moisture could get into the valve core and cause air leakage. If a valve cap is missing, install a new one as soon as possible.

A cold tire means the vehicle has been sitting for 3 hours and driven for less than 1 mile (1.6 km) in that 3 hour period.


Allow the tire to cool before measuring the inflation pressure. Always be sure the tire is cold before inflating to the recommended pressure.

#### **Tire Rotation**

To equalize tread wear, HYUNDAI recommends that the tires be rotated according to the maintenance schedule or sooner if irregular wear develops.

During rotation, check the tires for correct balance.

When rotating tires, check for uneven wear and damage. Abnormal wear is usually caused by incorrect tire pressure, improper wheel alignment, out-of-balance wheels, severe braking or severe cornering. Look for bumps or bulges in the tread or side of the tire. Replace the tire if you find any of these conditions. Replace the tire if fabric or cord is visible. After rotation, be sure to bring the front and rear tire pressures to specification and check lug nut tightness (proper torque is 79~94 lbf·ft [11~13 kgf·m]).



Disc brake pads should be inspected for wear whenever tires are rotated.

# *i* Information

The outside and inside of the unsymmetrical tire is distinguishable. When installing an unsymmetrical tire, be sure to install the side marked "outside" face the outside. If the side marked "inside" is installed on the outside, it will have a negative effect on vehicle performance.

### **MARNING**

Do not mix bias ply and radial ply tires under any circumstances. This may cause unusual handling characteristics that may cause loss of vehicle control resulting in an accident.

# Wheel Alignment and Tire Balance

The wheels on your vehicle were aligned and balanced carefully at the factory to give you the longest tire life and best overall performance.

In most cases, you will not need to have your wheels aligned again. However, if you notice unusual tire wear or your vehicle pulling one way or the other, the alignment may need to be reset.

If you notice your vehicle vibrating when driving on a smooth road, your wheels may need to be rebalanced.

#### NOTICE

Improper wheel weights can damage your vehicle's aluminum wheels. Use only approved wheel weights.

#### **Tire Replacement**



If the tire is worn evenly, a tread wear indicator will appear as a solid band across the tread. This shows there is less than 1/16 inch (1.6 mm) of tread left on the tire. Replace the tire when this happens.

Do not wait for the tread surface to become level with the tread wear indicators before replacing the tire.



# To reduce the risk of DEATH or SERIOUS INJURY:

- Replace tires that are worn, show uneven wear, or are damaged.
   Worn tires can cause loss of braking effectiveness, steering control, and traction.
- Always replace tires with the same size as each tire that was originally supplied with this vehicle. Using tires and wheels other than the recommended sizes could cause unusual handling characteristics, poor vehicle control, or negatively affect your vehicle's Anti-Lock Brake System (ABS) resulting in a serious accident.
- Tires degrade over time, even when they are not being used.
   Regardless of the remaining tread, HYUNDAI recommends that tires be replaced after six (6) years of normal service.
- When replacing tires, it is recommended to replace the two front or two rear tires as a pair. Replacing just one tire can seriously affect your vehicle's handling. If only replacing one pair of tires, it is recommended to install the pair of new tires on the rear axle.
- Heat caused by hot climates or frequent high loading conditions can accelerate the aging process.
   Failure to follow this warning may cause sudden tire failure, which could lead to a loss of vehicle control resulting in an accident.

#### Wheel Replacement

When replacing the metal wheels for any reason, make sure the new wheels are equivalent to the original factory units in diameter, rim width and offset.

#### **Tire Traction**

Tire traction can be reduced if you drive on worn tires, tires that are improperly inflated or on slippery road surfaces. Tires should be replaced when the tread depth is at least 2/32 inch (1.6 mm). To reduce the possibility of losing control, slow down whenever there is rain, snow or ice on the road.


#### **Tire Maintenance**

In addition to proper inflation, correct wheel alignment helps to decrease tire wear. If you find a tire is worn unevenly, have your dealer check the wheel alignment.

When you have new tires installed, make sure they are balanced. This will increase vehicle ride comfort and tire life. Additionally, a tire should always be rebalanced if it is removed from the wheel.

#### **Tire Sidewall Labeling**

This information identifies and describes the fundamental characteristics of the tire and also provides the tire identification number (TIN) for safety standard certification. The TIN can be used to identify the tire in case of a recall.



#### 1. Manufacturer or brand name

Manufacturer or brand name is shown.

#### 2. Tire size designation

A tire's sidewall is marked with a tire size designation. You will need this information when selecting replacement tires for your car. The following explains what the letters and numbers in the tire size designation mean.

Example tire size designation:

(These numbers are provided as an example only; your tire size designator could vary depending on your vehicle.)

#### 245/35 ZR19 93Y

245 - Tire width in millimeters.

- 35 Aspect ratio. The tire's section height as a percentage of its width.
- ZR Tire construction code (Radial).
- 19 Rim diameter in inches.
- 93 Load Index, a numerical code associated with the maximum load the tire can carry.
- Y Speed Rating Symbol. See the speed rating chart in this section for additional information.

#### Wheel size designation

Wheels are also marked with important information that you need if you ever have to replace one. The following explains what the letters and numbers in the wheel size designation mean.

Example wheel size designation:

#### 8.0J X 19

8.0 - Rim width in inches.

J - Rim contour designation.

19 - Rim diameter in inches.

#### Tire speed ratings

The chart below lists many of the different speed ratings currently being used for passenger vehicle tires. The speed rating is part of the tire size designation on the sidewall of the tire. This symbol corresponds to that tire's designed maximum safe operating speed.

Speed Rating Symbol	Maximum Speed	
S	112 mph (180 km/h)	
T	118 mph (190 km/h)	
Н	130 mph (210 km/h)	
V	149 mph (240 km/h)	
W	168 mph (270 km/h)	
Υ	186 mph (300 km/h)	

# 3. Checking tire life (TIN: Tire Identification Number)

Any tires that are over six years old, based on the manufacturing date, (including the spare tire) should be replaced by new tires. You can find the manufacturing date on the tire sidewall (possibly on the inside of the wheel), displaying the DOT Code. The DOT Code is a series of numbers on a tire consisting of numbers and English letters. The manufacturing date is designated by the last four digits (characters) of the DOT code.

#### DOT: XXXX XXXX OOOO

The front part of the DOT shows a plant code number, tire size and tread pattern and the last four numbers indicate week and year manufactured.

For example:

DOT XXXX XXXX 1425 represents that the tire was produced in the 14th week of 2025.

#### 4. Tire ply composition and material

The number of layers or plies of rubber-coated fabric in the tire. Tire manufacturers also must indicate the materials in the tire, which include steel, nylon, polyester, and others. The letter "R" means radial ply construction; the letter "D" means diagonal or bias ply construction; and the letter "B" means belted-bias ply construction.

# 5. Maximum permissible inflation pressure

This number is the greatest amount of air pressure that should be put in the tire. Do not exceed the maximum permissible inflation pressure. Refer to the Tire and Loading Information label for recommended inflation pressure.

#### 6. Maximum load rating

This number indicates the maximum load in kilograms and pounds that can be carried by the tire. When replacing the tires on the vehicle, always use a tire that has the same load rating as the factory installed tire.

#### 7. Uniform tire quality grading

Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width.

For example: TREAD WEAR 200 TRACTION AA TEMPERATURE A

#### Tread wear

The tread wear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course. For example, a tire graded 150 would wear one-and-a-half times (1½) as well on the government course as a tire graded 100.

The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate. These grades are molded on the sidewalls of passenger vehicle tires. The tires available as standard or optional equipment on your vehicle may vary with respect to grade.

#### Traction AA, A, B & C

The traction grades, from highest to lowest, are AA, A, B and C. Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.



#### **WARNING**

The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

#### Temperature A, B & C

The temperature grades are A (the highest), B and C representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel.

Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. Grade C responds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.



#### WARNING

The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, under-inflation, over-inflation, or excessive loading, either separately or in combination, can cause heat build-up and possible sudden tire failure. This may cause loss of vehicle control resulting in an accident.

#### **Tire Terminology and Definitions**

#### Air Pressure

The amount of air inside the tire pressing outward on the tire. Air pressure is expressed in pounds per square inch (psi) or kilopascal (kPa).

#### **Accessory Weight**

This means the combined weight of optional accessories. Some examples of optional accessories are automatic transmission, power seats, and air conditioning.

#### Aspect Ratio

The relationship of a tire's height to its width.

#### Belt

A rubber coated layer of cords that is located between the plies and the tread. Cords may be made from steel or other reinforcing materials.

#### Bead

The tire bead contains steel wires wrapped by steel cords that hold the tire onto the rim.

#### Bias Ply Tire

A pneumatic tire in which the plies are laid at alternate angles less than 90 degrees to the centerline of the tread.

#### **Cold Tire Pressure**

The amount of air pressure in a tire, measured in pounds per square inch (psi) or kilopascals (kPa) before a tire has built up heat from driving.

#### **Curb Weight**

This means the weight of a motor vehicle with standard and optional equipment including the maximum capacity of fuel, oil and coolant, but without passengers and cargo.

#### **DOT Markings**

A code molded into the sidewall of a tire signifying that the tire is in compliance with the U.S. Department of Transportation motor vehicle safety standards. The DOT code includes the Tire Identification Number (TIN), an alphanumeric designator which can also identify the tire manufacturer, production plant, brand and date of production.

#### **GVWR**

Gross Vehicle Weight Rating

#### **GAWR FRT**

Gross Axle Weight Rating for the Front Axle.

#### **GAWR RR**

Gross Axle Weight Rating for the Rear axle.

#### Intended Outboard Sidewall

The side of an asymmetrical tire, that must always face outward when mounted on a vehicle.

#### Kilopascal (kPa)

The metric unit for air pressure.

#### Light truck (LT) tire

A tire designated by its manufacturer as primarily intended for use on lightweight trucks or multipurpose passenger vehicles.

#### Load ratings

The maximum load that a tire is rated to carry for a given inflation pressure.

#### Load Index

An assigned number ranging from 1 to 279 that corresponds to the load carrying capacity of a tire.

#### Maximum Inflation Pressure

The maximum air pressure to which a cold tire may be inflated. The maximum air pressure is molded onto the sidewall.

#### Maximum Load Rating

The load rating for a tire at the maximum permissible inflation pressure for that tire.

#### Maximum Loaded Vehicle Weight

The sum of curb weight; accessory weight; vehicle capacity weight; and production options weight.

#### Normal Occupant Weight

The number of occupants a vehicle is designed to seat multiplied by 150 pounds (68 kg).

#### **Occupant Distribution**

Designated seating positions.

#### **Outward Facing Sidewall**

An asymmetrical tire has a particular side that faces outward when mounted on a vehicle. The outward facing sidewall bears white lettering or bears manufacturer, brand, and/or model name molding that is higher or deeper than the same moldings on the inner facing sidewall.

#### Passenger (P-Metric) tire

A tire used on passenger cars and some light duty trucks and multipurpose vehicles.

#### Ply

A layer of rubber-coated parallel cords.

#### Pneumatic tire

A mechanical device made of rubber, chemicals, fabric and steel or other materials, that, when mounted on an automotive wheel provides the traction and contains the gas or fluid that sustains the load.

#### Pneumatic options weight

The combined weight of installed regular production options weighing over 5 lb. (2.3 kg) in excess of the standard items which they replace, not previously considered in curb weight or accessory weight, including heavy duty breaks, ride levelers, roof rack, heavy duty battery, and special trim.

#### **Recommended Inflation Pressure**

Vehicle manufacturer's recommended tire inflation pressure as shown on the tire placard.

#### Radial Ply Tire

A pneumatic tire in which the ply cords that extend to the beads are laid at 90 degrees to the centerline of the tread.

#### Rim

A metal support for a tire and upon which the tire beads are seated.

#### Sidewall

The portion of a tire between the tread and the bead.

#### Speed Rating

An alphanumeric code assigned to a tire indicating the maximum speed at which a tire can operate.

#### **Traction**

The friction between the tire and the road surface. The amount of grip provided.

#### Tread

The portion of a tire that comes into contact with the road.

#### Treadwear Indicators

Narrow bands, sometimes called "wear bars", that show across the tread of a tire when only 1/16 inch of tread remains.

#### **UTQGS**

Uniform Tire Quality Grading Standards is a tire information system that provides consumers with ratings for a tire's traction, temperature and treadwear. Ratings are determined by tire manufacturers using government testing procedures. The ratings are molded into the sidewall of the tire.

#### Vehicle Capacity Weight

The number of designated seating positions multiplied by 150 lbs. (68 kg) plus the rated cargo and luggage load.

#### Vehicle Maximum Load on the Tire

Load on an individual tire due to curb and accessory weight plus maximum occupant and cargo weight.

#### Vehicle Normal Load on the Tire

Load on an individual tire that is determined by distributing to each axle its share of the curb weight, accessory weight, and normal occupant weight and dividing by 2.

#### Vehicle Placard

A label permanently attached to a vehicle showing the original equipment tire size and recommended inflation pressure.

#### **All Season Tires**

HYUNDAI specifies all season tires on some models to provide good performance for use all year round, including snowy and icy road conditions. All season tires are identified by ALL SEASON and/or M+S (Mud and Snow) on the tire sidewall. Snow tires have better snow traction than all season tires and may be more appropriate in some areas

#### **Summer Tires**

HYUNDAI specifies summer tires on some models to provide superior performance on dry roads. Summer tire performance is substantially reduced in snow and ice. Summer tires do not have the tire traction rating M+S (Mud and Snow) on the tire side wall. If you plan to operate your vehicle in snowy or icy conditions, HYUNDAI recommends the use of snow tires or all season tires on all four wheels.

#### **Snow Tires**

If you equip your car with snow tires, they should be the same size and have the same load capacity as the original tires. Snow tires should be installed on all four wheels: otherwise, poor handling may result. Snow tires should carry 4 psi (28 kPa) more air pressure than the pressure recommended for the standard tires on the tire label on the driver's side of the center pillar, or up to the maximum pressure shown on the tire sidewall, whichever is less. Do not drive faster than 75 mph (120 km/h) when your vehicle is equipped with snow tires.

#### **Radial-Ply Tires**

Radial-ply tires provide improved tread life, road hazard resistance and smoother high speed ride. The radial-ply tires used on this vehicle are of belted construction, and are selected to complement the ride and handling characteristics of your vehicle.

Radial-ply tires have the same load carrying capacity, as bias-ply or bias belted tires of the same size. and use the same recommended inflation pressure. Mixing of radialply tires with bias-ply or bias belted tires is not recommended. Any combinations of radial-ply and biasply or bias belted tires when used on the same vehicle will seriously deteriorate vehicle handling. The best rule to follow is: Identical pairs of radial-ply tires should always be used as a set for the front tires and a set for the rear tires.

Longer wearing tires can be more susceptible to irregular tread wear. It is very important to follow the tire rotation interval in this chapter to achieve the tread life potential of these tires. Cuts and punctures in radial-ply tires are repairable only in the tread area, because of sidewall flexing. Consult your tire dealer for radial-ply tire repairs.

#### ! WARNING

Do not mix bias ply and radial ply tires under any circumstances. This may cause unusual handling characteristics that may cause loss of vehicle control resulting in an accident.

#### **Low Aspect Ratio Tires**

The aspect ratio is lower than 50 on low aspect ratio tires.

Because low aspect ratio tires are optimized for handling and braking, their sidewall is a little stiffer than a standard tire. Also low aspect ratio tires tend to be wider and consequently have a greater contact patch with the road surface. In some instances they may generate more road noise compared with standard

#### ! CAUTION

The side wall of a low aspect ratio tire is shorter than the normal one. Thus, the low-aspect wheel and tire are easily damaged. Follow the below instructions.

- · When driving on a rough road or driving off a road, be careful not to damage the tires and wheels. After driving, inspect the tires and wheels.
- When passing over a pothole, speed bump, manhole, or curb stone, drive the vehicle slowly so as not to damage the tires and wheels.
- · When there is an impact on a tire. inspect the tire condition. Or. you can contact an authorized HYUNDAI dealer.
- Inspect the tire condition and pressure every 8,000 miles (13,000 km) to prevent tire damage.
- · It is difficult to recognize a tire damage only with your eyes. When there is a slight hint of a tire damage, check and replace the tire to prevent the damage caused by air leakage.
- · When a tire is damaged while driving on a rough road, off a road, or over obstacles, such as a pothole, manhole, or curb stone, your warranty does not cover the damage.
- The tire information is specified on the tire side wall.

#### **FUSES**



A vehicle's electrical system is protected from electrical overload damage by fuses.

This vehicle has 2 (or 3) fuse panels, one located in the driver's side panel bolster, the other in the engine compartment near the battery.

If any of your vehicle's lights, accessories, or controls do not work, check the appropriate circuit fuse. If a fuse has blown, the element inside the fuse will be melted or broken.

If the electrical system does not work, first check the driver's side fuse panel. Before replacing a blown fuse, turn the engine and all switches off, and then disconnect the negative battery cable. Always replace a blown fuse with one of the same rating.

If the replacement fuse blows, this indicates an electrical problem. Avoid using the system involved and immediately consult an authorized HYUNDAI dealer.

### A

#### WARNING

NEVER replace a fuse with anything but another fuse of the same rating.

- A higher capacity fuse could cause damage and possibly cause a fire.
- Do not install a wire or aluminum foil instead of the proper fuse even as a temporary repair. It may cause extensive wiring damage and possibly a fire.


#### NOTICE

Do not use a screwdriver or any other metal object to remove fuses because it may cause a short circuit and damage the system.

# Instrument Panel Fuse Replacement



- 1. Turn the vehicle off.
- 2. Turn all other switches OFF.
- 3. Open the fuse panel cover.
- 4. Refer to the label on the inside of the fuse panel cover to locate the suspected fuse location.





- 5. Pull the suspected fuse straight out. Use the removal tool provided in the engine compartment fuse panel.
- Check the removed fuse; replace it if it is blown. Spare fuses are provided in the engine compartment fuse panel.
- Push in a new fuse of the same rating, and make sure it fits tightly in the clips. If it fits loosely, consult an authorized HYUNDAI dealer.

In an emergency, if you do not have a spare fuse, use a fuse of the same rating from a circuit you may not need for operating the vehicle.

If the head light, turn signal light, tail light, interior lamp doesn't work and the bulbs are undamaged, consult an authorized HYUNDAI dealer.

# **Engine Compartment Panel Fuse Replacement**






- 1. Turn the engine off.
- 2. Turn all other switches OFF.
- Remove the fuse panel cover by pressing the tap and pulling up.
- 4. Check the removed fuse; replace it if it is blown. To remove or insert the fuse, use the fuse puller in the engine compartment fuse panel.
- Push in a new fuse of the same rating, and make sure it fits tightly in the clips. If it fits loosely, consult an authorized HYUNDAI dealer.

#### NOTICE

After checking the fuse panel in the engine compartment, securely install the fuse panel cover. You may hear a clicking sound if the cover is securely latched. If it is not securely latched, electrical failure may occur from water contact.

#### Multi fuse (Main fuse)



If the multi fuse is blown, it must be removed as follows:

- 1. Turn off the engine.
- 2. Disconnect the negative battery cable.
- 3. Remove the fuse panel cover by pressing the tab and pulling it up.
- 4. Remove the nuts shown in the picture above.
- 5. Replace the fuse with a new one of the same rating.
- Reinstall in the reverse order of removal.

### *i* Information

If the multi fuse is blown, consult an authorized HYUNDAI dealer.

### **Fuse/Relay Panel Description**


Instrument panel fuse panel



Inside the fuse/relay box cover, you can find the fuse/relay label describing fuse/relay names and ratings.

## *i* Information

Not all fuse panel descriptions in this manual may be applicable to your vehicle; the information is accurate at the time of printing. When you inspect the fuse box on your vehicle, refer to the fuse box label.



### Driver's side fuse panel

Fuse Name	Fuse Rating	Circuit Protected
MEMORY1	10A	Crash Pad Switch, Driver/Passenger Power Outside Mirror, Instrument Cluster, Air Conditioner Controller, Air Conditioner Control Module
AIR BAG2	10A	SRS (Supplemental Restraint System) Control Module
MODULE4	10A	Front View Camera, Crash Pad Switch, IBU, Front Console Switch, LSD Control Module, ECS Unit
MODULE7	7.5A	Not Used
START	7.5A	IBU, ECM (Engine Control Module), Engine Room Junction Block (RLY.5)
CLUSTER	7.5A	Instrument Cluster
IBU2	7.5A	IBU
A/C1	7.5A	Air Conditioner Control Module, Air Conditioner Controller, PTC HEATER RLY
TRUNK	10A	Trunk Lid Latch
S/HEATER FRT	20A	Front Seat Warmer Control Module
P/WINDOW LH	25A	Power Window Main Switch
MULTIMEDIA	15A	Audio/Video & Navigation Head Unit

### Driver's side fuse panel

Fuse Name	Fuse Rating	Circuit Protected
MDPS1	7.5A	MDPS (Motor Driven Power Steering) Unit
MODULE6	7.5A	IBU, IAU
SAFETY P/WINDOW DRV	25A	Driver Safety Power Window Module
P/WINDOW RH	25A	Power Window Main Switch, Passenger Power Window Switch
BRAKE SWITCH	10A	Stop Lamp Switch, IBU
IBU1	15A	IBU, Sport Mode Switch
MODULE2	10A	Engine Room Junction Block (RLY.2), Power Outside Mirror Switch, AMP, IBU, Audio/Video & Navigation Head Unit, IAU
AIR BAG1	15A	SRS Control Module, ODS(Occupant Detection System)
MODULE5	10A	Front Wireless Charger, Electro Chromic Mirror, Air Conditioner Controller, Air Conditioner Control Module, Audio/Video & Navigation Head Unit, Data Link Connector, AMP, Front Seat Warmer Control Module, Transmission Gear Shift Indicator
SAFETY P/WINDOW PASS	25A	Passenger Safety Power Window Module
AMP	25A	АМР
HEATED MIRROR	10A	Driver/Passenger Power Outside Mirror, Air Conditioner Controller

### Driver's side fuse panel


Fuse Name	Fuse Rating	Circuit Protected
DOOR LOCK	20A	Door Actuator Driver/Passenger/Rear Left/Rear Right
IAU	10A	IAU, Driver/Passenger Door NFC Module
MODULE3	7.5A	Sport Mode Switch, Stop Lamp Switch, Multifunction Switch, IAU
AIR BAG IND	7.5A	Instrument Cluster, Overhead Console Lamp
WASHER	15A	Multifunction Switch
WIPER	10A	ECM (Engine Control Module), IBU
MODULE1	10A	Driver/Passenger Smart Key Outside Handle, Data Link Connector, Hazard Switch, Multifunction Switch
SUNROOF	20A	Sunroof Unit
USB CHARGER	15A	Front USB Charger, Console USB Charger
IG1	25A	PCB Block (Fuse – ECU 3/ABS 3/DCT 2)



Inside the fuse/relay box cover, you can find the fuse/relay label describing fuse/relay names and ratings.

## *i* Information

Not all fuse panel descriptions in this manual may be applicable to your vehicle; the information is accurate at the time of printing. When you inspect the fuse panel in your vehicle, refer to the fuse panel label.



Туре	Fuse Name	Fuse Rating	Circuit Protected
MIDI FUSE-3	ALT	180A	Alternator, (Fuse – E-LSD, ABS 1, ABS 2, POWER OUTLET1)
	MDPS1	100A	MDPS (Motor Driven Power Steering) Unit
	COOLING FAN2	80A	Cooling Fan Controller
MIDI	EOP	60A	Electronic Oil Pump (PWR)
FUSE-2	RR HTD	50A	Rear Glass Heated
	PTC HEATER	50A	PTC HEATER
	B+5	60A	PCB Block (Engine Control Relay, Fuse - WIPER, ECS, A/C, HORN, ECU 2)
	B+1	60A	ICU Junction Block (IPS2/IPS5/IPS6/IPS7/IPS14)
MIDI	B+2	60A	ICU Junction Block (IPS1/IPS4/IPS8/IPS9/IPS10)
	B+3	50A	ICU Junction Block (Fuse - MEMORY1, TRUNK, S/HEATER FRT, MULTIMEDIA, P/WINDOW SAFETY DRV, P/WINDOW SAFETY PASS, AMP, Long Term Load Latch Relay), P/SEAT DRV, P/SEAT PASS
FUSE-1	BLOWER	50A	Engine Room Junction Block (RLY.13), Multipurpose Check Connector, Blower Motor
	IG1	40A	Engine Room Junction Block (RLY.4/6)
	IG2	40A	Engine Room Junction Block (RLY.3/5)
	DCT1	60A	TCM (Transmission Control Module)
	EPB	60A	EPB UNIT

Туре	Fuse Name	Fuse Rating	Circuit Protected
	POWER OUTLET2	20A	Front Power Outlet
	VACUUM PUMP1	20A	Engine Room Junction Block (RLY.7), Vacuum pump
	VACUUM PUMP2	10A	ESC (Electronic Stability Control) Control Module
	ECS	15A	ECS Unit
	E-LSD	20A	LSD Control Module
	E-CVVT3	20A	ECM (Engine Control Module)
	E-CVVT2	20A	ECM (Engine Control Module)
	E-CVVT1	40A	Engine Room Junction Block (RLY.1)
FUSE	DCT2	10A	TCM (Transmission Control Module)
	B+4	40A	ICU Junction Block (Fuse - AIR BAG 2, P/ WINDOW LH, P/WINDOW RH, BRAKE SWITCH, IBU 1, DOOR LOCK, IAU, MODULE 1, SUNROOF, Power Window Relay)
	AMS	10A	Battery Sensor
	TCU1	10A	[M/T] Ignition Lock & Clutch Switch
	FUEL PUMP	20A	FUEL PUMP Control Module
	ABS1	40A	ESC (Electronic Stability Control) Control Module
	ABS2	30A	ESC (Electronic Stability Control) Control Module, Multipurpose Check Connector
	POWER OUTLET1	40A	POWER OUTLET FRT
	WIPER	25A	Wiper Motor

Туре	Fuse Name	Fuse Rating	Circuit Protected
	ECS (15A)	15A	ECS Unit
	A/C	10A	ECV CLUTCH
	HORN	15A	Horn
	IGN COIL	20A	Ignition Coil #1~#4
	ECU3	10A	[M/T] Ignition Lock & Clutch Switch, ECM (Engine Control Module)
	SENSOR3	10A	Engine Room Junction Block (RLY.8)
FUSE	ECU2	15A	ECM (Engine Control Module)
	SENSOR2	10A	Oil Control Valve, Electronic Water Pump, Canister Close Valve, Active Exhaust Valve, Cooling Fan Controller, Purge Control Solenoid Valve, RCV Control Solenoid Valve, PCB Block (A/C Relay), Oil Level Sensor
	SENSOR1	15A	Oxygen Sensor (UP/DOWN)
	ABS3	10A	ESC (Electronic Stability Control) Control Module, Multipurpose Check Connector
	ECU1	20A	ECM (Engine Control Module)
	DIAGNOSIS	40A	Multipurpose Check Connector

#### **LIGHT BULBS**

Consult an authorized HYUNDAI dealer to replace most vehicle light bulbs. It is difficult to replace vehicle light bulbs because other parts of the vehicle must be removed before you can get to the bulb. This is especially true for removing the headlight assembly to get to the bulb(s).

Removing/installing the headlight assembly can result in damage to the vehicle.

## **MARNING**

- Prior to working on a light, depress the foot brake, shift to P (Park), apply the parking brake, press the Engine Start/Stop button to the OFF position and take the key with you when leaving the vehicle to avoid sudden movement of the vehicle and to prevent possible electric shock.
- Be aware the bulbs may be hot and may burn your fingers.

### NOTICE

Be sure to replace the burned-out bulb with one of the same wattage rating. Otherwise, it may cause damage to the fuse or electrical wiring system.

#### NOTICE

To prevent damage, do not clean the headlight lens with chemical solvents or strong detergents.

# i Information - Headlight desiccant (if equipped)

This vehicle is equipped with desiccant to reduce fogging inside the headlight due to moisture. The desiccant is consumable and its performance may change based on the used period or environment. If fogging inside the headlight due to moisture continues for a long time, consult an authorized HYUNDAI dealer.

## Information

The headlight and tail light lenses could appear frosty if the vehicle is washed after driving or the vehicle is driven at night in wet weather. This condition is caused by temperature difference between the lamp inside and outside and, it does not indicate a problem with your vehicle. When moisture condenses in the lamp, it will be removed after driving with the headlight on. The removable level may differ depending on lamp size, lamp position and environmental condition. However, if moisture is not removed, have your vehicle inspected by an authorized HYUNDAI dealer.

#### Headlight, Position Light, Turn Signal Light and Daytime Running Light Bulb Replacement



- (1) Headlight (Low)
- (2) Headlight (High)
- (3) Position light / Daytime running light (DRL) / Turn signal light
- (4) Side marker

Headlight/Daytime running light (DRL) / Position light / Turn Signal light / Side marker (LED type)

If the LED light does not operate, have the system inspected by an authorized HYUNDAI dealer.

The LED lights cannot be replaced as a single unit because it is an integrated unit. The LED lights has to be replaced with the unit.


A skilled technician should check or repair the LED light, for it may damage related parts of the vehicle.

#### Side Repeater Light Replacement



If the LED light (1) does not operate, have the vehicle checked by an authorized HYUNDAI dealer.

## Rear Combination Light Bulb Replacement



- (1) Stop light (LED)
- (2) Tail light (LED)
- (3) Turn signal light
- (4) Reverse light
- (5) Side marker (LED)

#### Tail/Stop light and rear side marker

If the tail/stop light and rear side marker do not operate, have the vehicle checked by an authorized HYUNDAI dealer.

## Turn signal light (Outer light) (Bulb type)

1. Open the trunk lid.



2. Remove the service cover by pulling out the service cover.



3. Loosen the assembly retaining nuts.



 Remove the rear combination light assembly from the body of the vehicle.



OCN7N091034L

[A]: Turn signal light

- Remove the socket from the assembly by turning the socket counterclockwise until the tabs on the socket align with the slots on the assembly.
- Remove the bulb from the socket by pressing it in and rotating it counterclockwise until the tabs on the bulb align with the slots in the socket.
   Pull the bulb out of the socket.
- Insert a new bulb by inserting it into the socket and rotating it until it locks into place.
- 8. Install the socket in the assembly by aligning the tabs on the socket with the slots in the assembly. Push the socket into the assembly and turn the socket clockwise.

## Reverse lamp (Inner lamp) (Bulb type)

1. Open the trunk.



Loosen the retaining screw of the trunk lid cover and then remove the cover.



- Remove the socket from the assembly by turning the socket counterclockwise until the tabs on the socket align with the slots on the assembly.
- 4. Remove the bulb by pulling it out.
- 5. Insert a new bulb by inserting it into the socket.
- 6. Install the light assembly to the trunk.
- 7. Reinstall the trunk lid cover by pushing in the screw.

## **High Mounted Stop Light Replacement**





[A]: High mounted stop light

- 1. Open the trunk.
- Remove the socket by turning it counterclockwise until the tabs on the socket align with the slots.
- Remove the bulb from the socket by pressing it in and rotating it counterclockwise until the tabs on the bulb align with the slots in the socket.
   Pull the bulb out of the socket.
- 4. Insert a new bulb by inserting it into the socket and rotating it until it locks into place.
- Install the socket in the assembly by aligning the tabs on the socket with the slots in the assembly.
  - Push the socket into the assembly and turn the socket clockwise.


## **License Plate Light Bulb Replacement**




- Using a flat-blade screwdriver gently pry the lens cover from the lamp housing.
- 2. Remove the bulb by pulling it straight out.
- 3. Install a new bulb.
- 4. Reinstall in the reverse order.

### **Interior Light Bulb Replacement**







- Using a flat-blade screwdriver, gently pry the lens or assembly from the interior light housing.
- 2. Remove the bulb by pulling it straight out.

## **MARNING**

Prior to working on the Interior Lights, ensure that the "OFF" button is depressed to avoid burning your fingers or receiving an electric shock.

- 3. Install a new bulb in the socket.
- 4. Align the lens tabs with the interior light housing notches and snap the lens into place.


#### Trunk room lamp (bulb type)



- Using a flat-blade screwdriver gently pry the assembly from the lamp housing.
- 2. Remove the lamp cover, then pull the bulb straight out it.
- 3. Install a new bulb.
- 4. Reinstall in the reverse order.

#### NOTICE

Use care not to dirty or damage lens, lens tab, and plastic housings.



If the LED lamp does not operate, have the system inspected by an authorized HYUNDAI dealer.

The LED lamps cannot be replaced as a single unit because it is an integrated unit. The LED lamps has to be replaced with the unit. A skilled technician should check or repair the LED lamp, for it may damage related parts of the vehicle.

#### **APPEARANCE CARE**

#### **Exterior Care**

#### NOTICE

If you park your vehicle near a stainless steel sign or glass facade building, the vehicle's exterior plastic parts such as a bumper, spoiler, garnish, lamp or outside rearview mirror might be damaged due to sunlight reflected from the sign or building. To prevent damage of the exterior plastic parts, you should avoid parking in areas where light may be reflected or use a car cover. (The exterior plastic parts applied to your vehicle may vary.)

#### Exterior general caution

It is very important to follow the label directions when using any chemical cleaner or polish. Read all warning and caution statements that appear on the label.

#### NOTICE

If you push or pull the spoiler to move the vehicle while parked or in a stationary state, the spoiler may be damaged.

#### Finish maintenance

#### Washing

To help protect your vehicle's finish from rust and deterioration, wash it thoroughly and frequently at least once a month with lukewarm or cold water.

If you use your vehicle for off-road driving, you should wash it after each off-road trip. Pay special attention to the removal of any accumulation of salt, dirt, mud, and other foreign materials. Make sure the drain holes in the lower edges of the doors and rocker panels are kept clear and clean.

Insects, tar, tree sap, bird droppings, industrial pollution and similar deposits can damage your vehicle's finish if not removed immediately.

Even prompt washing with plain water may not completely remove all these deposits. A mild soap, safe for use on painted surfaces, should be used.

After washing, rinse the vehicle thoroughly with lukewarm or cold water. Do not allow soap to dry on the finish.

#### High-pressure washing

- When using high-pressure washers, make sure to maintain sufficient distance from the vehicle.
   Insufficient clearance or excessive pressure can lead to component damage or water penetration.
- Do not spray the camera, sensors or its surrounding area directly with a high pressure washer. Shock applied from high pressure water may cause the device to not operate normally.
- Do not bring the nozzle tip close to boots (rubber or plastic covers) or connectors as they may be damaged if they come into contact with high pressure water.

### **⚠** WARNING

After washing the vehicle, test the brakes while driving slowly to see if they have been affected by water before getting on the road. If braking performance is impaired, dry the brakes by applying them lightly while maintaining a slow forward speed.

#### NOTICE

- Do not use strong soap, chemical detergents or hot water, and do not wash the vehicle in direct sunlight or when the body of the vehicle is warm.
- Be careful when washing the side windows of your vehicle.
- Especially, with high-pressure water, water may leak through the windows and wet the interior.
- To prevent damage to the plastic parts, do not clean with chemical solvents or strong detergents.

#### NOTICE



- Water washing in the engine compartment including high pressure water washing may cause the failure of electrical circuits located in the engine compartment.
- Never allow water or other liquids to come in contact with electrical/ electronic components inside the vehicle as this may damage them.

#### NOTICE

Matte paint finish vehicle (if equipped)
Automatic car wash which uses rotating

brushes should not be used as this can damage the surface of your vehicle. A steam cleaner which washes the vehicle surface at high temperature may result the oil to adhere and leave stains that is difficult to remove.

Use a soft cloth (for example, microfiber towel or sponge) when washing your vehicle and dry with a microfiber towel. When you hand wash your vehicle, you should not use a cleaner that finishes with wax. If the vehicle surface is too dirty (sand, dirt, dust, contaminant, etc.), clean the surface with water before washing the car.

#### Waxing

A good coat of wax is a barrier between your paint and contaminate. Keeping a good coat of wax on your vehicle will help protect it.

Wax the vehicle when water will no longer bead on the paint.

Always wash and dry the vehicle before waxing. Use a good quality liquid or paste wax, and follow the manufacturer's instructions. Wax all metal trim to protect it and to maintain its luster.

Removing oil, tar, and similar materials with a spot remover will usually strip the wax from the finish. Be sure to re-wax these areas even if the rest of the vehicle does not yet need waxing.

#### NOTICE

- Wiping dust or dirt off the body with a dry cloth will scratch the finish.
- Do not use steel wool, abrasive cleaners, or strong detergents containing highly alkaline or caustic agents on chrome-plated or anodized aluminum parts. This may result in damage to the protective coating and cause discoloration or paint deterioration.

#### NOTICE

Matte paint finish vehicle (if equipped)
Do not use any polish protector such as a detergent, an abrasive and a polish. In case wax is applied, remove the wax immediately using a silicon remover and if any tar or tar contaminant is on the surface use a tar remover to clean. However, be careful not to apply too

much pressure on the painted area.

#### Finish damage repair

Deep scratches or stone chips in the painted surface must be repaired promptly. Exposed metal will quickly rust and may develop into a major repair expense.

#### NOTICE

If your vehicle is damaged and requires any metal repair or replacement, be sure the body shop applies anticorrosion materials to the parts repaired or replaced.

#### NOTICE

Matte paint finish vehicle (if equipped)
In case of matte paint finish vehicles,
it is impossible to modify only the
damaged area and repair of the whole
part is necessary. If the vehicle is
damaged and painting is required, have
your vehicle maintained and repaired
by an authorized HYUNDAI dealer. Take
extreme care, as it is difficult to restore
the quality after the repair.

#### Bright-metal maintenance

- To remove road tar and insects, use a tar remover, not a scraper or other sharp object.
- To protect the surfaces of bright metal parts from corrosion, apply a coating of wax or chrome preservative and rub to a high luster.
- · During winter weather or in coastal areas, cover the bright metal parts with a heavier coating of wax or preservative. If necessary, coat the parts with non-corrosive petroleum ielly or other protective compound.

#### Underbody maintenance

Corrosive materials used for ice and snow removal and dust control may collect on the underbody. If these materials are not removed, accelerated rusting can occur on underbody parts such as the fuel lines, frame, floor pan and exhaust system, even though they have been treated with rust protection.

Thoroughly flush the vehicle underbody and wheel openings with lukewarm or cold water once a month, after off-road driving and at the end of each winter. Pay special attention to these areas because it is difficult to see all the mud and dirt. It will do more harm than good to wet down the road grime without removing it. The lower edges of doors, rocker panels, and frame members have drain holes that should not be allowed to clog with dirt; trapped water in these areas can cause rusting.



#### ! WARNING

After washing the vehicle, test the brakes while driving slowly to see if they have been affected by water. If braking performance is impaired, dry the brakes by applying them lightly while maintaining a slow forward speed.

#### Aluminum wheel maintenance

The aluminum wheels are coated with a clear protective finish.

- Do not use abrasive cleaner, polishing compound, solvent, or wire brushes on aluminum wheels.
- Clean the wheel when it has cooled.
- Use only a mild soap or neutral detergent, and rinse thoroughly with water. Also, clean the wheels after driving on salted roads.
- Do not wash the wheels with highspeed car wash brushes.
- Do not use any cleaners containing acid or alkaline detergents.

#### Corrosion protection

Protecting your vehicle from corrosion By using the most advanced design and construction practices to combat corrosion, HYUNDAI produces vehicles of the highest quality. However, this is only part of the job. To achieve the longterm corrosion resistance your vehicle can deliver, the owner's cooperation and assistance is also required.

#### Common causes of corrosion

The most common causes of corrosion on your vehicle are:

- Road salt, dirt and moisture that is allowed to accumulate underneath the vehicle.
- Removal of paint or protective coatings by stones, gravel, abrasion or minor scrapes and dents which leave unprotected metal exposed to corrosion.

#### **High-corrosion** areas

If you live in an area where your vehicle is regularly exposed to corrosive materials, corrosion protection is particularly important. Some of the common causes of accelerated corrosion are road salts, dust control chemicals, ocean air and industrial pollution.

#### Moisture breeds corrosion

Moisture creates the conditions in which corrosion is most likely to occur. For example, corrosion is accelerated by high humidity, particularly when temperatures are just above freezing. In such conditions, the corrosive material is kept in contact with the vehicle surfaces by moisture that is slow to evaporate.

Mud is particularly corrosive because it is slow to dry and holds moisture in contact with the vehicle. Although the mud appears to be dry, it can still retain moisture and promote corrosion.

High temperatures can also accelerate corrosion of parts that are not properly ventilated so the moisture can be dispersed. For all these reasons, it is particularly important to keep your vehicle clean and free of mud or accumulations of other materials. This applies not only to the visible surfaces but particularly to the underside of the vehicle.

#### To help prevent corrosion Keep your vehicle clean

The best way to prevent corrosion is to keep your vehicle clean and free of corrosive materials. Attention to the underside of the vehicle is particularly important.

- If you live in a high-corrosion area —
  where road salts are used, near the
  ocean, areas with industrial pollution,
  acid rain, etc.—, you should take extra
  care to prevent corrosion. In winter,
  hose off the underside of your vehicle
  at least once a month and be sure to
  clean the underside thoroughly when
  winter is over.
- When cleaning underneath the vehicle, pay particular attention to the components under the fenders and other areas that are hidden from view. Do a thorough job; just dampening the accumulated mud rather than washing it away will accelerate corrosion rather than prevent it. Water under high pressure and steam are particularly effective in removing accumulated mud and corrosive materials.
- When cleaning lower door panels, rocker panels and frame members, be sure that drain holes are kept open so that moisture can escape and not be trapped inside to accelerate corrosion.

#### Keep your garage dry

Don't park your vehicle in a damp, poorly ventilated garage. This creates a favorable environment for corrosion. This is particularly true if you wash your vehicle in the garage or drive it into the garage when it is still wet or covered with snow, ice or mud. Even a heated garage can contribute to corrosion unless it is well ventilated so moisture is dispersed.

Keep paint and trim in good condition Scratches or chips in the finish should be covered with "touch-up" paint as soon as possible to reduce the possibility of corrosion. If bare metal is showing through, the attention of a qualified body and paint shop is recommended.

Bird droppings are highly corrosive and may damage painted surfaces in just a few hours. Always remove bird droppings as soon as possible.

#### **Interior Care**

#### Interior general precautions

Prevent caustic solutions such as perfume and cosmetic oil, from contacting the interior parts because they may cause damage or discoloration. If they do contact the interior parts, wipe them off immediately. See the instructions for the proper way to clean vehicle interior surfaces.

#### NOTICE

- Never allow water or other liquids to come in contact with electrical/ electronic components inside the vehicle as this may damage them.
- When cleaning leather products (steering wheel, seats etc.), use neutral detergents or low alcohol content solutions. If you use high alcohol content solutions or acid/ alkaline detergents, the color of the leather may fade or the surface may get stripped off.
- During window tinting, make sure window tinting solution does not flow into electronic devices inside the vehicle. It may cause breakdown and malfunction of devices.

## Cleaning the upholstery and interior trim

Vehicle interior surfaces (if equipped)
Remove dust and loose dirt from interior surfaces with a whisk broom or a vacuum cleaner

If necessary, clean interior surfaces with a mixture of warm water and mild nondetergent cleaner (test all cleaners on a concealed area before use).

#### Fabric (if equipped)

Remove dust and loose dirt from fabric with a whisk broom or vacuum cleaner. Clean with a mild soap solution recommended for upholstery or carpets. Remove fresh spots immediately with a fabric spot cleaner. If fresh spots do not receive immediate attention, the fabric can be stained and its color can be affected. Also, its fire-resistant properties can be reduced if the material is not properly maintained.

#### NOTICE

Using anything but recommended cleaners and procedures may affect the fabric's appearance and fire-resistant properties.

#### Leather (if equipped)

- Features of seat leather
  - Leather is made from the outer skin of an animal, which goes through a special process to be available for use. Since it is a natural product, each part differs in thickness or density.

Wrinkles may appear as a natural result of stretching and shrinking depending on the temperature and humidity.

- The seat is made of stretchable fabric to improve comfort.
- The parts contacting the body are curved and the side supporting area is high which provides driving comfort and stability.
- Wrinkles may appear naturally from usage. It is not a fault of the products.

## $\triangle$

#### **CAUTION**

- Wrinkles or abrasions which appear naturally from usage are not covered by warranty.
- Belts with metallic accessories, zippers or keys inside the back pocket may damage the seat fabric.
- Make sure not to wet the seat. It may change the nature of natural leather.
- Jeans or clothes which could bleach may contaminate the surface of the seat covering fabric.

- · Caring for the leather seats
  - Vacuum the seat periodically to remove dust and sand on the seat. It will prevent abrasion or damage of the leather and maintain its quality.
  - Wipe the natural leather seat cover often with dry or soft cloth.
  - Use of proper leather protector may prevent abrasion of the cover and helps maintain the color. Be sure to read the instructions and consult a specialist when using leather coating or protective agent.
  - Light colored (beige, cream beige) leather is easily contaminated and the stain is noticeable. Clean the seats frequently.
  - Avoid wiping with wet cloth. It may cause the surface to crack.
- · Cleaning the leather seats
  - Remove all contaminations instantly. Refer to instructions below for removal of each contaminant.
  - Cosmetic products (sunscreen, foundation, etc.)
    - Apply cleansing cream on a cloth and wipe the contaminated spot. Wipe off the cream with a wet cloth and remove water with a dry cloth.
  - Beverages (coffee, soft drink, etc.)
     Apply a small amount of neutral detergent and wipe until contaminations do not smear.
  - Oil

Remove oil instantly with absorbable cloth and wipe with stain remover used only for natural leather.

Chewing gum
 Harden the gum with ice and remove gradually.

#### Cleaning the seat belt webbing

Clean the belt webbing with any mild soap solution recommended for cleaning upholstery or carpet. Follow the instructions provided with the soap. Do not bleach or re-dye the webbing because this may weaken the seat belt.

#### Cleaning the interior window glass

If the interior glass surfaces of the vehicle become hazy (that is, covered with an oily, greasy or waxy film), they should be cleaned with glass cleaner. Follow the directions on the glass cleaner container.

#### **NOTICE**

Do not scrape or scratch the inside of the rear window. This may result in damage to the rear window defroster grid.

#### **EMISSION CONTROL SYSTEM**

The emission control system of your vehicle is covered by a written limited warranty. Please see the warranty information contained in the Owner's Handbook & Warranty Information booklet in your vehicle.

Your vehicle is equipped with an emission control system to meet all applicable emission regulations. There are three emission control systems, as follows.

- (1) Crankcase emission control system
- (2) Evaporative emission control system
- (3) Exhaust emission control system

In order to ensure the proper function of the emission control systems, have your vehicle inspected and maintained by an authorized HYUNDAI dealer in accordance with the maintenance schedule in this manual.

#### NOTICE

For the Inspection and Maintenance Test (with Electronic Stability Control (ESC) system)

- To prevent the vehicle from misfiring during dynamometer testing, turn the Electronic Stability Control (ESC) system off by pressing the ESC switch (ESC OFF light illuminated).
- After dynamometer testing is completed, turn the ESC system back on by pressing the ESC switch again.

## 1. Crankcase Emission Control System

The positive crankcase ventilation system is employed to prevent air pollution caused by blow-by gases being emitted from the crankcase. This system supplies fresh filtered air to the crankcase through the air intake hose. Inside the crankcase, the fresh air mixes with blow-by gases, which then pass through the PCV valve into the induction system.

#### 2. Evaporative Emission Control System Including Onboard Refueling Vapor Recovery (ORVR)

The Evaporative Emission Control System is designed to prevent fuel vapors from escaping into the atmosphere. The ORVR system is designed to allow the vapors from the fuel tank to be loaded into a canister while refueling at the gas station, preventing the escape of fuel vapors into the atmosphere.

#### Canister

Fuel vapors generated inside the fuel tank are absorbed and stored in the onboard canister. When the engine is running, the fuel vapors absorbed in the canister are drawn into the surge tank through the purge control solenoid valve.

#### Purge Control Solenoid Valve (PCSV)

The purge control solenoid valve is controlled by the Engine Control Module (ECM); when the engine coolant temperature is low during idling, the PCSV closes so that evaporated fuel is not taken into the engine. After the engine warms-up during ordinary driving, the PCSV opens to introduce evaporated fuel to the engine.

## 3. Exhaust Emission Control System

The Exhaust Emission Control System is a highly effective system which controls exhaust emissions while maintaining good vehicle performance.

When the engine starts or fails to start, excessive attempts to restart the engine may cause damage to the emission system.

## Engine exhaust (carbon monoxide) precautions

 Carbon monoxide can be present with other exhaust fumes. If you smell exhaust fumes of any kind in your vehicle, drive with all the windows fully open. Have your vehicle checked and repaired immediately.

### ! WARNING

Engine exhaust gases contain carbon monoxide (CO). Though colorless and odorless, it is dangerous and could be lethal if inhaled. Follow the instructions on this page to avoid CO poisoning.

### ! WARNING

## CALIFORNIA PROPOSITION 65 WARNING

Engine exhaust and a wide variety of automobile components and parts, including components found in the interior furnishings in a vehicle, contain or emit chemicals known to the State of California to cause cancer and birth defects and reproductive harm. In addition, certain fluids contained in vehicles and certain products of component wear contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Do not operate the engine in confined or closed areas (such as garages) any more than what is necessary to move the vehicle in or out of the area.
- When the vehicle is stopped in an open area for more than a short time with the engine running, adjust the ventilation system (as needed) to draw outside air into the vehicle.
- Never sit in a parked or stopped vehicle for any extended time with the engine running.
- When the engine stalls or fails to start, excessive attempts to restart the engine may cause damage to the emission control system.

## Operating precautions for catalytic converters (if equipped)



#### ! WARNING

The exhaust system and catalytic system are very hot while the engine is running or immediately after the engine is turned off. To avoid SERIOUS INJURY or DEATH:

- Do not park, idle, or drive the vehicle over or near flammable objects, such as grass, vegetation, paper, leaves, etc. A hot exhaust system can ignite flammable items under your vehicle.
- Keep away from the exhaust system and catalytic converter or you may get burned.
  - Also, do not remove the heat sink around the exhaust system, do not seal the bottom of the vehicle, and do not coat the vehicle for corrosion control. It may present a fire risk under certain conditions.
- Removal of the muffler (including the catalytic converters) will result in excessive exhaust noise and emissions. This may lead to improper vehicle operation and vehicle not meeting local/federal regulations.
- Make sure that a normal exhaust sound is heard.

Your vehicle is equipped with a catalytic converter emission control device.

To prevent damage to the catalytic converter and to your vehicle, take the following precautions:

- Use only UNLEADED FUEL for gasoline engines.
- Do not operate the vehicle when there are signs of engine malfunction, such as misfire or a noticeable loss of performance.
- Do not misuse or abuse the engine.
   Examples of misuse are coasting with the engine off and descending steep grades in gear with the engine off.
- Do not operate the engine at high idle speed for extended periods (5 minutes or more).
- Do not modify or tamper with any part of the engine or emission control system. All inspections and adjustments must be made by an authorized HYUNDAI dealer.
- Avoid driving with extremely low fuel level. If you run out of gasoline, it could cause the engine to misfire and result in excessive loading of the catalytic converter.

#### **CALIFORNIA PERCHLORATE NOTICE**

Perchlorate Material-special handling may apply, See: "https://dtsc.ca.gov/perchlorate"

Notice to California Vehicle Dismantlers:

Perchlorate containing materials, such as air bag inflators, seatbelt pretensioners and keyless remote entry batteries, must be disposed of according to Title 22 California Code of Regulations Section 67384.10 (a).

# Index

A	
Air Bag - Advanced Supplemental Restraint System Additional Safety Precautions	3-533-533-363-413-523-403-333-479-252-152-152-119-649-695-865-88
В	
Battery  Battery Capacity Label  Battery Recharging  For Best Battery Service  Reset Items  Before Driving  Before Entering the Vehicle  Before Starting  Blind-Spot Collision-Avoidance Assist (BCA)	9-31 9-32 9-32 6-4 6-4 6-4
Blind-Spot Collision-Avoidance Assist Malfunction and Limitations  Blind-Spot Collision-Avoidance Assist Operation	7-23

Brake System 6-28 Anti-lock Brake System (ABS) 6-31 Disc Brakes Wear Indicator 6-28 Electronic Stability Control (ESC) 6-32 Good Braking Practices 6-39 High Performance Brake 6-29 Hill-Start Assist Control (HAC) 6-38
Parking Brake6-29 Power Brakes6-28
Vehicle Stability Management (VSM)6-37
Brake/Clutch Fluid
Bulb Wattage
С
Cabin Air Filter
Filter Replacement 9-27
California perchlorate notice9-75
Center Console Overview2-5
Child Restraint System (CRS)
Children Always in the Rear
Installing a Child Restraint System (CRS)
Selecting a Child Restraint System (CRS)
Climate Control Additional Features
Sunroof Inside Air Recirculation 5-103
Cluster Display4-25
Cluster Display Control4-25
Trip Computer4-31
View Modes4-26
Consumer Information
Cruise Control (CC)7-53
Cruise Control Operation

D	
Declaration of Conformity	7-81
Rear Corner Radar	7-81
Dimensions	2-8
Door Locks	5-22
Automatic Door Lock and Unlock Features	5-25
Child-Protector Rear Door Locks	5-26
Operating Door Locks from Inside the Vehicle	5-23
Operating Door Locks from Outside the Vehicle	5-22
Drive Mode Integrated Control System	6-44
Drive Mode	6-44
N Mode	6-46
NGS (N Grin Shift)	6-48
Vehicle Characteristic	6-49
Driver Attention Warning (DAW)	7-47
Driver Attention Warning Malfunction and Limitations	7-49
Driver Attention Warning Operation	7-48
Driver Attention Warning Settings	7-47
Dual Clutch Transmission (DCT)	6-18
Cluster Display for Transmission Temperature and Warning Message	6-20
Dual Clutch Transmission Operation	6-18
Good Driving Practices	6-27
Paddle Shifter (Manual Shift Mode)	6-26
Parking	6-26
E	
Electronic Control Suspension (ECS)	6.40
Electronic Control Suspension (ECS)  Electronic Limited Slip Differential	
Warning Messages	
Emission Control System	
Crankcase Emission Control System	
Evaporative Emission Control System Including Onboard Refueling Vapor	
Recovery (ORVR)	9-72
Exhaust Emission Control System	
Engine Compartment	
Engine Compartment Overview	9-3

Engine Coolant	
Changing Engine Coolant	9-22
Checking the Engine Coolant Level	9-19
Engine Number	2-15
Engine Oil	9-16
Checking the Engine Oil and Filter	9-17
Checking the Engine Oil Level	9-16
Engine Specification	2-8
Engine Start/Stop Button	6-5
Remote start	6-10
Explanation of Scheduled Maintenance Items	9-14
Exterior Lights	5-62
Battery Saver Function	5-65
Headlight Delay Function	5-65
High Beam Operation	5-63
Lighting Control	5-62
Turn Signals And Lane Change Signals	5-64
Exterior Overview (Front View)	2-2
Exterior Overview (Rear View)	2-3
F	
F	
Forward Collision–Avoidance Assist (FCA) (Front view camera only)	
Forward Collision–Avoidance Assist (FCA) (Front view camera only) Forward Collision-Avoidance Assist Malfunction and Limitations	7-7
Forward Collision–Avoidance Assist (FCA) (Front view camera only) Forward Collision-Avoidance Assist Malfunction and Limitations Forward Collision-Avoidance Assist Operation	7-7 7-4
Forward Collision–Avoidance Assist (FCA) (Front view camera only) Forward Collision-Avoidance Assist Malfunction and Limitations Forward Collision-Avoidance Assist Operation Forward Collision-Avoidance Assist Settings	7-7 7-4 7-3
Forward Collision–Avoidance Assist (FCA) (Front view camera only)  Forward Collision-Avoidance Assist Malfunction and Limitations  Forward Collision-Avoidance Assist Operation  Forward Collision-Avoidance Assist Settings  Forward/Reverse Parking Distance Warning (PDW)	7-7 7-4 7-3
Forward Collision–Avoidance Assist (FCA) (Front view camera only) Forward Collision-Avoidance Assist Malfunction and Limitations Forward Collision-Avoidance Assist Operation Forward Collision-Avoidance Assist Settings Forward/Reverse Parking Distance Warning (PDW) Forward/Reverse Parking Distance Warning Malfunction and Limitations	7-7 7-4 7-3 7-76 s7-79
Forward Collision–Avoidance Assist (FCA) (Front view camera only) Forward Collision-Avoidance Assist Malfunction and Limitations Forward Collision-Avoidance Assist Operation Forward Collision-Avoidance Assist Settings Forward/Reverse Parking Distance Warning (PDW) Forward/Reverse Parking Distance Warning Malfunction and Limitation Forward/Reverse Parking Distance Warning Operation	7-7 7-4 7-3 7-76 s7-79
Forward Collision–Avoidance Assist (FCA) (Front view camera only) Forward Collision-Avoidance Assist Malfunction and Limitations Forward Collision-Avoidance Assist Operation Forward Collision-Avoidance Assist Settings Forward/Reverse Parking Distance Warning (PDW) Forward/Reverse Parking Distance Warning Malfunction and Limitation Forward/Reverse Parking Distance Warning Operation Forward/Reverse Parking Distance Warning Settings	7-77-47-76 s7-777-76
Forward Collision–Avoidance Assist (FCA) (Front view camera only) Forward Collision-Avoidance Assist Malfunction and Limitations Forward Collision-Avoidance Assist Operation Forward/Collision-Avoidance Assist Settings Forward/Reverse Parking Distance Warning (PDW) Forward/Reverse Parking Distance Warning Malfunction and Limitation Forward/Reverse Parking Distance Warning Operation Forward/Reverse Parking Distance Warning Settings Fuel Filler Door	7-77-47-76 s7-777-767-76
Forward Collision–Avoidance Assist (FCA) (Front view camera only) Forward Collision-Avoidance Assist Malfunction and Limitations Forward Collision-Avoidance Assist Operation Forward Collision-Avoidance Assist Settings Forward/Reverse Parking Distance Warning (PDW) Forward/Reverse Parking Distance Warning Malfunction and Limitation Forward/Reverse Parking Distance Warning Operation Forward/Reverse Parking Distance Warning Settings Fuel Filler Door Fuel Requirements	7-77-47-37-76 s7-777-765-601-5
Forward Collision–Avoidance Assist (FCA) (Front view camera only) Forward Collision-Avoidance Assist Malfunction and Limitations Forward Collision-Avoidance Assist Operation Forward Collision-Avoidance Assist Settings Forward/Reverse Parking Distance Warning (PDW) Forward/Reverse Parking Distance Warning Malfunction and Limitation Forward/Reverse Parking Distance Warning Operation Forward/Reverse Parking Distance Warning Settings Fuel Filler Door Fuel Requirements Fuses	7-77-47-37-76 s7-777-765-601-5
Forward Collision–Avoidance Assist (FCA) (Front view camera only) Forward Collision-Avoidance Assist Malfunction and Limitations Forward Collision-Avoidance Assist Operation Forward Collision-Avoidance Assist Settings Forward/Reverse Parking Distance Warning (PDW) Forward/Reverse Parking Distance Warning Malfunction and Limitation Forward/Reverse Parking Distance Warning Operation Forward/Reverse Parking Distance Warning Settings Fuel Filler Door Fuel Requirements Fuses Engine Compartment Panel Fuse Replacement	7-77-47-37-76 s7-777-765-601-59-47
Forward Collision–Avoidance Assist (FCA) (Front view camera only) Forward Collision-Avoidance Assist Malfunction and Limitations Forward Collision-Avoidance Assist Operation Forward Collision-Avoidance Assist Settings Forward/Reverse Parking Distance Warning (PDW) Forward/Reverse Parking Distance Warning Malfunction and Limitation Forward/Reverse Parking Distance Warning Operation Forward/Reverse Parking Distance Warning Settings Fuel Filler Door Fuel Requirements Fuses Engine Compartment Panel Fuse Replacement Fuse/Relay Panel Description	7-77-47-76 s7-777-765-601-59-479-50
Forward Collision–Avoidance Assist (FCA) (Front view camera only) Forward Collision-Avoidance Assist Malfunction and Limitations Forward Collision-Avoidance Assist Operation Forward Collision-Avoidance Assist Settings Forward/Reverse Parking Distance Warning (PDW) Forward/Reverse Parking Distance Warning Malfunction and Limitation Forward/Reverse Parking Distance Warning Operation Forward/Reverse Parking Distance Warning Settings Fuel Filler Door Fuel Requirements Fuses Engine Compartment Panel Fuse Replacement	7-77-47-76 s7-777-765-601-59-479-50
Forward Collision–Avoidance Assist (FCA) (Front view camera only) Forward Collision-Avoidance Assist Malfunction and Limitations Forward Collision-Avoidance Assist Operation Forward Collision-Avoidance Assist Settings Forward/Reverse Parking Distance Warning (PDW) Forward/Reverse Parking Distance Warning Malfunction and Limitation Forward/Reverse Parking Distance Warning Operation Forward/Reverse Parking Distance Warning Settings Fuel Filler Door Fuel Requirements Fuses Engine Compartment Panel Fuse Replacement Fuse/Relay Panel Description	7-77-47-76 s7-777-765-601-59-479-50
Forward Collision–Avoidance Assist (FCA) (Front view camera only) Forward Collision-Avoidance Assist Malfunction and Limitations Forward Collision-Avoidance Assist Operation Forward/Reverse Parking Distance Warning (PDW) Forward/Reverse Parking Distance Warning Malfunction and Limitation Forward/Reverse Parking Distance Warning Operation Forward/Reverse Parking Distance Warning Settings Fuel Filler Door Fuel Requirements Fuses	7-77-47-76 s7-777-765-601-59-479-50

H	
Hazard Warning Flasher	8-2
High Beam Assist (HBA)	
Detecting Sensor	
High Beam Assist Malfunction and Limitations	
High Beam Assist Operation	
High Beam Assist Settings	
Hood	
How to Use This Manual	1-4
Hyundai Digital Key	5-12
Digital Key (Card Key)	
Digital Key (Smartphone)	
Limitations of the System	
Used Vehicle/Digital Key Maintenance	
HYUNDAI Motor America	1-2
1	
	0.7
If the Engine Overheats	
If the Engine Will not Start	
If the Engine Doesn't Turn Over or Turns Over Slowly	
If the Engine Turns Over Normally but Doesn't Start	
If You Have a Flat Tire (with Tire Mobility Kit)	
Components of the Tire Mobility Kit	
Introduction	
Notes on the Safe Use of the Tire Mobility Kit	
Using the Tire Mobility Kit when a Tire is Flat	
Important Safety Precautions	
Air Bag Hazards	
All bag Hazards	
Control Your Speed	
Driver Distraction	
Keep Your Vehicle in Safe Condition	
Restrain All Children	
In Case of an Emergency While Driving	
If the Engine Stalls at a Crossroad or Crossing	
If the Engine Stalls While Driving	
If you Have a Flat Tire While Driving	
11 Jou 11410 4 1 14t 1110 11 111tt D11111115	

Infotainment System	5-111
Antenna	5-111
Bluetooth® Wireless Technology Hands-free	5-113
How Vehicle Radio Works	5-114
Infotainment System	5-113
Steering Wheel Audio Control	5-112
USB Port	5-111
Voice Recognition	5-113
Instrument Cluster	4-4
Cluster Display Messages	4-21
Gauges and Meters	4-5
Instrument Cluster Control	4-5
Transmission Shift Indicator	4-10
Warning and Indicator Lights	4-11
Instrument Panel Overview	2-6
Intelligent Speed Limit Assist (ISLA)	7-40
Intelligent Speed Limit Assist Malfunction and Limitations	7-44
Intelligent Speed Limit Assist Operation	7-42
Intelligent Speed Limit Assist Settings	7-41
Interior Features	5-105
Clock	5-110
Coat Hook	5-110
Cup Holder	5-105
Power Outlet	5-106
Sunvisor	5-105
USB charger	5-107
Wireless Smartphone Charging System	5-107
Interior Lamps	5-69
Front Lamps	5-69
Interior Lamp AUTO Cut	5-69
Luggage Compartment Lamp	5-71
Mood lighting	5-70
Rear Lamp	5-70
Vanity Mirror Lamp	5-71
Welcome System	
Interior Overview	2-4
Introduction	1-2

J	
Jump Starting8	3-4
L	
Lane Following Assist (LFA)	60 58 57 14 17 15 14 58 59 61 62 62 59
M	
Maintenance Services9Owner Maintenance Precautions9Owner's Responsibility9Manual Climate Control System5-Heating and Air Conditioning5-System Maintenance5-System Operation5-	75 76 84
Manual Speed Limit Assist (MSLA)         7-           Manual Speed Limit Assist Operation         7-           Manual Speed Limit Assist Settings         7-           Manual Transmission (MT)         6-           Good Driving Practices         6-           Manual Transmission Operation         6-           Rev Matching         6-	37 38 37 12 14 12
Mirrors       5-         Inside Rearview Mirror       5-         Side View Mirrors       5-	31 31

N	
N Button	
0	
Open Source Software Notice 2- Owner Maintenance 9 Owner Maintenance Schedule 9	9-5
P	
Parking Brake 9- Checking the Parking Brake 9- Performance Option 6- Launch Control 6- Maximum Performance Driving (How to drive with Octane Number Learning) 6- N Power Shift (for dual clutch transmission) 6- N Sound Equalizer 6- N Track Sense Shift (for dual clutch transmission) 6- Performance Option Settings 6- Shift Light 6-	-24 -51 -52 -61 -59 -57 -51
R	
Rear Cross-Traffic Collision-Avoidance Assist (RCCA)       7-         Rear Cross-Traffic Collision Avoidance Assist Malfunction and Limitations. 7-         Rear Cross-Traffic Collision Avoidance Assist Operation       7-         Rear Cross-Traffic Collision Avoidance Assist Settings       7-         Rear Occupant Alert (ROA)       5-         Rear Occupant Alert Operation       5-         Rear View Monitor (RVM)       7-         Rear View Monitor Malfunction and Limitations       7-         Rear View Monitor Operation       7-         Rear View Monitor Settings       7-         Recommended Lubricants and Capacities       2-         Recommended SAE Viscosity Number       2-	.70 .67 .66 .27 .61 .64 .63 .61 .12
Reporting Safety Defects2-	17

	(	١	١	1
۰	٠	i	2	,

Safe Exit Warning (SEW)	7-32
Safe Exit Warning Malfunction and Limitations	7-34
Safe Exit Warning Operation	7-33
Safe Exit Warning Settings	7-32
Safety Messages	1-4
Scheduled Maintenance Services	9-7
Maintenance Under Severe Usage Conditions	9-12
Normal Maintenance Schedule	
Seat Belts	3-13
Additional Seat Belt Safety Precautions	3-19
Care of Seat Belts	3-21
Seat Belt Restraint System	3-14
Seat Belt Safety Precautions	3-13
Seat Belt Warning Light	3-14
Seats	3-3
Front Seats	3-5
Head Restraints	3-9
Rear seats	3-7
Safety Precautions	3-4
Seat Warmers	3-11
Smart Key	5-4
Battery Replacement	5-10
Immobilizer System	5-11
Locking	5-4
Loss of a Smart Key	5-8
Mechanical Key	5-8
Panic Button	5-7
Remotely Starting Vehicle	5-7
Smart Key Precautions	5-9
Start-up	5-8
Trunk Unlocking	5-7
Unlocking your vehicle (When the Two Press Unlock feature is off)	5-5
Unlocking your vehicle (When the Two Press Unlock feature is on)	5-6

Special Driving Conditions	0-02
Driving at Night	6-63
Driving in Flooded Areas	6-64
Driving in the Rain	6-63
Hazardous Driving Conditions	6-62
Highway Driving	6-64
Rocking the Vehicle	6-62
Smooth Cornering	6-63
Steering Wheel	5-29
Horn	5-30
Motor Driven Power Steering (MDPS)	5-29
Tilt Steering / Telescope Steering	5-30
Storage Compartment	5-104
Center Console Storage	5-104
Glove Box	5-104
Sunroof	5-49
Automatic Reversal	5-51
Resetting the Sunroof	5-52
Slide Open/Close	5-50
Sunroof Open Warning	5-52
Sunshade	5-49
Tilt Open/Close	5-50
_	
Т	
Theft-alarm System	5-28
Tire Pressure Monitoring System (TPMS)	
Changing a Tire with TPMS	8-13
Check Tire Pressure	8-9
Low Tire Pressure Position and Tire Pressure Telltale	8-11
Low Tire Pressure Telltale	
Tire Pressure Monitoring System	8-10
TPMS (Tire Pressure Monitoring System) Malfunction Indicator	
Tire Specification and Pressure Label	

Tires and Wheels
All Season Tires 9-44
Check Tire Inflation Pressure 9-35
Low Aspect Ratio Tires
Radial-Ply Tires
Recommended Cold Tire Inflation Pressures 9-34
Snow Tires 9-44
Summer Tires
Tire Care 9-34
Tire Maintenance
Tire Replacement9-37
Tire Rotation9-35
Tire Sidewall Labeling
Tire Terminology and Definitions
Tire Traction
Wheel Alignment and Tire Balance9-36
Wheel Replacement9-38
Towing
Emergency Towing8-23
Emergency Towing8-24
Removable Towing Hook8-23
Towing Service
Trailer Towing6-73
Trunk
Emergency Trunk Safety Release5-56
Smart Trunk Release
V
Vehicle Auto-Shut Off6-11
Deactivating Conditions 6-11
Operating Conditions 6-11
System Operation 6-11

Vehicle Break-in Process	1-/
Vehicle Certification Label	2-14
Vehicle Data Collection and Event Data Recorders	1-8
Vehicle Identification Number (VIN)	2-14
Vehicle Load Limit	6-69
Tire Loading Information Label	6-70
Vehicle Modifications	1-7
Vehicle Settings (Infotainment System)	4-33
Setting Your Vehicle	4-33
Volume and Weight	2-11
W	
Washer Fluid	9-24
Checking the Washer Fluid Level	9-24
Windows	5-44
Power Windows	5-45
Windshield Defrosting and Defogging	5-98
Auto Defogging System (only for automatic climate control system)	5-101
Automatic Climate Control System	5-99
Defogging Logic	5-100
Defroster	5-102
Manual Climate Control System	5-98
Winter Driving	6-65
Snow or Icy Conditions	6-65
Winter Precautions	6-67
Wiper Blades	9-28
Blade Inspection	9-28
Blade Replacement	9-28
Wipers and Washers	5-73
Windshield Washers	5-74
Windshield winers	5_73