LINK: CONTENT & A-Z

BMW X5.



The Ultimate Driving Machine®







## WELCOME TO BMW.

## Owner's Manual.

Thank you for choosing a BMW.

The more familiar you are with your vehicle, the better control you will have on the road. We therefore strongly suggest:

Read this Owner's Manual before starting off in your new BMW. Also use the Integrated Owner's Manual in your vehicle. It contains important notes on vehicle operation that will help you make full use of the technical features available in your BMW. The manual also contains information designed to enhance operating reliability and traffic safety, and to contribute to maintaining the value of your BMW.

At the time of production at the plant, the printed Owner's Manual is the most current resource. After a vehicle software update – such as, a Remote Software Upgrade – the Integrated Owner's Manual for the vehicle will contain the latest information.

You can find supplementary information in the additional brochures in the vehicle literature.

We wish you a safe and enjoyable ride.

## **TABLE OF CONTENTS**

After a vehicle software update – such as, a Remote Software Upgrade – the Integrated Owner's Manual for the vehicle will contain the latest information.

N	0	T	F	S
	_			_

nformation	. 6
Owner's Manual media	14
◆ QUICK REFERENCE	
Entering	16
Set-up and use	20
On the road	24
<b>↓</b> CONTROLS	
Dashboard	32
Sensors of the vehicle	37
Operating state of the vehicle	41
Drive	44
BMW Remote Software Upgrade	59
General settings	63
Personal settings	68
Connections	73
Opening and closing	82
Seats, mirrors and steering wheel 1	17
Fransporting children safely 1	35
Driving 1	41
Displays 1	59
_ights1	79
Safety 1	
Oriving stability control systems2	223
Oriver assistance systems2	230
Driving comfort2	280
Climate control 2	287

Interior equipment	305
Storage compartments	316
Cargo area	321
i DRIVING TIPS	
Things to remember when driving	
Trailer towing	336
Saving fuel	340
MOBILITY	
Refueling	346
Wheels and tires	
Engine compartment	381
Operating materials	384
Maintenance	391
Replacing components	393
Breakdown Assistance	398
Vehicle Care	406
Q REFERENCE	
Technical data	412
Appendix	
Even/thing from Δ to 7	418

© 2021 Bayerische Motoren Werke

Aktiengesellschaft

Munich, Germany

Reprinting, including excerpts, only with the written consent of BMW AG, Munich. US English ID7 VI/21, -

Printed on environmentally friendly paper, bleached without chlorine, suitable for recycling.

## Information

## **Using this Owner's Manual**

#### Orientation

The fastest way to find information on a particular topic is by using the index.

An initial overview of the vehicle is provided in the first chapter.

### Validity of the Owner's Manual

#### Production of the vehicle

At the time of production at the plant, the printed Owner's Manual is the most current resource. Due to updates after the editorial deadline, differences may exist between the printed Owner's Manual and the Integrated Owner's Manual in the vehicle.

Notes on updates can be found in the appendix of the printed Owner's Manual for the vehicle.

## After a software update in the vehicle

After a vehicle software update, such as via Remote Software Upgrade, the Integrated Owner's Manual for the vehicle will contain the latest information.

## Owner's Manual for Navigation, Entertainment, Communication

The Owner's Manual for Navigation, Entertainment, and Communication can be obtained as a printed book from the service center.

The topics are also discussed in the Integrated Owner's Manual in the vehicle.

# Additional sources of information

#### Service center

A service center will be glad to answer questions at any time.

#### Internet

Vehicle information and general information on BMW, for instance, on technology, are available on the Internet: www.bmwusa.com.

## Integrated Owner's Manual in the vehicle

The Integrated Owner's Manual specifically describes features and functions found in the vehicle. The Integrated Owner's Manual can be displayed on the Control Display.

#### **BMW Driver's Guide app**

The BMW Driver's Guide app specifically describes features and functions found in the vehicle. The app can be displayed on smartphones and tablets.

#### **BMW Driver's Guide Web**

Driver's Guide Web shows the most suitable information for the selected vehicle. If possible, only equipment and functions that are actually installed in the vehicle will be explained. Driver's Guide Web can be displayed in any current browser.

## Symbols and displays

### **Symbols in the Owner's Manual**

#### Icon Meaning



Precautions that must be followed in order to avoid the possibility of injury to vourself and to others as well as serious damage to the vehicle.



Measures that can be taken to help protect the environment.

Texts in vehicle used to select individual functions

>...<

Verbal instructions to use with the voice activation system.

Responses generated by the voice activation system.

### **Action steps**

Action steps to be carried out are presented as a numbered list. The steps must be carried out in the defined order

- 1. First action step.
- 2. Second action step.

#### **Enumerations**

Enumerations without mandatory order or alternative possibilities are presented as a list with bullet points.

- First possibility.
- Second possibility.

### **Icons on vehicle components**

This symbol on a vehicle component indicates that further information on the component is available in the Owner's Manual.

## Vehicle equipment and options

This Owner's Manual describes all models and all standard, country-specific and optional equipment that is offered in the model series. Therefore, this Owner's Manual also describes and illustrates features and functions that are not available in a vehicle, for example because of the selected optional equipment or the country-specific version.

This also applies to safety-related functions and systems.

When using these functions and systems, the applicable laws and regulations must be ob-

For any options and equipment not described in this Owner's Manual, refer to the Supplementary Owner's Manuals.

Your BMW service center is happy to answer any questions that you may have about the features and options applicable to your vehicle.

## Status of the Owner's **Manual**

#### **Basic information**

The manufacturer of your vehicle pursues a policy of constant development that is conceived to ensure that our vehicles continue to embody the highest quality and safety standards. In rare cases, therefore, the features described in this Owner's Manual may differ from those in your vehicle.

### Validity of the Owner's Manual

#### Production of the vehicle

At the time of production at the plant, the printed Owner's Manual is the most current resource. Due to updates after the editorial deadline, differences may exist between the printed Owner's

Manual and the Integrated Owner's Manual in the vehicle.

Notes on updates can be found in the appendix of the printed Owner's Manual for the vehicle.

## After a software update in the vehicle

After a vehicle software update, such as via Remote Software Upgrade, the Integrated Owner's Manual for the vehicle will contain the latest information

## For Your Own Safety

#### Intended use

Heed the following when using the vehicle:

- Owner's Manual.
- ▶ Information on the vehicle. Do not remove stickers.
- Technical vehicle data.
- ➤ The traffic, speed, and safety laws where the vehicle is driven.
- ▶ Vehicle documents and statutory documents.

### Warranty

Your vehicle is technically configured for the operating conditions and registration requirements applying in the country of first delivery, also known as homologation. If your vehicle is to be operated in a different country it might be necessary to adapt your vehicle to potentially differing operating conditions and registration requirements. Noncompliance with homologation requirements in a certain country may affect warranty coverage. Please consult the New Vehicle Limited Warranty Booklet for further information on warranty matters.

### Maintenance and repairs

Advanced technology, for instance the use of modern materials and high-performance elec-

tronics, requires suitable maintenance and repair work.

The manufacturer of the vehicle recommends that you entrust corresponding procedures to a BMW center. If you choose to use another service facility, BMW recommends use of a facility that performs work, e.g., maintenance and repair, according to BMW specifications with properly trained personnel, referred to in the Owner's Manual as "another qualified service center or repair shop".

If work is performed improperly, for instance maintenance and repair, there is a risk of subsequent damage and related safety risks.

Improperly performed work on the vehicle paintwork can lead to a failure or fault of components, e.g., the radar sensors, and thereby result in a safety risk.

#### Parts and accessories

BMW recommends the use of parts and accessory products approved by BMW.

Approved parts and accessories, and advice on their use and installation are available from a BMW center.

BMW parts and accessories have been tested by BMW for their safety and suitability in BMW vehicles.

BMW warrants genuine BMW parts and accessories.

BMW does not evaluate whether each individual product from another manufacturer can be used with BMW vehicles without presenting a safety hazard, even if a country-specific official approval was issued. BMW does not evaluate whether these products are suitable for BMW vehicles under all usage conditions.

## California Proposition 65 Warning

For vehicles sold in California, the law requires vehicle manufacturers to provide the following warning:

#### Marning

Engine exhaust and a wide variety of Automobile components and parts, including components found in the interior furnishings in a vehicle, contain or emit chemicals known to the State of California to cause cancer and birth defects and reproductive harm. In addition, certain fluids contained in vehicles and certain products of component wear contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Battery posts, terminals and related accessories contain lead and lead compounds. Batteries also contain other chemicals known to the State of California to cause cancer. Wash vour hands after handling. Used engine oil contains chemicals that have caused cancer in laboratory animals. Always protect your skin by washing thoroughly with soap and water. For more information go to www.P65Warnings.ca.gov/passenger-vehicle.

### Warning

Operating, servicing and maintaining a passenger vehicle or off-highway motor vehicle can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle in a well-ventilated area and wear gloves or wash your hands frequently when servicing your vehicle. For more information go to www.P65Warnings.ca.gov/passenger-vehicle.

## Service and warranty

We recommend that you read this publication thoroughly. Your vehicle is covered by the following warranties:

- New Vehicle Limited Warranty.
- Rust Perforation Limited Warranty.
- ▶ Federal Emissions System Defect Warranty.
- ▶ Federal Emissions Performance Warranty.
- California Emission Control System Limited Warranty.

Detailed information about these warranties is listed in the New Vehicle Limited Warranty Book-

Your vehicle has been specifically adapted and designed to meet the particular operating conditions and homologation requirements in your country and continental region in order to deliver the full driving pleasure while the vehicle is operated under those conditions. If you wish to operate your vehicle in another country or region, you may be required to adapt your vehicle to meet different prevailing operating conditions and homologation requirements. You should also be aware of any applicable warranty limitations or exclusions for such country or region. In such case, please contact Customer Relations for further information.

#### Maintenance

Maintain the vehicle regularly to sustain the road safety, operational reliability and the New Vehicle Limited Warranty.

Specifications for maintenance measures:

- BMW Maintenance system.
- ▶ Maintenance Booklet, available online and accessible via a QR code in the New Vehicle Limited Warranty Booklet.
- Warranty and Service Guide Booklet for Canadian models.

If the vehicle is not maintained or is improperly maintained, this could result in serious damage to the vehicle.

A failure to maintain your vehicle or improper maintenance may affect your warranty coverage. Please consult the New Vehicle Limited Warranty Booklet for further information on warranty matters.

Refer to section on engine oil change regarding recommended service intervals for oil changes.

## **Data memory**

#### **General information**

Electronic control devices are installed in the vehicle. Electronic control units process data they receive from vehicle sensors, self-generate or exchange with each other. Some control units are necessary for the vehicle to function safely or provide assistance during driving, for instance driver assistance systems. Furthermore, control units facilitate comfort or infotainment functions. Information about stored or exchanged data can be requested from the manufacturer of the vehicle, in a separate booklet, for example.

#### **Personal reference**

Each vehicle is marked with a unique vehicle identification number. Depending on the country, the vehicle owner can be identified with the vehicle identification number, license plate and corresponding authorities. In addition, there are other options to track data collected in the vehicle to the driver or vehicle owner, for instance, via the ConnectedDrive account that is used.

### Operating data in the vehicle

Control units process data to operate the vehicle. For example, this includes:

- Status messages for the vehicle and its individual components, e.g., wheel rotational speed, wheel speed, deceleration, lateral acceleration, engaged safety belt indicator.
- ► Ambient conditions, e.g., temperature, rain sensor signals.

The processed data is only processed in the vehicle itself and generally volatile. The data is not stored beyond the operating period.

Electronic components, e.g. control units and vehicle keys, contain components for storing tech-

nical information. Information about the vehicle condition, component usage, maintenance recommendations, events or faults can be stored temporarily or permanently.

This information generally documents the state of a component, a module, a system, or the surrounding area, for instance:

- Operating states of system components, for instance, fill levels, tire pressure, battery status.
- ▶ Malfunctions and faults in important system components, for instance lights and brakes.
- Responses by the vehicle to special driving situations such as airbag deployment or engagement of the driving stability control systems.
- ▶ Information on vehicle-damaging events.

The data is required to perform the control unit functions. Furthermore, it also serves to detect and correct malfunctions, and helps the vehicle manufacturer to optimize vehicle functions.

The majority of this data is stored temporarily and is only processed within the vehicle itself. In some circumstances the vehicle may store some data for an additional but limited period of time.

When servicing, for instance during repairs, service processes, warranty cases, and quality assurance measures, this technical information can be read out from the vehicle together with the vehicle identification number.

A dealer's service center or another qualified service center or repair shop can read out the information. The socket for OBD Onboard Diagnosis required by law in the vehicle is used to read out the data.

The data is collected, processed, and used by the relevant organizations in the service network. The data documents technical conditions of the vehicle, which can be used to determine vehicle maintenance status, and facilitate quality improvement.

Fault and event memories in the vehicle can be reset when a dealer's service center or another

qualified service center or repair shop performs repair or servicing work.

## Data entry and data transmission into the vehicle

#### **General information**

Depending on the vehicle equipment, comfort and individual settings can be stored in the vehicle and modified or reset at any time.

For example, this includes:

- Settings for the seat and steering wheel positions.
- Chassis and climate control settings.

If necessary, data can be transferred to the entertainment and communication system of the vehicle, for instance via smartphone.

This includes the following depending on the respective equipment:

- Multimedia data such as music, films or photos for playback in an integrated multimedia system.
- Address book data for use in conjunction with an integrated hands-free system or an integrated navigation system.
- Entered navigation destinations.
- Data on the use of Internet services.

This data can be stored locally in the vehicle or is found on a device that has been connected to the vehicle, e.g., a smartphone, USB stick or MP3 player. If this data is stored in the vehicle, it can be deleted at any time.

This data is only transmitted to third parties upon personal request as part of the use of online services. The transmission depends on the selected settings for the use of the services.

#### Incorporation of mobile devices

Depending on the vehicle equipment, mobile devices connected to the vehicle, for instance smartphones, can be controlled via the vehicle control elements.

The sound and picture from the mobile device can be played back and displayed through the multimedia system. Certain information is transferred to the mobile device at the same time. Depending on the type of incorporation, this includes, for instance position data and other general vehicle information. This optimizes the way in which selected apps, for instance navigation or music playback, work.

There is no further interaction between the mobile device and the vehicle, such as active access to vehicle data

How the data will be processed further is determined by the provider of the particular app being used. The extent of the possible settings depends on the respective app and the operating system of the mobile device.

#### **Services**

#### **General information**

If the vehicle has a wireless network connection, this enables data to be exchanged between the vehicle and other systems. The wireless network connection is realized via an in-vehicle transmitter and receiver unit or via personal mobile devices brought into the vehicle, for instance smartphones. This wireless network connection enables 'online functions' to be used. These include online services and apps supplied by the vehicle manufacturer or by other providers.

## Services from the vehicle manufacturer

Where online services from the vehicle manufacturer are concerned, the corresponding functions are described in the appropriate place, for instance the Owner's Manual or manufacturer's website. The relevant legal information pertaining to data protection may also be found on the manufacturer's website. Personal data may be used to perform online services. Data is exchanged over a secure connection, for instance with the IT systems of the vehicle manufacturer intended for this purpose.

Any collection, processing, and use of personal data above and beyond that needed to provide the services must always be based on a legal permission, contractual arrangement or consent. It is also possible to activate or deactivate the data connection as a whole. That is, with the exception of functions and services required by law such as Assist systems.

#### Services from other providers

When using online services from other providers, these services are the responsibility of the relevant provider and subject to their data privacy conditions and terms of use. The vehicle manufacturer has no influence on the content exchanged during this process. Information on the way in which personal data is collected and used in relation to services from third parties, the scope of such data, and its purpose, can be obtained from the relevant service provider.

### **Event Data Recorder EDR**

This vehicle is equipped with an event data recorder EDR. The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less.

The EDR in this vehicle is designed to record such data as:

- How various systems in your vehicle were operating.
- ▶ Whether or not the driver and passenger safety belts were fastened.
- ▶ How far, if at all, the driver was depressing the accelerator and/or brake pedal.
- ▶ How fast the vehicle was traveling.

This data can help provide a better understanding of the circumstances in which crashes and injuries occur.

EDR data is recorded by your vehicle only if a nontrivial crash situation occurs; no data is recorded by the EDR under normal driving conditions and no personal data, for instance name, gender, age, and crash location, are recorded.

However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR.

# Vehicle identification number

#### **General information**

Depending on the national-market version, the vehicle identification number is located in different positions in the vehicle. This chapter describes all possible positions for the series.

#### **Engine compartment**



The engraved vehicle identification number can be found in the engine compartment, on the right-hand side of the vehicle.

#### **Right nameplate**



The vehicle identification number can be found on the nameplate, on the right-hand side of the vehicle.

### Left nameplate



The vehicle identification number can be found on the nameplate, on the left-hand side of the vehicle.

### Windshield



The vehicle identification number can also be found behind the windshield.

#### **iDrive**

It is also possible to display the vehicle identification number via iDrive.

Additional information:

Displaying the vehicle identification number and software part number, refer to page 74.

## Reporting safety defects

#### For US customers

The following only applies to vehicles owned and operated in the US.

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration NHTSA, in addition to notifying BMW of North America, LLC, P.O. Box 1227, Westwood, New Jersey 07675-1227, Telephone 1-800-831-1117.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign.

However, NHTSA cannot become involved in individual problems between you, your dealer, or BMW of North America, LLC.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to http://www.safercar.gov; or write to: Administrator, NHTSA, 1200 New Jersey Avenue, SE., Washington, DC 20590. You can also obtain other information about motor vehicle safety from http://www.safercar.gov.

#### For Canadian customers

Canadian customers who wish to report a safety-related defect to Transport Canada, Defect Investigations and Recalls, may call the toll-free hotline 1-800-333-0510. You can also obtain other information about motor vehicle safety from http://www.tc.gc.ca/roadsafety.

## **Owner's Manual media**

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

### **General information**

#### Media at a glance

You can use various media formats to call up the content in the Owner's Manual. The following Owner's Manual media formats are available:

- Printed Owner's Manual.
- ▶ Integrated Owner's Manual in the vehicle.

## Validity of the Owner's Manual

#### Production of the vehicle

At the time of production at the plant, the printed Owner's Manual is the most current resource. Due to updates after the editorial deadline, differences may exist between the printed Owner's Manual and the Integrated Owner's Manual in the vehicle.

Notes on updates can be found in the appendix of the printed Owner's Manual for the vehicle.

## After a software update in the vehicle

After a vehicle software update, such as via Remote Software Upgrade, the Integrated Owner's

Manual for the vehicle will contain the latest information.

### **Printed Owner's Manual**

#### **Concept**

The printed Owner's Manual describes all standard, country-specific, and optional features offered with the series.

#### **General information**

The Owner's Manual for Navigation, Entertainment, and Communication can be obtained as a printed book from the service center.

### **Supplementary Owner's Manuals**

Also follow the Supplementary Owner's Manuals, which are included in addition to the onboard literature.

# Integrated Owner's Manual in the vehicle

#### **Principle**

The Integrated Owner's Manual specifically describes features and functions found in the vehicle.

The Integrated Owner's Manual can be displayed on the Control Display.

### **Selecting the Owner's Manual**



Press the button.

- 2. "CAR"
- 3. "Owner's Manual"
- Select the desired method of accessing the contents.

## Scrolling through the Owner's Manual

Turn the Controller, until the next or previous contents are displayed.

#### **Context help**

#### **General information**

The Integrated Owner's Manual can be accessed from any menu. Depending on the selected function, either the associated description or the main menu of the Integrated Owner's Manual will be displayed.

#### **Opening via iDrive**

Change directly to the Options menu from the function on the Control Display:

- 1. Press the button.
- 2. "Help"

## Opening when a Check Control message is displayed

Directly from the Check Control message on the Control Display:

i "Owner's Manual"

## **Entering**

## **Opening and closing**

#### **Buttons on the vehicle key**



- 1 Unlocking
- 2 Locking
- 3 To open the tailgate
- 4 Panic mode, pathway lighting

### Unlocking the vehicle



Press the button on the vehicle key.

Depending on the settings, either only the driver's door or all vehicle access points are unlocked.

If only the driver's door is unlocked, press the button on the vehicle key again to unlock the other vehicle access points.



Press and hold the button on the vehicle key after unlocking.

The windows and the glass sunroof are opened, as long as the button on the vehicle key is pressed.

### Locking the vehicle

- 1. Close the driver's door.
- 2. Press the button on the vehicle key.

  All vehicle access points are locked.

# **Buttons for the central locking system**

#### Overview



Buttons for the central locking system.

#### Locking



Press the button with the front doors closed.

The fuel filler flap remains unlocked.

#### **Unlocking**



Press the button.

#### Panic mode

You can trigger the alarm system if you find yourself in a dangerous situation.



- ▶ Press the button on the vehicle key and hold for at least 3 seconds.
- ▶ Briefly press the button on the vehicle key three times in succession.

To switch off the alarm: press any button.

#### **Comfort Access**

#### **Principle**

The vehicle can be accessed without operating the vehicle key.

Carrying the vehicle key with you, e.g., in your pants pocket, is sufficient.

The vehicle automatically detects the vehicle key when it is in close proximity or in the car's interior.

#### Unlocking the vehicle



Grasp the handle of a vehicle door completely.

#### Locking the vehicle



Touch the grooved surface on the handle of a closed vehicle door with your finger for approx. 1 second without grasping the door handle.

## Opening and closing the tailgate with no-touch activation

#### **Principle**

The tailgate can be opened and closed with notouch activation using the vehicle key you are carrying.

#### Performing the foot movement

- Stand in the middle behind the vehicle at approx. one arm's length away from the rear of the vehicle.
- 2. Wave a foot under the vehicle in the driving direction and immediately pull it back. With this movement, the leg must pass through the ranges of both sensors.



### **Tailgate**

#### **Opening**



▶ Unlock the vehicle and then press the button on the outer side of the tailgate.



Press and hold the button on the vehicle key for approx. 1 second.

With Comfort Access: Depending on the settings, the bottom tailgate also opens.

Selector lever position P must be engaged to open the tailgate with the vehicle key.

#### Closing

- 1. Without Comfort Access: closing the lower tailgate manually.
  - With Comfort Access: the lower tailgate will be closed automatically with the upper tailgate.
- 2. Press the button on the inside of the upper tailgate.



## Displays, control elements

## In the vicinity of the steering wheel




- 1 Light switch element
- 2 Turn signal indicator, high beams
- 3 Instrument cluster
- 4 Wipers

### **Indicator/warning lights**

The indicator/warning lights can light up in a variety of combinations and colors.

Several of the lights are checked for proper functioning and light up temporarily when drive-ready state is turned on.

#### **Driver's door**



- 1 Safety switch
- 2 Power windows
- 3 Central locking system
- 4 Exterior mirrors
- 5 Seats, comfort features
- 6 Opening/closing the tailgate

#### Switch console



- 1 Selector lever
- 2 Controller
- 3 Parking brake, Automatic Hold
- 4 Driving Dynamics Control
- 5 Start/Stop button
- **6** Assistance systems

#### **iDrive**

#### **Principle**

iDrive is the operating concept of the infotainment system and includes a large number of functions.

#### **Buttons on the Controller**

Button	Function
HOME	Go to the main menu.
	Go to Apps menu.
MEDIA	Go to the Media/Radio menu.
сом	Go to the Communication menu.
МАР	Go to navigation map.
NAV	Go to destination input menu for navigation.
BACK	Go to the previous display.
OPTION	Go to the Options menu.

#### **Voice control**

#### Activating the voice control system



Press the button on the steering wheel.

Say the command.

#### **Ending voice control**




Press the button on the steering wheel or Cancels.

## Set-up and use

# Seats, mirrors and steering wheel


#### **Electrically adjustable seats**



- Backrest width
- 2 Thigh support
- 3 Forward/backward, height, seat tilt
- 4 Upper backrest
- 5 Backrest tilt, head restraint
- 6 Lumbar support

### Adjusting the head restraint

#### Adjusting the height



Press switch up or down.

#### **Adjusting distance**



- Back: press the button and push the head restraint toward the rear.
- ▶ Forward: pull the head restraint toward the front.

After setting the distance, make sure that the head restraint engages correctly.

#### Side extensions



Fold the side extensions forward to increase lateral support.

### **Adjusting the exterior mirrors**



- 1 Adjusting
- 2 Selecting a mirror, Automatic Curb Monitor
- 3 Folding in and out

### Adjusting the steering wheel

#### **Electrical steering wheel adjustment**



Press the switch to adjust the forward/back position and height of the steering wheel to the seat position.

#### **Memory function**

#### **Principle**

The following settings can be stored and, if necessary, retrieved using the memory function:

- Seat position.
- > Exterior mirror position.
- ▶ Steering wheel position.
- ▶ Height of the Head-up Display.

#### **Storing**

- 1. Set the desired position.
- 2. SET Press the button. The writing on the button lights up.
- 3. Press the desired button 1 or 2 at the door while the writing is lit. A signal sounds.

#### **Calling up settings**

Press the desired button 1 or 2.

### Infotainment

#### **Radio**

#### **Buttons and functions**

Depending on the country and equipment version, the radio has the following buttons.

Button	Function
0	Press: turns sound output on/ off. Turn: adjusts the volume.
MODE	Change the entertainment source.
M4 PM	Press once: changes the station/track.
< ▷	Press and hold: fast forward/ rewind the track.
17	Programmable memory buttons.
1	
1 8	

Button	Function
BAND	Changeover of waveband/satellite radio.
	Menu Apps.

#### **Navigation destination input**

#### **Entering a destination via the search**

- 1. Press the button on the Controller.
- 2 0 104/1 1 21
- 2. "Where to?"
- 3. Enter at least two letters or characters.

Select point of interest categories from the points of interest menu as needed.

The search term may be completed automatically in orange lettering.

Move the Controller up to accept the suggested search term.

- OK Select the icon, if needed.
   A list of the results is displayed.
- 5. If necessary, "Filter"
- "Show results"
- 7. Select the desired entry.
- 8. If necessary, "Start guidance"

#### Connecting a mobile phone

#### **General information**

After the mobile phone is connected once to the vehicle, the mobile phone can be operated using iDrive and the steering wheel buttons.

## Connecting the mobile phone via Bluetooth

- 1. "COM"
- 2. "Mobile devices"
- 3. Tilt the Controller to the right.
- 4. "New device"

- "Phone calls and audio"
   The vehicle's Bluetooth name is displayed on the Control Display.
- Compare the control number displayed on the Control Display with the control number on the display of the mobile device, and confirm that the two match.
- 7. A Bluetooth connection is established.

The mobile device is connected to the vehicle and displayed in the device list.

### Using the telephone

#### Accepting a call

Depending on the equipment, incoming calls can be answered in several ways.

- Via iDrive:
  - <sup>™</sup> "Accept"



Press the corresponding button on the steering wheel.

- Via the selection list in the instrument cluster: Use the thumbwheel on the steering wheel to select: "Accept"
- ▶ Via touchscreen: tap on the corresponding entry on the Control Display.

#### Dialing a number

- 1. "COM"
- 2. If necessary, "Telephone"
- "Dial number:"
- Enter the numbers.
- Select the icon. The connection is established via the mobile phone to which this function has been assigned.

Establish the connection via the additional telephone:

- 1. Press the button.
- 2. "Call via"

#### **Apple CarPlay® preparation**

#### **Principle**

CarPlay allows certain functions of a compatible Apple iPhone to be used via Siri voice control and iDrive.

#### **Functional requirements**

- Compatible iPhone, iPhone 5 or later with iOS 7.1 or later.
- ▶ Corresponding mobile contract.
- If necessary, the setting for mobile data must be activated on the iPhone.
- Bluetooth, WLAN, and Siri voice control are activated on the iPhone.
- WLAN is activated on the vehicle.

#### Pairing the iPhone with CarPlay

- 1. "COM"
- 2. "Mobile devices"
- 3. "New device"
- "Phone calls and audio"
   The vehicle's Bluetooth name is displayed on the Control Display.
- On the mobile device, search for Bluetooth devices in the vicinity and select the vehicle.
   A control number is displayed.
- Compare the control number displayed on the Control Display with the control number on the display of the mobile device, and confirm that the two match.
- 7. "Use Apple CarPlay"

The iPhone is connected to the vehicle and displayed in the device list.

## On the road

## **Driving**

#### **Drive readiness**

#### **Turning on drive readiness**



- 1. Depress the brake pedal.
- 2. Press the Start/Stop button.

#### **Turning off drive-ready state**

Steptronic transmission:

- 1. Engage selector lever position P with the vehicle stopped.
- Press the Start/Stop button. The engine is switched off.
- 3. Set the parking brake.

### **Auto Start/Stop function**

The Auto Start/Stop function switches the engine off automatically while stationary to save fuel. The engine starts automatically under the following preconditions:

Steptronic transmission:

- By releasing the brake pedal.
- ▶ When Automatic Hold is activated: step on the accelerator pedal.

### **Parking brake**

#### **Setting**

Pull the switch.

The LED on the switch and the indicator light in the instrument cluster are illuminated.

#### Releasing

With drive-ready state switched on:
Press the switch while stepping on the brake pedal or selector lever position P is set.

The LED and indicator light turn off.

The parking brake is released.

#### **Parking**

The parking brake is automatically set if the vehicle is being held by Automatic Hold and the drive-ready state is switched off or the vehicle is exited

### **Steptronic transmission**

## Engaging selector lever position D, N, R



- Gear position D.
- Neutral N.
- R is reverse.


With the driver's safety belt fastened, briefly push the selector lever in the desired direction, past a resistance point, if needed. The selector lever returns to the center position in each case.

To prevent the vehicle from creeping after you select a gear position or reverse, maintain pressure on the brake pedal until you are ready to start.

A selector lever lock prevents the inadvertent shifting to selector lever position R or the inadvertent shifting from selector lever position P.

Engage selector lever position R only when the vehicle is stationary.

#### Releasing the selector lever lock



Press the button.

### **Engaging P**

Engage selector lever position P only when the vehicle is stationary.



Press button P.

## Steptronic transmission, Sport program and manual mode



Activate the Sport program/manual mode:

Press the selector lever to the left from selector lever position D.

#### Manual mode:


- To shift down: press the selector lever forward.
- ➤ To shift up: pull the selector lever rearwards.

End the sport program/manual mode:

Press the selector lever to the right.

# Turn signal, high beams, headlight flasher

#### **Turn signal**



- ▶ Blinking: press the lever past the resistance point.
- ➤ Triple turn signal activation: lightly tap the lever up or down.
- ▶ Brief blinking: press the lever to the resistance point and hold it there for as long as you want the turn signal to blink.

#### High beams, headlight flasher



Press the lever forward or pull it backward.

- High beams on, arrow 1.
   The high beams light up when the low beams are switched on.
- ▶ High beams off/headlight flasher, arrow 2.

### **Lights and lighting**

### **Light functions**

Icon	Function
Sil	Night vision.
OFF	Lights off.  Daytime driving lights.
€D O€	Parking lights.
AUTO	Automatic headlight control.  Adaptive light functions.
<b></b> ■D	Low beams.
<del>ن</del> ې:	Instrument lighting.

### Icon Function



Right roadside parking light.



Left roadside parking light.

## Window wiper system

#### Turn on window wiper system



Press the lever up until the desired position is reached.

- ▶ Resting position of the wipers: position 0.
- ▶ Rain sensor: position 1.
- Normal wiper speed: position 2.
- ▶ Fast wiper speed: position 3.

## Turn off the window wiper system and flick wipe



Press the lever down.

- ➤ Turn off: press the lever down until it reaches the 0 position.
- ► Flick wipe: press the lever down from the 0 position.

#### Activate/deactivate rain sensor



Activate: press the lever up once from its 0 position, arrow 1.

Deactivate: press the lever back into the 0 position

#### Adjusting the rain sensor sensitivity



Turn the thumbwheel on the wiper lever.

#### Cleaning the windshield



Pull the lever.

#### Switching on the rear wiper



Turn the outer switch upward.

- ▶ Resting position of the wiper, position 0.
- ▶ Intermittent mode, arrow 1. When reverse gear is engaged, the system switches to continuous operation.

#### Clean the rear window

Turn the outer switch in the desired direction.

- In resting position: turn the switch downward, arrow 3. The switch automatically returns to its idle position when released.
- ▶ In intermittent mode: turn the switch further, arrow 2. The switch automatically returns to its interval position when released.

### **Climate control**

#### **Automatic climate control**

Button	Function
*	Temperature.
MAX A/C	Maximum cooling.
AUTO	AUTO program.
<b>(S)</b>	Air recirculation mode.
.‰ <b>▲</b>	Air flow, manual.
OFF ▼	Intensity AUTO program.
₩,	Air distribution, manual.
MAX VIII/	Defrost function.
REAR	Rear window defroster.
#1	Active seat ventilation.
#	Seat and armrest heating.
MENU A/C	Air conditioning.
	Opening the Climate menu.
	For example, for the following settings: upper body temperature adjustment, pre-ventilation.

## **Intermediate stop**

#### Refueling

#### **Fuel cap**

1. To open the fuel filler flap, press on the rear edge, arrow. The fuel filler flap opens.



- 2. Turn the fuel cap counterclockwise.
- 3. Place the fuel cap in the bracket attached to the fuel filler flap.

#### Gasoline

For the best fuel efficiency, the gasoline should be sulfur-free or very low in sulfur content.

Fuels that are marked on the gas pump as containing metal must not be used.

#### Wheels and tires

#### Tire pressure specifications

The tire inflation pressure specifications can be found in the tire inflation pressure table in the printed Owner's Manual.

#### After correcting the tire pressure

With runflat tires:

Reinitialize the Flat Tire Monitor.

With Tire Pressure Monitor:

The corrected tire inflation pressures are applied automatically. Make sure that the correct tire settings have been made.

With tires that cannot be found in the tire pressure values on the Control Display, reset the Tire Pressure Monitor TPM.

#### Checking the tire pressure

Regularly check the tire inflation pressure and correct it as needed:

- At least twice a month.
- ▶ Before embarking on an extended trip.

#### Cleaning the wheels

The friction during hard braking may produce brake dust and make the rims dirty. Brake dust can be removed by cleaning the rims. BMW recommends using vehicle care and cleaning products from BMW.

#### **Electronic oil measurement**

#### **Functional requirements**

A current measured value is available after approx. 30 minutes of normal driving.

### Displaying the engine oil level

- 1. "CAR"
- 2. "Vehicle status"
- 3. "Engine oil level"

Different messages appear on the Control Display depending on the engine oil level. Pay attention to these messages.

## Adding engine oil

#### **General information**

Safely park the vehicle and switch off drive-ready state before adding engine oil.

#### Adding engine oil



Only add engine oil when the message is displayed in the instrument cluster.

Observe the quantity to be added in the message.

Take care not to add too much engine oil. Observe recommended engine oil types.

## **Providing assistance**

### **Hazard warning flashers**



The button is located in the center console.

#### **Breakdown Assistance**

#### **BMW Roadside Assistance**

- 1. "APPS"
- 2. "Installed apps"
- "BMW Assist"
- If necessary, "BMW Roadside Assistance" A voice connection is established.

#### **ConnectedDrive**

#### Concierge service

The BMW Assist Concierge service offers information on events, filling stations or hotels, and provides phone numbers and addresses. Many hotels can be booked directly by the BMW Concierge service. The Concierge service is part of the optional BMW Assist Response Center.

- 1. "COM"
- 2. "BMW Assist"
- 3. If necessary, select the entry for the Concierge Service.

A voice connection to the Concierge service is established.

#### **Teleservices**

Teleservices are services that help to maintain vehicle mobility.

Teleservices can comprise the following services:

- ▶ BMW Roadside Assistance.
- BMW Accident Assistance.
- ▶ Teleservice Call.
- Teleservice Report.
- ▶ Teleservice Battery Guard.
- Your dealer's service center.


## **Dashboard**

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are

not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## In the vicinity of the steering wheel



Window safety switch 113

Unle

Unlocking

<sup>2</sup>

Power windows 112



Locking

- 3 Exterior mirror adjustment button 128
- 4 Central locking system 98

**5** Seating comfort features



Front passenger seat functionality 120



Memory function 130



Massage function 131



Opening and closing the tailgate 103

7 Steering column stalk, left



Turn signal 149



High beams, headlight flasher 150



Automatic High Beam Assistant 182



Widgets 161 Trip data 175

- 8 Shift paddle
- 9 Steering wheel buttons, left



Manual Speed Limiter 230



Depending on the equipment: Cruise control on/off 232



Depending on the equipment: Active Cruise Control on/off 234



With steering and traffic jam assistant 244:



MODE

Cruise control, distance control and lane guidance on/off



Cruise control: to store the speed Speed Limit Assistant: accept suggested speed 242



Pause or continue cruise control



Active Cruise Control: increase distance



Active Cruise Control: reduce distance

Cruise control rocker switch

- **10** Instrument cluster 159
- 11 Steering wheel buttons, right



Selection lists 174



Volume, see Owner's Manual for Navigation, Entertainment and Communication 6



Voice control 52



Telephone, see Owner's Manual for Navigation, Entertainment and Communication 6

Thumbwheel for selection lists 174

12 Steering column stalk, right



Wipers 150



Rain sensor 151



Cleaning the windshield 151



Rear wiper in Canadian models 152



Rear wiper 152



Clean the rear window 152



Horn, entire surface



Steering wheel heating 130



Adjusting the steering wheel 130

**16** Glove compartment 317

17 Lights



Night Vision 203



Light switch 179



Lights off





Parking lights 180



Automatic headlight control 179

Adaptive light functions 182 Automatic High Beam Assis-

tant 182



Low beams 180



Instrument lighting 184



Right roadside parking light 180




Left roadside parking light 180



Unlocking the hood 382

## In the vicinity of the center console



1 Control Display 47



Hazard warning system 398



Intelligent Safety 191

- 3 Ventilation 292
- 4 Glove compartment 316
- 5 Automatic climate control 287
- 6 Radio/multimedia, see Owner's Manual for Navigation, Entertainment, and Communication 6
- 7 Controller with buttons 48



Two-axle ride level control 280



xOffroad driving mode 283



HDC Hill Descent Control 227



Parking brake 146



Automatic Hold 147

10 SPORT

Driving Dynamics Control 144

SPORT driving mode



COMFORT driving mode



ECO PRO driving mode



ADAPTIVE driving mode

11 START ENGINE STOP

Turning drive readiness state on/ off 141



Auto Start/Stop function 141



Parking assistance systems 253



Panorama View 274



DSC Dynamic Stability Control 223

**13** Steptronic transmission selector lever 153

## In the vicinity of the headliner



1 808

Emergency Call, SOS 400

4 🔍

Reading lights 185

2 \_\_\_\_

Glass sunroof 114

₩ ₩ Interior lights 184

PASSENGER AIR BAG OFF ON

Indicator light, front passenger airbag 190

## Sensors of the vehicle

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## **Overview**


Depending on the equipment, the following cameras and sensors are installed in the vehicle:

- ▶ Front camera.
- Cameras behind the windshield.
- ▶ Top view cameras.
- Rearview camera.
- Infrared camera.
- ▶ Front radar sensor.
- ▶ Radar sensors, side, front.
- ▶ Radar sensors, side, rear.
- ▶ Ultrasound sensors in the front/rear bumpers.
- ▶ Ultrasonic sensors, side.

Keep the vehicle cameras and sensors, as well as surrounding areas, clean and unobstructed.


## **Cameras**

#### Front camera



Front camera

#### Cameras behind the windshield




The cameras are located in the area of the interior mirror.

## **Top view cameras**




One camera is located at the bottom of each exterior mirror housing.

#### Rearview camera



The camera is located in the handle of the tailgate.

## Infrared camera



The infrared camera of the Night Vision is located in the radiator grille.

## System limits of the cameras


The cameras may not be fully functional and may provide incorrect information in the following situations:

- ▶ In heavy fog, wet conditions, or snowfall.
- On steep hills, in steep depressions or in tight curves.
- ▶ When the camera field of view is covered, for instance by a fogged up windshield or labels.
- ▶ If the camera lens is dirty or damaged.
- ▶ With exterior mirrors folded in.
- ▶ When driving toward bright lights or strong reflections, e.g., because of a setting sun.
- When it is dark outside. Does not apply to the infrared camera of the Night Vision.
- ▶ Infrared camera of the Night Vision: at very high outside temperatures.
- ➤ Camera behind the windshield: if the camera has overheated and been temporarily switched off due to excessively high temperatures.
- Camera behind the windshield: during calibration of the camera immediately after vehicle delivery.

If applicable, a Check Control message will be displayed when the system limits are reached.

## **Radar sensors**

## Front radar sensor




The radar sensor is located in the front bumper.

## Radar sensors, side, front



The radar sensors are located in the bumper.

## Radar sensors, side, rear



The radar sensors are located in the bumper.

## System limits of the radar sensors

The radar sensors may not be fully functional or may not be available in the following situations:

- ▶ If sensors are dirty, such as due to icing.
- ▶ If sensors are covered, such as by labels, films or a number plate baseplate.
- ▶ If the sensor is not aligned correctly, for instance due to parking damage.
- ▶ If the radiation range of the sensors is covered, e.g., by protruding cargo.
- When the field of view of the sensors is covered, e.g., by garage walls, hedges, snow hills, vehicles or trailers.
- ▶ After improper paint work on the vehicle in the area of the sensors.
- ▶ On steep hilltops or in sharp dips in the road.

If applicable, a Check Control message will be displayed when the system limits are reached.


## **Ultrasound sensors**

## Ultrasound sensors in the front/ rear bumpers



The ultrasound sensors of the Park Distance Control PDC are located in the bumpers.

## Ultrasonic sensors, side



The ultrasound sensors of the Automatic Parking Assistant are located on the side of the vehicle.

## System limits of the ultrasonic sensors

The detection of objects with ultrasonic measurements can run into physical limits, e.g., in the following situations:

- ▶ In case of dirty sensors.
- In case of covered sensors, such as due to labels.
- ▶ If the sensor is not aligned correctly, for instance due to parking damage.
- ▶ After improper paint work on the vehicle in the area of the sensors.
- ▶ For small children and animals.

- ▶ For persons with certain clothing, for instance jacket.
- In case of external interference of the ultrasound, for instance from passing vehicles, loud machines or other ultrasonic sources.
- Under certain weather conditions, e.g., high relative atmospheric humidity, wet conditions, snowfall, cold, extreme heat, or strong wind.
- With tow bars and trailer couplings of other vehicles.
- ▶ With thin or wedge-shaped objects.
- ▶ With moving objects.
- With elevated, protruding objects such as ledges.
- With objects with corners, edges, and smooth surfaces.
- With objects with a fine surface structure such as fences.
- ▶ For objects with porous surfaces.
- With small and low objects, for instance boxes.
- With soft obstacles or obstacles covered in foam material.
- With plants and bushes.
- In automatic car washes.
- On uneven surfaces, such as speed bumps.
- Due to heavy exhaust.
- Cargo that extends beyond the perimeter of the vehicle is not taken into account by the ultrasonic sensors.
- When the trailer hitch cover is not on straight.

If applicable, a Check Control message will be displayed when the system limits are reached.

## Operating state of the vehicle

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## **General information**

Depending on the situation, the vehicle is in one of the three states:

- Idle state.
- Standby state.
- Drive-ready state.

## Idle state

## **Principle**

When the vehicle is in idle state, it is switched off.

### **General information**

The vehicle is in idle state prior to opening from the outside and after exiting and locking.

## **Safety information**

#### Marning

An unsecured vehicle can begin to move and possibly roll away. There is a risk of accident. Before exiting, secure the vehicle against roll-

In order to ensure that the vehicle is secured. against rolling away, follow the following:

- Set the parking brake.
- > On uphill grades or on a downhill slope, turn the front wheels in the direction of the curb.
- ▷ On uphill grades or on a downhill slope, also secure the vehicle, for instance with a wheel chock.

#### Marning

Unattended children or animals in the vehicle can cause the vehicle to move and endanger themselves and traffic, for instance due to the following actions:

- ▶ Pressing the Start/Stop button.
- > Releasing the parking brake.
- > Opening and closing the doors or windows.
- ▶ Engaging selector lever position N.
- > Using vehicle equipment.

There is a risk of accidents or injuries. Do not leave children or animals unattended in the vehicle. Take the vehicle key with you when exiting and lock the vehicle.

## Automatic idle state

For instance, the idle state is automatically established under the following conditions:

- After several minutes, if no operation takes place on the vehicle.
- ▶ If the charge state of the vehicle battery is
- Depending on the setting via iDrive: when one or both front doors are opened after driving when exiting the vehicle.

In some situations, the idle state is not set automatically, for instance during a phone call or when the low beams are switched on.

## **Establishing idle state when** opening the front doors

After a trip, the sleep mode can be established by opening the front doors. For this purpose, the driver and front passenger must exit the vehicle.

- 1. "CAR"
- "Settings"
- 3. "Doors/ vehicle access"
- 4. "Turn off vehicle after opening door"

### Manual idle state

To establish idle state in the vehicle after completion of trip:



Press and hold the button on the radio until the OFF indicator on the instrument cluster goes out.

## Standby state

## **Principle**

When standby state is switched on, most functions can be used while the vehicle is stationary. Desired settings can be adjusted.

## **General information**

The vehicle is in the standby state after the front doors are opened from the outside.

## Display in the instrument cluster



OFF is displayed in the instrument cluster. The drivetrain is switched off and standby state switched on.

## **Drive readiness**

## **Principle**

Turning on drive-ready state corresponds to starting the engine.

### **General information**

Some functions, such as DSC Dynamic Stability Control, can only be used with drive-ready state switched on.

## **Safety information**



#### ⚠ DANGER

If the exhaust pipe is blocked or ventilation is insufficient, harmful exhaust gases can enter into the vehicle. The exhaust gases contain pollutants which are colorless and odorless. In enclosed areas, exhaust gases can also accumulate outside of the vehicle. There is danger to life. Keep the exhaust pipe free and ensure sufficient ventilation.



#### Marning

An unsecured vehicle can begin to move and possibly roll away. There is a risk of accident. Before exiting, secure the vehicle against roll-

In order to ensure that the vehicle is secured against rolling away, follow the following:

- Set the parking brake.
- On uphill grades or on a downhill slope, turn the front wheels in the direction of the curb.
- On uphill grades or on a downhill slope, also secure the vehicle, for instance with a wheel chock.

#### ▲ NOTICE

Repeated attempts to start the vehicle or repeated starting of the vehicle in rapid succession can cause the starter to overheat. This also results in unburned or inadequately burned fuel, and can cause the catalytic converter to overheat. There is a risk of damage to property, among other potential damage. Avoid repeated starting of the vehicle, particularly repeated starting in rapid succession.

## **Turning on drive readiness**

## **Principle**



Drive-ready state is switched on via the Start/Stop button.

## **Steptronic transmission**

- 1. Depress the brake pedal.
- 2. Press the Start/Stop button.

The ignition is activated automatically for a brief time and is stopped as soon as the engine starts.

Most of the indicator/warning lights in the instrument cluster light up for a varied length of time.

## **Gasoline engine**

Depending on the motorization, the full drive power may not be available for approximately 30 seconds after starting the engine. In this case, the vehicle will not accelerate as usual. Additional information:

Power gauge, refer to page 169.

## Display in the instrument cluster

The activated drive readiness is indicated in the instrument cluster, depending on the equipment, by the display of information required for driving or the READY display.

## **Turning off drive-ready state**

## Steptronic transmission

- 1. Engage selector lever position P with the vehicle stopped.
- Press the Start/Stop button.The engine is switched off. The vehicle switches into standby state.
- 3. Set the parking brake.

## **iDrive**

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## **Operating concept**

## **Principle**

iDrive is the operating concept of the infotainment system and includes a large number of functions.

#### **General information**

These functions can be operated as follows:

- ▶ Via the Controller.
- ▶ Via the touchscreen.
- ▶ Via the BMW Intelligent Personal Assistant.
- Depending on the equipment: with the gesture control.

## **Safety information**

## ⚠ Warning

Operating the integrated information systems and communication devices while driving can distract from traffic. It is possible to lose control of the vehicle. There is a risk of accident. Only use the systems or devices when the traffic situation allows. As warranted, stop and use the


systems and devices while the vehicle is stationary.

## Input and display

#### Main menu

#### General information

The main menu is divided into two areas. The left area contains menu items that can be used to call up all the iDrive functions. The right area contains widgets that provide quick access to certain functions.



#### Media/Radio

☐ All functions of the entertainment system, e.g., radio stations or connection with external devices.

#### Communication

A Phone and message functions, e-mail and calendar, and also the connection and management of mobile devices, such as smartphones.

### Navigation

Access to the navigation system, destination input and traffic bulletins. Configurable map views and other functions, such as points of interest and areas to be avoided.

#### My Car

Information about vehicle status and trips.

Access to the Integrated Owner's Manual and also administration of driver profiles and range of adjustments for vehicle and iDrive.

#### **Apps**

Management of apps, access to apps and vehicle functions. Additional apps and vehicle functions can be purchased from the BMW Store.

#### Widgets

Widgets provide quick access to frequently used functions. The configured widgets display dynamic contents such as the navigation map, and serve as interfaces at the same time.

#### **Letters and numbers**

Letters and numbers can be selected when making the destination input, for example.

Letters and numbers can be entered using the Controller, the touchpad, touchscreen or voice control. The keyboard's display changes automatically.

Icon	Function
abc ABC	Change between capital and lower-case letters.
ш	Enter a blank space.
EN	Switching between languages.
<u></u>	Use voice control.
OK	Confirm entry.
← →	Slide the input area to the left or right.

## **Entry comparison**

When entering names and addresses, the choice is narrowed down with every letter and number and added automatically as needed.

Entries are continuously compared with data stored in the vehicle.

- Only those letters and numbers are offered during entry for which data is available.
- Destination search: place names can be entered in all languages that are available in iDrive.

## Activating/deactivating the functions

Several menu items are preceded by a checkbox. The checkbox indicates whether the function is activated or deactivated. Selecting the menu item activates or deactivates the function.

- Function is activated.
- Function is deactivated.

#### Status information

#### General information

The status field can be found in the upper area of the Control Display. Status information is displayed in the form of symbols.

#### Radio symbols

Icon	Meaning	
н)	HD Radio station is being received.	
sxm	Satellite radio is switched on.	

#### Telephone symbols

Icon	Meaning
Pa	Incoming or outgoing call.
Z	Missed call.
att	Signal strength of mobile phone network.
	Network search.
ail	Mobile phone network is not available.
.îı	The critical charge state of the mobile phone has been reached.

Icon	Meaning
Rull	Roaming is active.
3al	Locating is active.
$\Box$	SMS text message received.
$\boxtimes$	Message received.
Ţ	Reminder.
<b>%</b>	Sending not possible.

#### **Entertainment symbols**

Icon	Meaning
<b>₽</b> n	Bluetooth audio.
ψ	USB device.
<b>6</b>	Connected Music.
Ēu	WLAN.
<b>€</b>	Apple CarPlay.
⚠	Android Auto.

#### Other symbols

Icon	Meaning
$\triangle$	Check Control message.
А	Sound output active.
IJ.	Sound output deactivated.
₫	Voice activation system active.
8	Request for the current vehicle position.
	Checking the current vehicle position.
	Driver profile.
1	Notifications.
	Service notifications.
i	Information.

Icon	Meaning
STOP	Stop.
€0	Data protection.
<b>FEB</b>	Destination guidance active.
11	Passengers on board.
O,	Do not disturb.

## **Programmable memory buttons**

#### **General information**

The iDrive functions can be stored on the programmable memory buttons and called up directly, for instance radio stations, navigation destinations, phone numbers and menu entries.

### **Overview**



1... 8 Programmable memory buttons

## Storing a function

A function can be stored on a programmable memory button. A button with a stored function can be overwritten with another function.

- 1. Select function via iDrive, for instance radio station.
- 2. Press and hold the desired button until the displayed bar on the Control Display has loaded completely.

#### **Executing a function**



Press the button.

The function will work immediately. This means. for instance that the number is dialed when a phone number is selected.

#### Displaying the key assignment

Touch buttons with finger. Do not wear gloves or use objects.

The assignment of the buttons is displayed in the upper area of the Control Display.

## **Deleting all button assignments**

All button assignments can be deleted.

- 1. Press and hold buttons 1 and 8 at the same. time.
- 2 "OK"

## **Control Display and** Controller

## **Principle**

The iDrive functions are displayed on the Control Display. The Control Display can be operated using the Controller, touchpad, and touchscreen.

## Overview



- 1 Control Display with touchscreen
- 2 Controller with buttons and touchpad

## **Control Display**

## **Safety information**



#### ∧ NOTICE

Objects in the area in the front of the Control Display can shift and damage the Control Display. There is a risk of damage to property. among other potential damage. Do not place objects in the area in front of the Control Display.

## Switching on/off automatically

The Control Display is turned on automatically when the vehicle is unlocked or as soon as the control display is needed for operation.

In certain situations, the Control Display is switched off automatically, for instance if no operation is performed on the vehicle for several minutes.

## Switching on/off manually

The Control Display can also be switched off manually.

- 1. Tip the Controller up.
- 2. "Screen off"

Press the Controller or any button on the Controller to switch it back on again.

## **System limits**

In the case of very high temperatures on the Control Display, for instance due to intense solar radiation, the brightness may be reduced down to complete deactivation. Once the temperature is reduced, for instance through shade or air conditioning, the normal functions are restored.

#### Controller

#### **General information**

The buttons can be used to open the menus directly. The Controller can be used to select menu items and enter the settings.


Some iDrive functions can be operated using the touchpad on the Controller.

### **Operation**

➤ Turn to switch between menu items, for example.



▶ Press to select a menu item, for example.



➤ Tilt in four directions to switch between displays, for example.




#### **Buttons on the Controller**

Button	Function
HOME	Go to the main menu.
	Go to Apps menu.
MEDIA	Go to the Media/Radio menu.
СОМ	Go to the Communication menu.
МАР	Go to navigation map.
NAV	Go to destination input menu for navigation.
BACK	Go to the previous display.
OPTION	Go to the Options menu.

# Operating via the Controller

## Opening the main menu

Press the button.



The main menu is displayed.

## Selecting a menu

## **Selecting menu items**

- Turn the Controller until the desired menu item is highlighted.
- 2. Press the Controller.

## Select a widget

- 1. Move the Controller in the main menu to the right.
- 2. Turn the Controller until the desired widget is selected.
- 3. Press the Controller.

It is also possible to select widgets in the instrument cluster.

## Adjusting the menu

## **Adjusting widgets**

The widgets can be adjusted in the main menu. It is possible to create multiple pages with widgets and switch between pages. The adjustments can only be performed when the vehicle is stationary.

- Select the desired page in the main menu.
   Only the currently selected page can be adjusted.
- 2. Tip the Controller up.
- 3. "Adjust main menu"
- 4. Select the desired adjustment:
  - Symbol and select desired widget: add new widget.

The requested widget will be inserted in the relevant position. A maximum of four widgets can be displayed per page.

- Select icon: delete selected widget.
- Add new page: "Add page".
- Delete selected page: "Delete page".
- Adjust the content of the widget: select widget.
- 5. "Done"

## **Adjusting contents**

Depending on the equipment, the contents of menus "MEDIA", "COM" and "NAV" can be adjusted, for instance to remove the entries of functions that are not used from the menu.

- 1. Select the menu.
- 2. "Personalize menu"
- 3. Select the desired setting.

## **Changing between displays**

After a menu item is selected, for instance "Settings", a new display appears.

- ➤ Tilt the Controller to the left. The current display closes and the previous display is shown.
- Press the hutton

The previous display re-opens.

➤ Tilt the Controller to the right.
The new display opens.

An arrow indicates that additional displays can be opened.

## Going to the Options menu



Press the button.

The "Options" menu is displayed.

The menu consists of various areas, for instance:

- "MEDIA": control options for the selected main menu.
- ▶ "Help": help for the selected menu.
- "Control display off": system settings.

## **Entering letters and numbers**

#### Input

- 1. Turn the Controller: select letter or number.
- 2. **OK**: confirm entry.

#### **Deleting**

icon	Function
l←	Press the Controller: delete letter or number.
l←	Hold the Controller down: delete all letters or numbers.

## **Using alphabetical lists**

For alphabetical lists with more than 30 entries, the letters for which an entry exists can be displayed in a text box.

- 1. Turn the Controller to the left or right quickly.
- Select the first letter of the desired entry. The first entry of the selected letter is displayed in the list.

## Operation via touchpad

## **General information**

Some iDrive functions can be operated using the touchpad on the Controller.

## **Selecting functions**

- 1. "CAR"
- 2. "Settinas"
- 3. "General settings"
- 4. "Touchpad"
- 5. Select the desired setting.

## **Entering letters and numbers**

- Enter characters as they are displayed on the Control Display.
- Always enter associated characters, such as accents or periods so that the letter can be clearly recognized.
- The set language determines what input is possible. Where necessary, enter special characters via the Controller.

## **Entering special characters**

Input	Operation
Delete a character.	Swipe to the left on the touchpad.
Enter a blank space.	Swipe to the right in the center of the touchpad.
Enter a hyphen.	Swipe to the right in the upper area of the touchpad.
Enter an under- score.	Swipe to the right in the lower area of the touchpad.

## Using the map

The map in the navigation system can be moved via the touchpad.

Function	Operation
Move map.	Swipe in the appropriate direction.
Enlarge/shrink map.	Drag in or out on the touch- pad with fingers.
Display menu.	Tap once.

## **Using alphabetical lists**

Alphabetical lists with more than 30 entries permit a direct jump to letters for which an entry exists.

Enter the first letter on the touchpad.

The first entry of the entered letter is displayed in the list.

## Operation via touchscreen


## **General information**

The Control Display is equipped with a touchscreen.

You can tap on menu items and widgets. Touch the touchscreen with your fingers. Do not use any objects.

## **Opening the main menu**

Tap on the icon.



The main menu is displayed.

## **Adjusting widgets**

The widgets can be adjusted in the main menu. It is possible to create multiple pages with widgets and switch between pages. The adjustments can only be performed when the vehicle is stationary.

- Select the desired page in the main menu.
   Only the currently selected page can be adiusted.
- 2. Tap the icon in the main menu.
- 3. Select the desired adjustment:
  - → Tap icon and select desired widget: add new widget.

The requested widget will be inserted in the relevant position. A maximum of four widgets can be displayed per page.

- X Tap icon: delete selected widget.
- ▶ Add new page: tap "Add page".
- Delete selected page: tap "Delete page".
- Adjust content of the widget: tap center of widget.
- 4. Tap "Done".

## Showing/hiding the display bar

In the upper area of the Control Display, it is possible to show or hide a display bar with additional functions.

- ➤ To show the display bar, pull down the display bar at the top edge of the screen.
- ➤ To hide the display bar, pull up the display bar at the top edge of the screen.

## **Changing between displays**

After a menu item is selected, a new display opens.

An arrow indicates that additional displays can be opened.

- Swipe to the left.
- ▶ Tap arrow.

The new display opens.

## **Entering letters and numbers**

#### Input

- 1. When approaching the touchscreen, a keyboard appears on the Control Display.
- 2. Enter desired letters and numbers.

## Deleting

Icon Function

<b> ←</b>	Tapping the icon: deletes the letter or number.
14	Tanning and holding the icon all letters:

Tapping and holding the icon all letters: deletes all letters or numbers.

## Using the map

The navigation map can be moved using the touchscreen.

Function	Operation
Move map.	Swipe in the appropriate direction.
Enlarge/shrink map.	Drag in or out with the fingers.
Display menu.	Tap once.

## **Using alphabetical lists**

For alphabetical lists with more than 30 entries, the letters for which an entry exists can be displayed in a text box.

- Tap the letter in front of the list.
   A letter box is displayed.
- 2. Tap the first letter of the desired entry.

# BMW Intelligent Personal Assistant

## **Principle**

The BMW Intelligent Personal Assistant is a personal assistant that enables natural voice operation of various vehicle functions. The Personal Assistant simplifies the operation of the vehicle with the automation of processes and habits.

#### **General information**

- BMW Intelligent Personal Assistant is available depending on the national-market version.
- ▶ The system includes special microphones on the driver side and the front passenger side.
- Say commands at a normal volume. Speaking directly into the microphone does not improve the speech recognition.
- Say the commands and numbers fluently as well as with normal volume, emphasis, and speed.
- >.... identifies commands that can be spoken.

## **Functional requirements**

- ▶ A language that is supported by the Personal Assistant must be set via iDrive.
  - Setting the system language, refer to page 64.
- Always say commands in the configured system language.

Enter the following settings to access the full range of functions:

- ▶ "Online speech processing" is activated.
- All settings under "BMW ConnectedDrive" activated.
- Activation word is activated.
- ▶ The Driver profile is activated.
- "Synchronize driver profile" under "Personalization" is activated.
- ▶ Relevant ConnectedDrive Services purchased from the ConnectedDrive Store.

# Activating the voice control system

#### **General information**

There are various methods for activating the voice control feature:

Press the button on the steering wheel.

The microphone on the driver's side is active.

Say the wake word >Hello BMW or a personal wake word.

The microphones on the driver's or front passenger's side are active with the following voice control, depending on where the activation word was spoken.

Then say the command. The activation word and the command can be spoken without pause in one sentence. No other commands may be available. In this case, operate the function via iDrive.

## **Button on the steering wheel**

- 1. Press the button on the steering wheel briefly.
- 2. Say the command.

#### Wake word

#### General information

Speaking the wake word >Hello BMW or the personal wake word will start the system.

#### Preset wake word

The preset wake word >Hello BMW can be activated and deactivated.

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. If necessary, "Personal assistant"
- 5. "Voice control"
- 6. "Wake word"
- 7. "Wake word"

#### Personal wake word

In addition to a preset activation word >Hello BMW+, a personal activation word can be set up in the active driver profile. The personal activation word can also be changed or deleted.

The activation word should consist of multiple syllables to ensure good recognition. An addition, such as 'Hello' is not necessary.

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. If necessary, "Personal assistant"
- 5. "Voice control"
- 6 "Wake word"
- 7. "Personal wake word"
- 8. "Set wake word"
- 9. Select the desired setting.

## Activation word from third-party providers

Depending on the national-market version, some third-party providers provide digital voice assistants, e.g., Siri, Amazon Alexa or Google Assistant. Supported voice assistants can be used with a connected smartphone in the vehicle. In addition to the preset or personal activation word, the activation word from connected third-party providers can be used.

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. If necessary, "Personal assistant"
- 5. "Voice control"
- 6. "Third-party providers"
- 7. Select the desired setting.

## **Ending voice control**

- Press the button on the steering wheel again.
- ▶ →Cancel
- ▶ Tilt the Controller to the right or left.
- Press the Controller.

## Possible commands

#### **General information**

Most contents on the Control Display can be spoken as commands, e.g. menu items or list entries. Say list entries as shown.

Instructions can be issued or questions can be asked where the Personal Assistant provides support.

## **Function examples**

#### Vehicle status and vehicle information

- > Is my tire pressure still OK?
- ▶ Show me the sport displays.
- ▶ →Open Owner's Manual.

#### **Navigation**

- ▶ Drive me to 300 Chestnut Ridge Road, Woodcliff Lake in New Jersey.
- > Take me home.«
- > Are there any traffic messages?

#### Communication

For example, when a mobile phone is connected, calls can be started or SMS can be sent.

- > Call John Doe on cell phone.
- ▶ Dial the number 18008311117.4
- New text message to John Doe: I'll be right there.

#### **Entertainment**

- ▶ →What song is this?
- ▶ →Play Blue Suede Shoes by Elvis Presley
- ▶ Next title.

#### Climate control

- > Turn off the air conditioning.
- ▶ Activate fresh air.

#### Windows and light

- > Open the windows automatically.
- ▶ Delete activation point for automatic power window.
- ▶ Ambient lighting.

### Owner's Manual via voice operation

You can ask simple questions about vehicle functions and the operation of the vehicle.

The voice control system and the feedback it provides does not replace the printed or Integrated Owner's Manual. The speech recognition and quality of the feedback may vary.

>How can the passenger airbag be deactivated

The Personal Assistant returns feedback. When stationary, the section of the integrated Owner's Manual is displayed on the Control Display.

#### Menu items

The commands of the menu items are spoken just as they are selected via the Controller.

- 1. Activating the voice control system.
- 2. →MEDIA«
- 3. Presets

The stored stations are displayed on the Control Display.

#### Help for voice control

- Voice commands: to have the available spoken commands announced.
- General information on voice controls have information on the operating principle of the voice control announced.
- → Helps: have help for the current menu read out loud.

## **Settings**

#### **Setting the voice control**

You can set the system to use standard dialog or a short version.

The short version of the voice control plays back short messages in abbreviated form.

- 1. "CAR"
- 2. "Settings"
- "General settings"
- 4. If necessary, "Personal assistant"
- "Voice control"
- "Response length"
- 7. Select the desired setting.

## Speaking during voice output

It is possible to answer during inquiries of the voice activation system. The function can be deactivated if inquiries are often undesirably inter-

rupted, for instance due to background noise or conversations in the vehicle.

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. If necessary, "Personal assistant"
- 5. "Voice control"
- 6. "Speaking during voice output"

## Online speech processing

Online voice processing improves the quality of the speech recognition and search results for points of interest. To use the functions, data is transmitted to a service provider via an encrypted connection and stored locally there.

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. If necessary, "Personal assistant"
- 5. "Voice control"
- 6. "Online speech processing"

## Adjusting the volume

Turn the volume button during the voice guidance until the desired volume is set.

The volume remains constant even if the volume of other audio sources is changed.

# Using the voice activation of the smartphone

Depending on the device, a smartphone connected to the vehicle can be used via voice control.

The device must be connected via Apple Car-Play or Android Auto.

 Press and hold the button on the steering wheel for approx. 3 seconds. The voice activation of the smartphone is activated.

2. Release the button.

If activation is successful, a confirmation appears on the Control Display.

## **Automating routines**

#### **General information**

The Personal Assistant can automate routines, for instance the automatic activation of the seat heating from a specific outside temperature. Rules are created for this purpose, which can be activated and deactivated at any time.

#### Activate/deactivate

- 1. "APPS"
- 2. "Installed apps"
- 3. "Personal assistant"
- 4. "Automate habits"
- 5. Select the desired setting.

## **Experience Modes**

## **Principle**

The Experience Modes combine different vehicle functions in the car's interior to an overall experience.

#### **General information**

For example, the selection of a mode harmonizes the ambient light and seat climate control.

## **Functional requirements**

- ➤ The Experience Modes app is installed in the vehicle.
- Drive-ready state is switched on.

#### Activate/deactivate

- 1. "CAR"
- 2. "Experience Modes"
- Select the desired mode.The mode can be deactivated: "End"

## Adjusting the mode

- 1. "CAR"
- 2. "Experience Modes"
- 3. Select the desired mode.
- 4. "Settings"
- 5. Select the desired setting.

## **Caring Car**

## **Principle**

Different vehicle functions in the car's interior are harmonized for the driver in a short-term program.

## **General information**

By selecting a program, the interior lighting, climate control and music selection will be adjusted. A program takes 3 minutes.

#### Activate/deactivate

- 1. "CAR"
- 2. "Caring Car"
- 3. Select the desired program.

The program can be stopped prematurely:

"End program"

## Adjusting a program

- 1. "CAR"
- 2. "Caring Car"
- 3. Select the desired program.
- 4. "Music settings"
- 5. Select the desired setting.

## System limits

- The Personal Assistant provides information about vehicle functions that may not be installed in the vehicle.
  - This also applies to safety-related functions and systems.
- Certain noises can be detected and may lead to problems. Keep the doors, windows, and glass sunroof closed.
- Noises from the front passenger or the occupants can impair the system. Avoid making other noise in the vehicle while speaking.
- ▶ Major language dialects can cause problems with the speech recognition feature.
- A poor data connection influences the response time of the Personal Assistant and the Search.

## **BMW Gesture Control**

## **Principle**

Several iDrive functions can be operated by hand motion using BMW Gesture Control.

## **Overview**



The camera in the headliner detects gestures that are carried out in the area of the center console at the height of the Control Display.

## Activate/deactivate

- 1. "CAR"
- 2. "Settings"

- 3. "General settings"
- 4. "Gesture control"
- 5. "Gesture control"

## **Settings**

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Gesture control"
- 5. Select the desired setting.

## **Carrying out gestures**

- ▶ Perform gestures underneath the interior mirror and next to the steering wheel.
- ▶ Execute gestures clearly.
- ➤ The gestures can also be executed from the front-passenger side.

## Possible gestures

Gesture	Operation	Function
	Move index finger forward and backward in the direction of the screen.	Accept call. Select a highlighted entry in a list during voice control. Confirm pop-up.
<b>1</b> → M	Move hand across the width of the Control Display in the direction of the front-passenger side.	Reject call. Close pop-up. End voice control.
Col	Slowly move hand clockwise in a circular pattern with the index finger stretched out forward.  Gesture is detected after one circular motion.	Increase the volume.
TO J	Slowly move forearm counterclockwise in a circular pattern with the index finger stretched out forward.  Gesture is detected after one circular motion.	Reduce the volume.
	Pinch with thumb and index finger and move hand horizontally to the right or left.	Surround View: turn camera view.  This gesture can only be executed while the vehicle is stationary.

Gesture	Operation	Function
	Move stretched out index and middle finger forward.	Individually assignable gesture.
	Move fist with thumb extended to the left back and forth.	Reverse Skip function. The previous title is played.
<b>***</b>	Move fist with thumb extended to right left back and forth.	Forward Skip function. The next title is played.
	Stretch out five fingers, form a fist and stretch five fingers out again.	Individually assignable gesture.

## **Assigning gesture individually**

#### **General information**

Two gestures can be assigned individually and can be configured for certain functions, such as:

- Destination guidance to home address.
- ▶ Mute/Playback
- ▶ Control Display on/off

#### **Select function**

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Gesture control"
- 5. "Function assignment gesture 1" or "Function assignment gesture 2"
- 6. Select the desired setting.

## **System limits**

Gesture recognition by the camera in the headliner can be disturbed by the following circumstances:

- The camera lens is covered.
- Dijects are located on the interior mirror.
- ➤ The camera lens is dirty, clean camera lens. Sensors and camera lenses, refer to page 409.
- ➤ The gesture is executed outside of the detection range.
- Wearing of gloves or jewelry.
- Smoking in the car's interior.

## **BMW Remote Software Upgrade**

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## **BMW Remote Software Upgrade**

## **Principle**

Remote Software Upgrade can be used to update the entire software of the vehicle. This makes new functions, functional enhancements or quality improvements available.

## **General information**

BMW recommends performing the Remote Software Upgrade as soon as it becomes available.

## **Safety information**

#### Warning

Unattended children or animals in the vehicle can cause the vehicle to move and endanger themselves and traffic, for instance due to the following actions:

- ▶ Pressing the Start/Stop button.
- > Releasing the parking brake.

- > Opening and closing the doors or windows.
- ▶ Engaging selector lever position N.
- ▶ Using vehicle equipment.

There is a risk of accidents or injuries. Do not leave children or animals unattended in the vehicle. Take the vehicle kev with you when exiting and lock the vehicle.

## **Functional requirement**

- Active ConnectedDrive contract.
- ▶ The integrated SIM card in the vehicle has been activated.
- Cellular network reception.
- A consent for the transmission of the corresponding data was given in the Data Protection menu.

## Search for an upgrade

Standby must be turned on to search for a software upgrade.

#### **Automatic search**

The vehicle regularly searches for updates in the background.

#### Manual search

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Remote Software Upgrade"
- 5. "Search for upgrades"
- 6. Follow the instructions on the Control Displav.

## Download of an upgrade

#### **Automatic download**

The available data for Remote Software Upgrade is automatically loaded into the vehicle. The download does not require an approval.

#### Via BMW app

If an upgrade is available, information about the new software version is displayed in the BMW app.

The data for the upgrade can then be down-loaded to a mobile device, for instance via an existing WLAN connection.

The data can then be transmitted from the mobile device to the vehicle.

This transmission method accelerates the download of the data, for instance in areas with limited mobile network availability.

- 1. Download the upgrade in the BMW app to the smartphone.
- 2. Follow the instructions in the BMW app.
- 3. Establish connection to the vehicle.
  - ▶ iOS: connect Bluetooth audio and WLAN.
  - Android: connect WLAN.

The data transfer of the upgrade from the mobile device to the vehicle occurs in the background only while driving.

Follow the instructions on the Control Display.

Additional information:

Connecting mobile devices to the vehicle, refer to page 73.

## Information about the version

#### **General information**

The information about the version contains a description of the updates that are included in the Remote Software Upgrade. During the download and after the installation has been completed

successfully, the information about the version can be displayed on the Control Display.

This information is also available in the ConnectedDrive customer portal.

## **Displaying information**

Display in the vehicle:

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Remote Software Upgrade"
- 5. "Info about version"

Display in the ConnectedDrive customer portal: www.bmw-connecteddrive.com.

## Installing the upgrade

#### **General information**

- The installation of the upgrade may result in a deletion of software changes such as performance increases that have not been installed by the manufacturer of the vehicle.
- ▶ The installation may take approx. 20 minutes.
- The installation cannot be terminated.
- ➤ The vehicle cannot be used during the installation.
- The vehicle can be exited during the installation.
- ➤ The installation does not occur until the consent was given.

## Prerequisites for the installation

- ▶ The battery is sufficiently charged.
- ► The outside temperature is above 14 °F/-10 °C.
- ▶ Vehicle is parked in a horizontal position.
- Hazard warning system is switched off.
- Selector lever position P is engaged.

- Engine is turned off and sufficiently cooled down.
- Automatic engine start for pre-conditioning is not activated via iDrive.

If applicable, follow the notes for further prerequisites on the control display.

If the prerequisites are not met, such as a sufficient vehicle battery charge state, the upgrade will not be offered for installation.

Pay attention to an offer for installation, for instance after extended driving.

## Preparing the vehicle

- Park the vehicle safely away from the public road.
- Cellular network reception must be ensured so that a fault message can be sent, for instance if the installation is terminated.
- Close the windows.
- Close the glass sunroof.
- Close the tailgate.
- ▶ Remove energy consuming devices, such as a mobile phone.
- ▶ Unhitch any trailer or load carrier.
- ➤ The vehicle key must be located in the vehicle for the consent for installation.
- Switch off the exterior lighting.
- Remove connected devices from the OBD socket.

## Starting installation

The upgrade can be installed when all prerequisites have been met.

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Remote Software Upgrade"
- 5. "Start upgrade now"

Follow the instructions on the Control Display.

#### **Functional limitations**

During the upgrade, the majority of functions is temporarily unavailable, for instance:

- ▶ Hazard warning system.
- Central locking system and, if necessary, Comfort Access.
- Parking lights.
- Horn.
- ▶ Alarm system.
- ▶ Emergency call.
- Power windows.
- ▶ Operation of the tailgate.
- Glass sunroof.
- Checking the fuel filler flap lock.

The driver's door can be locked and unlocked from the outside using the integrated key.

## After successful upgrade

The vehicle can be used again immediately.

Booked services, such as RTTI or Remote Services, will be reactivated automatically during the next trip.

After an extended stationary period, charge the vehicle battery with an extended drive.

#### **Malfunction**

In the event of a malfunction, follow the instructions on the control display or in the BMW app.

If the malfunction cannot be remedied, contact a dealer's service center or another qualified service center or repair shop.

## Validity of the Owner's Manual

#### **Production of the vehicle**

At the time of production at the plant, the printed Owner's Manual is the most current resource.

## After a software update in the vehicle

After a vehicle software update, such as via Remote Software Upgrade, the Integrated Owner's Manual for the vehicle will contain the latest information.

## **General settings**

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## **Time**

## Setting the time zone

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Date and time"
- 5. "Time zone:"
- 6. Select the desired setting.

## **Setting the time**

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Date and time"
- 5. "Time:"
- 6. Turn the Controller until the desired hours are displayed.
- 7. Press the Controller.
- 8. Turn the Controller until the desired minutes are displayed.
- 9. "OK"

## **Setting the time format**

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Date and time"
- 5. "Time format:"
- 6. Select the desired setting.

## Automatic time setting

Depending on your vehicle's optional features, the time, date and, if needed, the time zone are updated automatically.

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Date and time"
- 5. "Automatic time setting"

## **Date**

## Setting the date

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Date and time"
- 5. "Date:"
- Turn the Controller until the desired day is displayed.
- 7. Press the Controller.
- 8. Make the settings for the month and year.
- 9. "OK"

## **Setting the date format**

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Date and time"
- 5. "Date format:"
- 6. Select the desired setting.

## Language

## **Setting the system language**

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Language"
- 5. Select the desired setting.

## Setting the units of measurement

Depending on the country version, you can set the units of measurement for some values, for instance consumption, distances, and temperature.

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Units"
- 5. Select the desired menu item.
- 6. Select the desired setting.

## **Driver Attention Camera**

## **Principle**

A camera that monitors driver activity is located in the instrument cluster. The camera evaluates the head position and eye opening and uses the

data to analyze the attention of the driver. This system supports various vehicle assistance systems, e.g.:

- ▶ Fatigue alert.
- Steering and traffic jam assistant with Extended Traffic Jam Assistant.

## **Activating/deactivating**

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Driver Attention Camera"
- 5. Select the desired setting.

## **System limits**

The Driver Attention Camera may not be fully functional in the following situations:

- When the Driver Attention Camera is covered by the steering wheel rim.
- ▶ When the driver is wearing infrared impermeable sunglasses.

## Trip data settings

## **Principle**

The intervals in which the trip data will be reset can be configured.

## Resetting trip data

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Reset trip data"
- 5. Select the desired setting.

## **Speed warning**

## **Principle**

The speed warning can be used to set a speed limit. A warning will be issued when this speed limit is exceeded.

#### **General information**

The warning is repeated if the vehicle speed exceeds the set speed limit again, after it has dropped below it by 3 mph/5 km/h.

## **Adjusting**

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Speed warning"
- 5. "Warning at:"
- Turn the Controller until the desired speed is displayed.
- 7. Press the Controller.

## Activate/deactivate

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Speed warning"
- 5. "Speed warning"

# Accept current speed as the speed warning

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Speed warning"
- 5. "Select current speed"

# Activating/deactivating pop-ups

For some functions, pop-ups are displayed automatically on the Control Display. Some of these pop-ups can be activated or deactivated.

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Pop-ups"
- 5. Select the desired setting.

## **Control Display**

## **Brightness**

- 1. "CAR"
- 2. "Settings"
- 3. "Displays"
- 4. "Control display"
- 5. "Brightness at night"
- Press the Controller.
- Turn the Controller until the desired brightness is set.
- 8. Press the Controller.

Depending on the light conditions, the brightness settings may not be clearly visible.

## Reset vehicle data

All individual settings can be reset to the factory settings when the drive-ready state is switched off.

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Reset vehicle data"
- 5. "Reset vehicle data"

When the stored settings in a driver profile are synchronized with the ConnectedDrive account, these settings will remain in the ConnectedDrive account.

## **Notifications**

## **Principle**

The menu centrally displays all notifications arriving in the vehicle in form of a list.

#### **General information**

The following notifications can be displayed:

- ▶ Traffic messages.
- Check Control messages.
- Messages on service notifications.
- ▶ Communication messages, for example emails, SMS text messages or reminders.
- ▶ Messages, for instance from the BMW app.
- Messages from the manufacturer of the vehicle, for instance technical information or important customer information.

The number of notifications is additionally displayed in the status field.

## Go to notifications

- 1. Tip the Controller up.
- 2. "Notifications"
- 3. Select desired notification.

## **Delete notifications**

All notifications, except Check Control messages or messages from the vehicle manufacturer, can be deleted from the list.

Check Control messages or messages from the vehicle manufacturer are displayed as long as they are relevant.

- 1. Tip the Controller up.
- "Notifications"

- 3. Select desired notifications.
- 4. Press the button.
- 5. Select the desired setting.

## **Settings**

It is possible to set which notifications are permitted and which notifications will be displayed at the start of the trip and at the completion of the trip.

- 1. Tip the Controller up.
- 2. "Notifications"
- 3. Tilt the Controller to the right.
- 4. "Settings"
- 5. Select the desired setting.

## Display, notifications

### **General information**

The BMW Intelligent Personal Assistants allows the configuration of the range of messages that will be displayed. Depending on the situation, the desired condition can be activated.

Condition	Description
"Do not disturb"	Incoming calls and non-critical notifications are not displayed.
	Iton is shown in the status information with the number of messages.
"Passenger on board"	Private contents, such as messages, will not be displayed directly.
	I lcon is shown in the status information with the number of messages.

#### Activate/deactivate

- 1. Tip the Controller up.
- 2. "Notifications"
- 3. Tilt the Controller to the right.

- 4. "Notification display"
- 5. Select the desired setting.

## **Personal settings**

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## **Data protection**

#### **Data transmission**

## **Principle**

The vehicle offers different services, whose use requires a data transfer to BMW or a service provider. The data transmission can be deactivated for some services.

### **General information**

When the data transmission is deactivated, the respective service cannot be used.

Only make these settings while stationary.

## **Settings**

The data transfer can be configured in different stages or individually for separate services.

- 1. "CAR"
- 2. "Settings"
- "General settings"
- 4. "Data privacy"
- 5. Select the desired setting.

## Deleting personal data in the vehicle

#### **Principle**

Depending on the usage, the vehicle stores personal data, such as stored radio stations. This personal data can be permanently deleted using iDrive.

#### **General information**

Depending on the equipment, the following data is deleted:

- Driver profile settings.
- Stored radio stations.
- > Stored programmable memory buttons.
- > Travel and trip computer information.
- ▶ Navigation, for instance stored destinations.
- Phone book.
- Online data, for instance Favorites, cookies.
- Office data, for instance voice memos.
- Login accounts.
- ▶ Linking vehicle and ConnectedDrive account.

Altogether, the deletion of the data can take up to 15 minutes.

## **Functional requirement**

Data can only be deleted while stationary.

## **Deleting data**

The personal data in the vehicle will be deleted when the vehicle is reset to the factory settings.

Additional information:

Reset vehicle data, refer to page 65.

## **Driver profiles**

## **Principle**

Driver profiles can be created to store personal vehicle settings. If the vehicle is used by multiple drivers, each driver can create his personal driver profile. When a driver profile is selected, the vehicle will automatically apply the stored settings in the driver profile.

## **General information**

Three personal driver profiles can be created.

In addition, a guest profile is available that can be selected by any driver. The guest profile is active when a personal driver profile has not been selected.

Changes to the vehicle settings are automatically stored in the active driver profile or in the guest profile.

The vehicle can already adjust to the driver when it is unlocked. For this purpose, the recognition via a vehicle key or a digital key must be assigned to a driver profile.

ConnectedDrive countries: The settings stored in the driver's profile can be synchronized with the personal BMW ConnectedDrive account. It is thereby possible to use these settings in other BMW vehicles as well.

## **Functional requirements**

When a driver profile is created, switched or deleted, the vehicle must move at a maximum of walking speed.

#### Welcome screen

After the Control Display is switched on, the Welcome screen will be displayed.

The following actions can be carried out on the Welcome screen:

- Switching the driver profile.
- Starting the set-up assistant.

This option is offered in new vehicle for a limited period of time.

As soon as the engine is started or any button is pressed, the Welcome screen will be hidden.

## **Setup assistant**

The setup assistant is offered in new vehicles for a limited period of time on the Welcome screen to configure the most important settings for the vehicle.

"Getting started" Select to start the set-up assistant.

The set-up assistant can be started via iDrive at any time.

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Getting started"

The driver is guided step by step through the following functions:

- Setting the system language.
- ConnectedDrive countries:
   If the set-up assistant was opened in the quest profile: create driver profile.
- > Pairing mobile devices with the vehicle.
- If the set-up assistant was opened from an already defined driver profile: set up personal assistant.
- Depending on whether the set-up assistant was opened from an already defined driver profile or a guest profile: set up services or confirm the explanation for the transmission of vehicle related data.
- ▶ Set up other methods for use.

The selected settings are stored in the active driver's profile.

## **Guest profile**

The guest profile can be activated by any driver. Vehicle settings that are entered when the guest profile is active will be stored in the guest profile.

In the following cases the guest profile is automatically active:

- ▶ A driver profile has not been created yet.
- No driver profile has been assigned to the vehicle key that was used to unlock the vehicle.
- No driver profile has been assigned to the digital key that was used to unlock the vehicle.

The following limitations apply:

- ▶ The guest profile cannot be renamed.
- ▶ It is not possible to assign the recognition to the guest profile.
- ▶ It is not possible to assign a PIN to the guest profile.
- ConnectedDrive countries: It is not possible to synchronize with a ConnectedDrive account.

The guest profile is selected on the Welcome screen or via iDrive:

- 1. "CAR"
- 2. "Driver profiles"

As an alternative for Steps 1 and 2, the profile image can be tapped in the top status bar.

- 3. "Guest"
- 4. "OK"

## **Creating a driver profile**

- 1. "CAR"
- 2. "Driver profiles"
- Tilt the Controller to the right.As an alternative for Steps 1 to 3, the profile
- 4. "Add driver profile"

Non-ConnectedDrive countries: A name must be entered for the driver profile.

image can be tapped in the top status bar.

ConnectedDrive countries: An existing ConnectedDrive account must be assigned to a driver profile. The following options are available for this purpose:

▶ "Via My BMW app"

Scanning the displayed QR code will accept the access data for the ConnectedDrive account from the BMW app.

▶ "Log in"

The access data must be entered via iDrive.

▶ "New registration"

Scan the displayed QR code and follow the instructions on the smartphone.

## **Selecting recognition**

- 1. "CAR"
- 2. "Driver profiles"
- Tilt the Controller to the right.
   As an alternative for Steps 1 to 3, the profile image can be tapped in the top status bar.
- 4. "Driver recognition"
- 5. Select the desired setting:
  - ▶ "with vehicle key"

The vehicle key that is recognized in the car's interior is assigned to the driver profile. If multiple vehicle keys are detected, the unintended vehicle keys must be removed from the car's interior.

"With Digital Key"

The digital key that is recognized in the car's interior is assigned to the driver profile. If multiple digital keys are detected, the unintended digital keys must be removed from the car's interior.

6. "Activate linkage"

As soon as the vehicle detects the vehicle key or the digital key, the corresponding driver profile will be activated. If the vehicle key or the smartphone with the digital key is not carried with you or not recognized, the driver profile can only be selected on the Welcome screen when a PIN has been set up.

## Setting up a PIN

A driver profile with recognition cannot be activated without vehicle key and without digital key.

In this case, a PIN can be set up to activate the driver profile.

Countries in which ConnectedDrive is not available: If a PIN was not set up or the PIN is not known, the driver profile cannot be activated.

Countries in which ConnectedDrive is available: If a PIN was not set up or the PIN is not known, the driver's profile can be activated with the access data of the corresponding ConnectedDrive account.

- 1. "CAR"
- 2. "Driver profiles"
- Tilt the Controller to the right.
   As an alternative for Steps 1 to 3, the profile image can be tapped in the top status bar.
- 4. "Driver recognition"
- 5. "using PIN"

# Changing/canceling the recognition function

When another vehicle key or another digital key is assigned to a driver profile, the current assignment must be canceled first.

- 1. "CAR"
- 2. "Driver profiles"
- 3. Tilt the Controller to the right.

As an alternative for Steps 1 to 3, the profile image can be tapped in the top status bar.

- 4. "Driver recognition"
- 5. Select the desired setting:
  - "with vehicle key"
  - "With Digital Key"
- 6. "Activate linkage"

When the vehicle and vehicle key will be handed over, such as for maintenance, carry out the following steps first:

- ▶ Setting up PIN.
- ▶ Canceling recognition using the vehicle key.
- Switching to the guest profile.

The handed over vehicle key can then no longer be used to access the personal driver profile.

## Selecting a driver profile

Depending on the recognition setting, the driver profile will be selected automatically.

If the guest profile is active, the driver profile will be selected on the Welcome screen or via iDrive. A PIN may have to be entered.

- 1. "CAR"
- 2. "Driver profiles"

As an alternative for Steps 1 and 2, the profile image can be tapped in the top status bar.

- 3. Select driver profile.
- 4. "OK"

All settings stored in the selected driver profile are automatically applied.

# Switching synchronization with the ConnectedDrive account on/off

The settings stored in the driver's profile are synchronized with the personal ConnectedDrive account. This means that it is possible to use the personal settings in other BMW vehicles with ConnectedDrive access as well, if this function is supported.

The synchronization with the ConnectedDrive account is enabled when a driver profile is created or via iDrive:

- 1. "CAR"
- 2. "Driver profiles"
- 3. Tilt the Controller to the right.

As an alternative for Steps 1 to 3, the profile image can be tapped in the top status bar.

- 4. "Settings"
- 5. "Synchronize driver profile"
- 6. "Synchronize driver profile"

## Renaming a driver profile

Non-ConnectedDrive countries:

- 1. "CAR"
- 2. "Driver profiles"

As an alternative for Steps 1 and 2, the profile image can be tapped in the top status bar.

- 3. Select driver profile.
- 4. "Settings"
- 5. Enter a profile name.
- 6. **OK** Select the icon.

ConnectedDrive countries:

The name of the driver profile is transferred from the ConnectedDrive account. Changes for the profile name must be made in the Connected-Drive account.

## Selecting a profile picture

- 1. "CAR"
- 2. "Driver profiles"
- 3. Tilt the Controller to the right.

As an alternative for Steps 1 to 3, the profile image can be tapped in the top status bar.

- 4. "Avatar"
- 5. Select the desired profile picture.

ConnectedDrive countries:

The profile image is transferred from the ConnectedDrive customer portal or the BMW app.

## **Deleting the driver profile**

- 1. "CAR"
- 2. "Driver profiles"
- 3. Tilt the Controller to the right.

As an alternative for Steps 1 to 3, the profile image can be tapped in the top status bar.

- 4. "Settings"
- 5. "Remove driver profile"
- 6. Select the desired driver profile.
- 7. "Delete now"

ConnectedDrive countries: If the driver profile was synchronized with a ConnectedDrive account, the stored data in the ConnectedDrive account will be retained.

## System limits

A clear detection of the desired vehicle key may not be possible in the following cases, e.g.:

- ▶ The driver unlocks the vehicle via Comfort Access.
- ➤ The driver changes, but the vehicle is not locked and unlocked.
- When multiple vehicle keys are located in the outer area on the driver's side of the vehicle.

ConnectedDrive countries:

A driver profile can only be created and synchronized with the ConnectedDrive account when the vehicle has cellular network reception.

The use of personal settings that are stored in the ConnectedDrive account in other vehicles is subject to technical limitations. For example, settings may be stored for a system that is not available, or available in a non-compatible version, in other vehicles.

# **Connections**

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are

not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems applicable laws and regulations must be observed.

# Connecting mobile devices to the vehicle

### **Principle**

Various connection types are available for using mobile devices in the vehicle. The connection type to select depends on the mobile device and the desired function.

# **General information**

The following overview shows possible functions and the suitable connection types for them. The scope of functions depends on the mobile device.

the desired fariotism.	VICCI	
Function	Connection type	Symbol in the device list
Making calls via the hands-free system.	Bluetooth.	9
Using phone functions via iDrive or touchscreen.		
Other functions, e.g. Contacts or SMS.		
Playing music from the smartphone or the audio player.	Bluetooth audio.	ī.
WLAN in the vehicle:	WLAN.	•
Using apps in the vehicle.		
Wi-Fi hotspot:	WLAN.	<u>(i)</u>
Using the vehicle Internet access.		
Screen Mirroring:	WLAN.	
Showing the smartphone display on the Control Display.		
USB port:	USB.	Ų.
Playing music or videos from a USB device.		

Function	Connection type	Symbol in the device list
Apple CarPlay: Using apps via iDrive and via voice operation.	Bluetooth and WLAN.	<b>€</b>
Android Auto: Using apps via iDrive and via voice operation.	Bluetooth and WLAN.	٨

The following connection types require one-time pairing with the vehicle:

- Bluetooth.
- WLAN.

Paired devices are automatically recognized later on and connected to the vehicle.

# **Safety information**



Operating the integrated information systems and communication devices while driving can distract from traffic. It is possible to lose control of the vehicle. There is a risk of accident. Only use the systems or devices when the traffic situation allows. As warranted, stop and use the systems and devices while the vehicle is stationary.

# **Compatible devices**

### **General information**

Information on mobile devices compatible with the vehicle can be found at www.bmwusa.com/bluetooth.

Malfunctions may occur with devices not listed or deviating software versions.

# Displaying the vehicle identification number and software part number

When looking for compatible devices, you may have to state the vehicle identification number and the software part number. These numbers can be displayed in the vehicle.

- 1. "COM"
- 2. "Mobile devices"
- 3. Tilt the Controller to the right.
- 4. "Settings"
- 5. "Bluetooth® info"
- 6. "System information"

# Managing mobile devices

### **General information**

- After one-time pairing, the devices are automatically recognized and reconnected when standby state is switched on.
- ▶ After stored content on the SIM card or the mobile phone, such as contacts, has been detected, the data is transmitted to the vehicle and can be used via iDrive.
- For some devices, certain settings are necessary, for instance authorization; see the operating instructions of the device.

# Displaying the device list

All devices paired with or connected to the vehicle are displayed in the device list. A maximum of four devices can be connected to the vehicle via Bluetooth, and a maximum of ten devices can be connected to the vehicle via WLAN. A maximum of 20 devices will be detected.

- 1. "COM"
- 2. "Mobile devices"

An icon to the right of the device name indicates, for which function the device is used.

When the icon is displayed in white, this function is actively connected to the vehicle. The icon is displayed in gray when the function of the device is inactive.

lcon	Meaning
8	Telephone.
П	Bluetooth audio.
<u>:</u>	WLAN in the vehicle, Wi-Fi hotspot.
••	Apps.
	Screen Mirroring.
<b>€</b>	Apple CarPlay.
⚠	Android Auto.

# **Configuring the device**

Functions can be activated or deactivated for paired and connected devices.

The scope of functions depends on the mobile device.

Follow the information on the Control Display.

- 1. "COM"
- 2. "Mobile devices"
- 3. Select the desired device.
- 4. Select the desired setting:
  - ▶ "Connect device"

The functions that were assigned to the device before disconnecting are assigned to the device when it is reconnected. The

- functions may be deactivated on a device already connected.
- "Disconnect device"

The device remains paired and can be connected again.

▶ "Delete device"

The device is disconnected and removed from the device list.

"Connection mode"

Select a connection mode, for instance Apple CarPlay.

- ▶ "Telephone"
  Set telephone.
- ▶ "Bluetooth® audio"

Playback of music files on external devices such as audio devices or mobile phones via Bluetooth®.

▶ "Apps"

With the installed BMW app, apps from the smartphone can be displayed in the vehicle.

▶ "Wi-Fi®"

Connects the device with the WLAN in the vehicle.

# **Priority of the phones**

When multiple mobile phones are connected to the vehicle, you can specify the priority of the mobile phones for reconnection.

- 1. "COM"
- 2. "Mobile devices"
- 3. Tilt the Controller to the right.
- 4. "Settings"
- 5. "Priorities for telephones"
- 6. Select the desired device.
- 7. Select the desired priority by sliding.

# **Bluetooth connection**

# **Functional requirements**

- ➤ Compatible device with Bluetooth interface. Compatible devices, refer to page 74.
- The vehicle key or BMW display key is in the vehicle.
- ▶ The device is ready for operation.
- ▶ Bluetooth is switched on in the vehicle and on the device.
- ➤ The pairing readiness is displayed on the Control Display.
- Bluetooth presettings, such as visibility, may be required on the device; refer to the operating instructions of the device.

### **Activate Bluetooth**

- 1. "COM"
- "Mobile devices"
- 3. Tilt the Controller to the right.
- 4. "Settings"
- 5. "Bluetooth®"
- 6. Select setting.

# Connecting the device

- 1. "COM"
- 2. "Mobile devices"
- 3. Tilt the Controller to the right.
- 4. "New device"
- "Phone calls and audio"
   The vehicle's Bluetooth name is displayed on the Control Display.
- Compare the control number displayed on the Control Display with the control number on the display of the mobile device, and confirm that the two match.
- 7. A Bluetooth connection is established.

The mobile device is connected to the vehicle and displayed in the device list.

# **Frequently Asked Questions**

All requirements are met and all required steps were completed in the specified order. Despite that, the mobile device does not function as expected.

In this case, the following explanations can help:

Why could the mobile phone not be paired or connected?

- There are too many Bluetooth devices connected to the mobile phone or vehicle.
  - In the vehicle, delete Bluetooth connections with other devices.
  - Delete the Bluetooth connection from the device list on the mobile phone and start a new device search.
  - Too many Bluetooth devices with the same function are paired.
- The mobile phone is in power-save mode or has only a limited remaining battery life.
   Charge the mobile phone and deactivate the power-save mode where required.

Why does the mobile phone no longer react?

- ➤ The applications on the mobile phone do not function anymore.
  - Switch the mobile phone off and on again.
- Too high or too low ambient temperature for mobile phone operation.
  - Do not subject the mobile phone to extreme ambient temperatures.

Why can telephone functions not be used via iDrive?

- ▶ Phone functions are not configured for the mobile phone.
  - Connect the mobile phone with the telephone function.

Why are no or not all telephone book entries displayed or why are they incomplete?

- Transmission of the telephone book entries is not yet complete.
- It is possible that only the telephone book entries of the mobile phone or the SIM card are transmitted.
- ▶ It may not be possible to display telephone book entries with special characters.
- ▶ It may not be possible to transmit contacts from social networks.
- ➤ The number of phone book entries to be transmitted is too high.
- Data volume of the contact too large, for instance due to stored information such as memos.
  - Reduce the data volume of the contact.
- A mobile phone can only be connected as audio source or as telephone.
  - Configure the mobile phone and connect it with the telephone function.
- ➤ Contact was created in the contact list of the phone after the last synchronization.
  - Synchronize contacts again: "Reload contacts"

How can the telephone connection quality be improved?

- Adjust the strength of the Bluetooth signal on the mobile phone, depending on the mobile phone.
- ▶ Insert the mobile phone into the wireless charging tray.
- ➤ Adjust the volume of the microphone separately in the sound settings.

If all points in this list have been checked and the required function is still not available, contact Customer Relations, a dealer's service center or another qualified service center or repair shop.

# **WLAN** connection

### **General information**

For certain applications, such as apps, the data exchange between smartphone and vehicle occurs via WLAN.

# **Functional requirements**

- > Standby state is switched on.
- Compatible device with activated WLAN interface.

### **Activate WLAN in the vehicle**

- 1. "COM"
- 2. "Mobile devices"
- 3. Tilt the Controller to the right.
- 4. "Settings"
- 5. "Wi-Fi®"

# Wi-Fi hotspot

### **Principle**

Compatible devices with WLAN interface can use the Internet connection of the vehicle via the Wi-Fi hotspot.

### **General information**

Up to ten devices can be connected to the Wi-Fi hotspot simultaneously.

# **Functional requirements**

- Compatible device with activated WLAN interface.
  - Compatible devices, refer to page 74.
- ▶ WLAN is activated on the vehicle.
- ▶ Internet use is activated for the vehicle.
- Registration and data contract with a service provider where required.
- Standby state is switched on.

# Connecting a device to the Internet via the Wi-Fi hotspot

Using the Internet for the first time via the Wi-Fi hotspot requires registration and possibly a data volume purchase from a service provider.

Depending on the country version, data volume can be purchased via the connected mobile device or from the Connected Drive Store.

- 1. "COM"
- 2. "Mobile devices"
- 3. Tilt the Controller to the right.
- 4. "New device"
- 5. "Internet, apps"

Hotspot name and hotspot code are displayed on the Control Display.

- Activate Internet usage via WLAN if necessary.
  - "Open settings"
- 7. Activate Internet usage.
  - "Internet connection"
- 8. Tilt the Controller to the left.
- Search for WLAN networks on the mobile device. Select network name on the device.
- Enter hotspot code on the device and connect.

The device is displayed in the device list.

Additionally, a QR code will be displayed on the Control Display. Alternatively, this QR code can be used to pair the mobile device with the hotspot.

All devices connected via the hotspot use this data volume.

# Deactivating Internet usage via the Wi-Fi hotspot

Internet usage may be deactivated if the data volume is used up, for instance.

- 1. "COM"
- 2. "Mobile devices"

- 3. Tilt the Controller to the right.
- 4. "Settinas"
- 5. "Internet connection"
- 6. Select the desired setting.

# **Screen Mirroring**

### **General information**

Screen Mirroring enables mirroring (outputting) of the smartphone display on the Control Display.

# **Functional requirements**

- Compatible smartphone with Screen Mirroring interface.
  - Compatible devices, refer to page 74.
- Screen Mirroring is activated on the smartphone.
- WLAN is activated on the vehicle.

# Pairing a smartphone with Screen Mirroring

- 1. "COM"
- 2. "Mobile devices"
- 3. Tilt the Controller to the right.
- 4. "New device"
- 5. "Screen Mirroring"

The WLAN name of the vehicle is displayed on the Control Display.

Search for WLAN devices in the surrounding area of the smartphone.

The WLAN name of the vehicle appears on the device display. Select the WLAN name of the vehicle.

7. Confirm the connection via iDrive.

The device is connected and displayed in the device list.

# Apple CarPlay© preparation

# **Principle**

CarPlay allows certain functions of a compatible Apple iPhone to be used via Siri voice control and iDrive.

### **Functional requirements**

- Compatible iPhone, iPhone 5 or later with iOS 7.1 or later.
  - Compatible devices, refer to page 74.
- Corresponding mobile contract.
- Bluetooth, WLAN, and Siri voice control are activated on the iPhone.
- ▶ If necessary, the setting for mobile data must be activated on the iPhone.
- Booking the ConnectedDrive service: smartphone integration.
- WLAN and Bluetooth are enabled in the vehicle.

# Pairing the iPhone with CarPlay

- 1. "COM"
- 2. "Mobile devices"
- 3. Tilt the Controller to the right.
- 4. "New device"
- "Phone calls and audio"
   The vehicle's Bluetooth name is displayed on the Control Display.
- 6. On the mobile device, search for Bluetooth devices in the vicinity and select the vehicle.

  A control number is displayed.
- 7. Compare the control number displayed on the Control Display with the control number on the display of the mobile device, and confirm that the two match.
- 8. "Use Apple CarPlay"

The iPhone is connected to the vehicle and displayed in the device list.

# **Operation**

For more information, refer to the Integrated Owner's Manual or the Owner's Manual for Navigation. Entertainment, Communication.

### **Frequently Asked Questions**

All requirements are met and all required steps were completed in the specified order. Despite that, the mobile device does not function as expected.

In this case, the following explanations can help:

The iPhone has already been paired with Apple CarPlay. When a new connection is set up, Car-Play can no longer be selected.

- ▷ Delete the iPhone concerned from the device list.
- On the iPhone, delete the vehicle concerned from the list of stored connections under Bluetooth and under WLAN.
- ▶ Pair the iPhone as a new device.

If the steps listed have been carried out and the required function is still not available: contact Customer Relations, a dealer's service center or another qualified service center or repair shop.

# **Android Auto© preparation**

### **Principle**

Android Auto allows the operation of certain functions of a compatible smartphone via voice control and iDrive.

# **General information**

The range of services offered depends on the country.

# **Functional requirements**

➤ Compatible Android smartphone: Samsung or Google smartphone with Android 10 or an Android smartphone with Android 11, regardless of the manufacturer.

- ▶ Compatible devices, refer to page 74.
- Corresponding mobile contract.
- ▶ Bluetooth and WLAN are enabled on the smartphone.
- ▶ The smartphone must support a 5 Ghz WiFi connection.
- ▶ If necessary, the setting for mobile data must be activated on the smartphone.
- WLAN and Bluetooth are enabled in the vehicle.

# Pairing a smartphone with Android Auto

- 1. "COM"
- 2. "Mobile devices"
- 3. Tilt the Controller to the right.
- 4. "New device"
- 5. "Phone calls and audio"

The vehicle's Bluetooth name is displayed on the Control Display.

- On the mobile device, search for Bluetooth devices in the vicinity and select the vehicle.
   A control number is displayed.
- Compare the control number displayed on the Control Display with the control number on the display of the mobile device, and confirm that the two match.
- 8. "Use Android Auto"
- 9. If necessary, finish the setup on the mobile device.

The smartphone is connected to the vehicle and displayed in the device list.

# **Operation**

For more information, refer to the Integrated Owner's Manual or the Owner's Manual for Navigation, Entertainment, Communication.

# **Frequently Asked Questions**

All requirements are met and all required steps were completed in the specified order. Despite that, the mobile device does not function as expected.

In this case, the following explanations can help:

The smartphone has already been paired with Android Auto. When a new connection is set up, Android Auto can no longer be selected.

- Delete the smartphone concerned from the device list.
- On the smartphone, delete the vehicle concerned from the list of stored connections under Bluetooth and under WLAN.
- ▶ Pair the smartphone as a new device.

If the steps listed have been carried out and the required function is still not available: contact Customer Relations, a dealer's service center or another qualified service center or repair shop.

# **USB** connection

### **General information**

The following mobile devices can be connected to the USB port:

- Mobile phones.
- Audio devices such as MP3 players.
- USB storage devices.

Common file systems are supported. FAT32 and exFAT are the recommended formats.

A connected USB device will be supplied with charge current via the USB port if the device supports this. Follow the maximum charge current of the USB port.

The following uses are possible on USB ports with data transmission:

- Playing music files.
- Playing videos.

Follow the following when connecting:

- ▶ Do not use force when plugging the connector into the USB port.
- Use a flexible adapter cable.
- Protect the USB device against mechanical damage.
- Due to the large number of USB devices available on the market, it cannot be guaranteed that every device is operable on the vehicle.
- Do not expose USB devices to extreme environmental conditions, such as very high temperatures; refer to the operating instructions of the device.
- Due to the many different compression techniques, proper playback of the media stored on the USB device cannot be guaranteed in all cases.
- To ensure proper transmission of the stored data, do not charge a USB device via the onboard socket, when it is connected to the USB port.
- Depending on how the USB device is being used, settings may be required on the USB storage device, refer to the operating instructions of the device.

Not compatible USB devices:

- USB hard drives
- USB hubs.
- USB memory card readers with multiple slots.
- HFS-formatted USB devices.
- Devices such as fans or lamps.

# **Functional requirement**

Compatible device with USB port.

Additional information:

Compatible devices, refer to page 74.

# **Connecting the device**

Connect the USB device using a suitable adapter cable to a USB port.

The USB device is displayed in the device list.

Additional information:

USB port, refer to page 311.

# Opening and closing

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

# Vehicle key

### General information

Depending on the equipment version, the scope of delivery includes two vehicle keys or one vehicle key and the BMW display key.

Each vehicle key contains a replaceable battery.

Depending on the equipment and country version, various settings can be configured for the button functions.

A driver profile with personal settings can be assigned to a vehicle key.

To provide information on maintenance recommendations, the service data is stored in the vehicle kev.

To prevent possible locking in of the vehicle key, take the vehicle key with you when exiting the vehicle.

# **Safety information**

### Marning

The vehicle key has a button cell battery. Batteries or button cells can be swallowed and lead to serious or fatal injuries within two hours. for example, due to internal burns or chemical burns. There is an injury hazard or danger to life. Keep the vehicle key and batteries out of reach for children. Immediately seek medical help if there is any suspicion that a battery or button cell has been swallowed or is located in any part of the body.

### Marning

People or animals in the vehicle can lock the doors from the inside and lock themselves in. In this case, the vehicle cannot be opened from the outside. There is a risk of injury. Take the vehicle key with you so that the vehicle can be opened from the outside.



### Marning

For some country versions, unlocking from the inside is only possible with special knowledge.

Persons who spend a lengthy time in the vehicle while being exposed to extreme temperatures are at risk of injury or death. Do not lock the vehicle from the outside when there are people in it.



### Marning

Unattended children or animals in the vehicle can cause the vehicle to move and endanger themselves and traffic, for instance due to the following actions:

- ▶ Pressing the Start/Stop button.
- ▶ Releasing the parking brake.
- Opening and closing the doors or windows.
- ▶ Engaging selector lever position N.
- ▶ Using vehicle equipment.

There is a risk of accidents or injuries. Do not leave children or animals unattended in the vehicle. Take the vehicle key with you when exiting and lock the vehicle.

### **Overview**



- 1 Unlocking
- 2 Locking Stationary climate control through Remote Engine Start 298
- 3 To open the tailgate
- 4 Panic mode, pathway lighting

# **Unlocking**

### **General information**

The behavior of the vehicle during unlocking using the vehicle key depends on the following settings:

- ▶ If only the driver's door and the fuel filler flap or all access to the vehicle will be unlocked when the button is pressed for the first time.
- ▶ If the unlocking of the vehicle is confirmed with a light signal or a sound signal.
- ▶ If the welcome light is switched on when the vehicle is being unlocked.

Welcome lights, refer to page 181.

# Unlocking the vehicle



Press the button on the vehicle key.

If, due to the settings, only the driver's door and fuel filler flap were unlocked, press the button on the vehicle key again to unlock the other vehicle access points.

In addition, the following functions are executed:

- If a driver profile was assigned to the vehicle key, this driver profile will be activated and the settings that are stored in it will be applied.
- ➤ The interior lights are switched on, unless they were manually switched off.
- ▶ Folded in exterior mirrors are folded out. If the exterior mirrors were folded in via the button in the car's interior, they will not be folded out when unlocking.
- With alarm system: The alarm system will be switched off

After opening one of the front doors, the vehicle is ready for operation.

The light functions may depend on the ambient brightness.

# **Convenient opening**



Press and hold the button on the vehicle key after unlocking.

The windows and the glass sunroof with sun protection are opened, as long as the button on the vehicle key is pressed.

# Locking

### **General information**

The behavior of the vehicle during locking using the vehicle key depends on the following settings:

- ▶ If the locking of the vehicle is confirmed with a light signal or a sound signal.
- ▶ If the exterior mirrors are automatically folded in when the vehicle is locked. The exterior mirrors are not folded in when the hazard warning flashers are switched on.
- If pathway lighting is activated during locking.

### Locking the vehicle

- 1. Close the driver's door.
- Press the button on the vehicle key.

The following functions are executed:

- ▶ All doors, the tailgate, and the fuel filler flap are locked.
- ▶ With alarm system: The alarm system will be switched on.

If the drive-ready state is still switched on when you lock the vehicle, the vehicle horn honks twice. In this case, the drive-ready state must be switched off by means of the Start/Stop button.

# With Comfort Access: convenient closing

# **Safety information**



### Warning

With convenient closing, body parts can be jammed. There is a risk of injury. Make sure that the area of movement of the doors is clear during convenient closing.

### Closing



Press and hold the button on the vehicle key in the area close to the vehicle after locking.

The windows and the glass sunroof with sun protection are closed, as long as the button on the vehicle key is pressed.

The exterior mirrors are folded in unless they were folded in during locking. The exterior mirrors are not folded in when the hazard warning flashers are switched on.

# Switching on the interior and exterior lighting



Press the button on the vehicle key with the vehicle locked.

The function is not available for the first 10 seconds after locking.

- ▶ The interior lights are switched on, unless they were manually switched off. Interior lights, refer to page 184.
- Depending on the settings, parts of the exterior lighting will be switched on.

The light functions may depend on the ambient brightness.

# **Tailgate**

### General information

To avoid locking the vehicle key in the vehicle, do not place the vehicle key in the cargo area.

The following settings are available for the operation of the tailgate with the vehicle key:

- ▶ Whether the vehicle key opens only the upper tailgate or the upper and lower tailgate at the same time.
- Depending on the vehicle equipment and country version, it is possible to specify whether the tailgate can be unlocked with the vehicle key and how the vehicle doors will respond to this.

Selector lever position P must be engaged to open the tailgate with the vehicle key.

When the trailer power socket is occupied, the tailgate cannot be opened with the vehicle key.

### **Safety information**



### Marning

Body parts can be jammed when operating the tailgate. There is a risk of injury. Make sure that the area of movement of the tailgate is clear during opening and closing.



### Marning

The tailgate pivots out when it opens. There is a risk of injury or risk of damage to property. Make sure that the area of movement of the tailgate is clear during opening and closing.

### ∧ NOTICE

Sharp-edged or pointed objects can hit the windows and heat conductors while driving. There is a risk of damage to property, among other potential damage. Cover the edges and ensure that pointed objects do not hit the windows.

# **Opening**



Press and hold the button on the vehicle key for approx. 1 second.

# Switching pathway lighting on



Press and hold the button on the vehicle key for approx. 1 second.

It is possible to adjust the duration of the pathway lighting feature.

Additional information:


Pathway lighting, refer to page 181.

# Replacing the battery

### ∧ NOTICE

Improper batteries in the vehicle key can damage the vehicle key. There is a risk of damage to property, among other potential damage. Always replace the discharged battery with a battery with the same voltage, the same size and the same specification.

- 1. Remove the integrated key from the vehicle
  - Integrated key, refer to page 97.
- 2. Place the integrated key underneath the battery compartment cover, arrow 1, and lift the cover with a lever movement of the integrated key, arrow 2.



3. Push battery in arrow direction using a pointed object and lift it out.



- 4. Insert a type CR 2032 3V battery with the positive side facing up.
- 5. Press the cover closed.
- 6. Push the integrated key into the vehicle key until the integrated key engages.



Have old batteries disposed of by a dealer's service center or another qualified service center or repair shop or take

them to a collection point.

# **Additional vehicle keys**

Additional vehicle keys are available from a service center or another qualified service center or repair shop.

# Loss of vehicle keys

A lost vehicle key can be disabled and replaced by a dealer's service center or another qualified service center or repair shop.

If the lost vehicle key has an assigned driver profile, the connection to this vehicle key must be deleted. A new vehicle key can then be assigned to the driver profile.

### Malfunction

### **General information**

A Check Control message is displayed.

Vehicle key detection by the vehicle may malfunction under the following circumstances:

- ▶ The battery of the vehicle key is discharged.
- ▶ Fault of the radio link from transmission towers or other equipment with high transmitting power.
- Shielding of the vehicle key due to metal objects.
  - Do not transport the vehicle key together with metal objects.
- Fault of the radio link from mobile phones or other electronic devices in direct proximity to the vehicle key.

Do not carry the vehicle key in close proximity to other electronic devices.

- ▶ Fault of radio transmission by a charging process of mobile devices, for instance charging of a mobile phone.
- ➤ The vehicle key is located in direct proximity of the tray for wireless charging tray.

Place the vehicle key in a different location.

In the case of interference, the vehicle can also be unlocked and locked from the outside with the integrated key.

Additional information:

Integrated key, refer to page 97.

# Switching the drive-ready state on via emergency detection of the vehicle key



It is not possible to switch on the drive-ready state if the vehicle key has not been detected.

Proceed as follows in this case:

- Hold the rear of the vehicle key against the marked area on the steering column. Pay attention to the display in the instrument cluster.
- 2. If the vehicle key is detected:

Turn on drive-ready state within 10 seconds.

If the vehicle key is not recognized, slightly change the position of the vehicle key and repeat the procedure.

# **Frequently Asked Questions**

What precautions can be taken to be able to open a vehicle with an accidentally locked in vehicle key?

- ▶ The options provided by the Remote Services of the BMW app include the ability to lock and unlock a vehicle.
  - This requires an active BMW Connected-Drive contract and the BMW app must be installed on a smartphone.
- ▶ Unlocking the vehicle can be requested via the BMW ConnectedDrive Call Center.
  - An active BMW Connected Drive contract is required.

# **BMW** display key

### **General information**

Thescope of delivery of the BMW display key includes an additional mechanical key. If the display key is used, the mechanical key should be carried with you, for instance in the wallet. The mechanical key is used like the integrated key.

The display key supports all functions of the standard vehicle key.

In addition, the following functions are also available:

- Display status of doors and windows.
- Display status of the alarm system.
- Display service information.
- ▶ Call up range with available fuel.
- With parked-car heating: operate parked-car heating.
  - Without parked-car heating: operate pre-ventilation.
- ▶ Pre-conditioning through Remote Engine Start
- ▶ Level setting of the vehicle when stationary.

Additional information:

Integrated key, refer to page 97.

# **Safety information**



### Warning

People or animals in the vehicle can lock the doors from the inside and lock themselves in. In this case, the vehicle cannot be opened from the outside. There is a risk of injury. Take the vehicle key with you so that the vehicle can be opened from the outside.



### Marning

For some country versions, unlocking from the inside is only possible with special knowledge.

Persons who spend a lengthy time in the vehicle while being exposed to extreme temperatures are at risk of injury or death. Do not lock the vehicle from the outside when there are people in it.



### ⚠ Warning

Unattended children or animals in the vehicle can cause the vehicle to move and endanger themselves and traffic, for instance due to the following actions:

- ▶ Pressing the Start/Stop button.
- > Releasing the parking brake.
- > Opening and closing the doors or win-
- ▶ Engaging selector lever position N.
- ▶ Using vehicle equipment.

There is a risk of accidents or injuries. Do not leave children or animals unattended in the vehicle. Take the vehicle key with you when exiting and lock the vehicle.

### **Overview**



- 1 To open the tailgate
- 2 Unlocking
- 3 Press and hold or press three times in quick succession: panic mode
  Press briefly: pathway lighting
- A. Laaldaa
- 4 Locking
- 5 Display6 Back
- 7 Turn the display on/off
- 8 Micro-USB charging interface

# **Reception range**

The number of available display key functions depends on the distance from the vehicle.

- When you are in close proximity to the vehicle, all functions of the display key are available.
- ▶ The status information can be called up in the extended reception range.
  - With parked-car heating: the parked-car heating can be operated.
  - Without parked-car heating: the pre-ventilation can be operated.
- Outside of the reception range of the vehicle, you can display the last transmitted status information from the vehicle.

The icon is shown on the display if one of the buttons is pressed outside of the reception range.

# **Display**

### **General information**

The display is divided into the upper status line, the information area, and the lower status line.

### **Upper status line**

The upper status line displays the following information:

- ▶ 🗗 / 🗗 Vehicle secured/vehicle unsecured.
- Set time in the vehicle.
- Charge state of the display key battery.

### Information area

The information area can be used to access information and perform additional functions.

If the information area contains more than one page, then page indicators are shown beneath the information.

○●○ A solid indicator denotes the current page.

Swipe to the right or left with a finger to change between the pages.

If further information is available on a page, tap the appropriate icon.

To return to the original page:  $\footnotemark$  tap on the icon beneath the display.

### Lower status line

The lower status line indicates whether or not the display key is within reception range.

- "Connected": the display key is within reception range.
- "Updated": the display key is not within reception range. It indicates when the last data transfer from the vehicle took place.

### **Turning on/off**

The display will go out automatically after a brief period to conserve battery power.

Hiding the display on the display manually: press the button on the left side of the display key.

To show the display:

- Press the button on the left side of the display key.
- 2. Then, swipe with your finger from bottom to top to unlock the screen lock.

To turn off the display to increase the usable battery life:

- 1. If necessary, cancel the screen lock.
- 2. Press and hold the button on the left side of the display key for longer than 4 seconds.
- 3. "OK"

To turn the display on:

Press the button on the left side of the display key.

# **Operating concept**

The following information shows how to access the information and functions using the main menus.

Main menu	Information/Function
"Security	Მ/Ნ
information"	Door status.
	Alarm system status.
	After alarm triggering: date, time, and reason for triggering the alarm.
	Window status.
	Glass sunroof status.
"Entry level"	
"Vehicle information"	Maintenance indicators of Condition Based Service CBS.
	Status of the roadside parking lights.

Main menu	Information/Function
"Mobility info"	Range with available fuel.
"Preconditioning setting"	With parked-car heating: operate parked-car heating. Without parked-car heating: operate pre-ventilation. Stationary climate control through Remote Engine Start.

# **Display key battery**

### **General information**

Follow the following information:

- ▶ If the charge state of the display key battery declines, the display is switched off automatically. The battery must be recharged so that the display can be switched back on. The operability of the standard buttons is retained until the battery is completely discharged.
- ➤ Charge the battery for at least three hours before using the display key for the first time or if the key has not been used for an extended period.
- The display key can be used while it is being charged via the USB port. If the battery is fully discharged, it may take some time before the display key can be used again.
- Due to the large number of USB chargers available on the market, it cannot be guaranteed that every charger will function properly. The charging time depends on the charger used.
- ▶ Charging via the USB port may heat up the charger and the display key.
  - Charging in the wireless charging tray may heat up the tray and the display key.
  - At higher temperatures, the charge current through the display key may be reduced, and

- in isolated cases the charge process may be interrupted temporarily.
- ▶ When inserting the display key into the wireless charging tray, make sure there are no objects between it and the wireless charging tray.

### Safety information

### Warning

When charging a device that meets the Qi standard in the wireless charging tray, any metal objects located between the device and the tray can become very hot. Placing storage devices or electronic cards, such as chip cards. cards with magnetic strips or cards for signal transmission, between the device and the tray may impair the card function. There is a risk of injury and risk of damage to property. When charging mobile devices, make sure there are no objects between the device and the tray.

# Charging

### Via USB

Connect the display key via the micro-USB charging interface to a USB port.

### With thermoelectric cup holder: centered in the center console



- 1. Open the tray cover.
- 2. Place display key flush into the recess of the wireless charging tray.

Ensure that the display is facing up.

Close the tray cover.

### Without thermoelectric cup holder; on the left in the center console



- 1. Open the tray cover.
- 2. Place the display key into the middle of the wireless charging tray in front of the left cup holder.

Ensure that the display is facing up.

3. Close the tray cover.

### LED displays

Color	Meaning
Blue	The display key is charging.
	The blue LED stays illuminated once the inserted display key is fully charged.
Orange	The display key is not charging.
	Temperature on the display key possibly too high or foreign object in charging tray.
Red	The display key is not charging.
	Contact a dealer's service center or another qualified service center or repair shop.
	·

# Malfunction

### General information

A Check Control message is displayed.

BMW display key detection by the vehicle may malfunction under the following circumstances:

- ▶ The battery of the display key is discharged.
- ▶ Fault of the radio link from transmission towers or other equipment with high transmitting power.
- Shielding of the display key due to metal objects.
- ▶ Fault of the radio link from mobile phones or other electronic devices in direct proximity.
- Fault of radio transmission by a charging process of mobile devices, for instance charging of a mobile phone.

Do not transport the display key together with metal objects or electronic devices.

In the case of interference, the vehicle can also be unlocked and locked from the outside with the mechanical key.

# Turning on drive readiness via emergency detection of the BMW display key



It is not possible to switch on the drive-ready state if the display key has not been detected.

Proceed as follows in this case:

- Hold the display key with its rear against the marked area on the steering column. Pay attention to the display in the instrument cluster.
- If the display key is detected: Turn on drive-ready state within 10 seconds.

If the display key is not detected, slightly change the position of the display key and repeat the procedure.

### Resetting the BMW display key

If the charged display key cannot be turned on anymore or if the display does not respond to entries anymore, the display key can be reset.

Press and hold the following buttons on the display key at the same time for at least 10 seconds until the display is switched off and then on again:





# **Key Card**

# **Principle**

The Key Card allows the vehicle to be unlocked and locked, as well as started.

### **General information**

The Key Card is available with Comfort Access. Depending on the national-market version, the Key Card may not be available.

A digital key that has already been paired with the vehicle is installed on the Key Card. The digital key must be activated via iDrive.

Before leaving the vehicle, deactivate the Key Card or take the Key Card with you because the active Key Card can be used to start the vehicle. Always take the vehicle key with you to a service appointment.

# **Safety information**

### Marning

People or animals in the vehicle can lock the doors from the inside and lock themselves in. In this case, the vehicle cannot be opened from the outside. There is a risk of injury. Take the vehicle key with you so that the vehicle can be opened from the outside.

# Marning

For some country versions, unlocking from the inside is only possible with special knowledge.

Persons who spend a lengthy time in the vehicle while being exposed to extreme temperatures are at risk of injury or death. Do not lock the vehicle from the outside when there are people in it.

# ⚠ Warning

Unattended children or animals in the vehicle can cause the vehicle to move and endanger themselves and traffic, for instance due to the following actions:

- ▶ Pressing the Start/Stop button.
- ▶ Releasing the parking brake.
- > Opening and closing the doors or windows.
- ▶ Engaging selector lever position N.
- ▶ Using vehicle equipment.

There is a risk of accidents or injuries. Do not leave children or animals unattended in the vehicle. Take the vehicle key with you when exiting and lock the vehicle.

# Connection to the vehicle

The communication between the vehicle and the Key Card uses near field communication, NFC.

# **Activating/deactivating Key Card** in the vehicle

### General information

The Key Card must be located in the smartphone tray and a vehicle key must be located in the vehicle to activate the Key Card.

A vehicle key must be located in the vehicle to deactivate the Kev Card.

When BMW Digital Key is activated for the vehicle, a digital key can be used instead of the vehicle kev.

A deactivated Key Card remains in the list of paired digital keys.

### **Activate Key Card**

Tray with thermoelectric cup holder:



Tray without thermoelectric cup holder:




- 1. Open the cover of the smartphone tray.
- 2. Place Key Card centered into the smartphone tray.
- 3. Follow the instructions on the Control Display to activate the Key Card.

### **Deactivate Key Card**

- 1. "CAR"
- 2. "Settings"
- 3. "Doors/ vehicle access"
- 4. "Digital Key"
- 5. Select Key Card.
- 6. "Key active"

A deactivated Key Card remains in the list of paired digital keys.

# Unlocking and locking the vehicle



Hold activated Key Card directly and centered on the external door handle of the driver's door.

If the Key Card is not detected, slightly change the position of the Key Card and repeat the procedure.

# Starting the engine

Tray with thermoelectric cup holder:



Tray without thermoelectric cup holder:



- 1. Open the cover of the smartphone tray.
- 2. Place activated Key Card centered into the smartphone tray.
- 3. Press the Start/Stop button to start the engine.

With wireless charging tray: After starting the engine, take the Key Card out of the tray to make tray available for charging compatible smart-phones.

### Malfunction

The detection of the Key Card by the vehicle may be disrupted by objects between the sensors and the Key Card, for instance a wallet.

# **BMW Digital Key**

# **Principle**

BMW Digital Key allows the vehicle to be unlocked and locked, as well as started, with a compatible smartphone.

### **General information**

The availability of the BMW Digital Key depends on the equipment and national-market version.

BMW Digital Key can be used with a compatible smartphone or other compatible mobile terminals, such as a Smartwatch.

To unlock and start a vehicle with a compatible smartphone, this function must be offered by the smartphone manufacturer. The BMW app provides a check to determine if the smartphone and the vehicle are compatible.

A driver profile with individual settings can be assigned to a digital key.

Additional information:

Driver profiles, refer to page 69.

When using a smartphone as a digital key, always carry a vehicle key or the activated Key Card with you. This ensures access to the vehicle, even in the event of a smartphone failure. It is also useful to carry the vehicle key or the Key Card with you if the vehicle has to be handed over to another person. You can then hand over the vehicle key or the Key Card, instead of your smartphone. Always take the vehicle key with you to a service appointment.

# **Safety information**



People or animals in the vehicle can lock the doors from the inside and lock themselves in. In this case, the vehicle cannot be opened from the outside. There is a risk of injury. Take the vehicle key with you so that the vehicle can be opened from the outside.

# Marning

For some country versions, unlocking from the inside is only possible with special knowledge.

Persons who spend a lengthy time in the vehicle while being exposed to extreme temperatures are at risk of injury or death. Do not lock the vehicle from the outside when there are people in it.

# **⚠** Warning

Unattended children or animals in the vehicle can cause the vehicle to move and endanger themselves and traffic, for instance due to the following actions:

- ▶ Pressing the Start/Stop button.
- ▶ Releasing the parking brake.
- Opening and closing the doors or windows.
- ▶ Engaging selector lever position N.
- ▶ Using vehicle equipment.

There is a risk of accidents or injuries. Do not leave children or animals unattended in the vehicle. Take the vehicle key with you when exiting and lock the vehicle.

### Connection to the vehicle

The communication between the vehicle and the smartphone uses near field communication, NFC.

### **Functional requirements**

- ▶ The smartphone is compatible with BMW Digital Key
- ➤ The vehicle is linked with the Connected-Drive account of the vehicle owner.
- ➤ The rechargeable battery of the smartphone has a sufficient charge. The necessary minimum charge of the rechargeable battery depends on the smartphone.

# Enable the digital remote control key

Vehicle owner's smartphone is enabled as a digital remote control key in the vehicle. The vehicle owner must prove his authorization for the vehicle for this purpose.

The proof of authorization can be started via the BMW app or via the activation code in the corresponding smartphone function, for instance the Wallet app. Both vehicle keys must be located in the vehicle to be enabled.

Follow the instructions in the Digital Key menu in the BMW app or on the Control Display.

The valid service period of the digital key may be limited. The expiration date of the validity can be checked in the BMW app.

After a digital key has expired, it can still be used to move the vehicle until the vehicle is used with a different vehicle key or digital key.

# **Sharing digital keys**

### **General information**

Digital key allows the sharing of digital keys with other people. This option is available via the smartphone that is enabled as digital remote control key.

# Forwarding authorization

To share the digital key, select the corresponding function on the smartphone, for instance in the Wallet app.

As soon as a digital key is shared with another person, the person will receive an invitation. When the invitation is accepted, the digital key on the recipient's smartphone will be activated.

# Limiting the range of functions

Certain functions of the digital key can be limited before handing it over. For example, if the digital key is handed over to a novice driver, the switchoff of driving stability control system can be excluded. For more information, refer to the ConnectedDrive portal and the BMW app.

### **Authentication**

Depending on the recipient's smartphone model, an authentication may be required for security and safety reasons.

An authorized vehicle key, the digital remote control key or another method may be used for authentication. Follow the corresponding instructions on the smartphone or the Control Display.

# **Deleting a shared key**

### **General information**

Shared keys can be deleted via the smartphone with the digital remote control key, the smartphone with a shared key or via iDrive.

The deletion via the smartphone with the digital remote control key will not be performed until the vehicle is used with a key other than the key to be deleted.

The deletion via the smartphone with a shared key or via iDrive is executed immediately.

Deleted digital keys will be removed from the list of enabled digital keys.

Deleted digital keys cannot be restored.

### **Deletion via iDrive**

To be able to delete a digital key via iDrive, an authorized vehicle key must be located in the vehicle or the remote control key must be located in the smartphone tray.

- 1. "CAR"
- 2. "Settings"
- 3. "Doors/ vehicle access"
- 4. "Digital Key"
- 5. If necessary, select the digital key.
- 6. "Delete key"

### Reset the function

To reset the BMW Digital Key function, an authorized vehicle key must be located in the vehicle.


When resetting the BMW Digital Key function, all digital keys including the digital remote control key will be deleted.

After the reset, the vehicle can no longer be unlocked, locked or started with a digital key.

The digital remote control key must be enabled again to be able to use BMW Digital Key again.

- 1. "CAR"
- 2. "Settings"
- 3. "Doors/ vehicle access"
- 4. "Digital Key"
- 5. "Reset function"

# Unlocking and locking the vehicle



Hold the near field communication antenna of the smartphone directly and centered on the external door handle of the driver's door.

The position of the near field communication antenna depends on the smartphone model.

When locking the vehicle with the smartphone, make sure that all doors and also the tailgate are closed.

# Starting the engine

Tray with thermoelectric cup holder:



Tray without thermoelectric cup holder:



- 1. Open the cover of the smartphone tray.
- 2. Place smartphone centered into the smartphone tray.
  - Ensure that the display is facing up.
- 3. Close the cover of the smartphone tray.
- Press the Start/Stop button to start the engine.

# Sale of the smartphone

Delete all digital keys on the smartphone prior to selling the smartphone. This ensures that that the smartphone can no longer be used for the vehicle.

### Sale of the vehicle

Prior to selling a vehicle, reset the Digital Key function or remove the vehicle from the ConnectedDrive account of the current vehicle owner.

When the vehicle is removed from the ConnectedDrive account, all digital keys for the vehicle will be deleted.

### **Malfunction**

Digital key recognition by the vehicle may malfunction under the following circumstances:

- ➤ The smartphone is shielded from the sensors in the vehicle by a smartphone cover that is not suitable.
- Objects such as a chip card or the Key Card are located between the smartphone and the smartphone cover.

# **Integrated key**

### **General information**

The driver's door can be locked and unlocked without the vehicle key using the integrated key. Depending on the national-market version, the integrated key also fits the glove compartment.

# **Safety information**



### Marning

For some country versions, unlocking from the inside is only possible with special knowledge.

Persons who spend a lengthy time in the vehicle while being exposed to extreme temperatures are at risk of injury or death. Do not lock the vehicle from the outside when there are people in it.



### ∧ NOTICE

The door lock is permanently joined with the door. The door handle can be moved. When pulling the door handle with the integrated key inserted, paint or the integrated key can be damaged. There is a risk of damage to property, among other potential damage. Remove the integrated key before pulling the external door handle


# Removing



Press the button, arrow 1, and pull out the integrated key, arrow 2.

# Locking/unlocking via the door lock

1. Pull and hold the door handle outward with one hand.



2. Guide one finger of your other hand from the back under the cover and push the cover out. Use the thumb for counter support to prevent the cover from falling out of the door handle.



- 3. Remove the cover.
- 4. Unlock or lock the door lock using the integrated key.



The other doors must be unlocked or locked from the inside.

# **Alarm system**

The activated alarm system is triggered when the door is opened, if the vehicle has been unlocked via the door lock.

The alarm system is not switched on if the vehicle is locked with the integrated key.

# Buttons for the central locking system

# **General information**

In the event of a severe accident, the vehicle is automatically unlocked. The hazard warning system and interior lights come on.

### **Overview**



Buttons for the central locking system.

# Locking



Press the button with the front doors closed

- ▶ The fuel filler flap remains unlocked.
- ➤ The vehicle is not secured against theft when locking.

# **Unlocking**



Press the button.

### **Opening**



Press the button to unlock all the doors.

Pull the door opener above the armrest.

- Front doors: pull the door handle on the door to open the door. The other doors remain locked.
- Back doors: pull twice on the door handle on the door to be opened; the first time unlocks the door, the second time opens it. The other doors remain locked.

# **Comfort Access**

# **Principle**

The vehicle can be accessed without operating the vehicle key.

Carrying the vehicle key with you, e.g., in your pants pocket, is sufficient.

The vehicle automatically detects the vehicle key when it is in close proximity or in the car's interior.

# **General information**

Comfort Access supports the following functions:

- Unlocking and locking the vehicle from the door handle.
- Convenient closing.
- Touchless unlocking and locking of the vehicle.
- Unlocking and locking the vehicle using the BMW Digital Key.
- Open the tailgate.
- Open and close the tailgate with no-touch activation.

# **Functional requirements**

- ➤ To lock the vehicle, the vehicle key must be outside of the vehicle near the doors.
- ➤ The next unlocking and locking cycle is not possible until after approx. 2 seconds.

# **Unlocking**

### **General information**

The behavior of the vehicle during unlocking via the Comfort Access depends on the following settings:

- ▶ If the unlocking of the vehicle is confirmed with a light signal or a sound signal.
- ▶ If the welcome light is switched on when the vehicle is being unlocked.

### Unlocking the vehicle



Grasp the handle of a vehicle door completely.

In addition, the following functions are executed:

- If a driver profile was assigned to the vehicle key, this driver profile will be activated and the settings that are stored in it will be applied.
- ➤ The interior lights are switched on, unless they were manually switched off.
- ▶ Folded in exterior mirrors are folded out. If the exterior mirrors were folded in via the button in the car's interior, they will not be folded out when unlocking.
- With alarm system: The alarm system will be switched off.

# Locking


### **General information**

The behavior of the vehicle during locking via the Comfort Access depends on the following settings:

- ▶ If the locking of the vehicle is confirmed with a light signal or a sound signal.
- If the exterior mirrors are automatically folded in when the vehicle is locked. The exterior mirrors are not folded in when the hazard warning flashers are switched on.
- ▶ If pathway lighting is activated during locking.

# Locking the vehicle

Close the driver's door.



Touch the grooved surface on the handle of a closed vehicle door with your finger for approx. 1 second without grasping the door handle.

The following functions are executed:

- ▶ All doors, the tailgate, and the fuel filler flap are locked.
- ▶ With alarm system: The alarm system will be switched on.

# **Convenient closing**

### Safety information

# Marning

With convenient closing, body parts can be jammed. There is a risk of injury. Make sure that the area of movement of the doors is clear during convenient closing.

### Closing



Touch the grooved surface on the handle of a closed vehicle door with your finger and hold it there without grasping the door handle.

In addition to locking, the windows and glass sunroof with sun protection will be closed.

The exterior mirrors are folded in unless they were folded in during locking. The exterior mirrors are not folded in when the hazard warning flashers are switched on.

# **Opening the tailgate**

### **General information**

If the tailgate is opened via Comfort Access, locked doors are not unlocked.

To avoid locking the vehicle key in the vehicle, do not place the vehicle key in the cargo area.

### Safety information

### Marning

Body parts can be jammed when operating the tailgate. There is a risk of injury. Make sure that the area of movement of the tailgate is clear during opening and closing.

### Marning

The tailgate pivots out when it opens. There is a risk of injury or risk of damage to property. Make sure that the area of movement of the tailgate is clear during opening and closing.

### ∧ NOTICE

Sharp-edged or pointed objects can hit the windows and heat conductors while driving. There is a risk of damage to property, among other potential damage. Cover the edges and ensure that pointed objects do not hit the windows.

# **Opening**



Press the button on the outer side of the tailgate.

# Opening and closing the tailgate with no-touch activation

### **Principle**

The tailgate can be opened and closed with notouch activation using the vehicle key you are carrying. Two sensors detect a forward-directed foot motion in the central rear area and the tailgate is opened and closed.

### **General information**

Touchless opening and closing of the tailgate is not possible when equipped with trailer hitch.

Selector lever position P must be engaged for touchless opening of the tailgate.

To avoid locking the vehicle key in the vehicle. do not place the vehicle key in the cargo area.

If the vehicle key is in the sensor area, the tailgate may open or close inadvertently if you unintentionally move your foot or if a foot movement is detected.

The sensor has an approximate range of 5 ft/1.50 m extending from the rear of the vehicle.

If the tailgate is opened with no-touch activation, locked doors are not unlocked.

You can configure if only the upper tailgate will open or if the upper and lower tailgate opens. When closing, the upper and lower tailgate will always be closed.

Contactless opening and closing of the tailgate must be activated in the settings.

# Safety information



### Warning

During no-touch activation, vehicle parts may be touched, such as the hot exhaust gas system. There is a risk of injury. When moving your foot, make sure you have a firm stance and do not touch the vehicle

### Warning

Body parts can be jammed when operating the tailgate. There is a risk of injury. Make sure that the area of movement of the tailgate is clear during opening and closing.

### Warning

The tailgate pivots out when it opens. There is a risk of injury or risk of damage to property. Make sure that the area of movement of the tailgate is clear during opening and closing.



### ∧ NOTICE

Sharp-edged or pointed objects can hit the windows and heat conductors while driving. There is a risk of damage to property, among other potential damage. Cover the edges and ensure that pointed objects do not hit the windows.

### Settings

Contactless opening and closing of the tailgate can be switched on or off.

- 1. "CAR"
- 2. "Settings"
- 3. "Doors/ vehicle access"
- 4. "Tailgate"

# Performing the foot movement

- 1. Stand in the middle behind the vehicle at approx. one arm's length away from the rear of the vehicle.
- 2. Wave a foot under the vehicle in the driving direction and immediately pull it back. With

this movement, the leg must pass through the ranges of both sensors.



### **Opening**

Perform the foot movement described earlier. Before the tailgate opens, the hazard warning

Before the tailgate opens, the hazard warning system flashes.

Moving your foot again will stop the opening motion, and moving it one more time after that will close the tailgate.

### Closing

Perform the foot movement described earlier.

The hazard warning system flashes and an acoustic signal sounds.

Moving your foot again will stop the closing motion, and moving it one more time after that will re-open the tailgate.

# **System limits**

The detection of the foot movement may be limited due to the following external conditions:

- ▶ Ice, snow or slush on the rear of the vehicle.
- Dirt or road salt on the rear of the vehicle.

Movement in the range of the sensors may cause unintended opening or closing of the cargo area, for instance due to water running own when cleaning the vehicle or with heavy rainfall. To prevent such unintended opening or closing of the cargo area in such cases, keep the vehicle key at a sufficient distance from the rear of the vehicle.

# Touchless unlocking and locking of the vehicle

### **Principle**

The vehicle will be unlocked when the driver approaches the locked vehicle with the vehicle key.

When the driver walks away from the unlocked vehicle with the vehicle key, the vehicle will be locked.

### **General information**

The vehicle will be unlocked when an authorized vehicle key is detected in the unlocking zone.

The unlocking zone is located within a radius of approx. 3 ft/1 m around the door handles.

The vehicle will be locked when the vehicle key leaves the locking zone.

The locking zone is located within a radius of approx. 7 ft/2 m around the door handles.

If the vehicle key is located in the unlocking zone for an extended period of time without movement, the vehicle will be locked automatically.

If a passenger is detected in the front passenger seat during locking and the safety belt of the front passenger is engaged in the safety belt buckle during locking:

- ➤ The vehicle will be locked but not secured against theft.
- ▶ The fuel filler flap remains unlocked.

The behavior of the vehicle during touchless unlocking/locking depends on the following settings:

- ▶ If the automatic unlocking is active.
- ▶ If the automatic locking is active.
- ▶ If only the driver's door and the fuel filler flap or all access to the vehicle will be unlocked.

Only driver's door and fuel filler flap: the driver's door and fuel filler flap will only be unlocked when the driver approaches the vehicle on the driver's side.

All vehicle entry points: the vehicle will be unlocked regardless of the side on which the driver approaches the vehicle.

- If the unlocking and locking of the vehicle is confirmed with a light signal or a sound signal.
- ▶ If the welcome light is switched on when the vehicle is being unlocked.
- ▶ If pathway lighting is activated during locking.
- If the exterior mirrors are automatically folded out and in when the vehicle is unlocked and locked.

### **Functional requirements**

- ▶ The drive-ready state must be turned off.
- Unlocking: when entering the unlocking zone, the doors and tailgate must be closed.
- ▶ Locking: when leaving the locking zone, the doors and tailgate must be closed.
- For touchless locking of the vehicle, no second vehicle key can be located in a radius of six meters around the vehicle.
- If the vehicle has been in the idle state for several days, touchless unlocking/locking is not possible until after the vehicle has been driven.

### **Malfunction**

Vehicle key detection by the vehicle may malfunction under the following circumstances:

- ➤ The battery of the vehicle key is discharged.
  For replacing the battery, refer to page 85.
- Fault of the radio link from transmission towers or other equipment with high transmitting power.
- Shielding of the vehicle key due to metal objects.
  - Do not transport the vehicle key together with metal objects.
- Fault of the radio link from mobile phones or other electronic devices in direct proximity to the vehicle key.

Do not carry the vehicle key in close proximity to other electronic devices.

Wet or snowy conditions may disrupt the locking request detection on the door handles.

In the case of a malfunction, unlock and lock the vehicle using the buttons of the vehicle key or use the integrated key.

Additional information:

Integrated key, refer to page 97.

# **Tailgate**

### General information

To avoid locking the vehicle key in the vehicle, do not place the vehicle key in the cargo area.

Depending on the vehicle equipment and country version, it is possible to specify whether the tailgate can be unlocked with the vehicle key and how the vehicle doors will respond to this.

The tailgate consists of the upper and the lower tailgate. The lower tailgate opens downward to make loading the cargo area easier.

Selector lever position P must be engaged to open the tailgate with the vehicle key.

The following settings are available for the operation of the tailgate:

- ▶ The opening height of the upper tailgate.
- With Comfort Access: Whether the vehicle key opens only the upper tailgate or the upper and lower tailgate at the same time.
- ▶ With Comfort Access: Whether the button in the driver's door opens only the upper or the upper and lower tailgate together.
- ▶ Determines if the doors will be unlocked when the tailgate is opened with the vehicle key.

# **Safety information**

### Warning

Body parts can be jammed when operating the tailgate. There is a risk of injury. Make sure that the area of movement of the tailcate is clear during opening and closing.

### Marning

The tailgate pivots out when it opens. There is a risk of injury or risk of damage to property. Make sure that the area of movement of the tailgate is clear during opening and closing.

### ∧ NOTICE

Foreign objects, such as sand or icing, between the bumper and tailgate may cause damage when operating the lower tailgate. There is a risk of damage to property, among other potential damage. If necessary, remove foreign objects from the bumper and the lower tailgate before operating the lower tailgate.

### ⚠ NOTICE

Sharp-edged or pointed objects can hit the windows and heat conductors while driving. There is a risk of damage to property, among other potential damage. Cover the edges and ensure that pointed objects do not hit the windows.



### ⚠ NOTICE

Manual operation of the tailgate in the wrong sequence can damage the tailgate. There is a risk of damage to property, among other potential damage. Close the lower tailgate first before closing the upper tailgate manually.

# **Upper tailgate**

# **Opening**

### General information

When the trailer socket is occupied, the tailgate cannot be opened with the vehicle key or with the button in the car's interior.

The upper tailgate will be opened to the configured opening height.

### From the outside



- ▶ Unlock the vehicle and then press the button on the outer side of the tailgate.
- ▶ With Comfort Access: carry the vehicle key with you and press the button on the outer side of the tailgate.

Press and hold the button on the vehicle key for approx. 1 second.

With Comfort Access: If necessary, the lower tailgate will also be opened.

### From the inside



Press the button in the driver's door.

If the vehicle is locked, selector lever position P must be engaged first.

With Comfort Access: If necessary, the lower tailgate will also be opened.

### Interruption of the opening procedure

The opening procedure is interrupted in the following situations:

- When the vehicle starts moving.
- By pressing the used button used again.

### Closing

### **Functional requirement**

Without Comfort Access: The lower tailgate must be closed; otherwise, a Check Control message will be displayed.

### From the outside

Without Comfort Access:

- 1. Closing the lower tailgate manually.
- 2. Press the button on the inside of the upper tailgate.



With Comfort Access:

Press the button on the inside of the upper tailgate.

The lower tailgate will be closed automatically with the upper tailgate.

Press the button on the inside of the upper tailgate.

The vehicle will be locked after closing the tailgate. The driver's door must be closed for this purpose and the vehicle key must be outside of the vehicle in the area of the tailgate.

The lower tailgate will be closed automatically with the upper tailgate.

### From the inside

Without Comfort Access:

- 1. Closing the lower tailgate manually.
- 2. Pull and hold the button in the driver

The vehicle key must be located in the car's interior for this function.

With Comfort Access:

**~** 

Pull and hold the button in the driver door.

The vehicle key must be located in the car's interior for this function.

The lower tailgate will be closed automatically with the upper tailgate.

An acoustic signal sounds before the tailgate is closed.

### Interruption of the closing procedure

The closing procedure is interrupted in the following situations:

- ▶ If the vehicle starts off with a jerky movement.
- By pressing the used button used again.

# Lower tailgate

### **Opening**

### General information

When open, the lower tailgate can support loads of up to 550 lbs/250 kg.

### **Functional requirement**

The upper tailgate must be open.

### From the outside

Without Comfort Access:



Press the button on the lower tailgate and fold the lower tailgate down.

With Comfort Access:



Press the button on the lower tailgate.

### With Comfort Access: from the inside

Depending on the settings, the lower tailgate will be opened automatically with the upper tailgate.

# With Comfort Access: terminating the opening procedure

The opening procedure is interrupted in the following situations:

- ▶ When the vehicle starts moving.
- By pressing the button on the lower tailgate. Pressing again closes the tailgate.

### Closing

### **Functional requirements**

There is no cargo on the lower tailgate.

### From the outside

Without Comfort Access:

Closing the lower tailgate manually.

With Comfort Access:



Press the button on the lower tailgate.

### With Comfort Access: from the inside

The lower tailgate will be closed automatically with the upper tailgate.

### With Comfort Access: terminating the closing procedure

The closing procedure is interrupted in the following situations:

- ▶ If the vehicle starts off with a jerky movement.
- By pressing the button in the lower tailgate.

# **System limits**

Without Comfort Access: The upper tailgate is designed for electric operation via the provided operating points.

With Comfort Access: The upper tailgate and the lower tailgate are designed for electric operation via the provided operating points.

A manual operation of the tailgate can produce system states in which an electric operation is no longer possible.

For instance, this type of system state applies when there is a danger of collision between the upper and lower tailgate. In this case, an acoustic signal will sound and the upper tailgate must be completely opened manually.

Operate the tailgate manually in exceptional cases only such as in the event of a malfunction.

### Malfunction

# **Safety information**



### 🛕 Warning

With manual operation of a blocked tailgate, it can release itself unexpectedly from the blockage. There is a risk of injury or risk of damage to property. Do not operate the tailgate manually if it is blocked. Have it checked by a dealer's service center or another qualified service center or repair shop.

Without Comfort Access: Operate the unlocked upper tailgate manually and slowly without jerkina.

With Comfort Access: Operate the unlocked upper or lower tailgate manually and slowly without jerking. When closing, make sure the lower tailgate is closed first.

To close the tailgate fully, press down lightly only. Closing occurs automatically.

# Soft-close automatic **function**

# **Safety information**



### Marning

Body parts can be jammed while operating the doors. There is a risk of injury. Make sure that the area of movement of the doors is clear during opening and closing.

# Closing

To close the doors, push lightly. Closing occurs automatically.

# Valet parking mode

### **Principle**

In the valet parking mode, the Control Display is disabled. The operation via iDrive is no longer possible.

E.g., this mode can be used when the vehicle is handed over for valet parking.

### **General information**

In the valet parking mode, it is not possible to change vehicle settings via iDrive. Personal profiles cannot be changed. Personal data cannot be displayed.

Additionally, the following actions are carried out:

- ▶ The volume of the audio system is limited.
- The integrated Universal Remote Control is deactivated.
- DSC cannot be switched off.

### **Functional requirements**

- ▶ At least one driver profile has been created.
- ▶ A driver profile or the guest profile is active.
- ▶ At least one driver profile has an assigned ConnectedDrive account.

# Accessing the menu for the valet parking mode

### Via the switch-off screen

After switching off drive-ready state the switchoff screen will be displayed. Select the entry for the valet parking mode on the switch-off screen.

# Via the display bar at the upper edge of the Control Display

- 1. Tip the Controller up.
- 2. "Valet parking mode"

### Via the vehicle settings

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Valet parking mode"

# Activating the valet parking mode

### **General information**

Before activating the valet parking mode, a PIN must be set up to be able to deactivate the valet parking mode at a future time.

The procedure for entering the PIN varies depending on the active driver profile.

### **Driver profile with PIN**

A PIN has been stored for the active driver profile.

It is not necessary to enter another PIN.

"Activate now"

# **Driver profile without PIN**

A PIN must be assigned to the driver profile.

- 1. "PIN"
- 2. Enter PIN.
- "Activate now"

### **Guest profile**

The guest profile is the active driver profile.

A PIN must be entered.

- 1. "PIN"
- 2. Enter PIN.
- 3 "Activate now"

This PIN can be used once to deactivate the valet parking mode for the active guest profile.

# **Deactivating valet parking mode**

### **General information**

The lock screen of the valet parking mode is displayed on the Control Display.

The deactivation of the valet parking mode depends on which driver profile is selected on the lock screen.

### **Driver profile with PIN**

Regardless of which driver activated the valet parking mode, a driver can deactivate the valet parking mode by entering his/her PIN.

- 1. Select driver profile.
- 2. Enter the assigned PIN for the driver profile.

If you forgot the PIN, the valet parking mode must be deactivated by entering the assigned ConnectedDrive access data.

### **Driver profile without PIN**

The valet parking mode was activated by another person. To deactivate the valet parking mode, a driver without a PIN has to enter the access data for his Connected Drive account.

- 1. Select driver profile.
- 2. Enter the ConnectedDrive access data assigned to the driver profile.

### **Guest profile**

In the guest profile, the valet parking mode can only be deactivated if the valet parking mode was activated in the guest profile.

- 1. Select guest profile.
- Enter the PIN that was specified during activation.

If the PIN has been forgotten, the valet parking mode must be deactivated via a personal driver profile.

# **Settings**

### **General information**

Depending on the vehicle equipment and country version, various settings for opening and closing are possible.

These settings are stored for the driver profile currently used.

# **Unlocking and locking**

### **Doors**

- 1. "CAR"
- 2. "Settings"
- 3. "Key button settings"
- 4. Select the icon.
- 5. Select the desired setting:
  - ▶ "Driver's door only"

Only the driver's door and the fuel filler flap are unlocked. Pressing again unlocks the entire vehicle.

▶ "All doors"

The entire vehicle is unlocked.

# Confirmation signals from the vehicle

- 1. "CAR"
- 2. "Settings"
- 3. "Doors/ vehicle access"
- Deactivate or activate the desired confirmation signals:
  - ▶ "Flash when locking/unlocking" Unlocking is signaled by blinking twice, locking by blinking once.
  - With alarm system:

"Sound when locking/unlocking"

Unlocking is confirmed with two sound signals, locking is confirmed with one sound signal.

# Folding mirrors in automatically

- 1. "CAR"
- 2. "Settings"
- "Doors/ vehicle access"
- 4. "Fold mirrors in when locked"

# **Automatic unlocking**

- 1. "CAR"
- 2. "Settings"
- "Doors/ vehicle access"
- 4. Select the desired setting:
- 5. ▶ "Unlock doors when in Park"
  - "Unlock at end of trip"

After drive-ready state is switched off by pressing the Start/Stop button, the locked vehicle is automatically unlocked.

### **Automatic locking**

- 1. "CAR"
- 2. "Settings"
- "Doors/ vehicle access"
- 4. "Lock in a few minutes"

The vehicle locks automatically after a while if no door is opened after unlocking.

# **Tailgate**

# Opening height of the upper tailgate

You can set how far the upper tailgate can be opened.

When adjusting the opening height, make sure the clearance above the tailgate is at least 4 in/10 cm.

- 1. "CAR"
- 2. "Settings"
- "Doors/ vehicle access"
- 4. "Tailgate"

- 5. "Opening height"
- 6. Monitor the tailgate and set the desired opening height.

# With Comfort Access: upper or both tailgates

The button in the car's interior can be set up to open only the upper tailgate or the upper and lower tailgate together:

Via iDrive:

- 1. "CAR"
- 2. "Settings"
- 3. "Doors/ vehicle access"
- 4. "Tailgate"
- 5. Select the desired setting:
  - ▶ "Upper tailgate" Only the upper tailgate opens.
  - ▶ "Both tailgates"

The upper and lower tailgate will be opened together.

To open the upper and lower tailgate at the same time, the upper tailgate must be closed when the button is pressed.

This setting also applies to the touchless opening of the tailgate.

# Tailgate and doors

Depending on the vehicle equipment and country version, this setting may not be offered.

- 1. "CAR"
- 2. "Settings"
- 3. "Key button settings"
- 4. Select the icon.
- 5. Select the desired setting:
  - ▶ "Upper tailgate" The upper tailgate is opened.
  - "Upper tailgate + door(s)"

The tailgate is opened and the doors unlocked.

▶ "Both tailgates"

The upper and lower tailgate will be opened.

▶ "Both tailgates + door(s)" The upper and lower tailgate will be opened and the doors unlocked.



The following settings are available for the button on the vehicle key:

"Tailgate opens only when vehicle is unlocked."

The vehicle must be unlocked before the tailgate can be used with the vehicle key.

"Lock tailgate button"
 The operation of the tailgate via the vehicle key is disabled.

# **Comfort Access**

# **Touchless locking and unlocking**

Contactless locking and unlocking can be switched on or off.

- 1. "CAR"
- 2. "Settings"
- "Doors/ vehicle access"
- 4. "Comfort access"

# **Touchless opening of the tailgate**

For touchless unlocking, a setting can be entered to open only the upper tailgate or the upper and lower tailgate together:

Via iDrive:

- 1. "CAR"
- 2. "Settings"
- 3. "Doors/ vehicle access"
- 4. "Tailgate"
- 5. Select the desired setting:
  - "Upper tailgate"

Only the upper tailgate opens.

▶ "Both tailgates"

The upper and lower tailgate will be opened together.

To open the upper and lower tailgate at the same time, the upper tailgate must be closed when the button is pressed.

This setting also applies to opening the tailgate in the interior.

# Establishing idle state after opening the front doors

- 1. "CAR"
- 2. "Settings"
- 3. "Doors/ vehicle access"
- 4. "Turn off vehicle after opening door" ldle state, refer to page 41.

# Alarm system

#### **General information**

When the vehicle is locked, the vehicle alarm system reacts to the following changes:

- Opening a door, the hood, or the tailgate.
- Movements in the car's interior.
- ➤ Changes in the vehicle tilt, for instance, during attempts at stealing a wheel or when towing the vehicle.
- Disconnected battery voltage.
- ▷ Improper use of the socket for OBD Onboard Diagnosis.
- Locking the vehicle while a device is connected to the socket for the OBD Onboard-Diagnosis.

The alarm system signals these changes visually and acoustically:

Acoustic alarm:

Depending on local regulations, the acoustic alarm may be suppressed.

Visual alarm:

By flashing of the hazard warning system and headlights, where required.

Do not modify the system to ensure function of the alarm system.

# **Turning on/off**

The alarm system is switched on or off as soon as the vehicle is locked with the vehicle key or unlocked or locked via Comfort Access.

# Opening the doors with the alarm system switched on

The alarm system is triggered when a door is opened if the door was unlocked using the integrated key in the door lock.

# Opening the tailgate with the alarm system switched on

The tailgate can be opened even when the alarm system is switched on.

After the tailgate is closed, it is locked and monitored again provided the doors are locked. The hazard warning system flashes once.

#### Panic mode

You can trigger the alarm system if you find yourself in a dangerous situation.



- ▶ Press the button on the vehicle key and hold for at least 3 seconds.
- ▶ Briefly press the button on the vehicle key three times in succession.

To switch off the alarm: press any button.

# Indicator light on the interior mirror



The indicator light flashes briefly every 2 seconds:

The alarm system is switched on.

- ▶ Indicator light flashes for approx. 10 seconds, then it flashes briefly every 2 seconds:
  - Interior motion sensor and tilt alarm sensor are not active, as doors, hood, or tailgate are not correctly closed. Correctly closed access points are secured.
  - When the still open access points are closed, the interior motion sensor and tilt alarm sensor will be switched on.
- ➤ The indicator light goes out after unlocking: The vehicle has not been tampered with.
- ➤ The indicator light flashes after unlocking until drive-ready state is switched on, but no longer than approx. 5 minutes:

An alarm has been triggered.

#### Tilt alarm sensor

The tilt of the vehicle is monitored.

The alarm system responds in situations such as attempts to steal a wheel or when the vehicle is towed.

# **Interior motion sensor**

The windows and the glass sunroof must be closed for the system to function properly.

# **Avoiding unintentional alarms**

#### General information

The tilt alarm sensor and interior motion sensor can trigger an alarm, although no unauthorized action occurred.

Possible situations for an unwanted alarm:

- In automatic car washes.
- In duplex garages.
- During transport on trains carrying vehicles, at sea or on a trailer.
- ▶ With animals in the vehicle
- When the vehicle is locked after start of fuel-

The tilt alarm sensor and the interior motion sensor can be switched off in such situations.

#### Switching off the tilt alarm sensor and interior motion sensor



Press the button on the vehicle key within 10 seconds as soon as the vehicle is locked

The indicator light lights up for approx. 2 seconds and then continues to flash.

The tilt alarm sensor and interior motion sensor are switched off until the vehicle is locked again.

# **Ending the alarm**

- ▶ Unlock the vehicle with the vehicle key.
- ▶ Unlock the vehicle with the integrated key and activate the drive-ready state via emergency detection of the vehicle key.
  - Malfunction, refer to page 86.
- ▶ With Comfort Access: when carrying the vehicle key, grasp the driver's door or front passenger door handle completely.

# **Power windows**

#### **General information**

The windows can be opened with the vehicle key from the outside as well as closed with Comfort Access.

With Comfort Access: The windows can be closed from the outside via Comfort Access.

When a window is often opened in the same position, this task can be performed by the BMW Intelligent Personal Assistant, For instance when the same parking garage is frequently used.

Additional information:

- ▶ Vehicle key, refer to page 82.
- ▶ BMW Intelligent Personal Assistant, refer to page 52.

# Safety information



### Marning

When operating the windows, body parts and objects can be jammed. There is a risk of injury or risk of damage to property. Make sure that the area of movement of the windows is clear during opening and closing.

# Overview





Power windows



Safety switch

# **Functional requirements**

The windows can be operated under the following conditions.

- Standby state is switched on.
- ▶ Drive readiness is switched on.

The vehicle key must be in the car's interior.

# **Opening**



Press the switch to the resistance point.

The window opens while the switch is being held.

Press the switch beyond the resistance point.

The window opens automatically. Pressing the switch again stops the motion.

# Closing



Pull the switch to the resistance point.

The window closes while the switch is being held.

Pull the switch beyond the resistance point.

The window closes automatically if the door is closed. Pulling again stops the motion.

# Jam protection system

# **Principle**

The jam protection prevents objects or body parts becoming jammed between the door frame and window while a window is being closed.

#### **General information**

If resistance or a blockage is detected while a window is being closed, the closing action is interrupted.

#### Safety information



#### Warning

Accessories on the windows such as antennas can impact jam protection. There is a risk of injury. Do not install accessories in the area of movement of the windows.

# Closing without the jam protection system

In case of danger from the outside or if ice might prevent normal closing, proceed as follows:

Pull the switch past the resistance point and hold it there.

The window closes with limited jam protection. If the closing force exceeds a specific threshold, closing is interrupted.

Pull the switch past the resistance point again within approx. 4 seconds and hold it there.

The window closes without jam protection.

# Safety switch

# **Principle**

The safety switch can be used to prevent children, for instance from opening and closing the rear windows using the switches in the rear.

If an accident of a certain severity occurs, the safety function is switched off automatically.

# **Turning on/off**



Press the button.

The LED lights up if the safety function is switched on.

# Roller sunblinds, rear side windows

# **Safety information**



#### Warning

With closed roller sunblinds and open windows. the roller sunblinds may be strained while driving due to the wind. The roller sunblinds may be damaged and vehicle occupants may be harmed. There is a risk of injury. Do not open the windows while driving if the roller sunblinds are closed.

Pull out the roller sunblind at the loop and hook it onto the bracket.

# Glass sunroof

#### General information

The glass sunroof and the sun protection are operated using the same switch.

The glass sunroof can be opened from the outside with the vehicle key and also closed with Comfort Access.

With Comfort Access: The glass sunroof can be closed from the outside via Comfort Access.

# **Safety information**



#### Marning

Body parts can be jammed when operating the glass sunroof. There is a risk of injury. Make sure that the area of movement of the glass sunroof is clear during opening and closing.

### Overview





Opening/closing the glass sunroof.

# **Functional requirements**

The glass sunroof and the sun protection can be operated under the following conditions.

- Standby state is switched on.
- Drive readiness is switched on.

The vehicle key must be in the car's interior.

# Lifting/closing glass sunroof



Push switch briefly upward.

- The closed glass sunroof tilts and the sun protection opens slightly.
- The opened glass sunroof closes until it is in the tilted position. The sun protection does not move.
- The tilted glass sunroof closes.

# Opening/closing the glass sunroof and sun protection separately



- Slide switch back to the resistance point and hold.
   Holding down the switch opens the sun protection. If the sun protection is already fully open, the glass sunroof opens.
- Slide switch forward to the resistance point and hold.

The glass sunroof closes while the switch is being held. If the glass sunroof is already closed or in the tilted position, the sun protection closes.

Slide the switch back past the resistance point.

The sun protection opens automatically. If the sun protection is already fully open, the glass sunroof opens automatically.

Pressing the switch again stops the motion.

Push the switch forward past the resistance point.

The glass sunroof closes automatically. If the glass sunroof is already closed or in the tilted position, the sun protection closes automatically.

Pressing the switch again stops the motion.

# Opening/closing the glass sunroof and sun protection together



 Briefly press out the switch twice in succession toward the rear past the resistance point.

The glass sunroof and sun protection are opening together.

- Pressing the switch again stops the motion.
- Briefly press out the switch twice in succession toward the front past the resistance point.

The glass sunroof and sun protection are closing together.

Pressing the switch again stops the motion.

# **Comfort position**

In some models, the wind noises in the car's interior are lowest when the glass sunroof is not fully open. In these models, the automatic function initially only opens the glass sunroof up to this comfort position.

Pressing the switch again opens the glass sunroof fully.

# Jam protection system

#### Concept

The jam protection prevents objects or body parts from becoming jammed between the roof and glass sunroof while the glass sunroof is closing.

#### **General information**

If a resistance or blockage is detected while the glass sunroof is closing, the closing operation is interrupted once the roof reaches the half-open position, or it is stopped when closing from the tilted position.

# Closing from the open position without jam protection

In case of danger from the outside or if icing might prevent normal closing, proceed as follows:



- Close all doors.
- Push the switch forward past the resistance point and hold.
  - The glass sunroof closes with limited jam protection. If the closing force exceeds a specific threshold, closing is interrupted.
- 3. Push the switch forward again past the resistance point and hold until the glass sunroof closes without jam protection. Make sure that the closing path is clear.

# Closing from the lifted position without jam protection

In case of danger from the outside or if icing might prevent normal closing, proceed as follows:



- 1. Close all doors.
- 2. Push the switch forward past the resistance point and hold.

# Initializing after a power interruption

#### **General information**

After a power interruption during the opening or closing process, the glass sunroof can only be operated to a limited extent. Initializing the system can help in this case.

The system can be initialized under the following conditions:

- ▶ The vehicle is parked in a horizontal position.
- ➤ The vehicle will not be moved until the initialization is completed.
- ▶ The drive-ready state is established.
- ▶ The outside temperature is above 41 °F/5 °C.

During initialization, the glass sunroof closes without jam protection.

Make sure that the closing path is clear.

# Initializing the system



Press the switch up and hold it until the initialization is complete:

Initialization begins within 15 seconds.

- ▶ If the glass sunroof is closed, it opens then closes again.
- ▶ If the glass sunroof is open, it first closes, then opens and closes again.

Initialization is complete once the glass sunroof and sun protection have opened then closed again.

# Seats, mirrors and steering wheel

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

# Sitting safely

An ideal seat position that meets the needs of the occupants can make a vital contribution to relaxed, fatique-free driving.

In the event of an accident, the correct seat position plays an important role. Follow the information in the following chapters.

Additional information:

- Seats, refer to page 117.
- ▶ Safety belts, refer to page 123.
- ▶ Head restraints, refer to page 125.
- ▶ Airbags, refer to page 187.

# Seats, front

# General information

The seat setting for the driver's seat is stored for the driver profile currently used. When a driver profile is selected, the stored position is called up automatically.

The current seat position can be stored using the memory function.

# **Safety information**

#### 🗥 Warning

Seat setting while driving can lead to unexpected movements of the seat. Vehicle control could be lost. There is a risk of accident, Only adjust the seat on the driver's side when the vehicle is stationary.



# Marning


With a backrest inclined too far to the rear, the protective effect of the safety belt can no longer be ensured. There is a risk of sliding under the safety belt in an accident. There is a risk of injury or danger to life. Adjust the seat prior to starting the trip. Adjust the backrest so that it is in the most upright position as possible and do not adjust again while driving.



#### Marning


There is a risk of jamming when moving the seats. There is a risk of injury or risk of damage to property. Make sure that the area of movement of the seat is clear prior to any adjustment.

### **Overview**




- 1 Backrest width
- 2 Thigh support
- 3 Forward/backward, height, seat tilt
- 4 Upper backrest
- 5 Backrest tilt, head restraint
- 6 Lumbar support

# **Longitudinal direction**




Press switch forward or backward.

# Height



Press switch up or down.

### **Seat tilt**



Tilt switch up or down.


### **Backrest tilt**



Tilt switch forward or backward.


# **Thigh support**

# **Multifunctional seat**



Push the switch in the front or back.

#### **Sport seat**



Pull the lever at the front of the seat and push the thigh support forward or back.

# Lumbar support

# **Principle**

The curvature of the seat backrest can be adjusted in a way that it supports the lumbar region of the spine. The lower back and the spine are supported for upright sitting position.

# **Adjusting**



Press the front/rear section of the button:

The curvature is increased/ decreased.

Press the upper/lower section of the button:

The curvature is shifted up/down.

# **Backrest width**

# **Principle**

Adjusting the backrest width may improve lateral support when taking corners.

#### **General information**

The backrest width is changed by adjusting the side sections of the backrest.

To make it easier to enter and exit the vehicle, the backrest width temporarily opens fully.

# **Adjusting**



Press the front section of the button:

The backrest width decreases.

Press the rear section of the button:

The backrest width increases.

# **Upper backrest**

#### **Principle**

The upper backrest supports the back in the shoulder region. A correct setting leads to a relaxed seat position and reduces strain on the shoulder muscles.

#### **General information**

If the driver's door is opened when the driveready state is switched off, the upper backrest moves into the basic setting.

# **Adjusting**



Press the front section of the button:
 The upper backrest is inclined forward.

Press the rear section of the button:
 The upper backrest is inclined backward.

# Front passenger seat **functionality**

#### **Principle**

The front passenger seat can be adjusted with the switches of the driver's seat, for instance to increase the legroom in the rear.

If needed, the memory position for the front passenger seat can be stored.

#### Overview





Front passenger seat functionality

# **Turning on**

- Press the button. The LED lights up.
- 2. Adjust the front passenger seat on the driver's seat.
- 3. If needed, store the memory position for the front passenger seat.

# **Turning off**

Press the button. The LED goes out. The function deactivates itself automatically after some time.

# Rear seats

#### Second row of seats

#### General information

The seats of the second row of seats can be adjusted forward and backward including the backrest tilt.

The backrest tilt for the center section is adjusted together with the left rear seat backrest.

# **Safety information**

# Marning

There is a risk of jamming when moving the seats. There is a risk of injury or risk of damage to property. Make sure that the area of movement of the seat is clear prior to any adjust-



# Warning

There is a risk of jamming when folding down the center armrest in the rear. There is a risk of injury. Make sure that the area of movement of the center armrest is clear during folding down.



### Warning

When folding back the second row of seats. there is a danger of jamming. There is a risk of injury or risk of damage to property. Make sure that the area of movement of the second row of seats is clear prior to folding down.




#### Warning

Seats in the second row of seats are not locked when they are folded down and they can move. There is a risk of injury and risk of damage to property. Only fold the seats in the second row down while loading. When driving without a


load, fold back and lock the seats in the second row before driving away.

#### **Overview**



- 1 Resetting to standard position
- 2 Longitudinal direction
- 3 Backrest tilt


### Resetting to standard position



Press the button to reset to standard position.


The process is canceled if the button is pressed again.

# **Longitudinal direction**



Press switch forward or backward.

#### **Backrest tilt**



Tilt switch forward or backward.

#### Access to the third row of seats


# Safety information

#### ▲ Warning

If a rear seat backrest is not locked, unsecured cargo can be thrown about the car's interior; for instance, in the event of an accident, braking or an evasive maneuver. There is a risk of injury. Make sure that the rear seat backrest is locked after folding it back.

#### Fold down rear seat backrest

- 1. Fold middle section of the second seat row up as necessary.
- 2. Push the switch once forward or backward.



The seat automatically moves to the respective end position.

To avoid a collision, the position of the front seats may be adjusted automatically.

If the second row of seats is not locked, an acoustic signal will sound and a warning symbol will be displayed in the instrument cluster.

# Third row of seats

#### General information

The third row of seats consists of two divided seats.

# Fold up the backrest


#### Safety information



#### Marning

If a rear seat backrest is not locked, unsecured cargo can be thrown about the car's interior: for instance, in the event of an accident, braking or an evasive maneuver. There is a risk of injury. Make sure that the rear seat backrest is locked after folding it back.


1. Fold up and engage the backrest.



2. Adjust the head restraint correctly as needed.


#### Fold down rear seat backrest

- 1. Move the head restraints down, refer to page 127.
- 2. Slide the lever forward to unlock the backrest.



Fold the backrest down.

# Exiting from the third row of seats



The second row of seats can be folded down with the switch.

#### Additional information:

Access to the third row of seats, refer to page 121

### **Emergency unlocking rear seat** backrest

#### General information

The two outer backrests of the second seat row can be folded down manually, such as in the event of an electrical fault.

#### Unlocking from the second seat row



Pull the loop and fold the rear seat backrest forward.

#### Unlocking from the third seat row



Pull the loop and fold the rear seat backrest forward.

# Safety belts

# **General information**

The vehicle is fitted with five or seven safety belts to ensure occupant safety. However, they can only unfold their protective effect when adjusted correctly.

Always make sure that safety belts are being worn by the occupants before driving off. The airbags supplement the safety belts as an additional safety device. The airbags do not replace safety belts.

All belt fastening points are designed to achieve the best possible protective effect of the safety belts with proper use of the safety belts and correct seat setting. Notes on sitting safely, refer to page 117.

The two outer safety belt buckles of the second row of seats are intended for the persons sitting on the left and right.

The center safety belt buckle of the second row of seats is intended for the person sitting in the middle.

# **Safety information**



#### Marning

Use of a safety belt to buckle more than one person will potentially defeat the ability of the safety belt to serve its protective function. There is a risk of injury or danger to life. Do not allow more than one person to wear a single safety belt. Infants and children are not allowed on an occupant's lap, but must be transported and secured in designated child restraint systems.

#### Warning

The protective effect of safety gear, including safety belts, can be limited or lost when safety belts are fastened incorrectly. An incorrectly fastened safety belt can cause additional injuries, for instance in the event of an accident. braking or evasive maneuvers. There is a risk of injury or danger to life. Make sure that all occupants are wearing safety belts correctly.

# **⚠** Warning

With a rear backrest that is not locked, the protective effect of the middle safety belt is not guaranteed. There is a risk of injury or danger to life. If you are using the middle safety belt, lock the wider rear seat backrest.

# ⚠ Warning

The protective effect of safety gear, including safety belts, may not be fully functional or fail in the following situations:

- The safety belts or safety belt buckles are damaged, soiled, or changed in any other way.
- ➤ Seat belt tensioners or belt retractors were modified.

Safety belts can be imperceptibly damaged in the event of an accident. There is a risk of injury or danger to life. Do not modify safety belts, safety belt buckles, seat belt tensioners, belt retractors or belt anchors and keep them clean. Have the safety belts checked after an accident at the dealer's service center or another qualified service center or repair shop.

# **Correct use of safety belts**

- ▶ Wear the safety belt twist-free and tight to your body over your lap and shoulders.
- Wear the safety belt deep on your hips over your lap. The safety belt may not press on your stomach.
- Do not rub the safety belt against sharp edges, or guide it or jam it in across hard or fragile objects.
- Avoid thick clothing.
- ▶ Re-tighten the safety belt frequently upward around your upper body.

# **Buckling the safety belt**

- 1. Guide the safety belt slowly over shoulder and hip to put it on.
- Insert the tongue plate into the safety belt buckle. The safety belt buckle must engage audibly.



To ease accessibility to the safety belt buckle, an adjustable slider is available on the belt to help position the buckle when not in use.

When the safety belt is fastened, the driver's and front passenger's belt straps are automatically tightened once after driving away.

# Unbuckling the safety belt

- 1. Hold the safety belt firmly.
- 2. Press the red button in the safety belt buckle.
- 3. Guide the safety belt back into its roll-up mechanism.

# Safety belt reminder for driver's seat and front passenger seat

#### **General information**

The safety belt reminder is issued when the driver's safety belt is not buckled.

The safety belt reminder is also active when the front passenger seat belt is not buckled or objects are on the front passenger seat.

The safety belt reminder is also activated when a passenger unbuckles a safety belt during the trip.

# Display in the instrument cluster



The indicator light lights up and a signal sounds. Make sure that the safety belts are positioned correctly. The safety belt

reminder can also be activated if objects are placed on the front passenger seat.

# Safety belt reminder for rear seats

#### **General information**

The safety belt reminder is automatically activated each time the engine starts.

The safety belt reminder is also activated when a passenger unbuckles a rear seat safety belt during the trip.

#### Display in the instrument cluster

The indicator light in the instrument cluster illuminates after the engine is started.

The displays may vary depending on the equipment version and country variant.

#### Icon

#### **Description**



Green: the safety belt is buckled on the corresponding rear seat.





Red: the safety belt is not buckled on the corresponding rear seat.



# Safety mode

In critical driving situations, for instance during emergency braking, the front safety belts tighten automatically.

If the driving situation passes without an accident occurring, the belt tension relaxes.

If the belt tension does not loosen automatically, stop the vehicle and unbuckle the safety belt using the red button in the safety belt buckle. Fasten the safety belt before continuing on your trip.

# Front head restraints

#### **General information**

The current head restraint position can be stored using the memory function.

# **Safety information**

#### Warning

Removal or incorrect adjustment of head restraints can cause injuries in the head and neck area. There is a risk of injury.

- ▶ Before driving, install the removed head restraints on the occupied seats.
- > Adjust the head restraint so its center supports the back of the head at as close to eye level as possible.
- > Adjust the distance so that the head restraint is as close as possible to the back of the head. Adjust the distance via the backrest tilt as needed.



#### Marning

Body parts can be jammed when moving the head restraint. There is a risk of injury. Make sure that the area of movement is clear when moving the head restraint.

#### Marning

Objects on the head restraint reduce the protective effect in the head and neck area. There is a risk of injury.

- > Do not use seat or head restraint covers.
- ▶ Do not hang objects, for instance clothes hangers, directly on the head restraint.
- Only use accessories that have been determined to be safe for attachment to a head restraint.
- ▶ Do not use any accessories, for instance pillows, while driving.

#### **Active head restraint**

In the event of a rear-end collision with a certain severity, the active head restraint automatically reduces the distance from the head.

Have the active head restraint checked and if necessary replaced in the case of damage or if it was exposed to an accident.

# Adjusting the height



Press switch up or down.

# **Adjusting distance**



- Back: press the button and push the head restraint toward the rear.
- Forward: pull the head restraint toward the front.

After setting the distance, make sure that the head restraint engages correctly.

# Adjusting the side extensions



Fold the side extensions on the head restraint forward for increased lateral support in the resting position.

# Removing

The head restraints cannot be removed.

# Rear head restraints

# **Safety information**

#### 🛕 Warning

Removal or incorrect adjustment of head restraints can cause injuries in the head and neck area. There is a risk of injury.

- ▶ Before driving, install the removed head restraints on the occupied seats.
- > Adjust the head restraint so its center supports the back of the head at as close to eye level as possible.
- > Adjust the distance so that the head restraint is as close as possible to the back of the head. Adjust the distance via the backrest tilt as needed.

# Marning

Body parts can be jammed when moving the head restraint. There is a risk of injury. Make sure that the area of movement is clear when moving the head restraint.


# Warning

Objects on the head restraint reduce the protective effect in the head and neck area. There is a risk of injury.

- ▶ Do not use seat or head restraint covers.
- > Do not hang objects, for instance clothes hangers, directly on the head restraint.
- > Only use accessories that have been determined to be safe for attachment to a head restraint.
- ▶ Do not use any accessories, for instance pillows, while driving.

# Folding down the head restraints

To improve the view to the rear, the outside head restraints can be folded back. Only fold the head restraint back if no one will be sitting in the corresponding seat.



- ▶ To the rear: press the button, arrow 1, and fold the head restraint backward.
- > Forward: fold the head restraint toward the front as far as it will go. Make sure that the head restraint engages correctly.

# Adjusting the height



- ▶ To lower: press the button, arrow 1, and push the head restraint down.
- ▶ To raise: push the head restraint up.

After setting the height, make sure that the head restraint engages correctly.

# Removina

The head restraints cannot be removed.

# Cushions for head restraints in the rear

Only use the pillow when the vehicle is switched off.

- 1. Bring the head restraint to a sufficiently high position.
- 2. Attach the pillow and place the pillow band around the back of the head restraint, arrow 1.



3. Close pushbuttons, arrow 2.

# **Exterior mirrors**

#### General information

The mirror on the front passenger side is more curved than the driver's side mirror.

The mirror setting is stored for the driver profile currently in use. When a driver profile is selected, the stored position is called up automatically.

The current exterior mirror position can be stored using the memory function.

# **Safety information**



#### Marning

Objects reflected in the mirror are closer than they appear. The distance to the road users behind could be incorrectly estimated, for instance while changing lanes. There is a risk of accident. Estimate the distance to the traffic behind by looking over your shoulder.

#### Overview



- Adjusting
- Selecting a mirror, Automatic Curb Monitor
- 3 Folding in and out

# Adjusting electrically



Press the button.

The selected mirror moves along with the button movement.

# Selecting a mirror



To change over to the other mirror: Slide the switch.

# Malfunction

In case of an electrical malfunction, adjust the mirror by pressing the edges of the mirror glass.

# Folding in and out



#### ∧ NOTICE

Depending on the vehicle width, the vehicle can be damaged in car washes. There is a risk of damage to property, among other potential damage. Before washing, fold in the mirrors by hand or with the button.



Press the button.

Folding is only possible up to a speed of approx. 15 mph/20 km/h.

Folding the mirrors in and out is helpful in the following situations:

- In car washes.
- On narrow roads.

Mirrors that were folded in are folded out automatically at a speed of approx. 25 mph/40 km/h.

# **Automatic heating**

Both exterior mirrors are automatically heated as needed and when the drive-ready state is switched on.

# **Automatic dimming feature**

The exterior mirror on the driver's side is automatically dimmed. Photocells in the interior mirror are used to control this.

#### **Automatic Curb Monitor**

# **Principle**

If reverse gear is engaged, the mirror glass on the front passenger side is tilted downward. This improves your view of the curb and other low-lying obstacles when parking, for instance.

# **Activating**

- 1. slide the switch to the driver's side mirror position.
- 2. Engage selector lever position R.

When the trailer socket is in use or trailer towing is activated, the Automatic Curb Monitor is deactivated.

# **Deactivating**

Slide the switch to the front passenger's side mirror position.

# **Interior mirror**


#### **General information**

The interior mirror is dimmed automatically.

Photocells are used for control:

- ▶ In the mirror glass.
- ▶ On the rear of the mirror.

#### **Overview**



# **Functional requirements**

- ▶ Keep the photocells clean.
- ▶ Do not cover the area between the interior mirror and the windshield.

# Steering wheel

# **Safety information**



Steering wheel adjustments while driving can lead to unexpected steering wheel movements. Vehicle control could be lost. There is a risk of accident. Adjust the steering wheel while the vehicle is stationary only.

# **Electric steering wheel** adjustment

#### General information

The steering wheel adjustment is stored for the driver profile currently in use. When a driver profile is selected, the position is accessed automatically when the drive-ready state is switched on.

The current steering wheel position can be stored using the memory function.

To make it easier to enter and exit the vehicle, the steering wheel moves temporarily into the upper position.

# **Adjusting**



Press the switch to adjust the forward/back position and height of the steering wheel to the seat position.

# Steering wheel heating

#### Overview



Button for steering wheel heating

# **Turning on/off**



Press the button.

A Check Control message is displayed.

If the trip is resumed within approx. 15 minutes after an intermediate stop, the steering wheel heating turns on automatically if the function was turned on at the completion of the last trip.

# **Memory function**

# **Principle**

The following settings can be stored and, if necessary, retrieved using the memory function:

- Seat position.
- Exterior mirror position.
- Steering wheel position.
- ▶ Height of the Head-up Display.

# General information

Two memory locations with different settings can be set for each driver profile.

The following settings are not stored:

- Backrest width.
- Lumbar support.

# **Safety information**



### Marning

Using the memory function while driving can lead to unexpected seat or steering wheel movements. Vehicle control could be lost. There is a risk of accident. Only retrieve the memory function when the vehicle is stationary.



#### Marning

There is a risk of jamming when moving the seats. There is a risk of injury or risk of damage to property. Make sure that the area of movement of the seat is clear prior to any adjustment.

### Overview



The memory buttons are located on the front doors.

# **Storing**

- 1. Set the desired position.
- Press the button. The writing on the button lights up.
- 3. Press desired button 1 or 2 while the LED is lit. A signal sounds.

# Calling up settings

Press the desired button 1 or 2.

The stored position is called up.

The procedure stops when a switch for setting the seat is pressed or one of the memory buttons is pressed again.

The adjustment of the seat position on the driver's side is interrupted after a short time while driving.

# **Massage function**

# **Principle**

Depending on the program, the massage function ensures relaxed muscles and better blood circulation and can avoid fatique.

#### General information

Eight different massage programs can be selected:

- Hip activation.
- Upper-body activation.
- Whole body activation.
- Back massage.
- ▶ Shoulder massage.
- Lumbar massage.
- Upper body training.
- Whole-body exercise.

#### **Overview**





Massage function

# **Turning on**



Press the button once for each intensity

The maximum intensity level is reached when three LEDs are lit.

# **Turning off**



Press and hold the button until the LEDs turn off

# Adjusting the massage program

- 1. "CAR"
- 2. "Settings"
- "Seat comfort"
- 4. Select desired seat.
- "Seat massage"
- 6. Select the desired setting.

# **Seat and armrest heating**

# **Principle**

The system heats seats and armrests as needed.

#### **General information**

Seat heating can also be used without armrest heating. Deactivate the armrest heating as needed.

#### **Overview**

#### **Front**





Seat and armrest heating

#### Rear





Seat heating

# **Turning on**

- 1. Press the button.
- 2. Select the temperature level:
  - Press the button once for each level.
  - ➤ Turn the Controller until the desired level is reached. Press the Controller.
  - Select the desired level on the touchscreen.

Highest level reached when three red LEDs light up on the button or three red bars are shown on the Control Display.

If the trip is continued within approx. 15 minutes after a stop, the functions are switched on automatically with the temperature selected last.

When ECO PRO is activated, the heating output is reduced.

Additional information:

ECO PRO, refer to page 341.

# **Turning off**



Press and hold the button, until the LEDs turn off.

# **Seat heating distribution**

The heating effect in the seat cushion and the seat backrest can be distributed in different ways.

- 1. "CAR"
- 2. "Settings"
- 3. "Climate control"
- 4. Select the desired menu item.
- Select desired seat.
- Press the Controller and turn it to set the seat heating distribution.

# Switching armrest heating on/off

- 1. "CAR"
- 2. "Settings"
- 3. "Climate control"
- 4. "Seat and armrest heating"
- 5. Select desired seat.
- 6. "Heat armrests with seat"

# **Active seat ventilation**

# **Principle**

Integrated fans in the seat and armrest areas provide a comfortable seat temperature.

# **Overview**





Active seat ventilation

# **Turning on**



- Press the button.
- 2. Select the ventilation level:
  - Press the button once for each level.
  - ➤ Turn the Controller until the desired level is reached. Press the Controller.
  - Select the desired level on the touchscreen.

Highest level reached when three blue LEDs light up on the button or three blue bars are shown on the Control Display.

# **Turning off**



Press and hold the button, until the LEDs turn off.

# **Seat climate control**

# **Principle**

The seat climate control combines the functions of the seat heating and active seat ventilation.


# **General information**

The seat heating and active seat ventilation are operated with a common button on the climate control panel.

When both systems are active, a push of the button reduces the intensity of both functions by one level each.

The last active function or function that is configured with higher intensity will be activated directly when the system is switched on again. When both functions with the same intensity configuration are deactivated, the system will automatically activate the seat heating.

#### **Overview**





Seat climate control

# **Turning on**

- 1. 4
- Press the button.
- Select the desired setting via the touchscreen.

One red and one blue LED each will illuminate.

# **Turning off**



Press and hold the button, until the LEDs turn off

# **Climate control rules**

# **Principle**

Depending on the equipment, some heating and cooling functions can be automatically activated depending on the outside temperature.

# **General information**

The outside temperature at which the functions are to be automatically activated can be set via iDrive.

Activation is performed if the outside temperature exceeds or falls below the set temperature in the first few minutes after drive-ready state has been switched on. A new alignment is carried out after the settings have been changed.

Depending on the equipment package, the following functions can be automatically activated:

- Seat heating.
- Steering wheel heating
- Seat ventilation.

If the trip is continued within approx. 15 minutes after a stop, the functions are activated automatically with the levels that were last selected.

# **Functional requirement**

Drive-ready state is switched on.

# Activate/deactivate

- 1. "CAR"
- 2. "Settings"
- 3. "Climate control"
- 4. If necessary, "Automate habits"
- Select the desired function.
- 6. Activate the desired rule.
- 7. Set the level.

# Transporting children safely

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

# The right place for children

# **Safety information**

#### Marning

Unattended children or animals in the vehicle can cause the vehicle to move and endanger themselves and traffic, for instance due to the following actions:

- ▶ Pressing the Start/Stop button.
- ▶ Releasing the parking brake.
- > Opening and closing the doors or windows.
- ▶ Engaging selector lever position N.
- ▶ Using vehicle equipment.

There is a risk of accidents or injuries. Do not leave children or animals unattended in the vehicle. Take the vehicle key with you when exiting and lock the vehicle.

#### Marning

A heated vehicle may result in death to persons, especially children, or animals. There is a risk of injury or danger to life. Do not leave persons, especially children, or animals unattended in the vehicle.

### Warning

Exposure to intense sunlight can cause child restraint systems and their components to become very hot. Persons may sustain burn injuries when touching the hot components. There is a risk of injury. Do not expose the child restraint system to direct sunlight or cover where necessary. If necessary, let the child restraint system cool down before transporting a child. Do not leave children unattended in the vehicle.

# Transport children in the rear seat

#### General information

Accident research shows that the safest place for children is in the rear seat.

Children younger than 13 years of age or shorter than 5 ft/150 cm should be transported in the rear seat in suitable child restraint systems designed for the age, weight and size of the child. Children 13 years of age or older must wear a safety belt as soon as a suitable child restraint system can no longer be used due to their age, weight, or size.

# **Safety information**

#### Warning

The safety belt cannot be fastened correctly on children shorter than 5 ft. 150 cm without suitable additional child restraint systems. The protective effect of safety gear, including safety belts, can be limited or lost when safety belts are fastened incorrectly. An incorrectly fastened safety belt can cause additional injuries, for instance in the event of an accident, braking or evasive maneuvers. There is a risk of injury or danger to life. Secure children shorter than 5 ft, 150 cm using suitable child restraint systems.

# Children on the front passenger seat

#### General information

Before using a child restraint system on the front passenger seat, ensure that the front, knee, and side airbags on the front passenger side are deactivated.

Additional information:

For automatic deactivation of front passenger airbags, refer to page 190.

# **Safety information**



#### Warning

Active front passenger airbags can injure a child in a child restraint system when the airbags are activated. There is a risk of injury. Make sure that the front passenger airbags are deactivated and that the PASSENGER AIRBAG OFF indicator light lights up.

# **Installing child restraint systems**

#### General information

Pay attention to the specifications and the operating and safety information of the child restraint system manufacturer when selecting, installing. and using child restraint systems.

# Safety information



### Warning

The protective effect of child restraint systems and their fastening systems which have been damaged or exposed to an accident can be limited or lost. A child cannot be properly restrained in the event of an accident, braking or evasive maneuvers. There is a risk of injury or danger to life.

Do not use child restraint systems which have been damaged or exposed to an accident.

If a child restraint system and its fastening system has been damaged or exposed to an accident, have these systems checked and replaced by the dealer's service center or another qualified service center or repair shop.



#### Marning

The stability of the child restraint system is limited or compromised with incorrect seat setting or improper installation of the child seat. There is a risk of injury or danger to life. Make sure that the child restraint system fits securely against the backrest, If possible, adjust the backrest tilt for all affected backrests and correctly adjust the seats. Make sure that seats and backrests are securely engaged or locked. If possible, adjust the height of the head restraints or remove them.

# **Before mounting**

Before mounting child restraint systems, ensure that the rear seat backrests are locked.

Move the rear seats into the rearmost position to facilitate assembly of the child restraint system.

#### Third row of seats

Before installing a child restraint system in the third row of seats, note the following:

- Roll up the cargo cover and remove the case.
- ▶ Depending on the equipment version: lower the electric cargo cover.
- ▶ Remove the cargo area partition net.
- ▶ Bring seats and backrests of the second row of seats into the most forward position.
- ▶ Fold down the respective backrest of the second row of seats and lock.
- Raise the head restraints of the third row of seats into the highest position.

Do not change the settings that have been made after this.

# On the front passenger seat

# **Deactivating airbags**



Active front passenger airbags can injure a child in a child restraint system when the airbags are activated. There is a risk of injury. Make sure that the front passenger airbags are deactivated and that the PASSENGER AIRBAG OFF indicator light lights up.

Before installing a child restraint system in the front passenger seat, make sure that the front, knee and side airbags on the front passenger side are deactivated.

Additional information:

For automatic deactivation of front passenger airbags, refer to page 190.

#### Seat position and height

After installing a child restraint system, move the front passenger seat as far back as it will go and, if possible, bring it up to the highest position.

This seat position and height ensure the best possible position for the belt and offers optimal protection in the event of an accident.

If the upper attachment point of the safety belt is located in front of the belt guide of the child seat, move the front passenger seat carefully forward until the best possible belt guide position is reached.

#### **Backrest width**

Adjustable backrest width: before installing a child restraint system in the front passenger seat, open the backrest width completely. Do not change the backrest width again and do not call up a memory position.

# **Child seat security**



The safety belts in the rear and the front passenger safety belt can be permanently locked to fasten child restraint systems.

# Locking the safety belt

- 1. Pull out the belt strap completely.
- 2. Secure the child restraint system with the safety belt.
- Allow the belt strap to be pulled in and pull it tight against the child restraint system. The safety belt is disabled.

# Unlocking the safety belt

- 1. Unbuckle the safety belt buckle.
- 2. Remove the child restraint system.
- 3. Allow the belt strap to be pulled in completely.

# LATCH child seat mountings

### **General information**

LATCH: Lower Anchors and Tether for Children.

Pay attention to the specifications and the operating and safety information from the child restraint system manufacturer when selecting, installing, and using LATCH child restraint fixing systems.

# Mounts for the lower LATCH anchors

#### General information

The lower anchors may be used to attach the CRS to the vehicle seat up to a combined child and CRS weight of 65 lbs/30 kg when the child is restrained by the internal harnesses.

# Safety information



#### Warning

If the LATCH child restraint fixing systems are not correctly engaged, the protective effect of the LATCH child restraint fixing system is limited. There is a risk of injury or danger to life. Make sure that the lower mountings are securely engaged and that the LATCH child restraint fixing system fits securely against the backrest.

#### ⚠ Warning

The attachment points for child restraint systems in the vehicle are intended for attaching child restraint systems only. When other obiects are mounted, the attachment points can be damaged. There is a risk of injury or risk of damage to property. Attach only child restraint systems at the corresponding attachment points.

#### **Position**

#### Icon

#### Meaning



The corresponding icon shows the mounts for the lower LATCH anchors.

Seats equipped with lower mountings are marked with a pair, (2), of LATCH symbols.

For vehicles equipped with a middle seat:

It is not recommended to use the inner lower mountings of standard outer LATCH positions to fasten a child restraint system on the middle seat. Use the vehicle safety belt instead for the middle seat.

# Before installing LATCH child restraint fixing systems

Pull the safety belt away from the area of the child seat mountings.

# Assembly of LATCH child restraint fixing systems

- 1. Install child restraint system, see manufacturer's information.
- 2. Ensure that both LATCH anchors are properly engaged.

# Child restraint systems with tether strap

# **Safety information**

# ⚠ Warning

If the upper retaining strap is incorrectly used for the child restraint system, the protective effect is reduced. There is a risk of injury. Make sure that the upper retaining strap does not run over sharp edges and is not twisted as it passes the upper anchor.

# ▲ Warning

If the rear backrest is not locked, the protective effect of the child restraint system is limited or there is none. In certain situations, for instance braking maneuvers or in case of an accident, the rear backrest can fold forward. There is a risk of injury or danger to life. Make sure that the rear backrests are locked.

# ▲ Warning

The attachment points for child restraint systems in the vehicle are intended for attaching child restraint systems only. When other objects are mounted, the attachment points can be damaged. There is a risk of injury or risk of damage to property. Attach only child restraint systems at the corresponding attachment points.

# **Attachment points**




Icon

The respective icon shows the attachment point for the upper retaining strap. Seats with an upper top tether are marked with this icon. It is located on the rear seat backrest, the rear shelf or the rear seat.

# Routing the retaining strap

Meaning



- 1 Driving direction
- 2 Head restraint
- 3 Hook for upper retaining strap
- 4 Attachment point
- 5 Seat backrest
- 6 Upper retaining strap

# Attaching the upper retaining strap to the attachment point

- 1. Bring the seat of the second seat row into the base position.
  - Reset to base position, refer to page 121.
- 2. Raise the head restraint, if needed.
- Guide the upper retaining strap between or along both sides of the supports for the head restraint to the attachment point.
  - Middle seat: raise the head restraint, if needed, press the button on the mounts for this purpose. Guide the upper retaining strap

- between or along both sides of the supports of the head restraint to the attachment point.
- 4. If there is a retaining strap, run it between the backrest and the cargo cover.
- Hook the hook of the retaining strap to the attachment point.
- 6. Tighten the retaining strap by pulling it down.
- 7. Lower and engage head restraint as needed.

# Locking the doors and windows in the rear

#### **General information**

In certain situations it may be advisable to secure the rear doors and windows, for instance when transporting children.

#### **Doors**



Push the locking lever on the rear doors up.

The door can now be opened from the outside only.

# Safety switch for the rear



Press the button on the driver's door.

This disables various functions so that they cannot be operated from the rear.

Additional information:

Safety switch, refer to page 113.

# **Driving**

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

# **Start/Stop button**

# **Principle**



Pressing the Start/Stop button switches drive-ready state on or off.

Drive readiness is switched on when you depress the brake

pedal while pressing the Start/Stop button.

Pressing the Start/Stop button again switches the drive-ready state back off and standby state is switched back on.

Additional information:

- Drive-ready state, refer to page 42.
- Standby state, refer to page 42.

# **Driving away**

- 1. Turn on drive readiness.
- 2. Apply gear position.
- 3. Release the parking brake.
- 4. Drive away.

# **Auto Start/Stop function**

# **Principle**

The Auto Start/Stop function helps save fuel. The system switches off the engine during a stop, for instance in traffic jam or at traffic lights. Drive-ready state remains switched on. The engine starts automatically for driving off.

Additional information:

Coasting, refer to page 343.

#### **General information**

After each engine start using the Start/Stop button, the Auto Start/Stop function is ready. The function is activated from speeds of approx. 3 mph/5 km/h.

Depending on the selected driving mode, the system is automatically activated or deactivated.

# **Engine stop**

# **Functional requirements**

### Steptronic transmission

The engine is switched off automatically during a stop under the following conditions:

- The selector lever is in selector lever position
- The brake pedal remains depressed while the vehicle is stationary or the vehicle is held by Automatic Hold.
- ➤ The driver's safety belt is buckled or the driver's door is closed.

# Manual engine stop

If the engine was not switched off automatically when the vehicle stopped, the engine can be switched off manually:

- ▶ Depress the brake pedal forcefully again from the current pedal position.
- ▶ Engage selector lever position P.

When all functional preconditions are fulfilled, the engine switches off.

# Air conditioning system when the engine is switched off

The air flow from the air conditioning system is reduced when the engine is switched off.

# Displays in the instrument cluster

#### **General information**



The display in the instrument cluster indicates that the Auto Start/Stop function is ready for an automatic engine start.



The display indicates that the conditions for an automatic engine stop have not been met.

#### Total time with switched-off engine



ECO PRO driving mode: depending on the vehicle equipment, the total time that the engine has been switched off using the Auto Start/Stop function is displayed

on an automatic engine stop.

The total time can be reset via the trip data.

Additional information:

ECO PRO, refer to page 341.

#### **Functional limitations**

The engine is not switched off automatically in the following situations:

- ▶ In case of a steep downhill grade.
- Brake not engaged strongly enough.

- ➤ The outside temperature is high and automatic climate control is running.
- The car's interior has not yet been heated or cooled to the required level.
- Where there is a risk of window condensation when the automatic climate control is switched on.
- ▶ Engine or other parts not at operating temperature.
- ▶ Engine cooling is required.
- ➤ The wheels are at a sharp angle or the steering wheel is being turned.
- Vehicle battery is heavily discharged.
- ▶ At higher elevations.
- Hood is unlocked.
- ▶ HDC Hill Descent Control is activated.
- ▶ The Automatic Parking Assistant is activated.
- Stop-and-go traffic.
- ▶ Selector lever position in N or R.
- ▶ After driving in reverse.
- ▶ Use of fuel with high ethanol content.

# Starting the engine

# **Functional requirements**

#### Steptronic transmission

The engine starts automatically under the following preconditions:

- By releasing the brake pedal.
- ▶ When Automatic Hold is activated: step on the accelerator pedal.

# **Driving off**

After the engine starts, accelerate as usual.

# Safety mode

After the engine switches off automatically, it will not start again automatically if any one of the following conditions are met:

- ➤ The driver's safety belt is unbuckled and the driver's door is open.
- ▶ Hood was unlocked.

Some indicator lights light up for a varied length of time.

The engine can only be started via the Start/Stop button.

# **System limits**

Even if driving off was not intended, the deactivated engine starts up automatically in the following situations:

- ▶ In case of excessive warming of the interior when air conditioning is turned on.
- ▶ In case of excessive cooling of the interior when the heating is turned on.
- In case of a risk of window condensation when the automatic climate control is turned on.
- ▶ In case of a steering operation.
- ▶ When changing from gear lever position D to N or R
- When changing from gear lever position P to N, D, or R.
- ▶ In case of seriously discharged vehicle battery.
- ▶ When starting an oil level measurement.

# Without Mild-Hybrid technology: additional functions Auto Start/ Stop

Depending on the vehicle equipment and country-specific version, the vehicle features a variety of sensors for assessing the traffic situation. The Auto Start/Stop function uses this information to adapt to various traffic situations in a proactive manner.

For instance, this applies to the following situations:

When a situation is detected in which the stopping time is expected to be very short, the engine is not switched off automatically.

- A message appears on the Control Display, depending on the situation.
- ▶ When a situation is detected in which the vehicle needs to drive off immediately, the engine is started automatically.

The function may be restricted if the navigation data is invalid, outdated or not available, for example.

# Activating/deactivating the system manually

#### **Principle**

The engine is not automatically switched off.

The engine is started during an automatic engine stop.

# Without Mild-Hybrid technology: via button



(A)OFF

Press the button.

# Via selector lever position or Driving Dynamics Control

The Auto Start/Stop function is also deactivated in selector lever position M/S or in SPORT driving mode of the Driving Dynamics Control.

# Without Mild-Hybrid technology: display

- ▶ LED comes on: auto Start/Stop function is deactivated.
- LED goes out: auto Start/Stop function is activated.

# Switching off the vehicle during an automatic engine stop

### **General information**

During an automatic engine stop, the vehicle can be switched off permanently, for instance when leaving it.

# **Steptronic transmission**

- 1. Press the Start/Stop button.
  - ▶ Drive-ready state is switched off.
  - > Standby state is switched on.
  - Selector lever position P is engaged automatically.
- 2. Set the parking brake.

#### **Automatic deactivation**

#### General information

In certain situations, the Auto Start/Stop function is deactivated automatically for safety reasons, for instance if no driver is detected.

#### **Malfunction**

The Auto Start/Stop function no longer switches off the engine automatically. A Check Control message is displayed. It is possible to continue driving. Have the system checked by a dealer's service center or another qualified service center or repair shop.

# **Driving Dynamics Control**

# **Principle**

The Driving Dynamics Control influences the driving dynamics properties of the vehicle.

The vehicle can be adjusted depending on the situation using various driving modes.

# **General information**

The following systems are affected, for instance:

- ▶ Engine characteristics.
- ▶ Steptronic transmission.
- Steering.
- Integral Active Steering.
- Adaptive M chassis.
- Adaptive M Chassis Professional.
- ➤ Two-axle ride level control.
- Display in the instrument cluster.
- Cruise control.

#### **Overview**



# Displays in the instrument cluster



The selected driving mode is displayed in the instrument cluster.

# **Driving modes**



Buttons in the vehicle

Button	Driving mode	Configura- tion
SPORT	SPORT	INDIVIDUAL
SPORT	SPORT PLUS	

Button	Driving mode	Configura- tion
COMFORT	COMFORT	
ECO PRO	ECO PRO	INDIVIDUAL
ADAPTIVE	ADAPTIVE	

When drive-ready state is switched on, the COMFORT driving mode is selected automatically.

# **Driving modes in detail**

#### **COMFORT**

#### **Principle**

The COMFORT driving mode is a balanced setting between sporty and consumption optimized driving.

#### **Turning on**



Press the button repeatedly until COM-FORT is displayed in the instrument

cluster.

#### **SPORT**

#### **Principle**

The SPORT driving mode is a dynamic setting for more agility with an optimized suspension.

#### **Turning on**



Press the button repeatedly until SPORT is displayed in the instrument

cluster.

#### SPORT INDIVIDUAL

#### **Principle**

In the SPORT INDIVIDUAL driving mode, individual settings can be adjusted to support driving dynamics properties.

#### Configuration

- 1. "CAR"
- 2. "Settings"
- 3. "Driving mode"
- 4. "SPORT INDIVIDUAL"
- Select the desired setting.

Reset SPORT INDIVIDUAL to the standard settings:

"Reset to SPORT STANDARD".

#### SPORT PLUS

#### **Principle**

The SPORT PLUS driving mode is a dynamic setting for maximum agility with an adjusted drive.

#### Turning on



Press the button repeatedly until SPORT PLUS is displayed in the instrument cluster.

#### **ECO PRO**

#### Concept

In ECO PRO drive mode, consumption is optimized.

#### Turning on



Press the button repeatedly until ECO PRO is displayed in the instrument clus-

ter.

#### **ECO PRO INDIVIDUAL**

#### **Principle**

In the ECO PRO INDIVIDUAL driving mode, individual settings can be adjusted to support an economical driving style.

The engine control and comfort features, for instance the climate control output, are adjusted.

#### Configuration

- 1. "CAR"
- 2. "Settings"
- 3. "Driving mode"
- 4. "FCO PRO INDIVIDUAL"
- 5. Select the desired setting.

Reset ECO PRO INDIVIDUAL to the standard settings:

"Reset to ECO PRO STANDARD".

#### **ADAPTIVE**

#### **Principle**

The ADAPTIVE driving mode is a balanced driving mode that automatically adapts to the driving situation and driving style.

If the navigation system is active, upcoming road sections are considered.

#### Switching on



Press the button. ADAPTIVE is displayed in the instrument cluster.

# **INDIVIDUAL** configuration

#### **General information**

The last individual configuration is activated directly when the driving mode is called up again.

#### **Activating configuration of the drive** mode

Press the button for the desired drive mode several times.

# **Parking brake**

### **Principle**

The parking brake is used to prevent the vehicle from rolling when it is parked.

# **Safety information**

#### Marning

An unsecured vehicle can begin to move and possibly roll away. There is a risk of accident. Before exiting, secure the vehicle against rolling.

In order to ensure that the vehicle is secured against rolling away, follow the following:

- Set the parking brake.
- > On uphill grades or on a downhill slope, turn the front wheels in the direction of the curh
- > On uphill grades or on a downhill slope, also secure the vehicle, for instance with a wheel chock.



#### Marning

Unattended children or animals in the vehicle can cause the vehicle to move and endanger themselves and traffic, for instance due to the following actions:

- Pressing the Start/Stop button.
- ▶ Releasing the parking brake.
- > Opening and closing the doors or windows.
- ▶ Engaging selector lever position N.
- ▶ Using vehicle equipment.

There is a risk of accidents or injuries. Do not leave children or animals unattended in the vehicle. Take the vehicle key with you when exiting and lock the vehicle.

#### **Overview**





Parking brake

# Setting

#### With a stationary vehicle



Pull the switch.

The LED liahts up.



The indicator light in the instrument cluster illuminates red. The parking brake is set.

#### While driving

#### **General information**

To use as emergency brake while driving.



Pull the switch and hold it. The vehicle brakes hard while the switch is being pulled.



The indicator light in the instrument cluster illuminates red, a signal sounds, and the brake lights illuminate.

A Check Control message is displayed.

The parking brake is engaged when the vehicle is stationary.

#### With Emergency Stop Assistant



Pull the switch briefly to activate the emergency stop function.

Additional information:

Emergency Stop Assistant, refer to page 217.

### Releasing

#### Releasing manually

- Turn on drive readiness.
- Press the switch while stepping on the brake pedal or selector lever position P is set. The LED and indicator light turn off.

The parking brake is released.

#### Automatic release

The parking brake is released automatically when you drive away.

The LED and indicator light turn off.

#### **Automatic Hold**

#### **Principle**

Automatic Hold assists the driver by automatically setting and releasing the brake, such as when moving in stop-and-go traffic.

The vehicle is automatically held in place when it is stationary.

On uphill grades the system prevents the vehicle from rolling back when driving off.

#### **General information**

Under the following conditions, the parking brake is automatically engaged:

- Drive-ready state is switched off.
- ▶ The driver's door is opened while the vehicle is stationary.
- ▶ The moving vehicle is brought to a standstill using the parking brake.

#### **Safety information**

#### Marning

An unsecured vehicle can begin to move and possibly roll away. There is a risk of accident. Before exiting, secure the vehicle against rolling.

In order to ensure that the vehicle is secured against rolling away, follow the following:

- Set the parking brake.
- > On uphill grades or on a downhill slope. turn the front wheels in the direction of the curb.
- > On uphill grades or on a downhill slope, also secure the vehicle, for instance with a wheel chock.

#### **△** Warning

Unattended children or animals in the vehicle can cause the vehicle to move and endanger themselves and traffic, for instance due to the following actions:

- ▶ Pressing the Start/Stop button.
- Releasing the parking brake.
- > Opening and closing the doors or windows.
- ▶ Engaging selector lever position N.
- ▶ Using vehicle equipment.

There is a risk of accidents or injuries. Do not leave children or animals unattended in the vehicle. Take the vehicle key with you when exiting and lock the vehicle.



#### **⚠** NOTICE

If the vehicle is stationary, Automatic Hold engages the parking brake and prevents the vehicle from rolling in a car wash. There is a risk of damage to property, among other potential

damage. Deactivate Automatic Hold prior to entering the car wash.

#### Overview



AUTO H

Automatic Hold

#### **Establishing operational readiness** of Automatic Hold

1. Turn on drive readiness.



Press the button

The LED lights up.



The indicator light lights up green.

Automatic Hold is functional.

After every vehicle restart, the last selected setting is active.

#### **Automatic Hold holding the vehicle**

Operational readiness is established and the driver's door is closed.



After the brake is applied, the vehicle is kept from rolling as soon as the indicator light illuminates green.

### **Driving off**

Press the accelerator pedal to drive off.

The brake is released automatically and the indicator light of the parking brake is no longer illuminated.

# Activating the parking brake automatically

The parking brake is automatically set if driveready state is switched off while the vehicle is being held by Automatic Hold or if the vehicle is exited.



The indicator light changes from green to red.

The parking brake is not set automatically, if the drive-ready state is switched off, while the vehicle is coasting to a halt. Automatic Hold is deactivated.

#### Switching operational readiness off



Press the button.

The LED goes out.



The indicator light goes out.

Automatic Hold is switched off.

If the vehicle is being held by Automatic Hold, press additionally on the brake pedal, when switching off.

## **Malfunction**

If the parking brake fails or in case of a fault, secure the vehicle against rolling before exiting.

A Check Control message is displayed.

Secure the vehicle against rolling away, for instance with a wheel chock, after exiting the vehicle.

# After a power interruption

To reestablish parking brake functionality after a power interruption:

1. Turn on standby state.

2. Pull the switch while stepping on the brake pedal or selector lever position P is set and then push.

This process may take a few seconds. Some mechanical sounds associated with this process are normal.




The indicator light is no longer illuminated as soon as the parking brake is ready for operation again.

# **Turn signal**

# **Turn signal in exterior mirror**

When driving and during operation of the turn signals or hazard warning system, do not fold in the exterior mirrors, so that the signal lights on the exterior mirror are easy to see.

# **Blinking**



Press the lever past the resistance point.

### **Triple turn signal activation**

Lightly tap the lever up or down.

The triple turn signal duration can be adjusted.

- 1. "CAR"
- 2. "Settings"
- 3. "Exterior lighting"
- 4. "One-touch turn signal"
- Select the desired setting.

### **Brief blinking**

Press the lever to the resistance point and hold it there for as long as you want the turn signal to flash.

# High beams, headlight flasher

Press the lever forward or pull it backward.



- High beams on, arrow 1. The high beams light up when the low beams are switched on.
- ▶ High beams off/headlight flasher, arrow 2.

# Window wiper system

#### **General information**

Do not use the wipers if the windshield is dry, as this may damage the wiper blades or cause them to become worn more quickly.

# **Safety information**

#### Marning

If the wipers start moving in the folded away state, body parts can be jammed or damage may occur to parts of the vehicle. There is a risk of injury or risk of damage to property. Make sure that the vehicle is switched off when the wipers are in the folded away state and the wipers are folded in when switching on.

#### ∧ NOTICE

If the wipers are frozen to the windshield, the wiper blades can be torn off and the wiper motor can overheat when switching on. There is a risk of damage to property, among other potential damage. Defrost the windshield prior to switching the wipers on.

# **Turn on window wiper system**



Press the lever up until the desired position is reached.

- ▶ Resting position of the wipers, position 0.
- ▶ Rain sensor, position 1.
- ▶ Normal wiper speed, position 2.
- Fast wiper speed, position 3.

When the journey is interrupted with the window wiper system turned on: when the journey continues, the wipers resume at their previous speed.

# Turn off the window wiper system and flick wipe



Press the lever down.

- ➤ Turn off: press the lever down until it reaches the 0 position.
- ▶ Flick wipe: press the lever down from the 0 position.

The lever automatically returns to its 0 position when released

#### Rain sensor

#### **Principle**

The rain sensor automatically controls the time between wipes depending on the intensity of the rainfall.

#### **General information**

The sensor is located on the windshield, directly in front of the interior mirror.

# **Safety information**



#### ∧ NOTICE

If the rain sensor is activated, the wipers can accidentally start moving in vehicle washes. There is a risk of damage to property, among other potential damage. Deactivate the rain sensor in vehicle washes.

#### Activate rain sensor



Press the lever up once from its 0 position, arrow 1.

Wiping operation is started.

The LED in the wiper lever is illuminated.

In frosty conditions, wiping operation may not start.

#### Deactivate rain sensor

Press the lever back into the 0 position.

#### Adjusting the rain sensor sensitivity



Turn the thumbwheel to adjust the sensitivity of the rain sensor.

Upward: high rain sensor sensitivity.

Downward: low rain sensor sensitivity.

# Windshield washer system

#### Safety information



# ▲ Warning

The washer fluid can freeze onto the window at low temperatures and obstruct the view. There is a risk of accident. Only use the washer systems, if the washer fluid cannot freeze. Use washer fluid with antifreeze, if needed.



#### ∧ NOTICE

When the washer fluid reservoir is empty, the wash pump cannot work as intended. There is a risk of damage to property, among other potential damage. Do not use the washer system when the washer fluid reservoir is empty.

#### Cleaning the windshield



Pull the lever.

The system sprays washer fluid on the windshield and activates the wipers briefly.

#### Windshield washer nozzles

The windshield washer nozzles are automatically heated while standby state is switched on.

#### **Rear wiper**

#### Switching on the rear wiper



Turn the outer switch upward.

- ▶ Resting position of the wiper, position 0.
- ▶ Intermittent mode, arrow 1. When reverse gear is engaged, the system switches to continuous operation.

#### Clean the rear window

Turn the outer switch in the desired direction.

- ▶ In resting position: turn the switch downward, arrow 3. The switch automatically returns to its idle position when released.
- ▶ In intermittent mode: turn the switch further. arrow 2. The switch automatically returns to its interval position when released.

The function is deactivated if the washer fluid reservoir level is low

### Fold-away position of the wipers

#### **Principle**

In the fold-out position, the wipers can be folded out from the windshield, which is important, for instance, when changing the wiper blades or for folding away under frosty conditions.

#### **Safety information**



### Marning

If the wipers start moving in the folded away state, body parts can be jammed or damage may occur to parts of the vehicle. There is a risk of injury or risk of damage to property. Make sure that the vehicle is switched off when the wipers are in the folded away state and the wipers are folded in when switching on.



#### ⚠ NOTICE

If the wipers are frozen to the windshield, the wiper blades can be torn off and the wiper motor can overheat when switching on. There is a risk of damage to property, among other potential damage. Defrost the windshield prior to switching the wipers on.

#### Folding out the wipers

- 1. Turn on standby state.
- 2. Press and hold the wiper lever down, until the wipers stop in a close to vertical position.



3. Fold the wipers all the way out from the windshield.



#### Folding down the wipers

- 1. Fold the wipers back down onto the windshield
- 2. Switch on standby state and press and hold the wiper lever down again.

Wipers return to their resting position and are ready again for operation.

# **Steptronic transmission**

## **Principle**

The Steptronic transmission combines the functions of an automatic transmission with the possibility of manual shifting, if needed.

### **Safety information**



#### Warning

An unsecured vehicle can begin to move and possibly roll away. There is a risk of accident. Before exiting, secure the vehicle against rolling, for instance with the parking brake.

# **Selector lever positions**

#### **Gear position D**

Selector lever position for normal driving. All gears for forward travel are activated automatically.

#### R is reverse

Engage selector lever position R only when the vehicle is stationary.

#### **Neutral N**

The vehicle may be pushed or roll without power, for instance in vehicle washes in selector lever position N.

### Parking position P

#### General information

Selector lever position, for instance for parking the vehicle. The transmission blocks the individual wheels in selector lever position P.

Engage selector lever position P only when the vehicle is stationary.

#### P is engaged automatically

Selector lever position P is engaged automatically in situations such as the following:

- After the drive-ready state is switched off and selector lever position R, D or M/S is engaged.
- ▶ After the standby state has been turned off when selector lever position N is engaged.
- ▶ If the driver's safety belt is unbuckled, the driver's door is opened, and the brake pedal is not pressed while the vehicle is stationary and selector lever position D, M/S or R is engaged.

Before exiting the vehicle, make sure that selector lever position P is set. Otherwise, the vehicle may begin to move. Also set parking brake.

Additional information:

Parking brake, refer to page 146.

# **Engaging selector lever positions**

#### **General information**

To prevent the vehicle from creeping after you select a gear position, maintain pressure on the brake pedal until you are ready to start.

### **Functional requirements**

Only when the drive-ready state is switched on and the brake pedal is depressed is it possible to change from selector lever position P to another selector lever position.

The selection lever position P cannot be changed until all technical requirements are met.

# Engaging selector lever position D, N, R

A selector lever lock prevents the following faulty operation:

- Unintentional shifting into selector lever position R.
- ▶ Unintentional shifting from selector lever position P into another selector lever position.

- 1. Fasten driver's safety belt.
- 2. Press and hold the button to release the selector lever lock.



3. Push the selector lever in the desired direction, past a resistance point, if needed. The selector lever automatically returns to the center position when released.



# **Engaging selector lever position P**



Press button P.

## Rolling or pushing the vehicle

#### **General information**

In some situations, the vehicle is to roll without its own power for a short distance, for instance in a car wash, or be pushed.

#### **Engaging selector lever position N**



#### ∧ NOTICE

Selector lever position P is automatically engaged when standby state is switched off. There is a risk of damage to property, among other potential damage. Do not switch standby state off in car washes.

- 1. Switch on drive-ready state while pressing on the brake pedal.
- 2. If necessary, release the parking brake.
- 3. If necessary, switch off Automatic Hold. Automatic Hold, refer to page 147.
- 4. Depress the brake pedal.
- 5. Touch the selector lever lock and engage selector lever position N.
- 6. Switch off drive-ready state.

In this way, standby state remains switched on, and a Check Control message is displayed.

The vehicle can roll

Selector lever position P is engaged automatically after approximately 35 minutes.

If there is a malfunction, you may not be able to change the selector lever position.

Electronically unlock the transmission lock, if needed.

#### **Kickdown**

Kickdown is used to achieve maximum driving performance.


Step on the accelerator pedal beyond the resistance point at the full throttle position.

#### **Sport program M/S**

#### **Principle**

The shifting points and shifting times in the Sport program are designed for sportier handling. The transmission, for instance shifts up later and the shifting times are shorter.

#### Activating the Sport program



Press the selector lever to the left from selector lever position D.

The engaged gear is displayed in the instrument cluster, for instance S1.

The sport program of the transmission is activated.

#### **Ending the Sport program**

Press the selector lever to the right. D is displayed in the instrument cluster.

#### Manual mode M/S

### **Principle**

Manual gear-shifting is possible in manual mode.

#### **Activating manual mode**

1. Press the selector lever to the left from selector lever position D, arrow 1.



2. Press the selector lever forward or pull it backward, arrows 2.

Manual mode becomes active and the gear is changed.

The engaged gear is displayed in the instrument cluster, for instance M1.

#### **Shifting**

- ➤ To shift down: press the selector lever forward.
- ▶ To shift up: pull the selector lever rearwards.

The transmission continues shifting automatically in certain situations, for instance when RPM limits are reached.

# Steptronic Sport transmission: prevent automatic upshifting in M/S manual mode

Depending on the motorization: if driving mode SPORT is selected, the Steptronic Sport transmission does not automatically upshift in M/S manual mode once the maximum speed is reached.

In addition, there is no downshifting for kick-down.

Additional information:

SPORT, refer to page 145.

# **Ending the manual mode**

Press the selector lever to the right.

D is displayed in the instrument cluster.

### Shift paddles

#### **Principle**

The shift paddles on the steering wheel allow you to shift gears quickly while keeping both hands on the steering wheel.

#### **General information**

#### Shifting

The vehicle only shifts at suitable RPM and road speeds.

#### Short-term manual mode

In selector lever position D, actuating a shift paddle switches into manual mode temporarily.

After conservative driving in manual mode without acceleration or shifting via the shift paddles for a certain amount of time, the transmission switches back to automatic mode.

It is possible to switch into automatic mode:

- ▶ Keep the right shift paddle pulled until D is displayed in the instrument cluster.
- ▶ In addition to the pulled right shift paddle, pull the left shift paddle.

#### Continuous manual mode

In selector lever position S, actuating a shift paddle switches into manual mode permanently.

With the transmission version it is possible to switch into automatic mode:

- ➤ Keep the right shift paddle pulled until S is displayed in the instrument cluster.
- ▶ In addition to the pulled right shift paddle, pull the left shift paddle.

#### **Steptronic Sport transmission**

With the appropriate transmission version, the lowest possible gear can be selected by simultaneously activating kickdown and operating the

left shift paddles. This is not possible in shortterm manual mode.

#### **Shifting**



- Shifting up: pull the right shift paddle.
- ▶ Shifting down: pull left shift paddle.
- Downshifting to the lowest possible gear: keep the left shift paddle pulled.

The selected gear is briefly displayed in the instrument cluster, followed by the current gear.

# Displays in the instrument cluster



The selector lever position is displayed, for example P.

# Electronic unlocking of the transmission lock

#### **General information**

Electronically unlock the transmission lock to maneuver vehicle from a hazardous area.

Before unlocking the transmission lock, set the parking brake to prevent the vehicle from rolling away.

In vehicles with Mild-Hybrid technology and corresponding vehicle battery, the action steps for unlocking the transmission vary.

Additional information:

Vehicle battery, refer to page 394.

# Without Mild-Hybrid technology: engage selector lever position N

Unlocking is possible, if the starter can crank the engine.

- 1. Press and hold down brake pedal.
- Press the Start/Stop button. The starter must audibly start. Hold the Start/Stop button pressed.
- 3. With your free hand, press the button on the selector lever, arrow 1, and press the selector lever into selector lever position N and hold, arrow N, until selector lever position N is displayed in the instrument cluster.

A Check Control message is displayed.



- 4. Release Start/Stop button and selector lever.
- 5. Release brake, as soon as the starter stops.
- 6. Maneuver the vehicle from the hazardous area and secure it against rolling away.


Additional information:

Tow-starting/towing, refer to page 402.

# With Mild-Hybrid technology: engage selector lever position N

- 1. Press and hold down brake pedal.
- 2. Press and hold the Start/Stop button.
- 3. With your free hand, press the button on the selector lever, arrow 1, and press the selector lever into selector lever position N and hold, arrow N, until selector lever position N is displayed in the instrument cluster.

A Check Control message is displayed.



- 4. Release Start/Stop button and selector lever.
- 5. Release the brake.
- Maneuver the vehicle from the danger area and secure it against moving on its own.

Additional information:

Tow-starting/towing, refer to page 402.

#### **Launch Control**

#### **Principle**

Launch Control enables optimum acceleration on roads with good traction under dry surrounding conditions.

#### **General information**

The use of Launch Control causes premature component wear since this function represents a very heavy load for the vehicle.

Do not use Launch Control during the break-in.

Do not steer the steering wheel when driving off with Launch Control.

Additional information:

Breaking-in period, refer to page 330.

## **Functional requirement**

Launch Control is available when the engine is at operating temperature. The engine is at operating temperature after an uninterrupted trip of at least 6 miles/10 km.

#### Start with launch control

1. Turn on drive readiness.



Press the button.

TRACTION is displayed in the instrument cluster and the indicator light for DSC OFF lights up.

- 3. Engage selector lever position S.
- 4. With the left foot, forcefully press down on the brake.
- Press and hold down the accelerator pedal beyond the resistance point at the full throttle position, kickdown.
  - A destination flag is displayed in the instrument cluster.
- The starting engine speed adjusts. Wait briefly until the engine speed is constant. Keep the accelerator pedal in this position.
- 7. Release the brake within 3 seconds after the destination flag illuminates.

The vehicle accelerates.

Upshifting occurs automatically as long as the destination flag is displayed and the accelerator pedal is not released.

#### Repeated use during a trip

After Launch Control has been used, the transmission must cool down for approx. 5 minutes before Launch Control can be used again. Launch Control adjusts to the surrounding conditions, when used again.

# **After using Launch Control**

To increase driving stability, activate DSC Dynamic Stability Control again as soon as possible.

# System limits

An experienced driver may be able to achieve better acceleration values in DSC OFF mode.

# **Displays**

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

### Instrument cluster

### **Principle**


The instrument cluster is a variable display. When you change to a different program via Driving Dynamics Control, the displays in the instrument cluster adapt to the respective driving mode.

#### **General information**

Depending on the vehicle equipment, it may be possible to deactivate the display change in the instrument cluster via iDrive.

Some of the displays in the instrument cluster may differ from the illustrations in the Owner's Manual.

#### **Overview**



- 1 Fuel gauge 168 Range 171
- 2 Speedometer
- 3 Central display area 159 Navigation display
- 4 Depending on the equipment: Driver Attention Camera
- 5 Tachometer 168
  Selection lists 174
  Widgets 161

Trip odometer, see Trip data 175

ECO PRO displays 341

Power gauge 169

Status, Driving Dynamics Control 144

Transmission display 153

- **6** Engine temperature 170
- **7** Outside temperature 170
- 8 Check Control 162
- 9 Speed Limit Assistant 242Speed Limit Info 172

Time 63

### Central display area

Depending on the equipment and configuration, the following is displayed in the central display area of the instrument cluster:

- ▶ Navigation displays such as the map view or, if destination guidance is active, a route preview with route guidance information.
- Displays showing service notifications.
- Assisted Driving View. Information about the assist systems is displayed in an animated surrounding area of the vehicle.

Some displays in the central display area can be configured individually.

The displays may vary depending on the equipment version and country variant.

### **Driving mode view**

#### **Principle**

Depending on the equipment, if the driving mode view is activated, the displays in the instrument cluster will adapt to the respective driving mode when a program is changed via the Driving Dynamics Control.

#### Activate/deactivate

- 1. "CAR"
- 2. "Settings"
- 3. "Displays"
- 4. "Driving mode view"

### Settings

Individual displays in the instrument cluster can be configured individually.

- 1. "CAR"
- 2. "Settings"
- 3. "Displays"
- 4. "Instrument panel"
- 5. Select the desired setting.

# **Assisted Driving View**

#### **Principle**

Depending on the equipment, information about the driver assistance systems is displayed in an animated surrounding area of the vehicle when driver assistance is active.

#### General information

Depending on the settings. Assisted Driving View can be displayed permanently or temporarily with active driving assistance in the instrument cluster.

# **Safety information**



#### Marning

The system cannot serve as a substitute for the driver's personal judgment in assessing visibility and traffic situation. There is a risk of accident. Adjust driving style to traffic conditions, Watch traffic closely and actively intervene where appropriate.

# **Settings**

#### **Permanent display**

- 1. "CAR"
- 2. "Settinas"
- 3. "Displays"
- 4. "Instrument panel"
- 5. "Central display area"
- 6. "Assisted Driving View"

#### Temporary display

- 1. "CAR"
- 2. "Settings"
- 3. "Displays"

- 4. "Instrument panel"
- "Display Assisted Driving View when Driver Assistance is active"

# **Display**



Example: the indicator/warning lights for the Active Cruise Control with Stop & Go function ACC and the Lane Change Assistant indicate a lane change to the next lane. At the same time, the lane change to the next lane is shown with animation in the Assisted Driving View.

### **System limits**

The system's detection capability is limited. The system may indicate something wrong.

Only objects that are detected by the system are taken into account.

Additional information:

- ▶ Cameras, refer to page 37.
- Radar sensors, refer to page 38.

# **Widgets**

### **Principle**

Displays for specific functions can be displayed in the instrument cluster.

The following displays can be selected:

- ▶ Current entertainment source, e.g., radio.
- ▶ Torque and power.
- G-Meter.

- ▶ Trip data.
- Efficiency display.

### **Selecting**



Continue to press the button on the turn signal lever until the desired widget is selected.

# **Display**



#### **G**-meter

The G-meter indicates the forces that are applied in longitudinal and transverse direction on the vehicle occupants while driving.

## **Efficiency display**

### **Principle**

Information about driving style and consumption can be displayed in the form of a consumption display as a widget in the instrument cluster, for example.

#### General information

Depending on the activated driving mode, different information will be displayed:

Driving mode	Display
COMFORT	Average consumption.
SPORT	Current consumption.
	Energy recovery.
ECO PRO	ECO PRO bonus range.
	Distance traveled in Coasting mode.
	Current consumption.

#### **Average fuel consumption**

The average consumption indicates the fuel consumption when driving a specific route.

#### **Current consumption**

The current consumption displays the current consumption of fuel. Check whether you are currently driving in an efficient and environmentally-friendly manner.

#### **Energy recovery**

During energy recovery, the kinetic energy of the vehicle is converted into electric energy in coasting overrun mode. The vehicle battery is partially charged and fuel consumption can be reduced.

#### **ECO PRO bonus range**

In the ECO PRO driving mode, the yielded extension of the range as a result of fuel-efficient driving is displayed as ECO PRO bonus range.

# **Check Control**

# **Principle**


The Check Control system monitors functions in the vehicle and notifies you of faults in the monitored systems.

#### **General information**

A Check Control message is displayed as a combination of indicator or warning lights and text messages in the instrument cluster and, if applicable, in the Head-up Display.

In addition, an acoustic signal may sound and a text message may appear on the Control Display.

# **Hiding Check Control messages**



Press the button on the turn signal lever.

### **Continuous display**

Some Check Control messages are displayed continuously and are not cleared until the fault is eliminated. If several faults occur at once, the messages are displayed consecutively.

The messages can be hidden for approx. 8 seconds. After this time, they are displayed again automatically.

#### **Temporary display**

Some Check Control messages are hidden automatically after approx. 20 seconds. The Check Control messages are stored and can be displayed again later.

# **Displaying stored Check Control messages**

- 1. "CAR"
- 2. "Vehicle status"
- 3. 
  ↑ "Check Control messages"
- 4. Select the text message.

## **Display**

#### **Check Control**



At least one Check Control message is displayed or stored.

#### **Text messages**

Text messages in combination with an icon in the instrument cluster explain a Check Control message and the meaning of the indicator/warning lights.

#### Supplementary text messages

Additional information, such as the reason for a fault or the required action, can be called up via Check Control.

With urgent messages the added text will be automatically displayed on the Control Display.

Depending on the Check Control message, further help can be selected.

- 1. "CAR"
- "Vehicle status"
- 3. \(\Lambda\) "Check Control messages"
- 4. Select the desired text message.
- 5. Select the desired setting.

### Messages after trip completion

Certain messages displayed while driving are displayed again after drive-ready state is switched off.

# **Indicator/warning lights**

#### **Principle**

Indicator/warning lights in the instrument cluster display the status of some functions in the vehicle and indicate when a fault is present in the monitored systems.

#### **General information**

The indicator/warning lights can light up in a variety of combinations and colors.

Several of the lights are checked for proper functioning and light up temporarily when drive-ready state is switched on.

# **Red lights**

#### Safety belt reminder



Indicator light flashes or is illuminated: safety belt on the driver or passenger side is not buckled. The safety belt re-

minder can also be activated if objects are placed on the front passenger seat.

Make sure that the safety belts are positioned correctly.

#### Safety belt reminder for rear seats



The safety belt is not buckled on the corresponding rear seat.



The displays may vary depending on the equipment version and country variant.

#### Airbag system



Airbag system and seat belt tensioner may not be working.

Have the vehicle checked immediately by a dealer's service center or another qualified service center or repair shop.

### **Parking brake**



The parking brake is set.

Additional information:

For releasing the parking brake, refer to page 147.

#### **Brake system**



Brake system impaired. Continue to drive moderately.



Have the vehicle checked immediately BRAKE by a dealer's service center or another qualified service center or repair shop.

### Approach control warning with light braking function



The indicator light is illuminated: prewarning. Brake and increase distance.

Indicator light flashes and an acoustic signal sounds: acute warning. Brake and make an evasive maneuver, if necessary,

Additional information:

Approach control warning with light braking function, refer to page 192.

#### Intersection collision warning



The indicator light is illuminated: risk of collision with crossing vehicle.



Indicator light is illuminated: risk of collision with vehicle without detectable driving direction or prewarning for vehicles

that cross own driving direction.

Intervene yourself, for instance by braking.

Indicator light flashes and an acoustic signal sounds: acute warning when vehicles cross own driving direction.

Brake and make an evasive maneuver, if necessary.

Additional information:

Intersection collision warning, refer to page 197.

## **Pedestrian Warning with City Collision Mitigation**



Indicator light flashes and an acoustic signal sounds: imminent collision with a detected person or a cyclist.

Intervene immediately by braking or make an evasive maneuver.

Additional information:

Pedestrian Warning with City Collision Mitigation, refer to page 201.

#### Night Vision with pedestrian and animal detection



An infrared camera scans the area in front of the vehicle and issues a warning if it detects pedestrians and animals on the street.



The indicator light is illuminated: pre-

warning. Brake and make an evasive maneuver, if necessary.

Indicator light flashes and an acoustic signal sounds: acute warning. Immediate braking or evading maneuver.

Additional information:

Night Vision with pedestrian and animal detection, refer to page 203.

#### Active Cruise Control with Stop&Go function



Indicator light flashes and an acoustic signal sounds: braking and evading.

Additional information:

Active Cruise Control with Stop&Go function, refer to page 234.

### **Steering Assistant**



Indicator light flashes and an acoustic signal sounds: the system will be switched off.

Additional information:

Steering and Lane Control Assistant, refer to page 244.

#### **Drive** power



Reduced drive power due to an overheated drivetrain.

Additional information:

Power gauge, refer to page 169.

### **Yellow lights**

#### **Steering Assistant**



The indicator light lights up and an acoustic signal may sound: a system interruption is imminent.

The indicator warning light flashes: lane marking driven over.

Additional information:

Steering and Lane Control Assistant, refer to page 244.

#### **Antilock Braking System ABS**



The Brake Assistant function may not activate. Avoid abrupt braking. Take the longer braking distance into account.



ABS Have the system immediately checked by a dealer's service center or another

qualified service center or repair shop.

### **DSC Dynamic Stability Control**



The indicator light flashes: DSC controls the drive and braking forces. The vehicle is stabilized. Reduce speed and modify

your driving style to the driving circumstances.

The indicator light lights up: DSC has malfunctioned.

Have the system immediately checked by a dealer's service center or another qualified service center or repair shop.

Additional information:

DSC Dynamic Stability Control, refer to page 223.

#### **DSC Dynamic Stability Control is** deactivated or DTC Dynamic **Traction Control is activated**



DSC is deactivated or DTC is activated.

Additional information:

- DSC Dynamic Stability Control, refer to page 223.
- DTC Dynamic Traction Control, refer to page 225.

#### Flat Tire Monitor FTM



The FTM signals a tire pressure loss in a tire.

Reduce your speed and stop cautiously. Avoid sudden braking and steering maneuvers.

Additional information:

Run-flat tires, refer to page 373.

### Tire pressure monitor



The indicator light illuminates: the Tire Pressure Monitor reports a low tire pressure or a flat tire. Follow the information

in the Check Control message.

The indicator light flashes and is then illuminated continuously: flat tires or tire pressure losses cannot be detected.

- ▶ Fault caused by systems or devices with the same radio frequency: after leaving the area of the interference, the system automatically becomes active again.
- ▶ In the case of tires with special approval: the tire pressure monitor was unable to complete the reset. Reset the system again.
- A wheel without wheel electronics is mounted: have it checked by a dealer's service center or another qualified service center or repair shop as needed.
- Malfunction: have the system checked by a dealer's service center or another qualified service center or repair shop.

Additional information:

Tire pressure monitor, refer to page 366.

#### **Steering system**



Steering system may not be working. Have the system checked by a dealer's

service center or another qualified serv-

ice center or repair shop.

#### **Emissions**



➤ The warning light lights up: Emissions are deteriorating. Have the vehicle checked as soon as possible.

The warning light flashes under certain circumstances:

This indicates that there is excessive misfiring in the engine.

Reduce the vehicle speed and have the system checked immediately; otherwise, serious engine misfiring within a brief period can seriously damage emission control components, in particular the catalytic converter.

Additional information:

Socket for OBD Onboard Diagnosis, refer to page 392.

## **Green lights**

## Safety belt reminder for rear seats



The safety belt is buckled on the corresponding rear seat.



The displays may vary depending on the equipment version and country variant.

### **Turn signal**



Turn signal switched on.

Unusually rapid blinking of the indicator light indicates that a turn signal bulb has

failed.

Additional information:

Turn signal, refer to page 149.

### **Parking lights**



Parking lights are switched on.

Additional information:

Parking lights/low beams, refer to page 180.

#### Low beams



Low beams are switched on.

Additional information:

Parking lights/low beams, refer to page 180.

#### Lane departure warning



The indicator light lights up: the system is activated. Warnings can be issued.

Additional information:

Lane departure warning, refer to page 207.

#### **Automatic High Beam Assistant**



Automatic High Beam Assistant is switched on.

High beams are switched on and off automatically depending on the traffic situation.

Additional information:

Automatic High Beam Assistant, refer to page 182.

#### **Automatic Hold**



Automatic Hold is activated. The vehicle is automatically held in place when it is stationary.

Additional information:

Automatic Hold, refer to page 147.

#### **Manual Speed Limiter**



The indicator light lights up: the system CLIM is switched on.

The indicator light flashes: the set speed limit has been exceeded.

Additional information:

Manual Speed Limiter, refer to page 230.

#### **Cruise control**



Indicator light is illuminated: the system is active.

Additional information:

Cruise control, refer to page 232.

#### **Active Cruise Control with Stop&Go function**



The indicator light lights up: the system is switched on.



Additional information:

Active Cruise Control with Stop&Go function, refer to page 234.

#### **Speed Limit Assistant**



Depending on the equipment, indicator light illuminates together with the icon for a cruise control system: Speed Limit As-

sistant is active and detected speed limits can be applied manually for the displayed system.



Indicator light illuminates: the detected speed limit can be applied with the SET button. As soon as the speed limit has

been applied, a green checkmark is displayed.

Additional information:

Speed Limit Assistant, refer to page 242.

#### **Steering Assistant**



Indicator light lights up: the system supports the driver in keeping the vehicle within the lane.

Additional information:

Steering and Lane Control Assistant, refer to page 244.

#### Lane change assistant



Gray line for lane marking on the appropriate side: system detected a lane change request. Lane change not cur-

rently possible.



Arrow symbol for lane change green: the system carries out a lane change.



Arrow symbol for lane change gray: lane change not possible; functional requirements not met

Additional information:

Lane change assistant, refer to page 250.

#### **Extended Traffic Jam Assistant**



Indicator light is illuminated: the system is active

Additional information:

Assisted Driving Plus, refer to page 248.

### **Blue lights**

# **High beams**



High beams are switched on.

Additional information:

High beams, refer to page 150.

# **Drive** power



Reduced drive power due to a cold drivetrain.

Additional information:

Power gauge, refer to page 169.

#### **Gray lights**

#### Active Cruise Control with Stop&Go function



Indicator light is illuminated: the system is interrupted.

Indicator light flashes: the conditions are not adequate for the system to work or the system has been deactivated.

Additional information:

Active Cruise Control with Stop&Go function, refer to page 234.

#### Steering Assistant



Indicator light is illuminated: the system is ready.

Additional information:

Steering and Lane Control Assistant, refer to page 244.

### **Extended Traffic Jam Assistant**



Indicator light is illuminated: the system is interrupted.

Additional information:

Assisted Driving Plus, refer to page 248.

# White lights

#### **Extended Traffic Jam Assistant**



Indicator light is illuminated: the system is ready.

Additional information:

Assisted Driving Plus, refer to page 248.

# **Fuel gauge**

# **Principle**

The current fill level of the fuel tank is displayed.

#### **General information**

Vehicle inclination may cause the display to vary.

Additional information:

Refueling, refer to page 346.

# **Display**



An arrow next to the fuel pump symbol indicates the vehicle side on which the fuel filler flap is located.

The current range is displayed as

numerical value.

#### Indicator light in the instrument cluster



The yellow indicator light illuminates, once the fuel reserve is reached.

#### **Tachometer**

### General information

Always avoid RPM in the red warning field. In this range, the fuel supply is reduced to protect the enaine.

# **Activating/deactivating**

- 1. "CAR"
- 2. "Settings"
- 3. "Displays"
- 4. "Instrument panel"
- 5. "Engine display"
- 6. "Tachometer"

When the setting for the driving mode view is activated, the activated tachometer is only shown in the COMFORT or SPORT driving mode.

# Power gauge

#### **Principle**

The display indicates the drive power available as a percentage of its total power.

#### Activate/deactivate

- 1. "CAR"
- 2. "Settings"
- 3. "Displays"
- 4. "Instrument panel"
- 5. "Engine display"
- 6. "Power meter"

When the setting for the driving mode view is activated, the activated power gauge is only shown in the COMFORT driving mode.

# **Display**



Pointer in the area of arrow 1: display of the energy recovered by coasting or when decelerating, CHARGE.

Pointer in the area of arrow 2: output in percent, POWER.

### **Drive power**

The available drive power may be reduced due to certain factors, for instance a cold engine. De-

pending on the available drive power, the range for POWER is adjusted automatically.

If needed, icons in the power gauge indicate a reduction of the drive power.

Example symbol	Description
<b>6</b>	Reduced drive power due to a cold drivetrain.
€ <del>l</del> a	Reduced drive power due to an overheated drivetrain.

# **Shift lights**

### **Principle**

The Shift lights in the instrument cluster indicate the maximum shift point at which the best possible acceleration can be achieved.

#### **General information**

Depending on the equipment and national-market version, the Shift lights are active in the M manual mode of the Steptronic Sport transmission and with manual transmission.

### **Functional requirement**

- Depending on the equipment, either driving program SPORT or SPORT PLUS is activated.
- Head-up display is switched off or the display of the Shift lights in the Head-up display is deactivated.

#### **Turning on/turning off**

Steptronic Sport transmission:

- 1. If applicable, select SPORT or SPORT PLUS driving mode.
  - Press Driving Dynamics Control.
- Activate the M manual mode of the transmission.

### **Display**



Full Black Panel Display.

# Information about the driving style

- Current engine speed is displayed in the tachometer.
- Arrow 1: successive yellow illuminated fields indicate an increase in the speed.
- ▶ Arrow 2: successive orange illuminated fields indicate the upcoming shift moment.
- Arrow 3: the field lights up red. Do not wait any further to shift.

When the maximum speed is reached, the entire display flashes red and the fuel supply is interrupted in order to protect the engine.

# Standby state and driveready state



The lettering OFF in the instrument cluster indicates that driveready state is switched off and standby state is switched on.



The letters READY in the instrument cluster indicate that the drive readiness is turned on and the Auto Start/Stop function is ready to start the engine automat-

ically.

Additional information:

Operating state of the vehicle, refer to page 41.

# **Engine oil temperature**

# **Display**



- Cold engine: the pointer is at the low temperature end.
   Drive at moderate RPM and vehicle speeds.
- Normal operating temperature: the pointer is in the middle or in the lower half of the temperature display.
- ▶ Hot engine: the pointer is at the high end of the temperature range. In addition, a Check Control message is displayed.

Additional information:

Coolant level, refer to page 389.

# Indicator light in the instrument cluster



A red indicator light is displayed.

# **Outside temperature**

### **General information**

If the indicator drops to +37 °F/+3 °C or lower, a signal sounds.

A Check Control message is displayed.

There is an increased risk of ice on roads.

# **Safety information**



#### Marning

Even at temperatures above +37 °F/+3 °C there can be a risk of icy roads, for instance on bridges or shady sections of the road. There is a risk of accident. Modify your driving style to the weather conditions at low temperatures.

# Range

# **Principle**

The range indicates the distance that can still be covered with the current full tank of fuel.

#### **General information**

The estimated range available with the remaining fuel is permanently displayed in the instrument cluster.

With a low remaining range, a Check Control message is briefly displayed. With a sporty driving style, for instance fast cornering, the engine function is not always ensured.

The Check Control message appears continuously below a range of approx. 30 miles/50 km.

# **Safety information**



#### ⚠ NOTICE

With a driving distance of less than 30 miles/50 km the engine may no longer have sufficient fuel. Engine functions are not ensured anymore. There is a risk of damage to property, among other potential damage. Refuel promptly.

## **Display**



The current range is displayed as numerical value next to the fuel gauge.

# Service notifications

### **Principle**

The function displays the service notifications and the corresponding maintenance scopes.

#### General information

After switching on drive-ready state, the instrument cluster briefly displays available driving distance or time to the next scheduled maintenance.

A service advisor can read out the current service notifications from your vehicle key.

Some information on service notifications can also be shown on the BMW display key.

# **Display**

#### Detailed information on service notifications

More information on the type of service required may be displayed on the Control Display.

- 1. "CAR"
- "Vehicle status"
- 3. Required services"

Maintenance work and legally mandated inspections are displayed.

4. Select an entry to call up detailed information.

#### **Symbols**

Sym- bols	Description
OK	No service is currently required.



The time for recommended maintenance or a legally mandated inspection is approaching.



Service interval is exceeded.

### **Entering appointment dates**

Enter the dates for the mandatory vehicle inspections.

Make sure that the vehicle's date and time are set correctly.

- 1. "CAR"
- 2. "Vehicle status"
- 3. Required services"
- 4. "Vehicle inspection"
- 5. "Date:"
- Select the desired setting.

### **Gear shift indicator**

### **Principle**

The gear shift indicator recommends the most efficient gear for the current driving situation.

### **General information**

Depending on the design and country version, the gear shift indicator may be active in the M manual mode of the Steptronic transmission.

# Steptronic transmission: displaying

Suggestions to shift up or down are displayed in the instrument cluster.

On vehicles without a gear shift indicator, the engaged gear is displayed.

Example	Description
M3	Efficient gear is set.
<b>2-</b> 3	Shift into efficient gear.

# **Speed Limit Info**

#### **Speed Limit Info**

#### **Principle**

Speed Limit Info shows the currently valid speed limit in the instrument cluster and, if necessary, the Head-up Display.

#### General information

The camera in the area of the interior mirror detects traffic signs at the edge of the road as well as overhead sign posts.

Traffic signs with extra symbols are considered and compared with the vehicle's onboard data. The traffic sign will then be either displayed or ignored depending on the situation in the instrument cluster and the Head-up Display.

With the navigation system, the system takes into account the information stored in the navigation data and also displays speed limits present on routes without signs.

Without a navigation system, the system is subject to limitations imposed by technology. Traffic signs with speed limitations are detected and displayed only. Speed limitations due to entering or exiting towns, highway signs, etc. are not dis-

played. Speed limits with extra text characters are always displayed.

Speed limits for trailer towing will be displayed when the trailer power socket is occupied or trailer towing was activated via iDrive.

# **Safety information**



#### Marning

The system cannot serve as a substitute for the driver's personal judgment in assessing visibility and traffic situation. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.

#### Overview

#### Sensors

The system is controlled by the following sensors:

Cameras behind the windshield.

Additional information:

Sensors of the vehicle, refer to page 37.

# **Displaying Speed Limit Info**

#### **General information**

Depending on the vehicle equipment, Speed Limit Info is displayed permanently in the instrument cluster or via iDrive.

# **Activating**

- 1. "CAR"
- 2. "Settings"
- 3. "Driver Assistance"
- 4. If necessary, "Driving"
- 5. "Speed Limit Assistance"
- 6. "Speed limits"
- 7. "Show current limit"

## **Display**

#### **Speed Limit Info**



Current speed limit.

Without a navigation system the traffic signals are grayed out after curves or longer stretches of roadway.



Depending on the equipment, Speed Limit Info not available.



If the detected speed limit has been exceeded. the indicator light will flash.

# **Settings**

- 1. "CAR"
- 2. "Settings"
- "Driver Assistance"
- 4. If necessary, "Driving"
- 5. "Speed Limit Assistance"
- 6. Select the desired setting:
  - ▶ "Warn when speeding": activate/deactivate the flashing of the Speed Limit Info display in the instrument cluster and. where applicable, the Head-up Display when the currently valid speed limit is exceeded. The warning that is issued when a speed limit is exceeded may depend on the Speed Limit Assistant settings.
  - "Excess speed display": the speed limit that is detected by the Speed Limit Info is displayed with a marking in the speedometer in the instrument cluster.

### **System limits**

#### System limits of the sensors

Additional information:

Cameras, refer to page 37.

#### **Functional limitations**

The system may not be fully functional and may provide incorrect information in the following situations:

- ▶ When traffic signs are fully or partially concealed by objects, stickers or paint.
- When driving very close to the vehicle in front of you.
- In the case of navigation data that is invalid, outdated or not available.
- In areas not covered by the navigation system
- ▶ When roads differ from the navigation, such as due to changes in road layout.
- In case of electronic traffic signs.
- When passing buses or trucks with traffic signs applied to them.
- When the traffic signs do not correspond to the standard.
- When traffic signs that are valid for a parallel road are detected.
- ▶ In the presence of country-specific road signs or road layouts.

# **Selection lists**

#### Concept

Lists can be displayed and, if necessary, used for certain functions in the instrument cluster or the Head-up Display.

- Entertainment source.
- Current audio source.
- List of most recent telephone calls.

If necessary, the corresponding menu will open on the Control Display.

### **Display**



Depending on the equipment version, the list in the instrument cluster may differ from the illustration.

# Displaying and using the list

The lists can be displayed and operated using the buttons on the steering wheel.

Button	Function
三	Change the entertainment source.
	Pressing the button again will close the currently displayed list.
<b>\</b>	Show list of most recent telephone calls.
	Turn the thumbwheel to select the desired setting.
	Press the thumbwheel to confirm the setting.
	The list of the current entertainment source can be displayed in the instrument cluster again by turning the thumbwheel.

# **Trip data**

#### **Principle**

Values for the trip, such as the average consumption or trip kilometers, are displayed.

#### **General information**

The trip data can be displayed on the Control Display and in the instrument cluster.

The values can be displayed and reset depending on various intervals, such as after refueling.

# **Display on the Control Display**

#### Overview

The following information is displayed depending on the equipment and the set interval and driving mode:

- Configured interval for displaying trip data.
- ▶ Average fuel consumption depending on the configured interval.
- Average speed.
- ➤ Total time for shut off engine through the Auto Start/Stop function.
- ▶ Distance traveled in Coasting mode.
- ▶ Consumption history in form of a chart.

### **Displays**

- 1. "CAR"
- 2. "Driving information"
- 3. "Trip data"

# **Consumption history**

The average consumption is shown in the consumption history in form of a chart based on the distance traveled and the driving mode.

# Display in the instrument cluster

Depending on the equipment, information about the route can be displayed as widget in the instrument cluster. The following information is displayed:

- Total kilometers.
- ▶ Configured interval for displaying trip data.
- Distance traveled depending on the configured interval.
- Average speed.

Selecting and setting widgets in the instrument cluster.

Additional information:

Widgets, refer to page 161.

# Adjusting the display of the trip data

The intervals for the display of the trip data in the instrument cluster and on the Control Display are adjustable.


- 1. "CAR"
- 2. "Driving information"
- 3. "Trip data"
- 4. "Data since"
- 5. Select the desired setting:
  - "Start of trip ()": the values are automatically reset approx. four hours after the vehicle has come to a standstill.
  - ▶ "Refueling ()": the values are automatically reset after refueling with a larger quantity of fuel.
  - ▶ "Factory": Average consumption since delivery from the factory.
    - The values since the time of the factory delivery are displayed.
  - "Individual ()": the values since the last manual reset are displayed. The values can be reset at any time.

# Resetting average values manually

The following interval can be reset manually at any time: "Individual ()".

With the button on the turn signal lever:

 Continue to press the button on the turn signal lever until the widget for the trip data is selected.



Press and hold the button on the turn signal lever.

Via iDrive:

- 1. "CAR"
- 2. "Driving information"
- 3. "Trip data"
- 4. "Data since"
- 5. "Reset individual"

The average values and counters are reset. Once the average values and counters have been reset, the following interval is automatically set: "Individual ()".

# Sport displays

## Concept

The Sport displays especially support a sporty driving style.

# **Display on the Control Display**

#### Overview

The following information is displayed:

- Boost pressure.
- Engine oil temperature.
- ▶ G-Meter.

- Torque.
- Power.

#### **Displays**

- 1. "CAR"
- 2. "Driving information"
- 3. "Sport displays"

# Display in the instrument cluster

The Sport displays can be displayed in form of widgets in the instrument cluster.

The following widgets can be selected:

- Widget for torque and power.
- ▶ Widget for G meter.

Additional information:

Widgets, refer to page 161.

# Vehicle status

# **General information**

The status can be displayed and actions performed for several systems.

# Going to the vehicle status

- 1. "CAR"
- 2. "Vehicle status"

#### Information at a glance

Symbols	Description
(!)	"Flat Tire Monitor": status of the run-flat tires, refer to page 373.
(!)	"Tire Pressure Monitor": status of the Tire Pressure Monitor, refer to page 366.
<b>₹</b> →:	"Engine oil level": electronic oil measurement, refer to page 386.

Symbols	Description
$\triangle$	"Check Control messages": displaying stored Check Control messages, refer to page 162.
	"Required services": displaying service notifications, refer to page 171.

# **Head-up Display**

### **Principle**

The Head-up display projects important information in the driver's field of view, for instance the speed.

The driver can get information without averting his or her eyes from the road.

#### **General information**

Follow the information on cleaning the Head-up Display.

#### **Overview**



## **Turning on/off**

- 1. "CAR"
- 2. "Settings"
- 3. "Displays"
- 4. "Head-up display"
- 5. "Head-up display"

### **Display**

#### **Overview**

The following information is displayed on the Head-up Display:

- ▶ Vehicle speed.
- Navigation instructions.
- Check Control messages.
- Selection list in the instrument cluster.
- Driver assistance systems.
- Sport displays.

Some of this information is only displayed briefly as needed.

# Selecting displays in the Head-up Display

- 1. "CAR"
- 2. "Settings"
- 3. "Displays"
- 4. "Head-up display"
- 5. Select the desired setting.

#### **Setting the brightness**

The brightness is automatically adjusted to the ambient brightness.

The base setting can be adjusted manually.

- 1. "CAR"
- 2. "Settings"
- 3. "Displays"
- 4. "Head-up display"
- 5. "Brightness"
- Turn the Controller until the desired brightness is set.
- 7. Press the Controller.

When the low beams are switched on, the brightness of the Head-up Display can be adjusted using the instrument lighting.

#### Adjusting the height

- 1. "CAR"
- 2. "Settings"
- 3. "Displays"
- 4. "Head-up display"
- 5. "Height"
- Turn the Controller until the desired height is reached.
- 7. Press the Controller.

The height of the Head-up Display can also be stored using the memory function.

### **Setting the rotation**

The Head-up Display view can be rotated.

- 1. "CAR"
- 2. "Settings"
- 3. "Displays"
- 4. "Head-up display"
- 5. "Rotation"
- Turn the Controller until the desired setting is selected.
- 7. Press the Controller.

#### **Additional settings**

- 1. "CAR"
- 2. "Settings"
- 3. "Displays"
- 4. "Head-up display"
- 5. Select the desired setting:
  - "Speed Limit Assistance": access the settings for the speed assistant.
  - ▶ "Display infotainment lists in": set up if the selection lists are displayed in the instrument cluster or the Head-up Display.
  - "Sport displays": display tachometer and shift Lights in the Head-up Display.

- "Off": the Sport displays are not displayed in the Head-up Display.
- "In SPORT mode": the Sport displays are only displayed in SPORT driving mode.
- "Always": the Sport displays are continuously displayed in the Head-up Display.
- "Reduced height": if not all of the information is in the driver's field of vision, the information can be displayed in the lower section of the Head-up Display.

#### Visibility of the display

The visibility of the displays in the Head-up Display is influenced by the following factors:

- Seat position.
- Diplects on the cover of the Head-up Display.
- Sunglasses with certain polarization filters.
- Wet road.
- Unfavorable light conditions.

If the image is distorted, have the base settings checked by a dealer's service center or another qualified service center or repair shop.

### Special windshield

The windshield is part of the system.

The shape of the windshield makes it possible to display a precise image.

A film in the windshield prevents double images from being generated.

For this reason, it is strongly suggested to have the special windshield replaced by a dealer's service center or another qualified service center or repair shop, if necessary.

# Lights

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

# **Lights and lighting**

#### Switches in the vehicle



The light switch element is located next to the steering wheel.

Icon	Function
<b>Y</b> i\	Night vision.
OFF	Lights off.  Daytime driving lights.
∋D Œ	Parking lights.

Icon	Function
AUTO	Automatic headlight control.  Adaptive light functions.
<b></b> ■D	Low beams.
<del>ز.</del> )	Instrument lighting.
p <del></del>	Right roadside parking light.



Left roadside parking light.

# Automatic headlight control

### **Principle**

The low beams are switched on and off automatically depending on the ambient brightness, for example in tunnels, in twilight or if there is precipitation.

#### **General information**

A blue sky with the sun low on the horizon can cause the lights to be turned on.

If the low beams are switched on manually, the automatic headlight control is deactivated.

### **Activating**



Press the button on the light switch element.

The LED in the button lights up.



The indicator light in the instrument cluster is illuminated when the low beams are switched on.

**System limits** 

The automatic headlight control cannot replace your personal judgment of lighting conditions.

For example, the sensors are unable to detect fog or hazy weather. In these situations, turn the lights on manually.

# Parking lights, low beams and roadside parking lights

#### **General information**

If the driver's door is opened when the driveready state is switched off, the exterior lighting is automatically switched off after a period of time.

# **Parking lights**

#### **General information**

The parking lights can only be switched on in the low speed range.

### **Switching on**



Press the button on the light switch element.



The indicator light in the instrument cluster lights up.

The vehicle is illuminated on all sides.

Do not use the parking lights for extended periods; otherwise, they might drain the battery and it would then be impossible to switch on driveready state.

# **Turning off**



Press the button on the light switch element or switch on the drive-ready state.

After the drive-ready state is switched on, the automatic headlight control will be activated.

#### Low beams

#### **Switching on**



Press the button on the light switch element.

The low beams illuminate when drive-ready state is switched on.



The indicator light in the instrument cluster lights up.

Press the button again to switch on the low beams when the standby state is switched on.

#### **Turning off**

Depending on the country variant, the low beams can be switched off in the low speed range.



Press the button on the light switch element.

# Roadside parking lights

When the vehicle is parked, a one-sided roadside parking light can be switched on.

Depending on the country-specific version, the function may be deactivated.

Button	Function
P≒	Right roadside parking light on.
∋P	Left roadside parking light off.

Switching off the roadside parking light:



Press the button on the light switch element or switch on the drive-ready state.

### **Welcome lights**

### **Principle**

The exterior lighting is switched on automatically when approaching or unlocking the vehicle.

#### **General information**

Depending on the equipment, the exterior lighting of the vehicle can be set individually.

# Activating/deactivating welcome light

- 1. "CAR"
- 2. "Settings"
- 3. "Exterior lighting"
- 4. Depending on the equipment, select the following setting:
  - ▶ "Welcome and goodbye"

When unlocking the vehicle, individual light functions are switched on for a limited time.


▶ "Door handle lights"

for a limited time.

Door handles and the ground in front of the doors are illuminated for a limited time.

"Welcome Light Carpet"
The area next to the vehicle is illuminated

### **LED light carpet**



The light source is located in the position indicated.

Keep the light source clean and unobstructed.

### **Pathway lighting**

### **Principle**

For the illumination of the vehicle's surroundings after exiting the vehicle, the exterior lighting can be switched on for a defined period of time.

### Switching pathway lighting on

After switching off the drive-ready state, briefly push the turn signal lever forward.

### **Setting the duration**

- 1. "CAR"
- 2. "Settings"
- "Exterior lighting"
- 4. "Pathway lighting"
- 5. Select the desired setting.
- 6. "OK"

### **Daytime driving lights**

### **General information**

The daytime driving lights light up when driveready state is switched on.

# Activate/deactivate daytime driving lights

In some countries, daytime driving lights are mandatory, so it may not be possible to deactivate the daytime driving lights in front.

- 1. "CAR"
- 2. "Settings"
- 3. "Exterior lighting"
- Depending on country specifications: "Daytime driving lights" or "Daytime driving lights, rear"

## **Adaptive light functions**

### **Principle**

Adaptive light functions enable dynamic illumination of the road.

#### **General information**

The adaptive light functions may consist of one system or multiple systems, depending on the equipment version:

- Adaptive Light Control.
- Cornering light.

### **Activating**



Press the button on the light switch ele-

The LED in the button lights up.

The adaptive light functions are active when the drive-ready state is switched on.

## **Adaptive Light Control**

### **General information**

Depending on the steering angle and other parameters, the light from the headlight follows the course of the road.

To avoid blinding oncoming traffic, the Adaptive Light Control does not swivel to the opposite lane when the vehicle is at a standstill.

### **Cornering light**

### **Principle**

In tight curves, for instance on mountainous roads or when turning, an additional, cornering light is switched on that lights up the inside of the curve when the vehicle is moving below a certain speed.

### **General information**

The cornering light is automatically switched on depending on the steering angle or, where applicable, the use of turn signals.

When driving in reverse, the cornering lights may be automatically switched on regardless of the steering angle.

# Adaptive headlight range control

The adaptive headlight range control feature balances out acceleration and braking processes as well as the vehicle load conditions in order to avoid blinding oncoming traffic.

### Automatic High Beam Assistant

### **Principle**

The Automatic High Beam Assistant detects other road users early on and automatically switches the high beams on or off depending on the traffic situation.

### **General information**

The Automatic High Beam Assistant ensures that the high beams are switched on, whenever the traffic situation allows. In the low speed range, the high beams are not switched on by the system.

The system responds to light from oncoming traffic and traffic driving ahead of you, and to ambient lighting, for instance in towns and cities.


The high beams can be switched on and off manually at any time.

### **Activate Automatic High Beam Assistant**

Press the button on the light switch element.

The LED in the button lights up.

2. Press the button on the turn signal lever.





The indicator light in the instrument cluster is illuminated when the low beams are switched on

The headlights are automatically switched between low beams and high beams.




The blue indicator light in the instrument cluster lights up when the system switches on the high beams.

Driving interruption with activated Automatic High Beam Assistant: the Automatic High Beam Assistant remains activated when driving contin-

The Automatic High Beam Assistant is deactivated when manually switching the high beams on and off.

To reactivate the Automatic High Beam Assistant, press the button on the turn signal lever.

### **Deactivate Automatic High Beam Assistant**



Press the button on the turn signal lever.

### **Sensitivity of the Automatic High Beam Assistant**

#### General information

The sensitivity of the Automatic High Beam Assistant can be adjusted.

### **Safety information**



#### Marning

If adjustments have been made or the sensitivity has been modified, oncoming traffic may be momentarily blinded. There is a risk of accident. If adjustments have been made and the sensitivity has been modified, make sure that oncoming traffic is not momentarily blinded. Switch off the high beams manually if required.

### **Functional requirements**

- Setting at standstill only.
- Drive readiness is switched on.
- Light is turned off.

### Increase sensitivity

Push the turn signal lever to the front for approximately 10 seconds.

A Check Control message is displayed. The system responds more sensitively.

### Resetting the sensitivity

Push the turn signal lever to the front again for approx. 10 seconds or switch off the drive-ready state.

The sensitivity of the Automatic High Beam Assistant is reset to the factory settings.

### **System limits**

The Automatic High Beam Assistant cannot replace the driver's personal judgment of when to use the high beams. In situation that require this, therefore dimming manually.

The system is not fully functional in the following situations, and driver intervention may be necessary:

- ▶ In very unfavorable weather conditions, such as fog or heavy precipitation.
- When detecting poorly-lit road users such as pedestrians, cyclists, horseback riders and wagons; when driving close to train or ship traffic; or at animal crossings.
- In tight curves, on hilltops or in depressions, in crossing traffic or half-obscured oncoming traffic on highways.
- ▶ In poorly-lit towns and cities or in the presence of highly reflective signs.
- When the windshield in front of the interior mirror is fogged up, dirty or covered with stickers, etc.

## Laser high beams

### **Principle**

The headlight range of the high beams is increased and provides better illumination of the road.

### **General information**

When the high beams are switched-on, starting with a speed of approx. 37 mph/60 km/h, the laser high beams in the headlight are automatically switched on in addition to the LED high beams.

Depending on the country variant, further information can be obtained from the laser label on the headlight.

### **Safety information**



The label is in the headlight and is visible from the outside.

### **Instrument lighting**

### **Functional requirement**

The parking lights or low beams must be switched on to set the brightness.

### **Setting the brightness**



Adjust the brightness with the thumbwheel.

## **Interior lighting**

### **General information**

Depending on the equipment version, interior lights, footwell lights, entry lights, ambient lighting, and speaker lighting are automatically controlled.

#### **Overview**

#### **Buttons in the vehicle**





Interior lights



Reading lights

### **Turning interior lights on/off**



Press the button.

To switch off permanently: press the button and hold for approx. 3 seconds.

The interior lights in the rear of the vehicle can be switched on and off independently. The button is located in the rear headliner.

### **Turning reading lights on/off**



Press the button.

Depending on the vehicle equipment, the reading lights are located next to the interior lights in the front and rear.

## **Ambient light**

### **General information**

Depending on the equipment version, lighting can be adjusted for some lights in the car's interior.

# Activating/deactivating ambient light

- 1. "CAR"
- 2. "Settings"
- 3. "Interior lighting"
- 4. "Ambient lighting"

### **Turning ambient light on/off**

The ambient light is switched on when the vehicle is unlocked, and switched off when the vehicle is locked.

If the ambient light was deactivated via iDrive, it will not be switched on when the vehicle is unlocked.

### Selecting the color

- 1. "CAR"
- 2. "Settings"
- 3. "Interior lighting"
- 4. "Color"
- 5. Select the desired setting.

### **Setting the brightness**

- 1. "CAR"
- 2. "Settings"
- 3. "Interior lighting"
- 4. "Brightness"
- 5. Select the desired setting.

### **Dynamic light**

Individual actions, for example incoming calls or opened doors, are indicated by light effects.

- 1. "CAR"
- 2. "Settings"
- 3. "Interior lighting"
- 4. "Dynamic light"
- Select the desired setting.

### **Dimmed while driving**

Some lights of the interior lighting are dimmed when the vehicle is driven in the dark.

- 1. "CAR"
- 2. "Settings"
- 3. "Interior lighting"
- 4. "Dimmed for night driving"

# Panoramic glass sunroof, lighting

If the panoramic glass sunroof is opened or the sun protection is closed, the lighting is switched off.

## Bowers & Wilkins Diamond Surround Sound System

### **Principle**

Some speakers in the vehicle are illuminated. Brightness can be individually set.

### **General information**

If the speakers are muted, speaker lighting will be switched off.

# Activating/deactivating speaker lighting

- 1. "CAR"
- 2. "Settings"
- 3. "Interior lighting"
- 4. "Bowers & Wilkins"

### **Turning speaker lighting on/off**

The speaker lighting is switched on when the vehicle is unlocked, and switched off when the vehicle is locked.

### **Setting the brightness**

- 1. "CAR"
- 2. "Settings"
- 3. "Interior lighting"
- 4. "Bowers & Wilkins"
- 5. "Brightness"
- 6. Select the desired setting.


## **Safety**

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are

not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems applicable laws and regulations must be observed.

### **Airbags**



- 1 Front airbag, driver
- 2 Front airbag, front passenger
- **3** Head airbag

### **Front airbags**

Front airbags help protect the driver and the front passenger by responding to frontal impacts in which safety belts alone would not provide adequate protection.

- 4 Side airbag In the rear
- 5 Side airbag
- 6 Knee airbag

### Side airbag

In the event of a side collision, the side airbag protects the side of the body in the chest and lap area.

Depending on the equipment:

In the event of a side collision, the side airbag in the rear protects the chest and lap area on the side of the bodies of the occupants in the outer rear seats.

### **Head airbag**

In the event of a side collision, the head airbag protects the head.

### **Ejection Mitigation**

The head airbag system is designed as an ejection mitigation countermeasure to reduce the likelihood of ejections of vehicle occupants through side windows during rollovers or side collision events.

### **Knee airbag**

The knee airbag protects the legs in the event of a frontal impact.

#### **Protective effect**

#### **General information**

Airbags are not triggered in every impact situation, e.g., in less severe accidents.

# Information on optimum protective effect of the airbags

### ⚠ Warning

If the seat position is incorrect or the deployment area of the airbags is impaired, the airbag system cannot provide protection as intended and may cause additional injuries due to triggering. There is a risk of injury or danger to life. Follow the information on achieving the optimum protective effect of the airbag system.

- ▶ Keep a distance from the airbags.
- ➤ Always grasp the steering wheel on the steering wheel rim. Hold your hands at the 3 o'clock and 9 o'clock positions, to keep the

- risk of injury to your hands or arms as low as possible when the airbag is triggered.
- ➤ Adjust seat and steering wheel so that hands can be crossed over the steering wheel. Select the settings so that the shoulder rests against the backrest when crossing the hands and the upper body is as far back as possible while still maintaining a comfortable grip on the steering wheel.
- Make sure that the front passenger is sitting correctly, i.e., keeps his or her feet and legs in the floor area and does not support them on the dashboard.
- ▶ Make sure that occupants keep their heads away from the side airbag.
- There should be no additional persons, animals or objects between an airbag and a person.
- Dashboard and windshield on the front passenger side must stay clear - do not attach adhesive film or coverings and do not attach brackets or cables, for instance for navigation devices or mobile phones.
- Do not bond the airbag cover panels with adhesive, do not cover them or modify them in any way.
- Do not use the cover of the front airbag on the front passenger side as a storage area.
- Do not attach slip covers, seat cushions or other objects to the front passenger seat that are not specifically suited for seats with integrated side airbags.
- ▶ Do not hang pieces of clothing, such as jackets, over the backrests.
- Never modify either the individual components or the wiring in the airbag system. This also applies to steering wheel covers, the dashboard, and the seats.
- ▶ Do not disassemble the airbag system.

Even when you follow all instructions very closely, injury from contact with the airbags cannot be fully ruled out in certain situations.

The ignition and inflation noise may lead to short-term and, in most cases, temporary hearing impairment in sensitive occupants.

Vehicle modifications for a person with disabilities may affect the air bag system; contact BMW Customer Relations for further information.

Warnings and information on the airbags are also found on the sun visors.

### **Operational readiness of the** airbag system

### Safety information



#### Warning

Individual components can be hot after triggering of the airbag system. There is a risk of iniury. Do not touch individual components.

### Warning

Improperly executed work can lead to failure, malfunction or unintentional triggering of the airbag system. In the case of a malfunction, the airbag system might not trigger as intended despite the accident severity. There is a risk of injury or danger to life. Have the airbag system checked, repaired, disassembled and scrapped by a dealer's service center or another qualified service center or repair shop.

### Display in the instrument cluster



When drive-ready state is turned on, the warning light in the instrument cluster lights up briefly and thereby indicates the

operational readiness of the entire airbag system and the seat belt tensioners.

#### Malfunction



- Warning light does not come on when drive-ready state is turned on.
- ▶ The warning light lights up continuously.

Have the system checked.

### Strength of the driver's and front passenger airbag

#### General information

The power that triggers the driver's/front passenger airbags depends on the position of the driver's/front passenger seat.

To maintain the accuracy of this function over the long term, calibrate the front seats as soon as a respective message appears on the Control Display.

### Calibrating the front seats



#### Warning

There is a risk of jamming when moving the seats. There is a risk of injury or risk of damage to property. Make sure that the area of movement of the seat is clear prior to any adjustment.

A corresponding message appears on the Control Display.

- 1. Press the switch and move the respective seat all the way forward, until it stops.
- 2. Press the switch forward again. The seat still moves forward slightly.
- 3. Readjust the seat to the desired position.

The calibration procedure is completed when the message on the Control Display disappears.

If the message continues to be displayed, repeat the calibration.

If the message does not disappear after a repeat calibration, have the system checked as soon as possible.

## Automatic deactivation of the front passenger airbags

### **Principle**

The system reads if the front passenger seat is occupied by measuring the human body's resistance.

Front, knee, and side airbag on the front passenger's side are activated or deactivated.

#### **General information**

Before transporting a child on the front passenger seat, refer to the safety information and instructions for children on the front passenger seat, see Children.

### **Safety information**

#### Warning

To ensure the front passenger airbag function, the system must be able to detect whether a person is sitting in the front passenger seat. The entire seat cushion area must be used for this purpose. There is a risk of injury or danger to life. Make sure that the front passenger keeps his or her feet in the floor area.

### Fault of the automatic deactivation system

When transporting older children and adults, the front passenger airbags may be deactivated in certain seat positions. In this case, the indicator light for the front passenger airbags lights up.

In this case, change the seat position so that the front passenger airbags are activated and the indicator light goes out.

If it is not possible to activate the airbags, have the person sit in the rear.

To enable accurate recognition of the occupied seat cushion:

- ▶ Do not attach covers, cushions, ball mats or other items to the front passenger seat unless they are specifically determined to be safe for use on the front passenger seat.
- Do not place any electronic devices on the front passenger seat if a child restraint system is to be installed on it.
- Do not place objects under the seat that can press against the seat from below.
- No moisture in or on the seat.

### Indicator light for the front passenger airbags

The indicator light for the front-seat passenger airbag in the headliner indicates the operating state of the front-seat passenger airbag.

The light indicates whether the airbags are either activated or deactivated.

After drive-ready state is switched on, the light shortly lights up and then indicates whether the airbags are either activated or deactivated.



- ▶ The indicator light lights up when a child is properly seated in a child restraint system or when the seat is empty. The airbags on the front passenger side are not activated.
- ▶ The indicator light does not light up when, for instance a correctly seated person of sufficient size is detected on the seat. The airbags on the front passenger side are activated.

### **Detected child restraint systems**

The system generally detects children seated in a child restraint system, particularly in child restraint systems required by NHTSA at the point

in time when the vehicle was manufactured. After installing a child restraint system, make sure that the indicator light for the front passenger airbags lights up. This indicates that the child restraint system has been detected and the front passenger airbags are not activated.

### **Intelligent Safety**

### **Principle**

Intelligent Safety enables central operation of the driver assistance systems.

### **General information**

Depending on how the vehicle is equipped, Intelligent Safety consists of one or more systems that can help prevent an imminent collision.

- Approach control warning with light braking function.
- Evasion Assistant.
- ▶ Intersection collision warning.
- Daytime Pedestrian Collision Mitigation.
- Night Vision with pedestrian and animal detection.
- Lane departure warning.
- Active Blind Spot Detection.
- ▶ Side collision mitigation.

### **Safety information**



#### Marning

The system cannot serve as a substitute for the driver's personal judgment in assessing visibility and traffic situation. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.

#### ⚠ Warning

Indicators and warnings cannot serve as a substitute for the driver's personal judgment. Due to its limits, the system may not issue warnings or reactions, or these may be issued late or in a manner that is not consistent with their normal use. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.

#### Warning

Due to system limits, individual functions can malfunction during tow-starting/towing with the Intelligent Safety systems activated. There is a risk of accident. Switch all Intelligent Safety systems off prior to tow-starting/towing.

#### Overview

### **Button in the vehicle**





Intelligent Safety

### **Turning on/off**

Some Intelligent Safety systems are automatically active after every departure. Some Intelligent Safety systems activate according to the last setting.

#### **Button Status**



Button lights up green: all Intelligent Safety systems are switched on.



Button lights up orange: some Intelligent Safety systems are switched off or currently unavailable.



Button does not light up: all Intelligent Safety systems are switched off.

Press the button. (8)

The menu for the Intelligent Safety system is displayed.

If all Intelligent Safety systems were switched off, all systems are now switched on.

"Configure INDIVIDUAL": depending on the equipment version, the Intelligent Safety systems can be individually configured. The individual settings are activated and stored. As soon as a setting is changed on the menu, all settings of the menu are activated.



Press the button repeatedly. The following settings are switched between:

"ALL ON": all Intelligent Safety systems are switched on. Basic settings are activated for the sub-functions, for instance setting for warning time.

"INDIVIDUAL": the Intelligent Safety systems are switched on according to the individual settings. Some Intelligent Safety systems cannot be individually switched off.

Press and hold this button. All Intelligent Safety systems are switched off.

## Approach control warning with light braking function

### **Principle**

The Forward Collision Warning warns of a possible risk of collision and may brake independently. In the event of an accident, the system may reduce impact speed.

#### General information

Sensors detect the traffic situation.

The system issues a two-phase warning of a possible risk of collision with vehicles at speeds above approx. 3 mph/5 km/h. The timing of warnings may vary with the current driving situation.

When the vehicle is driven so that it is intentionally approaching another vehicle, the Forward Collision Warning and brake intervention are delayed in order to avoid false system reactions.

Depending on the vehicle equipment, the Driver Attention Camera in the instrument cluster captures the driver's field of vision. Additionally, the system checks for visual impairments. Field of vision and visibility also affect the timing of the warnings.

### **Safety information**



#### Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing visibility and traffic situation. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.



#### Warning

Indicators and warnings cannot serve as a substitute for the driver's personal judgment. Due to its limits, the system may not issue warnings or reactions, or these may be issued late or in a

manner that is not consistent with their normal use. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.



### Marning

Due to system limits, individual functions can malfunction during tow-starting/towing with the Intelligent Safety systems activated. There is a risk of accident. Switch all Intelligent Safety systems off prior to tow-starting/towing.

#### Overview

#### Button in the vehicle





Intelligent Safety

#### **Sensors**

The system is controlled by the following sensors:

- Cameras behind the windshield.
- With radar sensor: front radar sensor.

Additional information:

Sensors of the vehicle, refer to page 37.

### **Turning on/off**

### **Turning on automatically**

The system is automatically active when the vehicle is turned on.

### Switching on manually

Press the button.

The menu for the Intelligent Safety system is displayed.

If all Intelligent Safety systems were switched off, all systems are now switched on.

"Configure INDIVIDUAL": depending on the equipment version, the Intelligent Safety systems can be individually configured. The individual settings are activated and stored. As soon as a setting is changed on the menu, all settings of the menu are activated.

Press the button repeatedly. The following settings are switched between:

"ALL ON": all Intelligent Safety systems are switched on. Basic settings are activated for the subfunctions.

"INDIVIDUAL": the Intelligent Safety systems are switched on according to the individual settings. Some Intelligent Safety systems cannot be individually switched off.

### Manual switching off

Press and hold this button. All Intelligent Safety systems are switched off.

	Button	Status
	8	Button lights up green: all Intelligent Safety systems are switched on.
	8	Button lights up orange: some Intelligent Safety systems are switched off or currently unavailable.
	8	Button does not light up: all Intelligent Safety systems are switched off.

### **Setting the warning time**

- 1. "CAR"
- 2. "Settings"
- 3. "Driver Assistance"
- 4. "Safety and Warnings"
- 5. "Forward Collision Mitigation"
- 6. Select the desired setting:
  - ▶ "Earlv"
  - ▶ "Medium"
  - ▶ "Late": only acute warnings are displayed.

### Warning with braking function

### **Display**

A warning symbol appears in the instrument cluster and in the Head-up Display, where available, if a collision with a detected vehicle is imminent.

#### Icon

#### Measure



Icon lights up red: prewarning. Brake and increase distance.



Symbol flashes red and an acoustic signal sounds: acute warning.

Brake and make an evasive maneuver, if necessary.

### **Prewarning**

This warning is provided, for instance when there is impending danger of a collision or the distance to the vehicle ahead is too small.

If a prewarning is provided, respond by braking as warranted.

### Acute warning with braking function

An acute warning is displayed in case of the imminent danger of a collision when the vehicle approaches another object at a high differential speed.

Intervene in the case of an acute warning. Depending on the driving situation and the equipment version, the acute warning may be accompanied by a brief activation of the braking system.

With the warning time setting "Late" the brief activation of the braking system is omitted.

If an acute warning is provided, the system may also provide assistance, such as through automatic brake intervention, when there is risk of collision.

Acute warnings may be provided even when there has been no prior warning.

#### **Brake intervention**

The warning prompts the driver to intervene. If a warning is active, the maximum braking force is used when the brake is applied. The brake pedal must be applied sufficiently quickly and forcefully.

The system may also assist in braking if there is a risk of collision.

When the vehicle is traveling at a low speed, the vehicle may come to a complete stop.

City brake function: the brake intervention occurs to up to approx. 50 mph/80 km/h.

With radar sensor: the brake intervention occurs to up to approx. 155 mph/250 km/h.

At speeds above approx. 130 mph/210 km/h, the brake intervention occurs as a brief braking pressure. No automatic delay occurs.

The brake intervention can be interrupted by stepping on the accelerator pedal or by actively moving the steering wheel.

The system's ability to detect objects may be limited in some circumstances. Refer to the information in this Owner's Manual regarding the limitations of the system and actively intervene as warranted.

### **System limits**


### **Safety information**



### 🛕 Warning

The system is designed to operate in certain conditions and circumstances. Due to conditions or other factors, the system may not respond. There may be a risk of accident or risk of damage to property. Actively intervene as warranted. Refer to the information in this Owner's Manual regarding the scope of the system's operation and limitations.

### **Detection range**



The system's detection capability is limited. Only objects that are detected by the system are taken into account.

Thus, a system reaction might not come or might come late.

The following situations may not be detected, for instance:

- ▶ Slow moving vehicles when you approach them at high speed.
- ▶ Vehicles that suddenly swerve in front of you, or strongly decelerating vehicles.
- Vehicles with an unusual rear view.
- ▶ Two-wheeled vehicles ahead of you.

### **Upper speed limit**

If the vehicle speed exceeds approx. 155 mph/250 km/h, the system is deactivated temporarily. When the vehicle slows down to below this speed, the system is reactivated.

### System limits of the sensors

Additional information:

- ▶ Cameras, refer to page 37.
- ▶ Radar sensors, refer to page 38.

#### **Functional limitations**

The system may be limited in the following situations:

- In tight curves.
- ▶ If the driving stability control systems are limited or deactivated, for instance DSC OFF.
- ▶ Up to 10 seconds after the start of the engine via the Start/Stop button.

### Warning sensitivity

The more sensitive the warning settings are, for example the warning time, the more warnings are displayed. Therefore, there may also be an excess of premature or unjustified warnings and reactions.

### **Evasion Assistant**

### **Principle**

The Evasion Assistant supports the driver in making evasive maneuvers in certain situations. such as when obstacles or persons suddenly appear.

### General information

The system issues a warning and intervenes to support the driver if a lateral evasive maneuver is possible. Sensors monitor and detect the clearance around the vehicle. If the system identifies space alongside the vehicle, it supports an evasive maneuver begun by the driver by safely providing targeted supporting steering movements.

### **Safety information**



#### Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing visibility and traffic situation. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.

#### Marning

Indicators and warnings cannot serve as a substitute for the driver's personal judgment. Due to its limits, the system may not issue warnings or reactions, or these may be issued late or in a manner that is not consistent with their normal use. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.

### Overview

#### Sensors

The system is controlled by the following sensors:

- Cameras behind the windshield.
- Front radar sensor.
- ▶ Radar sensors, side, front.
- ▶ Radar sensors, side, rear.

Additional information:

Sensors of the vehicle, refer to page 37.

### **Functional requirements**

- Pedestrian Warning with braking function is switched on.
  - Pedestrian Warning with City Collision Mitigation, refer to page 201.
- Approach control warning with light braking function is switched on.

- Approach control warning with light braking function, refer to page 192.
- Sensors detect sufficient clearance around the vehicle.

### **Turning on/off**

The system is automatically active when the vehicle is turned on.

### Warning with evasion support

### Display in the instrument cluster

If a collision with a detected vehicle or a detected person is imminent, a warning symbol appears on the instrument cluster and in the Head-up Display.

#### Icon

#### Measure



Icon lights up red: prewarning. Brake and increase distance.



Symbol flashes red and an acoustic signal sounds: acute warning for obstacles.

Brake and make an evasive maneuver, if necessary.



Symbol flashes red and an acoustic signal sounds: acute warning for pedestrians

Brake and make an evasive maneuver, if necessary.

### Acute warning with evasion support

An acute warning is displayed when there is an imminent danger of collision due to the vehicle approaching another object at a high speed.

Intervene in the case of an acute warning. The system is designed to provide assistance by taking evasive action when there is a risk of collision.

Acute warnings may be provided even when there has been no prior warning.

### **System limits**


### **Safety information**



#### 🛕 Warning

The system is designed to operate in certain conditions and circumstances. Due to conditions or other factors, the system may not respond. There may be a risk of accident or risk of damage to property. Actively intervene as warranted. Refer to the information in this Owner's Manual regarding the scope of the system's operation and limitations.

### **Detection range**



The system's detection capability is limited.

Only objects that are detected by the system are taken into account.

Thus, a system reaction might not come or might come late.

The following situations may not be detected, for example:

- ▶ Slow moving vehicles when you approach them at high speed.
- ▶ Vehicles that suddenly swerve in front of you, or strongly decelerating vehicles.
- Vehicles with an unusual rear view.
- ▶ Two-wheeled vehicles ahead of you.

### System limits of the sensors

Additional information:

- ▶ Cameras, refer to page 37.
- Radar sensors, refer to page 38.

#### **Functional limitations**

The system may be limited in the following situations:

- ▶ In tight curves.
- ▶ If the driving stability control systems are limited or deactivated, for instance DSC OFF.
- ▶ Up to 10 seconds after the start of the engine via the Start/Stop button.

## Intersection collision warning

### **Principle**

The system may prevent some accidents with cross traffic at intersections and junctions. In the event of an accident, the system may reduce impact speed.

The system sounds a warning in the city speed range before an imminent collision and activates brakes independently, if needed.

#### **General information**

Sensors detect the traffic situation.

Vehicles that cross your driving direction can be detected by the system as soon as these vehicles enter into the detection range of the system.

At intersections and junctions, a warning is issued when a danger of collision with crossing traffic is detected.

The system issues a two-phase warning of a possible risk of collision with vehicles at speeds above approx. 6 mph/10 km/h. The timing of warnings may vary with the current driving situation.

The Driver Attention Camera in the instrument cluster captures the driver's field of vision. Additionally, the system checks for visual impairments. Field of vision and visibility also affect the timing of the warnings.

### **Safety information**



#### Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing visibility and traffic situation. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.

### Marning

Indicators and warnings cannot serve as a substitute for the driver's personal judgment. Due to its limits, the system may not issue warnings or reactions, or these may be issued late or in a manner that is not consistent with their normal use. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.



#### Warning

Due to system limits, individual functions can malfunction during tow-starting/towing with the Intelligent Safety systems activated. There is a risk of accident. Switch all Intelligent Safety systems off prior to tow-starting/towing.

#### Overview

#### Button in the vehicle





Intelligent Safety

#### Sensors

The system is controlled by the following sensors:

- Cameras behind the windshield.
- Front radar sensor.
- Radar sensors, side, front.

Additional information:

Sensors of the vehicle, refer to page 37.

### **Turning on/off**

### Turning on automatically

The system is automatically active when the vehicle is turned on

### Switching on manually




Press the button.

The menu for the Intelligent Safety system is displayed.

If all Intelligent Safety systems were switched off, all systems are now switched on.

"Configure INDIVIDUAL": depending on the equipment version, the Intelligent Safety systems can be individually configured. The individual settings are activated and stored. As soon as a setting is changed on the menu, all settings of the menu are activated.




"ALL ON": all Intelligent Safety systems are switched on. Basic settings are activated for the subfunctions.


"INDIVIDUAL": the Intelligent Safety systems are switched on according to the individual settings. Some Intelligent Safety systems cannot be individually switched off.

### **Manual switching off**

Press and hold this button.
All Intelligent Safety systems are switched off.

#### **Button Status**





Button does not light up: all Intelligent Safety systems are switched off.

### **Setting the warning time**

- 1. "CAR"
- 2. "Settings"
- 3. "Driver Assistance"
- 4. "Safety and Warnings"
- 5. "Forward Collision Mitigation"
- 6. Select the desired setting:
  - ▶ "Early"
  - ▶ "Medium"
  - ▶ "Late": only acute warnings are displayed.

### Warning with braking function

### **Display**

#### General information

A warning symbol appears in the instrument cluster and in the Head-up Display, where available, if a collision with a detected vehicle is imminent.

#### Icon Meaning



Danger of collision with vehicle crossing from the right.



Danger of collision with vehicle crossing from the left.



Danger of collision with vehicle for which the driving direction cannot be determined

#### Display with prewarning

The respective icon lights up red: prewarning for vehicles that cross your driving direction.

Intervene yourself, for instance by braking.

#### Display with acute warning

The respective icon flashes red and an acoustic signal sounds: acute warning when vehicles cross your driving direction.

Brake and make an evasive maneuver, if necessary.

### **Prewarning**

For example, a prewarning is displayed when a danger of collision with a crossing vehicle is detected.

If a prewarning is provided, respond by braking as warranted.

### Acute warning with braking function

An acute warning is displayed in the event of an immediate danger of collision with a crossing vehicle.

Intervene in the case of an acute warning. If an acute warning is provided, the system may provide assistance, such as through automatic brake intervention, when there is risk of collision.

Acute warnings may be provided even when there has been no prior warning.

#### **Brake intervention**

The warning prompts the driver to intervene.

The system may also assist in braking if there is a risk of collision.

The vehicle can be decelerated to a standstill.

The brake intervention can be interrupted by stepping on the accelerator pedal or by actively moving the steering wheel.

The system's ability to detect objects may be limited in some circumstances. Refer to the information in this Owner's Manual regarding the limitations of the system and actively intervene as warranted.

### **System limits**

### Safety information




#### Marning

The system is designed to operate in certain conditions and circumstances. Due to conditions or other factors, the system may not respond. There may be a risk of accident or risk of damage to property. Actively intervene as warranted. Refer to the information in this Owner's Manual regarding the scope of the system's operation and limitations.

### Upper speed limit

The system responds to crossing vehicles when your own speed is below approx. 50 mph/80 km/h.

### **Detection range**



The system's detection capability is limited.

Thus, a system reaction might not come or might come late.

The following situations may not be detected, for instance:

- Crossing vehicles when they are hidden by buildings, for instance.
- ▶ Vehicles that suddenly swerve in front of you, or strongly decelerating vehicles.
- Crossing bicycles.
- ▶ Vehicles with an unusual side appearance.

### System limits of the sensors

Additional information:

- ▶ Cameras, refer to page 37.
- ▶ Radar sensors, refer to page 38.

#### **Functional limitations**

The system may be limited in the following situations:

- ▶ In tight curves.
- ▶ If the driving stability control systems are limited or deactivated, for instance DSC OFF.
- ▶ Up to 10 seconds after the start of the engine via the Start/Stop button.

### Warning sensitivity

The more sensitive the warning settings are, for example the warning time, the more warnings are displayed. Therefore, there may also be an excess of premature or unjustified warnings and reactions.

## **Pedestrian Warning with City Collision Mitigation**

### **Principle**

The Pedestrian Warning warns in the city speed range of possible risk of collision with pedestrians and bicycle riders and may brake independently. In the event of an accident, the system may reduce impact speed.

#### General information

Sensors detect the traffic situation.

The system issues a warning of a possible risk of collision with pedestrians and cyclists at speeds above approx. 3 mph/5 km/h.

The system reacts to pedestrians and cyclists who are within the detection range of the system.

### **Safety information**



#### Marning

The system cannot serve as a substitute for the driver's personal judgment in assessing visibility and traffic situation. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.

#### ⚠ Warning

Indicators and warnings cannot serve as a substitute for the driver's personal judgment. Due to its limits, the system may not issue warnings or reactions, or these may be issued late or in a manner that is not consistent with their normal use. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.

#### Warning

Due to system limits, individual functions can malfunction during tow-starting/towing with the Intelligent Safety systems activated. There is a risk of accident. Switch all Intelligent Safety systems off prior to tow-starting/towing.

### Overview

#### Button in the vehicle





Intelligent Safety

#### Sensors


The system is controlled by the following sen-

- Cameras behind the windshield.
- With radar sensor: front radar sensor.

Additional information:

Sensors of the vehicle, refer to page 37.

### **Detection range**



The detection range in front of the vehicle is divided into two areas:

- ▶ Central area, arrow 1, directly in front of the vehicle.
- ▶ Extended area, arrows 2, to the right and left of the central area.

A collision is imminent if pedestrians are located within the central area. A warning is issued about pedestrians who are located within the extended area only if they are moving in the direction of the central area.

### **Turning on/off**

### Turning on automatically

The system is automatically active when the vehicle is turned on.


### Switching on manually

Press the button.

The menu for the Intelligent Safety system is displayed.

If all Intelligent Safety systems were switched off, all systems are now switched on.

"Configure INDIVIDUAL": depending on the equipment version, the Intelligent Safety systems can be individually configured. The individual settings are activated and stored. As soon as a setting is changed on the menu, all settings of the menu are activated.



tween:

"ALL ON": all Intelligent Safety systems are switched on. Basic settings are activated for the subfunctions.

"INDIVIDUAL": the Intelligent Safety systems are switched on according to the individual settings.

Some Intelligent Safety systems cannot be individually switched off.

### Manual switching off

Press and hold this button. All Intelligent Safety systems are switched off.

### **Button Status**



Button lights up green: all Intelligent Safety systems are switched on.



Button lights up orange: some Intelligent Safety systems are switched off or currently unavailable.



Button does not light up: all Intelligent Safety systems are switched off.

### Warning with braking function

### **Display**

If a collision with a pedestrian or a cyclist is imminent, a warning symbol appears on the instrument cluster and in the Head-up Display.



The red icon is displayed and a signal sounds.

Intervene immediately by braking or make an evasive maneuver.

#### **Brake intervention**

The warning prompts the driver to intervene. While a warning is active, the maximum braking force is used when the brake is applied. In order to activate the Brake Assistant function, the brakes must be applied sufficiently quickly and forcefully.

If there is a risk of collision, the system may also assist with brake intervention.

When the vehicle is traveling at a low speed, the vehicle may come to a complete stop.

The brake intervention can be interrupted by stepping on the accelerator pedal or by actively moving the steering wheel.

The system's ability to detect objects may be limited in some circumstances. Refer to the information in this Owner's Manual regarding the limitations of the system and actively intervene as warranted.

### **System limits**

### **Safety information**



The system is designed to operate in certain conditions and circumstances. Due to conditions or other factors, the system may not respond. There may be a risk of accident or risk of damage to property. Actively intervene as warranted. Refer to the information in this Owner's Manual regarding the scope of the system's operation and limitations.

### **Upper speed limit**

The system responds to pedestrians and cyclists when the speed of the vehicle is below approx. 50 mph/80 km/h.

### **Detection range**

The system's detection capability is limited.

Thus, a warning might not be issued or be issued late.

The following situations may not be detected, for instance:

- Partially covered pedestrians.
- Pedestrians that are not detected as such because of the viewing angle or contour.
- Pedestrians outside of the detection range.
- Pedestrians having a body size less than 32 in/80 cm.

### System limits of the sensors

Additional information:

- ▶ Cameras, refer to page 37.
- ▶ Radar sensors, refer to page 38.

#### **Functional limitations**

The system may be limited or may not be available in the following situations:

- If the driving stability control systems are deactivated, for instance DSC OFF.
- ▶ Up to 10 seconds after the start of the engine via the Start/Stop button.

# Night Vision with pedestrian and animal detection

### **Principle**

Night Vision with pedestrian and animal detection is a night vision system.

An infrared camera scans the area in front of the vehicle and issues a warning if it detects pedestrians and animals on the street.

### **General information**

The system detects warm objects that are similar in shape to human beings or animals. If necessary, the thermal image can be displayed on the Control Display.

#### Thermal image



The image shows the heat radiated by objects in the field of vision of the camera.

Warm objects have a light appearance and cold objects a dark appearance.

The ability to detect an object depends on the temperature difference between the object and the background and on the level of heat radiation emitted by the object. Objects that are similar in temperature to the environment or that radiate very little heat are difficult to detect.

For safety reasons, when driving at speeds above approx. 3 mph/5 km/h and in low ambient light, the image is only displayed when the low beams are switched on.

A freeze frame is displayed at regular intervals for a fraction of a second.

#### Pedestrian and animal detection



Object detection and warning only functions in darkness.

Objects whose form is similar to people with sufficient heat radiation are detected.

In addition, the system also detects animals above a certain minimum size, for instance deer.

Display on the Control Display with thermal image activated:

- ▶ People detected by the system: in light yellow/
- ▶ Animals detected by the system: in dark yel-

Range of object detection, with good ambient conditions:

- Pedestrian detection: up to approx. 330 ft/100 m.
- Detection of large animals: up to approx. 490 ft/150 m.
- Detection of medium animals: up to approx. 230 ft/70 m.

Environmental influences can limit the availability of object detection.

If the vehicle systems detect that the vehicle is located in a residential area, the animal detection is temporarily switched off.

### Safety information



#### Marning

The system cannot serve as a substitute for the driver's personal judgment in assessing visibility and traffic situation. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.



#### Warning

Indicators and warnings cannot serve as a substitute for the driver's personal judgment. Due to its limits, the system may not issue warnings or reactions, or these may be issued late or in a manner that is not consistent with their normal use. There is a risk of accident. Adjust driving

style to traffic conditions. Watch traffic closely and actively intervene where appropriate.

#### **Overview**

#### **Buttons in the vehicle**





Intelligent Safety





Thermal image

### **Sensors**

The system is controlled by the following sensors:

Infrared camera.

The camera is automatically heated when the external temperatures are low.

When the vehicle lighting is switched on, the camera objective is cleaned at regular intervals when the windshield washer system is activated.

Additional information:

Sensors of the vehicle, refer to page 37.

### **Turning on**

### **Turning on automatically**

When it is dark outside, the system is automatically active after every driving off.

### Switching on the thermal image

The thermal image from the Night Vision camera can be displayed on the Control Display in addition to the warning function. This function has no effect on object detection.



Press the button.

The image from the camera is displayed on the Control Display.

### Adjusting the thermal image

Brightness and contrast can be adjusted, when the thermal image is switched on.

- 1. Select brightness or contrast:
  - ▶ ' Brightness".
  - ▶ "Contrast".
- 2. Set the desired value.

### **Warning function**

### **Display**

Icon	Meaning	
着中节	Pedestrian Warning.	
/4	Animal warning.	
Symbol lights up red.	Prewarning.	
Symbol flashes red and a signal sounds.	Acute warning.	


The displayed icon may vary and shows the side of the road on which the person or animal was detected.

# Warning of people or animals in danger

If a collision with a person or an animal detected in this way is imminent, a warning symbol appears on the instrument cluster and in the Headup Display.

Although both the shape and the heat radiation are analyzed, unwarranted warnings cannot be ruled out.

### Warning area in front of the vehicle



The warning area for the Pedestrian Warning consists of two parts:

- ▶ Central area, arrow 1, directly in front of the vehicle.
- Extended area, arrows 2, to the right and left of the central area.

With animal warnings, no distinction is made between the central or extended area.

The entire area moves along with the vehicle direction according to the steering angle and changes with the vehicle speed. As the vehicle speed increases, the area becomes, for instance longer and wider.

### **Prewarning**

Prewarning for persons is displayed when a person is detected in the central area immediately in front of the vehicle as well as on the left or right side in the extended area.

Prewarning for animals is displayed when an animal is detected in the front of the vehicle.

If a prewarning is issued, intervene by braking or making an evasive maneuver.

### **Acute warning**

Acute warning is displayed if a person or an animal is detected in direct proximity in front of the vehicle.

If an acute warning is issued, brake or make an evasive maneuver immediately.

### **Display in the Head-up Display**

The warning is displayed simultaneously in the Head-up Display and on the instrument cluster.

### **System limits**

### System limits of the sensors

Additional information:

▶ Cameras, refer to page 37.

## Limits of pedestrian and animal detection

In some situations, it may occur that pedestrians are detected as animals or animals as pedestrians.

Small animals are not detected by the object detection function, even if they are clearly visible in the image.

Limited detection, for instance in the following circumstances:

- People or animals who are fully or partially covered, especially when their heads are covered.
- ▶ People who are not in an upright position, for instance lying down.
- Cyclists on unconventional bicycles (e.g., recumbent bicycles).
- After physical damage to the system, for instance after an accident.

## Lane departure warning

### **Principle**

The lane departure warning alerts when the vehicle is about to run off the road or exit the lane.

### **General information**

This camera-based system warns starting at a minimum speed.

The minimum speed is country-specific and is displayed in the menu for the intelligent Safety systems.

Warnings are issued by means of a steering wheel vibration. The severity of the steering wheel vibration can be adjusted.

The system does not provide a warning if the turn signal is set in the respective direction before leaving the lane.

Depending on the equipment version, if in the speed range up to 130 mph/210 km/h a lane marking is crossed, the system may intervene with a brief active steering intervention in addition to vibrating. The system thus helps keep the vehicle in the lane

### **Safety information**



#### Marning

The system cannot serve as a substitute for the driver's personal judgment in assessing road and traffic situation. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate. Do not jerk the steering wheel in response to a warning.



#### Warning

Indicators and warnings cannot serve as a substitute for the driver's personal judgment. Due to its limits, the system may not issue warnings or reactions, or these may be issued late or in a manner that is not consistent with their normal use. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.

### **Functional requirement**

The camera must detect the lane markings for the lane departure warning to be active.

#### Overview

#### **Button in the vehicle**





Intelligent Safety

#### Sensors

The system is controlled by the following sensors:

Cameras behind the windshield.

Additional information:

Sensors of the vehicle, refer to page 37.

### **Turning on/off**

### Turning on automatically

The lane departure warning activates automatically after departure if the function was switched on at the completion of the last trip.

Depending on the national-market version, the system is automatically active after every driving off. The base setting is thereby activated.

### Switching on manually

Press the button.

The menu for the Intelligent Safety system is displayed.

If all Intelligent Safety systems were switched off, all systems are now switched on.

"Configure INDIVIDUAL": depending on the equipment version, the Intelligent Safety systems can be individually configured. The individual settings are activated and stored. As soon as a setting is changed on the menu, all settings of the menu are activated.

Press the button repeatedly.

The following settings are switched between:

"ALL ON": all Intelligent Safety systems are switched on. Basic settings are activated for the subfunctions.

"INDIVIDUAL": the Intelligent Safety systems are switched on according to the individual settings. Some Intelligent Safety systems cannot be individually switched off.

### **Manual switching off**

Press and hold this button.

All Intelligent Safety systems are switched off.

#### **Button Status**

- Button lights up green: all Intelligent Safety systems are switched on.
- Button lights up orange: some Intelligent Safety systems are switched off or currently unavailable.
- Button does not light up: all Intelligent Safety systems are switched off.

### **Setting the warning time**

- 1. "CAR"
- 2. "Settings"
- 3. "Driver Assistance"
- 4. "Safety and Warnings"
- 5. "Lane Departure Warning"
- 6. Select the desired setting:
  - ▶ "Earlv"
  - ▶ "Medium"
  - "Reduced": some warnings are suppressed depending on the situation, for instance when purposely driving over lane markings in curves or with dynamic passing without blinker.
  - "Off": no warnings are issued.

## Setting the intensity of the steering wheel vibration

- 1. "CAR"
- 2. "Settings"
- 3. "Driver Assistance"
- "Steering Wheel Feedback"
- 5. "Vibration intensity"
- Select the desired setting.

The setting is applied to all Intelligent Safety systems.

### Switch steering intervention on/off

The steering intervention can be switched on and off separately for Active Blind Spot Detection and lane departure warning.

- 1. "CAR"
- 2. "Settings"
- "Driver Assistance"
- 4. "Safety and Warnings"
- 5. "Lane Departure Warning"
- 6. "Steering intervention"

Depending on the national-market version, the steering intervention is automatically active after every driving off.

### Display in the instrument cluster



The icon illuminates green: at lane marking was detected on at least one side of the vehicle and warnings can be issued.

### **Warning function**

### If you leave the lane

If you leave the lane and if a lane marking has been detected, the steering wheel vibrates in accordance with the steering wheel vibration set-

When the turn signal is switched on in the corresponding direction before changing the lane, a warning is not issued.

### Steering intervention

Depending on the equipment version: if, in the speed range up to 130 mph/210 km/h a lane marking is crossed, the system may intervene with a brief active steering intervention in addition to vibrating. The steering intervention helps keep the vehicle in the lane. The steering intervention can be noticed on the steering wheel and can be manually overridden at any time. During an active steering intervention, the display in the instrument cluster will blink.

### Warning signal

Depending on the equipment version: in the event of multiple active steering interventions by the system within 3 minutes without the driver's intervention at the steering wheel, an acoustic warning will sound. A short warning signal will sound at the second steering intervention. Beginning with the third steering intervention, an continuous warning will sound.

In addition, a Check Control message is displayed.

The warning signal and Check Control message are an encouragement to pay closer attention to the lane.

### With trailer towing

If the trailer power socket is occupied or trailer towing is activated, for instance during operation with trailer or bicycle rack, no steering intervention takes place.

### **End of warning**

For instance, the warning will be canceled in the following situations:

- Automatically after a few seconds.
- ▶ When returning to your own lane.
- When braking hard.
- ▶ When blinking.
- ▶ The Dynamic Stability Control (DSC) adjusts.

### **System limits**

### Safety information



#### Warning

The system is designed to operate in certain conditions and circumstances. Due to conditions or other factors, the system may not respond. There may be a risk of accident or risk of damage to property. Actively intervene as warranted. Refer to the information in this Owner's Manual regarding the scope of the system's operation and limitations.

### **System limits of the sensors**

Additional information:

▶ Cameras, refer to page 37.

#### **Functional limitations**

The system may be limited in the following situations:

- ▶ In the event of missing, worn, poorly visible, merging, diverging, or multiple lane markings such as in construction areas.
- ▶ With lane boundaries that are covered in snow, ice, dirt or water.
- ▶ In tight curves or on narrow roads.
- ▶ With lane boundaries that are covered by ob-
- When driving very close to the vehicle in front of vou.
- ▶ Up to 10 seconds after the start of the engine via the Start/Stop button.

A Check Control message may be displayed when the system is not fully functional.


### **Active Blind Spot Detection**

### **Principle**

Active Blind Spot Detection detects vehicles in the blind spot or vehicles approaching from behind in the adjacent lane.

The light in the exterior mirror warns the driver in different steps.

### General information



Radar sensors monitor the area behind and next to the vehicle when traveling faster than a minimum speed.

The minimum speed is country-specific and is displayed in the menu for the intelligent Safety systems.

The system indicates whether there are vehicles in the blind spot, arrow 1, or approaching from behind in the adjacent lane, arrow 2.

The light in the exterior mirror lights up dimmed.

Before you change lanes after setting the turn signal, the system issues a warning in the situations described above.

The light in the exterior mirror flashes and the steering wheel vibrates.

Vehicles with side collision mitigation: at speeds of up to 130 mph/210 km/h, the system can intervene with a brief active steering intervention and help guide the vehicle back into the lane. The steering intervention occurs when a minimum speed is reached. This minimum speed is displayed on the Control Display in the menu for the steering intervention.

### **Safety information**



#### Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing visibility and traffic situation. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.




### Marning

Indicators and warnings cannot serve as a substitute for the driver's personal judgment. Due to its limits, the system may not issue warnings or reactions, or these may be issued late or in a manner that is not consistent with their normal use. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.

#### Overview

#### Button in the vehicle





#### **Sensors**

The system is controlled by the following sensors:

▶ Radar sensors, side, rear.

Additional information:

Sensors of the vehicle, refer to page 37.

### **Turning on/off**

### **Turning on automatically**

Active Blind Spot Detection is automatically activated after departure if the function was switched on at the completion of the last trip.

### Switching on manually

Press the button.

The menu for the Intelligent Safety system is displayed.

If all Intelligent Safety systems were switched off, all systems are now switched on.

"Configure INDIVIDUAL": depending on the equipment version, the Intelligent Safety systems can be individually configured. The individual settings are activated and stored. As soon as a setting is changed on the menu, all settings of the menu are activated.

Press the button repeatedly.

The following settings are switched be-

"ALL ON": all Intelligent Safety systems are switched on. Basic settings are activated for the subfunctions.

"INDIVIDUAL": the Intelligent Safety systems are switched on according to the individual settings.

Some Intelligent Safety systems cannot be individually switched off.

### **Manual switching off**

Safety

tween:

Press and hold this button.
All Intelligent Safety systems are switched off.

#### **Button Status**

- Button lights up green: all Intelligent Safety systems are switched on.
- Button lights up orange: some Intelligent Safety systems are switched off or currently unavailable.
- Button does not light up: all Intelligent Safety systems are switched off.

### **Setting the warning time**

- 1. "CAR"
- 2. "Settings"
- "Driver Assistance"
- 4. "Safety and Warnings"
- 5. "Active Blind Spot Detection"
- Select the desired setting.

## Setting the intensity of the steering wheel vibration

- 1 "CAR"
- 2. "Settings"
- "Driver Assistance"
- 4. "Steering Wheel Feedback"

- 5. "Vibration intensity"
- 6. Select the desired setting.

The setting is applied to all Intelligent Safety systems.

### Vehicles with side collision mitigation: switching steering intervention on/off

The steering intervention can be switched on and off separately for Active Blind Spot Detection and lane departure warning.

- 1. "CAR"
- 2. "Settings"
- 3. "Driver Assistance"
- 4. "Safety and Warnings"
- 5. "Active Blind Spot Detection"
- 6. "Steering intervention"

### **Warning function**

### Light in the exterior mirror



### **Prewarning**

The dimmed light in the exterior mirror indicates when there are vehicles in the blind spot or approaching from behind.

### **Acute warning**

When the turn signal is switched on while a vehicle is in the critical zone, the steering wheel vibrates briefly and the light in the exterior mirror flashes brightly.

The warning stops when the other vehicle has left the critical area or the turn signal has been deactivated.

### Vehicles with side collision mitigation

When there is no response to the vibration of the steering wheel at speeds of up to 130 mph/210 km/h and the lane marking is crossed, the system intervenes with a brief active steering intervention. The steering intervention helps return the vehicle into the lane. The steering intervention can be noticed on the steering wheel and can be manually overridden at any time.

### Flashing of the light

A flashing of the light during vehicle unlocking serves as system self-test.

### System limits

### **Safety information**



#### Marning

The system is designed to operate in certain conditions and circumstances. Due to conditions or other factors, the system may not respond. There may be a risk of accident or risk of damage to property. Actively intervene as warranted. Refer to the information in this Owner's Manual regarding the scope of the system's operation and limitations.

### **Upper speed limit**

If the vehicle speed exceeds approx. 155 mph/250 km/h, the system is deactivated temporarily.

If the vehicle speed falls below approx. 155 mph/250 km/h, the system once again responds according to the setting.

### **System limits of the sensors**

Additional information:

- ▶ Radar sensors, refer to page 38.
- On vehicles with side collision warning: cameras, refer to page 37.

#### **Functional limitations**

The system may be limited in the following situations:

- ▶ When a vehicle is approaching at a speed much faster than your own.
- ▶ In tight curves or on narrow roads.
- ➤ The bumper is dirty, iced up or covered, for instance by stickers.

For vehicles with side collision mitigation, the steering intervention can be limited, for instance in the following situation:

- In the event of missing, worn, poorly visible, merging, diverging, or multiple lane markings such as in construction areas.
- ▶ With lane boundaries that are covered in snow, ice, dirt or water.
- With lane boundaries that are not white.
- With lane boundaries that are covered by objects.
- When driving very close to the vehicle in front of you.
- ▶ If the camera is impaired.
- ▶ Up to 10 seconds after the start of the engine via the Start/Stop button.

A Check Control message is displayed when the system is not fully functional.

If the trailer power socket is occupied or trailer towing is activated, for instance during operation with trailer or bicycle rack, the system cannot be switched on. A Check Control message is displayed.

### **Displaying warnings**

Depending on the selected warning settings, e.g., warning time, more or fewer warnings can


be displayed. However, there may also be an excess of premature warnings of critical situations.

## Side collision mitigation

### **Principle**

The side collision warning helps to avoid imminent side collisions.

#### **General information**



Radar sensors monitor the space next to the vehicle when traveling faster than a minimum speed of up to approx. 130 mph/210 km/h.

The minimum speed is country-specific and is displayed in the menu for the intelligent Safety systems.

The front camera determines the lane marking positions.

If, for instance, another vehicle is detected next to the vehicle and if there is a risk of collision with this vehicle, the system helps avoid the collision. For this purpose, the system issues a warning with a blinking LED in the exterior mirror and a vibrating steering wheel. If necessary, the system will carry out an active steering intervention.

### **Safety information**

#### Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing visibility and traffic situation. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.

### Marning

Indicators and warnings cannot serve as a substitute for the driver's personal judgment. Due to its limits, the system may not issue warnings or reactions, or these may be issued late or in a manner that is not consistent with their normal use. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.

### **Functional requirement**

The camera must detect the lane markings for the side collision mitigation with steering intervention to be active.

### Overview

#### **Button in the vehicle**



(8)

Intelligent Safety

#### Sensors

The system is controlled by the following sen-

- Cameras behind the windshield.
- ▶ Radar sensors, side, front.
- ▶ Radar sensors, side, rear.

Additional information:

Sensors of the vehicle, refer to page 37.

### **Turning on/off**

### Turning on automatically

The side collision mitigation activates automatically after departure if the function was switched on at the completion of the last trip.

### Switching on manually



Press the button.

The menu for the Intelligent Safety system is displayed.

If all Intelligent Safety systems were switched off, all systems are now switched on.

"Configure INDIVIDUAL": depending on the equipment version, the Intelligent Safety systems can be individually configured. The individual settings are activated and stored. As soon as a setting is changed on the menu, all settings of the menu are activated.



Press the button repeatedly.

The following settings are switched be-

tween:

"ALL ON": all Intelligent Safety systems are switched on. Basic settings are activated for the subfunctions.


"INDIVIDUAL": the Intelligent Safety systems are switched on according to the individual settings.


Some Intelligent Safety systems cannot be individually switched off.


### Manual switching off

Press and hold this button.
All Intelligent Safety systems are switched off.

#### **Button Status**







## Setting the intensity of the steering wheel vibration

- 1. "CAR"
- 2. "Settings"
- 3. "Driver Assistance"
- 4. "Steering Wheel Feedback"
- 5. "Vibration intensity"
- 6. Select the desired setting.

The setting is applied to all Intelligent Safety systems.

### **Warning function**

### Light in the exterior mirror



#### **Acute warning**

If there is a risk of collision, the light in the exterior mirror flashes and the steering wheel vibrates.

A Check Control message is displayed at the same time.

If necessary, an active steering intervention takes place to prevent the collision and maintain the vehicle within its own lane.

The steering intervention can be noticed on the steering wheel and can be manually overridden at any time.

### **System limits**

### **Safety information**

### Marning

The system is designed to operate in certain conditions and circumstances. Due to conditions or other factors, the system may not respond. There may be a risk of accident or risk of damage to property. Actively intervene as warranted. Refer to the information in this Owner's Manual regarding the scope of the system's operation and limitations.

### System limits of the sensors

Additional information:

- ▶ Cameras, refer to page 37.
- Radar sensors, refer to page 38.

#### **Functional limitations**

The system may be limited in the following situations:

- When a vehicle is approaching at a speed much faster than your own.
- ▶ In tight curves or on narrow roads.
- In the event of missing, worn, poorly visible, merging, diverging, or multiple lane markings such as in construction areas.

- ▶ With lane boundaries that are covered in snow, ice, dirt or water.
- ▶ With lane boundaries that are covered by obiects.
- ▶ When driving very close to the vehicle in front of you.
- ▶ Up to 10 seconds after the start of the engine via the Start/Stop button.

A Check Control message is displayed when the system is not fully functional.


If the trailer power socket is occupied or trailer towing is activated, for instance during operation with trailer or bicycle rack, the system cannot be switched on, A Check Control message is displayed.

## **Rear-end collision** preparation

### **Principle**

Depending on the equipment and national-market version, the rear-end collision preparation can react to vehicles approaching from behind.

### General information



Radar sensors monitor the area behind the vehicle.

When a vehicle approaches from the rear at a certain speed, the system can react as as follows:

- ▶ Where applicable, the hazard warning flashers will be switched on.
- ▶ Where applicable, the PreCrash functions are triggered.

### **Safety information**



#### Marning

The system cannot serve as a substitute for the driver's personal judgment in assessing visibility and traffic situation. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.

#### Marning

Indicators and warnings cannot serve as a substitute for the driver's personal judgment. Due to its limits, the system may not issue warnings or reactions, or these may be issued late or in a manner that is not consistent with their normal use. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.

### Overview

#### Sensors

The system is controlled by the following sensors:

▶ Radar sensors, side, rear.

Additional information:

Sensors of the vehicle, refer to page 37.

### Switching on/off

The system is automatically active when the vehicle is turned on.

The system is deactivated in the following situations:

- ▶ When driving in reverse.
- When the trailer power socket is in use or trailer towing is activated, for instance during operation with trailer or bicycle rack.

### **System limits**

### System limits of the sensors

Additional information:

▶ Radar sensors, refer to page 38.

### **Functional limitations**

The system may not be fully functional in the following situations:

- ▶ When a vehicle is approaching at a speed much faster than your own.
- ➤ The approaching vehicle is approaching slowly.

# If equipped with Equipment Stop Assistant

### **Principle**

If the driver is no longer fit to drive, the Emergency Stop Assistant helps to safely bring the vehicle to a standstill.

### **General information**

The emergency stop function is not triggered automatically. The emergency stop function can only be triggered manually by the occupants.

When the system is activated, the vehicle is brought to a standstill in its own lane by use of lane guidance.

Depending on the equipment version and national market version, the system includes a lane change function.

With lane change function: on motorways or motorway-like roads, the system steers the vehicle to the side of the road or shoulder where possible. On other roads or under high traffic condi-

tions, the vehicle is brought to a standstill on the actual road.

### **Overview**





Parking brake

### **Functional requirements**

- The function can be activated at speeds of approx. 6 mph/10 km/h up to approx. 155 mph/250 km/h.
- With lane change function: lane changes are executed when the traffic situation allows.

# Activating the emergency stop function

- **(P)** 
  - Pull the switch for the parking brake briefly to activate the emergency stop function.
- ▶ With lane change function: releasing the switch may trigger an automatic lane change.
- ➤ The system will take control of the vehicle for a maximum of 2 minutes.
- ▶ The hazard warning system is switched on.
- An emergency call is triggered.

# **Canceling the emergency stop function**

The driver can cancel the emergency stop function by actively taking control of the vehicle throughout the entire process.

For instance, the emergency stop function will be canceled in the following situations:

- When steering.
- ▶ When blinking.
- ▶ When depressing the accelerator pedal.
- ▶ When switching off the hazard warning system.
- ▶ When canceling the Emergency Request.
- When switching the selector lever position at standstill.
- ▶ When the switch of the parking brake is pressed.

### At standstill

As soon as the vehicle is stationary, the system will carry out the following settings:

- ▶ The vehicle is secured against rolling away.
- ▶ The interior lights are switched on.
- The central locking system is unlocked.

# Displays in the instrument cluster

### Icon Status



Emergency Stop function active.

Without lane change function:

### Icon Status



Green steering wheel symbol:

When lane markings are detected, the system keeps the vehicle in the lane.



Gray steering wheel symbol: Lane guidance is briefly interrupted.



Yellow steering wheel symbol:

Lane marking driven over.

When lane markings are detected, the system keeps the vehicle in the lane.

### Icon Status



Yellow steering wheel symbol:

The hands are not grasping the steering wheel. The system is still active.



Red steering wheel symbol and a signal sounds:

The hands are not grasping the steering wheel. Interruption of lane guidance is imminent.



Red steering wheel symbol and a signal sounds:

Lane guidance is switched off.

### **System limits**

Use the system only in the event of a driver failure.

The system cannot replace the driving performance of a driver who is fit to drive.

### **BMW Drive Recorder**

### **Principle**

The BMW Drive Recorder stores brief video recordings of the vehicle surroundings, e.g., to document surrounding traffic.

### **General information**

There are various ways for storing video recordings:

- Automatic storage of the recording. The function allows the documentation of the event of an accident.
- Manual storage of the recording. The function allows the documentation of traffic situations.

The system records up to 20 seconds before and after the activation of the storage.

Cameras of the assistance systems are used, for instance Panorama View.

Additionally, the following parameters are stored for the trip:

- Date.
- Time.
- ▶ Vehicle speed.
- ▶ Global Positioning System coordinates.

### **Data protection**

The permissibility of recording and using video recordings is contingent upon the statutory regulations of the country in which the system is to be used. The user is responsible for the use of the system and compliance with the respective regulations.

The manufacturer of the vehicle recommends confirming there are no statutory or regulatory constraints on use of the system in your state or country prior to the initial use. In addition, the laws with respect to use of the system should be verified in regular intervals, especially when borders are frequently crossed.

Other drivers of the vehicle must be informed about the system. In addition, information about the system is required when handing off the vehicle.

### **Functional requirements**

- BMW Drive Recorder is activated.
- Privacy Policy accepted.
- Recording type selected.
- Recording time selected.

# Activating/deactivating the BMW Drive Recorder

The BMW Drive Recorder must be activated before the first use of the recording function.

- 1. "Apps"
- 2. "Drive Recorder"
- 3. Accept Privacy Policy.
- 4. "Settings"

- 5. "Recording allowed"
- 6. Select the desired setting.

### **Recording functions**

### **Automatic recording**

The recording is stored automatically when the vehicle sensors detect an accident occurrence.

### **Manual recording**

### Using the button



Press and hold this button.

### Via iDrive

- 1. "Apps"
- 2. "Drive Recorder"
- 3. "Start recording"

To stop the recording: "Cancel".

Recording can also be started by selecting the widget on the Control Display.

# Recording playback and administration

Stored video recordings can be played back, exported and deleted.

For your own safety, the video recording is only displayed on the Control Display up to approx. 2 mph/3 km/h. In some national-market versions, the video recording is only displayed if the parking brake is engaged or if the selector lever is in

- 1. "Apps"
- 2. "Drive Recorder"
- 3. "Saved recordings"

selector lever position P.

- 4. Select desired recording.
- 5. Select the desired setting.

If a camera change occurred during the recording, different segments of the video can be selected.

### **Settings**

### General information

Different settings can be made.

### Recording type

- 1. "Apps"
- 2. "Drive Recorder"
- 3. "Settinas"
- 4. "RECORDING TYPE"
- 5. Select the desired setting.

### Recording time

- 1. "Apps"
- 2. "Drive Recorder"
- 3. "Settinas"
- 4. Select the desired setting.

### **Cameras**

- 1. "Apps"
- 2. "Drive Recorder"
- 3. "Settings"
- 4. "Camera selection"
- Select desired camera.

In case of an accident, the system switches automatically to "All" cameras.

If driver assistance systems are active, their camera views are selected automatically.

### **System limits**

In the event of serious accidents, it may not be possible to store recordings if the damage on the vehicle is too great or the power supply was interrupted.

### **Active Protection**

### **Principle**

Active Protection prepares occupants and the vehicle for a possible accident in critical driving or collision situations.

### **General information**

Depending on the equipment and national-market version. Active Protection consists of various PreCrash functions.

The system is used to detect certain critical driving situations that might lead to an accident. This includes the following critical driving situations:

- Emergency stop.
- Severe understeering.
- Severe oversteering.

Certain functions of several systems can, within the system limits, lead to Active Protection triggering:

- Forward Collision Warning: automatic brake intervention.
- ▶ Front collision mitigation: Brake Assistant
- Night Vision with pedestrian and animal detection: Brake Assistant.
- ▶ Rear collision preparation: detection of imminent rear collisions.

### Safety information



### Marning

The system cannot serve as a substitute for the driver's personal judgment. Due to the system limits, critical situation could not be detected reliably or in time. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.

### **Function**

When the safety belt is fastened, the driver's and front passenger's belt straps are automatically tightened once after driving away.

In accident-critical situations, the following individual functions become active as needed:

- Automatic pretensioning of the front safety
- Automatic window closing up to a narrow
- Automatic closing of the panoramic glass sunroof, including sun protection.
- ▶ For vehicles equipped with comfort seats in the front: automatic positioning of the backrest for the front passenger seat.

After a critical driving situation without an accident, the front safety belts are loosened again.

If the belt tension does not loosen automatically. stop the vehicle and unbuckle the safety belt using the red button in the buckle. Fasten the safety belt before continuing on your trip.

All other systems can be restored to the desired setting.

### PostCrash - iBrake

### **Principle**

In the event of an accident, PostCrash can bring the vehicle to a halt automatically without intervention by the driver in certain situations.

### General information

PostCrash can reduce the risk of another collision and subsequent consequences.

### At standstill

After coming to a halt, the brake is released automatically.

### Harder vehicle deceleration

In certain situations, it can be necessary to bring the vehicle to a halt more quickly than the Brake Assistant allows.

To do this, quickly apply extra force to the brake. For a brief period, the braking pressure will be higher than the braking pressure that is achieved by the automatic braking function. Automatic braking is interrupted.

### Interrupting automatic braking

It can be necessary to interrupt automatic braking in certain situations, for instance for an evasive maneuver.

Interrupt automatic braking:

- By pressing the brake pedal.
- By pressing the accelerator pedal.

### **Fatigue alert**

### **Principle**

The Fatigue Alert can detect decreasing alertness or fatigue of the driver during long, monotonous trips, for instance on highways. The system recommends a break.

### **Safety information**



### 🔼 Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing one's physical state. An increasing lack of alertness or fatique may not be detected or not be detected in time. There is a risk of accident. Make sure that the driver is rested and alert. Adjust driving style to traffic conditions.

### **Function**

The system is switched on each time drive-ready state is switched on.

After travel has begun, the system monitors certain aspects of the driver's behavior, so that decreasing alertness or fatigue can be detected.

This procedure takes the following criteria into account:

- Personal driving style, for instance steering behavior.
- Driving conditions, for instance time, length of trip.
- Depending on the equipment: attention of the driver through the Driver Attention Camera.

Starting at approx. 43 mph/70 km/h, the system is active and can also display a recommendation to take a break.

### **Break recommendation**

### **Adjusting**

The fatigue alert is active automatically with each switching on of drive-ready state and can thus display a break recommendation.

The break recommendation can also be switched on or off and adjusted via iDrive.

- 1. "CAR"
- 2. "Settinas"
- 3. "General settings"
- 4. "Fatigue and Focus Alert"
- 5. Select the desired setting.

### Display

If the driver becomes less alert or fatigued, a message is displayed in the Control Display with the recommendation to take a break.

During the display, various settings can be selected.

After a break, another recommendation to take a break cannot be displayed until after approximately 45 minutes.

### **System limits**

The function may be limited in the following situations and may issue an incorrect warning or no warning at all:

- When the time is set incorrectly.
- ▶ When the vehicle speed is mainly below about 43 mph/70 km/h.
- With a sporty driving style, such as during rapid acceleration or when cornering fast.
- ▶ In active driving situations, such as when changing lanes frequently.
- ▶ When the road condition is poor.
- In the event of strong side winds.

The system is reset approx. 45 minutes after parking the vehicle, for instance in the case of a break during longer trips on highways.

# **Driving stability control systems**

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

# Antilock Braking System ABS

The Antilock Braking System (ABS) prevents locking of the wheels during braking.

The vehicle maintains its steerability even during emergency braking, which increases the active driving safety.

ABS is operational every time you start the engine.

### **Brake assistant**

The Brake Assistant effects maximum braking assistance when the brake is applied quickly. It reduces the braking distance to a minimum during emergency braking. The advantages of the Antilock Braking System (ABS) are thereby utilized.

Do not reduce the pressure on the brake pedal for the duration of emergency braking.

### Adaptive brake assistant

In combination with Active Cruise Control ACC, this system ensures that the brakes respond even more rapidly when braking in critical situations.

### **Drive-off assistant**

### **Principle**

The drive-off assistant supports driving off on uphill grades.

### **Driving off**

- 1. Hold the vehicle in place with the foot brake.
- Release the foot brake and drive off without delay.

After the foot brake is released, the vehicle is held in place for approx. 2 seconds.

Depending on the vehicle loading or when a trailer is used, the vehicle may roll back slightly.

# DSC Dynamic Stability Control

### **Principle**

The Dynamic Stability Control (DSC) helps to keep the vehicle on a steady course by reducing drive power and by brake intervention on individual wheels.

### **General information**

DSC detects the following unstable driving conditions, for instance:

- ▶ Skidding, which can lead to oversteering.
- Loss of adhesion of the front wheels, which can lead to understeering.

### **Safety information**



### Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident, Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.



### Warning

When driving with a roof load, for instance with roof-mounted luggage rack, the vehicle's center of gravity is higher, which increases the risk of the vehicle tipping in critical driving situations. There may be a risk of accident or risk of damage to property. Driving with roof load only with activated Dynamic Stability Control.

### Overview

### **Button in the vehicle**





DSC OFF

### **Deactivating/activating DSC**

### **General information**

When DSC is deactivated, driving stability is reduced during acceleration and when driving in curves.

To increase driving stability, activate DSC again as soon as possible.

### **Deactivating DSC**



Hold the button down until DSC OFF is displayed in the instrument cluster and

the DSC OFF indicator light is illuminated.

### **Activating DSC**



Press the button.

DSC OFF and the DSC OFF indicator light turn off.

### **Display**

### In the instrument cluster

When DSC is deactivated, DSC OFF is displayed in the instrument cluster.

### **Indicator/warning lights**



The indicator light lights up: DSC is deactivated.



The indicator light flashes: DSC controls the drive and braking forces.

The indicator light lights up: DSC has malfunctioned.

# **DTC Dynamic Traction Control**

### **Principle**

Dynamic Traction Control (DTC) is a version of the Dynamic Stability Control (DSC) where drive power is optimized.

The system ensures maximum drive power on unusual road conditions, for instance unplowed snow covered roads, or loose road surfaces, but with somewhat limited driving stability.

### **General information**

When DTC is activated, the vehicle has maximum traction. Driving stability is limited during acceleration and when driving in curves.

You may find it useful to briefly activate DTC in the following situations:

- When driving in slush or on uncleared, snowcovered roads.
- ▶ When driving off from deep snow or loose ground.
- ▶ When driving with tire chains.

### Overview

### **Button in the vehicle**





DSC OFF

### **Activating/deactivating DTC**

### **Activating DTC**

Press the button.

TRACTION is displayed in the instrument cluster and the indicator light for DSC OFF lights up.

### **Deactivating DTC**

₽off

Press the button again.

TRACTION and the DSC OFF indicator light turn off.

### **Display**

### Display in the instrument cluster

If DTC is activated, TRACTION is displayed in the instrument cluster.

### **Indicator/warning lights**



The indicator light lights up: DTC is activated.

### **Automatic program change**

In certain situations, the Dynamic Stability Control (DSC) is activated automatically:

- ▶ If Active Cruise Control with Stop&Go function ACC is activated.
- On a brake intervention by the Intelligent Safety systems.
- ▶ The vehicle has a flat tire.

### **xDrive**

### **Principle**

xDrive is the all-wheel-drive system of the vehicle. Concerted action by the xDrive and and other suspension control systems, such as Dynamic Stability Control (DSC), further optimizes traction and driving dynamics.

### **General information**

xDrive variably distributes the driving power to the front and rear axles as demanded by the driving situation and road condition.

The Driving Dynamics Control is used to change the all-wheel distribution from traction oriented to sport oriented.

With the xOffroad package, the all-wheel-drive system is additionally adjusted for the respective xOffroad driving mode.

Because of the needs-based use of the allwheel-drive system, Efficient4x4 yields a reduction in consumption.

### **Display on the Control Display**

### Display xView display

- 1. "CAR"
- 2. "Driving information"
- 3. "xVIEW"

or

"xOFFROAD"

The following information is displayed:

- With a navigation system: compass display for the driving direction.
- ▶ With navigation system: elevation for the current position.
- ▶ With navigation system: destination flag in compass direction to the destination.
- ▶ Pitch attitude with degree indication and percentage.
- ▶ Transverse gradient with degree indication.
- Graphic display for the steering angle.
- Level adjustment of the two-axle ride level control.

With the xOffroad package, the following additional information can be displayed:

- ▶ With Surround View: depending on the speed, terrain-specific camera perspectives.
- > xOffroad driving mode currently active.
- Distribution of drive torque to the wheels.

### **Display in the Head-up Display**

Some of the information can also be displayed in the Head-up Display.

### M sport differential

The active M differential provides for continuously variable locking of the rear axle differential depending on the driving situation. This prevents spinning of a single rear wheel and thereby provides optimal traction in any driving situation.

The driver is responsible adapting his or her driving style to the situation.

# Automatic Differential Brake

### **Principle**

Automatic Differential Brake controls the driving power by automatic brake intervention on individual wheels.

### **General information**

The function works in the same way as a differential lock and improves traction on a loose surface, for example. The system detects when a wheel begins to spin and automatically brakes this wheel.

The driving force is diverted to the wheel with better traction.

As a result, the drive torque is transferred more efficiently to the wheels during accelerations.

### **HDC Hill Descent Control**

### **Principle**

HDC Hill Descent Control is a downhill control feature that controls the vehicle speed on steep downhill grades, for instance when driving on unpaved roads.

### **General information**

When the system is active, the vehicle moves at the speed set by the driver, without the driver having to depress the brake pedal.

While HDC is controlling the speed, the system automatically distributes the braking force to the individual wheels. This improves vehicle drivability and driving stability. If necessary, the Antilock Braking System prevents the wheels from locking.

Hill Descent Control can be activated at speeds below approx. 25 mph/40 km/h.

Speeds can be set between approx. 2 mph/3 km/h and approx. 20 mph/30 km/h. When the vehicle is driving downhill, the system reduces the speed to the set value, within the physical limits.

### **Overview**

### **Button in the vehicle**





### **Activating HDC**



Press the button.

The LED on the button lights up.

Speeds between approx. 2 mph/3 km/h and approx. 20 mph/30 km/h are adopted as the set speed.

Emergency braking function, Active PDC: the emergency braking function is deactivated.

Additional information:

Emergency brake function, Active PDC, refer to page 257.

### Display in the instrument cluster



An icon and the selected desired speed are displayed.

- Indicator green: HDC is active. The system is actively braking the vehicle.
- ▶ Gray display: HDC is on standby.

### **Display in the Head-up Display**

The HDC status can also be displayed in the Head-up Display.

# Increasing or decreasing vehicle speed

# Using the cruise control rocker switch

The set speed can be changed using the cruise control rocker switch on the steering wheel.



- Press the rocker switch up: the speed increases gradually.
- Press the rocker switch up and hold: the speed increases while the rocker switch is pressed.
- Press the rocker switch down: the speed decreases gradually.
- Press the rocker switch down and hold: the speed decreases while the rocker switch is pressed.

### Using the brake pedal

While HDC is controlling the speed, the set speed can be reduced by depressing the brake pedal.

### **Deactivating HDC**



Press the button again.

The LED goes out.

HDC is automatically deactivated above approx. 25 mph/40 km/h.

### **Malfunction**

If a malfunction occurs, a message is displayed in the instrument cluster.

### **Integral Active Steering**

### **Principle**

The Integral Active Steering increases the maneuverability and makes a more direct steering response possible.

### **General information**

Integral Active Steering is a combination of variable steering ratio and rear axle steering.

The steering is more direct because the variable steering ratio amplifies the wheel angle while maneuvering. The rear axle steering acts to increase maneuverability at low speeds by turning the rear wheels slightly in the opposite direction to the front wheels.

At higher speeds, the rear wheels are turned in the same direction as the front wheels. For instance, this results in a harmonious lane change.

In critical driving situations, the Integral Active Steering can stabilize the vehicle through purposeful steering of the rear wheels before the driver intervenes, for instance in case of oversteering.

### **Tuning**

The system offers several different tunings.

Driving mode	Integral Active Steering
COMFORT ECO PRO	Comfortable, for optimal travel comfort.
SPORT	Dynamic, for greater agility.

The different tunings are assigned to the different driving modes of the Driving Dynamics Control.

Additional information:

Driving Dynamics Control, refer to page 144.

### **Using tire chains**

In order to guarantee free movement of the wheels when operating with tire chains, rear axle steering of the integral active steering must be switched off when tire chains are mounted.

Additional information:

Rear axle steering during operation with tire chains, refer to page 365.

### **Malfunction**

In the event of a malfunction, the steering wheel must be turned further at lower speeds, while the vehicle responds more sensitively to steering wheel movements in the higher speed range.

The stability-enhancing intervention may be deactivated.

Proceed cautiously and drive defensively.

Have the system checked by a dealer's service center or another qualified service center or repair shop.

# **Driver assistance systems**

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

### **Manual Speed Limiter**

### **Principle**

The system can be used to set a speed limit, for instance to prevent the vehicle from exceeding speed limits.

### **General information**

The system can limit the speed, starting at a value of 20 mph/30 km/h. The vehicle can be driven at any speed below the set speed limit.

### Overview

### **Buttons on the steering wheel**

Rocker switch:

# Button Function System on/off. SET Store current speed. Speed Limit Assistant: accept suggested speed manually.

Changing the speed limit.

### **Operation**

### **Turning on**



Press the button on the steering wheel.

The current speed is accepted as the speed limit.

If the system is switched on while the vehicle is stationary or driving at low speeds,

20 mph/30 km/h is set as the speed limit.

The marking in the speedometer is set to the corresponding speed.

When the speed limit is switched on, DSC Dynamic Stability Control and COMFORT driving mode may be switched on as well.

### **Turning off**



Press the button on the steering wheel.

The system switches off automatically in the following situations, for example:

- ▶ When the engine is switched off.
- When cruise control is switched on.
- ▶ When certain programs are activated via the Driving Dynamics Control.

The displays turn off.

### Interrupting

If the reverse gear is engaged or at idle, the system is interrupted when rolling backwards.

### Changing the speed limit



Press the rocker switch up or down repeatedly until the desired speed limit is set.

- ▶ Each time the rocker switch is pressed to the resistance point, the speed limit increases or decreases by 1 mph/1 km/h.
- ▶ Each time the rocker switch is pressed past the resistance point, the desired speed changes by a maximum of 5 mph/10 km/h.

If the set speed limit is reached or unintentionally exceeded, such as when driving downhill, the vehicle is not actively braked.

When the speed limit is set during a trip to a value below the current speed, the vehicle coasts until it drops to the set speed limit.

The current speed can also be stored by pressing a button:



Press the button on the steering wheel.

### **Exceeding the speed limit**

When the vehicle speed exceeds the set speed limit, a warning is issued.

The speed limit can be exceeded intentionally. There is no warning in this case.

Press the accelerator pedal all the way down to intentionally exceed the set speed limit.

When the vehicle speed drops below the set speed limit, the limit is automatically reactivated.

### Warning when the speed limit is exceeded

### Visual warning



If the speed limit is exceeded: the indica-CLIM tor light in the instrument cluster flashes while the vehicle speed is greater than

the set speed limit.

### **Acoustic warning**

- ▶ If the speed limit is exceeded unintentionally, a signal sounds.
- ▶ When the speed limit is reduced to below the vehicle speed while driving, the signal sounds after some time.
- ▶ When the speed limit is intentionally exceeded by stepping on the accelerator pedal all the way down, there is no signal.

### **Displays in the instrument** cluster

### Display in the speedometer

Depending on the equipment, a mark in the speedometer displays the status of the system.



- ▶ Green marking: system is ac-
- ▶ Grey marking: system is interrupted.
- ▶ No marking: system is switched off.

### **Indicator light**



- ▶ The indicator light lights up: the system is switched on.
- ▶ The indicator light flashes: the set speed limit has been exceeded.
- ▶ Gray indicator light: the system has been interrupted.

### Cruise control

### **Principle**

With the Cruise Control, a set speed can be adiusted using the buttons on the steering wheel. The system maintains the set speed. The system accelerates and brakes automatically as needed.

### General information

The system can be activated starting at 20 mph/30 km/h.

Depending on the vehicle setting, the cruise control settings may change under certain conditions. For instance, acceleration can change depending on the driving mode.

### **Safety information**



### Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.

### Warning

The use of the system can lead to an increased risk of accidents in the following situations, for instance:

- ▶ On winding roads.
- ▶ In heavy traffic.
- > On slippery roads, in fog, snow, or wet conditions, or on a loose road surface.

There may be a risk of accident or risk of damage to property. Only use the system if driving at constant speed is possible.

### Marning

The set speed can be incorrectly adjusted or called up by mistake. There is a risk of accident. Adjust the set speed to the traffic conditions. Watch traffic closely and actively intervene where appropriate.

### Overview

### **Buttons on the steering wheel**

### **Button Function**



Cruise control on/off.



Continue cruise control with the last setting.

Pause cruise control.

SET

Store current speed.

Speed Limit Assistant: accept suggested speed manually.



Rocker switch:

Set speed.

### Switching cruise control on/off

### Turning on



Depending on the equipment version, press the relevant button on the steering wheel.



The indicator lights in the instrument cluster light up and the marking on the speedometer is set to the current speed.

Cruise control is active. The current speed is maintained and stored as set speed.

DSC Dynamic Stability Control is switched on, if necessary.

### **Turning off**



Depending on the equipment version, press the relevant button on the steering wheel.



The displays turn off. The stored set speed is deleted.

### Pausing cruise control

### Interrupting manually



When active, press the button.

### Interrupting automatically

The system is automatically interrupted in the following situations, for example:

- When braking manually.
- ▶ Gear lever position D is disengaged.
- Dynamic Traction Control DTC is activated or DSC Dynamic Stability Control is deactivated.
- ▶ The Dynamic Stability Control (DSC) adjusts.

### **Setting the speed**

### Maintaining and storing the speed



Press the rocker switch up or down once while the system is interrupted.

When the system is switched on, the current speed is maintained and stored as the set speed.

The stored speed is displayed on the speedometer.

DSC Dynamic Stability Control is switched on, if necessary.

The speed can also be stored by pressing a button.



Press the button.

### Changing the speed



Press the rocker switch up or down repeatedly until the desired speed is set.

If active, the displayed speed is stored and the vehicle reaches the stored speed when the road is clear.

- ▶ Each time the rocker switch is tapped to the resistance point, the set speed increases or decreases by 1 mph/1 km/h.
- ▶ Each time the rocker switch is pressed past the resistance point, the desired speed changes by a maximum of 5 mph/10 km/h.
  - The maximum speed that can be set depends on the vehicle.
- Pressing the rocker switch to the resistance point and holding it: vehicle accelerates or decelerates without pressure on the accelerator pedal.

After the rocker switch is released, the vehicle maintains its final speed. Pressing the switch beyond the resistance point causes the vehicle to accelerate more rapidly.

### **Continuing cruise control**

An interrupted cruise control can be continued by calling up the stored speed.

Make sure that the difference between current speed and stored speed is not too large before calling up the stored speed. Otherwise, unintentional deceleration or acceleration may occur.



Press the button with the system interrupted.

Cruise control is continued with the stored values.

In the following cases, the stored speed value is deleted and cannot be called up again:

- ▶ When the system is switched off.
- ▶ When drive-ready state is switched off.

# Displays in the instrument cluster

### Display in the speedometer

Depending on the equipment, a mark in the speedometer displays the status of the system.



- Green marking: system is active, the marking indicates the desired speed.
- Grey marking: system is interrupted, the marking indicates the stored speed.
- ▶ No marking: system is switched off.

### Indicator light



- Indicator light green: system is active.
- ▶ Gray indicator light: the system has been interrupted.
- ▶ No indicator light: system is switched off.

### **Displays in the Head-up Display**

Some system information can also be displayed in the Head-up Display.



The icon is displayed when the set speed is reached.

### **System limits**

The set speed is also maintained downhill. The speed may not be maintained on uphill grades if the drive power is insufficient.

In ECO PRO driving mode, the vehicle may exceed or drop below the set desired speed in some situations, for instance on downhill or uphill grades.

# Active Cruise Control with Stop&Go function ACC

### **Principle**

Using the Cruise Control, a desired speed and a distance to a vehicle ahead can be adjusted using the buttons on the steering wheel.

### **General information**

The system maintains the set speed on clear roads. The vehicle accelerates or brakes automatically.

If a vehicle is driving ahead of you, the system adjusts the speed of your vehicle so that the set distance to the vehicle ahead is maintained. The speed is adjusted as far as the given situation allows.

The distance can be adjusted in several steps. For safety reasons, it depends on the respective speed.

If the vehicle ahead of you brakes to a halt, and then proceeds to drive again within a brief period, the system is able to detect this within the given system limits.

Depending on the vehicle setting, the cruise control settings may change under certain conditions. For instance, acceleration can change depending on the driving mode.

### **Safety information**



### Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.

### Warning

An unsecured vehicle can begin to move and possibly roll away. There is a risk of accident. Before exiting, secure the vehicle against rolling.

In order to ensure that the vehicle is secured against rolling away, follow the following:

- Set the parking brake.
- > On uphill grades or on a downhill slope, turn the front wheels in the direction of the curb.
- > On uphill grades or on a downhill slope, also secure the vehicle, for instance with a wheel chock.

### 🛕 Warning

The set speed can be incorrectly adjusted or called up by mistake. There is a risk of accident. Adjust the set speed to the traffic conditions. Watch traffic closely and actively intervene where appropriate.

### Marning

Risk of accident due to too high speed differences to other vehicles, for instance in the following situations:

- ▶ When fast approaching a slowly moving vehicle.
- ▶ Vehicle suddenly swerving into own lane.
- ▶ When fast approaching standing vehicles.

There is a risk of injury or danger to life. Watch traffic closely and actively intervene where appropriate.

### **Overview**

### **Buttons on the steering wheel**

### **Button Function**



With steering and traffic jam assistant: Cruise control on/off.



With steering and traffic jam assistant: Select function.



Without steering and traffic jam assis-

Cruise control on/off.

**SET** 

Store current speed.

Speed Limit Assistant: accept suggested speed manually.

RES

With steering and traffic jam assistant: Pause cruise control.

Continue cruise control with the last setting.

Without steering and traffic jam assis-

Continue cruise control with the last setting.

Without steering and traffic jam assistant:

Pause cruise control.



Increase the distance.

Switch distance control on/off

### **Button Function**



Reduce distance.

Switch distance control on/off.



Rocker switch:

Set speed.

### Sensors

The system is controlled by the following sensors:

- Cameras behind the windshield.
- Front radar sensor.

Additional information:

Sensors of the vehicle, refer to page 37.

### **Application range**

The system is best used on well-constructed roads.

The minimum speed that can be set is 20 mph/30 km/h.

The maximum speed that can be set is limited and, e.g., depends on the vehicle and the vehicle equipment.

The system can also be activated when stationary.

### **Turning on/off and interrupting** cruise control

### With steering and traffic jam assistant: Assisted Driving Mode

### General information



This button is used to switch the confiaured function on and off.



The button can be used to set the primarily used function.

### Set function



When the system is active, press the button repeatedly until the desired func-

tion is selected in the toolbar. The toolbar for Assisted Driving mode is displayed at the bottom of the instrument cluster.

### Icon **Function**



Cruise control with distance control.



Depending on the equipment version, cruise control with distance control and steering and traffic jam assistant.



The selected function is shown in green.

### **Turning on**

With steering and traffic jam assistant:



Press the button on the steering

MODE If necessary, set the cruise control. Without steering and traffic jam assistant:



Press the button on the steering wheel.

The indicator lights in the instrument cluster light up and the marking on the speedometer is set to the current speed.

Cruise control is active. The current speed is maintained and stored as set speed.

DSC Dynamic Stability Control is switched on, if necessary.

### **Turning off**

To switch off the system while standing, step on brake pedal at the same time.

Press the button on the steering wheel:



With steering and traffic jam assistant.



Without steering and traffic jam assistant.

The displays turn off. The stored set speed is deleted.

### Interrupting manually

When active, press the button on the steering wheel:



With steering and traffic jam assistant.



Without steering and traffic jam assistant.

If interrupting the system while stationary, press on the brake pedal at the same time.

### Interrupting automatically

The system is automatically interrupted in the following situations:

- ▶ When the driver applies the brakes.
- ▶ When selector lever position D is disengaged.
- Dynamic Traction Control DTC is activated or DSC Dynamic Stability Control is deactivated.
- ▶ If DSC Dynamic Stability Control intervenes.
- ▶ If the safety belt and the driver's door are opened while the vehicle is standing still.
- If the system has not detected objects for an extended period, for instance on a road with very little traffic without curb or shoulder markings.
- If the detection range of the radar is impaired, for instance by contamination or heavy precipitation.
- After a longer stationary period when the vehicle has been braked to a stop by the system.

### **Setting the speed**

### Maintaining and storing the speed



Press the rocker switch up or down once while the system is interrupted. The system will be activated.

The current speed is maintained and stored as desired speed.

The stored speed is displayed on the speedometer.

DSC Dynamic Stability Control is switched on, if necessary.

The speed can also be stored by pressing a button.



Press the button.

### **Changing the speed**



Press the rocker switch up or down repeatedly until the desired speed is set.

If active, the displayed speed is stored and the vehicle reaches the stored speed when the road is clear.

- ▶ Each time the rocker switch is tapped to the resistance point, the set speed increases or decreases by 1 mph/1 km/h.
- ▶ Each time the rocker switch is pressed past the resistance point, the desired speed changes by a maximum of 5 mph/10 km/h.

Hold the rocker switch in position to repeat the action.

### Adjusting the distance

### Safety information



### Marning

The system cannot serve as a substitute for the driver's personal judgment. Due to the system limits, deceleration can be late. There may be a risk of accident or risk of damage to property. Be aware to the traffic situation at all times. Adjust the distance to the traffic and weather conditions and maintain the prescribed safety distance, possibly by braking.

### Reduce distance



Press the button repeatedly until the desired distance is set.

Instrument cluster will display selected distance.

### Increase the distance



Press the button repeatedly until the desired distance is set.

Instrument cluster will display selected distance.

### Automatic adaptation of the distance

Depending on the equipment and national-market version: the system can be adjusted so that the distance to the vehicle driving in front is automatically adjusted within the configured distance

according to the traffic situation or the ambient conditions, for instance poor visibility.

- 1. "CAR"
- 2. "Settings"
- "Driver Assistance"
- 4. If necessary, "Driving"
- 5. "Speed Limit Assistance"
- 6. "Adjust distance acc. to situation"

### **Continuing cruise control**

An interrupted cruise control can be continued by calling up the stored speed.

Make sure that the difference between current speed and stored speed is not too large before calling up the stored speed. Otherwise, unintentional deceleration or acceleration may occur.

Press the button on the steering wheel with the system interrupted:



With steering and traffic jam assistant.



Without steering and traffic jam assis-

Cruise control is continued with the stored values.

In the following cases, the stored speed value is deleted and cannot be called up again:

- ▶ When the system is switched off.
- When drive-ready state is switched off.

### **Changing between cruise control** with/without distance control

### Safety information



### Marning

The system does not react to traffic driving ahead of you, but instead maintains the stored speed. There may be a risk of accident or risk of damage to property. Adjust the set speed to the traffic conditions and brake as needed.

### Change over mode of the cruise control

Switching cruise control without distance control off and on:







Press and hold this button.

With steering and traffic jam assistant: switch on distance control:



Press the button.

Without steering and traffic jam assistant: switch on distance control:



Press the button.



Press the button.

After changing, a Check Control message is displayed.

### Displays in the instrument cluster

### General information

Depending on the equipment version, the displays in the instrument cluster may vary.

### Display in the speedometer

Depending on the equipment, a mark in the speedometer displays the status of the system.



- ▶ Green marking: system is active, the marking indicates the desired speed.
- ▶ Grey marking: system is interrupted, the marking indicates the stored speed.
- ▶ No marking: system is switched off.

### Distance to vehicle ahead of you

Selected distance to the vehicle ahead of you is shown.

### Icon

### Description



Distance 1



Distance 2



Distance 3



Distance 4

This value is set automatically after the system is switched on.



No distance control display, as the accelerator pedal is being pressed.

### **Detected vehicle**

### Icon Description



Green icon:

A vehicle has been detected ahead of you.

When the distance to the detected vehicle increases, the vehicle symbol in the distance display will move away.

If necessary, independent drive-off, such as by stepping on the accelerator pedal or by pressing the rocker switch.

### **Indicator/warning lights**

indicator/ warring rights	
Icon	Description
	Vehicle symbol white:
	No distance control display, as the accelerator pedal is being pressed.
	Green icon:
	A vehicle has been detected ahead of you.
	The vehicle symbol goes out if no vehicle in front is detected.
	Vehicle symbol flashes green:
	Vehicle in front drove off.
	Gray icon:
	System interrupted.

### Icon Description



Symbol flashes gray:

The conditions are not adequate for the system to work.

The system was deactivated but applies the brakes until you actively resume control by pressing on the brake pedal or accelerator pedal.



Vehicle symbol flashes red and a signal sounds:

Brake and make an evasive maneuver, if necessary.

### Alternative displays

### Icon Description



Indicator light green: system is active.

No indicator light: system is switched off.



Vehicle symbol flashes:

The conditions are not adequate for the system to work.

The system was deactivated but applies the brakes until you actively resume control by pressing on the brake pedal or accelerator pedal.



The vehicle symbol and distance bars blink red and an acoustic signal sounds:

Brake and make an evasive maneuver, if necessary.



System interrupted.

### **Displays in the Head-up Display**

### Set speed

Some system information can also be displayed in the Head-up Display.



The icon is displayed when the set speed is reached.

### **Distance information**



The icon is displayed when the distance from the vehicle traveling ahead is too short.

The distance information is active in the following situations:

- Active Cruise Control switched off.
- ▶ Display in the Head-up Display selected. Head-Up Display, refer to page 177.
- Distance too short.
- ▶ Speed greater than approx. 40 mph/70 km/h.


### **System limits**

### **System limits of the sensors**

Additional information:

- ▶ Cameras, refer to page 37.
- ▶ Radar sensors, refer to page 38.

### **Detection range**



The detection capability of the system and the automatic braking performance are limited.


Two-wheeled vehicles for instance might not be detected.

### **Deceleration**

The system does not decelerate in the following situations:

- For pedestrians or similarly slow-moving road users.
- ▶ Depending on the equipment, with red traffic lights.
- ▶ For cross traffic.
- ▶ For oncoming traffic.

### **Merging vehicles**




If a vehicle driving ahead of you suddenly merges into your lane, the system may not be able to automatically restore the selected distance. It may not be possible to restore the selected distance in certain situations, including if you are driving significantly faster than vehicles driving ahead of you, for instance when rapidly approaching a truck. When a vehicle driving ahead of you is reliably detected, the system requests that the driver intervene by braking and carrying out evasive maneuvers, if needed.

### **Cornering**



When the set speed is too high for a curve, the speed is reduced slightly. Because curves may not be anticipated in advance, drive into a curve at an appropriate speed.

The system has a limited detection range. Situations can arise in tight curves where a vehicle driving ahead will not be detected or will be detected very late.



When you approach a curve the system may briefly report vehicles in the next lane due to the bend of the curve. If the system decelerates you may compensate it by briefly accelerating. After releasing the accelerator pedal the system is reactivated and controls speed independently.

### **Driving off**

In some situations, the vehicle cannot drive off automatically; for example:

- ▶ On steep uphill grades.
- ▶ In front of bumps in the road.
- ▶ With a heavy trailer.

In these cases, step on the accelerator pedal.

### Weather

The following restrictions can occur under unfavorable weather or light conditions:

- Poorer vehicle detection.
- Short-term interruptions for vehicles that are already recognized.

Drive attentively, and react to the current traffic situation. If necessary, intervene actively, for instance by braking, steering or evading.

### **Drive power**

The set speed is also maintained downhill. The speed may not be maintained on uphill grades if the drive power is insufficient.

In ECO PRO driving mode, the vehicle may exceed or drop below the set desired speed in some situations, for instance on downhill or uphill grades.

### **Speed Limit Assistant**

### **Principle**

Speed Limit Assistant supports driving at the speed limit. A suggested speed can be applied.

### **General information**

When the systems in the vehicle, e.g., Speed Limit Info, detect a change of the speed limit, this new speed value can be applied for the following systems:

- Manual Speed Limiter.
- Cruise control.
- Active Cruise Control with Stop&Go function ACC.

The speed value is suggested as the new desired speed to be applied. To apply the speed value, the corresponding system must be activated.

### **Safety information**



### Marning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.



### Warning

The set speed can be incorrectly adjusted or called up by mistake. There is a risk of accident. Adjust the set speed to the traffic conditions. Watch traffic closely and actively intervene where appropriate.

### Overview

### **Buttons on the steering wheel**

### Button **Function**



Accept suggested speed manually.



Rocker switch:

Set speed, refer to Cruise Control.

### **Turning Speed Limit Assistant** on/off

- 1. "CAR"
- 2. "Settings"
- 3. "Driver Assistance"
- 4. If necessary, "Driving"
- 5. "Speed Limit Assistance"
- 6. "Speed limits"
- 7. Select the desired setting:

- ▶ "Adjust manually": detected speed limits can be applied manually.
- ▶ "Show anticipation": current and upcoming speed limits are displayed in the instrument cluster without being applied.
- ▶ "Show current limit": current speed limits are displayed without being applied in the instrument cluster.
- ▶ "Off": depending on the national-market version, Speed Limit Info and Speed Limit Assistant will be turned off.

### Displays in the instrument cluster

A message is displayed in the instrument cluster when the system and a driver assistance system are activated.

### Icon

### **Function**



Depending on the equipment version, the indicator light illuminates green, together with the icon for a cruise control system:

Speed Limit Assistant is active and detected speed limits can be applied manually for the displayed system.



Detected change of a speed limit with immediate effect.



Indicator light illuminates green: the detected speed limit can be applied with the SET button.

After it has been applied, a green checkmark is displayed.

### **Manual adoption**

A detected speed limit can be applied manually for the active driver assistance system.



When the SET icon lights up, press the button.

### Adapt to route

### **Principle**

The system can be configured so that the vehicle adapts the speed automatically to the route.

For instance, the speed will be reduced in the following situations, if necessary:

- Before making turns.
- Before a roundabout.
- Before a curve.

### **Adjustment**

- 1. "CAR"
- 2. "Settings"
- 3. "Driver Assistance"
- 4. If necessary, "Driving"
- 5. "Speed Limit Assistance"
- 6. "Adjust to route" or "Automatically adjust speed to route"

### **System limits**

Speed Limit Assistant is based on the Speed Limit Info system.

Consider the system limits of Speed Limit Info.

Upcoming speed limits can only be applied for the Active Cruise Control ACC.

Depending on the national-market version, the system may not respond at all or with limitations to the route when the navigation system is unable to clearly identify the position of the vehicle.

Additional information:

- System limits of Speed Limit Information, refer to page 174.
- System limits of the sensors, refer to page 37.

### **Steering Assistant**

### **Principle**

The Steering Assistant helps keep the vehicle in the lane. For this purpose, the system executes supporting steering movements, for instance when driving in a curve.

### General information

Depending on the speed, the system orients itself according to the lane markings or vehicles in front.

Sensors on the steering wheel detect whether the steering wheel is being touched.

### **Safety information**



### Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.

### Overview

### **Buttons on the steering wheel**

### **Button Function**



Steering and traffic jam assistant incl. Traffic Jam Assistant on/off.



Switch function on.

### Sensors

The system is controlled by the following sensors:

- Cameras behind the windshield.
- Front radar sensor.
- ▶ Radar sensors, side, front.
- ▶ Radar sensors, side, rear.

Additional information:

Sensors of the vehicle, refer to page 37.

### **Functional requirements**

- ▶ Speed below 130 mph/210 km/h.
- Sufficient lane width.
- ▶ Above approx. 43 mph, 70 km/h: lane marking on both sides is detected.
- ▶ Below approx. 43 mph, 70 km/h: lane marking on both sides or a vehicle driving ahead is detected.
- ▶ Hands on the steering wheel rim.
- Wide curves.
- Drive in the center of the lane.
- Turn signal switched off.
- ▶ The sensor system calibration process is complete.
- Cruise control with distance control active.
- Safety belt on the driver's side fastened.
- ▶ Forward Collision Warning active.
- Pedestrian Warning active.
- ▶ Side Collision Warning active.

### **Turning on/off**

### **Assisted Driving Mode**

### General information



This button is used to switch the confiaured function on and off.



The button can be used to set the primarily used function.

### Set function



When the system is active, press the button repeatedly until the desired function is selected in the toolbar. The toolbar for Assisted Driving mode is displayed at the bottom of the instrument cluster.

### Icon

### **Function**



Cruise control with distance control.



Depending on the equipment version, cruise control with distance control and steering and traffic jam assistant.



The selected function is shown in green.

### Turning on



Press the button on the steering

2. Mode Adjust the steering and traffic jam assistant if necessary.



Steering wheel symbol lights up gray.

The system is on standby and does not manipulate steering.

System activates automatically as soon as all function conditions are fulfilled.



Steering wheel symbol lights up green.

The system is active.

With the system switched on, the Pedestrian Warning with City Collision Mitigation and the side collision mitigation are active.

### **Turning off**



Press the button on the steering wheel.

The indicator goes out.

The system does not perform supportive steering wheel movements.

### Interrupting automatically

The system interrupts the supporting steering movements automatically, for example in the following situations:

- ▶ At a speed above 130 mph/210 km/h.
- When the steering wheel is released.
- ▶ When the driver applies the brakes.
- ▶ When you manipulate steering.
- When leaving own lane.
- ▶ When the turn signal is switched on.
- When the lane is too narrow.
- If a lane boundary is not detected for a certain period of time and no vehicle is driving ahead.
- ▶ The Active Cruise Control ACC is interrupted.
- The safety belt on the driver's side is unfastened.



Icon

Steering wheel symbol lights up gray. The system is on standby and does not manipulate steering.

System activates automatically as soon as all function conditions are fulfilled.

Description

# Displays in the instrument cluster

•	Gray steering wheel symbol: The system is on standby.
•	Green steering wheel symbol: The system is activated. The system supports the driver in keeping the vehicle within the lane.

Icon	Description
<b></b>	Yellow flashing steering wheel symbol:
	Lane marking driven over.
	The steering wheel vibrates where applicable.
	Yellow steering wheel symbol and a signal sounds, if applica- ble:
	System interruption is imminent.
•	Steering wheel symbol blinks red, signal sounds:
	System is switching off.
<b>.</b>	Yellow steering wheel symbol:
	The hands are not grasping the steering wheel. The system is still active.
<b>.</b> ♥	Red steering wheel symbol and a signal sounds:
	The hands are not grasping the steering wheel. System interruption is imminent.
	The system reduces the speed to a standstill if applicable.
	It is possible that the system will

### **Alternative displays**

Depending on the equipment version, the displays in the instrument cluster may vary and are displayed as follows:

not execute any supporting

steering movements.

lcon	Description
•	Gray steering wheel symbol: The system is on standby.
•	Green steering wheel symbol: The system is activated.

### **Description** Icon



Depending on equipment, vellow flashing steering wheel sym-

Lane marking driven over.

The steering wheel vibrates where applicable.



Yellow steering wheel symbol and a signal sounds, if applicable:

System interruption is imminent.



Depending on equipment, steering wheel symbol flashes red, signal sounds:

System is switching off.



Green steering wheel icon and lane marking icon:

The system supports the driver in keeping the vehicle within the lane.



Yellow steering wheel symbol:

The hands are not grasping the steering wheel. The system is still active.



Red steering wheel symbol and a signal sounds:

The hands are not grasping the steering wheel. System interruption is imminent.

It is possible that the system will not execute any supporting steering movements.

With Active Cruise Control, the system may reduce the speed.

### Displays on the steering wheel



The two LED lights above the buttons illuminate analogously to the displays in the instrument cluster:

- Yellow: system interruption is imminent.
- ▶ Red: system will be deactivated.

The steering wheel displays can be switched on/off if required.

- 1. "CAR"
- 2. "Settings"
- "Driver Assistance"
- 4. "Steering Wheel Feedback"
- 5. "Light elements"

### **Displays in the Head-up Display**

All system information can also be displayed in the Head-up Display.

### **System limits**

### **General information**

The system cannot be activated or meaningfully used in certain situations.

### Safety information



### Marning

The system is designed to operate in certain conditions and circumstances. Due to conditions or other factors, the system may not respond. There may be a risk of accident or risk of damage to property. Actively intervene as

warranted. Refer to the information in this Owner's Manual regarding the scope of the system's operation and limitations.

### System limits of the sensors

Additional information:

- Cameras, refer to page 37.
- ▶ Radar sensors, refer to page 38.

### Hands on the steering wheel

The sensors cannot detect hand-steering wheel contact in the following situations:

- Driving with gloves.
- ▶ Protective covers on the steering wheel.

### Narrow lanes

When driving within narrow lanes, the system cannot be activated or effectively used, for instance in the following situations:

- In construction areas.
- Depending on the equipment, with automatic formation of emergency lanes.
- ▶ Within city limits.

### Weather

The following restrictions can occur under unfavorable weather or light conditions:

- Poorer recognition of vehicles and lane mark-
- ▶ Short-term interruptions for vehicles that are already recognized.

Drive attentively, and react to the current traffic situation. If necessary, intervene actively, for instance by braking, steering or evading.

### **Extended Traffic Jam Assistant**

### **Principle**

Extended Traffic Jam Assistant supports the driver with vehicle control in traffic jam situations.

Supporting steering movements take place without the driver actively steering.

### **General information**

The system uses the sensors of the steering and lane control assistant.

### **Safety information**

### Marning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident. Adjust driving style to traffic conditions. Watch the traffic situation closely, be ready to take over steering and braking at any time, and actively intervene where appropriate.

State laws differ and the use of this function may violate the law. Before use, check your state and local laws.

Additionally, the notices for the Steering and Lane Control Assistant apply.

Additional information:

Steering and Lane Control Assistant, refer to page 244.

### **Functional requirements**

- ▶ The functional requirements of the steering and traffic jam assistant are fulfilled.
  - Functional requirements, refer to page 245.
- ▶ The steering and traffic iam assistant is active.

- ➤ The function is only available on certain street types, e.g. freeways.
- Driving on a road without pedestrians or cyclists.
- Sufficient lane width.
- Lane markings and a vehicle driving ahead are detected.
- ▶ Speed less than approx. 40 mph/60 km/h.
- The Driver Attention Camera in the instrument cluster detects that the driver is paying attention to the traffic.
- ➤ The function must be available in the country in which the vehicle is driven.

### **Turning on**



ASSIST PLUS As soon as all functional requirements are met, Extended Traffic Jam Assistant will be displayed as an additional icon in the toolbar. The toolbar is displayed at the bottom of the instrument cluster.



Select Extended Traffic Jam Assistant with the button on the steering wheel.

The icon for Extended Traffic Jam Assistant is shown in green.

Two green LED lights are illuminated on the steering wheel.

The indicator light in the instrument cluster is shown in green.

The system begins to assist the driver with vehicle control.

# Displays in the instrument cluster

Icon	Description
ASSIST PLUS	Indicator light green: system is active.
ASSIST PLUS READY	Indicator light white: system is ready.
ASSIST PLUS	Gray indicator light: the system has been interrupted.

### **Alternative displays**

Depending on the equipment version, the displays in the instrument cluster may vary and are displayed as follows:

Indicator light	Description
<b>⊕</b>	Indicator light green: system is active.

### Displays on the steering wheel



The two LED lights above the buttons illuminate analogously to the displays in the instrument cluster:

- ▶ Green: the system is active.
- > Yellow: system will be interrupted.
- ▶ Red: system will be deactivated.

### **System limits**

### **General information**

The limits of the Steering and Lane Control Assistant system apply.

Additional information:

Steering and Lane Control Assistant, refer to page 244.

### **Driver Attention Camera**

Always monitor the traffic conditions.

The Driver Attention Camera detects whether or not the driver is paying attention to the traffic conditions.

The Driver Attention Camera may not be fully functional in the following situations:

- ▶ When the Driver Attention Camera is covered by the steering wheel.
- ▶ With sunglasses with high protection from infrared light.

### Depending on the equipment version: **Automatic Lane Change Assistant**

### **Principle**

The system additionally supports the driver when changing lanes on multilane roads.

### General information

The system uses the sensors of the steering and lane control assistant.

### **Safety information**

### Marning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropri-

Additionally, the notices for the Steering and Lane Control Assistant apply.

Additional information:

Steering and Lane Control Assistant, refer to page 244.

### **Functional requirements**

- The functional requirements of the steering and traffic jam assistant are fulfilled.
  - Functional requirements, refer to page 245.
- Driving on a road without pedestrians or cyclists and with physical barriers to oncoming traffic, such as crash barriers.
- ▶ Lane markings have been detected.
- ▶ Maximum speed approx. 110 mph, 180 km/h.
- ▶ The minimum speed is country-specific.


### Switch lane change assist on/off

- 1. "CAR"
- 2. "Settinas"
- 3. "Driver Assistance"
- 4. If necessary, "Driving"
- 5. "Steering Assistance"
- 6. "Automatic Lane Change"

### **Changing lanes**

- 1. Ensure that the traffic situation permits changing lanes.
- Press the turn signal lever in the required direction to the pressure point for signaling briefly.

A supporting steering movement in the required direction can be detected a short time later.



After the lane change, the system helps keep the vehicle in the new lane.

### Canceling a lane change

The lane change can be canceled by steering movement into the opposite direction.

# Displays in the instrument cluster

Icon	Description
•	Green steering wheel symbol.
	Green arrow symbol for lane- changing.
	The system carries out a lane change.
	Green steering wheel symbol.
	Gray line for lane marking on the appropriate side.
	The system detected the lane change request. Lane change not currently possible.
<b>◆</b>	Depending on country specifications:
	Green steering wheel symbol.
	Gray arrow symbol for lane- changing.
	Lane change not possible; func-

### **Alternative displays**

Depending on the equipment version, the displays in the instrument cluster may vary and are displayed as follows:

tional requirements not met.

### Icon

### **Description**



Green steering wheel symbol. Gray line for lane marking on the appropriate side.

Green arrow symbol for lanechanging.

The system carries out a lane change.



Green steering wheel symbol.

Gray line for lane marking on the appropriate side.

No arrow symbol for lanechanging on the display.

The system detected the lane change request. Lane change not currently possible.



Depending on country specifica-

Green steering wheel symbol. Gray line for lane marking on the appropriate side.

Gray arrow symbol for lanechanging.

Lane change not possible; functional requirements not met.

### **System limits**

The limits of the Steering and Lane Control Assistant system apply.

Additional information:

Steering and Lane Control Assistant, refer to page 244.

### **Depending on the** equipment version: lane change with active guidance

### **Principle**

The system assists the driver when lane changes are necessary to reach a navigation destination.

### **General information**

The system uses the sensors of the steering and lane control assistant.

### **Safety information**

### Marning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropri-

Additionally, the notices for the Active Cruise Control and the Steering and Lane Control Assistant apply.

Additional information:

- Active Cruise Control, refer to page 234.
- ▶ Steering and Lane Control Assistant, refer to page 244.

### **Functional requirements**

- Active Cruise Control is activated.
- Driving on a highway or highway-like road.
- ▶ Lane markings on the side of the desired lane change detected.
- ▶ Navigation system: guidance is activated.

- Adaptation to the course of the route is activated.
- ➤ The function must be available in the country in which the vehicle is driven.

## **Changing lanes**

1. One or more lane changes are required to reach a navigation destination.

The system prepares for this lane change. For this purpose, the system determines a suitable opening in the traffic flow on the next lane.

- When a gap is detected, the speed is adapted so that the vehicle remains at the level of the opening.
- 3. A Check Control message indicates a lane change suggestion.

When Steering Assistant is active, a steering intervention in the direction of the relevant lane may occur.

 When the traffic situation permits a lane change, the driver can steer the vehicle into the next lane.

When equipped with Automatic Lane Change Assistant: after the Check Control message has been displayed, the Automatic Lane Change Assistant can be started by operating the turn signal.

## Display in the instrument cluster

#### Icon Function



The suggestion for the lane change is displayed and a green checkmark indicates the active function.

Depending on the equipment and national-market version, the traffic situation is displayed in the Assisted Driving View of the instrument cluster.

Additional information:

Assisted Driving View, refer to page 160.

## Turn on adaptation to the course of the route

- 1. "CAR"
- 2. "Settings"
- 3. "Driver Assistance"
- 4. If necessary, "Driving"
- 5. "Speed Limit Assistance"
- 6. "Adjust to route" or "Automatically adjust speed to route"

## **System limits**

The limits of the Active Cruise Control and Steering and Lane Control Assistant systems apply.

# Parking assistance systems

## **Principle**

The parking assistance systems support the driver in parking and maneuvering.

### **General information**

The parking assistance systems comprise the following individual systems.

Additional information:

- ▶ PDC Park Distance Control, refer to page 254.
- Depending on equipment version: emergency brake function, Active PDC, refer to page 257.
- Side parking aid, refer to page 258.
- Without Surround View: rearview camera, refer to page 259.
- ▶ Automatic Parking Assistant, refer to page 262.
- ▶ Automatic Parking Assistant, driving out of parking space, refer to page 266.
- ▶ Back-up Assistant, refer to page 267.

- Surround View with rearview camera, refer to page 269.
- ▶ Panorama View, refer to page 274.
- ▶ Remote 3D View, refer to page 276.
- ▶ Cross traffic warning, refer to page 277.

## **PDC Park Distance Control**

## **Principle**

Park Distance Control (PDC) helps with parking. Acoustic and visual warnings signal obstacles in front of or behind the vehicle.

Depending on the equipment version: obstacles that are detected by the side ultrasonic sensors may also be reported by the side protection.

#### **General information**

The range of the system, depending on obstacles and environmental conditions, is approx. 6 ft/2 m.

An acoustic warning sounds in case of an impending collision at a distance to the object of approx. 27 in/70 cm.

For objects behind the vehicle, the acoustic warning is already issued at a distance to the object of approx. 5 ft/1.50 m.

## **Safety information**



The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.

## ⚠ Warning

Due to high speeds when PDC Park Distance Control is activated, the warning can be delayed due to physical circumstances. There is a risk of injury or risk of damage to property. Avoid approaching an object too fast. Avoid driving off fast while PDC Park Distance Control is not yet active.

#### Overview

#### **Button in the vehicle**





Park assistance button

#### Sensors

The system is controlled by the following sensors:

- ▶ Ultrasound sensors in the front/rear bumpers.
- Depending on the equipment: ultrasonic sensors on the side.

Additional information:

Sensors of the vehicle, refer to page 37.

## **Turning on/off**

## **Turning on automatically**

The system switches on automatically in the following situations:

- ▶ If selector lever position R is engaged when the engine is running.
- Depending on the equipment version: while approaching detected obstacles at a speed slower than approx. 2.5 mph/4 km/h. The activation distance depends on the situation in question.

You may switch automatic activation when obstacles are detected on and off.

- 1. "CAR"
- 2. "Settings"
- 3. "Driver Assistance"
- 4. "Parking and Maneuvering"
- 5. If necessary, "Automatic PDC Activation"
- 6. "Automatic PDC Activation"

Depending on equipment, an additional camera view is also switched on.

## Automatic deactivation during forward travel

The system switches off when a certain driving distance or speed is exceeded.

Switch the system back on, if needed.

## Switching on/off manually



Press the park assistance button.

- On: the LED lights up.
- ▶ Off: the LED goes out.

The rearview camera image is displayed if the reverse gear is engaged when pressing the park assistance button.

Depending on the equipment version, the system cannot be switched off manually if the reverse gear is engaged.

## **Warning**

## Signal tones

#### **General information**

An intermittent tone indicates when the vehicle is approaching an object. E.g., when an object is detected at the rear left of the vehicle, a signal tone sounds from the rear left speaker.

The shorter the distance to the object, the shorter the intervals.

When the distance to a detected object is less than approx. 8 in/20 cm, a continuous tone is sounded.

When there are objects in front of and behind the vehicle at the same time, with a distance smaller than approx. 8 in/20 cm, an alternating constant tone will sound.

The intermittent tone and constant tone are switched off if the selector lever position P is engaged.

The intermittent tone is switched off after a short time when the vehicle is stationary.

#### Volume

The PDC signal tone volume can be adjusted.

- 1. "CAR"
- 2. "Settings"
- "Driver Assistance"
- 4. "Parking and Maneuvering"
- 5. "Volume PDC signal"
- 6. Set the desired value.

## Visual warning



The approach of the vehicle to an object is shown on the Control Display. Objects that are farther away are already displayed on the Control Display before a signal sounds.

The display appears as soon as PDC is activated.

The range of the sensors is represented in the colors green, yellow and red when obstacles are detected.

Lanes are faded in for better estimation of the required space.

When the image of the rearview camera is displayed, the switch can be made to PDC or to a different view with obstacle markings as needed:

- 1. Press the Controller to the left, if needed.
- 2. For instance "Park, sensors only"

Cross traffic warning: depending on the equipment, it is warned in the PDC display against vehicles approaching in the front or rear from the side.

Additional information:

Cross traffic warning, refer to page 277.

## **System limits**

## Safety information



#### Warning

The system is designed to operate in certain conditions and circumstances. Due to conditions or other factors, the system may not respond. There may be a risk of accident or risk of damage to property. Actively intervene as warranted. Refer to the information in this Owner's Manual regarding the scope of the system's operation and limitations.

## **Trailer towing**

With a trailer, a trailer power socket occupied or when trailer towing is activated, the rear PDC functions will be switched off.



White icon is displayed.

Depending on the vehicle equipment, the range of the sensors is shown as a shaded area on the Control Display.

#### System limits of the sensors

Additional information:

Ultrasonic sensors, refer to page 39.

#### Limits of ultrasonic measurement

The detection of objects with ultrasonic measurements can run into physical limits, e.g., in the following situations:

- With obstacles and persons at the edge of the lane.
- ▶ Low objects already displayed, for instance curbs, can move into the blind area of the sensors before or after a continuous tone sounds.

## **Unwarranted warnings**

Reaching the system limits can cause unwarranted warnings.

To prevent unwarranted alarms, switch off automatic Park Distance Control PDC activation on obstacle detection, for instance in automatic car washes.

## Malfunction

A Check Control message is displayed.



White icon is displayed, and the range of the sensors is dimmed on the Control Display.

PDC Park Distance Control malfunction. Have the system checked by a dealer's service center or another qualified service center or repair shop.

## **Depending on equipment** version: emergency brake function, Active PDC

## **Principle**

The emergency braking function of PDC initiates an emergency braking in case of acute risk of collision.

#### **General information**

Due to system limits, a collision cannot be prevented under all circumstances.

The function is available below walking speed when driving in reverse or rolling backward.

A press of the accelerator pedal interrupts the brake intervention.

After emergency braking to a stop, further creeping toward an obstacle is possible. Proceed with caution. To move forward, lightly press the accelerator pedal and release as needed.

If the accelerator pedal is depressed longer, the vehicle drives off. Manual braking is possible at any time.

The system uses the ultrasonic sensors of the Park Distance Control PDC and the Parking Assistant.

## Safety information

#### Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic and vehicle surroundings closely and actively intervene where appropriate.

Additionally, the safety information for the PDC Park Distance Control and the Automatic Parking Assistant apply.

Additional information:

- ▶ PDC Park Distance Control, refer to page 254.
- Automatic Parking Assistant, refer to page 262.

## **Temporary switching off**

The emergency brake function can be switched off temporarily:

Confirm the message on the Control Display.

During continued driving in this surrounding situation, no further emergency braking will occur.

## Settings

It is possible to set which areas on the vehicle will be protected by the system.

- 1. "CAR"
- 2. "Settings"
- "Driver Assistance"
- 4. "Parking and Maneuvering"
- 5. "Active PDC with braking interv."
- Select the desired setting.

## **System limits**

The limits of the systems of the Park Distance Control PDC and the Parking Assistant apply.

The system cannot be used in the following situations, for example:

- When Hill Descent Control is active, the emergency braking function is deactivated.
   Hill Descent Control HDC, refer to page 227.
- When driving with a trailer.

If required, deactivate the system via iDrive where applicable.

# With Parking Assistant: side parking aid

## **Principle**

The side protection warns of obstacles on the side of the vehicle.

#### **General information**

The system uses the ultrasonic sensors of the Park Distance Control PDC and the Parking Assistant.

## **Safety information**

## **⚠** Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic and vehicle surroundings closely and actively intervene where appropriate.

Additionally, the safety information for the PDC Park Distance Control and the Automatic Parking Assistant apply.

Additional information:

- ▶ PDC Park Distance Control, refer to page 254.
- Automatic Parking Assistant, refer to page 262.

## **Display**



To protect the sides of the vehicle, obstacle markings are displayed on the sides of the vehicle.

- Color markings: warning against detected obstacles.
- Gray markings, hatched area: no obstacles were detected.
- ▶ No markings, black area: the area next to the vehicle was not yet captured.

## Limits of the side parking aid

The system only displays stationary obstacles that were previously detected by sensors while passing them.

The system does not detect whether an obstacle moves later on. If the vehicle is stationary, the markings are shown in black after a certain time. The area next to the vehicle must be newly captured.

The side parking aid is not available when the trailer socket is occupied or trailer towing is activated.

Additionally, the limits of the systems of the Park Distance Control PDC and the Parking Assistant apply.

## Without Surround View: rearview camera

## **Principle**

The rearview camera provides assistance in parking and maneuvering backwards. The area behind the vehicle is shown on the Control Display.

Additionally, assistance functions can be shown in the display, e.g., help lines.

## **Safety information**



#### Marning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic and vehicle surroundings closely and actively intervene where appropriate.

#### **Overview**

## Depending on the vehicle equipment: button in the vehicle





Park assistance button

#### Sensors

The system is controlled by the following sen-

Rearview camera.

Additional information:

Sensors of the vehicle, refer to page 37.

## **Turning on/off**

## Turning on automatically

The system is switched on automatically if selector lever position R is engaged when the engine is running.

### Automatic deactivation during forward travel

The system switches off when a certain driving distance or speed is exceeded.

Switch the system back on, if needed.

## Depending on the vehicle equipment: switching on/off manually



Press the park assistance button.

- On: the LED lights up.
- ▶ Off: the LED goes out.

The parking assistance functions are shown on the Control Display.

## Switching the view via iDrive

If the rearview camera view is not displayed, change the view via iDrive:

- 1. If necessary, tilt the Controller to the side.
- 2. Rear view camera"

The rearview camera image is displayed.

## **Functional requirements**

- ▶ The tailgate is fully closed.
- Keep the recording range of the camera open. Protruding cargo, roof rack systems or trailers can limit the detection range of the camera.

## **Display on the Control Display**

#### **Toolbars**

The assistance functions can be activated manually via the toolbars on the sides of the Control Display.

- 1. Move the Controller to the right, if needed.
- 2. With corresponding equipment: Camera image"
- Prarking aid lines".
   Pathway lines and turning circle lines are displayed.
  - ▶ 🧖 "Obstacle mark.".

Depending on the vehicle equipment, the obstacles detected by PDC Park Distance Control are displayed by markings.

Zoom on trailer hitch:


- 1. Move the Controller to the left, if needed.
- 2. I "Trailer hitch".

A zoomed image of the trailer hitch is shown.

More than one assistance function can be active at the same time.

## **Parking aid lines**

#### Lanes



Lanes help you to estimate the space required when parking and maneuvering on level roads.

Lanes depend on the steering angle and are continuously adjusted to the steering wheel movements.

#### **Turning circle lines**



Turning circle lines can only be superimposed on the camera image together with lanes.


Turning circle lines show the course of the smallest possible turning radius on a level road.

Only one turning circle line is displayed after the steering wheel is turned past a certain angle.

## Parking using lanes and turning circle lines

- Position the vehicle so that the red turning circle line leads to within the limits of the parking space.
- Turn the steering wheel to the point where the green lane covers the corresponding turning circle line.

## **Obstacle marking**



Depending on the vehicle equipment, obstacles behind the vehicle are detected by the PDC Park Distance Control sensors.

Obstacle markings can be faded into the image of the rearriew camera.

The colored thresholds of the obstacle markings match the markings of the PDC Park Distance Control.

#### Zoom on trailer hitch

To make it easier to attach a trailer, you can zoom in on the view of the trailer hitch.



Two static circle segments show the distance between the trailer and the trailer hitch.

A docking line dependent on the steering angle helps with aiming for the trailer with the trailer hitch.

When zooming in, remember that the view may no longer show certain obstacles.

## **Setting brightness and contrast**

With the rearview camera switched on:

- 1. Move the Controller to the right, if needed.
- 2. C "Camera image"
- 3. Select the desired setting.

## **System limits**

## **System limits of the sensors**

Additional information:

▶ Cameras, refer to page 37.

#### **Deactivated camera**

When the camera is deactivated, for instance when the tailgate is open, the camera image is displayed hatched in gray.

## **Detection of objects**

Very low obstacles as well as high, protruding objects such as ledges may not be detected by the system.


Depending on the vehicle equipment, some assistance functions also consider data from the PDC Park Distance Control.

Follow the notes in the PDC Park Distance Control chapter.

The objects displayed on the Control Display may be closer than they appear. Do not estimate the distance from the objects on the display.

## **With Parking Assistant: Parking Assistant**

## **Principle**



The Automatic Parking Assistant supports the driver in the following situations:

- ▶ When parking parallel to the road, parallel parking.
- ▶ When parking in reverse perpendicular to the road, perpendicular parking. The system orients itself with the middle of the parking space.
- Depending on the equipment version: when driving out of parallel parking spaces.

## General information

## **Handling**

Automatic Parking Assistant handling is divided into three steps:

- Switching on and activating.
- Parking space search.
- Parking.

System status and instructions on required actions are displayed on the Control Display.

Ultrasound sensors measure parking spaces on both sides of the vehicle.

## **Steptronic transmission**

The Automatic Parking Assistant calculates the best possible parking line and takes control of

the following functions during the parking operation:

- Steering.
- Accelerating and braking.
- Changing gears.

The parking operation is automatic.

## **Safety information**

## 🛕 Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident, Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropri-



#### Warning

If the trailer hitch is used, the driver assistance system can cause damage due to covered sensors. There may be a risk of accident or risk of damage to property. The driver assistance system should not be used during trailer towing or if the trailer hitch is used, for instance bicycle rack.



#### ⚠ NOTICE

The system can steer the vehicle over or onto curbs. There is a risk of damage to property, among other potential damage. Watch traffic closely and actively intervene where appropriate.

The safety information of the PDC Park Distance Control apply in addition.

Additional information:

PDC Park Distance Control, refer to page 254.

#### **Overview**

#### **Button in the vehicle**





Park assistance button

#### Sensors

The system is controlled by the following sensors:

- ▶ Ultrasound sensors in the front/rear bumpers.
- ▶ Ultrasonic sensors, side.

Additional information:

Sensors of the vehicle, refer to page 37.

## **Functional requirements**

## For the measurement od parking spaces

- Maximum speed while driving forward approx.
   22 mph/35 km/h.
- ▶ Maximum distance to row of parked vehicles: 5 ft/1.5 m.

## Suitable parking space

General information:

- ▶ Gap behind an object that has a min. length of 1.7 ft/0.5 m.
- ▶ Gap between two objects with a minimum length of approx. 1.7 ft/0.5 m.

Parallel parking to the road:

- ▶ Min. length of gap between two objects: own vehicle length plus approx. 2.6 ft/0.8 m.
- ▶ Minimum depth: approx. 5 ft/1.5 m.

Perpendicular parking:

- ▶ Minimum width of the gap: own vehicle width plus approx. 2.3 ft/0.7 m.
- ▶ Minimum depth: own vehicle length.

The depth of diagonal parking spaces must be estimated by the driver. Due to technical limitations, the system is only able to approximate the depth of diagonal parking spaces.

## For the parking operation

- Doors and tailgate are closed.
- ▶ Driver's safety belt is fastened.

## Switching on with the button



Press the park assistance button.
The LED lights up.

The current status of the parking space search is indicated on the Control Display.

Automatic Parking Assistant is activated automatically.

## Switching on with reverse gear

1. Shift into reverse.

The current status of the parking space search is indicated on the Control Display.

2. If necessary, activate: 🗞 "Autom. Parking"

## Switching on via iDrive

Display of the rearview camera or PDC view must be active.

- 1. Move the Controller to the right.
- Activate the parking assistant on the Control Display: <sup>₱</sup>
   "Autom. Parking"

## **Display on the Control Display**

## System activated/deactivated

Icon	Meaning
P⊕	Gray: the system is not available. White: the system is available but not activated.
Pey	System is activated.
(((P))	Parking space search is active.
P <sub>©</sub>	The parking operation is active. The system takes over the steering.

## Parking space search and system status



- ▶ ((P)) Parking assistant is activated and parking space search is active.
- Control Display shows suitable parking spaces at the edge of the road next to the vehicle symbol. When Park Assistant is active, suitable parking spaces are highlighted and an acoustic signal sounds.
- ▶ If a diagonal or parallel parking space is clearly detected, the system automatically adjusts the suitable parking method. In the case of parking spaces suitable for parallel and diagonal parking, a selection menu is displayed. In this case, the desired parking method must be selected manually.

- ▶ 🦃 The parking operation is active. The system takes over the steering.
- Parking space search is always active whenever the vehicle is moving forward slow and straight, even if the system is deactivated.
   When the system is deactivated, the displays on the Control Display are shown in gray.

## Switching signal tone for suitable parking spaces on/off

- 1. "CAR"
- 2. "Settings"
- 3. "Driver Assistance"
- 4. "Parking and Maneuvering"
- 5. "Automatic Parking"
- 6. "Alert if parking space detected"

## Signal tones of the PDC Park Distance Control

During an automatic parking operation, no intermittent tone will sound from the PDC Park Distance Control.

A continuous tone sounds when the distance to a detected object is less than approx. 8 inches/20 cm.

## Parking using the Automatic Parking Assistant

## **Parking**

Switching on and activating the parking assistant

For this, engage the reverse gear or press the parking assist button and activate the system on the Control Display, if needed.

Automatic Parking Assistant is activated.

Pass the row of parked vehicles forward at a speed of up to approx. 22 mph/35 km/h and at a distance of maximum 5 ft/1.5 m.

The status of the parking space search and possible parking spaces are displayed on the Control Display.

3. Confirm the suggested parking space for the parking operation: select the parking space on the Control Display.

The system takes over the steering.

4. Follow the instructions on the Control Display.

At the end of the parking operation, the P selector lever position is set.

The end of the parking operation is indicated on the Control Display.

5. Adjust the parking position yourself, if needed.

## Interrupting manually

The Automatic Parking Assistant can be interrupted at any time:

Press the park assistance button.

▶ 🔊 "Autom. Parking": select the icon on the Control Display.

## Interrupting automatically

The system is interrupted automatically in the following situations:

- ▶ When the driver grasps the steering wheel or takes over steering.
- Possibly on snow-covered or slippery road.
- When there are obstacles that are hard to overcome, such as curbs.
- ▶ When there are obstacles that suddenly appear.
- ▶ If the PDC Park Distance Control displays clearances that are too small.
- ▶ When a maximum number of parking attempts or the time taken for parking is exceeded.
- When changing over to another function on the Control Display.

- If the tailgate is open.
- If doors are open.
- When setting the parking brake.
- During acceleration.
- ▶ When the brake pedal remains pressed for an extended period while the vehicle is stationary.
- ▶ When unfastening the driver's safety belt.

A Check Control message is displayed.

## Resuming

An interrupted parking operation can be continued, if needed,

Reactivate the parking assistant and follow the instructions on the Control Display.

## **Turning off**

The system can be switched off manually:



Press the park assistance button.

## **System limits**

## **Safety information**



## Warning

The system is designed to operate in certain conditions and circumstances. Due to conditions or other factors, the system may not respond. There may be a risk of accident or risk of damage to property. Actively intervene as warranted. Refer to the information in this Owner's Manual regarding the scope of the system's operation and limitations.

## No parking assistance

The Automatic Parking Assistant does not offer assistance in the following situations:

- In tight curves.
- When towing a trailer.
- For diagonal parking spaces.

## System limits of the sensors

Additional information:

▶ Ultrasonic sensors, refer to page 39.

#### **Functional limitations**

The system may be limited in the following situations:

- On bumpy road surfaces such as gravel roads.
- On slippery ground.
- On steep uphill or downhill grades.
- ▶ With accumulations of leaves/snow in the parking space.
- With a mounted emergency wheel.
- In case of changes to an already-measured parking space.
- With ditches or edges, for instance an edge of a port.
- Parking spaces that are not suitable may be detected or suitable parking spaces may not be detected at all.

### Malfunction

A Check Control message is displayed.

The Automatic Parking Assistant has malfunctioned. Have the system checked by a dealer's service center or another qualified service center or repair shop.

## **Depending on the** equipment version: driving out of a parking space using the parking assistant

## **Principle**

The system makes driving out of parallel parking spaces easier.

## General information

## Steptronic transmission

The parking assistant calculates an optimal line for pulling out of a parking space and takes control of the following functions during the maneuver:

- Steering.
- Accelerating and braking.
- Changing gears.

The vehicle maneuvers automatically until the vehicle reaches a position in which the driver can drive out of the parking space without further steering movements.

## **Safety information**



## Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.

## Marning

If the trailer hitch is used, the driver assistance system can cause damage due to covered sensors. There may be a risk of accident or risk of damage to property. The driver assistance system should not be used during trailer towing or if the trailer hitch is used, for instance bicycle rack.

Additionally, the safety information for the PDC Park Distance Control and the Automatic Parking Assistant apply.

Additional information:

- ▶ PDC Park Distance Control, refer to page 254.
- Automatic Parking Assistant, refer to page 262.

## **Functional requirements**

- ▶ The vehicle was parked manually and objects in front of and behind the car are detected. The distance to a detected curb is at least 6 inches/15 cm.
- ▶ The vehicle was parked using the parking assistant and an object is detected in front of the vehicle.
- ▶ The parking space is at least 2.6 ft/0.8 m longer than your vehicle.
- ▶ The vehicle has been parked in reverse.

## **Driving out of parking spaces**

- 1. Turn on drive readiness.
- 2. Steptronic transmission:
  - Press the park assistance button or shift into reverse gear when the vehicle is stationary to switch on the Automatic Parking Assistant.
- 3. Tilt the Controller to the right and activate the Automatic Parking Assistant on the Control Display: Parking"

- 4. On the Control Display, confirm the required direction for driving out of the parking space if necessary.
- 5. Follow the instructions on the Control Display.

Steptronic transmission:

The system takes control of the maneuver. A message will be displayed at the end of the maneuver.

6. Make sure that the traffic situation permits driving out of the parking space and drive off as usual.

The Automatic Parking Assistant is switched off automatically.

## **System limits**

The limits of the systems of the Park Distance Control PDC and the Parking Assistant apply.

## **With Parking Assistant: Reversing Assistant**

## **Principle**

The Back-up Assistant supports the driver when driving in reverse, for instance when driving out of tight or confusing parking or street situations.

The vehicle stores the driving movements of the last route. This stored route can be driven back with automated steering.

## General information

The system takes control of the steering when driving in reverse along the stored route.

The driver controls driving the vehicle via accelerator pedal and brake.

The Reversing Assistant uses the control elements and sensors of the PDC Park Distance Control and the Automatic Parking Assistant.

Additional information:

- ▶ PDC Park Distance Control, refer to page 254.
- ▶ Parking assistant, refer to page 262.

## **Safety information**

#### Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident, Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.

#### Warning

If the trailer hitch is used, the driver assistance system can cause damage due to covered sensors. There may be a risk of accident or risk of damage to property. The driver assistance system should not be used during trailer towing or if the trailer hitch is used, for instance bicycle rack.

Additionally, the safety information for the PDC Park Distance Control and the Automatic Parking Assistant apply.

Additional information:

- ▶ PDC Park Distance Control, refer to page 254.
- Automatic Parking Assistant, refer to page 262.

## **Functional requirements**

- Drive forward without interruption to store the route.
- A maximum of 165 ft/50 m will be stored.
- ▶ To store the route, do not exceed a driving speed of 22 mph/36 km/h.
- DSC Dynamic Stability Control is activated.

## **Driving back with automated** steering

- 1. Press the park assistance button or shift into reverse gear when the vehicle is stationary and the drive-ready state is switched on.
- 2. Move the Controller to the right.
- "Back-up Assistant" The system takes over the steering.
- 4. Follow the instructions on the Control Display where required.
- 5. Take your hands off the steering wheel and carefully drive off with the accelerator pedal and the brake.
  - When driving in reverse, pay attention to the vehicle's surroundings, and if you encounter an obstacle, stop immediately and take over control of the vehicle. Follow the instructions on the PDC Park Distance Control.
- 6. Stop no later than when normal traffic is reached and take control of the vehicle, such as by shifting to a forward gear.
  - At the end of the stored route, a signal will sound and a request will be displayed, also with the instruction to take control of the vehicle.

## **Terminating the system**

The system automatically cancels in situations such as the following:

- ▶ When the driver grasps the steering wheel or takes over steering.
- When engaging a forward gear.
- During activation or intervention by driving control systems or assist systems.
- After a few minutes when the vehicle is stationary.

- ▶ If the vehicle leaves the stored lane during reversing; for example, at the maximum steering angle.
- ▶ When the display on the Control Display is cross-faded with messages, e.g., due to incoming calls.

## **System limits**

- ▶ When you reach normal road traffic or if you encounter an obstacle, stop immediately and take over control of the vehicle.
- ▶ The maximum speed for driving in reverse is limited to approximately 6 mph/9 km/h. If the maximum speed is exceeded, a warning is issued and the function may be canceled.
- After driving a stored distance with major steering-wheel angles, the function of the system will be limited for the return trip.
- > Additionally, the limits of the systems of the Park Distance Control PDC and the Parking Assistant apply.

Different influences can lead to side deviations when driving back on the stored route. For example, this includes the following factors:

- > Steering movements when the vehicle is stationary while storing the distance covered.
- ▶ The speed is not adapted to the distance traveled.
- ▶ Road characteristics, such as gradients or inclines.

## With Parking Assistant Plus: Surround View

## **Principle**

Surround View supports the driver in parking and maneuvering. The area around the vehicle is shown on the Control Display.

#### General information

Several cameras capture the area from different selectable perspectives.

The following camera perspectives can be displayed:

- Automatic camera perspective: the system shows the camera perspective suitable for the respective driving situation.
- Rearview camera: for representing the areas behind the vehicle.
- ▶ Right-hand and left-hand side view: for representing the areas on the sides of the vehicle.
- ▶ Unobstructed camera perspective, movable via iDrive.
- Panorama View: to present cross traffic, for instance at junctions and driveways, depending on the currently engaged gear.

Depending on the view, the vehicle's surroundings or a part of it is depicted.

Additionally, assistance functions are shown in the display, e.g., help lines.

More than one assistance function can be active. at the same time.

Some assistance functions can be manually activated.

The following assistance functions are automatically displayed:

- Side parking aid.
- Door opening angle.

## **Safety information**



#### Marning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic and vehicle surroundings closely and actively intervene where appropriate.

#### **Overview**

#### **Buttons in the vehicle**





Park assistance button



Panorama View

#### Sensors

The system is controlled by the following sensors:

- Front camera.
- Top view cameras.
- Rearview camera.

Additional information:

Sensors of the vehicle, refer to page 37.

## **Turning on/off**

## **Turning on automatically**

The system is switched on automatically if selector lever position R is engaged when the engine is running.

The camera perspective suitable for the respective driving situation is displayed.

Additional information:

Park Distance Control, turn on/off, refer to page 254.

## Switching on/off manually



Press the park assistance button.

- ▷ On: the LED lights up.
- ▶ Off: the LED goes out.

Depending on the equipment version, the rearview camera cannot be switched off when the reverse gear is engaged.


## Automatic deactivation during forward travel

The system switches off when a certain driving distance or speed is exceeded.

Switch the system back on, if needed.

## **Display on the Control Display**

#### **Overview**



- 1 Toolbar, left
- 2 Camera image
- 3 Side view
- 4 Automatic camera perspective
- 5 Movable unobstructed camera perspective
- 6 Toolbar, right
- 7 Rearview camera
- 8 Selection window

#### Toolbar on the left

The left toolbar can be used for the direct selection of various views via iDrive. Move the Controller to the left, if needed.

- ▶ '
  ¶' "Parking": around the vehicle.
- ▶ (3) "3D view": available camera.

- ▶ ♣ "Trailer hitch".
- ▶ ⋴ "Car wash".

#### Side view

The side view can be selected for the right or left vehicle side.

This view helps when positioning the vehicle at the curb or with other obstacles on the side by displaying the side surroundings.

The side view looks from rear to front and in case of danger, focuses automatically on possible obstacles.

## **Automatic camera perspective**

The automatic camera perspective shows a steering-dependent view in the respective driving direction.

This perspective adapts to the respective driving situation.

As soon as obstacles are detected, the view changes to a fixed display of the area in front or at the rear behind the bumper or, if necessary, changes to a side view.

When reverse gear is engaged, the automatic camera perspective is, if necessary, exited and the system uses a fixed perspective of the rearview camera. If necessary, manually select the automatic camera perspective when reverse gear is engaged. The automatic camera perspective will be retained for the current parking operation.

## Movable unobstructed camera perspective

With selection of the movable camera perspective, a circle appears on the Control Display.

By turning the Controller or via touch function, specified perspectives on the circle can be selected.

The current perspective is marked with a camera symbol.

To leave the function, move the Controller sideways and select another camera function. With xOffroad package: when an xOffroad driving mode is activated, terrain-specific views will be displayed.

## **Toolbar on the right**

Assistance functions can be activated and settings can be entered via the right toolbar via iDrive. Move the Controller to the right, if needed.

- ▶ ♣ "Autom. Parking".
- ▶ See "Back-up Assistant".
- ▶ ば<sup>®</sup> "Camera image":
  - ▶ ☼ "Brightness".
  - ▶ "Contrast".
  - ▶ "Parking aid lines".
  - ▶ 🌇 "Obstacle mark.".
- ▶ ② "Settings": apply settings, for instance to use the activation points for Panorama View.

#### Rearview camera


This view shows the picture of the rearview camera.

#### **Selection window**

The individual camera perspectives can be selected in the selection window via iDrive.

## Parking aid lines

#### Lanes



Lanes help you to estimate the space required when parking and maneuvering on level roads.

Lanes depend on the steering angle and are continuously adjusted to the steering wheel movements.

#### **Turning circle lines**



Turning circle lines can only be superimposed on the camera image together with lanes.


Turning circle lines show the course of the smallest possible turning radius on a level road.

Only one turning circle line is displayed after the steering wheel is turned past a certain angle.

#### Parking using lanes and turning circle lines

- Position the vehicle so that the red turning circle line leads to within the limits of the parking space.
- Turn the steering wheel to the point where the green lane covers the corresponding turning circle line.

## **Obstacle marking**



Obstacles behind the vehicle are detected by the PDC Park Distance Control sensors.

Obstacle markings can be shown in the camera image.

The colored thresholds of the obstacle markings match the markings of the PDC Park Distance Control.

#### Car wash view



The car wash view assists when entering a car wash by displaying the floor and the vehicle's own track.

#### Zoom on trailer hitch

To make it easier to attach a trailer, you can zoom in on the view of the trailer hitch.



Two static circle segments show the distance between the trailer and the trailer hitch.

A docking line dependent on the steering angle helps with aiming for the trailer with the trailer hitch.

When zooming in, remember that the view may no longer show certain obstacles.

## Side parking aid

#### **Principle**

The system warns of obstacles on the side of the vehicle.

#### **Display**



To protect the sides of the vehicle, obstacle markings are displayed on the sides of the vehicle.

- ▶ No markings: no obstacles were detected.
- Color markings: warning against detected obstacles.

#### Limits of the side parking aid

The system only displays stationary obstacles that were previously detected by sensors while passing them.

The system does not detect whether an obstacle moves later on. For this reason, at standstill, the markings are not shown anymore in the display after a certain time. The area next to the vehicle must be newly captured.

## Door opening angle

#### **Principle**

If obstacle marking is activated, the Surround View indicates fixed obstacles that obstruct the opening angles of the doors.

The system does not provide a warning of approaching road users.

#### **Display**



The maximum opening angle of the doors is displayed in selector lever position P. As soon as the vehicle begins moving, the opening angles are replaced by parking aid lines.

#### Limits of the display

The vehicle's surroundings are displayed with distorted image for technical reasons.

Even if the symbols for the door opening angles do not cross other objects on the Control Display, the following needs to be noted when parking next to other objects:

Because of the perspective, higher, protruding objects may be closer than they appear on the Control Display.

## **Setting brightness and contrast**

Brightness and contrast can be adjusted with Surround View or Panorama View switched on.

- 1. Move the Controller to the right, if needed.
- 2. Comera image"
- 3. Select the desired setting.

## **Functional limitations**

The system can be used only to a limited extent in the following situations:

- ▶ In poor light.
- In case of soiled cameras.
- ▶ With a door open.
- ▶ With the tailgate open.
- ▶ With exterior mirrors folded in.

Gray hatched areas with icon, for instance open door, in the camera image mark areas that are currently not displayed.

## **System limits**

## **System limits of the sensors**

Additional information:

▶ Cameras, refer to page 37.

#### Non-visible areas

Because of the camera angle, the areas under the vehicle cannot be viewed by the cameras.

## **Detection of objects**

Very low obstacles as well as high, protruding objects such as ledges may not be detected by the system.

Some assistance functions also consider data from the PDC Park Distance Control.

Follow the notes in the PDC Park Distance Control chapter.

The objects displayed on the Control Display may be closer than they appear. Do not estimate the distance from the objects on the display.

Additional information:

PDC Park Distance Control, refer to page 254.

## **Malfunction**

A camera malfunction is displayed on the Control Display.




A yellow icon is displayed and the recording range of the malfunctioning camera is displayed in black on the Control

Display.

# With Parking Assistant Plus: Panorama View

## **Principle**



Panorama View gives you an earlier view of crossing traffic at blind driveway exits and intersections.

#### **General information**

Road users concealed by obstacles to the left and right of the vehicle can only be detected relatively late from the driver's seat. The cameras in the front and rear capture the sideways traffic area to improve the view.

Yellow lines in the screen display mark the front and rear end of the vehicle.

The camera image shows different levels of distortion in some areas and is thus not suitable for distance estimations.

Depending on the equipment version, the function can only be used when driving forward.

Additional information:

Surround View, refer to page 269.

## **Safety information**



#### Warning

The system cannot serve as a substitute for the driver's personal judgment in assessing the traffic situation. Based on the limits of the system, it cannot independently react to all traffic situations. There is a risk of accident. Adjust

driving style to traffic conditions. Watch traffic and vehicle surroundings closely and actively intervene where appropriate.

## **Overview**

#### **Button in the vehicle**





Panorama View

#### Sensors

The system is controlled by the following sensors:

- Front camera.
- Depending on the equipment: rearview camera.

Additional information:

Sensors of the vehicle, refer to page 37.

## **Display on the Control Display**



Press the button when the engine is running.

Depending on the driving direction, the image of the respective camera is displayed:

- ▶ "Front": front camera image.
- ▶ "Rear": rear camera image.

Depending on the vehicle equipment, cross traffic warning can additionally warn of approaching vehicles using radar sensors.

Additional information:

Cross traffic warning, refer to page 277.

## With navigation system: activation points

#### **Principle**

Positions where Panorama View should switch on automatically can be stored as activation points provided that a Global Positioning System signal is received.

#### **General information**

Up to ten activation points can be stored.

Activation points can be used when driving forward for the front camera.

## **Storing activation points**

- 1. Drive to the position at which the system is to be switched on, and stop.
  - Pre
    - Press the button.
- 3. Tilt the Controller to the right.
- "Activation point"The current position is displayed.
- 5. "Save activation point"

Activation points are, if possible, stored with town/city and street address, or else with the Global Positioning System coordinates.

## **Using activation points**

The use of activation points can be switched on and off.

- es P
  - Press the button.
- 2. Tilt the Controller to the right.
- 3. 
  Settings"
- 4. "Panorama View, GPS-based"
- 5. "Panorama View is displayed automatically when set activation points are reached."

## **Displaying activation points**



Press the button.

- 2. Tilt the Controller to the right.
- "Manage points"
   A list of all activation points is displayed.

## Renaming or deleting activation points



Press the button.

- 2. Tilt the Controller to the right.
- 3. Significant substitution of the state of

A list of all activation points is displayed.

- 4. Select an activation point as needed.
- 5. Select the desired setting.

#### **Functional limitations**

The Surround View functional limitations apply.

Additional information:

Surround View, refer to page 269.

## **System limits**

The limits of the Surround View system apply.

Additional information:

Surround View, refer to page 269.

# With Parking Assistant Plus: Remote 3D View

## **Principle**

The BMW app and the pictures of the Surround View cameras in combination with the corresponding equipment enable the display of the vehicle's surroundings on a mobile device.

The function displays a momentary view of the situation.

#### Sensors

The system is controlled by the following sensors:

- Front camera.
- ▶ Top view cameras.
- Rearview camera.

Additional information:

Sensors of the vehicle, refer to page 37.

## **Functional requirements**

- Data transmission must be activated.
   Data protection, refer to page 68.
- ▶ BMW app must be installed on the mobile device.
- ConnectedDrive countries: a driver profile with an existing ConnectedDrive account must be activated.

Driver profiles, refer to page 69.

## Switching the function on/off

## Switching on/off with other functions

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Data privacy"
- 5. Select the desired setting.

## Switching on/off individually

### Pre-adjustment

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Data privacy"
- 5. "Select services individually"
- 6. "My BMW app & customer portal"
- 7. "Remote 3D View"

#### Turning on/off

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Data privacy"
- "Individual selection"

## **System limits of the sensors**

Additional information:

▶ Cameras, refer to page 37.

#### **Functional limitations**

The system may not be fully functional or may not be available in the following situations:


- ▶ With a door or the tailgate open. Dark fields in the display indicate areas that are not recorded by the system.
- ▶ With manually folded in exterior mirrors.
- ▶ When other camera functions are being performed in the vehicle.
- ▶ When the vehicle moves faster than walking speed.
- ▶ It may not be possible to use the function in every country.
- ▶ For reasons of data protection, the function can only be used three times within two hours.

## **Cross traffic warning**

## **Principle**

At blind driveway exits or when driving out of perpendicular parking spaces, road users approaching from the side are detected sooner by the cross traffic warning than is possible from the driver's seat.

#### General information



Two radar sensors in the rear bumper monitor the area behind the vehicle.

The system indicates approaching road users.

Depending on the vehicle equipment, the traffic area in front of the vehicle is monitored as well. Two additional radar sensors are located in the front bumpers.

## **Safety information**

## Marning

The system cannot serve as a substitute for the driver's personal judgment in assessing visibility and traffic situation. There is a risk of accident. Adjust driving style to traffic conditions. Watch traffic closely and actively intervene where appropriate.

## Overview

#### **Button in the vehicle**





Park assistance button

#### Sensors

The system is controlled by the following sensors:

- Radar sensors, side, rear.
- Depending on the equipment: radar sensors, side, front.

Additional information:

Sensors of the vehicle, refer to page 37.

## Switching on/off

## Activating/deactivating the system

#### With the button



Press the park assistance button.

- 2. Tilt the Controller to the right.
- 3. Settings"
- 4. "Cross Traffic Warning"
- 5. "Cross traffic warning"

#### Via iDrive

- 1. "CAR"
- 2. "Settings"
- 3. "Driver Assistance"
- 4. "Parking and Maneuvering"
- 5. "Cross Traffic Warning"
- 6. "Cross traffic warning"

## Turning on automatically

If the system was activated on the Control Display, it is automatically switched on as soon as PDC Park Distance Control or Panorama View is active and a gear is engaged.

If reverse gear is engaged, the rear system is switched on.

Depending on the vehicle equipment, the front system is switched on when a forward gear is engaged.

## Switching off automatically

The system is automatically switched off in the following situations:

- When the speed exceeds walking speed.
- ▶ When a certain driving distance is exceeded.
- With an active parking operation of the Automatic Parking Assistant.

## **Warning**

### **General information**


The respective display is called up on the Control Display. A signal tone may sound and the light in the exterior mirror may flash.

## **Light in the exterior mirror**




The light in the exterior mirror flashes if vehicles are detected by the rear sensors and your own vehicle is moving in reverse.

## Display in the PDC Park Distance Control view



In the PDC Park Distance Control view, the respective boundary area flashes red, if vehicles are detected by the sensors.

## Display in the camera view



The respective boundary area, arrow 1, in the camera view flashes red, if vehicles are detected by the sensors.

Yellow lines, arrow 2, mark the bumper of your own vehicle.

## **Acoustic warning**

In addition to the optical indicator, a warning signal sounds if your own vehicle moves into the respective direction.

## **System limits**

## **System limits of the sensors**

Additional information:

▶ Radar sensors, refer to page 38.

#### **Functional limitations**

The system may be limited in the following situations:

- In tight curves.
- ▶ When crossing objects move at a very slow or a very fast speed.
- ▶ If other objects are in the capture range of the sensors, that hide cross traffic.

If the trailer power socket is occupied or trailer towing is activated, for instance during operation with trailer or bicycle rack, cross traffic warning is not available for the area behind the vehicle.

## **Driving comfort**

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## **Chassis components**

The chassis components are optimized for the vehicle and its application range and thereby ensure the best possible Driving Dynamics.

## Two-axle self-leveling suspension

## **Principle**

Air suspension ensures best possible driving comfort under all load conditions. Due to a variable adjustment of the front and rear axles, the damping is adjusted to the vehicle state.

## General information

Regardless of the load, the vehicle will be maintained at the configured vehicle level.

Depending on the driving situation, the vehicle level can be set to five levels.

▶ Entry level:

Lowest vehicle level setting.

The entry level can be set when the vehicle is stationary with the following features:

- ▶ With the rocker switch in the center console.
- ▶ With the BMW display key.
- With the button in the lower section of the tailgate.

The vehicle will adjust according to the selected driving mode at drive-off.

- Sport level:
  - Lowest vehicle level, for driving at higher speeds.
- Normal level:

Standard level for normal roads and speeds.

▶ High level 1:

Slightly elevated vehicle level for easy terrain at reduced speed.

If necessary, the vehicle will be lowered at higher speeds.

▶ High level 2:

Highest vehicle level, for terrains with major uneven surfaces in the lowest speed range.

If necessary, the vehicle will be lowered at higher speeds.

Level adjustment takes place when all doors are closed.

## **Safety information**



#### 🛕 Warning

Adjusting the vehicle height may result in trapped body parts or damaged vehicle parts. There is a risk of injury or risk of damage to property. When adjusting the vehicle height, make sure that the areas of movement around the vehicle and at the wheel housing are free.

#### **Overview**

#### Rocker switch in the vehicle



## **Setting the level**

## With the rocker switch in the center console

#### Setting the level



Up:

Push the rocker switch forward.

In the low speed range, the vehicle is raised to next higher level when the rocker switch is pressed.

Down:

Pull the rocker switch backward.

The vehicle will lower by one level.

#### Display

- ▶ LED on the rocker switch lights up: display of the current level.
- LED on the rocker switch is flashing: adjustment procedure active. The vehicle raises or lowers itself.
- ▶ LED on the rocker switch flashes fast: the selected level is not possible at this time.
- All LEDs on the rocker switch are flashing: system is initializing. The selected level will be adjusted after the initialization where required.

#### **Automatic**

#### While driving

In the SPORT driving mode, SPORT+ driving mode or at higher speeds, the vehicle lowers itself automatically.

When a set vehicle level is exited due to the speed, the vehicle level will be adjusted according to the selected driving mode.

#### In the event of a flat tire

When a loss of the tire inflation pressure is detected on a wheel, the wheel load will be reduced automatically to increase the possible range of travel. In this situation, only the normal level is available.

## With the BMW display key

#### **Principle**

The vehicle level can be adjusted with the BMW display key when the vehicle is stationary, for instance for easier loading or as an entry aid.

#### Setting the level

- 1. Apply parking brake and switch drive-ready state off using the Start/Stop button.
- 2. Closing the doors.
- 3. If necessary, switch on the display on the BMW display key and cancel the display lock.

BMW display key, refer to page 87.

- 4. On the BMW display key, change to the following menu: "Entry level".
- 5. "Height control"
- 6. ► "Lower": tap the button. The vehicle lowers itself to the entry level.
  - For safety reasons, lowering is only possible from the normal level or the Sport level.
  - "Raise": tap the button. The vehicle will raise itself from the entry level according to the selected driving mode.

#### Terminating the adjustment procedure

An adjustment procedure that was started on the BMW display key can be terminated with the BMW display key.

"Cancel": tap the button. The vehicle raises or lowers itself back to the starting level.

## With the button in the lower tailgate



When the tailgate is opened, the vehicle can be lowered to the entry level and

raised again by pressing the button. The flashing of the LED in the button indicates the level change.

During the raising procedure, the vehicle raises itself from the entry level to the level that was selected last or the normal level.

#### Terminating the adjustment procedure

An adjustment procedure that was started with the button in the lower tailgate can be terminated with this button.

Press the button again. The vehicle raises or lowers itself back to the starting level.

## **System limits**

- ▶ It is not possible to change the level during sporty driving.
- ▶ It may not be possible to change the level if the axles are limited.

- ▶ It may only be possible to lift the vehicle level while the engine is running.
- ▶ If the state of charge of the vehicle battery is too low, a level change may not be possible.
- ▶ If level adjustment is activated frequently in quick succession, the system switches off to prevent overheating and is temporarily unavailable or operates with a delay. Let the system cool down, if needed.
  - The rapidly flashing LED on the rocker switch indicates that the system is unavailable.
- ▶ If the load is increased, the highest driving level may be disabled or automatically exited in order to protect the system.
- When the trailer power socket is in use or when trailer towing is activated, only the normal level is available.

## Wheel change

Before a wheel change, deactivate the system:

Press the rocker switch forward or pull it backward for approx. 7 seconds. After the rocker switch is released, the LED indicator on the rocker switch will go out.

Activating the system: press the rocker switch forward or pull it backward for approx. 7 seconds. After the rocker switch is released, the LED indicator will reactivate.

## **Malfunction**

A Check Control message is displayed. The system is impaired. Vehicle handling may be altered and driving comfort may be noticeably reduced. Visit the nearest dealer's service center or another qualified service center or repair shop.

## Long periods when vehicle is parked

During long periods when the vehicle is parked, it can lower itself. This is not a malfunction.

When the drive-ready state is switched on with the doors closed, the vehicle is raised to the normal level automatically. Depending on the state of the vehicle, raising to normal level may take several minutes.

## xOffroad package

## **Principle**

The xOffroad package supports the driver when driving away from unpaved roads or with reduced traction. The system offers four different xOffroad driving modes for selection.

## xOffroad driving modes and levels

The xOffroad driving modes can be selected based on the ground conditions.

When an xOffroad driving mode is switched on, individual systems in the vehicle are set to the best possible traction and driving stability.

With the two-axle ride level control, the vehicle level is set for the corresponding xOffroad driving mode.

xOffroad driving mode	Level
"xGRAVEL"	High level 1
"xSAND"	High level 1
"xROCKS"	High level 2
"xSNOW"	Normal level.

## **General information**

The system optimizes handling and the traction on unpaved surfaces within the physical limits.

It is operated with the button and rocker switch in the center console.


Observe the information in the chapter Driving tips for driving on poor roads.

Additional information:

Driving on poor roads, refer to page 330.

#### **Overview**

## Button and rocker switch in the center console




- 1 Switch the xOffroad driving mode on/off.
- 2 Set the xOffroad driving mode.

## **Turning on**

Press button 1 or rocker switch 2 forward or pull back. The xOffroad driving mode "xGRAVEL" is switched on. The LED on the button lights up. The driving mode is displayed in the instrument cluster.

The effective speed range is displayed in the speedometer with a line below the scale.

## Setting the xOffroad driving mode



Push the rocker switch forward or pull it back repeatedly until the desired xOffroad driving mode is displayed in the instrument cluster.

## xOffroad driving modes in detail

## All driving modes

When the xOffroad driving modes are switched on, the following vehicle settings will be applied:

- Auto Start/Stop function is switched off.
- Transmission and accelerator pedal: the shifting behavior and response to the accelerator pedal are adjusted.
- ➤ The all-wheel-drive system is set to the best possible traction.
- Display on the Control Display: the power distribution on the wheels can also be displayed in the xOffroad display.
  - With the proper equipment, additional terrainspecific camera perspectives can be selected.
- ▶ Head-Up Display: in addition to the speed limit, the compass and the values for inclination angles and tilt angles will also be displayed in the Head-up Display.

#### "xGRAVEL"

This driving mode is active every time the xOffroad driving modes are switched on.

Setting for: "Optimized vehicle setting for easy terrain."

When switching on, the following additional vehicle settings are carried out, for example:

- Antilock Braking System: the response behavior is adjusted.
- DSC Dynamic Stability Control: the response behavior is adjusted.
- ➤ Two-axle ride level control: high level 1 is set.

#### "xSAND"

Setting for: "Optimized vehicle setting for heavy terrain with loose surface. For maximum traction, deactivate DSC."

When switching on, the following additional vehicle settings are carried out, for example:

- Antilock Braking System: the response behavior is adjusted.
- ▶ DSC Dynamic Stability Control: the response behavior is adjusted.
- ➤ Two-axle ride level control: high level 1 is set.

#### "xROCKS"

Setting for: "Optimized vehicle setting for heavy terrain with strong irregularities. For maximum traction, deactivate DSC."

When switching on, the following additional vehicle settings are carried out, for example:

- Antilock Braking System: the response behavior is adjusted.
- ▶ DSC Dynamic Stability Control: the response behavior is adjusted.
- ▶ Two-axle ride level control: high level 2 is set.

#### "xSNOW"

Setting for: "Optimized vehicle setting for assured handling on slippery road."

When switching on, the following additional vehicle settings are carried out, for example:

- ➤ Two-axle ride level control: normal level is set.
- Steptronic transmission: the shift behavior is set to gentle gear changes. The vehicle drives off in second gear.
- Accelerator pedal: the characteristic of the accelerator pedal is optimized for gentle handling.

## Manual switching off

Press button 1. The LED on the button goes out. The last driving mode that was set through the Driving Dynamics Control will be activated.

## **Display on the Control Display**

## Display xView display

- 1. "CAR"
- 2. "Driving information"
- 3. "xVIEW"

or

"xOFFROAD"

The following information is displayed:

- ▶ With a navigation system: compass display for the driving direction.
- With navigation system: elevation for the current position.
- ▶ With navigation system: destination flag in compass direction to the destination.
- ▶ Pitch attitude with degree indication and percentage.
- ▶ Transverse gradient with degree indication.
- ▶ Graphic display for the steering angle.
- Level adjustment of the two-axle ride level control.

With the xOffroad package, the following additional information can be displayed:

- ▶ With Surround View: depending on the speed, terrain-specific camera perspectives.
- > xOffroad driving mode currently active.
- Distribution of drive torque to the wheels.

## **System limits**

The xOffroad properties may be reduced at higher speeds where required.

## **Adaptive chassis**

## **Principle**

The adaptive suspension is an intelligent controllable suspension.

The chassis reduces body movements with a sporty driving style or on an uneven road.

## **General information**

The intelligent control of the chassis increases the driving dynamics and driving comfort depending on the road condition and driving style.

## **Tuning**

The system offers different shock absorber settings ranging from comfortable travel to sporty driving.

The shock absorbers are adjusted depending on the road condition and driving style as well as, depending on the equipment, the selected driving mode.

Additional information:

Driving Dynamics Control, refer to page 144.

## **Active roll stabilization**

## **Principle**

Active roll stabilization reduces the roll tendency of the body that occurs during rapid cornering or during quick evasive maneuvers.

## **General information**

The lateral tilt of the vehicle is balanced out by permanent adjustment on the front and rear axles. The vehicle is thus always stabilized.

Agility and driving comfort are increased under all driving conditions.

## **Tuning**

The system offers different settings ranging from comfortable travel to sporty driving.

The settings are assigned to the different driving modes of the Driving Dynamics Control.

Additional information:

Driving Dynamics Control, refer to page 144.

## **Adaptive M chassis**

## **Principle**

The Adaptive M chassis is an intelligent, controllable chassis.

The chassis reduces body movements with a sporty driving style or on an uneven road.

#### **General information**

The intelligent control of the chassis increases the driving dynamics and driving comfort depending on the road condition and driving style.

Depending on the equipment, the rear axle lock differential will be adjusted for the traction conditions as needed.

## **Tuning**

The system offers different shock absorber settings ranging from comfortable travel to sporty driving.

The shock absorbers are adjusted depending on the selected driving mode as well as the road condition and driving style.

Additional information:

Driving Dynamics Control, refer to page 144.

## Adaptive M Chassis Professional

## **Principle**

The Adaptive M Chassis Professional is an actively controlled sport chassis/suspension. The system increases driving comfort and minimizes the lateral tilt when driving around curves.

The Adaptive M Chassis Professional encompasses the following systems:

- Sport chassis.
- Adaptive chassis.

- Active roll stabilization.
- Integral Active Steering.

## **General information**

For active control, this system uses the available information, for instance from the navigation system or the Driving style analysis.

This information influences the control of the following systems, especially in ADAPTIVE driving mode:

- Adaptive chassis.
- Active roll stabilization.
- Integral Active Steering.

This further increases the agility and comfort of the vehicle.

The function may be restricted if the navigation data is invalid, outdated or not available, for example.

Depending on the equipment, the rear axle lock differential will be adjusted for the traction conditions as needed.

## **Performance Control**

Performance Control enhances the agility of the vehicle.

To increase maneuverability, wheels are braked individually when a sporty driving style is used.

## **Engine sound**

Depending on the equipment and national-market version, you may be able to configure the sound of the engine.

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Engine sound"
- 5. Select the desired setting.

## Climate control

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## **Air quality**

#### **General information**

The air quality in the interior is improved by the following components:

- ▶ Emission tested passenger compartment.
- ▶ Interior filter.
- ➤ Air conditioning system to control the temperature, air flow and recirculated-air mode.
- Pre-ventilation.
- ▶ Ionizer.
- Fragrancing.
- Automatic recirculated-air control.

## Interior filter


Depending on the equipment, the interior filter cleans the inflowing outside air and improves the air quality:

- Dust and pollen is filtered out from the inflowing air.
- Nano-particle emissions are reduced.
- Gaseous pollutants are filtered.
- ▶ Microbial particles and allergens are filtered.

## **Automatic climate control**

#### **Overview**

#### **Buttons in the vehicle**



### **Climate control functions**

Button	Function
<b>*</b>	Temperature.
MAX A/C	Maximum cooling.
AUTO	AUTO program.
<b>(</b>	Air recirculation mode.
- Seg. ▲	Air flow, manual.
OFF V	Intensity AUTO program.
#	Air distribution, manual.
MAX	Defrost function.
REAR	Rear window defroster.
	Depending on the equipment:

Button	Function
#	Seat and armrest heating, refer to page 132.
	or
#	Active seat ventilation, refer to page 133.
MENU A/C	Air conditioning.
AIC	Open Climate menu, such as for the following settings: upper body temperature adjustment, pre-ventilation.

Some of the functions can also be used via voice, e.g., temperature.

## **Opening the Climate menu**



MENU Press the button on the upper side.

The Climate menu is displayed.

For example, the following climate control functions can be accessed via the Climate menu:

- Fragrance.
- Air quality.
- Heating/ventilation.
- Pre-ventilation/heating

Individual settings can be entered for some of the climate functions, e.g., switching on/off, intensity.

## **Switching climate control** functions on/off

## **Turning on**

Press one of the following buttons:

- ▶ Temperature.
- ▶ Air conditioning.
- Maximum cooling.
- ▶ AUTO program.
- Air recirculation mode.

- ▶ Upper side of the air flow, manual button.
- Air distribution, manual.
- Defrosting the windshield

## **Turning off**

Complete system:

▶ Button on the driver's side:



Press and hold the button until the integrated automatic climate control switches off.

▶ Button on the passenger's side:



Press and hold the bottom button.

## **Temperature**

#### **Principle**

The automatic climate control cools or heats to the configured temperature and then keeps the temperature constant.

## Setting the temperature

Using the button:



Press the upper or lower button side to set the desired temperature.

Via iDrive:

- 1. "CAR"
- 2. "Settings"
- "Climate control"
- 4. "Heating/ventilation"
- 5. "Driver" or "Front passenger"
- 6. "Temperature:"
- 7. Set the desired temperature.
- 8. "OK"

Do not rapidly switch between different temperature settings. Otherwise, the automatic climate control will not have sufficient time to adjust the set temperature.

# **Temperature of the ventilation**

#### **General information**

The temperature of the ventilation in the upper body region can be adjusted.

The air flow of the ventilation in the upper body region heats or cools noticeably, depending on the adjusted temperature.

This does not change the set interior temperature for the driver and front passenger.

# Adjust temperature of the ventilation

- 1. "CAR"
- 2. "Settings"
- 3. "Climate control"
- 4. "Heating/ventilation"
- 5. "Driver" or "Front passenger"
- 6. "Temperature adjustment"
- 7. Set the desired temperature.

The temperature is individually adjusted, e.g. colder toward blue, warmer toward red.

# Air conditioning

# **Principle**

The air in the car's interior will be cooled and dehumidified and, depending on the temperature setting, warmed again.

# **Functional requirement**

The car's interior can only be cooled with the drive-ready state switched on.

# Switch climate control function on/off

Using the button:



MENU Press the button on the lower side.

Via iDrive:

- 1. "CAR"
- 2. "Settings"
- "Climate control"
- 4. "Heating/ventilation"
- 5. "A/C"

Depending on the weather, the windshield and the side windows may fog up briefly when driveready state is switched on.

Air conditioning is switched on automatically with the AUTO program.

When using the cooling mode, condensation that will exit below the vehicle.

# **Maximum cooling**

### **Principle**

The system is set to the lowest temperature, optimum air flow and recirculated-air mode with the drive-ready state switched on.

# **Functional requirement**

The function is available at an outside temperature above approx. 32 °F/0 °C and with the driveready state switched on.

# Switching maximum cooling on/off



Press the button.

The LED is illuminated when maximum cooling is switched on.

Air flows out of the air vents to the upper body region. The air vents need to be open for this.

The air flow can be adjusted with the program active.

# **AUTO** program

# **Principle**

The AUTO program cools, ventilates or heats the car's interior automatically.

The air distribution and the temperature are controlled automatically depending on the interior temperature and the desired temperature setting including the selected intensity of the air flow.

# Switching the AUTO program on/off

Using the button:

AUTO Press

Press the button.

The LED of the button is illuminated with the AUTO program switched on.

Via iDrive:

- 1. "CAR"
- 2. "Settings"
- 3. "Climate control"
- 4. "Heating/ventilation"
- 5. "Driver" or "Front passenger"
- 6. "Automatic"

Depending on the selected settings and outside influences, the air is directed to the windshield, side windows, upper body, and into the floor area.

Point the side air vents toward the side windows.

The cooling function is switched on with the AUTO program.

At the same time, a condensation sensor controls the program so as to prevent window condensation as much as possible.

The AUTO program is switched off automatically, when manual air distribution is set.

# Controlling the intensity of the air flow

With the AUTO program switched on, the intensity can be adjusted. This changes the automatic control for the air mass.

Using the button:



Press the lower or upper side of the button: decrease or increase intensity.

Via iDrive:

- 1. "CAR"
- 2. "Settings"
- 3. "Climate control"
- 4. "Heating/ventilation"
- 5. "Driver" or "Front passenger"
- 6. "Level"
- 7. Set the desired intensity.

The selected intensity is shown on the climate control display.

# Automatic recirculated-air control

### **Principle**

The automatic recirculated-air control recognizes pollutants in the outside air. The outside air supply is shut off and the interior air is recirculated.

#### **General information**

If the system is activated, a sensor detects pollutants in the outside air and controls the shut-off automatically.

If the system is deactivated, outside air continuously flows into the car's interior.

With constant air recirculation mode, the air quality in the car's interior deteriorates and window fogging increases.

If there is window condensation, switch off recirculated-air mode or defog the windows.

# Switching automatic recirculated-air control on/off

- 1. "CAR"
- 2. "Settings"
- 3. "Climate control"
- 4. "Air quality"
- 5. "Automatic"

### Air recirculation mode

### **Principle**

You may react to unpleasant odors or pollutants in the immediate environment by temporarily suspending the supply of outside air. The system then recirculates the interior air.

When recirculated-air mode is switched off, fresh air is directed into the vehicle's interior.

#### Switch air recirculation on/off

Using the button:

Press the button.

The LED of the button is illuminated when the air-recirculation mode is switched on.

#### Via iDrive:

- 1. "CAR"
- 2. "Settings"
- 3. "Climate control"
- 4. "Air quality"
- 5. Select the desired setting:
  - "Air recirculation"
  - "Fresh air"

To prevent window fogging, recirculated-air mode switches off automatically after a certain amount of time, depending on the environmental conditions.

With constant air recirculation mode, the air quality in the car's interior deteriorates and window fogging increases.

If there is window condensation, switch off recirculated-air mode or defog the windows.

# Air flow, manual

# **Principle**

The air flow for climate control can be adjusted manually.

#### **General information**

To adjust the air flow manually switch off AUTO program first.

# Adjusting the air flow manually



Press the lower or upper side of the button: decrease or increase air flow.

The selected air flow is shown on the climate control display.

The air flow may be reduced automatically to save battery power.

#### Manual air distribution

### **Principle**

The air distribution for climate control can be adjusted manually.

# Adjusting the air distribution manually



Press the button repeatedly. Select the desired setting:

- ▶ Windows, upper body region, and floor area.
- Upper body region and floor area.
- Floor area.
- Windows and floor area.
- Windows.
- ▶ Windows and upper body region.
- Upper body region.

The selected air distribution is shown on the climate control display.

# **SYNC** program

# **Principle**

The Sync program can be used to apply the settings on the driver's side to the passenger's side.

The Sync program can be used to apply the settings on the driver's side to the passenger's side and the rear

# Switching the SYNC program on/off

- 1. "CAR"
- 2. "Settings"
- "Climate control"
- 4. "Synchronize"

Depending on the equipment, the following settings of the driver's side can be transferred to the front-passenger side and the rear:

- ▶ Temperature.
- Air flow.
- Air distribution.
- ▶ AUTO program.

The program is switched off automatically if the settings on the front passenger side or in the rear are changed.

#### **Defrost function**

# **Principle**

Ice and condensation are quickly removed from the windshield and the front side windows.

# Switching the Defrost function on/off

Press the button.

The LED of the button is illuminated when the system is switched on.

The air flow can be adjusted manually with the system switched on.

If there is window condensation, switch on the AUTO program or the air conditioning to utilize the condensation sensor. Make sure that air can flow to the windshield.

# **Rear window defroster**

# **Principle**

Ice and condensation are removed from the rear window quickly.

#### **Functional requirement**

The function is operational when the drive-ready state is switched on.

# Switching rear window defroster on/off



Press the button. The LED is illuminated with rear window defroster

switched on.

The rear window defroster switches off automatically after a certain period of time.

# Microfilter/activated-charcoal filter

The microfilter removes dust and pollen from the incoming air.

The activated-charcoal filter also removes gaseous pollutants from the outside air that enters the vehicle.

Have this combined filter changed during vehicle maintenance.

# **Ventilation**

# **Principle**

The air flow directions can be adjusted individually for direct or indirect ventilation.

# **Setting the ventilation**

#### **General information**

Open the air vents and position them to ensure effective climate control.


#### **Direct ventilation**

The air flow is directed towards the passengers. The air flow heats or cools noticeably, depending on the adjusted temperature.

#### Indirect ventilation


The air flow is not directed towards the passengers. The vehicle interior is warmed or cooled indirectly, depending on the set temperature.

#### Front ventilation



- Lever for changing the air flow direction, arrow 1.
- ➤ Thumbwheel for variable opening and closing of the air vents, arrow 2.

# Ventilation in rear, center



- ▶ Lever for changing the air flow direction, arrow 1.
- ➤ Thumbwheel for variable opening and closing of the air vents, arrow 2.
- ➤ Thumbwheel for varying the temperature, arrow 3.

Toward blue: colder

Toward red: warmer.

# Ventilation in the rear, on the side



- Lever for changing the air flow direction, arrow 1.
- ➤ Thumbwheel for variable opening and closing of the air vents, arrow 2.

# Heating and ventilation, third row of seats

The air in the area of the third row of seats can be heated or circulated. The air vents are located in the storage area between the seats and in the floor area of the third row of seats.



- ▶ Button for switching on the fan, arrow 1. The LED lights up.
- ➤ Thumbwheel for the activation of the heat and distribution of the air, arrow 2.

Turn toward the front: activate the heater and distribute the air in the floor area.

Turn toward the rear: distribute the air in the storage area between the seats.

The heater is not ready for operation without switching on the fan. After the heater is switched

off, the fan can be used to circulate the interior air, for instance at high temperatures. To do this, switch on the fan, arrow 1, and turn the thumbwheel toward the rear, arrow 2.

# Rear automatic climate control

#### **Overview**

#### **Buttons in the vehicle**



#### **Climate control functions**

Button	Function
•	Temperature.
MAX A/C	Maximum cooling.
AUTO	AUTO program.
SF ▼	Air flow, manual. Intensity Auto program.
<b>₹</b> ,	Air distribution, manual.
##	Seat heating, refer to page 132.

# Switching climate control functions on/off

#### **Functional requirement**

The rear automatic climate control is not ready for operation if the automatic climate control is switched off or if the function for defrosting the windows and removing condensation is active.

### Switching on/off using iDrive

- 1. "CAR"
- 2. "Settings"
- 3. "Climate control"
- 4. "Heating/ventilation"
- 5. "Second row of seats"
- 6. "Activate heating/cooling"

### Switching on using the button

Press one of the following buttons:

- ▶ Temperature.
- Maximum cooling.
- > AUTO program.
- ▶ Upper side of the air flow, manual button.
- ▶ Air distribution, manual.

# Switching off using the button



Press and hold the bottom of the button.

# **Temperature**

# **Principle**

The automatic climate control cools or heats to the configured temperature and then keeps the temperature constant.

# Setting the temperature

Using the button:



Press the upper or lower button side to set the desired temperature.

#### Via iDrive:

- 1. "CAR"
- 2. "Settings"
- 3. "Climate control"
- 4. "Heating/ventilation"
- 5. "Second row of seats"
- 6. "Temp. left:" or "Temp. right:"
- 7. Set the desired temperature.

The selected temperature is shown on the climate control display.

Do not rapidly switch between different temperature settings. Otherwise, the automatic climate control will not have sufficient time to adjust the set temperature.

# **Maximum cooling**

# **Principle**

The system is set to the lowest temperature, optimum air flow and recirculated-air mode with the drive-ready state switched on.

# **Functional requirement**

The function is available at an outside temperature above approx. 32  $^{\circ}$ F/0  $^{\circ}$ C and with the driveready state switched on.

# Switching maximum cooling on/off

MAX A/C

Press the button.

The LED in the button is illuminated when maximum cooling is switched on.

Air flows out of the air vents to the upper body region. The air vents need to be open for this.

# **AUTO** program

#### **Principle**

The air flow, air distribution and the temperature are controlled automatically.

# Switching the AUTO program on/off

Using the button:

AUTO

Press the button.

The LED of the button is illuminated with the AUTO program switched on.

Via iDrive:

- 1. "CAR"
- 2. "Settings"
- 3. "Climate control"
- 4. "Heating/ventilation"
- 5. "Second row of seats"
- 6. "Automatic"

Depending on the selected settings and outside influences, the air is directed to the upper body and into the floor area.

# Controlling the intensity of the air flow

With the AUTO program activated, the automatic intensity control can be changed:

Using the button:



Pressing the lower or upper side of the button repeatedly: decrease or increase

intensity.

#### Via iDrive:

- 1. "CAR"
- 2. "Settings"
- 3. "Climate control"
- 4. "Heating/ventilation"
- 5. "Second row of seats"
- 6. "Level"
- 7. Set the desired intensity.

The air flow and air distribution are automatically regulated depending on the selected intensity.

The selected intensity is shown on the climate control display.

# Air flow, manual

# **Principle**

The air flow for climate control can be adjusted manually.

#### **General information**

To adjust the air flow manually switch off AUTO program first.

# Adjusting the air flow manually



Pressing the upper or lower side of the button repeatedly: decrease or increase

air flow.

The selected air flow is shown on the climate control display.

# **Manual air distribution**

# **Principle**

The air distribution for climate control can be adjusted manually.

# Adjusting the air distribution manually



Pressing the upper or lower side of the button. Select the desired setting:

- ▶ Upper body region.
- Upper body region and floor area.
- ▶ Floor area.

# Locking the control elements

# **Principle**

The control elements of the rear automatic climate control can be disabled.

#### Activate/deactivate

- 1. "CAR"
- 2. "Settings"
- 3. "Climate control"
- 4. "Heating/ventilation"
- 5. "Second row of seats"
- 6. "Disable controller"

# **Pre-ventilation**

# **Principle**

The car's interior can be cooled or heated before driving off with the pre-ventilation. Depending on set temperature and ambient temperature, the car's interior is ventilated or possibly heated using the residual engine heat.

## **General information**

The system can be switched on and off directly or via a preset departure time.

The activation time is determined based on the outside temperature. The system promptly switches on before the selected departure time.

# **Functional requirements**

- ➤ The vehicle is in idle state or standby state and not in drive-ready state.
- ▶ The battery is sufficiently charged. If pre-ventilation is switched on, the vehicle battery will be discharged. Thus, limit the maximum activation time to save the vehicle battery. The system will be available again after the engine is started or after a short trip.
- ▶ Make sure that the vehicle's date and time are set correctly.
- Open the air vents to allow air to flow out.

# Switching on/off directly

#### **General information**

There are different ways to switch the system on or off.

The system switches off automatically after a certain period of time. The system continues to run for some time after being switched off.

### **Using the button**

#### **Functional requirement**

When the vehicle is in standby state, the preventilation can be switched on or off with the automatic climate control buttons.

#### **Turning on**

Press one of the following buttons:

- Temperature.
- ▶ Air conditioning.
- Maximum cooling.
- > AUTO program.
- ▶ Air recirculation mode.
- ▶ Upper side of the air flow, manual button.
- ▶ Air distribution, manual.
- Defrosting the windshield

#### **Turning off**



Press and hold the bottom button.

The system switches off after leaving and locking the vehicle.

#### Via iDrive

# Turning on

- 1. "CAR"
- 2. "Settings"
- 3. "Climate control"
- 4 "Pre-ventilation"
- 5. "Start now"

#### Via BMW display key

#### Turning on

- Switch on the display of the BMW display key.
- 2. "Preconditioning setting"
- 3. Tap the \( \mathbb{S} \) icon or the \( \mathbb{H} \) icon.
- 4. "Activate now"
- 5. "Start"

#### **Turning off**

- Switch on the display of the BMW display key.
- 2. "Preconditioning setting"
- 3. Tap the \mathbb{S} icon or the \mathbb{s} icon.
- 4. "Stop"

### **Display**

Icon	Description
SS	Symbol on the climate control display.
	Flashing: the pre-ventilation is switched on.

# **Departure time**

# **Principle**

Different departure times can be set to ensure a comfortable interior temperature in the vehicle at the time of departure.

▶ One-time departure time: the time can be set.

The system is switched on once.

Departure time with weekday: time and day of the week can be set.

On the desired weekdays, the system will be switched on before the set departure time.

The departure time is preselected in two steps:

- Set departure times.
- Activate departure times.

A minimum of 10 minutes should pass between setting/activating the departure time and the planned departure time to allow a sufficient period of time for the climate control.

# Setting the departure time

#### Via iDrive

- 1. "CAR"
- 2. "Settings"
- "Climate control"
- 4. "Pre-ventilation"
- 5. "Departure plan"
- 6. Select the desired departure time.
- 7. Set the departure time.
- 8. Select day of the week, if needed.
- 9. "OK"

#### Via BMW display key

- 1. Switch on the display of the BMW display key.
- 2. "Preconditioning setting"
- 3. Tap the \mathbb{S} icon or the \mathbb{S} icon.
- 4. Select the desired departure time.
- 5. Set the departure time.
- 6. Select day of the week, if needed.
- 7. "OK"

# Activating the departure time

### **Functional requirement**

To switch on the parked-car ventilation automatically at the departure time, the departure time must be activated first.

#### Via iDrive

- 1. "CAR"
- 2. "Settings"

- 3. "Climate control"
- 4. "Pre-ventilation"
- 5. "Departure plan"
- 6. Activate the desired departure time.

### Via BMW display key

- 1. Switch on the display of the BMW display
- 2. "Preconditioning setting"
- 3. Tap the \( \mathbb{S} \) icon or the \( \mathbb{H} \) icon.
- 4. Tap on the icon.
- 5. Activate the desired departure time.

# **Display**

\&\text{\tin}\text{\tetx{\text{\tetx{\text{\text{\text{\text{\text{\text{\texi}\text{\text{\text{\tin}\text{\text{\text{\text{\texi}\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\tex{ signals an activated departure time.

# **Pre-conditioning through Remote Engine Start**

# **Principle**

Pre-conditioning cools or heats the car's interior prior to departure to a comfortable temperature. The system automatically cools, vents, and heats depending on the interior, external, and set temperature. Snow and ice may be removed more

The system starts the engine automatically and allows it to run for a limited period of time.

# Safety information



#### A DANGER

If the exhaust pipe is blocked or ventilation is insufficient, harmful exhaust gases can pollute the area in and around the vehicle or enter into the vehicle. The exhaust gases contain pollutants which are colorless and odorless. In enclosed areas or areas with insufficient ventilation, exhaust gases can also accumulate

outside of the vehicle. There is danger to life. Keep the exhaust pipe free and ensure sufficient ventilation. Do not switch on stationary climate control in enclosed areas or areas with insufficient ventilation, e.g. in enclosed garages.

# 

When stationary climate control is in operation, high temperatures can occur underneath the body, for instance caused by the exhaust gas system. If combustible materials, such as leaves or grass, come in contact with hot parts of the exhaust gas system, these materials can ignite. There is a risk of fire. Make sure that no combustible materials can come in contact with hot vehicle parts during stationary climate control operation, e.g. leaves, grass, gas, gasoline, oil or other combustible objects.

# **Functional requirements**

- ➤ The vehicle is in idle state or standby state and not in drive-ready state.
- Battery is sufficiently charged.
- For reasons of safety, the system can only be switched on twice consecutively. The system will be available again as soon as the driveready state is activated and deactivated again.
- ▶ The fuel tank capacity is sufficient.
- ▶ Hood is closed.
- ▶ Make sure that the vehicle's date and time are set correctly.
- ▶ Air vents are opened.

# **Enabling the automatic engine start function**

The automatic engine start must be enabled before using the system. Otherwise, the engine cannot switch on automatically to climatize the car's interior.

#### Via iDrive:

- 1. "CAR"
- 2. "Settings"
- "Climate control"
- 4. "Preconditioning/ventilation"
- 5. "Remote Engine Start"
- 6. "Starting engine for clim. control"
- 7. Confirm the disclaimer.

# Switching on/off directly

#### **General information**

The system switches off automatically after approx. 15 minutes.

For reasons of safety, the system can only be switched on twice consecutively. The system will be available again as soon as the drive-ready state is activated and deactivated again.

### Switching on via iDrive

- 1. "CAR"
- 2. "Settings"
- 3. "Climate control"
- 4. "Preconditioning/ventilation"
- 5 "Start now"

# Switching on/off via vehicle key

The system can be switched on and off using the vehicle key.



Press the button on the vehicle key three times within 1 second.

After operating the vehicle key, it will take approximately 3 seconds until the engine is switched on.

To switch off the system, press the button again three times

# Switching on via BMW display key

- 1. Switch on the display of the BMW display key.
- 2. "Preconditioning setting"
- 3. (3) Tap on the icon.
- 4. "Activate now"
- 5. "Start"

# Switching off via BMW display key

- Switch on the display of the BMW display key.
- 2. "Preconditioning setting"
- 3. (3) Tap on the icon.
- 4. "Stop"

# Switching off with the Start/Stop button

The system can be switched off directly as follows: pressing the Start/Stop button, without operating the brake pedal.

# Switching on via departure time

#### **General information**

Scheduled departure times can be set up in the system to ensure a comfortable interior temperature in the vehicle at the time of departure.

- ➤ One-time departure time: the time of the scheduled departure can be set.
  - The system is switched on once.
- Departure time with weekday: time and day of the week of the scheduled departure can be set.

The departure time is preselected in two steps:

- Set departure times.
- Activate departure times.

The climate control function will start approximately 10 minutes before the set departure time and continue for approximately 5 more minutes after the departure time.

A minimum of 10 minutes should pass between setting/activating the departure time and the planned departure time to allow a sufficient period of time for the climate control.

For reasons of safety, the system can only be switched on once. The system will be available again as soon as the drive-ready state is activated and deactivated again.

Observe the information about the intended use of the vehicle.

Additional information:

For Your Own Safety, refer to page 8.

# Adjusting the departure time via iDrive

- 1. "CAR"
- 2. "Settings"
- 3. "Climate control"
- 4. "Preconditioning/ventilation"
- 5. "Departure plan"
- 6. Select the desired departure time.
- 7. Set the departure time.
- 8. Select day of the week, if needed.

# Adjusting the departure time via BMW display key

- 1. Switch on the display of the BMW display key.
- 2. "Preconditioning setting"
- 3. Tap on the icon.
- 4. Select the desired departure time.
- 5. Set the departure time.
- 6. Select day of the week, if needed.
- 7. "OK"

# Activating the departure time via iDrive

- 1. "CAR"
- 2. "Settings"
- "Climate control"

- 4. "Preconditioning/ventilation"
- "Departure plan"
- 6. Activate the desired departure time.

# Activating the departure time via **BMW** display key

- 1. Switch on the display of the BMW display
- 2. "Preconditioning setting"
- 3. So Tap on the icon.
- 4. Activating the desired departure time:
  - Tap on the icon.

# **Display**



In the instrument cluster:

The engine runs for the purpose of operating the pre-conditioning. The vehicle is not ready to drive.

trol signals an activated departure time.

& The icon flashes while Remote Engine Start is running.

# Confirmation signals from the vehicle

The activation of the system is confirmed by flashing twice.

The parking lights are switched on as long as the system is switched on.

# **Ambient air package**

# **Principle**

The Ambient Air Package can be used to clean and scent the interior air with high-quality fraarances.

#### General information

Two different fragrances can be selected in the vehicle. A variety of other fragrances is possible by replacing the fragrance cartridges.

The following criteria can influence the perception of scents in the vehicle interior:

- Automatic climate control settings.
- ▶ Temperature and atmospheric humidity.
- ▶ Time of day and season.
- Physical condition of the vehicle occupants, for instance fatique.

BMW recommends the use of genuine BMW fragrance cartridges.

The genuine BMW fragrance cartridges are not suitable for refilling. When a cartridge is empty, replace it with a new fragrance cartridge.

# **Safety information**



# Marning

Refilled genuine BMW fragrance cartridges can cause the emission of harmful substances, malfunctions, and damage to the system. There is a risk of injury or risk of damage to property. Do not refill genuine fragrance cartridges. When a cartridge is empty, replace it with a new fragrance cartridge.

# **Opening the Climate menu**



Press the button on the upper side.

The Climate comfort menu is displayed.

Individual settings can be entered for some of the climate control functions.

## lonizer

# **Principle**

The ionizer cleans the car's interior air of suspended particles and improves the air quality.

# Switching the ionizer on/off

- 1. "CAR"
- 2. "Settings"
- 3. "Climate control"
- 4. "Air quality"
- 5. "Ionization"

# **Fragrancing**

#### **General information**

Fragrancing is done at intervals in order to avoid a habituation effect.

Two fragrance cartridges in the vehicle allow switching between the fragrances.

The fragrance cartridges are located in the glove compartment.

To ensure a pleasant fragrance inside of the vehicle when starting the trip, fragrancing can occur prior to the trip. The system is automatically switched on with the pre-ventilation if fragrancing was switched on at the completion of the last trip.

# **Functional requirements**

- ▶ The fragrance cartridges are sufficiently filled.
- ► The interior temperature is between 41 °F/+5 °C and 104 °F/+40 °C.
- ▶ Open the air vents to allow the fragrance to flow out.

# Selecting the fragrance

The car's interior is fragranced depending on the selected fragrance.

Two different fragrances can be selected in the vehicle.

- 1. "CAR"
- "Settings"
- 3. "Climate control"
- 4. "Fragrance"
- 5. Select the desired fragrance.

# Switching fragrancing on/off, adjusting intensity

- 1. "CAR"
- 2. "Settings"
- 3. "Climate control"
- 4. "Fragrance"
- 5. "Level"
- 6. Select the desired setting.

Highest intensity at Level 3.

# **Display**

The illustrations on the Control Display show the actual filling level of the fragrance cartridges.

- 1. "CAR"
- 2. "Settings"
- 3. "Climate control"
- 4. "Fragrance"

When an empty fragrance cartridge is indicated, the cartridge still contains a fluid carrying the fragrance. However, it is not sufficient for fragrancing.


When the fragrance cartridges are empty, a Check Control message is displayed once.

# Inserting fragrance cartridges

The fragrance cartridges are located in the glove compartment.

- 1. Open the glove compartment.
  - Front passenger side glove compartment, refer to page 316.
- 2. Press on the bottom of the cartridge holder.

The cartridge holder slides down.



3. Remove the cover of the new fragrance cartridge. Hold the cover on the top to slide it from the fragrance cartridge.



4. Insert the removed cover on the rear of the fragrance cartridge.



5. Position fragrance cartridge such that the chip faces away from the cartridge holder.



Insert the fragrance cartridge without pressure into the cartridge holder. The cartridge snaps lightly into place.




- Push the cartridge holder up, until it engages.
   Make sure that no objects press against the cartridge holder from below, otherwise the function of the ambient air package could be impacted.
- 8. Close the glove compartment.

# Removing the fragrance cartridge

The fragrance cartridges are located in the glove compartment.

- Open the glove compartment.
   Front passenger side glove compartment, refer to page 316.
- 2. Press on the bottom of the cartridge holder.

The cartridge holder slides down.



3. Pull desired fragrance cartridge from the holder.

Fragrance cartridge, arrow 1: first fragrance indicated on the Control Display.

Fragrance cartridge, arrow 2: second fragrance indicated on the Control Display.



4. Pull desired fragrance cartridge from the holder.



# Recycling

Empty fragrance cartridges can be taken to a dealer's service center or another qualified service center or repair shop for

recycling.

# Interior equipment

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

# **Integrated Universal Remote Control**

# **Principle**

The integrated Universal Remote Control in the interior mirror can operate up to 3 functions of remote-controlled systems such as garage door drives, barriers, or lighting systems.

#### **General information**

The Integrated Universal Remote Control replaces up to 3 different hand-held transmitters. To operate the remote control, the buttons on the interior mirror must be programmed with the desired functions. The hand-held transmitter for the particular system is required in order to program the remote control.

Before selling the vehicle, delete the stored functions for the sake of security.

If possible, do not install the antenna of the remote-controlled system, e.g. the garage door drive, near metal objects to ensure the best possible operation.

# **Safety information**



#### 🗥 Warning

The operation of remote-controlled systems with the integrated universal remote control, such as the garage door, may result in injury, for example, body parts becoming jammed in a garage door. There is a risk of injury or risk of damage to property. Make sure that the area of movement of the respective system is clear during programming and operation. Also follow the safety information for the hand-held transmitter.

# Compatibility



If this symbol is printed on the packaging or in the operating instructions of the system to be controlled, the system is


generally compatible with the integrated Universal Remote Control.

Additional questions are answered by:

- A dealer's service center or another qualified service center or repair shop.
- www.homelink.com on the Internet.

HomeLink is a registered trademark of Gentex Corporation.

# Control elements on the interior mirror



- ▶ Buttons, arrow 1.
- ▶ LED, arrow 2.
- ➤ The hand-held transmitter, arrow 3, is required for programming.

# **Programming**

#### General information

The battery of the hand-held transmitter must be fully charged at the time of programming to ensure an optimal range of the integrated universal remote control.

- 1. Turn on standby state.
- 2. Initial commissioning:

Press and hold the two outer buttons on the interior mirror simultaneously for approximately 10 seconds until the LED flashes green rapidly. This erases all programming of the buttons on the interior mirror.

- Press the interior mirror button to be programmed. The LED on the interior mirror will slowly begin flashing orange.
- Hold the hand-held transmitter for the system to be used approx. 1 to 12 in/2.5 to 30 cm away from the buttons on the interior mirror. The required distance depends on the handheld transmitter.
- 5. Press and hold the button of the desired function on the hand-held transmitter.

Canada: if programming with the hand-held transmitter was interrupted, hold down the interior mirror button and repeatedly press and release the hand-held transmitter button for 2 seconds.

6. ▶ The LED lights up green: programming completed.

Release the button.

▶ The LED flashes fast: programming is not complete.

Press the button on the interior mirror for 2 seconds and release. Perform this procedure three times to complete the programming procedure.

If the integrated universal remote control remains nonoperational, continue with the special features for change code wireless systems.

▶ LED does not flash green after 60 seconds: programming not completed.

Repeat steps 3 to 6.

To program other functions on other buttons, repeat steps  $3\ \text{to}\ 5.$ 

# Special feature of the rolling code wireless system

If you are unable to operate the remote-controlled system after repeated programming, please check if the system to be controlled features a rolling code radio system.

Refer to the operating instructions for the system.

For systems with a rolling code radio system, the integrated Universal Remote Control and the system also have to be synchronized.

Please read the operating instructions to find out how to synchronize the system.

Synchronizing is easier with the aid of a second person.

Synchronizing the universal remote control with the system:

- 1. Park the vehicle within range of the remotecontrolled system.
- 2. Program the relevant button on the interior mirror as described.
- 3. Locate and press the synchronizing button on the system being programmed, e.g. at the garage gate. You have approx. 30 seconds for the next step.
- 4. Hold down the programmed button on the interior mirror for approximately 3 seconds and then release it. If necessary, repeat this step up to three times in order to end synchronization. Once synchronization is complete, the programmed function will be carried out.

# Reprogramming individual **buttons**

- 1. Turn on standby state.
- 2. Press and hold the interior mirror button to be programmed.
- 3. As soon as the LED on the interior mirror flashes orange after approx. 20 seconds, release the button.
- 4. Hold the hand-held transmitter for the system to be used approx. 1 to 12 in/2.5 to 30 cm away from the buttons on the interior mirror. The required distance depends on the handheld transmitter.
- 5. Press and hold the button of the desired function on the hand-held transmitter.
  - Canada: if programming with the hand-held transmitter was interrupted, hold down the interior mirror button and repeatedly press and release the hand-held transmitter button for 2 seconds.
- 6. The LED can light up in different ways.
  - ▶ The LED lights up green: the programming procedure is completed.

- Release the button.
- ▶ The LED flashes fast: the hand-held. transmitter was detected but programming is not complete.
  - Press the button on the interior mirror for 2 seconds and release. Perform this procedure three times to complete the programming procedure.
  - If the integrated universal remote control remains nonoperational, continue with the special features for change code wireless systems.
- ▶ LED does not flash green after 60 seconds: programming not completed. Repeat steps 3 to 6.

If the programming procedure is not completed. the previous programming will remain unchanged.

# **Operation**



#### Warning

The operation of remote-controlled systems with the integrated universal remote control, such as the garage door, may result in injury, for example, body parts becoming jammed in a garage door. There is a risk of injury or risk of damage to property. Make sure that the area of movement of the respective system is clear during programming and operation. Also follow the safety information for the hand-held transmitter.

The system, such as the garage door, can be operated using the button on the interior mirror while the drive-ready or standby state is switched on. To do this, hold down the button within receiving range of the system until the function is activated. The interior mirror LED stavs lit while the wireless signal is being transmitted.

# **Deleting stored functions**

All stored functions will be deleted. The functions cannot be deleted individually.

Press and hold the two outer buttons on the interior mirror simultaneously for approximately 10 seconds until the LED on the interior mirror flashes green fast.

# **Sun visor**

### Glare shield

Fold the sun visor down or up.

#### Glare shield from the side

# **Folding out**

- 1. Fold the sun visor down.
- 2. Unhook it from the holder and swing it to the side.
- 3. Move it back to the desired position.

# **Folding in**

Proceed in the reverse order to close the sun visor.

# **Vanity mirror**

A vanity mirror is located in the sun visor behind a cover. When the cover is opened, the mirror lighting switches on.

# **Ashtray**

#### Front center console

# **Opening**

1. Press onto the cover.



2. The ashtray is located in a cup holder. Fold the ashtray cover upward.



### **Emptying**

1. Pull the ashtray with the closed cover out of the cup holder.



2. Turn the lid counterclockwise to open it.



3. Empty the container. Always empty the ashtray with the container open to prevent contamination of the lid.

# **Cigarette lighter**

# **Safety information**



Contact with the hot heating element or the hot socket of the cigarette lighter can cause burns. Flammable materials can ignite if the cigarette lighter falls down or is held against the objects. There is a risk of fire and an injury hazard. There is a risk of damage to property, among other potential damage. Take hold of the cigarette lighter by its handle. Make sure that children do not use the cigarette lighter.

#### ∧ NOTICE

If metal objects fall into the socket, they can cause a short circuit. There is a risk of damage to property, among other potential damage. Insert the cigarette lighter or socket cover again after using the socket.

#### Front center console




Press onto the cover.



A cigarette lighter is located between the cup holders in one of the marked positions.

#### Rear center console



The cigarette lighter is located in the socket.

# **Operation**



Push in the cigarette lighter.

The cigarette lighter can be removed as soon as it pops back out.

# **Sockets**

# **Principle**

The lighter socket can be used as a socket for electrical equipment when standby and driveready state are switched on.

# **General information**

The total load of all sockets must not exceed 140 watts at 12 volts.

Do not damage the socket by using non-compatible connectors.

# **Safety information**



#### Marning

Devices and cables in the unfolding area of the airbags, such as portable navigation devices, can hinder the unfolding of the airbag or be thrown around in the car's interior during unfolding. There is a risk of injury. Make sure that

devices and cables are not in the airbag's area of unfolding.



#### ⚠ NOTICE

Battery chargers that charge the vehicle battery via sockets or cigarette lighters in the vehicle may overload or damage the 12 V electrical system. There is a risk of damage to property, among other potential damage. Only connect battery chargers for the vehicle battery to the starting aid terminals in the engine compartment.



#### ⚠ NOTICE

If metal objects fall into the socket, they can cause a short circuit. There is a risk of damage to property, among other potential damage. Insert the cigarette lighter or socket cover again after using the socket.

### Front center console




Press onto the cover.



A socket is located between the cup holders in one of the marked positions.

Pull off the cover.

#### Rear center console



A socket is located in the center console. Pull off the cover.

# In the cargo area



A socket is located on the right side in the cargo area. Unfold the cover.

# **USB** port

#### General information

Follow the information regarding the connection of mobile devices to the USB port in the section on USB connections.

Additional information:

USB connections, refer to page 80.

#### In the center armrest



A USB port is located in the center armrest.

Properties:

- ▶ USB port Type C.
- For charging mobile devices and for data transmission.
- ▶ Charge current: max. 3 A.

# In the center console

#### ∧ NOTICE

Objects in the storage compartment, e.g., large USB connectors, may block or damage the cover when it is being opened or closed. There is a risk of damage to property, among other potential damage. Make sure that the area of movement of the cover is clear while opening and closing it.



Press onto the cover.



A USB port is located in the center console.



If the vehicle is equipped with thermo-cup holders, a USB port is located in the center console.

#### Properties:

- ▶ USB port Type A.
- ▶ For charging mobile devices and for data transmission.
- ▶ Charge current: max. 1.5 A.

# Wireless charging tray

# **Principle**

The wireless charging tray enables the following wireless functions:

- Charging the rechargeable battery of a mobile phone with Qi capability and of other mobile devices, which support the Qi standard.
- Charging the BMW Display key.

### **General information**

When inserting the mobile phone, make sure there are no objects between it and the wireless charging tray.


During charging, the surface of the tray and the mobile phone may become warm. Higher temperatures may lead to a reduction in the charge current through the mobile phone, and in isolated cases the charging process is paused temporarily. Follow the relevant instructions in the mobile phone owner's manual.

(1) The charge indicator shows on the Control Display whether a mobile phone with Qi capability is being charged.

#### NOTE

This device has been tested for human exposure limits and found compliant at a minimum distance of 2 in/5 cm during operation.

Therefore, a distance of 4 in/10 cm must be maintained in every direction when operating the device.



Mounting position of the product.

# **Safety information**

### Marning

When charging a device that meets the Qi standard in the wireless charging tray, any metal objects located between the device and the tray can become very hot. Placing storage devices or electronic cards, such as chip cards, cards with magnetic strips or cards for signal transmission, between the device and the tray may impair the card function. There is a risk of injury and risk of damage to property. When charging mobile devices, make sure there are no objects between the device and the tray.


### **Overview**

Tray across in the center console:



- LED 1
- 2 Storage area

Tray on the left in the center console:



- 1 LED
- 2 Storage area

# **Functional requirements**

- ▶ The mobile phone must compatibly support the required Qi standard.
  - If the mobile phone does not support the Qi standard, the mobile phone can be charged using a special Qi-compatible charging case.
- > Standby state is switched on.
- Observe the maximum dimensions of the mobile phone.
- ▶ Use only protective jackets and covers up to a maximum thickness of 0.07 in/2 mm; otherwise, the charging function may be impaired.
- ▶ The mobile phone to be charged is located in the center of the tray.

# **Operation**

# Inserting the mobile phone

The mobile phone must not exceed the maximum size of approximately 6.0 x 3.1 x 0.7 in/154.5 x 80 x 18 mm.

- 1. Open the tray cover.
- 2. Place the mobile phone centered in the tray with the display facing up.
- 3. Close the tray cover.

# Removing the mobile phone

- 1. Open the tray cover.
- 2. Remove the mobile phone.

# **LED** displays

Color	Meaning
Blue	The mobile phone is charging.
	The blue LED stays illuminated once the inserted mobile phone with Qi capability is fully charged.
Orange	The mobile phone is not charging.
	Temperature on the mobile phone possibly too high or foreign object in charging tray.
Red	The mobile phone is not charging.
	Contact a dealer's service center or another qualified service center or repair shop.

# Forgotten warning

#### **General information**

If the vehicle is equipped with the forgotten warning function, a warning can be output if a mobile phone with Qi capability was forgotten in the wireless charging tray when leaving the vehicle.

The forgotten warning is displayed in the instrument cluster.

# **Activating**

- 1. "CAR"
- 2. "Settings"
- 3. "General settings"
- 4. "Wireless charging tray"
- Activate reminder.

# **System limits**

At high temperatures on the mobile phone or in the vehicle, the charging functions of the mobile phone may be limited and some functions may no longer work.

# LTE-Compensator - Information and User Manual

Your car is equipped with a wireless charging tray (WCA) to charge your mobile phone and connect it to the mobile network. To ensure the best possible connection a signal booster (LTE-Compensator) is used in conjunction with the WCA. The following paragraphs refer to this booster:

This is a CONSUMER device.

BEFORE USE, you MUST REGISTER THIS DE-VICE with your wireless provider and have your provider's consent. Most wireless providers consent to the use of Compensators. Some providers may not consent to the use of this device on their network. If you are unsure, contact your provider. You MUST operate this device with approved antennas and cables as specified by the manufacturer. Antennas MUST be installed at least 20 cm (8 inches) from any person. You MUST cease operating this device immediately if requested by the FCC or a licensed wireless service provider. Warning E911 location information may not be provided or may be inaccurate for calls served by using this device.

Please observe additionally the following information

- Sprint Nextel will allow consumers to register their signal boosters by calling their toll-free number.
- T-Mobile online registration link: (www.T-Mobile.com/BoosterRegistration); (https://saqat.tmobile.com/sites/SignalBooster#).
- Verizon's online registration link: (http:// www.verizonwireless.com/wcms/consumer/ register-signal-booster.html).
- AT&T online registration link (https:// securec45.securewebsession.com/attsignalbooster.com/).
- ➤ U.S.Cellular online registration link (http:// www.uscellular.com/uscellular/support/fccbooster-registration.jsp).

Before use you must register your booster device with your wireless provider.

If you should be requested by the FCC to cease operating your booster you are not allowed to insert your mobile phone in the charging tray anymore unless the booster is permanently deactivated by your local BMW dealer.

You must not remove the booster from the car nor use it with any other than the preinstalled coupling device or antenna. Any modification of the existing antenna or coupling device as well as the use of other antennas or coupling devices will cause the cease of the booster's operating license.

The booster device fulfills the network protection standards as required by the FCC, such as intermodulation limits, oscillation detection and gain limits.

Booster Manufacturer: Kathrein Automotive

Model Number: LTECOMPB0
Part Number: 6803145-01
FCC-ID: 2ACC7LTECOMPB0

# BMW Travel & Comfort System

# **General information**


USB ports and fixtures for attaching special accessories, for instance coat hangers, are located on the backrests of the front seats.

Properties of the USB ports:

- ▶ USB port Type C.
- ▶ For charging of mobile devices.
- ▶ Charge current: max. 3 A.

Further information is available from a dealer's service center or another qualified service center or repair shop.


### **Overview**



The fixtures are located behind the marked covers.

# **Installing special accessories**

1. Slide the cover to the side.



Install the special accessories, refer to Installation Instructions.

# Storage compartments

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

# **Storage compartments**

#### General information

The vehicle interior contains multiple storage compartments for stowing objects.

# **Safety information**



#### Marning

Loose objects or devices with a cable connection to the vehicle, for instance mobile phones, can be thrown about the car's interior while driving, for instance in the event of an accident, braking or evasive maneuver. There is a risk of injury. Secure loose objects or devices with a cable connection to the vehicle in the car's interior.

#### ⚠ NOTICE

Anti-slip pads such as anti-slip mats can damage the dashboard. There is a risk of damage to property, among other potential damage. Do not use anti-slip pads.

# Front passenger side glove compartment

# **Safety information**



#### Marning

Folded open, the glove compartment protrudes in the car's interior. Objects in the glove compartment can be thrown into the car's interior while driving, for instance in the event of an accident, braking or evasive maneuvers. There is a risk of injury. Always close the glove compartment immediately after using it.

# Opening the glove compartment



Pull the handle.

The light in the glove compartment switches on.

# Closing the glove compartment

Fold cover closed.

# Locking the glove compartment

The glove compartment can be locked with an integrated key. This prevents access to the glove compartment.

After the glove compartment is locked, the vehicle key can be handed over without the

integrated key, for instance when the vehicle is parked by valet parking.

Additional information:

Integrated key, refer to page 97.

# **Driver's side glove** compartment

# **Safety information**



#### Marning

Folded open, the glove compartment protrudes in the car's interior. Objects in the glove compartment can be thrown into the car's interior while driving, for instance in the event of an accident, braking or evasive maneuvers. There is a risk of injury. Always close the glove compartment immediately after using it.

# **Opening the glove compartment**



Pull the handle.

# Closing the glove compartment

Fold cover closed.

# **Compartments in the doors**

# General information

There are storage compartments in the doors.

# **Safety information**

#### Warning

Breakable objects, such as glass bottles or glasses, can break in the event of an accident or a braking or evasive maneuver. Broken glass can be scattered in the car's interior. There is a risk of injury or risk of damage to property. Do not use any breakable objects while driving. Only stow breakable objects in closed storage compartments.

# Storage compartment in the center console

# **Opening the storage** compartment



Press onto the cover.

# Closing the storage compartment

Pull the cover on the handle bar back.

# Storage compartment in the rear center console

The rear of the center console contains one or two storage compartments.

# Center armrest, front

#### General information

A storage compartment is located in the center armrest between the seats.

# **Opening the storage** compartment



Press the button.

# Closing the storage compartment


Press cover down until it engages.

# Rear center armrest

# General information

A storage compartment is located in the center armrest between the seats.

# **Folding down**



Fold the center armrest forward.

# **Opening**



Press the button, arrow 1, and fold the cover up, arrow 2.

# Closing the storage compartment

Press cover down until it engages.

# Front cup holder

# **Safety information**



### 🛕 Warning

Unsuitable containers in the cup holders may damage the cup holders or be thrown about the car's interior in the event of an accident, an evasive maneuver, or forceful braking. Spilled liquids can distract from the traffic conditions and lead to an accident. Hot drinks can damage the cup holder or lead to scalding. There is a risk of injury or risk of damage to property. Do not force objects into the cup holder. Use lightweight, shatterproof, and sealable containers. Do not transport hot beverages.

# Opening the cup holder



Press onto the cover.



Two cup holders are located in the center console.

# Closing the cup holder

Pull the cover on the handle bar back.

# Maintaining the drink temperature

#### **General information**

When equipped with thermo-cup holder, drinks can be kept cool or warm.

# **Safety information**



#### Warning

Contact with the hot metal insert of the thermo-cup holder can cause burn injuries. There is a risk of injury. Do not touch the metal insert when the thermo-cup holder is switched on.

#### ∧ NOTICE

When the thermo-cup holder is switched on and the cover is closed, the thermo-cup holder can overheat. There is a risk of damage to property, among other potential damage. Switch the thermo-cup holder off before closing the cover.

#### NOTICE

Temperature sensitive items may be damaged by the hot metal insert of the thermo-cup holder. There is a risk of damage to property, among other potential damage. Use suitable containers only.

### **Turning on**



Press the button for keeping cool or warm once each.

- ▶ Blue LED lights up: keep drinks cool.
- Red LED lights up: keep drinks warm.

# **Turning off**



Press the button repeatedly until the I FDs turn off

# Rear cup holder

# **Safety information**



#### Marning

Unsuitable containers in the cup holders may damage the cup holders or be thrown about the car's interior in the event of an accident, an evasive maneuver, or forceful braking. Spilled liquids can distract from the traffic conditions and lead to an accident. Hot drinks can damage the cup holder or lead to scalding. There is a risk of injury or risk of damage to property. Do

not force objects into the cup holder. Use lightweight, shatterproof, and sealable containers. Do not transport hot beverages.



#### ∧ NOTICE

With an open cup holder, the center armrest cannot be folded back up. There is a risk of damage to property, among other potential damage. Press back the covers before the center armrest is folded up.

#### Second row of seats

#### **General information**

The cup holder can be adjusted for three different container sizes

# Opening the cup holder



Fold the center armrest forward.

Press the button and fold out the cup holder fully.

# Downsizing the cup holder

To make it smaller, the cup holder can be folded in in 2 steps.

# **Enlarging the cup holder**

To make a smaller cup holder bigger, first fold it in completely. Then fold the cup holder out again fully.

# Closing the cup holder

Fold in the cup holder fully, until it engages.

#### Third row of seats



The cup holders are located between the seats of the third row of seats.

# Clothes hooks

### General information

The clothes hooks are located in the grab handles in the rear and on the door pillar in the rear.

# **Safety information**



#### Marning

Clothing articles on the clothes hooks can obstruct the view while driving. There is a risk of accident. When suspending clothing articles from the clothes hooks, ensure that they will not obstruct the driver's view.



# ▲ Warning

Improper use of the clothes hooks can lead to a risk of objects flying about during braking and evasive maneuvers. There is a risk of injury and risk of damage to property. Only hang lightweight objects, for instance clothing articles, from the clothes hooks.

# Cargo area

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

# Loading

# **Safety information**

#### Marning

High gross weight can overheat the tires, damage them internally and cause a sudden tire pressure loss. Driving characteristics may be negatively impacted, reducing lane stability, lengthening the braking distances and changing the steering response. There is a risk of accident. Pay attention to the permitted load capacity of the tires and never exceed the permitted gross weight.

# Marning

Loose objects or devices with a cable connection to the vehicle, for instance mobile phones, can be thrown about the car's interior while driving, for instance in the event of an accident. braking or evasive maneuver. There is a risk of injury. Secure loose objects or devices with a cable connection to the vehicle in the car's interior.

### Marning

Improperly stowed objects can shift and be thrown into the car's interior, for instance in the event of an accident or during braking and evasive maneuver. Vehicle occupants can be hit and injured. There is a risk of injury. Stow and secure objects and cargo properly.

#### ∧ NOTICE


Fluids in the cargo area can cause damage. There is a risk of damage to property, among other potential damage. Make sure that no fluids leak in the cargo area.

# **Steps for Determining Correct Load Limit**

- 1. Locate the statement "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs" on your vehicle's placard.
- 2. Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- 3. Subtract the combined weight of the driver and passengers from XXX kg or XXX lbs
- 4. The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the "XXX" amount equals 1,400 lbs and there will be five 150 lbs passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs  $(1,400 - 750 (5 \times 150) = 650 \text{ lbs})$
- 5. Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available

- cargo and luggage load capacity calculated in Step 4.
- 6. If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle.

# **Payload**



The maximum load is the sum of the weight of the occupants and the cargo.

The greater the weight of the occupants, the less cargo that can be transported.

# Stowing and securing cargo

- ▶ Cover sharp edges and corners on the cargo.
- Heavy cargo: stow as far forward as possible, directly behind and at the bottom of the rear passenger seat backrests.
- Very heavy cargo: stow as far forward as possible, directly behind and at the bottom of the rear passenger seat backrests. When the rear seat is not occupied, secure each of the outer safety belts in the opposite buckle.
- ▶ Fold down the rear seat backrests completely to stow large cargo.
- ▶ Do not stack cargo above the upper edge of the backrests.
- Use the cargo area partition net to protect occupants. Make sure that objects cannot penetrate the cargo area partition net.


- Small and light cargo: secure with ratchet straps or, depending on the equipment, with a cargo net or draw straps.
- ► Larger and heavy cargo: secure with cargo straps.

# Lashing eyes in the cargo area

#### **General information**

Attach load securing aids, such as lashing straps, tensioning straps, draw straps or cargo nets, to the lashing eyes in the cargo area.

# Lashing eyes




There are four lashing eyes in the cargo area for securing cargo.

The front lashing eyes are located under covers.

# **Automatic sliding and anti**slip rails

# **Principle**



The system prevents slipping of the cargo in the cargo area when the anti-slip tracks are extended to the top.

### **General information**

Observe information and notes on loading.

The anti-slip tracks extend up automatically when one of the following conditions is met:

- ▶ Tailgate is closed.
- ▶ Inclination of the vehicle by more than approximately 13 %.
- ▶ Tailgate is open and the speed of approx. 3 mph/5 km/h is exceeded.

Additional information:

Load, refer to page 321.

# **Multifunction hook**

# **General information**


A multifunction hook is located on the left and right side in the cargo area.

# Safety information

#### Warning

Improper use of the multifunction hooks can lead to a risk of objects flying about during braking and evasive maneuvers, for example. There is a risk of injury and risk of damage to property. Only hang lightweight objects from the multifunction hooks. Only transport heavy luggage in the cargo area if it has been appropriately secured.

# Folding out the multifunction hook



Press on the multifunction hook and turn until it engages.

# Net


Small objects can be stowed in the net on the right side.

# Storage compartment on the left side

#### General information

A storage compartment is located on the left side in the cargo area.

# **Opening the storage** compartment




Press the button, arrow 1, and open the cover, arrow 2.

# Storage compartments under the cargo floor panel

#### General information

There are storage compartments beneath the cargo floor panel.

# **Opening the storage** compartments



Fold up the cargo floor panel.

# Closing the storage compartments

Push the cargo floor panel downward.

# **Enlarging the cargo area**

# **Principle**

The cargo area can be enlarged by folding down the rear seat backrests.

#### **General information**

The rear seat backrest of the second seat row is divided at a ratio of 40–20–40. The side rear seat backrests and the center section can be folded down separately.

The rear seat backrests can be folded down from the rear or from the cargo area.

Depending on the equipment version, the rear seat backrests can be folded down either manually or electrically.

# **Safety information**



#### Marning

Danger of jamming with folding down the backrests. There is a risk of injury or risk of damage to property. Make sure that the area of movement of the rear backrest and the of the head restraint is clear prior to folding down.



#### Marning

If a rear seat backrest is not locked, unsecured cargo can be thrown about the car's interior: for instance, in the event of an accident, braking or an evasive maneuver. There is a risk of injury. Make sure that the rear seat backrest is locked after folding it back.



#### Warning

The stability of the child restraint system is limited or compromised with incorrect seat setting or improper installation of the child seat. There is a risk of injury or danger to life. Make sure that the child restraint system fits securely

against the backrest. If possible, adjust the backrest tilt for all affected backrests and correctly adjust the seats. Make sure that seats and backrests are securely engaged or locked. If possible, adjust the height of the head restraints or remove them.

## **△** Warning

Once the rear seat backrest has been folded down, the locking bracket protrudes into the car's interior. There is a risk of damage to property, among other potential damage. When the rear seat backrest is folded down, pay attention to the protruding locking bracket and keep this area unobstructed.

## **△** NOTICE

Vehicle parts can be damaged when folding down the rear backrest. There is a risk of damage to property, among other potential damage. Make sure that the area of movement of the rear backrest including head restraint is clear when folding down.

## Manual reclining of the backrest

#### From the rear



Pull the lever and fold the rear seat backrest forward.

## Folding back the backrest

Return the rear seat backrest to the seat position and engage it. The red marking behind the lever disappears completely.


## **Electric reclining of the backrest**

#### From the rear



Pull the switch and fold the rear seat backrest forward.

## From the cargo area



Press the switch in the cargo area.

- Upper switch: the left and center rear seat backrests fold forward.
- ▶ Lower switch: the right rear seat backrest folds forward.

## Folding back the backrest

#### From the rear

Press the corresponding switch. The rear seat backrest sets itself upright.

## From the cargo area

Pull the corresponding switch. The rear seat backrest sets itself upright.

## Folding down the center section



Fold down the center armrest and pull on the loop.

## Cargo cover

## **Safety information**

## Warning

Loose objects or devices with a cable connection to the vehicle, for instance mobile phones, can be thrown about the car's interior while driving, for instance in the event of an accident. braking or evasive maneuver. There is a risk of injury. Secure loose objects or devices with a cable connection to the vehicle in the car's interior.


## Marning

A cargo cover that snaps back quickly can jam body parts or cause damage. There is a risk of injury or risk of damage to property. Do not let the cargo cover snap back into place.

#### ⚠ Warning

An incorrectly inserted cargo cover can be thrown about the car's interior, such as in the event of an accident or a braking or evasive maneuver. There is a risk of injury and risk of damage to property. Make sure the cargo cover is securely engaged in the brackets.


## Closing the cargo cover



Pull out the cargo cover, arrow 1, and hook both sides into the brackets, arrow 2.

## Removing the cargo cover

The cover can be removed to load bulky luggage.



Press the release button, arrow 1, and pull the cargo cover out toward the rear, arrow 2.

## Stowing the cargo cover

### **General information**

The cargo cover can be stowed in the storage compartment under the cargo floor panel.

#### Without third seat row

- 1. Open the storage compartment on the left side.
  - Storage compartment on the left side, refer to page 323.
- 2. Fold up the cargo floor panel.
- 3. Turn the cargo cover forward with the handle.
- 4. Stow the cargo cover on the left and lower it on the right side.
  - Make sure the cargo cover is positioned correctly in the right bracket.



5. Push the cargo floor down and close the storage compartment on the left side.

#### With third seat row

- 1. Open the storage compartment on the left side.
  - Storage compartment on the left side, refer to page 323.
- 2. Fold up the cargo floor panel.
- 3. Stow the cargo cover on the left and lower it on the right side.

Make sure the cargo cover is positioned correctly in the right bracket.



4. Push the cargo floor down and close the storage compartment on the left side.

## Inserting the cargo cover

Slide the cover forward horizontally into the two side brackets. Make sure that the cover audibly engages on both sides.

## Electric cargo cover

## **Principle**

The electric cargo cover opens and closes automatically with the tailgate. The cargo cover can be lowered below the cargo floor panel to stow bulky items or luggage.

## **General information**

Items in the range of movement are detected. The cargo cover stops automatically to prevent damage.

## Safety information



## Marning

Loose objects or devices with a cable connection to the vehicle, for instance mobile phones, can be thrown about the car's interior while driving, for instance in the event of an accident, braking or evasive maneuver. There is a risk of injury. Secure loose objects or devices with a

cable connection to the vehicle in the car's interior.

### Marning

Pinching of body parts may occur during operation of the electric cargo cover. Items in the range of movement may damage the cargo cover. There is a risk of injury or risk of damage to property. Make sure that the area of movement of the electric cargo cover is clear during opening and closing. In addition, make sure that the area of movement of the cover in the cargo floor is clear during lowering.



#### ∧ NOTICE

Items on the storage shelf may damage it. There is a risk of damage to property, among other potential damage. Do not deposit any objects on the cargo cover.




#### ∧ NOTICE

The manual operation of the electric cargo cover by hand may damage the cover. There is a risk of damage to property, among other potential damage. Use the buttons in the cargo area for operation.

#### Overview

## Positions of the cargo cover



- Automatic position, arrow 1.
- Base position, arrow 2.

#### Buttons in the vehicle



The buttons of the cargo cover are located in the cargo area on the left side.



Switching between automatic and base position.



Lowering or raising the cargo cover.

## Opening the cargo cover

When the tailgate is opened, the cargo cover is opened up to the automatic position.

To open the cargo cover completely up to the base position:



Press the button.

## Closing the cargo cover



Press the button.

The cargo cover will be closed up to the automatic position.

When the tailgate is closed, the cargo cover will be closed completely.

The cargo cover will not be closed automatically when it is in the base position while the tailgate is closing.

## Lowering the cargo cover

The cargo cover can be lowered to stow bulky luggage.



Press the button.

The cargo cover is lowered below the cargo floor panel.

## Raising the cargo cover

Press the button.

The cargo cover is raised to the base position.


Press the button.

The cargo cover is raised to the base position and closes up to the automatic posi-

Malfunctions

tion.

▶ If the closing force exceeds a certain value when closing the cargo cover, for example due to items in the range of motion, the cover will disengage from the mounting. The cargo cover stops in the guide rail.



To restore the functionality, close the cargo cover by hand, arrow 1, until it engages in the mounting, arrow 2.

Excessive or insufficient ambient temperatures may lead to the deactivation of the cargo cover. When the temperature is within normal range again, such as by switching on the air conditioning system, the function will be restored.

The function will be deactivated when the system can no longer detect the position of the cargo cover. An initialization is required.

### Initializing

#### **Functional requirements**

- Vehicle is parked in a horizontal position.
- Drive-ready state is activated.
- The area of movement of the cargo cover is clear.
- Dutside temperature is above 41 °F/5 °C.

#### Initializing the system



Press and hold the button until the initialization is finished.

The cargo cover moves to the different positions. The initialization is finished when a signal sounds.

If the button is released prematurely, the cargo cover will stop. The initialization is terminated.

Press and hold the button to restart the initialization.

## Cargo net, FlexNet

## **General information**

The flexible cargo net can also be used for securing the cargo.

Additional information:

Load, refer to page 321.

## **Attaching the FlexNet**

- 1. Attach the FlexNet to the side panel with the upper hooks.
- 2. Attach the FlexNet in the lashing eyes with the lower hooks.

## Things to remember when driving

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## **Break-in**

#### General information

Moving parts need to begin working together smoothly.

The following instructions will help you to achieve a long vehicle life and good efficiency.

During break-in, do not use the Launch Control.

## **Safety information**



#### Warning

Due to new parts and components, safety and driver assistance systems can react with a delay. There is a risk of accident. After installing new parts or with a new vehicle, drive conservatively and intervene early if necessary. Observe the break-in procedures of the respective parts and components.

### Engine, transmission, and axle drive

## Up to 1,200 miles/2,000 km

Do not exceed the maximum engine and road speed:

▶ For gasoline engine 4,500 rpm and 100 mph/160 km/h.

Avoid full throttle or kickdown under all circumstances

## From 1,200 miles/2,000 km

The engine and vehicle speed can gradually be increased.

#### **Tires**

Tire traction is not optimal due to manufacturing circumstances when tires are brand-new; they achieve their full traction potential after a break-in time.

Drive conservatively for the first 200 miles/300 km.

## **Brake system**

Brake discs and brake pads only reach their full effectiveness after approx. 300 miles/500 km. Drive moderately during this break-in period.

## Following part replacement

Observe the break-in procedures again, if components mentioned above are replaced.

## **Driving on poor roads**

## Concept

Because of its greater ground clearance, the vehicle can be driven on a variety of road types and qualities.

All-wheel drive can help improve drive power.

## **Safety information**



#### MOTICE

Objects in unpaved areas, for instance stones or branches, can damage the vehicle. There is a risk of damage to property, among other potential damage. Do not drive on unpaved terrain.

## When driving on poor roads

For your own safety, for the safety of passengers and of the vehicle, heed the following points:

- ▶ Familiarize yourself with the vehicle before drivina.
- Do not take risks when driving.
- Adjust the speed to the road surface conditions. The steeper and more uneven the road surface, the slower the speed should be.
- When driving on steep uphill or downhill grades: add engine oil and coolant up to near the MAX mark.
- ▶ On steep downhill grades, use Hill Descent Control HDC.
- Avoid that the chassis bottom coming in contact with the ground.
  - The ground clearance is no more than 7.8 inches/20 cm and can vary according to the vehicle's load.
- ▶ When wheels continue to spin, depress the accelerator pedal sufficiently so that driving stability control systems can distribute the driving force to the wheels. Activate DTC Dvnamic Traction Control if available.

## After a trip on poor roads

After a trip on poor roads, check wheels and tires for damage to maintain driving safety. Clear heavy soiling from the body.

## **General driving notes**

## Closing the tailgate

**Safety information** 



#### Warning

An open tailgate protrudes from the vehicle and can endanger occupants and other road users or damage the vehicle in the event of an accident, braking or evasive maneuvers. In addition, exhaust fumes may enter the vehicle interior. There is a risk of injury or risk of damage to property. Do not drive with the tailgate open.

## Driving with the tailgate open

If driving with the tailgate open cannot be avoided:

- Close all windows and the glass sunroof.
- Greatly increase the blower output.
- Drive moderately.

## Hot exhaust gas system



#### ⚠ Warning

High temperatures can occur underneath the body, for instance caused by the exhaust gas system, while driving. Contact with the exhaust gas system can cause burns. There is a risk of injury. Do not touch the hot exhaust gas system, including the exhaust pipe.



#### ⚠ Warning

If combustible materials, such as leaves or grass, come in contact with hot parts of the exhaust gas system, these materials can ignite. There is a risk of fire and an injury hazard. Do not remove the heat shields installed and never apply undercoating to them. Make sure that no combustible materials can come in contact with hot vehicle parts while driving, at idle or during parking.

## Mobile communication devices in the vehicle



#### Marning

Vehicle electronics and mobile phones can influence one another. There is radiation due to the transmission operations of mobile phones. There is a risk of injury or risk of damage to property. If possible, in the car's interior use only mobile phones with direct connections to an external antenna in order to exclude mutual interference and deflect the radiation from the car's interior.

## **Aguaplaning**

On wet or slushy roads, a wedge of water can form between the tires and road surface.

This phenomenon is referred to as aquaplaning. It is characterized by a partial or complete loss of contact between the tires and the road surface. ultimately undermining your ability to steer and brake the vehicle.

## **Driving through water**

#### **General information**

When driving through water, follow the following:

- Deactivate Auto Start/Stop function.
- Drive through calm water only.
- Drive through water only if it is not deeper than maximum 19.6 inches/50 cm.
- Drive through water no faster than walking speed, up to 3 mph/5 km/h.

## Safety information



#### ⚠ NOTICE

When driving too quickly through too deep water, water can enter into the engine compartment, the electrical system or the transmission. There is a risk of damage to property, among other potential damage. When driving through water, do not exceed the maximum indicated water level and the maximum speed for driving through water.

## **Braking safely**

#### General information

The vehicle is equipped with an Antilock Braking System ABS as a standard feature.

Perform emergency braking in situations that reauire such.

Steering is still responsive. You can still avoid any obstacles with a minimum of steering effort.

Pulsation of the brake pedal and sounds from the hydraulic circuits indicate that the Antilock Braking System ABS is in its active mode.

In certain braking situations, the perforated brake discs can emit functional noises. However, functional noises have no effect on the performance and operational reliability of the brake.

## Objects in the area around the pedals



## Marning

Objects in the driver's floor area can limit the pedal distance or block a depressed pedal. There is a risk of accident. Stow objects in the vehicle such that they are secured and cannot enter into the driver's floor area. Use floor mats that are suitable for the vehicle and can be safely attached to the floor. Do not use loose floor mats and do not layer several floor mats. Make sure that there is sufficient clearance for

the pedals. Ensure that the floor mats are securely fastened again after they were removed, for instance for cleaning.

## Pedal feel when driving off

After turning on the drive-ready state from the idle state, the pedal may feel unusual, short pedal distance. After the brake pedal has been fully released, the pedal will feel as usual again.

## **Driving in wet conditions**

In case of wet roads, exposure to road salt, in heavy rain, gently press the brake pedal every few kilometers.

Ensure that this action does not endanger other road users.

The heat generated during braking dries brake discs and brake pads and protects them against corrosion.

In this way braking efficiency will be available when you need it.

#### Hills

#### General information

Drive long or steep downhill gradients in the gear that requires least braking effort. Otherwise, the brake system may overheat and reduce braking effect.

You can increase the engine's braking effect by shifting down, going all the way to first gear, if needed.

#### Safety information



#### Warning

Light but consistent pressure on the brake pedal can lead to high temperatures, brakes wearing out and possibly even brake system failure. There is a risk of accident. Avoid placing excessive stress on the brake system.

#### ⚠ Warning

In idle state or with the engine switched off. safety functions, for instance engine braking effect, braking assistance and steering assistance, may not be available. There is a risk of accident. Do not attempt to drive in idle state or with the engine switched off.

#### Brake disc corrosion

Corrosion on the brake discs and contamination. on the brake pads are increased by the following circumstances:

- ▶ Low mileage.
- Extended periods when the vehicle is not used at all.
- Infrequent use of the brakes.
- Aggressive, acidic, or alkaline cleaning agents.

Corrosion buildup on the brake discs will cause a pulsating effect on the brakes in their response generally this cannot be corrected.

## Condensation water under the parked vehicle

When using the automatic climate control, condensation water develops and collects underneath the vehicle.

## Flag bracket

## Safety information



#### M NOTICE

At high speeds, a mounted flag can cause damage to the vehicle, the flag bracket, and the flag itself. There is a risk of damage to property, among other potential damage. Do not exceed a speed of 80 mph / 130 km/h. Remove flag before trips at high speeds.

#### Overview



The flag bracket is located on the side of the vehicle.

### **Mounting**

- 1. Remove the protective cap.
- 2. Insert flag horizontally.
- 3. Turn the flag clockwise by 90° to lock the flaa.

## **Roof-mounted luggage** rack

### **General information**

Installation only possible with roof rack.

Roof racks are available as special accessories.

## **Safety information**



When driving with a roof load, for instance with roof-mounted luggage rack, the vehicle's center of gravity is higher, which increases the risk of the vehicle tipping in critical driving situations. There may be a risk of accident or risk of damage to property. Driving with roof load only with activated Dynamic Stability Control.

## **Mounting**

Follow the installation instructions of the roof rack.

Be sure that adequate clearance is maintained for tilting and opening the glass sunroof.

## Loading

Because roof-mounted luggage racks raise the vehicle's center of gravity when loaded, they have a major effect on vehicle handling and steering response.

Therefore, note the following when loading and driving:

- ▶ Do not exceed the approved roof/axle weights and the approved gross vehicle weight.
- ▶ Be sure that adequate clearance is maintained for tilting and opening the glass sunroof.
- Distribute the roof load uniformly.
- ▶ The roof load should not extend past the loading area.
- Always place the heaviest pieces on the bottom.
- Secure the roof luggage firmly, for instance using ratchet straps.
- Do not let objects project into the opening path of the tailgate.
- Drive cautiously and avoid sudden acceleration and braking maneuvers. Take corners gently.

## **Driving on racetracks**



#### Warning

The vehicle is not designed for use in M Sport or motor sport type competition. There is a risk of accident. Do not use the vehicle for M Sport or motor sport type competitions.

Higher mechanical and thermal loads during racetrack operation lead to increased wear. Use of the vehicle in M Sport or motor sport type competition is an improper use of the vehicle and may affect your warranty coverage. Please consult the "New Vehicle Limited Warranty" Booklet for further information on warranty matters.

## **Trailer towing**

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## **General information**

The permissible trailer loads, axle weights, drawbar node weights, and the permissible gross vehicle weight are specified in the technical data.

The vehicle is equipped with an enhanced suspension system on the rear axle and, depending on the vehicle type, with a more powerful cooling system.

When the trailer power socket is in use, the vehicle will be raised or lowered to the normal level automatically. The adjustment to the normal level can occur when the trailer power socket is plugged in or when driving off.

## **Before driving**

## **Drawbar nose weight**

The maximum load of the towing vehicle is lowered by the weight of the trailer hitch and the drawbar nose weight. The drawbar nose weight increases the vehicle weight. Do not exceed the approved gross vehicle weight of the towing vehicle.

## Loading

Distribute cargo as evenly as possible on the cargo area.

Stow the load as low and close to the trailer axle as possible. A low center of gravity in the trailer increases the driving safety of the entire vehicle-trailer combination.

Do not exceed the approved gross vehicle weight of the trailer and the permissible trailer load of the vehicle. The smaller value applies in each case.

## Tire pressure

Note the tire inflation pressure of the vehicle and trailer.

For the vehicle, the tire inflation pressure for higher loads applies.

For the trailer, the specifications of the manufacturer apply.

Additional information:

Tire pressure specifications, refer to page 348.

## **Flat Tire Monitor FTM**

After correcting the tire inflation pressure or hitching/unhitching a trailer, initialize the Flat Tire Monitor.

Additional information:

Run-flat tires, refer to page 373.

## Tire pressure monitor

After correcting the tire pressure or hitching/ unhitching a trailer, reset the Tire Pressure Monitor.

Additional information:

Tire pressure monitor, refer to page 366.

## **Exterior mirrors**

Exterior mirrors, which allow the driver to see both rear edges of the trailer, are available as special accessories from a dealer's service center or another qualified service center or repair shop.

## **Electrical consumption**

#### **General information**

Before starting to drive, check the function of the trailer tail lights.

Keep the activation times of the electrical components short when towing a camper to save the vehicle battery power.

### **Trailer tail lights**

- ▶ Turn signals/brake lights: 54 watts per side.
- Rear lights: 100 watts in total.
- Backup light: 54 watts in total.

## **Towing a trailer**

## **General information**

If the trailer socket is occupied, some driver assistance systems are unavailable, or available to a limited extent. A Check Control message is displayed where applicable.

When driving with a trailer or load carrier and the trailer socket not occupied, some driver assistance systems may have functional limitations or may malfunction.

To prevent malfunctions, activate trailer towing.

When the trailer socket is occupied or trailer towing is activated, some driver assistance systems are unavailable, or available to a limited extent. A Check Control message is displayed where applicable.

Additional information:

Activating trailer towing, refer to page 338.

## **Safety information**

#### Warning

Depending on the design and loading of trailers, they may begin swinging at speeds exceeding approx. 50 mph/80 km/h. There may be a risk of accident or risk of damage to prop-

Adapt your speed when driving with a trailer. Immediately brake in the case of swinging. Apply necessary steering corrections as carefully as possible.



### Marning

The tire inflation pressure must be adjusted to the increased axle weight in trailer towing. Driving with too low tire inflation pressure can damage the tires. There may be a risk of accident or risk of damage to property. Do not exceed a speed of 60 mph / 100 km/h. Increase the tire inflation pressure of the towing vehicle by 0.2 bar. Note the maximum possible tire inflation pressure indicated on the tire.

## **Uphill grades**

#### General information

In the interest of safety and to avoid hindering the smooth flow of traffic, the towing of trailers is permissible on uphill grades up to 12 %.

If higher trailer loads are approved at a later point in time, the gradient limit is 8 %.

## Starting on uphill grades

The parking brake is automatically released when the accelerator pedal is activated.

In order to prevent rolling back during starting, use the parking brake.



Pull and release switch before starting

- The parking brake is set.
- Step on the accelerator pedal sufficiently to drive off.

#### Hills

A vehicle-trailer combination has the tendency to swing more readily on hills.

Manually shift down to the next-lowest gear before driving on a hill and drive downhill slowly.

## **Trailer stabilization control**

## **Principle**

This system supports the driver in stopping the swinging of a trailer.

The trailer stabilization control detects swinging and automatically brakes the vehicle quickly to leave the critical speed range and stabilize the vehicle-trailer combination.

### **General information**

If the trailer power socket is occupied but a trailer has not been hitched, the system can become active in certain driving situations, such as when using a bicycle rack with lighting.

## **Functional requirement**

The system is functional at speeds beginning at approx. 40 mph/65 km/h while a trailer is being towed and the trailer power socket is occupied.

## System limits

The system cannot intervene or not intervene in time in the following situations, for instance:

- ▶ If a trailer jackknifes suddenly, for instance on slippery roads or loose surfaces.
- ▶ If a trailer with a high center of gravity tilts, before swinging is detected.

- ▶ If DSC Dynamic Stability Control is deactivated or has malfunctioned.
- ▶ When the power consumption of a trailer is too low, for instance due to tail lights in LED technology, to be detected by the system.

## **Activating trailer towing**

## **Principle**


When driving with a trailer or load carrier and the trailer socket not occupied, some driver assistance systems may have functional limitations or may malfunction. To prevent malfunctions, activate trailer towing.

## **Activating**

- 1. "CAR"
- 2. "Settings"
- "General settings"
- 4. "Trailer mode"
- 5. "Trailer mode"

## Mount for trailer hitch

## **General information**



The mount for the trailer hitch is located on the rear of the vehicle.

Information on suitable trailer hitches is found on the underside of the mount, see arrow.

Remove the ball head when driving without a trailer or load carrier.

Follow the Maintenance Instructions, refer to page 408.

## **Safety information**



#### 🛕 Warning

During driving, high temperatures can occur underneath the vehicle body, for instance caused by the exhaust gas system. Contact with the hot components can cause burns. There is a risk of injury. Do not touch hot components. Do not perform work in the vicinity of hot components until after they have cooled down.

## Removing the cover




Pull the cover out of the back of the mount, and stow it in the vehicle.

## **Trailer connector**



The socket is located to the left of the mount for the trailer hitch.

## Fittings for trailer safety chain



There are two fittings on the mount for the trailer hitch for securing the trailer safety chain.

Secure the trailer safety chain to the fittings for increased safety when driving with a trailer. Ensure that the trailer safety chain can move

freely and is not dragging on the ground.

## **Brake Controller**

The vehicle manufacturer recommends that you have a Brake Controller installed by a dealer's service center or another qualified service center or repair shop.

Information on installing a Brake Controller can be obtained from a dealer's service center or another qualified service center or repair shop.

## Saving fuel

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## **Reducing fuel consumption**

#### **General information**

The vehicle contains advanced technologies for the reduction of consumption and emission values.

The fuel consumption depends on various factors, such as driving style, road conditions, maintenance or environmental factors.

Carrying out certain measures, such as a moderate driving style and regular maintenance, can influence fuel consumption and the environmental impact.

## Remove unnecessary cargo

Additional weight increases fuel consumption.

# Remove attached parts following use

Remove auxiliary mirrors, roof-mounted or rear carriers which are no longer required following use.

Attached parts on the vehicle impair the aerodynamics and increase the fuel consumption.

## Close the windows and glass sunroof

Driving with the glass sunroof and windows open results in increased drag and raises fuel consumption.

#### **Tires**

#### **General information**

Tires can affect consumption in various ways, for instance tire size may influence consumption.

## Check the tire pressure regularly

Check and, if needed, correct the tire inflation pressure at least twice a month and before starting on a long trip.

Low tire inflation pressure increases rolling resistance and thus raises fuel consumption and tire wear.

Observe the correct tire inflation pressure as well as the ECO tire inflation pressure, where applicable.

Additional information:

Tire pressure specifications, refer to page 348.

## **Drive away without delay**

Do not wait for the engine to warm-up while the vehicle remains stationary. Start driving right away, but at moderate RPM.

This is the fastest way of warming the cold engine up to operating temperature.

## **Proactive driving**

Driving smoothly and proactively reduces fuel consumption.

Avoid unnecessary acceleration and braking.

By maintaining a suitable distance to the vehicle driving ahead of you.

## **Avoid high RPM**

Driving at low engine speeds lowers fuel consumption and reduces wear.

If necessary, observe the vehicle's gear shift indicator.

## **Using coasting overrun mode**

When approaching a red light, take your foot off the accelerator and let the vehicle coast to a halt.

For going downhill take your foot off the accelerator and let the vehicle roll.

The fuel supply is interrupted in coasting overrun mode.

# Switch off the engine during longer stops

### Switching off the engine

Switch off the engine during longer stops, for instance at traffic lights, railroad crossings or in traffic jam.

## **Auto Start/Stop function**

The Auto Start/Stop function of the vehicle automatically switches off the engine during a stop.

If the engine is switched off and then restarted rather than leaving the engine running constantly, fuel consumption and emissions are reduced. Savings can begin within a few seconds of switching off the engine.

# Switch off any functions that are not currently needed

Functions such as seat heating and the rear window defroster require a lot of energy and increase fuel consumption, especially in city and stop-and-go traffic.

Switch off these functions if they are not needed.

The ECO PRO driving mode supports the energy conserving use of comfort features. These functions are automatically deactivated partially or completely.

#### Have maintenance carried out

Have the vehicle maintained regularly to achieve optimal vehicle efficiency and service life. BMW recommends that maintenance work be performed by a BMW service center.

Also refer to BMW Maintenance System.

## **ECO PRO**

## **Principle**

ECO PRO supports a driving style that saves on consumption. For this purpose, the engine control and comfort features, for instance the climate control output, are adjusted.

Steptronic transmission: under certain conditions the engine is automatically decoupled from the transmission in the D selector lever position. The vehicle continues traveling with the engine idling to reduce consumption. The D selector lever position remains engaged.

In addition, context-sensitive information, ECO PRO tips, are displayed to assist with an efficient driving style.

The achieved extended range is displayed in the instrument cluster as bonus range.

## **General information**

The system includes the following EfficientDynamics functions and EfficientDynamics displays:

- ▶ ECO PRO bonus range.
- ▶ ECO PRO seat climate control.
- ▶ ECO PRO climate control.
- ▶ ECO PRO light and sight.
- ▶ ECO PRO Limit.
- Coasting driving condition.
- Driving style analysis.

#### **Overview**





Button

## **Activating ECO PRO**



Press the button. ECO PRO is displayed in the instrument cluster.

## Configuring ECO PRO INDIVIDUAL

## **Via the Driving Dynamics Control**

- Activate ECO PRO.
- 2. "FCO PRO INDIVIDUAL"

#### Via iDrive

- 1. "CAR"
- 2. "Settings"
- 3. "Driving mode"
- 4. "ECO PRO INDIVIDUAL"
- 5. Select the desired setting.

## **ECO PRO limit speed**

▶ "ECO PRO speed": activate ECO PRO speed.

An ECO PRO tip is displayed if the speed of the set ECO PRO limit is exceeded.

"Notification at:"

Set the desired speed for the ECO PRO speed.

## Activating/deactivating ECO PRO functions

The following ECO PRO functions can be activated/deactivated:

- ▶ "Coasting"
- ▶ "ECO PRO seat heating"
- "ECO PRO climate control"
- "ECO PRO light and sight"

## Coasting

Efficiency can be optimized by disengaging or switching off the engine and coasting with the engine idling.

#### ECO PRO seat climate control

The activation of ECO PRO will reduce the output of the seat heating.

#### **ECO PRO climate control**

Climate control is set to be efficient.

This means, it is possible to deviate slightly from the set temperature or to heat or cool down the car's interior more slowly, to economize on consumption.

## **ECO PRO light and sight**

The output of exterior mirror heating and rear window defroster is reduced.

## Resetting the settings

Reset ECO PRO INDIVIDUAL to the standard settings:

"Reset to FCO PRO STANDARD"

## Displays in the instrument cluster

#### **General information**

When ECO PRO driving mode is activated, the display switches to a special configuration.

## **ECO PRO bonus range**



A modified driving style helps you extend your driving distance.

The range extension can be displayed as the bonus range in the instrument cluster.

The efficiency display includes the bonus range.


If the bonus range appears in gray, the current driving style is inefficient.

The display turns blue as soon as all conditions for efficient driving are met.

The intervals for resetting the bonus range depend on the settings of the trip data.

### **Consumption display**

Instrument cluster with enhanced features:



A pointer in the consumption display informs about the current driving style:

- ➤ The current consumption in relation to the average consumption is displayed.
- Pointer in the area of arrow 1: display of the energy recovered by coasting or when braking.
- ▶ Pointer in the area of arrow 2: display when accelerating.

If the acceleration is inefficient, the area between the average consumption and the current consumption is colored red.

In addition, the following information is displayed, depending on the situation:

- ▶ Depending on the equipment: the total distance driven while coasting.
- ➤ The total time that the engine has been switched off during automatic engine stops.
- A gear shift indicator recommending the use of a more efficient gear.

# **Indications on the Control Display**

#### **General information**

Information about the current effectiveness of the ECO PRO functions can be displayed as energy flow.

### **Displaying energy flow information**

- 1. "CAR"
- 2. "Driving information"
- 3. "Energy flow"

The following functions are displayed:

- ▶ Auto Start/Stop function.
- Energy recovery.
- Coasting.

## **Engine-Off / Coasting**

## **Principle**

Under certain conditions the engine is automatically decoupled from the transmission in the D selector lever position. The vehicle continues traveling with the engine idling to reduce consumption. Selector lever position D remains engaged. This driving condition is referred to as coasting.

Under certain conditions, the engine will not be operated at idle while coasting but switched off automatically in vehicles with Mild-Hybrid technology. When the engine is switched off, the lettering READY is displayed in the instrument cluster. The vehicle continues to coast without

consuming fuel. This driving condition is referred to as engine-off coasting.

As soon as the brake or accelerator pedal is depressed, the engine is automatically coupled to the transmission again.

#### **General information**

Coasting is a component of the ECO PRO driving mode.

Coasting is automatically activated when ECO PRO driving mode is called via the Driving Dynamics Control.

A proactive driving style helps the driver to use the function often and supports the efficient effect of coasting.

## **Functional requirements**

The function is available in the speed range from approx. 16 mph/25 km/h to 100 mph/160 km/h.

The function is active if the following conditions are met:

- ➤ The accelerator pedal is not depressed or the accelerator pedal is released.
- ▶ Brake pedal not depressed or only slightly depressed.
- The selector lever is in selector lever position D.
- ▶ Engine and transmission are at operating temperature.
- Active Cruise Control with Stop&Go function, ACC, not activated.

## **Operation via shift paddles**

## **Principle**

The coasting driving condition can be influenced with the shift paddles.

## Activating/deactivating coasting via shift paddles

- 1. Shift to the highest gear by pulling the right shift paddle.
- 2. To activate coasting mode, actuate the right shift paddle again.

To deactivate, actuate the left shift paddle.

## **Display**


## Display in the instrument cluster

The coasting distance traveled is indicated in coasting mode.

## **Indications on the Control Display**

The coasting mode is displayed under energy flow while driving.

The distance traveled in coasting mode is displayed in the trip data.



Color code blue: coasting mode.

## Displaying energy flow information

- 1. "CAR"
- 2. "Driving information"
- 3. "Energy flow"

## **System limits**

The function is not available under one of the following conditions.

- DSC OFF or TRACTION activated.
- ▶ Driving in the dynamic limit range and on steep uphill or downhill grades.

- Battery charge status temporarily too low or vehicle electrical system drawing excessive current.
- Trailer towing.
- ▶ HDC Hill Descent Control activated.

The more efficient the driving style, the more bars are displayed in color and the faster the bonus range increases.

In contrast, a reduced number of bars will be displayed with an inefficient driving style.

## **Driving style analysis**

## **Principle**

The function helps develop an especially efficient driving style and to conserve fuel.

For this purpose, the driving style is analyzed. The assessment is done in various categories and is displayed on the Control Display.

This display will help you adjust your driving style and save some fuel.

#### **General information**

The current trip is assessed.

To assist with an efficient driving style, ECO PRO tips are displayed during driving.

The range of the vehicle can be extended by adjusting your driving style.

This gain in range is displayed as a bonus range in the instrument cluster and on the Control Display.

## **Functional requirement**

This function is available in ECO PRO driving mode.

# Calling up the Driving style analysis

- 1. "CAR"
- 2. "Driving information"
- 3. "Driving style analysis"

## **Display on the Control Display**

The display of the Driving style analysis shows the efficiency of the Driving style.

## Refueling

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## Follow the following when refueling

#### General information

Follow the fuel recommendation prior to refueling.

When refueling, insert the filler nozzle completely into the filler pipe. Lifting up the filler nozzle during refueling causes:

- ▶ Premature switching off.
- Reduced return of the fuel vapors.

The fuel tank is full when the filler nozzle clicks off the first time

Make sure that the fuel cap is closed properly after refueling, otherwise the emissions warning light may light up.

Follow safety regulations posted at the filling station.

Additional information:

Fuel quality, refer to page 384.

## **Safety information**



#### ∧ NOTICE

With a driving distance of less than 30 miles/50 km the engine may no longer have sufficient fuel. Engine functions are not ensured anymore. There is a risk of damage to property, among other potential damage. Refuel promptly.

#### ∧ NOTICE

Fuels are toxic and aggressive. Overfilling of the fuel tank can damage the fuel system. Painted surfaces may be damaged by contact with fuel. Escaping fuel can harm the environment. There is a risk of damage to property, among other potential damage. Avoid overfilling.

## Fuel cap

## **Opening**

1. To open the fuel filler flap, press on the rear edge, arrow. The fuel filler flap opens.




pair shop.

Have fuel filler flap unlocked by a dealer's service center or another qualified service center or re-

2. Turn the fuel cap counterclockwise.





3. Place the fuel cap in the bracket attached to the fuel filler flap.

## Closing



The retaining strap of the fuel cap can be jammed and crushed during closing. The cap cannot be correctly closed. Fuel or fuel vapors can escape. There is a risk of injury or risk of damage to property. Pay attention that the retaining strap is not jammed or crushed when closing the cap.

- 1. Fit the fuel cap and turn it clockwise until you clearly hear a click.
- 2. Press on the fuel filler flap until it engages.

## **Emergency unlocking**

It may be necessary in certain situations to unlock the fuel filler flap manually, for instance with an electrical fault.

## Wheels and tires

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## Tire pressure

#### **General information**

The tire characteristics and tire pressure influence the following:

- The service life of the tires.
- Driving safety.
- Driving comfort.
- ▶ Fuel consumption.

## **Safety information**

## **⚠** Warning

A tire with too little or no tire inflation pressure may heat up significantly and sustain damage. This will have a negative impact on aspects of handling, such as steering and braking response. There is a risk of accident. Regularly check the tire inflation pressure, and correct it as needed, for instance twice a month and before a long trip.

## Tire pressure specifications

### In the tire inflation pressure table

The tire inflation pressure table, refer to page 348, contains all tire inflation pressure specifications for the specified tire sizes at the ambient temperature. The tire inflation pressure values apply to tire sizes approved by the manufacturer of the vehicle for the vehicle type.

To identify the correct tire inflation pressure, please note the following:

- ▶ Tire sizes of your vehicle.
- Maximum speed for driving.

## On the Control Display

The current tire inflation pressure values and the intended tire inflation pressure values for the mounted tires can be displayed on the Control Display.

To ensure that they are displayed correctly, the tire sizes must be stored in the system and must have been set for the mounted tires.

The current tire inflation pressure value is located on each tire.

The reference tire inflation pressure value is located in the lower area of the Control Display.

## **Checking the tire pressure**

#### **General information**

Tires heat up while driving. The tire pressure increases with the tire temperature.

Tires have a natural, consistent tire pressure loss.

The displays of inflation devices may under-read by up to 0.1 bar/2 psi.

# Checking using tire inflation pressure specifications in the tire inflation pressure table

- Determine the intended tire inflation pressure levels for the mounted tires.
- 2. Check the tire inflation pressure in all four tires, using a pressure gage, for example.
- Correct the tire inflation pressure if the actual tire inflation pressure deviates from the intended tire inflation pressure.
- 4. Check whether all valve caps are screwed onto the tire valves.

The tire inflation pressure specifications in the tire inflation pressure table only relate to cold tires or tires at the same temperature as the ambient temperature.

Only check the tire inflation pressure levels when the tires are cold, i.e.:

- ▶ A driving distance of max. 1.25 miles/2 km has not been exceeded.
- ▶ If the vehicle has not moved again for at least 2 hours after a trip.

Check the tire inflation pressure of the emergency wheel in the cargo area regularly, and correct it as needed.

# Checking using the tire inflation pressure specifications on the Control Display

- 1. "CAR"
- 2. "Vehicle status"
- 3. (!) "Tire Pressure Monitor"
- Check whether the current tire inflation pressure levels deviate from the intended tire pressure value.
- Correct the tire inflation pressure if the actual tire inflation pressure deviates from the intended tire inflation pressure.

## After correcting the tire pressure

With runflat tires:

Reinitialize the Flat Tire Monitor.

With Tire Pressure Monitor:

The corrected tire inflation pressures are applied automatically. Make sure that the correct tire settings have been made.

With tires that cannot be found in the tire pressure values on the Control Display, reset the Tire Pressure Monitor TPM.

# Tire inflation pressures up to 100 mph/160 km/h

For speeds of up to 100 mph/160 km/h and for optimum driving comfort, note the pressure values in the tire inflation pressure table and adjust as necessary.



These pressure values can also be found on the tire pressure label on the driver's door pillar.

Do not exceed a speed of 100 mph/160 km/h.

Tire size

# Tire pressure values up to 100 mph/160 km/h

## X5 sDrive40i, X5 xDrive40i, with two rows of seats

Pressure specifications

1110 3120	in bar/PSI	ocomounons
Specifications in bar/PSI with cold tires	<b>* † † † †</b>	†/D
265/50 R 19 110 H XL A/S	2.3 / 33	2.8 / 41
275/45 R 20 110 H XL A/S		
255/55 R 18 109 W XL		
265/50 R 19 110 H XL M+S		
275/45 R 20 110 V XL M+S		
Front: 275/45 R 20 110 Y XL	2.3 / 33	-
Rear: 305/40 R 20 112 Y XL	-	2.7 / 39
Front: 275/40 R 21 107 Y XL	2.4 / 35	-
Rear: 315/35 R 21 111 Y XL	-	2.9 / 42
Front: 275/35 R 22 104 Y XL	2.6 / 38	-
Rear: 315/30 R 22 107 Y XL	-	3.1 / 45
Front: 275/40 R 21 107 V XL M +S	2.4 / 35	-

Tire size	Pressure specifications in bar/PSI	
Rear: 315/35 R 21 111 V XL M +S	- 2.9 / 42	
Emergency wheel:	Speed up to a max. of 50 mph / 80 km/h	
T 155/80 R 19 114 M	4.2 / 60	

## X5 sDrive40i, X5 xDrive40i, with three rows of seats

Tire size	Pressure sp in bar/PSI	ecifications
Specifications in bar/PSI with cold tires	***	+ / / D
265/50 R 19 110 H XL A/S	2.3 / 33	2.8 / 41
275/45 R 20 110 H XL A/S		
255/55 R 18 109 W XL		
265/50 R 19 110 H XL M+S		
275/45 R 20 110 V XL M+S		
Front: 275/45 R 20 110 Y XL	2.3 / 33	-
Rear: 305/40 R 20 112 Y XL	-	2.7 / 39
Front: 275/40 R 21 107 Y XL	2.4 / 35	-
Rear: 315/35 R 21 111 Y XL	-	2.9 / 42

Tire size	Pressure spin bar/PSI	pecification
Front: 275/40 R 21 107 V M+S XL	2.4 / 35	-
Rear: 315/35 R 21 111 V M+S XL	-	2.9 / 42

#### X5 M50i

710 111001		
Tire size	Pressure spe in bar/PSI	ecifications
Specifications in bar/PSI with cold tires	* * * * + *	
275/45 R 20 110 H XL A/S	2.2 / 32	2.6 / 38
275/45 R 20 110 V XL M+S	2.3 / 33	2.8 / 41
Front: 275/40 R 21 107 Y XL	2.5 / 36	-
Rear: 315/35 R 21 111 Y XL	-	2.9 / 42
Front: 275/35 R 22 104 Y XL	2.7 / 39	-
Rear: 315/30 R 22 107 Y XL	-	3.1 / 45
Front: 275/40 R 21 107 V XL M +S	2.5 / 36	-
Rear: 315/35 R 21 111 V XL M +S	-	2.9 / 42
Emergency wheel: T 155/80 R 19 114 M	Speed up to a 50 mph / 80 k 4.2 / 60	

## Tire inflation pressures at max. speeds above 100 mph/160 km/h

## 

In order to drive at maximum speeds in excess of 100 mph/160 km/h, please observe, and, if necessary, adjust tire pressures for speeds exceeding 100 mph/160 km/h from the relevant table on the following pages. Otherwise, tire damage and accidents could occur.

For speeds over 100 mph/160 km/h and for optimum driving comfort, note the pressure values in the tire inflation pressure table and adjust as necessary.

## Tire pressure values over 100 mph/160 km/h

## X5 xDrive40i, X5 sDrive40i, with two rows of seats

in bar/PSI

Pressure specifications

Without high-speed tuning feature

Tire size

Specifications in bar/PSI with cold tires	* * * * + 1	
265/50 R 19 110 H XL A/S	2.5 / 36	3.0 / 44
275/45 R 20 110 H XL A/S		
255/55 R 18 109 W XL		
265/50 R 19 110 H XL M+S		
275/45 R 20 110 V XL M+S		
Front: 275/45 R 20 110 Y XL	2.3 / 33	-

Tire size	Pressure sp in bar/PSI	pecifications
Rear: 305/40 R 20 112 Y XL	-	2.7 / 39
Front: 275/40 R 21 107 Y XL	2.4 / 35	-
Rear: 315/35 R 21 111 Y XL	-	2.9 / 42
Front: 275/35 R 22 104 Y XL	2.6 / 38	-
Rear: 315/30 R 22 107 Y XL	-	3.1 / 45
Front: 275/40 R 21 107 V XL M +S	2.6 / 38	-
Rear: 315/35 R 21 111 V XL M +S	-	3.1 / 45
Emergency wheel:	Speed up to a max. of 50 mph / 80 km/h	
T 155/80 R 19 114 M	4.2 / 60	

With high-speed tuning feature

Tire size	Pressure s in bar/PSI	pecifications
Specifications in bar/PSI with cold tires	# # # + •	·
265/50 R 19 110 H XL M+S	2.5 / 36	3.0 / 44
275/45 R 20 110 V XL M+S	2.8 / 41	3.3 / 48
255/55 R 18 109 W XL	2.9 / 42	3.4 / 49

Tire size	Pressure sp in bar/PSI	ecifications
Front: 275/45 R 20 110 Y XL	2.8 / 41	-
Rear: 305/40 R 20 112 Y XL	-	3.1 / 45
Front: 275/40 R 21 107 Y XL	2.8 / 41	-
Rear: 315/35 R 21 111 Y XL	-	3.1 / 45
Front: 275/35 R 22 104 Y XL	2.8 / 41	-
Rear: 315/30 R 22 107 Y XL	-	3.3 / 48
Front: 275/40 R 21 107 V XL M +S	2.8 / 41	-
Rear: 315/35 R 21 111 V XL M +S	-	3.3 / 48
Emergency wheel:	Speed up to a 50 mph / 80 k	
T 155/80 R 19 114 M	4.2 / 60	

## X5 xDrive40i, X5 sDrive40i, with three rows of seats

Without high-speed tuning feature

<b>★</b> † <b>★</b> † <b>★</b> † • • • • • • • • • • • • • • • • • •	- <b>⅓</b> /Ø <b>3.</b> 0/44
2.5 / 36	3.0 / 44
2.3 / 33	-
	2.7 / 39
2.4 / 35	-
	2.9 / 42
2.6 / 38	-
	3.1 / 45
2	.4 / 35

### With high-speed tuning feature

Tire size	Pressure s in bar/PSI	pecifications
Specifications in bar/PSI with cold tires	***	+1/0
265/50 R 19	2.7 / 39	3.2 / 46

Tire size	Pressure sp in bar/PSI	ecifications
Front: 275/45 R 20 110 Y XL	2.9 / 42	-
Rear: 305/40 R 20 112 Y XL	-	3.4 / 49
Front: 275/40 R 21 107 Y XL	2.9 / 42	-
Rear: 315/35 R 21 111 Y XL	-	3.4 / 49
Front: 275/40 R 21 107 V XL M +S	2.9 / 42	-
Rear: 315/35 R 21 111 V XL M +S	-	3.4 / 49

### X5 M50i

Without high-speed tuning feature

vvitilout riigit-speed turiirig reature		
Pressure sp in bar/PSI	ecifications	
<b>*                                    </b>		
2.4 / 35	2.9 / 42	
2.5 / 36	3.0 / 44	
2.5 / 36	-	
-	2.9 / 42	
2.7 / 39	-	
-	3.1 / 45	
	in bar/PSI  * * * * * + *  2.4 / 35  2.5 / 36  2.5 / 36	

Tire size	Pressure spe in bar/PSI	ecifications
Front: 275/40 R 21 107 V XL M +S	2.7 / 39	-
Rear: 315/35 R 21 111 V XL M +S	-	3.1 / 45
Emergency wheel:	Speed up to a 50 mph / 80 k	
T 155/80 R 19 114 M	4.2 / 60	

With high-speed tuning feature

William Speed	iai iii ig Toatai c	
Tire size	Pressure s bar/PSI	pecifications in
Specifications in bar/PSI with cold tires	* * * * +	· / D
275/45 R 20 110 V XL M+S	2.8 / 41	3.3 / 48
Front: 275/40 R 21 107 Y XL	2.8 / 41	-
Rear: 315/35 R 21 111 Y XL	-	3.1 / 45
Front: 275/35 R 22 104 Y XL	3.1 / 45	-
Rear: 315/30 R 22 107 Y XL	-	3.4 / 49
Front: 275/40 R 21 107 V XL M +S	3.0 / 44	-

Tire size	Pressure specifications in bar/PSI
Rear: 315/35 R 21 111 V XL M +S	- 3.3 / 48
Emergency wheel:	Speed up to a max. of 50 mph / 80 km/h
T 155/80 R 19 114 M	4.2 / 60
	4.2 / 60

## **Tire marking**

#### Tire size

245/45 R 18 96 Y

245: nominal width in mm

45: aspect ratio in %

R: radial tire code

18: rim diameter in inches

96: load bearing capacity

Y: speed code letter

ZR tires: reinforced radial tire for speeds exceeding 150 mph/240 km/h

## **Maximum tire load**

Maximum tire load is the maximum permissible weight for which the tire is approved.

Locate the maximum tire load on the tire sidewall and the Gross Axle Weight Rating – GAWR – on the certification label on the driver door B-pillar. Divide the tire load by 1.1. It must be greater than one-half of the vehicle's Gross Axle Weight Rating – GAWR. Note, front vs. rear GAWR and tire loads, respectively.

## **Speed letter**

Designation	Maximum speed
Q	up to 100 mph/160 km/h
R	up to 106 mph/170 km/h
S	up to 112 mph/180 km/h
Т	up to 118 mph/190 km/h
Н	up to 131 mph/210 km/h
V	up to 150 mph/240 km/h
W	up to 167 mph/270 km/h
Υ	up to 186 mph/300 km/h
(Y)	above 186 mph/300 km/h

#### **Tire Identification Number**

DOT Code: DOT xxxx xxx 1921 xxxx: manufacturer code for the tire brand xxx: tire size and tire design

1921: tire age

Tires with DOT codes meet the guidelines of the U.S. Department of Transportation.

## Tire age

#### Recommendation

Regardless of the tire tread depth, replace tires at least every 6 years.

#### Manufacture date

You can find the manufacture date of the tire on the tire sidewall.

Designation	Manufacture date
DOT 1921	19th week 2021

## **Uniform Tire Quality Grading**

Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width.

E.g.: Treadwear 200; Traction AA; Temperature A

## **DOT Quality Grades**

Treadwear

Traction AA A B C

Temperature ABC

All passenger vehicle tires must conform to Federal Safety Requirements in addition to these grades.

#### **Treadwear**

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course. E.g., a tire graded 150 would wear one and one-half, 1 g, times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

#### **Traction**

The traction grades, from highest to lowest, are AA, A, B, and C.

Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.

The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

## **Temperature**

The temperature grades are A, the highest, B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades Band A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

## ⚠ Warning

The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure.

## **RSC - Run-flat tires**

Run-flat tires, refer to page 359, are labeled with a circular icon containing the letters RSC marked on the sidewall.

## M+S

Winter and all-season tires with better cold weather performance than summer tires.

## Tire tread

## **Summer tires**

Do not drive with a tire tread depth of less than 0.12 in/3 mm, otherwise there is an increased risk of aquaplaning.

#### Winter tires

Do not drive with a tire tread of less than 0.16 in/4 mm, as such tires are less suitable for winter operation.

## Minimum tread depth



Wear indicators are distributed around the tire circumference. These wear indicators have the legally required minimum height of 0.063 in/1.6 mm.

The positions of the wear indicators are marked on the tire sidewall with TWI, Tread Wear Indicator.

## **Tire damage**

## **General information**

Inspect your tires regularly for damage, foreign objects lodged in the tread, and tread wear.

Driving over rough or damaged road surfaces, as well as debris, curbs and other obstacles can cause serious damage to wheels, tires and suspension parts. This is more likely to occur with low-profile tires, which provide less cushioning between the wheel and the road. Be careful to avoid road hazards and reduce your speed, especially if your vehicle is equipped with low-profile tires.

Indications of tire damage or other vehicle malfunctions:

- Unusual vibrations.
- Unusual tire or running noises.
- Unusual handling such as a strong tendency to pull to the left or right.

Damage can be caused by the following situations, for instance:

- Driving over curbs.
- Road damage.
- Tire pressure too low.
- Vehicle overloading.
- Incorrect tire storage.

## **Safety information**



#### Marning

Damaged tires can lose tire inflation pressure, which can lead to loss of vehicle control. There is a risk of accident. If tire damage is suspected while driving, immediately reduce speed and stop. Have wheels and tires checked. For this purpose, drive carefully to the nearest dealer's service center or another qualified service center or repair shop. Have vehicle towed or transported as needed. Do not repair damaged tires, but have them replaced.



Tires can become damaged by driving over obstacles, e.g., curbs or road damage, at high speed. Larger wheels have a smaller tire crosssection. The smaller the tire cross-section. the higher the risk of tire damage. There may be a risk of accident and risk of damage to property. If possible, avoid driving over objects or road conditions that may damage tires, or drive over them slowly and carefully.

## **Changing wheels and tires**

## Mounting and wheel balancing

Have mounting and wheel balancing carried out by a dealer's service center or another qualified service center or repair shop.

## Approved wheels and tires

#### General information

The following properties are recommended and approved by the manufacturer of the vehicle for the approved wheels and tires per vehicle type and special equipment:

- Wheel and tire combinations.
- > Rim designs.
- Tire sizes.
- Tire brands

You can ask a manufacturer service center or another qualified service center or repair shop about the approved wheels and tires for the vehicle and the special equipment.

## Safety information



#### Warning

Wheels and tires which are not suitable for your vehicle can damage parts of the vehicle, for instance due to contact with the body due to tolerances despite the same official size rating. There is a risk of an accident. The manufacturer of your vehicle strongly suggests that you use wheels and tires that have been recommended by the vehicle manufacturer for your vehicle type.

#### Warning

Mounted steel wheels can cause technical problems, for instance unexpected loosening of the lug bolts and damage to the brake discs. There is a risk of accident. Do not mount steel wheels

#### Warning

Incorrect wheel/tire combinations will impair the vehicle's handling characteristics and a variety of system functions, such as the Antilock Braking System (ABS) or Dynamic Stability Control. There is a risk of accident. To maintain good handling and vehicle response, use only tires with a single tread configuration from a single manufacturer. The manufacturer of the vehicle recommends that you use wheels and tires that have been recommended by the vehicle manufacturer for your vehicle type. Following tire damage, have the original wheel/tire combination remounted on the vehicle as soon as possible

#### Warning

Unsuitable wheel studs, such as single-section wheel studs, may loosen or come off. The wheel may come loose during driving. There is a risk of accident. Use only two-section wheel studs that have been categorized as suitable for the respective wheel type by the manufacturer of the vehicle.

### Recommended tire brands



For each tire size, the manufacturer of the vehicle recommends certain tire brands. The tire brands can be identified by a star on the tire sidewall

#### **New tires**

Tire traction is not optimal due to production-related circumstances when tires are brand-new.

Drive conservatively for the first 200 miles/300 km.

### Retreaded tires



#### Warning

Retreaded tires can have different tire casing structures. With advanced age the service life can be limited. There is a risk of an accident. The manufacturer of your vehicle does not recommend the use of retreaded tires.

The manufacturer of the vehicle does not recommend the use of retreaded tires.

## Winter tires

### General information

Winter tires are recommended for operating on winter roads.

Although so-called all-season tires with M+S identification provide better winter traction than summer tires, they usually do not provide the same level of performance as winter tires.

#### Maximum speed of winter tires

If the maximum speed of the vehicle is higher than the permissible speed for the winter tires. then attach a label showing the permissible maximum speed in the field of vision. The label is available from a dealer's service center or another qualified service center or repair shop.

With winter tires mounted, observe and do not exceed the permissible maximum speed.

## **Changing runflat tires**

When changing from run-flat tires to standard tires, it must be ensured that the vehicle contains a compact spare tire ("donut") or tire mobility kit. Further information is available from a dealer's service center or another qualified service center or repair shop.

## Rotating wheels between axles

#### Marning

Rotating tires between the axles on vehicles with different tire sizes or rim sizes on the front and rear axles can cause damage to the tires and the vehicle. There is a risk of accident, Do not rotate the tires between the axles on vehicles with different tire sizes or rim sizes on the front and rear axles.

Different wear patterns can occur on the front and rear axles depending on individual driving conditions. The tires can be rotated in pairs between the axles to achieve even wear. Further information is available from a dealer's service center or another qualified service center or repair shop. After rotating, check the tire pressure and correct, if needed.

## Storing tires

## Tire pressure

Do not exceed the maximum tire inflation pressure indicated on the tire sidewall.

#### Storage

- Store wheels and tires in a cool, dry and dark
- Always protect tires against all contact with oil, grease, and solvents.
- Do not leave tires in plastic bags.
- Remove dirt from wheels or tires.

## **Runflat tires**

## **Principle**

Run-flat tires permit continued driving under restricted conditions even in the event of a complete tire pressure loss.

#### **General information**

The wheels consist of tires that are self-supporting, to a limited degree, and possibly special rims.

The reinforcement of the sidewall allows the tire to remain drivable to a restricted degree in the event of a tire pressure loss.

Follow the instructions for continued driving with a flat tire.

## **Safety information**



#### Warning

The vehicle handles differently when a run-flat tire has insufficient or no tire pressure; for instance, reduced lane stability when braking. braking distances are longer and the self-steering properties will change. There is a risk of accident. Drive moderately and do not exceed a speed of 50 mph/80 km/h.

## **⚠** Warning

Heavy trailers can start swinging when continuing to drive with a flat tire. There may be a risk of accident or risk of damage to property. Do not exceed a speed of 35 mph/60 km/h when driving with a trailer and a flat tire. Immediately brake in the case of swinging. Apply necessary steering corrections as carefully as possible.

### Identification



The tires are marked on the tire sidewall with Run-flat System Component RSC.

## Repairing a flat tire

## Safety measures

- ▶ Park the vehicle as far away as possible from passing traffic and on solid ground.
- ▶ Turn on the hazard warning system.
- Secure the vehicle against rolling away by setting the parking brake.
- ➤ Turn the steering wheel until the front wheels are in the straight-ahead position and engage the steering wheel lock.
- Have all vehicle occupants get out of the vehicle and ensure that they remain outside the hazardous area in a safe place, such as behind a guardrail.
- ▶ If necessary, set up a warning triangle at an appropriate distance.

## Tire repair set

## **Principle**


With the tire repair set, minor tire damage can be sealed temporarily to enable continued driving.

#### **General information**

- ➤ To enable continued driving, liquid sealant is pumped into the tire, which hardens and seals the damage from the inside.
- Follow the instructions on using the tire repair set found on the compressor and sealant bottle.
- Use of the tire repair set may be ineffective if the tire puncture measures approx. 4 mm or more.
- Contact a dealer's service center or another qualified service center or repair shop if the tire cannot be made drivable.
- ▶ Do not remove foreign bodies that have penetrated the tire. Remove foreign objects only when they are visibly protruding from the tire.
- ▶ Pull the speed limit sticker off the sealant bottle and apply it to the steering wheel.
- ➤ The use of a sealing compound can damage the wheel electronics. In this case, have the electronics checked and replaced at the next opportunity.
- ➤ The compressor can be used to check the tire inflation pressure.

### **Overview**


### **Storage**



The storage for the tire repair set is provided in the cargo area behind the left side panel.

Unlock the cover of the left side panel, arrow 1, and fold open, arrow 2.


#### Sealant bottle



- ▶ Sealant bottle, arrow 1.
- ▶ Filler hose, arrow 2.

Observe expiration date on the sealant bottle.

### Compressor



- 1 Sealant bottle unlocking
- 2 Sealant bottle holder
- 3 Tire pressure display
- 4 Reduce tire inflation pressure button
- **5** On/off switch
- **6** Compressor
- 7 Connector/cable for socket
- 8 Connection hose

### **Safety measures**

- ▶ Park the vehicle as far away as possible from passing traffic and on solid ground.
- ▶ Turn on the hazard warning system.
- ▶ Secure the vehicle against rolling away by setting the parking brake.
- ➤ Turn the steering wheel until the front wheels are in the straight-ahead position and engage the steering wheel lock.
- ▶ Have all vehicle occupants get out of the vehicle and ensure that they remain outside the hazardous area in a safe place, such as behind a guardrail.
- ▶ If necessary, set up a warning triangle at an appropriate distance.

### Filling the tire with sealing compound

### **Safety information**

#### ♠ DANGER

If the exhaust pipe is blocked or ventilation is insufficient, harmful exhaust gases can enter into the vehicle. The exhaust gases contain pollutants which are colorless and odorless. In enclosed areas, exhaust gases can also accumulate outside of the vehicle. There is danger to life. Keep the exhaust pipe free and ensure sufficient ventilation.

#### ∧ NOTICE

The compressor can overheat during extended operation. There is a risk of damage to property, among other potential damage. Do not run the compressor for more than 10 minutes.

### **Filling**

1. Shake the sealant bottle.



2. Pull filler hose completely out of the cover of the sealant bottle. Do not kink the hose.



3. Slide the sealant bottle into the holder on the compressor housing, ensuring that it engages audibly.



4. Screw the filler hose of the sealant bottle onto the tire valve of the nonworking wheel.



With the compressor switched off, insert the connector into the power socket in the vehicle interior.



6. With standby state or drive-ready state switched on, switch on the compressor.



Let the compressor run for max. 10 minutes to fill the tire with sealing compound and achieve a tire inflation pressure of approx. 2.0 bar.

While the tire is being filled with sealing compound, the tire inflation pressure may sporadically reach approx. 5 bar. Do not switch off the compressor in this phase.

# Checking and adjusting the tire inflation pressure

### Checking

- 1. Switch off the compressor.
- 2. Read the tire pressure on the tire pressure display.

To continue the trip, a tire inflation pressure of at least 2 bar must be reached.

# Removing and stowing the sealant bottle

- 1. Unscrew the filler hose of the sealant bottle from the tire valve.
- 2. Press the red unlocking device.
- Remove the sealant bottle from the compressor.
- Wrap and store the sealant bottle in suitable material to avoid contamination of the cargo area.

# Minimum tire inflation pressure is not reached

- 1. Pull the connector out of the power socket in the vehicle interior.
- 2. Drive 33 ft/10 m forward and back to distribute the sealing compound in the tire.
- 3. Screw the connection hose of the compressor directly onto the tire valve stem.



4. Insert the connector into the power socket in the vehicle interior.



With standby or drive readiness turned on, turn on the compressor and let it run for a maximum of 10 minutes. When the tire pressure does not reach at least 2 bar, contact a manufacturer service center or another qualified service center or repair shop.

When a tire pressure of at least 2 bar is reached, see Minimum tire inflation pressure is reached.

- 6. Unscrew the connection hose of the compressor from the tire valve.
- Pull the connector out of the power socket in the vehicle interior.
- 8. Stow the tire repair set in the vehicle.

# Minimum tire inflation pressure is reached

- Unscrew the connection hose of the compressor from the tire valve.
- 2. Pull the connector out of the power socket in the vehicle interior.
- 3. Stow the tire repair set in the vehicle.
- Immediately drive approx. 5 miles/10 km to ensure that the sealing compound is evenly distributed in the tire.

Do not exceed a speed of 50 mph/80 km/h. If possible, do not drive at speeds less than 12 mph/20 km/h.

### **Adjustment**

- 1. Stop at a suitable location.
- 2. Screw the connection hose of the compressor directly onto the tire valve stem.



3. Insert the connector into the power socket in the vehicle interior.



- 4. Correct the tire inflation pressure to at least 2.0 bar:
  - Increase tire pressure: with standby or drive readiness turned on, turn on the compressor and let it run for a maximum of 10 minutes.
  - ▶ Reduce tire inflation pressure: press the button on the compressor.
- 5. Unscrew the connection hose of the compressor from the tire valve.
- 6. Pull the connector out of the power socket in the vehicle interior.
- 7. Stow the tire repair set in the vehicle.

### **Continuing the trip**

Do not exceed the permissible maximum speed of 50 mph/80 km/h.

Reinitialize the Flat Tire Monitor.

Reset the Tire Pressure Monitor again.

Replace the faulty tire and the sealant bottle of the tire repair set promptly.

Additional information:

- ▶ Run-flat tires, refer to page 373.
- ▶ Tire pressure monitor, refer to page 366.

## **Tire chains**

### **Safety information**



#### Warning

With the mounting of tire chains on unsuitable tires, the tire chains can come into contact with vehicle parts. There may be a risk of accident or risk of damage to property. Only mount tire chains on tires that are designated by their manufacturer as suitable for the use of tire chains.



#### Marning

Insufficiently tight tire chains may damage tires and vehicle components. There may be a risk of accident or risk of damage to property. Make sure that the tire chains are always sufficiently tight. Re-tighten as needed according to the tire chain manufacturer's instructions.

### Fine-link tire chains

The manufacturer of the vehicle recommends the use of fine-link tire chains. Certain types of fine-link tire chains have been tested by the manufacturer of the vehicle and recommended as road-safe and suitable.

Information regarding suitable tire chains is available from a dealer's service center or another qualified service center or repair shop.

### Use

Use only in pairs on the rear wheels, equipped with the tires of the following size:

- ≥ 255/55 R18.
- > 265/50 R19.
- > 275/45 R20.

The wheel size and rim offset are located on the inside of the wheel.

Follow the tire chain manufacturer's instructions.

Do not initialize the Flat Tire Monitor after mounting tire chains, as doing so may result in incorrect readings.

Do not reset the Tire Pressure Monitor after mounting tire chains, as doing so may result in incorrect readings.

When driving with tire chains, briefly activate Dynamic Traction Control DTC to optimize the drive power.

### Maximum speed with tire chains

Do not exceed a speed of 30 mph/50 km/h when using tire chains.

### Rear axle steering during operation with snow chains

#### **General information**

In order to guarantee free movement of the wheels when operating with tire chains, rear axle steering of the integral active steering must be switched off when tire chains are mounted.

### Safety information



#### Marning

When rear axle steering is switched on and tire chains are mounted, there can be contact between tire chains and the body. There may be a risk of accident or risk of damage to property. With mounted tire chains, switch off the rear axle steering.

### Switching off rear axle steering

The rear axle steering is switched off by specifying that tire chains are installed.

- 1. "CAR"
- 2. "Settings"
- "General settings"
- 4. "Tire chains"
- "Tire chains installed"

Starting with the permissible maximum speed with snow chains of 30 mph/50 km/h the rear axle steering will be switched on again automatically.

## Tire pressure monitor

### **Principle**

The Tire Pressure Monitor monitors the tire pressure and issues a warning if the tire pressure has dropped.

#### **General information**

Sensors in the tire valves measure the tire inflation pressure and tire temperature.

Using the tire settings in iDrive, the system can automatically compare the predefined target pressures with the actual tire inflation pressures.

If tires are being used that are not specified on the tire inflation pressure details on the vehicle, such as tires with special approval, the system needs to be actively reset. The system will then take over the actual tire inflation pressures as the target pressures.

When operating the system, also note the information found in the Tire inflation pressure chapter.

Additional information:

Tire inflation pressure, refer to page 348.

### **Safety information**



#### Warning

The display of the target pressures is not a substitute for the tire inflation pressure details on the vehicle. Incorrect entries in the tire settings can lead to incorrect target tire inflation pressure values. In this case, it cannot be guaranteed that the notification of a tire pressure loss will be reliable. There is a risk of injury and risk of damage to property. Ensure that the tire sizes of the mounted tires are displayed correctly and match the details on the tires and on the vehicle.

### **Functional requirements**

The following conditions must be met for the system; otherwise, reliable message of a tire pressure loss is not assured:

- ▶ Every time a tire or wheel is changed, the correct details on the mounted tires must be entered in the tire settings.
- ▶ The Tire Pressure Monitor does not activate until after driving for a few minutes:
  - > After a tire or wheel replacement.
  - After a reset, for tires with special appro-
  - After changing the tire setting.
- ▶ For tires with special approval:
  - ▶ After a tire or wheel replacement, a reset was performed with the correct tire inflation pressure.
  - ▶ After the tire inflation pressure was adjusted to a new value, a reset was performed.
- Wheels with wheel electronics.

## **Tire settings**

### **General information**

The tire sizes of the mounted tires can be gathered from the tire inflation pressure details on the vehicle or directly on the tires.

The tire details do not need to be re-entered when the tire pressure is corrected.

For summer and winter tires, the tire details entered last are stored. After a tire or wheel replacement, the settings of the tire sets used last can be selected.

### **Changing settings**

- 1. "CAR"
- "Vehicle status"

- 3. (!) "Tire Pressure Monitor"
- 4. "Tire settings"
- 5. "Tire selection"
- 6. "Manual"
- 7. "Tire type"
  - ▶ "Summer"
  - "Winter/All-year"
- 8. Select the tire type that is mounted on the rear axle.

For tires with special approval:

"Other tires".

Observe further proceeding in the perform a reset section.

- 9. Select the maximum road speed that will be used with the tires.
- 10. "Save tire settings"

The measurement of the current tire inflation pressure is started. The measurement progress is displayed.

### Status display

#### **Current status**

The system status can be displayed on the Control Display, e.g., whether or not the system is active.

- 1. "CAR"
- 2. "Vehicle status"
- 3. (!) "Tire Pressure Monitor"

The current status is displayed.

### **Current tire pressure**

The current tire pressure is displayed for each tire.

The current tire inflation pressures may change during driving or depending on the outside temperature.

### **Current tire temperature**

Depending on the model, the current tire temperatures are displayed.

The current tire temperatures may change while driving or due to the outside temperature.

### Target pressure

The target pressure for the tires on the front and rear axles is displayed.

The specified target pressures take the influence of driving and outside temperature on the tire temperature into account. The appropriate target pressure is always displayed, independent of the weather situation, tire temperatures and travel times.

The displayed target pressure may change and may differ from the tire inflation pressure details on the door pillar of the driver's door. The tire inflation pressure can thus be corrected to the value of the displayed target pressures.

The target pressure is immediately adjusted if the vehicle load status is changed in the tire settings.

#### **Tire conditions**

#### General information

Tire and system status are indicated by the color of the wheels and a text message on the Control Display.

Any existing messages may not be deleted if the target pressure is not reached after the tire inflation pressure is corrected.

### All wheels green

- ➤ The system is active and bases warnings on the target pressures.
- ▶ For tires with special approval: the system is active and bases warnings on the tire inflation pressures stored during the last reset.

### One to four yellow wheels

A flat tire or major tire pressure loss has occurred in the indicated tires.

### **Gray wheels**

It may not be possible to identify tire pressure losses.

Possible causes:

- Malfunction.
- During tire inflation pressure measurement, after confirmation of the tire settings.
- ▶ For tires with special approval: a reset is performed for the system.

### For tires with special approval: perform a reset

- 1. "CAR"
- "Vehicle status"
- 3. "Tire Pressure Monitor"
- 4. Make sure that correct tire settings have been made.

Tire settings, refer to page 366.

- 5. Turn on drive-ready state and do not drive
- 6. Reset tire pressure: "Perform reset".
- 7. Drive away.

The wheels are displayed in gray and the following is displayed "Resetting tire pressure...".

After a travel time of several minutes, the set tire inflation pressures are accepted as the predefined tire inflation pressures. The reset is completed automatically while driving.

After a successfully completed reset, the wheels on the Control Display are shown in green and the following is displayed: "Reset successful."

You may interrupt this trip at any time. When you continue the reset resumes automatically.

### Messages: for tires without special approval

#### **General information**

A low tire inflation pressure may cause the DSC Dynamic Stability Control to be switched on.

### Safety information

#### Marning

A damaged regular tire with low or missing tire inflation pressure impacts handling, such as steering and braking response. Run-flat tires can maintain limited stability. There is a risk of accident. Do not continue driving if the vehicle is equipped with normal tires. Follow the information on run-flat tires and continued driving with these tires.

### If a tire inflation pressure check is required

#### Message

An icon with a Check Control message appears on the Control Display.

#### Possible cause Icon



Inflation was not carried out according to specifications, for instance when the tire has not been sufficiently inflated or in the case of a natural steady tire pressure loss.

#### Measure

Check the tire pressure and correct as needed.

### If the tire inflation pressure is too low

#### Message



A yellow warning light is illuminated in the instrument cluster.

In addition, an icon with a Check Control message appears on the Control Display.

#### Icon

#### Possible cause



There is a tire pressure loss.

#### Measure

- 1. Reduce the vehicle speed. Do not exceed a speed of 80 mph/130 km/h.
- 2. At the next opportunity, for instance at a filling station, check the tire inflation pressure in all four tires and correct if necessary.

### If there is a significant tire pressure loss

#### Message



A yellow warning light is illuminated in the instrument cluster.

In addition, an icon with the affected tire appears in a Check Control message on the Control Display.

#### Icon

#### Possible cause



There is a flat tire or a major tire pressure loss.

#### Measure

- 1. Reduce your speed and stop cautiously. Avoid sudden braking and steering maneuvers.
- 2. Check whether the vehicle is fitted with normal tires or run-flat tires
  - Run-flat tires are labeled with a circular icon containing the letters RSC marked on the tire sidewall.
  - Run-flat tires, refer to page 359.
- 3. Read the description on What to do in case of a flat tire.

Actions in the event of a flat tire, refer to page 370.

### Messages: for tires with special approval

#### **General information**

A low tire inflation pressure may cause the DSC Dynamic Stability Control to be switched on.

### Safety information

### Marning

A damaged regular tire with low or missing tire inflation pressure impacts handling, such as steering and braking response. Run-flat tires can maintain limited stability. There is a risk of accident. Do not continue driving if the vehicle is equipped with normal tires. Follow the information on run-flat tires and continued driving with these tires.

### If a tire inflation pressure check is required

#### Message

An icon with a Check Control message appears on the Control Display.

#### lcon

#### Possible cause



Inflation was not carried out according to specifications, e.g., the tire has not been sufficiently inflated.

The system has detected a wheel change, but no reset was done.

The tire inflation pressure has fallen below the level of the last reset.

No reset was performed for the system. The system issues a warning based on the tire inflation pressures stored during the last reset.

#### Measure

- Check the tire pressure and correct as needed.
- 2. Perform a system reset.

# If the tire inflation pressure is too low

#### Message



A yellow warning light is illuminated in the instrument cluster.

In addition, an icon with a Check Control message appears on the Control Display.

#### Icon Possible cause



There is a tire pressure loss.

No reset was performed for the system. The system issues a warning based on the tire inflation pressures stored during the last reset.

#### Measure

- Reduce the vehicle speed. Do not exceed a speed of 80 mph/130 km/h.
- At the next opportunity, for instance at a filling station, check the tire inflation pressure in all four tires and correct if necessary.
- 3. Reset the system.

# If there is a significant tire pressure loss

#### Message



A yellow warning light is illuminated in the instrument cluster.

In addition, an icon with the affected tire appears in a Check Control message on the Control Display.

#### Icon Possible cause



There is a flat tire or a major tire pressure loss.

No reset was performed for the system. The system issues a warning based on the tire inflation pressures stored during the last reset.

#### Measure

- Reduce your speed and stop cautiously. Avoid sudden braking and steering maneuvers.
- Check whether the vehicle is fitted with normal tires or run-flat tires.

Run-flat tires are labeled with a circular icon containing the letters RSC marked on the tire sidewall.

Run-flat tires, refer to page 359.

Read the description on What to do in case of a flat tire.

Actions in the event of a flat tire, refer to page 370.

### Actions in the event of a flat tire

#### Normal tires

1. Identify the damaged tire.

Check the tire pressure in all four tires, for instance using the tire pressure display of a flat tire kit.

For tires with special approval: when the tire pressure in all four tires is correct, the Tire Pressure Monitor may not have been reset. In this case, perform the reset.

If tire damage cannot be found, contact a dealer's service center or another qualified service center or repair shop.

2. Repair the flat tire, e.g., with a flat tire kit or by changing the wheel.

Use of sealing compound, for instance from the flat tire kit, may damage the wheel electronics.

Have the electronics replaced at the next opportunity.

#### **Runflat tires**

#### Safety information



#### Warning

The vehicle handles differently when a run-flat tire has insufficient or no tire pressure; for instance, reduced lane stability when braking, braking distances are longer and the self-steering properties will change. There is a risk of accident. Drive moderately and do not exceed a speed of 50 mph/80 km/h.

### Marning

Heavy trailers can start swinging when continuing to drive with a flat tire. There may be a risk of accident or risk of damage to property. Do not exceed a speed of 35 mph/60 km/h when driving with a trailer and a flat tire. Immediately brake in the case of swinging. Apply necessary steering corrections as carefully as possible.

#### Maximum speed

You may continue driving with a damaged tire at speeds up to 50 mph/80 km/h.

#### Continued driving with a flat tire

Follow the following when continuing to drive with a damaged tire:

- 1. Avoid sudden braking and steering maneuvers.
- 2. Do not exceed a speed of 50 mph/80 km/h.
- 3. Check the tire inflation pressure in all four tires at the next opportunity.

### Possible driving distance with a depressurized tire

The distance for which it may be possible to drive safely varies depending on how the vehicle is loaded and used, e.g., speed, road conditions, outside temperature. The driving distance may be less but may also be more if an economical driving style is used.

If the vehicle is loaded with an average weight and used under favorable conditions, the distance for which it may be safe to drive may be up to 50 miles/80 km.

#### Vehicle handling with damaged tires

Vehicles driven with a damaged tire will handle differently, potentially leading to conditions such as the following:

- ▶ Greater likelihood of skidding of the vehicle.
- Longer braking distances.
- ▶ Changed self-steering properties.

Modify your driving style. Avoid abrupt steering maneuvers or driving over obstacles, for instance curbs or potholes.

#### Final tire failure

Vibrations or loud noises while driving can indicate the final failure of a tire.

Reduce speed and stop; otherwise, pieces of the tire could come loose and cause an accident.

Do not continue driving. Contact a dealer's service center or another qualified service center or repair shop.

### System limits

### **Temperature**

The tire inflation pressure depends on the tire's temperature.

Driving or exposure to the sun will increase the tire's temperature, thus increasing the tire inflation pressure.

The tire inflation pressure is reduced when the tire temperature falls again.

These circumstances may cause a warning when temperatures fall very sharply.

Following a temperature-related warning, the target pressures are displayed on the Control Display again after a short distance.

### Sudden tire pressure loss

The system cannot indicate sudden serious tire damage caused by external circumstances.

### Failure performing a reset

Tires with special approval: the system will not function correctly if a reset was not performed, for example a flat tire may be indicated although the tire inflation pressures are correct.

#### **Malfunction**

### Message



The yellow warning light flashes and is then illuminated continuously. A Check Control message is displayed. It may not

be possible to identify tire pressure losses.

#### Measure

- A wheel without wheel electronics, such as an emergency wheel, is mounted: have the wheels checked, if needed.
- ➤ Fault caused by systems or devices with the same radio frequency: after leaving the area of the interference, the system automatically becomes active again.
- ➤ For tires with special approval: the system was unable to complete the reset. Perform a system reset again.
- Tire Pressure Monitor malfunction: have the system checked by a manufacturer service center or another qualified service center or repair shop.

### Declaration according to NHTSA/ FMVSS 138 Tire Pressure Monitoring System

Each tire, including the spare (if provided) should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label. (If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label, you should determine the proper tire inflation pressure for those tires.) As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale when one or more of your tires is significantly under-inflated. Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability. Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if underinflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale. Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly. Always check the TPMS malfunction telltale after

replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

### **Flat Tire Monitor FTM**

### **Principle**

The Flat Tire display detects a tire pressure loss while driving and issues a warning if the tire pressure has dropped.

### **General information**

The system detects tire pressure loss on the basis of rotation speed differences between the individual wheels while driving.

In the event of a tire pressure loss, the diameter and therefore the rotational speed of the corresponding wheel changes. The difference will be detected and reported as a flat tire.

The system does not measure the actual inflation pressure in the tires.

### **Functional requirements**

The following conditions must be met for the system; otherwise, reliable message of a tire pressure loss is not assured:

- ▶ After a tire or wheel replacement, an initialization was performed with the correct tire inflation pressure.
- ▶ After the tire pressure was adjusted to a new value, an initialization was performed.

## Status display

The current status of the Flat Tire Monitor FTM can be displayed, for instance whether the FTM is active.

- 1. "CAR"
- 2. "Vehicle status"
- 3. (!) "Flat Tire Monitor"

The status is displayed.

### **Initialization required**

An initialization must be performed in the following situations:

- ▶ After the tire inflation pressure has been ad-
- After a tire or wheel replacement.

### **Performing initialization**

When initializing, the set tire inflation pressures serve as reference values in order to detect a flat tire. Initialization is started by confirming the tire inflation pressures.

Do not initialize the system when driving with tire chains.

- 1. "CAR"
- 2. "Vehicle status"
- 3. "Flat Tire Monitor"
- 4. Turn on drive-ready state and do not drive
- 5. Start the initialization with: "Perform reset"
- Drive away.

The initialization is completed while driving, which can be interrupted at any time.

The initialization automatically continues when driving continues.

### Messages

#### **General information**

When a flat tire is indicated, DSC Dynamic Stability Control is switched on, if needed.

### **Safety information**



#### Marning

A damaged regular tire with low or missing tire inflation pressure impacts handling, such as steering and braking response. Run-flat tires can maintain limited stability. There is a risk of accident. Do not continue driving if the vehicle is equipped with normal tires. Follow the information on run-flat tires and continued driving with these tires.

#### Indication of a flat tire



A yellow warning light is illuminated in the instrument cluster.

In addition, an icon with a Check Control message appears on the Control Display.

#### Icon Possible cause



There is a flat tire or a major tire pressure loss.

#### Measure

- 1. Reduce your speed and stop cautiously. Avoid sudden braking and steering maneu-
- 2. Check whether the vehicle is fitted with normal tires or run-flat tires.

Run-flat tires are labeled with a circular icon containing the letters RSC marked on the tire sidewall.

Run-flat tires, refer to page 359.

### Actions in the event of a flat tire

#### **Normal tires**

1. Identify the damaged tire.

To do this, check the tire pressure in all four tires, for instance using the tire pressure display of a flat tire kit.

When the tire inflation pressure in all four tires is correct, the Flat Tire Monitor FTM may not have been initialized. In this case, initialize the system.

If identification of flat tire damage is not possible, please contact a dealer's service center or another qualified service center or repair shop.

2. Repair the flat tire, e.g., with a flat tire kit or by changing the wheel.

#### **Runflat tires**

#### Safety information

#### Marning

The vehicle handles differently when a run-flat tire has insufficient or no tire pressure; for instance, reduced lane stability when braking, braking distances are longer and the self-steering properties will change. There is a risk of accident. Drive moderately and do not exceed a speed of 50 mph/80 km/h.

### Marning

Heavy trailers can start swinging when continuing to drive with a flat tire. There may be a risk of accident or risk of damage to property. Do not exceed a speed of 35 mph/60 km/h when driving with a trailer and a flat tire. Immediately brake in the case of swinging. Apply necessary steering corrections as carefully as possible.

### Maximum speed

You may continue driving with a damaged tire at speeds up to 50 mph/80 km/h.

### Continued driving with a flat tire

Follow the following when continuing to drive with a damaged tire:

- 1. Avoid sudden braking and steering maneuvers.
- 2. Do not exceed a speed of 50 mph/80 km/h.
- 3. Check the tire inflation pressure in all four tires at the next opportunity.

When the tire inflation pressure in all four tires is correct, the Flat Tire Monitor may not have been initialized. In this case, initialize the system.

### Possible driving distance with a depressurized tire

The distance for which it may be possible to drive safely varies depending on how the vehicle is loaded and used, e.g., speed, road conditions, outside temperature. The driving distance may be less but may also be more if an economical driving style is used.

If the vehicle is loaded with an average weight and used under favorable conditions, the distance for which it may be safe to drive may be up to 50 miles/80 km.

#### Vehicle handling with damaged tires

Vehicles driven with a damaged tire will handle differently, potentially leading to conditions such as the following:

- ▶ Greater likelihood of skidding of the vehicle.
- Longer braking distances.
- Changed self-steering properties.

Modify your driving style. Avoid abrupt steering maneuvers or driving over obstacles, for instance curbs or potholes.

#### Final tire failure

Vibrations or loud noises while driving can indicate the final failure of a tire.

Reduce speed and stop; otherwise, pieces of the tire could come loose and cause an accident.

Do not continue driving. Contact a dealer's service center or another qualified service center or repair shop.

### **System limits**

The system could be delayed or malfunction in the following situations:

- ▶ A natural, even tire pressure loss in all four tires will not be recognized. Therefore, check the tire inflation pressure regularly.
- Sudden serious tire damage caused by external circumstances cannot be recognized in advance.

- ▶ The system has not been initialized.
- ▶ When driving on a snowy or slippery road.
- Sporty driving style: slip on traction wheels, high lateral acceleration (drifting).
- When driving with tire chains.

## **Changing wheels/tires**

### General information

When using run-flat tires or a flat tire kit, a wheel does not always need to be changed immediately when there is a tire pressure loss due to a flat tire.

If needed, the tools for changing wheels are available as accessories from a dealer's service center or another qualified service center or repair shop.

### **Safety information**



#### Marning

The vehicle jack is only provided for short-term lifting of the vehicle for wheel changes. Even if all safety measures are observed, there is a risk of the raised vehicle falling, if the vehicle jack tips over. There is a risk of injury or danger to life. When the vehicle is raised with the vehicle iack, do not lie under the vehicle and do not switch on the drive-ready state.

#### Marning

Supports such as wooden blocks under the vehicle jack reduce the capacity of the vehicle jack to bear weight. They have the potential to exert too much strain on the vehicle jack, causing it to tip over and the vehicle to fall. There is a risk of injury or danger to life. Do not place supports under the vehicle jack.

### **⚠** Warning

The jack, issued by the vehicle manufacturer, is provided in order to perform a wheel change in the event of a breakdown. The jack is not designed for frequent use; for example, changing from summer to winter tires. Using the jack frequently may cause it to become jammed or damaged. There is a risk of injury and risk of damage to property. Only use the jack to attach an emergency or spare wheel in the event of a breakdown.

### ▲ Warning

On soft, uneven or slippery ground, for example snow, ice, tiles, etc., the vehicle jack can slip away. There is a risk of injury. If possible, change the wheel on a flat, solid, and slip-resistant surface.

### **⚠** Warning

The vehicle jack is optimized for lifting the vehicle and for the jacking points on the vehicle only. There is a risk of injury. Do not lift any other vehicle or cargo using the vehicle jack.

### **⚠** Warning

When the vehicle jack is not inserted into the jacking point provided for this purpose, the vehicle may be damaged or the vehicle jack may slip when it is being cranked up. There is a risk of injury or risk of damage to property. When cranking up the vehicle jack, ensure that it is inserted in the jacking point next to the wheel housing.

### ⚠ Warning

A vehicle that is raised on a vehicle jack may fall off of the jack if lateral forces are exerted on it. There is a risk of injury and risk of damage to property. While the vehicle is raised, do not exert lateral forces on the vehicle or pull abruptly on the vehicle. Have a stuck wheel removed by a dealer's service center or another qualified service center or repair shop.

# Securing the vehicle against rolling

#### **General information**

The vehicle manufacturer recommends to additionally secure the vehicle against rolling away when changing a wheel.

#### On a level surface



Place wheel chocks or other suitable objects in front and behind the wheel that is diagonal to the wheel to be changed.

### On a slight downhill gradient



If you need to change a wheel on a slight downhill grade, place chocks and other suitable objects, for instance rocks, under the wheels of both the front and rear axles against the rolling direction.


### **Lug bolt lock**

### **Principle**

The wheel lug bolts have a special coding. The lug bolts can only be released with the adapter which matches the coding.

#### **Overview**

The adapter of the lug bolt lock is in the onboard vehicle tool kit or in a storage compartment close to the onboard vehicle tool kit.



- ▶ Lug lock bolt, arrow 1.
- Adapter, arrow 2.

### **Unscrewing**

- 1. Attach the adapter to the lug lock bolt.
- 2. Unscrew the lug lock bolt.
- Remove the adapter after unscrewing the lug bolt.

### Screwing on


- Attach the adapter to the lug lock bolt. If necessary, turn the adapter until it fits on the lug lock bolt.
- 2. Screw on the lug lock bolt. The tightening torque is 101 lbs ft/140 Nm.
- 3. Remove the adapter and stow it after screwing on the lug bolt.

### **Preparing the vehicle**

- ▶ Park the vehicle on solid and non-slip ground at a safe distance from traffic.
- ▶ Turn on the hazard warning system.
- Set the parking brake.
- ▶ Engage a gear or move the selector lever to position P.
- As soon as permitted by the traffic flow, have all vehicle occupants get out of the vehicle and ensure that they remain outside the hazardous area in a safe place, such as behind a guardrail.
- Depending on the vehicle equipment, get wheel change tools and, if necessary, the emergency wheel from the vehicle.
- If necessary, set up a warning triangle or portable hazard warning light at an appropriate distance.
- ▶ Secure the vehicle additionally against rolling.
- ▶ Loosen the lug bolts a half turn.
- Deactivate the air suspension level adjustment.

Two-axle ride level control, refer to page 280.

# Jacking points for the vehicle jack



The jacking points for the vehicle jack are located at the indicated positions.

### Jacking up the vehicle


### ⚠ Warning

Hands and fingers can be jammed when using the vehicle jack. There is a risk of injury. Comply with the described hand position and do not change this position while using the vehicle jack. 1. Hold the vehicle jack with one hand, arrow 1, and grasp the vehicle jack crank or lever with your other hand, arrow 2.



Insert the vehicle jack into the rectangular recess of the jacking point closest to the wheel to be changed.







3. Extend the vehicle jack by turning the vehicle jack crank or lever clockwise.



 Take your hand away from the vehicle jack as soon as the vehicle jack is under load and continue turning the vehicle jack crank or lever with one hand. 5. Make sure that the vehicle iack foot stands vertically and at a right angle beneath the jacking point.



6. Make sure that the vehicle jack foot stands vertically and perpendicularly beneath the jacking point after extending the vehicle jack.



7. Crank the vehicle up, until the vehicle jack is with the entire surface on the ground and the relevant wheel is maximum 1.2 inches/3 cm above ground.

### Mounting a wheel



#### Marning

Unsuitable wheel studs, such as single-section wheel studs, may loosen or come off. The wheel may come loose during driving. There is a risk of accident. Use only two-section wheel studs that have been categorized as suitable for the respective wheel type by the manufacturer of the vehicle.

Mount one emergency wheel only, as required.

- 1. Unscrew the lug bolts.
- 2 Remove the wheel

- 3. Put the new wheel or emergency wheel on and screw in at least two lug bolts in a crosswise pattern until hand-tight.
  - When non-original light-alloy wheels of the vehicle manufacturer are mounted, the accompanying lug bolts may have to be used as
- 4. Hand-tighten the remaining lug bolts and tighten all lug bolts well in a crosswise pattern.
- 5. Turn the vehicle jack crank counterclockwise to retract the vehicle jack and lower the vehicle.
- 6. Remove the vehicle jack and stow it securely.

### After the wheel change

- 1. Tighten the lug bolts crosswise. The tightening torque is 101 lbs ft/140 Nm.
- 2. Stow the nonworking wheel in the cargo area, if necessary.
- 3. Check tire inflation pressure at the next opportunity and correct as needed.
- 4. Reinitialize the Flat Tire Monitor. Reset the Tire Pressure Monitor again.
- 5. Check to make sure the lug bolts are tight with a calibrated torque wrench.
- 6. Have the damaged tire replaced at the nearest dealer's service center or another qualified service center or repair shop.

## **Emergency wheel**

### **Principle**

In the event of a flat tire, the emergency wheel can be used in place of the wheel with the defective tire. The emergency wheel is only intended for temporary use until the defective tire/wheel has been replaced.

### General information

Mount one emergency wheel only.

Also check the tire inflation pressure of the emergency wheel in the cargo area regularly, and correct it as needed.

### **Safety information**



#### Warning

The emergency wheel has particular dimensions. When driving with an emergency wheel, changed driving properties may occur, for instance reduced lane stability when braking, longer braking distance, and changed self-steering properties in the limit area. There is a risk of accident. Drive moderately and do not exceed a speed of 50 mph/80 km/h.

### Overview




The emergency wheel and the wheel change tools are located in the cargo area under the cargo floor panel.

### Removing the emergency wheel

- Depending on the vehicle equipment: press the button. The electric cargo cover travels up.
- 2. Fold up the cargo floor panel.
- 3. Depending on the equipment version: remove the crossmember. For this purpose, remove the wingnuts on both sides of the crossmember
- 4. Remove the tool holder from the emergency wheel.

5. Unscrew the butterfly screw, arrow 1.



- 6. Remove retaining plate, arrow 2.
- 7. If necessary, open the lower tailgate.
- 8. Remove the emergency wheel from the storage well.

### Inserting the emergency wheel

- Depending on the vehicle equipment: press the button. The electric cargo cover travels up.
- 2. Fold up the cargo floor panel.
- 3. Open the lower tailgate.
- 4. Place the emergency wheel in the storage well.
- 5. Position the retaining plate.
- 6. Screw on and tighten the butterfly screw.
- 7. Insert the tool holder.
- 8. Depending on the vehicle equipment: insert the crossmember and screw it tight with the wingnuts.
- 9. Push the cargo floor panel downward.

## **Engine compartment**


# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are

not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems applicable laws and regulations must be observed.


## **Overview**

### **Engines with 4 or 6 cylinders**



- 1 Vehicle identification number
- 2 Filler neck for washer fluid
- 3 Jump-starting, negative battery terminal
- 4 Jump-starting, positive battery terminal
- **5** Oil filler neck
- 6 Coolant reservoir, auxiliary cooling
- 7 Coolant reservoir, engine

### 8-cylinder engine



- Filler neck for washer fluid
- Jump-starting, negative battery terminal
- 3 Jump-starting, positive battery terminal
- 4 Coolant reservoir, engine

- 5 Coolant reservoir, auxiliary cooling
- Oil filler neck
- Vehicle identification number

## Hood

## **Safety information**



### ⚠ Warning

Improperly executed work in the engine compartment can damage vehicle components and impair vehicle functions. There is a risk of an accident and damage to property. Have work in the engine compartment performed by a dealer's service center or another qualified service center or repair shop.

#### Marning

The engine compartment accommodates moving components. Certain components in the engine compartment can also move with the vehicle switched off, for instance the radiator fan. There is a risk of injury. Do not reach into the area of moving parts. Keep articles of clothing and hair away from moving parts.



#### Warning

There are protruding parts, for instance locking hook, on the inside of the hood. There is a risk of injury. If the hood is open, pay attention to protruding parts and keep clear of these areas.

### ▲ Warning

An incorrectly locked hood can open while driving and restrict visibility. There is a risk of accident. Stop immediately and correctly close the hood.

### Marning

Body parts can be jammed when opening and closing the hood. There is a risk of injury. Make sure that the area of movement of hood is clear during opening and closing.

#### ∧ NOTICE

Folded-away wipers can be jammed when the hood is opened. There is a risk of damage to property, among other potential damage. Make sure that the wipers with the wiper blades mounted are folded down onto the windshield before opening the hood.

#### ∧ NOTICE

When the hood is closed, it must engage on both sides. Pressing again can damage the hood. There is a risk of damage to property, among other potential damage. Open the hood again and then close it energetically. Avoid pressing again.

### **Opening hood**

1. Pull lever, arrow 1.

Hood is unlocked.



- 2. After the lever is released, pull the lever again, arrow 2.
  - Hood can be opened.
- 3. Be careful of protruding parts on the hood.

### Closing the hood



Energetically close the hood from approx. 20 in/50 cm.

The hood must engage on both sides.

# **Operating materials**

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

### **Fuel recommendation**

#### **General information**

Depending on the region, many filling stations sell fuel that has been customized to winter or summer conditions. Fuel that is available in winter, for instance helps make a cold start easier.

### Gasoline

#### **General information**

For the best fuel efficiency, the gasoline should be sulfur-free or very low in sulfur content.

Fuels that are marked on the gas pump as containing metal must not be used.

Fuels with a maximum ethanol content of 25 %, i. e. E10 or E25, may be used for refueling.

Ethanol should meet the following quality standards:

US: ASTM 4806-xx

CAN: CGSB-3.511-xx

xx: comply with the current standard in each case.

### **Safety information**

#### CAUTION

The use of poor-quality fuels may result in harmful engine deposits or damage. Additionally, problems relating to drivability, starting and stalling, especially under certain environmental conditions such as high ambient temperature and high altitude, may occur.

If drivability problems are encountered, we recommend switching to a high quality gasoline brand and a higher octane grade — AKI number — for a few tank fills. To avoid harmful enaine deposits, it is highly recommended to purchase gasoline from Top Tier retailers.

Failure to comply with these recommendations may result in the need for additional maintenance.



#### ⚠ NOTICE

Even small quantities of the wrong fuel or wrong fuel additives can damage the fuel system and engine. Furthermore, the catalytic converter is permanently damaged. There is a risk of damage to property, among other potential damage. Do not refuel or add the following in the case of gasoline engines:

- ▶ Leaded gasoline.
- ▶ Metallic additives, for instance manganese or iron.

Do not press the Start/Stop button after refueling with the wrong fuel. Contact a dealer's service center or another qualified service center or repair shop.



#### ∧ NOTICE

Fuel that does not comply with the minimum quality can compromise engine function or cause engine damage. There is a risk of damage to property, among other potential damage. Do not fill with fuel that does not comply with the minimum quality.

#### ∧ NOTICE

Incorrect fuels can damage the fuel system and the engine. There is a risk of damage to property, among other potential damage. Do not use fuels with a higher ethanol content than recommended. Do not refuel with fuels containing methanol, e.g. M5 to M100.

### Recommended gas quality

BMW recommends AKI 91.

M Performance model:

BMW recommends AKI 93.

Refuel with this gasoline to achieve the rated performance and consumption values.

### Minimum fuel grade

BMW recommends AKI 89.

If you use gasoline with this minimum AKI Rating, the engine may produce knocking sounds when starting at high external temperatures. This has no effect on the engine life.

## BMW recommends Shell Quality Fuels

## **Engine oil**

#### General information

The engine oil consumption is dependent on your driving style and driving conditions.

Therefore, regularly check the engine oil level after refueling by taking a detailed measurement.

The engine oil consumption can increase in the following situations, for instance:

- Sporty driving style.
- Break-in of the engine.
- ▶ Idle operation of the engine.
- ▶ With use of engine oil types that are classified as not suitable.

Different Check Control messages appear on the Control Display depending on the engine oil level.

### Safety information



#### ∧ NOTICE

An engine oil level that is too low causes engine damage. There is a risk of damage to property, among other potential damage. Immediately add engine oil.



#### ⚠ NOTICE

Too much engine oil can damage the engine or the catalytic converter. There is a risk of damage to property, among other potential damage. Do not add too much engine oil. When too much engine oil is added, have the engine oil level corrected by a dealer's service center or another qualified service center or repair shop.

### **Electronic oil measurement**

#### **General information**

The electronic oil measurement has two measuring principles:

- Monitoring.
- Detailed measurement.

When making frequent short-distance trips or using a sporty driving style, for instance when taking curves aggressively, regularly perform a detailed measurement.

### **Monitoring**

#### **Principle**

The engine oil level is monitored electronically while driving and can be shown on the Control Display.

If the engine oil level is outside its permissible operating range, a Check Control message is displayed.



A red indicator light indicates that the engine oil pressure is too low.

### **Functional requirements**

A current measured value is available after approx. 30 minutes of normal driving.

### Displaying the engine oil level

- 1. "CAR"
- 2. "Vehicle status"
- 3. Engine oil level"

The engine oil level is displayed.

### System limits

When making frequent short-distance trips or using a sporty driving style, it may not be possible to calculate a measured value. In this case, the measured value for the last, sufficiently long trip is displayed.

#### **Detailed measurement**

#### **Principle**

The engine oil level is checked when the vehicle is stationary and displayed via a scale.

If the engine oil level is outside its permissible operating range, a Check Control message is displayed.

#### **General information**

During the measurement, the idle speed is increased somewhat.

#### **Functional requirements**

- Vehicle is parked in a horizontal position.
- Selector lever in selector lever position N or P and accelerator pedal not depressed.
- ➤ The drive-ready state is switched on by pressing the Start/Stop button.
- Engine is running and is at operating temperature.

### Performing a detailed measurement

- 1. "CAR"
- 2. "Vehicle status"
- 3. "Engine oil level"
- 4. "Engine oil measurement"
- "Start measurement"

The engine oil level is checked and displayed via a scale.

### Adding engine oil

#### **General information**

Only add engine oil when the message is displayed in the instrument cluster. The quantity to be added is indicated in the message shown on the Control Display.

Only add suitable types of engine oil.

Safely park the vehicle and switch off drive-ready state before adding engine oil.

Take care not to add too much engine oil.

### **Safety information**



#### Marning

Operating materials, for instance oils, greases, coolants, fuels, can contain harmful ingredients. There is a risk of injury or danger to life. Follow the instructions on the containers. Avoid the contact of articles of clothing, skin or eyes with operating materials. Do not refill operating materials into different bottles. Store operating materials out of reach of children.



#### ⚠ NOTICE

An engine oil level that is too low causes engine damage. There is a risk of damage to property, among other potential damage. Immediately add engine oil.



### ∧ NOTICE

Too much engine oil can damage the engine or the catalytic converter. There is a risk of damage to property, among other potential damage. Do not add too much engine oil. When too much engine oil is added, have the engine oil level corrected by a dealer's service center or another qualified service center or repair shop.

### Overview

The oil filler neck is located in the engine compartment.

Additional information:

For an overview, refer to page 381.

### Adding engine oil

1. Opening the hood.

Opening, refer to page 383.

Open the lid counterclockwise.



- Add engine oil.
- Close the lid.

### Engine oil types to add

#### General information

The engine oil grade is critical for the life of the engine.

Only add with the types of engine oil which are listed.

### **Safety information**



#### ⚠ NOTICE

Oil additives can damage the engine. There is a risk of damage to property, among other potential damage. Do not use oil additives.



#### ∧ NOTICE

Incorrect engine oil can cause malfunctions in the engine or damage it. There is a risk of damage to property, among other potential damage. When selecting an engine oil, make sure that the engine oil has the correct oil specification.

### Suitable engine oil types

Add engine oils that meet the following oil rating standards:

### Gasoline engine

BMW Lonalife-01 FE.

BMW Longlife-14 FE+.

BMW Longlife-17 FE+.

The BMW Longlife-14 FE+ and BMW Longlife-17 FE+ oil specifications are not suitable for the 50i gasoline engine.

### Alternative engine oil types

If an engine oil suitable for continuous use is not available, up to 1 US quart/liter of an engine oil with the following oil rating can be added:

### Oil specification

API SL.

API SM

APLSN.

### Viscosity grades

When selecting an engine oil, make sure that the engine oil has a suitable viscosity grade. The suitable viscosity grade is indicated on a label in the engine compartment.

#### Viscosity grades

SAE 0W-20.

SAF 0W-30.

The viscosity grade SAE 0W-20 is not suitable for gasoline engine 50i.

More information about suitable oil specifications and viscosity grades of engine oils can be reauested from a dealer's service center or another qualified service center or repair shop.

### **Engine oil change**



#### ∧ NOTICE

Engine oil that is not changed in timely fashion can cause increased engine wear and thus engine damage. There is a risk of damage to property. It is recommended that you do not exceed the service intervals indicated in the vehicle.

The vehicle manufacturer recommends that you have a dealer's service center or another qualified service center or repair shop change the engine oil.

BMW recommends Original BMW Engine Oil.

### Coolant

### General information

Coolant consists of water and coolant additive.

Not all commercially available additives are suitable for the vehicle. Do not mix additives of different colors. Observe the water - additive mixture ratio of 50:50. Information about suitable additives is available from a dealer's service center or another qualified service center or repair shop.

### **Safety information**



#### Warning

With the engine hot and the cooling system open, coolant can escape and lead to scalding. There is a risk of injury. Only open the cooling system with the engine cooled down.



### Marning

Additives are harmful and incorrect additives can damage the engine. There is a risk of injury and risk of damage to property. Do not allow additives to come into contact with skin, eyes or articles of clothing. Use suitable additives only.

### Coolant level

#### **General information**

Depending on the motorization, there are up to two coolant reservoirs in the engine compartment. Check and add the coolant levels on a reqular basis.

The coolant level is indicated using minimum and maximum markings in the filler neck of the coolant reservoir.

Depending on the engine installation, the coolant reservoir is located on the right side or the left side of the engine compartment.


Additional information:

For an overview, refer to page 381.

### Checking the coolant level

- 1. Let the engine cool down.
- 2. Opening the hood. Opening, refer to page 383.
- 3. Turn the lid of the coolant reservoir slightly counterclockwise to allow any excess pressure to dissipate, then open it.
- 4. Open the coolant reservoir lid.

5. The coolant level is correct if it lies between the minimum and maximum marks in the filler neck.



Close the lid.

### **Adding coolant**

- 1. Let the engine cool down.
- 2. Opening the hood. Opening, refer to page 383.
- 3. Turn the lid of the coolant reservoir slightly counterclockwise to allow any excess pressure to dissipate, then open it.
- 4. Open the coolant reservoir lid.
- 5. If the coolant is low, slowly add coolant up to the specified level: do not overfill.
- Close the lid.
- 7. Have the cause of the coolant loss eliminated as soon as possible.

### **Disposal**



Comply with the relevant environmental protection regulations when disposing of coolant and coolant additives.

### Washer fluid

### General information

All windshield washer jets are supplied from one tank.

Use a mixture of tap water and windshield washer concentrate. If desired, a windshield washer concentrate containing antifreeze can be used.

Recommended minimum fill quantity: 0.2 US gal/1 liter.

### **Safety information**

#### Warning

Some types of antifreeze can contain harmful substances and are flammable. There is a risk of fire and an injury hazard. Follow the instructions on the containers. Keep antifreeze away from ignition sources. Do not refill operating materials into different bottles. Store operating materials out of reach of children.

United States: the washer fluid mixture ratio is regulated by the U.S. EPA and many individual states: do not exceed the allowable washer fluid dilution ratio limits that apply. Follow the usage instructions on the washer fluid container.

Use of BMW's Windshield Washer Concentrate or the equivalent is recommended.



### Marning

Washer fluid can ignite and catch fire on contact with hot engine parts. There is a risk of injury or risk of damage to property. Only add washer fluid when the engine is cooled down. Next, fully close the lid of the washer fluid reservoir.



#### ⚠ NOTICE

Silicon-containing additives in the washer fluid for the water-repelling effect on the windows can lead to damage to the washing system. There is a risk of damage to property, among other potential damage. Do not add siliconcontaining additives to the washer fluid.

#### ∧ NOTICE

Mixing different windshield washer concentrates or antifreeze can damage the washing system. There is a risk of damage to property, among other potential damage. Do not mix different windshield washer concentrates or antifreeze. Follow the information and mixture ratios provided on the containers.

### Overview



The washer fluid reservoir is located in the enaine compartment.

### Malfunction

The use of undiluted windshield washer concentrate or alcohol-based antifreeze can lead to incorrect readings at temperatures below +5 °F/-15 °C.

## **Maintenance**

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## **BMW** maintenance system

The maintenance system provides service notifications and thereby provides support in maintaining road safety and the operational reliability of the vehicle.

In some cases, scopes and intervals of the maintenance system may vary according to the country version. Replacement work, spare parts, fuels and lubricants, and wear materials are calculated separately. Further information is available from a dealer's service center or another qualified service center or repair shop.

# **Condition Based Service CBS**

### **Principle**

Sensors and special algorithms take into account the driving conditions of the vehicle. CBS uses these to provide maintenance recommendations.

The system makes it possible to adapt the amount of maintenance corresponding to your user profile.

### **General information**

Information on service notifications can be displayed on the Control Display.

Additional information:

Service notifications, refer to page 171.

### Service data in the vehicle key

Information on the service notifications is continuously stored in the vehicle key. The service center can read this data out and suggest a maintenance scope for the vehicle.

Therefore, hand the service advisor the vehicle key with which the vehicle was driven most recently.

### Storage periods

Storage periods during which the vehicle battery was disconnected are not taken into account.

If this occurs, have a dealer's service center or another qualified service center or repair shop update the time-dependent maintenance procedures, such as checking brake fluid and, if necessary, changing the engine oil and the microfilter/ activated-charcoal filter.

# Maintenance Booklet for US Models

Please consult your Maintenance Booklet for additional information on the performance of service and maintenance work.

The manufacturer of your vehicle recommends that maintenance and repair be performed by a service center or another qualified service center or repair shop. Records of regular maintenance and repair work should be retained.

## Socket for OBD Onboard **Diagnosis**

#### General information

Devices connected to the OBD socket trigger the alarm system when the vehicle is locked. Remove any devices connected at the OBD socket before locking the vehicle.

### **Safety information**



#### ∧ NOTICE

The socket for Onboard Diagnosis is an intricate component intended to be used in coniunction with specialized equipment to check the vehicle's primary emissions system. Improper use of the socket for Onboard Diagnosis, or contact with the socket for Onboard Diagnosis for other than its intended purpose, can cause vehicle malfunctions and creates risks of personal and property damage. Given the foregoing, the manufacture of your vehicle strongly recommends that access to the socket for Onboard Diagnosis be limited to a dealer's service center or another qualified service center or repair shop or other persons that have the specialized training and equipment for purposes of properly utilizing the socket for Onboard Diagnosis.

### **Position**



Located on the driver's side is an OBD socket for reading the vehicle data.

### **Emissions**



- The warning light lights up: Emissions are deteriorating. Have the vehicle checked as soon as possible.
- ▶ The warning light flashes under certain circumstances:

This indicates that there is excessive misfiring in the engine.


Reduce the vehicle speed and have the system checked immediately; otherwise, serious engine misfiring within a brief period can seriously damage emission control components, in particular the catalytic converter.

## Replacing components

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

### Vehicle tool kit



The onboard vehicle tool kit is located under the cargo floor panel.

## Wiper blades

### **Safety information**



#### ⚠ NOTICE

The window may sustain damage if the wiper falls onto it without the wiper blade installed. There is a risk of damage to property, among other potential damage. Hold the wiper firmly when changing the wiper blade. Do not fold or switch on the wiper without a wiper blade installed.



#### ∧ NOTICE

Folded-away wipers can be jammed when the hood is opened. There is a risk of damage to property, among other potential damage. Make sure that the wipers with the wiper blades mounted are folded down onto the windshield before opening the hood.

### Replacing the front wiper blades

- 1. To change the wiper blades, fold up the wiper
  - Fold-away position of the wipers, refer to page 152.
- 2. Lift the wiper off of the windshield and hold.



3. Press the button, arrow 1, and pull out the wiper blade, arrow 2.



- 4. Insert the new wiper blade and press it on until it you hear it snap into the holder.
- 5. Fold down the wipers.

### Replacing the rear wiper blade

The wiper blade is engaged at the end of the wiper arm.

1. Lift off the wiper fully and pull off the wiper blade, arrow.



- 2. Attach a new wiper blade. The wiper blade must engage audibly.
- Fold down the wipers.

## **Lights and bulbs**

### **General information**

Lights and bulbs make an essential contribution to driving safety.

All headlights and lights are made using LED or laser technology.

Some items of equipment use light-emitting diodes installed behind a cover as a light source. These light-emitting diodes are related to conventional lasers and are officially designated as Class 1 light-emitting diodes.

The manufacturer of the vehicle recommends that you let a dealer's service center or another qualified service center or repair shop perform the work in case of a malfunction.

### **Safety information**



#### Warning

Focused laser light can irritate or permanently damage the retina of the eye. There is a risk of injury. The manufacturer of the vehicle recommends that the work on the lighting system including bulb replacement be performed by a dealer's service center or another qualified service center or repair shop.



### Marning

Intensive brightness can irritate or damage the retina of the eye. There is a risk of injury. Do not look directly into the headlights or other light sources. Do not remove the LED covers.

## **Headlight glass**

The inside of the headlight glass can fog up in cool or humid weather. When driving with the lights switched on, the condensation evaporates after a short time. The headlight glass does not need to be changed.

If despite driving with the headlights switched on, increasing humidity forms, for instance water droplets in the light, have the headlights checked.

## Vehicle battery

### General information

The battery is maintenance-free.

More information about the battery can be requested from a dealer's service center or another qualified service center or repair shop.

### **Safety information**

#### ♠ DANGER

Contact with live components can lead to an electric shock. There is a risk of injury or danger to life. Do not touch any components that are under voltage.

### Marning

Vehicle batteries that are not compatible can damage vehicle systems and impair vehicle functions. There is a risk of an accident and damage to property. Only vehicle batteries that are compatible with your vehicle type should be installed in your vehicle. Information on compatible vehicle batteries is available at your dealer's service center.

### Register the battery to the vehicle

The manufacturer of the vehicle recommends that you have a service center or another qualified service center or repair shop register the vehicle battery to the vehicle after the battery has been replaced. Once the battery has been registered again, all comfort features will be available without restriction and any Check Control messages displayed which relate to comfort features will disappear.

### Charging the battery

#### **General information**

Make sure that the battery is always sufficiently charged to guarantee that the battery remains usable for its full service life.



A discharged battery is indicated by a red indicator light.

Charge the battery when acceleration is insufficient.

The following circumstances can have a negative effect on the performance of the battery:

- Frequent short-distance drives.
- ➤ The vehicle is not used for more than a. month.

### Safety information



#### ∧ NOTICE

Battery chargers that charge the vehicle battery via sockets or cigarette lighters in the vehicle may overload or damage the 12 V electrical system. There is a risk of damage to property, among other potential damage. Only connect battery chargers for the vehicle battery to the starting aid terminals in the engine compartment.

### Charging the battery

Charge the battery only when the engine is off and via the starting aid terminals in the engine compartment.

With Mild Hybrid technology: charge the battery only when the hood is opened.

Additional information:

Starting aid terminals, refer to page 402.

### **Power interruption**

After a power interruption, some equipment needs to be newly initialized or individual settings updated, for example:

- ▶ With Memory function: store the positions again.
- Time: update.
- Date: update.
- ▶ Glass sunroof: initialize the system.

### Mild Hybrid technology

### **Principle**

Part of the Mild Hybrid technology is a battery that works with a voltage of 48 volts. Mild Hybrid technology can lower the fuel consumption.

Mild Hybrid technology influences the following functions.

Additional information:

- Auto Start/Stop function, refer to page 141.
- ▶ Engine-Off Coasting, refer to page 343.


### **Safety information**



### ♠ DANGER

Contact with live components can lead to an electric shock. There is a risk of injury or danger to life. Do not touch any components that are under voltage.


#### Overview



The battery for the Mild-Hybrid technology is located under a cover in the engine compartment on the front passenger side.

### Removing the cover

1. Turn lid up to the opened lock symbol f arrow 1.



2. Remove cover, arrow 2.

#### Information

A purple cable leads from the battery to the center of the vehicle.

Do not replace or work on the battery for the Mild Hybrid technology.

### Disposing of old batteries



Have old batteries disposed of by a dealer's service center or another qualified service center or repair shop or take

them to a collection point.

Maintain the filled battery in an upright position for transport and storage. Secure the battery so that it does not tip over during transport.

### **Fuses**

### General information

The fuses are located at different places in the vehicle.

Information on the fuse types and locations and the positions of the fuse boxes is available on the Internet: www.bmw.com/fusecard.

## **Safety information**



#### ▲ Warning

Incorrect and repaired fuses can overload electrical lines and components. There is a risk of fire. Never attempt to repair a blown fuse. Do not replace a nonworking fuse with a substitute of another color or amperage rating.

## **Replacing fuses**

The vehicle manufacturer recommends that you have a dealer's service center or another qualified service center or repair shop replace the fuses.

## **Breakdown Assistance**

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## **Hazard warning flashers**




The button is located in the center console.

The red light in the button flashes when the hazard warning flashers are activated.

## Warning triangle

The warning triangle is located in the left storage compartment of the cargo area.

1. Unlock the cover of the left side panel, arrow 1, and fold open, arrow 2.



Take the warning triangle out in the direction of the car's interior.



#### First-aid kit

#### **General information**

Some of the articles have a limited service life.

Check the expiration dates of the contents regularly and replace any expired items promptly.

#### **Storage**

Storage for the first-aid kit is provided in the left storage compartment of the cargo area.

1. Unlock the cover of the left side panel, arrow 1, and fold open, arrow 2.



 If necessary, remove the cargo cover from the storage under the cargo floor panel.
 Cargo cover, refer to page 326.

## **BMW Roadside Assistance**

#### **Principle**

Contact the BMW Group Roadside Assistance if assistance is needed in the event of a breakdown.

## **General information**

In the event of a breakdown, data on the vehicle's condition is transmitted to the BMW Roadside Assistance.

There are various ways of contacting BMW Roadside Assistance.

- Via a Check Control message.
   Supplementary text messages, refer to page 163.
- ▶ Calling with a mobile phone.
- Via the BMW app.

## **Functional requirements**

- Active ConnectedDrive contract, equipment with intelligent emergency call or BMW ConnectedDrive services.
- Cellular network reception.
- Standby state is switched on.

## **Starting manually**

If the vehicle is equipped with Teleservices, support is offered through Teleservice Diagnosis.

- 1. "APPS"
- 2. "Installed apps"
- 3. "BMW Assist"
- If necessary, "BMW Roadside Assistance" A voice connection is established.

## **Teleservice Diagnosis**

Teleservice Diagnosis enables the wireless transmission of detailed vehicle data that is important for vehicle diagnosis. This data is transmitted automatically. It may be necessary to approve this on the Control Display.

## **Teleservice Help**

Depending on the country, Teleservice Help enables an in-depth diagnosis of the vehicle by BMW Roadside Assistance via wireless transmission.

You can launch Teleservice Help by requesting it through BMW Roadside Assistance.

- 1. Park the vehicle in a safe place.
- 2. Set the parking brake.
- 3. Control Display is switched on.
- 4. Confirm Teleservice Help.

## **BMW Accident Assistance**

#### **Principle**

BMW Group Accident Assistance can be contacted if assistance is needed in the event of an accident.

#### **General information**

If the vehicle sensors detect a minor to moderately severe accident, which did not trigger any airbags, a Check Control message appears on the instrument cluster. In addition, a text message appears on the Control Display.

When BMW Accident Assistance is activated, data on the vehicle's condition is sent to BMW.

#### **Functional requirements**

- Active ConnectedDrive contract, equipment with intelligent emergency call or BMW ConnectedDrive services.
- Cellular network reception.
- Standby state is switched on.

#### Starting BMW Accident Assistance

# If an accident is detected automatically

A text message relating to BMW Accident Assistance appears on the Control Display.

The connection can be established directly:

"Contact accident assistance"

The Check Control message for BMW Accident Assistance can also be called up from the stored Check Control messages for a certain length of time.

Additional information:

Check Control, refer to page 162.

#### Starting manually

BMW Accident Assistance can also be contacted independently of the automatic accident detection function.

- 1. "APPS"
- 2. "Installed apps"
- 3. "BMW Assist"
- 4. "BMW Accident Assistance"

Follow the displays on the Control Display. A voice connection is established.

## **Emergency Call**

#### Intelligent emergency call

#### **Principle**

In case of an emergency, an emergency call can be triggered automatically by the system or manually.

#### **General information**

Only press the SOS button in an emergency.

The Intelligent Assist system establishes a connection with the BMW Response Center.

For technical reasons, the Emergency Call cannot be guaranteed under unfavorable conditions.

#### Overview





SOS button.

#### **Functional requirements**

- Standby state is switched on.
- ▶ The Assist system is functional.
- ▶ If the vehicle is equipped with intelligent emergency call: the integrated SIM card in the vehicle has been activated.

#### **Automatic triggering**

Under certain conditions, for instance if the airbags trigger, an emergency call is automatically initiated immediately after an accident of corresponding severity. Automatic Collision Notification is not affected by pressing the SOS button.

#### **Manual triggering**

- 1. Tap the cover.
- 2. Press and hold the SOS button until the LED in the area of the button illuminates green.
- ▶ The LED is illuminated green when an emergency call has been initiated.
  - If a cancel prompt appears on the Control Display, the emergency call can be aborted.
  - If the situation allows, wait in your vehicle until the voice connection has been established
- ▶ The LED flashes green when a connection to the BMW Response Center has been established

The BMW Response Center then makes contact with the occupants of the vehicle and initiates further steps to help.

Even if you are unable to respond, the BMW Response Center can take further steps to help you under certain circumstances.

For this purpose, data that serves to determine the necessary rescue measures, for instance the current position of the vehicle when it can be determined, is transmitted to the BMW Response Center.

Even if the BMW Response Center is no longer heard through the loudspeakers, the BMW Response Center may still be able to hear the occupants of the vehicle.

The BMW Response Center ends the emergency call.

#### Malfunction

The function of the Emergency Request may be impaired.

The LED in the area of the SOS button lights up for approximately 30 seconds. A Check Control message is displayed.

Have it checked by a dealer's service center or another qualified service center or repair shop.

## **Jump-starting**

#### General information

If the battery is discharged, the engine can be started using the battery of another vehicle and two jumper cables. Only use jumper cables with fully insulated clamp handles.

## **Safety information**



#### M DANGER

Contact with live components can lead to an electric shock. There is a risk of injury or danger to life. Do not touch any components that are under voltage.

#### Marning

If the jumper cables are connected in the incorrect order, sparking may occur. There is a risk of injury. Pay attention to the correct order during connection.

#### ∧ NOTICE

In the case of body contact between the two vehicles, a short circuit can occur during jumpstarting. There is a risk of damage to property. among other potential damage. Make sure that no body contact occurs.

#### **Preparation**

- 1. Check whether the battery of the other vehicle has a voltage of 12 volts. The voltage information can be found on the battery.
- 2. Switch off the engine of the assisting vehicle.
- 3. Switch off any electrical components in both vehicles.

## Starting aid terminals

The starting aid terminal in the engine compartment acts as the positive battery terminal.

A special connection on the body in the engine compartment acts as the negative battery terminal.

Additional information:

Overview of engine compartment, refer to page 381.

Open the cover of the positive battery terminal.

## **Connecting the cables**

Before you begin, switch off all unnecessary electronic systems/components, such as the radio, on the assisting and receiving vehicles.

- 1. Open the cover of the starting aid terminal.
- 2. Attach one terminal clamp of the positive iumper cable to the positive battery terminal. or to the corresponding starting aid terminal of the vehicle providing assistance.
- 3. Attach the terminal clamp on the other end of the cable to the positive battery terminal, or to the corresponding starting aid terminal of the vehicle to be started.

- 4. Attach one terminal clamp of the negative jumper cable to the negative battery terminal, or to the corresponding engine or body ground of assisting vehicle.
- 5. Attach the second terminal clamp to the negative battery terminal, or to the corresponding engine or body ground of the vehicle to be started.

## Starting the engine

Never use spray fluids to start the engine.

- 1. Start the engine of the assisting vehicle and let it run for several minutes at an increased idle speed.
- 2. Start the engine of the vehicle that is to be started in the usual way.
  - If the first starting attempt is not successful, wait a few minutes before making another attempt in order to allow the discharged battery to recharge.
- 3. Let both engines run for several minutes.
- 4. Disconnect the jumper cables in the reverse order.

Check the battery and recharge, if needed.

## **Tow-starting and towing**

## **Safety information**



#### Marning

Due to system limits, individual functions can malfunction during tow-starting/towing with the Intelligent Safety systems activated. There is a risk of accident. Switch all Intelligent Safety systems off prior to tow-starting/towing.

## **Steptronic transmission:** transporting the vehicle

#### **General information**

The vehicle is not permitted to be towed.

#### **Safety information**



#### ⚠ NOTICE

The vehicle can be damaged when towing the vehicle with a single lifted axle. There is a risk of damage to property, among other potential damage. The vehicle should only be transported on a loading platform.



#### ∧ NOTICE

The vehicle can become damaged when lifting and securing it.

There is a risk of damage to property, among other potential damage.

- ▶ Lift the vehicle using suitable means.
- ▷ Do not lift or secure the vehicle by its tow fitting, body parts, or suspension parts.


#### **Pushing the vehicle**

To remove a broken-down vehicle from the hazardous area, it can be pushed for a short distance.

Additional information:

Rolling or pushing the vehicle, refer to page 155.

#### Tow truck



The vehicle should only be transported on a loading platform.

## **Towing other vehicles**

#### **General information**

Switch on the hazard warning system, depending on local regulations.

If the electrical system has failed, clearly identify the vehicle being towed by placing a sign or a warning triangle in the rear window.

## **Safety information**



#### Marning

If the approved gross vehicle weight of the towing vehicle is lighter than the vehicle to be towed, the tow fitting can tear off or it will not be possible to control handling. There is a risk of accident. Make sure that the gross vehicle weight of the towing vehicle is heavier than the vehicle to be towed.



#### ∧ NOTICE

If the tow bar or tow rope is attached incorrectly, damage to other vehicle parts can occur. There is a risk of damage to property, among other potential damage. Correctly attach the tow bar or tow rope to the tow fitting.

#### Tow bar

The tow fittings used should be on the same side on both vehicles.

Should it prove impossible to avoid mounting the tow bar at an inclination, please follow the following:

- Free movement is limited going around corners.
- ➤ The tow bar will generate lateral forces if it is secured with an inclination.

#### **Tow rope**

Observe the following notes when using the tow rope:

- ▶ Use nylon ropes or straps, which will enable the vehicle to be towed without jerking.
- Make sure the tow rope is not twisted when fastening.
- ▶ Check the attachment of the tow fitting and tow rope in regular intervals.
- Do not exceed a towing speed of 30 mph/50 km/h.
- Do not exceed a towing distance of 3 miles/5 km.
- ▶ When starting to tow the vehicle, make sure that the tow rope is taut.

#### **Tow fitting**

#### **General information**



The screw-in tow fitting should always be carried in the vehicle.

The tow fitting can be screwed in at the front or rear of the vehicle.

The tow fitting is located beneath the cargo floor panel.

Observe the following notes when using the tow fitting:

- Use only the tow fitting provided with the vehicle.
- ➤ Turn the tow fitting at least 5 turns clockwise and screw it in as far as it will go. If necessary, tighten with a suitable object.
- After use, unscrew the tow fitting counterclockwise.
- Use the tow fitting for towing on paved roads only.
- Avoid lateral loading of the tow fitting, for instance do not lift the vehicle by the tow fitting.
- ► Check the attachment of the tow fitting in regular intervals.

Additional information:

Onboard vehicle tool kit, refer to page 393.

#### **Safety information**



#### ⚠ NOTICE

If the tow fitting is not used as intended, there may be damage to the vehicle or to the tow fitting. There is a risk of damage to property, among other potential damage. Follow the notes on using the tow fitting.

## Screw thread for tow fitting



Press on the mark on the edge of the cover to push it out.

#### **Tow-starting**

Do not tow-start the vehicle.

Start the engine by jump-starting, if possible.

Have the reasons for the starting difficulties corrected by a dealer's service center or another qualified service center or repair shop.

Additional information:

Jump-starting, refer to page 401.

## **Vehicle Care**

## Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## Washing the vehicle

#### General information

Regularly remove foreign objects such as leaves in the area below the windshield when the hood is raised.

Wash your vehicle frequently, particularly in winter. Intense contamination and road salt can damage the vehicle.

#### Steam cleaner and high pressure cleaner

#### Safety information



#### ⚠ NOTICE

When cleaning with high pressure cleaners, components can be damaged due to the pressure or temperatures being too high. There is a risk of damage to property, among other potential damage. Maintain sufficient distance and do not spray too long continuously. Follow the operating instructions for the high pressure cleaners.

#### **Distances and temperature**

- Maximum temperature: 140 °F/60 °C.
- Minimum distance from sensors, cameras, seals: 12 inches/30 cm.
- ▶ Minimum distance from glass sunroof: 31.5 in/80 cm.

#### Automatic washing systems or car washes

#### Safety information



#### ∧ NOTICE

Improper use of automatic washing systems or car washes can cause damage to the vehicle. There is a risk of damage to property, among other potential damage. Follow the following instructions:

- those that use soft brushes in order to avoid paint damage.
- ▶ Before driving into the car wash, make sure that the vehicle is not too large.
- > Do not drive through a car wash with guide rails higher than 4 in/10 cm to avoid damage to the body.
- ▷ Observe the tire width of the guide rail to avoid damage to tires and rims.
- ▶ Fold in exterior mirrors to avoid damage to the exterior mirrors.
- ▶ Deactivate the wiper and, if necessary, rain sensor to avoid damage to the window wiper system.

#### Driving into a car wash with a **Steptronic transmission**

#### Safety information



#### ∧ NOTICE

Selector lever position P is automatically engaged when standby state is switched off. There is a risk of damage to property, among other potential damage. Do not switch standby state off in car washes.

#### General information

In a car wash, the vehicle must be able to roll freely.

Some car washes do not permit persons in the vehicle. The vehicle cannot be locked from the outside when in selector lever position N. A signal sounds when an attempt is made to lock the vehicle.

Additional information:

Rolling or pushing the vehicle, refer to page 155.

#### Driving out of a car wash

Ensure that the vehicle key is in the car.

Turn on drive readiness.

Additional information:

Drive-ready state, refer to page 42.

#### **Headlights**

Do not rub wet headlights dry and do not use abrasive or acidic cleaning agents.

Soak areas that have been dirtied, for instance from insects, with auto shampoo and wash off with water.

Thaw ice with de-icing spray; do not use an ice scraper.

## After washing the vehicle

After washing the vehicle, apply the brakes briefly to dry them; otherwise, braking effect can be reduced. The heat generated during braking dries brake discs and brake pads and protects them against corrosion.

Completely remove all residues on the windows, to minimize loss of visibility due to smearing and to reduce wiper noises and wiper blade wear.

## Vehicle care

#### Vehicle care products

#### **General information**

BMW recommends using vehicle care and cleaning products from BMW. Suitable vehicle care products are available from a dealer's service center or another qualified service center or repair shop.

## Safety information



#### Warning

Cleansers can contain substances that are dangerous and harmful to your health. There is a risk of injury. When cleaning the interior, open the doors or windows. Only use products intended for cleaning vehicles. Follow the instructions on the container.

## Vehicle paintwork

#### **General information**

Regular vehicle care contributes to driving safety and value retention. Environmental influences in areas with elevated air pollution or natural contaminants, such as tree resin or pollen can affect the vehicle paintwork. Tailor the frequency and extent of your vehicle care to these influences.

Corrosive substances such as spilled fuel, oil, grease or bird droppings, must be removed immediately to prevent the finish from being altered or discolored.

#### Matte paintwork

Only use cleaning and care products suitable for vehicles with matte paintwork.

#### Leather care

Remove dust from the leather regularly, using a cloth or vacuum cleaner.

Otherwise, particles of dust and road grime chafe in pores and folds, and lead to heavy wear and premature degradation of the leather surface.

To guard against discoloration, such as from clothing, clean leather and provide leather care roughly every two months.

Clean light-colored leather more frequently because contamination on such surfaces is substantially more visible.

Use leather care products; otherwise, dirt and grease will gradually break down the protective coating of the leather surface.

## **Upholstery material care**

#### **General information**

Vacuum the upholstery regularly with a vacuum cleaner.

If upholstery is very contaminated, for instance with beverage stains, use a soft sponge or microfiber cloth with a suitable interior cleaner.

Clean the upholstery down to the seams using large sweeping motions. Avoid rubbing the material vigorously.

#### **Safety information**



#### ∧ NOTICE

Open hook and loop fasteners on articles of clothing can damage the seat covers and other cloth upholstery in the vehicle. There is a risk of damage to property, among other potential damage. Ensure that any Velcro® fasteners are closed

## **Caring for special components**

#### **Light-alloy wheels**

When cleaning the vehicle, use only neutral rim cleaners having a pH value from 5 to 9. Do not use abrasive cleaning agents or steam cleaners above 140 °F/60 °C. Follow the manufacturer's instructions

Aggressive, acidic or alkaline cleaning agents can destroy the protective coating of adjacent components, such as the brake disc.

After cleaning, apply the brakes shortly to dry them. The heat generated during braking dries brake discs and brake pads and protects them against corrosion.

#### Chrome surfaces

Carefully clean Chrome surfaces, especially in case of exposure to road salt, with plenty of water and added auto shampoo as needed.

#### **Rubber components**

Environmental influences can cause surface contamination of rubber parts and a loss of gloss. Use only water and suitable cleaning agents for cleaning.

Treat especially worn rubber parts with rubber care products at regular intervals. When cleaning rubber seals, do not use any silicon-containing vehicle care products in order to avoid damage or noises.

#### Fine wood parts

Clean fine wood facing and fine wood components only with a moist rag. Then dry with a soft cloth.

#### Kenaf

Only treat parts made of Kenaf fibers using suitable care products.

#### **Plastic components**



#### ∧ NOTICE

Cleaning agents that contain alcohol or solvents, such as lacquer thinners, heavy-duty grease removers, fuel and such, can damage plastic parts. There is a risk of damage to property, among other potential damage. Clean with a microfiber cloth. Dampen the cloth lightly with water, if needed.

Clean with a microfiber cloth.

Dampen the cloth lightly with water, if needed. Do not soak the headliner.

#### Safety belts



#### Marning

Chemical cleansers can destroy the safety belt webbing. Missing protective effect of the safety belts. There is a risk of injury or danger to life. Use only a mild soapy solution for cleaning the safety belts.

Dirty belt straps impede the reeling action and thus have a negative impact on safety.

Use only a mild soapy solution for cleaning the installed belt straps.

Safety belts should only be allowed to retract if they are dry.

#### Carpets and floor mats



#### 🛕 Warning

Objects in the driver's floor area can limit the pedal distance or block a depressed pedal. There is a risk of accident. Stow objects in the vehicle such that they are secured and cannot enter into the driver's floor area. Use floor mats that are suitable for the vehicle and can be safely attached to the floor. Do not use loose floor mats and do not layer several floor mats.

Make sure that there is sufficient clearance for the pedals. Ensure that the floor mats are securely fastened again after they were removed, for instance for cleaning.

The floor mats can be removed from the car's interior for cleaning.

If the floor carpets are very contaminated, clean with a microfiber cloth and water or a textile cleaner. To prevent matting of the carpet, rub back and forth in the driving direction only.

#### Mount for trailer hitch

Keep the mount clean.

Regularly grease or oil bearings and sliding surfaces with resin-free greases or oils.

Before using steam cleaners or high pressure cleaners on the vehicle, remove the ball head and insert the cover into the mount.

#### Sensors and camera lenses

To clean sensors and camera lenses, use a cloth moistened with a small amount of glass detergent.

## Displays, screens, and protective glass of the Head-up Display



#### ∧ NOTICE

Chemical cleaning agents, moisture or fluids of any kind can damage the surface of displays and screens. There is a risk of damage to property, among other potential damage. Clean with a clean, antistatic microfiber cloth.



#### 

The surface of displays can be damaged with improper cleaning. There is a risk of damage to property, among other potential damage. Avoid pressure that is too high and do not use any scratching materials.

Use a dry, clean antistatic microfiber cloth.

Clean the protective glass of the Head-up Display using a microfiber cloth and commercially available dish-washing soap.

## Taking the vehicle out of service

When the vehicle is shut down for longer than three months, special measures must be taken. Further information is available from a dealer's service center or another qualified service center or repair shop.

## **Technical data**

# Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are

not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

## **General information**

The technical data and specifications in the Owner's Manual are used as guidance values. The vehicle-specific data can deviate from this, for instance due to the selected optional equipment, country version or country-specific meas-

uring procedure. Detailed values can be found in the approval documents, on labels on the vehicle or can be obtained from a dealer's service center or another qualified service center or repair shop.

## **Dimensions**

The dimensions can vary depending on the model version, equipment version or country-specific measurement procedure.

The height of the vehicle can also differ, e.g. due to tires and vehicle load.

BMW X5		
Width with mirrors	in/mm	87.3/2,218
Width without mirrors	in/mm	78.9/2,004
Height	in/mm	69/1,753
Length	in/mm	194.3/4,936
Wheelbase	in/mm	117.1/2,975
Smallest turning radius diam.	ft/m	41.3/12.6

## Weights

X5 sDrive40i with two rows of seats			
Approved gross vehicle weight	lbs/kg	6,122/2,777	
Payload	lbs/kg	1,014/460	
Approved front axle weight	lbs/kg	2,822/1,280	
Approved rear axle weight	lbs/kg	3,589/1,628	
X5 sDrive40i with three rows of seats			
Approved gross vehicle weight	lbs/kg	6,651/3,017	
Payload	lbs/kg	1,376/624	
Approved front axle weight	lbs/kg	2,855/1,295	
Approved rear axle weight	lbs/kg	3,920/1,778	
X5 xDrive40i with two rows of seats			
Approved gross vehicle weight	lbs/kg	6,232/2,827	
Payload	lbs/kg	1,016/461	
Approved front axle weight	lbs/kg	2,921/1,325	
Approved rear axle weight	lbs/kg	3,677/1,668	
X5 xDrive40i with three rows of seats			
Approved gross vehicle weight	lbs/kg	6,762/3,067	
Payload	lbs/kg	1,462/663	
Approved front axle weight	lbs/kg	2,943/1,335	
Approved rear axle weight	lbs/kg	3,920/1,778	
X5 M50i powered by BMW M			
Approved gross vehicle weight	lbs/kg	6,559/2,975	
Payload	lbs/kg	1,030/467	

X5 M50i powered by BMW M		
Approved front axle weight	lbs/kg	3,241/1,470
Approved rear axle weight	lbs/kg	3,660/1,660

## **Trailer towing**

1,653/750
5,952/2,700
7,209/3,270
551/250
3,589/1,628
6,122/2,777

- a) The trailer load only applies to vehicles with a mount for trailer hitches retrofitted by BMW.
- b) The trailer load only applies to vehicles with a factory-installed mount for trailer hitches.

lbs/kg	1,653/750
lbs/kg	5,952/2,700
lbs/kg	7,209/3,270
lbs/kg	551/250
lbs/kg	3,920/1,778
lbs/kg	6,651/3,017
	lbs/kg lbs/kg lbs/kg lbs/kg

- a) The trailer load only applies to vehicles with a mount for trailer hitches retrofitted by BMW.
- b) The trailer load only applies to vehicles with a factory-installed mount for trailer hitches.

X5 xDrive40i with two rows of seats		
Trailer load without brakes	lbs/kg	1,653/750
a) Trailer load with brakes on uphill grades of up to 12 %	lbs/kg	5,952/2,700
b) Trailer load with brakes on uphill grades of up to 12 $\%$	lbs/kg	7,209/3,270

X5 xDrive40i with two rows of seats		
Maximum drawbar nose weight	lbs/kg	551/250
Approved rear axle weight, towing vehicle	lbs/kg	3,677/1,668
Approved gross vehicle weight, towing vehicle	lbs/kg	6,232/2,827

- a) The trailer load only applies to vehicles with a mount for trailer hitches retrofitted by BMW.
- b) The trailer load only applies to vehicles with a factory-installed mount for trailer hitches.

X5 xDrive40i with three rows of seats		
Trailer load without brakes	lbs/kg	1,653/750
a) Trailer load with brakes on uphill grades of up to 12 %	lbs/kg	5,952/2,700
b) Trailer load with brakes on uphill grades of up to 12 $\%$	lbs/kg	7,209/3,270
Maximum drawbar nose weight	lbs/kg	551/250
Approved rear axle weight, towing vehicle	lbs/kg	3,920/1,778
Approved gross vehicle weight, towing vehicle	lbs/kg	6,762/3,067

- a) The trailer load only applies to vehicles with a mount for trailer hitches retrofitted by BMW.
- b) The trailer load only applies to vehicles with a factory-installed mount for trailer hitches.

X5 M50i powered by BMW M		
Trailer load without brakes	lbs/kg	1,653/750
a) Trailer load with brakes on uphill grades of up to 12 %	lbs/kg	5,952/2,700
b) Trailer load with brakes on uphill grades of up to 12 %	lbs/kg	7,209/3,270
Maximum drawbar nose weight	lbs/kg	551/250
Approved rear axle weight, towing vehicle	lbs/kg	3,660/1,660
Approved gross vehicle weight, towing vehicle	lbs/kg	6,559/2,975

- a) The trailer load only applies to vehicles with a mount for trailer hitches retrofitted by BMW.
- b) The trailer load only applies to vehicles with a factory-installed mount for trailer hitches.

## **Capacities**

## BMW X5

Fuel tank, approx. US gal/liters 21.9/83.0

Observe further information on fuel quality, refer to page 384.

## **Appendix**

## **General information**

Any updates to the Owner's Manual of the vehicle are listed here.

# Updates made after the editorial deadline

The following chapters were updated in the printed version of the Owner's Manual after the editorial deadline for the Integrated Owner's Manual in the vehicle had closed:

Opening and closing: BMW Digital Key: general.

## **Everything from A to Z**

#### Index

_4

3D View, see Surround View 269 48V technology, see Mild Hybrid technology 396

#### Α

ABS Antilock Braking System 223 Acceleration Assistant, see Launch Control 158 Accessories and parts 8 Accident prevention, see Active Protection 220 ACC, see Active Cruise Control 234 Activated charcoal filter 292 Activation, trailer towing 338 Active Blind Spot Detection 210 Active Cruise Control with Stop&Go function ACC 234 Active damping control, see Adaptive M chassis/ suspension 286 Active Guard Plus, see Intelligent Safety 191 Active Guard, see Intelligent Safety 191 Active M Sport differential 226 Active PDC, see Emergency brake function 257 Active Protection 220 Active roll stabilization 285 Active seat ventilation 133 Active Steering, integral 228 Adaptive brake assistant 223 Adaptive chassis 285 Adaptive Light Control 182 Adaptive M chassis/suspension 286 Adaptive M suspension Professional 286 ADAPTIVE, see Driving Dynamics Control 146 Adding engine oil types 387 Adding oil 386 Additives, engine oil types 387 Adjusting contents, iDrive 49

Adjustments, steering wheel 129 Airbags 187 Airbags, indicator and warning light 189 Air circulation, see Recirculated-air mode 291 air conditioning, climate 289 Air distribution, manual 291 Air drying, see air conditioning 289 Air flow, automatic climate control 291 Air outlets, see Ventilation 292 Air pressure, tires 348 Air quality 287 Air suspension, see Two-axle ride level control 280 Alarm system 110 Alarm, unintentional 112 All-season tires, see Winter tires 358 All-wheel-drive, see xDrive 225 Ambient air package 301 Ambient light 185 Android Auto, connection to the vehicle 79 Android Auto preparation, connection to the vehicle 79 Android Auto preparation, smartphone integra-Animal detection, see Night Vision 203 Antifreeze, see Washer fluid 389 Antilock Braking System ABS 223 Anti-slip control, see DSC 223 Anti-slip rails 323 Anti-theft protection, lug bolt lock 377 Apple CarPlay preparation, connection to the vehicle 79 Apple CarPlay preparation, smartphone integra-Approach control warning with City braking function 192 Approach control warning with light braking function 192 Apps, see Owner's Handbook for Navigation, En-

Adjusting engine sound 286

Adjusting sound of the engine 286

tertainment, Communication 6

Aquaplaning 332	Backrest tilt 118
Armrest heating 132	Backrest tilt, rear seats 121
Ashtray 308	Backrest, width 119
Assistance when driving off, see Drive-off assis-	Bad road trips 330
tant 223	Bandages, see First-aid kit 398
Assistance with breakdown 398	Bar for tow-starting/towing 404
Assisted Driving Mode, see Steering Assis-	Basic position, rear seats 121
tant 244	Battery, disposing of 396
Assisted Driving Plus 248	Battery, vehicle 394
Assisted Driving View 160	Being towed, see Tow-starting and towing 402
Audio, see Owner's Manual for Navigation, En-	Belts, see Safety belts 123
tertainment and Communication 6	Blind spot collision warning 210
AUTO H button, see Parking brake 146	Blocking, power window, see Safety switch 113
Automatic activation, see Climate control	Bluetooth connection 76
rules 134	Blu-ray, see Owner's Handbook for Navigation,
Automatic car wash 406	Entertainment, Communication 6
Automatic climate control 287	BMW Accident Assistance 400
Automatic control, headlight 179	BMW Assist, see Owner's Manual for Navigation,
Automatic Curb Monitor, exterior mirror 129	Entertainment and Communication 6
Automatic deactivation, front-seat passenger air-	BMW Digital Key 93
bags 190	BMW display key 87
Automatic Differential Brake 226	BMW display key, malfunction 90
Automatic headlight control 179	BMW Drive Recorder 218
Automatic High Beam Assistant 182	BMW Gesture Control 56
Automatic Hold, see Parking brake 146	BMW Intelligent Personal Assistant 52
Automatic locking 109	BMW maintenance system 391
Automatic Parking Assistant 262	BMW Roadside Assistance 399
Automatic Recirculating Air Control 290	Bonus range, ECO PRO 343
Automatic sliding and anti-slip rails 323	Bottle holder, front, see Cup holder, front 318
Automatic tailgate 104	Bottle holder, rear, see Cup holder, rear 319
Automatic time setting 63	Bracket, flag 333
Automatic transmission, see Steptronic trans-	Brake assistant 223
mission 153	Brake assistant, adaptive 223
Automatic unlocking 109	Brake Controller 339
Automating routines, BMW Intelligent Personal	Brake discs, see Brake system 330
Assistant 55	Brake-in 330
AUTO program, automatic climate control 289	Brake pads, see Brake system 330
AUTO program, intensity 290	Brake system 330
Auto Start/Stop function 141	Braking, information 332
Average consumption, see Trip data 175	Breakdown assistance 398
Axle loads, approved 413	Breaking in 330
	Break recommendation, see Fatigue alert 221
В	Brightness, Control Display 65
	Button, central locking system 98
Backrest curvature, see Lumbar support 119	Button, Hill Descent Control HDC 227
Backrest, seats 117	Buttons on the steering wheel 32

Button, SOS, see Intelligent emergency call 400	Car wash 406
Button, Start/Stop 141	Car wash, automatic 406
Bypassing, see Jump-starting 401	Catalytic converter, see Hot exhaust gas sys-
	tem 331
C	CBS Condition Based Service 391
	Cell phone, see Owner's Manual for Navigation,
Cable for tow-starting/towing 404	Entertainment and Communication 6
Calendar day, see Date 63	Center armrest, front 318
California Proposition 65 Warning 8	Center armrest, rear 318
Call, gesture control 57	Center console 34
Camera-based assistance systems, see Intelli-	Central Information Display (CID), see Control
gent Safety 191	Display 47
Camera instrument cluster, see Driver Attention	Central locking switch, see Central locking sys-
Camera 64	tem 98
Camera lenses, care 409	Central locking system 98
Camera, rearview camera, see Surround	Central screen, see Control Display 47
View 269	Changes, technical, see For Your Own Safety 8
Camera, rearview camera, without Surround	Change, wheels and tires 357
View 259	Changing parts 393
Camera, see Surround View 269	Changing wheels 375
Cameras, see Sensors of the vehicle 37	Charging smartphone, see Wireless charging
CANCEL button, Active Cruise Control 234	tray 312
CANCEL button, cruise control 232	Charging tray for smartphones, see Wireless
Can holder, front, see Cup holder, front 318	charging tray 312
Can holder, rear, see Cup holder, rear 319	Chassis/suspension, electronic, see Adaptive M
Care 406	chassis/suspension 286
Care, Head-up Display 409	Chassis number, see Vehicle identification num
Care, light-alloy wheels 408	ber 12
Care of displays, screens 409	Check Control 162
Care, vehicle 407	Checking the engine oil level electronically 386
Cargo 321	Children, seating position 135
Cargo area 321	Children, transporting safely 135
Cargo area, enlarging 324	Child restraint systems, mounting 136
Cargo cover 326	Child restraint systems, see Transporting chil-
Cargo cover electric 327	dren safely 135
Cargo, stowing and securing 322	Child safety locks 140
Cargo straps, see Lashing eyes in the cargo	Child seat, mounting 136
area 322	Child seat mountings LATCH 138
Caring Car, BMW Intelligent Personal Assis-	Child seats, see Transporting children
tant 56	safely 135
Car key, see Vehicle key 82	Chrome-plated surfaces, care 408
Carpet, care 409	Chrome surfaces, care 408
CarPlay, connection to the vehicle 79	Cigarette lighter 309
Car seats, see Transporting children safely 135	Cigarette lighter, front 309
Cartridge replacement, see Ambient air pack-	Cigarette lighter, rear 310
age 301	Cleaning displays, screens 409

Cleaning, Head-up Display 409	Control Display 47
Clearance, water 332	Control Display, brightness 65
Climate control 287	Control display, pop-ups 65
Climate control rules 134	Controller 48
Closing with the Key Card 91	Control systems, driving stability 223
Closing with the smartphone, see BMW Digital	Convenient closing, vehicle key 84
Key 93	Convenient opening, vehicle key 83
Clothes hooks 320	Coolant 388
Coasting 343	Coolant level 389
Coasting with engine decoupled, see Coast-	Coolant temperature, see Engine tempera-
ing 343	ture 170
Coasting with idling engine 343	Cooling, maximum 289
Combination switch, see Turn signals 149	Cooling system 388
Combination switch, see Washer/wiper sys-	Cornering light 182
tem 150	Corrosion on brake discs 333
Comfort Access 98	Cosmetic mirror 308
COMFORT, see Driving Dynamics Control 144	Cross-country mobility, see xOffroad pack-
Communication, see Owner's Manual for Naviga-	age 283
tion, Entertainment and Communication 6	Cross traffic warning 277
Compact wheel, see Emergency wheel 379	Cruise control 232
Comparison of entries, see Entry comparison 45	Cruise control, active with Stop&Go func-
Compartments in the doors 317	tion 234
Compatible devices, see Suitable devices 74	Cruise control, see Active Cruise Control 234
Compressor 361	Cruise control with distance control, see Active
Concierge Service, see Owner's Handbook for	Cruise Control with Stop&Go function 234
Navigation, Entertainment, Communication 6	Cruise control without distance control, see
Condensation water under the parked vehi-	Cruise control 232
cle 333	Cruising range 171
Condensation, windshield 292	Cup holder, front 318
Condition Based Service CBS 391	Cup holder, rear 319
Confirmation signal from the vehicle 108	Cup holder, third row of seats 320
Connect device 73	Current consumption 161
ConnectedDrive, see Owner's Manual for Navi-	Customer service, see Owner's Manual for Navi-
gation, Entertainment and Communication 6	gation, Entertainment, Communication 6
Connecting electrical devices, see Sockets 310	
Connecting, mobile devices 73	D
Connections, Screen Mirroring 78	
Consumption display, ECO PRO 343	Damage, tires 356
Consumption display, widget in the instrument	Damping control active, see Adaptive M chassis/
cluster 161	suspension 286
Consumption, see Current consumption 161	Dashboard 32
Consumption, see Trip data 175	Dashboard, see Instrument cluster 159
Contacts, see Owner's Handbook for Navigation,	Dashcam, see BMW Drive Recorder 218
Entertainment, Communication 6	Data memory 10
Container for washer fluid 389	Data protection, settings 68
Continued driving with a flat tire 371, 374	Data, see Deleting personal data 68

Data, technical 412	Drive-off assistant, see DSC 223
Date 63	Drive power reduced, see Heavily discharged
Daytime driving lights 181	high-voltage battery 169
Daytime running lights 181	Driver activity, see Driver Attention Camera 64
DCC, see Cruise control 232	Driver assistance, driving, see Intelligent
Defrosting, see Defrosting windshield 292	Safety 191
Defrosting, windshield 292	Driver assistance, parking, see Parking assis-
Deleting personal data 68	tance systems 253
Departure schedule, see Pre-ventilation 296	Driver assistance, see Intelligent Safety 191
Departure time, pre-conditioning 300	Driver assistance systems 230
Departure time, pre-ventilation 297	Driver Attention Camera 64
Destination input 6	Drive readiness, see Operating condition of the
Device list 74	vehicle 41
Diagnosis connection 392	Drive-ready state, engine start 42
Differential lock 226	Driver Fatigue Alert, see Driver Attention Cam-
Digital Key 93	era 64
Digital Key, see BMW Digital Key 93	Driver profiles 69
Dimensions 412	Driver profile, setup 69
Dimmable exterior mirrors 129	Driver profiles, welcome screen 69
Dimmable interior mirror 129	Driving 141
Direct dial buttons, see Programmable memory	Driving Assistant, see Intelligent Safety 191
buttons 46	Driving comfort 280, 285
Direction indicator, see Turn signals 149	Driving Dynamics Control 144
Display, iDrive 44	Driving instructions, breaking in 330
Display in the windshield, see Head-up Dis-	Driving mode, ECO PRO 341
play 177	Driving mode, see Driving Dynamics Con-
Display key 87	trol 144
Display key, malfunction 90	Driving notes, general 331
Display key, see BMW display key 87	Driving on bad roads 330
Display lighting, see Instrument lighting 184	Driving out of parking space 266
Display, notifications, BMW Intelligent Personal	Driving stability control systems 223
Assistant 66	Driving, Start/Stop button 141
Display panel, see Instrument cluster 159	Driving style analysis, ECO PRO 345
Displays 159	Driving through water 332
Displays and symbols 7	Driving tips 331
Displays, ECO PRO 341	DSC Dynamic Stability Control 223
Display speed limit, see Speed Limit Info 172	DTC Dynamic Traction Control 225
Disposal, coolant 389	Dynamic damping, see Adaptive chassis 285
Disposal, vehicle battery 396	Dynamic damping, see Adaptive M chassis/
Distance control, see PDC 254	suspension 286
Door handle lighting, see Welcome lights 181	Dynamic Stability Control 223
Door opening angle, Surround View 270	Dynamic Stability Control DSC 223
Downhill control, see Hill Descent Control HDC 227	Dynamic Traction Control DTC 225
Drawbar nose weight, technical data 414	
Drive-off assistant 223	

ECO PRO 341
ECO PRO, bonus range 343
ECO PRO, driving style analysis 345
ECO PRO INDIVIDUAL, see Driving Dynamics
Control 144
ECO PRO, see Driving Dynamics Control 144
Efficiency display, widget in the instrument clus-
ter 161
Efficient4x4, see xDrive 225
Electronic oil measurement 386
Electronic Stability Program ESP, see DSC 223
E-mail, see Owner's Handbook for Navigation,
Entertainment, Communication 6
Emergency brake function when parking, Active
PDC 257
Emergency brake, see Emergency stop assis-
tant 217
Emergency braking, see PostCrash - iBrake 221
Emergency call 400
Emergency service, see BMW Accident Assis-
tance 400
Emergency service, see BMW Roadside Assis-
tance 399
Emergency stop assistant 217
Emergency unlocking, fuel filler flap 347
Emergency unlocking, rear seat backrest 123
Emergency unlocking, transmission lock 157
Emergency wheel 379
Energy recovery 161
Energy savings, see Gear shift indicator 172
Engine, automatic Start/Stop function 141
Engine compartment 381
Engine coolant 388
Engine idling when driving, see Coasting 343
Engine oil, adding 386
Engine oil change 388
Engine oil filler neck 386
Engine oil temperature 170
Engine oil types to add 387
Engine start, see Drive-ready state 42
Engine start, see Jump-starting 401
Engine storping, see Drive-ready state 42
Engine temperature 170
Engine temperature 170

for Navigation, Entertainment, Communication 6 Entering an address, navigation, see Owner's Manual for Navigation, Entertainment and Communication 6 Entertainment, see Owner's Manual for Navigation, Entertainment and Communication 6 Entertainment, selection list in the instrument cluster 174 Entry comparison 45 Equipment, interior 305 Error indicators, see Check Control 162 ESP Electronic Stability Program, see DSC 223 Evasion Assistant 195 Exchange, wheels and tires 357 Exhaust gas system 331 Exhaustion warner 221 Exhaust, see Exhaust gas system 331 Experience Modes, BMW Intelligent Personal Assistant 55 Exterior lighting during unlocking 83 Exterior lighting with the vehicle locked 84 Exterior mirror, Automatic Curb Monitor 129 Exterior mirror, automatic dimming feature 129 Exterior mirrors 128 Exterior mirrors, malfunction 128 External start, see Jump-starting 401 Eyelet for towing 404 Eyes, see Lashing eyes in the cargo area 322 F Factory settings, see reset vehicle data 65 Failure message, see Check Control 162 Fan, see Air flow 291 Fastening safety belts, see Safety belts 123 Fatique alert 221 Fault indicators, see Check Control 162 Filler neck for engine oil 386 Filter, see Interior filter 287 Fine wood parts, care 408 First-aid kit 398

First Steps, see Setup Wizard 69

Flag bracket 333

Fittings for trailer safety chain, trailer towing 339

Entering a destination, see Owner's Handbook

Flat tire, changing wheels 375	Fuel recommendation 384
Flat tire, continued driving 371, 374	Fuel tank, see Filling capacity 416
Flat tire, Flat Tire Monitor TPM 373	Fuses 396
Flat tire message, FTM 373	
Flat tire message, Tire Pressure Monitor 369	G
Flat Tire Monitor TPM 373	
Flat tire, repairing 360	Garage door opener, see Integrated Universal
Flat tire, see Tire Pressure Monitor 366	Remote Control 305
Flat tire warning light, FTM 373	Gasoline 384
Flat tire warning light, see Tire Pressure Moni-	Gasoline guality 385
tor 369	Gear change, Steptronic transmission 153
Flooding, driving through 332	Gear shift indicator 172
Floor carpet, care 409	General driving notes 331
Floor mats, care 409	General settings 63
Fold-away position, wiper 152	Gentleman function, see Front passenger seat
Foot brake 332	
Forward collision mitigation, see Intelligent	functionality 120 Gesture Control 56
Safety 191	Gesture Control 56  Gestures, see BMW Gesture Control 56
For Your Own Safety 8	Glare shield, see Sun visor 308
Fragrance cartridge, see Ambient air pack-	Glass sunroof, electric 114
age 301	
Fragrance, see Ambient air package 301	Glass sunroof, initialize the system 116 Glopal Positioning System, navigation 6
Fragrancing, see Ambient air package 301	
Front airbags 187	Glove compartment 316
Front collision mitigation 192	G-meter, widget in the instrument cluster 161
Front collision mitigation, see Forward Collision	GPS, navigation, see Owner's Handbook for
Warning 192	Navigation, Entertainment, Communication 6
Front collision mitigation, see Intersection Colli-	Gross vehicle weight, approved 413 Gross vehicle weight, trailer mode 414
sion Warning 197	<u> </u>
Front collision mitigation, see Pedestrian Warn-	Ground clearance, see xOffroad package 283
ing 201	11
Front fog lights, replacing, see Lights and	н
bulbs 394	
Front lights, replacing, see Lights and bulbs 394	Handbrake, see Parking brake 146
Front passenger airbags 190	Hand-held transmitter, alternating code 306
Front passenger airbags, automatic deactiva-	Hands-free device, see Owner's Handbook for
tion 190	Navigation, Entertainment, Communication 6
Front passenger seat functionality 120	Hazard warning system 398
Front-seat passenger airbags, indicator light 190	HDC Hill Descent Control 227
Front seats 117	Head airbag 188
Fuel 384	Headlight control, automatic 179
Fuel cap 346	Headlight flasher 150
Fuel filler flap 346	Headlight glass 394
Fuel filler flap, unlocking manually 347	Headlights, care 407
Fuel gauge 168	Headlights, replacing, see Lights and bulbs 394
Fuel quality 384	Head restraint pillow 128
i del quality 304	Head restraints and seats 117

Head restraints, front 125	Inflation pressure, tires 348
Head restraints, rear 127	Inflation pressure warning TPM, tires 373
Head-up Display 177	Information 6
Head-up Display, care 409	Initialization, Flat Tire Monitor FTM 373
Head-up Display, store position, see Memory	Input, iDrive 44
function 130	Instrument cluster 159
Heated steering wheel 130	Instrument lighting 184
Heavy cargo, stowing 322	Instrument panel, see Instrument cluster 159
Height, vehicle 412	Integral Active Steering 228
High-beam Assistant 182	Integrated key 97
High beams 150	Integrated Owner's Manual in the vehicle 14
High beams/low beams, see High-beam Assis-	Integrated Universal Remote Control 305
tant 182	Intelligent emergency call 400
Hill Descent Control HDC 227	Intelligent Personal Assistant 52
Hills 333	Intelligent Safety 191
Hill start assistant, see Drive-off assistant 223	Intended use 8
Holder for beverages, front 318	Intensity, AUTO program 290
Holder for beverages, rear 319	Interior equipment 305
HomeLink, see Integrated Universal Remote	Interior filter 287
Control 305	Interior lights 184
Homepage, see Internet 6	Interior lights during unlocking 83
Hood 382	Interior lights with the vehicle locked 84
Horn 32	Interior mirror, automatic dimming feature 129
Hotel function, see Valet parking mode 107	Interior mirrors 129
Hot exhaust gas system 331	Interior motion sensor 111
Hour, see Time 63	Internet hotspot 77
Humidity in the headlight, see Headlight	Internet page 6
glass 394	Intersection collision warning 197
	Interval indicator, see Service notifications 171
I	Ionization, see Ambient air package 301
'D   D   O   L 004	
iBrake - PostCrash 221	J
Ice, see Outside temperature 170	1 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2
Ice warning, see Outside temperature 170	Jacking points for the vehicle jack 378
Identification marks, tires 354	Jam protection system, glass sunroof 115
Identification number, see Vehicle identification	Jam protection system, windows 113
number 12	Joystick, Steptronic transmission 153
iDrive 44	Jump-starting 401
ID transmitter, see Vehicle key 82	Jump-starting terminals 402
Ignition key, see Vehicle key 82	17
Indicator light, front-seat passenger airbags 190	K
Indicator lights 163	
Individual air distribution 291	Kenaf, care 408
Individual settings, see Driver profiles 69	Key Card 91
Inductive charging, smartphone, see Wireless	Keyless Go, see Comfort Access 98
charging tray 312	Key, mechanical 97

Key, see BMW display key 87	Loading 321
Key, see Vehicle key 82	Loading the cargo area, see Stowing cargo 322
Kickdown, Steptronic transmission 153	Local time, see Time 63
Knee airbag 188	Lock control elements, rear automatic climate control 296
L	Locking, automatic 109
	Locking, see Opening and Closing 82
Label on recommended tires 358	Locking, settings 108
Lane change assistant 250	Locking, vehicle key 84
Lane control assistant with active side collision	Lock, lug bolts 377
protection, see Side collision mitigation 213	Loudspeaker lighting, see Bowers & Wilkins 186
Lane departure warning 207	Low beams, automatic, see High-beam Assis-
Lane lines, Surround View 270	tant 182
Lane threshold, warning 207	Low beams, operation 180
Language, setting 64	Lower back support, see Lumbar support 119
Laser headlights, replacing, see Lights and	Lower tailgate 105
bulbs 394	Lug bolt lock 377
Laser high beams 184	Luggage rack, see Roof-mounted luggage
Lashing eyes in the cargo area 322	rack 334
LATCH child seat mountings 138	Lumbar support 119
Launch Control 158	
Leather care 408	M
LED headlights, replacing, see Lights and	
bulbs 394	Maintenance 391
LED light carpet, see Welcome light 181	Maintenance recommendations 391
Length, vehicle 412	Maintenance recommendations, see Condition
Letters and numbers, entering 45	Based Service CBS 391
Light-alloy wheels, care 408	Maintenance, see Service notifications 171
Light control, adaptive 182	Maintenance system, BMW 391
Lighter, cigarettes 309	Make-up mirror 308
Lighting 179	Malfunction, BMW display key 90
Lighting, loudspeaker, see Bowers & Wil-	Malfunction, vehicle key 86
kins 186	Managing devices 74
Light in the exterior mirror, see Active Blind Spot Detection 210	Manual brake, see Parking brake 146 Manual control, air distribution 291
Light in the exterior mirror, see Cross traffic warning 277	Manual control, air flow 291 Manual mode, Steptronic transmission 153
Light replacement, see Lights and bulbs 394	Manual operation, fuel filler flap 347
Lights 179	Manual Speed Limiter 230
Lights and bulbs 394	Map update, see Owner's Handbook for Naviga-
Light switch 179	tion, Entertainment, Communication 6
LIM button, see Manual Speed Limiter 230	Marking, run-flat tire 359
List, instrument cluster, see Selection lists 174	Massage seat, front 131
List of all messages 66	Matt paint, care 408
List of all notifications 66	Maximum cooling 289
Load 322	

Maximum speed, display, see Speed Limit Info 172	N
Maximum speed, winter tires 359	Navigation, see Owner's Manual for Navigation,
M chassis/suspension, adaptive, see Adaptive M	Entertainment and Communication 6
chassis/suspension 286	Neck restraints, front, see Head restraints
Media of the Owner's Manual 14	front 125
Medical supplies, see First-aid kit 398	Neck restraints, rear, see Head restraints
Memory function 130	rear 127
Menu, instrument cluster, see Selection lists 174	Net, cargo area 323
	Neutral cleaner, see Light-alloy wheels, care 408
Menus, operating, iDrive 44	Night Vision device, see Night Vision 203
Messages 66	Night Vision with pedestrian and animal detec-
Messages, see Check Control 162	tion 203
Meters, see Instrument cluster 159	Notifications 66
Mild Hybrid technology 206	No-touch opening and closing of the tail-
Mild Hybrid technology 396	gate 101
Minimum tread depth, tires 356	Nylon rope for tow-starting/towing 404
Mobile communication devices in the vehi- cle 332	
	0
Mobile devices, managing 74 Mobile phone, connecting 73	
Mobile phone, see Owner's Manual for Naviga-	OBD Onboard Diagnosis 392
tion, Entertainment and Communication 6	OBD, see OBD Onboard Diagnosis 392
Mobile Service, see BMW Accident Assis-	Object detection, see Night Vision 203
tance 400	Obstacle marking, rearview camera 260
Mobile Service, see BMW Roadside Assis-	Obstacle marking, Surround View 270
tance 399	Octane number, see Gasoline quality 385
Mobility System, see Tire repair set 360	Odometer, see Trip data 175
MODE button, see Active Cruise Control 234	Oil, adding 386
Mode, ECO PRO 341	Oil change 388
Modifications, technical, see For Your Own	Oil filler neck 386
Safety 8	Oil level, checking electronically 386
Monitor, see Control Display 47	Oil service interval, see Service notifications 171
Mount for trailer hitch, care 409	Oil types to add, engine 387
Mounting for trailer hitch 338	Old battery 396
Mounting of child restraint systems 136	Onboard literature, printed 14
MP3 player, see Owner's Manual for Navigation,	Onboard vehicle tool kit 393
Entertainment, Communication 6	On-call service, see BMW Accident Assis-
M Sport differential, active 226	tance 400
Multifunction hook 323	On-call service, see BMW Roadside Assis-
Multifunction steering wheel, buttons 32	tance 399
Multimedia, see Owner's Manual for Navigation,	Opening and closing 82
Entertainment and Communication 6	Opening with the Key Card 91
	Opening with the smartphone, see BMW Digital Key 93
	Operating concept, iDrive 44
	Operating condition of the vehicle 41

Operation via voice 52	Performance Control 286
Optional equipment, see Vehicle equipment 7	Personal Assistant 52
Outside air, see Automatic Recirculating Air Con-	Personal data, deleting 68
trol 290	Personal profile, see Driver profiles 69
Outside temperature 170	Personal settings 68
Overheating of the engine, see Engine tempera-	Phone, connecting 73
ture 170	Physical units, see Set units of measurement 64
Overwintering, see Long-term vehicle stor-	Pillow for head restraints in the rear 128
age 410	Plastic parts, care 409
Owner's Manual, printed 14	Pop-ups, control display 65
Owner's Manual via voice operation, BMW Intelli-	Possible gestures, gesture control 57
gent Personal Assistant 54	PostCrash - iBrake 221
general contractions of	Power Display, instrument cluster 169
P	Power failure 395
•	Power gauge, see Sport displays 176
Paint, car care 407	Power Meter, see Power Display 169
Pair device 73	Power windows 112
Pairing, mobile devices, see Connections 73	Pre-conditioning 298
Panic alarm, see Panic mode 111	Pressure test tire, see Tire Pressure Moni-
Panic mode 111	tor 366
Panorama View 274	Pressure, tires 348
	Pre-ventilation 296
Panoramic glass sunroof, see Glass sunroof 114 Park Distance Control PDC 254	Printed onboard literature 14
	Profiles, see Driver profiles 69
Parking aid, see PDC 254  Parking assistance systems 252	Programmable memory buttons, iDrive 46
Parking assistance systems 253	Protective function, glass sunroof, see Jam pro-
Parking assistant 262 Parking Assistant, driving out of parking	tection system 115
space 266	Protective function, windows, see Jam protec-
Parking Assistant for driving out of parking	tion system 113
space 266	Push-and-turn reel, see Controller 48
Parking assistant Plus, see Surround View 269	
Parking Assistant Flus, see Surround view 205  Parking Assistant, see Automatic Parking Assis-	Q
tant 262	4
Parking, Automatic Hold, see Parking brake 146	Queuing Assistant, see Assisted Driving
Parking brake 146	Plus 248
Parking lights 180	1100 240
Parts and accessories 8	R
Passenger's side exterior mirror, tilt down, see	IX.
Automatic Curb Monitor 129	Racing track 334
Pathway lighting 181	Radar sensors, see Sensors of the vehicle 37
Pathway lighting, switching on 85	Radiator fluid 388
Pathway lines, rearview camera 260	Radio, see Owner's Manual for Navigation, En-
Payload, technical data 413	tertainment and Communication 6
PDC Park Distance Control 254	Rain sensor 151
Pedestrian detection, see Night Vision 203	Rear automatic climate control 294
Pedestrian Warning with braking function 201	Thear addomatic climate control 234

Rear automatic climate control, lock control ele-	RES CNCL button, Active Cruise Control
ments 296	ACC 234
Rear axle steering, see Integral Active Steering 228	RES CNCL button, cruise control 232 Reserve warning, see Range 171
Rear-end collision preparation 216	Reset settings, vehicle 65
Rear-end collision warning, see Rear-end collision preparation 216	Reset, Tire Pressure Monitor 368 Reset, vehicle data 65
Rear lights, replacing, see Lights and bulbs 394	Reset, vehicle settings 65
Rear seat backrests, folding down 324	Restricted Driving, see BMW Digital Key 93
Rear seat backrest tilt 121	RESUME button, Active Cruise Control 234
Rear seats 120	RESUME button, cruise control 232
Rear ventilation, third row of seats, ventilation,	Retreaded tires 358
third row of seats 293	Reversing Assistant 267
Rearview camera, see Surround View 269	Roadside parking lights 180
Rearview camera, without Surround View 259	Roller sunblinds, rear side windows 114
Rear-view mirrors, exterior 128	Rolling code hand-held transmitter 306
Rear-view mirrors, interior 129	RON, gasoline quality 385
Rear window defroster 292	Roofliner 36
Rear window wiper, operation 152	Roof-mounted luggage rack 334
Recirculated-air filter, see Microfilter/activated-	Rope for tow-starting/towing 404
charcoal filter 292	Route, navigation, see Owner's Handbook for
Recirculated-air mode 291	Navigation, Entertainment, Communication 6
Recommended tire brands 358	RSC Runflat System, see Runflat tire 359
Reduced drive power, see Heavily discharged	RTTI, see Owner's Handbook for Navigation, En-
high-voltage battery 169	tertainment, Communication 6
Refueling 346	Rubber components, care 408
Remote 3D View 276	Run-flat tire 359
Remote control for audio, see Owner's Hand-	
book for Navigation, Entertainment, Communication 6	S
Remote control, see Vehicle key 82	Safe braking 332
Remote control, universal 305	Safe Share function, see BMW Digital Key 93
Remote Engine Start, see Stationary climate control 298	Safety belt reminder for driver's seat and front passenger seat 124
Remote services, app, see Owner's Handbook for Navigation, Entertainment, Communica- tion 6	Safety belt reminder for the rear seats 125 Safety belts 123 Safety belts, care 409
Remote Software Upgrade 59	Safety locks, doors, and windows 140
Removable ball head 338	Safety package, see Active Protection 220
Renewal, wheels and tires 357	Safety switch, windows 113
Replacement, wheels and tires 357	Safety systems, see Airbags 187
Replacing bulbs, see Lights and bulbs 394	Safety systems, see Intelligent Safety 191
Replacing light diodes, see Lights and bulbs 394	Saving fuel 340
Replacing parts 393	Screen Mirroring, connection 78
Replacing the battery, vehicle key 85	Screen, see Control Display 47
Reporting safety malfunctions 13	Sealing compound, see Tire repair set 360

Seat and armrest heating 132	Side parking aid without Surround View 258
Seat heating 132	Side protection aid, Surround View, see Side
Seat heating, climate control rules 134	parking aid 270
Seating position for children 135	Side protection aid without Surround View, see
Seats and head restraints 117	Side parking aid 258
Seats, front 117	Signaling, horn 32
Seats, rear 120	Signals when unlocking, see Confirmation sig-
Seat ventilation, climate control rules 134	nals from the vehicle 108
Securing, cargo 322	Sitting safely 117
Selection list in the instrument cluster 174	Sleep mode, see Operating condition of the ve-
Selector lever, Steptronic transmission 153	hicle 41
Self-leveling suspension, see Two-axle ride level	Slide/tilt glass roof, see Glass sunroof 114
control 280	Slipperiness, see Outside temperature 170
Self-supporting tires, see Run-flat tires 359	Slippery road, see Outside temperature 170
Sensors, care 409	Smallest turning circle, vehicle 412
Sensors of the vehicle 37	Smartphone, connecting 73
Service and warranty 9	Smartphone Integration, Android Auto prepara-
Service Center, see BMW Accident Assis-	tion 79
tance 400	Smartphone Integration, Apple CarPlay prepara-
Service Center, see BMW Roadside Assis-	tion 79
tance 399	Smartphone, see Owner's Manual for Navigation,
Service notifications 171	Entertainment and Communication 6
Service notifications, see Condition Based Serv-	Smartphone, using via voice control 55
ice CBS 391	Smoker's package 308
Services, ConnectedDrive, see Owner's Manual	SMS, see Short messages, see Owner's Hand-
for Navigation, Entertainment and Communica-	book for Navigation, Entertainment, Communi-
tion 6	cation 6
SET button, Active Cruise Control 234	Socket for OBD Onboard Diagnosis 392
SET button, cruise control 232	Sockets, electrical devices 310
Set clock 63	Soft-close automatic, doors 106
Set day, see Date 63	Software Update, see Remote Software Up-
Set speed, see Active Cruise Control with	grade 59
Stop&Go function 234	Software Upgrade, see Remote Software Up-
Set system language, see Language 64	grade 59
Set time, see Time 63	SOS button, see Intelligent emergency call 400
Setting, Control Display 65	Sound output, see Owner's Handbook for Navi-
Settings, general 63	gation, Entertainment, Communication 6
Settings, locking/unlocking 108	Spare tire, see Emergency wheel 379
Settings, seats and head restraints 117	Speech recognition 52
Setup Wizard 69	Speed Limit Assist 242
Shift lights 169	Speed Limit Assistant 242
Shift paddles on the steering wheel 153	Speed Limit Device, Speed Limiter 230
Shift point indicator, tachometer 169	Speed limit display, see Speed Limit Info 172
Side airbag 187	Speed Limit Info 172
Side collision mitigation 213	Speed warning 65
Side parking aid, Surround View 270	

Sport chassis/suspension, see Adaptive M chas-	Store Mirror position, see Memory function 130
sis/suspension 286	Store seat position, see Memory function 130
Sport displays 176	Store steering wheel position, see Memory func-
SPORT INDIVIDUAL, see Driving Dynamics	tion 130
Control 144	Storing the vehicle 410
SPORT PLUS, see Driving Dynamics Con-	Stowing, cargo 322
trol 144	Straps for cargo, see Lashing eyes in the cargo
Sport program, Steptronic transmission 153	area 322
SPORT, see Driving Dynamics Control 144	Suitable devices 74
Sport suspension, see Adaptive M suspension	Suitable mobile phones 74
Professional 286	Summer tires, tread 356
Stability control systems 223	Sun visor 308
Standard equipment, see Vehicle equipment 7	Sun visor, sliding 308
Standby, see Operating condition of the vehi-	Supplementary Owner's Manuals 14
cle 41	Surface heating, see Seat and armrest heat-
Start/stop, automatic function 141	ing 132
Start/Stop button 141	Surround View 269
Starting aid terminals 402	Surround View, gesture control 57
Starting, see Drive-ready state 42	Suspension settings, see Driving Dynamics Con-
Starting the engine, see Drive-ready state 42	trol 144
Starting the engine with the Key Card 91	Swinging of trailer, see Trailer stabilization con-
Stationary climate control via Remote Engine	trol 338
Start 298	Switches, see Dashboard 32
Stations, AM/FM, see Owner's Handbook for	Switch for driving dynamics, see Driving Dynam-
Navigation, Entertainment, Communication 6	ics Control 144
Status control display, tires 367	Symbols and displays 7
Status information, iDrive 45	SYNC program, automatic climate control 291
Status of Owner's Manual 7	System settings, see General settings 63
Status, vehicle 176	
Steering and Lane Control Assistant 244	T
Steering Assistant, see Steering and Lane Con-	
trol Assistant 244	Tachometer 168
Steering column adjustment 129	Tailgate, automatic 104
Steering, see Integral Active Steering 228	Tailgate, opening and closing with no-touch acti-
Steering wheel, adjusting 129	vation 101
Steering wheel, buttons 32	Tailgate, vehicle key 84
Steering wheel heating 130	Tail lights, replacing, see Lights and bulbs 394
Steptronic Sport transmission, see Steptronic	Taking the vehicle out of service 410
transmission 153	Tank capacity 416
Steptronic transmission 153	Technical changes, see For Your Own Safety 8
Stopping the engine, see Drive-ready state 42	Technical data 412
Storage compartment, cargo area 323	Telephone, see Owner's Manual for Navigation,
Storage compartment, center console 317	Entertainment and Communication 6
Storage compartments 316	Telephone, selection list in the instrument clus-
Storage compartments, locations 316	ter 174
Storage, tires 359	

Teleservices, see Owner's Handbook for Navigation, Entertainment, Communication 6 Temperature, automatic climate control 288 Temperature display electric motor, see Sport displays 176 Temperature display, see outside temperature 170 Temperature, engine oil 170 Theft alarm system, see Alarm system 110 Thermal camera, see Night Vision 203 Thigh support 118 Third row of seats 122 Tilt alarm sensor 111 Tilt, backrest 118	Tow bar 404 Tow fitting 404 Towing 402 Tow rope 404 Tow-starting 402 TPM Flat Tire Monitor 373 Traction control 225 TRACTION, driving dynamics 225 Traffic bulletins, see Owner's Handbook for Navigation, Entertainment, Communication 6 Traffic Jam Assistant, see Assisted Driving Plus 248 Traffic jam assistant, see Steering and Lane Control Assistant 244
Tilt down, passenger's side exterior mirror, see Automatic Curb Monitor 129 Time 63 Time of day, see Time 63	Trailer hitch, care 409 Trailer hitch, removable ball head 338 Trailer hitch, view of rearview camera 260 Trailer hitch, view of Surround View 270
Time setting, automatic 63 Tire brands, recommended 358	Trailer loads 414 Trailer stabilization control 338
Tire chains 365 Tire change 357	Trailer towing 336 Trailer towing, activation 338
Tire damage 356 Tire identification marks 354	Trailer towing, technical data 414 Transmission lock, electronic unlocking 157
Tire inflation pressure 348 Tire inflation pressure monitoring, see TPM 373 Tire inflation pressure monitor TPM 373	Transmission, see Steptronic transmission 153 Transporting children safely 135 Travel & Comfort System 315
Tire marking 354 Tire pressure 348	Tread, tires 356 Trip computer, see Trip data 175
Tire Pressure Monitor 366 Tire Pressure Monitor, reset 368	Trip data 175 Triple turn signal activation 149
Tire repair set 360 Tires and wheels 348	Trip odometer, see Trip data 175 Trunk, see Cargo area 321
Tire sealant, see Tire repair set 360 Tire settings 366 Tires, run-flat 359	Turning circle lines, rearview camera 260 Turning circle line, Surround View 270 Turning circle, vehicle 412
Tire tread 356 Title, gesture control 57	Turn signal, indicator light 166 Turn signal, replacing bulbs, see Lights and
Tone, see Owner's Manual for Navigation, Entertainment and Communication 6 Tools 393	bulbs 394 Turn signals, high beams, headlight flasher 149 Two-axle ride level control 280
Top View, see Surround View 269 Torque indicator electric motor, see Sport displays 176	U
Torque indicator, see Sport displays 176	Ultrasonic sensors, see Sensors of the vehi-

Touchpad, Controller 50

cle **37** 

Ultrasonic sensors, see Sensors of the vehi-

Unintentional alarm, avoiding 112	Vehicle paint, care 407
Units of measurement 64	Vehicle status 176
Units, see Set units of measurement 64	Vehicle storage 410
Universal remote control 305	Vehicle washing 406
Unlock button, Steptronic transmission 153	Ventilation 292
Unlocking, automatic 109	Ventilation, see Pre-ventilation 296
Unlocking, see Opening and Closing 82	Venting, see Ventilation 292
Unlocking, settings 108	Vent, see Ventilation 292
Unlocking, vehicle key 83	Version Software, see Remote Software Up-
Unpaved roads, cross-country trips 330	grade 59
Unwarranted alarm, see Avoiding unintentional	Video recording, see BMW Drive Recorder 218
alarms 112	Video, see Owner's Manual for Navigation, En-
Updates made after the editorial deadline 7	tertainment and Communication 6
Upgrade, see Remote Software Upgrade 59	VIN, see Vehicle identification number 12
Upholstery material care 408	Voice command response 52
Upper backrest, front 119	Voice control 52
Upper retaining strap, top tether 139	Voice control, gesture control 57
USB connection 80	Voice control, see BMW Intelligent Personal As-
USB port, position in vehicle 311	sistant 52
Used battery, disposing of 396	Voice control system 52
Use, intended 8	Volume, gesture control 57
V	W
Valet parking mode 107	Wake word 53
Valet parking mode 107	Wake word 53 Warning against cross traffic 277
Vanity mirror 308	Warning against cross traffic 277
Vanity mirror 308 Variable steering, see Integral Active Steer-	Warning against cross traffic 277 Warning function, rear-end collision 216
Vanity mirror 308 Variable steering, see Integral Active Steering 228	Warning against cross traffic 277 Warning function, rear-end collision 216 Warning light in the exterior mirror, see Active
Vanity mirror 308 Variable steering, see Integral Active Steering 228 Vehicle battery 394	Warning against cross traffic 277 Warning function, rear-end collision 216 Warning light in the exterior mirror, see Active Blind Spot Detection 210
Vanity mirror 308 Variable steering, see Integral Active Steering 228 Vehicle battery 394 Vehicle breakdown, see Breakdown assis-	Warning against cross traffic 277 Warning function, rear-end collision 216 Warning light in the exterior mirror, see Active Blind Spot Detection 210 Warning light in the exterior mirror, see Cross
Vanity mirror 308 Variable steering, see Integral Active Steering 228 Vehicle battery 394 Vehicle breakdown, see Breakdown assistance 398	Warning against cross traffic 277 Warning function, rear-end collision 216 Warning light in the exterior mirror, see Active Blind Spot Detection 210 Warning light in the exterior mirror, see Cross traffic warning 277
Vanity mirror 308 Variable steering, see Integral Active Steering 228 Vehicle battery 394 Vehicle breakdown, see Breakdown assistance 398 Vehicle, breaking in 330	Warning against cross traffic 277 Warning function, rear-end collision 216 Warning light in the exterior mirror, see Active Blind Spot Detection 210 Warning light in the exterior mirror, see Cross traffic warning 277 Warning lights 163
Vanity mirror 308 Variable steering, see Integral Active Steering 228 Vehicle battery 394 Vehicle breakdown, see Breakdown assistance 398 Vehicle, breaking in 330 Vehicle care 407	Warning against cross traffic 277 Warning function, rear-end collision 216 Warning light in the exterior mirror, see Active Blind Spot Detection 210 Warning light in the exterior mirror, see Cross traffic warning 277 Warning lights 163 Warning messages, see Check Control 162
Vanity mirror 308 Variable steering, see Integral Active Steering 228 Vehicle battery 394 Vehicle breakdown, see Breakdown assistance 398 Vehicle, breaking in 330 Vehicle care 407 Vehicle care products 407	Warning against cross traffic 277 Warning function, rear-end collision 216 Warning light in the exterior mirror, see Active Blind Spot Detection 210 Warning light in the exterior mirror, see Cross traffic warning 277 Warning lights 163 Warning messages, see Check Control 162 Warning triangle 398
Vanity mirror 308 Variable steering, see Integral Active Steering 228 Vehicle battery 394 Vehicle breakdown, see Breakdown assistance 398 Vehicle, breaking in 330 Vehicle care 407 Vehicle care products 407 Vehicle data, reset 65	Warning against cross traffic 277 Warning function, rear-end collision 216 Warning light in the exterior mirror, see Active Blind Spot Detection 210 Warning light in the exterior mirror, see Cross traffic warning 277 Warning lights 163 Warning messages, see Check Control 162 Warning triangle 398 Warranty 8
Vanity mirror 308 Variable steering, see Integral Active Steering 228 Vehicle battery 394 Vehicle breakdown, see Breakdown assistance 398 Vehicle, breaking in 330 Vehicle care 407 Vehicle care products 407 Vehicle data, reset 65 Vehicle equipment 7	Warning against cross traffic 277 Warning function, rear-end collision 216 Warning light in the exterior mirror, see Active Blind Spot Detection 210 Warning light in the exterior mirror, see Cross traffic warning 277 Warning lights 163 Warning messages, see Check Control 162 Warning triangle 398 Warranty 8 Warranty Booklet 8
Vanity mirror 308 Variable steering, see Integral Active Steering 228 Vehicle battery 394 Vehicle breakdown, see Breakdown assistance 398 Vehicle, breaking in 330 Vehicle care 407 Vehicle care products 407 Vehicle data, reset 65 Vehicle equipment 7 Vehicle identification number 12	Warning against cross traffic 277 Warning function, rear-end collision 216 Warning light in the exterior mirror, see Active Blind Spot Detection 210 Warning light in the exterior mirror, see Cross traffic warning 277 Warning lights 163 Warning messages, see Check Control 162 Warning triangle 398 Warranty 8 Warranty Booklet 8 Washer fluid 389
Vanity mirror 308 Variable steering, see Integral Active Steering 228 Vehicle battery 394 Vehicle breakdown, see Breakdown assistance 398 Vehicle, breaking in 330 Vehicle care 407 Vehicle care products 407 Vehicle data, reset 65 Vehicle equipment 7 Vehicle identification number 12 Vehicle key 82	Warning against cross traffic 277 Warning function, rear-end collision 216 Warning light in the exterior mirror, see Active Blind Spot Detection 210 Warning light in the exterior mirror, see Cross traffic warning 277 Warning lights 163 Warning messages, see Check Control 162 Warning triangle 398 Warranty 8 Warranty 8 Warranty Booklet 8 Washer fluid 389 Washer nozzles, windshield 152
Vanity mirror 308 Variable steering, see Integral Active Steering 228 Vehicle battery 394 Vehicle breakdown, see Breakdown assistance 398 Vehicle, breaking in 330 Vehicle care 407 Vehicle care products 407 Vehicle data, reset 65 Vehicle equipment 7 Vehicle identification number 12 Vehicle key 82 Vehicle key, additional 86	Warning against cross traffic 277 Warning function, rear-end collision 216 Warning light in the exterior mirror, see Active Blind Spot Detection 210 Warning light in the exterior mirror, see Cross traffic warning 277 Warning lights 163 Warning messages, see Check Control 162 Warning triangle 398 Warranty 8 Warranty 8 Warranty Booklet 8 Washer fluid 389 Washer nozzles, windshield 152 Washer system 150
Vanity mirror 308 Variable steering, see Integral Active Steering 228 Vehicle battery 394 Vehicle breakdown, see Breakdown assistance 398 Vehicle, breaking in 330 Vehicle care 407 Vehicle care products 407 Vehicle data, reset 65 Vehicle equipment 7 Vehicle identification number 12 Vehicle key 82 Vehicle key, additional 86 Vehicle key, integrated key 97	Warning against cross traffic 277 Warning function, rear-end collision 216 Warning light in the exterior mirror, see Active Blind Spot Detection 210 Warning light in the exterior mirror, see Cross traffic warning 277 Warning lights 163 Warning messages, see Check Control 162 Warning triangle 398 Warranty 8 Warranty Booklet 8 Washer fluid 389 Washer nozzles, windshield 152 Washing the vehicle 406
Vanity mirror 308 Variable steering, see Integral Active Steering 228 Vehicle battery 394 Vehicle breakdown, see Breakdown assistance 398 Vehicle, breaking in 330 Vehicle care 407 Vehicle care products 407 Vehicle data, reset 65 Vehicle equipment 7 Vehicle identification number 12 Vehicle key 82 Vehicle key, additional 86 Vehicle key, integrated key 97 Vehicle key, loss 86	Warning against cross traffic 277 Warning function, rear-end collision 216 Warning light in the exterior mirror, see Active Blind Spot Detection 210 Warning light in the exterior mirror, see Cross traffic warning 277 Warning lights 163 Warning messages, see Check Control 162 Warning triangle 398 Warranty 8 Warranty Booklet 8 Washer fluid 389 Washer nozzles, windshield 152 Washing the vehicle 406 Washing, vehicle 406
Vanity mirror 308 Variable steering, see Integral Active Steering 228 Vehicle battery 394 Vehicle breakdown, see Breakdown assistance 398 Vehicle, breaking in 330 Vehicle care 407 Vehicle care products 407 Vehicle data, reset 65 Vehicle equipment 7 Vehicle identification number 12 Vehicle key 82 Vehicle key, additional 86 Vehicle key, integrated key 97 Vehicle key, loss 86 Vehicle key, malfunction 86	Warning against cross traffic 277 Warning function, rear-end collision 216 Warning light in the exterior mirror, see Active Blind Spot Detection 210 Warning light in the exterior mirror, see Cross traffic warning 277 Warning lights 163 Warning messages, see Check Control 162 Warning triangle 398 Warranty 8 Warranty Booklet 8 Washer fluid 389 Washer nozzles, windshield 152 Washer system 150 Washing the vehicle 406 Washing, vehicle 406 Wash view, Surround View 270
Vanity mirror 308 Variable steering, see Integral Active Steering 228 Vehicle battery 394 Vehicle breakdown, see Breakdown assistance 398 Vehicle, breaking in 330 Vehicle care 407 Vehicle care products 407 Vehicle data, reset 65 Vehicle equipment 7 Vehicle identification number 12 Vehicle key 82 Vehicle key, additional 86 Vehicle key, integrated key 97 Vehicle key, loss 86 Vehicle key, malfunction 86 Vehicle key, replacing the battery 85	Warning against cross traffic 277 Warning function, rear-end collision 216 Warning light in the exterior mirror, see Active Blind Spot Detection 210 Warning light in the exterior mirror, see Cross traffic warning 277 Warning lights 163 Warning messages, see Check Control 162 Warning triangle 398 Warranty 8 Warranty Booklet 8 Washer fluid 389 Washer nozzles, windshield 152 Washer system 150 Washing the vehicle 406 Washing, vehicle 406 Wash view, Surround View 270 Water on roads 332
Vanity mirror 308 Variable steering, see Integral Active Steering 228 Vehicle battery 394 Vehicle breakdown, see Breakdown assistance 398 Vehicle, breaking in 330 Vehicle care 407 Vehicle care products 407 Vehicle data, reset 65 Vehicle equipment 7 Vehicle identification number 12 Vehicle key 82 Vehicle key, additional 86 Vehicle key, integrated key 97 Vehicle key, loss 86 Vehicle key, malfunction 86 Vehicle key, replacing the battery 85 Vehicle key with display, malfunction 90	Warning against cross traffic 277 Warning function, rear-end collision 216 Warning light in the exterior mirror, see Active Blind Spot Detection 210 Warning light in the exterior mirror, see Cross traffic warning 277 Warning lights 163 Warning messages, see Check Control 162 Warning triangle 398 Warranty 8 Warranty Booklet 8 Washer fluid 389 Washer nozzles, windshield 152 Washer system 150 Washing the vehicle 406 Washing, vehicle 406 Wash view, Surround View 270 Water on roads 332 Water, see Condensation water under the parked
Vanity mirror 308 Variable steering, see Integral Active Steering 228 Vehicle battery 394 Vehicle breakdown, see Breakdown assistance 398 Vehicle, breaking in 330 Vehicle care 407 Vehicle care products 407 Vehicle data, reset 65 Vehicle equipment 7 Vehicle identification number 12 Vehicle key, additional 86 Vehicle key, integrated key 97 Vehicle key, integrated key 97 Vehicle key, malfunction 86 Vehicle key, replacing the battery 85 Vehicle key with display, malfunction 90 Vehicle key with display, see BMW display	Warning against cross traffic 277 Warning function, rear-end collision 216 Warning light in the exterior mirror, see Active Blind Spot Detection 210 Warning light in the exterior mirror, see Cross traffic warning 277 Warning lights 163 Warning messages, see Check Control 162 Warning triangle 398 Warranty 8 Warranty Booklet 8 Washer fluid 389 Washer nozzles, windshield 152 Washer system 150 Washing the vehicle 406 Washing, vehicle 406 Wash view, Surround View 270 Water on roads 332 Water, see Condensation water under the parked vehicle 333
Vanity mirror 308 Variable steering, see Integral Active Steering 228 Vehicle battery 394 Vehicle breakdown, see Breakdown assistance 398 Vehicle, breaking in 330 Vehicle care 407 Vehicle care products 407 Vehicle data, reset 65 Vehicle equipment 7 Vehicle identification number 12 Vehicle key 82 Vehicle key, additional 86 Vehicle key, integrated key 97 Vehicle key, loss 86 Vehicle key, malfunction 86 Vehicle key, replacing the battery 85 Vehicle key with display, malfunction 90	Warning against cross traffic 277 Warning function, rear-end collision 216 Warning light in the exterior mirror, see Active Blind Spot Detection 210 Warning light in the exterior mirror, see Cross traffic warning 277 Warning lights 163 Warning messages, see Check Control 162 Warning triangle 398 Warranty 8 Warranty Booklet 8 Washer fluid 389 Washer nozzles, windshield 152 Washer system 150 Washing the vehicle 406 Washing, vehicle 406 Wash view, Surround View 270 Water on roads 332 Water, see Condensation water under the parked

Weights 413
Welcome light during unlocking 83
Welcome lights 181
Welcome screen, driver profiles 69
Wheel base, vehicle 412
Wheels and tires 348
Wheels and tires, exchange 357
Widgets, iDrive 45
Widgets, instrument cluster 161
Width, vehicle 412
Wi-Fi connection 77
WiFi connection, see WLAN connection 77
Wi-Fi hotspot 77
Window, defrosting 292
Windows, powered 112
Windshield, defrosting 292
Windshield washer fluid, see Washer fluid 389
Windshield washer nozzles 152
Windshield wiper, see Wiper system 150
Winter storage, see Long-term vehicle stor-
age 410
Winter tires 358
Winter tires, tread 356
Wiper blades, replacing 393
Wiper fluid, see Washer fluid 389
Wiper, fold-away position 152
Wiper, see Washer/wiper system 150
Wiper system 150
Wireless charging, smartphone, see Wireless charging tray 312
Wireless charging tray for smartphones 312
WLAN connection 77
Wood parts, care 408
Wordmatch principle, see Entry comparison 45
Wrench, see Onboard vehicle tool kit 393
X
xDrive 225



xOffroad package 283



01405A37D22 ue

# California Proposition 65 Warning

For vehicles sold in California:

## **California Proposition 65 Warning**



#### WARNING

Operating, servicing and maintaining a passenger vehicle or off-highway motor vehicle can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle in a well-ventilated area and wear gloves or wash your hands frequently when servicing your vehicle. For more information go to www.P65Warnings.ca.gov/passenger-vehicle.

