#### **TABLE OF CONTENTS**

ina column.

manual.

Before driving

For owners

Index

When driving Driving, stopping and safe-driving information. Interior fea-Air conditioning and audio systems, as well as other interior features for a comfortable driving experience. tures Maintenance Cleaning and protecting your vehicle, performing do-itand care yourself maintenance, and maintenance information. When trouble What to do if the vehicle needs to be towed, gets a flat arises tire, or is involved in an accident. Vehicle Detailed vehicle information. specifications

Information on the hybrid system and adjusting and op-

erating features such as door locks, mirrors, and steer-

Reporting safety defects for U.S. owners, and seat belt

and SRS airbag instructions for Canadian owners

Alphabetical listing of information contained in this

1 Before driving		<del> </del>	1-7. Theft deterrent system Immobilizer system	
1-1.	Hybrid system Hybrid system		-8.	Safety information  Correct driving posture
1-2.	Key information Keys	35		Front passenger occupant classification system 104 Child restraint systems 109
1-3.	Opening, closing and locking the doors	_		Installing child restraints 113
	Smart key system Wireless remote control	48	2	When driving
	Trunk		2-1.	<b>Driving procedures</b> Driving the vehicle 124
1-4.	Adjustable components (seats, mirrors, steering wheel) Front seats			Power (ignition) switch
	Head restraints  Seat belts  Steering wheel  Anti-glare inside rear view mirror  Outside rear view mirrors	64 <b>2</b> 72 73	2-2.	Instrument cluster Gauges and meters
1-5.	Opening and closing the windows	2	2-3.	Operating the lights and wipers
	Power windows  Moon roof			Headlight switch
1-6.	<b>Refueling</b> Opening the fuel tank cap	83		washer 159

	systems		audio system
	Cruise control161		Bluetooth® audio system 242
	Driving assist systems 165		Using the Bluetooth®
			audio system 245
2-5.	Driving information		Operating a Bluetooth®
	Cargo and luggage 169		enabled portable player 250
	Vehicle load limits 172		Setting up a Bluetooth®
	Winter driving tips 173		enabled portable player 252 Bluetooth <sup>®</sup> audio system
	Trailer towing 177		setup 257
	Dinghy towing 178		Setup 237
		3-4.	Using the hands-free
3	Interior features		phone system
			(for cellular phone)
	_		Hands-free phone system
3-1.	Using the air conditioning		(for cellular phone)
	system and defogger		features
	Automatic air conditioning		Using the hands-free phone system
	system 182		(for cellular phone) 262
	Rear window and		Making a phone call 270
	outside rear view		Setting a cellular phone 274
	mirror defoggers 191		Security and system
3-2	Using the audio system		setup 279
<i>-</i> .	Audio system types 192		Using the phone book 283
	Using the radio 195		3 1
	Using the CD player 202	3-5.	Using the interior lights
	Playing MP3 and WMA		Interior lights list 291
	discs 210		• Interior light 292
	Operating an iPod 218		• Personal lights
	Operating a USB		
	memory 225	3-6.	Using the storage features
	Optimal use of the audio		List of storage features 294
	system 232		• Glove box
	Using the AUX port 237		• Console box
	Using the steering wheel		• Cup holders
	audio switches 239		/ taxillary 50x03

2-4. Using other driving

3-3. Using the Bluetooth®

3-7.	Other interior features		4-3.	Do-it-yourself maintenance	
	Sun visors	301		Do-it-yourself service	
	Vanity mirrors	302		precautions 33	35
	Clock	303		Hood 33	38
	Ashtray	304		Positioning a floor jack 33	39
	Power outlet			Engine compartment 34	41
	Seat heaters			12-volt battery 39	50
	Armrest	309		Tires 38	54
	Floor mat	310		Tire inflation pressure 30	63
	Trunk features			Wheels 30	67
	Garage door opener			Air conditioning filter 30	69
	Compass			Key battery 3	72
	Соттрасо	0.0		Checking and replacing	
				fuses 3	75
4	Maintenance and care			Light bulbs 38	85
4-1.	Maintenance and care		5	When trouble arises	
	Cleaning and protecting				
	the vehicle exterior	324			
	Cleaning and protecting		5-1.	Essential information	
	the vehicle interior	326		Emergency flashers 39	92
				If your vehicle needs to be	
4-2.	Maintenance			towed 39	93
	Maintenance			If you think something is	00
	requirements			wrong 39	
	General maintenance	331		Event data recorder 39	97
	Emission inspection and maintenance (I/M) programs	334			
	1 0	-			

5-2.	Steps to take in an
	emergency
	If a warning light turns
	on or a warning buzzer
	sounds 399
	If a warning message is
	displayed 408
	If you have a flat tire 419
	If the hybrid system will
	not start 429
	If the shift lever cannot
	be shifted from P 431
	If you lose your keys 432
	If the electronic key does
	not operate properly 433
	If the vehicle's 12-volt
	battery is discharged 436
	If your vehicle overheats 440
	If the vehicle becomes
	stuck 444
	If your vehicle has to be
	stopped in an
	emergency 446
6	Vehicle specifications
6-1.	Specifications
	Maintenance data
	(fuel, oil level, etc.) 450
	Fuel information
	Tire information
	The information 402
6-2.	Customization
	Customizable features 474
6-3.	Initialization
	Items to initialize 477

## 7 For owners


Reporting safety defects for U.S. owners	480
Seat belt instructions	
for Canadian owners	
(in French)	481
SRS airbag instructions	
for Canadian owners	
(in French)	484


## Index

Abbreviation list	496
Alphabetical index	497
What to do if	506

## **Pictorial index**


#### **Exterior**






## **Pictorial index**


#### Interior






\*: If equipped

#### Interior







\*: If equipped

## Pictorial index

#### Instrument panel




Air conditioning system P. 182




Rear window defogger switch/ Rear window defogger switch and outside rear view mirror defogger switch \* P. 191

\*: If equipped
\*1: Refer to "Navigation System Owner's Manual".

## Instrument panel





\*: If equipped
\*1: Refer to "Navigation System Owner's Manual".

#### For your information

#### Main Owner's Manual

Please note that this manual covers all models and all equipment, including options. Therefore, you may find some explanations for equipment not installed on your vehicle.

All specifications provided in this manual are current at the time of printing. However, because of the Toyota policy of continual product improvement, we reserve the right to make changes at any time without notice.

Depending on specifications, the vehicle shown in the illustrations may differ from your vehicle in terms of equipment.

#### Noise from under vehicle after turning off the hybrid system

Approximately five hours after the hybrid system is turned off, you may hear sound coming from under the vehicle for several minutes. This is the sound of a fuel evaporation leakage check and it does not indicate a malfunction.

#### Accessories, spare parts and modification of your Toyota

A wide variety of non-genuine spare parts and accessories for Toyota vehicles are currently available on the market. You should know that these parts are not covered by Toyota warranty and that Toyota is not responsible for their performance, repair, or replacement, or for any damage they may cause to, or adverse effect they may have on, your Toyota vehicle.

This vehicle should not be modified with non-genuine Toyota products. Modification with non-genuine Toyota products could affect its performance, safety or durability, and may even violate governmental regulations. In addition, damage or performance problems resulting from the modification may not be covered under warranty.

### Installation of a mobile two-way radio system

As the installation of a mobile two-way radio system in your vehicle may affect electronic systems such as the multi-port fuel injection system/sequential multi-port fuel injection system, cruise control system, anti-lock brake system, SRS airbag system or seat belt pretensioner system, be sure to check with your Toyota dealer for precautionary measures or special instructions regarding installation.

Despite their electromagnetic shielding high voltage parts and cables on hybrid vehicles emit approximately the same amount of electromagnetic waves as conventional gasoline powered vehicles or home electronic appliances.

Unwanted noise may occur in the reception of the mobile two-way radio.

#### **Scrapping your Toyota**

The SRS airbag and seat belt pretensioner devices in your Toyota contain explosive chemicals. If the vehicle is scrapped with the airbags and seat belt pretensioners left as they are, this may cause an accident such as fire. Be sure to have the systems of the SRS airbag and seat belt pretensioner removed and disposed of by a qualified service shop or by your Toyota dealer before you scrap your vehicle.

#### **Perchlorate Material**

Special handling may apply, See www.dtsc.ca.gov/hazardouswaste/perchlorate.

Your vehicle has components that may contain perchlorate. These components may include airbags, seat belt pretensioners, and wireless remote control batteries.

## **A** CAUTION

#### General precautions while driving

Driving under the influence: Never drive your vehicle when under the influence of alcohol or drugs that have impaired your ability to operate your vehicle. Alcohol and certain drugs delay reaction time, impair judgment and reduce coordination, which could lead to an accident that could result in death or serious injury.

Defensive driving: Always drive defensively. Anticipate mistakes that other drivers or pedestrians might make and be ready to avoid accidents.

Driver distraction: Always give your full attention to driving. Anything that distracts the driver, such as adjusting controls, talking on a cellular phone or reading can result in a collision causing death or serious injury to you, your occupants or others.

#### General precaution regarding children's safety

Never leave children unattended in the vehicle, and never allow children to have or use the key.

Children may be able to start the vehicle or shift the vehicle into neutral. There is also a danger that children may injure themselves by playing with the cigarette lighter, the windows, or other features of the vehicle. In addition, heat build-up or extremely cold temperatures inside the vehicle can be fatal to children.

## **A** CAUTION

#### ■ Disposal of the hybrid battery (traction battery)

If your vehicle is disposed of without the hybrid battery having been removed, there is a danger of serious electric shock if high voltage parts, cables and their connectors are touched. In the event that your vehicle must be disposed of, the hybrid battery must be disposed of by your Toyota dealer or a qualified service shop. If the hybrid battery is not disposed of properly, it may cause electric shock that can result in death or serious injury.

## Symbols used throughout this manual

#### Cautions & Notices



#### **A** CAUTION

This is a warning against anything which may cause death or injury to people if the warning is ignored. You are informed about what you must or must not do in order to reduce the risk of injury to yourself and others.



#### NOTICE


This is a warning against anything which may cause damage to the vehicle or its equipment if the warning is ignored. You are informed about what you must or must not do in order to avoid or reduce the risk of damage to your Toyota and its equipment.

## Symbols used in illustrations



#### Safety symbol

The symbol of a circle with a slash through it means "Do not", "Do not do this", or "Do not let this happen".



## Arrows indicating operations

- Indicates the action (pushing, turning, etc.) used to operate switches and other devices.
- Indicates the outcome of an operation (e.g. a lid opens).

## **Before driving**


1

1-1.	Hybrid system	22	1-5.	Opening and closing the windows	
				Power windows	77
1-2.	Key information			Moon roof	79
	Keys	35			
			1-6.	Refueling	
1-3.	Opening, closing and locking the doors			Opening the fuel tank cap	83
	Smart key system	37			
	Wireless remote control	48	1-7.	Theft deterrent system	
	Doors	51		Immobilizer system	88
	Trunk	55	4.0		
			1-8.	Safety information	
1-4.	Adjustable components (seats, mirrors,			Correct driving posture SRS airbags	
	steering wheel)	50		Front passenger occupant classification system	 104
	Front seats			Child restraint systems	
	Rear seats			Installing child	103
	Head restraints			restraints	 113
	Seat belts				
	Steering wheel	72			
	Anti-glare inside rear view mirror	73			
	Outside rear view	75_			
	mirrors	75			

## **Hybrid system**

Your vehicle is a hybrid vehicle. It has characteristics different from conventional vehicles. Be sure you are closely familiar with the characteristics of your vehicle, and operate with care.

The hybrid system combines a gasoline engine and an electric motor (traction motor) according to driving conditions, improving fuel efficiency and reducing exhaust emissions.



- Gasoline engine
- Electric motor (traction motor)
- When stopped/during take-off

The gasoline engine stops when the vehicle is stopped. During take-off, the electric motor (traction motor) drives the vehicle. At slow speeds or when traveling down a gentle slope, the engine is stopped and the motor is used.

#### ■ During normal driving

The gasoline engine is predominantly used. The electric motor (traction motor) charges the hybrid battery as necessary.

#### ■ When accelerating sharply

The power of the hybrid battery (traction battery) is added via the electric motor (traction motor) to that of the gasoline engine.

## ■ When braking (regenerative braking)

The electric motor (traction motor) charges the hybrid battery (traction battery).

#### ■ Regenerative braking

The electric motor converts kinetic energy to electric energy when:

- The accelerator pedal is released.
- The brake pedal is depressed with the shift lever in D or R.

### ■ Conditions in which the gasoline engine may not stop

The gasoline engine starts and stops automatically. However, it may not stop automatically in the following conditions:

- During gasoline engine warm-up
- During hybrid battery (traction battery) charging
- During low or high hybrid battery (traction battery) temperature

#### ■ Charging the battery

- As the gasoline engine charges the hybrid battery (traction battery), the battery does not need to be charged from an outside source. However, if the vehicle is left parked for a long time the hybrid battery will slowly discharge. For this reason, be sure to drive the vehicle at least once every several months for at least 30 minutes or 10 miles (16 km). If the hybrid battery becomes fully discharged, you are unable to jump-start the vehicle with the 12-volt battery, contact your Toyota dealer.
- If the shift lever is in N, the hybrid battery (traction battery) will not be charged. When driving in heavy traffic, operate the vehicle with the shift lever in D to avoid discharging the battery.

• To help prevent the 12-volt battery from becoming discharged, drive the vehicle at least once a month, and operate the accessories only when the "READY" indicator is on. When parking the vehicle, make sure the doors and trunk are closed and all lights are turned off.

#### After the 12-volt battery has discharged or has been changed or removed

The gasoline engine may not stop even if the vehicle is running on the hybrid battery (traction battery). If this continues for a few days, contact your Toyota dealer.

#### ■ Sounds and vibrations specific to a hybrid vehicle

There may be no engine sounds or vibration even though the vehicle is able to move. Always put the shift lever in P when parked.


The following sounds or vibrations may occur when the hybrid system is operating, and are not a malfunction:

- Motor sounds may be heard from the engine compartment.
- Sounds may be heard from the hybrid battery (traction battery) behind the rear seat when the hybrid system starts or stops.
- Sounds may be heard from the transaxle when the hybrid system starts or stops, or while the vehicle is idling.
- Engine sounds may be heard when accelerating sharply.
- Sounds may be heard due to the regenerative braking when you press the brake pedal.
- Vibration may be felt when the gasoline engine starts or stops.
- Cooling fan sounds may be heard from the air intake vents behind the rear seat.

### ■ Maintenance, repair, recycling, and disposal

Contact your Toyota dealer regarding maintenance, repair, recycling and disposal. Do not dispose of the vehicle yourself.


## High voltage components



- Air conditioning compressor
- 2 Power control unit
- High voltage cables
- 4 Hybrid battery (traction battery) and DC/DC converter
- Electric motor (traction motor) and transaxle
- 6 Caution label

Take care when handling the hybrid system, as it contains a high voltage system (about 650V at maximum) as well as parts that become extremely hot when the hybrid system is operating. Obey the caution labels attached to the vehicle.

#### ■ Hybrid battery air vent




There is an air intake vent on the package tray for the purpose of cooling the hybrid battery (traction battery). If the vent becomes blocked, the hybrid battery may overheat, leading to a reduction in hybrid battery output.

#### **Emergency shut off system**

The emergency shut off system blocks off the high voltage current and stops the fuel pump to minimize the risk of electrocution and fuel leakage when a certain level of impact is detected by the impact sensor. If the emergency shut off system activates, your vehicle will not restart. To restart the hybrid system, contact your Toyota dealer.

#### Energy monitor/consumption/past record screen




You can view the status of your hybrid system on the multi-information display ( $\rightarrow$ P. 150) and the navigation system screen\* ( $\rightarrow$ P. 27, 29).

The following images are examples only, and may vary slightly from actual conditions.


\*: Vehicles with Navigation System

#### **■** Energy monitor

• How to display on the navigation system screen (if equipped):



Press "INFO".




Touch "Fuel Consumption" on the "Information" screen.

If the "Consumption" or "Past Record" screen is displayed, touch [Energy].

• How to display on the multi-information display:


Press the "DISP" switch on the steering wheel several times to select the energy monitor display.




## 1-1. Hybrid system

	Navigation system screen	Multi-information display
When the vehicle is powered by both the gasoline engine and the electric motor (traction motor)	Energy Monitor  BATTERY  BATTERY  SECOND MOTOR  Consumption Past Record	<b>⊕</b> (111111111111111111111111111111111111
When the vehicle is powered by the gasoline engine	Energy Monitor  BATTERY  BELEGIED MOTOR  Consumption  Past Record	<b>8</b>
When the vehicle is charging the hybrid battery (traction battery)	Energy Monitor  BATTERY  BATTERY  Consumption  Past Record	<b>₩</b> 000 237 miles
When there is no energy flow	Energy Monitor  BATTERY  BATTERY  Consumption Past Record	<b>⊕</b> □ <del>+</del> ODO 237 miles
Hybrid battery (traction bat- tery) status	Low Full	Low Full

#### ■ Consumption (navigation system only)




Press "INFO".




Touch "Fuel Consumption" on the "Information" screen.

If the "Energy Monitor" or "Past Record" screen is displayed, touch Consumption.




- **1** Fuel consumption in the past 30 minutes
- Regenerated energy in the past 30 minutesOne symbol indicates 50 Wh. Up to 4 symbols are shown.
- Cruising range

#### ■ Past Record (navigation system only)




Press "INFO".



Touch "Fuel Consumption" on the "Information" screen.

If the "Energy Monitor" or "Consumption" screen is displayed, touch Past Record.




- Average fuel consumption
- 2 Best fuel economy among average

#### ■ Resetting the consumption data

Touching Clear will reset the fuel consumption or past record.

#### Hybrid warning message

A message is automatically displayed when a malfunction occurs in the hybrid system or an improper operation is attempted.



If a warning message is shown on the multi-information display, read the message and follow the instructions. ( $\rightarrow$ P. 408)

# ■If a warning light comes on or a warning message is displayed, or the 12-volt battery has been disconnected

The hybrid system may not start. In that case, try to start the system again. If the "READY" indicator does not come on, contact your Toyota dealer.

#### ■ When refueling, the fuel filler door may take a few moments to open

As part of emission system operation, it may take up to 10 seconds for the fuel filler door to automatically release after the opener switch is pressed. Before refueling is possible, a message will be shown on the multi-information display. ( $\rightarrow$ P. 83)

#### ■ Running out of fuel

When the vehicle has run out of fuel and the hybrid system cannot be started, refuel the vehicle with at least enough gasoline to make the low fuel level warning light (→P. 402) go off. If there is only a small amount of fuel, the hybrid system may not be able to start. (The minimum amount of fuel to add to make the low fuel level warning light go out is about 2.5 gal. [9.8 L, 2.1 Imp. gal.], when the vehicle is on a level surface. This value may vary when the vehicle is on a slope.)

#### ■ Hybrid battery (traction battery)


The hybrid battery (traction battery) has a limited service life. The lifespan of the hybrid battery (traction battery) can change in accordance with driving style and driving conditions.

#### **A** CAUTION

#### High voltage precautions

The vehicle has high voltage DC and AC systems as well as a 12-volt system. DC and AC high voltage is very dangerous and can cause severe burns and electric shock that may result in death or serious injury.

- Never touch, disassemble, remove or replace the high voltage parts, cables and their connectors.
- The hybrid system will become hot after starting as the system uses high voltage. Be careful of both the high voltage and the high temperature, and always obey the caution labels attached to the vehicle.



Never try to open the service plug access hole located in the luggage compartment. The service plug is used only when the vehicle is serviced and is subject to high voltage.

## **A** CAUTION

#### Road accident cautions

Observe the following precautions to reduce the risk of injury.

- Pull your vehicle off the road, put the shift lever in P, apply the parking brake, and turn the hybrid system off.
- Do not touch the high voltage parts, cables and connectors.
- If electric wires are exposed inside or outside your vehicle, an electric shock may occur. Never touch exposed electric wires.
- If a fluid leak occurs, do not touch it as it may be strong alkaline electrolyte from the hybrid battery (traction battery). If it comes into contact with your skin or eyes, wash it off immediately with a large amount of water or if possible, boric acid solution. Seek immediate medical attention.
- If a fire occurs in the hybrid vehicle, leave the vehicle as soon as possible. Never use a fire extinguisher that is not meant for electric fires. Using even a small amount of water may be dangerous.
- If your vehicle needs to be towed, do so with the front wheels raised. If the wheels with the electric motor (traction motor) are on the ground when towing, the motor may continue to generate electricity. This may cause an electricity leakage leading to a fire. (→P. 393)

#### Nickel-metal hydride battery

Your vehicle contains a sealed nickel-metal hydride battery. If disposed of improperly, it is hazardous to the environment and there is a risk of severe burns and electrical shock that may result in death or serious injury.

#### ■ If the system activates

- Carefully check to see if there are exposed high voltage parts or cables.
   Never touch the parts or cables. (→P. 25)
- Carefully inspect the ground under the vehicle. If you find that liquid has leaked onto the ground, the fuel system may have been damaged. Leave the vehicle as soon as possible.




#### **NOTICE**

#### Hybrid battery air vent


- Do not put foreign objects over the air vent. The hybrid battery (traction battery) may overheat and be damaged.
- Clean the air vent regularly to prevent the hybrid battery (traction battery) from overheating.
- Do not wet the air vent. It may cause a short circuit and damage the hybrid battery (traction battery).
- Do not load a large amount of water such as water cooler bottles into the vehicle. If water spills over the hybrid battery (traction battery), the battery may be damaged.

#### The following keys are provided with the vehicle.



- Electronic keys
  - Operating the smart key system (→P. 37)
  - Operating the wireless remote control function (→P. 48)
- Mechanical keys
- 3 Key number plate

#### Using the mechanical key



Take out the mechanical key.

After using the mechanical key, store it in the electronic key. Carry the mechanical key together with the electronic key. If the electronic key battery is depleted or the entry function does not operate properly, you will need the mechanical key. (→P. 433)

#### ■ When required to leave a key to the vehicle with a parking attendant

Lock the glove box as circumstances demand. Set the luggage security system. ( $\rightarrow$ P. 55, 295)

Remove the mechanical key for your own use and provide the attendant with the electronic key only.

#### ■ Key number plate

Keep the plate in a safe place such as your wallet, not in the vehicle. In the event that a key is lost, a new key can be made by your Toyota dealer using the key number plate. ( $\rightarrow$ P. 432)

#### ■When riding in an aircraft

When bringing an electronic key onto an aircraft, make sure you do not press any buttons on the electronic key while inside the aircraft cabin. If you are carrying an electronic key in your bag etc, ensure that the buttons are not likely to be pressed accidentally. Pressing a button may cause the electronic key to emit radio waves that could interfere with the operation of the aircraft

## A


#### NOTICE

#### ■ To prevent key damage

- Do not subject the keys to strong shocks, expose them to high temperatures by placing them in direct sunlight, or get them wet.
- Do not expose the keys to electromagnetic materials or attach any material that blocks electromagnetic waves to the key surface.
- Do not disassemble the electronic key.


# 1-3. Opening, closing and locking the doors Smart key system

The following operations can be performed simply by carrying the electronic key on your person, for example in your pocket. (The driver should always carry the electronic key.)



- Locks and unlocks the doors (→P. 38)
- **2** Unlocks the trunk ( $\rightarrow$ P. 38)
- 3 Starts and stops the hybrid system (→P. 135)


# Unlocking and locking the doors (front door handles only)



Grip the handle to unlock the door.


Make sure to touch the sensor on the back of the handle.

The door cannot be unlocked for 3 seconds after the door is locked.



Press the lock button to lock the door.


# Unlocking the trunk



Press the button to unlock the trunk.


# Antenna location and effective range


### ■ Antenna location



- 1 Antennas outside the cabin
- 2 Antenna outside the trunk
- 3 Antenna inside the trunk
- 4 Antennas inside the cabin

# ■ Effective range (areas within which the electronic key is detected)





The system can be operated when the electronic key is within about 2.3 ft. (0.7 m) of either of the outside front door handles. (Only the doors detecting the key can be operated.)

When starting the hybrid system or changing "POWER" switch modes

The system can be operated when the electronic key is inside the vehicle.

When unlocking the trunk

The system can be operated when the electronic key is within about 2.3 ft. (0.7 m) of the trunk release button.

#### **■** Operation signals

A buzzer sounds and the emergency flashers flash to indicate that the doors have been locked/unlocked. (Locked: Once; Unlocked: Twice)

#### ■ Conditions affecting operation

The smart key system uses weak radio waves. In the following situations, the communication between the electronic key and the vehicle may be affected, preventing the smart key system and wireless remote control from operating properly. (Ways of coping: →P. 433)

- When the electronic key battery is depleted
- Near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
- When carrying a portable radio, cellular phone, cordless phone or other wireless communication devices
- When the electronic key has come into contact with, or is covered by, a metallic object
- When multiple electronic keys are in the vicinity
- When carrying or using the electronic key together with the following devices that emit radio waves
  - Another vehicle's electronic key
  - A wireless key that emits radio waves
  - Personal computer
- If window tint with a metallic content or metallic objects are attached to the rear window

# ■ Switching the door unlock function

It is possible to set which doors the entry function unlocks.

STEP 1 Turn the "POWER" switch OFF.

When the indicator on the key surface is off, press and hold , , or ((i) for approximately 5 seconds while pressing on the key.

The setting changes each time an operation is performed, as shown below. (When changing the setting continuously, release the buttons, wait for at least 5 seconds, and repeat step 2.)

Multi-information display	Unlocking doors	Веер
18	Hold the driver's door handle to unlock only the driver's door.	Exterior: Beeps three
	Hold the front passenger's door handle to unlock all doors	Interior: Pings once
<b>4</b>	Hold either front door han- dle to unlock all doors	Exterior: Beeps twice Interior: Pings once

#### ■ Battery-saving function

In the following circumstances, the entry function is disabled in order to prevent the 12-volt battery from discharging and the electronic key battery from depleting.

- When the entry function has not been used for 2 weeks or more
- When the electronic key has been left within approximately 7 ft. (2 m) of the vehicle for 10 minutes or more

The system will resume operation when...

- The vehicle is locked using the door handle lock switch.
- The vehicle is locked/unlocked using the wireless remote control function. (→P. 48)
- The vehicle is locked/unlocked using the mechanical key. (→P. 433)

#### ■ Electronic key battery depletion

- The standard battery life is 1 to 2 years. (The battery becomes depleted even if the electronic key is not used.) If the smart key system or the wireless remote control function does not operate, or the detection area becomes smaller, the battery may be depleted. Replace the battery when necessary. (→P. 372)
- If the battery becomes low, an alarm will sound in the cabin when the hybrid system stops. (→P. 415)
- To avoid serious deterioration, do not leave the electronic key within 3 ft. (1 m) of the following electrical appliances that produce a magnetic field.
  - TVs
  - Personal computers
  - Recharging cellular phones or cordless phones
  - · Table lamps

#### ■ To operate the system properly

Make sure to carry the electronic key when operating the system. Do not get the electronic key too close to the vehicle when operating the system from the outside of the vehicle.

Depending on the position and holding condition of the electronic key, the key may not be detected correctly and the system may not operate properly. (The alarm may go off accidentally, or the door lock prevention may not function.)

# ■ Note for the smart key system

- Even when the electronic key is within the effective range (detection areas), the system may not operate properly in the following cases.
  - The electronic key is too close to the window or outside door handle, near the ground, or in a high place when the doors are locked or unlocked.
  - The electronic key is near the ground or in a high place, or too close to the rear bumper center when the trunk is unlocked.
  - The electronic key is on the instrument panel, package tray, floor, or in the auxiliary box of the driver's side instrument panel or glove box when the hybrid system is started or the "POWER" switch modes are changed.

- As long as the electronic key is within the effective range, the doors may be locked or unlocked by anyone.
- Even if the electronic key is not inside the vehicle, it may be possible to start the hybrid system if the electronic key is near the window.
- The doors may unlock if a large amount of water splashes on the door handle, such as in the rain or in a car wash. (The doors will automatically be locked after approximately 60 seconds if the doors are not opened and closed.)
- Gripping the door handle when wearing a glove may not unlock the door.
- If the wireless remote control is used to lock the doors when the electronic key is near the vehicle, there is a possibility that the door may not be unlocked by the entry function. (Use the wireless remote control to unlock the doors.)
- A sudden approach to the effective range or door handle may prevent the doors from being unlocked. In this case, return the door handle to the original position and check that the doors unlock before pulling the door handle again.

#### ■ When the vehicle is not driven for extended periods

To prevent theft of the vehicle, do not leave the electronic key within 6 ft. (2 m) of the vehicle.

# ■ Security feature

If a door is not opened within approximately 60 seconds after the vehicle is unlocked, the security feature automatically locks the vehicle again.

# ■ Alarms and warning indicators

A combination of exterior and interior alarms as well as warning messages shown on the multi-information display are used to reduce the chance of vehicle theft and accidents resulting from erroneous operation. Take appropriate measures according to the warning message on the multi-information display. ( $\rightarrow$ P. 408)

The following table describes circumstances and correction procedures when only alarms are sounded.

Alarm	Situation	Correction procedure
Exterior alarm sounds once for 2 seconds	Tried to lock the doors using the entry function while the electronic key is still inside the passenger compartment	Retrieve the electronic key from the passenger compartment and lock the doors again.
	Closed the trunk while the electronic key is still inside the trunk and all doors are locked	Retrieve the electronic key from the trunk and close the trunk lid.
Exterior alarm sounds once for 10 seconds	Tried to lock the vehicle using the entry function while a door is open	Close all of the doors and lock the doors again.
Exterior alarm sounds once for 60 seconds	Tried to exit the vehicle with the electronic key and lock the doors without first turning the "POWER" switch OFF	Turn the "POWER" switch OFF and lock the doors again.
Interior alarm sounds continu- ously	Tried to open the door and exit the vehicle without shifting the shift lever to P when the "POWER" switch is in ACCESSORY mode or ON mode	Shift the shift lever to P.
Interior alarm beeps repeatedly	Turned the "POWER" switch to ACCESSORY mode while the driver's door is open (Opened the driver's door when the "POWER" switch is in ACCESSORY mode.)	Turn the "POWER" switch OFF and close the driver's door.
	Turned the "POWER" switch OFF while the driver's door is open	Close the driver's door.

#### ■ If the smart key system does not operate properly

- Locking and unlocking the doors and trunk: Use the mechanical key.
   (→P. 433)
- Starting the hybrid system:→P. 434

#### ■ When the electronic key battery is fully depleted

→P. 372

#### ■ Customization that can be configured at Toyota dealer

It is possible to deactivate the smart key system, etc. (Customizable features →P. 474)

#### ■ Certification for the smart key system

► For vehicles sold in the U.S.A.

FCC ID: NI4TMLF-2 FCC ID: HYQ14AAB FCC ID: HYQ14AEM FCC ID: HYQ13BZH FCC ID: HYQ14ABK FCC ID: HYQ13BZW

#### NOTE:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### ► For vehicles sold in Canada

#### NOTE:

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

# **CAUTION**


## Caution regarding interference with electronic devices

- People with implanted pacemakers or cardiac defibrillators should keep away from the smart key system antennas. ( $\rightarrow$ P. 39) The radio waves may affect the operation of such devices. If necessary, the entry function can be disabled. Ask your Toyota dealer for details, such as the frequency of radio waves and timing of emitting the radio waves. Then, consult your doctor to see if you should disable the entry function.
- User of any electrical medical device other than implanted pacemakers and implanted cardiac defibrillators should consult the manufacturer of the device for information about its operation under the influence of radio waves.
  - Radio waves could have unexpected effects on the operation of such medical devices.

Ask your Toyota dealer for details for disabling the entry function.

# 1-3. Opening, closing and locking the doors Wireless remote control

The wireless remote control can be used to lock and unlock the vehicle from outside the vehicle.



- Locks all doors
- Unlocks all doors

Pressing the button unlocks the driver's door. Pressing the button again within 3 seconds unlocks the other doors.

- 3 Unlocks the trunk (press and hold)
- 4 Sounds an alarm (press and hold)

#### ■ Operation signals

Doors: A buzzer sounds and the emergency flashers flash to indicate that

the doors have been locked/unlocked. (Locked: Once; Unlocked: Twice)

Trunk: A buzzer sounds to indicate that the trunk has been unlocked.

#### ■ Door lock buzzer

If a door is not fully closed, a buzzer sounds continuously for 10 seconds if an attempt to lock the door is made. Fully close the door to stop the buzzer, and lock the vehicle once more.

#### ■ Panic mode



When ((i) is pressed for longer than about one second, an alarm will sound intermittently and the vehicle lights will flash to deter any person from trying to break into or damage your vehicle.

To stop the alarm, press any button on the wireless remote control.

## ■ Key battery depletion

→P. 43

#### ■ Security feature

→P. 44

# ■ When the electronic key battery is fully depleted

→P. 372

#### ■ Conditions affecting operation

→P. 41

# ■ Customization that can be configured at Toyota dealer

Settings (e.g. trunk unlocking function) can be changed. (Customizable features →P. 474)

#### ■ Certification for wireless remote control

► For vehicles sold in the U.S.A.

FCC ID: NI4TMLF-2 FCC ID: HYQ14AAB FCC ID: HYQ14AEM FCC ID: HYQ13BZH FCC ID: HYQ14ABK

FCC ID: HYQ13BZW

#### NOTE:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

► For vehicles sold in Canada

#### NOTE:

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

The vehicle can be locked and unlocked using the entry function, wireless remote control, key or door lock switch.


# **■** Entry function

#### ■ Wireless remote control

### ■ Key


→P. 433

#### ■ Door lock switch



- Locks all doors
- Unlocks all doors

#### ■ Inside lock button



- 1 Unlocks the door
- 2 Locks the door


The front doors can be opened by pulling the inside handle even if the lock buttons are in the lock position.

# Locking the front doors from the outside without a key

The door cannot be locked if the "POWER" switch is in ACCESSORY or ON mode, or the electronic key is left inside the vehicle.

Depending on the position of the electronic key, the key may not be detected correctly and the door may be locked.

# Rear door child-protector lock



The door cannot be opened from inside the vehicle when the locks are set.

These locks can be set to prevent children from opening the rear doors. Push down on each rear door switch to lock both rear doors.

# Automatic door locking and unlocking systems


The following functions can be set or cancelled:

Function	Operation
Shift position linked door locking function	Shifting the shift lever out of P locks all doors.
Shift position linked door unlocking function	Shifting the shift lever to P unlocks all doors.
Speed linked door lock- ing function	All doors are locked when the vehicle speed is approximately 12 mph (20 km/h) or higher.
Driver's door linked door unlocking function	All doors are unlocked when the driver's door is opened within 10 seconds after turning the "POWER" switch OFF.

# ■ Setting and canceling the functions

To switch between set and canceled, follow the procedure below:

Close all the doors and switch the "POWER" switch to ON mode. (Perform step 2 within 20 seconds.)



Shift the shift lever to P or N, and press and hold the driver's door lock switch ( or or ) for approximately 5 seconds and then release.

The shift lever and switch positions corresponding to the desired function to be set are shown as follows.

Use the same procedure to cancel the function.

Function	Shift lever position	Driver's door lock switch position
Shift position linked door locking function	P	a
Shift position linked door unlocking function	'	ā
Speed linked door locking function	N	a
Driver's door linked door unlocking function		a

When the setting or canceling operation is complete, all doors are locked and then unlocked.

#### ■ Customization that can be configured at Toyota dealer

Settings (e.g. unlocking function using a key) can be changed. (Customizable features →P. 474)

# **A** CAUTION

#### To prevent an accident

Observe the following precautions while driving the vehicle.

Failing to do so may result in a door opening and an occupant falling out, resulting in death or serious injury.


- Always use a seat belt.
- Always lock the doors.
- Ensure that all doors are properly closed.
- Do not pull the inside handle of the doors while driving. The doors may be opened and the passengers are thrown out of the vehicle and it may result in serious injury or death.
  - Be especially careful for the front doors, as the doors may be opened even if the inside lock buttons are in locked position.
- Set the rear door child protector locks when children are seated in the rear seat.

The trunk can be opened using the key, trunk opener, entry function or wireless remote control.

## ■ Opening the trunk from outside the vehicle

- ► Entry function
  - →P. 38
- ▶ Wireless remote control
  - →P. 48
- ▶ Key
  - →P. 433


# ■ Opening the trunk from inside the vehicle



Pull the lever to release the trunk lid

# Luggage security system


To protect luggage stored in the trunk against theft, do the following procedure.



Turn the mechanical key counterclockwise to lock the trunk opener feature.

The trunk lid cannot be opened even with the wireless remote control or the entry function.

#### ■Internal trunk release lever



The trunk lid can be opened by pulling up the glow-in-the-dark lever located on the inside of trunk lid.

The lever will continue to glow for some time after the trunk lid is closed.

### ■Trunk light

The trunk light turns on when the trunk is opened.

■Which key to the vehicle is to leave with a parking attendant after the luggage security system is set

→P. 35

# **A** CAUTION

#### Caution while driving

- Keep the trunk lid closed while driving. If the trunk lid is left open, it may hit near-by objects while driving or luggage in the trunk may be unexpectedly thrown out, causing an accident. In addition, exhaust gases may enter the vehicle, causing death or a serious health hazard. Make sure to close the trunk lid before driving.
- Before driving the vehicle, make sure that the trunk lid is fully closed. If the trunk lid is not fully closed, it may open unexpectedly while driving, causing an accident.
- Never let anyone sit in the trunk. In the event of sudden braking or a collision, they are susceptible to death or serious injury.

#### When children are in the vehicle

Observe the following precautions.

Failure to do so may result in death or serious injury.

- Do not allow children to enter the trunk. If a child is accidentally locked in the trunk, they could overheat or suffocate.
- Do not allow a child to open or close the trunk lid. Doing so may cause the trunk lid to operate unexpectedly, or cause the child's hands, head, or neck to be caught by the closing trunk lid.

### **A** CAUTION


#### Using the trunk

Observe the following precautions.

Failure to do so may cause parts of the body to be caught, resulting in serious injury.


- Remove any heavy loads, such as snow and ice, from the trunk lid before opening it. Failure to do so may cause the trunk lid to fall closed again after it is opened.
- When opening or closing the trunk lid, thoroughly check to make sure the surrounding area is safe.
- If anyone is in the vicinity, make sure they are safe and let them know that the trunk is about to open or close.
- Use caution when opening or closing the trunk lid in windy weather as it may move abruptly in strong wind.





- The trunk lid may fall if it is not opened fully. It is more difficult to open or close the trunk lid on an incline than on a level surface, so beware of the trunk lid unexpectedly opening or closing by itself. Make sure that the trunk lid is fully open and secure before using the trunk.
- When closing the trunk lid, take extra care to prevent your fingers etc. from being caught.
- When closing the trunk lid, make sure to press it lightly on its outer surface.
- Do not attach any accessories other than genuine Toyota parts to the trunk lid. Such additional weight on the trunk lid may cause the lid to fall closed again after it is opened.

## ▶ Power seat



- Seat position switch
- Seatback angle switch
- 3 Seat cushion (front) angle switch (driver's side only)
- Vertical height adjustment switch (driver's side only)
- **5** Lumbar support switch (driver's side only)

#### ▶ Manual seat




- Seatback angle adjustment lever
- 2 Seat position adjustment lever

# **A** CAUTION

# Seat adjustment

- Do not recline the seat more than necessary when the vehicle is in motion to reduce the risk of sliding under the lap belt.
  - If the seat is too reclined, the lap belt may slide past the hips and apply restraint forces directly to the abdomen or your neck may contact the shoulder belt, increasing the risk of death or serious injury in the event of an accident.
- Manual seat only: After adjusting the seat, make sure that the seat is locked in position.

# ■ Folding down rear seatbacks



Pull the seatback lever in the trunk for the seatback you wish to fold down.

# **A** CAUTION

# ■ After returning the seatback to the upright position

Observe the following precautions. Failure to do so may result in death or serious injury.

- Make sure the seatback is securely locked by pressing forward and rearward on the top of the seatback.
- Check that the seat belts are not twisted or caught in the seatback.


# **⚠** NOTICE

# When right seatback is folded down

Make sure the luggage loaded in the enlarged trunk will not damage the webbing of the rear center seat belt.

# 1-4. Adjustable components (seats, mirrors, steering wheel) Head restraints

# Head restraints are provided for all seats.




#### 1 Up

Pull the head restraints up.

#### 2 Down


Push the head restraint down while pushing the lock release button.

# ■ Removing the head restraints



Pull the head restraint up while pressing the lock release button.


## ■Installing the head restraints



Align the head restraint with the installation holes and push it down to the lock position.

Press and hold the lock release button when lowering the head restraint.

#### ■ Adjusting the height of the head restraints



Make sure that the head restraints are adjusted so that the center of the head restraint is closest to the top of your ears.

#### ■ Adjusting the rear center seat head restraint

Always raise the head restraint one level from the stowed position when using.

# **A** CAUTION

#### Head restraint precautions

Observe the following precautions regarding the head restraints. Failure to do so may result in death or serious injury.

- Use the head restraints designed for each respective seat.
- Adjust the head restraints to the correct position at all times.
- After adjusting the head restraints, push down on them and make sure they are locked in position.
- Do not drive with the head restraints removed.

# 1-4. Adjustable components (seats, mirrors, steering wheel) **Seat belts**


Make sure that all occupants are wearing their seat belts before driving the vehicle.

#### ■ Correct use of the seat belts



- Extend the shoulder belt so that it comes fully over the shoulder, but does not come into contact with the neck or slide off the shoulder.
- Position the lap belt as low as possible over the hips.
- Adjust the position of the seatback. Sit up straight and well back in the seat.
- Do not twist the seat belt.

# ■ Fastening and releasing the seat belt



Fastening the belt

Push the tab into the buckle until a clicking sound is heard.

Releasing the belt

Press the release button.

# ■ Adjusting the height of the belt (front seats)




- 1 Down
- 2 Up


Move the height adjuster up and down as needed until you hear a click.

# Seat belt comfort guide (outside rear seat)

If the shoulder belt fits close to a person's neck, use the seat belt comfort guide.




Pull out the comfort guide from the pocket.




Slide the belt past the slot of the guide.

The elastic cord must be behind the seat belt.



Buckle, position and release the seat belt.

# Seat belt pretensioners (front seats)



The pretensioner helps the seat belt to quickly restrain the occupant by retracting the seat belt when the vehicle is subjected to certain types of severe frontal collision.

The pretensioner may not activate in the event of a minor frontal impact, a side impact or a rear impact.


#### ■ Emergency locking retractor (ELR)

The retractor will lock the belt during a sudden stop or on impact. It may also lock if you lean forward too quickly. A slow, easy motion will allow the belt to extend so that you can move around fully.

#### ■ Automatic locking retractor (ALR)

When a passenger's shoulder belt is completely extended and then retracted even slightly, the belt is locked in that position and cannot be extended. This feature is used to hold the child restraint system (CRS) firmly. To free the belt again, fully retract the belt and then pull the belt out once more. (→P. 113)

#### ■ Pregnant women



Obtain medical advice and wear the seat belt in the proper way. (→P. 64)

Women who are pregnant should position the lap belt as low as possible over the hips in the same manner as other occupants. Extend the shoulder belt completely over the shoulder and position the belt across the chest. Avoid belt contact over the rounding of the abdominal area.

If the seat belt is not worn properly, not only a pregnant woman, but also the fetus could suffer death or serious injury as a result of sudden braking or a collision.

# ■ People suffering illness

Obtain medical advice and wear the seat belt in the proper way.

#### ■ Child seat belt usage


The seat belts of your vehicle were principally designed for persons of adult size.

- Use a child restraint system appropriate for the child, until the child becomes large enough to properly wear the vehicle's seat belt. (→P. 109)
- When the child becomes large enough to properly wear the vehicle's seat belt, follow the instructions on P. 64 regarding seat belt usage.

#### ■ Replacing the belt after the pretensioner has been activated


If the vehicle is involved in multiple collisions, the pretensioner will activate for the first collision, but will not activate for the second or subsequent collisions.

#### ■ Seat belt extender



If your seat belts cannot be fastened securely because they are not long enough, a personalized seat belt extender is available from your Toyota dealer free of charge.

#### ■ Rear seat belts



Use the seat belt after passing it through the guide if the seat belt comes free from the guide.

# **A** CAUTION

Observe the following precautions to reduce the risk of injury in the event of sudden braking, sudden swerving or an accident.

Failing to do so may cause death or severe injury.

#### Wearing a seat belt

- Ensure that all passengers wear a seat belt.
- Always wear a seat belt properly.
- Each seat belt should be used by one person only. Do not use a seat belt for more than one person at once, including children.
- Toyota recommends that children be seated in the rear seat and always use a seat belt and/or an appropriate child restraint system.
- Do not recline the seat any more than necessary to achieve a proper seating position. The seat belt is most effective when the occupants are sitting up straight and well back in the seats.
- Do not wear the shoulder belt under your arm.
- Always wear your seat belt low and snug across your hips.

# Adjustable shoulder anchor

Always make sure the shoulder belt is positioned across the center of your shoulder. The belt should be kept away from your neck, but not falling off your shoulder. Failure to do so could reduce the amount of protection in an accident and cause death or serious injuries in the event of a sudden stop, sudden swerve or accident. ( $\rightarrow$ P. 65)

# Seat belt pretensioners

- Do not place anything, such as a cushion, on the front passenger's seat. Doing so will disperse the passenger's weight, which prevents the sensor from detecting the passenger's weight properly. As a result, the seat belt pretensioner for the front passenger's seat may not activate in the event of a collision.
- If the pretensioner has activated, the SRS warning light will come on. In that case, the seat belt cannot be used again and must be replaced at your Toyota dealer.

# **CAUTION**

#### Child restraint lock function belt precaution

Do not allow children to play with the child restraint lock function belt. If the belt becomes twisted around a child's neck, it will not be possible to pull the belt out leading to choking or other serious injuries that could result in death. If this occurs and the buckle cannot be unfastened, scissors should be used to cut the belt.

#### Seat belt damage and wear

- Do not damage the seat belts by allowing the belt, plate, or buckle to be iammed in the door.
- Inspect the seat belt system periodically. Check for cuts, fraying, and loose parts. Do not use a damaged seat belt until it is replaced. Damaged seat belts cannot protect an occupant from death or serious injury.
- Ensure that the belt and tab are locked and the belt is not twisted. If the seat belt does not function correctly, immediately contact your Toyota dealer.
- Replace the seat assembly, including the belts, if your vehicle has been involved in a serious accident, even if there is no obvious damage.
- Do not attempt to install, remove, modify, disassemble or dispose of the seat belts. Have any necessary repairs carried out by your Toyota dealer. Inappropriate handling of the pretensioner may prevent it from operating properly resulting in death or serious injury.
- Always make sure the shoulder belt passes through the guide when using the seat belt. Failure to properly position the belt may reduce the amount of protection in an accident and could lead to serious injures in a collision or sudden stop.
- Always make sure that the seat belt is not twisted, does not get caught in the guide or the seatback and is arranged in the proper position.

# **CAUTION**

#### Using a seat belt comfort guide

- Make sure the belt is not twisted and that it lies flat. The elastic cord must be behind the belt and the guide must be on the front.
- To reduce the chance of injury in case of a sudden stop, sudden swerve or accident while driving, remove and store the comfort guide in its pocket when it is not in use.
- Always make sure the shoulder belt is positioned across the center of the shoulder. The belt should be kept away from the neck, and should not fall off the shoulder.

Failure to observe these precautions could reduce the effectiveness of the seat belt in an accident, causing death or serious injury.

#### Using a seat belt extender

- Do not wear the seat belt extender if you can fasten the seat belt without the extender.
- Do not use the seat belt extender when installing a child restraint system because the belt will not securely hold the child restraint system, increasing the risk of death or serious injury in the event of an accident.
- The personalized extender may not be safe on another vehicle, when used by another person, or at a different seating position other than the one originally intended.

#### NOTICE

# When using a seat belt extender


When releasing the seat belt, press on the buckle release button on the extender, not on the seat belt.

This helps prevent damage to the vehicle interior and the extender itself.


# 1-4. Adjustable components (seats, mirrors, steering wheel)

# Steering wheel

#### The steering wheel can be adjusted to a comfortable position.



Hold the steering wheel and press the lever down.



Adjust to the ideal position by moving the steering wheel horizontally and vertically.

After adjustment, pull the lever up to secure the steering wheel.



# **CAUTION**

## Caution while driving

Do not adjust the steering wheel while driving.

Doing so may cause the driver to mishandle the vehicle and cause an accident, resulting in death or serious injury.

# After adjusting the steering wheel


Make sure that the steering wheel is securely locked.

Otherwise, the steering wheel may move suddenly, possibly causing an accident and resulting in death or serious injury.

# 1-4. Adjustable components (seats, mirrors, steering wheel) Anti-glare inside rear view mirror

Glare from the headlights of vehicles behind can be reduced by using the following functions.

► Manual anti-glare inside rear view mirror



- Normal position
- 2 Anti-glare position

▶ Auto anti-glare inside rear view mirror In automatic mode, sensors are used to detect the headlights of vehicles behind and the reflected light is automatically reduced.




Turns automatic mode on/off

The indicator comes on when automatic mode is turned on.


The mirror will revert to the automatic mode each time the "POWER" switch is turned to ON mode.

#### Adjusting the height of rear view mirror



Adjust the height of the rear view mirror by moving it up and down.

#### ■To prevent sensor error (vehicles with auto anti-glare inside rear view mirror)



To ensure that the sensors operate properly, do not touch or cover them.




#### **A** CAUTION

#### Caution while driving

Do not adjust the position of the mirror while driving.


Doing so may lead to mishandling of the vehicle and an accident, resulting in death or serious injury.

Mirror angle can be adjusted using the switch when the "POWER" switch is in ACCESSORY or ON mode.



Select a mirror to adjust.

- 1 Left
- 2 Right



Adjust the mirror.

- 1 Up
- 2 Right
- 3 Down
- 4 Left

■ When the mirrors are fogged up (vehicles with mirror defoggers)

Turn on the mirror defoggers to defog the mirrors. ( $\rightarrow$ P. 191)

#### **CAUTION**

#### When driving the vehicle

Observe the following precautions while driving.

Failing to do so may result in loss of control of the vehicle and cause an accident, resulting in death or serious injury.

- Do not adjust the mirrors while driving.
- Both the driver and passenger side mirrors must be properly adjusted before driving.


#### When a mirror is moving

To avoid injury and mirror malfunction, be careful not to get your hand caught by the moving mirror.

■When the mirror defoggers are operating (vehicles with mirror defoggers)


Do not touch the rear view mirror surfaces, as they can become very hot and burn you.

# The power windows can be opened and closed using the following switches.



- Closing
- 2 One-touch closing\*
- 3 Opening
- 4 One-touch opening\*
  - \*: Pressing the switch in the opposite direction will stop window travel partway.

#### Lock switch



Press the switch down to lock passenger window switches.

Use this switch to prevent children from accidentally opening or closing a passenger window.

#### ■ The power windows can be operated when

The "POWER" switch is in ON mode.

#### ■ Operating the power windows after turning the hybrid system off

The power windows can be operated for approximately 45 seconds after the "POWER" switch is turned to ACCESSORY mode or turned OFF. They cannot, however, be operated once either front door is opened.

#### **A** CAUTION

#### Closing the windows

Observe the following precautions.


Failing to do so may result in death or serious injury.

- Check to make sure that all passengers do not have any part of their body in a position where it could be caught when a window is being operated.
- Do not allow children to operate the power windows. Closing a power window on someone can cause serious injury, and in some instances, even death.

# 1-5. Opening and closing the windows **Moon roof**\*

Use the overhead switches to open, close, and tilt the moon roof up and down.

#### ■ Opening and closing




### Open

The moon roof stops slightly before the fully open position. Push the switch again to fully open.

#### 2 Close

Push the switch in either direction to stop the moon roof partway.

### ■ Tilt up and down



#### 1 Tilt up

#### 2 Tilt down

Push the switch in either direction to stop the moon roof partway.

#### ■ The moon roof can be operated when

The "POWER" switch is in ON mode.

#### ■ Operating the moon roof after turning the hybrid system off

The moon roof can be operated for approximately 45 seconds after the "POWER" switch is turned to ACCESSORY mode or turned OFF. It cannot, however, be operated once either front door is opened.

#### ■ Jam protection function

If an object is detected between the moon roof and the frame while closing or tilting down, travel is stopped and the moon roof opens slightly.

#### ■To reduce wind noise

Drive with the moon roof opened to slightly before the fully open position as driving with the moon roof opened fully will cause wind noise.

#### ■Sunshade

The sunshade can be opened and closed manually. However, the sunshade will open automatically when the moon roof is opened.

#### ■ Moon roof open reminder function

An alarm will sound when the driver's door is opened with the moon roof not fully closed and the "POWER" switch OFF.

#### ■ When the moon roof does not close normally

Perform the following procedure:

- If the moon roof closes but then re-opens slightly
- STEP 1 Stop the vehicle.
- The moon roof will close, reopen and pause for approximately 10 seconds.\*2 Then it will close again, tilt up and pause for approximately 1 second. Finally, it will tilt down, open and close.
- Check to make sure that the moon roof is completely closed and then release the switch.
- If the moon roof tilts down but then tilts back up
- STEP 1 Stop the vehicle.
- Press and hold the "UP" switch\*1 until the moon roof moves into the tilt up position and stops.
- Release the "UP" switch once and then press and hold the "UP" switch again.\*1

The moon roof will pause for approximately 10 seconds in the tilt up position.\*<sup>2</sup> Then it will adjust slightly and pause for approximately 1 second. Finally, it will tilt down, open and close.

- Check to make sure that the moon roof is completely closed and then release the switch.
  - \*1: If the switch is released at the incorrect time, the procedure will have to be performed again from the beginning.
  - \*2: If the switch is released after the above mentioned 10 second pause, automatic operation will be disabled. In that case, press and hold the open/close switch in the close position or press and hold the "UP" switch. The moon roof will tilt up and pause for approximately 1 second. Then it will tilt down, open and close. Check to make sure that the moon roof is completely closed and then release the switch.

If the moon roof does not fully close even after performing the above procedure correctly, have the vehicle inspected by your Toyota dealer.

#### Opening the moon roof

Observe the following precautions.

Failing to do so may cause death or serious injury.

- Do not allow any passengers to put their hands or heads outside the vehicle while it is moving.
- Do not sit on top of the moon roof.

#### Closing the moon roof

Observe the following precautions.

Failing to do so may result in death or serious injury.

- Check to make sure that all passengers do not have any part of their bodies in a position where they could be caught when the moon roof is being operated.
- Do not allow children to operate the moon roof. Closing the moon roof on someone can cause death or serious injury.

#### Jam protection function

- Never try jamming any part of your body to activate the jam protection function intentionally.
- The jam protection function may not work if something gets caught just before the moon roof fully closes.


### Opening the fuel tank cap

The fuel tank of your vehicle has a special structure, which requires a reduction in fuel tank pressure before refueling. After the opener switch has been pressed, it will take several seconds until the vehicle is ready for refueling.


#### ■ Before refueling the vehicle

Turn the "POWER" switch OFF and ensure that all the doors and windows are closed.

#### ■ Opening the fuel tank cap




Press the fuel filler door opener switch.




When the message "REFUEL READY" appears, the fuel filler door will open.



If the pressure in the fuel tank is high, the message "PLEASE WAIT NOW OPENING" will appear on the multi-information display. It may take up to 10 seconds.




Turn the fuel tank cap slowly to open.



Hang the fuel tank cap on the back of the fuel filler door.

#### Closing the fuel tank cap



When replacing the fuel tank cap, turn it until a clicking sound is heard.


#### ■ Fuel type

Unleaded gasoline (Octane rating 87 [Research Octane Number 91] or higher)

#### ■ Fuel tank capacity

17.2 gal. (65 L, 14.3 lmp. gal.)

#### ■ When the fuel filler door opener is inoperable



- If the fuel filler door opener switch cannot be operated, contact your Toyota dealer to service the vehicle. In cases where refueling is urgently necessary, the fuel filler door can be opened using the lever in the trunk.
- Using the lever to open the fuel filler door may not allow for an adequate reduction in fuel tank pressure before refueling. To prevent fuel from spilling out, turn the cap slowly when removing it.
  - During refueling, fuel may spill out from the filler opening due to air being discharged from inside the fuel tank. Therefore, fill the fuel tank carefully and slowly.

#### **CAUTION**

#### Refueling the vehicle

Observe the following precautions while refueling the vehicle. Failure to do so may result in death or serious injury.

- Touch the vehicle or some other metal surface to discharge any static electricity.
  - Sparks resulting from discharging static electricity may cause the fuel vapors to ignite.
- Always hold the grips on the fuel tank cap and turn it slowly to remove it. A whooshing sound may be heard when the fuel tank cap is loosened. Wait until the sound cannot be heard before fully removing the cap. In hot weather, pressurized fuel may spray out of the filler neck and cause injury.
- Do not allow anyone that has not discharged static electricity from their bodies to come close to an open fuel tank.
- Do not inhale vaporized fuel. Fuel contains substances that are harmful if inhaled.
- Do not smoke while refueling the vehicle. Doing so may cause the fuel to ignite and cause a fire.
- Do not return to the vehicle or touch any person or object that is statically charged.
  - This may cause static electricity to build up, resulting in a possible ignition hazard.

#### When replacing the fuel cap

Do not use anything but a genuine Toyota fuel tank cap designed for your vehicle. Doing so may cause a fire or other incident which may result in death or serious injury.

### <u>^</u>

#### NOTICE


#### Refueling

- Finish refueling within 30 minutes. If more than 30 minutes passes, the internal valve closes. In this condition, fuel may spill out if you continue to refuel the vehicle. About 5 minutes after the valve is closed, a message "CLOSE FUEL LID" will appear on the multi-information display. To refuel the vehicle again, tighten the fuel tank cap and close the fuel filler door, and then push the fuel filler door opener switch again.
- Do not spill fuel during refueling.
  Doing so may damage the vehicle, such as causing the exhaust systems to operate abnormally or damaging fuel system components or the vehicle's painted surface.

### 1-7. Theft deterrent system Immobilizer system

The vehicle's keys have built-in transponder chips that prevent the hybrid system from starting if the key has not been previously registered in the vehicle's on-board computer.

Never leave the keys inside the vehicle when you leave the vehicle.



The indicator light flashes after the "POWER" switch has been turned OFF to indicate that the system is operating.

The indicator light stops flashing after the "POWER" switch has been turned to ACCES-SORY or ON mode to indicate that the system has been canceled.

#### ■ System maintenance

The vehicle has a maintenance-free type immobilizer system.

- Conditions that may cause the system to malfunction
  - If the key is in contact with a metallic object
  - If the key is in close proximity to or touching a key to the security system (key with a built-in transponder chip) of another vehicle

#### ■ Certifications for the immobilizer system

► For vehicles sold in the U.S.A.

FCC ID: NI4TMIMB-1

#### NOTE:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

For vehicles sold in Canada

#### NOTE:

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.



#### CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.




#### NOTICE

#### To ensure the system operates correctly

Do not modify or remove the system. If modified or removed, the proper operation of the system cannot be guaranteed.

### **Correct driving posture**

#### Drive in a good posture as follows:



- Sit upright and well back in the seat. (→P. 59)
- Adjust the position of the seat forward or backward to ensure the pedals can be reached and easily depressed to the extent required. (→P. 59)
- Adjust the seatback so that the controls are easily operable.
- Adjust the tilt and telescopic positions of the steering wheel downward so the airbag is facing your chest. (→P. 72)
- 5 Lock the head restraint in place with the center of the head restraint closest to the top of your ears. (→P. 62)
- Wear the seat belt correctly.(→P. 64)

#### While driving


- Do not adjust the position of the driver's seat while driving. Doing so could cause the driver to lose control of the vehicle.
- Do not place a cushion between the driver or passenger and the seatback. A cushion may prevent correct posture from being achieved, and reduce the effectiveness of the seat belt and head restraint, increasing the risk of death or serious injury to the driver or passenger.
- Do not place anything under the front seats. Objects placed under the front seats may become jammed in the seat tracks and stop the seat from locking in place. This may lead to an accident. The adjustment mechanism may also be damaged.

#### Adjusting the seat position

- Take care when adjusting the seat position to ensure that other passengers are not injured by the moving seat.
- Do not put your hands under the seat or near the moving parts to avoid injury.
  - Fingers or hands may become jammed in the seat mechanism.


### **SRS** airbags

The SRS airbags inflate when the vehicle is subjected to certain types of severe impacts that may cause significant injury to the occupants. They work together with the seat belts to help reduce the risk of death or serious injury.



- ▶ Front airbags
- Driver airbag/front passenger airbag Can help protect the head and chest of the driver and front passenger from impact with interior components.
- Driver knee airbagCan help provide driver protection.
- ► Side and curtain shield airbags
- Side airbags
  Can help protect the torso of the front seat occupants.
- 4 Curtain shield airbags Can help protect primarily the head of occupants in the outer seats.

#### Airbag system components



- Front airbag sensors
- Front passenger occupant classification system (ECU and sensors)
- Side and curtain shield airbag sensors
- 4 Front passenger airbag
- Side airbags
- 6 Curtain shield airbags
- "AIR BAG ON" and "AIR BAG OFF" indicator lights
- SRS warning light

- 9 Front passenger's seat belt buckle switch
- Airbag sensor assembly
- Curtain shield airbag sensors
- 12 Driver airbag
- Driver's seat position sensor
- Driver's seat belt buckle switch
- 15 Knee airbag

Your vehicle is equipped with ADVANCED AIRBAGS designed based on US motor vehicle safety standards (FMVSS208). The airbag system controls airbag deployment power for the driver and front passenger. The driver airbag system consists of the driver seat's position sensor etc. The front passenger's airbag system consists of the front passenger occupant classification sensor etc.

The main SRS airbag system components are shown above. The SRS airbag system is controlled by the airbag sensor assembly. The airbag sensor assembly consists of a safing sensor and an airbag sensor.

In certain types of severe frontal or side impacts, the SRS airbag system triggers the airbag inflators. A chemical reaction in the inflators quickly fills the airbags with non-toxic gas to help restrain the motion of the occupants.

#### **■**SRS warning light

This warning light system monitors the airbag sensor assembly, front airbag sensors, side and curtain shield airbag sensors, curtain shield airbag sensors, driver's seat position sensor, driver's seat belt buckle switch, front passenger occupant classification system, "AIR BAG ON" indicator light, "AIR BAG OFF" indicator light, front passenger's seat belt buckle switch, seat belt pretensioner assemblies, inflators, interconnecting wiring and power sources. (→P. 400)

#### ■ If the SRS airbags deploy (inflate)

- Bruising and slight abrasions may result from contact with a deploying (inflating) SRS airbag.
- A loud noise and white powder will be emitted.
- Parts of the airbag module (steering wheel hub, airbag cover and inflator) as well as the front seats, and parts of the front and rear pillars and roof side rail, may be hot for several minutes. The airbag itself may also be hot.
- The front windshield may crack.

#### ■ SRS airbag deployment conditions (front airbags)


- The SRS front airbags will deploy in the event of an impact that exceeds the set threshold level (the level of force corresponding to an approximately 12 - 18 mph [20 - 30 km/h] frontal collision with a fixed wall that does not move or deform).
  - However, this threshold velocity will be considerably higher if the vehicle strikes an object, such as a parked vehicle or sign pole, which can move or deform on impact, or if the vehicle is involved in an underride collision (e.g. a collision in which the front of the vehicle "underrides", or goes under, the bed of a truck, etc.).
- It is possible that in some collisions where the forward deceleration of the vehicle is very close to the designed threshold level, the SRS front airbags and the seat belt pretensioners may not activate together.
- The SRS front passenger airbag will not activate if there is no passenger sitting in the front passenger seat. However, the front passenger airbag may deploy if luggage is put in the seat, or the seat belt is fastened, even if the seat is unoccupied. (→P. 104)

# SRS airbag deployment conditions (side airbags and curtain shield airbags)

- The SRS side airbags and SRS curtain shield airbags will deploy in the event of an impact that exceeds the set threshold level (the level of force corresponding to the impact force produced by an approximately 3300 lb. [1500 kg] vehicle colliding with the vehicle cabin from a direction perpendicular to the vehicle orientation at an approximate speed of 12 18 mph [20 30 km/h]).
- The SRS side airbag on the passenger seat will not activate if there is no passenger sitting in the front passenger seat. However, the side airbag on the passenger seat may deploy if luggage is put in the seat, even if the seat is unoccupied. (→P. 104)

## ■ Conditions under which the SRS airbags may deploy (inflate), other than a collision


The SRS front airbags may also deploy if a serious impact occurs to the underside of your vehicle. Some examples are shown in the illustration.



- Hitting a curb, edge of pavement or hard surface
- Falling into or jumping over a deep hole
- Landing hard or vehicle falling

#### ■ Types of collisions that may not deploy the SRS airbag (front airbags)


The SRS front airbags are generally not designed to inflate if the vehicle is involved in a side or rear collision, if it rolls over, or if it is involved in a low-speed frontal collision. But, whenever a collision of any type causes sufficient forward deceleration of the vehicle, deployment of the SRS front airbags may occur.



- Collision from the side
- Collision from the rear
- Vehicle rollover


# ■ Types of collisions that may not deploy the SRS airbag (side airbags and curtain shield airbags)

The SRS side airbags and curtain shield airbag system may not activate if the vehicle is subjected to a collision from the side at certain angles, or a collision to the side of the vehicle body other than the passenger compartment.



- Collision from the side to the vehicle body other than the passenger compartment
- Collision from the side at an angle

The SRS side airbags and curtain shield airbags are not generally designed to inflate if the vehicle is involved in a frontal or rear collision, if it rolls over, or if it is involved in a low-speed side collision.




- Collision from the front
- Collision from the rear
- Vehicle rollover


#### ■When to contact your Toyota dealer

In the following cases, contact your Toyota dealer as soon as possible.


Any of the SRS airbags have been inflated.




• The front of the vehicle is damaged or deformed, or was involved in an accident that was not severe enough to cause the SRS airbags to inflate.



A portion of a door is damaged or deformed, or the vehicle was involved in an accident that was not severe enough to cause the SRS side airbags and curtain shield airbags to inflate.



• The pad section of the steering wheel or dashboard near the front passenger airbag cover or lower portion of the instrument panel is scratched, cracked, or otherwise damaged.



- The surface of the seats with the side airbag is scratched, cracked, or otherwise damaged.
- The portion of the front pillars, rear pillars or roof side rail garnishes (padding) containing the curtain shield airbags inside is scratched, cracked or otherwise damaged.

#### SRS airbag precautions

Observe the following precautions regarding the airbags. Failure to do so may cause death or serious injury.

- The driver and all passengers in the vehicle must wear their seat belts properly.
  - The SRS airbags are supplemental devices to be used with the seat belts.
- The SRS driver airbag deploys with considerable force, and can cause death or serious injury especially if the driver is very close to the airbag. The National Highway Traffic Safety Administration ("NHTSA") advises:

Since the risk zone for the driver's airbag is the first 2 - 3 in. (50 - 75 mm) of inflation, placing yourself 10 in. (250 mm) from your driver airbag provides you with a clear margin of safety. This distance is measured from the center of the steering wheel to your breastbone. If you sit less than 10 in. (250 mm) away now, you can change your driving position in several ways:

- Move your seat to the rear as far as you can while still reaching the pedals comfortably.
- Slightly recline the back of the seat. Although vehicle designs vary, many drivers can achieve the 10 in. (250 mm) distance, even with the driver seat all the way forward, simply by reclining the back of the seat somewhat. If reclining the back of your seat makes it hard to see the road, raise yourself by using a firm,
- non-slippery cushion, or raise the seat if your vehicle has that feature. If your steering wheel is adjustable, tilt it downward. This points the airbag toward your chest instead of your head and neck.

The seat should be adjusted as recommended by NHTSA above, while still maintaining control of the foot pedals, steering wheel, and your view of the instrument panel controls.

#### SRS airbag precautions




- If the seat belt extender has been connected to the driver's seat belt buckle but the seat belt extender has not also been fastened to the latch plate of the driver's seat belt, the SRS driver's airbag system will judge that the driver is wearing the seat belt even though the seat belt has not been connected. In this case, the driver's airbag may not activate correctly in a collision, resulting in death or serious injury in the event of collision. Be sure to wear the seat belt with the seat belt extender.
- The SRS front passenger airbag also deploys with considerable force, and can cause death or serious injury especially if the front passenger is very close to the airbag. The front passenger seat should be as far from the airbag as possible with the seatback adjusted, so the front passenger sits upright.
- Improperly seated and/or restrained infants and children can be killed or seriously injured by a deploying airbag. An infant or child who is too small to use a seat belt should be properly secured using a child restraint system. Toyota strongly recommends that all infants and children be placed in the rear seats of the vehicle and properly restrained. The rear seats are the safest for infants and children. ( $\rightarrow$ P. 109)



Do not sit on the edge of the seat or lean against the dashboard.

#### SRS airbag precautions



- Do not allow a child to stand in front of the SRS front passenger airbag unit or sit on the knees of a front passenger.
- Do not drive the vehicle while the driver. or passenger has items resting on their knees.



Do not lean against the door, the roof side rail or the front, side and rear pillars.



Do not allow anyone to kneel on the passenger seat toward the door or put their head or hands outside the vehicle.




Do not attach anything to or lean anything against areas such as the dashboard, steering wheel pad or lower portion of the instrument panel.

These items can become projectiles when SRS driver, front passenger and knee airbags deploy.

#### **CAUTION**

#### SRS airbag precautions



- Do not attach anything to areas such as the door, windshield glass, side door glass, front and rear pillars, roof side rail or assist grip.
- Do not hang coat hangers or other hard objects on the coat hooks. All of these items could become projectiles and seriously injure or kill you, should the SRS curtain shield airbag deploy.
- If a vinyl cover is put on the area where the SRS knee airbag will deploy, be sure to remove it.
- Do not use seat accessories which cover the parts where the SRS side airbags inflate as they may interfere with inflation of the airbags.
- Do not strike or apply significant levels of force to the area of the SRS airbag components ( $\rightarrow$ P. 93). Doing so can cause the SRS airbags to malfunction.
- Do not touch any of the component parts immediately after the SRS airbags have deployed (inflated) as they may be hot.

#### SRS airbag precautions

- If breathing becomes difficult after the SRS airbag has deployed, open a door or window to allow fresh air in. or leave the vehicle if it is safe to do so. Wash off any residue as soon as possible to prevent skin irritation.
- If the areas where the SRS airbags are stored, such as the steering wheel pad and front and rear pillars garnishes, are damaged or cracked, have them replaced by your Toyota dealer.

#### Modification and disposal of SRS airbag system components


Do not dispose of your vehicle or perform any of the following modifications without consulting your Toyota dealer.

The SRS airbags may malfunction or deploy (inflate) accidentally, causing death or serious injury.

- Installation, removal, disassembly and repair of the SRS airbags.
- Repairs, modifications, removal or replacement of the steering wheel, instrument panel, dashboard, seats or seat upholstery, front, side and rear pillars or roof side rail.
- Repairs or modifications of the front fender, front bumper, or side of the occupant compartment.
- Installation of snow plows, winches, etc. to the front grille (bull bars, kangaroo bar etc.).
- Modifications to the vehicle's suspension system.
- Installation of electronic devices such as mobile two-way radios or CD players.
- Modifications to your vehicle for a person with a physical disability.

### Front passenger occupant classification system

Your vehicle is equipped with a front passenger occupant classification system. This system detects the conditions of the front passenger seat and activates or deactivates the devices for the front passenger.



- SRS warning light
- 2 "AIR BAG OFF" indicator light
- 3 "AIR BAG ON" indicator light
- 4 Front passenger's seat belt reminder light

### Conditions and operation of the front passenger occupant classification system

### ■ Adult\*1

Indicator/ warning light	"AIR BAG ON" and "AIR BAG OFF" indi-	"AIR BAG
	cator lights	ON"
	SRS warning light	Off
	Front passenger's seat belt reminder light	Flashing <sup>*2</sup>
Devices	Front passenger airbag	- Activated
	Side airbag on the front	
	passenger seats	
	Curtain shield airbag in the front	
	passenger side	
	Front passenger's seat belt pretensioner	

## ■ Child\*3 or child restraint system\*4

Indicator/ warning light	"AIR BAG ON" and "AIR BAG OFF" indi- cator lights	"AIR BAG OFF" <sup>*5</sup>
	SRS warning light	Off
	Front passenger's seat belt reminder light	Flashing*2
Devices	Front passenger airbag	
	Side airbag on the front	Deactivated
	passenger seats	
	Curtain shield airbag in the front	
	passenger side	Activated
	Front passenger's seat belt pretensioner	

#### ■ Unoccupied

Indicator/ warning light	"AIR BAG ON" and "AIR BAG OFF" indi- cator lights	Not illuminated
	SRS warning light	Off
	Front passenger's seat belt reminder light	Oii
Devices	Front passenger airbag	
	Side airbag on the front	Deactivated
	passenger seats	
	Curtain shield airbag in the front	Activated
	passenger side	Activated
	Front passenger's seat belt pretensioner	Deactivated

#### ■ There is a malfunction in the system

	_	
Indicator/ warning light	"AIR BAG ON" and "AIR BAG OFF" indi-	"AIR BAG
	cator lights	OFF"
	SRS warning light	On
	Front passenger's seat belt reminder light	Off
Devices	Front passenger airbag	
	Side airbag on the front	Deactivated
	passenger seats	
	Curtain shield airbag in the front	
	passenger side	Activated
	Front passenger's seat belt pretensioner	

- \*1: The system judges a person of adult size as an adult. When a smaller adult sits in the front passenger seat, the system may recognize him/her as a child depending on his/her physique and posture.
- \*2: In the event the front passenger does not wear a seat belt.
- \*3: When a larger child who has outgrown a child restraint system sits in the front passenger seat, the system may recognize him/her as an adult depending on his/her physique or posture.

- \*4: Never install a rear-facing child restraint system on the front passenger seat. A forward-facing child restraint system should only be installed on the front passenger seat when it is unavoidable. (→P. 109)
- \*5: In case the indicator is not illuminated, consult this manual as for installing the child restraint system properly. (→P. 113)

#### Front passenger occupant classification system precautions

Observe the following precautions regarding the front passenger occupant classification system.

Failure to do so may cause death or serious injury.

- Wear the seat belt properly.
- Make sure the front passenger's seat belt tab has not been left inserted into the buckle before someone sits in the front passenger seat.
- Make sure the "AIR BAG OFF" indicator light is not illuminated when using the seat belt extender for the front passenger seat. If the "AIR BAG OFF" indicator light is illuminated, disconnect the extender tongue from the seat belt buckle, then reconnect the seat belt. Reconnect the seat belt extender after making sure the "AIR BAG ON" indicator light is illuminated. If you use the seat belt extender while the "AIR BAG OFF" indicator light is illuminated, the front passenger airbag and side airbag on the front passenger side may not activate correctly, which could cause death or serious injury in the event of collision.
- Do not apply a heavy load to the front passenger seat or equipment.
- Do not put weight on the front passenger seat by putting your hands or feet on the front passenger seat seatback from the rear passenger seat.
- Do not let a rear passenger lift the front passenger seat with their feet or press on the seatback with their legs.
- Do not put objects under the front passenger seat.

#### **CAUTION**

#### Front passenger occupant classification system precautions

- Do not recline the front passenger seatback so far that it touches a rear seat. This may cause the "AIR BAG OFF" indicator light to be illuminated. which indicates that the passenger's airbags will not deploy in the event of a severe accident. If the seatback touches the rear seat, return the seatback to a position where it does not touch the rear seat. Keep the front passenger seatback as upright as possible when the vehicle is moving. Reclining the seatback excessively may lessen the effectiveness of the seat belt system.
- If an adult sits in the front passenger seat, the "AIR BAG ON" indicator light is illuminated. If the "AIR BAG OFF" indicator is illuminated, ask the passenger to sit up straight, well back in the seat, feet on the floor, and with the seat belt worn correctly. If the "AIR BAG OFF" indicator still remains illuminated, either ask the passenger to move to the rear seat, or if that is not possible, move the front passenger seat fully rearward.
- When it is unavoidable to install the forward-facing child restraint system. on the front passenger seat, install the child restraint system on the front passenger seat in the proper order. ( $\rightarrow$ P. 113)
- Do not modify or remove the front seats.
- Do not kick the front passenger seat or subject it to severe impact. Otherwise, the SRS warning light may come on to indicate a malfunction of the detection system. In this case, contact your Toyota dealer immediately.
- Child restraint systems installed on the rear seat should not contact the front seatbacks.
- Do not use a seat accessory, such as a cushion or seat cover, that covers the seat cushion surface.
- Do not modify or replace the upholstery of the front seat.

# **Child restraint systems**

A child restraint system for a small child or baby must be properly restrained on the seat with the lap portion of the lap/shoulder belt.

The laws of all 50 states of U.S.A. and Canada now require the use of child restraint systems.

### Points to remember

Studies have shown that installing a child restraint system on a rear seat is much safer than installing one to the front passenger seat.

- Choose a child restraint system that suits your vehicle and is appropriate to the age and size of the child.
- For installation details, follow the instructions provided with the child restraint system.

General installation instructions are provided in this manual.  $(\rightarrow P. 113)$ 

# Types of child restraints

Child restraint systems are classified into the following 3 types according to the age and size of the child.

▶ Rear facing — Infant seat/convertible seat



► Forward facing — Convertible seat



▶ Booster seat



### ■ Selecting an appropriate child restraint system

- Use a child restraint system appropriate for the child until the child becomes large enough to properly wear the vehicle's seat belt.
- If a child is too large for a child restraint system, sit the child on a rear seat and use the vehicle's seat belt. (→P. 64)



### Child restraint precautions

- For effective protection in automobile accidents and sudden stops, a child must be properly restrained, using a seat belt or child restraint system depending on the age and size of the child. Holding a child in your arms is not a substitute for a child restraint system. In an accident, the child can be crushed against the windshield, or between you and the vehicle's interior.
- Toyota strongly urges the use of a proper child restraint system that conforms to the size of the child, installed on the rear seat. According to accident statistics, the child is safer when properly restrained in the rear seat than in the front seat.
- Never install a rear-facing child restraint system on the front passenger seat even if the "AIR BAG OFF" indicator light is illuminated. In the event of an accident, the force of the rapid inflation of the front passenger airbag can cause death or serious injury to the child if the rear-facing child restraint system is installed on the front passenger seat.
- A forward-facing child restraint system may be installed on the front passenger seat only when it is unavoidable. A child restraint system that requires a top tether strap should not be used in the front passenger seat since there is no top tether strap anchor for the front passenger seat. Adjust the seatback as upright as possible and always move the seat as far back as possible even if the "AIR BAG OFF" indicator light is illuminated, because the front passenger airbag could inflate with considerable speed and force. Otherwise, the child may be killed or seriously injured.

### Child restraint precautions

- Do not use the seat belt extender when installing a child restraint system on the front or rear passenger seat. If installing a child restraint system with the seat belt extender connected to the seat belt, the seat belt will not securely hold the child restraint system, which could cause death or serious injury to the child or other passengers in the event of a sudden stop, sudden swerve or accident.
- Do not allow the child to lean his/her head or any part of his/her body against the door or the area of the seat, front and rear pillars or roof side rail from which the side airbags or curtain shield airbags deploy even if the child is seated in the child restraint system. It is dangerous if the side airbags and curtain shield airbags inflate, and the impact could cause death or serious injury to the child.
- Make sure you have complied with all installation instructions provided by the child restraint manufacturer and that the system is properly secured. If it is not secured properly, it may cause death or serious injury to the child in the event of a sudden stop, sudden swerve or an accident.

### Child restraint lock function belt precaution

Do not allow children to play with the child restraint lock function belt. If the belt becomes twisted around a child's neck, it will not be possible to pull the belt out leading to choking or other serious injuries that could result in death. If this occurs and the buckle cannot be unfastened, scissors should be used to cut the belt.

# When the child restraint system is not in use

- Keep the child restraint system properly secured on the seat even if it is not in use. Do not store the restraint unsecured in the passenger compartment.
- If it is necessary to detach the child restraint system, remove it from the vehicle or store it securely in the trunk. This will prevent it from injuring passengers in the event of a sudden stop, sudden swerve or accident.

# Installing child restraints

Follow the child restraint system manufacturer's instructions. Firmly secure child restraints to the outside rear seats using the LATCH anchors or a seat belt. Attach the top tether strap when installing a child restraint.

The lap/shoulder belt can be used if your child restraint system is not compatible with the LATCH (Lower Anchors and Tethers for Children) system.




Child restraint LATCH anchors

LATCH anchors are provided for the outside rear seats. (Buttons displaying the location of the anchors are attached to the seats.)



Seat belts equipped with a child restraint locking mechanism (ALR/ELR belts except driver's seat belt) (→P. 64)




Anchor bracket (for top tether strap)

Anchor brackets are provided for all rear seats.

# Installation with LATCH system

# ► Type A




- Widen the gap between the seat cushion and seatback slightly.
- Latch the hooks of the lower straps onto the LATCH anchors.
- step 3 If the child restraint has a top tether strap, the top tether strap should be latched onto the top tether strap anchor.

For owners in Canada:

A symbol on a restraint system indicates the presence of a lower connector system.

# ► Type B




- Widen the gap between the seat cushion and seatback slightly.
- STEP 2 Latch the buckles onto the LATCH anchors.
- step 3 If the child restraint has a top tether strap, the top tether strap should be latched onto the top tether strap anchor.

For owners in Canada:


A symbol on a restraint system indicates the presence of a lower connector system.

# Installing child restraints using a seat belt (child restraint lock function belt)


# ■ Rear facing — Infant seat/convertible seat



Place the child seat on the rear seat facing the rear of the vehicle.




Run the seat belt through the child seat and insert the plate into the buckle. Make sure that the belt is not twisted.



Fully extend the shoulder belt and then allow it to retract slightly in order to activate the ALR lock mode.


Lock mode allows the seat belt to retract only.




While pushing the child seat down into the rear seat, allow the shoulder belt to retract until the child seat is securely in place.

After the shoulder belt has retracted to a point where there is no slack in the belt, pull the belt to check that in cannot be extended.


# ■ Forward facing — Convertible seat



Place the child seat on the seat facing the front of the vehicle.




Run the seat belt through the child seat and insert the plate into the buckle. Make sure that the belt is not twisted.



Fully extend the shoulder strap and then allow it to retract slightly into the ALR lock mode.

Lock mode allows the seat belt to retract only.




While pushing the child seat into the rear seat, allow the shoulder belt to retract until the child seat is securely in place.

After the shoulder belt has retracted to a point where there is no slack in the belt, pull the belt to check that it cannot be extended.

STEP 5 If the child restraint has a top tether strap, the top tether strap should be latched onto the top tether strap anchor. ( $\rightarrow$ P. 119)

### ■ Booster seat



Place the booster seat on the seat facing the front of the vehicle.




Sit the child in the booster seat. Fit the seat belt to the booster seat according to the manufacturer's instructions and insert the plate into the buckle. Make sure that the belt is not twisted.

Check that the shoulder belt is correctly positioned over the child's shoulder, and that the lap belt is as low as possible.


 $(\to P. 64)$ 

# Removing a child restraint installed with a seat belt




Push the buckle release button and fully retract the seat belt.

# Child restraint systems with a top tether strap



Secure the child restraint using the seat belt or LATCH anchors. Remove the head restraint.



Open the anchor bracket cover, latch the hook onto the anchor bracket and tighten the top tether strap.

Make sure the top tether strap is securely latched.

### ■ Laws and regulations pertaining to anchorages

The LATCH system conforms to FMVSS225 or CMVSS210.2.

Child restraint systems conforming to FMVSS213 or CMVSS213 specifications can be used.

This vehicle is designed to conform to the SAE J1819.



# **CAUTION**

# ■When installing a booster seat

Do not fully extend the shoulder belt to prevent the belt from going to ALR lock mode: (→P. 67)

ALR mode causes the belt to tighten only which could cause injury or discomfort to the child.

# **A** CAUTION

### When installing a child restraint system

Follow the directions given in the child restraint system installation manual and fix the child restraint system securely in place.

If the child restraint system is not correctly fixed in place, the child or other passengers may be seriously injured or even killed in the event of sudden braking, sudden swerving or an accident.





- If the driver's seat interferes with the child restraint system and prevents it from being attached correctly, attach the child restraint system to the righthand rear seat.
- Adjust the front passenger seat so that it does not interfere with the child restraint system.
- Only put a forward-facing or booster child seat on the front seat when unavoidable. When installing a forwardfacing or booster child seat on the front passenger seat, move the seat as far back as possible even if the "AIR BAG OFF" indicator light is illuminated. Failing to do so may result in death or serious injury if the airbags deploy (inflate).

### When installing a child restraint system

- When a booster seat is installed, always ensure that the shoulder belt is positioned across the center of the child's shoulder. The belt should be kept away from the child's neck, but not so that it could fall off the child's shoulder. Failing to do so may result in death or serious injury in the event of sudden braking, sudden swerving or an accident.
- Ensure that the belt and tab are securely locked and the seat belt is not twisted.
- Push and pull the child seat from side to side and forward to be sure it is secure.
- Follow all installation instructions provided by the child restraint system manufacturer.
- When a child restraint system with a top tether strap is installed, do not install the head restraint. The head restraint may interfere with the top tether strap preventing secure installation of the child restraint system.
- Make sure to properly store the removed head restraint in a secure place when you use the child restraint system on the rear seat.

### Do not use a seat belt extender

If a seat belt extender is used when installing a child restraint system, the seat belt will not securely hold the child restraint system, which could cause death or serious injury to the child or other passengers in the event of sudden braking, sudden swerving or an accident.

# ■ To correctly attach a child restraint system to the anchors

When using the LATCH anchors, be sure that there are no foreign objects around the anchors and that the seat belt is not caught behind the child restraint system. Make sure the child restraint system is securely attached, or it may cause death or serious injury to the child or other passengers in the event of a sudden stop, sudden swerve or an accident.

2

2-1.	Driving procedures	
	Driving the vehicle	124
	Power (ignition) switch	135
	Transmission	139
	Turn signal lever	141
	Parking brake	142
	Horn	143
2-2.	Instrument cluster	
	Gauges and meters	144
	Indicators and warning lights	147
	Multi-information	
	display	150
2-3.	Operating the lights and wipers	
	Headlight switch	154
	Fog light switch	158
	Windshield wipers and	
	washer	159
2-4.	Using other driving systems	
	Cruise control	161
	Driving assist systems	
	Driving assist systems	100
2-5.	Driving information	
	Cargo and luggage	169
	Vehicle load limits	172
	Winter driving tips	173
	Trailer towing	177
	Dinghy towing	178

### 2-1. Driving procedures

# **Driving the vehicle**

The following procedures should be observed to ensure safe driving.

### ■ Starting the hybrid system (→P. 135)

## Driving

STEP 1 With the brake pedal depressed, shift the shift lever to D.

(→P. 139)

STEP 2 Release the parking brake.

(→P. 142)

Gradually release the brake pedal and gently depress the accelerator pedal to accelerate the vehicle.

# ■ Stopping

STEP 1 With the shift lever in D, depress the brake pedal.

STEP 2 If necessary, set the parking brake.

When the vehicle is stopped for an extended period of time, shift the shift lever to P.  $(\rightarrow P. 139)$ 

# ■ Parking the vehicle

STEP 1 With the shift lever in D, depress the brake pedal.

STEP 2 Set the parking brake.

(→P. 142)

STEP 3 Shift the shift lever to P.

(→P. 139)

When parking on a hill, if necessary, block the wheels.

STEP 4 Turn the "POWER" switch OFF and stop the hybrid system.

STEP 5 Lock the door, making sure that you have the electronic key on your person.

# Starting on a steep uphill

- STEP 1 Firmly set the parking brake and shift the shift lever to D.
- STEP 2 Gently depress the accelerator pedal.
- STEP 3 Release the parking brake.

### ■ Driving in the rain

- Drive carefully when it is raining, because visibility will be reduced, the windows may become fogged-up, and the road will be slippery.
- Drive carefully when it starts to rain, because the road surface will be especially slippery.
- Refrain from high speeds when driving on an expressway in the rain, because there may be a layer of water between the tires and the road surface, preventing the steering and brakes from operating properly.

# ■ Breaking in your new Toyota

To extend the life of the vehicle, the following precautions are recommended to observe:

- For the first 186 miles (300 km): Avoid sudden stops.
- For the first 994 miles (1600 km):
  - Do not drive at extremely high speeds.
  - · Avoid sudden acceleration.
  - Do not drive continuously in the low gears.
  - Do not drive at a constant speed for extended periods.

# ■ Drum-in-disc type parking brake system

Your vehicle has a drum-in-disc type parking brake system. This type of brake system needs bedding-down of the brake shoes periodically or whenever the parking brake shoes and/or drum are replaced. Have your Toyota dealer perform the bedding down.

# ■ Operating your vehicle in a foreign country

Comply with the relevant vehicle registration laws and confirm the availability of the correct fuel.  $(\rightarrow P. 452)$ 

### ■ For efficient use

- Put the shift lever into D when driving In the N position, the gasoline engine operates but electricity cannot be generated. The hybrid battery (traction battery) will be discharged requiring unnecessary engine power to recharge.
- Drive your vehicle smoothly Avoid abrupt acceleration and deceleration. Gradual acceleration and deceleration will make more effective use of the electric motor (traction motor) without having to use gasoline engine power.
- Avoid repeated acceleration Repeated acceleration consumes hybrid battery (traction battery) power, resulting in poor acceleration. Battery power can be restored by driving with the accelerator pedal slightly released.
- Put the shift lever into P when parking In the N position, the hybrid battery (traction battery) does not recharge. Leaving the shift lever in N for an extended period of the time may discharge the hybrid battery. The vehicle cannot run if the hybrid battery is discharged.

### ■ Brake actuator

The brake actuator uses brake fluid pressurized by the pump to power-assist the brakes. If the brake actuator fails during driving, the brake system warning light comes on and the buzzer sounds continuously. In this case, the brakes may not work properly. If they do not work well, depress the brake pedal firmly. If the brake system warning light comes on, immediately stop your vehicle and contact your Toyota dealer.

In the following conditions, you may hear a sound in the engine compartment. This is not a malfunction.

- The driver's door is opened with the hybrid system turned off.
- The brake pedal is depressed with the hybrid system turned off.
- After the hybrid system is turned on.
- The brake pedal is depressed repeatedly with the hybrid system turned on.
- After the hybrid system is turned off.

The brake pedal may be hard to depress or the brake pedal stroke may be short before turning the hybrid system on. This is not a malfunction.

# ■ When braking the vehicle

When applying brakes, you may hear a sound coming from the motor generator.

However, this does not indicate any trouble.

### When starting the vehicle

Always keep your foot on the brake pedal while stopped with the hybrid system operating. This prevents the vehicle from creeping.

### When driving the vehicle

- Do not drive if you are unfamiliar with the location of the brake and accelerator pedals to avoid depressing the wrong pedal.
  - Accidentally depressing the accelerator pedal instead of the brake pedal will result in sudden acceleration that may lead to an accident that could result in death or serious injury.
  - When backing up, you may twist your body around, leading to a difficulty in operating the pedals. Make sure to operate the pedals properly.
  - Make sure to keep a correct driving posture even when moving the vehicle only slightly, allowing you to depress the brake and accelerator pedals properly.
  - Depress the brake pedal using your right foot. Depressing the brake pedal using your left foot may delay response in an emergency, resulting in an accident.
- The driver should pay attention to pedestrians when the vehicle is powered only by the electric motor (traction motor). Because there is no engine noise, the pedestrians may misjudge the vehicle's movement.
- Do not drive the vehicle over or stop the vehicle near flammable materials. The exhaust system and exhaust gases can be extremely hot. This may cause a fire if there is any flammable material nearby.
- Do not let the vehicle roll backwards while the shift lever is in a driving position, or roll forward while the shift lever is in R. Doing so may cause the hybrid system to stall or lead to poor brake and steering performance, resulting in an accident or damage to the vehicle.
- If the smell of exhaust is noticed inside the vehicle, open the windows and check that the trunk is closed. Large amounts of exhaust in the vehicle can cause driver drowsiness and an accident, resulting in death or a serious health hazard. Have the vehicle inspected by your Toyota dealer immediately.

- Do not shift the shift lever to P while the vehicle is moving. Doing so can damage the transmission and may result in a loss of vehicle control.
- Do not shift the shift lever to R while the vehicle is moving forward. Doing so can damage the transmission and may result in a loss of vehicle control.
- Do not shift the shift lever to D while the vehicle is moving backward. Doing so can damage the transmission and may result in a loss of vehicle control.
- Moving the shift lever to N while the vehicle is moving will disengage the hybrid system. Engine braking is not available with the hybrid system disengaged.
- During normal driving, do not turn off the hybrid system. Turning the hybrid system off while driving will not cause loss of steering or braking control, but the power assist to these systems will be lost. This will make it more difficult to steer and brake, so you should pull over and stop the vehicle as soon as it is safe to do so.
  - However, in the event of an emergency, such as if it becomes impossible to stop the vehicle in the normal way:  $(\rightarrow P. 399)$
- Use engine braking to maintain a safe speed when driving down a steep hill.
  - Using the brakes continuously may cause the brakes to overheat and lose effectiveness. (→P. 140)
- When stopped on an inclined surface, use the brake pedal and parking brake to prevent the vehicle from rolling backward or forward and causing an accident.
- Do not adjust the position of the steering wheel, the seat, or the inside or outside rear view mirrors while driving.
  - Doing so may result in a loss of vehicle control that can cause accidents that may result in death or serious injury.

- Always check that all passengers' arms, heads or other parts of their bodies are not outside the vehicle, as this may result in death or serious injury.
- Do not drive in excess of the speed limit. Even if the legal speed limit permits it, do not drive over 85 mph (140 km/h) unless your vehicle has highspeed capability tires. Driving over 85 mph (140 km/h) may result in tire failure, loss of control and possible injury. Be sure to consult a tire dealer to determine whether the tires on your vehicle are high-speed capability tires or not before driving at such speeds.

### When driving on slippery road surfaces

- Sudden braking, acceleration and steering may cause tire slippage and reduce your ability to control the vehicle, resulting in an accident.
- Sudden changes in braking force, such as engine braking and regenerative braking caused by shifting the shift lever to the B position, may cause the vehicle to skid, resulting in an accident.
- After driving through a puddle, lightly depress the brake pedal to make sure that the brakes are functioning properly. Wet brake pads may prevent the brakes from functioning properly. If the brakes on only one side are wet and not functioning properly, steering control may be affected, resulting in an accident.

# When shifting the shift lever

Be careful not to shift the shift lever with the accelerator pedal depressed. This may lead to unexpected rapid acceleration of the vehicle that may cause an accident and result in death or serious injury.

# When the vehicle is stopped

- Do not race the engine. If the vehicle is in any gear other than P or N the vehicle may accelerate suddenly and unexpectedly, and may cause an accident.
- Do not leave the vehicle with the hybrid system on for a long time. If such a situation cannot be avoided, park the vehicle in an open space and check that exhaust fumes do not enter the vehicle interior.

# **A** CAUTION

- In order to prevent accidents due to the vehicle rolling away, always keep depressing the brake pedal while the "READY" indicator is on. Apply the parking brake as necessary.
- If the vehicle is stopped on an incline, in order to prevent accidents caused by the vehicle rolling forward or backward, always depress the brake pedal and securely apply the parking brake as needed.
- Avoid revving or racing the engine. Running the engine at high speed while the vehicle is stopped may cause the exhaust system to overheat, which could result in a fire if combustible material is nearby.

### When the vehicle is parked

- Do not leave glasses, cigarette lighters, spray cans, or soft drink cans in the vehicle when it is in the sun.
  - Doing so may result in the following.
  - Gas may leak from a cigarette lighter or spray can, and may lead to a fire.
  - The temperature inside the vehicle may cause the plastic lenses and plastic material of eye glasses to deform or crack.
  - Soft drink cans may fracture, causing the contents to spray over the interior of the vehicle, and may also cause a short circuit in the vehicle's electrical components.
- Always apply the parking brake, shift the shift lever to P, stop the hybrid system and lock the vehicle.
  - Do not leave the vehicle unattended while the hybrid system is operating.
- Do not touch the exhaust pipe while the hybrid system is operating or immediately after turning the hybrid system off.
  - Doing so may cause burns.
- Do not leave the hybrid system operating in an area with snow build-up, or where it is snowing. If snowbanks build up around the vehicle while the hybrid system is operating, exhaust gases may collect and enter the vehicle. This may lead to death or a serious health hazard.

### Exhaust gases

- Exhaust gases include harmful carbon monoxide (CO) that is colorless and odorless. Inhaling exhaust gases may lead to death or a serious health hazard.
- If the vehicle is in a poorly ventilated area, stop the hybrid system. In a closed area, such as a garage, exhaust gases may collect and enter the vehicle. This may lead to death or a serious health hazard.
- The exhaust should be checked occasionally. If there is a hole or crack caused by corrosion, damage to a joint or abnormal exhaust noise, be sure to have the vehicle inspected and repaired by your Toyota dealer. Failure to do so may allow exhaust gases to enter the vehicle, resulting in death or a serious health hazard.

### When taking a nap in the vehicle

Always turn the hybrid system off. Otherwise, you may accidentally move the shift lever or depress the accelerator pedal, which could cause an accident or fire due to hybrid system overheating. Additionally, if the vehicle is parked in a poorly ventilated area, exhaust gases may collect and enter the vehicle. leading to death or a serious health hazard.

# When braking the vehicle

- When the brakes are wet, drive more cautiously. Braking distance increases when the brakes are wet, and may cause one side of the vehicle to brake differently than the other side. Also the parking brake may not securely hold the vehicle.
- If the electronically controlled brake system does not operate, do not follow other vehicles closely and avoid downhills or sharp turns that require braking.
  - In this case, braking is still possible, but it will require more force on the pedal than usual. Braking distance may also increase.
- The brake system consists of 3 individual hydraulic systems: If one of the systems fails, the others will still operate. In this case, the brake pedal should be depressed more firmly than usual and braking distance becomes longer.
  - Do not drive your vehicle if any hydraulic circuit has failed. Have your brakes fixed immediately.

# NOTICE

### When driving the vehicle

Do not use the accelerator pedal or depress the accelerator and brake pedals together to hold the vehicle on a hill.

### When parking the vehicle

Always put the shift lever in P. Failure to do so may cause the vehicle to move or the vehicle may accelerate suddenly if the accelerator pedal is accidentally depressed.

### Avoiding damage to vehicle parts

- Do not turn the steering wheel fully in either direction and hold it there for a long time.
  - Doing so may damage the power steering motor.
- When driving over bumps in the road, drive as slowly as possible to avoid damaging the wheels, underside of the vehicle, etc.

# If you hear a squealing or scraping noise (brake pad wear limit indicators)

Have the brake pads checked and replaced by your Toyota dealer as soon as possible.

Rotor damage can result if the pads are not replaced when needed.

It is dangerous to drive the vehicle when the wear limits of the brake pads and/or that of the brake discs are exceeded.

# If you get a flat tire while driving

A flat or damaged tire may cause the following situations. Hold the steering wheel firmly and gradually press the brake pedal to slow down the vehicle.

- It may be difficult to control your vehicle.
- The vehicle will make abnormal sounds.
- The vehicle will behave abnormally.

Replace a flat tire with a new one. (→P. 421)



### **NOTICE**

### When encountering flooded roads

Do not drive on a road that has flooded after heavy rain etc. Doing so may cause the following serious damage to the vehicle.

- Engine stalling
- Short in electrical components
- Engine damage caused by water immersion

In the event that you drive on a flooded road and the vehicle is flooded, be sure to have your Toyota dealer check the following.

- Brake function
- Changes in quantity and quality of oil and fluid used for the engine, hybrid system transaxle, etc.
- Lubricant condition for the bearings and suspension joints (where possible) and the function of all joints, bearings, etc.

# Power (ignition) switch

Performing the following operations when carrying the electronic key on your person starts the hybrid system or changes "POWER" switch modes.


### Starting the hybrid system

STEP 1 Check that the parking brake is set.

STEP 2 Check that the shift lever is set in P.

STEP 3 Sit in the driver's seat and firmly depress the brake pedal.

The "POWER" switch indicator turns green. If the indicator does not turn green, the hybrid system cannot be started.



Press the "POWER" switch.


The hybrid system can be started from any mode.

After a while, the "READY" indicator comes on with a beep sound.

The vehicle can move when the "READY" indicator is on even if the engine is stopped.

# ■ Changing "POWER" switch mode

Modes can be changed by pressing the "POWER" switch with the brake pedal released. (The mode changes each time the switch is pressed.)



### OFF\*

Emergency flashers can be used.

### 2 ACCESSORY mode

Some electrical components such as the audio system can be used.

The "POWER" switch indicator turns amber.


### 3 ON mode

All electrical components can be used.

The "POWER" switch indicator turns amber.

\*: If the shift lever is in a position other than P when turning off the hybrid system, the "POWER" switch will be turned to ACCESSORY mode, not to OFF.

### ■ Steering lock release



Make sure that the steering wheel lock is released.

To release the steering wheel lock, gently turn the wheel left or right while pressing the "POWER" switch.

If the steering wheel lock does not release, the "POWER" switch indicator will flash green.

### ■ If the hybrid system does not start

The immobilizer system may not have been deactivated. ( $\rightarrow$ P. 88)

■ When the "POWER" switch indicator flashes in amber

The system may be malfunctioning. Have the vehicle inspected by your Toyota dealer immediately.

■ If the "READY" indicator does not come on

If the "READY" indicator does not come on when you press the "POWER" switch with the shift lever in P and the brake pedal depressed, contact your Toyota dealer immediately.

### ■ Auto power off function

If the vehicle is left in ACCESSORY mode for more than an hour with the shift lever in P, the "POWER" switch will automatically turn off.

■ When the ambient temperature is low, such as during winter driving conditions

It may take time until the "READY" indicator comes on.

■ Sounds and vibrations specific to a hybrid vehicle

→P. 24

■ When the hybrid system is malfunctioning

→P. 400

■ Electronic key battery depletion

→P. 43

### ■ When the electronic key battery is discharged

→P 372

### ■ Conditions affecting operation

→P. 41

### ■ Note for the smart key system

→P. 43



# **A** CAUTION

## When starting the hybrid system

Always start the hybrid system while sitting in the driver's seat. Do not depress the accelerator pedal while starting the hybrid system under any circumstances.

Doing so may cause an accident resulting in death or serious injury.

### Stopping the hybrid system in an emergency

If you want to stop the hybrid system in an emergency while driving the vehicle, push and hold the "POWER" switch for more than 3 seconds.

However, do not touch the "POWER" switch while driving except in an emergency. Turning the hybrid system off while driving will not cause loss of steering or braking control, but the power assist to these systems will be lost. This will make it more difficult to steer and brake, so you should pull over and stop the vehicle as soon as it is safe to do so.



### NOTICE

# ■ To prevent the 12-volt battery from being discharged


Do not leave the "POWER" switch in ACCESSORY or ON mode for long periods without the hybrid system on.

# When starting the hybrid system

- Do not race a cold engine.
- If the hybrid system becomes difficult to start, have the hybrid system checked immediately.

# Select a shift position appropriate for the driving conditions.

■ Shifting the shift lever



While the "POWER" switch is in ON mode, depress the brake pedal and move the shift lever.

# ■ Shift position uses


Shift position	Function
Р	Parking the vehicle or starting the hybrid system
R	Reversing
N	Neutral
D	Normal driving
В	Position for engine braking

### ■When in heavy traffic

If the shift lever is in N, the hybrid battery (traction battery) will not be charged. To help prevent the battery from discharging, avoid putting the shift lever in N for an extended period of time.

### ■ If the shift lever cannot be shifted from P

→P. 431



- Right turn
- 2 Left turn
- Move and hold the lever partway to signal a lane change.

The right hand signal will flash until you release the lever.

4 Move and hold the lever partway to signal a lane change.

The left hand signal will flash until you release the lever.

# ■ Turn signals can be operated when

The "POWER" switch is in ON mode.


### ■ If the indicators flash faster than usual

Check that a light bulb in the front or rear turn signal lights has not burned out.

CTN21AI059

# 2-1. Driving procedures

# Parking brake



Sets the parking brake\*

(Depressing the pedal again releases the parking brake.)

\*: Fully depress the parking brake pedal with your left foot while depressing the brake pedal with your right foot.

### **■**Usage in winter time

See "Winter driving tips" for parking brake usage in winter time. (→P. 173)




### Before driving

Fully release the parking brake.

Driving the vehicle with the parking brake set will lead to brake components overheating, which may affect braking performance and increase brake wear.

# Horn




To sound the horn, press on or close to the mark.

# ■ After adjusting the steering wheel

Make sure that the steering wheel is securely locked. The horn may not sound if the steering wheel is not securely locked.  $(\rightarrow P. 72)$ 

# **Gauges and meters**



The following gauges, meters and displays illuminate when the "POWER" switch is in ON mode.

■ Engine coolant temperature gauge Displays the engine coolant temperature.

# 2 Fuel economy meter

Displays the current fuel consumption in analog form when the hybrid system is operating.

When only the electric motor (traction motor) powers the vehicle, the needle indicates "E-MODE".

# 3 Speedometer

Displays the vehicle speed.

# 4 Fuel gauge

Displays the quantity of fuel remaining in the tank.

# Odometer/trip meter/instrument panel light control and trip meter reset button

Switches between odometer and trip meter. Pushing and holding the button when the trip meter is being displayed will reset the trip meter.


Instrument panel light control: →P. 145

# 6 Multi-information display

→P. 150

#### Instrument panel light control

The brightness of the instrument panel lights can be adjusted.




#### Brighter

#### 2 Darker

When the headlight switch is turned on, the brightness will be reduced slightly unless the control dial is turned fully clockwise.

#### **■** Eco drive level



The brightness of the arcs around the fuel economy meter and speedometer change according to the eco drive level. The higher the fuel economy, the brighter the light becomes.

The eco drive level is also displayed on the multi-information display. (→P. 151)

Average fuel consumption	The brightness of the arcs
25 MPG or less (9.0 L/100km or more)	Does not illuminate
26 to 30 MPG (8.8 to 8.0 L/100km)	Illuminates weakly
31 to 35 MPG (7.8 to 7.0 L/100km)	Illuminates brightly
36 MPG or more (6.8 L/100km or less)	Illuminates most brightly



#### **NOTICE**


#### ■ To prevent damage to the engine and its components

The gasoline engine may be overheating if the engine coolant temperature gauge is in the red zone (H). In this case, immediately stop the vehicle in a safe place. Check the gasoline engine after it has cooled completely.  $(\rightarrow P. 440)$ 


# Indicators and warning lights

The indicator and warning lights on the instrument cluster and center panel inform the driver of the status of the vehicle's various systems.

#### ► Instrument cluster



#### ► Center panel



#### ■ Indicators

The indicators inform the driver of the operating state of the vehicle's various systems.



Turn signal indicator (→P. 141)



Front fog light indicator (→P. 158)



Headlight high beam indicator (→P. 156)




SRS airbag on-off indicator ( $\rightarrow$ P. 104)



Slip indicator (→P. 166)



Cruise control indicator (→P. 161)



Shift position indicators (→P. 139)



Cruise control set indicator ( $\rightarrow$ P. 161)



Immobilizer indicator (→P. 88)



Driving ready indicator (→P. 135)



Headlight indicator (→P. 154)




Tail light indicator (→P. 154)

(CANADA)

#### ■ Warning lights

Warning lights inform the driver of malfunctions in any of the vehicle's systems. (→P. 399)



- indicator)
- \*1: These lights turn on when the "POWER" switch is turned to ON mode to indicate that a system check is being performed. They will turn off after the hybrid system is started, or after a few seconds. There may be a malfunction in a system if a light does not come on, or if the lights do not turn off. Have the vehicle inspected by your Toyota dealer for details.
- \*2: For vehicles sold in U.S.A.
- \*3: For vehicles sold in Canada

## **A** CAUTION


#### If a safety system warning light does not come on

Should a safety system light such as the ABS or the SRS warning light not come on when you start the hybrid system, this could mean that these systems are not available to help protect you in an accident, which could result in death or serious injury. Have the vehicle inspected by your Toyota dealer immediately if this occurs.

#### 2-2. Instrument cluster

### Multi-information display

The multi-information display presents the driver with a variety of driving-related data, including the outside temperature.



 Outside temperature display (→P. 151)

Indicates the outside tempera-

Trip information

(→P. 151)

Displays driving range, fuel consumption and other cruising-related information.

Warning messages

 $(\to P. 408)$ 


Automatically displayed when a malfunction occurs in one of the vehicle's systems.

 Odometer and trip meter display

Odometer: Displays the total distance the vehicle has been driven.

Trip meter: Displays the distance the vehicle has been driven since the meter was last reset. Trip meters A and B can be used to record and display different distances independently.

#### Switch the display



Display items can be switched by pressing the "DISP" button.

The display will return to the outside temperature display when the "DISP" button is pressed and held.

Outside temperature



Displays the outside air temperature.

The temperature range that can be displayed is from -40°F (-40°C) to 122°F (50°C).

Cruising range



Displays the estimated maximum distance that can be driven with the quantity of fuel remaining.

- This distance is computed based on your average fuel consumption. As a result, the actual distance that can be driven may differ from that displayed.
- When only a small amount of fuel is added to the tank, the display may not be updated.

#### Average fuel consumption



Displays the average fuel consumption since the function was reset.

The function can be reset by pressing the "DISP" button for longer than one second when the average fuel consumption is displayed.

#### Driving distance



Displays the driving distance since the hybrid system was started.

#### Average vehicle speed



Displays the average vehicle speed since the hybrid system was started.

#### Cruise information off



Displays the odometer and trip meters only.

#### Zoom display of odometer and trip meter



Displays the odometer and one of the trip meters simultaneously.

#### Energy monitor



Displays the operating condition of the hybrid system.  $(\rightarrow P. 27)$ 

#### Eco drive level



Displays the eco drive level and the average fuel consumption since the hybrid system was started.

When the eco drive level increases, the eco drive level display may appear on the display, even if other information is currently being shown. This does not indicate a malfunction.

#### ■ Outside temperature display

In the following situations, the correct outside temperature may not be displayed, or the display may take longer than normal to change.

- When stopped, or driving at low speeds (less than 12 mph [20 km/h])
- When the outside temperature has changed suddenly (at the entrance/ exit of a garage, tunnel, etc.)




#### ■ The multi-information display at low temperatures

Allow the interior of the vehicle to warm up before using the liquid crystal information display. At extremely low temperatures, the information display monitor may respond slowly, and display changes may be delayed.

## 2-3. Operating the lights and wipers Headlight switch

#### The headlights can be operated manually or automatically.

► For U.S.A.



AUTO

The headlights, parking lights, daytime running lights and so on turn on and off automatically.

(When the "POWER" switch is turned to ON mode)


-00- The side marker, parking, tail, license plate, daytime running lights and instrument panel lights turn on.

The headlights and all lights listed above (except daytime running lights) turn on.

DRL OFF

The daytime running lights turn off.

#### ► For Canada




- The daytime running lights turn on.
- The headlights, parking lights, daytime running lights and so on turn on and off automatically.

  (When the "POWER" switch is turned to ON
- The side marker, parking, tail, license plate, daytime running lights and instrument panel lights turn on.

mode)

The headlights and all lights listed above (except daytime running lights) turn on.

#### Turning on the high beam headlights



■ With the headlights on, push the lever forward to turn on the high beams.

Pull the lever back to the center position to turn the high beams off.

2 Pull the lever toward you to turn on the high beams.

Release the lever to turn them off. You can flash the high beams with the headlights on or off.


#### ■ Daytime running light system

To make your vehicle more visible to other drivers, the headlights turn on automatically (at a reduced intensity) whenever the hybrid system is started and the parking brake is released. Daytime running lights are not designed for use at night.

For U.S.A.: Daytime running lights can be turned off by operating the switch.

Compared to turning on the headlights, the daytime running light system offers greater durability and consumes less electricity, so it can help improve fuel economy.

#### ■ Headlight control sensor



The sensor may not function properly if an object is placed on the sensor, or anything that blocks the sensor is affixed to the windshield.

Doing so interferes with the sensor detecting the level of ambient light and may cause the automatic headlight system to malfunction.

#### ■ Automatic light off system

- When only the tail lights are on: The tail lights turn off automatically if the "POWER" switch is turned to ACCESSORY mode or turned OFF and the driver's door is opened.
- If any of the doors or trunk lid is left open, the lights automatically turn off after 20 minutes.

To turn the lights on again, turn the "POWER" switch to ON mode, or turn the headlight switch off and then back to  $\frac{1}{2}$ 00 or  $\frac{1}{2}$ 0 position.

#### ■ Customization that can be configured at Toyota dealer

Settings of light sensor sensitivity can be changed. (Customizable features →P. 474)

#### **↑** NOTICE


#### ■ To prevent the 12-volt battery from being discharged

Do not leave the lights on longer than necessary when the hybrid system is off.

# 2-3. Operating the lights and wipers

# Fog light switch\*

The fog lights improve visibility in difficult driving conditions, such as in rain or fog. They can be turned on only when the headlights are on low beam.




- 1 Off
- 2 Front fog lights on

# 2-3. Operating the lights and wipers Windshield wipers and washer


#### Wiper intervals can be adjusted for intermittent operation.



- Intermittent windshield wiper operation
- 2 Low speed windshield wiper operation
- If High speed windshield wiper operation
- Temporary operation



- Increases the intermittent windshield wiper frequency
- Decreases the intermittent windshield wiper frequency



# Wash/wipe operation

Wipers operate automatically.

#### ■ The windshield wipers and washer can be operated when

The "POWER" switch is in ON mode.

#### ■ If no windshield washer fluid sprays

Check that the washer nozzles are not blocked and if there is washer fluid in the windshield washer fluid reservoir.

#### $\bigwedge$ N

#### NOTICE

#### When the windshield is dry

Do not use the wipers, as they may damage the windshield.


#### ■ When there is no washer fluid spray from the nozzle

Damage to the washer fluid pump may be caused if the lever is pulled toward you and held continually.

#### When a nozzle becomes blocked


Do not try to clear it with a pin or other object. The nozzle will be damaged.

# Use the cruise control to maintain a set speed without depressing the accelerator pedal.




- 1 Indicators
- 2 Cruise control switch

### ■ Setting the vehicle speed



Press the "ON-OFF" button to activate the cruise control.

Press the button again to deactivate the cruise control.




Accelerate or decelerate the vehicle to the desired speed, and push the lever down to set the speed.

"SET" indicator will come on.

#### Adjusting the set speed

To change the set speed, operate the lever until the desired set speed is obtained.



- Increases the speed
- 2 Decreases the speed

Fine adjustment: Momentarily move the lever in the desired direction.


Large adjustment: Hold the lever in the desired direction.

The set speed will be increased or decreased as follows:

Fine adjustment: By approximately 1 mph (1.6 km/h) each time the lever is operated.

Large adjustment: The set speed can be increased or decreased continually until the lever is released.

#### ■ Canceling and resuming the constant speed control



1 Pulling the lever toward you cancels the constant speed control.

The speed setting is also canceled when the brakes are applied.

Pushing the lever up resumes the constant speed control.

Resuming is available when the vehicle speed is more than approximately 25 mph (40 km/h).

#### ■ Cruise control can be set when

- The shift lever is in D.
- Vehicle speed is above approximately 25 mph (40 km/h).

#### ■ Accelerating

The vehicle can be accelerated normally. After acceleration, the set speed resumes.

#### ■ Automatic cruise control cancelation

Cruise control will stop maintaining the vehicle speed in any of the following situations.

- Actual vehicle speed falls more than approximately 10 mph (16 km/h) below the preset vehicle speed.
   At this time, the memorized set speed is not retained.
- Actual vehicle speed is below approximately 25 mph (40 km/h).
- VSC is activated.

#### ■ If the cruise control indicator light flashes

Press the "ON-OFF" button once to deactivate the system, and then press the button again to reactivate the system.

If the cruise control speed cannot be set or if the cruise control cancels immediately after being activated, there may be a malfunction in the cruise control system. Have the vehicle inspected by your Toyota dealer.

### **CAUTION**

#### ■ To avoid operating the cruise control by mistake

Switch the cruise control off using the "ON-OFF" button when not in use.

#### Situations unsuitable for cruise control

Do not use cruise control in any of the following situations.

Doing so may result in loss of control and could cause an accident resulting in death or serious injury.

- In heavy traffic
- On roads with sharp bends
- On winding roads
- On slippery roads, such as those covered with rain, ice or snow
- On steep hills Vehicle speed may exceed the set speed when driving down a steep hill.
- During emergency towing

# 2-4. Using other driving systems Driving assist systems

To help enhance driving safety and performance, the following systems operate automatically in response to various driving situations. Be aware, however, that these systems are supplementary and should not be relied upon too heavily when operating the vehicle.

#### ■ ABS (Anti-lock Brake System)

Helps to prevent wheel lock when the brakes are applied suddenly, or if the brakes are applied while driving on a slippery road surface.

#### ■ Brake assist

Generates an increased level of braking force after the brake pedal is depressed, when the system detects a panic stop situation.

#### ■ VSC (Vehicle Stability Control)

Helps the driver to control skidding when swerving suddenly or turning on slippery road surfaces.

#### **■ TRAC (Traction Control)**

Helps to maintain drive power and prevent the front wheels from spinning when starting the vehicle or accelerating on slippery roads.


#### **■** EPS (Electric Power Steering)

Employs an electric motor to reduce the amount of effort needed to turn the steering wheel.

#### ■ VDIM (Vehicle Dynamics Integrated Management)

Provides integrated control of the ABS, VSC, TRAC and EPS systems. Maintains vehicle stability when swerving on slippery road surfaces by controlling the brakes, hybrid system output, and steering assist.

#### When VSC and TRAC are operating



If the vehicle is in danger of slipping or the front wheels spin, the indicator flashes to indicate that VSC/TRAC have been engaged.

A buzzer (intermittent) sounds to indicate that VSC is operating.

#### ■ Sounds and vibrations caused by ABS, brake assist, VSC and TRAC

- A sound may be heard from the engine compartment when the hybrid system is started or just after the vehicle begins to move. This sound does not indicate that a malfunction has occurred in any of these systems.
- Any of the following conditions may occur when the above systems are operating. None of these indicates that a malfunction has occurred.
  - Vibrations may be felt through the vehicle body and steering.
  - A motor sound may be heard after the vehicle comes to a stop.

#### ■ Reduced effectiveness of EPS

The effectiveness of EPS is reduced to prevent the system from overheating when there is frequent steering input over an extended period of time. The steering wheel may feel heavy as a result. Should this occur, refrain from excessive steering input or stop the vehicle and turn the hybrid system off. The system should return to normal within 10 minutes.

#### ■ If the slip indicator comes on...

It may indicate a malfunction in the VSC and TRAC. Contact your Toyota dealer.

#### **A** CAUTION

#### ABS does not operate effectively when

- Tires with inadequate gripping ability are used (such as excessively worn tires on a snow covered road).
- The vehicle hydroplanes while driving at high speed on the wet or slick road

#### ■ Stopping distance when ABS is operating on the wet or slick roads

ABS is not designed to shorten the vehicle's stopping distance. Always maintain a safe distance from the vehicle in front of you in the following situations.

- When driving on dirt, gravel or snow-covered roads
- When driving with tire chains
- When driving over bumps in the road
- When driving over roads with potholes or uneven roads

#### TRAC may not operate effectively when

Directional control and power may not be achievable while driving on slippery road surfaces, even if the TRAC system is operating.

Do not drive the vehicle in conditions where stability and power may be lost.



### **CAUTION**

#### When VSC is activated

The slip indicator light flashes and a warning buzzer sounds. Always drive carefully. Reckless driving may cause an accident. Exercise particular care when the indicator light flashes and a buzzer sounds.

#### Replacing tires

Make sure that all tires are of the same size, brand, tread pattern and total load capacity. In addition, make sure that the tires are inflated to the recommended tire pressure level.

The ABS and VSC system will not function correctly if different tires are fitted on the vehicle.

Contact your Toyota dealer for further information when replacing tires or wheels.

#### Handling of tires and suspension

Using tires with any kind of problem or modifying the suspension will affect the driving assist systems, and may cause the system to malfunction.

# Take notice of the following information about storage precautions, cargo capacity and load.

- Stow cargo and luggage in the trunk whenever possible.
- Be sure all items are secured in place.
- Be careful to keep the vehicle level. Placing the weight as far forward as possible helps maintain vehicle balance.
- For better fuel economy, do not carry unnecessary weight.

#### **Capacity and distribution**

Cargo capacity depends on the total weight of the occupants.

(Cargo capacity) = (Total load capacity) - (Total weight of occupants)


#### Steps for Determining Correct Load Limit—

- (1)Locate the statement "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs." on your vehicle's placard.
- (2) Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- (3)Subtract the combined weight of the driver and passengers from XXX kg or XXX lbs.
- (4)The resulting figure equals the available amount of cargo and luggage load capacity.
  - For example, if the "XXX" amount equals 1400 lbs. and there will be five 150 lb passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs.  $(1400 750 (5 \times 150) = 650 \text{ lbs.})$
- (5) Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in Step 4.

(6)If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle.

Toyota does not recommend towing a trailer with your vehicle. Your vehicle is not designed for trailer towing.

#### **Example on your vehicle**



- Cargo capacity
- Total load capacity

When 2 people with the combined weight of 366 lb. (166 kg) are riding in your vehicle, which has a total load capacity of 900 lb. (410 kg), the available amount of cargo and luggage load capacity will be as follows:

In this condition, if 3 more passengers with the combined weight of 388 lb. (176 kg) get on, the available cargo and luggage load will be reduced as follows:

As shown in the above example, if the number of occupants increases, the cargo and luggage load will be reduced by an amount that equals the increased weight due to the additional occupants. In other words, if an increase in the number of occupants causes an excess of the total load capacity (combined weight of occupants plus cargo and luggage load), you must reduce the cargo and luggage on your vehicle.

### **A** CAUTION

#### Storage precautions

Observe the following precautions.

Failing to do so may result in death or serious injury.

- To prevent cargo and luggage from sliding forward during braking, do not stack anything in the enlarged trunk. Keep cargo and luggage low, as close to the floor as possible.
- Never allow anyone to ride in the enlarged trunk. It is not designed for passengers. They should ride in their seats with their seat belts properly fastened. Otherwise, they are much more likely to suffer death or serious bodily injury, in the event of sudden braking, sudden swerving or an accident.
- Do not place cargo or luggage in or on the following locations as the item may get under the brake or accelerator pedal and prevent the pedals from being depressed properly, block the driver's vision, or hit the driver or passengers, causing an accident.
  - Driver's feet
  - Front passenger or rear seats (when stacking items)
  - Package tray
  - Instrument panel
  - Dashboard
- Secure all items in the occupant compartment, as they may shift and injure someone during sudden braking, sudden swerving or an accident.

#### Capacity and distribution

- Do not exceed the maximum axle weight rating or the total vehicle weight rating.
- Even if the total load of occupant's weight and the cargo load is less than the total load capacity, do not apply the load unevenly. Improper loading may cause deterioration of steering or braking control which may cause death or serious injury.

## 2-5. Driving information

#### Vehicle load limits

Vehicle load limits include total load capacity, seating capacity. towing capacity and cargo capacity.

#### ■ Total load capacity: 900 lb. (410 kg)

Total load capacity means the combined weight of occupants, cargo and luggage.

#### Seating capacity: 5 occupants (Front 2, Rear 3)

Seating capacity means the maximum number of occupants whose estimated average weight is 150 lb. (68 kg) per person.

#### ■ Towing capacity

Toyota does not recommend towing a trailer with your vehicle.

#### ■ Cargo capacity

Cargo capacity may increase or decrease depending on the weight and the number of occupants.

#### ■ Total load capacity and seating capacity

These details are also described on the tire and loading information label. (→P. 363)



#### **CAUTION**

#### Overloading the vehicle

Do not overload the vehicle.

It may not only cause damage to the tires, but also degrade steering and braking ability, resulting in an accident.

Carry out the necessary preparations and inspections before driving the vehicle in winter. Always drive the vehicle in a manner appropriate to the prevailing weather conditions.

#### ■ Pre-winter preparations

- Use fluids that are appropriate to the prevailing outside temperatures.
  - · Engine oil
  - Engine/power control unit coolant
  - · Washer fluid
- Have the vehicle fitted with four snow tires or purchase a set of tire chains for the front tires.

Ensure that all tires are the same size and brand, and that chains match the size of the tires.

#### ■ Before driving the vehicle

Perform the following according to the driving conditions.

- Do not try to forcibly open a window or move a wiper that is frozen. Pour warm water over the frozen area to melt the ice.
   Wipe away the water immediately to prevent it from freezing.
- To ensure proper operation of the climate control system fan, remove any snow that has accumulated on the air inlet vents in front of the windshield.
- Remove any ice that has accumulated on the vehicle chassis.
- Periodically check for and remove any excess ice or snow that may have accumulated in the wheel well or on the brakes.

#### ■ When driving the vehicle


Accelerate the vehicle slowly and drive at a reduced speed suitable to road conditions.

#### ■ When parking the vehicle

Park the vehicle and move the shift lever to P without setting the parking brake. The parking brake may freeze up, preventing it from being released. If necessary, block the wheels to prevent inadvertent sliding or creeping.

#### Selecting tire chains

Use the correct tire chain size when mounting the snow chains. Chain size is regulated for each tire size.



Side chain:

- 1 0.12 in. (3 mm) in diameter
- 2 0.39 in. (10 mm) in width
- 1.18 in. (30 mm) in length Cross chain:
- 4 0.16 in. (4 mm) in diameter
- 5 0.55 in. (14 mm) in width
- 6 0.98 in. (25 mm) in length

#### Regulations on the use of snow chains

- Regulations regarding the use of tire chains vary according to location and type of road. Always check local regulations before installing chains.
- Install the chains on the front tires.
- Retighten the chains after driving 1/4 1/2 mile (0.5 1.0 km).

#### ■ Tire chains

Observe the following precautions when installing and removing chains.

- Install and remove tire chains in a safe location.
- Install tire chains on the front tires only. Do not install tire chains on rear tires.
- Install tire chains following the instructions provided in the accompanying manual.



### Driving with snow tires

Observe the following precautions to reduce the risk of accidents. Failing to do so may result in a loss of vehicle control and cause death or serious injury.

- Use tires of the size specified for your vehicle.
- Maintain the recommended level of air pressure.
- Do not drive in excess of 75 mph (120 km/h), regardless of the type of snow tires being used.
- Use snow tires on all, not just some wheels.

#### Driving with tire chains

Observe the following precautions to reduce the risk of accidents.

Failing to do so may result in the vehicle being unable to be driven safely, and may cause death or serious injury.

- Do not drive in excess of the speed limit specified for the tire chains being used or 30 mph (50 km/h), whichever is lower.
- Avoid driving on bumpy road surfaces or over potholes.
- Avoid sudden turns and braking, as use of chains may adversely affect vehicle handling.
- Slow down sufficiently before entering a curve to ensure that vehicle control is maintained.

## $\Lambda$

#### **NOTICE**

#### Repairing or replacing snow tires

Request repairs of and obtain replacement snow tires from Toyota dealers or legitimate tire retailers.

This is because the removal and attachment of snow tires affects the operation of the tire pressure warning valves and transmitters.

#### Fitting tire chains


The tire pressure warning valves and transmitters may not function correctly when tire chains are fitted.

Toyota does not recommend towing a trailer with your vehicle. Toyota also does not recommend the installation of a tow hitch or the use of a tow hitch carrier for a wheelchair, scooter, bicycle, etc. Your Toyota is not designed for trailer towing or for the use of tow hitch mounted carriers.



# 2-5. Driving information **Dinghy towing**

Your vehicle is not designed to be dinghy towed (with 4 wheels on the ground) behind a motor home.





■ To avoid serious damage to your vehicle

Do not tow your vehicle with four wheels on the ground.

**Interior features** 

3

	system and defogger	
	Automatic air conditioning system	182
	Rear window and outside rear view	
	mirror defoggers	191
3-2.	Using the audio system	
	Audio system types	192
	Using the radio	195
	Using the CD player	202
	Playing MP3 and WMA	
	discs	210
	Operating an iPod	218
	Operating a USB	
	memory	225
	Optimal use of the	
	audio system	
	Using the AUX port	237
	Using the steering	
	wheel audio switches	239


3-1. Using the air conditioning

**Interior features** 

3-3.	Using the Bluetooth <sup>®</sup> audio system Bluetooth <sup>®</sup> audio system Using the Bluetooth <sup>®</sup>	242	3-5.	Using the interior lights Interior lights list • Interior light • Personal lights	292
	audio system  Operating a Bluetooth <sup>®</sup> enabled portable player  Setting up a Bluetooth <sup>®</sup> enabled portable player	250	3-6.	Using the storage features List of storage features Glove box Console box Cup holders Auxiliary boxes	29 <sup>2</sup> 29 <sup>3</sup> 29 <sup>3</sup>
	Bluetooth <sup>®</sup> audio system setup	257	3-7.	Other interior features Sun visors Vanity mirrors	
3-4.	Using the hands-free phone system (for cellular phone) Hands-free phone system (for cellular phone) features	262 270 274 279		Clock	303 304 305 307 309 310 313


# 3-1. Using the air conditioning system and defogger Automatic air conditioning system

Air outlets are automatically selected and fan speed is automatically adjusted according to the temperature setting.



## ■ "ECO HEAT/COOL" switch

"ECO HEAT/COOL" mode enables the air conditioning to be operated at a reduced capacity in order to limit use of the hybrid battery (traction battery). The effectiveness of the air conditioning will be lower than normal.



#### On/off

When "ECO HEAT/COOL" mode is turned on, the switch indicator will come on and the "ECO" indicator will appear on the air conditioning display.

## Using the automatic mode

STEP 1 Press AUTO .

The air conditioning system will begin to operate. Air outlets and fan speed are automatically adjusted according to the temperature setting.

STEP 2 Turning



to the right increases the temperature and

turning

driver's side.



to the left decreases the temperature on the

The temperature for the driver and passenger seats can be set separately.  $(\rightarrow P. 183)$ 

## Adjusting the settings

## Adjusting the temperature setting



to the right increases the temperature and turning



**Turning** 

to the left decreases the temperature on the driver's side.

to the right (increase) or (



to the left (decrease) on

the passenger's side to separately adjust the temperature for the pas-

senger's and driver's side (dual mode). Press



to return the

driver's and passenger side temperatures to the same setting (simultaneous mode).

The air conditioning system switches between dual and simultaneous

mode each time



is pressed.

## Adjusting the fan speed

Press "\" (increase) or "\" (decrease) on the fan speed selector.


The fan speed is shown on the display. (7 levels)

Press to turn the fan off.


## ■ Changing the air outlets

Press the air flow selector button.


The air outlets switch each time the button is pressed. The air flow shown on the display indicates the following.




Air flows to the upper body.



Air flows to the upper body and feet.



Air flows to the feet.



Air flows to the feet and the windshield defogger operates.


Recirculated air mode will automatically switch to outside air mode.

## ■ Switching between outside air and recirculated air modes

Press = .

The mode switches between outside air mode (indicator off) and recirculated air mode (indicator on) modes each time the button is pressed.

## Defogging the windshield




## Defogging

The air conditioning system control operates automatically.

Recirculated air mode will automatically switch to outside air mode. It is not possible to return to recirculated air mode when the windshield defogger switch is on.


## Adjusting the position of and opening and closing the air outlets

#### ▶ Center outlets




Direct air flow to the left or right, up or down.

## ▶ Right and left side outlets



- Direct air flow to the left or right, up or down.
- 2 Turn the knob right to open the vent and left to close the vent.


#### ▶ Rear outlets



- Direct air flow to the left or right, up or down.
- Turn the knob up to open the vent and down to close the vent.

## Steering wheel switches

Some air conditioning features can be controlled using the switches on the steering wheel.



## Temperature selector

"DUAL" button indicator on: Individual setting on the driver's side only.

"DUAL" button indicator off: Simultaneous setting on the driver's and front passenger's sides.

- 2 Automatic mode
- 3 Off

## **■** Using the automatic mode

STEP 1 Press AUTO .

The air conditioning system will begin to operate. Air outlets and fan speed are automatically adjusted according to the temperature setting. (→P. 188)

STEP 2 Press " $\land$ " to increase the temperature and " $\lor$ " to decrease the temperature on  $\bigcirc$ .

The temperature for the driver and passenger seat can be set separately.  $(\rightarrow P. 188)$ 

## ■ Adjusting the temperature setting

Press " $\wedge$ " to increase the temperature and " $\vee$ " to decrease the temperature on  $\bigcirc$ .

## ■ Turning off the air conditioning system

Press (off).

#### **■**Using the automatic mode

Fan speed is adjusted automatically in accordance with the temperature setting and ambient conditions. As a result, the following may occur.

- Immediately after is pressed, the fan may stop for a while until warm or cool air is ready to flow.
- Cool air may flow to the area around the upper body when the heater is

#### ■ Using the system in recirculated air mode

The windows will fog up more easily if the recirculated air mode is used for an extended period.

#### ■ When the "ECO HEAT/COOL" mode is canceled

- ■The temperature control is set at "LO" (the lowest temperature) or "HI" (the highest temperature).
- The air flow is set in the floor/windshield mode or windshield mode.
- ■The "ECO HEAT/COOL" switch is pushed again.

## ■ Switching between outside air and recirculated air modes

Recirculated air mode or outside air mode may be automatically switched to in accordance with the temperature setting and the inside temperature.

## ■ Window defogger feature

Recirculated air mode may automatically switch to outside air mode in situations where the windows need to be defogged.

## ■ When outside air temperature approaches 32°F (0°C)

The air conditioning system may not operate even when is pressed.

## ■ When the indicator light on flashes

Press and turn off the air conditioning system before turning it on once more. There may be a problem in the air conditioning system if the indicator light continues to flash. Turn the air conditioning system off and have it inspected by your Toyota dealer.

## ■ Air conditioning odors

- During use, various odors from inside and outside the vehicle may enter into and accumulate in the air conditioning system. This may then cause odor to be emitted from the vents.
- To reduce potential odors from occurring:
  - It is recommended that the air conditioning system be set to outside air mode prior to turning the vehicle off.
  - The start timing of the blower may be delayed for a short period of time immediately after the air conditioning system is started in automatic mode.

#### ■ Windshield air flow button

When the "POWER" switch is set at ON mode after the 12-volt battery is reconnected, the indicator light on the button may flash and a motor sound may be heard. This does not indicate a malfunction.

#### ■ Plasmacluster™\*

This air conditioning system adopts plasmacluster technology, which helps to keep good air quality in the cabin by emitting positive and negative ions through the driver's side vent.

A slight noise may be heard during operation. This is not a malfunction. Also, static electricity may be discharged near the driver's side vent due to the high voltage used to operate the system.

To clean the drive's side vent, turn the system off and wipe the vent using a soft cloth.

- \*: Plasmacluster technology is manufactured under license from the SHARP Corporation.
  - "Plasmacluster™" is a trademark of the SHARP Corporation.

## **CAUTION**

#### To prevent the windshield from fogging up

during cool air operation in extremely humid weather. The difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up, blocking vour vision.

#### Plasmacluster™

Do not disassemble or repair the system because it contains high voltage parts. Call your Toyota dealer if the system needs repair.

#### NOTICE

### ■ To prevent the 12-volt battery from being discharged


Do not leave the air conditioning system on longer than necessary when the hybrid system is off.

## To prevent damage to the Plasmacluster™

Do not insert anything into the driver's side vent, attach anything to it, or use sprays around the drive's side vent. These things may cause the system not to work properly.

## 3-1. Using the air conditioning system and defogger Rear window and outside rear view mirror defoggers

#### Clear the rear window using the defogger.



#### On/off

The defoggers will automatically turn off the operation time. The operation time is between 15 minutes and 1 hour depending on the ambient vehicle temperature and speed.

## ■ Outside rear view mirror defoggers (if equipped)

Turning the rear window defogger on will turn the outside rear view mirror defoggers on.



## CAUTION

## Outside rear view mirror defoggers (if equipped)

The surfaces of the outside rear view mirrors become hot. Do not touch them to prevent from burning yourself.

## 3-2. Using the audio system


## **Audio system types**

► With navigation system


Owners of models equipped with a navigation system should refer to the "Navigation System Owner's Manual".

► Without navigation system

Type A: CD player with changer controller and AM/FM radio



Type B: CD player with changer and AM/FM radio



Title	Page
Using the radio	P. 195
Using the CD player	P. 202
Playing MP3 and WMA discs	P. 210
Operating an iPod	P. 218
Operating a USB memory	P. 225
Optimal use of the audio system	P. 232
Using the AUX port	P. 237
Using the steering wheel audio switches	P. 239

## Language settings (type B only)

The language used for all voice guidance, voice recognition and messages may be changed.

- STEP 2 Press \_\_ that corresponds to "MORE".
- STEP 3 Press \_\_ that corresponds to "LANG".
- STEP 4 Press that corresponds to the desired language.
- ► For vehicles sold in the U.S.A. "ENG" (English) or "ESP" (Spanish)
- ► For vehicles sold in Canada
  - "ENG" (English) or "FRAN" (French)

#### ■ Using cellular phones

Interference may be heard through the audio system's speakers if a cellular phone is being used inside or close to the vehicle while the audio system is operating.



## **A** CAUTION

#### For vehicles sold in U.S.A. and Canada

Part 15 of the FCC Rules

FCC Warning:

Any unauthorized changes or modifications to this equipment will void the user's authority to operate this device.

- Laser products
  - Do not take this unit apart or attempt to make any changes yourself. This is an intricate unit that uses a laser pickup to retrieve information from the surface of compact discs. The laser is carefully shielded so that its rays remain inside the cabinet. Therefore, never try to disassemble the player or alter any of its parts since you may be exposed to laser rays and dangerous voltages.
  - This product utilizes a laser. Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.



#### NOTICE


## To prevent battery discharge

Do not leave the audio system on longer than necessary with the engine off.


## ■To avoid damaging the audio system

Take care not to spill drinks or other fluids over the audio system.

## ► Type A



## ► Type B



## Setting station presets (excluding XM® Satellite Radio)

STEP 1 Search for desired stations by turning or pressing "\" or "\" on SER-TRICK \( \).

STEP 2 Press and hold a button (from 1 to 6 or one of

Type B: Each time  $\stackrel{\text{PRESETS}}{=}$  is pressed, station pages are changed. There are a total of 6 pages.

## Scanning radio stations (excluding XM® Satellite Radio)

## ■ Scanning the preset radio stations

) until you hear a beep.

Press and hold or or until you hear a beep.

Preset stations will be played for 5 seconds each.

STEP 2 When the desired station is reached, press or again.

## ■ Scanning all radio stations within range

STEP 1 Press SCAN or SCAN .

All the stations with reception will be played for 5 seconds each.

STEP 2 When the desired station is reached, press again.

## ■ Displaying radio text messages (for type B, FM mode only)

When a new radio text message is received, "MSG" is shown on

the display. To display the message, press 📴

If the text continues past the end of the display, " > " is displayed. Press

and hold and until you hear a beep.

Text messages are not displayed while driving.

## XM® Satellite Radio (if equipped)

## ■ Receiving XM<sup>®</sup> Satellite Radio



The display changes as follows each time  $\[ \]$  or  $\[ \]$  is pressed.

Type A: AM  $\rightarrow$  SAT1  $\rightarrow$  SAT2  $\rightarrow$  SAT3

Type B:  $AM \rightarrow FM \rightarrow SAT$ 

STEP 2 Turn or to select the desired channel in all the

categories or press " $\land$ " or " $\checkmark$ " on  $\check{\ }$  to select the desired channel in the current category.

## ■ Setting XM<sup>®</sup> Satellite Radio channel presets

Select the desired channel. Press and hold a button (from

to for one of a until you hear a beep.

Type B: Each time is pressed, station pages are changed. There are a total of 6 pages.

## ■ Changing the channel category

Press " $\wedge$ " or " $\vee$ " on  $\stackrel{\scriptscriptstyle \vee}{=}$  or  $\stackrel{\scriptscriptstyle \vee}{=}$  or  $\stackrel{\scriptscriptstyle \vee}{=}$ .

## ■ Scanning XM<sup>®</sup> Satellite Radio channels

Scanning channels in the current category

STEP 2 When the desired channel is reached, press or

scan again.

Scanning the preset channels

STEP 1 Press and hold on or until you hear a beep.

STEP 2 When the desired channel is reached, press or

scan again.

## ■ Displaying text information

Press or EXT or EXT.

Type A: Each time is pressed, the display changes in the following

Channel name  $\rightarrow$  Title (song/program title)  $\rightarrow$  Name (artist name/feature) → Channel number.

Type B: Each time is pressed, the display changes in the following order:

Title (song/program title)  $\rightarrow$  Title (song/program title)/Name (artist name/feature).

#### ■ When the battery is disconnected

All preset stations are erased. (type A only)

#### ■ Reception sensitivity

- Maintaining perfect radio reception at all times is difficult due to the continually changing position of the antenna, differences in signal strength and surrounding objects, such as trains, transmitters, etc.
- The radio antenna is mounted inside the rear window. To maintain clear radio reception, do not attach metallic window tinting or other metallic objects to the antenna wire mounted inside the rear window.

#### ■ XM<sup>®</sup> Satellite Radio

An XM<sup>®</sup> Satellite Radio is a tuner designed exclusively to receive broadcasts provided under a separate subscription. Availability is limited to the 48 contiguous states and 10 Canadian provinces.

XM<sup>®</sup> subscriptions

For detailed information about XM<sup>®</sup> Satellite Radio or to subscribe:

U.S.A. —

Visit on the web at www.xmradio.com or call 1-800-967-2346.

Canada —

Visit on the web at www.xmradio.ca or call 1-877-438-9677.

Radio ID

You will need the radio ID when activating XM® service or reporting a

problem. Select "CH000" using or , and the receiver's 8-character ID number will appear.

Satellite tuner

The tuner supports only Audio Services (Music and Talk) and the accompanying Text Information of XM<sup>®</sup> Satellite Radio.

## ■If XM<sup>®</sup> Satellite Radio does not operate normally

If a problem occurs with the  $\rm XM^{\rm I\! B}$  tuner, a message will appear on the display. Refer to the table below to identify the problem, and take the suggested corrective action.

ANTENNA or	The XM <sup>®</sup> antenna is not connected. Check whether the XM <sup>®</sup> antenna cable is attached securely.
CHECK ANTENNA	There is a short-circuit in the antenna or the surrounding antenna cable. See a Toyota certified dealer.
UPDATING	You have not subscribed to XM <sup>®</sup> Satellite Radio. The radio is being updated with the latest encryption code. Contact XM <sup>®</sup> Satellite Radio for subscription information. When a contract is canceled, you can choose the "CH000" and all free-to-air channels.
OI DAING	The premium channel you selected is not authorized. Wait for about 2 seconds until the radio returns to the previous channel or "CH001". If it does not change automatically, select another channel. If you want to listen to the premium channel, contact XM <sup>®</sup> Satellite Radio.
NO SIGNAL	The XM <sup>®</sup> signal is too weak at the current location. Wait until your vehicle reaches a location with a stronger signal.
LOADING	The unit is acquiring audio or program information. Wait until the unit has received the information.
OFF AIR or CHANNEL OFF AIR	The channel you selected is not broadcasting any programming. Select another channel.
	There is no song/program title or artist name/feature associated with the channel at this time. No action needed.

The channel you selected is no longer available.
Wait for about 2 seconds until the radio returns to the previous channel or "CH001". If it does not change automatically, select another channel.

Contact the XM<sup>®</sup> Listener Care Center at 1-800-967-2346 (U.S.A.) or 1-877-438-9677 (Canada)

#### ■ Certifications for the radio tuner


This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by trying one or more of the following:


- Reorienting or relocating the receiving antenna.
- Increasing the separation between the equipment and receiver.
- Connecting the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consulting the dealer or an experienced radio/TV technician for help.

# 3-2. Using the audio system Using the CD player

## ▶ Type A



## ▶ Type B



## **Loading CDs**

■ Loading a CD (type A)

Insert a CD.

■ Loading a CD (type B)

- STEP 1 Press LOAD .
- STEP 2 When the indicator on the slot turns from amber to green, insert a CD.
- Loading multiple CDs (type B only)
- STEP 1 Press and hold until you hear a beep.
- STEP 2 When the indicator on the slot turns from amber to green, insert a CD.

The indicator on the slot turns to amber when the CD is inserted.

When the indicator on the slot turns from amber to green again, insert the next CD.

Repeat the procedure for the remaining CDs.

To cancel, press . If you do not insert a disc within 15 seconds, loading will be canceled automatically.

## **Ejecting CDs**

■ Ejecting a CD (type A)

Press and remove the CD.

■ Ejecting a CD (type B)

STEP 1 To select the CD to be ejected, press \_\_\_ that corresponds to "▲" or "▼".

The selected CD number is shown on the display.

STEP 2 Press and remove the CD.

■ Ejecting all the CDs (type B only)

Press and hold until you hear a beep, and then remove the CDs.

## Selecting a track

Press "\" to move up or "\" to move down using in until the desired track number is displayed.

## Fast-forwarding and reversing tracks

Type A: Press  $\boxed{5}$  ( $\blacktriangleleft$ ) or  $\boxed{6}$  ( $\blacktriangleright \triangleright$ ).

Type B: Press and hold " $\wedge$ " or " $\vee$ " on  $\stackrel{\scriptstyle \vee}{\longleftarrow}$  .

## Scanning tracks

The first ten seconds of each track will be played.

## Selecting a CD (type B only)

## ■ Selecting a CD to play

Press 

that corresponds to "▲" or "▼".

## ■ Scanning loaded CDs

The first ten seconds of the first track on each CD will be played.

## Playing and pausing tracks (type B only)

## Random playback

#### Current CD

Press (RAND) or that corresponds to "RDM".

Songs are played in random order.

To cancel, press the same button until "OFF" is displayed.

## ■ All CDs (type B only)

Press that corresponds to "RDM" twice.

Tracks on all loaded CDs are played in random order.

To cancel, press the button again.

## Repeat play

## ■ Repeating a track

Press (RPT) or that corresponds to "RPT".

To cancel, press the same button until "OFF" is displayed.

## ■ Repeating all of the tracks on a CD (type B only)

Press \_\_\_ that corresponds to "RPT" twice.

To cancel, press the button again.

## Switching the display

Press or EXT or EXT.

Type A: Each time is pressed, the display changes in the following order:

Track no./Elapsed time  $\rightarrow$  CD title  $\rightarrow$  Track name.

Type B: Each time is pressed, the display changes in the following order:

Track title  $\rightarrow$  Track name/Artist name  $\rightarrow$  Track name/Elapsed time.

### ■ Display (type A)

Up to 12 characters can be displayed at a time.

If there are 13 characters or more, pressing and holding for 1 second or more will display the remaining characters.

A maximum of 24 characters can be displayed.

If is pressed for 1 second or more again or has not been pressed for 6 seconds or more, the display will return to the first 12 characters.

Depending on the contents recorded, the characters may not be displayed properly or may not be displayed at all.

## ■ Error messages

"CD CHECK": This indicates a problem either with the CD or

inside the player. The CD may be dirty, dam-

aged or inserted up-side down.

"WAIT" or "PLEASE WAIT": Operation has stopped due to a high tempera-

ture inside the player. Wait for a while and

then press  $\begin{tabular}{ll} \begin{tabular}{ll} \begin{tabula$ 

Toyota dealer if the CD still cannot be played back.

#### Discs that can be used

Discs with the marks shown below can be used.

Playback may not be possible depending on the recording format or disc features, or due to scratches, dirt or deterioration.









CDs with copy-protection features may not be used.

#### **■CD** player protection feature

To protect the internal components, playback is automatically stopped when a problem is detected while the CD player is being used.

## ■If CDs are left inside the CD player or in the ejected position for extended periods

CDs may be damaged and may not play properly.

#### ■ Lens cleaners

Do not use lens cleaners. Doing so may damage the CD player.




## CDs and adapters that cannot be used

Do not use the following types of CDs, 3 in. (8 cm) CD adapters or Dual Discs.

Doing so may damage the CD player and/or the CD insert/eject function.




 CD player with changer and AM/FM radio: CDs that have a diameter that is not 4.7 in. (12 cm)



Low-quality and deformed CDs

## **↑** NOTICE



 CDs with a transparent or translucent recording area



 CDs that have had tape, stickers or CD-R labels attached to them, or that have had the label peeled off

## CD player precautions

Failure to follow the precautions below may result in serious damage to the CDs or the player itself.


- Do not insert anything other than CDs into the CD slot.
- Do not apply oil to the CD player.
- Store CDs away from direct sunlight.
- Never try to disassemble any part of the CD player.




 Do not insert more than one CD at a time.

## Playing MP3 and WMA discs

## ▶ Type A



## ► Type B



## Loading and ejecting MP3 and WMA discs

→P. 203

## Selecting MP3 and WMA discs (type B only)

→P. 205

## Selecting and scanning a folder

■ Selecting folders one at a time

Press "\" or "\" on "\" or "\"

■ Scanning the first file of all the folders

STEP 1 Press and hold or or until you hear a beep.

The first ten seconds of the first file in each folder will be played.

STEP 2 When the desired folder is reached, press again.

■ Returning to the first folder

Press and hold "v" on or or until you hear a beep.

## Selecting and scanning files

Selecting one file at a time

Turn or "v" on "v" on "THE-FOLKE OR to select the desired file.

■ Selecting the desired file by cueing the files in the folder

Press  $\bigcirc$  or  $\bigcirc$  .

When the desired file is reached, press or once again.

## Fast-forwarding and reversing files

Type A: Press  $\boxed{5}$  ( $\blacktriangleleft$ ) or  $\boxed{6}$  ( $\blacktriangleright \triangleright$ ).

Type B: Press and hold "∧" or "∨" on ŠEENTRACK ^.

## Playing and pausing files (type B only)

Press 🗀 .

## Random playback

■ Playing files from a particular folder in random order

Press (RAND) or that corresponds to "RDM".

To cancel, press the same button until "OFF" is displayed.

■ Playing all of the files on a disc in random order (type B only)

Press \_\_ that corresponds to "RDM" twice.

To cancel, press the button again.

## Repeat play

## ■ Repeating a file

Press (RPT) or that corresponds to "RPT".

To cancel, press the same button until the "OFF" is displayed.

## ■ Repeating all of the files in a folder (type B only)

Type A: Press and hold (RPT) until you hear a beep.

Type B: Press that corresponds to "RPT" twice.

To cancel, press the button again.

## ■ Repeating all of the files in a disc (type B only)

Press \_\_ that corresponds to "RPT" three times.

To cancel, press the same button again.

## Switching the display

Press 
$$\stackrel{\text{TEXT}}{ ext{ }}$$
 or  $\stackrel{\text{TEXT}}{ ext{ }}$ .

Type A: Each time is pressed, the display changes in the following order:

Folder no./File no./Elapsed time  $\rightarrow$  Folder name  $\rightarrow$  File name  $\rightarrow$  Album title (MP3 only)  $\rightarrow$  Track title  $\rightarrow$  Artist name.

Type B: Each time is pressed, the display changes in the following order:

Track title  $\to$  Track title/Artist name  $\to$  Track title/Album name  $\to$  Track title/Elapsed time.

#### ■ Display

→P. 207

#### ■ Error messages

"CD CHECK": This indicates a problem either with the CD or

inside the player. The CD may be dirty, dam-

aged or inserted up-side down.

"WAIT" or "PLEASE WAIT": Operation has stopped due to a high tempera-

ture inside the player. Wait for a while and then

press or . Contact your Toyota

dealer if the CD still cannot be played.

#### ■ Discs that can be used

→P. 207

## ■CD player protection feature

→P. 208

■If CDs are left inside the CD player or in the ejected position for extended periods

→P. 208

#### ■ Lens cleaners

→P. 208

#### ■ MP3 and WMA files

MP3 (MPEG Audio LAYER3) is a standard audio compression format.

Files can be compressed to approximately 1/10 of their original size by using MP3 compression.

WMA (Windows Media Audio) is a Microsoft audio compression format.

This format compresses audio data to a size smaller than that of the MP3 format.

There is a limit to the MP3 and WMA file standards and to the media/formats recorded by them that can be used.

- MP3 file compatibility
  - Compatible standards MP3 (MPEG1 LAYER3, MPEG2 LSF LAYER3)
  - Compatible sampling frequencies
     MPEG1 LAYER3: 32, 44.1, 48 (kHz)
     MPEG2 LSF LAYER3: 16, 22.05, 24 (kHz)
  - Compatible bit rates
     MPEG1 LAYER3: 64, 80, 96, 112, 128, 160, 192, 224, 256, 320 (kbps)
     MPEG2 LSF LAYER3: 64, 80, 96, 112, 128, 144, 160 (kbps)
    - \* Compatible with VBR
  - Compatible channel modes: stereo, joint stereo, dual channel and monaural
- WMA file compatibility
  - Compatible standards WMA Ver. 7, 8, 9
  - Compatible sampling frequencies 32, 44.1, 48 (kHz)
  - · Compatible bit rates

Ver. 7, 8: CBR 48, 64, 80, 96, 128, 160, 192 (kbps)

Ver. 9: CBR 48, 64, 80, 96, 128, 160, 192, 256, 320 (kbps)

\* Only compatible with 2-channel playback

#### Compatible media

Media that can be used for MP3 and WMA playback are CD-Rs and CD-RWs.

Playback in some instances may not be possible, depending on the status of the CD-R or CD-RW. Playback may not be possible or the audio may jump if the disc is scratched or marked with fingerprints.

#### Compatible disc formats

The following disc formats can be used.

- Disc formats: CD-ROM Mode 1 and Mode 2
   CD-ROM XA Mode 2, Form 1 and Form 2
- File formats: ISO9660 Level 1, Level 2, (Romeo, Joliet)
   MP3 and WMA files written in any format other than those listed above may not play correctly, and their file names and folder names may not be displayed correctly.

Items related to standards and limitations are as follows.

- · Maximum directory hierarchy: 8 levels
- Maximum length of folder names/file names: 32 characters
- Maximum number of folders: 192 (including the root)
- Maximum number of files per disc: 255

#### File names

The only files that can be recognized as MP3/WMA and played are those with the extension .mp3 or .wma.

#### Multi-sessions

As the audio system is compatible with multi-sessions, it is possible to play discs that contain MP3 and WMA files. However, only the first session can be played.

## ■ID3 and WMA tags

ID3 tags can be added to MP3 files, making it possible to record the track title and artist name, etc.

The system is compatible with ID3 Ver. 1.0, 1.1, and Ver. 2.2, 2.3 ID3 tags. (The number of characters is based on ID3 Ver. 1.0 and 1.1.)

WMA tags can be added to WMA files, making it possible to record the track title and artist name in the same way as with ID3 tags.

#### MP3 and WMA playback

When a disc containing MP3 or WMA files is inserted, all files on the disc are first checked. Once the file check is finished, the first MP3 or WMA file is played. To make the file check finish more quickly, we recommend you do not write in any files other than MP3 or WMA files or create any unnecessary folders.

If the discs contain a mixture of music data and MP3 or WMA format data, only music data can be played.

#### Extensions

If the file extensions .mp3 and .wma are used for files other than MP3 and WMA files, they will be mistakenly recognized and played as MP3 and WMA files. This may result in large amounts of interference and damage to the speakers.

#### Playback

- To play MP3 files with steady sound quality, we recommend a fixed bit rate of 128 kbps and a sampling frequency of 44.1 kHz.
- CD-R or CD-RW playback may not be possible in some instances, depending on the characteristics of the disc.
- There is a wide variety of freeware and other encoding software for MP3 and WMA files on the market, and depending on the status of the encoding and the file format, poor sound quality or noise at the start of playback may result. In some cases, playback may not be possible at all.
- When files other than MP3 or WMA files are recorded on a disc, it may take more time to recognize the disc. In some cases, playback may not be possible at all.
- Microsoft, Windows, and Windows Media are the registered trademarks of Microsoft Corporation in the U.S. and other countries.




- CDs and adapters that cannot be used (→P. 208)
- CD player precautions (→P. 209)

# Operating an iPod\*

Connecting an iPod enables you to enjoy music from the vehicle speakers.

# ■ Connecting an iPod




Open the cover and connect an iPod using an iPod cable.

Turn on the power of the iPod if it is not turned on.



#### ■ Control panel



# Selecting a play mode

Press that corresponds to "BROWSE" to select iPod menu mode.

STEP 2 Press \_\_\_ that corresponds to the desired play mode.


#### ■ Play mode list

Play mode	First selection	Second selection	Third selection	Fourth selection
PLIST	Playlist select	Songs select	-	-
ARTIST	Artist select	Albums select	Songs select	-
ALBUM	Albums select	Songs select	-	-
GENRE	Genre select	Artists select	Albums select	Songs select
SONGS	Songs select	-	-	-
PODCST	Albums select	Songs select	-	-
COMPSR	Composers select	Albums select	Songs select	-
воок	Songs select	-	-	-

Depending on the model, the name of your iPod may be displayed at the top of the list.

#### ■ Selecting a list





Pressing \_\_ that corresponds to "MORE" changes to the second selection list.

STEP 3 Repeat the same procedure to select the desired song name.

To return to the previous selection list, press in that corresponds

to " 🖍 ".

# Selecting songs from a list

STEP 1 Press \_\_ that corresponds to "LIST".

The current play list is displayed.

Turning to select the desired song.

Press returns the screen from list display to the previous screen.

#### Selecting songs

# Playing and pausing songs

Press 🗀 .

# Fast-forwarding and reversing songs

Press and hold "∧" or "∨" on SEEK-TRACK ...

#### Shuffle playback

■ Playing songs from one playlist or album in random order

Press that corresponds to "RDM".

To cancel, press the button twice.

■ Playing songs from all the playlists or albums in random order

Press that corresponds to "RDM" twice.

To cancel, press the button again.

# Repeat play

Press \_\_ that corresponds to "RPT".

To cancel, press the button again.

Even when the repeat play option has not been selected, playback will automatically continue from the first song in the current play list once the last song has ended.

# Switching the display

Each time is pressed, the display changes in the following order:

Track title  $\to$  Track title/Artist name  $\to$  Track title/Album name  $\to$  Track title/Elapsed time

#### ■ About iPod

- Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.
- iPod is a trademark of Apple Inc., registered in the U.S. and other countries.

#### **■iPod functions**

- When an iPod is connected and the audio source is changed to iPod mode, the iPod will resume play from the same point in which it was last used.
- Depending on the iPod that is connected to the system, certain functions may not be available. Disconnecting the device and reconnecting it once again may resolve some malfunctions.

#### **■iPod problems**

To resolve most problems encountered when using your iPod, disconnect your iPod from the vehicle iPod connection and reset it.

For instructions on how to reset your iPod, refer to your iPod Owner's Manual.

# ■ Cable pass-through

→P. 300

#### ■ Error messages

"IPOD ERROR": This indicates a problem in the iPod, inside the

USB box or the connection between them.

"NO SONGS": This indicates that there is no music data in the

iPod.

"UPDATE YOUR IPOD": This indicates that the version of the iPod is not

compatible.

#### ■ Compatible models

Model	Generation	Software version
iPod	5th generation	Ver. 1.2.0 or higher
iPod nano	1st generation	Ver. 1.3.0 or higher
	2nd generation	Ver. 1.1.2 or higher
	3rd generation	Ver. 1.0.0 or higher
iPod touch	1st generation	Ver. 1.1.0 or higher
iPod classic	1st generation	Ver. 1.0.0 or higher

Depending on differences between models or software version etc., some models listed above might be incompatible with this system.

iPod 4th generation and earlier models are not compatible with this system. iPhone, iPod mini, iPod shuffle and iPod photo are not compatible with this system.

Items related to standards and limitations are as follows:

Maximum number of lists in device: 9999

• Maximum number of songs in device: 65,025

• Maximum number of songs per list: 65,025



# **CAUTION**

#### Caution while driving

Do not connect iPod or operate the controls.



#### **NOTICE**


#### ■To prevent damage to iPod

- Do not leave iPod in the vehicle. The temperature inside may become high, resulting in damage to the player.
- On not push down on or apply unnecessary pressure to the iPod while it is connected as this may damage the iPod or its terminal.
- Do not insert foreign objects into the port as this may damage the iPod or its terminal.

# Operating a USB memory\*

Connecting a USB memory enables you to enjoy music from the vehicle speakers.

#### ■ Connecting a USB memory




Open the cover and connect a USB memory.

Turn on the power of the USB memory if it is not turned on.



# ■ Control panel



#### Selecting and scanning a folder

#### ■ Selecting a folder

Press "\" or "\" on The rouse to select the desired folder.

#### ■ Returning to the first file of the first folder

Press and hold "v" on until you hear a beep.

#### ■ Scanning the first file of all the folders

STEP 1 Press and hold until you hear a beep.

The first ten seconds of the first file in each folder will be played.

STEP 2 When the desired folder is reached, press again.

#### Selecting and scanning files

# ■ Selecting a file

Turn or "v" on to select the desired file.

# ■ Scanning the files in a folder

Press 
$$\stackrel{\text{scan}}{\Longrightarrow}$$
 .

The first ten seconds of each file will be played.

To cancel, press 
$$\stackrel{\text{scan}}{\Longrightarrow}$$
 again.

When the desired file is reached, press again.

#### Playing and pausing files

Press 🗀 .

#### Fast-forwarding and reversing files

Press and hold "\" or "\" on SEEK-TRACK \( \).

#### Random playback

■ Playing files from a folder in random order

Press \_ that corresponds to "RDM".

To cancel, press the button twice.

■ Playing all the files from a USB memory in random order

Press \_\_ that corresponds to "RDM" twice.

To cancel, press the button again.

# Repeat play

■ Repeating a file

Press that corresponds to "RPT".

To cancel, press the button twice.

■ Repeating all the files in a folder

Press \_\_\_ that corresponds to "RPT" twice.

To cancel, press the button again.

#### Switching the display

Each time is pressed, the display changes in the following order:

Track title  $\to$  Track title/Artist name  $\to$  Track title/Album name  $\to$  Track title/Elapsed time

#### **■USB** memory functions

Depending on the USB memory that is connected to the system, certain functions may not be available. Disconnecting the device and reconnecting it once again may resolve some malfunctions.

#### ■ Cable pass-through

→P. 300

#### ■ Error messages

"USB ERROR": This indicates a problem in the USB memory or its connection.

"NO MUSIC": This indicates that no MP3/WMA files are included in the USB memory.

#### **■USB** memory

Compatible device

USB memory that can be used for MP3 and WMA playback.

Depending on the type of USB device, playback may not be possible.

Compatible device formats

The following device formats can be used:

- USB communication formats: USB2.0 FS (12 mbps)
- File formats: FAT16/32 (Windows)
- Correspondence class: Mass storage class
   MP3 and WMA files written in any format other than those listed above
   may not play correctly, and their file names and folder names may not
   be displayed correctly.

Items related to standards and limitations are as follows:

- · Maximum directory hierarchy: 8 levels
- Maximum number of folder in device: 999 (including the root)
- Maximum number of files in device: 65,025
- Maximum number of files per folder: 255
- MP3 and WMA files

MP3 (MPEG Audio LAYER 3) is a standard audio compression format.

Files can be compressed to approximately 1/10 of their original size using MP3 compression.

WMA (Windows Media Audio) is a Microsoft audio compression format.

This format compresses audio data to a size smaller than that of the MP3 format.

There is a limit to the MP3 and WMA file standards that can be used and to the media/formats on which the files are recorded.

#### MP3 file compatibility

 Compatible standards MP3 (MPEG1 AUDIO LAYERII, III, MPEG2 AUDIO LAYERII, III, MPEG2.5)

• Compatible sampling frequencies

MPEG1 AUDIO LAYERII, III: 32, 44.1, 48 (kHz)

MPEG2 AUDIO LAYERII, III: 16, 22.05, 24 (kHz)

MPEG2.5: 8, 11.025, 12 (kHz)

Compatible bit rates (compatible with VBR)

MPEG1 AUDIO LAYERII, III: 32-320 (kbps)

MPEG2 AUDIO LAYERII, III: 32-160 (kbps)

MPEG2.5: 32-160 (kbps)

 Compatible channel modes: stereo, joint stereo, dual channel and monaural

#### WMA file compatibility

- Compatible standards WMA Ver. 9
- Compatible sampling frequencies HIGH PROFILE 32, 44.1, 48 (kHz)
- Compatible bit rates
   HIGH PROFILE 32-320 (kbps, VBR)

#### File names

The only files that can be recognized as MP3/WMA and played are those with the extension .mp3 or .wma.

#### ID3 and WMA tags

ID3 tags can be added to MP3 files, making it possible to record the track title, artist name, etc.

The system is compatible with ID3 Ver. 1.0, 1.1, and Ver. 2.2, 2.3, 2.4 ID3 tags. (The number of characters is based on ID3 Ver. 1.0 and 1.1.)

WMA tags can be added to WMA files, making it possible to record the track title and artist name in the same way as with ID3 tags.

#### MP3 and WMA playback

When a device containing MP3 or WMA files is plugged, all files in the USB memory device are first checked. Once the file check is finished, the first MP3 or WMA file is played. To make the file check finish more quickly, we recommend you do not write in any files other than MP3 or WMA files or create any unnecessary folders.

#### Extensions

If the file extensions .mp3 and .wma are used for files other than MP3 and WMA files, they will be mistakenly recognized and played as MP3 and WMA files. This may result in large amounts of interference and damage to the speakers.

#### Playback

- To play MP3 file with steady sound quality, we recommend a fixed bit rate of at least 128 kbps and a sampling frequency of 44.1 kHz.
- There is a wide variety of freeware and other encoding software for MP3 and WMA files on the market, and depending on the status of the encoding and the file format, poor sound quality or noise at the start of playback may result. In some cases, playback may not be possible at all.
- · Microsoft, Windows, and Windows Media are the registered trademarks of Microsoft Corporation in the U.S.A. and other countries.



#### **A** CAUTION

#### Caution while driving

Do not use a USB memory, or connect a USB memory.




#### NOTICE

# To prevent damage to a USB memory


- Do not leave a USB memory in the vehicle. The temperature inside may become high, resulting in damage to the player.
- Do not push down on or apply unnecessary pressure to the USB memory while it is connected as this may damage the USB memory or its terminal.
- Do not insert foreign objects into the port as this may damage the USB memory or its terminal.

# Optimal use of the audio system

# ► Type A



#### ► Type B



# Using the audio control function

#### ■ Changing sound quality modes

▶ Type A

Pressing selects the mode to be changed in the following order:

► Type B

STEP 2 Press \_\_ that corresponds to the desired mode.

# ■ Adjusting sound quality

# ▶ Type A

Mode displayed	Sound qual- ity mode	Level	Turn to the left	Turn to the right
BAS	Bass*	-5 to 5	Low	High
TRE	Treble*	-5 to 5	LOW	riigii
FAD	Front/rear volume balance	F7 to R7	Shifts to rear	Shifts to front
BAL	Left/right volume balance	L7 to R7	Shifts to left	Shifts to right

<sup>\*:</sup> The sound quality level is adjusted individually in each radio mode or CD mode.

#### ▶ Type B

Mode displayed	Sound qual- ity mode	Level	Turn to the left	Turn to the right
BASS	Bass*	-5 to 5		
MID	Mid-range*	-5 to 5	Low	High
TREB	Treble*	-5 to 5		
FADE	Front/rear volume balance	F7 to R7	Shifts to rear	Shifts to front
BAL	Left/right volume balance	L7 to R7	Shifts to left	Shifts to right

<sup>\*:</sup> The sound quality level is adjusted individually in each audio mode.

#### ■ Adjusting the Automatic Sound Levelizer (ASL)

# ▶ Type A

When "ASL" is selected, turning to the right changes the "ASL" level in the order of "LOW", "MID" and "HIGH".

Turning to the left turns "ASL" off.

ASL automatically adjusts the volume and tone quality according to vehicle speed.

#### ► Type B

STEP 1 Press SETUP .

STEP 2 Press that corresponds to "MORE".

STEP 3 Press \_\_ that corresponds to "ASL".

STEP 4 Press that corresponds to "ON" or "OFF".

ASL automatically adjusts the volume and tone quality according to vehicle speed.

#### ■ Setting the number of preset pages (type B only)

The number of preset pages desired can be set from 1 to 6. The initial setting is 6 pages.

STEP 1 Press SETUP .

STEP 2 Press \_\_\_ that corresponds to "MORE".

STEP 3 Press \_\_ that corresponds to "PRESET".

Press that corresponds to the desired number of preset pages.

# ■ Language settings (type B only)

→P. 193

#### ■ Trademark owned by SRS Labs, Inc. (type A only)





The audio systems utilize SRS FOCUS<sup>®</sup> and SRS TruBass<sup>®</sup> audio enhancement technologies, under license from SRS Labs, Inc., in all modes except AM radio mode.

FOCUS, TruBass, SRS and symbols are trademarks of SRS Labs, Inc.


FOCUS and TruBass technologies are incorporated under license from SRS Labs, Inc.

# **Using the AUX port**


This port can be used to connect a portable audio device and listen to it through the vehicle's speakers.

STEP 1 Open the cover and connect the portable audio device.

# ► Type A



# ► Type B





#### ■ Operating portable audio devices connected to the audio system

The volume can be adjusted using the vehicle's audio controls. All other adjustments must be made on the portable audio device itself.


# ■ When using a portable audio device connected to the power outlet Noise may occur during playback. Use the power source of the portable audio device.

#### ■ Cable pass-through

→P. 300

# Using the steering wheel audio switches

Some audio features can be controlled using the switches on the steering wheel.



- Increases/decreases volume
- 2 Radio mode: Select radio stations

CD mode: Select tracks, files (MP3 and WMA) and discs

iPod mode:

Selects a song

USB memory mode:

Selects a file and folder

Bluetooth® audio mode:

Selects a track and album

Turn the power on, selects an audio source

#### Turning the power on

Press MODE when the audio system is turned off.

The audio system can be turned off by holding the switch down until you hear a beep.

#### Changing the audio source

Press MODE when the audio system is turned on. The audio source changes as follows each time the switch is pressed.

Type A:

$$FM1 \rightarrow FM2 \rightarrow CD \rightarrow AUX \rightarrow AM \rightarrow SAT1 \rightarrow SAT2 \rightarrow SAT3$$

Type B:

#### Adjusting the volume

Press "+" on for to increase the volume and "-" to decrease the volume.

Press and hold the switch to continue increasing or decreasing the volume.

#### Selecting a radio station

STEP 1 Press Mode to select the radio mode.

STEP 2 Press "\" or "\" on I to select a preset station.

To scan for receivable stations, press and hold " $\checkmark$ " or " $\land$ " on  $\boxed{\ }$  until you hear a beep.

#### Selecting a track/file or folder

STEP 1 Press MODE to select the CD, iPod or USB memory mode.

STEP 2 Press "\" or "\" on \( \subseteq \) to select the desired track/file.

#### Selecting a folder

STEP 1 Press MODE to select the MP3 and WMA mode.

STEP 2 Press and hold "\" or "\" on I until you hear a beep.

#### Selecting a disc in the CD player (CD player with changer only)

STEP 1 Press Mode to select the CD mode.

STEP 2 Press and hold "\" or "\" on I until you hear a beep.

# **A** CAUTION

#### ■ To reduce the risk of an accident

Exercise care when operating the audio switches on the steering wheel.

# 3-3. Using the Bluetooth® audio system Bluetooth® audio system\*

The Bluetooth<sup>®</sup> audio system enables you to enjoy music played on a portable digital audio player (portable player) from the vehicle speakers via wireless communication.

This audio system supports Bluetooth<sup>®</sup>, a wireless data system capable of playing portable audio music without cables. If your portable player does not support Bluetooth<sup>®</sup>, the Bluetooth<sup>®</sup> audio system will not function.

Owners of models equipped with a navigation system should refer to the "Navigation System Owner's Manual".

Title	Page
Using the Bluetooth® audio system	P. 245
Operating a Bluetooth® enabled portable player	P. 250
Setting up a Bluetooth® enabled portable player	P. 252
Bluetooth <sup>®</sup> audio system setup	P. 257

#### ■ Conditions under which the system will not operate

- If using a portable player that does not support Bluetooth<sup>®</sup>
- If the portable player is switched off
- If the portable player is not connected
- If the portable player's battery is low
- If the portable player is behind the seat or in the glove box or console box
- If metal is covering or touching the portable player

#### ■ When transferring ownership of the vehicle

Be sure to initialize the system to prevent personal data from being improperly accessed.  $(\rightarrow P. 281)$ 

■ About Bluetooth®



Bluetooth is a registered trademark of Bluetooth SIG. Inc.

#### ■ Compatible models

- Bluetooth<sup>®</sup> specifications: Ver. 1.2
- Following Profiles:
  - A2DP (Advanced Audio Distribution Profile) Ver. 1.0
  - AVRCP (Audio/Video Remote Control Profile) Ver. 1.0 or higher (Ver. 1.3 or higher recommended)

Portable players must correspond to the above specifications in order to be connected to the Bluetooth<sup>®</sup> audio system. However, please note that some functions may be limited depending on the type of portable player.

# ■ Certification for the Bluetooth® audio system

FCC ID: BABFT0001A IC ID: 2024B-FT0001A

MADE IN JAPAN

This device complies with Part 15 of the FCC Rules and RSS-210 Rules. Operation is subject to the following two conditions; (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.



# **CAUTION**

#### FCC WARNING

Changes or modifications in construction not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radio frequency exposure. This device is approved for Mobile Application only and, to comply with applicable FCC radio frequency exposure regulations, must be used with a distance of at least 7.9in. (20cm) between the antenna and the body of any person at all time during use.

#### Caution while driving

Do not connect portable players or operate the controls.




#### NOTICE

#### ■ To prevent damage to portable players

Do not leave portable players in the vehicle. The temperature inside the vehicle may become high, resulting in damage to the player.

# 3-3. Using the Bluetooth® audio system Using the Bluetooth® audio system

#### ■ Audio unit



## Display

A message, name, number, etc. is displayed.

Lower-case characters and special characters cannot be displayed.


- Displays information that is too long to be displayed at one time on the display (press and hold)
- 3 Selects items such as menu and number

Turn: Selects an item
Press: Inputs the selected
item

4 Bluetooth® connection condition

If "BT" is not displayed, the Bluetooth<sup>®</sup> audio system cannot be used.

# ■ Microphone



# Operating the system using voice commands

By following voice guidance instructions output from the speaker, voice commands enable to the operation of the Bluetooth<sup>®</sup> audio sys-

tem without the need to check the display or operate



# ■ Operation procedure when using voice commands Press the talk switch and follow voice guidance instructions.

# ■ Auxiliary commands when using voice commands

The following auxiliary commands can be used when operating the system using a voice command:

"Cancel": Exits the Bluetooth® audio system

"Repeat": Repeats the previous voice guidance instruction

"Go back": Returns to the previous procedure

"Help": Reads aloud the function summary if a help comment is registered for the selected function

# Using the Bluetooth® audio system for the first time

Before using the Bluetooth<sup>®</sup> audio system, it is necessary to register a Bluetooth<sup>®</sup> enabled portable player in the system. Follow the procedure below to register (pair) a portable player:

STEP 1 Press until "BT AUDIO" is displayed.

STEP 2 Press that corresponds to "SETUP".

The introductory guidance and portable player name registration instructions are heard.

STEP 3 Select "Pair Audio Player" using a voice command or



STEP 4 Register a portable player name by either of the following methods:

- a. Select "Record Name" using , and say the name to be registered.
- b. Press the talk switch and say the name to be registered.

A voice guidance instruction to confirm the input is heard.

STEP 5 Select "Confirm" using a voice command or



A passkey is displayed and heard, and a voice guidance instruction for inputting the passkey into the portable player is heard.

STEP 6 Input the passkey into the portable player.

Refer to the manual that comes with the portable player for the operation of the portable player.

Guidance for registration completion is heard.

If the portable player has a Bluetooth<sup>®</sup> phone, the phone can be registered at the same time. (→P. 264)

# Menu list of the Bluetooth® audio system

# ■ Normal operation

First menu	Second menu	Third menu	Operation detail
"Setup"	"BT·A Setup"	"Pair Audio Player"	Registering a portable player
		"Select Audio Player"	Selecting a portable player to be used
		"Change Name"	Changing the registered name of a portable player
		"List Audio Play- ers"	Listing the registered porta- ble players
		"Set Passkey"	Changing the passkey
		"Delete Audio"	Deleting a registered porta- ble player
	"System Setup"	"Guidance Volume"	Setting voice guidance volume
		"Device Name"	Displaying the Bluetooth <sup>®</sup> device address and name
		"Initialize"	Initializing the system

<sup>&</sup>quot;BT•A Setup" can be canceled by pressing the on-hook switch or saying the voice command, "Cancel".

#### ■ When using a voice command

For numbers, say a combination of single digits from zero to nine. Say the command correctly and clearly.

#### ■ Situations that the system may not recognize your voice

- When driving on rough roads
- When driving at high speeds
- When air is blowing out of the vents onto the microphone
- When the air conditioning fan emits a loud noise

#### ■ Operations that cannot be performed while driving


- Operating the system with
- Registering a portable player to the system

#### ■ Changing the passkey

→P. 255

# 3-3. Using the Bluetooth® audio system

# Operating a Bluetooth® enabled portable player



# Selecting an album

Press " $\vee$ " or " $\wedge$ " on  $\stackrel{\mathsf{YMF-FRUBE}^{\wedge}}{=}$ .

# **Selecting tracks**

Press " $\wedge$ " or " $\vee$ " on  $\stackrel{\scriptscriptstyle\checkmark}{=}$  sectoral scales.

# Playing and pausing tracks

Press 🗀.

#### Fast-forwarding and reversing tracks

Press and hold "\" or "\" on SEK-TRACK \( \).

# Switching the display

Press the .

Each time is pressed, the display changes in the following order:

Track title  $\to$  Track title/Artist name  $\to$  Track title/Album name  $\to$  Track title/Elapsed time

# Using the steering wheel audio switches

→P. 239

# ■ Bluetooth<sup>®</sup> audio system functions

Depending on the portable player that is connected to the system, certain functions may not be available.

#### ■ Error messages

"BT AUDIO ERROR": This indicates a problem in the system.

# 3-3. Using the Bluetooth® audio system Setting up a Bluetooth® enabled portable player

Registering a portable player in the Bluetooth $^{\rm B}$  audio system allows the system to function. The following functions can be used for registered portable players:

**■** Functions and operation procedures



STEP 3 Select one of the following functions using a voice com-



- Registering a portable player "Pair Audio Player"
- Selecting a portable player to be used "Select Audio Player"
- Changing the registered name "Change Name"
- Listing the registered portable players "List Audio Players"
- Changing the passkey "Set Passkey"
- Deleting a registered portable player "Delete Audio Player (Delete Audio)"

## Registering a portable player

Select "Pair Audio Player" using a voice command or perform the procedure for registering a portable player. (→P. 247)

### Selecting a portable player to be used

STEP 1 Select "Select Audio Player" using a voice command or



STEP 2 Select the portable player to be used by either of the following methods, and select "Confirm" by using a voice command or



- a. Press the talk switch and say the name of the desired portable player.
- b. Press the talk switch and say "List Audio Players". When the name of the desired portable player is read aloud, press the talk switch.

STEP 3 Press the talk switch and say "From Car" or "From Audio", and

select "Confirm" by using a voice command or  $\underline{\mathbf{q}}$ 



If "From Car" is selected, the portable player will be automatically connected whenever the "POWER" switch is in either ACCESSORY or IGNITION ON mode.

## Changing the registered name of a portable player

STEP 1 Select "Change Name" using a voice command or



STEP 2 Select the name of the portable player to be changed by either of the following methods, and select "Confirm" using a

voice command or

- a. Press the talk switch and say the name of desired portable player.
- b. Press the talk switch and say "List Audio Players". When the name of the desired portable player is read aloud, press the talk switch.

Press the talk switch or select "Record Name" using and say the new name.



STEP 4 Select "Confirm" using a voice command or

## Listing the registered portable players

Select "List Audio Players" using a voice command or  $\equiv$ 



. The list

of registered portable players will be read aloud.

When listing is complete, the system returns to "BT•A Setup".

Pressing the talk switch while the name of a portable player is being read aloud selects the portable player, and the following functions will become available:

- Selecting a portable player: "Select Audio Player"
- Changing a registered name: "Change Name"
- Deleting a portable player: "Delete Audio Player (Delete Audio)"

## Changing the passkey

STEP 1 Select "Set Passkey" using a voice command or =



STEP 2 Press the talk switch, say a 4 to 8-digit number, and select

"Confirm" using a voice command or  $\underline{\exists}$ 




STEP 3 When the entire number to be registered as a passkey has

been input, press

If the number to be registered has 8 digits, pressing of the knob is not necessary.

### Deleting a registered portable player

STEP 1 Select "Delete Audio Player (Delete Audio)" using a voice



STEP 2 Select the portable player to be deleted by either of the following methods and select "Confirm" using a voice command or



- a. Press the talk switch and say the name of the desired portable player.
- b. Press the talk switch and say "List Audio Players". When the name of the desired portable player is read aloud, press the talk switch.

If the portable player to be deleted is paired as a Bluetooth<sup>®</sup> phone, the registration of the mobile phone can be deleted at the same time. A voice guidance instruction to delete a mobile phone is heard.

STEP 3 Select "Confirm" by using a voice command or



■The number of portable players that can be registered

Up to 2 portable players can be registered in the system.

# 3-3. Using the Bluetooth® audio system Bluetooth® audio system setup

■ System setup items and operation procedures

→P. 279

## 3-4. Using the hands-free phone system (for cellular phone) Hands-free phone system (for cellular phone) features\*

This system supports Bluetooth<sup>®</sup>, which allows you to make or receive calls without using cables to connect a cellular phone and the system, and without operating the cellular phone.

Owners of models equipped with a navigation system should refer to the "Navigation System Owner's Manual".

## ■ Hands-free system quick guide

STEP 1 Setting a cellular phone. (→P. 262)

STEP 2 Adding an entry to the phonebook (Up to 20 names can be stored) (→P. 283)

STEP 3 Dialing by inputting a name. ( $\rightarrow$ P. 271)

Title	Page
Using the hands-free phone system ■ Operating the system by using a voice command ■ Using the hands-free phone system for the first time ■ Menu list of the hands-free phone system	P. 262
Making a phone call  Dialing by inputting a number Dialing by inputting a name Speed dialing When receiving a phone call Transferring a call Using the call history memory	P. 270
Setting a cellular phone  Registering a cellular phone Selecting the cellular phone to be used Changing a registered name Listing the registered cellular phones Deleting a cellular phone Changing the passkey Turning the hands-free phone automatic connection on/off	P. 274
Security and system setup  Setting or changing the PIN  Locking or unlocking the phone book  Setting voice guidance volume  Initialization	P. 279
Using the phone book  Adding a new phone number  Setting speed dials  Changing a registered name  Deleting registered data  Deleting speed dials  Listing the registered data	P. 283

#### ■ Conditions affecting operation

The hands-free phone system may not operate normally in the following situations:

- The cellular phone is turned off, or located outside the service area.
- The cellular phone has a low battery.
- The cellular phone is not connected to the system.
- The cellular phone is behind the seat or in the glove box, or metal material covers or touches the phone.

#### ■ When transferring ownership of the vehicle

Be sure to initialize the system to prevent personal data from being improperly accessed.

#### ■ Required profiles for the cellular phone

- HFP (Hands Free Profile) Ver. 1.0
- OPP (Object Push Profile) Ver. 1.1

#### ■ About Bluetooth®



Bluetooth is a registered trademark of Bluetooth SIG. Inc.

## ■ Certification for the hands-free phone system

FCC ID: BABFT0001A IC ID: 2024B-FT0001A

MADE IN JAPAN

This device complies with Part 15 of the FCC Rules and RSS-210 Rules. Operation is subject to the following two conditions; (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.



## **A** CAUTION

#### FCC WARNING

Changes or modifications in construction not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radio frequency exposure. This device is approved for Mobile Application only and, to comply with applicable FCC radio frequency exposure regulations, must be used with a distance of at least 7.9in. (20cm) between the antenna and the body of any person at all time during use.

#### Caution while driving

Do not use a cellular phone, or connect the Bluetooth® phone.




#### **NOTICE**

#### To prevent damage to a cellular phone

Do not leave a cellular phone in the vehicle. The temperature inside may become high resulting in damage to the phone.

## 3-4. Using the hands-free phone system (for cellular phone) Using the hands-free phone system (for cellular phone)

### ■ Audio unit



Display

A message, name, phone number, etc. is displayed.

Lower-case characters and special characters, such as an umlaut, cannot be displayed.


- Displays information that is too long to be displayed at one time on the display (press and hold)
- 3 Selects speed dials
- Selects items such as menu or number

Turn: Selects an item
Press: Inputs the selected
item

**5** Bluetooth<sup>®</sup> connection condition and reception level

If "BT" is not displayed, the hands-free phone system cannot be used.

## ■ Steering wheel




### 1 Volume

The voice guidance volume cannot be adjusted using this button.

## On-hook switch Turns the hands-free system off/ends a call/refuses a call

- 3 Off-hook switch
  Turns the hands-free system on/starts a call
- Talk switch Turns the voice command system on (press)/turns the voice command system off (press and hold)

## **■** Microphone



## Operating the system by using a voice command

By following voice guidance instructions output from the speaker, voice commands enable to the operation of the hands-free phone

system without the need to check the display or operate



## ■ Operation procedure when using a voice command Press the talk switch and follow voice guidance instructions.

## ■ Auxiliary commands when using a voice command

The following auxiliary commands can be used when operating the system using a voice command:

Cancel: Exits the hands-free phone system

Repeat: Repeats the previous voice guidance instruction

Go back: Returns to the previous procedure

Help: Reads aloud the function summary if a help comment is

registered for the selected function

## Using the hands-free phone system for the first time

Before using the hands-free phone system, it is necessary to register a cellular phone in the system. The phone registration mode will be entered automatically when starting the system with no cellular phone registered. Follow the procedure below to register a cellular phone:

STEP 1 Press the off-hook switch or the talk switch.

The introductory guidance and phone name registration instructions are heard.

STEP 2 Select "Pair Phone" using a voice command or

STEP 3 Register a phone name by either of the following methods.

- a. Select "Record Name" by using be registered.
- b. Press the talk switch and say a name to be registered. A voice guidance instruction to confirm the input is heard.
- STEP 4 Select "Confirm" by using a voice command or
- ▶ Registration to the hans-free phone system only
- STEP 5 Select "Phone Only" using a voice command or =
- ▶ Registration to the hans-free phone system and Bluetooth<sup>®</sup> audio system at a same time
- STEP 5 Select "Internal Audio (Int. Audio)" using a voice command or



STEP 6 Select "Confirm" by using a voice command or



A passkey is displayed and heard, and a voice guidance instruction for inputting the passkey into the cellular phone is heard.

STEP 7 Input the passkey into the cellular phone. Refer to the manual that comes with the cellular phone for the operation of the phone.

Guidance for registration completion is heard.

## Menu list of the hands-free phone system

## ■ Normal operation

First menu	Second menu	Third menu	Operation detail
Callback	-	-	Dialing a number stored in the incoming call history memory
Redial	-	-	Dialing a number stored in the outgoing call history memory
Dial by number	-	-	Dialing by inputting a number
Dial by name	-	-	Dialing by inputting a name registered in the phone book
Phonebook	Add Entry	-	Adding a new number
	Change Name	-	Changing a name in the phone book
	Delete Entry	-	Deleting the phone book data
	Delete Speed Dial	-	Deleting a registered speed dial
	List Names	-	Listing the phone book data
	Set Speed Dial (Speed Dial)	-	Registering a speed dial

First menu	Second menu	Third menu	Operation detail
Setup Pho Set	Security	Set PIN	Setting a PIN code
		Phonebook Lock	Locking the phone book
		Phonebook Unlock	Unlocking the phone book
	Phone Setup	Pair Phone	Registering the cellular phone to be used
		Change Name	Changing a registered name of a cellular phone
		Delete Phone	Deleting a registered cellular phone
		List phones	Listing the registered cellular phones
		Select phone	Selecting a cellular phone to be used
		Set Passkey	Changing the passkey
		Hands-free power	Setting a Hands-free power on/off
	System Setup	Guidance Vol- ume	Setting voice guidance volume
		Device Name	Displaying a device information
		Initialize	Initialization

## ■ Using a short cut key

First menu	Second menu	Operation detail
Dial "XXX (name)"	-	Dialing a number registered in the phone book
Dial "XXX (number)"	-	Dialing the input numbers
Phone book add entry	-	Adding a new number
Phone book change name	-	Changing the name of a phone number in the phone book
Phone book delete entry	-	Deleting phone book data
Phone book set speed dial	-	Registering a speed dial
Phone book delete speed dial	-	Deleting a speed dial
Phonebook	Phonebook Unlock	Unlocking the phone book
	Phonebook Lock	Locking the phone book

#### ■ Automatic volume adjustment

When vehicle speed is 50 mph (80 km/h) or more, the volume automatically increases. The volume returns to the previous volume setting when vehicle speed drops to 43 mph (70 km/h) or less.

#### ■ When using a voice command

For numbers, say a combination of single digits from zero to nine, # (pound), \* (star), and + (plus).

Say a command correctly and clearly.

#### ■ Situations that the system may not recognize your voice

- When driving on a rough road
- When driving at high speeds
- When air is blowing out of the vents onto the microphone
- When the air conditioning fan emits a loud noise

#### ■ Operations that cannot be performed while driving

- Operating the system with
- Registering a cellular phone to the system
- Changing the passkey

→P. 277

## 3-4. Using the hands-free phone system (for cellular phone) Making a phone call

## ■ Making a phone call

- Dialing by inputting a number "Dial by number"
- Dialing by inputting a name "Dial by name"
- Speed dialing
- Dialing a number stored in the outgoing history memory "Redial"
- Dialing a number stored in the incoming history memory "Call back"

## ■ Receiving a phone call

- Answering the phone
- Refusing the call
- Transferring a call
- Using the call history memory
  - Dialing
  - Storing data in the phone book
  - Deleting

## Dialing by inputting a number

- STEP 1 Press the talk switch and say "Dial by number".
- STEP 2 Press the talk switch and say the phone number.
- STEP 3 Dial by one of the following methods:
  - a. Press the off-hook switch.
  - b. Press the talk switch and say "Dial".
  - c. Select "Dial" by using

## Dialing by inputting a name

- STEP 1 Press the talk switch and say "Dial by name".
- STEP 2 Select a registered name to be input by either of the following methods:
  - a. Press the talk switch and say a registered name.
  - b. Press the talk switch and say "List names". Press the talk switch while the desired name is being read aloud.
- STEP 3 Dial by one of the following methods:
  - a. Press the off-hook switch.
  - b. Press the talk switch and say "Dial".
  - c. Select "Dial" by using

## Speed dialing

- STEP 1 Press the off-hook switch.
- Press the preset button in which the desired number is registered.
- STEP 3 Press the off-hook switch.

## When receiving a phone call

■ Answering the phone

Press the off-hook switch.

■ Refusing the call

Press the on-hook switch.

## Transferring a call

A call can be transferred between the cellular phone and system while dialing, receiving a call, or during a call. Use one of the following methods:

- a. Operate the cellular phone.
  - Refer to the manual that comes with the cellular phone for the operation of the phone.
- b. Press the off-hook switch\*1.
- c. Press the talk switch and say "Call Transfer"\*2.
- \*1: This operation can be performed only when transferring a call from the cellular phone to the system during a call.
- \*2: While the vehicle is in motion, a call cannot be transferred from the system to the cellular phone.

## Using the call history memory

Follow the procedure below to use a number stored in the call history memory:

- STEP 1 Press the talk switch and say "Redial" (when using a number stored in the outgoing call history memory) or "Call back" (when using a number stored in the incoming call history memory).
- STEP 2 Select the number by either of the following methods:
  - Say "Previous" or "Go back" until the desired number is displayed.
  - b. Select the desired number by using

The following operations can be performed:

Dialing: Press the off-hook switch or select "Dial" by using a voice

command or

Storing the number in the phone book: Select "Store" by using a

voice command or

Deleting: Select "Delete" by using a voice command or  $\exists$ 



#### ■ Call history

Up to 5 numbers can be stored in each of the outgoing and incoming call history memories.

## ■ When talking on the phone

- Do not talk simultaneously with the other party.
- Keep the volume of the received voice down. Otherwise, voice echo will increase.

## 3-4. Using the hands-free phone system (for cellular phone) **Setting a cellular phone**

Registering a cellular phone in the hands-free phone system allows the system to function. The following functions can be used for registered cellular phones:

#### **■** Functions and operation procedures

To enter the menu for each function, follow the steps below by

using a voice command or

- Registering a cellular phone
  - 1. "Setup"  $\rightarrow$  2. "Phone Setup"  $\rightarrow$  3. "Pair Phone"
- Selecting the cellular phone to be used
  - 1. "Setup"  $\rightarrow$  2. "Phone Setup"  $\rightarrow$  3. "Select Phone"
- Changing a registered name
  - 1. "Setup" → 2. "Phone Setup" → 3. "Change Name"
- Listing the registered cellular phones
  - 1. "Setup"  $\rightarrow$  2. "Phone Setup"  $\rightarrow$  3. "List Phones"
- Deleting a cellular phone
  - 1. "Setup"  $\rightarrow$  2. "Phone Setup"  $\rightarrow$  3. "Delete"
- Changing the passkey
  - 1. "Setup"  $\rightarrow$  2. "Phone Setup"  $\rightarrow$  3. "Set Passkey"

## Registering a cellular phone

Select "Pair Phone" by using a voice command or , and do the procedure for registering a cellular phone. (→P. 264)

## Selecting the cellular phone to be used

STEP 1 Select "Select Phone" by using a voice command or =



#### ▶ Pattern A

STEP 2 Select the cellular phone to be used by either of the following methods, and select "Confirm" by using a voice command or



- a. Press the talk switch and say the desired phone name.
- b. Press the talk switch and say "List phones". While the name of the desired cellular phone is being read aloud, press the talk switch.

#### Pattern B

STEP 2 Select the cellular phone to be used by using



## Changing a registered name

STEP 1 Select "Change Name" by using a voice command or



- STEP 2 Select the name of the cellular phone to be changed by either of the following methods:
  - a. Press the talk switch and say the desired phone name, and

select "Confirm" by using a voice command or

b. Press the talk switch and say "List phones". While the desired phone name is being read aloud, press the talk switch.

c. Select the desired phone name by using  $\equiv$ 



STEP 3 Press the talk switch or select "Record Name" by using



STEP 4 Select "Confirm" by using a voice command or



### Listing the registered cellular phones

and say a new name.

Selecting "List Phones" by using a voice command or  $\equiv$ 



the list of registered cellular phones to be read aloud. When listing is complete, the system returns to "Phone Setup".

Pressing the talk switch while the name of a cellular phone is being read selects the cellular phone, and the following functions will be available:

- · Selecting a cellular phone: "Select Phone"
- · Changing a registered name: "Change Name"
- Deleting a cellular phone: "Delete Phone"

## Deleting a cellular phone

STEP 1 Select "Delete Phone" by using a voice command or



STEP 2 Select the cellular phone to be deleted by either of the following methods and select "Confirm" by using a voice command



- a. Press the talk switch and say the name of the desired cellular phone.
- b. Press the talk switch and say "List phones". While the name of the desired cellular phone is being read aloud, press the talk switch.

### Changing the passkey

STEP 1 Select "Set Passkey" by using a voice command or



STEP 2 Press the talk switch, say a 4 to 8-digit number, and select

"Confirm" by using a voice command or



The number should be input 1 digit at a time.

STEP 3 When the entire number to be registered as a passkey has

been input, press ag

## Turning the hands-free phone automatic connection on/off

## ■ Turning off the automatic connection

STEP 1 Select "Handsfree Power" by using a voice command or



STEP 2 Select "Turn off" by using a voice command or



#### ■ Turning on the automatic connection

STEP 1 Select "Handsfree Power" by using a voice command or



STEP 2 Select "Turn on" by using a voice command or



## ■The number of cellular phones that can be registered

Up to 6 cellular phones can be registered in the system.

## 3-4. Using the hands-free phone system (for cellular phone) Security and system setup

To enter the menu of each setting, follow the steps below:

### ■ Security setting items and operation procedure

- Setting or changing the PIN (Personal Identification Number)
  - 1. "Setup"  $\rightarrow$  2. "Security"  $\rightarrow$  3. "Set PIN"
- Locking the phone book
  - 1. "Setup"  $\rightarrow$  2. "Security"  $\rightarrow$  3. "Phonebook Lock"
- Unlocking the phone book
  - 1. "Setup"  $\rightarrow$  2. "Security"  $\rightarrow$  3. "Phonebook Unlock"

## ■ System setup items and operation procedure

- Setting voice guidance volume
  - 1. "Setup"  $\rightarrow$  2. "System Setup"  $\rightarrow$  3. "Guidance Volume"
- Initialization
  - 1. "Setup"  $\rightarrow$  2. "System Setup"  $\rightarrow$  3. "Initialize"



can only be used for system setup operation.

## Setting or changing the PIN

## ■ Setting a PIN

STEP 1 Select "Set PIN" by using a voice command or



STEP 2 Enter a PIN by using a voice command or



When using , input the code 1 digit at a time.

### ■ Changing the PIN

STEP 1 Select "Set PIN" by using a voice command or

STEP 2 Enter the registered PIN by using a voice command or



STEP 3 Enter a new PIN by using a voice command or \_\_\_\_\_.



When using , input the code 1 digit at a time.

## Locking or unlocking the phone book

STEP 1 Select "Phonebook lock" or "Phonebook unlock" by using a 

STEP 2 Input the PIN by either of the following methods and select

"Confirm" by using a voice command or ::

- a. Press the talk switch and say the registered PIN.
- b. Input a new PIN by using

## Setting voice guidance volume

STEP 1 Select "Guidance Volume" by using

STEP 2 Change the voice guidance volume.

To decrease the volume: Turn counterclockwise.

To increase the volume: Turn clockwise.

## Initialization

STEP 1 Select "Initialize" and then "Confirm" by using



STEP 2 Select "Confirm" by using

#### ■ Initialization

- The following data in the system can be initialized:
  - Phone book
  - · Outgoing and incoming call history
  - Speed dials
  - Registered cellular phone data
  - · Security code
- Once the initialization has been completed, the data cannot be restored to its original state.

#### ■When the phone book is locked

The following functions cannot be used:

- Dialing by inputting a name
- Speed dialing
- Dialing a number stored in the call history memory
- Using the phone book

## 3-4. Using the hands-free phone system (for cellular phone) Using the phone book

To enter the menu of each setting, follow the steps below:

- Adding a new phone number
  - 1. "Phonebook" → 2. "Add Entry"
- Setting speed dial
  - 1. "Phonebook" → 2. "Set Speed Dial (Speed Dial)"
- Changing a registered name
  - 1. "Phonebook" → 2. "Change Name"
- Deleting registered data
  - 1. "Phonebook" → 2. "Delete Entry"
- Deleting speed dial
  - 1. "Phonebook" → 2. "Delete Speed Dial"
- Listing the registered data
  - 1. "Phonebook" → 2. "List Names"

## Adding a new phone number

The following methods can be used to add a new phone number:

- Inputting a phone number by using a voice command
- Transferring data from the cellular phone
- Inputting a phone number by using
- Selecting a phone number from outgoing or incoming call history

TUNE-SCROLL

### ■ Adding procedure

- STEP 1 Select "Add Entry" by using a voice command or
- STEP 2 Use one of the following methods to input a telephone number:
- ▶ Inputting a telephone number by using a voice command STEP2-1 Select "By Voice" by using a voice command or



- STEP2-2 Press the talk switch, say the desired number, and select "Confirm" by using a voice command.
- ► Transferring data from the cellular phone
  - STEP2-1 Select "By Phone" and then "Confirm" by using a

voice command or

STEP2-2 Transfer the data from the cellular phone.

Refer to the manual that comes with the cellular phone for the details of transferring data.

- STEP2-3 Select the data to be registered by either of the following methods:
  - a. Say "Previous" or "Next" until the desired data is displayed, and select "Confirm" by using a voice command.
  - b. Select the desired data by using

▶ Inputting a phone number by using =



STEP2-1 Select "Manual Input" by using =



STEP2-2 Input a phone number by using ±



, and press




once again.

Input the phone number 1 digit at a time.

➤ Selecting a phone number from outgoing or incoming call history STEP2-1 Select "Call History" by using a voice command or



STEP2-2 Select "Outgoing" or "Incoming" by using a voice



- STEP2-3 Select the data to be registered by either of the following methods:
  - a. Say "Previous" or "Go back" until the desired data is displayed, and select "Confirm" by using a voice command.
  - b. Select the desired data by using

STEP 3 Select the name to be registered by either of the following methods, and select "Confirm" by using a voice command or



- a. Press the talk switch and say the desired name.
- b. Select "Record Name" by using , and say the desired name.

STEP 4 Select "Confirm" by using a voice command or

In STEP 3, selecting "Set Speed Dial (Speed Dial)" instead of "Confirm" registers the newly added phone number as a speed dial.

## **Setting speed dials**

STEP 1 Select "Set Speed Dial (Speed Dial)" by using a voice com-



- STEP 2 Select the data to be registered as a speed dial by either of the following methods:
  - a. Press the talk switch, say desired number, and select "Con-


firm" by using a voice command or

b. Press the talk switch, and say "List names". While the desired name is being read aloud, press the talk switch,

and select "Confirm" by using a voice command or



c. Select the desired data by using




a. Press the desired preset button, and select "Confirm" by

using a voice command or

b. Press and hold the desired preset button.

## Changing a registered name





- STEP 2 Select the name to be changed by either of the following methods.
  - a. Press the talk switch, say desired name, and select "Con-

firm" by using a voice command or

- b. Press the talk switch, and say "List names". While the desired name is being read aloud, press the talk switch,
  - and select "Confirm" by using a voice command or  $_{\exists_{\underline{a}}}$



- c. Select the desired name by using
- STEP 3 Select "Record Name" with or the talk switch.
- STEP 4 Say a new name, and select "Confirm" by using a voice com-

mand or

#### **Deleting registered data**

STEP 1 Select "Delete Entry" by using a voice command or



STEP 2 Select the data to be deleted by either of the following methods, and select "Confirm" by using a voice command or



- a. Press the talk switch, and say the name of the desired phone number to be deleted.
- b. Press the talk switch, say "List phones". While the name of the desired phone number is being read aloud, press the talk switch.

#### **Deleting speed dials**

STEP 1 Select "Delete Speed Dial" by using a voice command or



Press the preset button in which the desired speed dial is registered, and select "Confirm" by using a voice command or



# Listing the registered data


Selecting "List names" by using a voice command causes a list of the registered data to be read aloud.

When listing is complete, the system returns to "Phonebook". Pressing the talk switch while the desired data is being read aloud selects the data, and the following function will be available.

- · Dialing: "Dial"
- · Changing a registered name: "Change Name"
- Deleting an entry: "Delete Entry"
- · Setting a speed dial: "Set Speed Dial (Speed Dial)"

## ■ Limitation of number of digits

A phone number that exceeds 24 digits cannot be registered.



- Personal lights (→P. 293)
- 2 Interior light (→P. 292)
- 3 Front door courtesy light

## ■ Illuminated entry system

The interior light (with the switch in the "DOOR" position) automatically turns on/off according to "POWER" switch mode, the presence of the electronic key, whether the doors are locked/unlocked and whether the doors are open/closed.

# ■ To prevent the 12-volt battery from being discharged


If the interior light remains on when the door is not fully closed and the interior light switch is in the "DOOR" position, the light will go off automatically after 20 minutes.

# ■ Customization that can be configured at Toyota dealer

Settings (e.g. the time elapsed before lights turn off) can be changed. (Customizable features →P. 474)


# Interior light

▶ Vehicles without moon roof



- Door position
- 2 Off
- 3 On


▶ Vehicles with moon roof



- 1 Door position
- 2 Off
- 3 On


# Personal lights

## ▶ Front



On/off


# ► Rear (vehicles with moon roof)



#### On/off

When either of the rear side doors is opened, the light on that side turns on automatically. Closing the rear side doors will turn the lights off.

# List of storage features



- 1 Auxiliary boxes
- 2 Glove box
- 3 Cup holders
- 4 Console box


# **A** CAUTION

# ■ Items that should not be left in the storage spaces

Do not leave glasses, lighters or spray cans in the storage spaces, as this may cause the following when cabin temperature becomes high:

- Glasses may be deformed by heat or cracked if they come into contact with other stored items.
- Lighters or spray cans may explode. If they come into contact with other stored items, the lighter may catch fire or the spray can may release gas, causing a fire hazard.

#### Glove box



- Open (pull the lever)
- 2 Lock with the mechanical key
- 3 Unlock with the mechanical key

## ■ Glove box light

The glove box light turns on when the tail lights are turned on.




# **A** CAUTION

# Caution while driving

Keep the glove box closed.


Injuries may result in the event of an accident or sudden braking.

## Console box



Lift the lid while pulling the lever.

#### ■When using the console box lid as an armrest (if equipped)



If necessary, the console box lid can slide forward. Pull the lid forward by grasping the front of the lid.

# ■ Tray in the console box



The tray slides forward/backward and can be removed.



# **A** CAUTION


# Caution while driving

Keep the console box closed.

Injuries may result in the event of an accident or sudden braking.


# Cup holders

## ▶ Front




Push the lid.

#### ► Rear



Pull the armrest down.

# ■ Using the cup holder (front) to store small items



Remove the holder.



# **A** CAUTION

#### Items unsuitable for the cup holder

Do not place anything other than cups or aluminum cans in the cup holders. Other items may be thrown out of the holders in the event of an accident or sudden braking and cause injury. If possible, cover hot drinks to prevent burns.


#### When not in use

Keep the cup holders closed.

Injuries may result in the event of an accident or sudden braking.


# **Auxiliary boxes**

#### ▶ Driver's side instrument panel




Pull the handle.

#### Overhead console




Push the lid.

# ► Front console




Push the lid.

# ► Center console (type A)




Push the lid.

# ► Center console (type B)



Lift the lid.

## ■ Cable pass-through



The auxiliary box of the front console is provided with a hole that allows cables to be passed into the cabin from the inside power outlet and AUX port or AUX port/ USB port.

- 1 Remove the lid.
- 2 Push out and remove the outer lid.




# ■ Caution while driving

Keep the auxiliary boxes closed.


Injuries may result in the event of an accident or sudden braking.

# Sun visors



- 1 Forward position: Flip down.
- Side position: Flip down, unhook, and swing to the side.


# 3-7. Other interior features Vanity mirrors



# Slide the cover.

The light turns on when the cover is opened. (if equipped)

Interior features




- Adjusts the hour.
- 2 Adjusts the minutes.

# ■The clock is displayed when

The "POWER" switch is in ACCESSORY or ON mode.

# 3-7. Other interior features

# Ashtray\*



An ashtray can be installed in a cup holder. (→P. 297)

# **A** CAUTION

#### When not in use

Keep the ashtray closed.


Injuries may result in the event of sudden braking, sudden swerving or an accident.

#### ■ To prevent fire


- Fully extinguish matches and cigarettes before putting them in the ashtray, then make sure the ashtray is fully closed.
- Do not place paper or any other type of flammable object in the ashtray.

# The power outlet can be used for 12 V accessories that run on less than 10 A.

#### ► Front console



#### ► Center console



## ■ The power outlet can be used when

The "POWER" switch is in ACCESSORY or ON mode.

#### ■ Cable pass-through

Connected cables can be passed through the hole in the auxiliary box to the front passenger's side of the auxiliary box. ( $\rightarrow$ P. 300)

# **↑** NOTICE

#### ■To avoid damaging the power outlet

Close the power outlet lid when the power outlet is not in use.

Foreign objects or liquids that enter the power outlet may cause a short circuit.

#### ■ To prevent the fuse from being blown

Do not use an accessory that uses more than 12 V 10 A.

#### ■ To prevent the 12-volt battery from being discharged

Do not use the power outlet longer than necessary when the hybrid system is off.

# CTN36Al070

- Heats the left front seat
- 2 Heats the right front seat

The indicator light comes on.

#### ■ The seat heaters can be used when

The "POWER" switch is in ON mode.

#### ■ When not in use

Turn the seat heater off. The indicator light turns off.

# **A** CAUTION

#### Burns

- Use caution when seating the following persons in a seat with the seat heater on to avoid the possibility of burns:
  - · Babies, small children, the elderly, the sick and the disabled
  - Persons with sensitive skin
  - Persons who are fatigued
  - Persons who have taken alcohol or drugs that induce sleep (sleeping drugs, cold remedies, etc.)
- Do not cover the seat with anything when using the seat heater.
   Using the seat heater with a blanket or cushion increases the temperature of the seat and may lead to overheating.

# **⚠** NOTICE


#### ■To prevent seat heater damage

Do not put unevenly weighted objects on the seat and do not stick sharp objects (needles, nails, etc.) into the seat.

#### ■ To prevent the 12-volt battery from being discharged

Turn the switches off when the hybrid system is off.

# Armrest



Pull the armrest down for use.


# **↑** NOTICE

■ To prevent damage to the armrest

Do not place too much strain on the armrest.

## Floor mat

Use only floor mats designed specifically for vehicles of the same model and model year as your vehicle. Fix them securely in place onto the carpet.



Fix the floor mat in place using the retaining hooks (clips) provided

The shape of the retaining hooks (clips) and the fixing procedure of the floor mat for your vehicle may differ from those shown in the illustration. For details, refer to the floor mat retention clip installation instructions supplied with the clips.

## **A** CAUTION


Observe the following precautions.

Failure to do so may cause the driver's floor mat to slip, possibly interfering with the pedals while driving. An unexpectedly high speed may result or it may become difficult to stop the vehicle, leading to a serious accident.

# When installing the driver's floor mat

- Do not use floor mats designed for other models or different model year vehicles, even if they are Toyota Genuine floor mats.
- Only use floor mats designed for the driver's seat.
- Always install the floor mat securely using the retaining hooks (clips) provided.
- Do not use two or more floor mats on top of each other.
- Do not place the floor mat bottom-side up or upside-down.


## Before driving




- Check that the floor mat is securely fixed in the right place with all the provided retaining hooks (clips). Be especially careful to perform this check after cleaning the floor.
- With the hybrid system stopped and the shift lever in P, fully depress each pedal to the floor to make sure it does not interfere with the floor mat.

# 3-7. Other interior features **Trunk features**

# ■ Grocery bag hooks



# ■ Cargo net





■ To prevent damage to the cargo net hooks

Avoid hanging things other than a cargo net on them.

The garage door opener can be programmed to operate garage doors, gates, entry doors, door locks, home lighting systems, security systems, and other devices.


The garage door opener (HomeLink<sup>®</sup> Universal Transceiver) is manufactured under license from HomeLink<sup>®</sup>.

# Programming HomeLink® (for U.S. owners)

To ensure correct programming into the HomeLink<sup>®</sup>, install a new battery in the hand-held transmitter prior to programming. Failure to install a new battery into the hand-held transmitter will affect both the range and accuracy of the HomeLink<sup>®</sup> in your vehicle.


The battery side of the hand-held transmitter must be pointed away from the HomeLink<sup>®</sup> during the programming process.

The HomeLink<sup>®</sup> compatible transceiver in your vehicle has 3 buttons which can be programmed to operate 3 different devices. Refer to the programming method below appropriate for the device.




- Buttons
- Indicator

# ■ Programming HomeLink®




Point the remote control for the device 1 to 3 in. (25 to 75 mm) from the HomeLink $^{\circledR}$  control buttons.

Keep the indicator light on HomeLink® in view while programming.



Press and hold down one of the buttons on HomeLink<sup>®</sup> and the button on the transmitter. When the indicator light on HomeLink<sup>®</sup> changes from a slow to a rapid flash after 20 seconds, you can release both buttons.



Test the operation of HomeLink<sup>®</sup> by pressing the newly programmed button.

If programming a garage door opener, check to see if the garage door opens and closes. If the garage door does not operate, see if your garage transmitter is of the Rolling Code type. Press and hold the programmed HomeLink® button. The garage door has the rolling code feature light the indicator HomeLink®) flashes rapidly for 2 seconds and then remains lit. If your transmitter is of the Rolling Code type, proceed to the heading "Programming a rolling code system".

Repeat the steps above to program another device for each of the remaining HomeLink® buttons.

# ■ Programming a Rolling Code system (for U.S. owners)

If your device is Rolling Code equipped, follow the steps under the heading "Programming HomeLink®" before proceeding with the steps listed below.

Description of the ceiling-mounted garage door opener motor. The exact location and color of the button may vary by brand of garage door opener.

Refer to the operation manual supplied with the garage door opener for the location of the training button.

STEP 2 Press the training button.

Following this step, you have 30 seconds in which to initiate step 3 below.

Press and release the vehicle's programmed HomeLink® button twice. The garage door may open.

If the garage door opens, the programming process is complete. If the door does not open, press and release the button a third time. This third press and release will complete the programming process by opening the garage door.

The ceiling-mounted garage door opener motor should now recognize the HomeLink<sup>®</sup> transceiver and operate the garage door.

Repeat the steps above to program another rolling code system for any of the remaining HomeLink<sup>®</sup> buttons.

# ■ Programming an entry gate (for U.S. owners)/Programming all devices in the Canadian market

Place your transmitter 1 to 3 in. (25 to 75 mm) away from the surface of HomeLink<sup>®</sup>.

Keep the indicator light on HomeLink® in view while programming.

- STEP 2 Press and hold the selected HomeLink® button.
- Repeatedly press and release (cycle) the device's remote control button for two seconds each until step 4 is complete.

- When the indicator light on the HomeLink® compatible transceiver starts to flash rapidly, release the buttons.
- Test the operation of HomeLink® by pressing the newly programmed button. Check to see if the gate/device operates correctly.
- Repeat the steps above to program another device for each of the remaining HomeLink<sup>®</sup> buttons.

# **■** Programming other devices

To program other devices such as home security systems, home door locks or lighting, contact your authorized Toyota dealer for assistance.

# ■ Reprogramming a button


The individual HomeLink<sup>®</sup> buttons cannot be erased but can be reprogrammed. To reprogram a button, follow the "Programming" instructions.

# Operating HomeLink®

Press the appropriate HomeLink<sup>®</sup> button. The HomeLink<sup>®</sup> indicator light on the HomeLink<sup>®</sup> transceiver should turn on.

 $\mathsf{HomeLink}^{\circledR}$  continues to send a signal for up to 20 seconds as long as the button is pressed.

# Erasing the entire HomeLink® memory (all three programs)



Press and hold down the 2 outside buttons for 20 seconds until the indicator light flashes.

If you sell your vehicle, be sure to erase the programs stored in the HomeLink<sup>®</sup> memory.

#### ■ Before programming

- Install a new battery in the transmitter.
- The battery side of the transmitter must be pointed away from Homel ink®.

#### ■ Certification for the garage door opener

► For vehicles sold in the U.S.A.

FCC ID: CB2300NHL3

#### NOTF:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

► For vehicles sold in Canada

#### NOTE:

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

#### ■ When support is necessary

Visit on the web at www.homelink.com or call 1-800-355-3515.

# **CAUTION**

#### ■ When programming a garage door or other remote control device

The garage door may operate, so ensure people and objects are out of danger to prevent potential harm.

#### Conforming to federal safety standards


Do not use the HomeLink® compatible transceiver with any garage door opener or device that lacks safety stop and reverse features as required by federal safety standards.

This includes any garage door that cannot detect an obstruction object. A door or device without these features increases the risk of death or serious injury.

# Compass\*

The compass on the anti-glare inside rear view mirror indicates the direction in which the vehicle is heading.

# ■ Operation




To turn the compass on or off, press and hold "AUTO" for 3 seconds.

# ■ Displays and directions

Display	Direction
N	North
NE	Northeast
E	East
SE	Southeast
S	South
SW	Southwest
W	West
NW	Northwest

# Calibrating the compass




The direction display deviates from the true direction determined by the earth's magnetic field. The amount of deviation varies according to the geographic position of the vehicle.

If you cross over a map boundary shown in the illustration, the compass will deviate.

To obtain higher precision or perfect calibration, refer to the following.

#### ■ Deviation calibration

STEP 1 Stop the vehicle in a place where it is safe to drive in a circle.



Press and hold "AUTO" for 6 seconds.


A number (1 to 15) appears on the compass display.

Press "AUTO" and, referring to the map above, select the number of the zone where you are.

If the direction is displayed several seconds after adjustment, the calibration is complete.


#### ■ Circling calibration

STEP 1 Stop the vehicle in a place where it is safe to drive in a circle.



Press and hold "AUTO" for 9 seconds.

C appears on the compass display.



Drive the vehicle at 5 mph (8 km/h) or less in a circle until a direction is displayed.

If there is not enough space to drive in a circle, drive around the block until the direction is displayed.

#### ■ Conditions unfavorable for correct operation

The compass may not show the correct direction in the following situations:

- The vehicle is stopped immediately after turning.
- The vehicle is on an inclined surface.
- The vehicle is in a place where the earth's magnetic field is subject to interference by artificial magnetic fields (underground car park/parking lot, under a steel tower, between buildings, roof car park/parking lot, near an intersection, near a large vehicle, etc.).
- The vehicle has become magnetized.
   (There is a magnet or metal object near the anti-glare inside rear view mirror.)
- The 12-volt battery has been disconnected.
- A door is open.



# **A** CAUTION

#### While driving the vehicle

Do not adjust the display. Be sure to adjust the display only when the vehicle is stopped.

#### When doing the circling calibration

Be sure to secure a wide space, and watch out for people and vehicles in the neighborhood. Do not violate any local traffic rules while performing circling calibration.



#### NOTICE

#### To avoid compass malfunctions

Do not place magnets or any metal objects near the anti-glare inside rear view mirror.

Doing this may cause a malfunction of the compass sensor.

#### ■ To ensure normal operation of the compass

- Do not perform circling calibration of the compass in a place where the earth's magnetic field is subject to interference by artificial magnetic fields.
- During calibration, do not operate electric systems (moon roof, power windows, etc.) as they may interfere with the calibration.

**Maintenance and care** 

· · · ·	mamiconarios ana care	
	Cleaning and protecting the vehicle exterior	324
	Cleaning and protecting the vehicle interior	326
4-2.	Maintenance	
	Maintenance requirements	329
	General maintenance	331
	Emission inspection and maintenance (I/M)	
	programs	334
4-3.	Do-it-yourself	
	maintenance	
	Do-it-yourself service	
	precautions	335
	Hood	338
	Positioning a floor jack	339
	Engine compartment	341
	12-volt battery	350
	Tires	354
	Tire inflation pressure	363
	Wheels	367
	Air conditioning filter	369
	Key battery	372
	Checking and replacing	
	fuses	
	Light bulbs	385

# Cleaning and protecting the vehicle exterior

# Perform the following to protect the vehicle and maintain it in prime condition:

- Working from top to bottom, liberally apply water to the vehicle body, wheel wells and underside of the vehicle to remove any dirt and dust.
- Wash the vehicle body using a sponge or soft cloth, such as a chamois.
- For hard-to-remove marks, use car wash soap and rinse thoroughly with water.
- Wipe away any water.
- Wax the vehicle when the waterproof coating deteriorates.

If water does not bead on a clean surface, apply wax when the vehicle body is cool.

#### Automatic car washes

- Fold the mirrors back before washing the vehicle.
- Brushes used in automatic car washes may scratch the vehicle surface and harm your vehicle's paint.

#### ■ High pressure car washes

- Do not allow the nozzles of the car wash to come within close proximity of the windows.
- Before car wash, check that the fuel filler door on your vehicle is closed properly.

#### ■ Aluminum wheels

- Remove any dirt immediately by using a neutral detergent. Do not use hard brushes or abrasive cleaners. Do not use strong or harsh chemical cleaners. Use the same mild detergent and wax as used on the paint.
- Do not use detergent on the wheels when they are hot, for example after driving for long distance in the hot weather.
- Wash detergent from the wheels immediately after use.

#### Bumpers

Do not scrub with abrasive cleaners



#### **A** CAUTION

#### Caution about the exhaust pipe

Exhaust gasses cause the exhaust pipe to become guite hot.

When washing the vehicle, be careful not to touch the pipe until it has cooled sufficiently, as touching a hot exhaust pipe can cause burns.



#### NOTICE

## To prevent paint deterioration and corrosion on the body and components (aluminum wheels etc.)

- Wash the vehicle immediately in the following cases:
  - After driving near the sea coast
  - After driving on salted roads
  - If you see coal tar or tree sap on the paint surface
  - If you see dead insects or insect droppings on the paint
  - After driving in an area contaminated with soot, oily smoke, mine dust, iron powder or chemical substances
  - · If the vehicle becomes heavily soiled in dust or mud
  - If liquids such as benzene and gasoline are spilled on the paint surface
- If the paint is chipped or scratched, have it repaired immediately.
- To prevent the wheels from corroding, remove any dirt and store in a place with low humidity when storing the wheels.

# Cleaning the exterior lights

- Wash carefully. Do not use organic substances or scrub with a hard brush. This may damage the surfaces of the lights.
- Do not apply wax on the surfaces of the lights. Wax may cause damage to the lenses.

# Cleaning and protecting the vehicle interior

The following procedures will help protect your vehicle's interior and keep it in top condition:

### ■ Protecting the vehicle interior

Remove dirt and dust using a vacuum cleaner. Wipe dirty surfaces with a cloth dampened with lukewarm water.

#### ■ Cleaning the leather areas

- Remove dirt and dust using a vacuum cleaner.
- Wipe any excess dirt and dust with a soft cloth dampened with diluted detergent.

Use a diluted water solution of approximately 5% neutral wool detergent.

- Wring out any excess water from the cloth and thoroughly wipe off all remaining traces of detergent.
- Wipe the surface with a dry, soft cloth to remove any remaining moisture. Allow the leather to dry in a shaded ventilated area.

# **■** Synthetic leather areas

- Remove loose dirt using a vacuum cleaner.
- Apply a mild soap solution to the synthetic leather.
- Allow the solution to soak in for a few minutes. Remove the dirt and wipe off the solution with a clean, damp cloth.

#### ■ Caring for leather areas

Toyota recommends cleaning the interior of the vehicle at least twice a year to maintain the quality of the vehicle's interior.

#### ■ Shampooing the carpets

There are several commercial foaming-type cleaners available. Use a sponge or brush to apply the foam. Rub in overlapping circles. Do not apply water. Excellent results are obtained by keeping the carpet as dry as possible.

#### ■ Seat belts

Clean with mild soap and lukewarm water using a cloth or sponge. Also check the belts periodically for excessive wear, fraying or cuts.

# **A** CAUTION

#### Water in the vehicle

- Do not splash or spill liquid in the vehicle, such as on the floor, in the hybrid battery (traction battery) air vents, or in the trunk.
   Doing so may cause the hybrid battery, electrical components etc. to mal-
  - Doing so may cause the hybrid battery, electrical components etc. to malfunction or catch fire.
- Do not get any of the SRS components or wiring in the vehicle interior wet.
   (→P. 93)

Electrical malfunction may cause the airbags to deploy or not function properly, resulting in death or severe injury.

# Cleaning the interior (especially instrument panel)

Do not use polish wax or polish cleaner. The instrument panel may reflect off the windshield, obstructing the driver's view and leading to an accident, resulting in death or serious injury.

# **⚠** NOTICE

#### Cleaning detergents

- Do not use organic substances such as benzene or gasoline, acidic or alkaline solutions, dye, bleach or other detergent. Doing so may discolor the vehicle interior or cause streaks or damage to painted surfaces.
- Do not use polish wax or polish cleaner. The instrument panel's or other interior part's painted surface may be damaged.

#### Preventing damage to leather surfaces

Observe the following precautions to avoid damage to and deterioration of leather surfaces.

- Remove any dust or dirt on leather surfaces immediately.
- Do not expose the vehicle to direct sunlight for extended periods of time.
   Park the vehicle in the shade, especially during summer.
- Do not place items made of vinyl, plastic, or that contain wax, on the upholstery, as they may stick to the leather surface if the vehicle interior heats up significantly.

#### Water on the floor

Do not wash the vehicle floor with water.

Vehicle systems such as the audio system may be damaged if water comes into contact with electrical components under the floor of the vehicle, and may also cause the body to rust.

# Cleaning the inside of the rear window

- Do not use glass cleaner to clean the rear window, as this may cause damage to the rear window defogger heater wires or antenna. Use a cloth dampened with lukewarm water to gently wipe the window clean. Wipe the window in strokes running parallel to the heater wires or antenna.
- Be careful not to scratch or damage the heater wires or antenna.

# Maintenance requirements

To ensure safe and economical driving, day-to-day care and regular maintenance is essential. It is the owner's responsibility to perform regular checks. Toyota recommends the following maintenance.

#### ■ General maintenance

Should be performed on a daily basis. This can be done by yourself or by a Toyota dealer.

#### ■ Scheduled maintenance

Should be performed at specified intervals according to the maintenance schedule.

For details about maintenance items and schedules, refer to the "Scheduled Maintenance Guide" or "Owner's Manual Supplement".

### ■ Do-it-yourself maintenance

You can perform some maintenance procedures yourself. Please be aware that do-it-yourself maintenance may affect warranty coverage.

The use of Toyota Repair Manuals is recommended.

For details about warranty coverage, see the separate "Owner's Warranty Information Booklet", "Owner's Manual Supplement".

# ■ Repair and replacement

It is recommended that genuine Toyota parts be used for repair to ensure performance of each system. If non-Toyota parts are used in replacement or if a repair shop other than a Toyota dealer performs repairs, confirm the warranty coverage.

#### ■ Allow inspection and repairs to be performed by a Toyota dealer

- Toyota technicians are well-trained specialists and are kept up to date with the latest service information. They are well informed about the operations of all systems on your vehicle.
- Keep a copy of the repair order. It proves that the maintenance that has been performed is under warranty coverage. If any problem should arise while your vehicle is under warranty, your Toyota dealer will promptly take care of it.

# **CAUTION**

#### ■ Warning in handling of 12-volt battery

- Engine exhaust, some of its constituents, and a wide variety of automobile components contain or emit chemicals known to the State of California to cause cancer and birth defects and other reproductive harm. Work in a well ventilated area.
- Oils, fuels and fluids contained in vehicles as well as waste produced by component wear contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Avoid exposure and wash any affected area immediately.
- 12-volt battery posts, terminals and related accessories contain lead and lead compounds which are known to cause brain damage. Wash your hands after handling. ( $\rightarrow$ P. 352)

# General maintenance

Listed below are the general maintenance items that should be performed at the intervals specified in the "Owner's Warranty Information Booklet" or "Owner's Manual Supplement/Scheduled Maintenance Guide". It is recommended that any problem you notice should be brought to the attention of your Toyota dealer or qualified service shop for advice.

### **Engine compartment**

Items	Check points
Brake fluid	At the correct level? (→P. 348)
Engine/power control unit coolant	At the correct level? (→P. 346)
Engine oil	At the correct level? $(\rightarrow P. 342)$
Exhaust system	No fumes or strange sounds?
Radiator/condenser/hoses	Not blocked with foreign matter? (→P. 348)
Washer fluid	At the correct level? (→P. 349)

#### **Trunk**

Items	Check points
12-volt battery	Check the connections. (→P. 350)

# Vehicle interior

Items	Check points
Accelerator pedal	Moves smoothly (without uneven pedal effort or catching)?
Transmission "Park" mechanism	Can the vehicle be held securely on an incline with the shift lever in P?
Brake pedal	<ul> <li>Moves smoothly?</li> <li>Does it have appropriate clearance and correct amount of free play?</li> </ul>
Brakes	<ul> <li>Not pull to one side when applied?</li> <li>Loss of brake effectiveness?</li> <li>Spongy feeling brake pedal?</li> <li>Pedal almost touches floor?</li> </ul>
Head restraints	Move smoothly and lock securely?
Indicators/buzzers	• Function properly?
Lights	Do all the lights come on?
Parking brake	<ul><li> Moves smoothly?</li><li> Can hold the vehicle securely on an incline?</li></ul>
Seat belts	<ul><li>Does the seat belt system operate smoothly?</li><li>Are the belts undamaged?</li></ul>
Seats	Do the seat controls operate properly?
Steering wheel	<ul><li> Moves smoothly?</li><li> Has correct free play?</li><li> No strange noises?</li></ul>

# Vehicle exterior

Items	Check points
Door/trunk	Operate smoothly?
Engine hood	• The lock system works properly?
Fluid leaks	Is there any leakage after parking?
Tires	<ul> <li>Inflation pressure is correct?</li> <li>Tire surfaces not worn or damaged?</li> <li>Tires rotated according to the maintenance schedule?</li> <li>Wheel nuts are not loose?</li> </ul>



# **A** CAUTION

# ■ If the hybrid system is running

Turn the hybrid system off and ensure that there is adequate ventilation before performing maintenance checks.

# Emission inspection and maintenance (I/M) programs

Some states have vehicle emission inspection programs which include OBD (On Board Diagnostics) checks. The OBD system monitors the operation of the emission control system.

## ■ If the malfunction indicator lamp comes on

The OBD system determines that a problem exists somewhere in the emission control system. Your vehicle may not pass the I/M test and may need to be repaired. Contact your Toyota dealer to service the vehicle.

#### ■ Your vehicle may not pass the I/M test:

When the 12-volt battery is disconnected or discharged

Readiness codes that are set during ordinary driving are erased.

Also, depending on your driving habits, the readiness codes may not be completely set.

When the fuel tank cap is loose

The malfunction indicator lamp comes on as a temporary malfunction and your vehicle may not pass the I/M test.

# ■ When the malfunction indicator lamp goes off after several driving trips

The error code in the OBD system will not be cleared unless the vehicle is driven 40 or more times.

# ■ If your vehicle does not pass the I/M test

Contact your Toyota dealer to prepare the vehicle for re-testing.

# Do-it-yourself service precautions

If you perform maintenance yourself, be sure to follow the correct procedures as given in these sections.

Items	Parts and tools
12-volt battery condition (→P. 350)	Warm water     Baking soda     Grease     Conventional wrench     (for terminal clamp bolts)
Brake fluid level (→P. 348)	_
Engine/power control unit coolant level (→P. 346)	"Toyota Super Long Life Coolant" or similar high quality ethylene glycol based non-silicate, non-amine, non-nitrite and non-borate coolant with long-life hybrid organic acid technology.  For the U.S.A.:  "Toyota Super Long Life Coolant" is pre-mixed with 50% coolant and 50% deionized water.  For Canada:  "Toyota Super Long Life Coolant" is pre-mixed with 55% coolant and 45% deionized water.  • Funnel (used only for adding coolant)
Engine oil level (→P. 342)	<ul> <li>Toyota Genuine Motor Oil or equivalent</li> <li>Rag or paper towel, funnel (used only for adding oil)</li> </ul>

# 4-3. Do-it-yourself maintenance

Items		Parts and tools
Fuses	(→P. 375)	Fuse with same amperage rating as original
Light bulbs	(→P. 385)	Bulb with same number and wattage rating as original
Radiator and condens	er (→P. 348)	_
Tire inflation pressure	e (→P. 363)	Tire pressure gauge     Compressed air source
Washer fluid	(→P. 349)	Water washer fluid containing antifreeze (for winter use)     Funnel

# **A** CAUTION

The engine compartment contains many mechanisms and fluids that may move suddenly, become hot, or become electrically energized. To avoid death or serious injury observe the following precautions.

#### When working on the engine compartment

- Make sure that the indicator on the "POWER" switch and the "READY" indicator are both off.
- Keep hands, clothing, and tools away from the moving fan and engine drive belt.
- Be careful not to touch the engine, power control unit, radiator, exhaust manifold, etc. right after driving as they may be hot. Oil and other fluids may also be hot.
- Do not leave anything that may burn easily, such as paper or rags, in the engine compartment.
- Do not smoke, cause sparks or expose an open flame to fuel. Fuel fumes are flammable.

#### When working near the electric cooling fans or radiator grille

Be sure the "POWER" switch is turned OFF.

With the "POWER" switch in ON mode, the electric cooling fans may automatically start to run if the air conditioning is on and/or the coolant temperature is high.  $(\rightarrow P. 348)$ 

# Safety glasses

Wear safety glasses to prevent flying or falling material, fluid spray, etc. from getting in the eyes.




#### NOTICE

# If you remove the air cleaner


Driving with the air cleaner removed may cause excessive engine wear due to dirt in the air. Also, a backfire could cause a fire in the engine compartment.

# Release the lock from the inside of the vehicle to open the hood.



Pull the hood release lever.

The hood will pop up slightly.



Lift the auxiliary catch lever and lift the hood.




# Pre-driving check

Check that the hood is fully closed and locked.


If the hood is not locked properly, it may open while the vehicle is in motion and cause an accident, which may result in death or serious injury.

When raising your vehicle with a floor jack, position the jack correctly. Improper placement may damage your vehicle or cause injury.

#### **■** Front




# ■ Rear



# **CAUTION**


#### When raising your vehicle

Make sure to observe the following to reduce the possibility of death or serious injury:



Lift up the vehicle using a floor jack such as the one shown in the illustration.

- When using a floor jack, follow the instructions of the manual provided with the jack.
- Do not use the jack that was supplied with your vehicle.
- Do not put any part of your body on get underneath the vehicle supported only by the floor jack.
- Always use floor jack and/or automotive jack stands on a solid, flat, level surface.
- Do not start or run the hybrid system while the vehicle is supported by the floor jack.
- Stop the vehicle on level firm ground, firmly set the parking brake and put the shift lever in P.
- Make sure to set the floor jack properly at the jack point. Raising the vehicle with an improperly positioned floor jack will damage the vehicle and may cause the vehicle to fall off the floor jack.
- Do not raise the vehicle while someone is in the vehicle.
- When raising the vehicle, do not place any objects on top of or underneath the floor jack.



- Brake fluid reservoir
  - (→P. 348)
- 2 Engine oil filler cap (→P. 343)
- 3 Engine oil level dipstick (→P. 342)
- 4 Power control unit coolant reservoir (→P. 346)
- Engine coolant radiator (→P. 348)


- 6 Fuse box  $(\rightarrow P. 375)$
- **7** Condenser (→P. 348)
- B Electric cooling fans
- Power control unit coolant radiator (→P. 348)
- Washer fluid tank (→P. 349)
- II Engine coolant reservoir (→P. 346)

# **Engine oil**

With the engine at operating temperature and turned off, check the oil level on the dipstick.


# ■ Checking the engine oil

STEP 1 Park the vehicle on level ground. After turning off the engine, wait more than five minutes for the oil to drain back into the bottom of the engine.




Hold a rag under the end and pull the dipstick out.

- STEP 3 Wipe the dipstick clean.
- STEP 4 Reinsert the dipstick fully.
- STEP 5 Holding a rag under the end, pull the dipstick out and check the oil level.
- STEP 6 Wipe the dipstick and reinsert it fully.



1 Low

# ■ Adding engine oil



If the oil level is below or near the low level mark, add engine oil of the same type as already in the engine.

Make sure to check the oil type and prepare the items needed before adding oil.

Engine oil selection	→P. 453
Oil quantity (Low → Full)	1.2 qt. (1.1 L, 1.0 lmp. qt.)
Items	Clean funnel

STEP 1 Remove the oil filler cap by turning it counterclockwise.

STEP 2 Add engine oil slowly, checking the dipstick.

STEP 3 Install the filler cap, turning it clockwise.

#### ■ Engine oil consumption

- ■The amount of engine oil consumed depends on the oil viscosity, the quality of the oil and the way the vehicle is driven.
- More oil is consumed under driving conditions such as high speeds and frequent acceleration and deceleration.
- A new engine consumes more oil.
- When judging the amount of oil consumption, keep in mind that the oil may have become diluted, making it difficult to judge the true level accurately.
- Oil consumption: Max. 1.1 qt./600 miles, 0.9 lmp. qt./600 miles (1.0 L per 1000 km)
- If you consume more than 1.1 qt. (1.0 L, 0.9 lmp. qt.) every 600 miles (1000 km), contact your Toyota dealer.

#### ■ After changing the engine oil (U.S.A. only)

To reset the oil change system, follow the procedure below:

- Turn off the hybrid system with the trip meter A reading shown.  $(\rightarrow P. 150)$
- The "POWER" switch must be set in ON mode while holding down the trip meter reset knob. A message "OIL MILEAGE RESET MODE" will appear on the display.
- Hold down the knob for at least 5 seconds. A message "COM-PLETE" will appear and the message "OIL MILEAGE RESET MODE" goes off.

# **A** CAUTION

#### Used engine oil

- Used engine oil contains potentially harmful contaminants which may cause skin disorders such as inflammation or skin cancer, so care should be taken to avoid prolonged and repeated contact. To remove used engine oil from your skin, wash thoroughly with soap and water.
- Dispose of used oil and filters only in a safe and acceptable manner. Do not dispose of used oil and filters in household trash, in sewers or onto the ground. Call your Toyota dealer, service station or auto parts store for information concerning recycling or disposal.
- Do not leave used engine oil within the reach of children.



#### NOTICE

# To prevent serious engine damage


Check the oil level on a regular basis.

- When replacing the engine oil
  - Be careful not to spill engine oil on the vehicle components.
  - Avoid overfilling, as the engine could be damaged.
  - Check the oil level on the dipstick every time you refill the vehicle.
  - Be sure the engine oil filler cap is properly tightened.

#### Coolant

The coolant level is satisfactory if it is between the "FULL" and "LOW" lines on the reservoir when the hybrid system is cold.


#### ► Engine coolant reservoir



- Reservoir cap
- 2 FULL
- 3 LOW

If the level is on or below the "L" line, add coolant up to the "F" line.  $(\rightarrow P. 440)$ 

#### ► Power control unit coolant reservoir



- Reservoir cap
- 2 "FULL"
- 3 "LOW"

If the level is on or below the "LOW" line, add coolant up to the "FULL" line. ( $\rightarrow$ P. 441)

#### ■ If the coolant level drops within a short time after replenishing

Visually check the radiator, hoses, coolant reservoir caps, radiator cap, drain cock and water pump.

If you cannot find a leak, have your Toyota dealer test the cap and check for leaks in the cooling system.

#### ■ Coolant selection

Only use "Toyota Super Long Life Coolant" or similar high quality ethylene glycol based non-silicate, non-amine, non-nitrite, and non-borate coolant with long-life hybrid organic acid technology.

U.S.A.: Toyota Super Long Life Coolant is a mixture of 50% coolant and 50% deionized water. (Enabled: -31°F [-35°C])

Canada: Toyota Super Long Life Coolant is a mixture of 55% coolant and 45% deionized water. (Enabled: -44°F [-42°C])

For more details about coolant, contact your Toyota dealer.

# **A** CAUTION

# When the hybrid system is hot

Do not remove the coolant reservoir cap.

The cooling system may be under pressure and may spray hot coolant if the cap is removed, causing burns or other injuries.

# **♠** NOTICE

# When adding coolant

Coolant is neither plain water nor straight antifreeze. The correct mixture of water and antifreeze must be used to provide proper lubrication, corrosion protection and cooling. Be sure to read the antifreeze or coolant label.

# If you spill coolant

Be sure to wash it off with water to prevent damage to parts or paint.

#### Radiators and condenser

Check the radiators and condenser and remove any foreign objects. If any of the above parts are extremely dirty or you are not sure of their condition, have your vehicle checked by your Toyota dealer.




# A CAUTION

#### ■ The radiators and condenser may be hot after driving

Do not touch the radiators or condenser, as they may be hot and may be burned.

#### **Brake fluid**

#### Checking fluid level



The brake fluid level should be between the "MAX" and "MIN" lines on the tank

If the level is low, take your vehicle to a Toyota dealer as soon as possible. Do not drive your vehicle if the red brake system warning light is on. Call a Toyota dealer for assistance.



# **A** CAUTION

#### When filling the reservoir

Take care because brake fluid can harm your hands or eyes and damage painted surfaces.

If fluid gets in your eyes, flush your eyes with clean water immediately.

If you still experience discomfort, see a doctor.




#### NOTICE

#### If the fluid level is low or high

It is normal for the brake fluid level to go down slightly as the brake pads wear or when the fluid level in the accumulator is high.

If the reservoir needs frequent refilling, it may indicate a serious problem.

#### Washer fluid



Add washer fluid in the following situations.

- Any washer does not work.
- The warning message appears on the multi-information display.



# **A** CAUTION

# When refilling the washer fluid

Do not refill the washer fluid when the hybrid system is hot or operating, as the washer fluid contains alcohol and may catch fire if spilled on the hybrid system etc.



#### NOTICE

# Do not use any fluid other than washer fluid

Do not use soapy water or engine antifreeze instead of washer fluid. Doing so may cause streaking on the vehicle's painted surfaces.

# Diluting washer fluid


Dilute washer fluid with water as necessary.

Refer to the freezing temperatures listed on the washer fluid tank.

# 4-3. Do-it-yourself maintenance


# 12-volt battery

#### ■ Location



The 12-volt battery is located in the right-hand side of the luggage compartment.


# ■ Removing the 12-volt battery cover



Remove the 12-volt battery cover.

#### **■** Exterior

Make sure that the 12-volt battery terminals are not corroded and that there are no loose connections, cracks, or loose clamps.



- 1 Terminals
- 2 Hold-down clamp

#### ■ Before recharging

When recharging, the 12-volt battery produces hydrogen gas which is flammable and explosive. Therefore, observe the following before recharging:

- If recharging with the 12-volt battery installed on the vehicle, be sure to disconnect the ground cable.
- Make sure the power switch on the charger is off when connecting and disconnecting the charger cables to the 12-volt battery.

#### ■ After recharging/reconnecting the 12-volt battery

In some cases, the hybrid system may not start. Follow one or both of the following procedures:

- After opening and closing the driver's door, wait 10 seconds then attempt to start the hybrid system. (If the system does not start first time, repeat the procedure.)
- With the shift lever in P and the "POWER" switch OFF, open and close the driver's door, then attempt to start the hybrid system.

If the system will not start even after multiple attempts at both methods, contact your Toyota dealer.

# **A** CAUTION

#### Chemicals in the 12-volt battery

The 12-volt battery contains poisonous and corrosive sulfuric acid and may produce hydrogen gas which is flammable and explosive. To reduce the risk of death or serious injury, take the following precautions while working on or near the 12-volt battery:

- Do not cause sparks by touching the 12-volt battery terminals with tools.
- Do not smoke or light a match near the 12-volt battery.
- Avoid contact with eyes, skin and clothes.
- Never inhale or swallow electrolyte.
- Wear protective safety glasses when working near the 12-volt battery.
- Keep children away from the 12-volt battery.

#### Where to safely charge the 12-volt battery

Always charge the 12-volt battery in an open area. Do not charge the 12-volt battery in a garage or closed room where there is not sufficient ventilation.

#### How to recharge the 12-volt battery

Only perform a slow charge (5 A or less). The 12-volt battery may explode if charged at a quicker rate.

# Emergency measures regarding electrolyte

- If electrolyte gets in your eyes Flush your eyes with clean water for at least 15 minutes and get immediate medical attention. If possible, continue to apply water with a sponge or cloth while traveling to the nearest medical facility.
- If electrolyte gets on your skin Wash the affected area thoroughly. If you feel pain or burning, get medical attention immediately.
- If electrolyte gets on your clothes It can soak through clothing on to your skin. Immediately take off the clothing and follow the procedure above if necessary.
- If you accidentally swallow electrolyte Drink a large quantity of water or milk. Follow with milk of magnesia, beaten raw egg or vegetable oil. Get emergency medical attention immediately.



# **CAUTION**

#### When replacing the 12-volt battery

Use a 12-volt battery designed for the CAMRY HYBRID. Failure to do so may cause gas (hydrogen) to enter the passenger compartment, causing a fire or explosion.

For replacement of the 12-volt battery, contact your Toyota dealer.



#### **NOTICE**


# When recharging the 12-volt battery

Never recharge the 12-volt battery while the hybrid system is operating. Also, be sure all accessories are turned off.

#### **Tires**

Replace or rotate tires in accordance with maintenance schedules and treadwear.

# ■ Checking tires




- New tread
- Treadwear indicator
- Worn tread

The location of treadwear indicators is shown by the "TWI" or "\(\triangle \)" marks, etc., molded on the sidewall of each tire.

Check spare tire condition and inflation pressure if not rotated.

#### ■ Tire rotation



Rotate the tires in the order shown.

To equalize tire wear and extend tire life, Toyota recommends that tire rotation is carried out at the same interval as tire inspection.

# ■ The tire pressure warning system

Your Toyota is equipped with a tire pressure warning system that uses tire pressure warning valves and transmitters to detect low tire inflation pressure before serious problems arise. (→P. 402)

The compact spare tire is not equipped with a tire pressure warning valve and transmitter.

# Installing tire pressure warning valves and transmitters

When replacing tires or wheels, tire pressure warning valves and transmitters must also be installed.

When new tire pressure warning valves and transmitters are installed, new tire pressure warning valve and transmitter ID codes must be registered in the tire pressure warning computer and tire pressure warning system must be initialized. Have tire pressure warning valve and transmitter ID codes registered by your Toyota dealer. (→P. 356)

# Initializing the tire pressure warning system

■ The tire pressure warning system must be initialized when the tire inflation pressure is changed (such as when changing traveling speed).


When the tire pressure warning system is initialized, the current tire pressure is set as the pressure benchmark.

- How to initialize the tire pressure warning system
- Park the vehicle in a safe place and turn off the hybrid system.

  Initialization is not performed while the vehicle is moving.
- STEP 2 Adjust the tire pressure to the specified cold tire inflation pressure level. ( $\rightarrow$ P. 457)

Make sure to adjust the tire pressure to the specified cold tire inflation pressure level. The tire pressure warning system will operate based on this pressure level.

STEP 3 Turn the "POWER" switch to ON mode.



Push and hold the tire pressure warning reset switch until the tire pressure warning light blinks slowly 3 times.

Wait for a few minutes with the ON mode, and then turn the "POWER" switch to OFF mode.

# Registering ID codes

The tire pressure warning valve and transmitter is equipped with a unique ID code. When replacing a tire pressure warning valve and transmitter, it is necessary to register the ID code of tire pressure warning valve and transmitter. Have the ID code registered by your Toyota dealer.

#### ■ When to replace your vehicle's tires

Tires should be replaced if:

- You have tire damage such as cuts, splits, cracks deep enough to expose the fabric or bulges indicating internal damage
- A tire goes flat repeatedly or cannot be properly repaired due to the size or location of a cut or other damage

If you are not sure, consult with your Toyota dealer.

#### ■ Replacing tires and wheels

If the ID code of the tire pressure warning valve and transmitter is not registered, the tire pressure warning system will not work properly. After about 20 minutes, the tire pressure warning light comes on after blinking for 1 minute to indicate a system malfunction.

#### ■ Tire life

Any tire over 6 years old must be checked by a qualified technician even if they have seldom or never been used or damage is not obvious.

- ■If the tread wears down below 0.16 in. (4 mm) on snow tires

  The effectiveness of snow tires is lost.
- If you press the tire pressure warning reset switch accidentally
  If initialization is performed, adjust the tire inflation pressure to the specified level and initialize the tire pressure warning system again.

# ■When the initialization of the tire pressure warning system has failed

Initialization can be completed in a few minutes. However, in the following cases, the settings has not been recorded and the system will not operate properly. If repeated attempts to record tire inflation pressure settings are unsuccessful, have the vehicle inspected by your Toyota dealer.


- When operating the tire pressure warning reset switch, the tire pressure warning light does not flash 3 times.
- After carrying out the initialization procedure, the tire pressure warning light blinks for 1 minute then stays on after driving for about 20 minutes.

#### ■ Routine tire inflation pressure checks

The tire pressure warning system does not replace routine tire inflation pressure checks. Make sure to check tire inflation pressure as part of your routine of daily vehicle checks.

#### ■ Maximum load of tire

Check that the maximum load of the replacement tire is greater than 1/2 of the Gross Axle Weight Ratings (GAWR) of either the front axle or the rear axle, whichever is greater.



For the GAWR, see the Certification Label. For the maximum load of the tire, see the load limit at maximum cold tire inflation pressure mentioned on the sidewall of the tire. ( $\rightarrow$ P. 462)

#### ■ Tire types

#### 1 Summer tires

Summer tires are high-speed performance tires best suited to highway driving under dry conditions. Since summer tires do not have the same traction performance as snow tires, summer tires are inadequate for driving on snow-covered or icy roads. For driving on snow-covered roads or icy roads, the use of snow tires is recommended. When installing snow tires, be sure to replace all four tires.

#### 2 All season tires

All season tires are designed to provide better traction in snow and to be adequate for driving in most winter conditions, as well as for use year round. All season tires, however, do not have adequate traction performance compared with snow tires in heavy or loose snow. Also, all season tires fall short in acceleration and handling performance compared with summer tires in highway driving.

#### 3 Snow tires

For driving on snow-covered roads or icy roads, we recommend using snow tires. If you need snow tires, select tires of the same size, construction and load capacity as the originally installed tires. Since your vehicle has radial tires as original equipment, make sure your snow tires also have radial construction. Do not install studded tires without first checking local regulations for possible restrictions. Snow tires should be installed on all wheels. ( $\rightarrow$ P. 173)

# ■ Initializing the tire pressure warning system

Initialize the tire pressure warning system with the tire inflation pressure adjusted to the specified level.

#### ■ Tire pressure warning system certification

FCC ID: PAXPMV107J FCC ID: HYQ13BCX IC ID: 3729A-PMV107J

IC ID: 1551A-13BCX

► For vehicles sold in the U.S.A.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### For vehicles sold in Canada

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

## **A** CAUTION

#### When inspecting or replacing tires

Observe the following precautions to prevent accidents.

Failure to do so may cause damage to parts of the drive train, as well as dangerous handling characteristics, which may lead to an accident resulting in death or serious injury.

- Do not mix tires of different makes, models or tread patterns. Also, do not mix tires of remarkably different treadwear.
- Do not use tire sizes other than those recommended by Toyota.
- Do not mix differently constructed tires (radial, bias-belted, or bias-ply tires).
- Do not mix summer, all season and winter tires.

#### ■ When initializing the tire pressure warning system

Do not press the tire pressure warning reset switch without first adjusting the tire inflation pressure to the specified level. Otherwise, the tire pressure warning light may not come on even if the tire inflation pressure is low, or it may come on when the tire inflation pressure is actually normal.

## **⚠** NOTICE

- Repairing or replacing tires, wheels, tire pressure warning valves, transmitters and tire valve caps
  - When removing or fitting the wheels, tires or the tire pressure warning valve and transmitter, contact your Toyota dealer as the tire pressure warning valve and transmitter may be damaged if not handled correctly.
  - When replacing tire valve caps, do not use tire valve caps other than those specified. The cap may become stuck.
- To avoid damage to the tire pressure warning valves and transmitters

When a tire is repaired with liquid sealants, the tire pressure warning valve and transmitter may not operate properly. If a liquid sealant is used, contact your Toyota dealer or other qualified service shop as soon as possible. Make sure to replace the tire pressure warning valve and transmitter when replacing the tire.  $(\rightarrow P. 355)$ 

#### Driving on rough roads

Take particular care when driving on roads with loose surfaces or potholes.

These conditions may cause losses in tire air pressure, reducing the cushioning ability of the tires. In addition driving on rough roads may cause damage to the tires themselves, as well as the vehicle's wheels and body.


## ■ If tire inflation pressures become low while driving

Do not continue driving, or your tires and/or wheels may be ruined.

# 4-3. Do-it-yourself maintenance Tire inflation pressure

#### **■** Tire inflation pressure

The recommended cold tire inflation pressure and tire size is displayed on the tire and loading information label. ( $\rightarrow$ P. 457)



One of the following labels will be attached to the driver's side center pillar.

## Type A




## Type C



## Type B




## Type D



CTN43AI182

## ■ Inspection and adjustment procedure



- Tire valve
- Tire pressure gauge

- STEP 1 Remove the tire valve cap.
- STEP 2 Press the tip of the tire pressure gauge onto the tire valve.
- STEP 3 Read the pressure using the graduations of the gauge.
- If the tire inflation pressure is not at the recommended level, adjust the pressure.

If you add too much air, press the center of the valve to lower.

- After completing the tire inflation pressure measurement and adjustment, apply soapy water to the valve and check for leakage.
- STEP 6 Reinstall the tire valve cap.

## ■ Tire inflation pressure check interval

You should check tire inflation pressure every two weeks, or at least once a month.

Do not forget to check the spare tire.

#### **■** Effects of incorrect tire inflation pressure

Driving with incorrect tire inflation pressure may result in the following:

- Reduced fuel efficiency
- Reduced driving comfort and tire life
- Reduced safety
- Damage to the drive train

If a tire needs frequent refilling, have it checked by your Toyota dealer.

### ■Instructions for checking tire inflation pressure

When checking tire inflation pressure, observe the following:

- Check only when the tires are cold.
  If your vehicle has been parked for at least 3 hours and has not been driven for more than 1 mile or 1.5 km, you will get an accurate cold tire inflation pressure reading.
- Always use a tire pressure gauge. The appearance of the tire can be misleading. In addition, tire inflation pressures that are even just a few pounds off can degrade ride and handling.
- Do not bleed or reduce tire inflation pressure after driving. It is normal for the tire inflation pressure to be higher after driving.
- Never exceed the vehicle capacity weight.
   Passengers and luggage weight should be placed so that the vehicle is balanced.

## **CAUTION**

#### ■ Proper inflation is critical to save tire performance

Keep your tires properly inflated. Otherwise, the following conditions may occur and result in an accident causing death or serious injury.

- Excessive wear
- Uneven wear
- Poor handling
- Possibility of blowouts resulting from overheated tires
- Poor sealing of the tire bead
- Wheel deformation and/or tire separation
- A greater possibility of tire damage from road hazards



#### NOTICE

## ■ When inspecting and adjusting tire inflation pressure

Be sure to reinstall the tire valve caps.

Without the valve caps, dirt or moisture could get into the valve and cause air leakage, which could result in an accident. If the caps have been lost, replace them as soon as possible.

If a wheel is bent, cracked or heavily corroded, it should be replaced.

Otherwise, the tire may separate from the wheel or cause loss of handling control.

#### ■ Wheel selection

When replacing wheels, care should be taken to ensure that they are equivalent to those removed in load capacity, diameter, rim width, and offset.

Replacement wheels are available at your Toyota dealer.

Toyota does not recommend using:

- Wheels of different sizes or types
- Used wheels
- Bent wheel that have been straightened

#### ■ Aluminum wheel precautions

- Use only Toyota wheel nuts and wrenches designed for use with your aluminum wheels.
- When rotating, repairing or changing your tires, check that the wheel nuts are still tight after driving 1000 miles (1600 km).
- Be careful not to damage the aluminum wheels when using tire chains.
- Use only Toyota genuine balance weights or equivalent and use a plastic or rubber hammer when balancing your wheels.

## ■When replacing wheels

The wheels of your Toyota are equipped with tire pressure warning valves and transmitters that allow the tire pressure warning system to provide advanced warning in the event of a loss in tire inflation pressure. Whenever wheels are replaced, the tire pressure warning valves and transmitters must be installed. ( $\rightarrow$ P. 355)

## **CAUTION**

#### When replacing wheels

- Do not use wheels that are a different size from those recommended in the Owner's Manual, as this may result in loss of handling control.
- Never use an inner tube in a leaking wheel which is designed for a tubeless tire. Doing so may result in an accident, causing serious injury or death.



#### NOTICE

#### Replacing tire pressure warning valves and transmitters

- Because tire repair or replacement may affect the tire pressure warning valves and transmitters, make sure to have tires serviced by your Toyota dealer or other qualified service shop. In addition, make sure to purchase your tire pressure warning valves and transmitters at your Toyota dealer.
- Ensure that only genuine Toyota wheels are used on your vehicle. Tire pressure warning valves and transmitters may not work properly with non-genuine wheels.

# Air conditioning filter


The air conditioning filter must be cleaned or changed regularly to maintain air conditioning efficiency.

#### ■ Removal method


STEP 1 Turn the "POWER" switch OFF.



Open the glove box. Slide off the damper.




Apply pressure to the glove box as shown to disconnect the claws.



Remove the filter cover.

## ■ Cleaning method




If the filter is dirty, clean by blowing compressed air through the filter from the bottom.

Hold the air gun 2 in. (5 cm) from the filter and blow for approximately 2 minutes at 72 psi (500 kPa, 5.0 kgf/cm<sup>2</sup> or bar).

If an air gun is not available, have the filter cleaned by your Toyota dealer.

## ■ Replacement method



Remove the air conditioning filter and replace it with a new one.

The "TUP" marks shown on the filter should be pointing up.

## ■ Checking interval

Inspect, clean and replace the air conditioning filter according to the maintenance schedule. In dusty areas or areas with heavy traffic flow, more frequent cleaning or early replacement may be required. (For scheduled maintenance information, please refer to the "Scheduled Maintenance Guide" or "Owner's Manual Supplement".)

## ■ If air flow from the vents decreases dramatically

The filter may be clogged. Check the filter and replace if necessary.

## <u>^</u>

## **NOTICE**

#### ■To prevent damage to the system


- When using the air conditioning system, make sure that a filter is always installed.
- When cleaning the filter, do not clean the filter with water.

## 4-3. Do-it-yourself maintenance


## **Key battery**

## Replace the battery with a new one if it is discharged.


- You will need the following items:
  - Flathead screwdriver (To prevent damage to the key, cover the tip of the screwdriver with rag.)
  - Small Phillips-head screwdriver
  - Lithium battery CR1632
- Replacing the battery



Take out the mechanical key.



Remove the cover.



#### Remove the depleted battery.

Insert a new battery with the "+" terminal facing up.

#### ■ If the key battery is discharged

The following symptoms may occur.

- The smart key system and wireless remote control will not function properly.
- The operational range is reduced.

#### ■ Use a CR1632 lithium battery

- Batteries can be purchased at your Toyota dealer, jewelers, or camera stores.
- Replace only with the same or equivalent type recommended by your Toyota dealer.
- Dispose of used batteries according to the local laws.

## **A** CAUTION

## Removed battery and other parts

Keep away from children. These parts are small and if swallowed by a child, they can cause choking. Failure to do so could result in death or serious injury.

## **⚠** NOTICE

#### For normal operation after replacing the battery

Observe the following precautions to prevent accidents.

- Always work with dry hands.
   Moisture may cause the battery to rust.
- Do not touch or move any other components inside the remote control.
- Do not bend either of the battery terminals.


# Checking and replacing fuses

If any of the electrical components do not operate, a fuse may have blown. If this happens, check and replace the fuses as necessary.

STEP 1 Turn the "POWER" switch OFF.


STEP 2 Open the fuse box cover.

▶ Engine compartment




Push the tab in and lift the lid off.

► Under the driver's side instrument panel



Remove the lid.

STEP 3 After a system failure, see "Fuse layout and amperage ratings" (→P. 377) for details about which fuse to check.




Take out the pullout tool.

Only type A fuse can be removed using the pullout tool.

STEP 5 Check if the fuse has blown.


## ▶ Type A



- Normal fuse
- 2 Blown fuse


Replace it with one of an appropriate amperage rating. The amperage rating can be found on the fuse box lid.

## ▶ Type B




- Normal fuse
- 2 Blown fuse

Replace it with one of an appropriate amperage rating. The amperage rating can be found on the fuse box lid.




## Fuse layout and amperage ratings

- **■** Engine compartment
- ► Fuse box cover



## ► Fuse block




	Fuse	Ampere	Circuit
1	SPARE	30 A	Spare fuse
2	SPARE	15 A	Spare fuse
3	SPARE	10 A	Spare fuse
4	RDI FAN	40 A	Electric cooling fans
5	CDS FAN	40 A	Electric cooling fans
6	RR DEF	50 A	Rear window defogger, MIR HTR
7	HTR SUB1	50 A	PTC heater
8	HTR SUB2	50 A	PTC heater
9	HTR	50 A	Air conditioning system
10	ABS MTR1	50 A	Electronically controlled brake system
11	ABS MTR2	40 A	Electronically controlled brake system
12	EPS	80 A	Electric power steering system

	Fuse	Ampere	Circuit
13	DC/DC	120 A	HTR, RR DEF, HTR SUB1, HTR SUB2, RDI FAN, CDS FAN, TAIL, PANEL, FR FOG, CIG, RADIO No.2, ECU-ACC, PWR OUTLET, GAUGE No.1, ECU-IG No.1, ECU-IG No.2, H-LP LVL, WASH, A/C No.2, S-HTR, WIP, P/SEAT, DOOR No.2, POWER, RR DOOR LH, RR DOOR RH, ECU-B No.2, OBD, FUEL OPN, PWR, STOP, S/ROOF, TI&TE, A/C, AM1
14	STR LOCK	20 A	Steering lock system
15	IG2	20 A	Multiport fuel injection system/ sequential multiport fuel injection system, starting system, GAUGE NO.2, INJ, IGN
16	HAZ	15 A	Emergency flashers
17	ETCS	10 A	Multiport fuel injection system/ sequential multiport fuel injection system, hybrid system
18	BATT FAN	10 A	Hybrid battery fan
19	ABS MAIN NO.3	10 A	Electronically controlled brake system
20	ABS MAIN NO.1	10 A	Electronically controlled brake system
21	ABS MAIN NO.2	10 A	Electronically controlled brake system
22	AM2	7.5 A	Main body ECU
23	EFI MAIN	30 A	Multiport fuel injection system/ sequential multiport fuel injection system, electronic throttle control system, EFI NO.3
24	AMP	25 A	Audio system

	Fuse	Ampere	Circuit
25	IGCT	30 A	Hybrid system ECU
26	DOOR NO.1	25 A	Main body ECU, power door lock
27	RADIO NO.1	15 A	Audio system, navigation system
28	ECU-B NO.1	10 A	Front passenger occupant classification system, main body ECU
29	DOME	10 A	Gauges and meters, vanity lights, trunk light, "POWER" switch light, door courtesy lights, interior light, personal lights, clock, smart key system
30	H-LP(LH)	15 A	Left-hand headlight (high beam)
31	H-LP(RH)	15 A	Right-hand headlight (high beam)
32	H-LP(LL)	15 A	Left-hand headlight (low beam)
33	H-LP(RL)	15 A	Right-hand headlight (low beam)
34	HORN	10 A	Horns
35	EFI NO.1	10 A	Multiport fuel injection system/ sequential multiport fuel injection system, smart key system
36	MPX-B	10 A	Gauges and meters
37	A/F	20 A	No circuit
38	S-HORN	7.5 A	No circuit
39	INV W/P	15 A	Hybrid system ECU, hybrid battery (traction battery), DC/DC converter, multiport fuel injection system/ sequential multiport fuel injection system
40	IGCT No.2	10 A	Hybrid system ECU, motor generator ECU
41	EFI NO.3	10 A	Fuel tank system, multiport fuel injection system/sequential multiport fuel injection system

## **■** Under the instrument panel



	Fuse	Ampere	Circuit
1	RR DOOR RH	25 A	Rear right power window
2	RR DOOR LH	25 A	Rear left power window
3	FUEL OPN	7.5 A	Fuel filter door opener, hybrid system
4	FR FOG	15 A	Front fog lights
5	OBD	7.5 A	On-board diagnosis system
6	ECU-B NO.2	7.5 A	Power windows
7	STOP	10 A	Stop lights, high mounted stop- light, shift lock control system, mul- tiport fuel injection system/ sequential multiport fuel injection system, main body ECU, electroni- cally controlled brake system, elec- tronic throttle control system
8	TI&TE	30 A	No circuit
9	AM1	7.5 A	Multiport fuel injection system/ sequential multiport fuel injection system
10	A/C	7.5 A	Air conditioning system

	Fuse	Ampere	Circuit
11	PWR	25 A	Power windows
12	DOOR NO.2	25 A	Main body ECU
13	S/ROOF	30 A	Moon roof
14	TAIL	15 A	Front side marker/parking lights, stop/tail lights, rear side marker lights, license plate lights, front turn signal lights, main body ECU
15	PANEL	7.5 A	Navigation system, seat heaters, emergency flashers, air conditioning system, audio system, clock, glove box light, instrument panel lights, steering switches, rear window defogger
16	ECU IG NO.1	10 A	Main body ECU, electric moon roof, tire pressure warning system, auto anti-glare inside rear view mirror, starting system, navigation system
17	ECU IG NO.2	7.5 A	Electronically controlled brake system, electric power steering system, shift lock control system
18	A/C NO.2	10 A	Air conditioning system, rear window defogger
19	WASH	10 A	Windshield wipers and washer
20	S-HTR	20 A	Seat heaters
21	GAUGE NO.1	10 A	Emergency flashers, back-up lights
22	WIP	25 A	Windshield wipers and washer
23	H-LP LVL	7.5 A	No circuit
24	INJ	15 A	No circuit

	Fuse	Ampere	Circuit
25	IGN	10 A	Multiport fuel injection system/ sequential multiport fuel injection system, SRS airbag system, steer- ing lock system, front passenger occupant classification system, smart key system, electronic throt- tle control system
26	GAUGE NO.2	7.5 A	Gauges and meters, clock
27	ECU-ACC	7.5 A	Clock, main body ECU, shift lock control system, outside rear view mirrors, smart key system
28	CIG	20 A	No circuit
29	PWR OUTLET	20 A	Power outlet
30	RADIO NO.2	7.5 A	Audio system, navigation system
31	MIR HTR	10 A	Outside rear view mirror defoggers
32	POWER	30 A	Power windows
33	P/SEAT	30 A	Power seat

## ■ After a fuse is replaced

- If the lights do not turn on even after the fuse has been replaced, a bulb may need replacing. (→P. 385)
- If the replaced fuse blows again, have the vehicle inspected by your Toyota dealer.

#### ■ If there is an overload in the circuits

The fuses are designed to blow, protecting the wiring harness from damage.

## **CAUTION**

## ■ To prevent system breakdowns and vehicle fire

Observe the following precautions.

Failing to do so may cause damage, and possibly a fire or injury.

- Never use a fuse of a higher amperage rating than indicated, or use any other object in place of a fuse.
- Always use a genuine Toyota fuse or equivalent. Never replace a fuse with a wire, even as a temporary fix. This can cause extensive damage or even fire.
- Do not modify the fuse or the fuse box.



#### ♠ NOTICE

#### Before replacing fuses

Have the cause of electrical overload determined and repaired by your Toyota dealer, as soon as possible.


# Light bulbs

You may replace the following bulbs yourself. The difficulty level of replacement varies depending on the bulb. If necessary bulb replacement seems difficult to perform, contact your Toyota dealer.

For more information about replacing other light bulbs, contact your Toyota dealer.


■ Prepare a replacement light bulb.
Check the wattage of the light bulb being replaced. (→P. 458)

#### **■** Bulb locations




## Replacing light bulbs

## ■ Headlights and daytime running lights



Turn the bulb base counterclockwise.


- Headlight (low beam)
- Place Headlight (high beam) and daytime running light




Unplug the connector while depressing the lock release.

- Headlight (low beam)
- Headlight (high beam) and daytime running light


## ■ Rear turn signal lights



Open the trunk lid and remove the cover.



Turn the bulb bases counter-clockwise.



Remove the light bulb.

#### ■ Lights other than the above

If any of the lights listed below has burnt out, have it replaced by your Toyota dealer.

- Front fog lights (if equipped)
- Front turn signal lights
- High mounted stoplight
- Front side marker/parking lights
- Stop/tail lights
- Back-up lights
- License plate lights
- Rear side marker lights

#### ■ Condensation build-up on the inside of the lens

Contact your Toyota dealer for more information in the following situations. Temporary condensation build-up on the inside of the headlight lens does not indicate a malfunction.

- Large drops of water have built up on the inside of the lens.
- Water has built up inside the headlight.

## ■LED stop/tail lights and high mounted stoplight

The stop/tail lights and high mounted stoplight consists of a number of LEDs. If any of the LEDs burn out, take your vehicle to your Toyota dealer to have the light replaced.

## **A** CAUTION

#### Replacing light bulbs

- Turn off the headlights. Do not attempt to replace the bulb immediately after turning off the headlights.
  - The bulbs become very hot and may cause burns.
- Do not touch the glass portion of the light bulb with bare hands. Hold the bulb by the plastic or metal portion.
  - If the bulb is scratched or dropped it may blow out or crack.
- Fully install light bulbs and any parts used to secure them. Failing to do so may result in heat damage, fire, or water entering the headlight unit. This may damage the headlights or cause condensation to build up on the lens.

#### To prevent damage or fire


Make sure bulbs are fully seated and locked.

5

-1.	Essential information	
	Emergency flashers	392
	If your vehicle needs to	
	be towed	393
	If you think something	
	is wrong	396
	Event data recorder	397
-2.	Steps to take in an	
	emergency	
	If a warning light turns	
	on or a warning buzzer	
	sounds	399
	If a warning message is	400
	displayed	408
	If you have a flat tire	419
	If the hybrid system will	400
	not start	429
	If the shift lever cannot	404
	be shifted from P	431
	If you lose your keys	432
	If the electronic key does	400
	not operate properly	433
	If the vehicle's 12-volt	400
	battery is discharged	436
	If your vehicle	4.40
	overheats	440
	If the vehicle becomes	444
	stuck	444
	If your vehicle has to be	
	stopped in an	446
	emergency	440

## 5-1. Essential information Emergency flashers

Use the emergency flashers if the vehicle malfunctions or is involved in an accident.



Press the switch to flash all the turn signal lights. To turn them off, press the switch once again.

## **⚠** NOTICE

### ■ To prevent battery discharge

Do not leave the emergency flashers on longer than necessary when the hybrid system is not operating.

# If your vehicle needs to be towed

If towing is necessary, we recommend having your vehicle towed by your Toyota dealer or a commercial towing service, using a lift-type truck or a flat bed truck.

Use a safety chain system for all towing, and abide by all state/provincial and local laws.

If towing from the front, the vehicle's rear wheels and axles must be in good condition. ( $\rightarrow$ P. 394)


If they are damaged, use a towing dolly or flat bed truck.

#### **Before towing**

The following may indicate a problem with your transmission. Contact your Toyota dealer before towing.

- The hybrid system is operating, but the vehicle will not move.
- The vehicle makes an abnormal sound.

## Towing with a sling-type truck




## **⚠** NOTICE

#### ■To prevent body damage

Do not tow with a sling-type truck, either from the front or rear.

## Towing with a wheel-lift type truck from the front




Release the parking brake.

## **№** NOTICE

## ■To prevent damaging the vehicle

When raising the vehicle, ensure adequate ground clearance for towing at the opposite end of the raised vehicle. Without adequate clearance, the vehicle could be damaged while being towed.

## Towing with a wheel-lift type truck from the rear




Use a towing dolly under the front wheels.



## ■ To prevent causing serious damage to the transmission

Never tow this vehicle from the rear with the front wheels on the ground.

## Using a flat bed truck



If you use chains or cables to tie down your vehicle, the angles shaded in black must be 45°.

Do not overly tighten the tie downs or the vehicle may be damaged.

# 5-1. Essential information If you think something is wrong

If you notice any of the following symptoms, your vehicle probably needs adjustment or repair. Contact your Toyota dealer as soon as possible.

#### Visible symptoms

- Fluid leaks under the vehicle (Water dripping from the air conditioning after use is normal.)
- Flat-looking tires or uneven tire wear
- Engine coolant temperature gauge needle continually points higher than normal

#### Audible symptoms

- Changes in exhaust sound
- Excessive tire squeal when cornering
- Strange noises related to the suspension system
- Pinging or other noises related to the hybrid system

## Operational symptoms

- Engine missing, stumbling or running rough
- Appreciable loss of power
- Vehicle pulls heavily to one side when braking
- Vehicle pulls heavily to one side when driving on a level road
- Loss of brake effectiveness, spongy feeling, pedal almost touches the floor

#### 5-1. Essential information Event data recorder

Your vehicle has computers that monitor and control certain aspects of your vehicle. These computers assist in driving and maintaining optimal vehicle performance.

Besides storing data useful for troubleshooting, there is an event data recorder (EDR) that records data in a crash or a near car crash event.

#### In a crash or a near car crash event

The SRS airbag sensor assembly contains the EDR. In a crash or a near car crash event, this device may record some or all of the following information:

- Gasoline engine speed
- Whether the brake pedal was applied or not
- Vehicle speed
- To what extent the accelerator pedal was depressed
- Position of the transmission shift lever
- Whether the driver and front passenger wore seat belts or not
- Driver's seat position
- Front passenger's occupant classification
- SRS airbag deployment data
- SRS airbag system diagnostic data
- Front passenger's occupant classification

The information above is intended to be used for the purpose of improving vehicle safety performance. Unlike general data recorders, the EDR does not record sound data such as conversation between passengers.

#### Disclosure of the data

Toyota will not disclose the data recorded in an EDR to a third party except when:

- An agreement from the vehicle's owner (or the leasing company for a leased vehicle) is obtained
- Officially requested by the police or other authorities
- Used as a defense for Toyota in a law suit
- Ordered by a court law

However, if necessary Toyota will:

- Use the data for research on Toyota vehicle safety performance
- Disclose the data to a third party for research purposes without disclosing details of the vehicle owner, and only when it is deemed necessary
- Disclose summarized data cleared of vehicle identification information to a non-Toyota organization for research purposes

Calmly perform the following actions if any of the warning lights turn on or flash. If a light turns on or flashes, but then turns off, this does not necessarily indicate a malfunction in the system.

#### Stop the vehicle immediately. Continuing to drive the vehicle may be dangerous.

The following warning indicates a possible problem in the brake system. Immediately stop the vehicle in a safe place and contact your Toyota dealer.

Warning light	Warning light/Details
BRAKE	Brake system warning light (red indicator) and warning buzzer*
(U.S.A.) (Canada)	<ul> <li>Low brake fluid</li> <li>Malfunction in the electronically controlled brake system This light also comes on when the parking brake is not released. If the light turns off after the parking brake is fully released the system is operating normally.</li> </ul>

<sup>\*:</sup> Parking brake engaged warning buzzer: The buzzer sounds to indicate that the parking brake is still engaged (with the vehicle having reached a speed of 3 mph [5 km/h]).

#### Stop the vehicle immediately.

The following warning indicates the possibility of damage to the vehicle that may lead to an accident. Immediately stop the vehicle in a safe place and contact your Toyota dealer.

Warning light	Warning light/Details
= +	Charging system warning light Indicates a malfunction in the vehicle's charging system.

#### Have the vehicle inspected immediately.

Failing to investigate the cause of the following warnings may lead to the system operating abnormally and possibly cause an accident. Have the vehicle inspected by your Toyota dealer immediately.

Warning light	Warning light/Details	
CHECK (U.S.A.)  (Canada)	Malfunction indicator lamp Indicates a malfunction in: • The hybrid system; • The electronic engine control system; • The electronic throttle control system; or • The transmission control system.	
*	SRS warning light Indicates a malfunction in: • The SRS airbag system; • The front passenger occupant classification system; or • The seat belt pretensioner system.	
(U.S.A.)  (ABS) (Canada)	ABS warning light Indicates a malfunction in:  • ABS; or  • The brake assist system.	
	Brake system warning light (yellow indicator) Indicates a malfunction in: • The regenerative braking system; or • The electronically controlled brake system.	
<b>@!</b>	Electric power steering warning light Indicates a malfunction in the EPS (Electric Power Steering) system.	

#### ■ If the malfunction indicator lamp comes on while driving

First check the following:

- Is the fuel tank empty?
  If it is, fill the fuel tank immediately.
- Is the fuel tank cap loose?
  If it is, tighten it securely.

The light will go off after taking several driving trips.

If the light does not go off even after several trips, contact your Toyota dealer as soon as possible.

#### ■ Brake system warning light operation

The following does not indicate a malfunction:

- After the hybrid system is turned on, the red and yellow brake system warning lights may stay on for about 60 seconds.
- Depressing the brake pedal repeatedly may turn on the red brake system warning light and buzzer.

### Follow the correction procedures.

After taking the specified steps to correct the suspected problem, check that the warning light turns off.

Warning light	Warning light/Details	Correction procedure
	Open door warning light (warning buzzer)*1 Indicates that a door or the trunk is not fully closed.	Check that all doors and the trunk are closed.
	Low fuel level warning light Indicates that remaining fuel is about 2.5 gal. (9.8 L, 2.1 lmp. gal.) or less	Refuel the vehicle.
	Driver's seat belt reminder light (warning buzzer)*2 Warns the driver to fasten his/her seat belt.	Fasten the seat belt.
(on the center panel)	Front passenger's seat belt reminder light (warning buzzer)*2 Warns the front passenger to fasten his or her seat belt.	Fasten the seat belt.
	Tire pressure warning light	
(!)	When the light comes on: Low tire inflation pressure.	Adjust the tire inflation pressure.
(U.S.A.)	When the light comes on after blinking for 1 minute: Malfunction in the tire pressure warning system.	Have the system checked by your Toyota dealer.

Warning light	Warning light/Details	Correction procedure
	Master warning light A buzzer sounds and the warning light comes on and flashes to indicate that the master warning system has detected a malfunction.	→P. 408

<sup>\*1:</sup> Open door warning buzzer:

The open door warning buzzer sounds to alert the driver that one or more of the doors is not fully closed (with the vehicle having reached a speed of 3 mph [5 km/h]).

\*2: Driver's and front passenger's seat belt reminders:

The driver's and front passenger's seat belts reminder sound to alert the driver and front passenger that his or her seat belt is not fastened. The buzzer sounds intermittently for 10 seconds after the vehicle has reached a speed of at least 12 mph (20 km/h). Then, if the seat belt is still unfastened, the buzzer will sound in a different tone for 20 more seconds.

#### Front passenger detection sensor and passenger seat belt reminder

- If luggage is placed on the front passenger seat, the front passenger detection sensor may cause the warning light to flash, even if a passenger is not sitting in the seat.
- If a cushion is placed on the seat, the sensor may not detect a passenger, and the warning light may not operate properly.

#### ■ When the tire pressure warning light comes on

Check the tire inflation pressure and adjust to the appropriate level. Pushing the tire pressure warning reset switch does not turn off the tire pressure warning light.

#### ■ The tire pressure warning light may turn on due to natural causes

The tire pressure warning light may turn on due to natural causes such as natural air leaks or tire inflation pressure changes caused by temperature. In this case, adjusting the tire inflation pressure will turn off the warning light (after a few minutes).

#### ■When a tire is replaced with a spare tire

The compact spare tire is not equipped with the tire pressure warning valve and transmitter. If a tire goes flat, the tire pressure warning light will not turn off even though the flat tire is replaced with the spare tire. Replace the spare tire with the repaired tire and adjust the proper tire inflation pressure. The tire pressure warning light will turn off after a few minutes.

#### ■ If the tire pressure warning system is inoperative

The tire pressure warning system will be disabled in the following conditions:

(When the condition becomes normal, the system will work properly.)

- If tires not equipped with tire pressure warning valves and transmitters are used.
- If the ID code on the tire pressure warning valves and transmitters is not registered in the tire pressure warning computer.
- If the tire inflation pressure is 73 psi (500 kPa, 5.1 kgf/cm² or bar) or higher.

The tire pressure warning system may be disabled in the following conditions:

(When the condition becomes normal, the system will work properly.)

- If electronic devices or facilities using similar radio wave frequencies are nearby.
- If a radio set at similar frequencies is in use in the vehicle.
- If a window tint that affects the radio wave signals is installed.
- If there is a lot of snow or ice on the vehicle, in particular around the wheels or wheel housings.
- If non-genuine Toyota wheels are used. (Even if you use Toyota wheels, the tire pressure warning system may not work properly with some types of tires.)
- If tire chains are used.

## ■If the tire pressure warning light comes on after blinking frequently for 1 minute

If the tire pressure warning light comes on after blinking frequently for 1 minute when the "POWER" switch is turned to ON mode, have it checked by your Toyota dealer.

#### ■ Customization that can be configured at Toyota dealer

The vehicle speed linked seat belt reminder buzzer can be disabled. (Customizable features →P. 474)

However, Toyota recommends that the seat belt reminder buzzer be operational to alert the driver and front passenger that the seat belts are not fastened



#### **A** CAUTION

#### If the tire pressure warning light comes on

Be sure to observe the following precautions. Failure to do so could cause loss of vehicle control and result in death or serious injury.

- Stop your vehicle in a safe place as soon as possible. Adjust the tire inflation pressure immediately.
- If the tire pressure warning light comes on even after tire inflation pressure adjustment, it is probable that you have a flat tire. Check the tires. If the tire is flat, change to the spare tire and have the flat tire repaired by the nearest Toyota dealer.
- Avoid abrupt maneuvering and braking. If the vehicle tires deteriorate, you could lose control of the steering wheel or the brakes.

#### If a blowout or sudden air leakage should occur

The tire pressure warning system may not activate immediately.

#### **CAUTION**

#### Maintenance of the tires

Each tire, including the spare (if provided), should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label (tire and load information label). (If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label [tire and load information label], you should determine the proper tire inflation pressure for those tires.)

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS-tire pressure warning system) that illuminates a low tire pressure telltale (tire pressure warning light) when one or more of your tires is significantly under-inflated. Accordingly, when the low tire pressure telltale (tire pressure warning light) illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly underinflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability.

Please note that the TPMS (tire pressure warning system) is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale (tire pressure warning light).



#### **A** CAUTION

Your vehicle has also been equipped with a TPMS (tire pressure warning system) malfunction indicator to indicate when the system is not operating properly. The TPMS (tire pressure warning system) malfunction indicator is combined with the low tire pressure telltale (tire pressure warning light). When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended.

TPMS (tire pressure warning system) malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS (tire pressure warning system) from functioning properly. Always check the TPMS (tire pressure warning system) malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS (tire pressure warning system) to continue to function properly.




#### NOTICE

#### Precaution when installing a different tire

When a tire of a different specification or maker is installed, the tire pressure warning system may not operate properly.

# 5-2. Steps to take in an emergency If a warning message is displayed

If a warning is shown on the multi-information display, stay calm and perform the following actions:



Master warning light

The master warning light also comes on or flashes in order to indicate that a message is currently being displayed on the multi-information display.

2 Multi-information display

If any of the warning lights turns on again after performing the following actions, contact your Toyota dealer.

#### Stop the vehicle immediately.

• The following warning indicates the possibility of damage to the vehicle that may lead to an accident. Immediately stop the vehicle in a safe place and contact your Toyota dealer.

Warning message	Details
LOW ENGINE OIL PRESSURE	
(U.S.A.)	Indicates an abnormal engine oil pressure.
Canada)	A buzzer also sounds. The warning light may turn on if the engine oil pressure is too low.
CHECK HYBRID SYSTEM	Indicates a malfunction in the hybrid system. A buzzer also sounds.

• The following warning indicates the possibility of damage to the vehicle that may lead to an accident. Immediately stop the vehicle in a safe place and allow the engine to cool.

Warning message	Details
WATER TEMP	Indicates that the engine coolant temperature is too high.  A buzzer also sounds.

• The following warning indicates the possibility of damage to the vehicle that may lead to an accident. Immediately stop the vehicle in a safe place and allow the power control unit and electric motor (traction motor) to cool.

Warning message	Details
HYBRID SYSTEM OVER HEAT	Indicates that the temperature for the power control unit coolant or electric motor (traction motor) is too high.  A buzzer also sounds.

#### Have the vehicle inspected immediately.

Failing to investigate the cause of the following warnings may lead to the system operating abnormally and possibly cause an accident. Have the vehicle inspected by your Toyota dealer immediately.

Warning message	Details
CHECK S/T LOCK	Indicates a malfunction in the steering lock system.  A buzzer also sounds.

### Follow the correction procedures.

After taking the specified steps to correct the suspected problem, check that the warning light turns off.

Warning message	Details	Correction procedure
DRIVER DOOR OPEN  PASSENGER DOOR OPEN  LEFT REAR DOOR OPEN  RIGHT REAR DOOR OPEN  A LEFT REAR DOOR OPEN  RIGHT REAR DOOR OPEN  A LEFT REAR DOOR OPEN  RIGHT REAR DOOR OPEN  A LEFT REAR DOOR OPEN  RIGHT REAR DOOR OPEN  A LEFT REAR	Indicates that one or more of the doors is not fully closed.  A buzzer sounds to indicate that one or more of the doors is not fully closed (with the vehicle having reached a speed of 3 mph [5 km/h]).	Make sure that all of the doors are closed.
TRUNK OPEN	Indicates that the trunk is not fully closed.  A buzzer sounds to indicate that the trunk is not fully closed (with the vehicle having reached a speed of 3 mph [5 km/h]).	Close the trunk.
MOONROOF OPEN	Indicates that the moon roof is not fully closed (with the "POWER" switch is turned OFF and the driver's door open).  A buzzer also sounds.	Close the moon roof.

Warning message	Details	Correction procedure
vvairiing filessage	Indicates that the parking brake is still	Correction procedure
PARK BRAKE	engaged with the vehicle having reached a speed of more than 3 mph (5 km/h).  A buzzer also sounds.	Release the parking brake.
LOW WASHER FLUID	Indicates that the washer fluid level is low. A buzzer also sounds.	Add washer fluid.
MAINT REQD	Indicates that the engine oil is scheduled to be changed. A buzzer also sounds.	
SOON (U.S.A. only)	Comes on approximately 4500 miles (7200 km) after the engine oil is changed. (The indicator will not work properly unless the oil maintenance data has been reset).	Check the engine oil, and change if necessary.
MAINT REQD	Indicates that the engine oil should be changed.  A buzzer also sounds.	
(U.S.A. only)	Comes on approximately 5000 miles (8000 km) after the engine oil is changed (and the oil maintenance data has been reset).	Check and change the engine oil.

Warning message	Details	Correction procedure
LOW T. BATT STOP THE VEHICLE SHIFT TO P	Indicates that the hybrid battery (traction battery) is low. A buzzer also sounds.	Stop the vehicle and shift the shift lever to P.
SHIFT TO  WHEN STARTING	Indicates that the transmission is not in P when attempting to start the hybrid system.  A buzzer also sounds.	Shift the shift lever to P before pressing the "POWER" switch.

#### ■ Changing the engine oil (U.S.A. only)

Make sure to reset the oil change system. ( $\rightarrow$ P. 344)

#### Messages displayed when refueling

The following messages are displayed after the fuel lid opener is pressed. If the messages do not change or are displayed continuously, have the vehicle checked by your Toyota dealer.

Message	Details
PLEASE WAIT	Preparing the vehicle for refueling. Wait a moment.
REFUEL READY	You may commence refueling. Finish refueling within 30 minutes.
CLOSE FUEL LID	Close the fuel lid.

#### Other messages

If the following message is displayed, take appropriate action and confirm that the message has disappeared.

Message	Details
SHIFT TO P WHEN PARKING	The driver's door is opened when the transmission is not in P with the hybrid system on.  Shift the shift lever to P.  A buzzer also sounds.

#### Follow the correction procedures.

After taking the specified steps to correct the suspected problem, check that the warning light turns off.

Interior buzzer	Exterior buzzer	Warning message	Details	Correction procedure
Once	_	KEY IS NOT DETECTED  (Comes on for 8 seconds)	Indicates that the electronic key is not present when the "POWER" switch is pressed.	Confirm the location of the electronic key.

Interior buzzer	Exterior buzzer	Warning message	Details	Correction procedure
Once	3 times	KEY IS NOT DETECTED	Indicates that a door other than the driver's door has been opened and closed with the "POWER" switch in any mode other than OFF and the electronic key outside of the detection area.	Confirm the location of the electronic key.
Once	3 times	KEY IS NOT DETECTED	Indicates that the driver's door has been opened and closed with the shift lever in P, the "POWER" switch in any mode other than OFF and the electronic key outside of the detection area.	Turn the "POWER" switch OFF or confirm the location of the electronic key.


Interior buzzer	Exterior buzzer	Warning message	Details	Correction procedure
Continuous	Continuous	KEY IS NOT DETECTED  SHIFT TO P RANGE  (Displayed alternately)	Indicates that the driver's door has been opened and closed (with the shift lever not in P, the "POWER" switch in any mode other than OFF and the electronic key outside of the detection area).	<ul> <li>Shift the shift lever to P.</li> <li>Confirm the location of the electronic key.</li> </ul>
Once	_	LOW KEY BATTERY	Indicates that the key battery is low.	Replace the battery. (→P. 372)
Once	_	WHEN STARTING. DEPRESSTHE BRAKE PEDAL	Indicates that a door has been opened or closed and the "POWER" switch has been turned twice to ACCESSORY mode the "POWER" switch OFF.	Press the "POWER" switch while depressing the brake pedal.

Interior buzzer	Exterior buzzer	Warning message	Details	Correction procedure
Once		DEPRESS THE BRAKE PEDAL, AND TOUCH THE POWER SWITCH WITH THE KEY	Indicates that the electronic key does not operate prop- erly.	→P. 434
Once		TO START, DEPRESS THE BRAKE PEDAL. AND PUSH THE POWER SWITCH		
Once	_	S/T IS NOT UNLOCKED	Indicates that the steering lock has not released within 3 seconds of pressing the "POWER" switch.	Press the "POWER" switch again while turning the steering wheel with the brake pedal depressed.


# 5-2. Steps to take in an emergency If you have a flat tire

#### Remove the flat tire and replace it with the spare provided.


- Before jacking up the vehicle
  - Stop the vehicle on a hard, flat surface.
  - Set the parking brake.
  - Shift the shift lever to P.
  - Stop the hybrid system.
  - Turn on the emergency flashers.
- Location of the spare tire, jack and tools




#### Taking out the jack and spare tire



Remove the luggage floor cover.




- 1 Loosen the nut and remove it.
- 2 Remove the spare tire cover.
- 3 Loosen the bolt and remove it.
- 4 Remove the jack tray.




Remove the hook.

### Replacing a flat tire




Chock the tires.


Flat tire		Wheel chock positions
Front	Left- hand side	Behind the rear right-hand side tire
	Right- hand side	Behind the rear left- hand side tire
Rear	Left- hand side	In front of the front right-hand side tire
	Right- hand side	In front of the front left-hand side tire




Slightly loosen the wheel nuts (one turn).



Turn the tire jack portion "A" by hand until the notch of the jack is in contact with the jack point.




Raise the vehicle until the tire is slightly raised off the ground.



Remove all the wheel nuts and the tire.

When resting the tire on the ground, place the tire so that the wheel design faces up to avoid scratching the wheel surface.


#### Installing the tire



Remove any dirt or foreign matter from the wheel contact surface.


If foreign matter is on the wheel contact surface, the wheel nuts may loosen while the vehicle is in motion, and the tire may come off the vehicle.

- Install the tire and loosely tighten each wheel nut by hand by approximately the same amount.
- ▶ Replacing an aluminum wheel with a compact spare tire




Tighten the nuts until the tapered portion comes into loose contact with the disc wheel seat.


▶ Replacing an aluminum wheel with an aluminum



Turn the nut washers until they come into contact with the disc wheel.



Lower the vehicle.



Firmly tighten each nut two or three times in the order shown in the illustration.

**Tightening torque:** 76 ft•lbf (103 N•m, 10.5 kgf•m)

STEP 5 Stow the flat tire, tire jack and all tools.

#### ■The compact spare tire

- The compact spare tire is identified by the label "TEMPORARY USE ONLY" on the tire sidewall.
  - Use the compact spare tire temporarily only in an emergency.
- Make sure to check the tire pressure of the compact spare tire. (→P. 457)

#### ■When using the compact spare tire

As the compact spare tire is not equipped with the tire pressure warning valve and transmitter, low inflation pressure of the spare tire will not be warned. Also, if you replace the compact spare tire after the tire pressure warning light comes on, the light remains on.

#### ■ If you have a flat front tire on a road covered with snow or ice

Install the compact spare tire on the rear of the vehicle. Perform the following steps and fit tire chains to the front tires.

STEP 1 Replace a rear tire with the compact spare tire.

STEP 2 Replace the flat front tire with the tire removed from the rear of the vehicle

STEP 3 Fit tire chains to the front tires.

#### ■ After completing the tire change (U.S.A. only)

The tire pressure warning system must be reset.  $(\rightarrow P. 355)$ 

#### ■ Jack point guide



The jack point guides are located under the rocker panel. They indicate the jack point positions.

#### **A** CAUTION

#### Using the tire jack

Improper use of the tire jack may lead to death or serious injuries due to the vehicle suddenly falling off the jack.

- Do not use the tire jack for any purpose other than replacing tires or installing and removing tire chains.
- Only use the tire jack that comes with this vehicle for replacing a flat tire.

Do not use it on other vehicles, and do not use other tire jacks for replacing tires on this vehicle.

- Always check that the tire jack is securely set to the jack point.
- Do not put any part of your body under the vehicle while it is supported by a jack.
- Do not start or run the hybrid system while your vehicle is supported by the jack.

#### **A** CAUTION

- Do not raise the vehicle while someone is in it.
- When raising the vehicle, do not put an object on or under the jack.
- Do not raise the vehicle to a height greater than that required to replace the tire.
- Use a jack stand if it is necessary to get under the vehicle.

Take particular care when lowering the vehicle to ensure that no one working on or near the vehicle will be injured.

#### Replacing a flat tire

Observe the following precautions to reduce the risk of death or serious injury.

- Never use oil or grease on the wheel bolts or wheel nuts. Oil and grease may cause the wheel nuts to be excessively tightened. leading to bolt or disc wheel damage. In addition, the oil or grease can cause the wheel nuts to loosen and the wheel may fall off, causing a serious accident. Remove any oil or grease from the wheel bolts or wheel nuts.
- Have the wheel nuts tightened with a torque wrench to 76 ft•lbf (103 N•m, 10.5 kgf•m) as soon as possible after changing wheels. Failure to follow these precautions could cause the nuts to loosen and the wheel may fall off, which could lead to an accident causing death or serious injury.

#### When using the compact spare tire

- Remember that your compact spare tire is specifically designed for use with your vehicle. Do not use your compact spare tire on another vehicle
- Do not use two compact spare tires simultaneously.
- Replace the compact spare tire with a standard tire as soon as possible.
- Avoid sudden acceleration, deceleration and braking, as well as sharp cornering.

#### **CAUTION**

#### Speed limit when using the compact spare tire

Do not drive at speeds in excess of 50 mph (80 km/h) when a compact spare tire is installed on the vehicle.

The compact spare tire is not designed for driving at high speeds. Failing to observe this precaution may lead to an accident causing death or serious injury.

#### When the compact spare tire is attached

The vehicle speed may not be correctly detected, and the following systems may not operate correctly:

- ABS
- Brake assist
- VSC
- TRAC
- VDIM
- Navigation system (if equipped)

### **⚠** NOTICE

#### Do not drive the vehicle with a flat tire.

Do not continue driving with a flat tire.

Driving even a short distance with a flat tire can damage the tire and the wheel beyond repair.

#### When replacing the tires

When removing or fitting the wheels, tires or the tire pressure warning valve and transmitter, contact your Toyota dealer as the tire pressure warning valve and transmitter may be damaged if not handled correctly.

## ■To avoid damage to the tire pressure warning valves and transmitters

When a tire is repaired with liquid sealants, the tire pressure warning valve and transmitter may not operate properly. If a liquid sealant is used, contact your Toyota dealer or other qualified service shop as soon as possible. Make sure to replace the tire pressure warning valve and transmitter when replacing the tire. ( $\rightarrow$ P. 355)

## Be careful when driving over bumps with the compact spare tire installed on the vehicle.

The vehicle becomes lower when driving with the compact spare tire compared to when driving with standard tires. Be careful when driving over uneven road surfaces.

#### Driving with tire chains and the compact spare tire

Do not fit tire chains to the compact spare tire.

Tire chains may damage the vehicle body and adversely affect driving performance.

# 5-2. Steps to take in an emergency If the hybrid system will not start

Reasons for the hybrid system not starting vary depending on the situation. Check the following and perform the appropriate procedure:

- The hybrid system will not start, even though the correct starting procedure is being followed. (→P. 135)
  - One of the following may be the cause of the problem.
  - The electronic key may not be functioning properly. (→P. 433)
  - There may be a malfunction in the immobilizer system.
     (→P. 88)
  - There may be a malfunction in the steering lock system.
  - The hybrid system may be malfunctioning due to an electrical problem such as an open circuit or a blown fuse. However, depending on the type of malfunction, an interim measure is available to start the hybrid system. (→P. 430)
- The interior lights and headlights are dim, or the horn does not sound or sounds at a low volume.

One of the following may be the cause of the problem.

- The 12-volt battery may be discharged. (→P. 436)
- The 12-volt battery terminal connections may be loose or corroded.

The interior lights and headlights do not turn on, or the horn does not sound.

One of the following may be the cause of the problem.

- One or both of the 12-volt battery terminals may be disconnected.
- The 12-volt battery may be discharged. (→P. 436)
- There may be a malfunction in the steering lock system.

Contact your Toyota dealer if the problem cannot be repaired, or if repair procedures are unknown.

#### **Emergency start function**

When the hybrid system does not start, the following steps can be used as an interim measure to start the hybrid system if the "POWER" switch is functioning normally.

- STEP 1 Set the parking brake.
- STEP 2 Shift the shift lever to P.
- STEP 3 Turn the "POWER" switch to ACCESSORY mode.
- Press and hold the "POWER" switch for about 15 seconds while depressing the brake pedal firmly.

Even if the hybrid system can be started using the above steps, the system may be malfunctioning. Have the vehicle checked by your Toyota dealer.


If the shift lever cannot be shifted with your foot on the brake, there may be a problem with the shift lock system (a system to prevent accidental operation of the shift lever). Have the vehicle inspected by your Toyota dealer.

The following steps may be used as an emergency measure to ensure that the shift lever can be shifted.

STEP 1 Set the parking brake.


STEP 2 Turn the "POWER" switch to ACCESSORY mode.

STEP 3 Depress the brake pedal.



Pry the cover up with a flathead screwdriver or equivalent.

STEP 5 Press the "POWER" switch and start the hybrid system. For your safety, keep the brake pedal depressed.



Press the shift lock override button.


The shift lever can be shifted while the button is pressed.

# 5-2. Steps to take in an emergency If you lose your keys

New genuine Toyota keys can be made by your Toyota dealer using the other key and the key number stamped on your key number plate. If communication between the electronic key and the vehicle is interrupted ( $\rightarrow$ P. 41) or the electronic key cannot be used because the battery is depleted, the smart key system and wireless remote control cannot be used. In such cases, the doors and trunk can be opened or the hybrid system can be started by following the procedure below.

## Locking and unlocking the doors and opening the trunk with the mechanical key

#### ▶ Doors




Using the mechanical key ( $\rightarrow$ P. 35) in order to perform the following operations:

- Locks all doors
- 2 Unlocks all doors

Turning the key rearward unlocks the driver's door. Turning the key once again unlocks the other doors.


#### ► Trunk



Turn the mechanical key clockwise to open.

## Changing "POWER" switch modes and starting the hybrid system

STEP 1 Shift the shift lever to P and apply the brakes.



Touch the Toyota emblem side of the electronic key to the "POWER" switch.

If any of the doors is opened and closed and while the key is touched to the "POWER" switch, an alarm will sound to indicate that the start function cannot detect the electronic key.

To change the "POWER" switch modes: Within 10 seconds of the buzzer sounding, release the brake pedal and press the "POWER" switch. Modes can be changed each time the switch is pressed. (→P. 136)

To start the hybrid system: Press the "POWER" switch within 10 seconds after the buzzer sounds, keeping the brake pedal depressed.

In the event that the hybrid system still cannot be operated, contact your Toyota dealer.

## ■ Stopping the hybrid system

Shift the shift lever to P and press the "POWER" switch as you normally do when stopping the hybrid system.

## ■ Replacing the key battery

As the above procedure is a temporary measure, it is recommended that the electronic key battery be replaced immediately when the battery is depleted.  $(\rightarrow P. 372)$ 

#### 5-2. Steps to take in an emergency

## If the vehicle's 12-volt battery is discharged


The following procedures may be used to start the hybrid system if the vehicle's 12-volt battery is discharged.

You can call your Toyota dealer or qualified repair shop.

If you have a set of jumper (or booster) cables and a second vehicle with a 12-volt battery, you can jump start your Toyota following the steps below.

Open the trunk lid and remove the 12-volt battery cover. (→P. 350)

In the event that the trunk opener cannot be used, use the mechanical key to open the trunk. ( $\rightarrow$ P. 433)



Connecting the jumper cables

- 1 Positive (+) battery terminal on your vehicle
- 2 Positive (+) battery terminal on the second vehicle
- 3 Negative (-) battery terminal on the second vehicle
- Connect the jumper cable to ground on your vehicle as shown in the illustration.

- Start the engine of the second vehicle. Increase the gasoline engine speed slightly and maintain at that level for approximately 5 minutes to recharge the 12-volt battery of your vehicle.
- Open and close any of the doors with the "POWER" switch OFF.
- Maintain the engine speed of the second vehicle and turn the "POWER" switch to ON mode, then start the hybrid system.
  - Make sure the "READY" indicator comes on. If the indicator does not comes on, contact your Toyota dealer.
- Once the hybrid system has started, remove the jumper cables in the exact reverse order in which they were connected.

Once the hybrid system starts, have the vehicle checked at your Toyota dealer as soon as possible.

## ■ Avoiding a discharged 12-volt battery

- Turn off the headlights and the audio system while the hybrid system is turned off.
- Turn off any unnecessary electrical components when the vehicle is running at a low speed for an extended period, such as in heavy traffic, etc.
- When the 12-volt battery is removed or discharged
  The hybrid system may not start. (→P. 351)
- Starting the hybrid system when the 12-volt battery is discharged

  The hybrid system cannot be started by push-starting.

## **CAUTION**

### Avoiding 12-volt battery fires or explosions

Observe the following precautions to prevent accidentally igniting the flammable gas that may be emitted from the 12-volt battery.

- Make sure each jumper cable is connected to the correct terminal.
- Do not allow the ends of the jumper cable used for the "+" terminals to come into contact with any other parts or metal surface in the area, such as brackets or unpainted metal.
- Do not allow the "+" and "-" terminals of the jumper cables to come into contact with each other.
- Do not smoke, use matches, cigarette lighters or allow open flame near the 12-volt battery.

### 12-volt battery precautions

The 12-volt battery contains poisonous and corrosive acidic electrolyte, while related parts contain lead and lead compounds. Observe the following precautions when handling the 12-volt battery.

- When working with the 12-volt battery, always wear safety glasses and take care not to allow any battery fluids (acid) to come into contact with skin, clothing or the vehicle body.
- Do not lean over the 12-volt battery.
- In the event that battery fluid comes into contact with the skin or eyes, immediately wash the affected area with water and seek medical attention. Place a wet sponge or cloth over the affected area until medical attention can be received.
- Always wash your hands after handling the 12-volt battery support, terminals, and other battery-related parts.
- Do not allow children near the 12-volt battery.



## NOTICE

## ■When handling jumper cables

Be careful that the jumper cables do not become tangled in the cooling fans or any of the belts when connecting or disconnecting them.

# 5-2. Steps to take in an emergency If your vehicle overheats

### The following may indicate that your vehicle is overheating:

- "WATER TEMP" is shown on the multi-information display:
   The engine may be overheating.
- "HYBRID SYSTEM OVER HEAT" is shown on the multi-information display:

The power control unit may be overheating.

Follow the correction procedure as described below.

## **Correction procedures**

## ■ If "WATER TEMP" is shown on the multi-information display

STEP 1 Stop the vehicle in a safe place and turn off the air conditioning system.

STEP 2 Check to see if steam is coming out from under the hood.

If you see steam:

Stop the hybrid system. Carefully lift the hood after the steam subsides and then restart the hybrid system.

If you do not see steam:

Leave the hybrid system operating and carefully lift the hood.


STEP 3 Check to see if the cooling fan is operating.

If the fans are operating:


Wait until the temperature of the engine (shown on the instrument cluster) begins to fall and then stop the hybrid system.

If the fans are not operating:

Stop the hybrid system immediately and call your Toyota dealer.



After the hybrid system has cooled down sufficiently, check the engine coolant level and inspect the radiator core (radiator) for any leaks.



Add engine coolant if necessary.

Water can be used in an emergency if engine coolant is unavailable. (→P. 454)

## If "HYBRID SYSTEM OVER HEAT" is shown on the multi-information display

Step 1 Stop the vehicle in a safe place and turn off the air conditioning system.

STEP 2 Leave the hybrid system operating and carefully lift the hood.

STEP 3 Check if the cooling fans are operating.


If the fans are operating:

Wait until "HYBRID SYSTEM OVER HEAT" disappears and then stop the hybrid system.


If the message does not disappear, call your Toyota dealer.

If the fans are not operating:

Stop the hybrid system immediately and call your local Toyota dealer.



After the hybrid system has cooled down, check the power control unit coolant level and inspect the cooling system for leaks.



Add power control unit coolant if necessary.

Water can be used in an emergency if power control unit coolant is unavailable. (→P. 454)

Have the vehicle checked at the nearest Toyota dealer as soon as possible.

## Overheating

The following symptoms may occur when your vehicle is overheating:

- Hybrid system output decreases.
- Steam is coming from the engine area.

## **A** CAUTION

- To prevent an accident or injury when inspecting under the hood of vour vehicle
  - If steam is seen coming from under the hood, do not open the hood until the steam has subsided. The engine compartment may be very hot, causing serious injury such as burns.
  - With a hybrid vehicle, there are times when the gasoline engine automatically starts to run or the cooling fans suddenly start to operate. Do not touch or approach the rotating parts of the belt or fans. Doing so may lead to fingers, clothes or tools getting caught, resulting in an accidental injury.
  - Do not loosen the coolant reservoir cap while the hybrid system and radiator are hot.
    - Serious injury, such as burns, may result from hot coolant and steam released under pressure.



## NOTICE

## When adding engine/power control unit coolant

Wait until the hybrid system has cooled down before adding engine/power control unit coolant.

When adding coolant, do so slowly. Adding cool coolant to a hot hybrid system too quickly can cause damage to the hybrid system.


## 5-2. Steps to take in an emergency

## If the vehicle becomes stuck

Carry out the following procedures if the tires spin or the vehicle becomes stuck in mud, dirt, or snow.

- STEP 1 Stop the hybrid system. Set the parking brake and put the shift lever in P.
- STEP 2 Remove the mud, snow, or sand from around the stuck tire.
- STEP 3 Place wood, stones or some other material to help provide traction under the tires.
- STEP 4 Restart the hybrid system.
- STEP 5 Shift the shift lever to the D or R position and carefully apply the accelerator to free the vehicle

## ■ Emergency hooks (if equipped)



When your vehicle becomes stuck and cannot move, the emergency hooks are used for another vehicle to pull your vehicle out in an emergency.

Your vehicle is not designed to tow another vehicle.



## **A** CAUTION

## When attempting to free a stuck vehicle

If you choose to rock the vehicle back and forth to free it, make sure the surrounding area is clear, to avoid striking other vehicles, objects or persons. The vehicle may also lunge forward or lunge back suddenly as it becomes free. Use extreme caution.

## When shifting the shift lever

Be careful not to shift the shift lever with the accelerator pedal depressed. This may lead to unexpected rapid acceleration of the vehicle that may cause an accident and result in death or serious injury.

## **⚠** NOTICE

- To avoid damaging the transmission and other components
  - Avoid spinning the wheels.
  - If the vehicle remains stuck after trying these procedures, the vehicle may require towing to be freed.

# 5-2. Steps to take in an emergency If your vehicle has to be stopped in an emergency

Only in an emergency, such as if it becomes impossible to stop the vehicle in the normal way, stop the vehicle using the following procedure:

STEP 1 Steadily step on the brake pedal with both feet and firmly depress it.

Do not pump the brake pedal repeatedly as this will increase the effort required to slow the vehicle.

STEP 2 Shift the shift lever to N.


If the shift lever is shifted to N

After slowing down, stop the vehicle in a safe place by the road.

STEP 4 Stop the hybrid system.

▶ If the shift lever cannot be shifted to N

Keep depressing the brake pedal with both feet to reduce vehicle speed as much as possible.



Stop the hybrid system by pressing and holding the "POWER" switch for 3 consecutive seconds or more.

STEP 5 Stop the vehicle in a safe place by the road.



## **A** CAUTION

## If the hybrid system has to be turned off while driving

Power assist for the brakes and steering wheel will be lost, making the brake pedal harder to depress and the steering wheel heavier to turn. Decelerate as much as possible before turning off the hybrid system.

5-2. Ste	ne to tal	va in a	n amar	MANCY
J-Z. GIG	ps io ia	חם ווו מו	n emen	4 <b>0</b> 1107

Vehicle specifications

6-1.	Specifications	
	Maintenance data (fuel, oil level, etc.)	450
	Fuel information	459
	Tire information	462
6-2.	Customization	
	Customizable features	474
		474
6-3.	Initialization	474
6-3.		

## 6-1. Specifications

## Maintenance data (fuel, oil level, etc.)

## **Dimensions and weights**


Overall length		189.2 in. (4805 mm)
Overall width		71.7 in. (1820 mm)
Overall height*		57.9 in. (1470 mm)
Wheelbase		109.3 in. (2775 mm)
Tread	Front	62.0 in. (1575 mm)
	Rear	61.6 in. (1565 mm)
Vehicle capacity weight (Occupants + luggage)		900 lb. (410 kg)

<sup>\*:</sup> Unladen vehicles


## Vehicle identification

#### ■ Vehicle identification number

The vehicle identification number (VIN) is the legal identifier for your vehicle. This is the primary identification number for your Toyota. It is used in registering the ownership of your vehicle.




This number is stamped on the top left of the instrument panel.



This number is also on the Certification label on the driver's side center pillar.

## **■** Engine number

The engine number is stamped on the engine block as shown.



## Engine

Model	2AZ-FXE engine
Туре	4 cylinder in-line, 4 cycle, gasoline
Bore and stroke	3.48 × 3.78 in. (88.5 × 96.0 mm)
Displacement	144.1 cu.in. (2362 cm <sup>3</sup> )
Drive belt tension	Automatic adjustment
Valve clearance (engine cold) Intake Exhaust	0.007 — 0.011 in. (0.19 — 0.29 mm) 0.015 — 0.019 in. (0.38 — 0.48 mm)

## Fuel

Fuel type	Unleaded gasoline only
Octane rating	87 (Research Octane Number 91) or higher
Fuel tank capacity (Reference)	17.2 gal. (65 L, 14.3 lmp. gal.)

## **Electric motor (traction motor)**

Туре	Permanent magnet synchronous motor
Maximum output	105 kW
Maximum torque	199 ft•lbf (270 N•m, 27.5 kgf•m)

## **Hybrid battery (traction battery)**

Туре	Nickel-Metal hydride battery
Voltage	7.2 V/module
Capacity	6.5 Ah (3HR)
Quantity	34 modules
Overall voltage	244.8 V

## **Lubrication system**


Oil capacity	
(Drain and refill — refer-	
ence)	
With filter	4.5 qt. (4.3 L, 3.8 lmp. qt.)
Without filter	4.3 qt. (4.1 L, 3.6 lmp. qt.)

## **■** Engine oil selection

"Toyota Genuine Motor Oil" is used in your Toyota vehicle. Use Toyota approved "Toyota Genuine Motor Oil" or equivalent to satisfy the following grade and viscosity.

Oil grade: ILSAC multigrade engine oil

Recommended viscosity: SAE 5W-20 or 0W-20




SAE 5W-20 or 0W-20 engine oil may be used. However, SAE 0W-20 is the best choice for good fuel economy and good starting in cold weather.

The 0W portion of the oil viscosity rating indicates the characteristic of the oil which allows cold startability. Oils with a lower value before the W allow for easier starting of the engine in cold weather.

The 20 in 0W-20 indicates the oil viscosity when the oil is at its operating temperature. An oil with a higher viscosity may be better suited if the vehicle is operated at high speeds, or under extreme load conditions.

How to read oil container label:

The ILSAC (International Lubricant Standardization and Approval Committee) Certification Mark is added to some oil containers to help you select the oil you should use.



## Cooling system

Gasoline engine	6.6 qt. (6.2 L, 5.5 lmp. qt.)
Power control	3.1 qt. (2.9 L, 2.6 lmp. qt.)
unit	
	Use either of the following.
Coolant type	"Toyota Super Long Life Coolant"
	<ul> <li>Similar high-quality ethylene glycol-based non-silicate,</li> </ul>
	non-amine, non-nitrite, and non-borate coolant with
	long-life hybrid organic acid technology
	Do not use plain water alone.

## Ignition system

Spark plug	
Make	DENSO SK20R11 NGK IFR6A11
Gap	0.043 in. (1.1 mm)

## **↑** NOTICE

## ■Iridium-tipped spark plugs

Use only iridium-tipped spark plugs. Do not adjust spark plug gap.

## **Electrical system**

12-volt battery	
Open voltage at 68°F (20°C):	12.6 — 12.8 V Fully charged 12.2 — 12.4 V Half charged 11.8 — 12.0 V Discharged (Voltage checked 20 minutes after the hybrid system and all the lights are turned off)
Charging rates	5 A max.

#### **Transaxle**

Fluid capacity*	4.3 qt. (4.1 L, 3.6 lmp. qt.)
Fluid type	Toyota Genuine ATF WS

\*: The fluid capacity is the quantity of reference. If replacement is necessary, contact your Toyota dealer.



#### NOTICE

## Transmission fluid type

Using transmission fluid other than "Toyota Genuine ATF WS" may cause deterioration in shift quality, locking up of your transmission accompanied by vibration, and ultimately damage the transmission of your vehicle.

#### **Brakes**

Pedal clearance *1	3.1 in. (80 mm)
Pedal free play	0.04 — 0.08 in. (1 — 2 mm)
Brake pad wear limit	0.04 in. (1.0 mm)
Parking brake pedal travel *2	7 — 10 clicks
Fluid type	SAE J1703 or FMVSS No.116 DOT 3

<sup>\*1:</sup> Minimum pedal clearance when depressed with a force of 110 lbf (490 N, 50 kgf) while the hybrid system is running

## Steering

Free play	Less than 1.2 in. (30 mm)
-----------	---------------------------

<sup>\*2:</sup> Parking brake pedal travel when depressed with a force of 67 lbf (300 N, 31 kgf).

## Tires and wheels

Tire size	P215/60R16 94V, T155/70D17 110M
Tire inflation pressure (Recommended cold tire inflation pressure)	Driving under normal conditions Front: 32 psi (220 kPa, 2.2 kgf/cm² or bar)* Rear: 32 psi (220 kPa, 2.2 kgf/cm² or bar)* Spare: 60 psi (420 kPa, 4.2 kgf/cm² or bar) *: When driving at high speeds above 100 mph (160 km/h), in countries where such speeds are permitted by law, add 3 psi (20 kPa, 0.2 kgf/cm² or bar) to the front tires and rear tires. Never exceed the maximum cold tire inflation pressure indicated on the tire sidewall.
Wheel size	16 × 6 1/2 J or 16 × 6 1/2 JJ, 17 × 4 T (compact spare)
Wheel nut torque	76 ft•lbf (103 N•m, 10.5 kgf•m)

## Light bulbs

	Light Bulbs	Bulb No.	W	Туре
	Headlights Low beam High beam	9005	55 60	A B
	Front side marker/ parking lights		5	D
Exterior	Exterior Front turn signal lights	_	21	D
Li Ba Fı	Rear turn signal lights	_	21	С
	License plate lights	_	5	С
	Back-up lights	921	16	С
	Front fog lights (if equipped)	_	55	А
Interior Door Vani	Personal lights	_	5	С
	Interior light	_	8	Е
	Door courtesy lights	168	5	С
	Vanity lights	_	8	С
	Glove box light	_	1.2	С
	Trunk light		3.8	С

A: H11 halogen bulbs

B: HB3 halogen bulbs

C: Wedge base bulbs (clear)

D: Wedge base bulbs (amber)

E: Double end bulbs

## Fuel information

You must only use unleaded gasoline in your vehicle.

Select octane rating 87 (Research Octane Number 91) or higher. Use of unleaded gasoline with an octane rating lower than 87 may result in engine knocking. Persistent knocking can lead to engine damage.

At minimum, the gasoline you use should meet the specifications of ASTM D4814 in the U.S.A. and CGSB3.5-M93 in Canada.

#### ■ Fuel tank opening for unleaded gasoline

To help prevent incorrect fueling, your Toyota has a fuel tank opening that only accommodates the special nozzle on unleaded fuel pumps.

### ■ If your engine knocks

- Consult your Toyota dealer.
- You may occasionally notice light knocking for a short time while accelerating or driving uphill. This is normal and there is no need for concern.

## ■ Gasoline quality

In very few cases, driveability problems may be caused by the brand of gasoline you are using. If driveability problems persist, try changing the brand of gasoline. If this does not correct the problem, consult your Toyota dealer.

## ■ Gasoline quality standards

- Automotive manufacturers in the U.S., Europe and Japan have developed a specification for fuel quality called the World-Wide Fuel Charter (WWFC) that is expected to be applied worldwide.
- The WWFC consists of four categories that are based on required emission levels. In the U.S., category 4 has been adopted.
- The WWFC improves air quality by lowering emissions in vehicle fleets. and improves customer satisfaction through better performance.

### ■ Toyota recommends the use of gasoline containing detergent additives

- Toyota recommends the use of gasoline that contains detergent additives to avoid build-up of engine deposits.
- All gasoline sold in the U.S. contains detergent additives to clean and/or keep clean intake systems.

#### ■ Toyota recommends the use of cleaner burning gasoline

Cleaner burning gasoline, including reformulated gasoline that contains oxygenates such as ethanol or MTBE (Methyl Tertiary Butyl Ether) is available in many areas.

Toyota recommends the use of cleaner burning gasoline and appropriately blended reformulated gasoline. These types of gasoline provide excellent vehicle performance, reduce vehicle emissions and improve air quality.

#### ■ Toyota does not recommend blended gasoline

- Toyota allows the use of oxygenate blended gasoline where the oxygenate content is up to 10% ethanol or 15% MTBE.
- If you use gasohol in your Toyota, be sure that it has an octane rating no lower than 87.
- Toyota does not recommend the use of gasoline containing methanol.

## ■ Toyota does not recommend gasoline containing MMT

Some gasoline contains octane enhancing additive called MMT (Methylcy-clopentadienyl Manganese Tricarbonyl).

Toyota does not recommend the use of gasoline that contains MMT. If fuel containing MMT is used, your emission control system may be adversely affected.

The malfunction indicator lamp on the instrument cluster may come on. If this happens, contact your Toyota dealer for service.

## $\triangle$

#### **NOTICE**

## Notice on fuel quality

- Do not use improper fuels. If improper fuels are used the engine will be damaged.
- Do not use leaded gasoline.
   Leaded gasoline can cause damage to your vehicle's catalytic converters causing the emission control system to malfunction.
- Do not use gasohol other than that stated here.
   Other gasohol may cause fuel system damage or vehicle performance problems.

### Fuel-related poor driveability

If after using a different type of fuel, poor driveability is encountered (poor hot starting, vaporization, engine knocking, etc.), discontinue the use of that type of fuel.


### When refueling with gasohol

Take care not to spill gasohol. It can damage your vehicle's paint.


## Tire information

## Typical tire symbols

### ▶ Standard tire



## ► Compact spare tire



(→P. 465)

2 DOT and Tire Identification Number (TIN) (→P. 464)

3 Uniform tire quality grading For details, see "Uniform Tire Quality Grading" that follows.

4 Location of treadwear indicators (→P. 354) 5 Tire ply composition and materials

Plies are layers of rubber-coated parallel cords. Cords are the strands which form the plies in a tire.

6 Radial tires or bias-ply tires

A radial tire has "RADIAL" on the sidewall. A tire not marked "RADIAL" is a bias-ply tire.


**T** "TUBELESS" or "TUBE TYPE"

A tubeless tire does not have a tube and air is directly filled in the tire. A tube type tire has a tube inside the tire and the tube maintains the air pressure.

- **B** Load limit at maximum cold tire inflation pressure  $(\rightarrow P. 358)$
- Maximum cold tire inflation pressure (→P. 457)
   This means the pressure to which a tire may be inflated.
- Summer tires or all season tires (→P. 359)
  An all season tire has "M+S" on the sidewall. A tire not marked "M+S" is a summer tire.
- 11 "TEMPORARY USE ONLY" (→P. 424)

A compact spare tire is identified by the phrase "TEMPORARY USE ONLY" molded into its sidewall. This tire is designed for temporary emergency use only.


## Typical DOT and Tire Identification Number (TIN)



- DOT symbol\*
- Tire Identification Number (TIN)
- Tire manufacturer's identification mark
- 4 Tire size code
- Manufacturer's optional tire type code (3 or 4 letters)
- 6 Manufacturing week
- Manufacturing year
  - \*: The DOT symbol certifies that the tire conforms to applicable Federal Motor Vehicle Safety Standards.

## Tire size


## **■** Typical tire size information



The illustration indicates typical tire size.


- Tire use
  (P = Passenger car,
  T = Temporary use)
- Section width (millimeters)
- Aspect ratio (tire height to section width)
- Tire construction code
  (R = Radial, D = Diagonal)
- 5 Wheel diameter (inches)
- 6 Load index (2 or 3 digits)
- Speed symbol (alphabet with one letter)

#### **■** Tire dimensions



- Section width
- 2 Tire height
- 3 Wheel diameter

## Tire section names



- Bead
- 2 Sidewall
- Shoulder
- 4 Tread
- 5 Belt
- 6 Inner liner
- 7 Reinforcing rubber
- 8 Carcass
- 9 Rim lines
- Bead wires
- Chafer

## **Uniform Tire Quality Grading**

This information has been prepared in accordance with regulations issued by the National Highway Traffic Safety Administration of the U.S.A. Department of Transportation.

It provides the purchasers and/or prospective purchasers of Toyota vehicles with information on uniform tire quality grading.

Your Toyota dealer will help answer any questions you may have as you read this information.

## ■ DOT quality grades

All passenger vehicle tires must conform to Federal Safety Requirements in addition to these grades. Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width.

For example: Treadwear 200 Traction AA Temperature A

#### ■ Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course.

For example, a tire graded 150 would wear one and a half (1-1/2) times as well on the government course as a tire graded 100.

The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

### ■ Traction AA, A, B, C

The traction grades, from highest to lowest, are AA, A, B and C, and they represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete.

A tire marked C may have poor traction performance.

Warning: The traction grade assigned to this tire is based on braking (straight ahead) traction tests and does not include cornering (turning) traction.

## ■ Temperature A, B, C

The temperature grades are A (the highest), B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel.

Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure.

The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109.

Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

Warning: The temperature grades for this tire are established for a tire that is properly inflated and not overloaded.

Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure.

## Glossary of tire terminology

Tire related term	Meaning
Cold tire inflation pressure	Tire pressure when the vehicle has been parked for three hours or more, or has not been driven more than 1 mile or 1.5 km under that condition
Maximum inflation pressure	The maximum cold inflated pressure to which a tire may be inflated, shown on the sidewall of the tire
Recommended inflation pressure	Cold tire inflation pressure recommended by a manufacturer
Accessory weight	The combined weight (in excess of those standard items which may be replaced) of automatic transmission, power steering, power brakes, power windows, power seats, radio and heater, to the extent that these items are available as factory-installed equipment (whether installed or not)
Curb weight	The weight of a motor vehicle with standard equipment, including the maximum capacity of fuel, oil and coolant, and if so equipped, air conditioning and additional weight optional engine
Maximum loaded vehi- cle weight	The sum of: (a) Curb weight (b) Accessory weight (c) Vehicle capacity weight (d) Production options weight

Tire related term	Meaning
Normal occupant weight	150 lb. (68 kg) times the number of occupants specified in the second column of Table 1* that follows
Occupant distribution	Distribution of occupants in a vehicle as specified in the third column of Table 1* below
Production options weight	The combined weight of installed regular production options weighing over 5 lb. (2.3 kg) in excess of the standard items which they replace, not previously considered in curb weight or accessory weight, including heavy duty brakes, ride levelers, roof rack, heavy duty battery, and special trim
Rim	A metal support for a tire or a tire and tube assembly upon which the tire beads are seated
Rim diameter (Wheel diameter)	Nominal diameter of the bead seat
Rim size designation	Rim diameter and width
Rim type designation	The industry manufacturer's designation for a rim by style or code
Rim width	Nominal distance between rim flanges
Vehicle capacity weight (Total load capacity)	The rated cargo and luggage load plus 150 lb. (68 kg) times the vehicle's designated seating capacity
Vehicle maximum load on the tire	The load on an individual tire that is determined by distributing to each axle its share of the maximum loaded vehicle weight, and dividing by two
Vehicle normal load on the tire	The load on an individual tire that is determined by distributing to each axle its share of curb weight, accessory weight, and normal occupant weight (distributed in accordance with Table 1* below), and dividing by two

Tire related term	Meaning
Weather side	The surface area of the rim not covered by the inflated tire
Bead	The part of the tire that is made of steel wires, wrapped or reinforced by ply cords and that is shaped to fit the rim
Bead separation	A breakdown of the bond between components in the bead
Bias ply tire	A pneumatic tire in which the ply cords that extend to the beads are laid at alternate angles substantially less than 90 degrees to the centerline of the tread
Carcass	The tire structure, except tread and sidewall rubber which, when inflated, bears the load
Chunking	The breaking away of pieces of the tread or sidewall
Cord	The strands forming the plies in the tire
Cord separation	The parting of cords from adjacent rubber compounds
Cracking	Any parting within the tread, sidewall, or inner- liner of the tire extending to cord material
СТ	A pneumatic tire with an inverted flange tire and rim system in which the rim is designed with rim flanges pointed radially inward and the tire is designed to fit on the underside of the rim in a manner that encloses the rim flanges inside the air cavity of the tire
Extra load tire	A tire designed to operate at higher loads and at higher inflation pressures than the corresponding standard tire
Groove	The space between two adjacent tread ribs
Innerliner	The layer(s) forming the inside surface of a tubeless tire that contains the inflating medium within the tire

Tire related term	Meaning
Innerliner separation	The parting of the innerliner from cord material in the carcass
Intended outboard sidewall	<ul> <li>(a) The sidewall that contains a whitewall, bears white lettering, or bears manufacturer, brand, and/or model name molding that is higher or deeper than the same molding on the other sidewall of the tire, or</li> <li>(b) The outward facing sidewall of an asymmetrical tire that has a particular side that must always face outward when mounted on a vehicle</li> </ul>
Light truck (LT) tire	A tire designated by its manufacturer as prima- rily intended for use on lightweight trucks or multipurpose passenger vehicles
Load rating	The maximum load that a tire is rated to carry for a given inflation pressure
Maximum load rating	The load rating for a tire at the maximum permissible inflation pressure for that tire
Maximum permissible inflation pressure	The maximum cold inflation pressure to which a tire may be inflated
Measuring rim	The rim on which a tire is fitted for physical dimension requirements
Open splice	Any parting at any junction of tread, sidewall, or innerliner that extends to cord material
Outer diameter	The overall diameter of an inflated new tire
Overall width	The linear distance between the exteriors of the sidewalls of an inflated tire, including elevations due to labeling, decorations, or protective bands or ribs
Passenger car tire	A tire intended for use on passenger cars, multipurpose passenger vehicles, and trucks, that have a gross vehicle weight rating (GVWR) of 10,000 lb. or less.

Tire related term	Meaning
Ply	A layer of rubber-coated parallel cords
Ply separation	A parting of rubber compound between adjacent plies
Pneumatic tire	A mechanical device made of rubber, chemicals, fabric and steel or other materials, that, when mounted on an automotive wheel, provides the traction and contains the gas or fluid that sustains the load
Radial ply tire	A pneumatic tire in which the ply cords that extend to the beads are laid at substantially 90 degrees to the centerline of the tread
Reinforced tire	A tire designed to operate at higher loads and at higher inflation pressures than the corresponding standard tire
Section width	The linear distance between the exteriors of the sidewalls of an inflated tire, excluding elevations due to labeling, decoration, or protective bands
Sidewall	That portion of a tire between the tread and bead
Sidewall separation	The parting of the rubber compound from the cord material in the sidewall
Snow tire	A tire that attains a traction index equal to or greater than 110, compared to the ASTM-E 1136 Standard Reference Test Tire, when using the snow traction test as described in ASTM F-1805-00, Standard Test Method for Single Wheel Driving Traction in a Straight Line on Snow-and Ice-Covered Surfaces, and which
	is marked with an Alpine Symbol ( 🎪 ) on at least one sidewall
Test rim	The rim on which a tire is fitted for testing, and may be any rim listed as appropriate for use with that tire

Tire related term	Meaning
Tread	That portion of a tire that comes into contact with the road
Tread rib	A tread section running circumferentially around a tire
Tread separation	Pulling away of the tread from the tire carcass
Treadwear indicators (TWI)	The projections within the principal grooves designed to give a visual indication of the degrees of wear of the tread
Wheel-holding fixture	The fixture used to hold the wheel and tire assembly securely during testing

<sup>\*:</sup> Table 1 — Occupant loading and distribution for vehicle normal load for various designated seating capacities

Designated seating capacity, Number of occupants	Vehicle normal load, Number of occupants	Occupant distribution in a normally loaded vehicle
2 through 4	2	2 in front
5 through 10	3	2 in front, 1 in second seat
11 through 15	5	2 in front, 1 in second seat, 1 in third seat, 1 in fourth seat
16 through 20	7	2 in front, 2 in second seat, 2 in third seat, 1 in fourth seat

#### **Customizable features**

Your vehicle includes a variety of electronic features that can be personalized to your preferences. Programming these preferences requires specialized equipment and may be performed by your Toyota dealer.

Some function settings are changed simultaneously with other functions being customized. Contact your Toyota dealer.

Item	Function	Default setting	Customized setting
	Smart key system	On	Off
Smart key system (→P. 37)	Operation signal (Emergency flashers)	On	Off
	Operation signal (Buzzer)	On	Off

Item	Function	Default setting	Customized setting
	Wireless remote control	On	Off
	Unlocking operation	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step.
	Automatic door lock function to be activated if door is not opened after being unlocked	On	Off
Wireless	Time elapsed before automatic door lock function is activated if	60 seconds	30 seconds
remote con- trol	door is not opened after being unlocked		120 seconds
(→P. 48)	Operation signal (Emergency flashers)	On	Off
	Operation signal (Buzzer)	On	Off
	Door lock buzzer	On	Off
	Panic function	On	Off
	Trunk unlocking function	On	Off
	Trunk unlocking operation	Press and hold	Press twice
			One short press

Item	Function	Default setting	Customized setting
	Unlocking using a key	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step.
Door lock	Speed-detecting auto- matic door lock function	Off	On
(→P. 51)	Opening driver's door unlocks all doors	Off	On
	Shifting gears to P unlocks all doors.	On	Off
	Shifting gears to position other than P locks all doors.	On	Off
Automatic	Light sensor sensitivity	Level 3	Level 1 to 5
light control	Time elapsed before headlights automatically turn off after doors	30 seconds	0 seconds
system (→P. 154)			60 seconds
(-71.104)	are closed		90 seconds
Lights (→P. 154)	Daytime running light system (U.S.A. only)	On	Off
	Time elapsed before lights turn off	15 seconds	7.5 seconds
Illumination (→P. 291)			30 seconds
	Operation when the doors are unlocked	On	Off
	Operation after the hybrid system is off	On	Off
Seat belt reminder (→P. 402)	Vehicle speed linked seat belt reminder buzzer	On	Off

The following items must be initialized for normal system operation in cases such as after the 12-volt battery is reconnected, or maintenance is performed on the vehicle.

Item	When to initialize	Reference
Engine oil mainte- nance data (U.S.A.)	After changing engine oil	P. 344
Tire pressure warning system	When the tire inflation pressure is charged (such as when changing traveling speed).	P. 355

## For owners

Reporting safety defects	
for U.S. owners	480
Seat belt instructions	
for Canadian owners	
(in French)	481
SRS airbag instructions	
for Canadian owners	
(in French)	484

# Reporting safety defects for U.S. owners

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Toyota Motor Sales, U.S.A., Inc. (Toll-free: 1-800-331-4331).

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Toyota Motor Sales, U.S.A., Inc.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to http://www.safercar.gov; or write to: Administrator, NHTSA, 1200 New Jersey Ave, S.E., Washington, DC 20590. You can also obtain other information about motor vehicle safety from http://www.safercar.gov.


# For owners

# **Seat belt instructions for Canadian owners (in French)**

The following is a French explanation of seat belt instructions extracted from the seat belt section in this manual.

See the seat belt section for more detailed seat belt instructions in English.


#### Utilisation correcte des ceintures de sécurité




- Tendez la sangle diagonale de sorte qu'elle couvre complètement l'épaule, sans entrer en contact avec le cou ou glisser de l'épaule.
- Placez la sangle abdominale le plus bas possible sur les hanches.
- Réglez la position du dossier de siège. Asseyez-vous le dos le plus droit possible et calezvous bien dans le siège.
- Ne vrillez pas la ceinture de sécurité.

#### Guide de confort de ceinture de sécurité (siège arrière extérieur)

Si la sangle diagonale gêne la personne au niveau du cou, utilisez le guide confort de la ceinture de sécurité.




Sortez le guide confort de sa poche.




Engagez la ceinture dans le guide.

Le cordon élastique doit passer sous la ceinture de sécurité.



Bouclez, positionnez et lâchez la ceinture de sécurité.

#### ■ Ceintures de sécurité arrière



Si la ceinture de sécurité est sortie de son guide, repassez-la dedans avant de l'utiliser.

#### Entretien et soin

#### ■ Ceintures de sécurité

Nettoyez avec un chiffon ou une éponge humectée d'eau savonneuse tiède. Profitez de l'occasion pour vérifier régulièrement que les ceintures ne sont pas effilochées, entaillées, ou ne paraissent pas exagérément usées.

## **A** ATTENTION


#### Détérioration et usure des ceintures de sécurité

Inspectez les ceintures de sécurité périodiquement. Contrôlez qu'elles ne sont pas entaillées, effilochées, et que leurs ancrages ne sont pas desserrés. N'utilisez pas une ceinture de sécurité défectueuse avant qu'elle ne soit remplacée. Une ceinture de sécurité défectueuse n'apporte aucune garantie de protection de l'occupant en cas d'accident.

# SRS airbag instructions for Canadian owners (in French)

The following is a French explanation of SRS airbag instructions extracted from the SRS airbag section in this manual.


See the SRS airbag section for more detailed SRS airbag instructions in English.



- ➤ Sacs de sécurité gonflables frontaux
- Sac de sécurité gonflable conducteur/sac de sécurité gonflable passager avant
  - Participent à la protection de la tête et du thorax du conducteur et du passager contre les chocs avec les éléments de l'habitacle.
- Sac de sécurité gonflable genoux conducteur Contribue à accroître la protection du conducteur.

- ▶ Sacs de sécurité gonflables latéraux et rideau
- Sacs de sécurité gonflables latéraux Participent à la protection du thorax des occupants des sièges avant.
- Sacs de sécurité gonflables rideau Participent principalement à la protection de la tête des occupants assis aux places extérieures.

## Composition du système de sacs de sécurité gonflables



- Capteurs de sacs de sécurité gonflables frontaux
- Système de classification de l'occupant du siège passager avant (ECU et capteurs)
- 3 Capteurs de sacs de sécurité gonflables latéraux et rideau
- Sac de sécurité gonflable passager avant
- Sacs de sécurité gonflables latéraux
- Sacs de sécurité gonflables rideau
- Témoins "AIR BAG ON" et "AIR BAG OFF"

- 8 Voyant SRS
- Contacteur de boucle de ceinture de sécurité passager avant
- Boîtier électronique de sacs de sécurité gonflables
- Capteurs de sacs de sécurité gonflables rideau
- 12 Sac de sécurité gonflable conducteur
- Capteur de la position du siège conducteur
- Contacteur de boucle de ceinture de sécurité conducteur
- Sac de sécurité gonflable de genoux

Votre véhicule est équipé de SACS DE SECURITE GONFLABLES INTELLIGENTS (ADVANCED AIRBAGS) conçus selon les normes de sécurité américaines applicables aux véhicules à moteur (FMVSS208). Le système de sac de sécurité gonflable contrôle la puissance de déploiement des sacs de sécurité gonflables conducteur et passager avant. Le système de sac de sécurité gonflable conducteur se compose d'un capteur de position de siège conducteur, etc. Le système de sac de sécurité gonflable passager avant se compose d'un capteur de classification des occupants du siège passager avant, etc..

Les principaux éléments du système de sacs de sécurité gonflables SRS sont illustrés ci-dessus. Le système des sacs de sécurité gonflables SRS est commandé par un boîtier électronique. Ce boîtier intègre un capteur de sécurité et un capteur de sac de sécurité gonflable.


Lorsque la violence du choc frontal ou latéral l'exige, le système de sacs de sécurité gonflables SRS déclenche les dispositifs pyrotechniques de gonflage (générateurs de gaz). Le déploiement rapide des sacs de sécurité gonflables est obtenu au moyen d'une réaction chimique dans les dispositifs pyrotechniques, qui produit un gaz inoffensif permettant d'amortir le mouvement des occupants.

#### ■Précautions à observer avec les sacs de sécurité gonflables SRS

Respectez les précautions suivantes avec les sacs de sécurité gonflables. À défaut, des blessures graves, voire mortelles, pourraient s'ensuivre.

- Le conducteur et tous les passagers à bord du véhicule doivent porter leur ceinture de sécurité correctement.
  - Les sacs de sécurité gonflables SRS sont des dispositifs de protection complémentaires aux ceintures de sécurité.
- Le sac de sécurité gonflable SRS conducteur se déploie avec une violence considérable, qui peut être très dangereuse voire mortelle si le conducteur se trouve très près du sac de sécurité gonflable.
  - L'autorité fédérale chargée de la sécurité routière aux États-Unis, la NHTSA (National Highway Traffic Safety Administration) conseille:
  - Sachant que la zone de danger pour le sac de sécurité gonflable conducteur se trouve dans les premiers 2 à 3 in. (50 à 75 mm) du déploiement, placez-vous à 10 in. (250 mm) du sac de sécurité gonflable conducteur pour garantir une marge de sécurité suffisante. Cette distance est à mesurer entre le moyeu du volant de direction et le sternum. Si vous êtes actuellement assis à moins de 10 in. (250 mm), vous pouvez changer votre position de conduite de différentes façons:
  - Reculez votre siège au maximum tout en atteignant confortablement les pédales;
  - Inclinez légèrement le dossier du siège. Bien que la conception des véhicules soit variable, la plupart des conducteurs peuvent s'asseoir à une distance de 10 in. (250 mm), même avec le siège conducteur complètement avancé, en inclinant simplement un peu le dossier du siège. Si vous avez des difficultés à voir la route après avoir incliné votre siège, utilisez un coussin ferme et antidérapant pour vous rehausser, ou si votre véhicule est équipé du réglage en hauteur du siège, remontez-le.
  - Si votre volant de direction est réglable, inclinez-le vers le bas. Cela a pour effet d'orienter le sac de sécurité gonflable en direction de votre poitrine plutôt que de votre tête et de votre cou.

Le siège doit être réglé selon les recommandations de la NHTSA cidessus, tout en conservant le contrôle des pédales, du volant de direction et la vue des commandes du tableau de bord.



#### ■Précautions à observer avec les sacs de sécurité gonflables SRS



- Si vous attachez une rallonge de ceinture de sécurité à la boucle du siège conducteur, mais pas à la ceinture de sécurité proprement dite, le système de sac de sécurité gonflable SRS conducteur pense que vous avez attaché votre ceinture de sécurité, alors qu'en fait c'est faux. Dans ce cas, il se peut que le sac de sécurité gonflable conducteur ne déploie se correctement en cas d'accident, et vous d'être tué ou grièvement blessé. Veillez donc à porter la ceinture de sécurité avec la rallonge de ceinture de sécurité.
- Le sac de sécurité gonflable SRS du passager avant se déploie également avec une violence considérable, qui peut être très dangereuse voire mortelle si le passager se trouve très près du sac de sécurité gonflable. Eloignez le siège passager au maximum du sac de sécurité gonflable, et réglez le dossier de siège de sorte telle sorte que le passager avant soit assis bien droit dans son siège.
- Les nourrissons et les enfants qui ne sont pas correctement assis et/ou protégés peuvent être grièvement blessés ou tués par le déploiement d'un sac de sécurité gonflable. Installez les enfants trop jeunes pour pouvoir utiliser la ceinture de sécurité dans un siège de sécurité enfant. Toyota recommande vivement que les nourrissons et les jeunes enfants soient installés sur le siège arrière du véhicule et convenablement attachés. C'est à l'arrière que les nourrissons et les enfants sont les mieux protégés.

#### ■Précautions à observer avec les sacs de sécurité gonflables SRS

• N'installez jamais un siège de sécurité enfant type dos à la route sur le siège passager avant, même si le témoin "AIR BAG OFF" est allumé. En cas d'accident, par la violence et la vitesse de son déploiement, le sac de sécurité gonflable passager avant peut blesser grièvement, voire tuer l'enfant si vous l'avez installé à la place du passager avant dans un siège de sécurité enfant type dos.



 Ne vous asseyez pas sur le bord du siège et ne vous appuyez pas contre la planche de bord.




- Ne laissez pas un enfant rester debout devant le sac de sécurité gonflable SRS passager avant ou bien s'asseoir sur les genoux du passager avant.
- Ne conduisez pas le véhicule avec quelque chose sur les genoux, et n'autorisez pas non plus le passager à voyager avec quelque chose sur les genoux.



Ne vous appuyez pas contre la porte, contre le rail latéral de toit ou contre les montants avant, latéraux et arrière.

#### ■Précautions à observer avec les sacs de sécurité gonflables SRS







Ne fixez ni ne posez aucun objet sur la planche de bord, la garniture centrale du moyeu de volant de direction ou la partie inférieure du tableau de bord. Au déploiement des sacs de sécurité gonflables SRS conducteur, passager avant et genoux, tout objet risque de se transformer en projectile.



- Ne fixez aucun objet sur les portes, la vitre de pare-brise, les vitres latérales, les montants avant et arrière, le rail latéral de toit et la poignée de maintien.
- Ne suspendez aux crochets à vêtements aucun cintre ni aucun objet dur. En cas de déploiement du sac de sécurité gonflable SRS rideau, ces objets peuvent se transformer en projectiles capables de vous blesser grièvement, voire de vous tuer.
- Si un cache en vinyle est mis dans la zone où le sac de sécurité gonflable SRS de genoux se déploie, assurez-vous de l'enlever.
- N'utilisez aucun accessoire de siège venant recouvrir les zones de déploiement des sacs de sécurité gonflables SRS latéraux, car il risquerait d'en gêner le déploiement.

#### ■ Précautions à observer avec les sacs de sécurité gonflables SRS

- Évitez de faire subir des chocs ou des pressions excessives aux zones renfermant les composants des sacs de sécurité gonflables SRS (→P. 486).
  - En effet, cela pourrait entraîner un fonctionnement anormal des sacs de sécurité gonflables SRS.
- Ne touchez aucun composant du système immédiatement après le déclenchement (déploiement) des sacs de sécurité gonflables SRS, car ils sont alors encore très chauds.
- Si vous avez des difficultés à respirer après le déploiement d'un sac de sécurité gonflable SRS, ouvrez une porte ou une vitre pour faire entrer de l'air frais, ou bien descendez du véhicule si cela ne présente pas de danger. Essuyez tout résidu dès que possible afin d'éviter d'éventuelles irritations de la peau.
- Si les parties renfermant les sacs de sécurité gonflables SRS, telles que la garniture du moyeu de volant et les garnitures de montants avant et arrière, apparaissent abîmées ou craquelées, faites-les remplacer par votre concessionnaire Toyota.

# **A** ATTENTION

#### Modification et mise au rebut des éléments du système de sacs de sécurité gonflables SRS

Consultez impérativement votre concessionnaire Toyota si vous avez besoin d'intervenir sur votre véhicule ou de procéder à l'une des modifications suivantes.

Les sacs de sécurité gonflables SRS risquent de ne pas fonctionner correctement ou de se déployer (gonfler) accidentellement, provoquant ainsi des blessures graves, voire mortelles.

- Installation, dépose, démontage et réparations des sacs de sécurité gonflables SRS.
- Réparations, modifications, dépose ou remplacement du volant, du tableau de bord, de la planche de bord, des sièges ou de leur garnissage, des montants avant, latéraux et arrière ou des rails latéraux de toit.
- Réparations ou modifications de l'aile avant, du bouclier avant, ou du côté de l'habitacle.
- Installation de chasse-neige, de treuils, etc. sur la calandre (pare-buffle, pare-kangourou, etc.).
- Modifications des suspensions du véhicule.
- Installation d'appareils électroniques tels que radio émetteur/récepteur ou lecteurs CD.
- Aménagements apportés au véhicule pour une personne atteinte d'un handicap physique.

#### Index

Abbreviation list	496
Alphabetical index	497
What to do if	506

For details of equipment related to the navigation system and navigation system screen, refer to the "Navigation System Owner's Manual".

# Abbreviation list Abbreviation/Acronym list

ABBREVIATIONS	MEANING
A/C	Air Conditioning
ABS	Anti-lock Brake System
ALR	Automatic Locking Retractor
CRS	Child Restraint System
DISP	Display
ECO	Economical/Ecology
ECU	Electronic Control Unit
EDR	Event data recorder
ELR	Emergency Locking Retractor
EPS	Electric Power Steering
GAWR	Gross Axle Weight Ratings
GVWR	Gross Vehicle Weight Rating
I/M	Emission inspection and maintenance
LATCH	Lower Anchors and Tethers for Children
LED	Light Emitting Diode
MMT	Methylcyclopentadienyl Manganese Tricarbonyl
M + S	Mud and Snow
MTBE	Methyl Tertiary Butyl Ether
OBD	On Board Diagnostics
SRS	Supplemental Restraint System
TIN	Tire Identification Number
TPMS	Tire Pressure Warning System
TRAC	Traction Control
VDIM	Vehicle Dynamics Integrated Management
VIN	Vehicle Identification Number
VSC	Vehicle Stability Control

# Alphabetical index

# Alphabetical index

Α	A/C 182 ABS 165
	Air conditioning filter 369 Air conditioning system
	Air conditioning system Air conditioning filter 369
	Automatic air conditioning
	system182
	Airbags
	•
	Airbag operating conditions 95
	Airbag precautions for
	your child
	Airbag warning light
	Curtain shield airbag
	operating conditions96
	Curtain shield airbag
	precautions 99
	Front passenger occupant
	classification system 104
	General airbag precautions 99
	Locations of airbags 92
	Modification and disposal
	of airbags 103
	Proper driving posture 90, 99
	Side airbag operating
	conditions96
	Side airbag precautions 99
	SRS airbags 92
	Antenna199
	Anti-lock brake system 165
	Armrest 309
	Ashtray 304
	Audio input 237

	Audio system	
	Antenna	199
	Audio input	237
	AUX port	237
	CD player/changer	202
	MP3/WMA disc	210
	Optimal use	232
	Portable music player	237
	Radio	195
	Steering wheel audio	
	switch	239
	Type	192
	Automatic air conditioning	
	system	182
	Automatic light control	
	system	
	AUX port	237
	Auxiliary boxes	298
В	<b>5</b>	
D	Back-up lights	450
	Wattage	458
	Battery	050
	Checking	350
	Hybrid battery	0.5
	(traction battery)	25
	If the vehicle has	
	discharged 12-volt	400
	battery	436
	Preparing and checking	
	before winter	
	Bluetooth® audio	242
	Bluetooth® phone	258
	Brake	0.40
	Fluid	
	Parking brake	
	Brake assist	165
	Break-in tips	40-

#### С

# Care 324 Interior 326 Seat belts 327 Cargo capacity 169 Cargo net 311 CD changer 202

#### 

Convertible seats,
installation113
Front passenger occupant
classification system104
Infant seats, definition109
Infant seats, installation113
Installing CRS with
LATCH anchors114

seat belts ......116

tether straps......119

Installing CRS with

Installing CRS with top

#### Child safety

Airbag precautions	99
Child restraint system	. 109
Child-protectors	52
How your child should wear	
the seat belt	68
Installing child restraints	.113
Moon roof precautions	82
Power window lock switch	77
Power window precautions	78
Removed key battery	
precautions	.373
Seat belt comfort guide	65
Seat belt extender	
precautions	71
Seat belt precautions	69
Seat heater precautions	.307
Trunk precautions	57
12-volt battery	
precautions352,	438
Child-protectors	52
Cleaning	
Exterior	.324
Interior	.326
Seat belts	.327
Clock	.303
Compass	.319
Condenser	
Console box	. 295
Cooling system	
Engine overheating	
Cruise control	
Cup holder	
Curtain shield airbags	
Cuctomizable features	171

ı	Daytime running light
	system 156
ı	Defogger
	Rear window 191
	Side mirror 191
ı	Dimension 450
ı	Dinghy towing178
ı	Display
	Trip information 151
	Warning message 408
ı	Do-it-yourself maintenance 335
ı	Door courtesy light
	Door courtesy light 291
	Wattage 458
ı	Doors
	Door glasses 77
	Door lock 37, 48, 51
	Side mirrors75
ı	Driver's seat belt reminder
	light 402
ı	Driving
	Break-in tips 125
	Correct posture 90
	Procedures124
	Winter driving tips 173

"ECO HEAT/COOL" switch 182
Electronic key
If your electronic key
battery is discharged433
Electric power steering165
Emergency flashers
Switch392
Emergency, in case of
If a warning light turns on399
If a warning message is
displayed408
If the electronic key does
not operate properly433
If the hybrid system
will not start429
If the shift lever cannot be
shifted from P431
If the vehicle has discharged
12-volt battery436
If the warning buzzer
sounds399
If you have a flat tire419
If you lose your keys432
If you think something is
wrong396
If your vehicle becomes
stuck444
If your vehicle has to be
stopped in an emergency446
If your vehicle needs to be
towed393
If your vehicle overheats440

Engine
Compartment341
Engine switch135
Hood338
How to start the
hybrid system135
Identification number450
Ignition switch135
If the hybrid system
will not start429
Overheating440
Power switch135
Engine/power control unit
coolant
Capacity454
Checking346
Preparing and checking
before winter173
Engine coolant temperature
gauge144
Engine oil
Capacity453
Checking342
Preparing and checking
before winter173
Engine oil maintenance
data344
Engine switch135
EPS165
Event data recorder397

F	Floor mat	310
	Fluid	
	Brake	348
	Washer	
	Front passenger occupant	
	classification system	104
	Front passenger's seat belt	
	reminder light	402
	Front seats	
	Adjustment	59
	Front side marker lights	
	Wattage	458
	Front turn signal lights	
	Wattage	458
	Fuel	
	Capacity	452
	Fuel gauge	
	Gas station information	
	Information	459
	Refueling	
	Type	
	Fuel door	
	Fuel economy meter	
	Fuel filler door	
	Fuses	375
G	Garage door opener	313
	Gas station information	
	Gauges	
	Glove box	
	Glove box light	
	Grocery bag hooks	

Н	Hands-free phone system	J	Jack
	(for cellular phone)		Positioning a floor jack339
	Hands-free phone system		Vehicle-equipped jack419
	(for cellular phone) 258		Jack handle419
	Hazard lights		
	Switch 392	K	Keyless entry48
	Head restraints		Kevs
	Adjusting62		Electronic key35
	Headlights		If you lose your keys432
	Replacing light bulbs 385		If your electronic key
	Switch 154		battery is discharged433
	Wattage 458		Key number35
	Heaters		Keyless entry48
	Seat heater 307		Keys35
	Side mirror191		Mechanical key35
	Hood 338		Wireless remote control key48
	Hooks		•
	Cargo hook 311	L	License plate lights
	Grocery bag hooks 311		Wattage458
	Horn 143		Light bulbs
	Hybrid system		Replacing385
	Emergency shut off system 26		Wattage458
	Energy monitor/		Lights
	consumption screen 26		Door courtesy lights291
	High voltage components 25		Emergency flasher switch392
	Power switch 135		Hazard light switch392
			Headlights switch154
	I/M test 334		Interior light switch292
	Identification		Personal light switch293
	Engine 450		Replacing light bulbs385
	Vehicle 450		Turn signal lever141
	Ignition switch135		Vanity lights302
	Illuminated entry system 291		Wattage458
	Immobilizer system 88		Load capacity172
	Indicator lights 147		Lock steering column137
	Initialization		_
	Items to initialize 477		
	Inside rear view mirror 73		
	Interior lights		
	Interior lights291		

М	Maintenance	Р	Parking brake	142
	Do-it-yourself		Parking lights	
	maintenance335		Switch	154
	General maintenance331		Wattage	458
	Maintenance data450		Personal lights	
	Maintenance requirements329		Switch	293
	Meter		Wattage	458
	Instrument panel light		Power outlet	305
	control145		Power switch	135
	Meters144		Power windows	77
	Mirrors			
	Inside rear view mirror73	R	Radiator	348
	Side mirror heater191		Radio	
	Side mirrors75		Rear seats	
	Vanity mirrors302		Folding down	61
	Moon roof79		Rear turn signal lights	
	MP3 disc210		Replacing light bulbs.	385
	Multi-information		Wattage	
	display150		Rear window defogger	
			Replacing	
N	Noise from under vehicle16		Fuses	375
			Key battery	
0	Odometer144		Light bulbs	
	Oil		Tires	
	Engine oil342		Reporting safety defec	
	Opener		U.S. owners	
	Fuel filler door83			
	Hood338			
	Trunk55			
	Outside rear view mirrors			
	Adjusting and folding75			
	Outside temperature			
	display150			
	Overheating,			
	Hybrid system440			
	Trybrid System440			

#### S

Seat belts	
Adjusting the seat belt 64	4
Automatic Locking	
Retractor6	7
Child restraint system	
installation11	3
Cleaning and maintaining	
the seat belts32	7
Emergency Locking	
Retractor 6	
How to wear your seat belt 6-	4
How your child should wear	
the seat belt 66	8
Pregnant women,	
proper seat belt use6	
Reminder light 403	
Seat belt extenders 68	
Seat belt pretensioners 6	
Seat heaters30	
Seating capacity173	2
Seats	
	_
Adjustment 59	
Adjustment precautions 6	
Adjustment precautions 60 Child seats/child restraint	0
Adjustment precautions 60 Child seats/child restraint system installation 113	3
Adjustment precautions 60 Child seats/child restraint system installation	0 3 6
Adjustment precautions 60 Child seats/child restraint system installation	0 3 6 2
Adjustment precautions 60 Child seats/child restraint system installation	0 3 6 2 0
Adjustment precautions 60 Child seats/child restraint system installation	0 3 6 2 0
Adjustment precautions 60 Child seats/child restraint system installation 113 Cleaning 60 Head restraint 60 Properly sitting in the seat 90 Seat heaters 300 Service reminder	0 3 6 2 0 7
Adjustment precautions 60 Child seats/child restraint system installation 111 Cleaning 320 Head restraint 60 Properly sitting in the seat 90 Seat heaters 300 Service reminder indicators 14	0 3 6 2 0 7
Adjustment precautions 60 Child seats/child restraint system installation 111 Cleaning 320 Head restraint 60 Properly sitting in the seat 90 Seat heaters 300 Service reminder indicators 140 Shift lever	0 3 6 2 0 7
Adjustment precautions 60 Child seats/child restraint system installation 111 Cleaning 320 Head restraint 60 Properly sitting in the seat 90 Seat heaters 300 Service reminder indicators 140 Shift lever If the shift lever cannot	0 3 6 2 0 7
Adjustment precautions 66 Child seats/child restraint system installation 111 Cleaning 320 Head restraint 66 Properly sitting in the seat 90 Seat heaters 300 Service reminder indicators 146 Shift lever If the shift lever cannot be shifted from P 43	0 3 6 2 0 7
Adjustment precautions 60 Child seats/child restraint system installation 111 Cleaning 320 Head restraint 60 Properly sitting in the seat 90 Seat heaters 300 Service reminder indicators 140 Shift lever If the shift lever cannot be shifted from P 43 Transmission 130	0 3 6 2 0 7 7
Adjustment precautions 60 Child seats/child restraint system installation 111 Cleaning 320 Head restraint 60 Properly sitting in the seat 90 Seat heaters 300 Service reminder indicators 14 Shift lever If the shift lever cannot be shifted from P 43 Transmission 130 Shift lock system 43	0 36207 7 191
Adjustment precautions 60 Child seats/child restraint system installation 113 Cleaning 320 Head restraint 60 Properly sitting in the seat 90 Seat heaters 300 Service reminder indicators 144 Shift lever If the shift lever cannot be shifted from P 43 Transmission 135 Shift lock system 435 Side airbags 95	0 36207 7 191
Adjustment precautions 60 Child seats/child restraint system installation 113 Cleaning 60 Properly sitting in the seat 90 Seat heaters 30 Service reminder indicators 14 Shift lever If the shift lever cannot be shifted from P 43 Transmission 13 Shift lock system 43 Side airbags 95 Side marker lights	0 36207 <b>7</b> 19 <b>12</b>
Adjustment precautions 60 Child seats/child restraint system installation 113 Cleaning 320 Head restraint 60 Properly sitting in the seat 90 Seat heaters 300 Service reminder indicators 144 Shift lever 15 the shift lever cannot be shifted from P 43 Transmission 133 Shift lock system 43 Side airbags 93 Side marker lights Replacing lights bulbs 383	0 36207 <b>7</b> 19 <b>12</b> 5
Adjustment precautions 60 Child seats/child restraint system installation 113 Cleaning 60 Properly sitting in the seat 90 Seat heaters 30 Service reminder indicators 14 Shift lever If the shift lever cannot be shifted from P 43 Transmission 13 Shift lock system 43 Side airbags 95 Side marker lights	0 36207 <b>7</b> 19 <b>12</b> 54

Side mirror	
Adjusting and folding	75
Smart key system	
Entry function	37
Starting the hybrid system	135
Spare tire	
Inflation pressure	363
Storage location	419
Spark plug	455
Specifications	450
Speedometer	144
Steering	
Column lock release	137
Steering wheel	
Adjustment	72
Air conditioning system	
switches	_
Audio switches	239
Storage feature	294
Storage precautions	171
Stuck	
If your vehicle becomes	
stuck	444
Sun visors	301
Sunshade	
Roof	80
Switch	
"ECO HEAT/COOL"	
switch	
Emergency flasher switch	
Engine switch	
Hazard light switch	
Ignition switch	135
Light switches	
Power door lock switch	
Power switch	135
Power window switch	77
Window lock switch	
Wiper and washer switch	450

ш
-


Tail lights	
Switch	154
Theft deterrent system	
Immobilizer system	88
Tire inflation pressure	363
Tire information	
Glossary	468
Size	465
Tire identification number	464
Uniform tire quality	
grading	466
Tires	
Chains	173
Checking	354
If you have a flat tire	419
Inflation pressure	363
Inflation pressure sensor	355
Replacing	419
Rotating tires	354
Size	457
Snow tires	173
Spare tire	419

Tools	419
Total load capacity	172
Towing	
Dinghy towing	178
Trailer towing	177
TRAC	165
Traction control	165
Transmission	
If the shift lever cannot be	
shifted from P	431
Transmission	139
Trip information	150
Trip meter	144
Trunk	
Opener	55
Trunk light	
Trunk light	56
Wattage	458
Turn signal lights	
Replacing light bulbs	385
Switch	141
Wattage	458


7	Vanity lights	Warning messages
	Vanity lights302	Engine coolant
	Wattage 458	temperature409
	Vanity mirrors 302	Engine oil maintenance411
	VDIM 165	Engine oil pressure409
	Vehicle dynamics integrated	Hybrid system409
	management 165	Moon roof411
	Vehicle identification	Open door411
	number 450	Parking brake411
	Vehicle stability control 165	Smart key system415
	VSC 165	Steering lock410
		Trunk411
Ī	Warning buzzers	Washer fluid411
	Brake system399	Washer
	Open door 402	Checking349
	Seat belt reminder 402	Preparing and checking
	Warning lights	before winter173
	Anti-lock brake system 400	Switch159
	Brake assist system 400	Washing and waxing324
	Brake system399	Weight
	Charging system 399	Cargo capacity169
	Electric power steering 400	Load limits172
	Low fuel level 402	Weight450
	Low tire pressure warning	Wheels367
	light 402	Window glasses77
	Malfunction indicator lamp 400	Window lock switch77
	Master warning light 402	Windows
	Open door 402	Power windows77
	Pretensioners 400	Rear window defogger191
	Seat belt reminder light 402	Washer159
	SRS airbags 400	Windshield wipers159
		Wireless remote control key
		Replacing the battery372
		Wireless remote control48

# What to do if... What to do if...

A tire is punctured	P. 419 If you have a flat tire
The hybrid system does not start	P. 429 If the hybrid system will not start P. 88 Immobilizer system P. 436 If the vehicle's 12-volt battery is discharged P. 433 If the electronic key does not operate properly
The shift lever cannot be moved	P. 431 If the shift lever cannot be shifted from P
The coolant temperature is high  Steam can be seen coming from under the hood	P. 440 If your vehicle overheats
A key is missing	P. 432 If you lose your keys
The 12-volt battery runs out	P. 436 If the vehicle's 12-volt battery is discharged
The doors cannot be locked	P. 51 Doors
The vehicle is stuck in mud or sand	P. 444 If the vehicle becomes stuck
A warning light or indicator light comes on	P. 399 If a warning light turns on or a warning buzzer sounds



#### **■**Warning lights




The warning message is displayed

Brake system warning light (yellow indicator)

P. 400

P. 408 If a warning message is displayed

#### **GAS STATION INFORMATION**



Fuel tank capacity (Reference)	17.2 gal. (65 L, 14.3 lmp. gal.)	
Fuel type	Unleaded gasoline only	P. 85, 452
Cold tire inflation pressure		P. 457
Engine oil capacity (Drain and refill — reference)	With filter 4.5	(L, Imp. qt.) (4.3, 3.8) (4.1, 3.6)
Engine oil type		P. 453