

XC90
OWNER'S MANUAL



VÄLKOMMEN!

We hope your Volvo will give you many years of happy motoring. The vehicle is designed for the safety and comfort of you and your passengers. Volvo strives to be one of the world's safest passenger vehicles. Your Volvo is also designed to meet applicable safety and environmental requirements.

To increase your enjoyment of your Volvo, we recommend that you read the instructions and maintenance information contained in this owner's

manual. The owner's manual is also available as a mobile app (Volvo Manual) and on Volvo Cars support page (support.volvocars.com).

We also encourage everyone to always use seat belts in this and other vehicles. You should also not drive if you are under the influence of alcohol or medicines or if your ability to drive is for some other reason impaired.

TABLE OF CONTENTS

OWNER'S INFORMATION

Owner's information	16
Owner's Manual in the center display	17
Navigate in the Owner's Manual in the center display	18
Owner's manual in mobile devices	20
Volvo Cars support site	20
Using the Owner's Manual	21
The Owner's Manual and the envi- ronment	23

YOUR VOLVO

Contacting Volvo	26
/olvo ID	26
Creating and registering a Volvo ID	27
Orive-E – purer driving pleasure	27
ntelliSafe - driver support	28
Sensus - connection and entertainment	30
Software Updates	33
Data recording	33
erms & Conditions for Services	34
Customer Privacy Policy	34
mportant information on accessories and extra equipment	35
Accessory installation	36
Connecting equipment to the vehi- cle's data link connector	36
echnician certification	37
/iewing the Vehicle Identification Number (VIN)	38
/olvo Structural Parts Statement	38
Oriver distraction	30

SAFETY

Safety	42
Safety during pregnancy	43
Occupant safety	43
Reporting safety defects	44
Recall information	45
Whiplash Protection System	46
Seat belts	47
Buckling and unbuckling seat belts	48
Seat belt tensioners	50
Resetting the electric seat belt tensioners	51
Door and seat belt reminders	51
Airbags	52
Driver/passenger-side airbags	53
Occupant weight sensor	56
Side airbags	60
Inflatable curtain	60
Safety mode	61
Starting and moving the vehicle when it is in safety mode	62
Child safety	63
Child restraints	65
Infant seats	67
Convertible seats	69
Booster cushions	71

Top tether anchors	72
Lower child seat attachment points	74
ISOFIX/LATCH lower anchors	74
Integrated booster cushion*	76
Folding up the integrated booster cushion*	77
Folding down the integrated booster cushion*	78

DISPLAYS AND VOICE CONTROL

nstruments and controls in left-hand drive vehicles	82
nstrument panel	84
nstrument panel settings	88
-uel gauge	89
Trip computer	89
Displaying trip data in the instrument panel	91
Resetting the trip odometer	92
Displaying trip statistics in the center display	92
Frip statistics settings	93
Date and time	94
Ambient temperature sensor	94
ndicator symbols in the instrument panel	95
Warning symbols in the instrument panel	97
nstrument panel licenses	98
App menu in instrument panel	104
Handling the App menu in the instru- ment panel	105
Messages in the instrument panel	106
Handling messages in the instru- nent panel	107
Handling messages saved from the nstrument panel	109
Center display overview	111

Handling the center display	114
Activating and deactivating the center display	117
Navigating in the center display's views	117
Handling tiles in the center display	121
Function view in the center display	124
Moving apps and buttons in the center display	126
Symbols in the center display status bar	126
Using the center display keyboard	128
Changing keyboard language in the center display	131
Entering characters, letters and words by hand in the center display	131
Changing the appearance of the center display	133
Turning off and adjusting the volume of the center display system sounds	133
Changing system units of measurement	134
Changing system language	134
Opening settings in the center display	134
Opening contextual setting in the center display	135
Changing settings in the center display	136
Resetting user data when the vehicle changes owners	136
Resetting center display settings	137

Setting types in the center display	137
Table of settings in the center display	138
Driver profiles	139
Selecting a driver profile	140
Changing a driver profile's name	141
Resetting driver profile settings	141
Linking a remote key to a driver profile	141
Messages in the center display	142
Handling messages in the center display	143
Handling messages saved from the center display	144
Head-up display*	144
Activating and deactivating the head-up display*	146
Head-up display settings*	146
Voice control	147
Using voice commands	148
Voice control for cellular phones	149
Voice control for radio and media	150
Voice control settings	150

LIGHTING

Lighting panel and controls	154
Adjusting light functions via the center display	155
Parking lights	156
Daytime running lights	156
Low beams	157
Using high beam	158
Active high beam	159
Using turn signals	160
Active Bending Lights*	161
Front fog lights/cornering illumination*	161
Rear fog light	162
Brake lights	163
Emergency brake lights	163
Hazard warning flashers	164
Using home safe lighting	164
Welcome Light	164
Interior Lighting	165
Adjusting interior lighting	167

WINDOWS, GLASS AND MIRRORS

Windows, glass and mirrors	170
Pinch protection for windows and sun curtains	170
Reset procedure for pinch protection	171
Power windows	171
Operating the power windows	172
Jsing sun curtains*	173
Rearview/door mirrors	173
Adjusting the rearview mirror dim- ming function	174
Adjusting the door mirrors	175
Panoramic roof*	176
Operating the panoramic roof*	177
Auto closing the panoramic roof* sun curtain	179
Jsing the windshield wipers	180
Heated windshield washer nozzles*	181
Jsing the rain sensor	181
Jsing the rain sensor's memory function	182
Jsing the windshield and headlight washers	183
Jsing the rear window wiper/washer	184
Jsing automatic rear window wiping when backing up	185

SEATS AND STEERING WHEEL

Manual front seats	188
Power front seats*	189
Adjusting the power front seats*	189
Storing memory settings in power front seats*	190
Using stored memory in a powered front seat	191
Front seat massage settings*	192
Adjusting front seat massage settings*	192
Adjusting front seat cushion length	193
Adjusting front seat side bolster settings*	194
Adjusting front seat lumbar support*	194
Adjusting the passenger seat from the driver's seat*	195
Folding the second row backrests	196
Adjusting the second row head restraints	198
Moving the second row seats forward/rearward*	199
Adjusting the second row backrest tilt	200
Getting into and out of the third row of seats*	201
Folding the third row backrests*	202
Steering wheel controls and horn	203
Adjusting the steering wheel	203

CLIMATE CONTROL

Climate	206
Climate zones	206
Climate control sensors	207
Perceived temperature	207
Climate control system voice commands	208
Air quality	209
Clean Zone*	209
Clean Zone Interior Package*	210
Interior Air Quality System*	210
Activating and deactivating the air quality sensor*	211
Passenger compartment air filter	211
Air distribution	212
Adjusting air distribution	212
Opening, closing and directing air vents	213
Air distribution options	214
Climate system controls	217
Activating and deactivating power front seats*	219
Activating and deactivating the heated front seat*	220
Activating and deactivating the heated rear seats*	220
Activating and deactivating front seat ventilation*	221

Activating and deactivating the heated steering wheel*	222
Activating and deactivating automatic steering wheel heating*	223
Activating auto climate control	223
Activating and deactivating recirculation	224
Activating and deactivating the recirculation timer setting	224
Activating and deactivating max defroster	225
Activating and deactivating the heated windshield*	226
Activating and deactivating automatic windshield heating*	227
Activating and deactivating the heated rear window and door mirrors	227
Automatically activating and deactivating the heated rear window and door mirrors	228
Setting the blower speed for the front seats	228
Setting the blower speed for the rear seats*	229
Setting the temperature for the front seats	230
Setting the temperature for the rear seats*	231
Synchronize temperature	232
Activating and deactivating air conditioning	233

		KEY, LOCKS AND ALARM
Activating and deactivating climate	233	Lock indication
control for the third-row seats*		Lock confirmation settings
Activating and deactivating auto-start of third-row climate control*	234	Remote key
		Locking and unlocking using the remote key
		Settings for remote and inside door unlock
		Unlocking the tailgate using the remote key
		Remote key range
		Replacing the remote key's battery
		Ordering additional remote keys
		Red Key - restricted remote key*
		Red Key* settings
		Detachable key blade
		Locking and unlocking with detachable key blade
		Electronic immobilizer
		Start and lock system type designations
		Keyless and touch-sensitive surfaces*
		Keyless locking and unlocking*
		Keyless unlock settings*
		Keyless tailgate unlock*
		Antenna locations for the start and lock system

Locking and unlocking from inside the vehicle	25
Unlocking the tailgate from inside the vehicle	25
Activating and deactivating child safety locks	25
Automatic locking when driving	25
Opening and closing the power tailgate*	25
Setting a maximum height for the power tailgate*	26
Foot movement tailgate operation*	26
Private Locking	26
Activating and deactivating private locking	26
Alarm	26
Arming and disarming the alarm	26
Foreign Component Detection*	26

DRIVER SUPPORT

Driver support systems	270
Speed-dependent steering wheel resistance	270
Stability system Roll Stability Control	271
Electronic Stability Control	272
Electronic Stability Control Sport mode	273
Activating/deactivating Sport mode in Electronic Stability Control	273
Electronic Stability Control Sport mode limitations	274
Electronic Stability Control symbols and messages	275
Speed limiter	276
Activating and starting Speed Limiter	277
Managing Speed Limiter speed	277
Deactivating and putting Speed Limiter in standby mode	278
Reactivating Speed Limiter from standby mode	279
Turning off Cruise Control	279
Cruise Control limitations	280
Automatic Speed Limiter	280
Activating/deactivating Automatic Speed Limiter	282
Changing Automatic Speed Limiter tolerance	283
Automatic Speed Limiter limitations	283

Cruise control	284
Activating and starting Cruise Control	285
Managing Cruise Control speed	286
Deactivating and putting Cruise Con- trol in standby mode	287
Reactivating Cruise Control from standby mode	288
Switching off Cruise Control	288
Distance Alert*	289
Head-up display for Distance Alert	290
Activating/deactivating Distance Alert	291
Setting a time interval for Distance Alert	291
Distance Alert limitations	292
Adaptive Cruise Control*	293
Adaptive Cruise Control and collision warning	296
Head-up display for Adaptive Cruise Control with collision warning	297
Activating and starting Adaptive Cruise Control	297
Managing Adaptive Cruise Control speed	298
Setting Adaptive Cruise Control time intervals	299
Deactivating/reactivating Adaptive Cruise Control	300
Passing assistance with Adaptive	302

Starting passing assistance with Adaptive Cruise Control	302
Limitations of passing assistance with Adaptive Cruise Control	303
Switching target vehicles with Adaptive Cruise Control	303
Automatic braking with Adaptive Cruise Control	304
Adaptive Cruise Control limitations	305
Switching between Cruise Control and Adaptive Cruise Control	305
Symbols and messages for Adaptive Cruise Control	307
Pilot Assist	309
Pilot Assist and collision warning	312
Head-up display for Pilot Assist during collision risks	313
Activating and starting Pilot Assist	313
Managing Pilot Assist speed	314
Setting a time interval for Pilot Assist	315
Deactivating/reactivating Pilot Assist	317
Passing assistance with Pilot Assist	319
Starting passing assistance with Pilot Assist	319
Passing assistance with Pilot Assist limitations	319
Switching target vehicles with Pilot Assist	320
Automatic braking with Pilot Assist	320

Pilot Assist limitations	321
Pilot Assist* symbols and messages	322
Radar sensor	324
Radar sensor limitations	325
Recommended maintenance for the radar sensor	328
Radar sensor type approval	328
Camera	329
Camera limitations	330
Recommended maintenance for the camera/radar sensor	333
City Safety™	333
City Safety parameters and sub-functions	334
Setting a warning distance for City Safety	336
Detecting obstacles with City Safety	337
City Safety in crossing traffic	339
Limitations of City Safety in crossing traffic	340
City Safety and delayed evasive maneuvers	341
City Safety limitations	342
City Safety messages	344
Rear Collision Warning	345
Rear Collision Warning limitations	345
BLIS*	346
Activating/deactivating BLIS	347

BLIS limitations	348
Recommended maintenance for BLIS	349
BLIS messages	350
Cross Traffic Alert*	351
Activating/deactivating Cross Traffic Alert	352
Cross Traffic Alert limitations	352
Recommended maintenance for Cross Traffic Alert	353
Cross Traffic Alert messages	354
Road Sign Information*	355
Activating/deactivating Road Sign Information	356
Road Sign Information and sign displays	356
Road Sign Information and Sensus Navigation	357
Road Sign Information with Speed Warning and Settings	357
Activating/deactivating Speed Warning in Road Sign Information	358
Road Sign Information with speed camera information	359
Road Sign Information limitations	359
Driver Alert Control	360
Activating/deactivating Driver Alert Control	361

Selecting guidance to a rest area if the Driver Alert Control warning has been given	362
Driver Alert Control limitations	362
Lane Keeping Aid	362
Steering assistance with Lane Keeping Aid	364
Activating/deactivating Lane Keeping Aid	365
Selecting type of assistance for Lane Keeping Aid	365
Lane Keeping Aid limitations	365
Lane Keeping Aid symbols and messages	367
Lane Keeping Aid symbols in the instrument panel	369
Steering assistance at risk of collision	370
Activating/deactivating steering assistance during collision risks	370
Run-Off Mitigation with steering assistance	371
Run-Off Mitigation with steering assistance levels	371
Activating/deactivating Run-Off Mitigation with steering assistance	372
Limitations of Run-Off Mitigation with steering assistance	372
Steering assistance during collision risks from oncoming traffic	373

Activating/deactivating Steering assistance during collision risks with oncoming vehicles	374
Limitations of steering assistance during collision risks from oncoming traffic	374
Steering assistance during collision risks from behind*	375
Activating/deactivating Steering assistance during collision risks from behind*	376
Limitations of steering assistance during collision risks from behind	376
Symbols and messages for steering assistance during collision risks	378
Park Assist*	379
Park Assist front, rear and sides	380
Activating/deactivating Park Assist	381
Park Assist limitations	381
Recommended maintenance for Park Assist	382
Park Assist symbols and messages	383
Park Assist Camera*	384
Park Assist Camera views	385
Park Assist Camera trajectory lines	386
Sensor field from Park Assist for Park Assist Camera	388
Starting the Park Assist Camera	389

Park Assist Camera limitations	389
Recommended maintenance of the Park Assist Camera	391
Park Assist Camera symbols and messages	392
Park Assist Pilot*	393
Types of parking with Park Assist Pilot	393
Parking with Park Assist Pilot	394
Leaving a parking space with Park Assist Pilot	397
Park Assist Pilot* limitations	398
Recommended maintenance for Park Assist Pilot	400
Park Assist Pilot* messages	401

STARTING AND DRIVING

starting the vehicle	404
witching off the vehicle	406
gnition modes	407
Selecting ignition mode	408
Brake functions	408
Brakes	409
Brake Assist System	410
Braking on wet roads	410
Braking on salted roads	411
Maintenance of the brake system	411
Parking brake	411
ctivating and deactivating the park- ng brake	412
Settings for automatically activating ne parking brake	413
Parking on a hill	414
Parking brake malfunction	414
auto-hold brakes	415
ctivating and deactivating Auto- old at a standstill	416
Hill Start Assist	416
Braking assist after a collision	417
ransmission	417
Gear selector positions for automatic ransmissions	418

Deactivating the automatic shiftlock The kickdown function Gear indicator* All Wheel Drive (AWD)* Drive modes* Changing drive mode* ECO drive mode Activating and deactivating ECO drive mode using the function button Start/Stop function Driving with the Start/Stop function Temporarily deactivating the Start/ Stop function Conditions for the Start/Stop function Leveling control* and suspension Leveling control settings* Low Speed Control* Activating and deactivating Low Speed Control* using the function button	Using the steering wheel paddles* to shift	419
The kickdown function 422 Gear indicator* 422 All Wheel Drive (AWD)* 423 Drive modes* 425 Changing drive mode* 426 ECO drive mode 426 Activating and deactivating ECO drive mode using the function button 426 Driving with the Start/Stop function 426 Driving with the Start/Stop function 426 Conditions for the Start/Stop function 436 Leveling control* and suspension 436 Leveling control* and suspension 436 Leveling control settings* 436 Low Speed Control* 436 Activating and deactivating Low 526 Speed Control* using the function button 436 Hill Descent Control* 436 Activating and deactivating Hill 526 Descent Control* using the function 436 Activating and deactivating Hill 526 Descent Control* using the function 436	Shiftlock	421
Gear indicator* All Wheel Drive (AWD)* Drive modes* Changing drive mode* ECO drive mode Activating and deactivating ECO drive mode using the function button Start/Stop function Driving with the Start/Stop function Temporarily deactivating the Start/ Stop function Conditions for the Start/Stop function Leveling control* and suspension Leveling control settings* Activating and deactivating Low Speed Control* Activating and deactivating Hill Descent Control* using the function 428 436 437 438	Deactivating the automatic shiftlock	421
All Wheel Drive (AWD)* Drive modes* Changing drive mode* ECO drive mode Activating and deactivating ECO drive mode using the function button Start/Stop function Driving with the Start/Stop function Temporarily deactivating the Start/ Stop function Conditions for the Start/Stop function Leveling control* and suspension Leveling control settings* Activating and deactivating Low Speed Control* Activating and deactivating Hill Descent Control* Activating and deactivating Hill Descent Control* using the function	The kickdown function	422
Drive modes* Changing drive mode* ECO drive mode Activating and deactivating ECO drive mode using the function button Start/Stop function Driving with the Start/Stop function Temporarily deactivating the Start/ Stop function Conditions for the Start/Stop function Leveling control* and suspension Leveling control settings* Low Speed Control* Activating and deactivating Low Speed Control* using the function button Hill Descent Control* Activating and deactivating Hill Descent Control* using the function	Gear indicator*	422
Changing drive mode* ECO drive mode Activating and deactivating ECO drive mode using the function button Start/Stop function Driving with the Start/Stop function Temporarily deactivating the Start/ Stop function Conditions for the Start/Stop function Leveling control* and suspension Leveling control settings* Low Speed Control* Activating and deactivating Low Speed Control* using the function button Hill Descent Control* Activating and deactivating Hill Descent Control* using the function	All Wheel Drive (AWD)*	423
ECO drive mode Activating and deactivating ECO drive mode using the function button Start/Stop function Driving with the Start/Stop function Temporarily deactivating the Start/ Stop function Conditions for the Start/Stop function Leveling control* and suspension Leveling control settings* Low Speed Control* Activating and deactivating Low Speed Control* using the function button Hill Descent Control* Activating and deactivating Hill Descent Control* using the function	Drive modes*	423
Activating and deactivating ECO drive mode using the function button Start/Stop function Driving with the Start/Stop function Temporarily deactivating the Start/ Stop function Conditions for the Start/Stop function Leveling control* and suspension Leveling control settings* Low Speed Control* Activating and deactivating Low Speed Control* using the function button Hill Descent Control* Activating and deactivating Hill Descent Control* using the function	Changing drive mode*	425
drive mode using the function button Start/Stop function Driving with the Start/Stop function Temporarily deactivating the Start/ Stop function Conditions for the Start/Stop function Leveling control* and suspension Leveling control settings* Low Speed Control* Activating and deactivating Low Speed Control* using the function button Hill Descent Control* Activating and deactivating Hill Descent Control* using the function	ECO drive mode	426
Driving with the Start/Stop function 428 Temporarily deactivating the Start/ 430 Stop function 430 Conditions for the Start/Stop function 430 Leveling control* and suspension 432 Leveling control settings* 435 Low Speed Control* 436 Activating and deactivating Low 5peed Control* using the function button 437 Activating and deactivating Hill 438 Descent Control* using the function		428
Temporarily deactivating the Start/ Stop function Conditions for the Start/Stop function Leveling control* and suspension Leveling control settings* Low Speed Control* Activating and deactivating Low Speed Control* using the function button Hill Descent Control* Activating and deactivating Hill Descent Control* using the function	Start/Stop function	428
Stop function Conditions for the Start/Stop function 430 Leveling control* and suspension 432 Leveling control settings* 435 Low Speed Control* 436 Activating and deactivating Low 5peed Control* 436 Hill Descent Control* 437 Activating and deactivating Hill 438 Descent Control* 438	Driving with the Start/Stop function	428
Leveling control* and suspension 432 Leveling control settings* 435 Low Speed Control* 436 Activating and deactivating Low 5peed Control* using the function button 437 Activating and deactivating Hill 438 Descent Control* using the function		430
Leveling control settings* Low Speed Control* Activating and deactivating Low Speed Control* 436 Speed Control* 437 Hill Descent Control* Activating and deactivating Hill Descent Control* 438	Conditions for the Start/Stop function	430
Low Speed Control* Activating and deactivating Low Speed Control* using the function button Hill Descent Control* Activating and deactivating Hill Descent Control* using the function	Leveling control* and suspension	432
Activating and deactivating Low Speed Control* using the function button Hill Descent Control* Activating and deactivating Hill Descent Control* using the function	Leveling control settings*	435
Speed Control* using the function button Hill Descent Control* 437 Activating and deactivating Hill 438 Descent Control* using the function	Low Speed Control*	435
Activating and deactivating Hill 438 Descent Control* using the function		436
Descent Control* using the function	Hill Descent Control*	437
	Descent Control* using the function	438

Economical driving	438
Preparing for a long trip	439
Winter driving	440
Driving through standing water	441
Opening/closing the fuel filler door	441
Refueling	442
Fuel	442
Octane rating	443
Emission controls	445
Overheating of engine and transmission	446
Battery drain	447
Jump starting using another battery	447
Detachable towbar*	448
Driving with a trailer	449
Trailer Stability Assist*	451
Checking trailer lights	452
Towing using a towline	453
Attaching and removing the towing eyelet	454
Recovery	455
HomeLink®*	456
Programming HomeLink®*	457
Using HomeLink	458
Type approval for HomeLink®*	459
Compass	459

Activating and deactivating the compass	460
Calibrating the compass	460

AUDIO, MEDIA AND INTERNET Audio, media and Internet 464 Sound settings 464 Apps 465 Download apps 466 Updating apps 467 Deleting apps 468 Radio 468 Starting the radio 469 Changing waveband and radio station 469 Searching for a radio station 470 Storing radio favorites 471 Radio settings 471 **RBDS** 472 HD Radio™ 472 Activating and deactivating the HD Radio $^{\mathsf{TM}}$ 474 HD Radio™ sub-channels 474 HD Radio™ limitations 475 SiriusXM® Satellite radio* 476

Using SiriusXM® Satellite radio*

SiriusXM Travel Link®* - Weather

SiriusXM Travel Link®*

Settings for SiriusXM® Satellite radio*

SiriusXM Travel Link®* - Notifications

477

478

480

481

482

SiriusXM Travel Link®* - Fuel	483
SiriusXM Travel Link®* - Sports	484
Media player	485
Playing media	486
Controlling and changing media	487
Media searches	488
Gracenote [®]	489
CD player*	489
Video	490
Playing video	490
Playing DivX®	490
Video settings	491
Streaming media via Bluetooth®	491
Connecting a device via Bluetooth®	491
Playing media via the USB port	492
Connecting a device via the USB port	492
Apple [®] CarPlay [®] *	493
Using Apple [®] CarPlay [®] *	493
Settings for Apple [®] CarPlay [®] *	494
Tips for using Apple® CarPlay®*	495
Android Auto*	496
Using Android Auto*	496
Settings for Android Auto*	497

Tips for using Android Auto*	498
Phone	498
Connecting a phone to the car via Bluetooth for the first time	499
Connecting a phone to the car via Bluetooth automatically	501
Connecting a phone to the car via Bluetooth manually	501
Disconnecting a Bluetooth-connected phone	502
Switch between phones connected via Bluetooth	502
Removing a Bluetooth-connected phone	503
Handling phone calls	503
Handling text messages	504
Text message settings	505
Managing the phone book	505
Phone settings	506
Settings for Bluetooth devices	507
Internet-connected vehicle*	507
Connecting the car to the Internet via a mobile device (Bluetooth)	509
Connecting the car to the Internet via a mobile device (Wi-Fi)	509
Connect the car to the Internet via car modem (SIM card)	510
Vehicle modem settings	511

Sharing Internet from the vehicle via Wi-Fi hotspot (tethering)	511
No or poor Internet connection	512
Deleting Wi-Fi networks	513
Wi-Fi technology and security	513
Terms of use and data sharing	514
Activating and deactivating data sharing	514
Compatible file formats for media	514
Technical specifications for USB devices	515
Hard disk storage space	516
License agreement for audio and media	517

Tires 528 Tire direction of rotation 530 Tread wear indicator 531 Tire terminology 531 Tire sidewall designations 532 Uniform Tire Quality Grading 534 Checking tire pressure 535 Adjusting tire pressure 536 Recommended tire pressure 537 Tire pressure monitoring system* 537 Calibrating the tire pressure monitoring system* 539 Viewing tire pressure status in the center display* 540 Action when warned of low tire pressure 541 When changing wheels 542 Tool kit 542 Jack* 543 Wheel bolts 543

544

546

547

548

549

549

WHEELS AND TIRES

Removing a wheel

Installing a wheel

Accessing the spare wheel

Spare wheel

Snow tires

Snow chains

Tire sealing system	550
Using the tire sealing system	551
Inflate tires with the compressor included in the tire sealing system	555
Determining the vehicle's permitted weight	556

LOADING, STORAGE AND PASSENGER COMPARTMENT

Passenger compartment interior	558
Tunnel console	559
Electrical outlets	560
Using the electrical outlets	562
Using the glove compartment	563
Sun visors	564
Cargo compartment	564
Loading recommendations	564
Roof loads and load carriers	566
Grocery bag holders	566
Load anchoring eyelets	567
Installing and removing the cargo compartment cover*	567
Operating the cargo compartment cover*	568
Installing and removing the steel cargo grid*	570
Installing and removing the cargo net*	571

MAINTENANCE AND SERVICE

Volvo's service program	576
Data transfer between vehicle and workshop over Wi-Fi	578
Download Center	579
Handling system updates via Down- load Center	579
Vehicle status	580
Scheduling service and repairs	580
Sending vehicle information to the workshop	582
Hoisting the vehicle	583
Opening and closing the hood	585
Climate control system service	586
Replacing a windshield with head-up display*	586
Engine compartment overview	587
Engine oil	587
Checking and filling engine oil	588
Refilling coolant	590
Replacing bulbs	591
Removing the plastic cover to replace bulbs	593
Removing the rectangular headlight cover	593
Location of exterior lights	594
Replacing the low beam headlight bulbs	595


Replacing the high beam headlight bulbs	595
Replacing daytime running lights/ front parking light bulbs	596
Replacing front turn signal bulbs	597
Bulb specifications	597
Start battery	598
Support battery	601
Battery symbols	602
Fuses and fuseboxes	603
Replacing fuses	604
Fuses in the engine compartment	605
Fuses under the glove compartment	608
Fuses in the cargo compartment	611
Cleaning the interior	615
Cleaning the center display	615
Cleaning the head-up display*	616
Cleaning fabric upholstery and ceiling liner	617
Cleaning the seat belt	617
Cleaning floor mats and inlay mats	617
Cleaning leather upholstery	618
Cleaning the leather steering wheel	619
Cleaning interior plastic, metal and wood surfaces	620
Cleaning the exterior	620

Polishing and waxing	621
Hand washing	621
Automatic car washes	623
High-pressure washing	624
Cleaning the wiper blades	624
Cleaning exterior plastic, rubber and trim components	625
Cleaning rims	626
Corrosion protection	626
Paintwork	627
Touching up minor paint damage	627
Color codes	628
Changing rear window wipers	629
Replacing windshield wiper blades	630
Windshield wipers in the service position	631
Filling washer fluid	632

SPECIFICATIONS	
Type designations	636
Dimensions	639
Weights	641
Towing capacity and tongue weight	642
Engine specifications	643
Engine oil specifications	644
Coolant specifications	645
Transmission fluid specifications	645
Brake fluid specifications	645
Fuel tank volume	646
Air conditioning specifications	646
Approved tire pressure	647


INDEX

Index 649



Owner's information

Owner's information is available in several different formats, both digital and printed. The Owner's Manual is available on the vehicle's center display, as a mobile app and on Volvo Cars' support website. There is also a Quick Guide in the glove compartment, as well as a supplement to the Owner's Manual containing information about e.g. fuses, specifications, etc. A printed Owner's Manual can be ordered.



Vehicle's center display¹



In the center display, pull down Top view and tap **Owner's manual**. This gives you access to visual navigation with exterior and interior images of the vehicle. The information is searchable and is divided into catego-

ries.

Mobile app



In App Store or Google Play, search for "Volvo Manual".

Download the app to your smartphone or tablet and select your vehicle model. The app contains instructive videos and offers visual navigation, includ-

ing exterior and interior images of the vehicle. You can easily navigate between sections in the Owner's Manual and the contents are searchable.

Volvo Cars support site



Go to support.volvocars.com and select your country. Owner's Manuals are available here for viewing online and in PDF format. The support site also contains instructive videos and additional information and

assistance concerning your vehicle and owning a Volvo. The website is available on most markets.

Printed information



The glove compartment contains a printed supplement to the Owner's Manual¹, which contains information on fuses and specifications as well as a summary of important and practical information.

There is also a printed Quick Guide with useful information about the most commonly used features and functions in your vehicle.

Other printed information may also be provided in the vehicle, depending on equipment level, market, etc.

A printed Owner's Manual and accompanying supplement can also be ordered. Contact a Volvo retailer to order.

¹ For markets without Owner's Manuals in the center display, a complete printed manual is provided along with the vehicle.

! CAUTION

The driver is always responsible for operating the vehicle in a safe manner and adhering to all applicable laws and regulations. It is also important that the vehicle is operated, maintained and serviced according to Volvo's recommendations provided in the owner's information.

If the information in the center display differs from the printed information, the printed information always takes precedence.

i NOTE

Changing languages in the center display could mean that certain owner's information will not comply with national or local laws and regulations. Do not change to a language that you do not fully understand, as this could make it difficult to navigate back through the menu.

Related information

- Owner's Manual in the center display (p. 17)
- Owner's manual in mobile devices (p. 20)
- Volvo Cars support site (p. 20)
- Using the Owner's Manual (p. 21)

Owner's Manual in the center display


A digital version of the Owner's Manual is available in the vehicle's center display².

The digital Owner's Manual can be accessed from Top view and in certain cases, the contextual Owner's Manual can also be accessed from Top view.

(i) NOTE

The digital Owner's Manual is not available during driving.

OWNER'S MANUAL




The Owner's Manual is accessed from Top view.

To open the Owner's Manual, pull down Top view in the center display and tap **Owner's manual**.

The information in the Owner's Manual can be accessed directly via the Owner's Manual start page or via its Top menu.

Contextual Owner's Manual



The contextual Owner's Manual is accessed from Top view.

When a contextual Owner's Manual is available, it will be shown to the right of **Owner's manual** in Top view.

Tap the contextual Owner's Manual to open an article in the Owner's Manual related to the information displayed on the screen. For example, tap **Navigation Manual** to open an article related to navigation.

Certain apps in the vehicle only. For third-party apps that have been downloaded, it is not possible to e.g. access app-specific articles.


² Available in most markets.

Related information

- Navigate in the Owner's Manual in the center display (p. 18)
- Navigating in the center display's views (p. 117)
- Download apps (p. 466)

Navigate in the Owner's Manual in the center display

The digital Owner's Manual can be accessed from the center display's Top view. The contents are searchable and it is easy to navigate among the various sections.



The Owner's Manual is accessed from Top view.

 To open the Owner's Manual, pull down Top view in the center display and tap Owner's manual.

There are a number of ways to find information in the Owner's Manual. The options can be accessed from the Owner's Manual start page and from the Top menu.

Opening the menu in the Top menu

- Tap
 in the upper list in the Owner's Manual.
 - > A menu will open, displaying different options for finding information:

Start page



Tap the symbol to return to the Owner's Manual start page.

Categories



The articles in the Owner's Manual are structured into main and sub-categories. The same article may appear in several relevant categories in order to make them easier to find.

- 1. Tap Categories.
 - > The main categories are listed.
- 2. Tap a main category ().
 - A list of sub-categories (□) and articles(□) will appear.
- 3. Tap an article to open it.

To go back, tap the left arrow.

Quick Guide



Tap the symbol to go to a page with links to a selection of useful articles about the vehicle's most commonly used features and functions. The articles can also be accessed via categories, but have been collected

here for quick access. Tap an article to read it in its entirety.

Exterior and interior hotspots



Exterior and interior overviews of the vehicle. Hotspots are provided for certain functions, components, etc. Tap a hotspot to come to a relevant article.



- Press Exterior or Interior.
 - Exterior or interior images of the vehicle are shown with hotspots. The hotspots lead to articles about the corresponding function, component, etc. Swipe the screen horizontally to scroll between the images.

- 2. Tap a hotspot.
 - > The title of a relevant article will be displayed.
- 3. Tap the title to open the article.

To go back, tap the left arrow.

Favorites



Tap the symbol to go to articles saved as favorites. Tap an article to read it in its entirety.

Saving or deleting favorite articles

Save an article as a favorite by tapping the $\fintright \fightharpoonup at the upper right when the article is open. When an article has been saved as a favorite, the star symbol will be filled in: <math>\fintright \fintright \fightharpoonup at the context of the property of the star symbol will be filled in: <math>\fintright \fintright \fintright$

To remove an article from the list of favorites, tap its star again.

Video



Tap the symbol to go to brief instructive videos for various functions in the vehicle.

Information



Tap the symbol for information about the current version of the Owner's Manual in your vehicle and other useful information.

Using the search function in the Top menu

- Tap Q in the Owner's Manual upper menu.
 A keyboard will appear at the bottom of the screen.
- 2. Enter a search word, e.g. "seat belt".
 - > Suggested articles and categories will be displayed as characters are entered.
- 3. Tap the article or category to read it.

Related information

- Owner's Manual in the center display (p. 17)
- Using the center display keyboard (p. 128)
- Using the Owner's Manual (p. 21)

Owner's manual in mobile devices

The Owner's Manual is available as a mobile app³ and can be downloaded from the App Store and Google Play. The app is adapted for both smartphones and tablets.





The Owner's Manual can be downloaded as a mobile app from the App Store or Google Play. This QR code will take you directly to the app. You can also search for "Volvo manual" in the App Store or Google


Play.

The app contains videos and exterior/interior images of the vehicle. These images contain hotspots for various functions, components, etc., which lead directly to related information. You

3 Certain mobile devices

can easily navigate between sections in the Owner's Manual and the contents are searchable.





The mobile app is available on both App Store and Google Play.

Related information

Using the Owner's Manual (p. 21)

Volvo Cars support site

Volvo Cars' website and support site contain additional information about your vehicle.

Online support

Go to support.volvocars.com to visit the site. The support site is available in most markets.

The site contains support for e.g. Internet-based services and functions, Volvo On Call, the navigation system* and apps. Videos and step-by-step instructions explain various procedures, such as how to connect the vehicle to the Internet via a cellular phone.

Downloadable information

Maps

For vehicles equipped with Sensus Navigation, maps can be downloaded from the support site.

Mobile apps

Beginning with model year 2014, the Owner's Manual is available as an app for certain Volvo models. The Volvo On Call app can also be downloaded from the support site.

Owner's manuals in PDF format

Owner's Manuals are available for downloading in PDF format. Select the vehicle model and year to download the desired manual.

20 *Option/accessory.

Contact

Contact information for customer support and your nearest Volvo retailer are available on the support site.

Related information

- Contacting Volvo (p. 26)
- Volvo ID (p. 26)

Using the Owner's Manual

Reading your Owner's Manual is a good way to get to know your new Volvo, preferably before driving it for the first time.

Reading your Owner's Manual is a good way to familiarize yourself with new features and functions, get advice on the best way to handle your vehicle in different situations, and to learn how to get the most out of everything your Volvo has to offer. Pay particular attention to the safety warnings provided in the Owner's Manual.

The intention of this owner's information is to explain all of the possible features, functions and options included in a Volvo vehicle. It is not intended as an indication or guarantee that all of these features, functions and options are included in every vehicle. Some terminology used may not exactly match terminology used in sales, marketing and advertising materials.

Volvo continuously works to develop and improve our products. Modifications can mean that information, descriptions and illustrations in the Owner's Manual differ from the equipment in the vehicle. We reserve the right to make changes without prior notice.

Do not remove this manual from the vehicle. If a problem should occur, you will not have the necessary information on where and how to get professional assistance.

© Volvo Car Corporation

Option/accessory

In addition to standard equipment, the Owner's Manual also describes options (factory-installed equipment) and certain accessories (extra retrofitted equipment).

All options and accessories are marked with an asterisk: *.

The equipment described in the Owner's Manual is not available in all vehicles. Vehicles may be equipped differently depending on market requirements and national or local laws and regulations.

For more information on which equipment is standard and which is an option or accessory, please contact your Volvo retailer.

Footnotes

Certain parts of the Owner's Manual contain information in the form of footnotes at the bottom of the page or at the end of a table. This information supplements the text that the footnote number refers to. If the footnote refers to text in a table, a letter is used instead of a number.

Messages

There are several displays in the vehicle that show messages and menu texts. The appearance of these texts differs from the normal texts provided. Example of messages and menu texts: **Phone, New message.**

Decals


There are various types of decals affixed in the vehicle to communicate important information in a clear and concise manner. The importance of these decals is explained as follows, in descending order of importance.

Risk of injury



Black ISO symbols on a yellow warning field, white text/image on a black message field. Used to indicate potential danger. Ignoring a warning of this type could result in serious injury or death.

Risk of damage



White ISO symbols and white text/image on a black or blue warning field and message field. Used to indicate potential danger, Ignoring a warning of this type could result in damage.

Information



White ISO symbols and white text/image on a black message field.



The decals shown in the Owner's Manual do not claim to be exact reproductions of those found in the vehicle. The purpose is to show approximately how they look and about where they are located. The information that applies for your vehicle in particular is found on the decal on the vehicle.

Procedures

Procedures that must be carried out in a certain order are shown as numbered lists in the Owner's Manual.

- When a series of illustrations are provided along with the step-by-step instructions, the numbers of the steps correspond with the numbers of the illustrations.
- A Lists using letters instead of numbers are used in cases where the order in which the instructions are carried out is not important.
- Arrows with or without numbers are used to indicate the direction of movement.
- Arrows with letters are used to indicate a movement in cases where the order in which the instructions are carried out is not important.

If there are no illustrations associated with stepby-step instructions, the steps are indicated by ordinary numbers.

Position lists

Red circles containing a number are used in general overview illustrations of components. The corresponding number is used in the position list's description of that component.

Bullet lists

Bullets are used for items (components, functions, information, etc.) that can be listed in a random order.

For example:

- Coolant
- Engine oil

Related information

Related information offers references to other parts of the manual containing information associated with the information you are currently reading.

Images

Illustrations and images used in the Owner's Manual are sometimes generic and are intended to provide an overview or an example of a certain function or feature. These images vary depending on equipment level and market and may differ from the appearance of your vehicle.

Continues on next page

>> This symbol is shown in the lower right-hand corner to indicate that the current topic continues on the next page.

Continuation from previous page

◀◀ This symbol is shown in the upper left-hand corner to indicate that the current topic is a continuation from the previous page.

Related information

- Owner's Manual in the center display (p. 17)
- Owner's manual in mobile devices (p. 20)
- Volvo Cars support site (p. 20)

The Owner's Manual and the environment

The Owner's Manual is printed on paper from responsibly managed forests.

The Forest Stewardship Council (FSC)® symbol certifies that the paper pulp in the printed Owner's Manual comes from FSC®-certified forests or other responsibly managed sources.



Related information

Drive-E – purer driving pleasure (p. 27)

Contacting Volvo

Use the following contact information if you would like to get in touch with Volvo in the United States or Canada.

In the USA:

Volvo Car USA, LLC

Customer Care Center

1 Volvo Drive,

P.O. Box 914

Rockleigh, New Jersey 07647

1-800-458-1552

www.volvocars.com/us

In Canada:

Volvo Car Canada I td.

Customer Care Centre

9130 Leslie Street, Suite 101

Richmond Hill, Ontario L4B 0B9

1-800-663-8255

www.volvocars.com/ca

Volvo ID

A Volvo ID gives you access to a wide range of personalized Volvo services¹ online.

A Volvo ID can be created from the vehicle or the Volvo On Call app². To access certain functions and services, the vehicle must be registered to a personal Volvo ID. Registering a Volvo ID to the vehicle gives you access to a wide range of Volvo services directly from the vehicle.

Examples of services:

- Volvo On Call Volvo ID is used to log in to the Volvo On Call app.
- Send to Car Send an address from an online map service directly to the vehicle.
- Book service and repairs Register your preferred workshop/retailer on volvocars.com to schedule service directly from the vehicle.

Advantages of having a Volvo ID

- Only one username and password are needed to access online services (i.e. you only need to remember one username and one password).
- If you change your username or password for one service (e.g. Volvo On Call), it will also be automatically changed for the other services.

Related information

- Creating and registering a Volvo ID (p. 27)
- Scheduling service and repairs (p. 580)

¹ The services available may vary over time and depending on equipment level and market.

² For Volvo On Call users.

Creating and registering a Volvo ID

A Volvo ID can be created in two ways. If your Volvo ID was created with the Volvo On Call app, the Volvo IDmust also be registered to the vehicle to enable access to the Volvo ID services.

Creating a Volvo ID using the app

- 1. Download the Volvo ID app from Download Center in the center display's App view.
- 2. Start the app and register a personal email address.
- 3. Follow the instructions that will be sent automatically to this email address.
 - > A Volvo ID has now been created and is automatically registered to the vehicle. The Volvo ID services can now be used.

Creating a Volvo ID using the Volvo On Call app³

- 1 Download the latest version of the Volvo On Call app from a smartphone, via e.g. App Store, Windows Phone or Google Play.
- 2. On the app's start page, create a Volvo ID and enter a personal email address.
- 3. Follow the instructions that will be sent automatically to this email address.
 - > A Volvo ID has now been created. See below for information on how the ID is registered to the vehicle.

Registering your Volvo ID to the vehicle

If your Volvo ID was created using the Volvo On Call app, follow these steps to register the ID to the vehicle.

1. If you have not already done so, download the Volvo ID app from Download Center in App view.

(i) NOTE

To download apps the vehicle must be connected to the internet.

- 2. Start the app and enter your Volvo ID/email address.
- 3. Follow the instructions that will be automatically sent to the email address connected to your Volvo ID.
 - > Your Volvo ID has now been registered to the vehicle. The Volvo ID services can now be used.

Related information

- Volvo ID (p. 26)
- Download apps (p. 466)
- Handling system updates via Download Center (p. 579)
- Internet-connected vehicle* (p. 507)

Drive-E - purer driving pleasure

Volvo is committed to the well-being of its customers. As a natural part of this commitment, we care about the environment in which we all live. Concern for the environment means an everyday involvement in reducing our environmental impact.

Volvo's environmental activities are based on a holistic view, which means we consider the overall environmental impact of a product throughout its complete life cycle. In this context, design, production, product use, and recycling are all important considerations. In production, Volvo has partly or completely phased out several chemicals including CFCs, lead chromates, asbestos, and cadmium: and reduced the number of chemicals used in our plants 50% since 1991.

Volvo was the first in the world to introduce into production a three-way catalytic converter with a Lambda sond, now called the heated oxygen sensor, in 1976. The current version of this highly efficient system reduces emissions of harmful substances (CO, HC, NOx) from the exhaust pipe by approximately 95 - 99% and the search to eliminate the remaining emissions continues. Volvo is the only automobile manufacturer to offer CFC-free retrofit kits for the air conditioning system of all models as far back as the 1975 model 240. Advanced electronic engine controls and cleaner fuels are bringing us closer to our

³ Vehicles with Volvo On Call

• goal. In addition to continuous environmental refinement of conventional gasoline-powered internal combustion engines, Volvo is actively looking at advanced technology alternative-fuel vehicles.

When you drive a Volvo, you become our partner in the work to lessen the vehicle's impact on the environment. To reduce your vehicle's environmental impact, you can:

- Maintain proper air pressure in your tires.
 Tests have shown decreased fuel economy with improperly inflated tires.
- Follow the recommended maintenance schedule in your Warranty and Service Records Information booklet.
- Drive at a constant speed whenever possible.
- See a trained and qualified Volvo service technician as soon as possible for inspection if the check engine (malfunction indicator) light illuminates, or stays on after the vehicle has started.
- Properly dispose of any vehicle-related waste such as used motor oil, used batteries, brake pads, etc.
- When cleaning your vehicle, please use genuine Volvo car care products. All Volvo car care products are formulated to be environmentally friendly.

Related information

- Economical driving (p. 438)
- The Owner's Manual and the environment (p. 23)
- Air quality (p. 209)

IntelliSafe - driver support

IntelliSafe is Volvo Cars' philosophy regarding vehicle safety. IntelliSafe consists of a number of systems, both standard and optional, that are designed to help make driving safer, prevent accidents and protect passengers and other road users.

Support

IntelliSafe includes driver support functions such as Adaptive cruise control* which helps the driver to maintain an even speed combined with a preselected time interval to the vehicle ahead.

Pilot Assist⁴ helps the driver keep the vehicle in the current traffic lane by providing steering assistance and maintaining an even speed and a set time interval to the vehicle ahead.

Park Assist Pilot* helps the driver pull into and out of parking spaces.

Other examples of systems that can help the driver are the Active main beam, Cross Traffic Alert (CTA)* and Blind Spot Information (BLIS)* systems.

Prevention

City Safety is a function intended to help prevent accidents. The function can help prevent or mitigate a collision with pedestrians, cyclists, large animals or other vehicles. Light, sound and pulsations in the brake pedal are provided to alert of a

28 *Option/accessory.

⁴ Depending on market, this function can be either standard or optional.

possible collision and help the driver act in time to prevent it. If the driver does not react to the warning and the risk of collision is determined to be imminent, City Safety can automatically apply the brakes.

Lane assistance (LKA) is another example of a function that can help prevent accidents by helping the driver - on expressways and similar larger roads - to reduce the risk of the car accidentally leaving its own lane.

The function **Steering aid during increased collision risk** can help the driver reduce the risk of the car leaving its lane unintentionally and/or colliding with another vehicle or obstacle by actively steering the car back into its lane and/or swerving.

Protection

To help protect the driver and passengers, the vehicle is equipped with seat belt tensioners that pull the seat belts taut in collisions and other critical situations. The vehicle also has airbags, inflatable curtains and the Whiplash Protection System (WHIPS), which helps prevent whiplash injuries.

Related information

- Driver support systems (p. 270)
- Active high beam (p. 159)
- Safety (p. 42)
- Seat belts (p. 47)

- Airbags (p. 52)
- Whiplash Protection System (p. 46)

Sensus - connection and entertainment

Sensus makes it possible to surf the Internet, use apps, and turn your vehicle into a Wi-Fi hotspot.

This is Sensus



Sensus provides an intelligent interface and Internet connection to the digital world. An intuitive navigation structure offers access to relevant assistance, information and entertainment when it is needed, without distracting the driver.

Sensus includes all of the solutions in the vehicle related to entertainment, Internet connection and navigation*, and serves as the user interface between the driver and the vehicle. Sensus is what makes communication between you, the vehicle and the world around you possible.

Information when it's needed, where it's needed

The vehicle's displays present the right information at the right time. Information is presented in

different displays depending on how it should be prioritized by the driver.

30 *Option/accessory.



Different types of information are shown in different displays depending on how the information should be prioritized.

Head-up display*



The head-up display presents information that the driver should react to immediately. For example, traffic warnings, speed information

and navigation messages*. Road sign information and incoming phone calls are also shown in the head-up display. These can be handled using the right-side steering wheel keypad or the center display.

Instrument panel



12"* instrument panel.

4◀



8-inch instrument panel.

The instrument panel displays information such as speed, incoming phone calls or the track currently playing. It is controlled using the steering wheel keypads.

Center display



Many of the vehicle's main functions are controlled from the center display, a touchscreen that reacts to taps and other gestures. This minimizes the number of physical buttons and controls needed in the vehicle. The screen can also be operated while wearing gloves.

The center display is used to control e.g. the climate and entertainment systems and to adjust the power seats*. The information presented in the center display can be handled by the driver or, in some situations, by a passenger.

Voice control system



The voice control system enables the driver to control certain vehicle functions without taking their hands off the wheel. The system can understand natural speech. Use voice commands to e.g. play a song, make a

phone call, increase the temperature in the passenger compartment or have a text message read aloud.

Related information

- Head-up display* (p. 144)
- Instrument panel (p. 84)
- Center display overview (p. 111)
- Voice control (p. 147)
- Internet-connected vehicle* (p. 507)
- Sharing Internet from the vehicle via Wi-Fi hotspot (tethering) (p. 511)

Software Updates

So that you as a Volvo customer shall have the best possible experience from your car, Volvo is continuously developing the systems in the cars and the services that you are offered.

You can update the software in your Volvo to the latest version when your car is serviced at an authorized Volvo dealer. The latest software update gives you access to new functions and improvements, as well as previous improvements included with previous software updates.

For more information about released updates and answers to frequently asked questions, please go to support.volvocars.com.



NOTE

Functionality after updating may vary depending on market, model, model year and options.

Related information

- Sensus connection and entertainment (p. 30)
- Handling system updates via Download Center (p. 579)

Data recording

As part of Volvo's commitment to safety and quality, certain information is recorded regarding vehicle operation, functionality and incidents.

This vehicle is equipped with an event data recorder (EDR). The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an airbag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less. The EDR in this vehicle is designed to record such data as:

- How various systems in your vehicle were operating;
- Whether or not the driver and passenger safety belts were buckled/fastened;
- How far (if at all) the driver was depressing the accelerator and/or brake pedal; and,
- How fast the vehicle was traveling.

These data can help provide a better understanding of the circumstances in which crashes and injuries occur.

EDR data is only recorded by the vehicle if a more serious collision situation occurs. No data is recorded by the EDR under normal driving conditions and the EDR never registers who is driving the vehicle or the location of a crash or a near crash-like situation. However, other parties, such

as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation. To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed.

Furthermore, your vehicle is equipped with a number of computers whose task is to continuously control and monitor the vehicle's operation. They can also register some of this information during normal driving conditions, most importantly if they detect a fault relating to the vehicle's operation and functionality or upon activation of the vehicle's active safety systems (e.g. City Safety and the auto-brake function). Some of the registered information is required by technicians when carrying out service and maintenance to enable them to diagnose and rectify any faults that have occurred in the vehicle and to enable Volvo to fulfill legal and other regulatory requirements. Information thus registered in the vehicle is registered in the vehicle's computers until the vehicle is serviced or repaired. In addition to the above, the registered information may - on an aggregated basis - be used for research and product development purposes in order to continuously improve the safety and quality of Volvo vehicles.

For additional information, please contact Volvo.

Related information

- Contacting Volvo (p. 26)
- Volvo Structural Parts Statement (p. 38)

Terms & Conditions for Services

Volvo offers services to help make driving your Volvo as safe and comfortable as possible.

These services comprise everything from assistance in emergencies to navigation and various maintenance services.

Before using the services, it is important to read the Terms and Conditions for the services at support.volvocars.com.

Related information

• Customer Privacy Policy (p. 34)

Customer Privacy Policy

Volvo respects and safeguards the personal privacy of everyone who visits our websites.

This policy refers to the handling of customer

This policy refers to the handling of customer data and personal information. The purpose is to give current, past and potential customers a general understanding of:

- The circumstances in which we collect and process your personal data.
- The types of personal data we collect.
- Why we collect your personal data.
- How we process your personal data.

The policy can be read in its entirety at support.volvocars.com.

Related information

- Terms of use and data sharing (p. 514)
- Terms & Conditions for Services (p. 34)
- Data recording (p. 33)

Important information on accessories and extra equipment

Incorrectly connected or installed accessories or extra equipment may have an adverse effect on the vehicle's electronics.

We strongly recommend that Volvo owners use only genuine, Volvo-approved accessories, and that accessory installations be performed only by a trained and qualified Volvo service technician. Certain accessories only work when the associated software is installed in the vehicle's computer system.

The equipment described in the Owner's Manual is not available in all vehicles. Vehicles may be equipped differently depending on market requirements and national or local laws and regulations.

Optional or accessory equipment may not be available in all countries or markets. Please note that some vehicles may be equipped differently, depending on special legal requirements. For more information on which equipment is standard and which is an option or accessory, please contact your Volvo retailer.

(i) NOTE

Do not export your Volvo to another country before investigating that country's applicable safety and exhaust emission requirements. In some cases it may be difficult or impossible to comply with these requirements. Modifications to the emission control system(s) may render your Volvo not certifiable for legal operation in the U.S., Canada and other countries.

♠ WARNING

CALIFORNIA proposition 65

Engine exhaust, some of its constituents, and certain vehicle components contain or emit chemicals known to the state of California to cause cancer, and birth defects or other reproductive harm. In addition, certain fluids contained in vehicles and certain products of component wear contain or emit chemicals known to the State of California to cause cancer, and birth defects or other reproductive harm.

Certain of the vehicle's components, such as airbag modules, seat belt tensioners, adjustable steering wheel columns and button cell batteries, may contain perchlorate materials. Special handling may apply for service or vehicle end of life disposal.

See www.dtsc.ca.gov/hazardouswaste/perchlorate.

M WARNING

The driver is always responsible for operating the vehicle in a safe manner and for complying with current statutes and regulations.

It is also essential to maintain and service the vehicle according to Volvo's recommendations as stated in the owner's information and the service and warranty booklet.

If the on-board information differs from the printed owner's manual, the printed information always takes precedence.

Related information

- Accessory installation (p. 36)
- Connecting equipment to the vehicle's data link connector (p. 36)
- Using the Owner's Manual (p. 21)

Accessory installation

We strongly recommend that Volvo owners use only genuine, Volvo-approved accessories, and that accessory installations be performed only by a trained and qualified Volvo service technician. Certain accessories only work when the associated software is installed in the vehicle's computer system.

- Genuine Volvo accessories are tested to
 ensure compatibility with the performance,
 safety, and emission systems in your vehicle.
 Additionally, a trained and qualified Volvo
 service technician knows where accessories
 may and may not be safely installed in your
 Volvo. In all cases, please consult a trained
 and qualified Volvo service technician before
 installing any accessory in or on your vehicle.
- Accessories that have not been approved by Volvo may or may not be specifically tested for compatibility with your vehicle.
- Any of your vehicle's performance and safety systems could be adversely affected if you install accessories that Volvo has not tested, or if you allow accessories to be installed by someone unfamiliar with your vehicle.
- Damage caused by unapproved or improperly installed accessories may not be covered by your new vehicle warranty. See your Warranty and Service Records Information booklet for more warranty information. Volvo assumes no responsibility for death, injury, or expenses

that may result from the installation of nongenuine accessories.


Related information

 Important information on accessories and extra equipment (p. 35)

Connecting equipment to the vehicle's data link connector

Incorrectly connected or installed software or diagnostic tools may have an adverse effect on the vehicle's electronics.

We strongly recommend that Volvo owners use only genuine, Volvo-approved accessories, and that accessory installations be performed only by a trained and qualified Volvo service technician. Certain accessories only work when the associated software is installed in the vehicle's computer system.



On-board Diagnostic (OBDII) socket under the dashboard on the driver's side.

(\mathbf{i})

NOTE

Volvo Cars takes no responsibility for the consequences of connecting non-authorized equipment to the On-board Diagnostic (OBDII) socket. This socket should only be used by a trained and qualified Volvo service technician.

Type approval USA

FCC ID: 2AGKKACUII-06

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.



WARNING

Changes or modifications not expressively approved by the party responsible for compliance could void the user's authority to operate the equipment.

Canada

IC: 20839-ACUII06

This device complies with Industry Canada license-exempt RSS standards. Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Related information

 Important information on accessories and extra equipment (p. 35)

Technician certification

In addition to Volvo factory training, Volvo supports certification by the National Institute for Automotive Service Excellence (A.S.E.).

Certified technicians have demonstrated a high degree of competence in specific areas. Besides passing exams, each technician must also have worked in the field for two or more years before a certificate is issued. These professional technicians are best able to analyze vehicle problems and perform the necessary maintenance procedures to keep your Volvo at peak operating condition.

Viewing the Vehicle Identification Number (VIN)

When contacting a Volvo retailer, about e.g. your Volvo On Call subscription, your Vehicle Identification Number (VIN⁵) may be needed.

- Tap **Settings** in the Top view in the center display.
- Proceed to System → System Information
 → Vehicle Identification Number.
 - The vehicle identification number will be displayed.

Volvo Structural Parts Statement

Volvo is one of the leading companies for car safety.

Volvo engineers and manufactures vehicles designed to help protect vehicle occupants in the event of a collision.

Volvos are designed to absorb the impact of a collision. This energy absorption system including, but not limited to, structural components such as bumper reinforcement bars, bumper energy absorbers, frames, rails, fender aprons, A-pillars, B-pillars and body panels must work together to maintain cabin integrity and protect the vehicle occupants.

The supplemental restraint system including but not limited to air bags, side curtain air bags, and deployment sensors work together with the above components to provide proper timing for air bag deployment.

Due to the above, Volvo Car USA does not support the use of aftermarket, alternative or anything other than original Volvo parts for collision repair.

Volvo Car USA also recommends using Volvoapproved replacement glass. The use of aftermarket glass, particularly a windshield, can have an adverse effect on collision avoidance and advanced lighting systems. In addition Volvo does not support the use or reuse of structural components from an existing vehicle that has been previously damaged. Although these parts may appear equivalent, it is difficult to tell if the parts have been previously replaced with non-OE parts or if the part has been damaged as a result of a prior collision. The quality of these used parts may also have been affected due to environmental exposure.

Related information

Data recording (p. 33)

⁵ Vehicle Identification Number

Driver distraction

A driver has a responsibility to do everything possible to ensure his or her own safety and the safety of passengers in the vehicle and others sharing the roadway. Part of this responsibility is avoiding distractions, including performing activities that are not directly related to controlling the vehicle in the driving environment.

Your new Volvo is, or can be, equipped with feature-rich entertainment and communication systems. These include hands-free cellular telephones, navigation systems, and multipurpose audio systems. You may also own other portable electronic devices for your own convenience. When used properly and safely, they enrich the driving experience. Improperly used, any of these could cause a distraction.

For all of these systems, we want to provide the following warning that reflects the strong Volvo concern for your safety. Never use these devices or any feature of your vehicle in a way that distracts you from the task of driving safely. Distraction can lead to a serious accident. In addition to this general warning, we offer the following guidance regarding specific new features that may be found in your vehicle:

↑ WARNING

- Never use a hand-held cellular telephone while driving. Some jurisdictions prohibit cellular telephone use by a driver while the vehicle is moving.
- If your vehicle is equipped with a navigation system, set and make changes to your travel itinerary only with the vehicle parked.
- Never program your audio system while the vehicle is moving. Program radio presets with the vehicle parked, and use your programmed presets to make radio use quicker and simpler.
- Never use portable computers or personal digital assistants while the vehicle is moving.

Related information

• Audio, media and Internet (p. 464)

Safety

The vehicle is equipped with a number of safety systems that work together to help protect the vehicle's driver and passengers in the event of an accident.

The vehicle is equipped with a number of sensors that may react in the event of an accident and activate different safety systems, such as the airbag system and seat belt tensioners. Depending on the specific conditions of the accident, e.g. collisions at certain angles, overturning or swerving, the systems react differently to help provide the best protection.

There are also mechanical safety systems such as the Whiplash Protection System. The vehicle is also built so that a large part of the force of a collision is distributed to the vehicle's members. pillars, floor, roof and other parts of the body.

After an accident, the vehicle's safety mode may be activated if any important function in the vehicle has been damaged.

Warning symbol in the instrument panel



The warning symbol in the instrument panel illuminates when the vehicle's electrical system is in ignition mode II. The symbol will go out after approx. 6

seconds if no faults are detected in the vehicle's safety systems.

WARNING

If the warning symbol remains illuminated or switches on while driving and the message SRS airbag Service urgent Drive to workshop is displayed in the instrument panel, this indicates that something in the safety system is not functioning properly. Volvo recommends contacting an authorized Volvo workshop for repairs as soon as possible.

WARNING

Never attempt to alter or repair any of the vehicle's safety systems yourself. Incorrectly performed repairs to any system could impair function and lead to serious injury. Volvo recommends contacting an authorized Volvo workshop.



If this dedicated warning symbol is not functioning, the general warning symbol will illuminate instead and the same message will be displayed in the instru-

ment panel.

Related information

- Safety during pregnancy (p. 43)
- Occupant safety (p. 43)
- Reporting safety defects (p. 44)
- Recall information (p. 45)
- Seat belts (p. 47)

- Airbags (p. 52)
- Whiplash Protection System (p. 46)
- Safety mode (p. 61)
- Child safety (p. 63)

Safety during pregnancy

It is important that seat belts are worn correctly during pregnancy and that pregnant drivers adjust their seating position accordingly.

Seat belt



The seat belt should fit closely against the shoulder, with the diagonal section between the breasts and to the side of the stomach.

The lap section of the seat belt should lie flat over the thighs and as far as possible under the stomach. Never let it ride upward. Remove unnecessary slack and make sure the seat belt fits as close as possible to the body. Make sure there are no twists in the seat belt.

Seating position

As pregnancy progresses, pregnant drivers should adjust the seat and steering wheel to a position that allows them to retain full control of

the vehicle (which means they should be able to easily reach the steering wheel and foot pedals). Try to maintain as much distance as possible between the stomach and the steering wheel.

Related information

- Safety (p. 42)
- Seat belts (p. 47)
- Manual front seats (p. 188)
- Power front seats* (p. 189)

Occupant safety

Safety is Volvo's cornerstone.

Volvo's concern for safety

Our concern for safety dates back to 1927 when the first Volvo rolled off the production line. Three-point seat belts (a Volvo invention), safety cages, and energy-absorbing impact zones were designed into Volvo vehicles long before it was fashionable or required by government regulation.

We will not compromise our commitment to safety. We continue to seek out new safety features and to refine those already in our vehicles. You can help. We would appreciate hearing your suggestions about improving automobile safety. We also want to know if you ever have a safety concern with your vehicle. Call us in the U.S. at: 1-800-458-1552 or in Canada at: 1-800-663-8255.

Occupant safety reminders

How safely you drive doesn't depend on how old you are but rather on:

- How well you see.
- Your ability to concentrate.
- How quickly you make decisions under stress to avoid an accident.

The following suggestions are intended to help you cope with the ever changing traffic environment.

- Never drink and drive.
- If you are taking any medication, consult your physician about its potential effects on your driving abilities.
- Take a driver-retraining course.
- Have your eyes checked regularly.
- Keep your windshield and headlights clean.
- Replace wiper blades when they start to leave streaks.
- Take into account the traffic, road, and weather conditions, particularly with regard to stopping distance.
- Never send text messages while driving.
- Refrain from using or minimize the use of a cell phone while driving.

Related information

- Safety (p. 42)
- Reporting safety defects (p. 44)
- Recall information (p. 45)

Reporting safety defects

The following information will help you report any perceived safety-related defects in your vehicle.

Reporting safety defects in the U.S.

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Volvo Car USA, LLC, If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign, However, NHTSA cannot become involved in individual problems between you, your retailer, or Volvo Car USA, LLC. To contact NHTSA, you may either call the Auto Safety Hotline tollfree at

1-888-327-4236

(TTY: 1-800-424-9153) or write to: NHTSA, U.S. Department of Transportation, Washington D.C. 20590.

You can also obtain other information about motor vehicle safety from http://www.safercar.gov, where you can also enter your vehicle's VIN (Vehicle Identification Number) to see if it has any open recalls.

Volvo strongly recommends that if your vehicle is covered under a service campaign, safety or emission recall or similar action, it should be completed as soon as possible. Please check with your local retailer or Volvo Car USA, LLC if your vehicle is covered under these conditions.

NHTSA can be reached at:

Internet:

http://www.nhtsa.gov

Telephone:

1-888-DASH-2-DOT (1-888-327-4236).

Reporting safety defects in Canada

If you believe your vehicle has a defect that could cause a crash or could cause injury or death, you should immediately inform Transport Canada in addition to notifying Volvo Car Canada Ltd.

Transport Canada can be contacted at:

1-800-333-0510

Teletypewriter (TTY): 613 990-4500

Fax: 1-819-994-3372

Mailing Address: Transport Canada - Road Safety, 80 rue Noël, Gatineau, (Quebec) J8Z 0A1

Related information

- Safety (p. 42)
- Occupant safety (p. 43)
- Recall information (p. 45)
- Viewing the Vehicle Identification Number (VIN) (p. 38)

Recall information

On our website, select the "Own" tab on the upper left side of the screen and click the heading "Recall Information" on the right side of the screen. Enter your Vehicle Identification Number (VIN) for your vehicle (found at the base of the windshield). If your vehicle has any open Recalls, they will be displayed on this page.

You can also enter the Vehicle Identification Number in the search field on the National Highway Traffic Safety Administration's (NHTSA) website at: www.nhtsa.gov.

Volvo customers in Canada

For any questions regarding open recalls for your vehicle, please contact your authorized Volvo retailer. If your retailer is unable to answer your questions, please contact Volvo Customer Relations at 800-663-8255, Monday through Friday, 8:30 A.M. to 5:00 P.M. EST or volvocars.com/ca. You may also write us at:

Volvo Car Canada Ltd.

Customer Care Centre

9130 Leslie Street, Suite 101

Richmond Hill, Ontario L4B 0B9

www.tc.gc.ca

Related information

- Safety (p. 42)
- Reporting safety defects (p. 44)
- Occupant safety (p. 43)

Whiplash Protection System

The Whiplash Protection System (WHIPS) is designed to help reduce the risk of whiplashtype injuries. The system consists of energy absorbing backrests and seat cushions as well as specially designed head restraints in the front seats.

WHIPS is activated in the event of a rear-end collision and adapted to the angle and speed of the collision and to the characteristics of the colliding vehicle.

When WHIPS is activated, the front seat backrests move rearward and the seat cushions move downward to change the seating positions of the driver and front seat passenger. This movement helps absorb some of the forces that could result in whiplash.

WARNING

WHIPS is a supplement to the seat belt. Always wear your seat belt.

WARNING

Do not attempt to alter or repair the seat or WHIPS on your own. Volvo recommends contacting an authorized Volvo workshop.

If the front seats have been subjected to severe stress, e.g. in a collision, the seats must be replaced. Even if the seats appear undamaged, some of their protective properties may have been lost.



Do not place any objects on the floor behind or under the front seats or on the rear seat that could prevent WHIPS from functioning correctly.

Λ

WARNING

Do not squeeze box-like cargo between the rear seat cushion and the front seat backrest.

If the rear seat backrests are folded down, cargo must be secured to prevent it from sliding forward against the front seat backrests in the event of a collision.



WARNING

If a rear seat backrest is folded down or if a rear-facing child restraint is being used in the rear seat, the seat in front must be moved forward so that it does not come into contact with the backrest or child restraint.

Seating position

For WHIPS to provide optimal protection, the driver and passenger must be seated correctly and the system's function must not be impeded in any way.

Set the front seat to the correct seating position before starting to drive.

The driver and the front seat passenger should sit in the center of the seat with their heads as close as possible to the head restraints.

Related information

- Safety (p. 42)
- Manual front seats (p. 188)
- Power front seats* (p. 189)

• Rear Collision Warning (p. 345)

Seat belts

Seat belts should always be worn by all occupants in your vehicle. Children should be properly restrained using an infant seat, adjustable child seat or booster cushion as determined by age, weight and height.

Most states and provinces make it mandatory for occupants of a vehicle to use seat belts.

Seat belt maintenance

Check periodically that the seat belts are in good condition. Use water and a mild detergent for cleaning. Check the seat belt mechanism's function as follows: attach the seat belt and pull rapidly on the strap.

- Never repair the belt yourself. Repairs should only be performed by a trained and qualified Volvo service technician.
- Any device used to induce slack into the shoulder belt portion of the three-point belt system will have a detrimental effect on the amount of protection available in the event of a collision.
- The seat back should not be tilted too far back. The shoulder belt must be taut in order to function properly.
- Do not use any type of child restraint in the front passenger seat. We recommend that children who have outgrown these devices sit in the rear seat with the seat belt properly fastened.

Related information

- Safety (p. 42)
- Seat belt tensioners (p. 50)
- Buckling and unbuckling seat belts (p. 48)
- Door and seat belt reminders (p. 51)

Buckling and unbuckling seat belts

Make sure that all passengers have buckled their seat belts before starting to drive.

Buckling seat belts

1. Pull out the belt slowly and make sure it is not twisted or damaged.

If the seat belt in the second row center seating position is used, make sure it is properly positioned in the correct seat belt guide.

i NOTE

Each seat belt is equipped with a retractor that will lock up in the following situations:

- if the belt is pulled out rapidly
- during braking and acceleration
- if the vehicle is leaning excessively
- when driving in turns
- if the automatic locking retractor/emergency locking retractor (ALR/ELR) is activated. Each seat belt (except for the driver's) is equipped with an ALR function, which is designed to keep the seat belt taut when installing a child restraint. ALR is activated when the seat belt is pulled out as far as possible. If this is done, a sound from the seat belt retractor will be audible, which is normal. The seat belt can now only be fed into the retractor, not pulled out. This function is automatically disabled when the seat belt is unbuckled and fully retracted.

- 2. Buckle the seat belt by pushing the latch plate into the receptacle.
 - > A distinct "click" indicates that the belt is locked into place.


Always insert the seat belt latch plate into the belt buckle on the correct side. Failure to do so could cause the seat belts and belt buckles to malfunction in a collision. There is a risk of serious injury.

The height of the seat belts in the front seats and outboard rear seating positions can be adjusted.



Press the button on the seat belt holder and move the belt up or down.

Position the belt as high as possible without it chafing against the neck.



The belt should be positioned closely against the inside of the shoulder (against the collarbone, not down over the arm).

 Tighten the lap section of the seat belt over the hips by pulling the diagonal section upward toward the shoulder.



The lap section of the seat belt should be positioned low on the hips (not against the abdomen).

™ WARNING

Never use a seat belt for more than one occupant. Never wear the shoulder portion of the belt under the arm, behind the back or otherwise out of position. Such use could cause injury in the event of an accident. As seat belts lose much of their strength when exposed to violent stretching, they should be replaced after any collision, even if they appear to be undamaged.

Do not use clips or fasten the belts around hooks or other parts of the interior. This will prevent the seat belt from fitting properly.

↑ WARNING

Never damage the seat belts and never insert any foreign objects into the belt buckle. This may cause the seat belts and belt buckles to malfunction in a collision. There is a risk of serious injury.

Unbuckling seat belts

 Press the red button on the seat belt receptacle and make sure the seat belt retracts fully into the retractor slot. If it does not fully retract, guide the belt manually into the slot and make sure it does not hang loose.

If the seat belt in the second row center seating position is used, make sure it is properly positioned in the correct seat belt guide.

Related information

- Seat belts (p. 47)
- Seat belt tensioners (p. 50)
- Door and seat belt reminders (p. 51)

Seat belt tensioners

The vehicle is equipped with standard and electric seat belt tensioners that can help tension the seat belt in a critical situation or collision.

Standard seat belt tensioners

All seat belts are equipped with a standard seat belt tensioner.

In a collision of sufficiently violent force, the seat belt tensioners will tension the seat belts in order to more effectively restrain the occupants.

Electric seat belt tensioners

The driver's and front passenger's seat belts are equipped with electric seat belt tensioners.

The seat belt tensioners interact and can be activated in conjunction with the City Safety and Rear Collision Warning driver support systems. In critical situations, such as if the vehicle brakes suddenly, begins to skid or runs off the road (e.g if the vehicle rolls into a ditch, lifts off the ground or hits an obstacle in the road), or if there is a risk of collision, the seat belts can be pulled taut by the seat belt tensioner's electric motor.

The electric seat belt tensioner helps to position the occupant more effectively in the seat, which reduces the risk of the occupant striking the interior of the passenger compartment and improves the effect of other safety systems such as the airbags.

When a critical situation has passed, the seat belt and the electric seat belt tensioner are reset automatically. However, they can also be reset manually.

⚠ WARNING

Never attempt to alter or repair the seat belt on your own. Volvo recommends contacting an authorized Volvo workshop.

If the seat belt has been exposed to extreme forces, e.g. in conjunction with a collision, the entire seat belt must be replaced. Even if the seat belt appears undamaged, some of its protective properties may have been lost. Also replace the seat belt if it is worn or damaged. The new seat belt must be type approved and intended for the same seating position as the replaced seat belt.

Related information

- Seat belts (p. 47)
- Buckling and unbuckling seat belts (p. 48)
- Resetting the electric seat belt tensioners (p. 51)
- City Safety™ (p. 333)
- Rear Collision Warning (p. 345)

Resetting the electric seat belt tensioners

The electric seat belt tensioners are designed to be reset automatically, but if the seat belt remains taut it can be reset manually.

- 1. Stop the vehicle in a safe location.
- 2. Unbuckle the seat belt and then rebuckle it.
 - > The seat belt and the electric seat belt tensioner will be reset.

★ WARNING

Never attempt to alter or repair the seat belt on your own. Volvo recommends contacting an authorized Volvo workshop.

If the seat belt has been exposed to extreme forces, e.g. in conjunction with a collision, the entire seat belt must be replaced. Even if the seat belt appears undamaged, some of its protective properties may have been lost. Also replace the seat belt if it is worn or damaged. The new seat belt must be type approved and intended for the same seating position as the replaced seat belt.

Related information

- Seat belt tensioners (p. 50)
- Seat belts (p. 47)

Door and seat belt reminders

This system is intended to remind occupants to buckle their seat belts and to alert the driver if a door or the hood, tailgate or fuel filler door is open.

Graphics in the instrument panel



Graphics in the instrument panel with various types of warnings. The warning colors for the doors/tailgate vary depending on the vehicle's speed.

The instrument panel graphic shows the seats where seat belts are buckled and not buckled.

The same graphic also indicates if the hood, tailgate, fuel filler door or any door is open.

Confirm the graphic by briefly pressing the **O** button on the right-side steering wheel keypad.

Seat belt reminder



Reminder light in ceiling console.

The seat belt reminder consists of an audible signal and a symbol in the instrument panel.

The reminder light varies depending on the vehicle's speed, driving time and distance driven.

A seat belt status graphic in the instrument panel indicates when the driver's or a passenger's seat belt is buckled or unbuckled.

Child seats are not included in the seat belt reminder system.

Front seats

An audible signal and an indicator light remind unbuckled occupants to fasten their seat belts.

Rear seat

The rear seat belt reminder has two functions:

- To indicate which seat belts are buckled in the rear seats. This will also be displayed in an instrument panel graphic.
- To provide audio and visual reminders if any seat belt in the rear seat is removed while the vehicle is in motion. The reminder will stop when the seat belt has been rebuckled.

Door/hood/tailgate and fuel filler door reminder

If the hood, tailgate, fuel filler door or any door is not properly closed, this will be indicated by a graphic in the instrument panel. Stop the vehicle safely and close the open door, hood, etc.



If the vehicle is moving at a speed under approx. 10 km/h (6 mph), the information symbol will illuminate in the instrument panel.



If the vehicle is moving at a speed above approx. 10 km/h (6 mph), the warning symbol will illuminate in the instrument panel.

Related information

- Seat belts (p. 47)
- Buckling and unbuckling seat belts (p. 48)

Airbags

The vehicle is equipped with airbags and inflatable curtains for the driver and passengers.

↑ WARNING

- If the airbag warning light stays on after the engine has started or if it illuminates while you are driving, have the vehicle inspected by a trained and qualified Volvo service technician as soon as possible.
- Never attempt to alter or repair any of the vehicle's safety systems yourself. Incorrectly performed repairs to any system could impair function and lead to serious injury. All work on these systems should be performed by a trained and qualified Volvo service technician.

52

. WARNING

If your vehicle has become water-damaged in any way (e.g., soaked floor mats/standing water on the floor of the vehicle), do not attempt to start the engine. This may cause airbag deployment, which could result in serious injury. Volvo recommends towing the vehicle directly to an authorized Volvo workshop.

Before attempting to tow the vehicle:

- 1. Switch off the ignition for at least 10 minutes and disconnect the battery.
- Follow the instructions for manually overriding the shiftlock system.

Deployed airbags

If any of the airbags have deployed:

- Do not attempt to drive the vehicle. Have it towed to an authorized workshop.
- If necessary, seek medical attention.

Related information

- Safety (p. 42)
- Driver/passenger-side airbags (p. 53)
- Side airbags (p. 60)
- Inflatable curtain (p. 60)

Driver/passenger-side airbags

As a supplement to the seat belts, the vehicle is equipped with driver and passenger side front airbags.



Driver/passenger side front airbags.

In a frontal collision, the airbags help protect the driver's and passenger's head, face and chest and the driver's knees and legs.

A collision of a sufficiently violent force will trigger the sensors and one or more airbags will inflate. The airbag helps cushion the initial impact of the collision for the passenger. The airbag deflates when compressed by the collision. A small amount of powder will also be released from the airbag. This may appear to be smoke and is normal. The entire process, from inflation to deflation of the airbag, occurs within tenths of a second.

(i) NOTE

The sensors react differently depending on the circumstances of the accident and whether or not the seat belt is used. Does not apply to all belt positions.

In some accident situations, only one (or none) of the airbags will be deployed. The sensors monitor the impact of the collision and react accordingly to deploy one, several or no airbags.

↑ WARNING

The seat belt and the airbag work together. If the seat belt is not used or is used incorrectly, the airbag may not provide the intended protection in a collision.

To help prevent injury in the event the airbag is deployed, passengers should sit as upright as possible, with their feet on the floor and their backs against the seat backrest.

↑ WARNING

Volvo recommends contacting an authorized Volvo workshop for repairs. Incorrectly performed repairs to the airbag system could impair function and lead to serious injury.

The front airbag system

The front airbag system includes gas generators surrounded by the airbags, and deceleration sen-

sors that activate the gas generators, causing the airbags to be inflated with nitrogen gas.

As the movement of the seats' occupants compresses the airbags, some of the gas is expelled at a controlled rate to provide better cushioning. Both seat belt tensioners also deploy, minimizing seat belt slack. The entire process, from inflation to deflation of the airbag, occurs within tenths of a second.

The location of the front airbags is indicated by **SRS AIRBAG** embossed on the steering wheel pad and above the glove compartment, and by decals on both sun visors and on the front and far right side of the dash.

The **driver's side front airbag** is folded and located in the steering wheel hub.

The **knee airbag** is folded on the underside of the dashboard on the driver's side. The text **AIRBAG** is embossed on the panel.

The **passenger's side front airbag** is folded behind a panel located above the glove compartment.

- The airbags in the vehicle are designed to be a SUPPLEMENT to-not a replacement for-the three-point seat belts. For maximum protection, wear seat belts at all times. Be aware that no system can prevent all possible injuries that may occur in an accident.
- Never drive with your hands on the steering wheel pad/airbag housing.
- The front airbags are designed to help prevent serious injury. Deployment occurs very quickly and with considerable force.
 During normal deployment and depending on variables such as seating position, one may experience abrasions, bruises, swellings, or other injuries as a result of deployment of one or both of the airbags.
- When installing any accessory equipment, make sure that the front airbag system is not damaged. Any interference in the system could cause malfunction.

Front airbag deployment

 The front airbags are designed to deploy during certain frontal or front-angular collisions, impacts, or decelerations, depending on the crash severity, angle, speed and object impacted. The airbags may also deploy in

- certain non-frontal collisions where rapid deceleration occurs.
- The airbag system sensors, which trigger the front airbags, are designed to react to both the impact of the collision and the inertial forces generated by it, and to determine if the intensity of the collision is sufficient for the seat belt tensioners and/or airbags to be deployed.

However, not all frontal collisions activate the front airbags.

- If the collision involves a nonrigid object (e.g., a snow drift or bush), or a rigid, fixed object at a low speed, the front airbags will not necessarily deploy.
- Front airbags do not normally deploy in a side impact collision, in a collision from the rear or in a rollover situation.
- The amount of damage to the bodywork does not reliably indicate if the airbags should have deployed or not.

i NOTE

- Deployment of front airbags occurs only one time during an accident. In a collision where deployment occurs, the airbags and seat belt pretensioners activate.
 Some noise occurs and a small amount of powder is released. The release of the powder may appear as smoke-like matter. This is a normal characteristic and does not indicate fire.
- Volvo's front airbags use special sensors that are integrated into the front seat belt buckles. The point at which the airbag deploys is determined by whether or not the seat belt is being used, as well as the severity of the collision.
- Collisions can occur where only one of the airbags deploys. If the impact is less severe, but severe enough to present a clear injury risk, the airbags are triggered at partial capacity. If the impact is more severe, the airbags are triggered at full capacity.

♠ WARNING

- Do not use child safety seats or child booster cushions/backrests in the front passenger's seat. We also recommend that occupants under 140 cm (4 feet 7 inches) in height who have outgrown these devices sit in the rear seat with the seat belt fastened. See also the Occupant Weight Sensor information.
- Never drive with the airbags deployed.
 The fact that they hang out can impair the steering of your vehicle. Other safety systems can also be damaged.
- The smoke and dust formed when the airbags are deployed can cause skin and eye irritation in the event of prolonged exposure.

Should you have questions about any component in the SRS system, please contact a trained and qualified Volvo service technician or Volvo customer support:

In the United States

Volvo Car USA, LLC

Customer Care Center

1 Volvo Drive

P.O. Box 914

Rockleigh, New Jersey 07647

1-800-458-1552

www.volvocars.com/us

In Canada

Volvo Car Canada Ltd.

Customer Care Centre

9130 Leslie Street, Suite 101

Richmond Hill, Ontario L4B 0B9

1-800-663-8255

www.volvocars.com/ca

Airbag decals



Airbag decal on the outside of both sun visors

44



Passenger's side airbag decal

MARNING

- Children must never be allowed in the front passenger's seat.
- Occupants in the front passenger's seat must never sit on the edge of the seat, sit leaning toward the instrument panel or otherwise sit out of position.
- The occupant's back must be as upright as comfort allows and be against the seat back with the seat belt properly fastened.
- Feet must be on the floor, e.g., not on the dash, seat or out of the window.

. MARNING

- No objects or accessory equipment, e.g. dashboard covers, may be placed on, attached to, or installed near the air bag cover (the area above the glove compartment) or the area affected by airbag deployment.
- There should be no loose articles, such as coffee cups on the floor, seat, or dashboard area.
- Never try to open the airbag cover on the steering wheel or the passenger's side dashboard. This should only be done by a trained and qualified Volvo service technician.
- Failure to follow these instructions can result in injury to the vehicle's occupants.

Related information

- Airbags (p. 52)
- Occupant weight sensor (p. 56)

Occupant weight sensor

The Occupant Weight Sensor (OWS) is designed to meet the regulatory requirements of Federal Motor Vehicle Safety Standard (FMVSS) 208 and is designed to disable (will not inflate) the passenger's side front airbag under certain conditions.



Occupant Weight Sensor (OWS) indicator light

Disabling the passenger's side front airbag

Volvo recommends that ALL occupants (adults and children) shorter than 140 cm (4 feet 7 inches) be seated in the back seat of any vehicle with a front passenger side airbag and be properly restrained for their size and weight.

The OWS works with sensors that are part of the front passenger's seat and seat belt. The sensors are designed to detect the presence of a properly

seated occupant and determine if the passenger's side front airbag should be enabled (may inflate) or disabled (will not inflate).

The OWS will disable (will not inflate) the passenger's side front airbag when:

- the front passenger's seat is unoccupied, or has small/medium objects in the front seat,
- the system determines that an infant is present in a rear-facing infant seat that is installed according to the manufacturer's instructions.
- the system determines that a small child is present in a forward-facing child restraint that is installed according to the manufacturer's instructions,
- the system determines that a small child is present in a booster seat,
- a front passenger takes his/her weight off of the seat for a period of time,
- a child or a small person occupies the front passenger's seat.

The OWS uses a PASSENGER AIRBAG OFF indicator lamp which will illuminate and stay on to remind you that the passenger's side front airbag is disabled. The PASSENGER AIRBAG OFF indicator lamp is located in the overhead console, near the base of the rearview mirror.

(i) NOTE

When the ignition is switched on, the OWS indicator light will illuminate for several seconds while the system performs a self-diagnostic test.

However, if a fault is detected in the system:

- The OWS indicator light will stay on
- The SRS warning light will come on and stay on and a text message will be displayed.

M WARNING

If a fault in the system is detected and indicated as described, be aware that the passenger's side front airbag will not deploy in the event of a collision. In this case, the SRS system and Occupant Weight Sensor should be inspected by a trained and qualified Volvo service technician as soon as possible.

MARNING MARNING

- Never try to open, remove or repair any components in the OWS system. This could cause the system to malfunction. Maintenance or repairs should only be carried out by an a trained and qualified Volvo service technician.
- The front passenger's seat should not be modified in any way. This could reduce pressure on the seat cushion, which might interfere with the OWS system's function.

44

Passenger's seat occu- pancy status	OWS indi- cator light status	Passenger's side front air- bag status	
Seat unoccu- pied	OWS indi- cator light lights up.	Passenger's side front airbag disabled	
Seat occu- pied by low weight occu- pant/object ^A	OWS indicator light lights up	Passenger's side front air- bag disabled	
Seat occu- pied by heavy occupant/ object	OWS indicator light is not lit	Passenger's side front air- bag enabled	

A Volvo recommends that children always be properly restrained in appropriate child restraints in the rear seats. Do not assume that the passenger's side front airbag is disabled unless the PASSENGER AIRBAG OFF indicator lamp is it. Make sure the child restraint is properly installed. If there is any doubt as to the status of the passenger's side front airbag, move the child restraint to the rear seat.

The OWS is designed to enable (may inflate) the passenger's side front airbag in the event of a collision anytime the system senses that a person of adult size is sitting properly in the front passenger's seat. The PASSENGER AIRBAG OFF indicator lamp will be off and remain off.

If a person of adult size is sitting in the front passenger's seat, but the PASSENGER AIRBAG OFF indicator lamp is on, it is possible that the person isn't sitting properly in the seat. If this happens:

- Turn the vehicle off and ask the person to place the backrest in an upright position.
- Have the person sit upright in the seat, centered on the seat cushion, with the person's legs comfortably extended.
- Restart the vehicle and have the person remain in this position for about two minutes.
 This will allow the system to detect that person and enable the passenger's frontal airbag.
- If the PASSENGER AIRBAG OFF indicator lamp remains on even after this, the person should be advised to ride in the rear seat.

This indicates limitations in OWS classification capability. It does not indicate OWS malfunction.

Modifications

If you are considering modifying your vehicle in any way to accommodate a disability, for example by altering or adapting the driver's or front passenger's seat(s) and/or airbag systems, please contact Volvo at:

In the United States

Volvo Car USA, LLC

Customer Care Center

1 Volvo Drive

P.O. Box 914

Rockleigh, New Jersey 07647 1-800-458-1552

In Canada

Volvo Car Canada Ltd.
Customer Care Centre
9130 Leslie Street, Suite 101
Richmond Hill, Ontario L4B 0B9
1-800-663-8255

♠ WARNING

- No objects that add to the total weight on the seat should be placed on the front passenger's seat. If a child is seated in the front passenger's seat with any additional weight, this extra weight could cause the OWS system to enable the airbag, which might cause it to deploy in the event of a collision, thereby injuring the child.
- The seat belt should never be wrapped around an object on the front passenger's seat. This could interfere with the OWS system's function.
- The front passenger's seat belt should never be used in a way that exerts more pressure on the passenger than normal. This could increase the pressure exerted on the weight sensor by a child, and could result in the airbag being enabled, which might cause it to deploy in the event of a collision, thereby injuring the child.

- Keep the following points in mind with respect to the OWS system. Failure to follow these instructions could adversely affect the system's function and result in serious injury to the occupant of the front passenger's seat:
- The full weight of the front seat passenger should always be on the seat cushion. The passenger should never lift him/ herself off the seat cushion using the armrest in the door or the center console, by pressing the feet on the floor, by sitting on the edge of the seat cushion, or by pressing against the backrest in a way that reduces pressure on the seat cushion. This could cause OWS to disable the front, passenger's side airbag.

↑ WARNING

- Do not place any type of object on the front passenger's seat in such a way that jamming, pressing, or squeezing occurs between the object and the front seat, other than as a direct result of the correct use of the Automatic Locking Retractor/ Emergency Locking Retractor (ALR/ELR) seat belt.
- No objects should be placed under the front passenger's seat. This could interfere with the OWS system's function.

Related information

Driver/passenger-side airbags (p. 53)

Side airbags

The side airbags, on the driver's and passenger sides, protect the chest and hip in a collision.



The side airbags are located in the front seats' outer backrest frames and help protect the driver and front seat passenger.

A collision of a sufficiently violent force will trigger the sensors and one or more side airbags will inflate. The side airbags inflate between the seat occupant and the door panel to help cushion the initial impact of the collision. The airbag deflates when compressed by the collision. The side airbags are normally only deployed on the side of the vehicle impacted by the collision.

Volvo recommends contacting an authorized Volvo workshop for repairs. Incorrectly performed repairs to the side airbag system could impair function and lead to serious injury.

♠ WARNING

Do not place any objects in the area between the outer edges of the seats and the door panels, as this could impair the function of the side airbags.

Volvo recommends only using seat covers approved by Volvo. Other seat covers could prevent the side airbags from functioning properly.

MARNING

The side airbag is a supplement to the seat belt. Always wear your seat belt.

Related information

• Airbags (p. 52)

Inflatable curtain

The inflatable curtain, Inflatable Curtain (IC), helps to prevent the driver and passengers from striking their heads on the inside of the vehicle during a collision.



The inflatable curtains are installed along both sides of the inside of the roof and help protect occupants in the vehicle's outer seats. **IC AIRBAG** is embossed on the panels.

A collision of a sufficiently violent force will trigger the sensors and the inflatable curtain will inflate

Λ

WARNING

Volvo recommends contacting an authorized Volvo workshop for repair. Incorrectly performed repairs to the inflatable curtain system could impair function and lead to serious injury.



WARNING

Never hang or attach heavy objects in the handle in the ceiling. The hooks are only intended for lightweight garments (not for hard objects such as umbrellas).

Never screw or mount anything to the vehicle's headlining, door pillars or side panels. This could impair the intended protective properties. Volvo recommends only using Volvo original parts that are approved for placement in these areas.



WARNING

If objects are loaded higher than the upper edge of the side windows, leave a 10 cm (4 in.) space between the objects and the window. Objects placed closer to this could impede the function of the inflatable curtain concealed inside the headlining.



WARNING

The inflatable curtain is a supplement to the seat belt. Always wear your seat belt.

Related information

Airbags (p. 52)

Safety mode

Safety mode is a feature that is triggered after a collision if there is potential damage to an important function in the vehicle, such as the fuel lines, sensors for one of the safety systems, the brake system, etc.

If the vehicle has been involved in a collision, the text **Safety mode See Owner's manual** may appear in the instrument panel along with the warning symbol if the panel is undamaged and the vehicle's electrical system is intact. The message indicates that one or more of the vehicle's functions may be reduced.



WARNING

Never attempt to restart the vehicle if you smell fuel fumes when the message **Safety mode See Owner's manual** is displayed in the instrument panel. Leave the vehicle immediately.

If safety mode has been set, it may be possible to reset the system in order to start and move the vehicle a short distance, for example, if it is blocking traffic.

Never attempt to perform repairs or reset electrical components on your own after the vehicle has been in safety mode. This could result in injury or prevent the vehicle from functioning properly. Volvo recommends having the vehicle inspected and reset to normal operating status by an authorized Volvo workshop after **Safety mode See Owner's manual** has been displayed.

MARNING

When the vehicle is in safety mode, it should not be towed behind another vehicle. It should be towed from the site on a tow truck. Volvo recommends towing the vehicle directly to an authorized Volvo workshop.

Related information

- Safety (p. 42)
- Starting and moving the vehicle when it is in safety mode (p. 62)
- Recovery (p. 455)

Starting and moving the vehicle when it is in safety mode

If safety mode has been set, it may be possible to reset the system in order to start and move the vehicle a short distance, for example, if it is blocking traffic.

Starting the vehicle when it is in safety mode

 Check the vehicle for damage, particularly for fuel leakage. Make sure you do not detect any gasoline fumes.

If the damage to the vehicle is minor and there is no fuel leakage/fumes, you may attempt to start the engine.

♠ WARNING

Never attempt to restart the vehicle if you smell fuel fumes when the message **Safety mode See Owner's manual** is displayed in the instrument panel. Leave the vehicle immediately.

2. Switch off the ignition.

- 3. Then try to start the vehicle.
 - The vehicle's electrical system will perform a system check and then attempt to reset to normal operating mode.

(!) CAUTION

If the message **Safety mode See Owner's manual** is still displayed, the vehicle should not be driven or towed behind another vehicle. If the vehicle needs to be moved, it must be towed on a tow truck. Even if no damage is apparent, there may be hidden damage that could make the vehicle impossible to control.

Moving the vehicle when it is in safety mode

- If the message Normal mode The vehicle is now in normal mode is displayed after attempting to start the engine, the vehicle may be moved carefully from its present position if, for example, it is blocking traffic.
- 2. Do not move the vehicle farther than absolutely necessary.

MARNING

When the vehicle is in safety mode, it should not be towed behind another vehicle. It should be towed from the site on a tow truck. Volvo recommends towing the vehicle directly to an authorized Volvo workshop.

Related information

- Safety mode (p. 61)
- Starting the vehicle (p. 404)
- Recovery (p. 455)

Child safety

Children should always be seated safely when traveling in the vehicle.

General information

Volvo recommends the proper use of restraint systems for all occupants including children. Remember that, regardless of age and size, a child should always be properly restrained in a vehicle.

Your vehicle is also equipped with ISOFIX/ LATCH attachments, which make it more convenient to install child seats.

Some restraint systems for children are designed to be secured in the vehicle by lap belts or the lap portion of a lap-shoulder belt. Such child restraint systems can help protect children in vehicles in the event of an accident only if they are used properly. However, children could be endangered in a crash if the child restraints are not properly secured in the vehicle. Failure to follow the installation instructions for your child restraint can result in your child striking the vehicle's interior in a sudden stop.

Holding a child in your arms is NOT a suitable substitute for a child restraint system. In an accident, a child held in a person's arms can be crushed between the vehicle's interior and an unrestrained person. The child could also be injured by striking the interior, or by being ejected from the vehicle during a sudden maneuver or

impact. The same can also happen if the infant or child rides unrestrained on the seat. Other occupants should also be properly restrained to help reduce the chance of injuring or increasing the injury of a child.

All states and provinces have legislation governing how and where children should be carried in a vehicle. Find out the regulations existing in your state or province. Recent accident statistics have shown that children are safer in rear seating positions than front seating positions when properly restrained. A child restraint system can help protect a child in a vehicle. Here's what to look for when selecting a child restraint system:

It should have a label certifying that it meets applicable Federal Motor Vehicle Safety Standards (FMVSS 213) - or in Canada, CMVSS 213.

Make sure the child restraint system is approved for the child's height, weight and development - the label required by the standard or regulation, or instructions for infant restraints, typically provide this information.

In using any child restraint system, we urge you to carefully look over the instructions that are provided with the restraint. Be sure you understand them and can use the device properly and safely in this vehicle. A misused child restraint system can result in increased injuries for both the infant or child and other occupants in the vehicle.

When a child has outgrown the child safety seat, you should use the rear seat with the standard seat belt fastened. The best way to help protect the child here is to place the child on a cushion so that the seat belt is properly located on the hips. Legislation in your state or province may mandate the use of a child seat or cushion in combination with the seat belt, depending on the child's age and/or size. Please check local regulations.

A specially designed and tested booster cushion and backrest can be obtained from your Volvo retailer. See also the article "Integrated booster cushion."



- Do not use child safety seats or child booster cushions/backrests in the front passenger's seat. We also recommend that children under 140 cm (4 feet 7 inches) in height who have outgrown these devices sit in the rear seat with the seat belt fastened.
- On hot days, the temperature in the vehicle interior can rise very quickly. Exposure to these high temperatures for even a short period of time can cause heat-related injury or death. Small children are particularly at risk. Never leave children unattended in a vehicle.

Child seats should always be registered.

Volvo's recommendations

Why does Volvo believe that no child should sit in the front seat of a vehicle? It's quite simple really. A front airbag is a very powerful device designed, by law, to help protect an adult.

Because of the size of the airbag and its speed of inflation, a child should never be placed in the front seat, even if he or she is properly belted or strapped into a child safety seat. Volvo has been an innovator in the field of safety since it was founded. And we have no intention of resting on our laurels. But we need your help. Please

remember to put your children in the back seat, and buckle them up.

A child restraint should never be reused if:

- The vehicle has been involved in a collision, no matter how minor
- Its history is unknown
- It is older than the manufacturer's expiration date

Volvo has some very specific recommendations

- Always wear your seat belt.
- Airbags are a SUPPLEMENTAL safety device which, when used with a three-point seat belt can help reduce serious injuries during certain types of accidents. Volvo recommends that you do not disconnect the airbag system in your vehicle.
- Volvo strongly recommends that everyone in the vehicle be properly restrained.
- Volvo recommends that ALL occupants (adults and children) shorter than 140 cm (4 feet 7 inches) be seated in the rear seat of any vehicle with a front passenger side airbag.
- Drive safely!

Related information

- Safety (p. 42)
- Child restraints (p. 65)
- Activating and deactivating child safety locks (p. 257)

Child restraints

Suitable child restraints should always be used when children travel in the vehicle.


Child restraint systems



Infant seat

There are three main types of child restraint systems: infant seats, convertible seats and booster cushions. They are classified according to the child's age and size.

The child restraint should be secured using a three-point seat belt, ISOFIX/LATCH anchors or top tether anchors.



Convertible seat

A child seat should never be used in the front passenger seat of any vehicle with a front passenger airbag - not even if the "Passenger airbag off" symbol near the rear-view mirror is illuminated. If the severity of an accident were to cause the airbag to inflate, this could lead to serious injury or death to a child seated in this position.



Booster cushion

. WARNING

Always refer to the child restraint manufacturer's instructions for detailed information on securing the restraint.

- When not in use, keep the child restraint system secured or remove it from the passenger compartment to help prevent it from injuring passengers in the event of a sudden stop or collision.
- A small child's head represents a considerable part of its total weight and its neck is still very weak. Volvo recommends that children up to age 4 travel, properly restrained, facing rearward. In addition, Volvo recommends that children should ride rearward facing, properly restrained, as long as possible.

Automatic Locking Retractor/ Emergency Locking Retractor (ALR/ ELR)

To make child seat installation easier, each seat belt (except for the driver's belt) is equipped with a locking mechanism to help keep the seat belt taut.

When attaching the seat belt to a child seat:

- Attach the seat belt to the child seat according to the child seat manufacturer's instructions.
- 2. Pull the seat belt out as far as possible.
- 3. Insert the seat belt latch plate into the buckle (lock) in the usual way.

 Release the seat belt and pull it taut around the child seat.

A sound from the seat belt retractor will be audible at this time and is normal. The belt will now be locked in place. This function is automatically disabled when the seat belt is unlocked and the belt is fully retracted.

↑ WARNING

Do not use child safety seats or child booster cushions/backrests in the front passenger's seat. We also recommend that children who have outgrown these devices sit in the rear seat with the seat belt properly fastened.

Child restraint registration and recalls

Child restraints could be recalled for safety reasons. You must register your child restraint to be reached in a recall. To stay informed about child safety seat recalls, be sure to fill out and return the registration card that comes with new child restraints.

Child restraint recall information is readily available in both the U.S. and Canada. For recall information in the U.S., call the U.S. Government's Auto Safety Hotline at 1-800-424-9393 or go to http://www-odi.nhtsa.dot.gov/cars/problems/recalls/register/childseat/index.cfm. In Canada, visit Transport Canada's Child Safety website at http://www.tc.gc.ca/roadsafety/childsafety/menu.htm.

Related information

- Child safety (p. 63)
- Infant seats (p. 67)
- Convertible seats (p. 69)
- Booster cushions (p. 71)
- Integrated booster cushion* (p. 76)
- Top tether anchors (p. 72)
- Lower child seat attachment points (p. 74)
- ISOFIX/LATCH lower anchors (p. 74)

Infant seats

Suitable child restraints should always be used when children (depending on their age/size) are seated in the vehicle.

Securing an infant seat with a seat belt



Do not place the infant seat in the front passenger's seat

- 1. Place the infant seat in the rear seat of the vehicle.
- 2. Attach the seat belt to the infant seat according to the child restraint manufacturer's instructions.



Route the seat belt through the infant seat.

WARNING

- An infant seat must be in the rear-facing position only.
- The infant seat should not be positioned behind the driver's seat unless there is adequate space for safe installation.

M WARNING

A child seat should never be used in the front passenger seat of any vehicle with a front passenger airbag - not even if the "Passenger airbag off" symbol near the rear-view mirror is illuminated. If the severity of an accident were to cause the airbag to inflate, this could lead to serious injury or death to a child seated in this position.

3.



Fasten the seat belt.

Fasten the seat belt by inserting the latch plate into the buckle (lock) until a distinct click is audible.



Pull out the shoulder section of the seat belt.

 Pull the shoulder section of the seat belt out as far as possible to activate the belt's automatic locking function.

i NOTE

The locking retractor will automatically release when the seat belt is unbuckled and allowed to retract fully.

5. Press the infant seat firmly in place, let the seat belt retract and pull it taut. A sound from the seat belt retractor's automatic locking function will be audible at this time and is normal. The seat belt should now be locked in place.



Check that the infant seat is properly secured.

Press and pull the infant seat along the direction of the seat belt to check that it is properly held in place by the seat belt.

⚠ WARNING

It should not be possible to move the child restraint more than 2.5 cm (1 in.) in any direction along the seat belt path.

The infant seat can be removed by unbuckling the seat belt and letting it retract completely.

Related information

- Child restraints (p. 65)
- Convertible seats (p. 69)
- Booster cushions (p. 71)
- Top tether anchors (p. 72)
- Lower child seat attachment points (p. 74)
- ISOFIX/LATCH lower anchors (p. 74)

Convertible seats


Suitable child restraints should always be used when children (depending on their age/size) are seated in the vehicle.

Securing a convertible seat with a seat belt



Do not place the convertible seat in the front passenger's seat.

Convertible seats can be used in either a forward or rearward-facing position, depending on the age and size of the child.



Route the seat belt through the convertible seat.

↑ WARNING

Always use a convertible seat that is suitable for the child's age and size. See the convertible seat manufacturer's recommendations.

 Place the convertible seat in the rear seat of the vehicle.

- A small child's head represents a considerable part of its total weight and its neck is still very weak. Volvo recommends that children up to age 4 travel, properly restrained, facing rearward. In addition, Volvo recommends that children should ride rearward facing, properly restrained, as long as possible.
- Convertible child seats should be installed in the rear seat only.
- A rear-facing convertible seat should not be positioned behind the driver's seat unless there is adequate space for safe installation.
- Attach the seat belt to the convertible seat according to the child restraint manufacturer's instructions.



Fasten the seat belt.

- Fasten the seat belt by inserting the latch plate into the buckle (lock) until a distinct click is audible.
- Pull the shoulder section of the seat belt out as far as possible to activate the belt's automatic locking function.

i NOTE

The locking retractor will automatically release when the seat belt is unbuckled and allowed to retract fully.

5. Press the convertible seat firmly in place, let the seat belt retract and pull it taut. A sound from the seat belt retractor's automatic locking function will be audible at this time and is normal. The seat belt should now be locked in place.



Pull out the shoulder section of the seat belt.

Push and pull the convertible seat along the seat belt path to ensure that it is held securely in place by the seat belt.

MARNING

It should not be possible to move the child restraint more than 2.5 cm (1 in.) in any direction along the seat belt path.

The convertible seat can be removed by unbuckling the seat belt and letting it retract completely.



Ensure that the convertible seat is securely in place.

A child seat should never be used in the front passenger seat of any vehicle with a front passenger airbag - not even if the "Passenger airbag off" symbol near the rear-view mirror is illuminated. If the severity of an accident were to cause the airbag to inflate, this could lead to serious injury or death to a child seated in this position.

Related information

- Child restraints (p. 65)
- Infant seats (p. 67)
- Booster cushions (p. 71)
- Top tether anchors (p. 72)
- Lower child seat attachment points (p. 74)
- ISOFIX/LATCH lower anchors (p. 74)

Booster cushions

Suitable child restraints should always be used when children (depending on their age/size) are seated in the vehicle.

Securing a booster cushion



Position the child correctly on the booster cushion.

Booster cushions are recommended for children who have outgrown convertible seats.

- Place the booster cushion in the rear seat of the vehicle.
- With the child properly seated on the booster cushion, attach the seat belt to or around the cushion according to the manufacturer's instructions.

SAFETY

3. Fasten the seat belt by inserting the latch plate into the buckle (lock) until a distinct click is audible.



Positioning the seat belt.

4. Ensure that the seat belt is pulled taut and fits snugly around the child.

⚠ WARNING

- The hip section of the three-point seat belt must fit snugly across the child's hips, not across the stomach.
- The shoulder section of the three-point seat belt should be positioned across the chest and shoulder.
- The shoulder belt must never be placed behind the child's back or under the arm.


Related information

- Child restraints (p. 65)
- Convertible seats (p. 69)
- Infant seats (p. 67)
- Top tether anchors (p. 72)
- Lower child seat attachment points (p. 74)
- ISOFIX/LATCH lower anchors (p. 74)

Top tether anchors

Your Volvo is equipped with child restraint top tether anchorages for all three seating positions in the rear seat. They are located on the rear side of the backrests.

Child restraint anchorages



Top tether anchors and symbols on the rear side of the second row backrests. There is no symbol for the center anchor position.

Securing a child seat

- 1. Place the child restraint on the rear seat.
- 2. Route the top tether strap under the head restraint and attach it to the anchor.
- Attach the strap for the lower tether anchors in the lower ISOFIX/LATCH attachment points. If the child restraint is not equipped with straps for the lower tether anchors, or if the child restraint is used on the center seating position, follow the instructions for attaching a child restraint using the automatic locking seat belt.
- 4. Firmly tension all straps.

Refer also to the child seat manufacturer's instructions for information on securing the child seat.



NOTE

On models equipped with the optional cargo area cover, this cover should be removed before a child seat is attached to the child restraint anchors.

↑ WARNING

- Always refer to the recommendations made by the child restraint manufacturer.
- Volvo recommends that the top tether anchors be used when installing a forward-facing child restraint.
- Never route a top tether strap over the top of the head restraint. The strap should be routed beneath the head restraint.
- Child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used for adult seat belts or harnesses. The anchorages are not able to withstand excessive forces on them in the event of collision if full harness seat belts or adult seat belts are installed to them. An adult who uses a belt anchored in a child restraint anchorage runs a great risk of suffering severe injuries should a collision occur.
- Do not install rear speakers that require the removal of the top tether anchors or interfere with the proper use of the top tether strap.

Related information

- Child restraints (p. 65)
- Lower child seat attachment points (p. 74)


ISOFIX/LATCH lower anchors (p. 74)

Lower child seat attachment points

The vehicle is equipped with lower child restraint attachment points in the second row of seats. The lower child seat attachment points are intended for use with certain rear-facing child restraints.

Always follow the manufacturer's installation instructions when attaching a child seat to the lower child seat attachment points.

Location of child seat attachment points



Location of the child seat attachment points in the second row of seats.

The child seat attachment points in the second row of seats are located on the rear section of the front seat floor rails.

Related information

- Child restraints (p. 65)
- Top tether anchors (p. 72)
- ISOFIX/LATCH lower anchors (p. 74)

ISOFIX/LATCH lower anchors

Lower anchors for ISOFIX/LATCH-equipped child seats are located in the second row, outboard seats, hidden below the backrest cushions.

Using the ISOFIX/LATCH lower child seat anchors



Location of the ISOFIX/LATCH anchors

Symbols on the seat back upholstery mark the ISOFIX/LATCH anchor positions as shown. To access the anchors, kneel on the seat cushion and locate the anchors by feel. Always follow your child seat manufacturer's installation instructions, and use both ISOFIX/LATCH lower anchors and top tethers whenever possible.


To access the anchors

- 1. Put the child restraint in position.
- Kneel on the child restraint to press down the seat cushion and locate the anchors by feel.
- Fasten the attachment on the child restraint's lower straps to the ISOFIX/LATCH lower anchors.
- 4. Firmly tension the lower child seat straps according to the manufacturer's instructions.

Volvo's ISOFIX/LATCH anchors conform to FMVSS/CMVSS standards. Always refer to the child restraint system's manual for weight and size ratings.

(i) NOTE

- The rear center seat is not equipped with ISOFIX/LATCH lower tether anchors. If a child restraint is used in this seat, attach the restraint's upper anchor strap (if equipped with these) to the top tether anchor point for this strap and secure the child restraint with the vehicle's center seat belt.
- Always follow your child seat manufacturer's installation instructions, and use both ISOFIX/LATCH lower anchors and top tethers whenever possible.



Fasten the attachment correctly to the ISOFIX/LATCH lower anchors

↑ WARNING

- Be sure to fasten the attachment correctly to the anchor (see the illustration).
 If the attachment is not correctly fastened, the child restraint may not be properly secured in the event of a collision.
- The ISOFIX/LATCH lower child restraint anchors are only intended for use with child seats positioned in the outboard seating positions. These anchors are not certified for use with any child restraint that is positioned in the center seating position. When securing a child restraint in the center seating position, use only the vehicle's center seat belt.

Related information

- Child restraints (p. 65)
- Top tether anchors (p. 72)
- ISOFIX/LATCH lower anchors (p. 74)

Integrated booster cushion*1

The integrated booster cushion in the second row center seating position helps ensure that a child can sit comfortably and safely.

The integrated booster cushion has been specially designed to help safeguard children in the rear seat when used with the vehicle's seat belts.

If using a booster cushion does not result in proper positioning of the shoulder strap, then the child should be placed in a properly secured child restraint. The shoulder belt must never be placed behind the child's back or under the arm.

Only used for children in the weight range 15-36 kg (33-80 lbs) and height range 97-137 cm (38-54 inches).

In Canada: 18 kg (40 lbs) is the minimum weight requirement for a child using booster cushions according to the Canadian regulation CMVSS 213.4



Correct seating position: the seat belt is positioned across the collarbone.

Before driving, make sure that:

- the booster cushion is locked into position
- the head restraint is set to the same height as the child's head, so that, if possible, the entire back of the child's head is covered
- the seat belt is taut, in contact with the child's body and not twisted
- the seat belt is not positioned across the child's throat or below the shoulder
- the lap section of the seat belt is placed low over the child's hips to provide the best protection.

DEATH or SERIOUS INJURY can occur

- Follow all instructions on this child restraint and in the vehicle's owner's manual.
- Make sure the booster cushion is securely locked before the child is seated.
- Only use for children who weigh between 15-36 kg (33-80 lbs) and who are between 97-137 cm (38-54 tum) in height. In Canada: 18 kg (40 lbs) is the minimum weight requirement for a child using booster cushions according to the Canadian regulation CMVSS 213.4
- Use only the vehicle's lap and shoulder belt system when restraining the child in this booster cushion.
- In the event of a collision while the integrated booster cushion was occupied, the entire booster cushion and seat belt must be replaced. The booster cushion should also be replaced if it is badly worn or damaged in any way. This work should be performed by a trained and qualified Volvo service technician only.

76 *Option/accessory.


¹ Canada only: This cushion may be referred to as a built-in booster cushion.

Related information


- Child restraints (p. 65)
- Folding up the integrated booster cushion* (p. 77)
- Folding down the integrated booster cushion* (p. 78)

Folding up the integrated booster cushion*

When the integrated booster cushion is used, it must be folded up.



Pull the handle forward and upward to release the booster cushion.



Press the booster cushion rearward to lock it into position.

DEATH or SERIOUS INJURY can occur

- Follow all instructions on this child restraint and in the vehicle's owner's manual.
- Make sure the booster cushion is securely locked before the child is seated.
- Only use for children who weigh between 15-36 kg (33-80 lbs) and who are between 97-137 cm (38-54 tum) in height. In Canada: 18 kg (40 lbs) is the minimum weight requirement for a child using booster cushions according to the Canadian regulation CMVSS 213.4
- Use only the vehicle's lap and shoulder belt system when restraining the child in this booster cushion.
- In the event of a collision while the integrated booster cushion was occupied, the entire booster cushion and seat belt must be replaced. The booster cushion should also be replaced if it is badly worn or damaged in any way. This work should be performed by a trained and qualified Volvo service technician only.

Related information

- Integrated booster cushion* (p. 76)
- Folding down the integrated booster cushion* (p. 78)


Folding down the integrated booster cushion*

When the integrated booster cushion in the rear seat is not in use, it should be stowed (folded down).



Pull the handle forward to release the booster cushion.

78 * Option/accessory.



Press down on the center of the booster cushion to lock it into position.

! CAUTION

Make sure that there are no objects (e.g. toys) on the seat under the integrated booster cushion before folding it down.

i NOTE

The integrated booster cushion must be stowed (folded down) before folding down the seat backrest.

↑ WARNING

DEATH or SERIOUS INJURY can occur

- Follow all instructions on this child restraint and in the vehicle's owner's manual.
- Make sure the booster cushion is securely locked before the child is seated.
- Only use for children who weigh between 15-36 kg (33-80 lbs) and who are between 97-137 cm (38-54 tum) in height. In Canada: 18 kg (40 lbs) is the minimum weight requirement for a child using booster cushions according to the Canadian regulation CMVSS 213.4
- Use only the vehicle's lap and shoulder belt system when restraining the child in this booster cushion.
- In the event of a collision while the integrated booster cushion was occupied, the entire booster cushion and seat belt must be replaced. The booster cushion should also be replaced if it is badly worn or damaged in any way. This work should be performed by a trained and qualified Volvo service technician only.

Related information

- Integrated booster cushion* (p. 76)
- Folding up the integrated booster cushion* (p. 77)



Instruments and controls in lefthand drive vehicles

The overviews show the location of the vehicle's displays and controls.

Steering wheel and dashboard



- Parking lights, daytime running lights, low beams, high beams, turn signals, front fog lights/cornering illumination*, rear fog light, trip computer reset
- Steering wheel paddles for manual shifting*
- 3 Head-up display*
- Instrument panel
- 6 Wipers and washers, rain sensor*
- 6 Right-side steering wheel keypad
- Steering wheel adjustment

- 8 Horn
- Left-side steering wheel keypad
- 10 Hood open
- Display lighting, tailgate unlock/open*/close*, halogen headlight height adjustment

Ceiling console



- Front reading lights and courtesy lighting
- Panoramic roof*
- 3 Ceiling console display
- 4 HomeLink®*

Center and tunnel console



- Center display
- Hazard warning flashers, defrosting, media, glove compartment open
- Gear selector
- Start knob
- 6 Drive modes*
- Parking brake
- Auto-hold brakes

Driver's door

*Option/accessory.



- 1 Memory for power front seat settings*, door mirrors and head-up display*
- Central locking
- Power windows, door mirrors, electric child safety locks*
- Controls for front seat

Related information

- Manual front seats (p. 188)
- Adjusting the power front seats* (p. 189)
- Adjusting the steering wheel (p. 203)
- Lighting panel and controls (p. 154)
- Starting the vehicle (p. 404)
- Instrument panel (p. 84)
- Center display overview (p. 111)
- Transmission (p. 417)

Instrument panel

The instrument panel displays information related to the vehicle and driving.

The instrument panel contains gauges, indicators and monitoring and warning symbols. What is shown in the instrument panel varies depending on the equipment, settings and functions currently active.

The instrument panel is activated as soon as a door is opened, i.e. in ignition mode **0**. The panel will power down after a short period of time if it is not used. To reactivate it, do one of the following:

- Depress the brake pedal.
- Activate ignition mode I.
- Open one of the doors.

The instrument panel is available in two versions: 12"* and 8".

\triangle

WARNING

If the instrument panel is not functioning properly, information about brakes, airbags or other safety-related systems may not be displayed. The driver will then not be able to check the status of the vehicle systems or receive relevant warnings and information.



WARNING

If the instrument panel turns off, does not activate when the ignition is switched on, or part/all of the panel cannot be read, do not drive the vehicle. Consult a workshop immediately. Volvo recommends an authorized Volvo workshop.





Location in the instrument panel:

Left side	In the center	Right side
Speedometer	Indicator and warning symbols	Tachometer/ECO gauge ^A
Trip odometer	Ambient temperature sensor	Gear indicator
Odometer ^B	Clock	Drive Mode
Cruise control/speed limiter information	Message (also graphics in some cases)	Fuel gauge
Road sign information*	Door and seat belt status	Start/Stop function's status
-	Media player	Distance to empty tank

*Option/accessory.

Left side	In the center	Right side
-	Navigation system map	Current fuel consumption
-	Phone	App menu (activated using steering wheel keypad)
-	Voice Control	-
-	Compass ^A	-

A Depends on selected drive mode. B Total distance.

Instrument panel 8"



Location in the instrument panel:

Left side	In the center	Right side
Fuel gauge	Speedometer	Media player
Drive Mode	Road sign information*	Phone

44

Left side	In the center	Right side
Gear indicator	Cruise control/speed limiter information	Navigation information
Tachometer/ECO gauge ^A	Door and seat belt status	Clock
Distance to empty tank	Start/Stopp function's status	App menu (activated using steering wheel keypad)
Ambient temperature sensor	-	Current fuel consumption
Indicator and warning symbols	-	Odometer ^B
-	-	Trip odometer
-	-	Indicator and warning symbols
-	-	Voice Control
-	-	Engine temperature gauge
-	-	Message (also graphics in some cases)
-	-	Compass ^A

A Depends on selected drive mode. B Total distance.

Dynamic symbol



Dynamic symbol in basic mode.

the type of message displayed. The severity of the control or warning symbol is indicated by an amber or red marking around the symbol. An animation may be used to change the symbol into a larger image in order to graphically depict the location of a problem or to clarify information.

In the center of the instrument panel is a dynamic symbol that changes appearance according to



Example with indicator symbol.

Related information

- Instrument panel settings (p. 88)
- Warning symbols in the instrument panel (p. 97)
- Indicator symbols in the instrument panel (p. 95)
- Trip computer (p. 89)
- Messages in the instrument panel (p. 106)
- Handling the App menu in the instrument panel (p. 105)

Instrument panel settings

Display settings for the instrument panel can be set in the instrument panel's app menu and in the center display's Settings menu.

Settings in instrument panel's app menu

The app menu can be used to set what information will be displayed in the instrument panel:

- trip computer
- media player
- phone
- navigation system*.

Center display settings

Selecting type of information

- Tap **Settings** in the center display's Top view.
- Tap My Car → Displays → Driver Display Information.
- 3. Select a background:
 - Show no information in the background
 - Show information for current playing media
 - Show navigation even if no route is set¹.

Select theme

- 1. Tap **Settings** in the center display's Top view.
- Tap My Car → Displays → Display
 Themes
- 3. Select a theme (appearance) for the instrument panel:
 - Glass
 - Minimalistic
 - Performance
 - · Chrome Rings.

Select language

- Tap Settings in the center display's Top view.
- Tap System → System Languages and Units → System Language to select language.
 - > A change made here will affect the language in all displays.

The settings are personal and saved automatically in the active driver profile.

Related information

- Instrument panel (p. 84)
- Handling the App menu in the instrument panel (p. 105)

*Option/accessory.

Changing settings in the center display (p. 136)

¹ The map is only shown with the 12" instrument panel*. With the 8" instrument panel, only guidance is shown.

Fuel gauge

The fuel gauge in the instrument panel shows the fuel level in the tank.



Fuel gauge in 12" instrument panel:

The beige area in the fuel gauge indicates the amount of fuel left in the tank.

When the fuel level is low and it is time to refuel, the fuel pump symbol will illuminate with an amber-colored light. The trip computer also indicates the approximate distance driven on the fuel remaining in the tank.



Fuel gauge in 8" instrument panel:

The bars in the fuel gauge indicate the amount of fuel left in the tank.

When the fuel level is low and it is time to refuel, the fuel pump symbol will illuminate with an amber-colored light. The trip computer also indicates the approximate distance driven on the fuel remaining in the tank. When the fuel level is critically low, only an amber bar will be displayed. Refuel as soon as possible.

Related information

- Instrument panel (p. 84)
- Refueling (p. 442)
- Fuel tank volume (p. 646)

Trip computer

The vehicle's trip computer registers and calculates data while driving such as mileage, fuel consumption and average speed.

To help promote fuel-efficient driving, data is recorded on both current and average fuel consumption. Data from the trip computer can be displayed in the instrument panel.

44



12" instrument panel*.



8-inch instrument panel.

The trip computer includes the following gauges:

- Trip odometer
- Odometer
- Current fuel consumption

- Distance to empty tank
- Tourist alternative speedometer

Unit standards for distance, speed, etc. can be changed via system settings in the center display.

Trip odometer

There are two trip odometers: TM and TA.

TM can be reset manually and TA is reset automatically if the vehicle is not used for four hours.

During a drive, the trip odometer registers data on:

- Mileage
- Driving time
- Average speed
- Average fuel consumption

The readings since the trip odometer's last reset are displayed.

Odometer

The odometer records the vehicle's total mileage. This reading cannot be reset.

Current fuel consumption

This gauge shows the vehicle's fuel consumption at that moment. The reading is updated about once a second.

Distance to empty tank

The trip computer calculates the distance that can be driven on the fuel remaining in the tank.

This calculation is based on average fuel consumption during the last 30 km (20 miles) and the amount of fuel remaining in the tank.

When the gauge displays "----", there is not enough fuel remaining to calculate the remaining mileage. Refuel as soon as possible.



NOTE

This may vary if your driving style changes.

An economical driving style will generally increase how far you can drive on a certain amount of fuel.

Tourist - alternative speedometer

The alternative digital speedometer makes it easier to drive in countries where speed limit signs are shown in a different measurement unit than the one shown in the vehicle's gauges.

When used, the digital speed is displayed in the opposite unit to that shown in the analog speed-ometer. If **mph** is used in the analog speedometer, the equivalent speed in **km/h** will be shown in the digital speedometer.

Related information

- Displaying trip data in the instrument panel (p. 91)
- Resetting the trip odometer (p. 92)

- Displaying trip statistics in the center display (p. 92)
- Instrument panel (p. 84)

Displaying trip data in the instrument panel

Data recorded and calculated by the trip computer can be displayed on the instrument panel. This data is stored in a trip computer app. You can choose which information the instrument panel will display in the app menu.



Open and navigate in the app menu² using the righthand steering wheel keypad.

- App menu
- Left/right
- Op/down
- 4 Confirm

- 1. Open the app menu in the instrument panel by pressing (1).
 - (The App menu cannot be opened while there is an unacknowledged message in the instrument panel. The message must be confirmed before the App menu can be opened.)
- 2. Navigate to the trip computer app by moving left or right using (2).
 - > The top four menu rows show measured values for trip odometer TM. The next four menu rows show measured values for trip odometer TA. Scroll up or down in the list using (3).
- 3. Scroll down to the option buttons to choose which information to show in the instrument panel:
 - Distance to empty tank
 - Odometer
 - Mileage for trip odometer TM, TA or no display of mileage
 - Current fuel consumption, average fuel consumption for TM or TA, or no display of fuel consumption
 - Tourist (alternative speedometer).

Select or clear a selection using the **O** button (4). The change will apply immediately.

² The illustration is generic - details may vary according to vehicle model.

Related information

- Trip computer (p. 89)
- Resetting the trip odometer (p. 92)

Resetting the trip odometer

Resetting the trip odometer using the left-side steering wheel lever.



 Reset all information in trip odometer TM (i.e. mileage, average fuel consumption, average speed and driving time) by pressing and holding the RESET button on the left-hand steering wheel lever.

Tapping the **RESET** button only resets the distance driven.

The TA trip odometer can not be manually reset. It resets automatically if the vehicle is not used for four hours or more.

Related information

• Trip computer (p. 89)

Displaying trip statistics in the center display

Trip computer statistics can be displayed graphically in the center display, providing an overview that facilitates more fuel-efficient driving.



Open the **Driver performance** app in the App view to display trip statistics.

Each bar in the graph represents a driving distance of 1 kilometers, 10 kilometers or

100 kilometers (or miles). The bars are added from the right as you drive. The bar at the far right shows the data for the current trip.

Average fuel consumption and total driving time are calculated from the most recent reset of the trip statistics.



Trip computer statistics³.

Related information

- Trip statistics settings (p. 93)
- Trip computer (p. 89)

Trip statistics settings

Trip statistics settings can be reset or adjusted.

 Open the **Driver performance** app in the App view to display trip statistics.



2. Tap Preferences to

- change the graph scale. Select 1, 10 or 100 km/miles for the bar.
- reset data after each trip. Performed when the vehicle remains stationary for more than 4 hours.
- reset data for current trip.

Trip statistics, calculated average consumption, and total driving time are always reset simultaneously.

Unit standards for distance, speed, etc. can be changed via system settings in the center display.

Related information

- Displaying trip statistics in the center display (p. 92)
- Trip computer (p. 89)

• Resetting the trip odometer (p. 92)

³ The illustration is generic - details may vary according to vehicle model.

Date and time

The clock is displayed in both the instrument panel and the center display.

Location of clock



Location of clock in 12" and 8" instrument panels.

In the center display, the clock is located at the top right of the status bar.

Certain messages and other information may obscure the clock in the instrument panel.

Time and date settings

 Select Settings → System → Date and Time in the center display's Top view to change settings for time and date format.

Adjust the time and date by tapping the up or down arrows on the touchscreen.

Automatic time for vehicles with GPS

When the vehicle is equipped with a navigation system, **Auto Time** is also available. The time zone will then be automatically set to the vehicle's location. In some navigation systems, the current location must also be set to determine the correct time zone. If **Auto Time** is not selected, the time and date can be adjusted using the up and down arrows on the touchscreen.

Daylight savings time

In some countries, an automatic change to daylight savings time can be selected by activating **Auto**. For other countries, daylight savings time can be changed by selecting **On** or **Off**.

Related information

- Instrument panel (p. 84)
- Changing settings in the center display (p. 136)

Ambient temperature sensor

The ambient temperature is shown in the instrument panel.

The sensor detects the temperature outside the vehicle.



Location of the ambient temperature sensor in 12" and 8" instrument panels.

If the vehicle has been stationary, the sensor reading may be higher than the actual temperature.

When the ambient temperature is between -5 $^{\circ}$ C and +2 $^{\circ}$ C (23 and 36 $^{\circ}$ F), a snowflake symbol will be displayed in the instrument panel as a warning for possible slippery conditions.

The snowflake symbol is also temporarily lit in the head-up display if the vehicle is equipped with one.

To change the measurement standard for the temperature sensor and other readings, go to system settings in the center display's Top view.

Related information

- Instrument panel (p. 84)
- Changing system units of measurement (p. 134)

Indicator symbols in the instrument panel

The indicator symbols alert the driver that a function has been activated, that a system is running, or that a fault or error may have occurred.

Symbol	Meaning	
	Information, see the message in the display	
	The information symbol illuminates and a message is displayed in the instrument panel if one of the vehicle's systems requires the driver's attention. The information symbol may also illuminate in combination with other symbols.	
	Fault in brake system	
(!))	This symbol illuminates if there is a problem with the parking brake.	
А		
BRAKE		


Symbol	Meaning
(ABS)	Fault in ABS system If this symbol is illuminated, the ABS system is malfunctioning. The vehicle's regular brakes will still work, but without the ABS function.
ABS	
A PARK	Auto-brake on This symbol illuminates when the function is activated and the brakes or parking brakes are being used. The brakes hold the vehicle at a standstill after it has stopped.

•

Meaning Symbol Tire pressure system This symbol illuminates to indicate low tire pressure. If there is a fault in the tire pressure system, the symbol will first flash for approximately 1 minute and then glow steadily. This may occur if the system cannot detect or alert the driver of low tire pressure as intended. **Emission control system** If this symbol illuminates after starting the engine, it could indicate a fault in the vehicle's emission control system. Have the vehicle checked by a workshop. Volvo recommends contacting an authorized Volvo workshop. Left/right turn signals These symbols flash when the turn signals are used.

Symbol	Meaning	
$\overline{}$	Parking lights	
÷0 €	This symbol illuminates when the parking lights are on.	
، ماللام	Fault in headlight system	
	This symbol illuminates if a fault has been detected in the ABL (Active Bending Lights) function or another fault in the headlight system.	
— CA	Active high beams on	
	This symbol lights up in blue when the active high beams are on.	
	Active high beams off	
	This symbol lights up in white when the active high beams are off.	
	High beams on	
	This symbol illuminates when the high beams are on or flashed.	
= []	Active high beams on	
	This symbol lights up in blue when the active high beams are on. Park-	

ing lights are on.



Symbol Meaning Stability system This symbol flashes when the stability system is actively working to stabilize the vehicle. If the symbol glows steadily, there is a fault in the system. Stability system, Sport mode This symbol illuminates when Sport mode is activated. Sport mode offers a more active driving experi-

This symbol illuminates when Sport mode is activated. Sport mode offers a more active driving experience. If the system detects that accelerator pedal, steering wheel and cornering movements are more active than in normal driving, it allows a certain level of controlled lateral movement of the rear wheels before intervening and stabilizing the vehicle.



Lane Keeping Aid

White symbol: Lane Keeping Aid is on and lane marker lines are detected.

Gray symbol: Lane Keeping Aid is on but no lane marker lines are detected.

Amber symbol: Lane Keeping Aid is alerting/intervening.

Symbol Meaning Lane Keeping Aid and rain



Lane Keeping Aid and rain sensor

White symbol: Lane Keeping Aid is on and lane marker lines are detected. The rain sensor is on. Gray symbol: Lane Keeping Aid is

Gray symbol: Lane Keeping Aid on but no lane marker lines are detected. The rain sensor is on.

A Canadian models. B US models.

Related information

- Instrument panel (p. 84)
- Warning symbols in the instrument panel (p. 97)

Warning symbols in the instrument panel

The warning symbols alert the driver that an important function is activated or that a serious fault or error has occurred.

Symbol

Meaning WARNING



The red warning symbol illuminates to indicate that a fault has been detected that could affect safety and/or driveability. An explanatory message will be simultaneously displayed in the instrument panel. The warning symbol may also illuminate in combination with other symbols.



Seat belt reminder

This symbol will glow steadily or flash if the driver or front seat passenger has not fastened their seat belt or if anyone in the rear seat has removed their seat belt.

Symbol Meaning Airbags If this symbol remains illuminated or comes on while driving, a fault has been detected in one of the vehicle's safety systems. Read the message in the instrument panel. Volvo recommends contacting an authorized Volvo workshop. Fault in brake system If this symbol illuminates, the brake fluid level may be too low. Contact vour nearest authorized workshop to have the brake fluid level checked and adjusted. Parking brake on This symbol glows steadily when the parking brake is applied. A flashing symbol indicates that a

fault has occurred. Read the mes-

sage in the instrument panel.

Symbol Meaning Low oil pressure If this symbol illuminates while driving, the engine oil level is too low. Stop the engine immediately and check the engine oil level. Add oil if necessary. If the symbol illuminates and the oil level is normal, contact a workshop. Volvo recommends contacting an authorized Volvo workshop. Generator not charging This symbol illuminates during driving if a fault is detected in the electrical system. Contact a workshop. Volvo recommends contacting an authorized Volvo workshop. Collision risk City Safety warns the driver if there is a risk of a collision with another vehicle, pedestrian, cyclist or large animal.

Related information

- Indicator symbols in the instrument panel (p. 95)
- Instrument panel (p. 84)

Instrument panel licenses

A license is an agreement on the right to conduct a certain activity or the right to use someone else's right according to terms and conditions specified in the agreement. The following text is Volvo's agreement with the manufacturer or developer.

PARK

A Canadian models. B US models.

Boost Software License 1.0

Permission is hereby granted, free of charge, to any person or organization obtaining a copy of the software and accompanying documentation covered by this license (the "Software") to use. reproduce, display, distribute, execute, and transmit the Software, and to prepare derivative works of the Software, and to permit third-parties to whom the Software is furnished to do so, all subject to the following: The copyright notices in the Software and this entire statement, including the above license grant, this restriction and the following disclaimer, must be included in all copies of the Software, in whole or in part, and all derivative works of the Software, unless such copies or derivative works are solely in the form of machine-executable object code generated by a source language processor.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE AND NON-INFRINGEMENT. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR ANYONE DISTRIBUTING THE SOFTWARE BE LIABLE FOR ANY DAMAGES OR OTHER LIABILITY, WHETHER IN CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

BSD 4-clause "Original" or "Old" License

Copyright (c) 1982, 1986, 1990, 1991, 1993 The Regents of the University of California. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- All advertising materials mentioning features or use of this software must display the following acknowledgement: This product includes software developed by the University of California, Berkeley and its contributors.
- Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY

AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL. SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO. PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES: LOSS OF USE, DATA, OR PROFITS: OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY. WHETHER IN CONTRACT, STRICT LIABILITY. OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE. EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

SD 3-clause "New" or "Revised" License Copyright (c) 2011-2014. Yann Collet.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of the organisation nor the names of its contributors may be used to endorse or promote products derive from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR

SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

BSD 2-clause "Simplified" license

Copyright (c) <YEAR>, <OWNER> All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER

OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The views and conclusions contained in the software and documentation are those of the authors and should not be interpreted as representing official policies, either expressed or implied, of the FreeBSD Project.

FreeType Project License

1. 1 Copyright 1996-1999 by David Turner. Robert Wilhelm, and Werner Lemberg Introduction The FreeType Project is distributed in several archive packages; some of them may contain, in addition to the FreeType font engine, various tools and contributions which rely on, or relate to, the FreeType Project. This license applies to all files found in such packages, and which do not fall under their own explicit license. The license affects thus the FreeType font engine, the test programs, documentation and makefiles, at the very least. This license was inspired by the BSD, Artistic, and IJG (Independent JPEG Group) licenses, which all encourage inclusion and use of free software in commercial and freeware products alike. As a consequence, its main points are that: o We don't promise that this software works. However, we are be interested in any kind of bug reports, ('as is' distribution) o You can use this software for whatever you want, in parts or full form, without having to pay us. ('royalty-free' usage) o You may not pretend that you wrote this software. If you use it, or only parts of it, in a program, you must acknowledge somewhere in your documentation that you've used the FreeType code. (`credits') We specifically permit and encourage the inclusion of this software, with or without modifications, in commercial products,

provided that all warranty or liability claims are assumed by the product vendor. Legal Terms O. Definitions Throughout this license, the terms 'package', 'FreeType Project', and `FreeType archive' refer to the set of files originally distributed by the authors (David Turner, Robert Wilhelm, and Werner Lemberg) as the 'FreeType project', be they named as alpha, beta or final release, 'You' refers to the licensee, or person using the project, where 'using' is a generic term including compiling the project's source code as well as linking it to form a 'program' or `executable'. This program is referred to as `a program using the FreeType engine'. This license applies to all files distributed in the original FreeType archive, including all source code, binaries and documentation, unless otherwise stated in the file in its original, unmodified form as distributed in the original archive. If you are unsure whether or not a particular file is covered by this license, you must contact us to verify this. The FreeType project is copyright (C) 1996-1999 by David Turner, Robert Wilhelm, and Werner Lembera, All rights reserved except as specified below. 1. No Warranty THE FREETYPE ARCHIVE IS PROVIDED 'AS IS' WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED. INCLUDING, BUT NOT LIMITED TO. WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

- IN NO EVENT WILL ANY OF THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY DAMAGES CAUSED BY THE USE OR THE INABILITY TO USE, OF THE FREETYPE PROJECT. As you have not signed this license, you are not required to accept it. However, as the FreeType project is copyrighted material, only this license, or another one contracted with the authors, grants you the right to use, distributing, or modifying the FreeType project, you indicate that you understand and accept all the terms of this license.
- 2. Redistribution Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met: o Redistribution of source code must retain this license file ('licence.txt') unaltered; any additions, deletions or changes to the original files must be clearly indicated in accompanying documentation. The copyright notices of the unaltered, original files must be preserved in all copies of source files, o Redistribution in binary form must provide a disclaimer that states that the software is based in part of the work of the FreeType Team, in the distribution documentation. We also encourage you to put an URL to the FreeType web page in your documentation, though this isn't mandatory. These conditions apply to any software derived from or based

- on the FreeType code, not just the unmodified files. If you use our work, you must acknowledge us. However, no fee need be paid to us.
 - 3. Advertising The names of FreeType's authors and contributors may not be used to endorse or promote products derived from this software without specific prior written permission. We suggest, but do not require, that you use one or more of the following phrases to refer to this software in your documentation or advertising materials: `FreeType Project', `FreeType Engine', `FreeType library', or `FreeType Distribution'.
 - 4. Contacts There are two mailing lists related to FreeType: o freetype@freetype.org Discusses general use and applications of FreeType, as well as future and wanted additions to the library and distribution. If you are looking for support, start in this list if you haven't found anything to help you in the documentation. o devel@freetype.org Discusses bugs, as well as engine internals, design issues, specific licenses, porting, etc. o http://www.freetype.org Holds the current FreeType web page, which will allow you to download our latest development version and read online documentation. You can also contact us individually at: David Turner <david.turner@freetype.org> Robert Wilhelm <robert.wilhelm@freetype.org> Werner Lemberg <werner.lemberg@freetype.org>

Libpng License

This copy of the libpng notices is provided for your convenience. In case of any discrepancy between this copy and the notices in the file png.h that is included in the libpng distribution, the latter shall prevail.

COPYRIGHT NOTICE, DISCLAIMER, and LICENSE:

If you modify libpng you may insert additional notices immediately following this sentence.

libpng versions 1.0.7, July 1, 2000, through 1.0.13, April 15, 2002, are Copyright (c) 2000-2002 Glenn Randers-Pehrson and are distributed according to the same disclaimer and license as libpng-1.0.6 with the following individuals added to the list of Contributing Authors

Simon-Pierre Cadieux

Eric S. Raymond

Gilles Vollant

and with the following additions to the disclaimer:

There is no warranty against interference with your enjoyment of the library or against infringement. There is no warranty that our efforts or the library will fulfill any of your particular purposes or needs. This library is provided with all faults, and the entire risk of satisfactory quality, performance, accuracy, and effort is with the user.

libpng versions 0.97, January 1998, through 1.0.6, March 20, 2000, are Copyright (c) 1998, 1999 Glenn Randers-Pehrson, and are distributed according to the same disclaimer and license as libpng-0.96, with the following individuals added to the list of Contributing Authors:

Tom Lane

Glenn Randers-Pehrson

Willem van Schaik

libpng versions 0.89, June 1996, through 0.96, May 1997, are Copyright (c) 1996, 1997 Andreas Dilger Distributed according to the same disclaimer and license as libpng-0.88, with the following individuals added to the list of Contributing Authors:

John Bowler

Kevin Bracey

Sam Bushell

Magnus Holmgren

Greg Roelofs

Tom Tanner

libpng versions 0.5, May 1995, through 0.88, January 1996, are Copyright (c) 1995, 1996 Guy Eric Schalnat, Group 42, Inc. For the purposes of this copyright and license, "Contributing Authors" is defined as the following set of individuals:

Andreas Dilger

Dave Martindale

Guy Eric Schalnat

Paul Schmidt

Tim Wegner

The PNG Reference Library is supplied "AS IS". The Contributing Authors and Group 42, Inc. disclaim all warranties, expressed or implied, including, without limitation, the warranties of merchantability and of fitness for any purpose. The Contributing Authors and Group 42, Inc. assume no liability for direct, indirect, incidental, special, exemplary, or consequential damages, which may result from the use of the PNG Reference Library, even if advised of the possibility of such damage.

Permission is hereby granted to use, copy, modify, and distribute this source code, or portions hereof, for any purpose, without fee, subject to the following restrictions:

- The origin of this source code must not be misrepresented.
- Altered versions must be plainly marked as such and must not be misrepresented as being the original source.

 This Copyright notice may not be removed or altered from any source or altered source distribution.

The Contributing Authors and Group 42, Inc. specifically permit, without fee, and encourage the use of this source code as a component to supporting the PNG file format in commercial products. If you use this source code in a product, acknowledgment is not required but would be appreciated.

A "png_get_copyright" function is available, for convenient use in "about" boxes and the like: printf("%s",png_get_copyright(NULL));

Also, the PNG logo (in PNG format, of course) is supplied in the files "pngbar.png" and "pngbar.jpg (88x31) and "pngnow.png" (98x31).

Libpng is OSI Certified Open Source Software. OSI Certified Open Source is a certification mark of the Open Source Initiative.

Glenn Randers-Pehrson randeg@alum.rpi.edu April 15, 2002

MIT License

Copyright (c) <year> <copyright holders>

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

∢ zlib License

The zlib/libpng License Copyright (c) <year> <copyright holders>

This software is provided 'as-is', without any express or implied warranty. In no event will the authors be held liable for any damages arising from the use of this software.

Permission is granted to anyone to use this software for any purpose, including commercial applications, and to alter it and redistribute it freely, subject to the following restrictions:

- The origin of this software must not be misrepresented; you must not claim that you wrote the original software. If you use this software in a product, an acknowledgment in the product documentation would be appreciated but is not required.
- Altered source versions must be plainly marked as such, and must not be misrepresented as being the original software.
- 3. This notice may not be removed or altered from any source distribution.

SGI Free Software B License Version 2.0. SGI FREE SOFTWARE LICENSE B (Version 2.0, Sept. 18, 2008)

Copyright (C) [dates of first publication] Silicon Graphics, Inc. All Rights Reserved. Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions: The above copyright notice including the dates of first publication and either this permission notice or a reference to http://oss.sgi.com/projects/FreeB/ shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL SILICON GRAPHICS, INC. BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Except as contained in this notice, the name of Silicon Graphics, Inc. shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Software without prior written authorization from Silicon Graphics, Inc.

Related information

Instrument panel (p. 84)

App menu in instrument panel

The application menu (App menu) in the instrument panel provides quick access to commonly used functions for certain apps.



The App menu in the instrument panel can be used instead of the center display. The illustration is generic – layout may vary.

The App menu is displayed in the instrument panel and is controlled using the right-side steering wheel keypad. The app menu makes it easier to switch between different apps or functions within the apps without having to let go of the steering wheel.

App menu functions

Different apps provide access to different types of functions. The following apps and their functions can be controlled from the App menu:


Арр	Functions
Trip com- puter	Select a trip odometer, change instrument panel display settings, etc.
Media player	Select active source for media player.
Phone	Call a contact from the call list.
Navigation	Guide to destination, etc.

Related information

- Instrument panel (p. 84)
- Center display overview (p. 111)
- Handling the App menu in the instrument panel (p. 105)

Handling the App menu in the instrument panel

The App (application) menu in the instrument panel is controlled using the right-side steering wheel keypad.



App menu and right-side steering wheel keypad.

- 1 Open/close
- 2 Left/right
- 3 Up/down
- 4 Confirm

Opening and closing the app menu

- Tap open/close (1).

(The App menu cannot be opened while there is an unacknowledged message in the instrument panel. The message must be confirmed before the App menu can be opened.)

> The App men opens/closes.

The App menu turns off automatically after a period of inactivity or after certain selections are made.

Navigating and making selections in the App menu

- 1. Navigate among the apps available by pressing the left/right arrow keys (2).
 - > Functions for the previous/next app will be shown in the App menu.
- 2. Scroll through the functions for the selected app using the up or down arrows (3).
- 3. Confirm or make a selection for the function by pressing confirm (4).
 - > The function will be activated and, for some selections, the App menu will then close.

The next time the App menu is opened, the functions for the most recently selected app will be displayed automatically.

Related information

- App menu in instrument panel (p. 104)
- Messages in the instrument panel (p. 106)

Messages in the instrument panel

The instrument panel shows messages in certain circumstances to inform or assist the driver.



Message in the instrument panel⁴.



Message in the instrument panel⁵.

The messages may appear in different parts of the instrument panel depending on what other information is currently being displayed. The message will disappear from the instrument panel after a short period of time or after it has been acknowledged or any required action has been taken. Messages that need to be saved are stored in the **Car status** app, which can be opened from the App view in the center display.

The message may be shown along with graphics, symbols or buttons to e.g. acknowledge the message or accept a request.

High-priority messages for the driver are displayed in the instrument panel.

⁴ With 8" instrument panel.

⁵ With 12" instrument panel.

Service messages

The following table lists a selection of important service messages and what they mean.

Message	Meaning
Stop safely ^A	Stop and switch off the engine. Serious risk of damage - contact a workshop ^B .
Turn off engine ^A	Stop and switch off the engine. Serious risk of damage - contact a workshop ^B .
Service urgent Drive to work- shop ^A	Contact a workshop ^B to have the vehicle inspected immediately.
Service required ^A	Contact a workshop ^B to have the vehicle inspected as soon as possible.
Regular main- tenance Book time for maintenance	Time for service - contact a workshop ^B . Shown before the next service date.
Regular main- tenance	Time for service - contact a workshop ^B . Shown on the next service date.
tenance	

Message	Meaning
Regular main- tenance	Time for service - contact a workshop ^B . Shown when
Maintenance overdue	the date for service has passed.
Temporarily off ^A	A function has been tem- porarily deactivated and will be reactivated auto- matically while driving or after the engine is restar- ted.

A Part of message, shown along with information on the location of the problem.

B An authorized Volvo workshop is recommended.

Related information

- Handling messages in the instrument panel (p. 107)
- Handling messages saved from the instrument panel (p. 109)
- Messages in the center display (p. 142)

Handling messages in the instrument panel

Messages in the instrument panel are controlled using the right-side steering wheel keypad.

44



Messages in the instrument panel⁶ and the right-side steering wheel keypad.



Messages in the instrument panel⁷ and the right-side steering wheel keypad.

- 1 Left/right
- Confirm

Some messages in the instrument panel contain one or more buttons for e.g. confirming the message or accepting a request.

Handling new messages

For messages with buttons:

- 1. Navigate among the buttons available by pressing the left/right arrow keys (1).
- Confirm your selection by pressing confirm (2).
 - > The message will disappear from the instrument panel.

For messages without buttons:

- Close the message by pressing confirm (2) or let the message automatically time-out after a short period.
 - > The message will disappear from the instrument panel.

Messages that need to be saved are stored in the **Car status** app, which can be opened from the App view in the center display. The message **Car message stored in Car Status application** will simultaneously appear in the center display.

- Messages in the instrument panel (p. 106)
- Handling messages saved from the instrument panel (p. 109)
- Messages in the center display (p. 142)

⁶ With 8" instrument panel.

⁷ With 12" instrument panel.

Handling messages saved from the instrument panel

Messages saved from the instrument panel and center displays are handled in the center display.



Saved messages can be viewed in the Car Status app.



The messages displayed in the instrument panel that need to be saved are stored in the **Car status** app in the center display. The message **Car message stored in Car Status application** will simul-

taneously appear in the center display.

Reading saved messages

To read a saved message immediately:

- Tap the button to the right of the message Car message stored in Car Status application in the center display.
 - > The saved message will be displayed in the **Car status** app.

To read saved messages at a later time:

- 1. Open the **Car status** app from App view in the center display.
 - > The app will open in the bottom tile of Home view.
- 2. Select the Messages tab in the app.
 - > A list of saved messages will be displayed.
- 3. Tap a message to expand/minimize it.
 - More information about the message will appear in the list and the image to the left of the app will display information about the message in graphic form.

Handling saved messages

In expanded form, some messages have two buttons available for booking service or reading the Owner's Manual. Booking service for saved messages:

- With the message in expanded form, tap Request appoint.Call to make Appointment⁸ for assistance booking service.
 - With Request appoint.: The Appointments tab will open in the app and create a request for a service/repair appointment.
 - With **Call to make Appointment**: The phone app will open and call a service center to make an appointment for service or repairs.

Reading the Owner's Manual for saved messages:

- With the message in expanded form, tap Owner's manual to read relevant information about the message in the Owner's Manual.
 - > The Owner's Manual will open in the center display and provide information related to the message.

Saved messages in the app are automatically deleted each time the engine is started.

⁸ Market dependent. Volvo ID and selected workshop also need to be registered


DISPLAYS AND VOICE CONTROL

- Messages in the instrument panel (p. 106)
- Handling messages in the instrument panel (p. 107)
- Messages in the center display (p. 142)

Center display overview

Many of the vehicle's functions can be controlled from the center display. The center display and its possibilities are presented below.





Three of the center display's basic views. Swipe to the right/left to access Function or App view9.

1 Function view – vehicle functions that can be activated or deactivated with one tap. Certain

functions, called "trigger functions", open windows with settings options. One example

is the **Camera**. Settings for the head-up display* are also started from Function view, but

112

⁹ In right-hand drive vehicles, these views are mirror images of the ones shown here.

- adjusted using the right-side steering wheel keypad.
- Home view the initial view displayed when the screen is turned on.
- App view shows downloaded apps (thirdparty apps) as well as apps for integrated functions, such as FM radio. Tap an app icon to open that app.
- Status bar current vehicle activities are shown at the top of the screen. Network and connection information is shown to the left of the status bar, Media-related information, the clock and information about background activities are shown to the right.
- Top view pull the tab down to open Top view. From here, you can access Settings, Owner's manual, Profile and messages stored in the vehicle. In certain cases, contextual setting (e.g. Navigation Settings) and the contextual Owner's Manual (e.g. Navigation Manual) can also be accessed in Top view.
- 6 Navigation takes you to map navigation with e.g. Sensus Navigation*. Tap the tile to expand it.
- Media most recently used media-related apps. Tap the tile to expand it.
- Phone used to access phone-related functions. Tap the tile to expand it.

- Fourth tile most recently used apps or vehicle functions not associated with the other tiles. Tap the tile to expand it.
- Climate row information and direct interaction to set temperature and seat heating for example*. Tap the symbol in the center of the climate bar to open Climate view and additional setting options.

- Handling the center display (p. 114)
- Navigating in the center display's views (p. 117)
- Function view in the center display (p. 124)
- Apps (p. 465)
- Symbols in the center display status bar (p. 126)
- Opening settings in the center display (p. 134)
- Opening contextual setting in the center display (p. 135)
- Owner's Manual in the center display (p. 17)
- Media player (p. 485)
- Phone (p. 498)
- Climate system controls (p. 217)
- Turning off and adjusting the volume of the center display system sounds (p. 133)
- Changing the appearance of the center display (p. 133)

- Changing system language (p. 134)
- Changing system units of measurement (p. 134)
- Cleaning the center display (p. 615)
- Messages in the center display (p. 142)

Handling the center display

Many of the vehicle's functions and features can be controlled and adjusted from the center display. The center display is a touchscreen that reacts to taps and other gestures.

Using the center display's touchscreen

The touchscreen reacts differently depending on whether the user taps, drags or swipes the screen. It is possible to e.g. move between differ-

ent views, mark objects, scroll in a list and move apps by touching the screen in various ways.

An infrared light curtain just above the surface of the screen enables the screen to detect when a finger is directly in front of the screen. This technology makes it possible to use the screen even while wearing gloves.

Two people can interact with the screen at the same time, e.g. to adjust climate system settings for both the driver and passenger sides.

!) CAUTION

Do not use sharp objects on the screen as this could cause scratches.

The following table presents the various procedures for using the screen:

Procedure	Gesture	Result
6	Tap once.	Marks an object, confirms a selection or activates a function.
	Double-tap.	Zooms in on a digital object, such as a map*.
	Press and hold.	Grabs hold of an object so it can be moved. Can be used to move apps or points on a map*. Press and hold your finger on the screen and drag the object to the desired position.
	Tap once with two fingers.	Zooms out from a digital object, such as a map*.

*Option/accessory.

Procedure	Gesture	Result
	Drag	Moves between screen views or scrolls in a list, text or a view. Press and hold to drag apps or points on a map*. Drag horizontally or vertically over the screen.
	Swipe	Moves between screen views or scrolls in a list, text or a view. Drag horizontally or vertically over the screen.
		Note that touching the upper part of the screen could cause Top view to open.
The state of the s	Stretch	Zooms in.
	Pinch	Zooms out.

Returning to Home view from another view


- 1. Briefly press the home button below the center display.
 - > The most recent Home view mode will be displayed.
- 2. Press briefly again.
 - > All of the Home view's tiles will return to standard mode.



In Home view's standard mode – short press on the Home button. An animation describing access to the various views is shown on the screen.

Scrolling in lists, articles or views

A scroll indicator is displayed on the screen when it is possible to scroll up or down in the view. Swipe down/up anywhere in the view.



The scroll indicator will be shown in the center display when it is possible to scroll in the view.

Using the center display controls



Temperature control.

Digital controls are available for many of the vehicle's functions. For example, to set the temperature:

- drag the control to the desired temperature,
- tap + or to raise or lower the temperature by degrees, or
- tap the desired temperature on the control.

- Activating and deactivating the center display (p. 117)
- Moving apps and buttons in the center display (p. 126)
- Using the center display keyboard (p. 128)

Activating and deactivating the center display

The center display can be dimmed and reactivated using the home button under the screen.



Center display's home button.

When the home button is used, the screen will go dark and the touchscreen no longer reacts to touch. The climate har will remain visible. All functions connected to the screen continue to operate, such as climate, audio, guiding* and apps. The center display screen can be cleaned when the display is dimmed. The dimming function can also be used to darken the screen so it is not a distraction while driving.

- 1. Press and hold the button beneath the screen
 - > The screen will go dark (the climate bar will remain visible). All functions connected to the screen continue to operate.
- 2. To reactivate the screen, briefly press the Home button.
 - > The view that was displayed before the screen was turned off will be displayed again.

NOTE

The screen cannot be turned off when a prompt to perform an action is being displayed on the screen.

NOTE

The center display is turned off automatically when the engine is off and the driver's door is opened.

Related information

- Cleaning the center display (p. 615)
- Changing the appearance of the center display (p. 133)
- Center display overview (p. 111)

Navigating in the center display's views

There are five different basic views in the center display: Home view, Top view, Climate view, App. view and Function view. The screen is automatically activated when the driver's door is opened.

Home view

Home view is the view displayed when the screen is activated. It consists of four tiles: Navigation. Media. Phone and a fourth tile.

An app or vehicle function selected from the App or Function views will start in the respective tile in Home view. For example, FM radio will start in the Media tile.

The fourth tile contains the most recently used app or vehicle function that is not related to the other three tiles

The tiles display brief information about the respective apps.



(i) NOTE

When the vehicle is started, information on the current status of apps will be displayed in the respective tile in Home view.

l**4** [j

NOTE

In Home view's standard mode – short press on the Home button. An animation describing access to the various views is shown on the screen.



NOTE


When the vehicle is moving:

- Certain functions (e.g. using the center display's keyboard) may be deactivated.
- Certain texts (e.g. those generated by apps) will be shortened to three rows.
 Tap the **Read out** button to have the entire message read aloud.
- The message will be shortened to one row. Tap the **Read out** button to have the entire message read aloud.

Status bar

Current vehicle activities are shown at the top of the screen in the status bar. Network and connection information is shown to the left of the status bar. Media-related information, the clock and information about background activities are shown to the right.

Top view



Top view when expanded.

There is a tab in the center of the status bar at the top of the screen. Open Top view by tapping the tab or by dragging/swiping from the top of the screen downward.

Top view always provides access to:

- Settings
- Owner's manual
- Profile
- The vehicle's stored messages.

In certain cases, Top view provides access to:

 Contextual setting (e.g. Navigation Settings). Change settings directly in Top

- view when an app (e.g. navigation) is being used.
- Contextual Owner's Manual (e.g. Navigation Manual). Access articles in the digital Owner's Manual related to the content shown on the screen, directly in Top view.

To exit Top view, tap the screen outside Top view, press the Home button or tap the screen at the bottom of Top view and swipe upward. The views behind will become visible again and can be used.



NOTE

The top view is not available at start-up/shut-down or when a message is being shown on the screen. Similarly, it is not available when the climate view is shown.

Climate view

The climate bar is always visible at the bottom of the screen. The most common climate settings can be made directly there, such as setting temperature and seat heating*.




Tap the symbol in the center of the climate bar to open Climate view and access additional climate system settings.



Tap the symbol to close Climate view and return to a previous view.

118

App view



App view showing the vehicle's apps.


Swipe the screen from right to left¹⁰ to access App view from Home view. This view displays downloaded apps (third-party apps) as well as apps for integrated functions, such as FM radio. Brief information will be displayed directly in App view for certain apps, such as unread text messages for Messages.

Tap an app to open it. It will then be opened in its associated tile, e.g. Media.

Depending on the number of apps, it is possible to scroll down in the App view. This is done by sweeping/dragging from the bottom upwards.

To return to Home view, swipe the screen from left to right¹⁰ or press the Home button.

Function view



Function view with buttons for various vehicle functions.

Swipe the screen from left to right 10 to access Function view from Home view. From Function view, you can activate or deactivate various vehicle functions such as BLIS*, Lane Keeping Aid* and Park Assist*.

¹⁰ Applies for left-hand drive vehicles. For right-hand drive vehicles, swipe in the other direction.

If there are many functions, you can also scroll downward through the view. This is done by sweeping/dragging from the bottom upwards.

Unlike in App view, where you tap an app to open it, in Function view, tapping a function activates or deactivates it. Certain functions (trigger functions) open in their own window when tapped.

To return to Home view, swipe the screen from right to left¹⁰ or press the Home button.

- Handling tiles in the center display (p. 121)
- Symbols in the center display status bar (p. 126)
- Opening settings in the center display (p. 134)
- Opening contextual setting in the center display (p. 135)
- Owner's Manual in the center display (p. 17)
- Driver profiles (p. 139)
- Climate system controls (p. 217)
- Apps (p. 465)
- Function view in the center display (p. 124)
- Center display overview (p. 111)

¹⁰ Applies for left-hand drive vehicles. For right-hand drive vehicles, swipe in the other direction.

Handling tiles in the center display

Home view consists of four tiles: Navigation, Media, Phone and a fourth tile. These views can be expanded.

◀ Expanding a tile from standard mode



Standard mode and expanded mode of a tile in the center display.

Expanding a tile:

For tiles Navigation, Media and Phone: Tap the screen anywhere in the tile. When a tile is expanded, the extra tile in the home view is temporarily forced away. The other two tiles will be minimized and only show certain information. When the extra tile is tapped, the other three tiles are minimized and only certain information is displayed.

Expanded view provides access to the basic functions of the respective apps.

Closing an expanded tile:

- The tile can be closed in three different ways:
 - Tap the top section of the expanded tile.
 - Tap another tile (it will then be opened in expanded mode instead).
 - Press briefly on the Home button under the center display.

Opening or closing a tile in full-screen mode

The fourth tile¹¹ and tile for **Navigation** can be opened in full-screen mode to show additional information and possible settings.

When a tile is opened in full-screen mode, no information from the other tiles is displayed.



In expanded mode, open the app in full-screen mode. Tap the symbol.



To return to expanded mode, tap the symbol or press the Home button under the screen.



Center display's home button.

You can always press the Home button to return to Home view. To return to Home view's standard view from full-screen mode, press the Home button twice.

- Handling the center display (p. 114)
- Activating and deactivating the center display (p. 117)
- Navigating in the center display's views (p. 117)

Related information

 $^{^{11}\,}$ Does not apply to all apps or vehicle functions opened via the fourth tile

Function view in the center display

Function view, which is one of the center display's basic views, contains all of the vehicle's function buttons. From the Home view, navigate to Function view by swiping from left to right over the screen¹².

Different types of buttons

There are three different types of buttons for vehicle functions; see below:

Type of button	Functions	Vehicle function affected	
Function buttons	Have On/Off modes. When a function is active, an LED indicator light will illuminate to the left of the button's icon. Press the button to turn the function on or off.	Most buttons in Function view are function buttons.	
Trigger buttons	Do not have On/Off modes. Pressing a trigger button opens a window for the function. This can be, for example, a window to change seat position.	Camera Headrest Fold Head-up Display Adjustments	
Parking buttons	Have On/Off and scanning modes. Similar to function buttons, but have an extra mode for parking scanning.	Park In Park Out	

¹² Applies for left-hand drive vehicles. For right-hand drive vehicles, swipe in the other direction.

Button modes



When a function or parking button's LED indicator is green, the function is activated (on). For some functions, an additional text explaining the function will be shown when the function is initially activated. The text will be displayed for a few seconds and then the button will be displayed with the LED indicator illuminated.

For Lane Keeping Aid, for example, the text Works only at certain speeds will be displayed when the button is pressed.

Press the button briefly to activate or deactivate the function.



The function is deactivated when the LED indicator light is switched off.



A warning triangle in the right-hand section of the button indicates that something is not working correctly.

- Handling the center display (p. 114)
- Navigating in the center display's views (p. 117)

Moving apps and buttons in the center display

The apps and buttons for vehicle functions can be moved and organized in the App and Function views.

- Swipe from right to left¹³ to access App view or swipe from left to right¹³ to access Function view.
- 2. Press and hold an app or button.
 - > The app or button will change size and become slightly transparent. It can then be moved.
- 3. Drag the app or button to an available position in the view

A maximum of 48 rows can be used to position apps or buttons. To move an app or button outside the visible view, drag it to the bottom of the view. New rows will be added and the app or button can be placed in one of these.

Apps or buttons placed below the view's normal display will not be visible on the screen.

Swipe the screen to scroll up or down in the view to display information outside the view.

(i) NOTE

Hide the apps that are rarely or never used by moving them far down, outside of the visible view. This makes it easier to find the apps used more frequently.

(i)

NOTE

Apps and vehicle function buttons cannot be situated at spots already in use.

Related information

- Function view in the center display (p. 124)
- Apps (p. 465)
- Handling the center display (p. 114)

Symbols in the center display status bar

Overview of symbols displayed in the center display status bar.

The status bar shows current vehicle activities and in certain cases, also their status. Due to the limited space in the status bar, not all symbols will be displayed at all times.

Symbol	Meaning
	Connected to the Internet.
	Could not connect to Internet.
R	Roaming activated.
11	Cell phone network signal strength.
*	Bluetooth device connected.
*	Bluetooth activated but no device connected.
•	Information sent to and from GPS.
	Connected to Wi-Fi network.

¹³ Applies for left-hand drive vehicles. For right-hand drive vehicles, swipe in the other direction.

Symbol	Meaning
(<u>(</u>))	Tethering activated (Wi-Fi hotspot). This means that the vehicle shares an available Internet connection.
	Vehicle modem activated.
•	USB sharing active.
0	Action in progress.
3	Timer for preconditioning active. ^A
	Audio source being played.
	Audio source paused.
	Phone call in progress.
□□X	Audio source muted.
NEWS	News broadcasts from current radio station. ^B
TP	Traffic information being received. ^B
15:45	Clock.

A Only hybrid models.

B Not available in all markets.

- Navigating in the center display's views (p. 117)
- Messages in the center display (p. 142)

Using the center display keyboard

You can use the keyboard in the center display to enter characters or to switch to handwriting mode to "write" letters and characters on the screen.

The keyboard can be used to enter characters (letters, numbers, symbols, etc.) to e.g. send text messages from the vehicle, enter passwords or search for information in the digital Owner's Manual.

The keyboard will only appear when it is possible to enter text on the screen.



NOTE

The keyboard cannot be used while the vehicle is moving.



The illustration shows an overview of some of the buttons that may be shown on the keyboard. The appearance may vary depending on language settings and the context in which the keyboard is used.

- Row showing suggestions for words or characters 14. The suggested words change as new letters are entered. Scroll through the list of suggested words by tapping the right or left arrows. Tap a suggestion to select it. Please note that this function is not available in all languages. When unavailable, this row will not be shown on the keyboard.
 - Available characters are adapted to the language selected for the keyboard (see number 7 below). Tap a character to enter it.
 - Oifferent buttons are displayed here depending on the context in which the keyboard is used, e.g. @ to enter an email address or the return key to start a new line.
 - This button hides the keyboard. In cases where this is not possible, the button will not be displayed.
 - (5) Used to enter uppercase letters. Tap once to enter one uppercase letter and then continue with lowercase letters. Tap twice for caps lock (all text will be entered in uppercase letters). Tap again to return the keyboard to lowercase letters. In this mode, the first letter after a period, exclamation point or question mark will be automatically entered in uppercase form. The first letter entered in text fields will also be uppercase. In text fields intended for names or addresses, each word will be automatically started with an

- 6 Used to enter numbers. The number keyboard (2) will then be displayed. Tap ABC, which is shown instead of 123 in number mode, to return to the keyboard with letters, or #√~ to display the keyboard with special characters.
- Used to change the keyboard language, e.g. EN. The available characters and word suggestions (1) vary depending on the selected language. In order to toggle between keyboard languages, the languages must first be added under Settings.
- Space bar.
- Oblete. Tap to delete characters one at a time. Press and hold to delete multiple characters quickly.
- Used to change to handwriting mode.

Tap the confirm button over the keyboard (not shown in illustration) once to confirm the text that has been entered. The button's appearance differs depending on the context.

Variants of letters or characters



Variants of a letter or character, e.g. **é** or **è**, can be entered by pressing and holding the letter or character. A box containing possible variants of the letter or character will appear. Tap the desired variant. If no variant is selected, the original letter/character will be used.

- Changing keyboard language in the center display (p. 131)
- Entering characters, letters and words by hand in the center display (p. 131)
- Handling the center display (p. 114)
- Handling text messages (p. 504)

uppercase letter. In text fields intended for passwords, website addresses or email addresses, all letters will automatically be lowercase unless uppercase is selected.

¹⁴ For Asian languages.

Changing keyboard language in the center display

In order to toggle between keyboard languages, the languages must first be added under Settings.

Adding or deleting languages in Settings

The keyboard is automatically set to the same language as the system language. The keyboard language can be manually changed without affecting the system language.

- 1. Tap Settings in Top view.
- Tap System → System Languages and Units → Keyboard Layouts.
- 3. Select one or more languages in the list.
 - > It is now possible to toggle between the selected languages using the keyboard.

If no language has been selected under **Settings**, the keyboard will remain in the same language as the vehicle's system language.

Toggling between keyboard languages



If more than one language has been selected in **Settings**, the button in the keyboard can be used to switch between the different languages. To toggle between keyboard languages from the list:

- 1. Press and hold the button.
 - > A list will appear.
- Select the desired language. If more than four languages have been selected under Settings, you can scroll through the list shown on the keyboard.
 - > The keyboard and word suggestions will be adapted to the selected language.

To change keyboard language without displaying the list:

- Tap the button.
 - > The keyboard layout will change to the next language in the list without displaying the list.

Related information

- Changing system language (p. 134)
- Using the center display keyboard (p. 128)

Entering characters, letters and words by hand in the center display

Characters, letters and words can be entered in the center display by handwriting them on the touchscreen.



Tap the button on the center display's keyboard to switch from the keyboard to handwriting mode.



- Space for entering characters/letters/ words/parts of words.
- 2 Text field displaying suggested characters or words¹⁵ as they are written on the screen (1).
- Suggestions for characters/letters/words/ parts of words. You can scroll through the list.

••

DISPLAYS AND VOICE CONTROL

- Space bar. Blank spaces can be created by writing a dash (–) in the field for handwritten letters (1). See "Writing blank spaces in freetext fields" below
 - Delete. Tap once to erase one character/ letter at a time. Wait a moment before tapping again to erase the next character, letter etc.
 - Return to the standard keyboard layout.
 - Switch off/on screen tap sounds.
 - 8 Hide the keyboard. In cases where this is not possible, the button will not be displayed.
 - Change language for text input.

Handwriting characters/letters/words

- Write a character, a letter, a word or parts of a word in the field for handwritten letters (1).
 Write the word or part of the word vertically or horizontally.
 - > A number of suggestions for characters, letters or words will be displayed (3). The most likely will be shown at the top of the list.

(!) CAUTION

Do not use sharp objects on the screen as this could cause scratches.

- The character/letter/word will be entered automatically after a short pause if no other action is taken.
 - > The character/letter/word at the top of the list will be used. Tap one of the other characters/letters/words in the list to use it instead.

Erasing/changing handwritten characters/ letters



Erase text in the text field (2) by swiping over the handwriting field (1).

- Characters/letters can be erased or changed in several ways:
 - Tap the desired letter or word in the list (3).
 - Tap the delete button (5) to erase the letter and start again.
 - Swipe horizontally from right to left¹⁶ over the handwriting field (1). Erase several letters at once by swiping over the area several times.
 - Tap the X box in the text field (2) to erase all written text.

¹⁵ Certain system languages only.

¹⁶ For Arabic keyboards, swipe in the other direction. Swiping from right to left will create a blank space.

New lines in free-text fields in handwriting mode



Create a new line by drawing above the characters in the handwriting field as shown in the illustration¹⁷.

Writing blank spaces in free-text fields



Make a blank space by drawing a line from left to right 18.

Related information

• Using the center display keyboard (p. 128)

Changing the appearance of the center display

The appearance of the center display can be changed by selecting a different theme.

- 1. Tap **Settings** in the Top view.
- Tap My Car → Displays → Display
 Themes.
- Select a theme, e.g. Minimalistic or Chrome Rings.

In addition to these themes, you can also choose between **Normal** and **Bright**. In **Normal**, the background of the screen is dark and the text is light. This option is the default setting for all themes. If the bright version is selected, the background will be light and the text will be dark. This option can, for example, make the screen easier to see in bright daylight conditions.

These alternatives are always available for selection and are not affected by the ambient lighting.

Related information

- Opening settings in the center display (p. 134)
- Activating and deactivating the center display (p. 117)
- Cleaning the center display (p. 615)

Turning off and adjusting the volume of the center display system sounds

The volume of the center display system sounds can be adjusted or turned off completely.

- 1. Tap **Settings** in the Top view in the center display.
- Tap Sound → System Volumes.
- Pull the control under Touch Sounds to adjust the volume or turn off screen tap sounds. Pull the control to the desired sound level.

- Center display overview (p. 111)
- Changing settings in the center display (p. 136)
- Sound settings (p. 464)

¹⁷ For Arabic keyboards, draw the same character, but in mirror image.

¹⁸ For Arabic keyboards, draw the line from right to left.

Changing system units of measurement

Unit settings are adjusted in the **Settings** menu in the center display.

- Tap **Settings** in the Top view in the center display.
- Proceed to System → System Languages and Units → Units of Measurement.
- 3. Select one of the following measurement standards:
 - Metric kilometers, liters and degrees Celsius.
 - Imperial miles, gallons and degrees Celsius.
 - US miles, gallons and degrees Fahrenheit.
 - > The units in the instrument panel, center display and head-up display are changed.

Related information

- Center display overview (p. 111)
- Opening settings in the center display (p. 134)
- Changing settings in the center display (p. 136)
- Changing system language (p. 134)

Changing system language

Language settings are adjusted in the **Settings** menu in the center display.

$|\mathbf{i}|$

NOTE

Changing languages in the center display could mean that certain owner's information will not comply with national or local laws and regulations. Do not change to a language that you do not fully understand, as this could make it difficult to navigate back through the menu.


- Tap **Settings** in the Top view in the center display.
- Proceed to System → System Languages and Units.
- Select System Language. A voice control symbol indicates that the language can be used for voice commands.
 - > Languages in the instrument panel, center display and head-up display are changed.

Related information

- Center display overview (p. 111)
- Opening settings in the center display (p. 134)
- Changing settings in the center display (p. 136)
- Changing system units of measurement (p. 134)

Opening settings in the center display

The center display is used to manage Settings and to display information for many of the vehicle's functions.



Top view with **Settings** button.

- Open Top view by tapping the tab or by dragging/swiping from the top of the screen downward.
- 2. Tap **Settings** to open the Settings menu.
- Tap one of the categories shown and tap again to navigate to sub-categories and their respective settings.
- Tap Back to move backward in the Settings menu.

Tap Close to close the Settings menu.

Related information

- Center display overview (p. 111)
- Changing settings in the center display (p. 136)
- Setting types in the center display (p. 137)
- Table of settings in the center display (p. 138)

Opening contextual setting in the center display

Most of the settings for the vehicle's basic apps can be changed directly in Top view in the center display via contextual settings.



Top view with button for contextual settings.

Apps that are factory-installed in your vehicle, e.g. **FM radio** and **USB**, are part of Sensus and are used to control the vehicle's integrated functions. The settings for these apps can be changed directly in Top view in the center display.

When contextual setting is available:

- 1. Pull down Top view when an app is in expanded form, e.g. **Navigation**.
- Tap Navigation Settings.
- 3. Change the desired settings and confirm.

Tap **Close** or press the Home button under the center display to close Settings view.

Most of the vehicle's basic apps have this contextual setting option, but not all.

Third-party apps

Third-party apps are apps that are not factory-installed in the vehicle's system, but can be downloaded, e.g. **Volvo ID**. Settings for these apps are changed in the apps themselves, not in Top view.

- Opening settings in the center display (p. 134)
- Center display overview (p. 111)
- Resetting center display settings (p. 137)
- Download apps (p. 466)

Changing settings in the center display

You can change **Settings** and information for many of the vehicle's functions via the center display.

- Open Top view by tapping the tab or by dragging/swiping from the top of the screen downward.
- 2. Tap **Settings** to open the Settings menu.
- 3. Tap one of the categories and sub-categories to navigate to the desired setting.
- 4. Change the setting(s). Different types of settings are changed in different ways.
 - > Changes are saved immediately.



A sub-category in the Settings menu with various possible settings; has a multi-selection button and radio buttons.

Related information

- Center display overview (p. 111)
- Resetting center display settings (p. 137)
- Setting types in the center display (p. 137)
- Table of settings in the center display (p. 138)

Resetting user data when the vehicle changes owners

If the vehicle changes owners, all user data and system settings should be reset to factory defaults.

Vehicle settings can be reset at different levels. Reset all user data and system settings to their original factory defaults when the vehicle changes owner. It is also important to change the owner of the Volvo On Call service.

Related information

Resetting center display settings (p. 137)

Resetting center display settings

All settings made in the center display's Settings menu can be reset to default values.

Two types of reset

There are two ways to reset the settings in the Settings menu:

- Factory Reset- erases all data and files and resets all settings to factory default.
- Reset Personal Settings- erases personal data and resets personalized settings to factory default.

Resetting settings

Follow these instructions to reset the settings.

i NOTE

Factory Reset is only possible when the vehicle is stationary.

- Tap **Settings** in the Top view in the center display.
- Proceed to System → Factory Reset.
- Select the type of reset you would like to do.
 A pop-up window will appear.

4. Tap **OK** to confirm the reset.

For Reset Personal Settings, confirm the reset by tapping Reset for the active profile or Reset for all profiles.

> The selected settings will be reset.

Related information

- Center display overview (p. 111)
- Opening settings in the center display (p. 134)
- Changing settings in the center display (p. 136)
- Table of settings in the center display (p. 138)

Setting types in the center display

Different types of settings are changed in different ways. Refer to the table below for a description of the different types of settings.

Types of settings

Type of setting	Description
Trigger function	Starts an app or a separate view for more advanced settings. Tap the text to e.g. connect a Bluetooth® device.
Radio but- ton	Select one of the possible set- tings by tapping the desired radio button to e.g. change the system language.
Multi- selection button	Select a level for a particular setting by pressing the desired part of the button, e.g. to select sensitivity level for City Safety.
Checkbox	Tap the checkbox to activate/ deactivate a function, e.g. to select automatic start for heated seats.

4◀

Type of setting	Description
Slider	Select a level for a function by pressing and dragging the slider control, e.g. to set volume level.
Informa- tion dis- play	This is not an actual setting, but instead displays information such as the vehicle's VIN number.

Related information

• Center display overview (p. 111)

Table of settings in the center display

The center display's Settings menu has a number of main categories and sub-categories that contain settings and information for many of the vehicle's features and functions.

There are seven main categories: My Car, Sound, Navigation, Media, Communication, Climate and System.

Each category, in turn, contains a number of subcategories and possible settings. The table below shows the first level of sub-categories. The possible settings for a function or an area are described in more detail in their respective sections of the Owner's Manual.

Some settings are personal, which means that they can be saved to a **Driver Profiles**. Others are global, which means that they are not linked to a driver profile.

My Car

ny Cai
Sub-categories
Displays
IntelliSafe
Drive Preferences/Individual Drive Mode*
Lights and Lighting
Mirrors and Convenience

Sub-c	ategories
Locki	ng
Parkii	ng Brake and Suspension
Wiper	s
Sound	i
Sub-c	ategories
Tone	
Balan	се
Syste	m Volumes
laviga	ation
Sub-c	ategories
Мар	
Route	and Guidance
Traffic	:
/ledia	
Sub-c	ategories
AM/F	M Radio
Sirius	YM
Sirius	AIVI

SiriusXM Travel Link

Sub-categories

Gracenote®

Video

Communication

Sub-categories

Phone

Text Messages

Android Auto*

Apple CarPlay*

Bluetooth Devices

Wi-Fi

Vehicle Wi-Fi Hotspot

Vehicle Modem Internet

Volvo On Call

Volvo Service Networks

Climate

The **Climate** main category does not have any sub-categories.

System

Sub-categories

Driver Profile

Date and Time

System Languages and Units

Privacy and data

Keyboard Layouts

Voice Control*

Factory Reset

System Information

Related information

- Center display overview (p. 111)
- Changing settings in the center display (p. 136)
- Resetting center display settings (p. 137)

Driver profiles

Many of the vehicle's settings can be customized to the driver's personal preferences and saved in one or more driver profiles.

These personal settings are automatically saved in the active driver profile. Each key can be linked to one driver profile. When the linked key is used, the vehicle is customized to the specific settings of that driver profile.

Which settings are saved in driver profiles?

The vehicle has settings that can be made either personal or global. The personal settings are saved in driver profiles.

Settings that can be saved in a driver profile include, among other things, screens, mirrors, front seats, navigation*, audio and media system, language and voice control.

Some settings are global settings. These settings can be changed but are not saved to a specific driver profile. Changes to global settings affect all profiles.

Global settings

Global settings and parameters do not change when driver profiles are changed. They remain the same regardless of which driver profile is currently active.

Keyboard layout is an example of a global setting. If driver profile X is used to add additional keyboard languages, these languages will also be available for driver profile Y. The settings for keyboard layout are not saved to a specific driver profile - the settings are global.

Personal settings

If driver profile X has been used to e.g., set the brightness for the center display, driver profile Y will not be affected by this setting. It will only be saved to driver profile X because brightness setting is a personal setting.

Related information

- Selecting a driver profile (p. 140)
- Changing a driver profile's name (p. 141)
- Resetting driver profile settings (p. 141)
- Linking a remote key to a driver profile (p. 141)
- Table of settings in the center display (p. 138)

Selecting a driver profile

When the center display starts up, the selected driver profile will be shown at the top of the screen. The most recently used driver profile will be active the next time the vehicle is unlocked. A different driver profile can be selected once the vehicle has been unlocked. However, if the remote key has been linked to a driver profile, this profile will be used instead.

There are two options for switching between driver profiles.

Option 1:

- Tap the name of the driver profile shown at the top of the center display when the display starts up.
 - > A list will appear, showing driver profiles that can be selected.
- 2. Select desired driver profile.
- 3. Tap Confirm.
 - > The driver profile has now been selected and the system will load the settings stored in that profile.

Option 2:

- 1. Pull down Top view in the center display.
- 2. Tap Profile.
 - > The same list as in option 1 will be displayed.
- 3. Select desired driver profile.

- 4. Tap Confirm.
 - The driver profile has now been selected and the system will load the settings stored in that profile.

- Driver profiles (p. 139)
- Navigating in the center display's views (p. 117)
- Changing a driver profile's name (p. 141)
- Linking a remote key to a driver profile (p. 141)

Changing a driver profile's name

It is possible to change the names of the different driver profiles used in the vehicle.

- Tap **Settings** in the Top view in the center display.
- Tap System → Driver Profiles.
- 3. Select Edit Profile.
 - > A menu will open in which the driver profile can be changed.
- 4. Tap the Profile Name box.
 - A keyboard will be displayed and can be used to change the name. Tap to close the keyboard.
- Save the name change by pressing Back or Close.
 - > The name has now been changed.



Profile names may not begin with a space. If a space is entered first, the profile name will not be saved.

Related information

- Selecting a driver profile (p. 140)
- Using the center display keyboard (p. 128)

Resetting driver profile settings

Settings that have been saved for one or more driver profiles can be reset when the vehicle is stationary.

(i) N

NOTE

Factory Reset is only possible when the vehicle is stationary.

- 1. Tap **Settings** in the Top view.
- Tap System → Factory Reset → Reset Personal Settings.
- Select option Reset for the active profile, Reset for all profiles or Cancel.

Related information

- Driver profiles (p. 139)
- Resetting center display settings (p. 137)

Linking a remote key to a driver profile

A remote key can be linked to a driver profile. This driver profile and all of its settings will then automatically be selected every time the vehicle is used with that particular remote key.

The first time the remote key is used, it is not linked to any specific driver profile. The **Guest** profile is automatically activated when the ignition is switched on.

A driver profile can also be selected manually without linking it to any key. When the vehicle is unlocked, the last active driver profile will be activated. If the key has ever been linked to a driver profile, it is not necessary to manually select a driver profile when using that particular key.

Linking a remote key to a specific driver profile

First select the profile you would like to link to the key (if that profile is not already active). The active profile can then be linked to the key.

- 1. Tap **Settings** in the Top view in the center display.
- Tap System → Driver Profiles.
- Mark the desired profile. The display will return to Home view. The **Guest** profile cannot be linked to a remote key.

DISPLAYS AND VOICE CONTROL

- 4. Pull down Top view again and tap Settings
 → System → Driver Profiles → Edit
 Profile.
 - 5. Select Connect key to link the profile with the key. A driver profile can only be linked to the key currently being used in the vehicle. If there are any other keys in the vehicle, More than one key is found, put the key you want to connect on backup reader will be displayed.



Location of the backup reader in the tunnel console.

- > When Profile connected to key is displayed, the key and driver profile have been linked.
- 6. Tap **OK**.
 - > The key used is now linked to the driver profile and will remain so as long as the Connect key box is not deselected.


Related information

- Driver profiles (p. 139)
- Changing a driver profile's name (p. 141)

Remote key (p. 237)

Messages in the center display

The center display shows messages in certain circumstances to inform or assist the driver.



Messages in the center display's Top view.

Messages with lower priority for the driver are shown in the center display.

Most of the messages are shown in the center display's status bar. The message will disappear from the status bar after a short period of time or after the required action has been taken. Messages that need to be saved are stored in Top view in the center display.

The message may be shown along with graphics, symbols or a button to e.g. activate/deactivate a function connected to the message.

Pop-up messages

Messages are sometimes shown as pop-up windows. Pop-up messages have a higher priority than messages shown in the status bar and require acknowledgment/action before they disappear. Messages that need to be saved are stored in Top view in the center display.

Related information

- Handling messages in the center display (p. 143)
- Handling messages saved from the center display (p. 144)
- Messages in the instrument panel (p. 106)

Handling messages in the center display

Messages in the center display are handled in the center display's views.



Messages in the center display's Top view.

Some messages in the center display have a button (or several buttons in a pop-up message) to e.g. activate/deactivate a function related to the message.

Handling new messages

For messages with buttons:

- Tap the button to perform the action or let the message automatically time-out after a short period.
 - > The message will disappear from the status bar.

For messages without buttons:

- Close the message by tapping it or let the message automatically time-out after a short period.
 - > The message will disappear from the status bar.

Messages that need to be saved are stored in Top view in the center display.

- Messages in the center display (p. 142)
- Handling messages saved from the center display (p. 144)
- Messages in the instrument panel (p. 106)

Handling messages saved from the center display

Messages saved from the instrument panel and center displays are handled in the center display.



Saved messages and possible selections in Top view.

Messages that have been shown in the center display and that need to be saved are stored in the center display's Top view.

Reading saved messages

- 1. Open Top view in the center display.
 - A list of saved messages will be displayed. Messages with an arrow to the right can be expanded.
- 2. Tap a message to expand/minimize it.
 - More information about the message will appear in the list and the image to the left of the app will display information about the message in graphic form.

Handling saved messages

Some messages have a button to e.g. activate/deactivate a function related to the message.

Tap the button to perform the action.

Saved messages in Top view are automatically deleted when the ignition is switched off.

Related information

- Messages in the center display (p. 142)
- Handling messages in the center display (p. 143)
- Messages in the instrument panel (p. 106)

Head-up display*

The head-up display is a complement to the instrument panel and projects information from the instrument panel onto the windshield. The projected images can only be seen from the driver's seat.



Incoming phone calls.

The head-up display projects warnings and information related to speed, cruise control functions, navigation, etc. onto the windshield in the driver's field of vision. Traffic information and incoming phone calls can also be shown on the head-up display.

NOTE

The driver's ability to see information in the head-up display may be impeded by:

- the use of polarizing sunglasses
- a driving posture in which the driver is not centered in the seat
- objects on the display unit's glass cover
- unfavorable lighting conditions.

CAUTION

The information is projected from a display unit located in the dashboard. To help prevent damage to the display unit's glass cover, do not place any objects on the glass and prevent objects from falling onto it.



Examples of what might be shown on the display.

- Speed
- Cruise control
- Navigation
- Road signs

A number of symbols may be projected temporarily onto the head-up display, including:



If the warning symbol appears, read the warning message in the instrument panel.



If the information symbol appears, read the warning message in the instrument panel.

(i) NOTE

People with certain types of vision problems may experience headaches or eye strain when using the head-up display.

City Safety in head-up-display

If City Safety is activated, the information in the head-up display will be replaced by a City Safety graphic. This graphic will illuminate even if the head-up display is turned off.



A City Safety graphic flashes to attract the driver's attention.

- Activating and deactivating the head-up display* (p. 146)
- Cleaning the head-up display* (p. 616)
- Replacing a windshield with head-up display* (p.586)

Activating and deactivating the head-up display*

The head-up display can be activated and deactivated when the vehicle has been started.



Press the **Head-up Display** button in the center display's Function view. An indicator light in the button will illuminate when the function is activated.

Related information

- Head-up display settings* (p. 146)
- Head-up display* (p. 144)

Head-up display settings*

Adjusting settings for the head-up display. Settings can be adjusted in the center display's Settings menu when the vehicle is started and a projected image is displayed on the windshield.

This setting is stored as a personal setting in the driver profile.

Selecting display options

Select the functions to be shown in the head-up display.

- Tap **Settings** in the center display's Top view.
- Tap My Car → Displays → Head-Up Display Options.
- Select one or more functions:
 - Show Navigation
 - Show Road Sign Information
 - Show Driver Support
 - Show Phone.

Adjusting brightness and height position



- Press the Head-up Display Adjustments button in the center display's Function view.
- Adjust the brightness of the projected image and the height position in the driver's field of vision using the right-side steering wheel lever.



- Decreasing brightness
- 2 Increasing brightness
- Raising position

- 4 Lowering position
- 6 Confirm

The brightness of the graphic is automatically adapted to the light conditions in its background. Brightness is also affected by adjustments to the brightness of the other displays in the vehicle.

The height position can be stored in the front power seat's* memory function.

Calibrating the horizontal position

If the windshield or display unit has been replaced, the head-up display's horizontal position may need to be calibrated. Calibration means that the projected image is rotated clockwise or counterclockwise.

- Tap **Settings** in the center display's Top view.
- Select My Car → Displays → Head-Up
 Display Options → Head-Up Display
 Calibration.
- Calibrate the horizontal position of the image using the right-side steering wheel keypad.



- Rotate counterclockwise
- 2 Rotate clockwise
- Confirm

Related information

- Head-up display* (p. 144)
- Activating and deactivating the head-up display* (p. 146)

Voice control¹⁹

The driver can use voice commands to control certain functions in the media player, a Bluetooth-connected phone, the climate system and the Volvo navigation system*.

Voice commands offer extra convenience and help minimize distractions so drivers can concentrate on driving and keep their attention on the road and traffic situation.

MARNING

The driver is always responsible for ensuring that the vehicle is operated in a safe manner and that all applicable traffic regulations are followed.



Voice control microphone

¹⁹ Certain markets only.

■ Voice control is carried out as a dialog, with spoken commands from the user and verbal responses from the system. The voice control system uses the same microphone as devices connected with Bluetooth, and the voice control system responds through the vehicle's loudspeakers. In certain cases, text messages will also be displayed in the instrument panel. The functions are controlled using the right-side steering wheel keypad and settings are made in the center display.

System updates

The voice control system is continuously improved. For optimal functionality, always download the latest update at support.volvocars.com.

Related information

- Using voice commands (p. 148)
- Voice control for cellular phones (p. 149)
- Voice control for radio and media (p. 150)
- Climate control system voice commands (p. 208)
- Voice control settings (p. 150)

Using voice commands²⁰



Press the button for voice control (of control to local) on the right-side steering wheel keypad to activate the system and initiate a voice command dialog.

These may include:

- Wait until after the tone, and then speak in your normal voice at a normal speed.
- Do not speak while the system is responding (the system is unable to process commands during this time).
- Avoid background noises in the passenger compartment by keeping doors, windows and the panoramic roof* closed.

Voice control can be canceled by:

- saving "Cancel".
- pressing and holding the steering wheel keypad's voice command button (¿).

To speed up the voice command dialog and skip system responses, press the voice command button & while the system is responding and give your next command.

Voice command examples

Press &£, say "Call [First name] [Last name] [number category]" - calls the selected contact from the phone book. If the contact has several phone numbers (e.g. home, cell, work), the right category must also be given.

Press (and say "Call Robyn Smith cellular".

Commands/phrases

The following commands can always be used:

- "Repeat" repeats the most recent voice command in the current dialog.
- "Cancel" cancels the dialog.
- "Help" initiates a help dialog. The system responds with commands that can be used in the current situation, an instruction or an example.

Commands for specific functions, such as phone and audio, are described in the sections related to that function.

²⁰ Certain markets only.

Numbers

Number commands can be given in different ways depending on the function to be controlled:

- Phone numbers and zip codes should be given by stating each number individually, e.g. zero three one two two four four three (03122443).
- Addresses can be given by stating each number individually or in a group, e.g. two two or twenty-two (22). For English and Dutch language settings, groups of numbers can also be said in sequence, e.g. twenty-two twenty-two (22 22). For English, double or triple digits can also be used, e.g. double zero (00). Numbers in the range 0-2300 can be used.
- Frequencies can be given as ninety-eight point eight (98.8), one hundred four point two, or hundred four point two (104.2).

Related information

- Voice control (p. 147)
- Voice control for cellular phones (p. 149)
- Voice control for radio and media (p. 150)
- Climate control system voice commands (p.208)
- Voice control settings (p. 150)

Voice control for cellular phones²¹

Call a contact in the phone book, have a text message read aloud or dictate short messages using voice commands to a Bluetooth-connected phone.

To access a contact in the phone book, the voice command must contain the contact information. entered in the phone book. If a contact, e.g. Robyn Smith, has several phone numbers listed in the phone book, a number category such as home or cellular can also be specified, i.e. "Call Robyn Smith cellular".

Tap (and say one of the following commands:

- "Call [contact]" call the selected contact from the phone book.
- "Call [phone number]" call a phone number.
- "Recent calls" display the list of recent calls.
- "Read message" read a text message aloud. If there are several messages, select the message to read aloud.
- "Message to [contact]" the user is prompted to dictate a short message. The message will then be read aloud and the user can choose to send²² or re-dictate the message. The vehicle must be connected to the Internet to access this function.

- Voice control (p. 147)
- Using voice commands (p. 148)
- Voice control for radio and media (p. 150)
- Climate control system voice commands (p.208)
- Voice control settings (p. 150)
- Internet-connected vehicle* (p. 507)

²¹ Certain markets only.

²² Only certain phones can send messages via the vehicle. For additional information on compatibility, see support volvocars.com.

Voice control for radio and media²³

Voice commands for the radio and media players are shown below.

Tap (and say one of the following commands:

- "Media" initiates a dialog for media and radio and displays examples of commands.
- "Play [artist]" plays music by the selected artist.
- "Play [song title]" plays the selected song.
- "Play [song title] from [album]" plays the selected song from the selected album.
- "Play [radio station]" starts the selected radio station.
- "Tune to [frequency]" tunes to the selected radio frequency in the currently active waveband. If no radio source is active, the FM band will be started as default.
- "Tune to [frequency] [waveband]" tunes to the selected radio frequency on the selected waveband.
- "Radio" starts FM radio.
- "Radio FM" starts FM radio.
- "Radio AM" starts AM radio.
- "SiriusXM" starts SiriusXM radio*
- "CD" starts playback from CD*.
- 23 Certain markets only.
- 24 Certain markets only.

- "USB" starts playback from USB.
- "iPod" starts playback from iPod.
- "Bluetooth" starts playback from a Bluetooth-connected media source.
- "Similar music" plays music from a USBconnected device with music similar to that currently playing.

Related information

- Voice control (p. 147)
- Using voice commands (p. 148)
- Voice control for cellular phones (p. 149)
- Climate control system voice commands (p. 208)
- Voice control settings (p. 150)

Voice control settings²⁴

Settings for the voice control system are made here.

Settings → System → Voice Control

Settings can be personalized in the following areas:

- Repeat Voice Command
- Gender
- Speech Rate

Sound settings

Select sound settings under:

Settings → Sound → System Volumes → Voice Control

Language settings

The voice control system is not available for all languages. The languages available for voice commands are indicated by the we icon in the list of languages.

Changing the language here will also change the language in the menus, messages and help texts.

Settings → System → System Languages and Units → System Language

- Voice control (p. 147)
- Using voice commands (p. 148)
- Voice control for cellular phones (p. 149)
- Climate control system voice commands (p. 208)
- Voice control for radio and media (p. 150)
- Sound settings (p. 464)
- Changing system language (p. 134)

Lighting panel and controls

The lighting panel and controls can be used to adjust both exterior and interior lighting. The lighting ring on the left-side steering wheel lever can be used to activate and adjust the exterior lighting. The brightness of the interior lighting can be adjusted using the thumb wheel on the dashboard.

Exterior lighting



Lighting ring position.

With the ignition in position II or when the engine is running, the following functions apply for the various lighting ring positions:

Position	Meaning		
0	In the US: Daytime running lights and parking lights are off.		
	In Canada: Daytime running lights and parking lights are on.		
	High beam flash can be used.		
∃D OΞ	Parking lights when the vehicle is parked.		
	In the US: Daytime running lights are off.		
	In Canada: Daytime running lights are on.		
	High beam flash can be used.		
■ D	Low beams and parking lights.		
	High beams can be activated.		
	High beam flash can be used.		

Position	Meaning			
AUTO	Daytime running lights and parking lights in daylight conditions. ^A			
	Low beams and parking lights in weak daylight or dark conditions or when the front fog lights* and/or rear fog light are activated.			
	Active high beam can be activated.			
	High beams can be activated when low beams are on.			
	High beam flash can be used.			
 ■CA	Active high beams on/off.			
A US models only: Daytime running lights and parking lights can				

A US models only: Daytime running lights and parking lights ca be deactivated in the center display.



Volvo recommends use of Daytime Running Lights in the US. Its use is mandatory in Canada.

Volvo recommends using position AUTO when the vehicle is in motion.

The vehicle lighting system cannot in all situations determine when the daylight is too weak or not strong enough, e.g. when there is fog or rain.

The driver is always responsible for driving the vehicle with lighting that is safe for the traffic conditions and as specified by applicable traffic regulations.

Thumbwheel in instrument panel



Thumb wheel (to the left) for adjusting interior brightness.

Related information

- Adjusting light functions via the center display (p. 155)
- Interior Lighting (p. 165)
- Parking lights (p. 156)

- Using turn signals (p. 160)
- Using high beam (p. 158)
- Low beams (p. 157)
- Front fog lights/cornering illumination* (p. 161)
- Rear fog light (p. 162)
- Active Bending Lights* (p. 161)
- Brake lights (p. 163)
- Emergency brake lights (p. 163)
- Hazard warning flashers (p. 164)

Adjusting light functions via the center display


Multiple light functions can be adjusted and activated via the center display. These include automatic high beam, home safe lighting, and approach lighting.

- 1. Tap **Settings** in the Top view.
- Tap My Car → Lights and Lighting.
- 3. Select Exterior Lights or Interior Lighting.

- Lighting panel and controls (p. 154)
- Active high beam (p. 159)
- Using home safe lighting (p. 164)
- Welcome Light (p. 164)
- Using turn signals (p. 160)
- Opening settings in the center display (p. 134)
- Function view in the center display (p. 124)

Parking lights

The parking lights can be used to help other road users see the vehicle if it is stopped or parked. Use the lighting ring on the steering wheel lever to turn on the parking lights.



Lighting ring in the parking light position.

Turn the lighting ring to the **EDGE** position to turn on the parking lights (the license plate lighting will also illuminate).

Canadian models: If the ignition is in the **II** position or the engine is running, the daytime running lights will illuminate instead of the front parking lights. With the lighting ring in this position, the parking lights will remain on regardless of what position the ignition is in.

US models: When AUTO mode is selected, the daytime running lights can be deactivated in the center display. The parking lights will also be

deactivated. In weak daylight or dark conditions, the parking lights and low beams will be illuminated.

In dark conditions, the rear parking lights also illuminate when the tailgate is opened to alert following traffic. This happens regardless of what position the lighting ring or ignition is in.

Related information

- Lighting panel and controls (p. 154)
- Ignition modes (p. 407)
- Replacing daytime running lights/front parking light bulbs (p. 596)

Daytime running lights

The vehicle has sensors that detect ambient lighting conditions. With the lighting ring in the AUTO position, the daytime running lights will always be activated when the ignition is in mode II or when the engine is running. In weak daylight or dark conditions, the headlights automatically switch to low beams.



Lighting ring in **AUTO** position.

With the steering wheel lever's lighting ring in the AUTO position, the daytime running lights (DRL¹) will illuminate when the vehicle is driven in daylight conditions. The headlights will switch automatically from daytime running lights to low beams in weak daylight or dark conditions. The headlights will also switch to low beams if the front fog lights* and/or rear fog light are activated.

US models: When AUTO mode is selected, the daytime running lights can be deactivated in the center display. The parking lights will also be deactivated. In weak daylight or dark conditions, the parking lights and low beams will be illuminated.

In the **US**: With the lighting ring in the 0 or $\exists 0$ 0 position, the daytime running lights will be off.

In **Canada**: With the lighting ring in the **0** or **5005** position, the daytime running lights will be on.

i NOTE

Volvo recommends use of Daytime Running Lights in the US. Its use is mandatory in Canada.

♠ WARNING

The system is an energy saving aid – it cannot in all situations determine when the daylight is too weak or not strong enough, e.g. when there is fog or rain.

The driver is always responsible for driving the vehicle with lighting that is safe for the traffic conditions and as specified by applicable traffic regulations.

Related information

- Lighting panel and controls (p. 154)
- Ignition modes (p. 407)
- Low beams (p. 157)
- Replacing daytime running lights/front parking light bulbs (p. 596)

Low beams

When driving with the lighting ring in the AUTO position, low beam will be automatically activated in weak daylight or dark conditions, when the ignition is in **II** position or when the engine is running.



Lighting ring in AUTO position.

With the lighting ring in the AUTO position, the low beams will be automatically activated if:

- the front fog lights* are activated
- the rear fog light is activated
- the rear and front fog lights are activated.

With the lighting ring in the position, the low beams will always be activated when the ignition is in mode II or when the engine is running.

¹ Daytime Running Lights

11 Tunnel detection

The vehicle will detect if it enters a tunnel and shift from daytime running lights to low beams.

Note that the left-hand steering wheel lever must be in AUTO position for tunnel detection to work.

Related information

- Lighting panel and controls (p. 154)
- Ignition modes (p. 407)
- Daytime running lights (p. 156)
- Replacing the low beam headlight bulbs (p. 595)

Using high beam

High beam is operated via the left-hand steering wheel lever. High beam is the vehicle's strongest lighting and should be used when driving in dark conditions, provided it does not blind other road users, to improve visibility.



Steering wheel lever with lighting ring.

High beam flash

Move the steering wheel lever slightly backward to the high beam flash mode. The high beams will illuminate until the lever is released.

High beams

The high beams can be activated when the lighting ring is in mode AUTO 2 or D. Activate high beams by moving the steering

wheel lever forward. Deactivate by moving the steering wheel lever backward.

When the high beams are activated, the ₹O symbol will be illuminated in the instrument panel.

- Lighting panel and controls (p. 154)
- Active high beam (p. 159)
- Replacing the high beam headlight bulbs (p. 595)

² When the low beams are on.

Active high beam

Active high beams is a function that uses camera sensors in the upper edge of the windshield to detect the headlights of approaching vehicles or the taillights of the vehicle directly ahead. When either of these is detected, the vehicle's headlights will automatically switch from high beams to low beams.



Active high beam is enabled by moving the lighting ring on the steering wheel lever to $\,$ AUTO $\,$.

The function can also detect street lighting. When the camera sensor no longer detects an approaching vehicle or a vehicle ahead, the headlights will return to high beams.

This function can be used in dark conditions when the vehicle's speed is approx. 20 km/h (approx. 12 mph) or higher.

If active high beams are deactivated when the high beams are on, the headlights will automatically switch to low beams.

When active high beams are activated, a white Mean symbol will be displayed in the instrument panel.

When high beams are on, the symbol will be blue. For LED headlights, this applies even if the high beams are partially dimmed, i.e. if the headlights are illuminated with slightly more than low beams.

Vehicles with halogen headlights

When the camera sensor no longer detects the headlights of approaching vehicles or the taillights of a vehicle ahead, the headlights will return to high beams after a second or so.

Vehicles with LED3 headlights*

If the active high beams are equipped with the auto on/off function⁴, the headlights will return to high beams a second or so after the camera sensor no longer detects the headlights of approaching vehicles or the taillights of a vehicle ahead.

Limitations for active high beams

The camera sensor on which the function is based has limitations.



If this symbol and the message **Active High Beam Temporarily**

unavailable is displayed in the instrument panel, switching between high

and low beams must be done manually. The lighting ring on the steering wheel lever can remain in the AUTO position. The SC symbol will go out when the message is displayed.



The same applies if this symbol along with the message Windscreen sensor Sensor blocked, see Owner's manual is displayed.

Active high beams may be temporarily unavailable in certain situations, e.g. heavy fog or rain. When active high beams become available again, or the windshield sensors are no longer blocked, the message will disappear and the SC symbol will be displayed.

MARNING

Automatic high beam is an aid in using the best possible light based on prevailing conditions.

The driver is always responsible for manually switching between high and low beam when traffic situations or weather conditions require this.

³ LED (Light Emitting Diode)

⁴ Depends on the vehicle's equipment level.

Related information

- Lighting panel and controls (p. 154)
- Using high beam (p. 158)
- Camera limitations (p. 330)

Using turn signals

The vehicle's turn signals are controlled using the left-side steering wheel lever. The turn signals flash three times or continuously, depending on how far up or down the lever is moved.



Turn signals.

Triple flash indicator

Move the steering wheel lever up or down to the first position and release. The turn signals will flash three times. This function can be activated/deactivated in the center display.

i NOTE

- This automatic flashing sequence can be interrupted by immediately moving the lever in the opposite direction.
- If the turn signal indicator flashes more quickly than normal, refer to the message in the instrument panel.

Continuous flashing sequence


Move the lever up or down as far as possible.

The lever will stop in its end position and can be moved back manually or automatically by moving the steering wheel.

- Hazard warning flashers (p. 164)
- Adjusting light functions via the center display (p. 155)
- Replacing front turn signal bulbs (p. 597)

Active Bending Lights*

Active Bending Lights (ABL) are designed to help provide maximum illumination in curves and intersections. Depending on equipment level, vehicles with LED⁵ headlights* may be equipped with Active Bending Lights.



Headlight pattern with function deactivated (left) and activated (right).

Active Bending Lights follow the movement of the steering wheel to help provide maximum illumination in curves and intersections, improving visibility for the driver.

The function is automatically activated when the engine is started. If a fault is detected in the system, the "" symbol will illuminate in the instrument panel and a message will be displayed.

The function is only active in weak daylight or dark conditions and only when the vehicle is moving and the low beams are on.

Deactivating/activating the function

The function is activated as the default factory setting and can be activated and deactivated in the center display's Function view:



Tap the **Active Bending Lights** button.

Related information

- Adjusting light functions via the center display (p. 155)
- Front fog lights/cornering illumination*
 (p. 161)

Front fog lights/cornering illumination*

The front fog lights have a stronger beam than low beam, making them particularly effective in fog.



Front fog lights button.

The fog lights can be switched on when the ignition is in II mode or when the engine is running and the lighting ring is in position AUTO , $\blacksquare D$ or $\blacksquare D \square \blacksquare D$.

Tap the button to activate or deactivate the function. The \Rightarrow symbol in the instrument panel comes on when the front fog lights are on.

The front fog lights turn off automatically when the start knob is turned clockwise to turn off the

⁵ LED (Light Emitting Diode)

ignition or when the lighting ring is turned to the position.



NOTE

Regulations concerning fog light use vary from country to country.

Cornering illumination*

The front fog lamps can include the cornering lights function, which temporarily illuminates the area diagonally in front of the car in the direction the steering wheel is turned on a sharp bend, or in the direction shown by the direction indicators.

The function is activated in weak daylight or dark conditions when the lighting ring is in AUTO or

pmode and the vehicle speed is less than about 30 km/h (about 20 mph).

Both cornering illumination are also illuminated as a complement to the taillights when reversing.

The function is activated as the default factory setting and can be activated and deactivated using the center display.


Related information

- Lighting panel and controls (p. 154)
- Ignition modes (p. 407)
- Rear fog light (p. 162)
- Active Bending Lights* (p. 161)

 Adjusting light functions via the center display (p. 155)

Rear fog light

The rear fog light is considerably brighter than ordinary taillights and should only be used to help other road users see the vehicle when visibility is reduced by conditions such as fog, snow, smoke or dust.



Rear fog light button.

The rear fog light consists of a light on the rear of the vehicle on the driver's side.

The rear fog light can only be used when:

- the ignition is in II mode or when the engine is running and the lighting ring is in position AUTO or D.
- the lighting ring is in the EDGE position and the front fog lights are on.

Press the button for On/Off. The O\(\pm\) symbol in the instrument panel illuminates when the rear fog light is on.

The rear fog light turns off automatically when:

- the start knob is turned clockwise to turn off the ignition or when the lighting ring is turned to the 0 position.
- the lighting ring is in the FOSE position and the front fog lights are turned off.



Regulations concerning rear fog light use vary from country to country.

Related information

- Lighting panel and controls (p. 154)
- Front fog lights/cornering illumination* (p. 161)
- Ignition modes (p. 407)

Brake lights

The brake lights are automatically illuminated when braking.

The brake lights illuminate when the brake pedal is depressed. They also illuminate when the brakes are automatically applied by one of the driver support systems.

Related information

- Emergency brake lights (p. 163)
- Brake functions (p. 408)

Emergency brake lights

The emergency brake lights are activated to warn following vehicles of hard braking.

This function causes an additional taillight on each side of the vehicle to illuminate.


The emergency brake lights are activated in the event of hard braking or if the ABS system is activated and the vehicle is traveling at a high speed.

After the driver decelerates to a low speed and then releases the brake, the brake lights resume their normal brightness.

- Brake lights (p. 163)
- Brakes (p. 409)
- Hazard warning flashers (p. 164)

Hazard warning flashers

Hazard warning flashers warn other road users by all of the vehicle's turn signals being activated at the same time. The function can be used to warn about a traffic hazard.



Hazard warning flashers button.

Press the button to activate the hazard warning flashers.



Regulations concerning the use of hazard warning flashers may vary from country to country.

Related information

- Emergency brake lights (p. 163)
- Using turn signals (p. 160)

Using home safe lighting

Some of the exterior lights remain on to illuminate the area around the vehicle. This is called home safe lighting.

To activate home safe lighting:

- 1. Switch off the ignition.
- 2. Push the left-side steering wheel lever toward the dashboard and release.
- Exit the vehicle and lock the doors.

When the function is activated, a symbol will be shown in the instrument panel and the parking lights, outer door handle lights* and the license plate lights will be illuminated.

The length of time home safe lighting remains illuminated can be set in the center display.

Related information

- Adjusting light functions via the center display (p. 155)
- Welcome Light (p. 164)

Welcome Light

Approach lighting is activated when the vehicle is unlocked and can be used to provide light as you walk toward the vehicle.

The function is activated when the remote key is used for unlocking. The parking lights, outer door handle lights*, license plate lights, interior ceiling lights, footwell lighting and trunk/cargo compartment lighting will be illuminated. If a door is opened while the function is activated, the lighting in the outer door handle* and the interior lighting will remain illuminated for a longer period of time.

This function can be activated and deactivated in the center display.

Related information

- Adjusting light functions via the center display (p. 155)
- Using home safe lighting (p. 164)
- Remote key (p. 237)

Interior Lighting

The interior is equipped with several different types of lighting to improve the experience. This includes reading lamps, glove box lighting and ground lighting.

All lighting in the passenger compartment can be turned on and off manually within 5 minutes after:

- the engine has been switched off and the ignition is in mode **0**.
- the vehicle is unlocked but the engine has not been started.

Front ceiling lighting



The controls in the ceiling console for the front reading lights and courtesy lighting.

- Reading light left side
- Passenger compartment lighting
- Courtesy lighting auto switch
- Reading light right side

Reading lights

The reading lights on the right and left sides are switched on and off by briefly pressing the buttons in the ceiling console. To adjust the brightness, press and hold the button.

Passenger compartment lighting

Briefly press the button in the ceiling console to switch on or off the footwell lighting and ceiling lighting.

Courtesy lighting auto switch

Activate the auto switch by briefly pressing the **AUTO** button in the ceiling console. With Auto activated, the indicator light in the button and the courtesy lighting come on and are turned off as follows.

The courtesy lighting:

- comes on when the vehicle is unlocked and when the ignition is switched off
- goes off when the engine is started and when the vehicle is locked
- comes on or goes off when a side door is opened or closed
- remains on for 2 minutes if any of the side doors are open.

Rear roof lighting

Reading lights are located in the rear section of the vehicle and can also be used as passenger compartment lighting. **4**◀



Reading lights over the rear seat⁶.



In vehicles with panoramic roofs*, there are two lamp units, one on each side of the ceiling.⁷

Briefly press the button on the light to turn on or off the reading lights. To adjust the brightness, press and hold the button.

Glove compartment lighting

The glove compartment lighting comes on or goes off when the glove compartment is opened or closed.

Vanity mirror lighting*

The vanity mirror lighting comes on or goes off when the cover over the mirror is opened or closed.

Ground lighting*

The ground lighting comes on or goes off when a door is opened or closed.

Doorsill lighting

The doorsill lighting comes on or goes off when a door is opened or closed.

Cargo compartment lighting

The cargo compartment lighting comes on or goes off when the tailgate is opened or closed.

Ambient Lighting

The ambient lighting comes on when the doors are opened and goes out when the vehicle is locked. Ambient lighting brightness can be adjusted in the center display and also fine-tuned using the thumb wheel in the dashboard.

Mood lighting*

The vehicle is equipped with several LEDs that provide faint lighting in various colors. This light-

ing is on when the engine is running. Mood lighting can be adjusted in the center display and also fine-tuned using the thumb wheel in the dashboard.

Lighting in the door storage compartments

Lighting in the door storage compartments comes on when the doors are opened and goes out when the vehicle is locked. The brightness can be adjusted using the thumb wheel in the dashboard.

Lighting in the front tunnel console cupholders

The lighting in front console cupholders switches on when the vehicle is unlocked and off when the vehicle is locked. The brightness can be adjusted using the thumb wheel in the dashboard.

- Adjusting interior lighting (p. 167)
- Lighting panel and controls (p. 154)
- Ignition modes (p. 407)
- Passenger compartment interior (p. 558)

⁶ There are also reading lights over the third row of seats*.

⁷ Does not apply to the third row of seats*.

Adjusting interior lighting

Illumination in the vehicle varies depending on ignition mode. The interior lighting can be adjusted with a thumb wheel in the dashboard and certain light functions can also be adjusted via the center display.



The thumb wheel on the dashboard at the steering wheel can be used to adjust the brightness of the display lighting, instrument lights, ambient lighting and mood lighting*

Adjust ambient decor lighting

- 1. Tap **Settings** in the Top view in the center display.
- 2. Tap My Car → Lights and Lighting → Interior Lighting.
- 3. Choose from among the following settings:
 - Under Ambient Light Intensity, select Off, Low or High.
 - Under Ambient Light Level, select Reduced or Full.

Adjusting mood lighting*

The vehicle is equipped with several LEDs that provide faint lighting in various colors. This lighting is on when the engine is running.

Changing the brightness

- 1. Tap **Settings** in the Top view in the center display.
- Tap My Car → Lights and Lighting → Interior Lighting → Interior Mood Lighting.
- 3. Under Interior Mood Light Intensity, select Off. Low or High.

Changing the color of the light

- 1. Tap **Settings** in the Top view in the center display.
- Tap My Car → Lights and Lighting → Interior Lighting

 Interior Mood Lighting.
- 3. Choose By Temperature or By Color to change the color of the light.

If By Temperature is selected, the light will change according to the temperature set for the passenger compartment.

If By Color is selected, the subcategory Theme Colors can be used to make further adjustments.

- Interior Lighting (p. 165)
- Adjusting light functions via the center display (p. 155)
- Ignition modes (p. 407)



Windows, glass and mirrors

The vehicle is equipped with controls for windows, glass and mirrors. Some of the windows in the car are laminated.

Laminated glass

The windshield and panoramic roof* have laminated glass. The glass is reinforced, which provides better protection against break-ins and improved soundproofing in the passenger compartment. Laminated glass is available as an option for some other glass surfaces.



The symbol shows the windows containing laminated class¹

Related information

- Pinch protection for windows and sun curtains (p. 170)
- Panoramic roof* (p. 176)
- Power windows (p. 171)
- Rearview/door mirrors (p. 173)
- Using sun curtains* (p. 173)
- Head-up display* (p. 144)
- Using the windshield wipers (p. 180)

- Using the windshield and headlight washers (p. 183)
- Activating and deactivating the heated windshield* (p. 226)
- Activating and deactivating the heated rear window and door mirrors (p. 227)

Pinch protection for windows and sun curtains

All windows and sun curtains* that are controlled electrically have a pinch protection function that is triggered if anything blocks them while they are opening or closing.

If pinch protection is activated, movement will stop and then retract automatically to approx. 50 mm (2 inches) from the point at which it was blocked (or to full ventilation position).

If pinch protection has been triggered, it is still possible to operate the window or sun curtain once more in the same direction without pinch protection, if this is done within 10 seconds after pinch protection has been triggered. It is thus still possible to override pinch protection when closing is interrupted (e.g. due to ice) by pressing and holding down the control until the window or sun curtain is fully closed.



WARNING

If the starter battery is disconnected, the function for automatic opening and closing must be reset to function correctly. A reset is required in order for the pinch protection to work.

¹ Does not apply to windshield and panoramic roof*, which are always laminated and therefore do not have this symbol.

Related information

- Reset procedure for pinch protection (p. 171)
- Operating the power windows (p. 172)
- Using sun curtains* (p. 173)
- Panoramic roof* (p. 176)

Reset procedure for pinch protection

If the power windows are not operating properly, you can try a reset procedure.

⚠ WARNING

If the starter battery is disconnected, the function for automatic opening and closing must be reset to function correctly. A reset is required in order for the pinch protection to work.

If the problem persists or if it affects the panoramic roof or sunroof, contact a workshop.²

Resetting a power window

- 1. Start with the window in the closed position.
- Then operate the window in manual mode three times upward toward the closed position.
 - > The system will be automatically initiated.

Related information

- Pinch protection for windows and sun curtains (p. 170)
- Operating the power windows (p. 172)
- Using sun curtains* (p. 173)

Power windows

The power windows are operated using the control panels found in the doors. The driver's door has controls for operating all windows and for activating the child safety locks.



Driver's door control panel.

- Electric child safety locks* that deactivate the controls in the rear doors to prevent the doors or windows from being opened from the inside.
- Rear window controls.
- 3 Front window controls.

The power windows have pinch protection. If there is any problem with the pinch protection, a rest procedure can be tested.

² An authorized Volvo workshop is recommended.

™ MARNING

Children, other passengers or objects can be trapped by the moving parts.

- Always operate the windows with caution.
- Do not allow children to play with the operating controls.
- Never leave a child alone in the vehicle.
- Remember to always cut the current to the power windows by setting the vehicle's electrical system to ignition mode 0 and then taking the remote key with you when leaving the vehicle.
- Never stick objects or body parts out through the windows, even if the vehicle electrical system is completely turned off.

Related information

- Operating the power windows (p. 172)
- Pinch protection for windows and sun curtains (p. 170)
- Reset procedure for pinch protection (p. 171)

Operating the power windows

All power windows can be operated using the control panel in the driver's door. The control panels in the other doors can be used to operate that particular door.

The power windows have pinch protection. If there is any problem with the pinch protection, a rest procedure can be tested.

⚠ WARNING

Children, other passengers or objects can be trapped by the moving parts.

- Always operate the windows with caution.
- Do not allow children to play with the operating controls.
- Never leave a child alone in the vehicle.
- Remember to always cut the current to the power windows by setting the vehicle's electrical system to ignition mode 0 and then taking the remote key with you when leaving the vehicle.
- Never stick objects or body parts out through the windows, even if the vehicle electrical system is completely turned off.



Operating the power windows.

- Operating manually. Move one of the controls slightly up or down. The power windows go up or down while the control is held in position.
- Operating with automatic controls. Move one of the controls up or down to its end position and release it. The window moves automatically to its fully closed/open position.

To use the power windows, the ignition must be in at least mode I or II. After the ignition has been switched off, the power windows can be operated for several minutes or until a door is opened. Only one control panel can be operated at a time.

It can also be operated using keyless opening* with the door handle.

WARNING

Make sure that no child or other passenger comes into contact with the windows as they are closing with keyless closing*.



(i) NOTE

One way to reduce the pulsating wind noise heard when the rear windows are open is to also open the front windows slightly.



NOTE

The windows cannot be opened at speeds over approx. 180 km/h (ca112 mph), but they can be closed

The driver is always responsible for following applicable traffic regulations.

Related information

- Power windows (p. 171)
- Pinch protection for windows and sun curtains (p. 170)
- Reset procedure for pinch protection (p. 171)
- Keyless locking and unlocking* (p. 252)
- Locking and unlocking using the remote key (p.239)
- Locking and unlocking from inside the vehicle (p. 255)

Using sun curtains*

Sun curtains are integrated into each of the rear doors.

In the rear door - manually operated



The illustration is generic - the design may vary.



Hook with locking mechanism

Pull up the sun curtain and hook it to the upper section of the door frame.

The window can be opened and closed when the sun curtain is being used.

Related information

- · Pinch protection for windows and sun curtains (p. 170)
- Reset procedure for pinch protection (p. 171)
- Power windows (p. 171)

Rearview/door mirrors

The rearview mirror and door mirrors can be used to improve the driver's visibility behind the vehicle.

Rearview mirror

The rearview mirror can be easily adjusted manually. The rearview mirror can be equipped with HomeLink*, auto-dim* and compass*.

Door mirrors



WARNING

The door mirror on the passenger side is curved to improve visibility. Objects in the mirror may appear farther away than they actually

The joystick in the drivers' door control panel is used to adjust the position of the door mirrors. There are also several automatic settings that can also be connected to the memory function buttons for the power seat*.

- HomeLink®* (p. 456)
- Compass (p. 459)
- Adjusting the rearview mirror dimming function (p. 174)
- Adjusting the door mirrors (p. 175)

- Storing memory settings in power front seats* (p. 190)
- Activating and deactivating the heated rear window and door mirrors (p. 227)

Adjusting the rearview mirror dimming function

Bright light entering the vehicle from behind, e.g. from the headlights of following vehicles, could reflect in the rearview mirror and door mirrors and cause a glare. Use the dimming function when light from behind is distracting.

Auto-dim

If bright light enters the vehicle from behind, the door mirrors will automatically dim. Auto-dim is always active when the engine is running, except when reverse gear is engaged.



(i) NOTE

When the level of sensitivity is changed, this change will not be noticeable immediately but will instead take effect after a short period of time.

The sensitivity level for dimming will affect both the rearview mirror and door mirrors.

- 1. Tap Settings in the Top view in the center display.
- Tap My Car → Mirrors and Convenience.
- 3. Under Rearview Mirror Auto Dimming. select Normal, Dark or Light.

The rearview mirror instead has two sensors one pointing forward and one pointing rearward which work together to identify and eliminate

glare. The forward-pointing sensor monitors ambient light, while the rearward-pointing sensor monitors light from the headlights of following vehicles.

For the door mirrors to be equipped with autodim, the rearview mirror must also be equipped with auto-dim



NOTE

If the sensors are obstructed by e.g. a parking permit, transponder, sunshade or objects on the seats or in the cargo compartment in a way that prevents light from reaching the sensors, the auto-dim function in the door and rearview mirrors will be reduced.


Related information

- Rearview/door mirrors (p. 173)
- Adjusting the door mirrors (p. 175)

Adjusting the door mirrors

To improve visibility to the rear, the door mirrors need to be adjusted to the driver's height and seating position. There are several automatic settings that can also be connected to the memory function buttons for the power seat*.

Controls used for door mirrors



Door mirror controls.

The joystick in the drivers' door control panel is used to adjust the position of the door mirrors.

- Press the L button for the left door mirror or R for the right door mirror. The button will light up.
- Adjust the position using the joystick located between the buttons.
- 3. Press the **L** or **R** button again. The light in the button will go out.

Resetting the mirrors' position

A mirror that has been moved out of position manually (e.g. hit or bumped into) must be electrically returned to its normal position for automatic folding to function properly.

- 1. Fold in the mirrors by pressing the **L** and **R** buttons at the same time.
- Open them again by pressing the L and R buttons at the same time.
- 3. Repeat the above procedure as needed.

The mirrors are now reset to their original positions.

Automatically folding door mirrors*

The door mirrors can be automatically folded when driving or parking in tight spaces.

- 1. Press the **L** and **R** buttons at the same time (ignition must be in mode **I** or higher).
- Release the buttons after about 1 second. The mirrors will automatically stop when they are completely folded in.

Open the mirrors by pressing $\bf L$ and $\bf R$ at the same time. The mirrors will automatically stop when they are completely open.

Tilting when parking³

The door mirrors can be tilted down to improve the driver's view along the sides of the vehicle (e.g. to see the curb while parking).

 Select reverse gear and press the L or R mirror button.

Please note that the button may need to be pressed twice depending on settings. When the door mirror is tilted down, the light in the button will flash. When reverse gear is engaged, the door mirrors will automatically start to move after 3 seconds and will reach their original position after about 8 seconds.

Automatically tilting when parking³

With this setting, the door mirrors will automatically tilt down when reverse gear is engaged. The folded position is preset and cannot be adjusted. To immediately return the door mirrors to their original position, press the $\bf L$ or $\bf R$ button twice.

- 1. Tap **Settings** in the center display's Top view.
- Tap My Car → Mirrors and Convenience.
- Under Exterior Mirror Tilt at Reverse, select Off, Driver, Passenger or Both to activate/deactivate and to select which mirror to tilt.

³ Only on models equipped with a power driver's seat with memory buttons*.

Automatic folding when the vehicle is locked*

The door mirrors automatically fold in when the vehicle is locked and open when the vehicle is unlocked using the remote key.

- Tap **Settings** in the center display's Top view.
- 2. Tap My Car → Mirrors and Convenience.
- Select Fold Mirror When Locked to activate/deactivate.

Related information

- Rearview/door mirrors (p. 173)
- Adjusting the rearview mirror dimming function (p. 174)
- Storing memory settings in power front seats* (p. 190)
- Activating and deactivating the heated rear window and door mirrors (p. 227)

Panoramic roof*

The panoramic roof is divided into two glass sections. The front section can be opened vertically at the rear edge (ventilation position) or horizontally (open position). The rear section cannot be moved.

The panoramic roof has a wind deflector and sun curtain made of perforated fabric (located beneath the glass sections) for extra protection in e.g. bright sunlight.



The panoramic roof and sun curtain are operated using the controls in the ceiling.

It can also be operated using keyless opening* with the door handle.

To operate the panoramic roof and sun curtain, the ignition must be in mode I or II.

↑ WARNING

Children, other passengers or objects can be trapped by the moving parts.

- Always operate the windows with caution.
- Do not allow children to play with the operating controls.
- Never leave a child alone in the vehicle.
- Remember to always cut the current to the power windows by setting the vehicle's electrical system to ignition mode 0 and then taking the remote key with you when leaving the vehicle.
- Never stick objects or body parts out through the windows, even if the vehicle electrical system is completely turned off.

!) CAUTION

- Do not open the panoramic roof when load carriers are installed.
- Never place heavy objects on the panoramic roof.

(!) CAUTION

- Remove ice and snow before opening the panoramic roof.
- Do not operate the panoramic roof if it is frozen in place.

Wind blocker



The panoramic roof is equipped with a wind blocker that folds up when the roof is open.

Related information

- Operating the panoramic roof* (p. 177)
- Auto closing the panoramic roof* sun curtain (p. 179)
- Pinch protection for windows and sun curtains (p. 170)
- Keyless locking and unlocking* (p. 252)
- Locking and unlocking using the remote key (p. 239)
- Locking and unlocking from inside the vehicle (p. 255)

Operating the panoramic roof*

The panoramic roof and sun curtain are operated using a control in the ceiling panel, and both are equipped with pinch protection.

Children, other passengers or objects can be trapped by the moving parts.

- Always operate the windows with caution.
- Do not allow children to play with the operating controls.
- Never leave a child alone in the vehicle.
- Remember to always cut the current to the power windows by setting the vehicle's electrical system to ignition mode 0 and then taking the remote key with you when leaving the vehicle.
- Never stick objects or body parts out through the windows, even if the vehicle electrical system is completely turned off.

! CAUTION

- Do not open the panoramic roof when load carriers are installed.
- Never place heavy objects on the panoramic roof.

(!) CAUTION

- Remove ice and snow before opening the panoramic roof.
- Do not operate the panoramic roof if it is frozen in place.

To operate the panoramic roof and sun curtain, the ignition must be in mode I or II.

It can also be operated using keyless opening* with the door handle.

∕↑ WARNING

Make sure that no child or other passenger comes into contact with the windows as they are closing with keyless closing*.

! CAUTION

Check that the panoramic roof is properly closed when closing.

The movement of the roof will stop if the control is released during manual operation or when the glass has reached the comfort⁴ or fully open/closed position. The movement of both the panoramic roof and the sun curtain is also stopped if the control in the ceiling is operated again in the

⁴ The comfort position is a position which helps keep wind and resonance sounds to a comfortably low level.

d direction opposite that of the current direction of movement.


The panoramic roof and sun curtain are also equipped with pinch protection.



NOTE

For manual opening, the sun curtain must be completely open before the panoramic roof can be opened. For the reverse procedure, the panoramic roof must be completely closed before the sun curtain can be completely closed.

Opening and closing ventilation position




Ventilation position, rear edge raised.

- Open by pushing the control upward once.
- Close by pushing the control downward once.

When ventilation mode is selected, the rear edge of the front section of the roof is raised. If the sun curtain is fully closed when ventilation position is selected, it will automatically open approx. 50 mm (approx. 2 inches).

If the panoramic roof is closed from the ventilation position, the sun curtain will also automatically close.

Fully opening and closing the panoramic roof with the control in the ceiling



- Operation, manual mode
- Operation, automatic mode

Manual operation

- 1. To open the sun curtain, pull the control backward to the manual open mode.
- To open the panoramic roof to the comfort position, pull the control backward a second time to the manual opening position.
- To open the panoramic roof fully, pull the control backward a third time to the manual opening position.

Close by repeating the above procedure in reverse - push the control forward/down to the manual closing position.

Auto operation

- To open the sun curtain to the fully open position, pull the control backward to the auto open mode and release.
- To open the panoramic roof to the comfort position, pull the control backward a second time to the automatic opening position and release.
- To open the panoramic roof fully, pull the control backward a third time to the automatic opening position and release.

Close by repeating the above procedure in reverse - push the control forward/down to the auto close position.

Automatic operation - rapid opening or closing

The panoramic roof and sun curtain can be opened or closed simultaneously:

- Open press the control backward twice to the automatic operation position and release.
- Close press the control forward/down twice to the automatic operation position and release.

Related information

- Panoramic roof* (p. 176)
- Auto closing the panoramic roof* sun curtain (p. 179)
- Pinch protection for windows and sun curtains (p. 170)

- Keyless locking and unlocking* (p. 252)
- Locking and unlocking using the remote key (p. 239)
- Locking and unlocking from inside the vehicle (p. 255)

Auto closing the panoramic roof* sun curtain

With this function, the sun curtain closes automatically 15 minutes after the car has been locked if it is parked in hot weather. This is done to lower the passenger compartment temperature and protect the upholstery against being bleached by the sun.

The function is deactivated as the default factory setting and can be activated or deactivated using the center display.

- Tap **Settings** in the Top view in the center display.
- Tap My Car → Locking.

Select Auto Close Sunroof Curtain to activate/deactivate.

i NOTE


The sun curtain also closes when all windows are closed with keyless closing*.

- Panoramic roof* (p. 176)
- Operating the panoramic roof* (p. 177)
- Pinch protection for windows and sun curtains (p. 170)
- Keyless locking and unlocking* (p. 252)

- Locking and unlocking using the remote key (p. 239)
- Locking and unlocking from inside the vehicle (p. 255)

Using the windshield wipers

The windshield wipers clean the windshield. The right-side steering wheel lever is used to adjust windshield wiper settings.



Right-hand steering wheel lever.

1 Thumb wheel, used to set rain sensor sensitivity and interval wiper speed.

Single sweep



Move the lever down and release for a single sweep.

Wipers off



Move the lever to position **0** to turn off the windshield wipers.

Interval wipers

ers are selected.

Set the number of sweeps per time unit with the thumb wheel when interval wip-

Continuous wipers



Move the lever upward for the wipers to operate at normal speed.



Move the lever upward again for the wipers to operate at high speed.

! CAUTION

Before activating the wipers, make sure that the wiper blades are not frozen in place and that any snow or ice on the windshield and rear window has been scraped away.

! CAUTION

Use plenty of washer fluid when the wipers clean the windshield. The windshield must be wet when the windshield wipers are working.

Related information

- Using the rain sensor (p. 181)
- Using the windshield and headlight washers (p. 183)
- Using automatic rear window wiping when backing up (p. 185)
- Heated windshield washer nozzles* (p. 181)
- Using the rain sensor's memory function (p. 182)
- Using the rear window wiper/washer (p. 184)

- Filling washer fluid (p. 632)
- Windshield wipers in the service position (p. 631)
- Replacing windshield wiper blades (p. 630)
- Changing rear window wipers (p. 629)

Heated windshield washer nozzles*


The washer nozzles are heated automatically in cold weather to prevent the washer fluid from freezing.

Related information

- Using the rain sensor (p. 181)
- Using the windshield and headlight washers (p. 183)
- Using automatic rear window wiping when backing up (p. 185)
- Using the rain sensor's memory function (p. 182)
- Using the rear window wiper/washer (p. 184)
- Filling washer fluid (p. 632)
- Windshield wipers in the service position (p. 631)
- Replacing windshield wiper blades (p. 630)
- Changing rear window wipers (p. 629)
- Using the windshield wipers (p. 180)

Using the rain sensor

The rain sensor monitors the amount of water on the windshield and automatically starts the windshield wipers. Rain sensor sensitivity can be adjusted using the thumb wheel on the righthand steering wheel lever.



Right-hand steering wheel lever.

- 1 Rain sensor button
- Thumb wheel, sensitivity/interval wiper speed

When the rain sensor is activated, the 🎾 rain sensor symbol will be displayed in the instrument panel.

Activating the rain sensor

When the rain sensor is activated, the engine must be running or the ignition must be in mode I or II. The windshield wiper lever must also be in position **0** or in the single sweep position.

If the lever is pressed down, the wipers will make additional sweeps across the windshield.

Turn the thumb wheel upward for increased sensitivity and downward for decreased sensitivity. The wipers will make one extra sweep when the thumb wheel is turned upward.

Deactivate the rain sensor

Deactivate the rain sensor by pressing the Prain sensor button or moving the lever upward to another wiper mode.

The rain sensor is automatically deactivated in ignition mode ${\bf 0}$ or when the engine is switched off.

The rain sensor is also automatically deactivated when the wiper blades are put in the service position. The rain sensor will reactivate when service mode is switched off.

! CAUTION

The windshield wipers may start inadvertently and be damaged in automatic car washes. Deactivate the rain sensor when the engine is running or when the ignition is in mode I or II. The symbol in the instrument panel will go out.

Related information

- Using the windshield and headlight washers (p. 183)
- Using automatic rear window wiping when backing up (p. 185)
- Heated windshield washer nozzles* (p. 181)
- Using the rain sensor's memory function (p. 182)
- Using the rear window wiper/washer (p. 184)
- Filling washer fluid (p. 632)
- Windshield wipers in the service position (p. 631)
- Replacing windshield wiper blades (p. 630)
- Changing rear window wipers (p. 629)
- Using the windshield wipers (p. 180)

Using the rain sensor's memory function

The rain sensor monitors the amount of water on the windshield and automatically starts the windshield wipers.

Activating/deactivating memory function

The rain sensor's memory function can be set to activate so that the rain sensor button does not need to be pressed each time the engine is started:

- 1. Tap **Settings** in the Top view in the center display.
- Tap My Car → Wipers.
- Select Rain Sensor Memory to activate/ deactivate the memory function.

Related information

- Using the rain sensor (p. 181)
- Using the windshield and headlight washers (p. 183)
- Using automatic rear window wiping when backing up (p. 185)
- Heated windshield washer nozzles* (p. 181)
- Using the rear window wiper/washer (p. 184)
- Filling washer fluid (p. 632)

- Windshield wipers in the service position (p. 631)
- Replacing windshield wiper blades (p. 630)
- Changing rear window wipers (p. 629)
- Using the windshield wipers (p. 180)

Using the windshield and headlight washers

The windshield and headlight washers clean the windshield and headlights. Use the right-side steering wheel lever to start the windshield and headlight washers.

Starting the windshield and headlight washers



Washing function, right-hand steering wheel lever.

- Move the right-hand steering wheel lever toward the steering wheel to start the windshield and headlight washers.
 - > After the lever is released, the wipers make several extra sweeps.

CAUTION

Avoid activating the washer system when it is frozen or the fluid reservoir is empty. Otherwise, there is a risk of damaging the pump.

Headlight washer*

To save washer fluid, the headlights are washed automatically according to a defined interval when the headlights are on.

Reduced washing

When there is about 1 liter (1 gt) of washer fluid left in the reservoir and the Washer fluid Level low, refill message is displayed in the instrument panel together with the symbol, the washer fluid supply to the headlights is cut off. This is to prioritize windshield cleaning and visibility through it. The headlights are only washed if high or low beam is on.

- Using the rain sensor (p. 181)
- Using automatic rear window wiping when backing up (p. 185)
- Heated windshield washer nozzles* (p. 181)
- Using the rain sensor's memory function (p. 182)
- Using the rear window wiper/washer (p. 184)
- Filling washer fluid (p. 632)

WINDOWS, GLASS AND MIRRORS

- Windshield wipers in the service position (p. 631)
- Replacing windshield wiper blades (p. 630)
- Changing rear window wipers (p. 629)
- Using the windshield wipers (p. 180)


Using the rear window wiper/ washer

The rear window wiper/washer cleans the rear window. Use the right-side steering wheel lever to start and control the wiper/washer.

Activating the rear window wiper/ washer

(i) NOTE

The rear window wiper is equipped with overheating protection that switches off the motor wiper if it becomes overheated. The rear window wiper can be operated again after a cooling-down period.



- for interval rear window wiper. Select
 - for continuous rear window Select wiper.

Move the right-side steering wheel lever forward to wash/wipe the rear window.

Related information

- Using the rain sensor (p. 181)
- Using the windshield and headlight washers (p. 183)
- Using automatic rear window wiping when backing up (p. 185)
- Heated windshield washer nozzles* (p. 181)
- Using the rain sensor's memory function (p. 182)
- Filling washer fluid (p. 632)
- Windshield wipers in the service position (p.631)
- Replacing windshield wiper blades (p. 630)
- Changing rear window wipers (p. 629)
- Using the windshield wipers (p. 180)

Using automatic rear window wiping when backing up

If reverse gear is engaged while the windshield wipers are on, the rear window wipers will start. This function is deactivated when a different gear is selected.

- 1. Tap **Settings** in the Top view in the center display.
- Tap My Car → Wipers.
- Select Auto Rear Wiper to activate/deactivate automatic rear window wiping when backing up.

If the rear window wipers are already in continuous wiper mode, no change will be made.

- Using the rain sensor (p. 181)
- Using the windshield and headlight washers (p. 183)
- Heated windshield washer nozzles* (p. 181)
- Using the rain sensor's memory function (p. 182)
- Using the rear window wiper/washer (p. 184)
- Filling washer fluid (p. 632)
- Windshield wipers in the service position (p. 631)
- Replacing windshield wiper blades (p. 630)

- Changing rear window wipers (p. 629)
- Using the windshield wipers (p. 180)



Manual front seats

The power front seats can be adjusted in a number of different ways for optimal comfort and ergonomics.



- Raise/lower the front edge of the seat cushion* by moving the control up/down.
- Change the length of the seat cushion* by pulling up the lever and moving the cushion forward/backward.
- Move the seat forward/backing by lifting the handle and moving the seat to a suitable distance from the steering wheel and pedals. Check to make sure the seat is securely locked into place after its setting has been changed.
- 4 Adjust lumbar support* by pressing the button up/down/forward/rearward.

- Raise/lower the seat by moving the control up/down.
- 6 Change the backrest tilt by turning the knob on the backrest.

 Do not adjust the seat while driving. The seat should be adjusted so that the driver can comfortably reach and operate the pedals and gear selector.

After adjusting the seat, make sure that it is securely locked into position before starting to drive.

Related information

- Power front seats* (p. 189)
- Adjusting the power front seats* (p. 189)
- Storing memory settings in power front seats* (p. 190)
- Using stored memory in a powered front seat (p. 191)
- Adjusting front seat massage settings* (p. 192)
- Adjusting front seat cushion length (p. 193)
- Front seat massage settings* (p. 192)
- Adjusting front seat side bolster settings* (p. 194)

- Adjusting front seat lumbar support* (p. 194)
- Adjusting the passenger seat from the driver's seat* (p. 195)

¹ Only applies to the driver's seat.

Power front seats*

The power front seats can be adjusted in a number of different ways for optimal comfort and ergonomics. The power seats can be moved forward/backward and up/down. The height and length* of the seat cushion and the tilt of the backrest can be adjusted. Lumbar support can be adjusted up, down, forward and backward.

The power seats have an overload protector that is triggered if a seat is blocked by any object. If this occurs, remove the object and attempt to adjust the seat again.

The power seats can be adjusted for a certain period of time after the door is unlocked without the engine running. The seats can always be adjusted while the engine is running. They can also be adjusted for a short period after the engine is turned off.


Related information

- Manual front seats (p. 188)
- Adjusting the power front seats* (p. 189)
- Storing memory settings in power front seats* (p. 190)
- Using stored memory in a powered front seat (p. 191)
- Adjusting front seat massage settings* (p. 192)
- Adjusting front seat cushion length (p. 193)
- Front seat massage settings* (p. 192)

- Adjusting front seat side bolster settings* (p. 194)
- Adjusting front seat lumbar support* (p. 194)
- Adjusting the passenger seat from the driver's seat* (p. 195)

Adjusting the power front seats*

Set the desired sitting position using the control on the front seat's seating section. To activate the multifunction control and set the various convenience functions, turn the control upward/downward.



- To activate the multi-function control and set the various comfort functions, turn the control* upwards/downwards.
- Raise/lower the front edge of the seat cushion by moving the control up/down.
- **3** Raise/lower the seat by moving the control up/down.
- Move the seat forward/rearward by moving the control forward/rearward.
- 6 Change the backrest tilt by moving the control forward/backward.

Only one movement (forward/rearward/up/ down) can be performed at a time.

The front seat backrests cannot be folded down completely.


Related information

- Manual front seats (p. 188)
- Power front seats* (p. 189)
- Storing memory settings in power front seats* (p. 190)
- Using stored memory in a powered front seat (p. 191)
- Adjusting front seat massage settings* (p. 192)
- Adjusting front seat cushion length (p. 193)
- Front seat massage settings* (p. 192)
- Adjusting front seat side bolster settings* (p. 194)
- Adjusting front seat lumbar support* (p. 194)
- Adjusting the passenger seat from the driver's seat* (p. 195)

Storing memory settings in power front seats*

The memory function can be used to store the settings for the seat, door mirrors and head-up display*.

Three different settings can be stored using the memory function. The memory function controls are located on one or both of the front doors*.



- Memory button
- Memory button
- Memory button
- Button M for storing a setting.

Storing a position

1. Adjust the seat, door mirrors and head-up display to the desired position.

- Press and hold the **M** button. The indicator light in the button will illuminate.
- Within three seconds, press and hold the 1, 2 or 3 button.
 - > When the position has been stored in the memory button, an audible signal will sound and the indicator light in the M button will go out.

If none of the memory buttons are pressed within three seconds, the ${\bf M}$ button will go out and no position will be stored.

The seat must be adjusted again before a new memory position can be stored.

Related information

- Manual front seats (p. 188)
- Power front seats* (p. 189)
- Adjusting the power front seats* (p. 189)
- Using stored memory in a powered front seat (p. 191)
- Adjusting front seat massage settings* (p. 192)
- Adjusting front seat cushion length (p. 193)
- Front seat massage settings* (p. 192)
- Adjusting front seat side bolster settings* (p. 194)
- Adjusting front seat lumbar support* (p. 194)
- Adjusting the passenger seat from the driver's seat* (p. 195)

Using stored memory in a powered front seat

The memory function can be used to store the settings for the seat, door mirrors and head-up display*.

Using a stored position

A stored position can be used with the front door open or closed:

Front door open

Briefly press one of the memory buttons (1-3). The seat, door mirrors and head-up display will move and stop at the positions stored in that button.

Front door closed

Press and hold one of the memory buttons (1-3) until the seat, door mirrors and headup display stop in the positions stored in that memory button.

If the memory button is released, the seat, door mirrors and head-up display will stop moving.

WARNING

- Because the front seats can be adjusted with the ignition off, children should never be left unattended in the vehicle.
- Movement of the seat can be STOPPED at any time by pressing any button on the power seat control panel.
- Do not adjust the seat while driving.
- The seat should be adjusted so that the brake pedal can be depressed fully. In addition, position the seat as far rearward as comfort and control allow.
- The seat rails on the floor must not be obstructed in any way when the seat is in motion.

- Manual front seats (p. 188)
- Power front seats* (p. 189)
- Adjusting the power front seats* (p. 189)
- Storing memory settings in power front seats* (p. 190)
- Adjusting front seat massage settings* (p. 192)
- Adjusting front seat cushion length (p. 193)
- Front seat massage settings* (p. 192)
- Adjusting front seat side bolster settings* (p. 194)

- Adjusting front seat lumbar support* (p. 194)
- Adjusting the passenger seat from the driver's seat* (p. 195)

Front seat massage settings*

The settings can be adjusted using either the multifunction control* on the seat or the center display. The adjustment settings are shown in the center display.



Multifunction control, located on the side of the seat cushion.

Massage settings

The following massage settings are available:

- On/Off: Select On/Off to turn on/off the massage function.
- Programs 1-5: There are 5 preset massage programs. Select Swell, Tread, Advanced, Lumbar or Shoulder.
- Intensity: Select Low, Normal or High.
- Speed: Select Slow, Normal or Fast.

Restarting the massage function

The massage function turns off automatically after 20 minutes. The function is reactivated manually.

- Tap Restart, which is displayed in the center display, to restart the selected massage program.
 - > The massage program will restart. If no selection is made, the message will be stored in Top view.

Related information

- Manual front seats (p. 188)
- Power front seats* (p. 189)
- Adjusting the power front seats* (p. 189)
- Storing memory settings in power front seats* (p. 190)
- Using stored memory in a powered front seat (p. 191)
- Adjusting front seat massage settings* (p. 192)
- Adjusting front seat cushion length (p. 193)
- Adjusting front seat side bolster settings* (p. 194)
- Adjusting front seat lumbar support* (p. 194)
- Adjusting the passenger seat from the driver's seat* (p. 195)

Adjusting front seat massage settings*

The settings for the multifunctional seats can be adjusted using either the mutifunction control on the seat or the center display. The adjustment settings are shown in the center display*.

Adjusting front seat massage settings*

The front seat backrests have a massage function. Air-filled cushions provide the massaging action and a number of settings are available.

The massage function can only be activated when the engine is running.

- Activate the multifunction control by turning the control upward/downward. The seat settings view will appear in the center display.
- 2. Select Massage in the seat settings view.
- 3. Select massage settings by tapping the center display or by moving the cursor up/down using the multifunction control's upper/lower buttons. Change a setting in the selected function by tapping the arrows on the center display or by using the multifunction control's front/rear buttons.

Related information

- Manual front seats (p. 188)
- Power front seats* (p. 189)
- Adjusting the power front seats* (p. 189)

- Storing memory settings in power front seats* (p. 190)
- Using stored memory in a powered front seat (p. 191)
- Adjusting front seat cushion length (p. 193)
- Front seat massage settings* (p. 192)
- Adjusting front seat side bolster settings* (p. 194)
- Adjusting front seat lumbar support* (p. 194)
- Adjusting the passenger seat from the driver's seat* (p. 195)

Adjusting front seat cushion length

The settings can be adjusted using either the multifunction control* on the seat or the center display. The adjustment settings are shown in the center display.



Multifunction control, located on the side of the seat cushion.

Turn the control up or down to activate the multifunction control.

Adjusting the seat cushion

The length of the seat cushion can be adjusted using the multifunction control on the side of the seat.

1. Activate the multifunction control by turning the control upward/downward. The seat settings view will appear in the center display.

- Select Cushion extension in the seat settinas view.
 - Push in the front part of the four-way button (the round one) to extend the seat cushion.
 - Press the rear part of the four-way button to shorten the seat cushion.

- Manual front seats (p. 188)
- Power front seats* (p. 189)
- Adjusting the power front seats* (p. 189)
- Storing memory settings in power front seats* (p. 190)
- Using stored memory in a powered front seat (p. 191)
- Adjusting front seat massage settings* (p. 192)
- Front seat massage settings* (p. 192)
- Adjusting front seat side bolster settings* (p. 194)
- Adjusting front seat lumbar support* (p. 194)
- Adjusting the passenger seat from the driver's seat* (p. 195)

Adjusting front seat side bolster settings*

The settings can be adjusted using either the multifunction control* on the seat or the center display. The adjustment settings are shown in the center display.



Multifunction control, located on the side of the seat cushion.

The side bolsters in the front seat backrests can be inflated/deflated to adjust the amount of support provided.

To adjust the side bolsters:

 Activate the multifunction control by turning the control upward/downward 1. The seat settings view will appear in the center display.

- 2. Select **Side bolsters** in the seat settings view.
 - Press the front part of the four-way button to increase side bolster support 2.
 - Press the rear part of the four-way button to decrease side bolster support.

Related information

- Manual front seats (p. 188)
- Power front seats* (p. 189)
- Adjusting the power front seats* (p. 189)
- Storing memory settings in power front seats* (p. 190)
- Using stored memory in a powered front seat (p. 191)
- Adjusting front seat massage settings* (p. 192)
- Adjusting front seat cushion length (p. 193)
- Front seat massage settings* (p. 192)
- Adjusting front seat lumbar support* (p. 194)
- Adjusting the passenger seat from the driver's seat* (p. 195)

Adjusting front seat lumbar support*

Activate the multifunction control* by turning the control upward/downward. The seat settings view will appear in the center display.



Multifunction control, located on the side of the seat cushion.

Lumbar support can be adjusted in four directions by pressing the four-way lumbar support button on the side of the seat cushion. The lumbar support can be adjusted forward/backward and up/down.

Adjusting front seat lumbar support*

To adjust the lumbar support:

 Activate the multifunction control by turning the control upward/downward. The seat settings view will appear in the center display.

- 2. Select Lumbar in the seat settings view.
 - Press the four-way button (the round button) up/down to move the lumbar support upward/downward.
 - Press the front part of the four-way button to increase lumbar support.
 - Press the rear part of the four-way button to decrease lumbar support.

Related information

- Manual front seats (p. 188)
- Power front seats* (p. 189)
- Adjusting the power front seats* (p. 189)
- Storing memory settings in power front seats* (p. 190)
- Using stored memory in a powered front seat (p. 191)
- Adjusting front seat massage settings* (p. 192)
- Adjusting front seat cushion length (p. 193)
- Front seat massage settings* (p. 192)
- Adjusting front seat side bolster settings* (p. 194)
- Adjusting the passenger seat from the driver's seat* (p. 195)

Adjusting the passenger seat from the driver's seat*

The front passenger seat can be adjusted from the driver's seat.

Activating the function

The function is activated via the function view in the center display:



Tap the **Adjust Passenger Seat** button to activate.

Adjust passenger seat

The driver must adjust the passenger seat within 10 seconds of activating the function. If no adjustment is made within this time, the function will be deactivated.

The driver adjusts the passenger seat using the controls on the driver's seat:



- 1 Move the passenger seat forward/rearward by moving the control forward/rearward.
- Change the backrest tilt of the passenger seat by moving the control forward/backward.

- Manual front seats (p. 188)
- Power front seats* (p. 189)
- Adjusting the power front seats* (p. 189)
- Storing memory settings in power front seats* (p. 190)
- Using stored memory in a powered front seat (p. 191)
- Adjusting front seat massage settings* (p. 192)
- Adjusting front seat cushion length (p. 193)
- Front seat massage settings* (p. 192)

- Adjusting front seat side bolster settings* (p. 194)
- Adjusting front seat lumbar support* (p. 194)

Folding the second row backrests

The second row of seats has three individual seating positions. The backrests can be folded down separately.

- Adjust the seat and ensure it locks into position before driving. Use caution when adjusting the seat. Uncontrolled or careless adjustments could lead to injury.
- Long objects must always be securely tied down to help prevent injury or damage in the event of sudden braking.
- Always turn off the engine and apply the parking brake when loading or unloading the vehicle.
- Put the gear selector in P to help prevent the gear selector from being inadvertently moved.

(!) CAUTION

When the backrest is folded down, make sure there are no objects in the rear seat, and the seat belts are not buckled. Otherwise there is a risk of damage to the upholstery.

! CAUTION

The seat cushion of the integrated child restraint* must be in the stowed position before the center seat backrest can be folded down.

The armrest* in the center seat must be raised before the seat backrest is folded down.

If the vehicle has private locking*, the ski hatch must be closed before the seat backrest is folded down.

i NOTE

The front seats may need to be pushed forward and/or the backrest adjusted so that the rear seat backrests can be fully lowered.

The rear seats may also need to be moved rearward.

The seats in the second row must be in the upright position before they can be folded down completely. They should not be folded down when they are tilted forward to access the third row of seats.

Center seat



To fold down the backrest:

- 1. Fold down the head restraint manually.
- 2. Pull the strap on the right side of the center seat.
- Fold the backrest down until it locks into position. The seat cushion will move downward/forward when the backrest is folded down and create a flat surface.

To return the backrest to the upright position:

- 1. Pull the strap.
- 2. Fold up the backrest and release the strap. Push the backrest until it locks into position.
- 3. Adjust the head restraint if necessary.

Outboard seats



To fold down the backrest:

(\mathbf{i})

NOTE

When folding down a second row seat backrest, always start from the seat's normal upright position. Do not use the handle for folding down the seat when the seat is in the position for accessing the third row.

 Pull up and hold the handle on the side of the seat while the backrest is being folded down.

- Make sure that backrest and head restraint do not come in contact with the seat in front while the backrest is being folded down. Fold the backrest down until it locks into position.
 - The seat cushion will move downward/ forward when the backrest is folded down and create a flat surface. The head restraint folds down automatically when the backrest is lowered.

↑ WARNING

Make sure the backrest is securely locked into position after it is folded down.

To return the backrest to the upright position:

- Pull up and hold the handle on the side of the seat while the backrest is being folded up.
- Make sure that backrest and head restraint do not come in contact with the seat in front while the backrest is being folded up. Fold up the backrest and release the handle.
- 3. Press the backrest until it locks into position.
- I. Fold up the head restraint manually.

Make sure that the rear seat backrest and head restraint are locked securely in place after the seat is folded up.

The head restraints at the outer seats must always be raised when there is a passenger in one of these spots of the rear seat.

∴ WARNING

The head restraints on the outboard secondrow seats must always be folded up when there are passengers in the third row of seats*.

Related information

- Adjusting the second row head restraints (p. 198)
- Moving the second row seats forward/rearward* (p. 199)
- Adjusting the second row backrest tilt (p. 200)
- Getting into and out of the third row of seats* (p. 201)
- Folding the third row backrests* (p. 202)

Adjusting the second row head restraints

Adjust the center head restraint in the rear seat to the seat occupant's height. Fold down the outboard head restraints* to improve rear visibility.

Adjusting the center head restraint



The center head restraint should be adjusted to suit the passenger's height. The entire back of the head should be covered if possible. Manually move the restraint up or down as needed.



To lower the restraint, press and hold the button (located between the backrest and the head restraint, see illustration) while carefully lowering the head restraint.

MARNING

The center seat head restraint must be in its lowest position when the seat is not occupied. When the center seat is occupied, the head restraint must be correctly adjusted to the passenger's height, covering the entire back of the head if possible.

Electrically folding down the rear seat's outboard head restraints*



The outer head restraints can be folded via the center display's function view. The head restraint can be folded down when the vehicle is in ignition mode 0.



Tap the Headrest Fold button to activate/deactivate folding.

Manually push the head restraint until it clicks into position.

WARNING

Do not lower the head restraint if there are passengers in any of the rear seats.

WARNING

The head restraint must be locked in the upright position after it has been folded up.

WARNING

The head restraints on the outboard secondrow seats must always be folded up when there are passengers in the third row of seats*.

Related information

- Folding the second row backrests (p. 196)
- Moving the second row seats forward/rearward* (p. 199)
- Adjusting the second row backrest tilt (p. 200)
- Getting into and out of the third row of seats* (p. 201)
- Folding the third row backrests* (p. 202)

Moving the second row seats forward/rearward*

In vehicles with 7 seats*, the seats in the second row can be moved forward or rearward individually to help optimize legroom for passengers in the second and third rows. The second row seats cannot be moved forward or backward in 5-seat models.



- Lift the handle under the seat.
- Move the seat forward or backward to the desired position.
- 3. Release the handle and press the seat until it locks into position.

Check to make sure the seat is securely locked into place after its position has been changed.

™ MARNING

- Adjust the seat and ensure it locks into position before driving. Use caution when adjusting the seat. Uncontrolled or careless adjustments could lead to injury.
- Long objects must always be securely tied down to help prevent injury or damage in the event of sudden braking.
- Always turn off the engine and apply the parking brake when loading or unloading the vehicle.
- Put the gear selector in P to help prevent the gear selector from being inadvertently moved.

Related information

- Folding the second row backrests (p. 196)
- Adjusting the second row head restraints (p. 198)
- Adjusting the second row backrest tilt (p. 200)
- Getting into and out of the third row of seats* (p. 201)
- Folding the third row backrests* (p. 202)

Adjusting the second row backrest tilt

Backrest tilt can be adjusted separately for each seat in the second row.

Center seat



- 1. Pull the strap on the right side of the center seat.
- Adjust backrest tilt forward/backward by decreasing/increasing pressure on the backrest.
- Release the strap to lock the backrest in its new position and press on the backrest until the lock engages.

Check to make sure the seat is securely locked into place after its position has been changed.

Outboard seats



- 1. Pull the handle on the side of the seat upward.
- Adjust backrest tilt forward/backward by decreasing/increasing pressure on the backrest.
- Release the handle to lock the backrest in its new position and press on the backrest until the lock engages.

Check to make sure the seat is securely locked into place after its position has been changed.

- Adjust the seat and ensure it locks into position before driving. Use caution when adjusting the seat. Uncontrolled or careless adjustments could lead to injury.
- Long objects must always be securely tied down to help prevent injury or damage in the event of sudden braking.
- Always turn off the engine and apply the parking brake when loading or unloading the vehicle.
- Put the gear selector in P to help prevent the gear selector from being inadvertently moved.

Related information

- Folding the second row backrests (p. 196)
- Adjusting the second row head restraints (p. 198)
- Moving the second row seats forward/rearward* (p. 199)
- Getting into and out of the third row of seats* (p. 201)
- Folding the third row backrests* (p. 202)

Getting into and out of the third row of seats*

The second row of seats can be adjusted for easier access to the third row of seats*.



To fold down the backrest:

- Pull the handle on the upper side of the right or left outboard second row seat upward/ forward.
- Fold the backrest down and move the entire seat forward.

To return the seat to the upright position:

Push the seat rearward to its end position.
 The backrest should then easily return to the correct position.

i NOTE

If a backrest in the second row of seats does not lock back into the upright position after being folded down (e.g. for getting in or out of the third row of seats), it may need to be pushed forward again and then pushed back with more force.

⚠ WARNING

Make sure that the rear seat backrest and head restraint are locked securely in place after the seat is folded up.

The head restraints at the outer seats must always be raised when there is a passenger in one of these spots of the rear seat.

- Folding the second row backrests (p. 196)
- Adjusting the second row head restraints (p. 198)
- Moving the second row seats forward/rearward* (p. 199)
- Adjusting the second row backrest tilt (p. 200)
- Folding the third row backrests* (p. 202)

Folding the third row backrests*

The third row has two individual seats. These can be folded down separately.



To fold down the third-row seat backrests, it may be necessary to change the position/tilt the seats in the second row.



1. Pull the handle on the upper side of the backrest upward/forward.

- Make sure that backrest and head restraint do not come in contact with the seat in front while the backrest is being folded down. Fold the backrest down.
 - > The seat cushion will move downward/ forward when the backrest is folded down and create a flat surface. The head restraint folds down automatically when the backrest is lowered.

To return the seat to the upright position, fold the backrest up manually until it locks into position. Fold up the head restraint manually.

. MARNING

Make sure that the rear seat backrest and head restraint are locked securely in place after the seat is folded up.

The head restraints at the outer seats must always be raised when there is a passenger in one of these spots of the rear seat.

Related information

- Folding the second row backrests (p. 196)
- Adjusting the second row head restraints (p. 198)
- Moving the second row seats forward/rearward* (p. 199)
- Adjusting the second row backrest tilt (p. 200)

 Getting into and out of the third row of seats* (p. 201)

Steering wheel controls and horn

The steering wheel has a horn and controls for e.g. driver support systems and voice control.



Steering wheel keypads and paddles*.

- 1 Driver support system controls².
- Paddle* for manually shifting gears (automatic transmission).
- 3 Controls for voice commands, adjusting the head-up display, accessing menus and messages, and handling phone calls.

Horn




The horn is located in the center of the steering wheel.

Related information

Adjusting the steering wheel (p. 203)

Adjusting the steering wheel

The steering wheel can be adjusted to various positions.



The steering wheel's reach and height can be adjusted.

MARNING

Adjust the steering wheel and ensure it locks into position before driving. Never adjust the steering wheel while driving.

Steering wheel force can be adjusted with speed-dependent power steering. Steering wheel force is adjusted according to the vehicle's speed to give the driver an enhanced sense of control and stability.

² Speed limiter*, Cruise Control, Adaptive Cruise Control*, Distance Alert* and Pilot Assist*.





Steering wheel adjuster lever.

- 1. Move the lever forward to release the steering wheel.
- 2. Adjust the steering wheel to the desired position.
- Pull the lever back to lock the steering wheel into place. If the lever is difficult to move, press the steering wheel lightly while pulling the lever.

Related information

• Steering wheel controls and horn (p. 203)



Climate

The vehicle is equipped with electronic climate control. The climate system cools, heats and dehumidifies the air in the passenger compartment.

All of the climate system functions are controlled from the center display and the buttons on the center console.

Certain rear seat functions can also be controlled from the climate controls* on the rear of the tunnel console.


Related information

- Climate zones (p. 206)
- Climate control sensors (p. 207)
- Perceived temperature (p. 207)
- Climate control system voice commands (p. 208)
- Air quality (p. 209)
- Air distribution (p. 212)
- Climate system controls (p. 217)

Climate zones

The vehicle is divided into climate zones to make it possible to set different temperatures for different parts of the passenger compartment.


2-zone climate system



Climate zones with 2-zone climate system.

In 2-zone climate systems, the passenger compartment temperature can be set separately for the left and right sides of the vehicle.

4-zone climate system*



Climate zones with 4-zone climate system.

In 4-zone climate systems, the passenger compartment temperature can be set separately for the left and right sides of the vehicle, and for the front and rear seats.


Related information

Climate (p. 206)

Climate control sensors

The climate system has a number of sensors to help regulate the climate settings in the vehicle.

Location of the sensors



- Humidity sensor in the rearview mirror console.
- 2 Ambient temperature sensor in the rightside door mirror.
- 3 Passenger compartment temperature sensor near the buttons in the center console.
- 4 Sunlight sensors on the upper side of the dashboard.



Do not cover or block the sensors with clothing or other objects.

On vehicles equipped with the Interior Air Quality System*, there is also an air quality sensor in the climate system's air intake.

Related information

- Climate (p. 206)
- Interior Air Quality System* (p. 210)

Perceived temperature

The climate control system regulates the climate in the passenger compartment based on perceived temperature, not actual temperature.

The selected passenger compartment temperature is based on the physical perception of the current ambient temperature, airflow speed, humidity, sunlight in the passenger compartment, etc.

The system has a sunlight sensor that detects which side of the vehicle the sunlight is shining on and adjusts the temperature accordingly. This means that the temperature of the air coming out of the vents may be different for the left and right sides, even if the temperature setting is the same for both sides.

Related information

Climate (p. 206)

Climate control system voice commands¹

Voice commands can be used for the climate control system to e.g. change temperature, activate seat heating* or change blower speed.

Tap (and say one of the following commands:

- "Climate" starts a command dialog for climate controls and provides examples of commands that can be used.
- "Set temperature to X degrees" sets desired temperature.
- "Raise temperature"/"Lower temperature" - raises/lowers the set temperature.
- "Sync temperature" synchronizes the temperature for all climate zones in the vehicle with the temperature set for the driver's side.
- "Air on feet"/"Air on body" opens the desired air vent.
- "Air on feet off"/"Air on body off" closes the desired air vent.
- "Set fan to max"/"Turn off fan" changes blower speed to Max/Off.
- "Raise fan speed"/"Lower fan speed" raises/lowers the set blower speed.

- "Turn on auto" activates automatic climate control.
- "Air condition on"/"Air condition off" activates/deactivates air conditioning.
- "Recirculation on"/"Recirculation off" activates/deactivates air recirculation.
- "Turn on defroster "/"Turn off defroster"
 activates/deactivates window and door mirror defrosting.
- "Turn on max defroster"/"Turn off max defroster" - activates/deactivates max defroster.
- "Turn on electric defroster"/"Turn off electric defroster" - activates/deactivates heated windshield*.
- "Turn on rear defroster"/"Turn off rear defroster" - Activates/deactivates heated rear window and door mirrors.
- "Turn steering wheel heat on"/"Turn steering wheel heat off" - activates/deactivates heated steering wheel*.
- "Raise steering wheel heat"/"Lower steering wheel heat" - raises/lowers the level of steering wheel heating*.
- "Turn on seat heat"/"Turn off seat heat"
 activates/deactivates seat heating*.
- "Raise seat heat"/"Lower seat heat" raises/lowers the level of seat heating*.

- "Turn on seat ventilation"/"Turn off seat ventilation" - activates/deactivates seat ventilation*.
- "Raise seat ventilation"/"Lower seat ventilation" - raises/lowers the level of seat ventilation*.

Related information

- Climate (p. 206)
- Voice control (p. 147)
- Using voice commands (p. 148)
- Voice control settings (p. 150)

¹ Certain markets only.

Air quality

The materials used in the passenger compartment and air filtering system have been selected to ensure a high level of air quality in the passenger compartment.

Materials used in the passenger compartment

The materials in the passenger compartment are designed to be pleasant and comfortable, even for people with asthma or allergies.

The materials have been developed and tested to minimize dust in the passenger compartment and make it easier to keep clean.

The mats in both the passenger compartment and cargo compartment can be easily removed for cleaning.

Use Volvo-recommended cleaning agents and car care products to clean the interior.

Air filtering systems

In addition to the passenger compartment filter, the Clean Zone Interior Package* and Interior Air Quality System* also help maintain high air quality in the passenger compartment.


Related information

- Climate (p. 206)
- Clean Zone* (p. 209)
- Clean Zone Interior Package* (p. 210)
- Interior Air Quality System* (p. 210)

• Passenger compartment air filter (p. 211)

Clean Zone*

The Clean Zone function monitors the conditions affecting good air quality in the passenger compartment and indicates whether they are fulfilled or not.



- A The indicator is shown in the center display's Climate view.
- The indicator is shown in the climate bar when Climate view is not open.

If the conditions are not met, the text **Clean Zone** will be shown in white. When all the conditions are met, the text will change to blue.

Clean Zone monitors whether:

- All doors and tailgate are closed.
- All side windows and panoramic roof* are closed.
- The Interior Air Quality System* is activated.

- The blower is activated.
 - Air recirculation is deactivated.



NOTE

Clean Zone does not indicate that the air quality is good, but only that the conditions for good air quality have been met.

Related information

- Air quality (p. 209)
- Clean Zone Interior Package* (p. 210)
- Interior Air Quality System* (p. 210)
- Passenger compartment air filter (p. 211)

Clean Zone Interior Package*

Clean Zone Interior Package (CZIP) is a series of modifications that filters even more allergy and asthma-inducing substances from the passenger compartment.

CZIP includes the following:

- An enhanced function that starts the blower when the vehicle is unlocked using the remote key. The blower will then fill the passenger compartment with fresh air. The function starts when required and switches off automatically after a period of time or when one of the passenger compartment doors is opened. The amount of time the blower runs gradually decreases due to reduced need up until the vehicle is 4 years old.
- The fully automatic Interior Air Quality System (IAQS).

Related information

- Air quality (p. 209)
- Clean Zone* (p. 209)
- Interior Air Quality System* (p. 210)
- Passenger compartment air filter (p. 211)

Interior Air Quality System*

Interior Air Quality System (IAQS) is a fully automatic air quality system that removes gases and particles to reduce odors and contaminants in the passenger compartment.

IAQS is part of the Clean Zone Interior Package (CZIP) and removes air contaminants such as particles, hydrocarbons, nitric oxides and groundlevel ozone.

If the system's air quality sensors detect contaminants in the outside air, the air intake closes and air recirculation is activated.



NOTE

To ensure optimal air quality in the passenger compartment, the air quality sensor should always be engaged.

Recirculation is limited in cold weather to prevent fogging.

In the event of fogging, use the defroster functions for the windshield, side windows and rear window.

Related information

- Activating and deactivating the air quality sensor* (p. 211)
- Air quality (p. 209)
- Clean Zone* (p. 209)

- Clean Zone Interior Package* (p. 210)
- Passenger compartment air filter (p. 211)

Activating and deactivating the air quality sensor*

The air quality sensor is part of the fully automated Interior Air Quality System (IAQS).

The air quality sensor can be switched on or off.

- Tap **Settings** in the Top view in the center display.
- 2. Tap Climate.
- Select Air Quality Sensor to activate/deactivate the air quality sensor.

Related information

Interior Air Quality System* (p. 210)

Passenger compartment air filter

All air entering the passenger compartment through the climate control system intake is filtered.

Replacing the passenger compartment filter

To maintain the high performance of the climate control system, the filter must be replaced regularly. Follow Volvo's service schedule for recommended replacement intervals. When driving in areas with a lot of smog, dust, etc., the filter may need to be changed more frequently.



There are two types of passenger compartment filters. Make sure that the correct filter is installed.

- Air quality (p. 209)
- Clean Zone* (p. 209)
- Clean Zone Interior Package* (p. 210)
- Interior Air Quality System* (p. 210)

Air distribution


The climate system distributes incoming air through a number of vents in the passenger compartment.

Automatic and manual air distribution

When the auto-climate feature is on, air distribution is regulated automatically. Air distribution can also be controlled manually.

Adjustable air vents

Certain air vents in the vehicle are adjustable, which means they can be opened/closed and the direction of the air flow from the vent can be adjusted.



Location of adjustable air vents in the passenger compartment.


- 2-zone system four vents on the dashboard and one on each of the pillars between the front and rear doors.
- 2 4-zone system* two additional vents on the rear side of the tunnel console.
- 4-zone system* and seven seats one additional vent on each of the pillars behind the rear doors.

Related information

- Climate (p. 206)
- Adjusting air distribution (p. 212)
- Opening, closing and directing air vents (p. 213)
- Air distribution options (p. 214)

Adjusting air distribution

Air distribution can be adjusted manually if needed.



Air distribution buttons in Climate view.

- Air distribution windshield defrost vents
- 2 Air distribution dashboard and center console air vents
- Air distribution floor air vents
- 1. Open Climate view in the center display.
- 2. Tap one or more air distribution buttons to open/close the airflow for that vent.
 - > The air distribution changes and the buttons will light up or go out.

Related information

- Air distribution (p. 212)
- Opening, closing and directing air vents (p. 213)
- Air distribution options (p. 214)


Opening, closing and directing air vents

Some of the air vents in the passenger compartment can be individually opened, closed and directed.

Misting can be eliminated by directing the outer air vents towards the door windows.

Direct the outer air vents into the passenger compartment to maintain a comfortable temperature in warm weather.

Opening and closing the air vents




Air vent thumb wheel2.

 Turn the thumb wheel to open/close the airflow from the vent.

The more white lines that are visible, the stronger the airflow.

Directing air flow



Airflow control².

 Move the control from side to side or up and down to direct airflow from the vent.

- Air distribution (p. 212)
- Adjusting air distribution (p. 212)
- Air distribution options (p. 214)

 $^{2\,\}mbox{The illustration}$ is generic - air vent design varies depending on its location.

Air distribution options

Air distribution can be adjusted manually if needed. The following options are available.

	Air distribution	Purpose
* J	If all air distribution buttons are deselected in manual mode, the clim	nate control system will revert to automatic mode.
* J	Main airflow from defroster vents. Some airflow from other vents.	Helps remove ice and condensation in cold and humid weather (blower speed should not be set too low).
* 🗾	Main airflow from dashboard vents. Some airflow from other vents.	Provides effective cooling in warm weather.
* 🗾	Main airflow from floor vents. Some airflow from other vents.	Provides heating or cooling in footwell areas.

	Air distribution	Purpose
* /	Main airflow from defroster and dashboard vents. Some airflow from other vents.	Provides a comfortable climate in warm and dry weather.
* [Main airflow from defroster and floor vents. Some airflow from other vents.	Provides a comfortable climate and effective defogging in cold and humid weather.
* J	Main airflow from dashboard and floor vents. Some airflow from other vents.	Provides a comfortable climate in sunny, cool weather.
* /	Main airflow from defroster, dashboard and floor vents.	Provides balanced comfort in the passenger compartment.

CLIMATE CONTROL

◀ Related information

- Air distribution (p. 212)
- Opening, closing and directing air vents (p. 213)
- Adjusting air distribution (p. 212)

Climate system controls

The climate system functions are controlled from physical buttons on the center console, the center display, and the climate panel on the rear side of the tunnel console*.

Physical buttons in the center console



- Button for heated windshield* and max defroster.
- Button for heated rear window and door mirrors.

Climate bar in the center display

The most common climate system functions can be controlled from the climate bar.



- 1 Temperature control for the driver and passenger sides.
- 2 Control for heated* and ventilated* driver and passenger seats, and heated steering wheel*.
- 3 Button for opening Climate view. The graphic in the button shows activated climate system settings.

Climate view in the center display


Tap the center button on the climate bar to open Climate view. Climate view is divided into the following tabs:

- Main climate
- Rear climate*

Toggle between the tabs by swiping the screen to the left/right or by tapping the desired heading.

Main climate

In addition to the functions in the climate bar, other main climate system functions can be controlled from the **Main climate** tab.




- 1 Max, Electric, Rear Controls for defrosting windows and door mirrors.
- 2 AC Air conditioning controls.
- Recirc Air recirculation controls.
- 4 Air distribution controls.

CLIMATE CONTROL

- 6 Blower control for the front seats (also for the rear seats on vehicles with 2-zone systems).
 - 6 AUTO Automatic climate control.


Rear climate control*

All climate system functions for the rear seat can be controlled from the **Rear climate** tab.



- 2nd row climate Climate functions for the second row of seats. Blower control for the second row of seats.
- 2 3rd row climate Climate functions for the third row of seats*.
- Rear seat temperature control.
- A Rear seat heating control*.

Climate controls on the rear side of the tunnel console*



- Rear seat heating control*.
- Blower control for rear seats.
- Rear seat temperature control.
- 4 Button for locking/unlocking climate panel.

If the vehicle has heated rear seats* but does not have a climate panel on the rear side of the tunnel console, there will be buttons on the rear side of the tunnel console for the heated seats.

The climate panel has a screen lock to help prevent inadvertently changing blower speed and temperature. When the screen is locked, only the controls for seat adjustment* and the unlock button will be displayed.

After unlocking, blower speed and temperature can also be changed from the climate panel and

all selected climate settings will be displayed. The screen locks automatically after a period of inactivity.

Related information

- Climate (p. 206)
- Activating and deactivating power front seats* (p. 219)
- Activating and deactivating the heated rear seats* (p. 220)
- Activating and deactivating front seat ventilation* (p. 221)
- Activating and deactivating the heated steering wheel* (p. 222)
- Activating auto climate control (p. 223)
- Activating and deactivating recirculation (p. 224)
- Activating and deactivating max defroster (p. 225)
- Activating and deactivating the heated windshield* (p. 226)
- Activating and deactivating the heated rear window and door mirrors (p. 227)
- Setting the blower speed for the front seats (p. 228)
- Setting the blower speed for the rear seats* (p. 229)
- Synchronize temperature (p. 232)

- Activating and deactivating air conditioning (p. 233)
- Activating and deactivating climate control for the third-row seats* (p. 233)

Activating and deactivating power front seats*

The seats can be heated for added comfort for the driver and passengers in cold weather.



Steering wheel and seat buttons in the climate row.

- Tap the left- or right-side steering wheel and seat button in the center display's climate bar to open the controls for steering wheel and seat heating.
 - If the vehicle is not equipped with ventilated seats or heated steering wheel, the button for seat heating is directly accessible in the climate bar.
- Tap the seat heating button repeatedly to select one of the four levels: Off, High, Medium or Low.
 - > The level is changed and the set level is displayed in the button.

Related information

- Climate system controls (p. 217)
- Activating and deactivating the heated front seat* (p. 220)

Activating and deactivating the heated front seat*

The seats can be heated for added comfort for the driver and passengers in cold weather. Seat heating can be set to automatically activate when the engine is started. When set to automatically activate, heating will be turned on at low ambient temperatures.

- Tap **Settings** in the Top view in the center display.
- 2. Tap Climate.
- Select Auto Driver Seat Heating Level and Auto Passenger Seat Heating Level to activate/deactivate automatic start of heated driver's and passenger seat.
- 4. Select **Low**, **Medium** or **High** to select level after the function has been activated.

Related information

- Climate system controls (p. 217)
- Activating and deactivating power front seats* (p. 219)

Activating and deactivating the heated rear seats*

The seats can be heated for added comfort for the driver and passengers in cold weather.

Activating and deactivating the heated rear seats from the front seats*



Seat heating buttons in the **Rear climate** group in Climate view.

- Open Climate view in the center display and select the **Rear climate** tab.
- Tap the seat heating button repeatedly to select one of the four levels: Off, High, Medium or Low.
 - > The level is changed and the set level is displayed in the button.

Activating and deactivating the heated rear seats from the rear seat

With 2-zone system:



Buttons for seat heating on the rear side of the tunnel console.

- Press repeatedly on the left or right seat heating buttons on the rear side of the tunnel console to select one of four levels: Off, High, Medium or Low.
 - > The level is changed and the indicator lights in the button display the level.

With 4-zone system*:



Seat heating controls and indicator lights on the rear side of the tunnel console.

- Press repeatedly on the left or right seat heating buttons in the climate panel on the tunnel console to select one of four levels:
 Off, High, Medium or Low.
 - > The level will be changed and the climate panel screen will show the new level.

Related information

Climate system controls (p. 217)

Activating and deactivating front seat ventilation*

The seats can be ventilated to provide increased comfort in warm weather.

The ventilation system consists of fans in the seats and backrest that draw air through the seat upholstery. The cooler the passenger compartment is, the greater the cooling effect of the ventilation. The system can be activated when the engine is running.



Steering wheel and seat buttons in the climate row.

 Tap the left- or right-side steering wheel and seat button in the center display's climate bar to open the controls for steering wheel and seat heating.

If the vehicle is not equipped with heated seats or heated steering wheel, the button for seat ventilation is directly accessible in the climate bar.

- Tap the seat ventilation button repeatedly to select one of the four levels: Off, High, Medium or Low.
 - > The level is changed and the set level is displayed in the button.

Related information

Climate system controls (p. 217)

Activating and deactivating the heated steering wheel*

The steering wheel can be heated for added comfort in cold weather.



Steering wheel and seat buttons in the climate row.

- Tap the driver's side steering wheel and seat button in the climate bar in the center display to open the controls for steering wheel and seat heating.
 - If the vehicle is not equipped with heated or ventilated seats, the button for steering wheel heating is directly accessible in the climate bar.
- Tap the steering wheel heating button repeatedly to select one of the four levels: Off, High, Medium or Low.
 - > The level is changed and the set level is displayed in the button.

Related information

- Climate system controls (p. 217)
- Activating and deactivating automatic steering wheel heating* (p. 223)

Activating and deactivating automatic steering wheel heating*

The steering wheel can be heated for added comfort in cold weather.

Steering wheel heating can be set to automatically activate when the engine is started. When set to automatically activate, heating will be turned on at low ambient temperatures.

- Tap **Settings** in the Top view in the center display.
- 2. Tap Climate.
- Select Auto Steering Wheel Heating Level to activate/deactivate automatic start of heated steering wheel.
- Select Low, Medium or High to select level after the function has been activated.

Related information

Activating and deactivating the heated steering wheel* (p. 222)

Activating auto climate control

If auto climate control is activated, several climate system functions are controlled automatically.



Auto climate button in Climate view.

1. Open Climate view in the center display.

- 2. Tap or press and hold AUTO.
 - Tap air recirculation, air conditioning and air distribution are controlled automatically.
 - Press and hold air recirculation, air conditioning and air distribution are controlled automatically. Temperature and blower speed are changed to standard settings: 22 °C (72 °F) and speed 3 (speed 2 in the rear seat³).
 - > Auto climate mode is activated and the button lights up.



It is possible to change the temperature and blower speed without deactivating automatic climate control. Automatic climate control is deactivated when the air distribution is changed manually or when the max defroster is activated.

Related information

Climate system controls (p. 217)

³ For vehicles with 4-zone climate system*.

Activating and deactivating recirculation

The climate system's recirculation function helps shut out smog, smoke, exhaust fumes, etc. by reusing the air in the passenger compartment.



Air recirculation button in Climate view.

- 1. Open Climate view in the center display.
- 2. Tap Recirc.
 - > Air recirculation is activated/deactivated and the button lights up/goes out.



If the air in the vehicle is recirculated too long, there is a risk of fogging on the inside of the windows.

(i) NOTE

Recirculation cannot be activated when the max defroster is on.

Related information

- Climate system controls (p. 217)
- Activating and deactivating the recirculation timer setting (p. 224)

Activating and deactivating the recirculation timer setting

The climate system's recirculation function helps shut out smog, smoke, exhaust fumes, etc. by reusing the air in the passenger compartment. When the recirculation timer is activated, air recirculation will switch off automatically after 20 minutes.

- Tap **Settings** in the Top view in the center display.
- Tap Climate.
- Tap Recirculation Timer to activate/deactivate the recirculation timer.

Related information

 Activating and deactivating recirculation (p. 224)

Activating and deactivating max defroster

Max defroster is used to quickly remove condensation and ice from windows.

Activating and deactivating max defroster from the center console

A button in the center console offers quick access to the max defroster.

On vehicles with heated windshields*, the max defroster can only be activated separately from Climate view in the center display.



Button in center console.

Vehicles without a heated windshield:

- Tap the button.
 - > The max defroster is activated/deactivated and the button lights up/goes out.

Vehicles with a heated windshield:

- Press the button repeatedly to switch between the three levels;
 - Activated windshield heating
 - Activated windshield heating and max defroster
 - Deactivated.
 - > The heated windshield and max defroster are activated/deactivated and the button lights up/goes out.

(i) NOTE

The max defroster starts after a slight delay to avoid a brief increase in blower speed if the heated windshield function has been deactivated by pressing the button twice in quick succession.

Activating and deactivating max defroster from the center display



Max defroster in Climate view.

- 1. Open Climate view in the center display.
- 2. Tap **Max**.
 - > The max defroster is activated/deactivated and the button lights up/goes out.

Max defroster deactivates automatic climate control and air recirculation, activates the air conditioning, and changes blower speed to 5 and temperature to HI.

When max defroster is deactivated, the climate system reverts to the previous settings.



The volume increases when the blower speed is changed to **5**.

Related information

• Climate system controls (p. 217)

Activating and deactivating the heated windshield*

Windshield heating is used to quickly remove condensation and ice from the windshield.

Activating and deactivating windshield heating from the center console

A button in the center console is used to quickly access windshield heating.



Button in center console.

- Press the button repeatedly to switch between the three levels:
 - · Activated windshield heating
 - Activated windshield heating and max defroster
 - Deactivated.
 - The heated windshield and max defroster are activated/deactivated and the button lights up/goes out.

Activating and deactivating windshield heating from the center display



Windshield heating button in Climate view.

- 1. Open Climate view in the center display.
- 2. Tap Electric.
 - > Windshield heating is activated/deactivated and the button lights up/goes out.



Triangular areas at the far sides of the windshield are not heated and will take slightly longer to defrost/de-ice.



The heated windshield may affect the performance of transponders and other communication equipment.

(\mathbf{i})

NOTE

If windshield heating is activated when the Start/Stop function auto-stops the engine, the engine will be restarted.

Related information

- Climate system controls (p. 217)
- Activating and deactivating automatic windshield heating* (p. 227)

Activating and deactivating automatic windshield heating*

Windshield heating is used to quickly remove condensation and ice from the windshield. Windshield heating can be set to automatically activate when the engine is started. With automatic start activated, heating will be activated when there is a risk of ice or condensation on the windows or mirrors. Heating is automatically switched off when the window or door mirror is sufficiently warm and the condensation or ice is gone.

- Tap **Settings** in the Top view in the center display.
- 2. Tap Climate.
- Select Auto Front Defroster to activate/ deactivate automatic windshield heating.

Related information

 Activating and deactivating the heated windshield* (p. 226)

Activating and deactivating the heated rear window and door mirrors

The heated rear window and door mirrors are used to quickly remove condensation and ice from the glass.

Activating and deactivating the heated rear window and door mirrors from the center console

A button in the center console offers quick access to the heated rear window and door mirrors functions.



Button in center console.

- Tap the button.
 - Heated windows and door mirrors are activated and the button lights up/goes out.

Activating and deactivating the heated rear window and door mirrors from the center display



Rear window/door mirror heating button in Climate view.

- 1. Open Climate view in the center display.
- 2. Tap Rear.
 - Heated windows and door mirrors are activated and the button lights up/goes out.

Related information

- Climate system controls (p. 217)
- Automatically activating and deactivating the heated rear window and door mirrors (p. 228)

Automatically activating and deactivating the heated rear window and door mirrors

The heated rear window and door mirrors are used to quickly remove condensation and ice from the glass.

It is possible to select whether rear window and door mirror heating should be automatically activated or deactivated when the engine is started. With automatic start activated, heating will be activated when there is a risk of ice or condensation on the windows or mirrors. Heating is automatically switched off when the window or door mirror is sufficiently warm and the condensation or ice is gone.

- Tap **Settings** in the Top view in the center display.
- 2. Tap Climate.
- Select Auto Rear Defroster to activate/ deactivate automatic rear window and door heating.

Related information

 Activating and deactivating the heated rear window and door mirrors (p. 227)

Setting the blower speed for the front seats⁴

The blower can be set to several different automatically controlled speeds for the front seat.



Blower control buttons in Climate view.

- 1. Open Climate view in the center display.
- Tap the desired blower speed: Off, 1-5 or Max.
 - > The blower speed will be changed and the buttons for the set speed will light up.

! CAUTION

The air conditioning will not engage if the blower is turned off completely, which may cause fogging on the inside of the windows.

 $^{{\}bf 4}$ The same setting applies to the rear seats with the 2-zone climate system.

(i)

NOTE

The climate system automatically adapts airflow as needed within the set blower speed, which means that airflow speed may vary slightly within the same blower speed.


Related information

Climate system controls (p. 217)

Setting the blower speed for the rear seats*

The blower can be set to several different automatically controlled speeds for the rear seat.

Setting blower speed for the rear seats from the front seats



Blower control buttons in the **Rear climate** tab in Climate view.

 Open Climate view in the center display and select the **Rear climate** tab. 2. Tap the desired blower speed, 1-5.

The blower speed for the second and third rows of seats* can be switched off by tapping **2nd row climate**.

The blower speed for the third row of seats is linked to the setting for the second row, but can be switched off separately* by pressing **3rd row climate**.

> The blower speed will be changed and the buttons for the set speed will light up.

Setting blower speed for the rear seats from the rear seats

1. Tap the unlock button on the tunnel console's climate panel to access the controls.

44



Blower controls on the rear climate panel of the tunnel console.

- 2. Tap the desired blower speed, 1-5.
 - > The blower speed will be changed and the buttons for the set speed will light up.



The blower speed for the rear seat cannot be set if the blower speed for the front seat is **Off**.

The rear seat blower speed can only be turned off from the climate view in the center display.

(i) NOTE

The climate system automatically adapts airflow as needed within the set blower speed, which means that airflow speed may vary slightly within the same blower speed.

Related information

• Climate system controls (p. 217)

Setting the temperature for the front seats⁵

The temperature can be set to the desired number of degrees for the front seat climate zones.



Temperature buttons in the climate bar.

 Tap the left- or right-side temperature buttons in the center display's climate bar to open the control.

⁵ The same setting applies to the rear seats with the 2-zone climate system.



Temperature control.

- 2. Set the temperature by doing one of the following:
 - dragging the control to the desired temperature, or
 - tapping +
 to raise/lower the temperature.
 - > The temperature will be set and the button will display the new temperature.

i NOTE

Heating/cooling cannot be accelerated by choosing a higher/lower temperature than the desired temperature.

Related information

• Climate system controls (p. 217)

Setting the temperature for the rear seats*

The temperature can be set to the desired number of degrees for the rear seat climate zones.

Setting the temperature for the rear seats from the front seats



Temperature buttons in the $\mbox{\bf Rear climate}$ tab in Climate view.

- Open Climate view in the center display and select the **Rear climate** tab.
- 2. Tap the left- or right-side temperature button to open the control.



Temperature control.

- 3. Set the temperature by:
 - dragging the control to the desired temperature
 - tapping +
 to raise/lower the temperature.
 - > The temperature will be set and the button will display the new temperature.

Setting the temperature for the rear seats from the rear seats

1. Tap the unlock button on the tunnel console's climate panel to access the controls.

44



Temperature controls on the rear climate panel of the tunnel console.

- 2. Tap the left or right side's ♦ buttons to lower/raise the temperature.
 - The temperature will be changed and the climate panel screen will show the new temperature.



NOTE

Heating/cooling cannot be accelerated by choosing a higher/lower temperature than the desired temperature.

Related information

Climate system controls (p. 217)

Synchronize temperature

The temperature in the different climate zones of the vehicle can be synchronized with the temperature set for the driver's side.



Synchronization button on the driver's side temperature control.

- Tap the driver's side temperature button in the center display's climate bar to open the control.
- 2. Tap Synchronize temperature.
 - > The temperature for all of the vehicle's climate zones will be synchronized with the one set for the driver's side and the synchronization symbol will be displayed next to the temperature button.

Synchronization is stopped with another press on **Synchronize temperature** or by changing the temperature setting for a climate zone other than the driver's.

Related information

• Climate system controls (p. 217)

Activating and deactivating air conditioning

The air conditioning cools and dehumidifies incoming air as needed.



Air conditioning button in Climate view.

- 1. Open Climate view in the center display.
- 2. Tap AC.
 - > The air conditioning is activated/deactivated and the button lights up/goes out.

When the air conditioning is activated, it will be switched on and off automatically by the climate system as needed.



For optimum function of the air conditioning, close all side windows and the panoramic roof*.

(i) NOTE

The air conditioning cannot be activated when the fan speed is set to **Off**.

Related information

• Climate system controls (p. 217)

Activating and deactivating climate control for the third-row seats*

The air conditioning cools and dehumidifies incoming air as needed.



Air conditioning button in the **Rear climate** tab in Climate view.

- 1. Open Climate view in the center display and select the **Rear climate** tab.
- 2. Tap 3rd row climate.
 - > The air conditioning is activated/deactivated and the button lights up/goes out.

•

NOTE

The air conditioning for the third row of seats is automatically activated if any of the third row seat belts are buckled.

It is not possible to manually activate air conditioning for the third row of seats if the main air conditioning system is deactivated or the climate system* for the second row of seats is deactivated.

Related information

- Climate system controls (p. 217)
- Activating and deactivating auto-start of third-row climate control* (p. 234)

Activating and deactivating autostart of third-row climate control*

The air conditioning cools and dehumidifies incoming air as needed.

On models with a 4-zone climate*, the air conditioning for the third row of seats can be set to start automatically when the engine is started.

- Tap **Settings** in the Top view in the center display.
- 2. Tap Climate.
- Select Auto Third Row Climate to activate/deactivate the air conditioning for the third row of seats when the engine is started.

Related information

 Activating and deactivating climate control for the third-row seats* (p. 233)

KEY, LOCKS AND ALARM

Lock indication

When the vehicle is locked or unlocked, the turn signals will flash to indicate that the vehicle has been locked or unlocked correctly.

Exterior confirmation

Locking

 The turn signals will flash once and the door mirrors will fold in¹ to confirm the vehicle is locked.

Unlocking

 The turn signals will flash twice and the door mirrors will fold out¹ to confirm the vehicle is unlocked.

All doors, tailgate and hood must be closed for confirmation to be given. If only the driver's door is closed when the vehicle is locked², the vehicle will be locked but the turn signals will only flash to indicate locking when all doors and the hood and tailgate have been closed.

Lock and alarm indicator



The locks and alarm indicator on the dashboard will display the status of the locking system.

A long flash indicates that the vehicle is locked. When the vehicle is locked, this will be indicated by short, pulsing flashes.

Other indicators

The home safe lighting and approach lighting functions also indicate when the vehicle is locked or unlocked.

Lock button indicators

Front door



Lock buttons with indicator lights in front door.

Illuminated indicator lights in both front door lock buttons indicate that all doors are locked. If any door is opened, the lights in both doors will go out.

¹ Only vehicles with power folding mirrors.

² Does not apply to vehicles equipped with keyless locking/unlocking (Passive Entry*).

In rear door*



Lock button with indicator light in rear door.

Illuminated indicator lights in each door indicate that that particular door is locked. If any door is unlocked and opened, the indicator light in that door will go out. The lights in the other doors will remain illuminated.

Related information

- Lock confirmation settings (p. 237)
- Welcome Light (p. 164)
- Using home safe lighting (p. 164)

Lock confirmation settings

Settings for how the vehicle confirms locking and unlocking can be adjusted in the center display's Settings menu.

- 1. Tap **Settings** in the center display's Top view.
- Tap My Car → Locking.
- Tap Visible Locking Feedback to deactivate the function or to select when the vehicle should provide a visible response: during Lock, Unlock or Both.
- Select to receive an audible response when locking the vehicle by marking Audible Locking Feedback.

Folding door mirrors* confirmation

- Tap Settings in the center display's Top view.
- Tap My Car → Mirrors and Convenience.
- 3. Select **Fold Mirror When Locked** to activate or deactivate the function.

Related information

Lock indication (p. 236)

Remote key

The remote key is used to lock and unlock doors, the tailgate and the fuel filler door. The remote key must be in the vehicle in order to start the engine.



Remote control key, on left, and button-less key ((Key Tag)*), on right.

The remote key is not physically used to start the ignition because the vehicle is standard-equipped with keyless start (Passive Start). To start the vehicle, the key must be in the front section of the passenger compartment, e.g. in the driver's pocket or in a cup holder in the tunnel console.

The keyless system for locking/unlocking the doors, tailgate (Passive Entry*) and fuel filler door is available as an option. This system has a range in a semicircle with a radius of approximately 1.5 meter (5 feet) out from the driver's door and approx. 1 meter (3 feet) out from the tailgate.

With keyless start in combination with keyless locking and unlocking, the remote key can be located anywhere in the passenger compartment or cargo compartment in order to start the engine.

Each remote key supplied with the vehicle can be linked to a driver profile with unique settings for the vehicle. When a key with a specific profile is used, the vehicle settings are adjusted according to that profile.

Buttonless key, Key Tag

For vehicles equipped with keyless locking and unlocking*, a smaller, lighter and button-less key (Key Tag³) is also provided. It works the same way as the regular remote key as regard keyless start and keyless locking and unlocking⁴. It does not have a detachable key blade and its battery cannot be replaced.

Remote key buttons



The remote key has four buttons, one on the left side and three on the right.

Locking - Press once to lock the doors, tailgate and fuel filler door and arm the alarm.

Press and hold to close all windows.

Unlocking - Press once to unlock the doors, tailgate and fuel filler door and disarm the alarm.

Press and hold to open all windows at the same time⁵.

Tailgate - Unlock and disarm the tailgate only. On vehicles equipped with the power tailgate*, press and hold to automatically open the tailgate. Press and hold to close an

open tailgate (an audible warning signal will sound).

Panic alarm - Used to attract attention in emergency situations. Press and hold the button for at least 3 seconds or press twice within 3 seconds to activate the turn signals and horn. To deactivate, wait at least 5 seconds and press the button again. If no action is taken, the panic alarm will deactivate automatically after 3 minutes.

If anyone is left in the vehicle, make sure that power to the power windows and panoramic roof* is cut off by always taking the remote key with you when you leave the vehicle.

(i) NOTE

Be aware of the risk of locking the Key Tag in the vehicle. If the remote key/Key Tag is left in the vehicle, it will be deactivated when the vehicle is locked and the alarm set using another valid key.

The deactivated key will be reactivated when the vehicle is unlocked.

³ Även kallad sportnyckel.

⁴ The key is waterproof up to a depth of approx. 10 meters (30 feet) for up to 60 minutes, making it suitable for use in activities in and around water.

⁵ The total airing function can be used to e.g. quickly air out the vehicle in hot weather.

Interference

Electromagnetic fields or obstructing objects may interfere with the remote key's functions for keyless start and keyless locking and unlocking*.

$\overline{\mathbf{i}}$

NOTE

Avoid storing the remote control key near metal objects or electronic devices, e.g. cell phones, tablets, laptops or chargers – preferably no closer than 10-15 cm (4-6 in.).

If you experience interference, use the remote key's detachable blade to unlock the vehicle and place the remote key in the backup key reader in the tunnel console cup holder to disarm the alarm.

$|\mathbf{i}|$

NOTE

When the remote control key is placed in the cup holder, make sure that no other vehicle keys, metal objects or electronic devices (e.g. cell phones, tablets, laptops or chargers) are found in the cup holder. Multiple vehicle keys close to each other in the cup holder can disrupt their functionality.

Related information

- Locking and unlocking using the remote key (p. 239)
- Remote key range (p. 241)

- Replacing the remote key's battery (p. 242)
- Detachable key blade (p. 248)
- Red Key restricted remote key* (p. 246)
- Electronic immobilizer (p. 250)

Locking and unlocking using the remote key

All doors, tailgate and fuel filler door can be locked and unlocked simultaneously using the buttons on the remote key.

Locking with remote key



Remote key.

- Press the 🗓 button on the remote key to lock.

■ To activate the locking sequence, the driver's door must be closed⁶. If any of the other doors or the tailgate are open, they will be locked and the alarm will be armed once they are closed.



NOTE

Be aware of the risk of locking the Key Tag in the vehicle. If the remote key/Key Tag is left in the vehicle, it will be deactivated when the vehicle is locked and the alarm set using another valid kev.

The deactivated key will be reactivated when the vehicle is unlocked.

Locking when the tailgate is open



(i) NOTE

If the vehicle is locked and the tailgate is still open, make sure that the remote key is not left in the cargo compartment when the tailgate is closed and the entire vehicle is locked⁷

Unlocking with remote key

Press the putton on the remote key to unlock.

Automatic relocking

If none of the doors or tailgate are opened within two minutes after being unlocked, they will automatically relock. This function reduces the risk of inadvertently leaving the vehicle unlocked.

Remote key not working



NOTE

Move closer to the vehicle and try to unlock it again.

If the remote key is not working to lock or unlock the vehicle, its battery may be discharged. Use the detachable key blade to lock/unlock the driver's door instead.

Related information

- Settings for remote and inside door unlock (p. 240)
- Unlocking the tailgate using the remote key (p. 241)
- Remote key (p. 237)
- Replacing the remote key's battery (p. 242)
- Locking and unlocking with detachable key blade (p. 249)

Settings for remote and inside door unlock

Several different sequences are available for remote unlocking.

- 1. Tap **Settings** in the center display's Top view
- Tap My Car → Locking → Remote and Interior Unlock
- Select alternative:
 - All Doors
 - unlocks all doors at the same time.
 - Single Door
 - unlocks the driver's door. Press the remote key unlock button twice to unlock all doors.

The settings made here also affect central locking using the inside door handle.

Related information

- Locking and unlocking using the remote key (p. 239)
- Locking and unlocking from inside the vehicle (p. 255)

⁶ If the vehicle is equipped with keyless locking/unlocking, all side doors must be closed.

⁷ If the vehicle is equipped with keyless locking/unlocking and the key is detected inside the vehicle, the tailgate will not lock when it is closed.*

Unlocking the tailgate using the remote key

The remote key can be used to unlock the tailgate while keeping the rest of the vehicle locked.



Use the button on the remote key to disarm and unlock the tailgate.

- 1. Press the button on the remote key.
 - > The lock and alarm indicator on the dashboard will go out to indicate that the vehicle is no longer fully armed.

The tailgate will be unlocked but remain closed. However, the side doors will remain locked and armed.

To open the tailgate, lightly grasp the rubberized pressure plate on the underside of the tailgate handle and open the tailgate.

If the tailgate is not opened within 2 minutes, it will be relocked and the alarm armed.

With the optional power tailgate* -

- Hold and press (about 1.5 seconds) the button on the remote key
 - The tailgate will unlock and open. However, the side doors will remain locked and armed.

Related information

- Locking and unlocking using the remote key (p. 239)
- Opening and closing the power tailgate* (p. 259)

Remote key range


In order to function correctly, the remote key must be within a certain distance from the vehicle.

Manual use

The remote key's functions for e.g. locking and unlocking, which are activated by pressing (a) or (b), have a range of approx. 20 meter (65 feet) from the vehicle.

If the vehicle's locks do not react, move closer and try again.

Keyless use⁸



The shaded areas around the vehicle illustrate the range of the system's antennas.

⁸ Models equipped with keyless locking/unlocking (Passive Entry*) only.

For keyless use, a remote key or the Key Tag must be within the shaded areas shown in the illustration, i.e. a semicircle with a radius of approx. 1.5 meter (5 feet) along the sides of the vehicle or approx. 1 meter (3 feet) from the tailgate.



NOTE

The functions of the remote control key can be disrupted by ambient radio waves, buildings, topographical conditions, etc. The vehicle can always be locked/unlocked using the kev blade.

If the remote key is removed from the vehicle



If the remote key is removed from the vehicle while the engine is running, the warning message Vehicle key not found Removed from vehicle will be

displayed in the instrument panel and an audible signal will sound when the last door is closed.

The message will disappear when the key is returned to the vehicle and the O button on the right-side steering wheel keypad is pressed or when the last door is closed again.

Related information

- Remote key (p. 237)
- Antenna locations for the start and lock system (p. 255)

Kevless and touch-sensitive surfaces* (p.251)

Replacing the remote key's battery

The battery in the remote key must be replaced when it is discharged.



(i) NOTE

All batteries have a limited service life and must eventually be replaced (does not apply for Key Tag). The battery's service life varies depending on how often the vehicle/key is used.

The remote key battery should be replaced if:



the information symbol illuminates and the message Vehicle key bat, low See Owner's manual is displayed in the instrument panel

and/or

the locks do not react after several attempts to lock or unlock the vehicle using the remote key within approx. 20 meter (65 feet) from the vehicle.



NOTE

Move closer to the vehicle and try to unlock it again.

The battery in the smaller key without buttons⁹ (the Key Tag) cannot be replaced. A new key can be ordered from an authorized Volvo workshop.

! CAUTION

An end-of-life Key Tag must be turned in to an authorized Volvo workshop. The key must be deleted from the vehicle because it can still be used to start the vehicle via backup start.

Opening the key and replacing the battery



- Hold the remote key with the front side (with the Volvo logo) facing up and move the button on the key ring section to the right. Slide the front cover slightly upward.
 - The cover will loosen and can be removed from the key.



- Turn the key over, move the button to the side and slide the rear cover slightly upward.
 - The cover will loosen and can be removed from the key.

⁹ This key is provided with vehicles equipped with keyless locking/unlocking (Passive Entry*).



Use a screwdriver or similar object to turn the battery cover counterclockwise so the markers point to **OPEN**.

Remove the cover carefully by pressing e.g. a fingernail into the indentation.

Pry the cover up.



The battery's positive side (+) faces upward. Carefully pry out the battery as shown in the illustration.

CAUTION

Avoid touching new batteries and their contact surfaces with your fingers as this will impair their function.



- Insert a new battery with the positive side (+) facing upward. Do not touch the contact surfaces of the remote key battery.
 - Place the edge of the battery downward into the holder. Slide the battery forward until it locks into place under the two plastic catches.
 - Press the battery downward until it locks into place under the upper black plastic catch.



(i) NOTE

Use batteries with the designation CR2032, 3 V.

(i) NOTE

Volvo recommends that batteries used in the remote control key satisfy UN Manual of Test and Criteria, Part III, sub-section 38.3. The factory installed batteries and batteries replaced by an authorized Volvo workshop satisfy the above criterion.



Replace the battery cover and turn it clockwise until it points to **CLOSE**.



- Put the rear cover back into position and press it down until it clicks into place.
 - Slide the cover back.
 - > A second click indicates that the cover is correctly positioned and locked into place.



- Turn the remote key over and press the front cover down until it clicks into place.
 - Slide the cover back.
 - > An additional click indicates that the cover is correctly in place.

! CAUTION

Be sure to dispose of end-of-life batteries in a way that protects the environment.

Related information

• Remote key (p. 237)

Ordering additional remote keys

Two remote keys are provided with the vehicle. One Key Tag is also included if the vehicle is equipped with keyless locking/unlocking*. Additional keys can be ordered.

A total of 12 keys can be programmed and used for the same vehicle. An additional driver profile will be added for each new remote key. This also applies to the key tag.

Loss of a remote key

If you lose your remote key, you can order a replacement from a workshop - an authorized Volvo workshop is recommended. Bring the other remaining remote keys to the workshop. As an anti-theft measure, the code of the lost remote key must be erased from the system.

The current number of keys registered for the vehicle can be checked via driver profiles in the center display's Top view. Select Settings → System → Driver Profiles.

(i) NOTE

Volvo recommends that you order a new or duplicate remote control key from an authorized Volvo workshop.

You can also obtain additional or duplicate remote control keys from certain independent repair facilities and locksmiths that are qualified to make remote control keys. Each key must be programmed to work with your vehicle.

A list of independent repair facilities and/or locksmiths known to Volvo that can cut and code replacement keys can be found:

- on Volvo's website www.volvocars.com/us
- by calling Volvo Customer Care 1-800-458-1552.

Related information

Remote key (p. 237)

Red Key - restricted remote key*

A Red Key makes it possible for the vehicle owner to set limitations for certain vehicle properties. The limitations are intended to promote safe use of the vehicle, e.g. when it is loaned out.



For a Red Key, it is possible to define the vehicle's maximum speed, set speed reminders and limit the audio system's volume. Several of the driver support systems will also always be active. Otherwise, the Red Key functions in the same way as a standard remote key.

One or more Red Keys can be ordered from a Volvo retailer. A total of twelve keys can be programmed and used for the same vehicle. Up to ten may be restricted keys, but at least two must be standard remote keys.

These restrictions are intended to help reduce the risk of accidents and help the driver feel more

secure when handing over the vehicle to e.g. a young driver, parking attendant or workshop. The settings for a Red Key cannot be changed by its user; a regular remote key is needed to change settings.

Related information

- Red Key* settings (p. 247)
- Remote key (p. 237)

Red Key* settings

The holder of a regular remote key can adjust settings for a Red Key. Certain driver support functions are always active.

- Tap **Settings** in the center display's Top view.
- Tap System → Driver Profiles → Red Key.
 - > The following settings can be made:
 - Set Time Gap For Adaptive Cruise Control
 - Reduced Maximum Volume
 - Max Speed Limit
 - Speed Limit Warning

Adaptive Cruise Control*:

Default setting: Longest interval

Reduced maximum volume (On/Off):

Default setting: On

Speed Limiter (On/Off):

- Setting interval: 50-250 km/h (30-160 mph)
- The default setting is 120 km/h (75 mph)
- Increments: 1 km/h (1 mph)



The following symbol and message will be shown in the instrument panel

Red key Speed limitation cannot be exceeded.

Speed reminder (On/Off):

- Setting interval: 0-250 km/h (0-160 mph)
- Default setting: 50, 70 and 90 km/h (30, 45 and 55 mph)
- Increments: 1 km/h (1 mph)
- Maximum number of simultaneous reminders: 6

Driver support functions

The following driver support functions will always be active for a Red Key user:

- Blind Spot Information (BLIS)*
- Lane Keeping Aid (LKA)*
- Distance Alert*
- City Safety
- Driver Alert Control (DAC)*
- Road Sign Information*

Related information

Red Key - restricted remote key* (p. 246)

Detachable key blade

The remote key contains a detachable metal key blade that can be used to activate a number of functions and preform certain actions.

A Volvo workshop can provide you with the key blade's unique code, which is recommended in case you need to order a new key blade.

Using the detachable key blade

The detachable key blade can be used to:

- manually open the left-side front door if central locking cannot be activated with the remote key.
- emergency lock all doors.
- activate/deactivate the rear door mechanical child safety locks.

The button-less Key Tag¹⁰ does not have a detachable key blade. If needed, use the standard remote key's detachable key blade.

Detaching the key blade



- 1 Hold the remote key with the front side (with the Volvo logo) facing up and move the button on the key ring section to the right. Slide the front cover slightly upward.
 - The cover will loosen and can be removed from the key.



Remove the key blade by pulling it up.



- Put the key blade back into its designated spot in the remote key after use.
 - Replace the cover by pressing it down until it clicks into place.
 - Slide the cover back.
 - > An additional click indicates that the cover is correctly in place.

Related information


- Locking and unlocking with detachable key blade (p. 249)
- Remote key (p. 237)

¹⁰ Supplied with vehicles equipped with keyless locking/unlocking (Passive Entry*).

Locking and unlocking with detachable key blade

The detachable key blade can be used to unlock the vehicle from the outside, e.g. if the battery in the remote key is discharged.

Unlocking



- Pull the front left-hand door handle to its end position to access the lock cylinder.
- Put the key in the lock cylinder.
- Turn the key clockwise 45 degrees so that the key blade is pointing straight rearward.
- Turn the key blade back 45 degrees to its original position. Remove the key from the lock cylinder and release the handle so that it returns to its original position against the vehicle.
- Pull the door handle.
 - > The door will open.


Lock the door in the same way, but turn the key 45 degrees counterclockwise in step (3).

Turning off the alarm

(i)

NOTE

When the door is unlocked using the detachable key blade and then opened, the alarm will be triggered.



Location of the backup key reader in the cup holder.

Turn off the alarm by:

- Place the remote control key on the key symbol in the backup reader in the bottom of the cup holder in the tunnel console.
- 2. Turn the start knob clockwise and release it.
 - > The start knob will automatically return to its original position - the alarm signal will stop and the alarm will be turned off.


Locking

The vehicle can also be locked using the remote key's detachable key blade, e.g. if either the vehicle's or remote key's batteries are discharged.

The left-hand front door can be locked by inserting the detachable key into the door's lock cylinder.

This is the only door with a lock cylinder. The other doors have lock mechanisms in the side of the door that must be pushed in using the key blade. The door will then be locked mechanically and cannot be opened from the outside.

The doors can still be opened from inside.



Manual door lock. This is not the child lock.

 Remove the detachable key blade from the remote key. Insert the key blade into the opening for the lock mechanism and push the key in as far as possible, about 12 mm.

- The door can be opened from both the outside and the inside.
 - B The door cannot be opened from the outside.

 To return to position A, open the door using the inside door handle.

The doors can also be unlocked by pressing the unlock button on the remote key or the central lock button in the driver's door.

(i) NOTE

- The door's lock controls only lock that specific door, not all doors simultaneously.
- A manually locked rear door with an activated manual or electric child safety lock cannot be opened from either the outside or inside of the vehicle. A rear door locked in this way can only be unlocked using the remote key or the central unlocking button.

Related information

- Detachable key blade (p. 248)
- Arming and disarming the alarm (p. 267)
- Replacing the remote key's battery (p. 242)
- Remote key (p. 237)

Electronic immobilizer

The electronic immobilizer is a start inhibitor that helps prevent the vehicle from being started by an unauthorized person.

The vehicle can only be started with the right remote key.

The following instrument panel error messages are related to the electronic immobilizer:

Symbol	Message	Meaning
(((,[])	Vehicle key not found See Owner's manual	Remote key not recognized during start. Place the remote key on the key symbol in the cup holder and try to start the vehicle again.

Related information

- Remote key (p. 237)
- Ordering additional remote keys (p. 246)

Start and lock system type designations

The following information contains type designations for the start and lock system.

Alarm system

USA FCC ID: MAYDA 5823(3)

This device complies with part 15 of the FCC rules. Operation is subject to the following conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Canada IC: 4405A-DA 5823(3)

This device is subject to the following conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Remote keys (Passive entry/Passive start*) USA

Volvo Standard Key FCC ID: YGOHUF8423

Volvo Tag ID FCC ID: YGOHUF8432

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Canada

Volvo Standard Key IC: 4008C-HUF8423

Volvo Tag ID IC: 4008C-HUF8432

This device complies with Industry Canada license-exempt RSS standards. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Immobilizer and Passive entry/Passive start* systems

USA-FCC ID: LTQVO3134

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Canada-IC:3659A-VO3134

This device complies with Industry Canada license-exempt RSS standards. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Related information

Remote key (p. 237)

Keyless and touch-sensitive surfaces*

If the vehicle is equipped with keyless locking and unlocking, it is only necessary to have the remote key within range, e.g. in a pocket or bag, which makes it easier to open the vehicle if your hands are full.

◆ Pressure-sensitive surfaces

Door handle

There are indentations on the outside of the outer door handles for locking, and pressure-sensitive surfaces on the inside of the handles for unlocking.



- 1 Pressure-sensitive indentation for locking
- Pressure-sensitive surface for unlocking

(i) NOTE

It is important that only one pressure-sensitive surface is activated at a time. If the handle is grasped at the same time as the lock area is pressed, there is a risk that double commands may be sent. This may cause the requested action (locking/unlocking) to be delayed or not performed at all.

Tailgate

The tailgate handle has a rubberized pressure plate that can only be used for unlocking.



i NOTE


Please be aware that the system could be activated in a car wash if the remote key is within range.

Related information

- Keyless locking and unlocking* (p. 252)
- Keyless tailgate unlock* (p. 254)

Keyless locking and unlocking*

The vehicle can be locked or unlocked from outside using the door or tailgate handles if the vehicle is equipped with keyless locking/unlocking (Passive Entry)*.



- 1 Pressure-sensitive indentation for locking
- Pressure-sensitive surface for unlocking

252 * Option/accessory.



Rubberized pressure plate on the tailgate used only for unlocking.

(i) NOTE

One of the vehicle's remote keys must be within range for locking and unlocking to be possible.

i NOTE

Please be aware that the system could be activated in a car wash if the remote key is within range.

Keyless locking

All of the doors have to be closed before the vehicle can be locked. However, the tailgate can be open when a door handle is used for locking.

- To lock, touch the marked area on the outside of one of the door handles after the
 door is closed or press the button on the
 lower edge of the tailgate¹¹ before it is
 closed.
 - The lock indicator light in the windshield will flash to confirm that the vehicle is locked.

To close all door windows at the same time - place your finger on the pressure-sensitive indentation on the outside of the door handle and hold it there until the side windows have closed.

Locking when the tailgate is open

(i) NOTE

If the vehicle is locked and the tailgate is still open, make sure that the remote key is not left in the cargo compartment when the tailgate is closed and the entire vehicle is locked ¹².

Keyless unlocking

- To unlock, grasp a door handle or press the rubberized pressure plate on the underside of the tailgate handle.
 - > The lock indicator light in the windshield will go out to confirm that the vehicle is unlocked. Open the doors or tailgate as usual.

Automatic relocking

If none of the doors or tailgate are opened within two minutes after being unlocked, they will automatically relock. This function reduces the risk of inadvertently leaving the vehicle unlocked.

Related information

- Keyless unlock settings* (p. 254)
- Keyless tailgate unlock* (p. 254)
- Keyless and touch-sensitive surfaces* (p. 251)

¹¹ Applies to vehicles with power tailgate*.

¹² If the key is detected in the vehicle, the tailgate will not lock when it is closed.

Keyless unlock settings*

Several different sequences are available for kevless unlocking.

- 1. Tap **Settings** in the center display's Top view.
- Tap My Car → Locking → Keyless Unlock
- Select alternative:
 - All Doors
 - unlocks all doors at the same time.
 - Single Door
 - unlocks the selected door.

Related information

- Keyless locking and unlocking* (p. 252)
- Keyless and touch-sensitive surfaces* (p.251)

Kevless tailgate unlock*

The tailgate can be opened using the remote key. The key only needs to be within range, e.g. in a pocket or bag.

The tailgate is held closed by an electronic locking mechanism.



To open the tailgate:

- 1. Lightly press the rubberized pressure plate on the underside of the tailgate handle.
 - > The lock will disengage.



One of the vehicle's remote keys must be within range behind the vehicle for unlocking to be possible.

2. Lift the outer handle to fully open the tailgate.

CAUTION

- Only light pressure on the rubberized pressure plate is necessary to release the tailgate's locking mechanism.
- Use the handle to lift the tailgate and do not apply force to the rubberized pressure plate. Too much force can damage the pressure plate's electrical connections.

Hands-free unlocking of the tailgate is also possible using a foot movement under the rear bumper; see the separate section.

WARNING

Do not drive with the tailgate open. Toxic exhaust fumes can be sucked into the vehicle through the cargo compartment.


Related information

- Keyless locking and unlocking* (p. 252)
- Keyless and touch-sensitive surfaces* (p.251)
- Remote key range (p. 241)
- Foot movement tailgate operation* (p. 263)

254 * Option/accessory.

Antenna locations for the start and lock system

The vehicle is equipped with a keyless start and lock system¹³ that uses a number of integrated antennas positioned throughout the vehicle.



Location of the antennas,

- 1 Under the cup holder in the front section of the tunnel console
- 2 In the upper front section of the left-side rear door 14
- 3 In the upper front section of the right-side rear door 14
- 4 In the center of the rear seat backrest14

♠ WARNING

Individuals with an implanted pacemaker should not allow the pacemaker to come closer than 22 cm (9 in.) to the Keyless system antennas. The aim of this is to prevent disturbances between the pacemaker and the Keyless system.

Related information

- Keyless and touch-sensitive surfaces* (p. 251)
- Remote key range (p. 241)

Locking and unlocking from inside the vehicle

The doors and tailgate can be locked and unlocked from inside the vehicle using the central lock buttons in the front doors. The lock buttons in the rear doors* can be used to lock/unlock that particular door.

Central locking



Button with indicator light for locking and unlocking in front door.

Unlocking using the front door buttons

Press the 😈 button to unlock all side doors and the tailgate.

Press and hold the \bigcirc button to open all side windows at the same time 15.

¹³ The keyless lock system only applies to vehicles equipped with keyless locking and unlocking (Passive Entry*).

¹⁴ Only in vehicles equipped with keyless locking and unlocking (Passive Entry*).

¹⁵ The total airing function can be used to e.g. quickly air out the vehicle in hot weather.

◄ Alternative unlocking method



Alternative unlocking method using side door opening handle.

- Pull either of the side door inside opening handles and release.
 - Depending on the remote key settings, either all doors will be unlocked or just the selected door will be unlocked and opened.

To change this setting, tap Settings → My Car → Locking → Remote and Interior Unlock in the Top view of the center display.

Locking using the front door buttons

- Press the 🛈 button (both front doors must be closed).
 - > All doors and the tailgate will lock.

Press and hold the \bigcirc button to close all side windows at the same time.

Locking using the rear door button*



Button with indicator light for locking/unlocking in rear door.

The lock buttons in the rear doors only lock/unlock that particular door.

Unlocking the rear door

- Pull the opening handle to unlock the rear door.
- 2. Pull the opening handle again to open the rear door 16.

- Settings for remote and inside door unlock (p. 240)
- Unlocking the tailgate from inside the vehicle (p. 257)
- Activating and deactivating child safety locks (p. 257)

256 * Option/accessory.

Related information

¹⁶ Provided the child safety lock is not activated.

Unlocking the tailgate from inside the vehicle

The tailgate can be locked from the inside using a button on the dashboard.

1.



Press the \to button on the dashboard.

The tailgate will unlock and can be opened from the outside by pressing the rubberized pressure plate on the handle.

With the optional power tailgate* -

- Press and hold the button on the dashboard.
 - > The tailgate will open.

Related information

- Locking and unlocking from inside the vehicle (p. 255)
- Opening and closing the power tailgate* (p. 259)

Activating and deactivating child safety locks

Child safety locks help prevent children from opening the rear doors from inside the vehicle. There is an electric safety lock* and a manual safety lock.

Activating and deactivating electric child safety locks*

The electric child safety lock can be activated and deactivated in any ignition mode higher than **0**. The lock can be activated and deactivated up to 2 minutes after the engine is turned off if no door has been opened.



Button for electric activation and deactivation.

1. Start the engine and select any ignition mode higher than **0**.

- Press the button on the driver's door control panel.
 - The message Rear child lock Activated will be shown in the instrument panel and the indicator light will illuminate to show that the child safety locks are activated.

When the electric child safety locks are activated:

- the rear windows can only be opened using the driver's door control panel
- the rear doors cannot be opened from the inside.

To deactivate the child safety locks:

- Press the button on the driver's door control panel.
 - The message Rear child lock Deactivated will be shown in the instrument panel and the indicator light will go out to show that the child safety locks are deactivated.

When the engine is turned off, the current setting will be saved. If the locks were activated when the engine was turned off, they will remain activated the next time the engine is started.

Symbol	Message	Meaning
	Rear child lock Acti- vated	The child safety locks are activated.
a a	Rear child lock Deacti- vated	The child safety locks are deactivated.

Activating and deactivating manual child safety locks



Manual child safety lock (this is not the manual door lock).

- Use the detachable key blade in the remote key to turn the control.
- A The door cannot be opened from the inside.
- B The door can be opened from both the outside and the inside.

i NOTE

- The door's knob control only locks that specific door, not both rear doors simultaneously.
- There are no manual child safety locks on models equipped with electronic child safety locks.

Related information

- Locking and unlocking from inside the vehicle (p. 255)
- Detachable key blade (p. 248)

Automatic locking when driving

The doors and tailgate will automatically lock when the vehicle begins to move.

Related information

 Locking and unlocking from inside the vehicle (p. 255)

Opening and closing the power tailgate*

The tailgate can be opened and closed automatically with the optional power tailgate.

Opening the power tailgate

To open the tailgate, do one of the following:

 Press and hold the button on the remote key until the tailgate begins to open.



 Press and hold the button on the dashboard until the tailgate begins to open.



Press lightly on the tailgate's outside handle.



 Move your foot in a kicking motion* under the rear bumper.



Closing the power tailgate

To close the tailgate 17, do one of the following:

 Press the button on the lower edge of the tailgate to close.



> The tailgate will close automatically - the tailgate will remain unlocked.



NOTE

The button remains active 24 hours after the tailgate was opened. After this time, the tailgate must be closed manually.

- Press and hold the button on the remote key.
 - The tailgate closes automatically and an audible signal will sound - the tailgate will remain unlocked.

- Press and hold the button on the dashboard.
 - > The tailgate closes automatically and an audible signal will sound - the tailgate will remain unlocked.
- Move your foot in a kicking motion* under the rear bumper.
 - The tailgate closes automatically and an audible signal will sound - the tailgate will remain unlocked.

*Option/accessory.

¹⁷ Vehicles equipped with keyless locking and unlocking (Passive Entry*) have a button for closing and a button for closing and locking.

Closing and locking¹⁷ the power tailgate

- Press the button on the lower edge of the tailgate to close and simultaneously lock the tailgate and doors (all doors must be closed in order to lock).
 - > The tailgate closes automatically the tailgate and doors lock, and the alarm* is activated.

(i) NOTE

- One of the vehicle's remote keys must be within range for locking and unlocking to be possible.
- When the keyless locking or closing* functions are used, three audible signals will sound if the key is not detected close enough to the tailgate.

(!) CAUTION

When operating the tailgate manually, open and close it slowly. If you encounter resistance, do not use force. This could lead to damage and loss of function.

Interrupting opening or closing

Interrupt opening or closing by doing one of the following:

- Press the button on the dashboard.
- Press the button on the remote key.
- Press the close button on the underside of the tailgate.
- Press the rubberized pressure plate on the underside of the tailgate's outer handle.
- Using a foot movement*.

Tailgate movement is interrupted and stops. The trunk lid can then be opened or closed manually.

Pinch protection

If anything obstructs the tailgate with enough force to prevent it from opening or closing, pinch protection will be activated.


- When opening the tailgate will stop moving and an audible signal will sound.
- When closing the tailgate will stop, a long audible signal will sound and the tailgate will return to the programmed maximum opening position.

MARNING

Be aware of the risk of serious injury when operating the tailgate. Before opening/closing, make sure that no one is in the path of the tailgate who could be injured by its movement.

Always operate the tailgate with caution.

Preloaded springs



Preloaded springs for the power tailgate.

Do not attempt to open or access the preloaded springs in the power tailgate struts. They are preloaded with high pressure and can cause injury if opened.

¹⁷ Vehicles equipped with keyless locking and unlocking (Passive Entry*) have a button for closing and a button for closing and locking.

Related information

- Setting a maximum height for the power tailgate* (p. 262)
- Foot movement tailgate operation* (p. 263)
- Remote key range (p. 241)

Setting a maximum height for the power tailgate*

The tailgate can be set to stop opening at a certain height, for example if the tailgate needs to be opened in a garage with a low ceiling.

Setting maximum opening height:

1. Open the tailgate to the desired opening height.

(i) NOTE

It is not possible to program an opening position lower than half-open tailgate.

- 2. Press the co button on the lower edge of the tailgate and hold for at least 3 seconds.
 - > Two brief audio signals will sound to indicate that the position has been stored.

Resetting to maximum opening position:

- Move the tailgate manually to its highest possible position and press the co button on the tailgate for at least 3 seconds.
 - > Two audio signals will sound to indicate that the stored position has been erased. The tailgate can then be opened to its maximum position.

(i) NOTE

If the system has been working continuously for a prolonged period of time, it will be switched off to avoid overload. It can be used again after approximately 2 minutes.

Related information

Opening and closing the power tailgate* (p. 259)

262 * Option/accessory.

Foot movement tailgate operation*

To make it easier to operate the tailgate when your hands are full, it can be opened and closed by moving your foot in a forward kicking motion under the rear bumper.



The sensor is located to the left of center under the rear bumper¹⁸.

One of the vehicle's remote keys must be within range behind the vehicle (approx. 1 meter (3 feet)) for opening and closing to be possible. This applies even if the vehicle is unlocked in order to prevent the trunk lid from inadvertently opening e.g. at a car wash.

Foot movement operation



Kicking motion within the sensor's activation area.

- Make one slow forward kicking motion with your foot under the left section of the rear bumper. Take a step back. Do not touch the bumper.
 - A brief audible signal will be heard when opening or closing is activated - the tailgate will open/close.

If the tailgate is open, it will always close¹⁹ when the foot motion sensor is activated.

If several opening attempts have been made without the remote key in range behind the vehicle, foot movement operation will not be available for a short period of time.

Do not keep your foot under the vehicle in a kicking motion. This may prevent activation.

Interrupting opening or closing with a foot movement

 Make **one** slow forward kicking motion while the tailgate is opening or closing to stop its movement.

The remote key does not need to be within range of the vehicle to interrupt opening or closing.

(i) NOTE

There is a risk of reduced or lost function if there are large amounts of snow, ice, dirt, etc. on the rear bumper. Make sure to keep the bumper clean.

i NOTE

Please note that the system could be inadvertently activated in a car wash or similar if the remote key is within range.

Vehicle with skid plate accessory*

If the vehicle is equipped with skid plate, the sensor is located towards the left corner of the bumper.

 $^{^{18}}$ If the vehicle is equipped with skid plate*, the sensor is located towards the left corner of the bumper.

¹⁹ Applies to vehicles with power tailgate*.

44



To activate opening and closing using a foot movement on a vehicle with skid plate, make a kicking motion from the side of the vehicle. One of the vehicle's remote keys must be within range (approx. 1 meter (3 feet)) for opening and closing to be possible.



Kicking motion within the sensor's activation area.

Related information

- Keyless and touch-sensitive surfaces* (p. 251)
- Opening and closing the power tailgate* (p. 259)
- Remote key range (p. 241)

Private Locking

The glove compartment and the tailgate can be locked using the private locking function to prevent them from being opened, e.g. when the vehicle is left at a workshop or with a valet.



The function button for private locking is located in the center display's Function view.
Depending on the current status of the lock, **Private**Locking Unlocked or **Private**Locking Locked will be dis-

played.

Related information

 Activating and deactivating private locking (p. 265)

264 *Option/accessory.

Activating and deactivating private locking

Private locking is activated using the function button in the center display and a PIN code.



For the valet lock function to be activated the car must be in at least ignition mode **I**.

Entering security code before initial use

The first time the function is used, a security code must be selected. This code can then be used to deactivate private locking if the selected PIN code has been lost or forgotten. The security code functions as a PUK (security) code for all PIN codes used for private locking.

Save the security code in a safe place.

To create a security code:

 Tap the button for private locking in Function view.



> A pop-up window will appear.

- 2. Enter your security code.
 - > The security code is saved. The private locking function is now ready for activation.

If the system has been reset, the above procedure will need to be repeated.

Activating private locking

 Tap the button for private locking in Function view.



- > A pop-up window will appear.
- Enter the code you would like to use to unlock the glove compartment and the tailgate and tap Confirm.
 - The glove compartment and tailgate will lock. A green indicator light will illuminate next to the button in Function view to confirm locked status.

Deactivating private locking

Tap the button for private locking in Function view.



- > A pop-up window will appear.
- 2. Enter the code used for locking and tap **Confirm**
 - > The glove compartment and tailgate will unlock. The green indicator light next to the button in Function view will go out to confirm unlocked status.

i NOTE

If you have forgotten or lost your PIN code or if the PIN code has been entered incorrectly more than three times, the security code can be used to deactivate private locking.

i NOTE

If private locking is activated and the vehicle is unlocked using Volvo On Call* or the Volvo On Call* app, private locking will be deactivated automatically.

Related information

Private Locking (p. 264)

Alarm

The alarm emits sound and light signals if anyone without a valid remote key attempts to break into the vehicle or interferes with the start battery or alarm siren.

When armed, the alarm will be triggered if:

- the hood, tailgate or any door is opened.
- a battery cable is disconnected
- the alarm siren is disconnected.

Alarm signals

The following occurs if the alarm is triggered:

- A siren will sound for 30 seconds or until the alarm is turned off.
- All turn signals will flash for 5 minutes or until the alarm is turned off.

If the reason the alarm was triggered is not rectified, the alarm cycle will repeat up to 10 times²⁰.

Alarm indicator



A red indicator light on the dashboard shows the status of the alarm:

- Indicator off the alarm is disarmed.
- Indicator flashes once every two seconds the alarm is armed.
- The indicator flashes quickly after the alarm has been disabled for up to 30 seconds or until the ignition is put in I mode by turning the start knob clockwise and then releasing the alarm has been triggered.

²⁰ Certain markets only.

In the event of alarm system failure



If a problem is detected in the alarm system, a symbol and the message Alarm system failure Service required will appear in the instrument

panel. Contact a workshop - an authorized Volvo workshop is recommended.



Do not attempt to repair or alter any of the components in the alarm system yourself. Any such attempt could affect the terms and conditions of your insurance policy.

Related information

• Arming and disarming the alarm (p. 267)

Arming and disarming the alarm

The alarm is armed when the vehicle is locked.

Arming the alarm

Lock and arm the vehicle by:

- \bullet pressing the lock button on the remote key $\ensuremath{\overline{\mathbb{Q}}}$
- touch the marked surface on the outside of the door handle or the rubberized pressure plate on the tailgate²¹.

If the vehicle is equipped with both keyless locking/unlocking* and power tailgate*, the button <a>s on the lower edge of the tailgate can also be used to lock and arm the vehicle.



A red LED light on the dashboard will flash every other second when the vehicle is locked and the alarm is armed.

Unlock and disarm the vehicle alarm by:

- pressing the unlock button on the remote key \mathbb{R}
- grip a door handle or press the tailgate's rubberized pressure plate²¹.


Disarming the alarm

²¹ Only vehicles with keyless locking and unlocking* (Passive Entry).

Disarming the alarm without a functioning remote key

The vehicle can be unlocked and disarmed even if the remote key is not functioning, e.g. if the battery is discharged.

- Open the driver's door using the detachable key blade.
 - > This will trigger the alarm.



Location of the backup key reader in the cup holder.

- Place the remote key on the key symbol in the backup reader in the tunnel console's cup holder.
- 3. Turn the start knob clockwise and release.
 - > The alarm will be disarmed.

Turning off a triggered alarm

 Press the unlock button on the remote key or put the ignition into mode I by turning the start knob clockwise and then releasing it.

(i) NOTE

- Remember that the alarm is armed when the vehicle is locked.
- The alarm will be triggered if any of the doors is opened from the inside.

Automatically arming and disarming the alarm

Automatically arming the alarm helps prevent inadvertently leaving the vehicle without alarm protection.

If the vehicle is unlocked using the remote key (and the alarm is disarmed) but none of the doors or tailgate are opened within two minutes, the alarm will be automatically rearmed. The vehicle will also re-lock.

On some markets, the alarm will be automatically armed following a slight delay after the driver's door has been opened and closed without being locked.

To change this setting:

- Tap **Settings** in the center display's Top view.
- Tap My Car → Locking.
- Select Passive Arming Deactivation to temporarily deactivate the function.

Related information

• Alarm (p. 266)

Foreign Component Detection*

The Foreign Component Detection function detects if an unknown component has been connected to the vehicle.

Each LED headlight* is customized for the vehicle. If an unrecognized headlight is used, the message **Unknown vehicle part. Service required, unknown part found.** will be displayed in the instrument panel. Volvo recommends contacting an authorized Volvo workshop.

Related information

• Volvo's service program (p. 576)

*Option/accessory.

Driver support systems

The vehicle is equipped with a number of driver support systems that can provide the driver with active or passive assistance in various situations.

The system can, for example, help the driver maintain a set speed or a set time interval to the vehicle ahead, help prevent a collision by warning the driver and applying the brakes, or assist the driver while parking.

Some of the systems are standard and others are options. This also varies from market to market.

Related information

- Speed-dependent steering wheel resistance (p. 270)
- Electronic Stability Control (p. 272)
- Stability system Roll Stability Control (p. 271)
- Rear Collision Warning (p. 345)
- Speed limiter (p. 276)
- Cruise control (p. 284)
- Distance Alert* (p. 289)
- Adaptive Cruise Control* (p. 293)
- Pilot Assist (p. 309)
- Radar sensor (p. 324)
- Camera (p. 329)
- City SafetyTM (p. 333)
- BLIS* (p. 346)

- Cross Traffic Alert* (p. 351)
- Road Sign Information* (p. 355)
- Driver Alert Control (p. 360)
- Lane Keeping Aid (p. 362)
- Steering assistance at risk of collision (p. 370)
- Park Assist* (p. 379)
- Park Assist Camera* (p. 384)
- Park Assist Pilot* (p. 393)

Speed-dependent steering wheel resistance

Speed-dependent power steering increases the steering wheel resistance in pace with the vehicle's speed to give the driver an enhanced feeling of control and stability.

Steering may feel stiffer on highways. When parking and at low speeds, it will be easier to move the steering wheel.



NOTE

In some situations, the power steering may become too hot and require temporary cooling – during such time the power steering will work at reduced output and the steering wheel may feel more difficult to move.

In parallel with the temporarily reduced steering assistance, the driver display shows a message as well as a STEERING WHEEL symbol.

270 *Option/accessory.

<u>∧</u> wa

WARNING

While the power steering is working at reduced power, the driver support functions with steering assistance are not available.

In such a situation, the driver display shows the Power steering failure or Power Steering Assist Temporarily Reduced message, combined with a STEERING WHEEL symbol.

Changing the level of steering wheel resistance*

To change the level of steering wheel resistance, see the description of the INDIVIDUAL option under "Available drive modes" in the "Drive modes" section.

On models not equipped with drive mode controls and the INDIVIDUAL option, steering wheel resistance can instead be set in the center display's Top view under:

Settings → My Car → Drive Modes → Steering force

Steering wheel resistance settings cannot be accessed when turning at speeds above 10 km/h (6 mph).

Related information

- Drive modes* (p. 423)
- Pilot Assist (p. 309)

- Lane Keeping Aid (p. 362)
- Steering assistance at risk of collision (p. 370)
- Park Assist Pilot* (p. 393)

Stability system Roll Stability Control

The Roll Stability Control (RSC¹) system helps minimize the risk of a rollover in the event of e.g. a sudden evasive maneuver or if the vehicle begins to skid.

The RSC system monitors the lateral angle at which the vehicle is leaning and registers any changes. Using this information, the system calculates the likelihood of a rollover. If there is an imminent risk of a rollover, Electronic Stability Control is activated, engine torque is reduced and brakes are applied to one or more of the wheels until the vehicle has regained stability.



WARNING

The vehicle's stability systems, including RSC do not replace the driver's responsibility for operating the vehicle in a safe manner. Speed and driving style should always be adapted to the current road, traffic and weather conditions. Posted speed limits should always be respected.

Electronic Stability Control

The Electronic Stability Control (ESC²) function helps the driver avoid skidding and improves the vehicle's directional stability.



This symbol will be displayed in the instrument panel when the ESC system is intervening.

When the ESC has intervened to apply the brakes, a pulsing sound may be heard and the

vehicle may accelerate more slowly than expected when the accelerator pedal is depressed.

The ESC system consists of the following subfunctions:

- Stability control³
- Spin control and active vaw control
- Engine drag control
- Trailer Stability Assist

- The Electronic Stability Control system ESC is supplementary driver support intended to facilitate driving and make it safer – it cannot handle all situations in all traffic, weather and road conditions.
- ESC is not a substitute for the driver's attention and judgment. The driver is always responsible for ensuring the vehicle is driven in a safe manner, at the appropriate speed, with an appropriate distance to other vehicles, and in accordance with current traffic rules and regulations.

Stability control³

This function helps control the driving and braking force of each individual wheel in an attempt to stabilize the vehicle.

Spin control and active yaw control

This function is active at low speeds and brakes the wheels that are spinning to transfer additional power from wheels that are not spinning.

This function also helps prevent the wheels from spinning while the vehicle is accelerating.

Engine drag control

Engine drag control (EDC⁴) helps prevent inadvertent wheel lock, e.g. after downshifting or using engine braking when driving at low speeds on a slippery surface.

Inadvertent wheel lock while driving could impair the driver's ability to steer the vehicle.

Trailer Stability Assist*5

Trailer Stability Assist (TSA⁶) is designed to help stabilize a vehicle that is towing a trailer if the vehicle and trailer have begun to sway. For more information, see "Trailer Stability Assist".



NOTE

The TSA function is deactivated if **ESC Sport Mode** is activated.

Related information

- Electronic Stability Control Sport mode (p. 273)
- Activating/deactivating Sport mode in Electronic Stability Control (p. 273)

272 * Option/accessory.

¹ Roll Stability Control

² Electronic Śtability Control

³ Also called traction control.

⁴ Engine Drag Control

⁵ Trailer Stability Assist is included if the vehicle is equipped with a Volvo original towbar.

⁶ Trailer Stability Assist

- Electronic Stability Control Sport mode limitations (p. 274)
- Electronic Stability Control symbols and messages (p. 275)

Electronic Stability Control Sport mode

The ESC⁷ system is always activated and cannot be switched off. However, the driver can select ESC Sport Mode, which offers more active driving characteristics.

With the **ESC Sport Mode** sub-function selected, intervention from ESC is reduced and more lateral movement is permitted, giving the driver more control of the vehicle than usual.

When **ESC Sport Mode** is selected, ESC may seem to be disabled even though it is often assisting the driver.



NOTE

When the **ESC Sport Mode** function is selected, the trailer stabilizer (TSA⁸) is switched off.

ESC Sport Mode also helps provide maximum traction if the vehicle gets stuck or is driving on a loose surface such as deep snow or loose sand.

Related information

Electronic Stability Control (p. 272)

Activating/deactivating Sport mode in Electronic Stability Control

The ESC⁹ system is always activated and cannot be switched off. However, the driver can select Sport mode, which offers more active driving characteristics.



Sport mode can be activated/ deactivated in the center display's Function view.

- Tap the ESC Sport Mode button in Function view.
 - Sport mode is activated when the indicator light is green, and deactivated when the indicator light is gray.



When **ESC Sport Mode** is activated, this symbol will illuminate with a steady glow in the instrument panel. It will remain on until the driver deactivates

the function or until the engine is turned off. The ESC system will return to normal mode the next time the engine is started.

Related information

Electronic Stability Control (p. 272)

⁷ Electronic Stability Control

⁸ Trailer Stability Assist

⁹ Electronic Stability Control

Electronic Stability Control Sport mode limitations

There are certain limitations associated with the ESC¹⁰ system's subfunction ESC Sport Mode being activated.

The **ESC Sport Mode** function cannot be selected when any of the following functions are activated:

- Speed limiter
- Cruise control
- Adaptive Cruise Control
- Pilot Assist.

Related information

• Electronic Stability Control (p. 272)

¹⁰ Electronic Stability Control

Electronic Stability Control symbols and messages

A number of symbols and messages related to Electronic Stability Control (ESC) may be displayed in the instrument panel.

Some examples of symbols and messages are shown in the table below.

Symbol	Message	Meaning
*	Steady glow for approx. 2 seconds.	System check when the engine is started.
\$\$ 	Flashing light.	The ESC is actively operating.
OFF	Steady glow.	Sport mode is activated. Note: The ESC system is not deactivated in this mode, but has partially reduced functionality.
₹	ESC Temporarily off	The ESC system's functionality has been temporarily reduced due to high brake system temperatures. The function will be automatically reactivated when the brakes have cooled. See the message in the instrument panel.
? ?	ESC Service required	The ESC system is not functioning properly. Stop the vehicle in a safe place, turn off the engine and then restart it. Consult a workshop if the message persists – an authorized Volvo workshop is recommended.

A text message can be erased by briefly pressing the O button in the center of the right-side steering wheel keypad.


If the message persists: Contact a workshop – an authorized Volvo workshop is recommended.

Related information

• Electronic Stability Control (p. 272)

Speed limiter

A Speed Limiter (SL¹¹) could be described as a reverse cruise control. The driver regulates the vehicle's speed using the accelerator pedal, but is prevented by the Speed Limiter from inadvertently exceeding a preset maximum speed.



Function buttons and symbols 12.

- [†]: Activates the Speed Limiter from standby mode and resumes the set maximum speed.
- 1 +: Increases the set maximum speed
- 2 : From standby mode activates the Speed Limiter and sets the current speed
- 2 (5): From active mode deactivates/puts the Speed Limiter in standby mode

- 3 : Reduces the set maximum speed
- 4 Marker for set maximum speed
- The vehicle's current speed
- 6 The set maximum speed

⚠ WARNING

- The Speed Limiter function is supplementary driver support intended to facilitate driving and help make it safer it cannot handle all situations in all traffic, weather and road conditions.
- The driver must always pay attention to traffic conditions and take action if the Speed Limiter is not maintaining a suitable speed.
- The Speed Limiter is not a substitute for the driver's attention and judgment. The driver is always responsible for ensuring the vehicle is driven in a safe manner, at the appropriate speed, with an appropriate distance to other vehicles, and in accordance with current traffic rules and regulations.

Related information

- Cruise Control limitations (p. 280)
- Activating and starting Speed Limiter (p. 277)
- Managing Speed Limiter speed (p. 277)
- Deactivating and putting Speed Limiter in standby mode (p. 278)
- Reactivating Speed Limiter from standby mode (p. 279)
- Turning off Cruise Control (p. 279)
- Automatic Speed Limiter (p. 280)
- Automatic Speed Limiter limitations (p. 283)
- Activating/deactivating Automatic Speed Limiter (p. 282)
- Changing Automatic Speed Limiter tolerance (p. 283)


¹¹ Speed Limiter

¹² Note: This illustration is general and details may vary depending on model.

Activating and starting Speed Limiter

The Speed Limiter (SL¹³) function must be selected and activated in order to regulate speed.

Putting Speed Limiter in standby mode



Note: This illustration is general and details may vary depending on model.

- Press

 (1) or ► (3) and scroll to the Speed

 Limiter function (4).
 - > The symbol (4) will appear, indicating that the Speed Limiter is in standby mode.

Starting the Speed Limiter

The Speed Limiter can only be activated while the engine is running. The lowest maximum speed that can be set is 30 km/h (20 mph).

the symbol displayed, press the

- button (2) on the steering wheel keypad.
- > The Speed Limiter will be started and the vehicle's current speed will be set as the maximum speed.


Related information

Speed limiter (p. 276)

Managing Speed Limiter speed

The Speed Limiter (SL¹⁴) can be set to various speeds.

Setting/changing set speed



Note: This illustration is general and details may vary depending on model.

- Change a set speed by pressing the + (1)
 or (3) buttons briefly or by pressing and
 holding them:
 - Press briefly: Press briefly: each press changes the speed in +/- 5 mph (+/- 5 km/h) increments.
 - Press and hold: Release the button when the set speed indicator (4) has moved to the desired speed.
- The most recently set speed will be stored.

With the Speed Limiter in standby mode and


¹³ Speed Limiter

Related information

Speed limiter (p. 276)

Deactivating and putting Speed Limiter in standby mode

The Speed Limiter (SL¹⁵) can be temporarily deactivated and put in standby mode.



Note: This illustration is general and details may vary depending on model.

To deactivate the Speed Limiter and put it in standby mode:

- Press the button on the steering wheel (2).
 - > The speed limit markings and symbols in the instrument panel will change from WHITE to GRAY. This indicates that the Speed Limiter is temporarily deactivated and the driver can exceed the set maximum speed.

Temporarily deactivating using the accelerator pedal

The set maximum speed can be temporarily deactivated and exceeded using the accelerator pedal without first putting the Speed Limiter in standby mode, e.g. when quick acceleration is required.

To do so:

- Depress the accelerator as far as possible and then release it when the desired speed has been reached.
 - > The Speed Limiter will remain activated and the symbol in the instrument panel will be WHITE.
- 2. Release the accelerator pedal fully when the temporary acceleration is completed.
 - The vehicle will automatically slow down to a speed below the most recently set maximum speed.

Related information


Speed limiter (p. 276)

¹⁴ Speed Limiter

¹⁵ Speed Limiter

Reactivating Speed Limiter from standby mode

Speed Limiter (SL¹⁶) can be reactivated after having been temporarily deactivated and put in standby mode.



Note: This illustration is general and details may vary depending on model.

To reactivate the Speed Limiter from standby mode:

- Press the 3[†] button on the steering wheel
 (1).
 - > The speed limit markings in the instrument panel will change from GRAY to WHITE. The vehicle's speed will once again be limited to the most recently set speed.

or

> The speed limit markings and symbols in the instrument panel will change from GRAY to WHITE and the vehicle's current speed will be set as the maximum speed.

Related information

• Speed limiter (p. 276)

Turning off Cruise Control

The Speed Limiter (SL¹⁷) can be turned off.



Note: This illustration is general and details may vary depending on model.

- 1. Press the (5) button on the steering wheel (2).
 - > The Speed Limiter will go into standby mode.
- 2. Press the ◀ (1) or ▶ (3) buttons on the steering wheel to select another function.
 - > The Speed Limiter symbol and marking (4) in the instrument panel will go out and the set maximum speed will be erased.
- 3. Press the (2) button on the steering wheel keypad again.
 - > Another function will be activated.

⁻ Press the (9) button on the steering wheel (2).

¹⁶ Speed Limiter

Related information

Speed limiter (p. 276)

Cruise Control limitations

On steep downgrades, the Speed limiter's braking capacity may not be sufficient and the set maximum speed may be exceeded. If this happens, **Speed limit exceeded** will be displayed in the instrument panel to alert the driver.



NOTE

A text message on exceeded max. speed is activated if the speed is exceeded by at least 3 km/h (ca 2 mph).

Related information

• Speed limiter (p. 276)

Automatic Speed Limiter

The Automatic Speed Limiter (ASL¹⁸) function helps the driver adapt the vehicle's maximum speed to the posted speed limits.

The Speed Limiter (SL¹⁹) function can be switched to Automatic Speed Limiter (ASL).

The Automatic Speed Limiter function uses speed information from the Road Sign Information function 20 to automatically adapt the vehicle's maximum speed.

¹⁷ Speed Limiter

¹⁸ Automatic Speed Limiter

¹⁹ Speed Limiter

²⁰ Road Sign Information - RSI

- The ASL function is supplementary driver support intended to facilitate driving and help make it safer – it cannot handle all situations in all traffic, weather and road conditions.
- Even if the driver can clearly see the speed limit sign, the speed information from the Road Sign Information (RSI) function to ASL may be incorrect. In such cases, the driver must intervene and accelerate or brake to an appropriate speed.
- ASL is not a substitute for the driver's attention and judgment. The driver is always responsible for ensuring the vehicle is driven in a safe manner, at the appropriate speed, with an appropriate distance to other vehicles, and in accordance with current traffic rules and regulations.
- See also the heading "Road Sign Information limitations".

Is SL or ASL active?

The symbols in the instrument panel indicate which Speed Limiter function is active:

Symbol		ASL
	✓	✓
709 Road sign symbol ^B after "70" = ASL is activated.		√

A WHITE symbol: The function is active. GRAY symbol: Standby

ASL symbol



The road sign symbol (next to the stored speed ("70" here) in the center of the speedometer) can be displayed in three different colors, which are

explained in the following table:

Road sign symbol's color	Explanation	
Greenish-yel- low	ASL is active	
Gray	ASL is in standby mode	
Amber/orange	ASL is temporarily in standby mode, e.g. because a speed limit sign could not be read.	

Related information

• Speed limiter (p. 276)

B See "ASL symbol" below for an explanation of the symbol's different colors.

Activating/deactivating Automatic Speed Limiter

The Automatic Speed Limiter (ASL²¹) is a supplement to the Speed Limiter (SL²²) and can be activated/deactivated.

Activating ASL



The **Speed Sign Assist** button is located in the center display's Function view.

To activate the Automatic Speed Limiter:

- 1. Tap the Speed Sign Assist button.
 - ASL will go into standby mode and a green indicator light will illuminate. A road sign symbol will be displayed in the center of the speedometer in the instrument panel.
- 2. Pressing the () button on the steering wheel keypad.
 - > ASL will be activated and set to the vehicle's current speed.

(i) NOTE

- If the Automatic Speed Limiter function is activated, road sign information is shown in the driver display even if RSI is not activated.
- To remove road sign information from the driver display, you must deactivate **both** Automatic Speed Limiter and RSI.
- When the Automatic Speed Limiter function is activated but RSI is deactivated, no warnings are given from RSI. In this situation, settings for RSI cannot be adjusted either to be able to adjust settings as well as receive warnings, RSI must be activated.

Deactivating ASL

To deactivate the Automatic Speed Limiter:

- Tap the Speed Sign Assist button in Function view.
 - > ASL will be deactivated, the indicator light in the button will be GRAY and SL will be activated instead.

The vehicle will no longer follow the posted maximum speed after switching from ASL to SL – it then only follows the maximum speed stored in the memory.

Related information

Speed limiter (p. 276)


²¹ Automatic Speed Limiter

²² Speed Limiter

Changing Automatic Speed Limiter tolerance

The Automatic Speed Limiter (ASL²³) can be set to different tolerance levels.

It is also possible to allow the vehicle to drive above or below the posted speed limit. For example, if the vehicle is following a current posted speed limit of 70 km/h (43 mph), the driver can instead allow the vehicle to maintain a speed of 75 km/h (47 mph).



Function buttons and symbols²⁴.

- - > The vehicle will then use the selected tolerance of 5 km/h (4 mph) as long as the posted speed limit the vehicle passes is 70 km/h (43 mph).

This tolerance level will be followed until the vehicle passes a sign with a lower or higher speed. The vehicle will then adjust to the new speed limit and the set tolerance will be deleted from the system's memory.

If Road Sign Information* is activated, the posted speed limit will then be indicated by a RED marking on the speedometer's speed scale.

The set tolerance can be adjusted in the same way as for the Speed Limiter's speed.

(\mathbf{i})

NOTE

The highest possible selectable tolerance is +/- 10 km/h (5 mph).

Related information

Speed limiter (p. 276)

Automatic Speed Limiter limitations

ASL utilizes the speed limit information provided by the RSI²⁵ system, not from the speed limit signs that the vehicle passes.

If RSI²⁵ is unable to interpret and provide ASL with speed information, ASL will go into standby mode and switch over to SL. The driver will then have to actively brake to bring the vehicle down to the appropriate speed.

ASL will be reactivated when ${\rm RSI}^{25}$ is once again able to interpret and provide speed information to ASL.

See "Road Sign Information limitations" for more information.

Related information

• Speed limiter (p. 276)

²³ Automatic Speed Limiter

²⁴ Note: This illustration is general and details may vary depending on model.

²⁵ Road Sign Information (RSI)

Cruise control

Cruise Control (CC²⁶) helps the driver maintain an even speed to provide a more relaxing driving experience on highways and long, straight roads with even traffic flows.

Overview



Function buttons and symbols²⁷.

- 1 2 : Activates Cruise Control from standby mode and resumes the set speed
- 1 +: Increases the set speed
- 2 S: From standby mode activates Cruise Control and sets the current speed
- 2 S: From active mode deactivates/puts Cruise Control in standby mode

- 3 : Reduces the set speed
- Marker for set speed
- The vehicle's current speed
- 6 Set speed

(i) NOTE

In vehicles equipped with Adaptive Cruise Control*, it is possible to switch between cruise control and Adaptive Cruise Control – see the heading "Switching between CC and ACC".

MARNING

- The cruise control function is supplementary driver support intended to facilitate driving and help make it safer it cannot handle all situations in all traffic, weather and road conditions.
- The driver is advised to read all sections in the Owner's Manual about this function to learn of its limitations, which the driver must be aware of before using the function (see the link list at the end of this article).
- Cruise control is not a substitute for the driver's attention and judgment. The driver is always responsible for ensuring the vehicle is driven in a safe manner, at the appropriate speed, with an appropriate distance to other vehicles, and in accordance with current traffic rules and regulations.

Related information

- Activating and starting Cruise Control (p. 285)
- Managing Cruise Control speed (p. 286)
- Deactivating and putting Cruise Control in standby mode (p. 287)

284 *Option/accessory.

²⁶ Cruise Control

²⁷ Note: This illustration is general and details may vary depending on model.

- Reactivating Cruise Control from standby mode (p. 288)
- Switching off Cruise Control (p. 288)

Activating and starting Cruise Control

The Cruise Control (CC²⁸) function must be selected and activated in order to regulate speed.



Note: This illustration is general and details may vary depending on model.

Putting Cruise Control in standby mode

To put Cruise Control in standby mode:

- Tap ◀ (1) or ▶ (3) and scroll to the (4) function.
 - > A symbol will appear and Cruise Control can then be activated.

Activating/starting Cruise Control

In order to start Cruise Control from standby mode, the vehicle's current speed must be 30 km/h (20 mph) or higher. The lowest speed that can be set is 30 km/h (20 mph).

To start Cruise Control:

- With the function displayed, press
 - $oldsymbol{oldsymbol{eta}}$ (2) on the steering wheel keypad.
 - > Cruise Control will be started and the vehicle's current speed will be set.



Cruise control can then not be connected at speeds below 30 km/h (20 mph).

Related information

Cruise control (p. 284)

²⁸ Cruise Control

Managing Cruise Control speed

Cruise Control (CC²⁹) can be set to various speeds.

Setting/changing set speed



Note: This illustration is general and details may vary depending on model.

For vehicles with only CC

- Change a set speed by pressing the + (1) or (3) buttons briefly or by pressing and holding them:
 - Press briefly: Press briefly: each press changes the speed in +/- 1 mph (+/- 1 km/h) increments.
 - Press and hold: Release the button when the set speed indicator (4) has moved to the desired speed.

• The most recently set speed will be stored.

If speed is increased by depressing the accelerator pedal while pressing the + (1) button on the steering wheel, the vehicle's speed when the button is pressed will be stored as the set speed.

Temporarily increasing speed using the accelerator pedal, e.g. when passing another vehicle, will not affect the setting. The vehicle will return to the set speed when the accelerator pedal is released.

For vehicles with both CC and ACC

- Change a set speed by pressing the + (1)
 or (3) buttons briefly or by pressing and holding them:
 - Press briefly: Press briefly: each press changes the speed in +/- 5 mph (+/- 5 km/h) increments.
 - **Press** and **hold**: Release the button when the set speed indicator (4) has moved to the desired speed.
- The most recently set speed will be stored.

If speed is increased by depressing the accelerator pedal while pressing the + (1) button on the steering wheel, the vehicle's speed when the button is pressed will be stored as the set speed.

Temporarily increasing speed using the accelerator pedal, e.g. when passing another vehicle, will not affect the setting. The vehicle will return to the set speed when the accelerator pedal is released.

Using engine braking instead of applying the brakes

Cruise Control regulates speed by lightly applying the brakes. On downgrades, it can sometimes be desirable to roll a bit faster and let speed be reduced instead by engine braking alone. The driver can temporarily disengage the Cruise Control braking function.

To disengage CC:

- Press the accelerator pedal about halfway down and then release it.
 - > Cruise Control will automatically disengage the automatic brake function and speed will only be reduced using the engine braking function.

How drive mode affects cruise control

The way the cruise control maintains the vehicle's speed can vary depending on the selected drive mode³⁰.

²⁹ Cruise Control

³⁰ For more information, see "Drive modes"

Cruise Control Eco Cruise

In the ECO drive mode, cruise control's acceleration and deceleration will be smoother than in other drive modes to help provide optimal fuel efficiency and reduced environmental impact. Because of this, the vehicle's actual speed may be slightly above or below the set speed.

For more information, see "ECO drive mode" under "Eco Cruise".

Cruise Control Dynamic Cruise

With the Dynamic drive mode, cruise control's acceleration and deceleration will be faster and more immediate than in other drive modes.

Related information

• Cruise control (p. 284)

Deactivating and putting Cruise Control in standby mode

Cruise Control (CC³¹) can be temporarily put into standby mode and then reactivated.

Deactivating and putting Cruise Control in standby mode



Note: This illustration is general and details may vary depending on model.

To put Cruise Control in standby mode:

- Press the button on the steering wheel (2).
 - The Cruise Control markings and symbols will change from WHITE to GRAY, indicating that Cruise Control is temporarily deactivated and the driver needs to control the vehicle's speed.

Standby mode due to action by the driver

Cruise Control will be temporarily deactivated and put in standby mode if:

- the brakes are applied
- the gear selector is moved to N
- the vehicle is driven faster than the set speed for more than 1 minute

The driver must then control the vehicle's speed.

Temporarily increasing speed using the accelerator pedal, e.g. when passing another vehicle, will not affect the setting. The vehicle will return to the set speed when the accelerator pedal is released.

Automatic standby mode

Cruise Control will be temporarily deactivated and put in standby mode if:

- the wheels lose traction
- the engine speed (rpm) is too low/high
- the temperature in the brake system becomes too high
- the vehicle's speed goes below 30 km/h (20 mph).

The driver must then control the vehicle's speed.

Related information

• Cruise control (p. 284)

³¹ Cruise Control

Reactivating Cruise Control from standby mode

Cruise Control (CC³²) can be temporarily put into standby mode and then reactivated.

Reactivating Cruise Control from standby mode



Note: This illustration is general and details may vary depending on model.

To start Cruise Control from standby mode:

- Press the 3[†] button on the steering wheel
 (1).
 - > The Cruise Control marking in the instrument panel will change from GRAY to WHITE and the vehicle will then return to the most recently set speed.

or

32 Cruise Control

To start Cruise Control from standby mode:

- Press the (5) button on the steering wheel (2).
 - > The Cruise Control markings and symbols in the instrument panel will change from GRAY to WHITE and the vehicle's current speed will be set.

⚠ WARNING

A noticeable increase in speed may follow when the speed is resumed with the \circlearrowleft steering wheel button.

Related information

Cruise control (p. 284)

Switching off Cruise Control

Cruise control (Cruise Control - CC) can be turned off.



Function buttons and symbols³³.

To turn off Cruise Control:

- 1. Press the (5) button on the steering wheel (2).
 - > Cruise Control will go into standby mode.
- Press the ◀ (1) or ▶ (3) buttons on the steering wheel to select another function.
 - The Cruise Control symbol (4) in the instrument panel will go out and the set speed will be erased.
- 3. Press the (2) button on the steering wheel keypad again.
 - > Another function will be activated.

(i) NOTE

In vehicles equipped with Adaptive Cruise Control*, it is possible to switch between cruise control and Adaptive Cruise Control – see the heading "Switching between CC and ACC".

Related information

• Cruise control (p. 284)

Distance Alert*

The Distance Alert³⁴ function can help the driver become aware if the time interval to the vehicle in front is too short.


However, the vehicle must be equipped with a head-up display in order to display the Distance Alert, which will then be indicated by a symbol on the windshield as long as the time interval to the vehicle ahead is shorter than the set time interval.

Distance Alert is active at speeds above 30 km/h (20 mph) and only reacts for vehicles ahead moving in the same direction as your vehicle. No distance information is provided for oncoming, slow-moving or stationary vehicles.

³³ Note: This illustration is general and details may vary depending on model.

³⁴ Distance Alert

44



Distance Alert warning light on the windshield³⁵.

A warning light will appear on the windshield and glow steadily if the time interval to the vehicle ahead is shorter than the set time interval.

i NOTE

Visual warnings on the windshield may be difficult to notice in cases of strong sunlight, reflections, extreme light contrasts, or if the driver is wearing sunglasses or is not looking straight ahead.

(i) NOTE

- Distance Alert is only available in vehicles that can display information on the windshield with a head-up display.
- Distance Alert is deactivated while Adaptive Cruise Control is active.

↑ WARNING

Distance Alert only reacts of the time interval to the vehicle ahead is shorter than the preset value – vehicle speed is not affected.

(i) NOTE

Depending on market, this function may be either Standard or Optional.

Related information

- Head-up display for Distance Alert (p. 290)
- Activating/deactivating Distance Alert (p. 291)
- Setting a time interval for Distance Alert (p. 291)
- Distance Alert limitations (p. 292)

Head-up display for Distance Alert³⁶

In vehicles equipped with a head-up display*, a symbol will be displayed on the windshield as long as the time interval to the vehicle ahead is shorter than the set time interval.



Distance Alert warning symbol on the windshield³⁷.

For this to be possible, however, the **Show Driver Support** function must be activated under Settings in the center display's menus (see "Head-up display" for instructions).

³⁵ Note: This illustration is general and details may vary depending on model.

³⁶ The Distance Alert function is only available in vehicles that can display information on the windshield with a head-up display.

³⁷ Note: This illustration is general and details may vary depending on model.



(i) NOTE

Visual warnings on the windshield may be difficult to notice in cases of strong sunlight, reflections, extreme light contrasts, or if the driver is wearing sunglasses or is not looking straight ahead.

Related information

- Distance Alert* (p. 289)
- Head-up display* (p. 144)

Activating/deactivating Distance Δlert³⁸

It is possible to set time intervals for Distance Alert or to turn the function off.

On/Off



Press the Distance Alert button in the center display's Function view.

- GREEN button indicator light Distance Alert is on.
- GRAY button indicator light Distance Alert is off.

Distance Alert is automatically activated each time the engine is started.

Related information

Distance Alert* (p. 289)

Setting a time interval for Distance Alert39

The Distance Alert function can be set to different time intervals



Different time intervals to the vehicle ahead can be selected and are shown in the instrument panel as 1-5 horizontal bars. The more bars, the longer the time interval. One bar represents an interval of

approx, 1 second to the vehicle ahead, 5 bars represents approx. 3 seconds.

The same symbol appears when the Adaptive Cruise Control function is activated.

³⁸ The Distance Alert function is only available in vehicles that can display information on the windshield with a head-up display.

³⁹ The Distance Alert function is only available in vehicles that can display information on the windshield with a head-up display.

4◀



Controls for setting a time interval.

- 1 Reduce the time interval
- Increase the time interval
- Oistance indicator
- Press the (1) or (2) button to decrease or increase the time interval.
 - > The distance indicator (3) shows the current time interval.

(i) NOTE

- The greater the vehicles' speed, the greater the distance between them for a set time interval.
- Only use the time intervals permitted by local traffic regulations.
- The set time interval is also used by the Adaptive Cruise Control and Pilot Assist functions.

. WARNING

- Only use a time interval suitable for the current traffic conditions.
- The driver should be aware that short time intervals give them limited time to react and act to any unforeseen traffic situation.

Related information

• Distance Alert* (p. 289)

Distance Alert limitations⁴⁰

Distance Alert functionality may be reduced in certain situations.

⁴⁰ The Distance Alert function is only available in vehicles that can display information on the windshield with a head-up display.

WARNING

- The radar sensor has a limited field of vision. In some situations, it may detect a vehicle later than expected or not detect other vehicles at all.
- The radar sensor cannot cover all driving situations and traffic, weather and road conditions.
- The driver is responsible for maintaining a safe distance and speed and must intervene if the various driver support systems do not maintain a suitable speed or suitable distance to the vehicle ahead.
- Maintenance of radar sensor components may only be performed by a trained and qualified Volvo technician.
- Strong sunlight, reflections from the road surface, strong lighting contrasts or using sunglasses may make the warning light in the windshield difficult to see. Poor weather or winding roads can affect the radar sensor's capacity to detect vehicles ahead.
- A vehicle's size (e.g., a motorcycle) can also affect the radar sensor's capacity to detect another vehicle. This may result in the warning light illuminating at a shorter distance than the one that has been set or not illuminating at all.

High speeds may also result in the warning light illuminating at a shorter distance than the one that has been set due to limitations in the radar sensor's range.

NOTE

The function uses the vehicle's radar unit. which has some general limitations - see the section "Radar unit limitations".


Related information

Distance Alert* (p. 289)

Adaptive Cruise Control*

Adaptive Cruise Control (ACC41) helps the driver maintain a constant speed with a set time interval to the vehicle ahead.

Adaptive Cruise Control helps provide a more relaxed driving experience on long trips on highways or long, straight roads with even traffic flows.



The camera/radar sensor measures the distance to the vehicle ahead42.

The driver sets a speed and a time interval to the vehicle ahead. If the camera/radar sensor detects a slower-moving vehicle ahead, your vehicle's speed will be automatically adapted according to the set time interval to that vehicle. When there are no longer slower-moving vehicles ahead, the vehicle will return to the set speed.

- The Adaptive Cruise Control function is supplementary driver support intended to facilitate driving and help make it safer – it cannot handle all situations in all traffic, weather and road conditions.
- The driver is advised to read all sections in the Owner's Manual about this function to learn of its limitations, which the driver must be aware of before using the function (see the link list at the end of this article).
- Adaptive Cruise Control is not a substitute for the driver's attention and judgment. The driver is always responsible for ensuring the vehicle is driven in a safe manner, at the appropriate speed, with an appropriate distance to other vehicles, and in accordance with current traffic rules and regulations.

i) NOTE

Depending on market, this function may be either Standard or Optional.

Adaptive Cruise Control regulates speed by accelerating and braking. It is normal for the

brakes to emit a slight sound when they are being used to adjust speed.

Adaptive Cruise Control always attempts to regulate speed smoothly. The driver must apply the brakes in situations requiring immediate braking. For example, when there are great differences in speed between vehicles or if the vehicle ahead brakes suddenly. Due to limitations in the radar sensor, braking may occur unexpectedly or not at all.

Adaptive Cruise Control is designed to follow a vehicle ahead in the same lane and maintain a time interval to that vehicle set by the driver. If the radar sensor does not detect a vehicle ahead, it will instead maintain the speed set by the driver. This will also happen if the speed of the vehicle ahead exceeds the set speed for your vehicle.

 Adaptive Cruise Control can follow another vehicle at speeds from a standstill up to 200 km/h (125 mph).

- Adaptive Cruise Control is not a collision avoidance system. The driver is always responsible and must intervene if the system fails to detect a vehicle ahead.
- Adaptive Cruise Control does not brake for people or animals and does not brake for small vehicles, such as bikes and motorcycles. Similarly, it does not brake for low trailers, oncoming, slow-moving or stationary vehicles and objects.
- Do not use Adaptive Cruise Control in demanding situations, such as in city traffic, at intersections, on slippery surfaces, with a lot of water or slush on the road, in heavy rain/snow, in poor visibility, on winding roads, or on on/off ramps.

! CAUTION


Maintenance of Adaptive Cruise Control components may only be performed by a workshop – an authorized Volvo workshop is recommended.

⁴¹ Adaptive Cruise Control

⁴² Note: This illustration is general and details may vary depending on model.

Overview

Controls



Function buttons and symbols⁴².


- 1 d: Activates Adaptive Cruise Control from standby mode and resumes the set speed
- 1 +: Increases the set speed
- ② N: From active mode deactivates/ switches the Adaptive Cruise Control to standby mode
- 3 : Reduces the set speed
- Increases the time interval to the vehicle ahead

- 6 Reduces the time interval to the vehicle ahead
- Target vehicle indicator: ACC has detected and is following a target vehicle using the set time interval
- 7 Symbol for time interval to the vehicle ahead

(i) NOTE

In vehicles equipped with Adaptive Cruise Control*, it is possible to switch between cruise control and Adaptive Cruise Control – see the heading "Switching between CC and ACC".

Instrument panel



Speed indicators⁴².

- 1 Set speed
- 2 Speed of the vehicle ahead.
- 3 The current speed of your vehicle.

See "Adaptive Cruise Control symbols and messages" for examples of different combinations of symbols depending on the traffic situation.


Related information

- Adaptive Cruise Control and collision warning (p. 296)
- Head-up display for Adaptive Cruise Control with collision warning (p. 297)
- Activating and starting Adaptive Cruise Control (p. 297)

⁴² Note: This illustration is general and details may vary depending on model.

- Managing Adaptive Cruise Control speed (p. 298)
- Setting Adaptive Cruise Control time intervals (p. 299)
- Deactivating/reactivating Adaptive Cruise Control (p. 300)
- Passing assistance with Adaptive Cruise Control (p. 302)
- Starting passing assistance with Adaptive Cruise Control (p. 302)
- Limitations of passing assistance with Adaptive Cruise Control (p. 303)
- Switching target vehicles with Adaptive Cruise Control (p. 303)
- Automatic braking with Adaptive Cruise Control (p. 304)
- Adaptive Cruise Control limitations (p. 305)
- Switching between Cruise Control and Adaptive Cruise Control (p. 305)
- Symbols and messages for Adaptive Cruise Control (p. 307)

Adaptive Cruise Control and collision warning



Collision warning light on the windshield⁴³.

Adaptive Cruise Control utilizes approx. 40% of the vehicle's braking capacity. If a situation requires more braking force than the Adaptive Cruise Control can provide, and if the driver does not apply the brakes, a warning light and audible warning signal will be activated to alert the driver that immediate action is required.

i) NOTE

Visual warnings on the windshield may be difficult to notice in cases of strong sunlight, reflections, extreme light contrasts, or if the driver is wearing sunglasses or is not looking straight ahead.

Adaptive Cruise Control only issues a warning for vehicles detected by its radar unit – thus, a warning may come after a delay or not at all.

 Never wait for a warning. Apply the brakes when necessary.

Related information

Adaptive Cruise Control* (p. 293)

⁴³ Note: This illustration is general and details may vary depending on model.

Head-up display for Adaptive Cruise Control with collision warning

In vehicles equipped with a head-up display*, a flashing warning symbol will be displayed on the windshield.



Collision warning symbol on the windshield⁴⁴.

i NOTE

Visual warnings on the windshield may be difficult to notice in cases of strong sunlight, reflections, extreme light contrasts, or if the driver is wearing sunglasses or is not looking straight ahead.

Related information

Adaptive Cruise Control* (p. 293)

Activating and starting Adaptive Cruise Control

Adaptive Cruise Control (ACC⁴⁵) must first be activated and then started before it can regulate speed and distance.

Putting Adaptive Cruise Control in standby mode



Note: This illustration is general and details may vary depending on model.


Adaptive Cruise Control is in standby mode each time the engine is started. To put ACC in standby mode from active mode:

- Press ◄ (2) or ► (3) on the steering wheel keypad and scroll to the
 - > The symbol will appear and Adaptive Cruise Control will go into standby mode.

Starting/activating Adaptive Cruise Control

To start ACC:

- The driver's seat belt must be buckled and the driver's door must be closed.
- There must be a vehicle ahead (target vehicle) within a reasonable distance or your vehicle's current speed must be at least 15 km/h (9 mph).



Note: This illustration is general and details may vary depending on model.

⁴⁴ Note: This illustration is general and details may vary depending on model.

⁴⁵ Adaptive Cruise Control

- With the (4) function displayed, press
 (1) on the steering wheel keypad.
 - Adaptive Cruise Control will start and the current speed will be stored, which will be shown by numbers in the center of the speedometer.



ACC will only regulate the time interval to the vehicle ahead when the distance symbol shows two vehicles.



A speed interval will be marked at the same time.

The higher speed is the set speed for your vehicle and the lower speed is the speed of the vehicle ahead (target vehicle).

Related information

Adaptive Cruise Control* (p. 293)

Managing Adaptive Cruise Control speed

Adaptive Cruise Control (ACC⁴⁶) can be set to various speeds.

Setting/changing set speed



Note: This illustration is general and details may vary depending on model and market.

- 1 +: Increases the set speed.
- 2 -: Reduces the set speed.
- Set speed.

- Change a set speed by pressing the + (1) or (2) buttons briefly or by pressing and holding them:
 - Press briefly: Press briefly: each press changes the speed in +/- 5 mph (+/- 5 km/h) increments.
 - Press and hold: Release the button when the set speed indicator (3) has moved to the desired speed.
- The most recently set speed will be stored.

If speed is increased by depressing the accelerator pedal while pressing the + button on the steering wheel, the vehicle's speed when the button is pressed will be stored as the set speed.

Temporarily increasing speed using the accelerator pedal, e.g. when passing another vehicle, will not affect the setting. The vehicle will return to the set speed when the accelerator pedal is released.

⁴⁶ Adaptive Cruise Control

Automatic transmission

Adaptive Cruise Control can follow another vehicle at speeds from a standstill up to 200 km/h (125 mph).

The lowest speed that can be set for Adaptive Cruise Control is 30 km/h (20 mph). When following another vehicle, ACC can monitor that vehicle's speed and slow your own vehicle down to a standstill, but it is not possible to set speeds lower than 30 km/h (20 mph).

The highest possible speed that can be set is 200 km/h (125 mph).

Related information

Adaptive Cruise Control* (p. 293)

Setting Adaptive Cruise Control time intervals

Adaptive Cruise Control (ACC47) can be set to various time intervals to the vehicle ahead.



Different time intervals to the vehicle ahead can be selected and are shown in the instrument panel as 1-5 horizontal bars. The more bars, the longer the time interval. One bar represents an interval of


approx, 1 second to the vehicle ahead, 5 bars represents approx. 3 seconds.

The same symbol appears when the Distance Alert function is activated.

(i) NOTE

When the symbol in the instrument panel shows two vehicles, ACC is following the vehicle ahead at a preset time interval.

When only one vehicle is shown, there is no vehicle ahead within a reasonable distance.



Controls for setting a time interval⁴⁸.

- Reduce the time interval
- Increase the time interval
- Distance indicator
- Press the (1) or (2) button to decrease or increase the time interval.
 - > The distance indicator (3) shows the current time interval.

In order to help your vehicle follow the vehicle ahead as smoothly and comfortably as possible, Adaptive Cruise Control allows the time interval to vary noticeably in certain situations. At low speeds, when the distance to the vehicle ahead is short, Adaptive Cruise Control increases the time interval slightly.

⁴⁷ Adaptive Cruise Control

⁴⁸ Note: This illustration is general and details may vary depending on model.

(i) NOTE

- The greater the vehicles' speed, the greater the distance between them for a set time interval.
- Only use the time intervals permitted by local traffic regulations.
- If the Adaptive Cruise Control does not seem to respond with a speed increase when activated, it may be because the time interval to the vehicle ahead is shorter than the set time interval.

♠ WARNING

- Only use a time interval suitable for the current traffic conditions.
- The driver should be aware that short time intervals give them limited time to react and act to any unforeseen traffic situation.

Setting how ACC should maintain distance* to the vehicle ahead

A number of different settings can be made for how Adaptive Cruise Control should maintain a time interval to the vehicle ahead. Settings are made using the **DRIVE MODE** controls. Select one of the following:

- Eco ACC will focus on providing optimal fuel economy, which will increase the time interval to the vehicle ahead.
- Comfort ACC will focus on following the set time interval to the vehicle ahead as smoothly as possible.
- Dynamic ACC will focus on following the set time interval to the vehicle ahead more exactly, which could mean faster acceleration and heavier braking.

For more information, see "Drive modes".

Additional information is provided in the sections "Managing Cruise Control speed" and "ECO drive mode".


Related information

Adaptive Cruise Control* (p. 293)

Deactivating/reactivating Adaptive Cruise Control

Adaptive Cruise Control (ACC⁴⁹) can be temporarily put into standby mode and then reactivated.

Deactivating and putting Adaptive Cruise Control in standby mode



Note: This illustration is general and details may vary depending on model.

⁴⁹ Adaptive Cruise Control

To temporarily deactivate Adaptive Cruise Control and put it in standby mode:

- Press the button on the steering wheel (2).
 - The kg symbol in the instrument panel changes color from WHITE to GRAY and the set speed in the center of the speedometer will change from BEIGE to GRAY.

★ WARNING

- If Adaptive Cruise Control is in standby mode, the driver must intervene and regulate both speed and distance to the vehicle ahead.
- If the vehicle comes too close to a vehicle ahead when Adaptive Cruise Control is in standby mode, the driver is instead warned of the short distance by the Distance Alert function.

Standby mode due to action by the driver

Adaptive Cruise Control will be temporarily deactivated and put in standby mode if:

- the brakes are applied.
- the gear selector is moved to N
- the vehicle is driven faster than the set speed for more than 1 minute

Temporarily increasing speed using the accelerator pedal, e.g. when passing another vehicle, will not affect the setting. The vehicle will return to the set speed when the accelerator pedal is released.

Automatic standby mode

Adaptive Cruise Control is dependent on other systems, such as Electronic Stability Control (ESC⁵⁰). If any of these other systems stops working, Adaptive Cruise Control will automatically switch off.

♠ WARNING

With automatic standby mode, the driver is warned by an acoustic signal and a message on the instrument panel.


 The driver must then regulate vehicle speed, apply the brakes if necessary, and maintain a safe distance to other vehicles.

Adaptive Cruise Control may go into standby mode if:

- your vehicle's speed goes below 5 km/h
 (3 mph) and ACC cannot determine if the
 vehicle ahead is stationary or if it is another
 object, e.g. a speed bump.
- your vehicle's speed goes under 5 km/h
 (3 mph) and the vehicle ahead turns so that
 ACC no longer has a vehicle to follow.

- the driver opens the door.
- the driver unbuckles the seat belt.
- the engine speed (rpm) is too low/high.
- one or more of the wheels lose traction.
- the brake temperature is high.
- the parking brake is applied.
- the camera/radar sensor is covered by snow or heavy rain (the camera lens/radar waves are blocked)

Reactivating Adaptive Cruise Control from standby mode



Note: This illustration is general and details may vary depending on model.

⁵⁰ Electronic Stability Control

- To reactivate ACC from standby mode:
 - Press the button on the steering wheel (1).
 - > Speed will be set to the most recently stored speed.

↑ WARNING

A noticeable increase in speed may follow when the speed is resumed with the 3^{\dagger} steering wheel button.

Related information

Adaptive Cruise Control* (p. 293)

Passing assistance with Adaptive Cruise Control

Adaptive Cruise Control (ACC⁵¹) can assist the driver when passing other vehicles.

How passing assistance works

When ACC is following another vehicle and you indicate that you intend to pass that vehicle by using the turn signal⁵², Adaptive Cruise Control will begin accelerating toward the vehicle ahead **before** your vehicle has moved into the passing lane.

The function will then delay a speed reduction to avoid early braking as your vehicle approaches a slower-moving vehicle.

The function remains active until your vehicle has passed the other vehicle.

Please note that this function can be activated in more situations than just passing another vehicle, such as when a direction indicator is used to indicate a lane change or before exiting to another road – the vehicle will then briefly accelerate.

Related information

Adaptive Cruise Control* (p. 293)

Starting passing assistance with Adaptive Cruise Control

Requirements for passing assistance

In order to activate passing assistance:

- your vehicle must be following a vehicle ahead (target vehicle)
- your vehicle's current speed must be at least 70 km/h (43 mph)
- the set speed for ACC must be high enough to safely pass another vehicle.

Starting parking assistance

To start passing assistance:

- Turn on the left turn signal.
 - > Passing assistance will start.

Related information

Adaptive Cruise Control* (p. 293)

⁵¹ Adaptive Cruise Control

⁵² Only the left-hand turn signal for left-hand drive vehicles, or right-hand turn signal for right-hand drive vehicles.

Limitations of passing assistance with Adaptive Cruise Control

Passing assistance functionality may be reduced in certain situations.

WARNING

The driver should be aware that if conditions suddenly change when using Parking Assistance, the function may implement an undesired acceleration in certain conditions

Some situations should be avoided, e.g. if:

- the vehicle is approaching an exit in the same direction as passing would normally occur
- the vehicle ahead slows before your vehicle has had time to switch to the passing lane
- traffic in the passing lane slows down
- a vehicle for right-hand traffic is driven in a country with left-hand traffic (or vice versa).

Situations of this type can be avoided by temporarily putting ACC⁵³ in standby mode.


Related information

Adaptive Cruise Control* (p. 293)

Switching target vehicles with **Adaptive Cruise Control**

At certain speeds, models with automatic transmissions and Adaptive Cruise Control (ACC54) can switch target vehicles.

Switching target vehicles



If the target vehicle ahead turns suddenly, there may be stationary traffic ahead.

When Adaptive Cruise Control is actively following another vehicle at speeds under 30 km/h (20 mph) and switches targets from a moving vehicle to a stationary vehicle, Adaptive Cruise Control will brake for the stationary vehicle.

When Adaptive Cruise Control follows another vehicle at speeds over approx, 30 km/h (20 mph) and changes target vehicle - from a moving vehicle to a stationary one - Adaptive Cruise Control will ignore the stationary vehicle and instead accelerate to the stored speed.

• The driver must then intervene and apply the brakes.

Automatic standby mode when switching targets

Adaptive Cruise Control will be disabled and go into standby mode:

- if your vehicle's speed goes below 5 km/h (3 mph) and Adaptive Cruise Control cannot determine if the target object is a stationary vehicle or another object, e.g. a speed bump.
- if your vehicle's speed goes under 5 km/h (3 mph) and the vehicle ahead turns so that Adaptive Cruise Control no longer has a vehicle to follow.

Related information

Adaptive Cruise Control* (p. 293)

⁵³ Adaptive Cruise Control

⁵⁴ Adaptive Cruise Control

Automatic braking with Adaptive Cruise Control

The Adaptive cruise control (ACC⁵⁵) has a special brake function in slow traffic and while stationary.

Braking function in slow traffic and at a standstill

In slow-moving, stop-and-go traffic or when stopped at a traffic light, driving will resume automatically if the vehicle is stopped for less than approx. 3 seconds. If it takes more than 3 seconds for the vehicle ahead to begin moving again, Adaptive Cruise Control will go into standby mode and the Auto-hold brake function will activate.

- Adaptive Cruise Control can be reactivated in one of the following ways:
 - Pressing the 5 button on the steering wheel keypad.
 - Pressing the accelerator pedal.
 - > Adaptive Cruise Control will resume following the vehicle ahead if it begins to move within approx. 6 seconds.

(i) NOTE

ACC can keep the vehicle stationary for no more than 5 minutes – after that time the parking brake is applied and Adaptive Cruise Control is deactivated.

The parking brake must be released before Adaptive Cruise Control can be reactivated.

Deactivation of the Auto-hold brake function

In certain situations, Auto-hold will be deactivated when the vehicle is at a standstill and Adaptive Cruise Control will go into standby mode. This means that the brakes will be released and the vehicle could begin to roll. The driver must actively apply the brakes to keep the vehicle stationary.

This can occur if:

- the driver depresses the brake pedal
- the parking brake is applied
- the gear selector is moved to the P, N or R positions
- the driver puts Adaptive Cruise Control in standby mode.

Auto Activate Parking Brake

In certain situations, the parking brake will be applied to keep the vehicle at a standstill.

This occurs if Adaptive Cruise Control is keeping the vehicle stationary using the brakes and:

- the driver opens the door or unbuckles his/her seat belt
- ACC has kept the vehicle at a standstill for more than approx. 5 minutes
- the brakes overheat
- the driver switches off the engine manually.

Related information

• Adaptive Cruise Control* (p. 293)

⁵⁵ Adaptive Cruise Control

Adaptive Cruise Control limitations

Adaptive Cruise Control (ACC⁵⁶) may have limited functionality in certain situations.

Steep roads and/or heavy loads

Adaptive Cruise Control is primarily intended to be driven on flat roads. The function may not be able to maintain the correct time interval to the vehicle ahead when driving down steep hills. The driver should be extra attentive and prepared to apply the brakes.

 Do not use Adaptive Cruise Control if the vehicle is carrying a heavy load or towing a trailer.

Other limitations

 The Off Road drive mode cannot be selected if Adaptive Cruise Control is activated.

i NOTE

The function uses the vehicle's camera unit, which has some general limitations – see the section "Camera unit limitations".

i NOTE

The function uses the vehicle's radar unit, which has some general limitations – see the section "Radar unit limitations".

Related information

Adaptive Cruise Control* (p. 293)

Switching between Cruise Control and Adaptive Cruise Control

In vehicles equipped with Adaptive Cruise Control (ACC⁵⁷), the driver can switch between Cruise Control (CC⁵⁸) and ACC.

A symbol in the instrument panel indicates which cruise control system is active

CC	ACC
(5) A	A
Cruise control	Adaptive Cruise Control

A WHITE symbol: The function is active. GRAY symbol: Standby mode

Switching from ACC to CC

To do so:

 Press the button on the steering wheel keypad to put Adaptive Cruise Control in standby mode.

⁵⁶ Adaptive Cruise Control

- Tap the Cruise Control button in the center display's Function view. The button's indicator will change from GRAY to GREEN.
 - > The symbol in the instrument panel will change from ACC to CC, indicating that Adaptive Cruise Control is off and Cruise Control is in standby mode.
 - 3. Pressing the S button on the steering wheel keypad.
 - > Cruise Control will start and the vehicle's current speed will be set.

★ WARNING

Switching from ACC to CC means that the vehicle:

- will no longer maintain a preset time interval to the vehicle ahead.
- will only follow the stored speed and the driver must therefore apply the brakes when necessary.

If CC is active when the engine is turned off, ACC will be automatically activated the next time the engine is started.

Switching from CC to ACC

To do so:

- Press the button on the steering wheel keypad to put Cruise Control in standby mode.
- Tap the Cruise Control button in Function view. The button's indicator will change from GREEN to GRAY.
 - > The symbols in the instrument panel will switch from CC to CC to ACC to indicate that Adaptive Cruise Control is in standby mode.
- 3. Pressing the 6 button on the steering wheel keypad.
 - > Adaptive Cruise Control will go into active mode and set the vehicle's current speed and the selected time interval to the vehicle ahead.

Related information

Adaptive Cruise Control* (p. 293)


⁵⁷ Adaptive Cruise Control

⁵⁸ Cruise Control


Symbols and messages for Adaptive Cruise Control

A number of symbols and messages relating to Adaptive Cruise Control (ACC⁵⁹) may be displayed in the instrument panel and/or the head-up display*.

Several examples⁶⁰ are provided below.



The previous illustration⁶¹ shows that Adaptive Cruise Control is set to maintain a speed of 110 km/h (68 mph) and that there is no target vehicle ahead to follow.



The previous illustration⁶¹ shows that Adaptive Cruise Control is set to maintain a speed of 110 km/h (68 mph) and is following a target

vehicle ahead, which is traveling at the same speed.

⁵⁹ Adaptive Cruise Control

⁶⁰ In the following illustration, Road Sign Information (RSI) indicates that the maximum permitted speed is 130 km/h (80 mph).

⁶¹ Note: This illustration is general and details may vary depending on model.

∢∢

Symbol	Message	Meaning
গৈ	The symbol is WHITE.	The vehicle is maintaining the set speed.
	Adaptive cruise	Adaptive Cruise Control is in standby mode.
(.)	Unavailable	
	The symbol is GRAY.	
\ \frac{1}{2}	Adaptive cruise	The system is not functioning as intended. Contact a workshop – an authorized Volvo workshop is
(,)	Service required	recommended.
	The symbol is GRAY.	
(Ii	Windscreen sensor	Clean the windshield in front of the camera and radar sensors.
	Sensor blocked, see Owner's manual	

A text message can be erased by briefly pressing the O button in the center of the right-side steering wheel keypad.

If the message persists: Contact a workshop – an authorized Volvo workshop is recommended.

Related information


• Adaptive Cruise Control* (p. 293)

Pilot Assist

Pilot Assist helps the driver keep the vehicle in the current traffic lane by providing steering assistance and maintaining an even speed and a set time interval to the vehicle ahead.

How Pilot Assist works

The Pilot Assist function is primarily intended for use on highways and other major roads where it can help provide a more comfortable and relaxing driving experience.



The camera/radar sensor monitors the distance to the vehicle ahead and detects lane markings⁶².

- Camera and radar sensor
- Distance monitor
- Cane marker line monitors

The driver sets the desired speed and distance to the vehicle ahead. Pilot Assist monitors the distance to the vehicle ahead and the traffic lane's side markers using the camera and radar sensor. The system maintains the set time interval to the vehicle ahead by automatically adjusting your vehicle's speed and keeps your vehicle in its lane by providing steering assistance.

Pilot Assist's steering assistance is based on monitoring the direction of the vehicle ahead and the traffic lane's side marker lines. The driver can override Pilot Assist's steering recommendations at any time and steer in another direction, e.g. to change lanes or avoid obstacles on the road.

If the camera/radar sensor cannot detect the lane's side marker lines or if Pilot Assist is unable for some other reason to clearly interpret the lane, Pilot Assist will temporarily deactivate steering assistance until it can once again interpret the lane markings. However, the speed and distance warnings will remain active.

↑ WARNING

Pilot Assist is deactivated automatically and resumes working without prior notice.



The color of the steering wheel symbol indicates the current status of steering assistance:

- GREEN indicates that steering assistance is active
- GRAY (as shown in illustration) indicates that steering assistance is deactivated.

⁶² Note: This illustration is general and details may vary depending on model.

™ / WARNING

- The Pilot Assist function is supplementary driver support intended to facilitate driving and help make it safer – it cannot handle all situations in all traffic, weather and road conditions.
- The driver is advised to read all sections in the Owner's Manual about this function to learn of its limitations, which the driver must be aware of before using the function (see the link list at the end of this article).
- Pilot Assist should only be used if there are clear lane lines painted on each side of the lane. All other use will increase the risk of contact with nearby obstacles that cannot be detected by the functions.
- Pilot Assist is not a substitute for the driver's attention and judgment. The driver is always responsible for ensuring the vehicle is driven in a safe manner, at the proper position within the lane, at the appropriate speed, with an appropriate distance to other vehicles, and in accordance with current traffic rules and regulations.

(i) NOTE

Depending on market, this function may be either Standard or Optional.

Pilot Assist regulates speed by accelerating and braking. It is normal for the brakes to emit a slight sound when they are being used to adjust speed.

Pilot Assist attempts to smoothly regulate speed. The driver must apply the brakes in situations requiring immediate braking. For example, when there are great differences in speed between vehicles or if the vehicle ahead brakes suddenly. Due to limitations in the camera and radar sensor, braking may occur unexpectedly or not at all.

Pilot Assist is designed to follow a vehicle ahead in the same lane and maintain a time interval to that vehicle set by the driver. If the radar sensor does not detect a vehicle ahead, it will instead maintain the speed set by the driver. This will also happen if the speed of the vehicle ahead exceeds the set speed for your vehicle.

- Pilot Assist can follow another vehicle at speeds from a standstill up to 200 km/h (125 mph).
- Pilot Assist can provide steering assistance from near-stationary speeds up to 140 km/h (87 mph).

↑ WARNING

- Pilot Assist is not a collision avoidance system. The driver must intervene if the system fails to detect a vehicle ahead.
- Pilot Assist does not brake for people, animals, objects, small vehicles (e.g. cycles and motorcycles), low trailers as well as oncoming, slow or stationary vehicles.
- Do not use Pilot Assist in demanding situations, such as in city traffic, at intersections, on slippery surfaces, with a lot of water or slush on the road, in heavy rain/snow, in poor visibility, on winding roads, on highway on- or off-ramps, or with a trailer connected to the vehicle.

! CAUTION

Maintenance of the integrated components in Pilot Assist may only be performed by a workshop – an authorized Volvo workshop is recommended.

In curves and forks in the road

Pilot Assist is designed to interact with the driver. The driver should never wait for steering assistance from Pilot Assist, but instead should always be ready to increase his or her own steering efforts, particularly in curves.

When the vehicle is approaching an off-ramp or a fork in the road, the driver should steer toward the desired lane to indicate to Pilot Assist the desired direction of travel.


Pilot Assist strives to keep the vehicle in the center of the lane

When Pilot Assist provides steering assistance, it strives to position the vehicle in the center of the lane between the lane markings. For the smoothest driving experience possible, the driver should permit the vehicle to find the optimal positioning. The driver should check that the vehicle is positioned safely in the lane and can always adjust the vehicle's position by applying more force to the steering wheel.

If Pilot Assist does not position the vehicle appropriately in the lane, the driver should turn off Pilot Assist or switch to Adaptive Cruise Control.

Overview

Controls




Function buttons and symbols⁶².

- +: Increases the set speed
- 2 : From standby mode activates Pilot Assist and sets the current speed
- 2 S: From active mode deactivates/puts Pilot Assist in standby mode
- 3 ◀: Switches from Pilot Assist to Adaptive Cruise Control
- 4 -: Reduces the set speed

- 5 Increases the time interval to the vehicle ahead
- 6 ►: Switches from Adaptive Cruise Control to Pilot Assist
- Reduces the time interval to the vehicle ahead
- 8 Function symbol
- Symbols for target vehicle and distance to the vehicle ahead
- Symbol for activated/deactivated steering assistance

⁶² Note: This illustration is general and details may vary depending on model.

◄ Instrument panel



Speed indicators⁶².

- 1 Set speed
- Speed of the vehicle ahead
- The current speed of your vehicle

See "Pilot Assist symbols and messages" for examples of different combinations of symbols depending on the traffic situation.


Related information

- Pilot Assist and collision warning (p. 312)
- Head-up display for Pilot Assist during collision risks (p. 313)
- Activating and starting Pilot Assist (p. 313)
- Managing Pilot Assist speed (p. 314)

- Setting a time interval for Pilot Assist (p. 315)
- Deactivating/reactivating Pilot Assist (p. 317)
- Passing assistance with Pilot Assist (p. 319)
- Starting passing assistance with Pilot Assist (p. 319)
- Passing assistance with Pilot Assist limitations (p. 319)
- Switching target vehicles with Pilot Assist (p. 320)
- Automatic braking with Pilot Assist (p. 320)
- Pilot Assist limitations (p. 321)
- Pilot Assist* symbols and messages (p. 322)

Pilot Assist and collision warning

Collision warning



Collision warning light on the windshield⁶³.

Pilot Assist uses approx. 40% of the vehicle's braking capacity. If a situation requires more braking force than Pilot Assist can provide, and if the driver does not apply the brakes, a warning light and audible warning signal will be activated to alert the driver that immediate action is required.

⁶² Note: This illustration is general and details may vary depending on model.

⁶³ The illustration is generic - details may vary according to vehicle model.

NOTE

Visual warnings on the windshield may be difficult to notice in cases of strong sunlight, reflections, extreme light contrasts, or if the driver is wearing sunglasses or is not looking straight ahead.

WARNING

Pilot Assist only issues a warning for vehicles detected by its camera and radar unit - thus. a warning may come after a delay or not at all.

Never wait for a warning. Apply the brakes when necessary!

Related information

Pilot Assist (p. 309)

Head-up display for Pilot Assist during collision risks

In vehicles equipped with a head-up display*, a flashing warning symbol will be displayed on the windshield.



Collision warning symbol on the windshield⁶⁴

(i) NOTE


Visual warnings on the windshield may be difficult to notice in cases of strong sunlight, reflections, extreme light contrasts, or if the driver is wearing sunglasses or is not looking straight ahead.

Related information

Pilot Assist (p. 309)

Activating and starting Pilot Assist

Pilot Assist must first be activated and then started before it can regulate speed and distance and provide steering assistance.



Note: This illustration is general and details may vary depending on model.

To start Pilot Assist:

- The driver's seat belt must be buckled and the driver's door must be closed.
- There must be a vehicle ahead (target vehicle) within a reasonable distance or your vehicle's current speed must be at least 15 km/h (9 mph).

⁶⁴ Note: This illustration is general and details may vary depending on model.

- With Adaptive Cruise Control in standby mode:
 - 1 Press the ▶ button on the steering wheel (6).
 - > The symbol will change to Pilot Assist in standby mode (8).
 - 2. Press the (5) button on the steering wheel (2).
 - Pilot Assist will start and the current speed will be stored, which will be shown by numbers in the center of the speedometer.

...or...

With Adaptive Cruise Control started:

- Press the ► button on the steering wheel (6).
 - > Pilot Assist will start.



Pilot Assist will only regulate the time interval to the vehicle ahead when the distance symbol shows a vehicle (1) over the steering wheel symbol.



A speed interval will be marked at the same time.

The higher speed is the set speed for your vehicle and the lower speed is the speed of the vehicle ahead (target vehicle).

Hands on the steering wheel

Pilot Assist only functions if the driver's hands are on the steering wheel. If Pilot Assist detects that the driver's hands are not on the steering wheel, the driver will be instructed to actively steer the vehicle by a text message and an audible signal.

If Pilot Assist still cannot detect the driver's hands on the steering wheel, the function will go into standby mode. Pilot Assist must then be reactivated by pressing the $\ \ \ \ \ \ \ \ \ \$ button on the steering wheel.



NOTE

Note that the Pilot Assist function only works when the driver's hands are on the steering wheel.


Related information

Pilot Assist (p. 309)

Managing Pilot Assist speed

Pilot Assist can be set to various speeds.

Setting/changing set speed



Note: This illustration is general and details may vary depending on model and market.

- 1 +: Increases the set speed
- 2 : Reduces the set speed
- 3 Set speed

- Change a set speed by pressing the + (1) or - (2) buttons briefly or by pressing and holding them:
 - Press briefly: Press briefly: each press changes the speed in +/- 5 mph (+/- 5 km/h) increments.
 - Press and hold: Release the button when the set speed indicator (3) has moved to the desired speed.
- The most recently set speed will be stored.

If speed is increased by depressing the accelerator pedal while pressing the + button on the steering wheel, the vehicle's speed when the button is pressed will be stored as the set speed.

Temporarily increasing speed using the accelerator pedal, e.g. when passing another vehicle, will not affect the setting. The vehicle will return to the set speed when the accelerator pedal is released.

Automatic transmission

Pilot Assist can follow another vehicle at speeds from a standstill up to 200 km/h (125 mph).

The lowest speed that can be set for Pilot Assist is 30 km/h (20 mph). When following another vehicle, ACC can monitor that vehicle's speed and slow your own vehicle down to a standstill, but it is not possible to set speeds lower than 30 km/h (20 mph).

The highest possible speed that can be set is 200 km/h (125 mph).

Related information

Pilot Assist (p. 309)

Setting a time interval for Pilot **Assist**

Pilot Assist can be set to different time intervals.



Different time intervals to the vehicle ahead can be selected and are shown in the instrument panel as 1-5 horizontal bars. The more bars, the longer the time interval. One bar represents an interval of

approx, 1 second to the vehicle ahead, 5 bars represents approx. 3 seconds.




(i) NOTE

When the symbol in the instrument panel shows a vehicle and a steering wheel, Pilot Assist follows a vehicle ahead at a preset time interval.

When only a steering wheel is shown, there is no vehicle ahead within a reasonable distance.

44



Controls for setting a time interval⁶⁵.

- Reduce the time interval
- Increase the time interval
- Oistance indicator
- Press the (1) or (2) button to decrease or increase the time interval.
 - > The distance indicator (3) shows the current time interval.

In order to follow the vehicle ahead as smoothly as possible, Pilot Assist allows the time interval to vary considerably in certain situations. For example, at low speeds and short distances to the vehicle ahead, Pilot Assist increases the time interval slightly.

(i) NOTE

- The greater the vehicles' speed, the greater the distance between them for a set time interval.
- Only use the time intervals permitted by local traffic regulations.
- If Pilot Assist does not seem to respond with a speed increase when activated, it may be because the time interval to the vehicle ahead is shorter than the set time interval.

♠ WARNING

- Only use a time interval suitable for the current traffic conditions.
- The driver should be aware that short time intervals give them limited time to react and act to any unforeseen traffic situation.

Setting how Pilot Assist should maintain distance* to the vehicle ahead

The driver can choose different drive modes to determine how Pilot Assist should maintain a time interval to the vehicle ahead. Settings are made using the **DRIVE MODE** controls.

Select one of the following:

- Eco Pilot Assist will focus on providing optimal fuel economy, which will increase the time interval to the vehicle ahead.
- Comfort Pilot Assist will focus on following the set time interval to the vehicle ahead as smoothly as possible.
- Dynamic Pilot Assist will focus on following the set time interval to the vehicle ahead more exactly, which could mean faster acceleration and heavier braking.

For more information, see "Drive modes".

Additional information is provided in the sections "Managing Cruise Control speed" and "ECO drive mode".

Related information


Pilot Assist (p. 309)

⁶⁵ Note: This illustration is general and details may vary depending on model.

Deactivating/reactivating Pilot Assist

Pilot Assist can be temporarily put into standby mode and then reactivated.

Deactivating and putting Pilot Assist in standby mode



Note: This illustration is general and details may vary depending on model.

To temporarily deactivate Pilot Assist and put it in standby mode:

- Press the button on the steering wheel (2).
 - Pilot Assist goes into standby mode the symbol (8) in the instrument panel changes color from WHITE to GRAY and the set speed in the center of the speedometer will change from BEIGE to GRAY.

...or...

- - > Pilot Assist is turned off and Adaptive Cruise Control will go into active mode.

★ WARNING

- With Pilot Assist in standby mode, the driver must intervene and steer and regulate both speed and distance to the vehicle ahead.
- If the vehicle comes too close to a vehicle ahead when Pilot Assist is in standby mode, the driver is instead warned of the short distance by the Distance Alert function.

Standby mode due to action by the driver

Pilot Assist will be temporarily deactivated and put in standby mode if:

- the brakes are applied.
- the gear selector is moved to N
- a turn signal is used for more than 1 minute.
- the vehicle is driven faster than the set speed for more than 1 minute

Temporarily increasing speed using the accelerator pedal, e.g. when passing another vehicle, will not affect the setting. The vehicle will return to the set speed when the accelerator pedal is released.

When the turn signals are used, Pilot Assist's steering assistance will be temporarily deactivated. When the turn signal is switched off, steering assistance will be automatically reactivated if the traffic lane's side markings can still be detected.

◄ Automatic standby mode

Pilot Assist is dependent on other systems, such as Electronic Stability Control (ESC 66). If any of these other systems stops working, Pilot Assist will automatically switch off.

With automatic standby mode, the driver is warned by an acoustic signal and a message on the instrument panel.


 The driver must then regulate vehicle speed, apply the brakes if necessary, and maintain a safe distance to other vehicles.

Adaptive Cruise Control may go into standby mode if, e.g.:

- the driver opens the door.
- the brake temperature is high.
- the driver's hands are not on the steering wheel.
- the parking brake is applied.
- the engine speed (rpm) is too low/high.
- the driver unbuckles the seat belt.
- one or more of the wheels lose traction.
- the camera/radar sensor is covered by snow or heavy rain (the camera lens/radar waves are blocked)

- your vehicle's speed goes below 5 km/h
 (3 mph) and Pilot Assist cannot determine if
 the vehicle ahead is stationary or if it is
 another object, e.g. a speed bump.
- your vehicle's speed goes under 5 km/h
 (3 mph) and the vehicle ahead turns so that
 Pilot Assist no longer has a vehicle to follow.

Reactivating Pilot Assist from standby mode



Note: This illustration is general and details may vary depending on model.

To reactivate Pilot Assist:

- Press the 'J' button on the steering wheel (1).
 - > Speed will be set to the most recently stored speed.

⚠ WARNING

A noticeable increase in speed may follow when the speed is resumed with the \circlearrowleft steering wheel button.

Related information

• Pilot Assist (p. 309)

⁶⁶ Electronic Stability Control

Passing assistance with Pilot Assist

Pilot Assist can assist the driver when passing other vehicles.

How passing assistance works

When Pilot Assist is following another vehicle and you indicate that you intend to pass that vehicle by using the turn signal⁶⁷, Pilot Assist will begin accelerating toward the vehicle ahead **before** your vehicle has moved into the passing lane.

The function will then delay a speed reduction to avoid early braking as your vehicle approaches a slower-moving vehicle.

The function remains active until your vehicle has passed the other vehicle.

⚠ WARNING

Please note that this function can be activated in more situations than just passing another vehicle, such as when a direction indicator is used to indicate a lane change or before exiting to another road – the vehicle will then briefly accelerate.

Related information

Pilot Assist (p. 309)

Starting passing assistance with Pilot Assist

Requirements for passing assistance

In order to activate passing assistance:

- your vehicle must be following a vehicle ahead (target vehicle)
- your vehicle's current speed must be at least 70 km/h (43 mph)
- **the set speed** for Pilot Assist must be high enough to safely pass another vehicle.

Starting parking assistance

To start passing assistance:

- Turn on the left turn signal.
 - > Passing assistance will start.

Related information

Pilot Assist (p. 309)

Passing assistance with Pilot Assist limitations

Passing assistance functionality may be reduced in certain situations.

MARNING

The driver should be aware that if conditions suddenly change when using Parking Assistance, the function may implement an undesired acceleration in certain conditions.

Some situations should be avoided, e.g. if:

- the vehicle is approaching an exit in the same direction as passing would normally occur
- the vehicle ahead slows before your vehicle has had time to switch to the passing lane
- traffic in the passing lane slows down
- a vehicle for right-hand traffic is driven in a country with left-hand traffic (or vice versa).

Situations of this type can be avoided by temporarily putting Pilot Assist in standby mode.

Related information


Pilot Assist (p. 309)

⁶⁷ Only the left-hand turn signal for left-hand drive vehicles, or right-hand turn signal for right-hand drive vehicles.

Switching target vehicles with Pilot Assist

At certain speeds, models with automatic transmissions and Pilot Assist can switch target vehicles.

Switching target vehicles



If the target vehicle ahead turns suddenly, there may be stationary traffic ahead.

When Pilot Assist is actively following another vehicle at speeds **under** 30 km/h (20 mph) and switches targets from a moving vehicle to a stationary vehicle, Pilot Assist will brake for the stationary vehicle.

. MARNING

When Pilot Assist follows another vehicle at speeds **over** approx. 30 km/h (20 mph) and changes target vehicle – from a moving vehicle to a stationary one – Pilot Assist will **ignore** the stationary vehicle and instead accelerate to the stored speed.

 The driver must then intervene and apply the brakes.

Automatic standby mode when switching targets

Pilot Assist disengages and goes into standby mode if:

- your vehicle's speed goes below 5 km/h
 (3 mph) and Pilot Assist cannot determine if
 the target object is a stationary vehicle or
 another object, e.g. a speed bump.
- your vehicle's speed goes under 5 km/h
 (3 mph) and the vehicle ahead turns so that
 Pilot Assist no longer has a vehicle to follow.

Related information

Pilot Assist (p. 309)

Automatic braking with Pilot Assist

Pilot Assist has a special braking function in slow traffic and at a standstill.

Braking function in slow traffic and at a standstill

In slow-moving, stop-and-go traffic or when stopped at a traffic light, driving will resume automatically if the vehicle is stopped for less than approx. 3 seconds. If it takes more than 3 seconds for the vehicle ahead to begin moving again, Pilot Assist will go into standby mode and the Auto-hold brake function will activate.

- Pilot Assist can be reactivated by:
 - Pressing the 5 button on the steering wheel keypad.
 - Pressing the accelerator pedal.
 - Pilot Assist will resume following the vehicle ahead if it begins to move within approx. 6 seconds.

i NOTE

Pilot Assist can keep the vehicle stationary for no more than 5 minutes – after that time the parking brake is applied and the function is deactivated.

The parking brake must be released before Pilot Assist can be reactivated.

Deactivation of the Auto-hold brake function

In certain situations, Auto-hold will be deactivated when the vehicle is at a standstill and Pilot Assist will go into standby mode. This means that the brakes will be released and the vehicle could begin to roll. The driver must actively apply the brakes to keep the vehicle stationary.

This can occur if:

- the driver depresses the brake pedal
- the parking brake is applied
- the gear selector is moved to the P, N or R positions
- the driver puts Pilot Assist in standby mode.

Auto Activate Parking Brake

In certain situations, the parking brake will be applied to keep the vehicle at a standstill.

This occurs if Pilot Assist is keeping the vehicle stationary using the brakes and:

- the driver opens the door or unbuckles his/her seat belt
- Pilot Assist has kept the vehicle at a standstill for more than approx. 5 minutes
- the brakes overheat
- the driver switches off the engine manually.

Related information

Pilot Assist (p. 309)

Pilot Assist limitations

Pilot Assist functionality may be reduced in certain situations.

Pilot Assist is a driver support function designed to simplify driving and assist the driver in many situations. However, the driver is always responsible for maintaining a suitable distance to vehicles or objects around it and ensuring that the vehicle is correctly positioned in the traffic lane.

In some situations, Pilot Assist may have trouble helping the driver properly or may be deactivated automatically – we advise against using Pilot Assist in such cases. Examples of such situations include:

- the lane markings are worn, missing or cross each other.
- lane division is unclear, for example, when the lanes divide or merge or at exits or when there are multiple sets of markings.
- edges or other lines than lane markings are present on or near the road, e.g. curbs, joints or repairs to the road surface, edges of barriers, roadside edges or strong shadows.
- the lane is narrow or winding.
- the lane contains ridges or holes.
- weather conditions are poor, e.g. rain, snow or fog or slush or reduced visibility with poor light conditions, backlighting, wet road surface, etc.

The driver should also note that Pilot Assist has the following limitations:

 High curbs, roadside barriers, temporary obstacles (traffic cones, safety barriers, etc.) are not detected. Alternatively, they may be detected incorrectly as lane markings, with a subsequent risk of contact between the vehicle and such obstacles.

- The driver is responsible for ensuring that the vehicle maintains a suitable distance from such obstacles
 - The camera and radar sensors do not have the capacity to detect all oncoming objects and obstacles in traffic environments, e.g. potholes, stationary obstacles or objects that completely or partially block the route.
 - Pilot Assist does not "see" pedestrians, animals, etc.
 - The recommended steering input is limited in force, which means that it cannot always help the driver to steer and keep the vehicle within the lane.
 - Pilot Assist is switched off if the power steering is working with reduced powere.g. during cooling due to overheating (see section "Speed-dependent steering force").

The driver can always correct or adjust steering assistance provided by Pilot Assist by turning the steering wheel to the desired position.

Steep roads and/or heavy loads

Pilot Assist is primarily intended to be driven on flat roads. The function may not be able to maintain the correct time interval to the vehicle ahead when driving down steep hills. The driver should

be extra attentive and prepared to apply the brakes.

• Do not use Pilot Assist if the vehicle is carrying a heavy load or towing a trailer.

(i) l

NOTE

Pilot Assist cannot be activated if a trailer, bike carrier or similar is connected to the vehicle electrical system.

Other limitations

 The Off Road drive mode cannot be selected when Pilot Assist is activated.

(i)

NOTE

The function uses the vehicle's camera unit, which has some general limitations – see the section "Camera unit limitations".

(\mathbf{i})

NOTE

The function uses the vehicle's radar unit, which has some general limitations – see the section "Radar unit limitations".


Related information

- Pilot Assist (p. 309)
- Speed-dependent steering wheel resistance (p. 270)

Pilot Assist* symbols and messages


A number of symbols and messages relating to Pilot Assist may be displayed in the instrument panel and/or the head-up display*.

Several examples⁶⁸ are provided below.




The previous illustration⁶⁹ shows that Pilot Assist is set to maintain a speed of 110 km/h (68 mph) and that there is no target vehicle ahead to follow.

Pilot Assist will not provide any steering assistance because it cannot detect the lane's side marking lines.



The previous illustration⁶⁹ shows that Pilot Assist is set to maintain a speed of 110 km/h (68 mph) and is following a target vehicle ahead that is traveling at the same speed.

Pilot Assist will not provide any steering assistance because it cannot detect the lane's side marking lines.




The previous illustration⁶⁹ shows that Pilot Assist is set to maintain a speed of 110 km/h (68 mph) and is following a target vehicle ahead that is traveling at the same speed.

In this example, Pilot Assist will also provide steering assistance because it can detect the lane's side marking lines.

⁶⁸ In the following illustration, Road Sign Information (RSI) indicates that the maximum permitted speed is 130 km/h (80 mph).

⁶⁹ Note: This illustration is general and details may vary depending on model.

4◀



The previous illustration⁶⁹ shows that Pilot Assist is set to maintain a speed of 110 km/h (68 mph) and that there is no target vehicle ahead to follow.

In this example, Pilot Assist will provide steering assistance because it can detect the lane's side marking lines.

Related information

Pilot Assist (p. 309)

Radar sensor

The radar sensor is used by several driver support systems to detect other vehicles.



Note: This illustration is general and details may vary depending on model.

The radar sensor is used by the following functions:

- Distance Alert*
- Adaptive Cruise Control*
- Lane Keeping Aid
- Pilot Assist*
- City Safety

Any modifications to the radar sensor may make its use illegal.

- Radar sensor limitations (p. 325)
- Recommended maintenance for the radar sensor (p. 328)
- Radar sensor type approval (p. 328)

Related information

⁶⁹ Note: This illustration is general and details may vary depending on model.

Radar sensor limitations

The radar sensor used by several of the driver support functions has certain limitations, which also affect the functions using the radar sensor.

Obstructed camera



The area marked in the illustration must be kept free of decals, objects, solar film, etc.⁷⁰

The radar sensor is located on the upper interior section of the windshield along with the camera.

(!) CAUTION

Do not place, affix or mount anything on the inside or outside of the windshield, or in front of or around the camera and radar unit – this could disrupt camera and radar-based functions.

It could cause functions to be reduced, deactivated completely or produce an incorrect function response.



If this symbol and the message
"Windscreen sensor Sensor
blocked, see Owner's manual" is
displayed in the instrument panel, it

means that the camera and radar sensor are unable to detect other vehicles, cyclists, pedestrians and large animals in front of the vehicle and that the vehicle's camera and radar-based functions may be obstructed, reduced, completely disabled or providing inaccurate responses.

The following table shows some of the situations that can cause the message to be displayed, and suggested actions:

Cause	Action
The area of the windshield in front of the camera/radar sensor is dirty or covered by ice or snow.	Clean the windshield in front of the camera/radar sensor and remove dirt, ice and snow.
Thick fog, heavy rain or snow is blocking the radar signals or the camera's range of visibility.	No action. Heavy precipitation may sometimes prevent the camera/radar sensor from functioning.

⁷⁰ Note: This illustration is general and details may vary depending on model.

Cause	Action
Water or snow is spraying/swirling up and blocking the radar signals or the camera's range of visibility.	No action. Very wet or snow-covered roads may sometimes prevent the camera/radar sensor from functioning.
There is dirt between the inside of the windshield and the camera/radar sensor.	Consult a workshop to have the area of the windshield on the inside of the camera's casing cleaned. An authorized Volvo workshop is recommended.



NOTE

Keep the windshield in front of the camera and radar unit clean.


Vehicle speed

The radar sensor's ability to detect a vehicle ahead is significantly reduced if:

the speed of the vehicle ahead differs greatly from your vehicle's speed

Limited field of vision

The radar sensor has a limited field of vision. In some situations, it may detect a vehicle later than expected or not at all.



The radar sensor's field of vision.

1 The radar sensor's detection of vehicles very close to your vehicle may be delayed in certain situations, e.g. if a vehicle pulls in

between your vehicle and the vehicle directly ahead.

- Small vehicles, such as motorcycles, or vehicles that are not driving in the center of the lane may remain undetected.
- In curves, the radar may detect the wrong vehicle or lose sight of a target vehicle.

Low trailers



Low trailer in the radar shadow.

Low trailers may also be difficult or even impossible for the radar to detect. The driver should be extra alert when driving behind vehicles towing low trailers when Adaptive Cruise Control or Pilot Assist is activated.

High temperatures

If the temperature in the passenger compartment is very high, the camera/radar sensor will switch off temporarily for approx. 15 minutes after the engine is started to protect its electronic components. When the temperature has cooled sufficiently, the camera/radar sensor will automatically restart.

Damaged windshield

CAUTION

If there are cracks, scratches or stone chips on the windshield in front of any of the camera and radar unit "windows" and this covers an area of about 0.5×3.0 mm

 $(0.02 \times 0.12 \text{ in.})$ or more, contact a workshop to have the windshield replaced - an authorized Volvo workshop is recommended.

Failure to take action could result in reduced performance for the driver support systems that use the camera and radar unit.

It could cause functions to be reduced, deactivated completely or produce an incorrect function response.

To avoid the risk of loss of function, malfunction or reduced function of the driver support systems that use the radar unit, the following also apply:

- Volvo advises against repairing cracks, scratches or stone chips in the area in front of the camera and radar unit - the entire windshield should instead be replaced.
- Before replacing the windshield, contact an authorized Volvo workshop to verify that the right windshield has been ordered and installed.

The same type of windshield wipers or wipers approved by Volvo should be used for replacement.

CAUTION

If the windshield is replaced, the camera and radar unit must be recalibrated by a workshop to help ensure proper functioning of all of the vehicle's camera and radar-based systems an authorized Volvo workshop is recommended.

Related information

Radar sensor (p. 324)

Recommended maintenance for the radar sensor

In order for the camera/radar sensor to function properly, the area of the windshield in front of the unit must be kept free of dirt, ice, snow, etc. and should be washed regularly with water and car washing detergent.



NOTE

Dirt, ice and snow covering the camera and radar unit reduce their function and can make measurement impossible.

It could cause functions to be reduced, deactivated completely or produce an incorrect function response.

Related information

• Radar sensor (p. 324)

Radar sensor type approval

The type approval for the vehicle radar sensor in the ACC⁷¹, PA⁷² and BLIS⁷³ functions can be read here.

ACC⁷¹, PA⁷² and BLIS⁷³ USA & Canada:

FCC ID: L2C0054TR IC: 3432A-0054TR

FCC ID: L2C0055TR IC: 3432A-0055TR

This device complies with Part 15 of the FCC Rules and with Industry Canada license-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Cet appareil est conforme aux CNR d'Industrie Canada a applicables aux appareils radio exempts de licence. L'exploitation est autorisée à condition que l'appareil ne produise pas de brouillage préjudiciable et qu'il accepte tout brouillage, même celui susceptible d'en compromettre le fonctionnement. Note: Changes or modifications not expressively approved by the party responsible for compliance could void the user's authority to operate the equipment. The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met.

Note: This equipment complies with radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body.

Related information

• Radar sensor (p. 324)

⁷¹ ACC = Adaptive Cruise Control

⁷² PA = Pilot Assist

⁷³ BLIS = Blind Spot Information

Camera

The camera is used by several driver support systems to e.g. detect lane marker lines or road signs.



Note: This illustration is general and details may vary depending on model.

The camera is used by the following functions:

- Adaptive Cruise Control*
- Pilot Assist*
- Lane Keeping Aid*
- Steering assistance at risk of collision
- City Safety
- Driver Alert Control*
- Road Sign Information*
- Active high beams*

Related information

- Camera limitations (p. 330)
- Recommended maintenance for the camera/ radar sensor (p. 333)

Camera limitations

The camera used by several of the driver support functions has certain limitations, which also affect the functions using the camera.

Reduced visibility

The camera has the same limitations as the human eye. In other words, its "vision" is impaired by adverse weather conditions such as heavy snowfall/rain, dense fog, swirling dust/snow, etc. These conditions may reduce the function of systems that depend on the camera or cause these systems to temporarily stop functioning.

Strong sunlight, reflections from the road surface, ice or snow covering the road, a dirty road surface, or unclear lane marker lines may drastically reduce the camera's ability to detect the side of a lane, a pedestrian, a cyclist, a large animal or another vehicle.

Obstructed camera



The area marked in the illustration must be kept free of decals, objects, solar film, etc. 74

The camera is located on the upper interior section of the windshield along with the radar sensor.

!) CAUTION

Do not place, affix or mount anything on the inside or outside of the windshield, or in front of or around the camera and radar unit – this could disrupt camera and radar-based functions.

It could cause functions to be reduced, deactivated completely or produce an incorrect function response.



If this symbol and the message
"Windscreen sensor Sensor
blocked, see Owner's manual" is
displayed in the instrument panel, it

means that the camera and radar sensor are unable to detect other vehicles, cyclists, pedestrians and large animals in front of the vehicle and that the vehicle's camera and radar-based functions may be obstructed, reduced, completely disabled or providing inaccurate responses.

The following table shows some of the situations that can cause the message to be displayed, and suggested actions:

⁷⁴ Note: This illustration is general and details may vary depending on model.

Cause	Action
The area of the windshield in front of the camera/radar sensor is dirty or covered by ice or snow.	Clean the windshield in front of the camera/radar sensor and remove dirt, ice and snow.
Thick fog, heavy rain or snow is blocking the radar signals or the camera's range of visibility.	No action. Heavy precipitation may sometimes prevent the camera/radar sensor from functioning.
Water or snow is spraying/swirling up and blocking the radar signals or the camera's range of visibility.	No action. Very wet or snow-covered roads may sometimes prevent the camera/radar sensor from functioning.
There is dirt between the inside of the windshield and the camera/radar sensor.	Consult a workshop to have the area of the windshield on the inside of the camera's casing cleaned. An authorized Volvo workshop is recommended.
Bright sunlight	No action. The camera/radar sensor will reset automatically when lighting conditions improve.



(i) NOTE

Keep the windshield in front of the camera and radar unit clean.

High temperatures

If the temperature in the passenger compartment is very high, the camera/radar sensor will switch off temporarily for approx. 15 minutes after the engine is started to protect its electronic components. When the temperature has cooled sufficiently, the camera/radar sensor will automatically restart.

Damaged windshield

CAUTION

If there are cracks, scratches or stone chips on the windshield in front of any of the camera and radar unit "windows" and this covers an area of about 0.5×3.0 mm $(0.02 \times 0.12 \text{ in.})$ or more, contact a workshop to have the windshield replaced - an authorized Volvo workshop is recommended.

Failure to take action could result in reduced performance for the driver support systems that use the camera and radar unit.

It could cause functions to be reduced, deactivated completely or produce an incorrect function response.

To avoid the risk of loss of function, malfunction or reduced function of the driver support systems that use the radar unit, the following also apply:

- Volvo advises against repairing cracks, scratches or stone chips in the area in front of the camera and radar unit - the entire windshield should instead be replaced.
- Before replacing the windshield, contact an authorized Volvo workshop to verify

DRIVER SUPPORT

- 44
- that the right windshield has been ordered and installed.
- The same type of windshield wipers or wipers approved by Volvo should be used for replacement.

1

CAUTION

If the windshield is replaced, the camera and radar unit must be recalibrated by a workshop to help ensure proper functioning of all of the vehicle's camera and radar-based systems – an authorized Volvo workshop is recommended.

Related information

• Camera (p. 329)

Recommended maintenance for the camera/radar sensor

In order for the camera/radar sensor to function properly, the area of the windshield in front of the unit must be kept free of dirt, ice, snow, etc. and should be washed regularly with water and car washing detergent.



Dirt, ice and snow covering the camera and radar unit reduce their function and can make measurement impossible.


It could cause functions to be reduced, deactivated completely or produce an incorrect function response.

Related information

Camera (p. 329)

City Safety™

City Safety can alert the driver with light, sound and pulsations in the brake pedal to help the driver detect pedestrians, cyclists, large animals and vehicles that appear suddenly – the vehicle will then attempt to automatically brake if the driver does not act within a reasonable amount of time.



Location of the camera and radar sensor⁷⁵.

City Safety can help prevent a collision or lower the vehicle's speed at the point of impact.

City Safety is an aid intended to assist the driver if a collision with a pedestrian, large animal, cyclist or vehicle is imminent.

City Safety can help the driver avoid a collision when e.g. driving in stop-and-go traffic, when

changes in the traffic ahead and driver distraction could lead to an incident.

The function assists the driver by automatically applying the brakes if there is an imminent risk of a collision and the driver does not react in time by braking and/or steering away.

City Safety activates a brief, forceful braking in an attempt to stop your vehicle immediately behind the vehicle or object ahead.

City Safety is activated in situations in which the driver should have applied the brakes much earlier, which means that the system will not be able to assist the driver in all situations.

City Safety is designed to be activated as late as possible to help avoid unnecessary intervention.

Normally, the occupants of the vehicle will not be aware of City Safety except when the system intervenes when a collision is imminent.

⁷⁵ Note: This illustration is general and details may vary depending on model.

- The City Safety function is supplementary driver support intended to help improve driving safety – it cannot handle all situations in all traffic, weather and road conditions.
- The City Safety auto-brake function can prevent a collision or reduce collision speed, but to ensure full brake performance the driver should always depress the brake pedal – even when the car autobrakes.
- The warning and steering assistance are only activated if there is a high risk of collision – you must therefore never wait for the collision warning or City Safety to intervene.
- Warnings and brake interventions for pedestrians and cyclists are disengaged at vehicle speeds over 80 km/h (50 mph).
- City Safety does not activate auto-braking intervention during heavy acceleration.
- City Safety is not a substitute for the driver's attention and judgment. The driver is always responsible for ensuring the vehicle is driven in a safe manner, at the appropriate speed, with an appropriate distance to other vehicles, and in accordance with current traffic rules and regulations.

The driver is advised to read all sections in the Owner's Manual that relate to City Safety to learn about factors such as its limitations and what the driver should be aware of before using the system (see the list of links for all subsections).

Related information

- City Safety parameters and sub-functions (p. 334)
- Setting a warning distance for City Safety (p. 336)
- Detecting obstacles with City Safety (p. 337)
- City Safety in crossing traffic (p. 339)
- Limitations of City Safety in crossing traffic (p. 340)
- City Safety and delayed evasive maneuvers (p. 341)
- City Safety limitations (p. 342)
- City Safety messages (p. 344)

City Safety parameters and subfunctions

City Safety can help avoid a collision with a vehicle, cyclist or large animal ahead by reducing the vehicle's speed using its automatic braking function.

If the difference in speed is greater than the speeds specified below, the City Safety autobrake function cannot prevent a collision, but it can help mitigate its effects.

Vehicles

City Safety can help prevent a collision with a vehicle ahead by reducing your vehicle's speed by up to 60 km/h (37 mph).

Cyclists

City Safety can help prevent a collision with a cyclist ahead by reducing your vehicle's speed by up to 50 km/h (30 mph).

Pedestrians

City Safety can help prevent a collision with a pedestrian ahead by reducing your vehicle's speed by up to 45 km/h (28 mph).

Large animals

If there is a risk of colliding with a large animal, City Safety can help reduce your vehicle's speed by up to 15 km/h (9 mph).

The braking function for large animals is primarily intended to mitigate the force of a collision at higher speeds. Braking is most effective at speeds above 70 km/h (43 mph) and less effective at lower speeds.

City Safety sub-functions



Function overview⁷⁶.

- 1 Audio-visual collision warning
- Camera/radar sensor distance monitoring

City Safety carries out three steps in the following order:

- 1. Collision warning
- 2. Brake assistance
- 3. Auto-brake

Descriptions of what happens in these three steps are provided below.

1 - Collision warning

The driver is first alerted to the risk of an imminent collision.

City Safety can detect pedestrians, cyclists or vehicles that are stationary, are moving in the same direction as your vehicle and are ahead of your vehicle. City Safety can also detect pedestrians, cyclists or large animals that are crossing the road in front of your vehicle.

If there is a risk of a collision with a pedestrian, large animal, cyclist or another vehicle, or with a vehicle described in the section "City Safety in crossing traffic", the driver will be alerted with light, sound and pulsations in the brake pedal. At lower speeds, during hard braking or if the accelerator pedal is pressed, the brake pedal pulsation warning will not be given. The intensity of the brake pedal pulsations varies according to the vehicle's speed.

2 - Brake assistance

If the risk of a collision increases after the collision warning, brake support will be activated.

If the system determines that the pressure the driver is exerting on the brake pedal is insufficient to prevent the collision, brake support will increase pressure.

⁷⁶ Note: This illustration is general and details may vary depending on model.

3 - Auto-brake

The automatic braking function is activated at the last moment.

If the driver has not taken evasive action by this stage and a collision is imminent, the automatic braking function will be triggered. This occurs whether or not the driver is pressing the brake pedal. Full braking force will be applied to reduce the speed at impact or reduced braking effect will be applied if this is sufficient to avoid the collision.

The seat belt tensioners may be activated along with the automatic braking function. See "Seat belt tensioners" for more information.

In certain situations, auto-braking may begin with a limited braking force before applying full braking force.

If City Safety has prevented a collision, the vehicle will be kept at a standstill until the driver takes action. If the vehicle has slowed to avoid colliding with a slower-moving vehicle ahead, your speed will be reduced to that vehicle's speed.

Auto-braking can always be cancelled if the driver presses hard on the accelerator pedal.



(i) NOTE

When City Safety activates the brakes, the brake lights come on.

When City Safety applies the brakes, a text message will appear in the instrument panel to notify the driver that the function is/was activated



WARNING

City Safety may not be used to change how the driver operates the vehicle. The driver must not only rely on City Safety to brake the vehicle.

Related information

City Safety™ (p. 333)

Setting a warning distance for City Safety

City Safety is always active, but the function's warning distance can be adjusted.



NOTE

The City Safety function cannot be deactivated. It is activated automatically each time the engine/electric motor is started.

The alert distance determines the sensitivity of the system and regulates the distance at which the light, sound and brake pulsations will be activated.

To select warning distance:

- Select Settings → My Car → IntelliSafe in the center display's Top view.
- 2. Under City Safety Warning, tap Late, Normal or Early to set the desired warning distance.

If the driver feels that the Early setting is giving too many warnings or finds them irritating, the Normal or Late warning distance settings can be selected instead.

If the driver feels that the warnings are too frequent and distracting, the warning distance can be reduced. This will reduce the total number of warnings, but it will also result in City Safety providing warnings at a later stage.

The **Late** warning distance setting should therefore only be used in exceptional cases, such as when a more dynamic driving style is preferred.

- No automatic system can guarantee 100% correct function in all situations. You should therefore never test use of City Safety in the direction of people, animals or vehicles – this could lead to severe damage, serious personal injury or even death.
- City Safety warns the driver if there is a risk of collision, but the function cannot reduce the driver's reaction time.
- Even if the warning distance has been set to Early, warnings may be perceived as late in certain situations – e.g. when there are large speed differences or if the vehicle ahead suddenly brakes heavily.
- With the warning distance set to Early, warnings come further in advance. This may cause the warnings to come more frequently than with warning distance Normal, but is recommended since it can make City Safety more effective.

(i) NOTE

The warning with direction indicators for Rear Collision Warning is deactivated if the collision warning distance in the City Safety function is set to the lowest level "Late".

The seat belt tensioning and braking functions remain active.

Related information

City Safety™ (p. 333)

Detecting obstacles with City Safety

City Safety can detect vehicles, cyclists, large animals and pedestrians.

Vehicles

City Safety detects most types of vehicles that are either stationary, moving in the same direction as your vehicle or those described in "City Safety in crossing traffic".

For City Safety to be able to detect a vehicle in the dark, its headlights and taillights must be on and clearly visible.

Cyclists



Optimal examples of what City Safety would interpret to be a cyclist: clear body and bicycle shapes.

For optimal performance, the system's function for cyclist detection needs the clearest possible information about the contours of the bicycle and of the cyclist's head, arm, shoulders, legs, torso

and lower body in combination with normal human movements.

If large portions of the cyclist's body or the bicycle itself are not visible to the function's camera, it will not be able to detect a cyclist.

The system can only detect adult cyclists riding on bicycles intended for adults.


∴ WARNING

City Safety is supplementary driver support, but it cannot detect all cyclists in all situations and, for example, cannot see:

- partially obscured cyclists.
- cyclists if the background contrast of the cyclist is poor - warning and brake interventions may then be late or not occur at all.
- cyclists in clothing that hides their body contour.
- bikes loaded with large objects.

The driver is always responsible for ensuring that the vehicle is driven correctly and with a safety distance suitable for the speed.

Pedestrians



Optimal examples of what the system considers to be a pedestrian: clear body contours.

For optimal performance, the system's function for pedestrian detection needs the clearest possible information about body and bicycle contours. This entails being able to detect the contours of the pedestrian's head, arm, shoulders, legs, torso and lower body in combination with normal human movements.

In order to detect a pedestrian, there must be a contrast to the background, which could depend on clothing, weather conditions, etc. If there is little contrast, the person may be detected late or not at all, which may result in a delayed reaction from the system or no reaction at all.

City Safety can detect pedestrians even in dark conditions if they are illuminated by the vehicle's headlights.


♠ WARNING

City Safety is supplementary driver support, but it cannot detect all pedestrians in all situations and, for example, cannot see:

- partially obscured pedestrians, people in clothing that hides their body contour or pedestrians shorter than 80 cm (32 in.).
- pedestrians if the background contrast of the pedestrians is poor - warning and brake interventions may then be late or not occur at all.
- pedestrians who are carrying large objects.

The driver is always responsible for ensuring that the vehicle is driven correctly and with a safety distance suitable for the speed.

Large animals



Optimal examples of what City Safety would interpret as a large animal: stationary or moving slowly and with clear body contours.

For optimal performance, the system's function for detecting large animals (e.g. moose, horses, etc.) needs the clearest possible information about body contours. This entails being able to detect the animal straight from the side in combination with normal movements for that animal.

If parts of the animal's body are not visible to the function's camera, the system will not be able to detect the animal.

City Safety can detect large animals even in dark conditions if they are illuminated by the vehicle's headlights.

⚠ WARNING

City Safety is supplementary driver support, but it cannot detect all large animals in all situations and, for example, cannot see:

- partially obscured larger animals.
- larger animals seen from the front or from behind.
- running or fast moving larger animals.
- larger animals if the contrast of the animal's background is poor warning and brake interventions may then occur late or not at all.
- smaller animals such as cats and dogs.


The driver is always responsible for ensuring that the vehicle is driven correctly and with a safety distance suitable for the speed.

Related information

City Safety[™] (p. 333)

City Safety in crossing traffic

City Safety can assist the driver when turning in the path of an oncoming vehicle in an intersection.



1: Sector in which City Safety can detect an oncoming vehicle in crossing traffic.

In order for City Safety to detect an oncoming vehicle in situations where there is a risk of a collision, that vehicle must be within the sector in which City Safety can analyze the situation.

The following criteria must also be met:

- your vehicle's speed must be at least 4 km/h (3 mph)
- your vehicle must be making a left turn
- the oncoming vehicle's headlights must be on


- The "City Safety in crossing traffic" function is supplementary driver support intended to improve driving safety it cannot handle all situations in all traffic, weather and road conditions.
- Warnings and brake interventions due to a collision risk with an oncoming vehicle often come very late.
- Never wait for a collision warning or for City Safety to intervene.
- City Safety is not a substitute for the driver's attention and judgment. The driver is always responsible for ensuring the vehicle is driven in a safe manner, at the appropriate speed, with an appropriate distance to other vehicles, and in accordance with current traffic rules and regulations.

Related information

City SafetyTM (p. 333)

Limitations of City Safety in crossing traffic

In certain situations, it may be difficult for City Safety to help the driver avoid a collision with crossing traffic.



For example:

- on slippery roads when Electronic Stability Control (ESC) is actively operating
- if an approaching vehicle is detected at a late stage
- if the oncoming vehicle is partially obstructed by another vehicle or object
- if the oncoming vehicle's headlights are off
- if the oncoming vehicle is moving erratically and e.g. suddenly changes lanes at a late stage.

i) NOTE

The function uses the vehicle's camera unit, which has some general limitations – see the section "Camera unit limitations".

(i) NOTE

The function uses the vehicle's radar unit, which has some general limitations – see the section "Radar unit limitations".


Related information

City Safety[™] (p. 333)

City Safety and delayed evasive maneuvers

City Safety can assist the driver by automatically braking the vehicle when it is not possible to avoid a collision by steering alone.

City Safety assists the driver by periodically attempting to predict possible "escape routes" to the sides of the vehicle in the event a slow-moving or stationary vehicle were to be detected at a late stage.



Your vehicle (1) cannot detect any potential escape routes for veering away from the vehicle ahead (2) and may therefore apply the brakes at an earlier stage.

Own vehicle

Slow-moving/stationary vehicles

City Safety will not intervene to automatically apply the brakes if it is possible for the driver to avoid a collision by steering the vehicle.

However, if City Safety determines that an evasive maneuver would not be possible due to traffic in the adjacent lane(s), the function can assist the driver by automatically starting to apply the brakes at an earlier stage.

WARNING

- The possibility of City Safety predicting a certain situation is supplementary driver support intended to improve driving safety - it cannot handle all situations in all traffic. weather and road conditions.
- City Safety is not a substitute for the driver's attention and judgment. The driver is always responsible for ensuring the vehicle is driven in a safe manner, at the appropriate speed, with an appropriate distance to other vehicles, and in accordance with current traffic rules and regulations.

Limitations of City Safety during evasive maneuvers



The function uses the vehicle's camera unit. which has some general limitations - see the section "Camera unit limitations".

(i) NOTE

The function uses the vehicle's radar unit. which has some general limitations - see the section "Radar unit limitations".

Related information

City Safety™ (p. 333)

City Safety limitations

City Safety functionality may be reduced in certain situations.

Surroundings

Low objects

Hanging objects, such as flags for overhanging loads or accessories such as auxiliary lights or front protective grids that extend beyond the height of the hood, may limit City Safety functionality.

Slippery road conditions

The extended braking distance on slippery roads may reduce City Safety's capacity to help avoid a collision. In these types of situations, the Antilock Braking System and Electronic Stability Control (ESC⁷⁷) will help provide optimal braking power with maintained stability.

Backlighting

The visual warning signal in the windshield may be difficult to detect in bright sunlight, if there are reflections, or if the driver is wearing sunglasses or not looking straight ahead.

Heat

If the temperature in the passenger compartment is high due to e.g. bright sunlight, the visual warning signal in the windshield may be temporarily disabled.

Camera and radar sensor's field of vision

The camera's field of vision is limited and in certain situations, it may be unable to detect pedestrians, large animals, cyclists or vehicles, or it may detect them later than expected.

Vehicles that are dirty may be detected later than clean vehicles, and in dark conditions, motorcycles may be detected late or not at all.

If a text message displayed in the instrument panel indicates that the camera/radar sensor is obstructed, it may be difficult for City Safety to detect pedestrians, large animals, cyclists, vehicles or lane markings in front of the vehicle. City Safety functionality may therefore be reduced.

Text messages may not be displayed for all situations in which the windshield sensors are blocked. The driver must therefore always keep the windshield in front of the camera/radar sensor clean.

(1)

CAUTION

Maintenance and replacement of City Safety components may only be performed by a workshop – an authorized Volvo workshop is recommended.

Driver intervention

Backing up

City Safety is temporarily deactivated when the vehicle is backing up.

Low speed

City Safety is not activated at very low speeds under 4 km/h (3 mph). The system will therefore not intervene in situations in which your vehicle is approaching another vehicle very slowly, such as when parking.

Active driver

Action by the driver always has priority. City Safety will therefore not react or will react at a later stage with a warning or intervention in situations in which the driver is clearly steering and operating the accelerator pedal, even if a collision is unavoidable.

An active and aware driving style may therefore delay collision warnings and intervention in order to minimize unnecessary warnings.

⁷⁷ Electronic Stability Control

Other limitations

Λ

WARNING

- Warnings and brake interventions can be triggered late or not at all if the traffic situation or external influences prevent the camera and radar unit from properly detecting pedestrians, cyclists, large animals or vehicles ahead of the vehicle.
- To be able to detect vehicles at night, its front and rear lights must work and illuminate clearly.
- The camera and radar unit have a limited range for pedestrians and cyclists the system can provide effective warnings and brake interventions if the relative speed is lower than 50 km/h (30 mph). For stationary or slow-moving vehicles, warnings and brake interventions are effective at vehicle speeds of up to 70 km/h (43 mph). Speed reduction for large animals is less than 15 km/h (9 mph) and can be achieved at vehicle speeds over 70 km/h (43 mph). At lower speeds, the warning and brake intervention for large animals is less effective.
- Warnings for stationary or slow-moving vehicles and large animals can be disengaged due to darkness or poor visibility.

- Warnings and brake interventions for pedestrians and cyclists are disengaged at vehicle speeds over 80 km/h (50 mph).
- Do not place, affix or mount anything on the inside or outside of the windshield, or in front of or around the camera and radar unit – this could disrupt camerabased functions.
- Objects, snow, ice or dirt in the area of the camera sensor can reduce the function, disengage it completely or give an improper function response.



NOTE

The function uses the vehicle's camera unit, which has some general limitations – see the section "Camera unit limitations".



NOTE

The function uses the vehicle's radar unit, which has some general limitations – see the section "Radar unit limitations".

Market limitations

City Safety is not available in all countries. If City Safety is not shown in the center display's **Settings** menu, your vehicle is not equipped with this function.

In the center display's Top view, tap:

Settings → My Car → IntelliSafe

Related information

City Safety™ (p. 333)

City Safety messages

A number of messages related to City Safety may be displayed in the instrument panel.

Some examples of symbols and messages are shown in the table below.

Message	Meaning
City Safety	When City Safety is braking or has activated the automatic braking function, one or more symbols may illuminate in
Automatic intervention	the instrument panel and a text message may be displayed.
City Safety	The system is not functioning as intended. Contact a workshop – an authorized Volvo workshop is recommended.
Reduced functionality Service required	

A text message can be erased by briefly pressing the $\,O\,$ button in the center of the right-side steering wheel keypad.

If the message persists: Contact a workshop – an authorized Volvo workshop is recommended.

Related information

City Safety™ (p. 333)

Rear Collision Warning

The Rear Collision Warning (RCW) function can help the driver avoid rear-end collisions from vehicles approaching from behind.

RCW is automatically activated each time the engine is started.

RCW can warn the driver of a potential collision with vehicles approaching from behind by rapidly flashing the turn signals.

If, at a speed below 30 km/h (20 mph), the RCW function detects that the car is in danger of being hit from behind, the seatbelt tensioners may tension the front seatbelts and activate the Whiplash Protection System safety system.

Immediately before a collision from behind, RCW may also activate the foot brake in order to reduce the forward acceleration of the car during the collision. However, the brakes will only be applied if your vehicle is stationary. The brakes will be immediately released if the accelerator pedal is depressed.

Related information

- Rear Collision Warning limitations (p. 345)
- Whiplash Protection System (p. 46)

Rear Collision Warning limitations

In some situations, it may be difficult for RCW to warn the driver of a collision risk.

This may be the case if:

- the vehicle approaching from the rear is detected at a late stage
- the vehicle approaching from the rear changes lanes at a late stage
- the vehicle approaching from the rear is moving at a speed above 80 km/h (50 mph)
- a trailer, bicycle holder or similar is connected to the vehicle's electrical system - the RCW function will then be automatically deactivated.

(i) NOTE

In certain markets RCW does **not** warn with the direction indicators due to local traffic regulations – in such cases, that part of the function is deactivated.

i) NOTE

The warning with direction indicators for Rear Collision Warning is deactivated if the collision warning distance in the City Safety function is set to the lowest level "Late".

The seat belt tensioning and braking functions remain active.

Related information

• Rear Collision Warning (p. 345)

BLIS*

The BLIS⁷⁸ function is designed to help provide assistance in heavy traffic with several lanes moving in the same direction by helping the driver to detect the presence of vehicles in the "blind spot" area behind and to the side of the vehicle.


BLIS is a driver support system designed to alert the driver of:

- vehicles in your "blind spot"
- vehicles approaching rapidly in adjacent lanes.



Location of BLIS indicator light.⁷⁹

- 1 Indicator light
- The BLIS button in the center display's Function view is used to activate/deactivate the function.



BLIS overview

- Blind spot zone
- Rapidly approaching vehicle zone.

The BLIS function is active at speeds above 10 km/h (6 mph).

The system is designed to react to:

- vehicles passing your vehicle
- vehicles that are rapidly approaching your vehicle from behind.

When BLIS detects a vehicle in zone 1 or a rapidly approaching vehicle in zone 2, an indicator light will illuminate in the relevant rearview mirror and glow steadily. If the driver then uses the turn signal on the side in which the warning has been

⁷⁸ Blind Spot Information Systems

⁷⁹ Note: This illustration is general and details may vary depending on model.

given, the indicator light will become brighter and begin flashing.



NOTE

The light illuminates on the side of the vehicle where the system has detected the vehicle. If the vehicle is passed on both sides simultaneously, both lights come on.

⚠ WARNING

- The BLIS function is supplementary driver support intended to facilitate driving and help make it safer – it cannot handle all situations in all traffic, weather and road conditions.
- The responsibility for changing lanes safely and using good judgment always rests with the driver.
- BLIS is not a substitute for the driver's attention and judgment. The driver is always responsible for ensuring the vehicle is driven in a safe manner, at the appropriate speed, with an appropriate distance to other vehicles, and in accordance with current traffic rules and regulations.

Related information

- Activating/deactivating BLIS (p. 347)
- BLIS limitations (p. 348)

- Recommended maintenance for BLIS (p. 349)
- BLIS messages (p. 350)

Activating/deactivating BLIS

The BLIS⁸⁰ function can be activated/deactivated.



Location of BLIS indicator light.81

- 1 Indicator light
- 2 The BLIS button in the center display's Function view is used to activate/deactivate the function.
- Tap the BLIS button in Function view.
 - The BLIS indicator light shows the status of the function: GREEN (on) or GRAY (off).

If BLIS is activated when the engine is started, the indicator lights in the rearview mirrors will flash once.

If BLIS is deactivated when the engine is turned off, it will remain off the next time the engine is started and the indicator lights will not illuminate.

Related information

BLIS* (p. 346)

BLIS limitations

BLIS⁸² functionality may be reduced in certain situations.



Keep this area clean (on both the left and right sides of the vehicle) 83 .

Examples of limitations:

- Dirt, ice and snow covering the sensors may reduce functionality and prevent the system from providing warnings.
- The BLIS function is automatically deactivated if a trailer, bicycle holder or similar is connected to the vehicle's electrical system.
- For BLIS to function optimally, bicycle holders, luggage racks or similar should not be mounted on the vehicle's towbar.

- BLIS does not work in sharp curves.
- BLIS does not work when the vehicle is being reversed.

Related information

BLIS* (p. 346)

⁸⁰ Blind Spot Information

⁸¹ Note: This illustration is general and details may vary depending on model.

⁸² Blind Spot Information

⁸³ Note: This illustration is general and details may vary depending on model.

Recommended maintenance for BLIS

- For optimal performance, it is important to keep the areas in front of the sensors clean.
- Do not attach any objects, tape or decals to the surface of the sensors.



Keep this area clean (on both the left and right sides of the vehicle) 84 .

The BLIS sensors are located on the inside of each of the rear fenders/bumpers and are also used by the Cross Traffic Alert (CTA) and Rear Collision Warning functions.

(!) CAUTION

Repair of BLIS and CTA components or repainting of the bumper may only be performed by a workshop – an authorized Volvo workshop is recommended.

Related information

- BLIS* (p. 346)
- Cross Traffic Alert* (p. 351)
- Activating/deactivating Cross Traffic Alert (p. 352)
- Cross Traffic Alert limitations (p. 352)
- Recommended maintenance for Cross Traffic Alert (p. 353)
- Cross Traffic Alert messages (p. 354)
- Rear Collision Warning (p. 345)

⁸⁴ Note: This illustration is general and details may vary depending on model.

BLIS messages

A number of messages related to BLIS⁸⁵ may be displayed in the instrument panel.

Some examples of symbols and messages are shown in the table below.

Message	Meaning
Blind spot sensor	The system is not functioning as intended. Contact a workshop – an authorized Volvo workshop is recommended.
Service required	
Blind spot system off	BLIS and CTA have been deactivated because a trailer has been connected to the vehicle's electrical system.
Trailer attached	

A text message can be erased by briefly pressing the O button in the center of the right-side steering wheel keypad.

If the message persists: Contact a workshop – an authorized Volvo workshop is recommended.


Related information

BLIS* (p. 346)

⁸⁵ Blind Spot Information

Cross Traffic Alert*

CTA⁸⁶ is a supplementary driver support system to BLIS⁸⁷ that is intended to help the driver detect vehicles crossing behind the vehicle while backing up.



CTA overview.

CTA supplements BLIS by detecting traffic crossing from the side, e.g. when backing out of a parking space.

CTA is primarily designed to detect vehicles, but in certain cases can also detect pedestrians or smaller objects such as bicycles.

CTA is only active when the vehicle is moving backward or if reverse gear is engaged.

If CTA detects that something is approaching your vehicle from the side:

- an audible signal will sound from either the left or right speaker, depending on which side of your vehicle the object is approaching from.
- an icon will illuminate in the PAS⁸⁸ graphic on the screen.
- an icon will appear in the Park Assist Camera's Top view.



Illuminated CTA icon in the PAS⁸⁸ graphic⁸⁹ on the screen.

- The Cross Traffic Alert function is supplementary driver support intended to facilitate driving and make it safer it cannot handle all situations in all traffic, weather and road conditions.
- The responsibility for reversing the vehicle safely and using good judgment always rests with the driver.
- Cross Traffic Alert is not a substitute for the driver's attention and judgment. The driver is always responsible for ensuring the vehicle is driven in a safe manner, at the appropriate speed, with an appropriate distance to other vehicles, and in accordance with current traffic rules and regulations.

Related information

- Activating/deactivating Cross Traffic Alert (p. 352)
- Cross Traffic Alert limitations (p. 352)
- Recommended maintenance for Cross Traffic Alert (p. 353)
- Cross Traffic Alert messages (p. 354)

⁸⁶ Cross Traffic Alert

⁸⁷ Blind Spot Information

⁸⁸ Park Assist System: Parking assistance with reversing sensors

⁸⁹ Note: This illustration is general and details may vary depending on model.

Activating/deactivating Cross Traffic Alert

The driver can choose to deactivate the CTA⁹⁰ function as follows:



Press the **Cross Traffic Alert** button in the center display's Function view.

- GRAY button indicator light CTA is deactivated.
- GREEN button indicator light CTA is activated.

CTA is automatically activated each time the engine is started.

Related information


Cross Traffic Alert* (p. 351)

Cross Traffic Alert limitations


CTA⁹¹ functionality may be reduced in certain situations.

CTA does not function optimally in all situations and has certain limitations. The CTA sensors, for example, cannot "see" through other parked vehicles or objects blocking the vehicle.

Below are a few examples of situations in which CTA's field of vision may be initially limited and approaching vehicles may therefore not be detected until they are very close to your vehicle:



The vehicle is parked very far into a parking space.



In a diagonal parking space, CTA may be completely "blind" on one side of your vehicle.

- 1 CTA's blind zone.
- CTA's field of vision.

However, as you back your vehicle slowly out of a parking space, CTA's field of vision changes in relation to the obstructing vehicle/object and its blind zone is reduced.

⁹⁰ Cross Traffic Alert

⁹¹ Cross Traffic Alert

Examples of further limitations

- Dirt, ice and snow covering the sensors may reduce functionality and prevent the system from providing warnings. For additional information, see the section "Recommended maintenance for Cross Traffic Alert".
- CTA is automatically deactivated if a trailer, bicycle holder or similar is connected to the vehicle's electrical system.
- For CTA to function optimally, bicycle holders, luggage racks or similar should not be mounted on the vehicle's towbar.

Related information

Cross Traffic Alert* (p. 351)

Recommended maintenance for **Cross Traffic Alert**

- For optimal performance, it is important to keep the areas in front of the sensors clean.
- Do not attach any objects, tape or decals to the surface of the sensors.



Keep this area clean (on both the left and right sides of the vehicle)92

The CTA sensors are located on the inside of each of the rear fenders/bumpers and are also used by the BLIS93 and Rear Collision Warning functions.

CAUTION

Repair of BLIS and CTA components or repainting of the bumper may only be performed by a workshop - an authorized Volvo workshop is recommended.

Related information

- Cross Traffic Alert* (p. 351)
- BLIS* (p. 346)
- Rear Collision Warning (p. 345)

⁹² Note: This illustration is general and details may vary depending on model.

⁹³ Blind Spot Information

Cross Traffic Alert messages

A number of messages related to CTA⁹⁴ may be displayed in the instrument panel.

Some examples of symbols and messages are shown in the table below.

Message	Meaning
Blind spot sensor	The system is not functioning as intended. Contact a workshop – an authorized Volvo workshop is recommended.
Service required	
Blind spot system off	BLIS and CTA have been deactivated because a trailer has been connected to the vehicle's electrical system.
Trailer attached	

A text message can be erased by briefly pressing the \bigcirc button in the center of the right-side steering wheel keypad.

If the message persists: Contact a workshop – an authorized Volvo workshop is recommended.


Related information

• Cross Traffic Alert* (p. 351)

⁹⁴ Cross Traffic Alert

Road Sign Information*

The Road Sign Information (RSI95) function notifies the driver of speed-related road signs the vehicle is passing.



Examples of signs that can be detected⁹⁶.

If the vehicle passes a speed limit sign, it will be displayed in the instrument panel and the headup display*.



In certain markets, the Road Sign Information function (RSI) is only available in combination with Sensus Navigation.

WARNING

- The Road Sign Information function is supplementary driver support intended to facilitate driving and help make it safer it cannot handle all situations in all traffic. weather and road conditions.
- Road Sign Information is not a substitute for the driver's attention and judgment. The driver is always responsible for ensuring the vehicle is driven in a safe manner, at the appropriate speed, with an appropriate distance to other vehicles, and in accordance with current traffic rules and regulations.

Related information

- Activating/deactivating Road Sign Information (p. 356)
- Road Sign Information and sign displays (p. 356)
- Road Sign Information and Sensus Navigation (p. 357)
- Road Sign Information with Speed Warning and Settings (p. 357)
- Activating/deactivating Speed Warning in Road Sign Information (p. 358)

- Road Sign Information with speed camera information (p. 359)
- Road Sign Information limitations (p. 359)

⁹⁵ Road Sign Information

⁹⁶ Road signs differ according to market - the illustrations shown here are just some examples.

Activating/deactivating Road Sign Information

The Road Sign Information function can be switched **On** or **Off**.



Press the **Road Sign Information** button in the center display's Function view.

- GREEN button indicator light RSI is activated.
- GRAY button indicator light RSI is deactivated.

(i) NOTE


- If the Automatic Speed Limiter function is activated, road sign information is shown in the driver display even if RSI is not activated.
- To remove road sign information from the driver display, you must deactivate **both** Automatic Speed Limiter and RSI.
- When the Automatic Speed Limiter function is activated but RSI is deactivated, no warnings are given from RSI. In this situation, settings for RSI cannot be adjusted either to be able to adjust settings as well as receive warnings, RSI must be activated.

Related information

Road Sign Information* (p. 355)

Road Sign Information and sign displays

Road Sign Information (RSI⁹⁷) displays road signs in different ways depending on the sign and situation.



Example 98 of registered speed information.

When RSI has registered a speed limit sign, the sign will be displayed as a symbol in the instrument panel and a RED marking will be shown in the speedometer's speed scale.

⁹⁷ Road Sign Information

⁹⁸ Road signs differ according to market – the illustrations shown here are just examples.

Signs for "School" and "Children playing"



If the warning sign⁹⁸ "School" or "Children playing" is included in the satellite navigator's map data⁹⁹, a symbol of this type will be displayed in the instrument panel.

Related information

Road Sign Information* (p. 355)

Road Sign Information and Sensus Navigation

If the vehicle is equipped with Sensus Navigation, speed-related information will be provided in the following situations:

- In cases where the speed limit is given indirectly, e.g. signs for highways or other major roads.
- If a previously detected speed sign is deemed to be no longer valid and no new sign has been passed.

(i) NOTE

In certain markets, the Road Sign Information function (RSI) is only available in combination with Sensus Navigation.

(i) NOTE

If a downloaded third-party app is used for navigation, there is no support for speed-related information.

Related information

Road Sign Information* (p. 355)

Road Sign Information with Speed Warning and Settings

The Speed Limit Warning sub-function for RSI¹⁰⁰ can be switched On or Off.

Speed Limit Warning alerts the driver if the vehicle's speed has exceeded the applicable speed limit or the preset Speed Limiter speed. The warning will be repeated once if the driver



does not slow down.

When Speed Warning is activated, the symbol for the current speed limit in the instrument panel¹⁰¹ will flash temporarily if that speed is exceeded.



The driver can be alerted if the vehicle is exceeding a detected speed limit and is approaching a speed camera.

 $^{^{\}rm 98}\,$ Road signs differ according to market – the illustrations shown here are just examples.

⁹⁹ Only vehicles with Sensus Navigation.

¹⁰⁰Road Sign Information

 $^{^{101}\}mbox{Road}$ signs differ according to market – the illustration shown here is just an example.

≪ Settings

Adjusting the Speed Warning limit

The driver can adjust the settings to be alerted at a higher speed than the posted speed limit.

To adjust the Speed Warning limit:

- Select Settings → My Car → IntelliSafe
 → Road Sign Information in the center
 display's Top view.
- 2. Mark Speed Limit Warning.
 - > The function is activated and a speed limit selector is displayed.
- Tap the up/down arrows on the screen to adjust the speed at which the Speed Warning will be given.



Please note that the set warning limit will not be used when a speed camera symbol is displayed in the instrument panel.

Audible alert On/Off

An audible alert can also be given along with the Speed Warning.

To adjust the audible alert settings:

Select Settings → My Car → IntelliSafe
 → Road Sign Information in the center
 display's Top view.

2. Select/deselect **Road Sign Audio Warning** to activate/deactivate the audible alert.

When **Road Sign Audio Warning** is activated, the driver will also be alerted if the vehicle is approaching a one-way/"no-entry" road or entrance.

Related information

Road Sign Information* (p. 355)

Activating/deactivating Speed Warning in Road Sign Information

To activate the **Speed Limit Warning** sub-function:

- Select Settings → My Car → IntelliSafe
 → Road Sign Information in the center
 display's Top view.
- 2. Mark Speed Limit Warning.
 - > The function is activated and a speed limit selector is displayed.

(see description for "selecting speed limit" in section "Road Sign Information with Speed warning and Settings")

Related information

- Road Sign Information* (p. 355)
- Road Sign Information with Speed Warning and Settings (p. 357)

Road Sign Information with speed camera information

Vehicles equipped with RSI¹⁰² and Sensus Navigation* can provide information on upcoming speed cameras in the instrument panel.



Speed camera information in the instrument panel 103.



If the vehicle exceeds a detected speed limit with the Speed Warning function activated, the driver is given a speed warning when the vehicle is approaching a speed camera if the navigation map

for the vehicle's current location contains information on speed cameras.

For more information on Speed Warnings in conjunction with speed cameras, see "Road Sign Information with Speed Warning and settings" and "Road Sign Information limitations".

(i)

NOTE

- For an audible alert to be provided if the speed is exceeded, the Speed Limit Warning function must be activated and the Road Sign Audio Warning subfunction must be On. Audible alerts are provided if the vehicle's speed exceeds the speed displayed by RSI in the instrument panel.
- Information about speed cameras on the navigation map is not available for all markets/areas.

Related information

- Road Sign Information* (p. 355)
- Road Sign Information with Speed Warning and Settings (p. 357)
- Road Sign Information limitations (p. 359)

Road Sign Information limitations

Road Sign Information (RSI¹⁰⁴) functionality may be reduced in certain situations.

RSI could have reduced functionality due to e.g.:

- faded road signs
- signs located in a curve in the road
- twisted or damaged signs
- signs positioned high above the road
- fully/partially obstructed or poorly positioned signs

¹⁰²Road Sign Information

¹⁰³Note: This illustration is general and details may vary depending on model and market/region.

¹⁰⁴Road Sign Information

- signs partially or fully covered by frost, snow and/or dirt
 - digital road maps¹⁰⁵ that are outdated, incorrect or do not contain speed information¹⁰⁶.

(i) NOTE

Certain types of bike carriers that are connected to the trailer socket may be interpreted as a connected trailer by the RSI function. In such cases, the instrument panel may indicate incorrect speed information.

i NOTE

The function uses the vehicle's camera unit, which has some general limitations – see the section "Camera unit limitations".

Related information


Road Sign Information* (p. 355)

Driver Alert Control


The Driver Alert Control (DAC) function is designed to help capture the driver become aware of erratic behavior, e.g. if the driver is distracted or showing signs of fatigue.

The objective of DAC is to detect slowly deteriorating driving behavior and is primarily intended to be used on major roads. The function is not intended for use in city traffic.

DAC is activated when the vehicle's speed exceeds 65 km/h (40 mph) and remains active as long as speeds are above 60 km/h (37 mph).



A camera monitors the traffic lane's marker lines and compares the direction of the road with the driver's movements of the steering wheel.





If the driving behavior becomes noticeably erratic, the driver will be alerted by this symbol in the instrument panel and the message **Time for a break** soon?

If driving behavior does not improve but instead becomes even more erratic, the driver will be alerted by the same symbol in the instrument panel, an audible signal and the message **Time for a break**.

If the **Rest Stop Guidance** function is activated in Sensus Navigation* when the **Time for a break** warning is given, suggestions will also be provided for suitable places to take a break.

¹⁰⁵Vehicles equipped with Sensus Navigation.

¹⁰⁶Map data and speed information is not available for all areas.

The warnings will be repeated after a short time if driving behavior does not improve.

- The Driver Alert Control function is supplementary driver support intended to facilitate driving and help make it safer – it cannot handle all situations in all traffic, weather and road conditions.
- Driver Alert Control must not be used to extend a period of driving. The driver should plan in breaks at regular intervals and make sure they are well rested.
- Driver Alert Control is not a substitute for the driver's attention and judgment. The driver is always responsible for ensuring the vehicle is driven in a safe manner, at the appropriate speed, with an appropriate distance to other vehicles, and in accordance with current traffic rules and regulations.

♠ WARNING

An alarm from Driver Alert Control should be taken very seriously since a sleepy driver is often not aware of their own condition.

If the alarm sounds or you feel fatigued:

• Stop the vehicle safely as soon as possible and rest.

Studies have shown that it is just as dangerous to drive while tired as it is to drive under the influence of alcohol or other stimulants.

Related information

- Activating/deactivating Driver Alert Control (p. 361)
- Selecting guidance to a rest area if the Driver Alert Control warning has been given (p. 362)
- Driver Alert Control limitations (p. 362)

Activating/deactivating Driver Alert Control

The Driver Alert Control (DAC) function can be activated/deactivated.

On/Off

To change DAC settings:

- Tap **Settings** in the center display's Top view.
- Select My Car → IntelliSafe → Driver Alert Control.
- Select/deselect Alertness Warning to activate/deactivate DAC.

Related information

Driver Alert Control (p. 360)

Selecting guidance to a rest area if the Driver Alert Control warning has been given

The Rest Stop Guidance function can be switched on or off.

When the guide is activated, it will automatically display suggestions for a suitable place to take a break if the DAC warning is given.

To select Rest Stop Guidance:

- Tap **Settings** in the center display's Top view.
- Select My Car → IntelliSafe → Driver Alert Control.
- Select/deselect Rest Stop Guidance to activate/deactivate the function.

Related information

Driver Alert Control (p. 360)

Driver Alert Control limitations

Driver Alert Control (DAC) functionality may be reduced in certain situations.

In certain situations, the system may provide a warning even if it has not detected a change in driving behavior, e.g.:

- in strong crosswinds
- on grooved road surfaces.

Λ

WARNING

In certain cases, driving behavior might not be affected despite the driver's fatigue – when using the Pilot Assist function – resulting in the driver not getting a warning from DAC.

It is therefore very important to always stop and take a break at the slightest sign of fatigue, regardless of whether the DAC function has issued a warning or not.



NOTE

The function uses the vehicle's camera unit, which has some general limitations – see the section "Camera unit limitations".

Related information


• Driver Alert Control (p. 360)

Lane Keeping Aid (LKA¹⁰⁷) is designed to actively steer the vehicle on freeways, highways and other major roads to help the driver reduce the risk of the vehicle unintentionally veering out of the lane.

Lake Keeping Assistance steers the vehicle back into the lane and/or alerts the driver using vibrations in the steering wheel.

Lane Keeping Aid is active at speeds between 65-200 km/h (40-125 mph) on roads with clearly visible traffic lane marker lines.


On narrow roads, the function may be unavailable and go into standby mode. The function will become available again when the road becomes sufficiently wide.




A camera monitors the road/traffic lane's marker lines.

Lane Keeping Aid

¹⁰⁷Lane Keeping Aid



Lane Keeping Aid steers the vehicle back into its lane.



Lane Keeping Aid alerts the driver using vibrations in the steering wheel 108.

Depending on the settings used, Lane Keeping Aid functions in different ways:

- With Assist¹⁰⁹ activated: When the vehicle approaches a lane marker line, LKA will actively steer the vehicle back into the lane using light pressure on the steering wheel.
- With Warning 109 activated: If the vehicle is about to move over a lane marker line, the driver will be alerted by vibrations in the steering wheel.

(i) NOTE

When the direction indicator is activated, the Lane Keeping Aid does not provide any warning or intervene with steering.


⚠ WARNING

- The Lane Keeping Aid function is supplementary driver support intended to help improve driving safety it cannot handle all situations in all traffic, weather and road conditions.
- The function is not a substitute for the driver's attention and judgment. The driver is always responsible for ensuring the vehicle is driven in a safe manner, at the appropriate speed, with an appropriate distance to other vehicles, and in accordance with current traffic rules and regulations.

¹⁰⁸The steering wheel vibrations vary. The more time the vehicle is over the lane marker line, the longer the vibrations.

¹⁰⁹See "LKA assistance options" under "Activating/deactivating Lane Keeping Aid".

Lane Keeping Aid does not intervene



Lane Keeping Aid does not intervene in sharp inside curves.

In certain cases, such as when a turn signal is used or when "straightening out" an inside curve, Lane Keeping Aid will not provide steering assistance or alerts.

Related information

- Steering assistance with Lane Keeping Aid (p. 364)
- Lane Keeping Aid limitations (p. 365)
- Activating/deactivating Lane Keeping Aid (p. 365)
- Selecting type of assistance for Lane Keeping Aid (p. 365)
- Lane Keeping Aid symbols and messages (p. 367)

 Lane Keeping Aid symbols in the instrument panel (p. 369)

Steering assistance with Lane Keeping Aid

The LKA¹¹⁰ steering assistance function only functions if the driver's hands are on the steering wheel, which the system continuously monitors.



If the driver does not keep his/her hands on the steering wheel, the driver display shows this symbol combined with a message, which prompts the driver to actively steer the car:

Lane Keeping Aid - Apply steering

If the driver does not begin to steer the vehicle, the symbol will be displayed again, accompanied by an audible signal and this message:

 Lane Keeping Aid - Standby until steering applied

If the driver still does not begin to steer the vehicle, LKA¹¹⁰ will go into standby mode. The function will remain unavailable until the driver begins actively steering the vehicle again.

Related information

Lane Keeping Aid (p. 362)

¹¹⁰Lane Keeping Aid

Activating/deactivating Lane Keeping Aid

The Lane Keeping Aid (LKA¹¹¹) function can be switched **On** or **Off**.

On/Off



Press the **Lane Keeping Aid** button in the center display's Function view.

- GREEN button indicator light LKA is activated.
- GRAY button indicator light LKA is deactivated.

Related information

Lane Keeping Aid (p. 362)

Selecting type of assistance for Lane Keeping Aid

The driver can determine what types of assistance LKA¹¹² should provide if the vehicle veers from its lane.

- Select Settings → My Car → IntelliSafe in the center display's Top view.
- Under Lane Keeping Aid Mode, select what assistance LKA should provide:
 - Assist the driver will receive steering assistance but no warning.
 - **Both** the driver will receive both steering assistance and a warning.
 - Warning the driver will only receive a warning.

Related information

Lane Keeping Aid (p. 362)

Lane Keeping Aid limitations

In certain demanding driving conditions, Lane Keeping Aid may not be able to properly assist the driver. In these situations, it is recommended that the function be deactivated.

Examples of such situations include:

- road work
- winter driving conditions
- poor road surfaces
- a very sporty driving style
- bad weather with reduced visibility
- roads with indistinct or no lane markings
- sharp edges or lines other than the lane's side markings
- when the power steering works at reduced power - e.g. during cooling due to overheating (see section "Speed-dependent steering force").



The function uses the vehicle's camera unit, which has some general limitations – see the section "Camera unit limitations".

¹¹¹Lane Keeping Aid

¹¹²Lane Keeping Aid

DRIVER SUPPORT

◀ Related information

- Lane Keeping Aid (p. 362)
- Speed-dependent steering wheel resistance (p. 270)

Lane Keeping Aid symbols and messages

A number of symbols and messages related to Lane Keeping Aid LKA¹¹³ may be displayed in the instrument panel.

Some examples of symbols and messages are shown in the table below.

Symbol	Message	Meaning
(li	Driver support system Reduced functionality Service required	The system is not functioning as intended. Contact a workshop – an authorized Volvo workshop is recommended.
(i)	Windscreen sensor Sensor blocked, see Owner's manual	The camera's ability to detect the lane in front of the vehicle is reduced.
	Lane Keeping Aid Apply steering	LKA's steering assistance is disabled when the driver's hands are not on the wheel. Follow the instructions and steer the vehicle.
	Lane Keeping Aid Standby until steering applied	LKA will go into standby mode until the driver begins steering the vehicle again.

¹¹³Lane Keeping Aid

DRIVER SUPPORT

A text message can be erased by briefly pressing the O button in the center of the right-side steering wheel keypad.

If the message persists: Contact a workshop – an authorized Volvo workshop is recommended.

Related information

• Lane Keeping Aid (p. 362)

Lane Keeping Aid symbols in the instrument panel

Lane Keeping Aid (LKA¹¹⁴) uses symbols in the instrument panel for various situations.



Some examples of symbols and descriptions of the situations in which they might appear are provided below.

Available



Available - the marker lines in the symbol are WHITE.

Lane Keeping Aid is able to detect one or both of the traffic lane's side marker lines.

Unavailable



Unavailable – the marker lines in the symbol are GRAY.

Lane Keeping Aid is unable to detect the lane marker lines, the vehicle's speed is too low or the road is too narrow.

Steering/warning indicator



Steering/warning – the marker lines in the symbol are COLORED.

Indicates that the Lane Keeping Aid system is alerting the driver and/or attempting to steer the vehicle back into the lane.

Related information

Lane Keeping Aid (p. 362)

¹¹⁴Lane Keeping Aid

Steering assistance at risk of collision

The Collision avoidance assistance function is intended to help the driver reduce the risk of the vehicle inadvertently veering from the traffic lane and/or colliding with another vehicle or obstacle by actively steering the vehicle back into the lane and/or swerving out of the way.

Collision avoidance assistance consists of three sub-functions:

- Run-Off Mitigation with steering assistance
- Steering assistance during collision risks from oncoming traffic
- Steering assistance during collision risks from behind*

After the system has automatically intervened, this text message will appear in the instrument panel:

 Collision avoidance assistance – Automatic intervention



NOTE

It is always the driver who must decide how much the vehicle should be in control – the vehicle can never take command.

Related information

- Activating/deactivating steering assistance during collision risks (p. 370)
- Symbols and messages for steering assistance during collision risks (p. 378)
- Run-Off Mitigation with steering assistance (p. 371)
- Run-Off Mitigation with steering assistance levels (p. 371)
- Activating/deactivating Run-Off Mitigation with steering assistance (p. 372)
- Limitations of Run-Off Mitigation with steering assistance (p. 372)
- Steering assistance during collision risks from oncoming traffic (p. 373)
- Activating/deactivating Steering assistance during collision risks with oncoming vehicles (p. 374)
- Limitations of steering assistance during collision risks from oncoming traffic (p. 374)
- Steering assistance during collision risks from behind* (p. 375)
- Activating/deactivating Steering assistance during collision risks from behind* (p. 376)
- Limitations of steering assistance during collision risks from behind (p. 376)

Activating/deactivating steering assistance during collision risks

The driver can choose to have this function **On** or **Off**.

To switch off the function:

- Select Settings → My Car → IntelliSafe in the center display's Top view.
- 2. Deselect Collision avoidance assistance.
 - > The function will be deactivated.



NOIE

When the **Collision avoidance assistance** function is deactivated, all subfunctions of the following are deactivated:

- Steering assistance at risk of run-off
- Steering assistance at risk of head-on collision
- Steering assistance during collision risks from behind*

Although it is possible to deactivate the function, the driver is advised to keep it activated since it can help improve driving safety in most cases.

Related information

 Steering assistance at risk of collision (p. 370)

Run-Off Mitigation with steering assistance

This sub-function is intended to help reduce the risk of the vehicle inadvertently running off the road by actively steering the vehicle back onto the road.

The function is active at speeds between 65-140 km/h (40-87 mph) on roads with clearly visible traffic lane markings/lines.

The system uses a camera to monitor the edges of the road and the painted side marker lines. If the vehicle is about to cross the edge of the road, the function will attempt to steer the vehicle back onto the road. If this is not sufficient to keep the vehicle on the road, the brakes will also be applied.

However, the function will **not** provide either steering assistance or braking if the turn signal is used. The function will also not be activated if it detects that the driver is actively operating the vehicle.

After the system has automatically intervened, this text message will appear in the instrument panel:

 Collision avoidance assistance – Automatic intervention

★ WARNING

- The "Steering assistance at risk of runoff" subfunction is supplementary driver support intended to help improve driving safety – it cannot handle all situations in all traffic, weather and road conditions.
- The function cannot detect barriers, rails or similar obstacles at the side of the road.
- "Steering assistance at risk of run-off" is not a substitute for the driver's attention and judgment. The driver is always responsible for ensuring the vehicle is driven in a safe manner, at the appropriate speed, with an appropriate distance to other vehicles, and in accordance with current traffic rules and regulations.

Related information


 Steering assistance at risk of collision (p. 370)

Run-Off Mitigation with steering assistance levels

This function has two activation levels for intervention:


- Steering assistance only
- Steering assistance with braking

Steering assistance only



Intervention with steering assistance.

◀ Steering assistance with braking



Intervention with steering assistance and braking.

Braking intervention assists in situations where steering assistance alone is not sufficient. Braking force is automatically adapted according to the situation at the moment the vehicle begins to run off the road.

Related information

 Steering assistance at risk of collision (p. 370)

Activating/deactivating Run-Off Mitigation with steering assistance

The driver can choose to have this function **On** or **Off**.

To switch off the function:

- Select Settings → My Car → IntelliSafe in the center display's Top view.
- 2. Deselect Collision avoidance assistance.
 - > The function will be deactivated.

i NOTE

When the **Collision avoidance assistance** function is deactivated, all subfunctions of the following are deactivated:

- Steering assistance at risk of run-off
- Steering assistance at risk of head-on collision
- Steering assistance during collision risks from behind*

Although it is possible to deactivate the function, the driver is advised to keep it activated since it can help improve driving safety in most cases.

Related information

 Steering assistance at risk of collision (p. 370)

Limitations of Run-Off Mitigation with steering assistance

In certain demanding driving conditions, the function may not be able to properly assist the driver. In these situations, it is recommended that it is turned off.

Examples of such situations include:

- road work
- winter driving conditions
- narrow roads
- poor road surfaces
- a very sporty driving style
- bad weather with reduced visibility
- roads with indistinct or no lane markings
- sharp edges or lines other than the lane's side markings
- when the power steering works at reduced power - e.g. during cooling due to overheating (see section "Speed-dependent steering force").

(i) NOTE

The function uses the vehicle's camera unit, which has some general limitations – see the section "Camera unit limitations".

i

NOTE


The function uses the vehicle's radar unit, which has some general limitations – see the section "Radar unit limitations".

Related information

- Steering assistance at risk of collision (p. 370)
- Speed-dependent steering wheel resistance (p. 270)

Steering assistance during collision risks from oncoming traffic

This sub-function can help assist a distracted driver who has not noticed that the vehicle is veering into oncoming traffic.



The function provides assistance by swerving your vehicle back into your own lane.

- Oncoming vehicles
- Own vehicle

The function is active at speeds between 60-140 km/h (37-87 mph) on roads with clearly visible traffic lane markings/lines.

If your vehicle is starting to veer from your own lane and a vehicle is approaching from the opposite direction, this function can help the driver steer the vehicle back into its own lane.

However, the function will **not** provide steering assistance if the turn signal is used. The function will also not be activated if it detects that the driver is actively operating the vehicle.

After the system has automatically intervened, this text message will appear in the instrument panel:

Collision avoidance assistance –
Automatic intervention

↑ WARNING

- The "Steering assistance at risk of headon collision" subfunction is supplementary driver support intended to improve driving safety – it cannot handle all situations in all traffic, weather and road conditions.
- Pilot Assist is only activated if there is a high risk of collision – you must therefore never wait for the function to intervene.
- The function is not a substitute for the driver's attention and judgment. The driver is always responsible for ensuring the vehicle is driven in a safe manner, at the appropriate speed, with an appropriate distance to other vehicles, and in accordance with current traffic rules and regulations.

Related information

 Steering assistance at risk of collision (p. 370)

Activating/deactivating Steering assistance during collision risks with oncoming vehicles

The driver can choose to have this function **On** or **Off**.

To switch off the function:

- Select Settings → My Car → IntelliSafe in the center display's Top view.
- 2. Deselect Collision avoidance assistance.
 - > The function will be deactivated.

(i) NOTE

When the **Collision avoidance assistance** function is deactivated, all subfunctions of the following are deactivated:

- Steering assistance at risk of run-off
- Steering assistance at risk of head-on collision
- Steering assistance during collision risks from behind*

Although it is possible to deactivate the function, the driver is advised to keep it activated since it can help improve driving safety in most cases.

Related information

 Steering assistance at risk of collision (p. 370)

Limitations of steering assistance during collision risks from oncoming traffic

The function may have limited functionality in certain situations and not intervene, e.g.:

- for smaller vehicles such as motorcycles
- on roads that do not have clear lane markings
- if more than half of your vehicle has moved into the adjacent lane
- outside the speed range 60-140 km/h (37-87 mph)
- when the power steering works at reduced power - e.g. during cooling due to overheating (see section "Speed-dependent steering force").

Functionality may also be reduced in other situations, such as:

- road work
- winter driving conditions
- narrow roads
- poor road surfaces
- a very sporty driving style
- bad weather with reduced visibility.

In these demanding driving conditions, the function may not be able to properly assist the driver. In these situations, it is recommended that it is turned off.

i

NOTE

The function uses the vehicle's camera unit, which has some general limitations – see the section "Camera unit limitations".

i NOTE


The function uses the vehicle's radar unit, which has some general limitations – see the section "Radar unit limitations".

Related information

- Steering assistance at risk of collision (p. 370)
- Speed-dependent steering wheel resistance (p. 270)

Steering assistance during collision risks from behind*

If you become distracted and do not notice your vehicle starting to veer out of the lane while another vehicle is approaching from behind or is in your vehicle's blind spot, this sub-function can help provide assistance.



The function provides assistance by steering your vehicle back into your own lane.

Another vehicle in blind spot zone



If your vehicle is beginning to veer out of your lane while another vehicle is in your blind spot or another vehicle is rapidly approaching in the next lane, this function can help the driver steer the vehicle back into its own lane.

Even if the driver intentionally changes lanes using a turn signal without noticing another vehi-

cle approaching, the function can provide assistance.

The function is active at speeds between 60-140 km/h (37-87 mph) on roads with clearly visible traffic lane markings/lines.

After the system has automatically intervened, this text message will appear in the instrument panel:

 Collision avoidance assistance – Automatic intervention

- The "Steering assistance at risk of rearend collision" subfunction is supplementary driver support intended to improve driving safety – it cannot handle all situations in all traffic, weather and road conditions.
- Pilot Assist is only activated if there is a high risk of collision – you must therefore never wait for the function to intervene.
- The function is not a substitute for the driver's attention and judgment. The driver is always responsible for ensuring the vehicle is driven in a safe manner, at the appropriate speed, with an appropriate distance to other vehicles, and in accordance with current traffic rules and regulations.

Related information

 Steering assistance at risk of collision (p. 370)

Activating/deactivating Steering assistance during collision risks from behind*

The driver can choose to have this function **On** or **Off**.

To switch it off:

- Select Settings → My Car → IntelliSafe in the center display's Top view.
- 2. Deselect Collision avoidance assistance.
 - > The function will be deactivated.

(i) NOTE

When the **Collision avoidance assistance** function is deactivated, all subfunctions of the following are deactivated:

- Steering assistance at risk of run-off
- Steering assistance at risk of head-on collision
- Steering assistance during collision risks from behind*

Although it is possible to deactivate the function, the driver is advised to keep it activated since it can help improve driving safety in most cases.

Related information

 Steering assistance at risk of collision (p. 370)

Limitations of steering assistance during collision risks from behind

The function may have limited functionality in certain situations and not intervene, e.g.:

- for smaller vehicles such as motorcycles
- if more than half of your vehicle has moved into the adjacent lane
- on roads/lanes with indistinct or no side lane markings
- outside the speed range 60-140 km/h (37-87 mph)
- when the power steering works at reduced power - e.g. during cooling due to overheating (see section "Speed-dependent steering force").

Functionality may also be reduced in other situations, such as:

- road work
- winter driving conditions
- narrow roads
- poor road surfaces
- a very sporty driving style
- bad weather with reduced visibility.

In these demanding driving conditions, the function may not be able to properly assist the driver. In these situations, it is recommended that it is turned off.

i NOTE

The function uses the vehicle's camera unit, which has some general limitations – see the section "Camera unit limitations".

i NOTE

The function uses the vehicle's radar unit, which has some general limitations – see the section "Radar unit limitations".

In addition to the camera and radar sensor, the function also uses the vehicle's rearward-facing radar, which has certain general limitations the driver should be aware of. See additional information in the section "BLIS limitations".

Related information

- Steering assistance at risk of collision (p. 370)
- Speed-dependent steering wheel resistance (p. 270)

Symbols and messages for steering assistance during collision risks

A number of symbols and messages related to the function may be displayed in the instrument panel.

Some examples of symbols and messages are shown in the table below.

Symbol	Message	Meaning
	Collision avoidance assistance Automatic intervention	When the function is activated, a message will appear to alert the driver.
(Ii)	Windscreen sensor Sensor blocked, see Owner's manual	The camera's ability to detect the lane in front of the vehicle is reduced.

A text message can be erased by briefly pressing the \bigcirc button in the center of the right-side steering wheel keypad.

If the message persists: Contact a workshop – an authorized Volvo workshop is recommended.

Related information

• Steering assistance at risk of collision (p. 370)

Park Assist*

The Park Assist function can help the driver when maneuvering in tight spaces by indicating distances to obstacles using audible signals and graphics in the center display.



Display view showing obstacle zones and sensor sectors

The center display shows an overview of the vehicle in relation to objects that have been detected.

The marked sector indicates where the obstacle is located. The closer the vehicle symbol is to a marked sector, the closer the detected obstacle is to your vehicle.

The audible signals will also speed up the closer the obstacle is to the vehicle. The volume of the audio system will be automatically lowered.

Audible signals for obstacles in front and to the sides of the vehicle are active when the vehicle is

moving but will cease after the vehicle has been stationary for approx. 2 seconds. Audible signals for obstacles behind the vehicle will remain active even when the vehicle is stationary.

If a detected obstacle is within 30 cm (1 ft) from the front or rear of the vehicle, the tone will become constant and the active sensor's field closest to the vehicle symbol will be filled in.

The volume of the Park Assist audible signals can be adjusted while the signal is being given using the >II knob or in the center display's Top view under **Settings**.

(\mathbf{i})

NOTE

 Acoustic warnings are only given for objects directly in front of the vehicle's path.

↑ WARNING

- The Parking Assist function is supplementary driver support intended to facilitate driving and help make it safer it cannot handle all situations in all traffic, weather and road conditions.
- The parking sensors have dead/blind spots where objects cannot be detected.
- Pay particular attention to people and animals near the vehicle.
- Parking Assist is not a substitute for the driver's attention and judgment. The driver is always responsible for ensuring the vehicle is driven in a safe manner, at the appropriate speed, with an appropriate distance to other vehicles, and in accordance with current traffic rules and regulations.


Related information

- Park Assist front, rear and sides (p. 380)
- Activating/deactivating Park Assist (p. 381)
- Park Assist limitations (p. 381)
- Recommended maintenance for Park Assist (p. 382)
- Park Assist symbols and messages (p. 383)

Park Assist front, rear and sides

Park Assist has different parameters depending on which part of the vehicle is approaching an obstacle.

Back



Note: This illustration is general and details may vary depending on model.

The rear sensors will be activated if the vehicle begins rolling backward or if reverse gear is engaged.

The distance monitored begins approx. 1.5 meters (5 feet) behind the vehicle.


The rear sensors will be automatically deactivated if the vehicle is backing up with a trailer attached.

(i)

NOTE

When reversing with e.g. a trailer or bike carrier on the trailer hitch – without Volvo original trailer cables – the Parking Assist system may have to be turned off manually to prevent the sensors from reacting to these.


Side sensors



Park Assist's side sensors are automatically activated when the engine is started. They are active at speeds below 10 km/h (6 mph).

The distance monitored begins approx. 30 cm (1 ft) from the sides. The audible signal for obstacles along the sides of the vehicle is emitted from the side speakers.

Front camera



Note: This illustration is general and details may vary depending on model.

Park Assist's front sensors are automatically activated when the engine is started. The front sensors are active at speeds below 10 km/h (6 mph).

The distance monitored begins approx. 80 cm (2.5 ft) in front of the vehicle.



NOTE

The Parking Assist system is deactivated when the parking brake is applied or when ${\bf P}$ is selected on vehicles with automatic transmission.

! CAUTION

When installing auxiliary lights: Make sure these do not obscure the sensors – the auxiliary lights could be perceived as an obstacle.

Related information

• Park Assist* (p. 379)

Activating/deactivating Park Assist

The Park Assist Pilot function can be activated/deactivated.

On/Off

Park Assist's front and side sensors are automatically activated when the engine is started. The rear sensors are activated if the vehicle is moving backward or reverse gear is engaged.



The function can be activated/ deactivated in the center display's Function view.

- Tap the Park Assist button in Function view.
 - > The Park Assist Pilot indicator light shows the status of the function: GREEN (on) or GRAY (off).

In vehicles equipped with Park Assist Camera, Park Assist can also be activated/deactivated from the relevant camera view.

Related information

Park Assist* (p. 379)

Park Assist limitations

Park Assist may not be able to detect all conditions in all situations and functionality may therefore be limited in certain cases.

The driver should be aware of the following limitations for Park Assist:

⚠ WARNING



Be extra cautious when reversing if this symbol is shown when a trailer, bike carrier or similar is attached and electrically connected to the vehicle.

The symbol indicates that the rear parking assist sensors are **deactivated** and will not warn of any obstacles.

(!) CAUTION

Objects such as chains, thin and glossy poles or low obstacles may end up in the "signal shadow" and then go temporarily undetected by the sensors – the pulsating tone may then unexpectedly stop instead of becoming a constant tone as expected.

The sensors cannot detect high objects, such as protruding ramps.

 In such situations, pay extra attention and maneuver/drive the vehicle very slowly or stop the current parking maneuver – there may be a high risk of damage to the vehicle or other objects since information from the sensors is not always reliable in such situations.

(!) CAUTION

In some circumstances, the Park Assist System may produce false warnings due to external sound sources with the same ultrasonic frequencies as those the system works with.

Examples of such sources are horns, wet tires on asphalt, pneumatic brakes, exhaust noise from motorcycles, etc.

(i) NOTE


When a trailer hitch is configured with the vehicle electrical system, the trailer hitch protrusion is included when the function measures the distance to objects behind the vehicle.

Related information

Park Assist* (p. 379)

Recommended maintenance for Park Assist

For Park Assist to function optimally, its sensors must be cleaned regularly with water and car washing detergent.



Location of the Park Assist sensors 115.

(i) NOTE

Dirt, ice and snow covering the sensors could cause false warnings, reduced function, or no function.

Related information

Park Assist* (p. 379)

¹¹⁵Note: This illustration is general and details may vary depending on model.

Park Assist symbols and messages

Symbols and messages for the Park Assist may be displayed in the instrument panel and/or the center display.

Some examples of symbols and messages are shown in the table below.

Symbol	Message	Meaning
Pw		The rear Park Assist sensors are turned off and no acoustic warnings for obstacles/objects will be provided.
	Park Assist System	One or more of the sensors are blocked. Check and clean/remove the obstacle as soon as pos-
	Sensors blocked, cleaning needed	sible.
	Park Assist System	The system is not functioning as intended. Contact a workshop – an authorized Volvo workshop
	Unavailable Service required	is recommended.

A text message can be erased by briefly pressing the O button in the center of the right-side steering wheel keypad.

If the message persists: Contact a workshop – an authorized Volvo workshop is recommended.

Related information

Park Assist* (p. 379)

Park Assist Camera*

The Park Assist Camera can help provide the driver when maneuvering in tight spaces by alerting the driver to obstacles using the camera screen and graphics in the center display. The Park Assist Camera is a support function that is automatically activated when reverse gear is engaged. It can also be started manually from the center display.



Example camera view¹¹⁶.

- 1 Zoom¹¹⁷ zoom in/out
- 2 360° view* activate/deactivate all cameras
- R PAS* activate/deactivate Parking Assist
- Lines activate/deactivate trajectory lines

- **Towbar*** activate/deactivate trajectory lines for towbar*118
- 6 CTA* activate/deactivate Cross Traffic Alert

⚠ WARNING

- The Parking Camera function is supplementary driver support intended to facilitate driving and help make it safer it cannot handle all situations in all traffic, weather and road conditions.
- The parking cameras have dead/blind spots where objects cannot be detected.
- Pay particular attention to people and animals near the vehicle.
- Objects/obstacles may be closer to the vehicle than they appear on the screen.
- The parking cameras are not a substitute for the driver's attention and judgment.
 The driver is always responsible for ensuring the vehicle is driven in a safe manner, at the appropriate speed, with an appropriate distance to other vehicles, and in accordance with current traffic rules and regulations.

Related information

- Park Assist Camera views (p. 385)
- Park Assist Camera trajectory lines (p. 386)
- Sensor field from Park Assist for Park Assist Camera (p. 388)
- Starting the Park Assist Camera (p. 389)
- Park Assist Camera limitations (p. 389)
- Recommended maintenance of the Park Assist Camera (p. 391)
- Recommended maintenance of the Park Assist Camera (p. 391)
- Park Assist Camera symbols and messages (p. 392)

¹¹⁶The illustration is generic - details may vary according to vehicle model.


¹¹⁷The trajectory lines will not be displayed when zooming in.

¹¹⁸Not available in all markets

Park Assist Camera views

PAC can display a 360° panoramic view as well as separate views for each of the other cameras: rear, front, left and right.

360° view*



The location of the cameras and their approximate fields of vision.

The **360° view** function activates all Park Assist Cameras and all four sides of the vehicle are shown in the center display at once to help the driver see what is around the vehicle while maneuvering at low speeds.

From the 360° view, each camera view can be activated separately:

 Tap the screen to select the camera's field of vision, e.g. in the area in front/above the front camera.



The active cameras will be indicated by a camera symbol on the vehicle symbol in the center display.

If the vehicle is equipped with **Park Assist System***, the dis-

tance to detected obstacles will be illustrated by fields in different colors.

The cameras can be activated automatically or manually. See "Starting the Park Assist Camera" for more information.

Back



The rear camera¹¹⁹ is located above the license plate.

The rear camera shows a wide area behind the vehicle. On certain models, part of the bumper and the towbar (if installed) may be visible.

Objects on the center display may appear to be leaning slightly. This is normal.

Front camera



The front Park Assist Camera¹²⁰ is located in the grille.

The front camera can be useful when pulling out from areas with limited visibility, such as a driveway surrounded by a hedge. The front camera is active at speeds up to 25 km/h (16 mph) and is automatically turned off when the vehicle exceeds this speed.

If the vehicle does not reach a speed of 50 km/h (30 mph) and speed falls below 22 km/h (14 mph) within 1 minute after the front camera turns off, the camera will be reactivated.

¹¹⁹Note: This illustration is general and details may vary depending on model.

¹²⁰Note: This illustration is general and details may vary depending on model.

44 Side cameras



The side cameras 120 are located in the rearview mirrors.

The side cameras can show views along each side of the vehicle.

Related information

Park Assist Camera* (p. 384)

Park Assist Camera trajectory lines

The Park Assist Camera uses trajectory lines and fields on the screen to indicate the vehicle's position in relation to its immediate surroundings.



Example 121 of trajectory lines.

The trajectory lines show the anticipated trajectory for the vehicle's outermost dimensions based on the current position of the steering wheel to

help simplify parallel parking, backing into tight spaces or attaching a trailer.

The lines on the screen are projected as if they were painted lines on the ground behind the vehicle and are directly affected by the way in which the steering wheel is turned. This enables the driver to see path the vehicle will take, even if he/she turns the steering wheel.

These lines also indicate the outermost limits that any object (towbar, rearview mirrors, corners of the body, etc.) extends out from the vehicle.

(i) NOTE

- When reversing with a trailer that is not electrically connected to the vehicle, the screen guide lines show the path the vehicle will take - not the trailer.
- The screen does not show guide lines when a trailer is electrically connected to the vehicle's electrical system.
- Guide lines are not shown when zooming in.


¹²⁰Note: This illustration is general and details may vary depending on model.

¹²¹The illustration is generic - details may vary according to vehicle model.

! CAUTION

- Bear in mind that when the rearward camera view is selected, the screen only shows the area behind the vehicle – pay attention to the sides and front of the vehicle when steering while reversing.
- The same applies to the reverse pay attention to what is happening with the rear parts of the vehicle when the front camera view is selected.
- Note that the guide lines show the shortest path pay extra attention to ensure that the vehicle sides do not come in contact with/travel over anything when steering while driving forward or that the vehicle front moves toward/over anything when steering while reversing.

Trajectory lines in 360° view*



360° view with trajectory lines 121.

In the 360° view, trajectory lines are shown behind, in front of, or to the sides of the vehicle, depending on the direction of travel.

- When driving forward: Front lines
- When backing up: Side lines and rear lines.

When the front or rear camera is selected, the trajectory lines will be shown regardless of the vehicle's direction of travel.

With a side camera selected, the trajectory lines will only be shown if the vehicle is backing up.

Trajectory lines for a towbar*



Towbar with trajectory line 121.

1 Towbar - activate trajectory lines for towbar.

2 Zoom - zoom in/out.

The camera can help make hitching a trailer easier by showing an anticipated trajectory line for the towbar's path toward the trailer.

¹²¹The illustration is generic - details may vary according to vehicle model.

1. Tap Towbar (1).

The trajectory line for the towbar's anticipated path toward the vehicle will appear and the vehicle's trajectory lines will disappear.

Trajectory lines cannot be displayed for both the vehicle and the towbar at the same time.

- 2. Tap **Zoom** (2) for a close-up view for more precise maneuvering.
 - > The camera will zoom in.

Related information

Park Assist Camera* (p. 384)

Sensor field from Park Assist for Park Assist Camera

If the vehicle is equipped with Park Assist, distances will be shown in the 360° view with colored fields for each sensor that has detected an obstacle.

Front and rear sensors



The screen can display colored sensor fields on the vehicle symbol 122.

The front and rear fields change colors (from yellow to orange to red) as the vehicle moves closer to an obstacle.

Front and rear field colors	Distance in meters (feet)
Yellow	0.6-1.5 (2.0-4.9)
Orange	0.4-0.6 (1.3-2.0)
Red	0-0.4 (0-1.3)

Side sensor fields

The side sensor fields will only be shown in orange.

Side field color	Distance in meters (feet)
Orange	0-0.3 (0-1.0)

Related information

Park Assist Camera* (p. 384)

¹²²The illustration is generic - details may vary according to vehicle model.

Starting the Park Assist Camera

The Park Assist Camera starts automatically when reverse gear is engaged or can be started manually using one of the center display's function buttons.

Camera view when backing up

When reverse gear is engaged, the screen shows the rear view¹²³.

Camera view when manually starting the camera



Start the Park Assist Camera using this button in the center display's Function view.

The screen will first show the most recently used camera view. However, each time the

engine is started, the previous side view will be replaced by the 360° view and a previously displayed zoomed-in rear view will be replaced by the regular rear view.

Automatically deactivating the camera

Front view switches off when the vehicle's speed reaches 25 km/h (16 mph) to help avoid distracting the driver. It will be automatically reactivated if the vehicle's speed falls below 22 km/h (14 mph) within 1 minute as long as the vehicle's speed has not exceeded 50 km/h (31 mph).

Other camera views switch off at 15 km/h (9 mph) and are not reactivated.

Related information

• Park Assist Camera* (p. 384)

Park Assist Camera limitations

The Park Assist Camera may not be able to detect all conditions in all situations and functionality may therefore be limited.

The driver should be aware of the following limitations for the Park Assist Camera:



Be extra cautious when reversing if this symbol is shown when a trailer, bike carrier or similar is attached and electrically connected to the vehicle.

The symbol indicates that the rear parking assist sensors are **deactivated** and will not warn of any obstacles.



A bike carrier and other accessories mounted on the rear of the vehicle can obscure the camera's view.

¹²³In Canada, it is also possible to select the 360° view.

◆ Blind sectors



There are "blind" sectors between the cameras' fields of vision.

With 360° view selected, objects/obstacles may not be detected if they are located in the "joints" where the edges of the individual camera views meet.

Even if it seems as though only a fairly small section of the screen image is obstructed, this may mean that a relatively large sector is hidden and obstacles there may not be detected until they are very near the vehicle.

Defective camera



If a camera sector is dark and contains this symbol, this indicates that the camera is not functioning properly.

See the following illustration for an example.



The vehicle's left-side camera is malfunctioning.

Dark camera sector

A dark camera sector may also be displayed in the following situations, but **without** the defective camera symbol:

- a door is open
- the tailgate is open
- a rearview mirror is folded in

Lighting conditions

The camera image is automatically adjusted according to the current lighting conditions. This

means that the brightness and quality of the image may vary slightly. Poor lighting conditions may result in reduced image quality.

Related information

Park Assist Camera* (p. 384)

Recommended maintenance of the Park Assist Camera

Each of the Park Assist Cameras, located above the license plate, the grille and in both door mirrors, require a certain degree of maintenance. Clean the camera lenses regularly using lukewarm water and car washing detergent. Wash gently to avoid scratching the lens.



(i) NOTE

Keep the camera lens free of dirt, snow and ice to help ensure the best functionality. This is particularly important in poor light conditions.

Related information

Park Assist Camera* (p. 384)

Park Assist Camera symbols and messages

Symbols and messages for the Park Assist Camera may be displayed in the instrument panel and/or the center display.

Some examples of symbols and messages are shown in the table below.

Symbol	Message	Meaning
Dii		The rear Park Assist sensors are turned off and no acoustic warnings or field markings for obstacles/objects will be provided.
		The camera is not functioning properly.
	Park Assist System	One or more of the sensors are blocked. Check and clean/remove the obstacle as soon as possible.
	Sensors blocked, cleaning needed	
	Park Assist System	The system is not functioning as intended. Contact a workshop – an authorized Volvo workshop is recommended.
	Unavailable Service required	

A text message can be erased by briefly pressing the O button in the center of the right-side steering wheel keypad.

authorized Volvo workshop is recommended.

Park Assist Camera* (p. 384)

Park Assist Pilot*

Park Assist Pilot (PAP¹²⁴) helps the driver pull into and out of parking spaces.

PAP first checks whether there is sufficient space and then steers the car into the space.

The center display uses symbols, graphics and messages to inform the driver of what steps need to be taken and when.

- The PAP function is supplementary driver support intended to facilitate driving and help make it safer – it cannot handle all situations in all traffic, weather and road conditions.
- Pay particular attention to people and animals near the vehicle.
- PAP is not a substitute for the driver's attention and judgment. The driver is always responsible for ensuring the vehicle is driven in a safe manner, at the appropriate speed, with an appropriate distance to other vehicles, and in accordance with current traffic rules and regulations.

(i) NOTE

The PAP function measures the space and steers the vehicle – the driver's role is to:

- keep close watch of the area around the vehicle
- follow the instructions on the center display
- change gears (reverse/forward) a "ping" sound indicates when the driver should change gears
- regulate and maintain a safe speed
- apply the brakes and stop.

Related information


- Types of parking with Park Assist Pilot (p. 393)
- Parking with Park Assist Pilot (p. 394)
- Leaving a parking space with Park Assist Pilot (p. 397)
- Park Assist Pilot* limitations (p. 398)
- Recommended maintenance for Park Assist Pilot (p. 400)
- Park Assist Pilot* messages (p. 401)

Types of parking with Park Assist Pilot

Park Assist Pilot (PAP¹²⁵) can be used for the following types of parking.

¹²⁴Park Assist Pilot 125Park Assist Pilot

← Parallel parking




Overview of parallel parking.

The PAP function parks the vehicle using the following steps:

- 1. The system searches for and measures potential parking spaces.
- 2. The vehicle is steered while it is backing into the parking space.
- 3. The vehicle's position in the space is adjusted by driving forward/backward.

The **Park Out** function can be used to receive assistance from PAP while pulling out of a parking space. See the heading "Pulling out of a parking space" under "Parking with Park Assist Pilot".

Perpendicular parking



Perpendicular parking overview.

The PAP function parks the vehicle using the following steps:

- 1. The system searches for and measures potential parking spaces.
- The vehicle is steered while it is backing into the space and its position is adjusted by driving forward/backward.

(i) NOTE

The PAP function **Park Out cannot** help the vehicle leave a perpendicular parking space – the function should only be used for parallel parking.

Related information

Park Assist Pilot* (p. 393)

Parking with Park Assist Pilot

Park Assist Pilot (PAP¹²⁶) helps the driver park using three different steps. The function can also help the driver pull out of a parking space.

(i) NOTE

The PAP function measures the space and steers the vehicle – the driver's role is to:

- keep close watch of the area around the vehicle
- follow the instructions on the center display
- change gears (reverse/forward) a "ping" sound indicates when the driver should change gears
- regulate and maintain a safe speed
- apply the brakes and stop.

Information about the actions required by the driver are provided in the center display using symbols, graphics and/or text.

PAP can be activated if the following criteria have been met after the engine is started:

- No trailer is hitched to the vehicle
- Your vehicle's speed is lower than 30 km/h (20 mph).



NOTE

The distance between the vehicle and parking spots should be 0.5-1.5 meters (1.6-5.0 ft) when PAP is looking for parking.

Parking

PAP parks the vehicle using the following steps:


- 1. The system searches for and measures potential parking spaces.
- 2. The vehicle is steered while it is backing into the parking space.
- The vehicle is positioned in the parking space (the driver may be prompted to shift gears).

Searching for and measuring potential parking spots




The function can be activated in the center display's Function view.

It can also be accessed from the camera views.



Parallel parking overview.



Perpendicular parking overview.

To do so:


- The vehicle's speed may not exceed 30 km/h (20 mph) when parallel parking or 20 km/h (12 mph) when perpendicular parking.
- Tap Park In in Function view or in Camera view.
 - PAP will search for a potential parking space and measure it to determine if it is big enough.
- Be prepared to stop the vehicle when a graphic and message in the center display indicate that a suitable parking space has been found.
 - > A pop-up window will appear.
- Select Parallel parking or Perpendicular parking and engage reverse gear.

i NOTE


PAP searches for space for parking, shows instructions and guides the vehicle on its passenger side. But, if so desired the vehicle can be parked on the driver's side of the street:

 Activate the turn signals on the driver's side – the system will then search for space to park on that side of the vehicle instead.

◀ Backing into a parking space



Parallel.



Perpendicular.

To back into a parking space:


1. Make sure the path behind your vehicle is clear and engage reverse gear.

- 2. Back up slowly and carefully without touching the steering wheel and do not exceed a speed of 7 km/h (4 mph).
- 3. Be prepared to stop the vehicle when instructed to do so by a graphic and message in the center display.

i NOTE

- Keep your hands away from the steering wheel when the PAP function is activated.
- Make sure that the steering wheel is not hindered in any way and can rotate freely.
- To achieve the best results wait until the steering wheel is finished turning before beginning to drive forward/in reverse.

Positioning the vehicle in the parking space



Parallel.



Perpendicular.

To do so:

 Move the gear selector to D, wait until the steering wheel turns and then drive slowly forward.

- Be prepared to stop the vehicle when instructed to do so by a graphic and message in the center display.
- Engage reverse gear and back up slowly.
- Be prepared to stop the vehicle when instructed to do so by a graphic and message in the center display.

The function will switch off automatically and a graphic and message will appear to indicate that parking has been completed. Adjustments can always be made be the driver afterward. Only the driver can determine when the vehicle is correctly parked.

CAUTION

The warning distance is shorter when the sensors are used by PAP compared to when they are used by the Parking Assist system.

Related information

Park Assist Pilot* (p. 393)

Leaving a parking space with Park Assist Pilot

The function Park Out can also help the driver to leave a parking space.



NOTE

Leaving a parking space with the Park Out function should only be used in connection with parallel parking - it does not work for perpendicular parking.



The Park Out function is activated in the center display's Function view or in Camera view.

To do so:

- 1. Tap Park Out in Function view or in Camera view.
- 2. Move the gear selector to the suitable position (e.g. D or R) for the direction in which you will be pulling out of the parking space.
- 3. Be prepared to stop the vehicle when instructed to do so by a graphic and message in the center display. Follow the instructions in the same way as for the parking procedure.

Note that the steering wheel can "spring" back when the procedure is completed and the driver may need to turn the steering wheel back to the maximum position in order to pull out of the parking space.

If PAP determines that the driver can pull out of the parking space without any extra maneuvers, the function will be deactivated, even if it seems as though the vehicle is not completely out of the parking space.

Related information

Park Assist Pilot* (p. 393)

Park Assist Pilot* limitations

Park Assist Pilot PAP¹²⁷ may not be able to detect all conditions in all situations and functionality may therefore be limited.

♠ WARNING

- The PAP function is supplementary driver support intended to facilitate driving and help make it safer – it cannot handle all situations in all traffic, weather and road conditions.
- Pay particular attention to people and animals near the vehicle.
- Bear in mind that the front end of the vehicle may swing out towards oncoming traffic during the parking maneuver.
- Objects situated higher than the detection area of the sensors are not included when the parking maneuver is calculated, which could cause PAP to swing into the parking space too early. Such parking spaces should be avoided for this reason.
- PAP is not a substitute for the driver's attention and judgment. The driver is always responsible for ensuring the vehicle is driven in a safe manner, at the appropriate speed, with an appropriate distance to other vehicles, and in accordance with current traffic rules and regulations.

The driver should be aware of the following limitations for Park Assist Pilot:

The parking sequence is cancelled

A parking sequence will be cancelled if:

- the driver moves the steering wheel
- the vehicle's speed exceeds 7 km/h (4 mph)
- the driver taps Cancel in the center display
- when the anti-lock brakes or the Electronic stability control are engaged - e.g. when a wheel loses grip on a slippery road
- when the power steering works at reduced power - e.g. during cooling due to overheating (see section "Speed-dependent steering force").

A message in the center display will explain why the parking sequence was cancelled.

! CAUTION

Under certain circumstances, PAP may not be able to find parking spaces – one reason may be that the sensors are disrupted by external sound sources that emit the same ultrasonic frequencies that the system works with.

Examples of such sources include horns, wet tires on asphalt, pneumatic brakes, exhaust noise from motorcycles, etc.

¹²⁷Park Assist Pilot

i

NOTE

Dirt, ice and snow covering the sensors reduce their function and can make measurement impossible.

Driver responsibility

The driver should keep in mind that PAP is a parking aid — not an infallible fully automatic system. The driver must always be prepared to take control and cancel a parking sequence if necessary.

There are a number of things to keep in mind when parking, including:

- The driver is always responsible for determining if the space suggested by PAP is suitable for parking.
- Do not use PAP when using snow chains or a temporary spare tire.
- Do not use PAP if there are any objects protruding from the vehicle.
- Heavy rain or snowfall may inhibit PAP's ability to accurately measure a parking space.
- While searching and measuring the parking space, PAP may be unable to detect objects located far into the space.
- PAP may not suggest parking spaces on narrow streets if it does not detect sufficient space for maneuvering the vehicle.

- Use approved tires¹²⁸ inflated to the correct tire pressure because this affects PAP's ability to provide parking assistance.
- PAP's function is based on the way the vehicles are parked behind and in front of your parking space. If they are, for example, parked too close to the curb, there is a risk that your vehicle's tires or wheel rims could be damaged by the curb during the parking procedure.
- Perpendicular parking spaces may not be detected or may be suggested unnecessarily if a parked vehicle is sticking out more than other parked vehicles.
- PAP is intended to provide parking assistance on straight streets, not sections of street with sharp curves or bends. Always make sure that your vehicle is parallel to relevant parking spaces when PAP is measuring the parking space.

CAUTION


Switching to another approved wheel and/or tire dimension could change the tire circumference, which would then require the PAP system to be updated. Consult a workshop – an authorized Volvo workshop is recommended.

- Park Assist Pilot* (p. 393)
- Speed-dependent steering wheel resistance (p. 270)

^{128&}quot;Approved tires" refers to tires of the same type and make as the vehicle's original, factory-installed tires.

Recommended maintenance for Park Assist Pilot

For Park Assist Pilot (PAP¹²⁹) to function optimally, its sensors must be cleaned regularly with water and car washing detergent.



Location of the Park Assist sensors 130.



Dirt, ice and snow covering the sensors could cause false warnings, reduced function, or no function.

Related information

Park Assist Pilot* (p. 393)

¹²⁹Park Assist Pilot

¹³⁰Note: This illustration is general and details may vary depending on model.

Park Assist Pilot* messages

Messages for Park Assist Pilot PAP¹³¹ may be displayed in the instrument panel and/or the center display.

Some examples of symbols and messages are shown in the table below.

Message	Meaning
Park Assist System	One or more of the sensors are blocked. Check and clean/remove the obstacle as soon as possible.
Sensors blocked, cleaning needed	
Park Assist System	The system is not functioning as intended. Contact a workshop – an authorized Volvo workshop is recommended.
Unavailable Service required	

A text message can be erased by briefly pressing the \bigcirc button in the center of the right-side steering wheel keypad.

If the message persists: Contact a workshop – an authorized Volvo workshop is recommended.

Related information

Park Assist Pilot* (p. 393)

¹³¹Park Assist Pilot



Starting the vehicle

The vehicle can be started using the start knob in the tunnel console when the remote key is in the passenger compartment.



Start knob in the tunnel console.

Before starting:

- Buckle your seat belt.
- Adjust the seat, steering wheel and mirrors.
- Make sure you can fully depress the brake pedal.

The remote key is not physically used to start the ignition because the vehicle is equipped with the keyless Passive Start system.

To start the vehicle:

- The remote key must be inside the vehicle.
 For vehicles with Passive Start, the key must
 be in the front section of the passenger
 compartment. With the optional keyless locking/unlocking function*, the key can be anywhere in the vehicle.
- 2. Press and hold down the brake pedal¹ as far as possible.
- Turn the start knob clockwise and release.
 The control will automatically return to the original position.

! WARNING

- Never use more than one inlay mat at a time on the driver's floor. If any other type of floor mat is used, remove the original mat from the driver's seat floor before driving. All types of mats must be securely anchored in the attachment points in the floor. Make sure the floor mat does not impede the movement of the brake pedal or accelerator pedal in any way, as this could be a serious safety hazard.
- Volvo's floor mats are specially manufactured for your vehicle. They must be properly secured in the attachment points in the floor to help ensure they cannot slide and become trapped under the pedals.

The starter motor will crank until the engine starts or until its overheating protection is triggered.

¹ If the vehicle is moving, it is only necessary to turn the start knob clockwise to start the engine.



Location of the backup reader in the tunnel console.

If the **Vehicle key not found** message is shown in the instrument panel at start, place the remote key at the backup reader and then make a new start attempt.

i NOTE

When the remote key is placed in the backup reader, make sure that no other vehicle keys, metal objects or electronic devices (e.g. cellular phones, tablets, laptops or chargers) are in the backup reader. Multiple vehicle keys close to each other in the backup reader can disrupt their functionality.

(!) CAUTION

If the engine has not responded after 3 attempts – wait for 3 minutes before starting a new attempt. Starting capability increases if the starter battery is given time to recover.

Never remove the remote control key from the vehicle while driving or the vehicle is being towed.

M WARNING

- Always remove the remote key from the passenger compartment when you leave the vehicle and make sure the ignition is in mode 0.
- Always put the gear selector in P and apply the parking brake before leaving the vehicle. Never leave the vehicle unsupervised while the engine is running.
- Always open the garage door fully and make sure that ventilation is very good before starting the engine in a garage.
 The exhaust fumes produced by the vehicle contain carbon monoxide, which is invisible and odorless but very toxic.

Always take along the remote control key when leaving the vehicle and make sure that the vehicle electrical system is in ignition mode **0** – especially if there are children in the vehicle.

i NOTE

With a cold start, idling speed may be considerably higher than normal for certain engine types. This is done to get the emissions system up to normal operating temperature as quickly as possible, which minimizes exhaust emissions and protects the environment.

! CAUTION

- When starting in cold weather, the automatic transmission may shift up at slightly higher engine speeds than normal until the automatic transmission fluid reaches normal operating temperature.
- Do not race a cold engine immediately after starting. This could prevent fluids from properly lubricating vital components in the engine before it has reached the proper operating temperature.
- The engine should be idling when the gear selector is moved. Never accelerate until the gear is fully engaged. Accelerating rapidly before a gear is properly engaged could lead to harder wear of components.
- To help prevent the transmission oil from overheating, select P or N when idling at a standstill for prolonged periods of time.

Related information

- Switching off the vehicle (p. 406)
- Ignition modes (p. 407)
- Adjusting the steering wheel (p. 203)
- Jump starting using another battery (p. 447)
- Selecting ignition mode (p. 408)

Switching off the vehicle

The vehicle can be switched off using the start knob in the tunnel console.



Start knob in the tunnel console.

To switch off the vehicle:

 Turn the start knob clockwise and release to switch off the vehicle. The control will automatically return to the original position.

If the vehicle rolls:

 Turn clockwise and hold the knob until the vehicle switches off.

Related information

- Starting the vehicle (p. 404)
- Ignition modes (p. 407)
- Adjusting the steering wheel (p. 203)
- Jump starting using another battery (p. 447)

• Selecting ignition mode (p. 408)

Ignition modes

The vehicle's ignition can be put in various modes (levels) to make different functions available.

To enable the use of a limited number of functions when the engine is not running, the ignition can be put in one of three different levels: **0**, **I** and **II**. These levels are referred to as "ignition modes" in the Owner's Manual.

The following table shows which functions are available in each ignition mode:

Mode	Functions
0	• The odometer, clock and temperature gauge are illuminated ^A .
	 The power seats* can be adjusted.
	The power windows can be used.
	 The center display is activated and can be used^A.
	• The 12 V outlet in the cargo compartment* can be used.
	 The infotainment system can be used^A.
	In this ignition mode, the functions are available for a limited time and then switch off automatically.
-	The panoramic roof, power windows, 12 V outlet in passenger compartment, Bluetooth, navigation, phone, blower and windshield wipers can be used.
	The power seats can be adjusted.
	• The 12 V outlet in the cargo compartment can be used.
	Electrical current will be taken from the battery in this ignition mode.

Mode	Functions
II	 The headlights illuminate. Warning/indicator lights illuminate for 5 seconds.
	 A number of other systems are activated. However, seat and rear window heating can only be acti- vated when the engine is running.
	This ignition mode uses a lot of current from the battery and should be avoided whenever possible!

A Also activated when the door is opened.

- Starting the vehicle (p. 404)
- Adjusting the steering wheel (p. 203)
- Jump starting using another battery (p. 447)
- Selecting ignition mode (p. 408)

Selecting ignition mode

The vehicle's ignition can be put in various modes (levels) to make different functions available.

Selecting an ignition mode



Start knob in the tunnel console.

 Ignition mode 0 - Unlock the vehicle and keep the remote key in the passenger compartment.

(i) NOTE

To set level I or II without engine start – do **not** depress the brake pedal (or clutch pedal for vehicles with manual transmission) when selecting this ignition mode.

- Ignition mode I Turn the start knob clockwise and release it. The control will automatically return to the original position.
- Ignition mode II Turn the start knob clockwise and hold it there for approx. 5 seconds.
 Release the knob, which will automatically return to its original position.
- Back to ignition mode 0 To return to ignition mode 0 from mode I and II, turn the start knob clockwise and release it. The control will automatically return to the original position.

Related information

- Starting the vehicle (p. 404)
- Switching off the vehicle (p. 406)
- Ignition modes (p. 407)
- Adjusting the steering wheel (p. 203)
- Jump starting using another battery (p. 447)

Brake functions

The vehicle's brakes are used to reduce speed or prevent the vehicle from rolling.

In addition to the wheel brakes and parking brakes, the vehicle is also equipped with a number of automatic brake assist functions. These systems help the driver by e.g. keeping the vehicle stationary when the brake pedal is not depressed (e.g. at a traffic light or intersection), when starting up a hill or when driving down a hill.

Depending on how the vehicle is equipped, the following brake assist functions may be included:

- Auto-hold brakes (Auto Hold)
- Hill Start Assist (Hill Start Assist)
- Braking assist after a collision
- City Safety
- Hill Descent Control (Hill Descent Control)*

Related information

- Brakes (p. 409)
- Parking brake (p. 411)
- Auto-hold brakes (p. 415)
- Braking assist after a collision (p. 417)
- Hill Start Assist (p. 416)
- City Safety[™] (p. 333)
- Hill Descent Control* (p. 437)

Brakes

The brake pedal is used to apply the vehicle's regular brakes, which are part of the brake system.

The vehicle is equipped with two brake circuits. If one brake circuit is damaged, the brake pedal will go down further when depressed. More pressure will then be required from the driver for normal braking effect.

The driver's pressure on the brake pedal is enhanced by a power braking function.

⚠ WARNING

Power braking only functions if the engine is running.

If the brake pedal is used when the engine is turned off, the pedal will feel stiffer than usual and greater pressure must be applied to brake the vehicle.

In very hilly areas or when driving with a heavy load, engine braking in manual gear should be used to augment the brakes. Engine braking is most effective if the same gear is used both uphill and downhill. Use the Off Road* drive mode to increase the engine braking effect when driving on steep downgrades at low speeds.

Anti-lock brakes

The vehicle is equipped with an Anti-lock Braking System (ABS), which can help prevent the

wheels from locking and help maintain steering control when braking. Vibrations may be felt from the brake pedal when ABS is operating, which is normal.

After the vehicle is started, a brief test of the ABS system is automatically performed when the driver releases the brake pedal. An additional automatic test of the system may be performed when the vehicle is traveling at a low speed. During the test, the brake pedal may feel as though it is pulsating.

Symbols in the instrument panel

Symbol Meaning Check the brake fluid level. If the level is low, fill brake fluid and check to determine the reason for the loss of brake fluid. Α BRAKE В Steady glow for 2 seconds after the engine is started: Automatic function check. Steady glow for more than 2 seconds: Fault in the ABS system. The vehicle's regular brake system is still working, but without the ABS function.

- A Canadian models.
- B US models.

↑ WARNING

- If both symbols illuminate at the same time and the brake level is below the MIN mark in the reservoir or if a brake system-related message is shown in the instrument panel: DO NOT DRIVE. Have the vehicle towed to a trained and qualified Volvo service technician and have the brake system inspected.
- If both symbols illuminate at the same time and the brake level is normal (not below the MIN mark in the reservoir) or if a brake system-related message is shown in the instrument panel: drive the vehicle carefully to an authorized Volvo workshop and have the brake system inspected by a trained and qualified Volvo service technician.

Related information

- Brake Assist System (p. 410)
- Auto-hold brakes (p. 415)
- Hill Start Assist (p. 416)
- Braking on wet roads (p. 410)
- Braking on salted roads (p. 411)
- Maintenance of the brake system (p. 411)
- Brake lights (p. 163)

Brake Assist System

The brake enhancing system, Brake Assist System (BAS), helps increase braking force and thereby reduce braking distance.

The system monitors the driver's braking habits and increases braking force when necessary. Braking force can be increased up to the point at which the ABS intervenes. The function is deactivated when pressure on the brake pedal is decreased.

$\overline{(i)}$

NOTE

When BAS is activated, the brake pedal will go down slightly more than usual. Press (hold) down the brake pedal as long as necessary.

When the brake pedal is released, all braking ceases.

Related information

Brakes (p. 409)

Braking on wet roads

Prolonged driving in heavy rain without braking may cause braking effect to be slightly delayed the first time the brakes are applied.

This may also occur after washing the vehicle. It will then be necessary to apply greater pressure to the brake pedal. You should therefore maintain a greater distance to the vehicle ahead.

Firmly apply the brakes after washing the vehicle or driving on wet roads. This helps warm up the brake discs, enabling them to dry more quickly and protecting them against corrosion. Consider the current traffic situation when braking.

- Brakes (p. 409)
- Braking on salted roads (p. 411)

Braking on salted roads

When driving on salted roads, a layer of salt may form on the brake discs and brake pads.

This could increase stopping distance. Maintain an extra large safety distance to the vehicle ahead. Make sure to also:

- Apply the brakes from time to time to help remove salt. Make sure braking does not pose a risk to any other road users.
- Gently apply the brakes when you have finished driving and before driving again.

Related information

- Brakes (p. 409)
- Braking on wet roads (p. 410)

Maintenance of the brake system

Regularly check the brake system components for wear.

To keep the vehicle as safe and reliable as possible, follow the Volvo service schedule specified in the Warranty and Maintenance Records Information booklet. New and replaced brake pads and brake discs do not provide optimal braking effect until they are "broken in" by driving a few hundred kilometers (miles). Compensate for the reduced braking effect by applying greater pressure to the brake pedal. Volvo recommends only using brake pads approved for your Volvo.

(!)

. CAUTION

The brake system's components should be regularly checked for wear.

Contact a workshop for advice on how to do this or let a workshop perform the inspection - an authorized Volvo workshop is recommended.

Related information

Brakes (p. 409)

Parking brake

The parking brake helps keep the vehicle stationary by mechanically locking two wheels.



The parking brake controls are located in the tunnel console between the seats.

When the electric parking brake is being applied, a faint sound can be heard from the brake's electric motor. This sound can also be heard during the automatic function check of the parking brake.

If the vehicle is stationary when the parking brake is applied, it will only be applied to the rear wheels. If it is applied while the vehicle is moving, the normal brakes will be used on all four wheels. Braking will be transferred to only the rear wheels when the vehicle is almost stopped.

Related information

- Activating and deactivating the parking brake (p. 412)
- Parking on a hill (p. 414)
- Parking brake malfunction (p. 414)
- Auto-hold brakes (p. 415)

Activating and deactivating the parking brake

Use the parking brake to help keep the vehicle stationary when it is parked.

Activating the parking brake



- 1. Pull up the control.
 - The symbol in the instrument panel will illuminate when the parking brake is activated.
- 2. Make sure the vehicle is stationary.

Symbol in the instrument panel

Symbol Meaning The symbol will be illuminated when the parking brake is activated. A flashing symbol indicates that a fault has been detected. Read the message in the instrument panel.

- A Canadian models.
- B LIS models

Automatic activation

The parking brake is applied automatically:

- if the Auto-hold function (automatic brake application when the vehicle is stationary) is activated and the vehicle has been stationary for a prolonged period of time (5-10 minutes).
- when the gear selector is moved to P on a steep hill.
- when the ignition is switched off and the setting for automatically activating the parking brake is activated in the center display.

Emergency braking

In an emergency, the parking brake can be activated when the vehicle is moving by pulling and holding up the control. The braking process is canceled when the control is released or if the accelerator pedal is depressed.



NOTE

In case of emergency braking at high speeds, a signal sounds during the brake procedure.

Deactivating the parking brake



Deactivating manually

- 1. Depress the brake pedal firmly.
- 2. Press the control.
 - > The parking brake will release and the symbol in the instrument panel will go out.

Deactivating automatically

- 1. Fasten your seat belt.
- 2. Depress the brake pedal firmly.
- Start the vehicle.
- 4. Move the gear selector to **D** or **R** and press the accelerator pedal.
 - > The parking brake will release and the symbol in the instrument panel will go out.



NOTE

When the vehicle is initially started, the parking brake could disengage automatically even if the driver's seat belt is not buckled.

Related information

- Settings for automatically activating the parking brake (p. 413)
- Parking brake malfunction (p. 414)
- Parking brake (p. 411)
- Parking on a hill (p. 414)

Settings for automatically activating the parking brake

Choose whether the parking brake should be activated automatically when the vehicle is switched off.

This selection is made in the Settings menu in the center display.

- 1. Tap **Settings** in the Top view.
- Tap My Car → Parking Brake and Suspension and select or deselect the Auto Activate Parking Brake function.

- Activating and deactivating the parking brake (p. 412)
- Parking brake (p. 411)

Parking on a hill

Always use the parking brake when parking on a hill.

Always apply the parking brake when parking on an incline. Selecting a gear or putting the automatic transmission in **P** may not be sufficient to keep the vehicle stationary in all situations.

If the vehicle is pointing uphill:

 Turn the front wheels so they are pointing away from the curb.

If the vehicle is pointing downhill:

 Turn the front wheels so they are pointing toward the curb.

Heavy load uphill

Heavy loads, such as a trailer, could cause the vehicle to roll backward when the parking brake is released automatically on steep uphill gradients. To help avoid this, pull the control upward while you are driving away. Release the control when the vehicle gains traction.

Related information

 Activating and deactivating the parking brake (p. 412)

Parking brake malfunction

If you are unable to deactivate or activate the parking brake after several attempts, contact an authorized Volvo workshop.

A audible warning signal will sound if the parking brake is applied while the vehicle is being driven.

If the vehicle must be parked before the problem is rectified, turn the wheels as when parking on an incline and put the gear selector in **P**.

Low battery charge level

If the battery charge level is too low, it will not be possible to apply or release the parking brake. Connect an auxiliary battery to the vehicle if the battery is discharged.

Replacing brake pads

Due to the design of the electric parking brake, the rear brake pads must be replaced by a workshop. An authorized Volvo workshop is recommended.

Symbols in the instrument panel

Symbol	Meaning
(P)	A flashing symbol indicates that a fault has been detected. See the message in the instrument panel.
PARK B	
(!) A	Fault in the brake system. See the message in the instrument panel.
BRAKE	
(P)	Information message in the instrument panel.

- A Canadian models.
- B US models.

Related information

- Activating and deactivating the parking brake (p.412)
- Start battery (p. 598)
- Volvo's service program (p. 576)

Auto-hold brakes

With the Auto-hold brake function, the driver can release the brake pedal and the brakes will remain applied, for example, when the vehicle has stopped at a traffic light or intersection. When the vehicle stops, the brakes are activated automatically. The function can use either the normal brakes or the parking brakes to keep the vehicle stationary and works on flat surfaces or hills. When driving off, the brakes will be automatically released if the driver's seat belt is buckled.



(i) NOTE

When braking to a stop on an uphill or downhill gradient, depress the brake pedal with slightly more force than usual before releasing to ensure that the vehicle cannot move at all.

The parking brake is activated if:

- the vehicle is switched off
- the driver's door is opened
- the driver's seat belt is removed
- the vehicle has been stationary for a prolonged period of time (5-10 minutes)

Symbols in the instrument panel

Meaning Symbol This symbol illuminates when the function is using the normal brakes to keep the vehicle stationary. This symbol illuminates when the function is using the parking brake to keep the vehicle stationary.

A Canadian models. B IJS models.

PARK

В

- Activating and deactivating Auto-hold at a standstill (p. 416)
- Brakes (p. 409)
- Parking brake (p. 411)
- Hill Start Assist (p. 416)

Activating and deactivating Autohold at a standstill

The Auto-hold brake function at a standstill is activated with the button in the tunnel console.



- Press the button in the tunnel console to activate or deactivate the function.
 - The indicator light in the button will illuminate when the function is activated. The function will remain active the next time the vehicle is started.

When shutting off



If the function is active and holding the vehicle stationary using the normal brakes (A symbol lit), the brake pedal must be depressed while pressing the

button in order to deactivate Auto-hold.

- The function will remain off until it is reactivated.
- When Auto-hold is switched off, Hill Start Assist (HSA) will remain active to help prevent the vehicle from rolling backward when starting up a hill.

Related information

Auto-hold brakes (p. 415)

Hill Start Assist

The function for assisting when starting the vehicle on inclines, Hill Start Assist (HSA), helps prevent the vehicle from rolling backward when starting on an uphill gradient. When backing up a hill, HSA helps prevent the vehicle from rolling forward.

The function retains pressure from the brake pedal in the brake system for several seconds after the brake pedal has been released.

This temporary braking effect is released after a few seconds or when the driver begins driving.

Hill Start Assist is available even if the Auto-hold brake function is switched off.

- Auto-hold brakes (p. 415)
- Brakes (p. 409)

Braking assist after a collision

In a collision in which the activation level is reached for the pyrotechnic seat belt tensioners or airbags, or if a collision with a large animal is detected, the vehicle's brakes will be automatically activated. This function is intended to help prevent or reduce the effects of any subsequent collision.

After a serious collision, it may no longer be possible to control and steer the vehicle. In order to avoid or mitigate a possible further collision with a vehicle or an object in the vehicle's path, the brake assist system is activated automatically to help stop the vehicle safely.

The brake lights and hazard warning flashers are activated during braking. When the vehicle has stopped, the hazard warning flashers will continue to flash and the parking brake will be applied.

If braking is not appropriate, e.g. if there is a risk of being hit by passing traffic, the driver can override the system by depressing the accelerator pedal.

This function assumes that the brake system is intact after a collision.

Brake assist is part of the Rear Collision Warning and Blind Spot Information safety systems.

Related information

- Rear Collision Warning (p. 345)
- BLIS* (p. 346)
- Brake functions (p. 408)

Transmission

The transmission is part of the vehicle's driveline (power transmission) between the engine and the drive wheels. The function of the transmission is to change gears depending on speed and power needs.

The vehicle has an 8-speed automatic transmission. The number of gears allows the engine's torque and power band to be effectively utilized. Two of the gears are overdrive gears that save fuel when driving at a constant engine speed. Manual shifting is also possible. The instrument panel shows the gear currently in use.

! CAUTION

Check the operating temperature of the transmission to help avoid damage to any of the drive system components. If there is a risk of overheating, a warning symbol will appear in the instrument panel and a text message will be displayed. Follow the recommendations given.

Symbols in the instrument panel

If a problem should occur with the transmission, a symbol and a message will appear in the instrument panel.

44

Symbol Meaning Information and messages related



Information and messages related to the transmission. Follow the recommendations provided.



Hot or overheated transmission. Follow the recommendations provided.



Reduced performance/Acceleration performance reduced

In the event of a temporary fault in the driveline, the vehicle may go into a "limp home" mode with reduced power output to help avoid damage to the driveline.

Related information

- Gear selector positions for automatic transmissions (p. 418)
- Gear indicator* (p. 422)

Gear selector positions for automatic transmissions

In vehicles with an automatic transmission, the system selects the optimal gear for the current driving conditions. The transmission also has a manual mode.



The instrument panel shows which gear is currently in use:

P, R, N, D or M.

In manual gear mode, the gear indicator in the instrument panel displays the gear currently being used.

Gear selector positions

Park - P

In **P** mode, the transmission is mechanically locked.

Select **P** when the vehicle is parked or when starting the engine. The vehicle must be stationary when Park is selected.

To move the gear selector from Park, the brake pedal must be depressed and the ignition in mode II.

When parking – apply the parking brake before shifting to Park.

Always apply the parking brake when parking on an incline. Selecting a gear or putting the automatic transmission in ${\bf P}$ may not be sufficient to keep the vehicle stationary in all situations.

(i) NOTE

The gear selector must be in the ${\bf P}$ position before the vehicle can be locked and the alarm set.

Reverse - R

Select ${\bf R}$ when backing up. The vehicle must be stationary when Reverse is selected.

Neutral - N

No gear is selected and the engine can be started. Apply the parking brake if the vehicle is stationary with the gear selector in **N**.

To move the gear selector from Neutral to another gear, the brake pedal must be depressed and the ignition in mode **II**.

D drive mode

 ${f D}$ is the normal driving gear position. The transmission shifts up or down automatically depending on acceleration and speed. The vehicle must be stationary when the gear selector is moved from ${f R}$ to ${f D}$.

Manual shifting mode - M

Manual shifting mode can be selected at any time during a drive. Engine braking will occur when the accelerator pedal is released.

Select manual shifting mode by moving the gear selector sideways from ${\bf D}$ to ${\bf \pm}$. The current gear will be displayed in the instrument panel.

- Push the gear selector forward toward + (plus) and release to shift up one gear.
- Pull the gear selector backward toward -(minus) and release to shift down one gear.



 $\label{eq:manual_shifting} \text{ mode in the instrument panel}^2.$

For smooth shifting and engine performance, the transmission will shift down automatically if the vehicle's speed becomes too low for the selected gear.

Move the gear selector sideways to ${\bf D}$ at any time to return to automatic shifting.

Related information

- Shiftlock (p. 421)
- Using the steering wheel paddles* to shift (p. 419)
- The kickdown function (p. 422)
- Gear indicator* (p. 422)

Using the steering wheel paddles* to shift

The steering wheel paddles are a supplement to the gear selector and make it possible to shift manually without removing your hands from the steering wheel.

Activating the steering wheel paddles

In order to shift gears using the paddles, they must first be activated:

- Pull one of the paddles toward the steering wheel.
 - > A number in the instrument panel indicates the current gear being used.



Instrument panel when the paddles are activated for shifting.

² The illustration is generic - details may vary according to vehicle model.

In shift mode M, the paddles are automatically activated.



Instrument panel when the paddles are activated for shifting in manual mode.

Change

To shift one gear:

 Pull one of the paddles toward the steering wheel and then release.



- 1 "-": Shift down one gear.
- 2 "+": Shift up one gear.

As long as the engine speed (rpm) is within the permissible range for the selected gear, a gear shift will take place each time a paddle is pulled.

After each gear shift, a number indicating the current gear will be displayed in the instrument panel.

Turning off Start/Stop

Manual deactivation in gear position D

 Deactivate the paddles by pulling the right paddle (+) toward the steering wheel and holding it until the number of the current gear is no longer displayed in the instrument panel.

Automatic deactivation

In gear position **D**, the steering wheel paddles are deactivated after a short period of time if they are not used. The number of the current gear will no longer be displayed in the instrument panel. If engine braking is currently being used, the paddles will remain active until engine braking stops.

In gear position \mathbf{M} , the paddles will not activate automatically.

Related information


- Gear selector positions for automatic transmissions (p. 418)
- Gear indicator* (p. 422)

Shiftlock

The automatic transmission's shiftlock function helps prevent inadvertently moving the gear selector between different positions.

There are two types of shiftlocks: mechanical and automatic.

Mechanical shiftlock



The gear selector can be moved back and forth between ${\bf N}$ and ${\bf D}$. The other positions have a shiftlock that is operated using the lock button on the gear selector.

Press and hold the shiftlock button and move the gear selector forward or backward between **P**, **R**, **N** and **D**.

Automatic shiftlock

The automatic shiftlock has a separate safety system.

From Park - P

To move the gear selector from the ${\bf P}$ position, the brake pedal must be depressed and the ignition in mode ${\bf II}$.

From Neutral - N

If the gear selector is in \mathbf{N} and the vehicle has been stationary for at least 3 seconds (with or without the engine running), the gear selector will be locked in that position.

To move the gear selector from N to another gear, the brake pedal must be depressed and the ignition in mode II.


Related information

- Gear selector positions for automatic transmissions (p. 418)
- Deactivating the automatic shiftlock (p. 421)

Deactivating the automatic shiftlock

The automatic shiftlock can still be disengaged even when there is no electrical current to the vehicle.

Deactivating the automatic shiftlock



If the vehicle cannot be driven (e.g. due to a discharged battery), the gear selector must be moved to the $\bf N$ position so that the vehicle can be moved.

- Lift the rubber mat in the storage compartment in front of the gear selector. Locate the hole with a spring-loaded button in the bottom of the compartment.
- Press a small screwdriver or similar object into the hole and hold it down.
- Move the gear selector to **N** and release the button.
- 4. Replace the rubber mat.



Related information

- Shiftlock (p. 421)
- Gear selector positions for automatic transmissions (p. 418)

The kickdown function

Kickdown is used when maximum acceleration is needed, e.g. when passing.

When the accelerator pedal is depressed all the way to the floor (past the normal full accelerator position), the transmission will automatically engage kickdown, i.e. immediately shift down to a lower gear.

If the accelerator pedal is released from the kick-down position, the transmission will automatically shift up again.

Safety function

The transmission control module is equipped with a downshift protection feature to help prevent the engine from overheating.

In some conditions, the transmission will prevent downshifting/kickdown if this would lead to such high engine speed (rpm) that the engine could be damaged. If the driver still attempts downshifting or kickdown at a high rpm, nothing will happen and the original gear will remain selected.

With kickdown, the vehicle can downshift one or more steps at a time depending on the engine speed. The vehicle upshifts when the engine reaches its maximum rpm to prevent engine damage.

Related information

Gear selector positions for automatic transmissions (p. 418)

Gear indicator*

The gear indicator in the instrument panel shows the gear currently being used for manual shifting and indicates when another gear should be selected to optimize fuel economy.

For eco-friendly driving when manually shifting, it is important to use the correct gear and to shift gears in good time.

The gear indicator in the instrument panel shows the gear currently being used and indicates with an upward-facing arrow if a higher gear should be selected.



Gear indicator in 12" instrument panel*.



Gear indicator in 8" instrument panel.

Related information

Gear selector positions for automatic transmissions (p. 418)

All Wheel Drive (AWD)*

All-wheel drive, All Wheel Drive (AWD), also called four-wheel drive, means that power is distributed to all four wheels, which improves traction.

To achieve the best traction, power is automatically directed to the wheels that have the best grip. The system continuously calculates the need for torque to the rear wheels, and can immediately redistribute up to half of the engine's torque to the rear wheels.

All-wheel drive also has a stabilizing effect at higher speeds. In normal driving conditions, most of the engine's power is directed to the front wheels. When the vehicle is stationary, all-wheel drive is always activated in preparation for maximum traction during acceleration.

All-wheel drive reacts differently depending on which drive mode* is selected.

Related information

- Drive modes* (p. 423)
- Low Speed Control* (p. 435)
- Transmission (p. 417)

Drive modes*

Drive modes affect the vehicle's driving characteristics in different ways to enhance and simplify the driving experience in certain types of situations.

Drive modes enable easy access to the vehicle's many functions and settings in different driving situations. The following systems are adapted to help optimize driving characteristics in each drive mode:

- Steering
- Engine/transmission/all-wheel drive*
- Brakes
- Pneumatic suspension* and shock absorbers
- Instrument panel
- Start/Stop function
- Climate control settings

Select the drive mode that is best suited to the current driving conditions. Keep in mind that not all drive modes are available in all situations.

Available drive modes

COMFORT

• This is the vehicle's default mode.

When the engine is started, the vehicle will be in Comfort mode and the Start/Stop function will be activated. This setting offers driving comfort, light steering and soft suspension.

FCO

Adapt the vehicle for more fuel-efficient and eco-friendly driving with Eco mode.

In this mode, the Start/Stop function is activated, the ground clearance is lower to reduce air resistance and certain climate settings are reduced.

The instrument panel has an ECO gauge to facilitate fuel-efficient driving.

OFF ROAD

Maximizes the vehicle's ability to traverse difficult terrain or poor roads.

In this mode, ground clearance is high, steering is light, and all-wheel drive and Hill Descent Control are activated. The Start/Stop function is deactivated.

This mode can only be activated at low speeds. The permitted speed range will be shown in the speedometer. If this speed is exceeded, Off road mode will be deactivated and another drive mode activated.

In Off road mode, a compass will be displayed between the speedometer and the tachometer in the instrument panel.



NOTE

This drive mode is not designed to be used for normal street driving.



NOTE

Due to the increased ground clearance, if the OFF ROAD mode was selected when the engine was switched off, the suspension will lower when the engine is restarted.

CAUTION

Do not use the OFF ROAD drive mode when towing a trailer without an electrical connection. This could result in damage to the pneumatic suspension system's bellows.

DYNAMIC

Dynamic mode is designed to provide sportier driving characteristics and a faster acceleration response.

Gear shifting will be faster and more distinct and the transmission will prioritize gears with a higher traction force.

Steering response is faster, suspension is stiffer and ground clearance is lower to help reduce body roll when cornering.

The Start/Stop function is deactivated.

INDIVIDUAL

Customizes drive mode to personal preferences.

Select one of the drive modes as a basis and adjust the settings to achieve your preferred driving characteristics. These settings will be stored in your driver profile.

Individual drive mode is only available if it has been activated in the center display.



Settings view³ for Individual drive mode.

1. Tap **Settings** in the Top view.

³ The image is schematic and the details may vary depending on vehicle model or software update.

- Tap My Car → Individual Drive Mode and select Individual Drive Mode.
- Under Presets, select one of the following drive modes as a basis: Eco, Comfort or Dynamic.

The following settings can be modified:

- Driver Display
- Steering force
- Powertrain Characteristics
- Brake Characteristics
- Suspension Control
- ECO Climate
- Start/Stop.

Related information

- Changing drive mode* (p. 425)
- ECO drive mode (p. 426)
- Economical driving (p. 438)
- Start/Stop function (p. 428)
- Low Speed Control* (p. 435)
- Hill Descent Control* (p. 437)
- All Wheel Drive (AWD)* (p. 423)

Changing drive mode*

The drive mode is changed using the control in the tunnel console.

Select the drive mode that is best suited to the current driving conditions. Keep in mind that not all drive modes are available in all situations.

To change drive mode:



- Press the **DRIVE MODE** control.
 - > A pop-up menu will appear in the center display.
- 2. Roll the wheel upward or downward to the desired drive mode.
- 3. Press the drive mode control or tap its button in the center display to confirm the selection.
 - > The selected drive mode is shown in the instrument panel.

If a drive mode is grayed out in the pop-up menu, it cannot be selected.

- Drive modes* (p. 423)
- Activating and deactivating ECO drive mode using the function button (p. 428)
- Activating and deactivating Low Speed Control* using the function button (p. 436)
- Activating and deactivating Hill Descent Control* using the function button (p. 438)

ECO drive mode

The Eco drive mode optimizes the vehicle's driving characteristics for more fuel-efficient and eco-friendly driving.

Use this mode to save fuel and promote ecofriendly driving.

When ECO mode is activated, the following characteristics are modified:

- The automatic transmission's shifting points.
- Engine control and accelerator pedal response.
- Eco Coast functionality is activated and engine braking is disabled when the accelerator pedal is released at speeds between 65 and 140 km/h (40 and 87 mph).
- Some of the climate system settings will be reduced or switched off.
- The suspension's self-leveling function* will lower ground clearance to help reduce wind resistance.
- Information will be shown in the ECO gauge in the instrument panel to help promote more eco-friendly and economical driving.

Coast function Eco Coast

Eco Coast essentially deactivates engine braking, allowing the vehicle's kinetic energy to be used to roll greater distances. When the driver releases the accelerator pedal, the transmission is automatically disengaged from the engine. Engine

speed is reduced to idling speed to reduce fuel consumption.

This function is most effective in driving situations where the vehicle can roll freely for a long distance, e.g. on roads with slight downgrades or when a decrease in speed is anticipated, such as when approaching an area with a lower speed limit.

Activating Eco Coast

The function is activated when the accelerator pedal is fully released and the following conditions are met:

- Eco drive mode is activated.
- The gear selector is in D.
- The vehicle's speed is approximately 65-140 km/h (40-87 mph).
- The gradient of the downgrade is less than approximately 6%.

COASTING will be displayed in the instrument panel when Eco Coast is being used.

Limitations

Eco Coast is not available if:

- The engine and/or transmission are not at normal working temperatures.
- The gear selector is moved from **D** to manual shifting mode.
- The vehicle's speed is not within the 65-140 km/h (40-87 mph) range.

- The gradient of the downgrade is more than approximately 6%.
- The steering wheel paddles* are being used for manual shifting.

Deactivating and turning off Eco Coast

In certain situations, it may be advisable to deactivate or turn off Eco Coast so that engine braking can be used. These situations might include driving down steep hills or before passing another vehicle to help ensure this can be done as safely as possible.

Deactivate Eco Coast by:

- Pressing the accelerator or brake pedal.
- Moving the gear selector to manual mode.
- Using the steering wheel paddles* to shift.

Turn off Eco Coast by:

 Switching drive mode* or switching off drive mode Eco in Function view.

It is possible to roll short distances even without Eco Coast in order to help conserve fuel. However, for the best fuel economy, Eco Coast should be activated and used to roll longer distances.

Cruise control Eco Cruise

When cruise control is activated in the Eco drive mode, the vehicle's acceleration and deceleration will be slower than in other drive modes to help further conserve fuel. Because of this, the vehicle's actual speed may be slightly above or below the set speed.

- On a level road, the vehicle's actual speed may differ from the set speed when cruise control is active and the vehicle is coasting.
- On a steep uphill gradient, the vehicle's speed is reduced until the transmission downshifts. Reduced acceleration is then initiated in order to reach the set speed.
- On a downhill gradient in which the vehicle is coasting, the vehicle's actual speed may be slightly above or below the set speed. The function uses engine braking to keep the set speed. If necessary, the normal brakes are also applied.

ECO gauge in the instrument panel

The ECO gauge indicates how economical current driving is:

- A low reading in the green area of the gauge indicates economical driving.
- A high reading is shown when driving is not economical, e.g. heavy braking or rapid acceleration.

The ECO gauge also has an indicator showing how a reference driver would drive in the same driving situation. This is shown by the short pointer in the gauge.



Eco gauge in 12" instrument panel*.



Eco gauge in 8" instrument panel.

ECO Climate

In Eco mode, ECO climate is automatically activated in the passenger compartment to help reduce energy consumption.

i NOTE

When the ECO function is activated, settings for certain climate system and electricity consuming functions are reduced. Some of these settings can be reset manually, but full functionality will only be restored by switching off the ECO function or adapting the Individual* drive mode to full climate system functionality.

If condensation forms on the windows, tap the max defroster button, which will function normally.

- Changing drive mode* (p. 425)
- Activating and deactivating ECO drive mode using the function button (p. 428)
- Drive modes* (p. 423)
- Economical driving (p. 438)
- Start/Stop function (p. 428)

Activating and deactivating ECO drive mode using the function button

Vehicles equipped with drive mode controls in the tunnel console have a function button for Eco drive mode in the center display's Function view.

When the engine is switched off, ECO mode is deactivated and must therefore be reactivated each time the engine is started. **ECO** will be displayed in the instrument panel when the function is activated.

Selecting Eco drive mode in the center display's Function view

Tap the **Driving Mode ECO** button to activate or deactivate the function.



> An indicator light in the button will illuminate when the function is activated.

Related information

- ECO drive mode (p. 426)
- Changing drive mode* (p. 425)
- Drive modes* (p. 423)

Start/Stop function

Start/Stop is a function that temporarily switches off the engine when the vehicle has stopped, e.g. at a traffic light or in heavy traffic, and then starts it again automatically when the brake pedal is released.

The Start/Stop function reduces fuel consumption, which helps to reduce exhaust emissions.

The system makes it possible to drive more economically and climate-smart by letting the engine auto-stop when appropriate.

Related information

- Driving with the Start/Stop function (p. 428)
- Conditions for the Start/Stop function (p. 430)
- Drive modes* (p. 423)

Driving with the Start/Stop function

Start/Stop is a function that temporarily turns off the engine when the vehicle is stationary and then automatically starts it again when the vehicle starts moving.

The Start/Stop function is available when the engine is started and can be activated if certain conditions are met. The instrument panel indicates if the function is available, active or not available.

All of the vehicle's ordinary systems, such as lighting, radio, etc. function normally when the engine has been auto-stopped. Certain functions may be temporarily reduced, however, such as the climate system's blower speed or extremely high audio system volume.

Auto-stop

To auto-stop the engine:

 Stop the vehicle by applying the brakes and keep the brake pedal depressed. The engine will auto-stop.

In Eco or Comfort⁴ drive mode, the engine may auto-stop before the vehicle has completely stopped.

With Adaptive Cruise Control or Pilot Assist activated, the engine will auto-stop after approximately three seconds.

⁴ Normal start mode

Auto-start

The following conditions must be met for the engine to auto-start.

- Release the brake pedal. The engine will auto-start and the vehicle can be driven. On an uphill gradient, Hill Start Assist (HSA) will activate to help prevent the vehicle from rolling backward.
- When Auto-hold is activated, auto-start will be delayed until the accelerator is pressed.
- When Adaptive Cruise Control or Pilot Assist are activated, the engine will auto-start when the accelerator pedal is depressed or the button on the left-side steering wheel
- Maintain pressure on the brake pedal and press the accelerator pedal. The engine will auto-start.

keypad is pressed.

 On a downhill gradient: Release the brake pedal slightly so that the vehicle begins to roll. The engine will auto-start after a slight increase in speed.

Symbols in the instrument panel 12" instrument panel*

- **READY** will be displayed in the tachometer when Start/Stop is available.
- An indicator in the tachometer will point toward READY when Start/Stop is active and the engine has auto-stopped.

- READY will be grayed-out when Start/Stop is not available.
- No message will be shown when the function is turned off.



The function is active and the engine has auto-stopped.

8" instrument panel

The symbol is displayed at the bottom of the speedometer.

Symbol	Meaning
(A)	White symbol: the function is available.
(A)	Beige symbol: The function is active and the engine has autostopped.

Symbol	Meaning
(A)	the function is not available because the conditions have not been met.
	No symbol will be shown when the function is turned off.

- Temporarily deactivating the Start/Stop function (p. 430)
- Conditions for the Start/Stop function (p. 430)
- Start/Stop function (p. 428)
- Hill Start Assist (p. 416)
- Auto-hold brakes (p. 415)

Temporarily deactivating the Start/ Stop function

In certain situations, it may be advisable to temporarily turn the Start/Stop function off.



To turn off Start/Stop, tap the **Start/Stop** function button in the center display's Function view. The indicator light in the button will go out when the function has been turned off.

The function will remain turned off until:

- it is reactivated
- the drive mode is changed to Eco or Comfort
- the engine is restarted.

Related information

- Driving with the Start/Stop function (p. 428)
- Conditions for the Start/Stop function (p. 430)

Conditions for the Start/Stop function

Certain conditions must be met for Start/Stop to function.

If any condition is not met, this will be indicated in the instrument panel.

The engine does not auto-stop

The engine will not auto-stop if:

- the vehicle has not reached a speed of ca 10 km/h (6 mph) after starting.
- after several auto-stops, the speed must again exceed approximately ca 10 km/h (6 mph) before the next auto-stop.
- the driver's seat belt is unbuckled.
- the start battery's charge is below the minimum level.
- the engine is not running at its normal operating temperature.
- the ambient temperature is under approximately -5 °C (23 °F) or over approximately 30 °C (86 °F).
- windshield heating is activated.
- the climate system settings and the actual climate in the passenger compartment differ.
- the vehicle is backing up.
- the start battery's temperature is above or below the permitted limits.
- the driver is turning the steering wheel hard.

- the road gradient is very steep.
- the hood is open.
- driving at high altitude and the engine has not reached its normal operating temperature.
- ABS has been activated.
- hard braking (even if the ABS system has not been activated).
- many starts during a short period of time have triggered the starter motor's overheating protection.
- a trailer's electrical system is connected to the vehicle's electrical system.
- the transmission is not running at its normal operating temperature.
- The gear selector is in mode M (±).

The engine does not auto-start

The engine will not auto-start after an auto-stop if:

 the driver is not wearing a seat belt, the gear selector is in the P position and the driver's door is open. The engine must be started normally.

The engine auto-starts while the brake pedal is depressed

In the following situations, the engine will autostart even if the brake pedal is depressed:

- High levels of condensation on the inside of the windows.
- the climate system settings and the actual climate in the passenger compartment differ.
- Electrical current consumption is temporarily high or the start battery's charge is below the minimum level.
- The brake pedal is pumped repeatedly.
- The hood is open.
- The vehicle begins to roll or increases speed slightly if the engine auto-stopped before the vehicle was at a standstill.
- The driver's seat belt is unbuckled with the gear selector in the **D** or **N** positions.
- The gear selector is moved from **D** to **R** or **M** (±).
- The driver's door is opened with the gear selector in D. An audible signal and a text message informs the driver that the ignition is on.

Do not open the hood if the engine has autostopped. Turn off the engine by switching off the ignition before lifting the hood.

Related information

- Start/Stop function (p. 428)
- Driving with the Start/Stop function (p. 428)

Temporarily deactivating the Start/Stop function (p. 430)

Leveling control* and suspension

The vehicle's leveling control system adjusts the suspension and shock absorbers automatically to help provide good comfort and control while driving. Leveling can also be controlled manually to facilitate loading or getting in and out of the vehicle.

Pneumatic suspension and shock absorbers

The system is adapted to the selected drive mode and vehicle speed. The pneumatic suspension reduces the vehicle's ground clearance at higher speeds to reduce air resistance and increase stability. The shock absorbers are normally set to provide the best possible comfort

and are adjusted continuously according to the road surface and the vehicle's acceleration, braking and cornering.



The instrument panel indicates when the suspension level is being adjusted.

The level cannot be adjusted when any of the side doors or the tailgate is open.

Parking

When parking, make sure that there is adequate space above and below the vehicle since ground

clearance may vary depending on e.g. ambient temperature, how the vehicle is loaded, if loading mode is used, which drive mode is selected after the engine is started, etc.

The level may also be adjusted a period after the vehicle is parked. This is to compensate for any height changes that may occur due to temperature changes in the air springs when the vehicle cools.

Transporting

When transporting the vehicle on a ferry, train or truck, only secure (lash) the vehicle around the tires, not using any other parts of the chassis. Changes in the pneumatic suspension may occur during transport, which could adversely affect the lashing and result in damage.

Symbols and messages in driver display

Symbol	Message	Meaning
	Suspension Deactivated by user	Level control has been switched off manually by the user.
	Suspension Temporarily reduced performence	Level control performance has been temporarily reduced due to extensive system use. If this message appears frequently (e.g. several times in one week) contact a workshop ^A .
**************************************	Suspension Service required	A fault has occurred. Visit a workshop ^A as soon as possible.
- WW.	Suspension failure Stop safely	A critical fault has occurred. Stop safely, have the car towed to a workshop ^A .

44

1	Symbol	Message	Meaning
	-Wills	Suspension	A fault has occurred. If the message appears while driving, contact a workshop ^A .
		Slow down Vehicle too high	
		Suspension	Level control to target height is in progress.
		Auto adjusting vehicle level	

A An authorized Volvo workshop is recommended.

- Leveling control settings* (p. 435)
- Drive modes* (p. 423)

Leveling control settings*

The vehicle can be lowered or raised to make it easier to load or for passengers to get in and out.

Turn off leveling control before lifting the vehicle with a jack to help avoid problems with the pneumatic suspension.

Adjusting loading mode



Use the buttons in the cargo compartment to raise or lower the rear section of the vehicle to facilitate loading or unloading the vehicle or connecting or disconnecting a trailer.

Center display settings

Easy Entry and Exit Suspension Control

The vehicle can be lowered to make it easier to get in and out.

Activating easy entry in the center display:

- 1. Tap **Settings** in the Top view.
- Tap My Car → Mirrors and Convenience.
- Select Easy Entry and Exit Suspension Control.
 - > When the vehicle is parked and the engine is turned off, the level is lowered. (Level adjustment will stop if a side door is opened and will resume after a slight delay when the door has been closed.) When the engine is started and the vehicle begins to move, the level will be raised to the height set by the selected drive mode.

Disable Leveling Control

In certain situations, this function must be turned off, e.g. before the vehicle is raised using a jack*. The level difference caused by raising the vehicle with a jack could cause problems with the pneumatic suspension.

Turning off the function in the center display:

- 1. Tap **Settings** in the Top view.
- Tap My Car → Parking Brake and Suspension.
- 3. Select Disable Leveling Control.

Related information

- Leveling control* and suspension (p. 432)
- Loading recommendations (p. 564)

Low Speed Control*

The low-speed function, Low Speed Control (LSC), facilitates and improves control and traction on rough roads and slippery surfaces, e.g. when towing a trailer on grass or up boat ramps.

In vehicles equipped with drive mode control*, the function is included in the Off Road drive mode.

Low Speed Control is designed for driving on rough roads and when towing trailers at low speeds, up to approximately 40 km/h (25 mph).

When driving at low speeds, LSC prioritizes low gears and all-wheel drive to help avoid wheel spin and improve traction on all wheels. The accelerator pedal will be less responsive to improve traction and speed control at low speeds.

The function is activated together with Hill Descent Control (HDC), which makes it possible to control speed going down steep hills using the accelerator pedal and reduces the need to use the brake pedal. The system makes it possible to maintain a low and uniform speed when driving down steep hills.

NOTE

When LSC with HDC is activated, the feel of the accelerator pedal and engine response will change.



(i)

NOTE

This drive mode is not designed to be used for normal street driving.



NOTE

The function is deactivated when driving at high speeds and must be reactivated at lower speeds if so desired.

Related information

- Activating and deactivating Low Speed Control* using the function button (p. 436)
- Changing drive mode* (p. 425)
- Hill Descent Control* (p. 437)
- All Wheel Drive (AWD)* (p. 423)

Activating and deactivating Low Speed Control* using the function button

Vehicles that are not equipped with drive mode controls in the tunnel console have a function button for Low Speed Control with Hill Descent Control in the center display's Function view.

Selecting Low Speed Control in the center display's Function view

Tap the Hill Descent Control button to activate or deactivate the function.



> An indicator light in the button will illuminate when the function is activated.

When the engine is switched off, the function will be automatically deactivated.



(i) NOTE

The function is deactivated when driving at high speeds and must be reactivated at lower speeds if so desired.

Related information

- Low Speed Control* (p. 435)
- Changing drive mode* (p. 425)

Hill Descent Control*

The function for assisting when driving downhill, Hill Descent Control (HDC), is a low-speed function with increased engine braking. The function makes it possible to increase or decrease the vehicle's speed on steep downhill gradients by only using the accelerator pedal, without applying the brakes.

In vehicles equipped with drive mode control*, the function is included in the Off Road drive mode.

HDC is designed for driving on rough roads at low speeds and downhill gradients with slipperv or otherwise difficult road surfaces. The driver does not need to use the brake pedal but can instead focus on steering.



WARNING

HDC is only intended to be a supplementary braking aid and it does not function in all situations.

The driver is always ultimately responsible for operating the vehicle in a safe manner.

Function

Hill Descent Control allows the vehicle to move forward or backward at very low speeds assisted by the brake system. The driver can increase the speed by pressing the accelerator pedal. When the accelerator pedal is released, the vehicle will return to very low speed regardless of how steep the hill is and without the brakes needing to be applied. The brake lights will illuminate when the function is activated.

The driver can brake to stop or slow the vehicle at any time by depressing the brake pedal.

HDC is activated along with Low Speed Control (LSC), which facilitates and improves traction and control on rough and slippery surfaces. The system is intended to be used at low speeds, up to approximately 40 km/h (25 mph).

To keep in mind when using HDC

- If the function is switched off while driving on a steep downhill gradient, braking effect will be gradually reduced.
- HDC can be used in gear positions **D** and **R**, and in manual gears 1 or 2.
- It is not possible to manually shift to third gear or higher when HDC is active.



(i) NOTE

When LSC with HDC is activated, the feel of the accelerator pedal and engine response will change.



NOTE

This drive mode is not designed to be used for normal street driving.



NOTE

The function is deactivated when driving at high speeds and must be reactivated at lower speeds if so desired.

- Activating and deactivating Hill Descent Control* using the function button (p. 438)
- Changing drive mode* (p. 425)
- Low Speed Control* (p. 435)
- All Wheel Drive (AWD)* (p. 423)

Activating and deactivating Hill Descent Control* using the function button

Vehicles that are not equipped with drive mode controls in the tunnel console have a function button for Hill Descent Control with Hill Descent Control in the center display's Function view.

Selecting Hill Descent Control in the center display's Function view

HDC only works at low speeds.

 Tap the Hill Descent Control button to activate or deactivate the function.



> An indicator light in the button will illuminate when the function is activated.

When the engine is switched off, the function will be automatically deactivated.



NOTE

The function is deactivated when driving at high speeds and must be reactivated at lower speeds if so desired.

Related information

- Hill Descent Control* (p. 437)
- Changing drive mode* (p. 425)

Economical driving

Drive economically and environmentally conscious by thinking ahead, avoiding rapid starts and stops and adapting driving style and speed to the current traffic conditions.

Driving economically conserves natural resources

Observe the following rules:

- Do not warm up the engine by idling. It is better to begin driving normally immediately after starting the engine. A cold engine uses more fuel than a warm engine and is subject to increased wear.
- Whenever possible, avoid using the vehicle to drive short distances. The engine does not have time to reach a normal operating temperature and this leads to increased fuel consumption.
- Maintain a steady speed and a generous following distance to traffic ahead to minimize braking.
- For lower fuel consumption, activate Eco drive mode.
- Use the Eco Coast function in drive mode
 Eco engine braking is deactivated, allowing
 the vehicle's kinetic energy to be used to roll greater distances.
- Use gear **D** as often as possible and avoid using the kick-down function.

- Fuel consumption is increased at high speeds air resistance increases with speed.
- Remove unnecessary items from the vehicle

 the heavier the load, the higher the fuel
 consumption.
- Maintain the correct pressure in the tires and check pressure regularly.
- The type of tires used could affect fuel consumption - consult a retailer for advice on suitable tires.
- Do not use winter tires after the winter season has ended.
- Roof loads increase air resistance and increase fuel consumption. Remove roof boxes, ski racks, etc. that are not in use.
- Avoid driving with the windows open.
- Using the trip computer's fuel consumption indicators can help you learn how to drive more economically.

Other factors that decrease fuel consumption

- Dirty air cleaner.
- Dirty engine oil and clogged oil filter.
- Incorrect front-end alignment.
- Incorrect wheel alignment.

Some of the above items and others are checked as part of Volvo's standard maintenance schedule.

Related information

- Drive-E purer driving pleasure (p. 27)
- ECO drive mode (p. 426)
- Checking tire pressure (p. 535)

Preparing for a long trip

It is important to have the vehicle's systems and equipment checked carefully before driving long distances.

Check that:

- the engine is running properly and that fuel consumption is normal
- there are no leaks (fuel, oil or other fluid)
- the brake pedal is functioning optimally
- all lights are working adjust the headlight height if the vehicle is carrying a heavy load
- tire tread depth and air pressure are at correct levels. Change to snow tires when driving in areas where there is a risk of snowy or icy roads.
- the start battery is sufficiently charged
- the wiper blades are in good condition

- Checking tire pressure (p. 535)
- Filling washer fluid (p. 632)
- Winter driving (p. 440)
- Economical driving (p. 438)
- Vehicle modem settings (p. 511)
- Loading recommendations (p. 564)
- Driving with a trailer (p. 449)
- Pilot Assist (p. 309)

STARTING AND DRIVING

- Speed limiter (p. 276)
- Tire sealing system (p. 550)

Winter driving

It is important to check the vehicle before driving in cold/snowy conditions to make sure it can be driven safely.

Before the cold season arrives:

- Make sure the engine coolant contains 50% antifreeze. This mixture helps protect the engine from frost erosion down to approx. -35 °C (-31 °F). Do not mix different types of antifreeze as this could pose a health risk.
- Keep the fuel tank well filled to prevent condensation from forming.
- Check the viscosity of the engine oil. Oil with low viscosity (thinner oil) improves coldweather starting and reduces fuel consumption when driving with a cold engine.

CAUTION

Low-viscosity oil should not be used with hard driving or in hot weather.

- Check the condition and charge level of the start battery. Cold weather places greater demands on the start battery and reduces its capacity.
- Use washer fluid containing antifreeze to help prevent ice from forming in the washer fluid reservoir.

Slippery driving conditions

For optimal traction and roadholding, Volvo recommends using snow tires on all wheels whenever there is a risk of snow or ice on the road



NOTE

Certain countries require use of winter tires by law. Not all countries permit the use of studded tires.

Practice driving on slippery surfaces under controlled conditions to learn how the vehicle reacts.

- Snow tires (p. 549)
- Snow chains (p. 549)
- Braking on salted roads (p. 411)
- Braking on wet roads (p. 410)
- Filling washer fluid (p. 632)
- Start battery (p. 598)
- Replacing windshield wiper blades (p. 630)
- Changing rear window wipers (p. 629)
- Refilling coolant (p. 590)

Driving through standing water

Driving the vehicle through a deep pool of standing water on a water-covered roadway is called fording. This must be done with great caution. The vehicle can be driven through water up to a depth of 45 cm (17.7 in) at no more than walking speed. Be particularly careful when driving through flowing water.

When driving through standing water, drive slowly and do not stop the vehicle. When you have passed the water, press lightly on the brake pedal and check that the brakes are functioning properly. Water, mud, slush, etc. can make the brake linings slippery, resulting in delayed braking effect.

- If the vehicle is equipped with contacts for an electric heater or trailer coupling, clean these after driving in water or mud.
- Do not allow the vehicle to stand in water up to the sills any longer than absolutely necessary. This could result in electrical malfunctions.

(!) CAUTION

- Engine damage could occur if water enters the air cleaner.
- If water enters the transmission, the lubricating ability of the oils is reduced and the service life of these systems is shortened.
- Damage to any component, engine, transmission, turbocharger, differential or its internal components caused by flooding, vapor lock or insufficient oil is not covered under warranty.
- If the engine stalls while the vehicle is in water, do not attempt to restart it. Have the vehicle towed out of the water to a workshop. An authorized Volvo workshop is recommended. Risk of engine failure.

Related information

- Recovery (p. 455)
- Low Speed Control* (p. 435)

Opening/closing the fuel filler door

The vehicle must be unlocked before the fuel filler door can be opened⁵.



An arrow next to the fuel pump symbol in the instrument panel indicates the side of the vehicle on which the fuel filler door is located.

- 1. Open the fuel filler door by pressing lightly on its rear edge.
- 2. After refueling, press the fuel filler door lightly to close it.

Related information


Refueling (p. 442)

⁵ Only locking and unlocking using the remote key, Passive Entry or Volvo On Call will affect the status of the fuel filler door.

Refueling

The fuel tank is equipped with a fuel filling system without a cover.

Refueling the vehicle at a service station



Refueling is done as follows.

- Turn off the engine and open the fuel filler door.
- 2. Select a fuel approved for use in the vehicle. For more information on approved fuels, see the section on "Gasoline".
- Insert the pump's nozzle into the fuel filler pipe's opening. There are two flaps just inside the fuel filler pipe and the pump's nozzle must push both of these flaps open before fuel can be added.

- Avoid overfilling the tank. Do not press the handle on the filler nozzle again after it has initially stopped pumping.
 - > The fuel tank is now filled.



NOTE

An over-full tank may overflow in hot weather.

(!) CAUTION

Avoid spilling gasoline during refueling. In addition to causing damage to the environment, gasolines containing alcohol can cause damage to painted surfaces, which may not be covered under the New Vehicle Limited Warranty.

Refueling from a fuel container

When filling from a fuel container, use the funnel provided in a foam block under the floor hatch in the cargo compartment.

- 1. Open the fuel filler door.
- Insert the funnel into the fuel filler pipe's opening. There are two flaps just inside the fuel filler pipe and the tube section of the funnel must push both of these flaps open before fuel can be added.

Related information

Opening/closing the fuel filler door (p. 441)

Fuel

Volvo recommends the use of detergent gasoline to control engine deposits.

Deposit control gasoline (gasoline with detergent additives)

Detergent gasoline is effective in keeping injectors and intake valves clean. Consistent use of deposit control gasolines will help ensure good driveability and fuel economy. If you are not sure whether the gasoline contains deposit control additives, check with the service station operator.



NOTE

Volvo recommends not using external fuel injector cleaning systems, e.g. do not add detergent additives to gasoline before or after refueling.

Unleaded fuel

All Volvo vehicles have a three-way catalytic converter and must only use unleaded gasoline. US and Canadian regulations require that pumps delivering unleaded gasoline are labeled "UNLEADED". Only the nozzles of these pumps will fit in your vehicle's fuel filler inlet. It is unlawful to dispense leaded fuel into a vehicle labeled "unleaded gasoline only". Leaded gasoline damages the three-way catalytic converter and the heated oxygen sensor system. Repeated use of leaded gasoline will lessen the effectiveness of

the emission control system and could result in loss of emission warranty coverage. State and local vehicle inspection programs will make detection of misfueling easier, possibly resulting in emission test failure for misfueled vehicles.



NOTE

Some U.S. and Canadian gasolines contain an octane enhancing additive called methyl-cyclopentadienyl manganese tricarbonyl (MMT). If such fuels are used, your Emission Control System performance may be affected, and the Check Engine Light (malfunction indicator light) located on your instrument panel may light. If this occurs, please return your vehicle to a trained and qualified Volvo service technician for service.

Gasoline containing alcohol and ethers, "Oxygenated fuels"

Some fuel suppliers sell gasoline containing "oxygenates" which are usually alcohols or ethers. In some areas, state or local laws require that the service pump be marked indicating use of alcohols or ethers. However, there are areas in which the pumps are unmarked. If you are not sure whether there is alcohol or ethers in the gasoline you buy, check with the service station operator. To meet seasonal air quality standards, some areas require the use of "oxygenated" fuel.

Volvo permits the use of the following "oxygenated" fuels. However, the specified octane ratings must still be met.

Alcohol - Ethanol

Fuels containing up to 10% ethanol by volume may be used. Ethanol may also be referred to as Ethyl alcohol, or "Gasohol".

Ethers - MTBE/ETBE: Fuels containing up to 15% MTBE/ETBE may be used.

Methanol

Do not use gasolines containing methanol (methyl alcohol, wood alcohol). This practice can result in vehicle performance deterioration and can damage critical parts in the fuel system. Such damage may not be covered under the New Vehicle Limited Warranty.

Related information

- Octane rating (p. 443)
- Opening/closing the fuel filler door (p. 441)
- Refueling (p. 442)
- Emission controls (p. 445)

Octane rating

Volvo demands premium fuel (91 octane⁶ or higher) for all T5, T6 and T8 engines. See both supplied decal examples.

⁶ AKI (Anti Knock Index) is an average value of RON (Research Octane Number) and MON (Motor Octane Number) - (RON)+(MON)/2

◀ Minimum octane

Decals



Sample fuel pump octane label⁶.



Decal on the inside of the fuel filler flap on cars that require premium fuel⁷.

TOP TIER Detergent Gasoline

Volvo endorses the use of "TOP TIER Detergent Gasoline" where available to help maintain engine performance and reliability. TOP TIER Detergent Gasoline meets a new standard jointly established by leading automotive manufactures to meet the needs of today's advanced engines. Qualifying gasoline retailers (stations) will, in most cases, identify their gasoline as having met the "TOP TIER Detergent Gasoline" standards.

i NOTE

Information about TOP TIER Detergent Gasoline is available at www.toptiergas.com.

(i) NOTE

When switching to higher octane fuel or changing gasoline brands, it may be necessary to fill the tank more than once before a difference in engine operation is noticeable.

Fuel Formulations

Do not use gasoline that contains lead or manganese as a knock inhibitor, and do not use lead additives. Besides damaging the exhaust emission control systems on your vehicle, lead has been strongly linked to certain forms of cancer.

Many fuels contain benzene as a solvent. Unburned benzene has been strongly linked to certain forms of cancer. If you live in an area where you must fill your own gas tank, take precautions. These may include:

- standing upwind away from the filler nozzle while refueling
- refueling only at gas stations with vapor recovery systems that fully seal the mouth of the filler neck during refueling
- wearing neoprene gloves while handling a fuel filler nozzle.

Use of Additives

With the exception of gas line antifreeze during winter months, do not add solvents, thickeners, or other store-bought additives to your vehicle's fuel, cooling, or lubricating systems. Overuse may damage your engine, and some of these additives contain organically volatile chemicals. Do not needlessly expose yourself to these chemicals.

MARNING

Never carry a cell phone that is **switched on** while refueling your vehicle. If the phone rings, this may cause a spark that could ignite gasoline fumes, resulting in fire and injury.

⁶ AKI (Anti Knock Index) is an average value of RON (Research Octane Number) and MON (Motor Octane Number) - (RON)+(MON)/2

⁷ For supplementary information - see the car's Service and Warranty Booklet.

Λ

WARNING

Carbon monoxide is a poisonous, colorless, and odorless gas. It is present in all exhaust gases. If you ever smell exhaust fumes inside the vehicle, make sure the passenger compartment is ventilated, and immediately return the vehicle to a trained and qualified Volvo service technician for correction.

Demanding driving

In demanding driving conditions, e.g. when driving in a hot climates, driving with a trailer or driving for longer periods at higher altitudes (mountain landscapes) than normal, it is recommended switching to a higher octane fuel than AKI 91⁶ or changing gasoline brand to take full advantage of your car's engine capacity and obtain the optimum driving force.

Related information

- Fuel (p. 442)
- Emission controls (p. 445)

Emission controls

Three-way catalytic converter

- Keep your engine properly tuned. Certain
 engine malfunctions, particularly involving the
 electrical, fuel or distributor ignition systems,
 may cause unusually high three-way catalytic
 converter temperatures. Do not continue to
 operate your vehicle if you detect engine
 misfire, noticeable loss of power or other
 unusual operating conditions, such as engine
 overheating or backfiring. A properly tuned
 engine will help avoid malfunctions that
 could damage the three-way catalytic converter.
- Do not park your vehicle over combustible materials, such as grass or leaves, which can come into contact with the hot exhaust system and cause such materials to ignite under certain wind and weather conditions.
- Excessive starter cranking (in excess of one minute), or an intermittently firing or flooded engine can cause three-way catalytic converter or exhaust system overheating.
- Remember that tampering or unauthorized modifications to the engine, the Engine Control Module, or the vehicle may be illegal and can cause three-way catalytic converter or exhaust system overheating. This includes: altering fuel injection settings or components, altering emission system components

or location or removing components, and/or repeated use of leaded fuel.



NOTE

Unleaded fuel is required for vehicles with three-way catalytic converters.

Heated oxygen sensors

The heated oxygen sensors monitor the oxygen content of the exhaust gases. Readings are fed into a control module that continuously monitors engine functions and controls fuel injection. The ratio of fuel to air into the engine is continuously adjusted for efficient combustion to help reduce harmful emissions.

- Octane rating (p. 443)
- Fuel (p. 442)

⁶ AKI (Anti Knock Index) is an average value of RON (Research Octane Number) and MON (Motor Octane Number) - (RON)+(MON)/2

Overheating of engine and transmission

In demanding driving conditions, such as driving in mountainous areas or hot weather, there is a risk of the engine or transmission overheating, especially when carrying heavy loads.

- Engine power may be temporarily limited.
- Remove any auxiliary lights mounted in front of the grille when driving in hot weather.
- If the temperature in the engine's cooling system becomes too high, a warning symbol will appear in the instrument panel along with the message Engine temperature High temperature Stop safely. Pull over to a safe location and let the engine idle for a few minutes to cool down.
- If the message Engine temperature High temperature Turn off engine or Engine coolant Level low, turn off engine is displayed, stop the vehicle and turn off the engine.
- If the transmission begins to overheat, an alternative gear shifting program will be selected. An integrated protective function will also be activated, the warning symbol will illuminate and the message Transmission warm Reduce speed to lower temperature or Transmission hot Stop safely, wait for cooling will be displayed in the instrument panel. Follow the recommendations given by reducing speed or stopping

the vehicle safely and letting the engine idle for a few minutes to let the transmission

- If the vehicle begins to overheat, the air conditioning may be temporarily switched off.
- After a prolonged period of driving in demanding conditions, do not turn off the engine immediately after stopping.

$|(\mathbf{i})|$

NOTE

Symbol Meaning

It is normal for the engine's cooling fan to operate for a short time after the engine is switched off.

Symbols in the instrument panel

,	-
} } π	High engine temperature. Follow the recommendations provided.
	Low coolant level. Follow the recommendations provided.
(D)	Transmission hot/overheated/cooling. Follow the recommendations provided.

Related information

- Refilling coolant (p. 590)
- Driving with a trailer (p. 449)
- Preparing for a long trip (p. 439)
- Gear indicator* (p. 422)

Battery drain

The electrical functions in the vehicle drain the battery to varying degrees. Avoid using ignition mode II when the engine is switched off. Use ignition mode I instead, as this uses less electrical current.

Note that certain accessories may also drain power from the electrical system. Do not use functions that use a lot of electrical current when the engine is turned off. Examples of such functions are:

- blower
- headlights
- windshield wipers
- audio system (especially at high volume).

If the starter battery voltage is low, a message is shown in the driver display. The vehicle's energy-saving function will then turn off or reduce certain functions, such as the blower and/or the audio system.


 Charge the battery by starting the engine and let it run for at least 15 minutes (driving charges the battery faster than letting the engine idle).

Related information

- Start battery (p. 598)
- Ignition modes (p. 407)

Jump starting using another battery

If the start battery is discharged, current from another battery can be used to start the vehicle.



Jumper cable connecting points.

To avoid short circuits or other damage, the following steps are recommended when jump starting the battery using another battery:

- 1. Put the ignition in mode **0**.
- Make sure the auxiliary battery (the battery used to jump start the discharged battery) has a voltage of 12 volts.
- If the auxiliary battery is in another vehicle, turn off that vehicle's engine and make sure that the vehicles are not touching each other.

4. Clamp the red jumper cable onto the auxiliary battery's positive (+) terminal (1).

! CAUTION

Connect the jump cable carefully to prevent short circuits with other components in the engine compartment.

- Fold back the cover over your vehicle's positive (+) jump start terminal (2).
- 6. Clamp the other end of the red jumper cable to your vehicle's positive (+) jump start terminal (2).
- 7. Clamp the black jumper cable onto the auxiliary battery's negative (-) terminal (3).
- 8. Clamp the other end of the black jumper cable to your vehicle's negative (-) ground point (4).
- Make sure the jumper cables are securely attached to help prevent sparks while jump starting.
- Start the engine of the assisting vehicle and let it run for a few minutes at a higher idling speed than normal, about 1500 rpm.

11. Start the engine of the vehicle with the dead battery.



CAUTION

Do not touch the connections between the cable and the vehicle during the start attempt. Risk of sparking.

12. Remove the jumper cables in the reverse order – first the black cables and then the red cables.

Make sure that none of the clamps of the black jumper cables come into contact with either vehicle's positive (+) jump start terminals or either of the red jumper cable's connected clamps.



WARNING

PROPOSITION 65 WARNING! Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the state of California to cause cancer and reproductive harm. Wash hands after handling.

♠ WARNING

- Batteries generate hydrogen gas, which is flammable and explosive.
- Do not connect the jumper cable to any part of the fuel system or to any moving parts. Avoid touching hot manifolds.
- Battery fluid contains sulfuric acid. Do not allow battery fluid to contact eyes, skin, fabrics or painted surfaces.
- If contact occurs, flush the affected area immediately with water. Obtain medical help immediately if eyes are affected.
- Never expose the battery to open flame or electric spark. Do not smoke near the battery. Failure to follow the instructions for jump starting can lead to injury.

Related information

- Starting the vehicle (p. 404)
- Ignition modes (p. 407)
- Adjusting the steering wheel (p. 203)
- Selecting ignition mode (p. 408)


Detachable towbar*

Volvo recommends the use of Volvo towbars that are specially designed for the vehicle.



NOTE

The optional detachable trailer hitch may not be available in all markets or on all models. Consult your Volvo retailer.



- A Ball holder
- Cotter pin
- Towbar assembly
- Locking bolt
- Safety wire attachment bracket

Installing the ball holder

- If necessary, remove the cotter pin from the locking bolt and slide the locking bolt out of the towbar assembly.
- 2. Slide the ball holder into the towbar assembly.
- 3. Align the hole in the ball holder with the one in the towbar assembly.
- 4. Slide the locking bolt through the towbar assembly/ball holder.
- 5. Insert the cotter pin in the hole at the end of the locking bolt.

- Be sure the towbar is securely locked in position before attaching anything to it.
- Always attach the trailer's safety wire securely to the towbar's safety wire attachment bracket.

Removing the ball holder

- Remove the cotter pin from the locking bolt and slide the locking bolt out of the ball holder/towbar assembly.
- 2. Pull the ball holder out of the towbar assembly.

Stowing the ball holder

Λ

WARNING

When not in use, the detachable ball holder should always be properly stowed in the designated location under the floor of the cargo compartment.

Related information

- Driving with a trailer (p. 449)
- Towing capacity and tongue weight (p. 642)

Driving with a trailer

There are a number of things to consider when towing a trailer, such as the towbar, the trailer and how the load is distributed in the trailer.

Load-carrying capacity is determined by the vehicle's curb weight. The total weight of all passengers and any installed accessories, e.g. towbar, reduces the vehicle's load-carrying capacity by the corresponding amount.

- Towbars used on the vehicle must be approved for the applicable use.
- Distribute the load on the trailer so that the weight on the towbar complies with the specified maximum towball weight. The tongue weight is calculated as part of the vehicle's payload.
- Increase the tire pressure to the recommended pressure for a full load.
- The engine is subjected to more load than usual when towing a trailer.
- Towing a trailer affects the vehicle's handling, durability and driving economy.
- Do not drive with a heavy trailer when the vehicle is very new. Wait until the mileage has reached at least 1000 km (620 miles).
- On long and steep downgrades, the vehicle's brakes are subjected to much more load than usual. When manually shifting, downshift and adapt speed accordingly.

- Follow applicable regulations regarding permitted speed and weight.
 - Drive slowly when towing a trailer up a long and steep incline.
 - The maximum trailer weights given only apply to altitudes up to 1000 meters (3280 feet) above sea level. At higher altitudes, engine power (and thus the vehicle's climbing ability) is decreased due to the reduced air density, and the maximum trailer weight must therefore be reduced. The weight of the vehicle and trailer must be decreased by 10% for each additional 1000 m (3280 feet) or part thereof.
 - Avoid driving with a trailer on inclines of more than 12%.
 - Avoid overloading and other incorrect use.
 - The trailer's brakes must be balanced with the vehicle's brakes to help ensure safe stops (follow applicable local regulations).

! CAUTION

- Bumper-attached trailer hitches must not be used on Volvos, nor should safety chains be attached to the bumper.
- Trailer hitches attaching to the vehicle rear axle must not be used.
- Never connect a trailer's hydraulic brake system directly to the vehicle brake system, nor a trailer's lighting system directly to the vehicle lighting system. Consult your nearest authorized Volvo retailer for correct installation.
- When towing a trailer, the trailer's safety chains or wire must be correctly fastened to the attachment points provided in the trailer hitch on the vehicle. The safety chain or wire must never be fastened to or wound around the towing ball.

i) NOTE

The optional detachable trailer hitch may not be available in all markets or on all models. Consult your Volvo retailer.

i NOTE

Extreme weather conditions, towing a trailer, driving at high altitudes and fuel quality are factors that significantly increase a vehicle's fuel consumption.

Trailer weights

MARNING

Please adhere to the recommendations provided for trailer weight. If the recommendations are not followed, the vehicle and trailer may be difficult to control during evasive maneuvers and braking.

(i) 1

NOTE

The specified maximum trailer weights are those permitted by Volvo. National vehicle regulations may set additional restrictions on trailer weight and speed. The trailer hitches may be certified for higher towing weights than the vehicle is permitted to tow.

Self-leveling suspension*

The vehicle's self-leveling system attempts to keep the vehicle at a constant level, regardless of load (up to the maximum permitted weight). When the vehicle is stationary, the rear end of the vehicle will be slightly lowered, which is normal.

Driving in hilly terrain or hot weather

In certain conditions, there is a risk of overheating when driving with a trailer. If overheating of the engine and drive system is detected, a warning symbol will illuminate in the instrument panel along with a message.

The automatic transmission selects the optimal gear for the current load and engine speed.

Steep inclines

Do not lock the automatic transmission into a higher gear than what the engine can handle – it is not always preferable to drive in high gears at low rpm.

Parking on a hill

- 1. Depress the brake pedal.
- 2. Apply the parking brake.
- 3. Put the gear selector in P.
- 4. Release the brake pedal.

Put chocks behind the wheels when the vehicle is parked on a hill with a trailer attached.

Starting on a hill

- 1. Depress the brake pedal.
- 2. Put the gear selector in **D**.
- Release the parking brake.
- 4. Release the brake pedal and start driving.

Related information

- Trailer Stability Assist* (p. 451)
- Checking trailer lights (p. 452)
- Towing capacity and tongue weight (p. 642)
- Overheating of engine and transmission (p. 446)

Trailer Stability Assist (TSA⁸) is a function designed to help stabilize a vehicle that is towing a trailer when the vehicle and trailer have begun to sway. The function is part of the Electronic Stability Control system ESC⁹.

Reasons for swaying

A vehicle towing a trailer may begin to sway for various reasons. Normally this only occurs at high speeds. However, if the trailer is overloaded or unevenly distributed, e.g. too far back, there is a risk of swaying even at low speeds.

Swaying may be caused by factors such as:

- The vehicle and trailer are hit by a sudden, strong crosswind.
- The vehicle and trailer are traveling on an uneven road or over a bump.
- Sudden movements of the steering wheel.

Once swaying has begun, it can be difficult or impossible to stop it. This makes the vehicle and trailer difficult to control and there is a risk of swerving into oncoming traffic or driving off the road.

Trailer Stability Assist function

Trailer Stability Assist continuously monitors the vehicle's movements, particularly lateral move-

ments. If swaying is detected, the brakes are applied individually on the front wheels, which has a stabilizing effect on the vehicle and trailer. This is often enough to enable the driver to regain control of the vehicle.

If the Trailer Stability Assist function's first attempt is not adequate to stop the swaying motion, the brakes are applied on all wheels and engine power is temporarily reduced. As the swaying motion begins to decrease and the vehicle and trailer have once again become stable, TSA stops regulating the brakes/engine power and the driver regains control of the vehicle.



NOTE

Trailer Stability Assist is deactivated if the driver selects the sport mode by deactivating **ESC** in the center display's menu system.

Trailer Stability Assist may not intervene if the driver tries to compensate for the swaying motion by moving the steering wheel rapidly, because the system will then not be able to determine if it is the trailer or the driver causing the swaying.

Trailer Stability Assist*

⁸ Trailer Stability Assist

⁹ Electronic Stability Control

•



When Trailer Stability Assist is activated, the **ESC** symbol is displayed in the instrument panel.

Related information

- Driving with a trailer (p. 449)
- Electronic Stability Control (p. 272)

Checking trailer lights

When connecting a trailer, make sure that all of the lights on the trailer are functioning before starting to drive.

Trailer turn signals and brake lights

If one or more of the turn signals or brake lights on the trailer is not working, a symbol and message will be displayed in the instrument panel. The other lights on the trailer must be checked manually by the driver before the vehicle is driven.

Symbol	Message
←	 Trailer turn indicator Right turn indicator malfunction Trailer turn indicator Left turn indicator malfunction
(E)	Trailer brake light Malfunction

If any of the trailer's turn signal lights is not working, the turn signal symbol in the instrument panel will also flash more quickly than normal.

Trailer rear fog light

When a trailer is connected, the vehicle's rear fog light may not illuminate and rear fog light functionality is instead transferred to the trailer. If this is the case, check to see if the trailer is equipped with a rear fog light before activating the vehicle's

fog lights when driving with a trailer to help ensure safe operation.

Checking trailer lights*

Automatic check

When the trailer has been connected to the vehicle's electrical system, its lights can be checked by automatically activating them. This function helps the driver check that the trailer's lights are functioning correctly before starting to drive.

In order to perform this check, the engine must be turned off.

- When a trailer is connected to the towbar, the message Automatic Trailer Lamp Check will appear in the instrument panel.
- Acknowledge the message by pressing the O button on the right-side steering wheel keypad.
 - > The light check will begin.
- 3. Get out of the vehicle to perform the check.
 - All of the lights on the trailer will begin flashing, and then illuminate separately one at a time.
- 4. Visually check that all of the trailer's lights are functioning correctly.
- 5. After a short time, all of the trailer's lights will start flashing again.
 - > The light check is completed.

Disabling the automatic check

The automatic light check can be disabled in the center display.

- 1. Tap **Settings** in the Top view.
- Tap My Car → Lights and Lighting.
- 3. Deselect Automatic Trailer Lamp Check.

Manual check

If the automatic check has been disabled, the check can be started manually.

- 1. Tap **Settings** in the Top view.
- Tap My Car → Lights and Lighting.
- 3. Select Manual Trailer Lamp Check.
 - > The light check will begin. Get out of the vehicle to perform the check.

Related information

• Driving with a trailer (p. 449)

Towing using a towline

This section refers to one vehicle being towed behind another using a towline.

Before towing another vehicle, check applicable speed limit regulations.

Preparations and towing

(!) CAUTION

Note that the vehicle must always be towed with the wheels rolling forward.

 Do not tow a vehicle with automatic transmission at a speed greater than 80 km/h (50 mph) or for a distance greater than 80 km (50 miles).

. WARNING

- Ignition mode II must be active all airbags are deactivated in ignition mode I.
- Always have the remote key in the vehicle when it is towed.

★ WARNING

The brake and steering servos do not work when the engine is off – it takes about 5 times more pressure on the brake pedal and steering requires much more effort than normal.

- 1. Turn on the hazard warning flashers.
- 2. Attach the towline to the towing eyelet.
- Put the vehicle in ignition mode II without pressing the brake pedal, turn the start knob clockwise and hold it there for about 4 seconds. Release the knob, which will automatically return to its original position.
- 4. Move the gear selector to neutral **(N)** and release the parking brake.

If the battery charge level is too low, it may not be possible to release the parking brake. Connect an auxiliary battery to the vehicle if the battery is discharged.

- > The towing vehicle can now start driving.
- Keep the towline taut when the towing vehicle slows down by applying light pressure to the brake pedal. This will help avoid jarring movements.
- Be prepared to apply the brakes to stop the vehicle.

Jump starting

Do not tow the vehicle to start the engine. Use an auxiliary battery if the start battery's charge level is so low that the engine cannot be started.

(!) CAUTION

Attempting to tow with the engine running could result in damage to the three-way catalytic converter.

Related information

- Attaching and removing the towing eyelet (p. 454)
- Hazard warning flashers (p. 164)
- Recovery (p. 455)
- Jump starting using another battery (p. 447)
- Selecting ignition mode (p. 408)

Attaching and removing the towing eyelet


Use the towing eyelet when towing. Screw the towing eyelet securely into place in the threaded outlet behind the cover on the right-hand side of the front and rear bumpers.

(i)


NOTE

If the vehicle is equipped with a towbar, there is no rear attachment for the towing eye.


Attaching the towing eyelet



Take out the towing eyelet, which is stored in a foam block under the floor in the cargo compartment.



- Front: Remove the cover by pressing on the mark with a finger.
 - > The cover turns along its center line and can then be removed.



- Rear: Remove the cover press the marker with your finger while prying open the opposite side/corner open with a coin or similar.
 - > The cover turns along its center line and can then be removed.

 Screw in the towing eyelet until it reaches its stop. Fasten the eyelet securing by, for example, inserting a lug wrench* through it and using this as a lever.



(I) CAUTION

It is important that the towing eye is screwed in securely as far as possible.

Removing the towing eyelet:

 After use, unscrew the towing eyelet and return it to its storage location.

Replace the cover on the bumper.

In certain conditions, the towing eyelet may be used to pull the vehicle onto a flatbed tow truck. The vehicle's position and ground clearance determines if this is possible.

If the incline of the tow truck is too steep or if the ground clearance under the vehicle is insufficient,

attempting to pull it up using the towing eyelet may result in damage.

If necessary, lift the vehicle using the tow truck's lifting device instead of using the towing eyelet.

∕↑ WARNING

No person or object should be behind the tow truck when the vehicle is lifted onto the bed of the truck.

(!) CAUTION

The towing eyelet is only intended for towing on roads, and must **not** be used to pull vehicles from ditches or any similar purpose involving severe strain. Call a tow truck for professional assistance.

Related information

- Towing using a towline (p. 453)
- Recovery (p. 455)
- Tool kit (p. 542)

Recovery

This section refers to transporting the vehicle with a tow truck or similar vehicle.

Call a professional towing service for assistance.

In certain conditions, the towing eyelet can be used to pull the vehicle onto a flatbed tow truck.

For vehicles equipped with leveling control*:

If the vehicle is equipped with pneumatic suspension, this feature must be turned off before the vehicle is lifted onto a tow truck. Turning off the function in the center display.

- 1. Tap **Settings** in the Top view.
- Tap My Car → Parking Brake and Suspension.
- Select Disable Leveling Control.

The vehicle's location and ground clearance determine if it can be lifted onto a tow truck. If the incline of the tow truck is too steep or if the ground clearance under the vehicle is insufficient, attempting to pull it up may result in damage. In this case, the vehicle should only be lifted with the tow truck's lifting equipment.

MARNING

No person or object should be behind the tow truck when the vehicle is lifted onto the bed of the truck.

(I) CAUTION

The towing eyelet is only intended for towing on roads, and must **not** be used to pull vehicles from ditches or any similar purpose involving severe strain. Call a tow truck for professional assistance.

(!) CAUTION

Note that the vehicle must always be towed with the wheels rolling forward.


Related information

 Attaching and removing the towing eyelet (p. 454)

HomeLink®*10

HomeLink^{®11} is a programmable remote control, integrated in the vehicle electrical system, that can control up to three different devices (e.g. garage door opener, alarm system, outdoor and indoor lighting, etc.) and thereby replace the remote controls for these.

General



The illustration is generic - the design may vary.

- Button 1
- Button 2
- Button 3
- 4 Indicator light

HomeLink® is delivered integrated in the rearview mirror. The HomeLink® panel consists of three programmable buttons and an indicator light in the mirror.

For more information about HomeLink®, please visit www.HomeLink.com, www.youtube.com/ HomeLinkGentex or call 1-800-355-3515.

Save the original remote controls for future programming (e.g. for use in another vehicle). It is also advisable to delete the button programming if the vehicle is sold.

Related information

- Using HomeLink (p. 458)
- Programming HomeLink®* (p. 457)
- Type approval for HomeLink®* (p. 459)

¹⁰ Certain markets only.

¹¹ HomeLink and the HomeLink house symbol are registered trademarks of Gentex Corporation.

Programming HomeLink®*12

Follow these instructions to program HomeLink®, reset all programming, or program individual buttons.




In some vehicles, the ignition must be on or in the "accessory position" before HomeLink® can be programmed or used. It can be a good idea to put new batteries in the remote control being replaced by HomeLink® for faster programming and better radio signal transmission. The HomeLink® buttons should be reset before programming.

While HomeLink[®] is being programmed, the garage door or gate being programmed may be activated. Make sure that no one is near the door or gate during programming. When programming a garage door opener, it is advised to park outside of the garage.

- Point the remote control at the HomeLink[®] button to be programmed and hold it about 2-8 cm (1-3 inches) from the button. Do not obstruct the HomeLink[®] indicator light.
 - **Note:** Some remote controls are more effective at programming HomeLink® from a distance of about 15-20 cm (6-12 inches). Try moving the remote control closer or further away if you are experiencing any difficulties programming.
- Press and hold both the remote control button and the HomeLink® button to be programmed.
- Do not release the buttons until the indicator light has stopped flashing slowly (about once a second) and either flashes quickly (about 10 times a second) or glows steadily.
 - > **Steady glow:** Indication that programming is complete. Press the programmed button twice to activate.

Flashing quickly: The device being programmed with HomeLink® may have a security function that requires an extra step. Try pressing the programmed button twice to see whether the programming works. Otherwise, continue with the following steps.



- Locate the "training" button¹³ on the receiver for the e.g. garage door opener. It is usually located near the antenna bracket on the receiver.
- Press and release the "training" button once. Programming must be completed within 30 seconds after pressing the button.
- Press and release the HomeLink® button to be programmed. Repeat the press/hold/ release sequence a second time. For some receivers, the sequence may need to be repeated a third time.
 - Programming is now completed and the garage door, gate, etc. should now be activated when the programmed button is pressed.

If you experience any difficulties programming, please contact HomeLink® at:

¹² Certain markets only.

¹³ The name and color of the button varies depending on the manufacturer.

www.HomeLink.com, www.youtube.com/ HomeLinkGentex or call 1-800-355-3515.

Programming individual buttons

To program an individual HomeLink® button:

- Press and hold the desired button for about 20 seconds.
- When the indicator light on HomeLink® starts flashing slowly, it is possible to program as usual.

Note: If the button you are reprogramming does not program with a new device, it will return to the previously saved programming.

Resetting the HomeLink® buttons

It is only possible to reset all HomeLink® buttons at once. It is not possible to reset individual buttons. Individual buttons can only be reprogrammed.

- Press and hold the outer buttons (1 and 3) on HomeLink[®] for about 10 seconds.
 - > When the indicator light goes from a steady glow to flashing, the buttons have been reset and are ready for reprogramming.

Related information

- Using HomeLink (p. 458)
- HomeLink®* (p. 456)
- Type approval for HomeLink®* (p. 459)

Using HomeLink

Once HomeLink® is programmed, it can be used instead of the separate remote controls. Press and hold the programming button. The garage door, gate, alarm system, etc. will be activated (this may take several seconds). If the button is held down for more than 20 seconds, reprogramming will begin. The indicator light will glow steadily or flash when the button has been pressed. The original remote controls may be used concurrently with HomeLink® if desired.

(i)

NOTE

If the ignition is off, HomeLink® works for 30 minutes after the driver's door has been opened.

↑ WARNING

- If you use HomeLink® to open a garage door or gate, be sure no one is near the gate or door while it is in motion.
- Do not use HomeLink® with any garage door opener that lacks safety stop and reverse features as required by US federal safety standards (this includes any garage door opener model manufactured before April 1, 1982). A garage door that cannot detect an object - signaling the door to stop and reverse - does not meet current U.S. federal safety standards. For more information, contact HomeLink at: www.homelink.com.

Related information

- HomeLink^{®*} (p. 456)
- Programming HomeLink®* (p. 457)
- Type approval for HomeLink®* (p. 459)

Type approval for HomeLink®*14

FCC (USA) and IC (Canada)

This device complies with FCC rules part 15 and Industry Canada RSS-210. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference that may be received including interference that may cause undesired operation.

⚠ WARNING

The transmitter has been tested and complies with FCC and IC rules. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device. 15

Type approval for EU

Gentex Corporation hereby declares that HomeLink® Model UAHL5 complies with the Radio equipment directive 2014/53/EU.

Wavelengths within which the radio equipment operates:

- 433.05MHz-434.79MHz <10mW E.R.P.
- 868.00MHz-868.60MHz <25mW E.R.P.
- 868.70MHz-868.20MHz <25mW E.R.P.
- 869.40MHz-869.65MHz <25mW E.R.P.

869.70MHz-870.00MHz <25mW E.R.P.

Certificate holder address: Gentex Corporation, 600 North Centennial Street, Zeeland MI 49464, USA

For more information, see support.volvocars.com.

Related information

HomeLink^{®*} (p. 456)

Compass

An integrated compass in the upper right corner of the rearview mirror shows the direction the vehicle is traveling.



Rearview mirror with compass.

Eight different compass directions are shown with the abbreviations: N (north), NE (northeast), E (east), SE (southeast), S (south), SW (southwest), W (west) and NW (northwest).

- Activating and deactivating the compass (p. 460)
- Calibrating the compass (p. 460)

¹⁴ Certain markets only.

¹⁵ The term "IC:" before the certification/registration number only signifies that Industry Canada technical specifications were met.

Activating and deactivating the compass

An integrated compass in the upper right corner of the rearview mirror shows the direction the vehicle is traveling.

Activating and deactivating the compass

The compass is automatically activated when the vehicle is started.

To deactivate/activate the compass manually:

 Use a paper clip or similar object to press the button on the bottom of the mirror.

Related information

- Compass (p. 459)
- Calibrating the compass (p. 460)

Calibrating the compass

The globe is divided into 15 magnetic zones. The compass should be calibrated if the vehicle is driven from one zone to another.


To calibrate the compass:

- Stop the vehicle in a large, open area away from steel constructions and high-voltage power lines.
- Start the engine and switch off all electrical equipment (climate system, wipers, etc.) and make sure all doors are closed.

(i) NOTE

Calibration may fail or not even be initiated if electrical equipment is not turned off.

Hold the button on the bottom of the rearview mirror pressed for about 3 seconds
(using e.g. a paper clip). The number of the
current magnetic zone is shown.




Magnetic zones.

- Press the button on the underside of the mirror repeatedly until the desired magnetic zone (1-15) appears (see the map of magnetic zones).
- Wait until the display again shows C, or press and hold the button on the underside of the rearview mirror for approx. 6 seconds until C is displayed.
- Drive slowly in a circle at a speed of no more than 10 km/h (6 mph) until a compass direction is shown in the display. This indicates that calibration is complete. Drive in a circle two more times to fine-tune the calibration.
- Vehicles with heated windshields*: If C is shown in the display when the windshield heating function is activated, perform step 6 above with the heating function on.

8. Repeat the above procedure as needed.

- Compass (p. 459)
- Activating and deactivating the compass (p. 460)



Audio, media and Internet

The audio and media system consists of a media player and a radio. A cellular phone can also be connected through Bluetooth to use hands-free functions or play music in the vehicle. When the vehicle is connected to the Internet, it is also possible to use apps to play media.



Audio and media overview

The functions can be controlled using voice commands, the steering wheel keypad or the center display. The number of speakers and amplifiers varies depending on the audio system installed in the vehicle.

System updates

The audio and media system is continuously improved. When the vehicle has an Internet connection, system updates can be downloaded for optimal functionality; see support.volvocars.com.

Related information

- Media player (p. 485)
- Radio (p. 468)
- Phone (p. 498)
- Internet-connected vehicle* (p. 507)
- Apps (p. 465)
- Voice control (p. 147)
- Ignition modes (p. 407)
- Driver distraction (p. 39)
- Handling system updates via Download Center (p. 579)
- License agreement for audio and media (p. 517)

Sound settings

The audio system is precalibrated for optimal sound reproduction but these settings can be personalized.

The system's volume is normally adjusted using the volume control below the center display or the right-side steering wheel keypad. This applies, for example, when playing music or the radio or during phone calls and active traffic messages.

Optimal sound reproduction

The audio system is precalibrated for optimal sound reproduction using digital signal processing. This calibration takes into account speakers, amplifiers, passenger compartment acoustics, listener position, etc. for each combination of vehicle model and audio system. There is also a dynamic calibration that takes into account the volume control setting and the vehicle's speed.

Sound settings as needed

In Top view under **Settings Sound**, the following settings can be selected:

- Tone personal preference for bass, treble, equalizer for example.
- Balance balance between right/left and front/rear speakers.
- System Volumes adjusts volume in the various systems of the car, e.g. Voice Control, Park Assist and Phone Ringtone.

Sound experience*



Recreate the acoustics from the Gothenburg Concert Hall.

Sound Experience is opened from the center display's app view and gives access to further audio settings. The following settings are possible:

- Studio the sound can be optimized for Driver, All and Rear.
- Individual stage surround sound mode with settings for intensity and enclosure.
- Concert hall reproduces the acoustics of Gothenburg's Concert Hall

Active noise suppression*

Some vehicles are equipped with an active noise suppression function that reduces engine noise in the passenger compartment using the audio system. Microphones in the ceiling liner detect

distracting noise and the audio system sends out a counteracting sound to help reduce the unwanted noise.



Microphones in the ceiling lining.

(i) NOTE

Do not cover the vehicle microphones.

Related information

- Media player (p. 485)
- Voice control settings (p. 150)
- Phone settings (p. 506)
- Audio, media and Internet (p. 464)
- Internet-connected vehicle* (p. 507)

Apps

The App view contains applications (apps) that provide access to certain vehicle services.

Swipe the center display screen from right to left¹ to access the App view from the Home view. This view displays downloaded apps (third-party apps) as well as apps for integrated functions, such as FM radio.



App view. (generic illustration; basic apps vary depending on market and model)

Several basic apps are always available. More apps such as web radio and music services can be downloaded when the car is connected to the Internet

Some apps can only be used when the vehicle is connected to the Internet.

Start an app by pressing the app in the center display's app view.

Related information

- Download apps (p. 466)
- Updating apps (p. 467)
- Deleting apps (p. 468)
- Apple® CarPlay®* (p. 493)
- Android Auto* (p. 496)
- Internet-connected vehicle* (p. 507)
- Hard disk storage space (p. 516)
- Terms of use and data sharing (p. 514)

Download apps

New apps can be downloaded when the vehicle is connected to the Internet



NOTE

Data downloading can affect other services such as transfer data, e.g. web radio. If the affect on other services is experienced as problematic, the download can be interrupted. Alternatively, it may be appropriate to switch off or cancel other services.



NOTE

When downloading using a phone, pay extra attention to the data traffic costs.

1. Open the **Download Center** app in App view.



2. Select New apps to open a list of apps that are available but are not installed in the vehicle.

¹ Applies for left-hand drive vehicles. For right-hand drive vehicles, swipe in the other direction.

- Tap on the row for an app in order to expand in the list and get more information about the app.
- 4. Select **Install** to start the download and installation of the app.
 - > The current status of the download and installation will be shown.

If a download cannot be started immediately, a message will be displayed. The app will remain in the list and it will be possible to reattempt downloading.

Canceling a download

Tap Abort to cancel a download in progress.

Note that only a download can be cancelled. An installation cannot be cancelled once it has begun.

Related information

- Apps (p. 465)
- Updating apps (p. 467)
- Deleting apps (p. 468)
- Internet-connected vehicle* (p. 507)
- Handling system updates via Download Center (p. 579)
- Hard disk storage space (p. 516)

Updating apps

Apps can be updated when the vehicle is connected to the Internet.



NOTE

Data downloading can affect other services such as transfer data, e.g. web radio. If the affect on other services is experienced as problematic, the download can be interrupted. Alternatively, it may be appropriate to switch off or cancel other services.



NOTE

When downloading using a phone, pay extra attention to the data traffic costs.

If an app is being used while an update is in progress, it will be restarted to complete the update.

Update all

1. Open the **Download Center** app in App view.



- 2. Select Install all.
 - > The update will begin.

Update certain apps

- 1. Open the **Download Center** app in App view.
- Select Application updates to open a list of all available updates.
- Find the desired app and select Install.
 The update will begin.

- Apps (p. 465)
- Download apps (p. 466)
- Deleting apps (p. 468)
- Handling system updates via Download Center (p. 579)
- Internet-connected vehicle* (p. 507)

Deleting apps

When the vehicle is connected to the Internet, it is possible to uninstall apps.

If the app is being used, it must be closed before it can be uninstalled.

 Open the **Download Center** app in App view.



- 2. Select **Application updates** to open a list of all installed apps.
- Find the desired app and select **Uninstall** to begin uninstalling the app.
 - > When the app has been uninstalled, it will be removed from the list.

Related information

- Apps (p. 465)
- Download apps (p. 466)
- Updating apps (p. 467)
- Handling system updates via Download Center (p. 579)
- Internet-connected vehicle* (p. 507)

Radio

The radio can receive broadcasting from AM and FM wavebands with HD Radio™

Technology and SiriusXM[®] Satellite radio *. When the vehicle has an Internet connection, it is also possible to listen to web radio.





The radio can be controlled using voice commands, the right-side steering wheel keypad or the center display.

Related information

- Starting the radio (p. 469)
- Changing waveband and radio station (p. 469)
- Storing radio favorites (p. 471)
- Radio settings (p. 471)

- RBDS (p. 472)
- HD Radio[™] (p. 472)
- SiriusXM[®] Satellite radio* (p. 476)
- Internet-connected vehicle* (p. 507)
- Voice control for radio and media (p. 150)
- Media player (p. 485)

Starting the radio

The radio is started from the center display's App view.

 Open the desired waveband (e.g. FM) from App view.



Select a radio station.

Related information

- Radio (p. 468)
- Searching for a radio station (p. 470)

- Changing waveband and radio station (p. 469)
- Storing radio favorites (p. 471)
- Radio settings (p. 471)
- Voice control for radio and media (p. 150)

Changing waveband and radio station

Instructions for changing wavebands, waveband lists and radio stations in the selected list are provided here.

Changing wavebands

Swipe from App view on the center display and select the desired waveband (e.g. **FM**) or open the App menu in the instrument panel with the right-side steering wheel keypad and make your selection there.

Changing a list in a waveband



- 1. Tap Library.
- Select playback from Stations, Favorites or Genres.
- 3. Tap the desired station in the list.

Favorites - only plays selected favorite channels.

▶

Genres - only plays channels broadcasting the selected genre or program type, e.g. pop, classical, etc.

Changing radio stations in a selected list

- Press M or M under the center display or on the right-side steering wheel keypad.
 - > Move step-by-step through the selected list.

It is also possible to change radio station in the selected list via the center display.

Related information

- Radio (p. 468)
- Searching for a radio station (p. 470)
- Voice control for radio and media (p. 150)
- Storing radio favorites (p. 471)
- Radio settings (p. 471)
- App menu in instrument panel (p. 104)

Searching for a radio station

The radio automatically compiles a list of the radio stations that are sending out the strongest signals in the vehicle's current location.



Searching is performed in different ways depending on the waveband selected:

- AM stations and frequency.
- FM, stations, genres and frequency.
- 1. Tap Library.
- 2. Tap Q.
 - > Search view will displayed and the keyboard will open.
- 3. Enter a search word/phrase.
 - > The search will start and change as characters are entered. Search results will be displayed by category.

Searching for a station manually



Searching manually makes it possible to find and tune to stations that are not on the automatically compiled list of the strongest stations in the area.

Tap Manual tuning, drag the control or tap K≺ or ▷ . Press and hold to skip to the next available station in the frequency band. You can also use the right-side steering wheel keypad.

- Radio (p. 468)
- Starting the radio (p. 469)
- Changing waveband and radio station (p. 469)
- Voice control for radio and media (p. 150)
- Radio settings (p. 471)

Storing radio favorites

It is possible to add a radio a radio station in the Radio favorites app and in the list of favorites for the waveband (e.g. FM). Instructions for adding and removing favorites are provided below.

Radio favorites



Radio favorites shows saved favorites from all wavebands.

- Open the Radio favorites app from App view.
- 2. Tap the desired station in the list to listen.

Adding and deleting radio favorites

 Tap to add/remove a radio channel from the waveband's list of favorites or Radio favorites.

If a favorite station is deleted here, it will also be deleted from that waveband's list of favorites.

Related information

- Radio (p. 468)
- Starting the radio (p. 469)
- Searching for a radio station (p. 470)
- Changing waveband and radio station (p. 469)

- Voice control for radio and media (p. 150)
- Radio settings (p. 471)
- App menu in instrument panel (p. 104)

Radio settings

There are a number of different radio functions that can be activated and deactivated.

Canceling a traffic message

A current broadcast (e.g. a traffic message) can be temporarily interrupted by pressing \bigcirc in the right-side steering wheel keypad or tapping **Cancel** in the center display.

Activating and deactivating radio functions

Pull down Top view and select **Settings** → **Media** and the desired waveband to see available functions.

AM/FM Radio

- HD Radio AM: HD Radio™ Technology: makes it possible for AM audio to achieve an audio quality comparable to analog FM.
- HD Radio FM: HD Radio™ Technology: makes it possible to achieve a sound quality comparable with a CD.
- Show Broadcast Information: shows information on program content, artists, etc.
- Freeze Program Name: select to stop the program service name from scrolling continuously. Instead it freezes after 20 seconds.

← SiriusXM® Satellite radio*

Pull down Top view and select **Settings** → **Media** → **SiriusXM** to show a list of available options.

Related information

- Radio (p. 468)
- Settings for SiriusXM[®] Satellite radio* (p. 478)
- Symbols in the center display status bar (p. 126)

RBDS

RBDS radio

RBDS (Radio Broadcast Data System) enables certain functionality², such as:

- Searches for program types or new broadcasts
- Text information about currently broadcast programs

Related information

- Radio (p. 468)
- Radio settings (p. 471)

HD Radio™

HD Radio is a brand name registered by the DTS, Inc.³. They are the developer of a broadcasting technology called IBOC or In Band On Channel, which refers to the method of transmitting a digital radio broadcast signal centered on the same frequency as the AM or FM station's present frequency.

Introduction



Display when the radio is receiving an HD Radio broadcast (generic illustration)



NOTE

HD Radio volume may fade in and out at times due to coverage limitations.

² Certain stations only.

³ HD Radio™ technology is manufactured under license from DTS' U.S. and foreign Patents. HD Radio™ and the HD and HD Radio logos are proprietary trademarks of DTS.

The IBOC system is referred to as a "hybrid" since it is both analog and digital. During hybrid operation, receivers still continue to receive the analog (non-digital) signal. HD Radio receivers incorporate both modes of reception, where the receiver will automatically switch to the analog signal if the digital signal cannot be decoded or is lost by the receiver.

When you have tuned to an HD Radio station, the symbol will appear in the infotainment system display. The symbol will be displayed in different colors:

- Grayed-out symbol: No HD Radio broadcast reception
- White symbol: the radio is actively receiving an HD broadcast
- Orange symbol: the radio is receiving an HD broadcast with digital sound

More information about HD Radio and IBOC can be found on DTS, Inc.'s website, www.dts.com.

Artist Experience™

A radio station's logo and album art can be displayed. If a station opts to provide this information, it is broadcast once every 12 minutes, which means that there may be a delay before the logo/album art appear on the screen. The radio can store 100 station logos so the next time the radio is tuned to the same station, the logo will be displayed immediately. Album art is synched with the artist that you are currently listening to.

Ball game mode

This feature means that a main FM station (HD1) will broadcast live events, where the content of the programming is more important than sound quality, in analog mode only to help prevent the delay between analog and digital broadcasting. The HD Radio symbol will be white during live broadcasts and "Live" will be displayed next to the symbol.

Benefits of digital broadcasting

- Better sound (FM sounds near CD quality and AM as analog FM).
- Some FM frequencies offer a greater number of listening choices through "multicasting" (consisting of a frequency's main channel and any sub-channels that may also be available on that particular frequency.)
- When receiving a digital signal there is no multipath disturbance or hisses/pops/crackling due to outside influences.

How HD Radio ™ Technology broadcasting works

HD Radio works similarly to conventional radio and broadcasts of this type are available in many areas of the United States. However, there are a few key differences:

- Instead of transmitting one analog signal, stations send out a bundled signal - both analog and digital.
- An HD Radio receiver can receive both digital and analog broadcasts. Depending on the terrain and location of the vehicle (which will influence the signal strength), the receiver will determine which signal to receive.

- Radio (p. 468)
- Activating and deactivating the HD Radio[™] (p. 474)
- HD Radio[™] sub-channels (p. 474)
- HD Radio™ limitations (p. 475)
- Changing waveband and radio station (p. 469)
- Searching for a radio station (p. 470)

Activating and deactivating the HD Radio™

HD Radio is deactivated when the car leaves the factory.

When listening to an HD Radio station and driving through areas with weak HD signals (fringe areas), you may experience that the radio repeatedly switches between analog/digital and digital/analog reception. If this happens, it may be desirable to switch HD off.

Carry out the following to activate or deactivate HD Radio:

- 1. Drag down the top view and tap on **Settings**.
- Press Media and AM/FM Radio.
- Press HD Radio AM or HD Radio FM to activate/deactivate the function.

If HD radio is deactivated, the radio will be unable to receive digital broadcasts but it will continue to function as a conventional radio (analog AM/FM receiver). Please note that when HD is switched off, it will not be possible to tune in to sub-channels.

Note that if you activate or deactivate HD Radio only the selected wavelength band is affected.

Related information

- HD Radio[™] (p. 472)
- HD Radio[™] sub-channels (p. 474)

- HD Radio[™] limitations (p. 475)
- Opening contextual setting in the center display (p. 135)

HD Radio™ sub-channels

In many cases, a main HD Radio station (FM wavebands only) will also have sub-channels offering additional types of programming or music.

Sub-channels



Example of an HD Radio station with sub-channels

If any sub-channels are available, they will listed below the main channel on the screen. In this example, WILD-FM HD2 is a sub-channel.

Selecting sub-channels

To listen to a station's sub-channel(s), tap the station on the screen or press the forward/back arrow keys on the right-side steering wheel keypad or below the screen.

Sub-channels can also be saved as radio favorites.

If you tap a sub-channel favorite, it may take up to **6 seconds** before the channel becomes audible. If you tap a station while you are out of digital range of the transmitter, **No reception** will be displayed.

Related information

- HD Radio[™] (p. 472)
- Activating and deactivating the HD Radio[™] (p. 474)
- Changing waveband and radio station (p. 469)
- Searching for a radio station (p. 470)
- HD Radio[™] limitations (p. 475)

HD Radio™ limitations

Limitations

- Main channel vs. sub-channels (FM only):
 The main channel is the only channel that
- The main channel is the only channel that can receive in hybrid mode (both digital and analog). If a frequency has sub-channels, they are broadcast in digital mode only. The main FM channel will be displayed as, for example, "WRIF-FM HD1". The sub-FM channels will be displayed as "WRIF-FM HD2", "WRIF-FM HD3", etc.
- PReception coverage area: Due to current IBOC transmitter power limitations, the reception coverage area in digital mode is somewhat more limited than the station's analog coverage area. Be aware that, like all radio transmission technology, terrain, time of day, vegetation and buildings can have a positive or negative effect on radio reception.
- Analog to digital/digital to analog blending: Analog to digital blending will occur as the signal strength reaches a preset threshold in the receiver. This will be noticeable in fringe areas (areas with weak reception) and is normal.

i NOTE

There may be a noticeable difference in sound quality when a change from analogue to digital or digital to analogue occurs, such as:

- Volume increase or decrease
- Equalizer settings, i.e., Bass/ Midrange/ Treble cut or boost
- Time alignment (Digital program material in extreme cases can be as much as 8 seconds behind the analogue). This will noticeable as a "stuttering" effect.

The above items are dependant on the broadcaster's equipment settings and do not indicate a fault in the vehicle's radio receiver or antenna systems.

- HD Radio™ (p. 472)
- Activating and deactivating the HD Radio[™] (p. 474)
- HD Radio™ sub-channels (p. 474)

SiriusXM® Satellite radio*

The SiriusXM® Satellite system broadcasts from of a number of high elevation satellites in geosynchronous orbit.

Listening to satellite radio

The digital signals from the satellites are line-ofsight, which means that physical obstructions such as bridges, tunnels, etc, may temporarily interfere with signal reception.

Avoid any obstructions, such as metallic objects transported on roof racks or in a ski box, or other antennas that may impede signals from the SiriusXM® satellites.

Selecting SiriusXM® Satellite radio mode

1. From the center display's Home view, swipe from right to left to come to App view.



2. Tap the SiriusXM® Satellite radio icon.



Home view with SiriusXM® Satellite radio activated

If there is no subscription activated, tap channel 1, where you will be prompted on the screen to phone SiriusXM[®].

If a cell phone is paired and connected to the vehicle, you can also subscribe by:

From Home view, pull down the Settings menu.

- 2. Open the settings menu for SiriusXM® Satellite radio.
- 3. Tap Unsubscribed Services
- To call SiriusXM®, enter the phone number. They will activate the subscription of your choice. This may take several minutes.

When the subscription has been activated, tap the SiriusXM® Satellite radio icon to start the function and display the channel list included in your subscription.

Related information

- Radio (p. 468)
- Using SiriusXM® Satellite radio* (p. 477)
- Settings for SiriusXM[®] Satellite radio* (p. 478)
- SiriusXM Travel Link®* (p. 480)

Using SiriusXM® Satellite radio*

SiriusXM[®] Satellite radio offers several features for finding and listening to music, news, sporting events, etc. being broadcast on satellite radio stations.

SiriusXM® Satellite radio functions



With SiriusXM[®] Satellite radio activated, tap **Library** to display a screen offering the following functions:

- Search (the magnifying glass icon)
- Channels
- Favorites
- Categories

If you have used this view previously, you will be returned to the most recently used one.

Search

Tap the magnifying glass to display a screen where you can enter text using the center display's keyboard or by writing in the free-text field to search for e.g., a station number, an artist, song title, etc.

Channels

Tap to display a complete list of the channels included in your subscription. Tap a channel name to listen. If a subscription to a channel has expired, its name will be grayed-out on the screen.

For quick access to a channel that you often listen to, tap the star to the right of the channel's name. It will then be added to your list of favorites.

Favorites

Tap to display the channels that you have added to this list. Tap a channel name to listen.

Categories/Genres

Tap to display the categories available. Tap a category or genre name to display the channels that it contains and then tap a channel to listen.

If an alert has been set (see the section "Alerts" below) and an alert is active for an artist, song or team, virtual categories will also be temporary created and displayed. The channels currently broadcasting the song, artist or broadcasting a program with the selected team will be listed in a virtual category.

EPG (Electronic Program Guide)

On the center display's Home view, tap **EPG** for information about e.g., when a program is being broadcast and its name, description, artist, etc. If no information is currently available, **No information** will be displayed.

Alerts

If this feature has been selected under **SiriusXM Settings**, the **Alerts** button will be displayed on the Home view.

To add e.g., an artist's name, song title or a sports team to the list of alerts:

- 1. Tune to any channel that is broadcasting a song, game, etc., of your choice.
- 2. Tap the Alerts button.
- A pop-up window will be displayed showing a list of alerts (nothing will be displayed if the selected channel does not support the alert function).
- 4. Select one of the alternatives in list (only one can be selected at a time).
- The song/artist/team will now be added to the list of alerts. Favorite sports teams can also be added to the list using "Game Alert" in the SiriusXM satellite radio settings.
 - > When your choice is being broadcast on a channel, you will be informed by a pop-up.

iTunes tagging

From the center display's Top view, tap **SiriusXM Settings**. Tap the **iTunes Tagging** menu. Tap the **iTunes Tagging** box to activate/deactivate this function and tap **Close** to return to Home view. Tap **Tags List** to display a list of all tagged songs.

If the function is activated, the **iTunes tag** button will be displayed in Home view. If a song is played that you would like to buy in the iTunes store, tap this button while the song is playing to tag it. If a song with **iTunes Tagging** information is available, the button will be selectable. Tap the button to tag the song. If you would like to buy a tagged song via iTunes, Tap the iTunes tag button.

To buy a song in iTunes, begin by connecting an iPhone/iPod/iPad to the USB port in the tunnel console. The iTunes tagging list will automatically be transferred to the device and removed from the list in the vehicle. If the device is connected when a song is tagged, the data will automatically be saved in the device. To purchase the song, consult the iTunes support page.

Related information

- SiriusXM[®] Satellite radio* (p. 476)
- Entering characters, letters and words by hand in the center display (p. 131)
- Settings for SiriusXM[®] Satellite radio* (p. 478)


- Settings for SiriusXM[®] Satellite radio* (p. 478)
- Connecting a device via the USB port (p. 492)

Settings for SiriusXM® Satellite radio*

There are numerous settings that can be made to enhance your SiriusXM[®] Satellite radio listening experience.

Settings

Drag down the top view and tap on **Settings** → **Media** → **SiriusXM**. The following alternatives will be displayed:



Traffic Jump

Tap to display a list of cities from which you can choose to get traffic/weather information (or **Traffic jump off** to deactivate the feature). Tap to select a city (**JUMP** will be displayed on the Home screen next to **Library**). Tap **Back** to return to the list of settings or **Close** to return to the Home screen.

From the Home screen, tap JUMP to activate the function. When traffic/weather information is available from the selected city, the radio will automatically tune to the channel providing the information. When the information/announcement is finished, the radio will automatically return to the channel that you were previously listening to.

During an announcement, tap **JUMP** to interrupt the message and return to the station that you were currently listening to.

Alert Notifications

Tap the box to activate/deactivate. When activated, you will be notified if a song, artist, etc. that you have selected is playing. You will be asked if you want to listen.

Alert Notifications Sound

Opt to receive an audible alert when one of your selected choices is being played.

Sort Channels

Select how to sort your channels list.

iTunes Tagging

Tap to display a menu with the options: **iTunes Tagging** and **Tags List**. With this feature activated, songs can be tagged for later purchase from the iTunes store.

Game Alerts

Tap to display a list of sports.

Tap a sport to display a list of teams and tap a box on the right side of the screen to select a team as a favorite. An alert will then be provided when information about the team is being broadcast.

Tap **Confirm** below the list to return to the list of sports.

Tap **Back** to return to the list of settings or **Close** to return to the main screen.

Unsubscribed Services

If you have a SiriusXM® Satellite radio subscription, any channels not included in the subscription will be listed here. Call SiriusXM™ to subscribe. The phone number will be shown on the screen. If a cell phone is paired and connected to the vehicle, tap the phone number to make the call.

Skipped Stations

Tap to display a list of channels that you would like to skip (hide). Hide channels from the channel list by tapping the boxes to the right of the screen. Skipped (hidden) channels will not be shown in the channel list. However, a channel

previously selected as a favorite will still be displayed in the list of favorites, even it has been added to the skip list.

Skipped Categories

Tap to display a list of categories. Tap a category to skip (hide) it. It will not be displayed in the list of categories.

- SiriusXM[®] Satellite radio* (p. 476)
- Using SiriusXM® Satellite radio* (p. 477)

SiriusXM Travel Link®*

SiriusXM Travel Link is a feature offered by SiriusXM® Satellite radio* that can provide information about e.g., weather forecasts, weather alerts, service stations, sports, etc. in the vicinity of the vehicle.

Starting SiriusXM Travel Link



SiriusXM Travel Link services are only available in vehicles equipped with the Sensus Navigation system.

From the center display's App view, tap **Travel Link** to activate the feature. A disclaimer text will be displayed. Tap **OK** to display a list of SiriusXM Travel Link services:

- Alerts
- Fuel
- Sports
- Weather
- Favorites

In order to use one or more of these services, the user has to subscribe to the ones desired.

To subscribe to a SiriusXM Travel Link service:

- 1. Open the center display's Top view.
- 2. Tap Settings.

- Press SiriusXM Travel Link and Subscription Status.
 - > To subscribe, call the phone number listed on the screen.

Any services not subscribed will be grayed out and contain the text **Service not subscribed**.

When the services have been activated (subscribed), tap the one of your choice to start it.

The following applies for all of the SiriusXM Travel Link services:

- Pressing the **Back** button will take you back to the previous screen
- Pressing the Close button will take you to the SiriusXM Travel Link home screen.

i NOTE

If the Close button is used to return to the SiriusXM Travel Link home screen, the following applies (the Weather service is used here as an example):

- If you have already used the Weather function, tapping Weather again in the SiriusXM Travel Link home screen before using any other SiriusXM Travel Link service will return you to the point where you left the Weather service.
- If another SiriusXM Travel Link service is used (e.g., Fuel, Sports, etc.) before you return to the Weather service, you will be returned to the default Weather view (in this case, Local).

The same principle applies to all of the **SiriusXM Travel Link** services.

Favorites

Many SiriusXM Travel Link selections can be saved for easy access as favorites by tapping the "star" icon next to the selection where applicable.

To display a list of your favorites, tap the **Favorites** application in the SiriusXM Travel Link home screen.

Related information

- SiriusXM[®] Satellite radio* (p. 476)
- SiriusXM Travel Link®* Fuel (p. 483)

- SiriusXM Travel Link®* Sports (p. 484)
- SiriusXM Travel Link®* Weather (p. 481)
- SiriusXM Travel Link®* Notifications (p. 482)

SiriusXM Travel Link®* - Weather

This SiriusXM Travel Link service provides weather-related information near the vehicle, at a local ski resort, etc.

From the SiriusXM Travel Link home screen, to display weather-related information:

Tap the Weather button to display this screen.

At the top of the screen, the following categories will be displayed:

- Search (the magnifying glass icon)
- Local
- Ski condition
- Areas
- Favorites

Tap the category of your choice.

Search

Tap the magnifying glass icon. If the function is supported in the current context, a keyboard will appear on the screen. Enter the text of your choice and tap **Search** for detailed information from the SiriusXM Travel Link database.

Local4

Information from the closest weather station will be displayed and the following alternatives are available:

- Map view
- Today
- 5 days

Map view

Tap the map to display it in full-screen mode. Tap **Back** to return to the original map view.

Tap **Map options** to display the following alternatives.

- Weather radar
- Storm attributes
- Surface features
- Tropical storm tracks
- Winds

Tap the relevant box to the right of the option to select/deselect it. Tap **Done** to confirm and return to the previous screen or **Cancel**.

Today

Tap to see the current temperature, or the temperature in 3/6 hours.

Tap **Back** to return to the **Local** screen or **Close** to return to the SiriusXM Travel Link home screen.

⁴ This is the weather default unless another alternative has been selected.

44 5 days

Tap to see weather information for the coming 5 days.

Tap **Back** to return to the **Local** screen or **Close** to return to the SiriusXM Travel Link home screen.

Ski condition

Tap to display a list of ski areas in the vicinity of the vehicle. Tap a name in the list for information such as if the ski area is open/closed, temperature, wind conditions, snow conditions, the number of lifts that are in operation, etc.

- Weather locations
- Ski location

Tap Map view to display a map and a weather legend.

Tap **Map options** to display the following alternatives.

- Weather radar
- Storm attributes
- Surface features
- Tropical storm tracks
- Winds

Tap the relevant box to the right of the option to select/deselect it. Tap **Done** to confirm and return to the previous screen or **Cancel**.

Areas

Tap **Areas** to display a list of areas/locations in states from the SiriusXM Travel Link database.

Scroll to a state and tap to display:

- Weather locations: tap arrow to the right to display a list of towns. Scroll to desired town and tap for detailed weather information. You can choose Map view, today, 5 days or Favorites (star)
- **Ski locations**: tap arrow at right to display local ski areas. Tap an area for detailed info.

For information about storing a location, state, town, etc. as a favorite, see the heading "Favorites" in the article "SiriusXM Travel Link."

Related information

- SiriusXM Travel Link^{®*} (p. 480)
- SiriusXM Travel Link®* Fuel (p. 483)
- SiriusXM Travel Link®* Sports (p. 484)
- SiriusXM Travel Link®* Notifications (p. 482)

SiriusXM Travel Link®* - Notifications

This SiriusXM Travel Link service provides notifications of potential weather problems or other emergency situations in the vicinity of the vehicle.

From the SiriusXM Travel Link home screen, to show notifications:

- Tap the Alerts button to display this screen.
- If any notifications are currently available, a message will appear at the top of the screen.
 They can also be listed from the Settings menu in the center display's Top view.
- If no notifications are available, No active alerts will be displayed.

Types of notifications

To select the types of notifications to be displayed:

- 1. From the **Alerts** screen, tap the **Select** alerts button at the bottom of the screen.
- This displays the types of notifications that can be displayed. Tap the box to the right of each type of notification to select/deselect it.
- Tap **Done** when you have made your selections. You will return to the **Alerts** screen.

Information about a notification

If any notifications have been displayed on the screen, tap one for more detailed information (i.e., the location of the weather problem on a map and a description of the situation).

If a phone number is available in a notification, a Call button will be displayed. Tap this button for additional information

Related information

- SiriusXM Travel Link®* (p. 480)
- SiriusXM Travel Link®* Fuel (p. 483)
- SiriusXM Travel Link®* Sports (p. 484)
- SiriusXM Travel Link®* Weather (p. 481)

SiriusXM Travel Link®* - Fuel⁵

This SiriusXM Travel Link service provides information and guidance to service stations near the vehicle providing the type of fuel that you prefer/ require for your vehicle.

From the Sirius XM Travel Link home screen, to show fuel information:

Tap the Fuel button to display the main fuel

The following categories are shown:

- Search (the magnifying glass icon)
- Nearby
- Recommended
- **Favorites**
- **Brands**

Tap one of the alternatives to display its screen.

(i) NOTE

In each of the categories listed, tapping the Select fuel type button near the bottom of the screen opens a sub-view where you can specify the type of fuel preferred/required (Regular, Midrange, Premium, Diesel, Electric 120V, etc.) Tap Done to return to the previous screen.

Search

Tap the magnifying glass icon. If the function is supported in the current context, a keyboard will appear on the screen. Enter the text of your choice and tap Search for detailed information if available

Nearby

Tap for a list of service stations in the vicinity of the vehicle, with the nearest station at the top of the list.

The following information will be provided where available:

- For vehicles using gasoline, the price information for regular gasoline (unless another grade/type of fuel has been selected in Select fuel type)
- For electric vehicles/hybrids, information about charging stations, showing the total number of charging ports and the number of ports currently not in use
- the distance to the station
- a star icon to set the service station as a favorite

Tap the name of a service station to display more detailed information.

For guidance to the service station, tap the **Start** navigation or Add as waypoint buttons. See

⁵ This service is not available in Canada

the Sensus Navigation* supplement for additional information about using the navigation system.

Recommended

Tap for a list of service stations near the vehicle, displayed according to the price of regular gasoline (unless another grade/type of fuel has been selected in **Select fuel type**) or of stations offering the greatest number of available charging ports for electric vehicles/hybrids. The station offering the lowest price/most available charging ports will be displayed at the top of the list. Tap the name of a service station to display more detailed information.

Favorites

Tap for a list of service stations that have been stored as favorites. See also the heading **Favorites** in the article "SiriusXM Travel Link" for information explaining how to create favorites. Tap the name of a service station to display more detailed information.

In addition to the **Select fuel type** button at the bottom of the screen, tap the **Edit** button to delete individual stations from the list or tap **Delete** to clear the list. Tap **Done** to return to the previous screen.

Brands

1. Tap **Brands** to display a list of service station brands in the area.

- Tap a brand to display a list of service stations affiliated with that brand (BP, Exxon, etc.).
- 3. Tap the name of a service station to display more detailed information.

In addition to the **Select fuel type** button at the bottom of the screen, tap the **Sort** button to arrange the list according to **Nearest** or **Cheapest/Recommended**. Tap **Done** to return to the previous screen.

Related information

- SiriusXM Travel Link®* (p. 480)
- SiriusXM Travel Link®* Notifications (p. 482)
- SiriusXM Travel Link®* Sports (p. 484)
- SiriusXM Travel Link®* Weather (p. 481)

SiriusXM Travel Link®* - Sports

This SiriusXM Travel Link service provides information about sporting events, tournaments, teams, leagues, etc.

From the SiriusXM Travel Link home screen, to display sports information:

 Tap the **Sports** button to display the main sports screen.

A number of sports categories will be listed (Football, Baseball, Basketball, etc.)

Tap a sport to select a league in that sport (NFL, MLB, etc.) or a sport organization (PGA, LPGA, etc.).

The following is an example of the result of tapping Baseball:

- 1. MLB (Major League Baseball) will be displayed.
- Tap MLB to display the two leagues in Major League Baseball (American League or National League).
- 3. Tap one of the league names to display the divisions in the league.

- 4. Tap one of the divisions to display:
 - In progress: play-by-play information about a match/game/tournament currently in progress. Continue tapping to display. In the detailed view, you can also select a radio station that is currently broadcasting an ongoing sporting event
 - Headlines for MLB: Tap to display brief headline information
 - **Scheduled**: schedules for coming matches, games, etc.
 - Scores: match/game results

The same principle applies to all sports.

Related information

- SiriusXM Travel Link®* (p. 480)
- SiriusXM Travel Link®* Notifications (p. 482)
- SiriusXM Travel Link®* Fuel (p. 483)
- SiriusXM Travel Link®* Weather (p. 481)

Media player

The media player can play audio from the CD player* and from external audio sources connected via USB port or Bluetooth. It can also play video format via the USB port.

When the vehicle is connected to the Internet, it is also possible to listen to web radio, audio books and to access music services via apps.





The media player is controlled from the center display. Several functions can also be controlled using voice commands or the right-side steering wheel keypad.

The radio, which is also handled by the media player, is described in a separate section.

- Playing media (p. 486)
- Controlling and changing media (p. 487)
- Media searches (p. 488)
- Apps (p. 465)
- Radio (p. 468)
- CD player* (p. 489)
- Video (p. 490)
- Streaming media via Bluetooth® (p. 491)
- Playing media via the USB port (p. 492)
- Internet-connected vehicle* (p. 507)

Playing media

The media player is controlled from the center display. Several other functions can also be controlled using the right-side steering wheel keypad or by using voice commands.

The radio can also be controlled in the media player. See the section describing the radio.

Starting a media source



App view. (Generic illustration; basic apps vary depending on market and model).

CD*

- Insert a CD.
- 2. Open the CD app from App view.
- Select the track you would like to play.
 Playback will begin.

USB flash drive

- 1. Inset a USB flash drive.
- 2. Open the **USB** app from App view.
- Select the track you would like to play.
 Playback will begin.

MP3 player and iPod®

(i) NOTE

To start playback from an iPod, the iPod app must be used (not USB).

When an iPod is used as source, the car's audio and media system has a menu structure similar to the iPod player's own menu structure.

- Connect a media source.
- Start playback in the connected media source.
- Open the app (iPod, USB) from App view.
 Playback will begin.

Bluetooth-connected device

- 1. Activate Bluetooth in the media source.
- Connect a media source.
- Start playback in the connected media source.
- 4. Open the **Bluetooth** app from App view.
 - > Playback will begin.

Media with Internet connection

Medial playback from apps with Internet connection:

- 1. Connect the vehicle to the Internet.
- 2. Open the app from the App view.
 - > Playback will begin.

Read the separate section on how to download apps.

Video

- 1. Connect a media source.
- 2. Open the **USB** app from App view.
- 3. Tap the title you would like to play.
 - > Playback will begin.

Apple CarPlay

CarPlay is described in a separate section.

Android Auto

Android Auto is described in a separate section.

Related information

- Handling the App menu in the instrument panel (p. 105)
- Radio (p. 468)
- Controlling and changing media (p. 487)
- Connecting a device via the USB port (p. 492)
- Connecting a device via Bluetooth® (p. 491)
- Download apps (p. 466)
- Internet-connected vehicle* (p. 507)
- Video (p. 490)
- Apple[®] CarPlay^{®*} (p. 493)
- Android Auto* (p. 496)
- Voice control for radio and media (p. 150)
- Compatible file formats for media (p. 514)

Controlling and changing media

Media playback can be controlled using voice commands, the steering wheel keypad or the center display.



The media player can be controlled using voice commands, the right-side steering wheel keypad or the center display.



Volume - turn the knob under the center display or tap
on the right-side steering wheel keypad to raise or lower the volume.

Play/pause - tap the image for the track you would like to play, or press the button below the center display or O on the right-side steering wheel keypad.

Changing track/song - tap the desired track in the center display, or press KCI or DDI below the center display or on the right-side steering wheel keypad.

Rewinding/fast-forwarding - tap the time axis in the center display and drag it sideways, or press and hold K or D below the center display or on the right-side steering wheel keypad.

Changing media source - select from among previous sources in the app, tap the desired app in App view or use the right-side steering wheel keypad to select the app in the app menu (a).



Library - tap the button to play from the library.



Shuffle - tap the button to play tracks in a random order.

•



Similar - tap the button to use Gracenote to search for similar music on the USB device and create a playlist from the music found. The playlist can contain up to 50 tracks.



Change device - tap the button to toggle between USB devices when more than one is connected.

Related information

- Media player (p. 485)
- Media searches (p. 488)
- Sound settings (p. 464)
- Apps (p. 465)
- Gracenote[®] (p. 489)
- Voice control for radio and media (p. 150)

Media searches

Searches can be performed to locate a specific artist, composer, song title, album, video, audio book or playlist. If the vehicle is connected to the Internet, it is also possible to search for podcasts (online digital media).



- Tap Q.
 - > Search view will displayed and the keyboard will open.
- 2. Enter a search word/phrase.
- 3. Tap Search.
 - A search will be performed on connected devices and the results will be displayed by category.

Swipe the screen horizontally to display each category separately.

Related information

- Media player (p. 485)
- Internet-connected vehicle* (p. 507)
- Playing media (p. 486)
- Entering characters, letters and words by hand in the center display (p. 131)

Gracenote®

Gracenote identifies artists, albums, tracks and any associated images that can be displayed during playback.

Gracenote $\mathsf{MusicID}^{@}$ is a standard for music recognition.

- 1. Tap **Settings** in the Top view.
- Tap Media → Gracenote ®.
- 3. Choose settings for Gracenote data:
- Gracenote® Online Search search
 Gracenote's online database for currently
 playing media.
- Gracenote
 [®] Multiple Results select how
 Gracenote data should be displayed if there
 are multiple search results.
 - 1 the file's original data will be used.
 - 2 Gracenote data will be used.
 - 3 Gracenote or original data can be selected.
- None no result will be displayed.

Updating Gracenote


The contents of the Gracenote database are continuously updated. For optimal functionality, update to the latest version. See support.volvocars.com for information and downloads.

Related information

- Playing media (p. 486)
- License agreement for audio and media (p. 517)

CD player*

The media player can play CDs with compatible audio files.



- Disc slot.
- 2 Eject button.

- Playing media (p. 486)
- Voice control for radio and media (p. 150)
- Compatible file formats for media (p. 514)

Video

The media player can play videos from USB-connected devices.

Video is not available when the vehicle is moving; only audio will be played. Video will resume when the vehicle is stationary.

Information on compatible media formats is provided in a separate section.

Related information

- Playing video (p. 490)
- Playing DivX[®] (p. 490)
- Video settings (p. 491)
- Compatible file formats for media (p. 514)

Playing video

The USB app in App view is used to play videos.

- 1. Connecting media source (USB device).
- 2. Open the USB app from App view.
- Tap the title you would like to play.
 Playback will begin.

Related information

- Video (p. 490)
- Playing DivX® (p. 490)
- Video settings (p. 491)
- Compatible file formats for media (p. 514)

Playing DivX®

The DivX Certified[®] device must be registered to play purchased DivX video-on-demand (VOD) movies.

- 1. Tap **Settings** in the Top view.
- Tap Video → DivX ® VOD to get a registration code.
- 3. Go to vod.divx.com for more information and to complete the registration process.

- Video (p. 490)
- Playing video (p. 490)
- Video settings (p. 491)
- Compatible file formats for media (p. 514)

Video settings

Some video playback settings can be adjusted, e.g. language.

The following can be adjusted by opening Top view and tapping Settings → Video or with the video player in full-screen mode: Audio Language, Off and Subtitle Language.

Related information

Video (p. 490)

Streaming media via Bluetooth®

The vehicle's media player is equipped with Bluetooth and can play audio files from Bluetooth-enabled external devices such as cellular phones and tablets.

In order for the media player to be able to wirelessly play audio files from an external device, the device must be connected to the vehicle via Bluetooth.

Related information

- Connecting a device via Bluetooth® (p. 491)
- Connecting a phone to the car via Bluetooth for the first time (p. 499)
- Playing media (p. 486)
- Compatible file formats for media (p. 514)

Connecting a device via Bluetooth®

Connect a Bluetooth® device to the vehicle to wirelessly play media and give the vehicle an Internet connection if it is available.

Many cellular phones on the market currently offer wireless Bluetooth® technology, but not all phones are fully compatible with the vehicle. For additional information on compatibility, see support.volvocars.com.

The procedure for connecting a media device is the same as for connecting a cellular phone to the vehicle via Bluetooth®.

- Streaming media via Bluetooth® (p. 491)
- Connecting a phone to the car via Bluetooth for the first time (p. 499)
- Playing media (p. 486)

Playing media via the USB port

External audio sources, such as an iPod® or MP3 player, can be connected to the audio system via the vehicle's USB port.

Devices with rechargeable batteries can be charged when they are connected via the USB port and the ignition is in mode I, II or the engine is running.

The content on the external source can be read faster if it only contains data of a compatible format. Video files can also be played via the USB port.

Some MP3 players have their own file system that the vehicle has support for.


Related information

- Connecting a device via the USB port (p. 492)
- Playing media (p. 486)
- Video (p. 490)
- Ignition modes (p. 407)
- Technical specifications for USB devices (p. 515)
- Apple[®] CarPlay^{®*} (p. 493)
- Android Auto* (p. 496)

Connecting a device via the USB port

External audio sources, such as an iPod[®] or MP3 player, can be connected to the audio system via any of the vehicle's USB ports.

If the vehicle has two USB ports, the phone must be connected to the port with the white frame to use Apple CarPlay* or Android Auto*.



USB ports (type A) in the tunnel console. Route the cable forward to help avoid pinching when the cover is closed.

Related information

- Playing media (p. 486)
- Playing media via the USB port (p. 492)
- Media player (p. 485)
- Technical specifications for USB devices (p. 515)

- Technical specifications for USB devices (p. 515)
- Apple[®] CarPlay^{®*} (p. 493)
- Android Auto* (p. 496)

Apple® CarPlav®*

With CarPlay, you can listen to music, make phone calls, get driving instructions, send/ receive messages and use Siri, all while remainina focused on drivina.



CarPlav works with select Apple devices. If the car does not already support CarPlay. this can be retrofitted. Contact a Volvo retailer to install CarPlay.

Information about supported apps and compatible phones is available on the Apple website: www.apple.com/ios/carplay/. Using apps that are not compatible with CarPlay could cause the connection between iPhone and the vehicle to be lost. Please note that Volvo is not responsible for the content of CarPlay.

When using map navigation via CarPlay, guidance will only be shown on the center display and not in the instrument panel or head-up display.

CarPlay apps can be controlled from the center display, a phone or with the right-side steering wheel keypad (for certain functions). The apps can also be voice-controlled using Siri. Press and hold the we button on the steering wheel to start voice control with Siri. Press briefly to activate the vehicle's own voice control system. If Siri cuts off too soon, press and hold the w 6 button on the steering wheel.

By using Apple CarPlay you acknowledge the following: Apple CarPlay is a service provided by Apple Inc. under its terms and conditions. Volvo Cars is thus not responsible for Apple CarPlay or its features/applications. When using Apple CarPlay, certain information from your car (including its position) is transferred to your iPhone. In relation to Volvo Cars, you are fully responsible for your and any others person's use of Apple CarPlay.

Related information

- Using Apple® CarPlay®* (p. 493)
- Settings for Apple® CarPlay®* (p. 494)
- Voice control (p. 147)
- Resetting center display settings (p. 137)

Using Apple® CarPlay®*

To use CarPlay, the Siri voice control must be activated in your phone. The phone must also have an Internet connection via Wi-Fi or a mobile network.

Connecting an iPhone and starting CarPlay

NOTE

CarPlay can only be used if Bluetooth is disabled. A cell phone or media player connected to the vehicle via Bluetooth will therefore not be available when CarPlay is active. An alternative source must be used to provide an Internet connection for the vehicle's apps. Use Wi-Fi or the vehicle's integrated modem.

- 1. Connect an iPhone to the USB port. If there are two USB ports, use the one with the white frame.
- 2. Read the information in the pop-up window and then tap OK.
- Tap Apple CarPlay in App view.
- 4. Read the terms and conditions and then tap Accept to connect.
 - > The CarPlay tile will open and compatible apps will be displayed.

⁶ Apple and CarPlay are registered trademarks of Apple Inc.

- 5. Tap the desired app.
 - > The app will start up.

Starting CarPlay

CarPlay can be started as follows after an iPhone is connected

- 1. Connect an iPhone to the USB port. If there are two USB ports, use the one with the white frame.
 - > If the auto start setting is selected the name of the phone will be displayed.
- 2. Tap the name of the phone the CarPlay tile will open and compatible apps will be displayed.
- 3. If the CarPlay tile does not open, tap Apple CarPlay in App view.
 - > The CarPlay tile will open and compatible apps will be displayed.
- 4. Tap the desired app.
 - > The app will start up.

CarPlay will run in the background if another app is started in the same tile. To display CarPlay in the tile, tap the CarPlay icon in App view.

Switching connection between CarPlay and iPod

CarPlay to iPod

1. Tap **Settings** in the Top view.

- 2. Proceed to Communication → Apple CarPlay.
- 3. Uncheck the box for the Apple device that should no longer start CarPlay automatically when the USB cable is connected
- 4. Remove and then reinsert the Apple device into the USB port.
- 5. Open the **iPod** app from App view.

iPod to CarPlay

- Tap Apple CarPlay in App view.
- 2. Read the information in the pop-up window and then tap OK.
- 3. Remove and then reinsert the Apple device into the USB port.
 - > The Apple CarPlay tile will open and compatible apps will be displayed⁷.

Related information

- Connecting a device via the USB port (p.492)
- Apple® CarPlav®* (p. 493)
- Settings for Apple® CarPlay®* (p. 494)
- Connecting the car to the Internet via a mobile device (Wi-Fi) (p. 509)
- Connect the car to the Internet via car modem (SIM card) (p. 510)
- Voice control (p. 147)

Settings for an Apple device connected through CarPlav8.

Automatic start

- 1. Tap **Settings** in the Top view.
- Tap Communication → Apple CarPlay and select the desired setting:
 - Check the box CarPlay will start automatically when the USB cable is connected.
 - Uncheck the box CarPlav will not start automatically when the USB cable is connected.

A maximum of 20 Apple devices can be stored in the list. When the list is full and a new device is connected, the oldest one will be deleted.

To delete the list, the settings must be rest in the center display (factory reset).

System Volumes

- 1. Tap **Settings** in the Top view.
- Tap Sound → System Volumes to change the settings for the following:
 - Voice Control
 - Navi Voice Guidance
 - Phone Ringtone

Settings for Apple® CarPlay®*

⁷ Apple, CarPlay, iPhone and iPod are registered trademarks of Apple Inc.

Related information

- Apple[®] CarPlay^{®*} (p. 493)
- Using Apple® CarPlay®* (p. 493)
- Resetting center display settings (p. 137)

Tips for using Apple® CarPlay®*

Here are some useful tips for when you use CarPlay®.

- Update your iPhone with the latest version of iOS operating system and ensure that the apps have been updated.
- In the event of a problem with CarPlay, disconnect the phone from the USB port and reconnect. Otherwise, try to close the app on the phone that is not working and then restart the app, or try closing all apps and restart your phone.
- If the apps do not appear when CarPlay starts (black screen), try minimizing and expanding the tile for CarPlay.
- Using apps that are not compatible with CarPlay may sometimes mean that the connection between the phone and the car is broken. Information about supported apps and compatible phone models can be found on Apple's website. You can also search for CarPlay in the App Store to find information about apps that are compatible with CarPlay in your market.
- CarPlay only works with iPhone⁹.

(i) NOTE

Availability and functionality can vary depending on market.

Related information

Apple[®] CarPlay^{®*} (p. 493)

⁸ Apple and CarPlay are registered trademarks of Apple Inc..

⁹ Apple, CarPlay and iPhone are registered trademarks owned by Apple Inc.

Android Auto*

Android Auto lets you listen to music, make calls, get driving directions and use apps customized for your vehicle from an Android device.

Android Auto can be used with selected Android devices.



For information on supported apps and compatible devices, please go to www.android.com/ auto/. For third-party apps, see Google Play. Please note that Volvo is not responsible for the content of Android Auto.

Android Auto is started from App view. After Android Auto has been initially started, the app will start automatically the next time the device is connected. The automatic start setting can be deactivated in Settings.

(i) NOTE

When a phone is connected to Android Auto, it is possible to steam to another media player via Bluetooth. Bluetooth is active while Android Auto is in use.

When using navigation guidance provided by Android Auto, navigation will only be shown on the center display and not in the instrument panel or head-up display.

Android Auto can be controlled from the center display, with the right-side steering wheel keypad or by using voice commands. Press and hold the button to activate voice control and tap the same button to deactivate.

By using Android Auto, you acknowledge the following: Android Auto is a service provided by Google Inc. under its terms and conditions. Volvo Cars is not responsible for Android Auto or its features or applications. When you use Android Auto, your car transfers certain information (including its location) to your connected Android phone. You are fully responsible for your and any other person's use of Android Auto.

Related information

- Using Android Auto* (p. 496)
- Settings for Android Auto* (p. 497)

Using Android Auto*

To use the **Android Auto** app, the phone must be connected to the vehicle's USB port.

Connecting an Android device for the first time

- Connect the Android phone to the USB port.
 If there are two USB ports, use the one with the white frame.
- 2. Read the information in the pop-up window and then tap **OK**.
- 3. Tap Android Auto in App view.
- Read the terms and conditions and then tap Accept to connect.
 - > The Android Auto tile will open and compatible apps will be displayed.
- 5. Tap the desired app.
 - > The app will start up.

From a previously connected Android device

- 1. Connect the device to the USB port.
 - > If the auto start setting is selected the name of the phone will be displayed.
- Tap the name of the phone the Android Auto tile will open and compatible apps will be displayed.
- If the automatic start setting is not activated open the Android Auto app from App view.
 - > The Android Auto tile will open and compatible apps will be displayed.
- 4. Tap the desired app.
 - > The app will start up.

Android Auto will run in the background if another app is started in the same tile. To display Android Auto in the tile, tap the Android Auto icon in App view.

Related information

- Android Auto* (p. 496)
- Settings for Android Auto* (p. 497)
- Connecting a device via the USB port (p. 492)
- Voice control (p. 147)

Settings for Android Auto*

Settings for phones initially connected with Android Auto.

Automatic start

- 1. Tap **Settings** in the Top view.
- Tap Communication → Android Auto and select setting:
 - Check the box Android Auto will start automatically when the USB cable is connected.
 - Uncheck the box Android Auto will not start automatically when the USB cable is connected.

A maximum of 20 Android devices can be stored in the list. When the list is full and a new device is connected, the oldest one will be deleted.

A factory reset must be performed to delete the list.

System Volumes

- 1. Tap **Settings** in the Top view.
- Tap Sound → System Volumes to change the settings for the following:
 - Voice Control
 - Navi Voice Guidance
 - Phone Ringtone

- Android Auto* (p. 496)
- Using Android Auto* (p. 496)
- Resetting center display settings (p. 137)

Tips for using Android Auto*

Here are some useful tips for when you use Android Auto.

- Ensure that your apps are updated.
- When starting the car, wait until the center display has started, connect the phone and then open Android Auto from the app view.
- In the event of problems with Android Auto, disconnect your Android phone from the USB port and then reconnect via USB. Otherwise, try closing the app on the phone and then restarting the app.
- When a phone is connected to Android Auto it is still possible to playback media via Bluetooth to another media player. The Bluetooth function is on when Android Auto is used.

Related information

Android Auto* (p. 496)

Phone

A phone equipped with Bluetooth can be wirelessly connected to the vehicle's integrated hands-free system.


The audio and media system offers hands-free functionality for remotely controlling a number of the phone's features. The phone's integrated controls can also be used, even when it is connected to the vehicle.

When the phone has been paired and connected to the vehicle, it can be used as an Internet connection or to make or receive calls, send or receive text messages or wirelessly play music.



The phone is controlled from the center display but the App menu (accessed using the right-side steering wheel keypad) and voice commands can also be used to control certain functions.

Overview



- Microphone.
- Phone.
- 3 Phone handling in the center display.
- Keypad for controlling phone functions shown in the center display and voice commands.
- 6 Instrument panel.

Related information

- Handling phone calls (p. 503)
- Managing the phone book (p. 505)
- Handling text messages (p. 504)
- Connecting a phone to the car via Bluetooth for the first time (p. 499)

- Connecting a phone to the car via Bluetooth automatically (p. 501)
- Connecting a phone to the car via Bluetooth manually (p. 501)
- Disconnecting a Bluetooth-connected phone (p. 502)
- Switch between phones connected via Bluetooth (p. 502)
- Removing a Bluetooth-connected phone (p. 503)
- Phone settings (p. 506)
- Voice control (p. 147)
- Handling the App menu in the instrument panel (p. 105)
- Sound settings (p. 464)
- Connecting the car to the Internet via a mobile device (Bluetooth) (p. 509)

Connecting a phone to the car via Bluetooth for the first time

Pair a Bluetooth-enabled phone to the vehicle to make calls, send/receive text messages and wirelessly play media from the vehicle, or connect the vehicle to the Internet.

Two Bluetooth devices can be connected at the same time, but in that case, only one will be used for wireless playback. The most recently paired phone will be automatically connected to make calls, send/receive text messages, play media or use as an Internet connection. To change what the phone is used for when it is paired, go to **Bluetooth Devices** settings.

After the device has been connected/registered for the first time via Bluetooth, the device no longer needs to be visible/searchable. It just needs to have Bluetooth activated. To connect the vehicle to the Internet using a phone, the phone's Wi-Fi sharing function (personal hotspot/tethering) must be activated. A maximum of 20 paired Bluetooth devices can be stored in the vehicle.

There are two ways to pair a phone to the vehicle. Searching for the phone from the vehicle or searching for the vehicle from the phone.

Option 1 - searching for the phone from the vehicle

1. Make the phone discoverable/visible using its Bluetooth function.

- To connect the vehicle to the Internet via the phone's Bluetooth function, activate Internet sharing (tethering/personal hotspot) via Bluetooth in the phone.
- 3. Open the phone tile.
 - If no phone has been paired to the vehicle, tap Add phone.
 - If a phone has been paired to the vehicle, tap Change . Tap Add phone in the pop-up window.
 - > A list of available Bluetooth devices will be displayed. The list will be updated as new devices are discovered.
- 4. Tap the name of the phone you would like to connect.
- Make sure that the code displayed in the vehicle matches the one in the phone. Confirm the code in both cases.
- In the phone, accept or cancel the options for selecting the phone's contacts and text messages.

(i) NOTE

- The message function must be activated in certain phones.
- Not all cell phones are fully compatible and may not be able to display contacts and messages in the vehicle.

Option 2 - searching for the vehicle from the phone

- 1. Open the phone tile.
 - If no phone has been paired to the vehicle, tap Add phone → Make vehicle discoverable
 - If a phone has been paired to the vehicle, tap Change ☐ . Tap Add phone → Make vehicle discoverable in the popup window.
- 2. Activate Bluetooth in the phone.
- To connect the vehicle to the Internet via the phone's Bluetooth function, activate Internet sharing (tethering/personal hotspot) via Bluetooth in the phone.
- 4. Search in the phone for Bluetooth devices.
 - > A list of available Bluetooth devices will be displayed.
- 5. Select the vehicle's name from the list of devices in the phone.
- 6. A pop-up window for the connection is shown in the car. Confirm the connection.
- Make sure that the code displayed in the vehicle matches the one in the external device, Confirm the code in both cases.
- In the phone, accept or cancel the options for selecting the phone's contacts and text messages.

(i) NOTE

- The message function must be activated in certain phones.
- Not all cell phones are fully compatible and may not be able to display contacts and messages in the vehicle.

(i) NOTE

If the phone's operating system is being updated, it is possible that the connection will be interrupted. Delete the phone from the car and reconnect.

Compatible phones

Many cellular phones on the market currently offer wireless Bluetooth technology, but not all phones are fully compatible with the vehicle. For additional information on compatibility, see support.volvocars.com.

- Phone (p. 498)
- Connecting a phone to the car via Bluetooth automatically (p. 501)
- Connecting a phone to the car via Bluetooth manually (p. 501)
- Disconnecting a Bluetooth-connected phone (p. 502)

- Switch between phones connected via Bluetooth (p. 502)
- Removing a Bluetooth-connected phone (p. 503)
- Settings for Bluetooth devices (p. 507)
- Connecting the car to the Internet via a mobile device (Bluetooth) (p. 509)

Connecting a phone to the car via Bluetooth automatically

A phone can be automatically connected to the vehicle via Bluetooth. The phone must have first been paired with the vehicle.

Only the two most recently connected phones can be connected automatically.

- 1. Activate Bluetooth in the phone before turning the vehicle's ignition to mode I.
 - To simultaneously connect the vehicle to the Internet, the phone's personal hotspot must also be activated
- 2. Turn the ignition to ${\bf I}$ or higher.
 - > The phone will be connected.

Related information

- Phone (p. 498)
- Connecting a phone to the car via Bluetooth for the first time (p. 499)
- Connecting a phone to the car via Bluetooth manually (p. 501)
- Disconnecting a Bluetooth-connected phone (p. 502)
- Switch between phones connected via Bluetooth (p. 502)
- Removing a Bluetooth-connected phone (p. 503)
- Settings for Bluetooth devices (p. 507)

- Connecting the car to the Internet via a mobile device (Bluetooth) (p. 509)
- Ignition modes (p. 407)

Connecting a phone to the car via Bluetooth manually

A phone can be manually connected to the vehicle via Bluetooth. The phone must have first been paired with the vehicle.

1. Activate Bluetooth in the phone.

To simultaneously connect the vehicle to the Internet, the phone's personal hotspot must also be activated.

- 2. Open the phone tile.
 - > A list of available phones will be displayed.
- 3. Tap the name of the phone you would like to connect.
 - > The phone will be connected.

- Phone (p. 498)
- Connecting a phone to the car via Bluetooth for the first time (p. 499)
- Connecting a phone to the car via Bluetooth automatically (p. 501)
- Disconnecting a Bluetooth-connected phone (p. 502)
- Switch between phones connected via Bluetooth (p. 502)
- Removing a Bluetooth-connected phone (p. 503)

- Settings for Bluetooth devices (p. 507)
- Connecting the car to the Internet via a mobile device (Bluetooth) (p. 509)

Disconnecting a Bluetoothconnected phone

Disconnect a Bluetooth-connected phone from the vehicle by deactivating Bluetooth in the phone.

When the phone is out of range of the vehicle, it will be automatically disconnected. If a call is in progress when the phone is disconnected from the vehicle, the call will be transferred from the vehicle's speakers and microphone to the cellular phone.

Related information

- Phone (p. 498)
- Phone settings (p. 506)
- Switch between phones connected via Bluetooth (p. 502)
- Removing a Bluetooth-connected phone (p. 503)
- Settings for Bluetooth devices (p. 507)

Switch between phones connected via Bluetooth

It is possible to switch between Bluetooth-connected phones.

- 1. Open the phone tile.
- Tap Change or pull down Top view and tap Settings → Communication →
 Bluetooth Devices → Add device.
 - > A list of available Bluetooth devices will be displayed.
- 3. Tap the name of the phone you would like to connect.

- Phone (p. 498)
- Connecting a phone to the car via Bluetooth for the first time (p. 499)
- Settings for Bluetooth devices (p. 507)
- Disconnecting a Bluetooth-connected phone (p. 502)
- Removing a Bluetooth-connected phone (p. 503)

Removing a Bluetooth-connected phone

Phones in the list of registered Bluetooth devices can be removed.

- 1. Tap **Settings** in the Top view.
- Tap Communication → Bluetooth Devices.
 - > A list of registered Bluetooth devices is displayed.
- Tap the name of the phone you would like to remove.
- 4. Tap Remove device and confirm.
 - > The phone is no longer registered in the vehicle.

Related information

- Phone (p. 498)
- Connecting a phone to the car via Bluetooth for the first time (p. 499)
- Disconnecting a Bluetooth-connected phone (p. 502)
- Switch between phones connected via Bluetooth (p. 502)
- Settings for Bluetooth devices (p. 507)

Handling phone calls

Handling phone calls in the vehicle for a Bluetooth-connected cellular phone.



Generic illustration.

Making calls

- Open the phone tile.
- Initiate a call by selecting the phone number from the recent calls list, entering the number on the keypad or selecting a number from the phone book (list of contacts). You can search or scroll to find a contact in the phone book. Tap in the phone book to add a contact to Favorites.
- 3. Tap 📞 .
- 4. Tap
 to end the call.

Calls can also be made from the list of recent calls using the app menu, which can be opened using the button on the right-side steering wheel keypad.

Making multiple calls

While the call is in progress:

- 1. Tap Add call.
- Select from the list of recent calls, favorites or contacts.
- Tap an item/row in the list of recent calls or for the contact in the phone book.
- 4. Tap Swap call to switch between calls.
- 5. Tap to end the current call.

Group (conference) calls

While multiple calls are in progress:

- 1. Tap Join calls to merge ongoing calls.

Incoming calls

Incoming phone calls will be shown on the instrument panel and in the center display. Manage the calls using the right-side steering wheel keypad or the center display.

- 1. Tap Answer/Reject.

Incoming calls while another call is in progress

- 1. Tap Answer/Reject.
- 2. Tap
 to end the call.

Privacy

- While a call is in progress, tap **Privacy** and select setting:
 - Switch to mobile phone the handsfree function will be disabled and the call will proceed on the cellular phone.
 - Driver focused the microphone in the ceiling liner on the passenger side will be muted and the call will proceed using the vehicle's hands-free function.

Related information

- Phone (p. 498)
- Connecting a phone to the car via Bluetooth for the first time (p. 499)
- Voice control for cellular phones (p. 149)
- Handling the App menu in the instrument panel (p. 105)
- Entering characters, letters and words by hand in the center display (p. 131)
- Managing the phone book (p. 505)
- Handling text messages (p. 504)
- Sound settings (p. 464)

Handling text messages

A Bluetooth-connected cellular phone's text messages can be handled in the vehicle.

Text message functionality needs to be activated in certain phones. Not all phones are fully compatible and therefore cannot display contacts and messages in the vehicle. For additional information on compatibility, see support.volvocars.com.

Handling text messages in the center display

Text messages are only shown in the center display if the relevant setting is made.



Tap **Messages** in App view to handle text messages in the center display.

i) NOTE

When the vehicle is moving:

- Only one row of the message will be displayed. Tap **Read out** to have the entire message read aloud.
- The center display's keyboard cannot be used.

Reading text messages in the center display



Tap the icon to have the message read aloud.

Sending text messages in the center display¹⁰

- 1. It is possible to reply to text messages or create a new message.
 - To reply to a text message tap the name of the contact who sent the message and then tap Answer.
 - To create a new message tap Create new. Select a contact or enter a phone number.
- 2. Write the message.
- 3. Tap Send.

Handling test messages in the instrument panel

Text messages are only shown in the instrument panel if the relevant setting is made.

Reading new text messages in the instrument panel

To have the message read aloud, select
 Read out using the steering wheel keypad.

¹⁰ Only certain phones can send messages via the vehicle. For additional information on compatibility, see support.volvocars.com.

Dictating replies in the instrument panel

After the test message has been read aloud, it is possible to answer briefly with dictation if the vehicle has an Internet connection.

 Tap **Answer** using the steering wheel keypad. A dictation dialog will start.

Message notification

Notifications can be activated and deactivated in the text message settings.

Related information

- Phone (p. 498)
- Text message settings (p. 505)
- Phone settings (p. 506)
- Internet-connected vehicle* (p. 507)
- Voice control for cellular phones (p. 149)
- Entering characters, letters and words by hand in the center display (p. 131)
- Connecting a phone to the car via Bluetooth for the first time (p. 499)

Text message settings

Settings for handling text messages received through a connected phone can be personalized.

- 1. Tap **Settings** in the Top view.
- Tap Communication → Text Messages and select settings:
 - Notification in center display display text message notifications in the center display's status bar.
 - Notification in driver display displays notifications in the driver's display and incoming messages can be managed using the steering wheel's right-hand keypad.
 - Text message tone select tone for incoming text messages.

Related information

- Phone (p. 498)
- Connecting a phone to the car via Bluetooth for the first time (p. 499)
- Handling text messages (p. 504)
- Phone settings (p. 506)

Managing the phone book

Contacts in a Bluetooth-connected cellular phone can be managed in the vehicle.



- 1 Scroll by letter or # to find contacts. Only letters matching existing contacts in the phone book will be shown.
- **2** Search contacts tap \bigcirc to search by phone number or name in the phone book.
- **3** Favorites tap $\stackrel{\checkmark}{\swarrow}$ to add/remove a contact from the list of favorites.

(i) NOTE

Only contacts from an active Bluetooth-connected phone are shown in the center display. Up to 3000 contacts can be displayed.

4 Sorting

The phone book is sorted in alphabetical order and special characters and numbers are sorted under # . The list can be sorted by either first name or last name. This is adjusted in your cellular phone settings.

Related information

- Phone (p. 498)
- Phone settings (p. 506)
- Voice control for cellular phones (p. 149)
- Entering characters, letters and words by hand in the center display (p. 131)
- Connecting a phone to the car via Bluetooth for the first time (p. 499)

Phone settings

When the phone is connected to the car, the following settings can be made:

- 1. Tap **Settings** in the Top view.
- Tap Communication → Phone and select settings:
 - Ringtones select a ring tone. Ring tones from the cellular phone or the vehicle can be used. Some phones are not fully compatible and it may not be possible to use the phone's ring tones in the vehicle. For additional information on compatibility, see support.volvocars.com.
 - Sort order select sort order in the contact list.

Call notifications in head up display*

- Tap **Settings** in the center display's Top view.
- Tap My Car → Displays → Head-Up Display Options.
- 3. Select Show Phone.

Related information

- Phone (p. 498)
- Text message settings (p. 505)
- Settings for Bluetooth devices (p. 507)

- Connecting a phone to the car via Bluetooth for the first time (p. 499)
- Head-up display* (p. 144)
- Sound settings (p. 464)

* Option/accessory.

Settings for Bluetooth devices

Settings for Bluetooth-connected devices.

- 1. Tap **Settings** in the Top view.
- Tap Communication → Bluetooth Devices and select settings:
- Add device start the procedure for pairing a new device.
- Previously paired devices list connected/paired devices.
- Remove device remove a connected device.
- Allowed services for this device select what the device will be used for: making calls, sending/receiving messages, streaming media, Internet connection.
- Internet connection connect the vehicle to the Internet using the device's Bluetooth connection.

Bluetooth® declaration of conformity USA

FCC CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

Canada

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Related information

- Phone (p. 498)
- Phone settings (p. 506)
- Internet-connected vehicle* (p. 507)
- Connecting a phone to the car via Bluetooth for the first time (p. 499)

Internet-connected vehicle*

When the vehicle is connected to the Internet, it is possible to use web radio and music services via apps, download software and contact retailers from the vehicle.

The vehicle can be connected to the Internet using Bluetooth, Wi-Fi or the vehicle's integrated modem.

AUDIO, MEDIA AND INTERNET

When the vehicle is connected to the Internet, other devices may share the vehicle's Internet connection (Wi-Fi hotspot)¹¹.

The connection status is shown by a symbol in the center display's status bar.



(i) NOTE

Data (data traffic) is transfered when using the internet, which can incur additional costs.

Activating data roaming can cause additional charges.

Contact your network operator about data traffic costs.

(i) NOTE

When using Apple CarPlay, it is only possible to connect the vehicle to the Internet using Wi-Fi or the vehicle's modem.

(i) NOTE

When using Android Auto, it is possible to connect the vehicle to the Internet using Wi-Fi, Bluetooth or the vehicle's modem.

Read Terms and Conditions for Services and Customer Privacy Policy at

support.volvocars.com before connecting the car to the Internet.

- Symbols in the center display status bar (p. 126)
- Connecting the car to the Internet via a mobile device (Bluetooth) (p. 509)
- Connecting the car to the Internet via a mobile device (Wi-Fi) (p. 509)
- Connect the car to the Internet via car modem (SIM card) (p. 510)
- Apps (p. 465)
- No or poor Internet connection (p. 512)

- Sharing Internet from the vehicle via Wi-Fi hotspot (tethering) (p. 511)
- Deleting Wi-Fi networks (p. 513)
- Wi-Fi technology and security (p. 513)
- Volvo ID (p. 26)
- Terms of use and data sharing (p. 514)

¹¹ This is not possible when the vehicle is connected to another Wi-Fi hotspot.

Connecting the car to the Internet via a mobile device (Bluetooth)

Establish an Internet connection using Bluetooth and tethering from a phone and get access to multiple connected services in your vehicle. The phone and the network service provider must support Internet sharing (tethering) and the subscription must include data transfer.

- To connect the vehicle to the Internet via a Bluetooth-connected phone, the phone must first be paired with the vehicle via Bluetooth. Ensure that the personal hotspot (portable/ personal hotspot) is activated in your phone.
- If the phone has been connected via Bluetooth previously, tap **Settings** in the center display's Top view.
- In the center display: Tap Communication
 → Bluetooth Devices.
- Mark the window for Bluetooth Internet connection under the heading Internet connection.
 - Your vehicle is now connected to the Internet via your Bluetooth-connected phone.

i NOTE

When using Apple CarPlay, it is only possible to connect the vehicle to the Internet using Wi-Fi or the vehicle's modem.

Related information

- Internet-connected vehicle* (p. 507)
- Connect the car to the Internet via car modem (SIM card) (p. 510)
- Connecting a phone to the car via Bluetooth for the first time (p. 499)
- Connecting the car to the Internet via a mobile device (Wi-Fi) (p. 509)
- Apple® CarPlay®* (p. 493)
- No or poor Internet connection (p. 512)
- Settings for Bluetooth devices (p. 507)

Connecting the car to the Internet via a mobile device (Wi-Fi)

Establish an Internet connection via Wi-Fi tethering from a phone and get access to multiple connected services in your vehicle.

The phone and the network service provider must support Internet sharing (tethering) and the subscription must include data transfer.



- Activate Internet sharing (personal hotspot) in the phone.
- 2. Tap **Settings** in the Top view.
- Proceed to Communication → Wi-Fi.
- Activate/deactivate by tapping to check/ uncheck the Wi-Fi box.
- Tap the name of the network you would like to connect.
- 6. Enter the network password.
- 7. If a different connection was used previously, confirm the connection change.
 - > The vehicle will connect to the network.

Please note that certain cellular phones will disable Internet sharing (tethering) when the connec-

tion to the vehicle has been broken, e.g. when the phone has been removed from the vehicle. The phone's tethering function will then need to be reactivated the next time the phone's hotspot is used to connect to the Internet.

When a phone is connected to the vehicle, it will be saved for future use. When the maximum number of 50 connected phones has been reached, the first will be deleted. To display a list of saved networks or to manually delete saved networks, tap Settings > Communication > Wi-Fi > Saved networks

Technical and security requirements for Wi-Fi connection are described in a separate section.

Related information


- Internet-connected vehicle* (p. 507)
- Deleting Wi-Fi networks (p. 513)
- No or poor Internet connection (p. 512)
- Wi-Fi technology and security (p. 513)

Connect the car to the Internet via car modem (SIM card)

For vehicles equipped with Volvo On Call, it is possible to establish an Internet connection via the vehicle modem and a personal SIM card (P-SIM).

When the vehicle is connected using the integrated modem, the Volvo On Call services will use this connection.

1.



Insert a personal SIM card in the holder.

- 2. Tap **Settings** in the Top view.
- Tap Communication → Vehicle Modem Internet.
- Activate/deactivate by tapping to check/ uncheck the Vehicle modem Internet box.

- 5. If a different connection was used previously, confirm the connection change.
- 6. Enter the SIM card's PIN code.
 - > The vehicle will connect to the network.

Related information

- Internet-connected vehicle* (p. 507)
- No or poor Internet connection (p. 512)
- Vehicle modem settings (p. 511)

Option/accessory.

Vehicle modem settings

Your vehicle is equipped with a modem that can be used to connect the vehicle to the Internet. It is also possible to share this Internet connection over Wi-Fi.

- 1. Tap **Settings** in the Top view.
- Tap Communication → Vehicle Modem Internet and select settings:
- Vehicle modem Internet select this to use the vehicle's modem to connect to the Internet.
- Data usage tap Reset to reset the counter for the amount of data received and sent.
- Network

Select carrier - select a service provider manually or automatically.

Data roaming - if the box is checked, the vehicle modem will attempt to connect to the Internet when the vehicle is outside its home network (e.g. if you are in another country). Please note that this could entail additional charges. Consult with your service provider for data roaming terms under your contract.

SIM card PIN

Change PIN - a maximum of 4 digits can be entered.

Disable PIN - select whether a PIN code will be required to access the SIM card.

 Send request code - used to e.g. download or check the balance remaining on a prepaid phone card. This function is specific to your service provider.

Related information

- Connect the car to the Internet via car modem (SIM card) (p. 510)
- No or poor Internet connection (p. 512)

Sharing Internet from the vehicle via Wi-Fi hotspot (tethering)

When the vehicle is connected to the Internet, other devices may share the vehicle's Internet connection 12



The network service provider (SIM card) must support Internet sharing (tethering).

1. Tap **Settings** in the Top view.

- Tap Communication → Vehicle Wi-Fi Hotspot.
 - 3. Tap **Network name** to assign a name to the hotspot.
 - Tap Password and create a password. This
 password can then be used to connect other
 devices to this hotspot.
 - Tap Frequency band and select a frequency for the hotspot to use to transmit data. Please note that selecting a frequency is not possible on all markets.
 - Activate/deactivate by tapping to check/ uncheck the Vehicle Wi-Fi Hotspot box.
 - If Wi-Fi was previously used to connect to the Internet, confirm the change of connections.
 - > It is now possible for external devices to connect to the vehicle's Wi-Fi hotspot.

i NOTE

Activation of Wi-Fi hotspot can cause additional charges from your network operator.

Contact your network operator about data traffic costs.

The connection status is shown by a symbol in the center display's status bar.

Tap **Connected devices** to see a list of currently connected devices.

Related information

- Symbols in the center display status bar (p. 126)
- Internet-connected vehicle* (p. 507)
- No or poor Internet connection (p. 512)

No or poor Internet connection

Factors affecting the Internet connection.

The amount of data transmitted depends on the services or apps currently in use in the vehicle. Streaming music, for example, involves the transmission of a large amount of data, and this requires a good connection and a strong signal.

Phone to vehicle

Internet connection speed may vary depending on the location of the cellular phone in the vehicle. Move the phone closer to the center display to increase signal strength. Make sure that nothing is between the phone and center display that could be blocking the signal.

Phone to network operator

The speed of the mobile network varies depending on the coverage in the vehicle's current location. Coverage may be poorer in e.g. tunnels, mountainous areas, deep valleys or indoors. Connection speed is also dependent on the subscription you have with your service provider.



If you experience any problems with data traffic, contact your network service provider.

512 *Option/accessory.

¹² This does not apply when the vehicle is connected to the Internet via Wi-Fi.

Restarting the phone

If you experience any Internet connection problems, it may help to restart your phone.

Related information

- Internet-connected vehicle* (p. 507)
- Wi-Fi technology and security (p. 513)

Deleting Wi-Fi networks

Networks that are not needed can be deleted.

- 1. Tap **Settings** in the Top view.
- Proceed to Communication → Wi-Fi → Saved networks.
- 3. Tap **Forget** to delete the network.
- 4. Confirm the selection.
 - > The vehicle will no longer connect to the deleted network.

Deleting all networks

All networks can be deleted at once by performing a factory reset. Please note that all user data and system settings will be restored to original default factory settings.

Related information

- Internet-connected vehicle* (p. 507)
- No or poor Internet connection (p. 512)
- Resetting center display settings (p. 137)
- Connecting the car to the Internet via a mobile device (Wi-Fi) (p. 509)

Wi-Fi technology and security

Networks must meet certain criteria in order for the vehicle to connect.

It is possible to connect to the following types of networks:

- Frequency 2.4 or 5 GHz¹³.
- Standards 802.11 a/b/g/n.
- Security type WPA2-AES-CCMP.

The vehicle's Wi-Fi system is designed to handle Wi-Fi devices inside the vehicle.

Performance may be impaired if multiple devices are using a frequency at the same time.

Related information

• Internet-connected vehicle* (p. 507)

¹³ Selecting a frequency is not possible on all markets.

Terms of use and data sharing

The first time certain services and apps are started, a pop-up window with the heading Terms and conditions and Data sharing may open.

The aim is to inform the user about Volvo's terms of use and data sharing policy. By accepting data sharing, the user accepts that certain information will be sent from the vehicle. This is required for certain services and apps to work with full functionality.

Data sharing can be set from the center display's Settings menu.

Related information

 Activating and deactivating data sharing (p. 514)

Activating and deactivating data sharing

Data sharing for relevant services and apps can be set via the Settings menu in the center display.

- 1. Tap **Settings** in the Top view in the center display.
- Tap System → Privacy and data.
- 3. Select **Data sharing** to enable or disable data sharing.
- When data sharing is enabled, settings for individual services and apps in the list below can be changed.

When data sharing is disabled, the previous settings for individual services and apps are saved and restored when data sharing is enabled again.

Related information

• Terms of use and data sharing (p. 514)

Compatible file formats for media

In order to play media, the following file formats must be used.

Audio files

ruaio illo		
For- mat	File extension	Codec
MP3	.mp3	MPEG1 Layer III, MPEG2 Layer III, MP3 Pro (mp3 compatible), MP3 HD (mp3 compatible)
AAC	.m4a, .m4b, .aac	AAC LC (MPEG-4 part III Audio), HE-AAC (aacPlus v1/v2)
WMA	.wma	WMA8/9, WMA9/10 Pro
WAV	.wav	LPCM
FLAC	.flac	FLAC

Video files

Format	File extension
MP4	.mp4, m4v
MPEG-PS	.mpg, .mp2, .mpeg, .m1v

Format	File extension
AVI	.avi
AVI (DivX)	.avi, divx
ASF	.asf, .wmv
MKV	.mkv

Subtitles

Format	File extension
SubViewer	.sub
SubRip	.srt
SSA	.ssa

DivX®

DivX-certified devices have been tested for highquality DivX (.divx, .avi) video playback. When you see the DivX logo, you have the freedom to play your favorite DivX videos.

Profile	DivX Home Theater
Video codec	DivX, MPEG-4
Resolution	720x576
Audio speed (bit rate)	4.8Mbps
Frame rate	30 fps

File extension	.divx, .avi
Max. file size	4 GB
Audio codec	MP3, AC3
Subtitles	XSUB
Special functions	Multiple subtitles, multiple audio, resume play
Reference	Meets all requirements of the DivX Home Theater profile. Visit divx.com for more information and soft- ware tools to convert your files into DivX Home Theater video.

Related information

- Media player (p. 485)
- Video (p. 490)
- Playing DivX® (p. 490)

Technical specifications for USB devices

For the contents of USB devices to be read, the following specifications must be met.

Any folder structures will not be shown in the center display during playback.

	Max. number
Files	15 000
Folders	1 000
Folder levels	8
Playlists	100
Tracks in a playlist	1 000
Subfolders	No limit

Technical specifications for the USB-A connector

- Type A port
- Version 2.0
- Voltage 5 V
- Max. current 2.1 A

Related information

• Playing media via the USB port (p. 492)

Hard disk storage space

It is possible to view how much space is remaining on the vehicle's hard disk.

Storage information for the vehicle's hard disk can be shown, including total capacity, available capacity and how much space is used for installed apps. The information is found under

Settings → System → System Information → Storage.

Related information

• Apps (p. 465)

License agreement for audio and media

A license is an agreement on the right to conduct a certain activity or the right to use someone else's right according to terms and conditions specified in the agreement. The following texts are Volvo's agreements with manufacturers/developers.

Bowers & Wilkins



Bowers & Wilkins and B&W are trademarks of the B&W Group Ltd. Nautilus is a trademark of B&W Group Ltd. Kevlar is a registered trademark of DuPont.

Dirac Unison®



Dirac Unison co-optimizes the loudspeakers in frequency, time and space for the best possible bass integration and clarity. It enables a faithful reproduction of the acoustic characteristics of specific performance venues. Using advanced algorithms, Dirac Unison controls all loudspeakers digitally based on acoustic high-precision measurements. Like a conductor of an orchestra, it guarantees that the loudspeakers perform in perfect unison.

DivX®



DivX[®], DivX Certified[®] and associated logos are trademarks of DivX, LLC and are used under license.

This DivX Certified[®] device can play DivX® Home Theater Home Theater video files up to 576p (including .avi, .divx). Download free software at www.divx.com to create, play and stream digital video.

ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified® device must be registered in order to play purchased DivX Video-on-Demand (VOD) movies. To obtain your registration code, locate the DivX VOD section in your device setup menu. Go to vod.divx.com for more information on completing the registration process.

Patent number

Covered by one or more of the following patents in the US: 7,295,673; 7,460,668; 7,515,710; 8,656,183; 8,731,369; RE45,052.

Gracenote®



30518

Portions of the content are copyright © of Gracenote or its providers.

Gracenote, the Gracenote logo and logotype, "Powered by Gracenote" and Gracenote MusicID are either registered trademarks of Gracenote, Inc. in the United States and/or other countries.

Gracenote® End User License Agreement

This application or device contains software from Gracenote, Inc. in Emeryville, California, United States ("Gracenote"). The software from Gracenote (the "Gracenote Software") enables this application to perform disc and/or file identification and obtain music-related information, including name, artist, track, and title information ("Gracenote Data") from online servers or embedded databases (collectively "Gracenote Servers") and to perform other functions. You may use Gracenote Data only by means of the intended End-User functions of this application or device.

You agree that you will use Gracenote Data, the Gracenote Software, and Gracenote Servers for your own personal non-commercial use only. You agree not to assign, copy, transfer or transmit the Gracenote Software or any Gracenote Data to any third party. YOU AGREE NOT TO USE OR EXPLOIT GRACENOTE DATA, THE GRACENOTE SOFTWARE, OR GRACENOTE SERVERS, EXCEPT AS EXPRESSLY PERMITTED HEREIN.

You agree that your non-exclusive license to use the Gracenote Data, the Gracenote Software, and Gracenote Servers will terminate if you violate these restrictions. If your license terminates, you agree to cease any and all use of the Gracenote Data, the Gracenote Software, and Gracenote Servers. Gracenote reserves all rights in all Gracenote Data, all Gracenote Software, and all Gracenote Servers, including all ownership rights. Under no circumstances will Gracenote become liable for any payment to you for any information that you provide. You agree that Gracenote, Inc. may enforce its rights under this Agreement against you directly in its own name.

The Gracenote service uses a unique identifier to track queries for statistical purposes. The purpose of a randomly assigned numeric identifier is to allow the Gracenote service to count queries without knowing anything about who you are. For more information, see the web page for the Gracenote Privacy Policy for the Gracenote service.

The Gracenote Software and each item of Gracenote Data are licensed to you "AS IS." Gracenote makes no representations or warranties, express or implied, regarding the accuracy of any Gracenote Data from in the Gracenote Servers. Gracenote reserves the right to delete data from the Gracenote Servers or to change data categories for any cause that Gracenote deems sufficient. No warranty is made that the Gracenote Software or Gracenote Servers are error-free or that functioning of Gracenote Software or Gracenote Servers will be uninterrupted. Gracenote is not obligated to provide you with new enhanced or

additional data types or categories that Gracenote may provide in the future and is free to discontinue its services at any time.

GRACENOTE DISCLAIMS ALL WARRANTIES EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE, AND NON-INFRINGEMENT. GRACENOTE DOES NOT WARRANT THE RESULTS THAT WILL BE OBTAINED BY YOUR USE OF THE GRACENOTE SOFTWARE OR ANY GRACENOTE SERVER. IN NO CASE WILL GRACENOTE BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES OR FOR ANY LOST PROFITS OR LOST REVENUES.

© Gracenote, Inc. 2009

Sensus software

This software uses parts of sources from clib2 and Prex Embedded Real-time OS - Source (Copyright (c) 1982, 1986, 1991, 1993, 1994), and Ouercus Robusta (Copyright (c) 1990, 1993), The Regents of the University of California. All or some portions are derived from material licensed to the University of California by American Telephone and Telegraph Co. or Unix System Laboratories, Inc. and are reproduced herein with the permission of UNIX System Laboratories, Inc. Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met: Redistributions of

source code must retain the above copyright notice, this list of conditions and the following disclaimer. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution. Neither the name of the <ORGANIZATION> nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission. THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES. INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT. INDIRECT. INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES: LOSS OF USE, DATA, OR PROFITS: OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE. EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This software is based in part on the work of the Independent JPEG Group.

This software uses parts of sources from "libtess". The Original Code is: OpenGL Sample Implementation, Version 1.2.1, released January 26, 2000, developed by Silicon Graphics, Inc. The Original Code is Copyright (c) 1991-2000 Silicon Graphics, Inc. Copyright in any portions created by third parties is as indicated elsewhere herein. All Rights Reserved. Copyright (C) [1991-2000] Silicon Graphics, Inc. All Rights Reserved. Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"). to deal in the Software without restriction. including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions: The above copyright notice including the dates of first publication and either this permission notice or a reference to http:// oss.sqi,com/projects/FreeB/ shall be included in all copies or substantial portions of the Software. THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL

SILICON GRAPHICS, INC. BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE. Except as contained in this notice, the name of Silicon Graphics, Inc. shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Software without prior written authorization from Silicon Graphics, Inc.

This software is based in parts on the work of the FreeType Team.

This software uses parts of SSLeay Library: Copyright (C) 1995-1998 Eric Young (eay@cryptsoft.com). All rights reserved

Linux software

This product contains software licensed under GNU General Public License (GPL) or GNU Lesser General Public License (LGPL), etc.

You have the right of acquisition, modification, and distribution of the source code of the GPL/ LGPL software.

You may download Source Code from the following website at no charge: http://www.embedded-carmultimedia.jp/linux/oss/download/TVM_8351_013

The website provides the Source Code "As Is" and without warranty of any kind.

By downloading Source Code, you expressly assume all risk and liability associated with downloading and using the Source Code and complying with the user agreements that accompany each Source Code.

Please note that we cannot respond to any inquiries regarding the source code.

camellia:1.2.0

Copyright (c) 2006, 2007

NTT (Nippon Telegraph and Telephone Corporation). All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer as the first lines of this file unmodified.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY NTT "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A

PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL NTT BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Unicode: 5.1.0

COPYRIGHT AND PERMISSION NOTICE

Copyright c 1991-2013 Unicode, Inc. All rights reserved. Distributed under the Terms of Use in http://www.unicode.org/copyright.html.

Permission is hereby granted, free of charge, to any person obtaining a copy of the Unicode data files and any associated documentation (the "Data Files") or Unicode software and any associated documentation (the "Software") to deal in the Data Files or Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, and/or sell copies of the Data Files or Software, and to permit persons to whom the Data Files or Software are furnished to do so, provided that (a)


the above copyright notice(s) and this permission notice appear with all copies of the Data Files or Software, (b) both the above copyright notice(s) and this permission notice appear in associated documentation, and (c) there is clear notice in each modified Data File or in the Software as well as in the documentation associated with the Data File(s) or Software that the data or software has been modified.

THE DATA FILES AND SOFTWARE ARE PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OF THIRD PARTY RIGHTS, IN NO EVENT SHALL THE COPYRIGHT HOLDER OR HOLDERS INCLUDED IN THIS NOTICE BE LIABLE FOR ANY CLAIM, OR ANY SPECIAL INDIRECT OR CONSEQUENTIAL DAMAGES, OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE DATA FILES OR SOFTWARE.

Except as contained in this notice, the name of a copyright holder shall not be used in advertising or otherwise to promote the sale, use or other

dealings in these Data Files or Software without prior written authorization of the copyright holder.

Declaration of Conformity



USA

FCC CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

Canada

This device complies with Industry Canada license-exempt RSS standards. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

(◀

Country/ Area	
Brazil:	Modelo.NR-0V ANATEL 1801-14-5334 (01)0/894497(00999)
	Este equipamento opera em caráter secundário isto e, náo tem direito a protecão contra interferência prejudicial, mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário.
	Para consultas, visite: www.anatel.gov.br
EU:	Manufacturer: Mitsubishi Electric Corporation Sanda Works 2-3-33, Miwa, Sanda-city. Hyogo, 669-1513, Japan Mitsubishi Electric Corporation hereby declares that this type of radio equipment [Audio Navigation Unit] conforms with directive 2014/53/EU. For more information, see support.volvocars.com.
United Arab Emi- rates:	TRA REGISTERED No. ERO133275/14 DEARLER No. DA0088122/12

Country/ Area	
Kazakh- stan	
	Model name: NR-0V
	Manufacturer: Mitsubishi Electric Corporation
	Export country: Japan

∢∢

Country/ Area	
China:	1.
	■ 使用频率: 2.4 - 2.4835 GHz
	■ 等效全向辐射功率(EIRP): 天线增益< 10dBi 时: ≤100 mW 或≤20 dBm ①
	■ 最大功率谱密度: 天线增益< 10dBi 时: <20 dBm / MHz(EIRP) ①
	■ 载频容限: 20 ppm
	■ 帯外发射功率(在 2.4-2.4835GHz 頻段以外) ≤-80 dBm / Hz (EIRP)
	■ 杂散发射(辐射)功率(对应载波±2.5 倍信道带宽以外):
	● ≤-36 dBm / 100 kHz (30 - 1000 MHz)
	● ≤-33 dBm / 100 kHz (2.4 - 2.4835 GHz)
	● ≤-40 dBm / 1 MHz (3.4 - 3.53 GHz)
	● ≤-40 dBm / 1 MHz (5.725 - 5.85 GHz)
	● <-30 dBm / 1 MHz (其它 1 - 12.75 GHz)
	2. 不得擅自更改发射频率、加大发射功率(包括额外加装射频功率放大器),不得擅自外接天线或改用其它发射天线;
	3. 使用时不得对各种合法的无线电通信业务产生有害干扰;一旦发现有干扰现象时,应立即停止使用,并采取措施消除干扰后方可继续使用;
	4. 使用微功率无线电设备,必须忍受各种无线电业务的干扰或工业、科学及医疗应用设备的辐射干扰;
	5. 不得在飞机和机场附近使用。

Country/ Area	
Korea:	B 급 기기 (가정용 방송통신기자재)
	이 기기는 가정용(B 급) 전자파적합기기로서 주로
	가정에서 사용하는 것을 목적으로 하며, 모든
	지역에서 사용할 수 있습니다.
	해당 무선설비는 전파혼신 가능성이 있으므로 인명안전과 관련된 서비스는 할 수 없습니다.
Malaysia	This device has been certified under the Communications & Multimedia Act of 1998, Communications and Multimedia (Technical Standards) Regulations 2000.To retrieve your device's serial number, please visit (support.volvocars.com) and search for "SIRIM Label Verification". Device category: Navigation equipment for vehicle (Bluetooth) Model: NR-0V Type Approval No.: RBAY/18A/1015S(15-4067)

44

Country/ Area	
Mexico:	NOM-ANCE
Taiwan:	低功率電波輻射性電機管理辦法
	第十二條
	經型式認證合格之低功率射頻電機,非經許可,公司、商號或使用者均不得擅自
	變更頻率、加大功率或變更原設計之特性及功能。
	第十四條
	低功率射頻電機之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時,應
	立停用,改善至無干擾時方得繼續使用。前項合法通信,指依電信法規定作業之無線
	電通信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備
	之干擾。

- Audio, media and Internet (p. 464)
- Internet-connected vehicle* (p. 507)
- Media player (p. 485)
- Gracenote® (p. 489)
- Sensus connection and entertainment (p. 30)

WHEELS AND TIRES

Tires

The function of the tires is to carry loads, provide traction on road surfaces, reduce vibrations and protect the wheels from wear.

The tires significantly influence the vehicle's driving characteristics. The type, dimensions, tire pressure and speed rating have a considerable impact on how the vehicle performs.

Your vehicle is equipped with tires according to the vehicle's tire information placard on the B-pillar (the structural member at the side of the vehicle, at the rear of the driver's door opening).

∴ WARNING

A damaged tire could cause the driver to lose control of the vehicle.

! CAUTION

Some Volvo models are equipped with an Ultra High Performance tire and wheel combination designed to provide maximum dry pavement performance with consideration for hydroplaning resistance. They may be more susceptible to road hazard damage and, depending on driving conditions, may achieve a tread life of less than 30,000 km (20,000 miles). Even if this vehicle is equipped with Volvo's advanced AWD or stability system, these tires are not designed for winter driving, and should be replaced with winter tires when weather conditions dictate.

The tires have good road holding characteristics and offer good handling on dry and wet surfaces. It should be noted however that the tires have been developed to give these features on snow/ice-free surfaces.

Most models are equipped with "all-season" tires, which provide a somewhat higher degree of roadholding on slippery road surfaces than tires without the "all-season" rating. However, for optimal roadholding on icy or snow-covered roads, we recommend snow tires on all four wheels.


When replacing tires, be sure that the new tires are the same size designation, type (radial) and preferably from the same manufacturer, on all

four wheels. Otherwise there is a risk of altering the vehicle's roadholding and handling characteristics.

Recommended tires

On delivery, the car is equipped with Volvo original tires that have the VOL¹ marking on the side of the tires. These tires have been designed specifically for your vehicle. It is therefore important when replacing tires that the new tires have this same marking to help maintain the vehicle's driving characteristics, comfort and fuel consumption.

New tires



Tires are perishable goods. After a few years, they will begin to harden and their friction properties will gradually deteriorate. Always replace tires with the freshest tires possible. This is particularly important for snow tires. A series of numbers is

¹ This may vary for certain tire dimensions.

imprinted on the sidewall of the tire. The last four digits in the series is the Department of Transportation (DOT) stamp and indicates the week and year the tire was manufactured. The tire in the illustration has 0717 as the last four digits, which means it was manufactured week 7 of 2017.

Tire age

Tires degrade over time, even when they are not being used. It is recommended that tires generally be replaced after 6 years of normal service. Heat caused by hot climates, frequent high loading conditions or Ultra Violet (U.V.) exposure can accelerate the aging process. The temporary spare 2 should also be replaced at 6-year intervals, even if it has never been used. A tire with e.g., visible cracks or discoloration should be replaced immediately.

Tire economy

- Maintain correct tire pressure.
- Avoid fast starts, hard braking and tire screeching.
- Tire wear increases with speed.
- Correct front wheel alignment is very important.
- Unbalanced wheels impair tire economy and driving comfort.

- Tires must maintain the same direction of rotation throughout their lifetime.
- When replacing tires, the tires with the most tread should be mounted on the rear wheels to reduce the chance of oversteer during hard braking.
- Hitting curbs or potholes can damage the tires and/or wheels permanently.

Tire rotation

Your vehicle has no required tire rotation. Driving style, tire pressure, climate and road conditions affect how quickly the tires age and exhibit signs of wear. Maintaining the correct tire pressure helps keep tread wear evenly distributed.

To help prevent differences in tread depth and wear patterns forming on the tires, the front and rear wheels should be rotated, i.e. the front tires moved to the rear and the rear tires moved to the front. Ideally, tire rotation should be done the first time after approximately 5000 km (ca 3100 miles) and thereafter at 10,000 km (approx. 6200 miles) intervals.

If you have any questions regarding tread depth, Volvo recommends consulting an authorized Volvo workshop. If significant differences in wear (> 1 mm difference in tread depth) between the tires have already occurred, the least worn tires should always be mounted on the rear wheels. A front-wheel skid (understeer) is usually easier to

control than a rear-wheel skid (oversteer). If the front wheels skid, the vehicle will continue in a straight line instead of the rear wheels skidding to the side, which could cause you to completely lose control of the vehicle. It is therefore important that the rear wheels never lose grip before the front wheels.

Storing wheels and tires

When storing complete wheels (tires mounted on rims), they should be suspended off the floor or placed on their sides on the floor.

Tires not mounted on rims should be stored on their sides or standing upright, but should not be suspended.



CAUTION

Tires should preferably be stored in a cool, dry, dark place, and should never be stored in close proximity to solvents, gasoline, oils, etc.

² Not available on all models

™ WARNING


- The wheel and tire sizes for your Volvo are specified to meet stringent stability and handling requirements. Unapproved wheel/tire size combinations can negatively affect your vehicle's stability and handling.
- Any damage caused by installation of unapproved wheel/tire size combinations will not be covered by your new vehicle warranty. Volvo assumes no responsibility for death, injury, or expenses that may result from such installations.

Related information

- Checking tire pressure (p. 535)
- Tire direction of rotation (p. 530)
- Tread wear indicator (p. 531)
- Tire pressure monitoring system* (p. 537)
- Tire sealing system (p. 550)
- Uniform Tire Quality Grading (p. 534)
- Tire terminology (p. 531)
- Tire sidewall designations (p. 532)
- Loading recommendations (p. 564)

Tire direction of rotation

Tires with tread designed to roll in only one direction are marked with an arrow on the sidewall.



The arrow shows the tire's direction of rotation.

- The tire should maintain the same direction of rotation throughout its service life.
- Tires should only be moved between the front and back, never from right to left or vice versa.
- Incorrectly mounted tires impair the vehicle's braking properties and ability to force aside rain, snow and slush.
- The tires with the most tread should always be mounted on the rear wheels to help reduce the risk of skidding.

i NOTE

Use tires of the same type, dimensions and make (manufacturer) on each axle.

Related information

Tires (p. 528)

*Option/accessory.

Tread wear indicator

The tread wear indicator shows the status of the tire's tread



The tread wear indicator is a narrow elevated strip running across the tire's longitudinal tread grooves. The letters TWI (Tread Wear Indicator) are visible on the side of the tire. When approximately 1.6 mm (1/16 inch) is left on the tread, the tread will be at the same height as the tread wear indicator. Replace the tire as soon as possible. Tires with low tread offer very poor traction in rain or snow.

Related information

Tires (p. 528)

Tire terminology

The following is a glossary of tire-related terms. The tire suppliers may have additional markings, notes or warnings such as standard load, radial tubeless, etc.

- Tire information placard: A placard showing the OE (Original Equipment) tire sizes, recommended inflation pressure, and the maximum weight the vehicle can carry.
- Tire Identification Number (TIN): A number on the sidewall of each tire providing information about the tire brand and manufacturing plant, tire size and date of manufacture.
- **Inflation pressure**: A measure of the amount of air in a tire.
- Standard load: A class of P-metric or Metric tires designed to carry a maximum load at 35 psi [37 psi (2.5 bar) for Metric tires]. Increasing the inflation pressure beyond this pressure will not increase the tires load carrying capability.
- Extra load: A class of P-metric or Metric tires designed to carry a heavier maximum load at 41 psi [43 psi (2.9 bar) for Metric tires]. Increasing the inflation pressure beyond this pressure will not increase the tire's load carrying capability.
- kPa: Kilopascal, a metric unit of air pressure.
- PSI: Pounds per square inch, a standard unit of air pressure.

- B-pillar: The structural member at the side of the vehicle behind the front door.
- Bead area of the tire: Area of the tire next to the rim.
- Sidewall of the tire: Area between the bead area and the tread.
- Tread area of the tire: Area of the perimeter of the tire that contacts the road when mounted on the vehicle.
- Rim: The metal support (wheel) for a tire or a tire and tube assembly upon which the tire beads are seated.
- Maximum load rating: a figure indicating the maximum load in pounds and kilograms that can be carried by the tire. This rating is established by the tire manufacturer.
- Maximum permissible inflation pressure: the greatest amount of air pressure that should ever be put in the tire. This limit is set by the tire manufacturer.
- Recommended tire inflation pressure: inflation pressure, established by Volvo, which is based on the type of tires that are mounted on a vehicle at the factory. This information can be found on the tire inflation placard(s) located on the driver's side B-pillar and in the tire inflation table in this chapter.
- Cold tires: The tires are considered to be cold when they have the same temperature as the surrounding (ambient) air. This tem-


perature is normally reached after the vehicle has been parked for at least 3 hours.

Related information

• Tires (p. 528)

Tire sidewall designations

The following information can be found on a tire's sidewall.



Federal law mandates that tire manufacturers place standardized information on the sidewall of all tires (see the illustration).

The vehicle has been certified with certain combinations of wheels and tires.

The following information is listed on the tire sidewall:

The tire designation:

i NOTE

Please be aware that the following tire designation is an **example only** and that this particular tire may not be available on your vehicle.

- 215: the width of the tire (in millimeters) from sidewall edge to sidewall edge. The larger the number, the wider the tire.
- 2. **65**: The ratio of the tire's height to its width in percent.
- 3. **R**: Radial tire (the designation **RF** and the symbol indicate that the vehicle is equipped with optional self-supporting run flat tires³
- 4. **15**: The diameter of the wheel rim (in inches).
- 95: The tire's load index. In this example, a load index of 95 equals a maximum load of 1521 lbs (690 kg).
- 6. H: The tire's speed rating, or the maximum speed at which the tire is designed to be driven for extended periods of time, carrying a permissible load for the vehicle, and with correct inflation pressure. For example, H indicates a speed rating of 210 km/h (130 mph).

 $[\]ensuremath{^3}$ Self-supporting run flat tires may not be available on all models.

(i)

NOTE

The tire's load index and speed rating may not appear on the sidewall because they are not required by law.

- 7. M+S or M/S = Mud and Snow, AT = All Terrain. AS = All Season
- 8. U.S. DOT Tire Identification Number (TIN): This begins with the letters "DOT" and indicates that the tire meets all federal standards. The next two numbers are the factory code where the tire was manufactured, the next two are the tire size code and the last four numbers represent the week and year the tire was made. For example, 0717 means that the tire was manufactured during week 7 of 2017. The numbers in between are marketing codes used at the manufacturer's discretion. This information helps a tire manufacturer identify a tire for safety recall purposes.
- Tire Ply Composition and Material Used: Indicates the number of plies indicates or the number of layers of rubber-coated fabric in the tire tread and sidewall. Tire manufacturers also must indicate the ply materials in the tire and the sidewall, which include steel, nylon, polyester, and others.
- 10. Maximum Load: Indicates the maximum load in pounds and kilograms that can be carried by the tire. Refer to the vehicle's tire

information placard located on the B-Pillar for the correct tire pressure for your vehicle.

- 11. Treadwear, Traction, and Temperature grades.
- 12. **Maximum permissible inflation pressure:** the greatest amount of air pressure that should ever be put in the tire. This limit is set by the tire manufacturer.

Speed Symbol

A tire's Speed Symbol (SS) indicates the maximum speed for which the tire has been certified and should be at least equivalent to the vehicle's top speed.

Winter tires, with or without studs, are exceptions and may use a lower SS. When winter tires are installed, the vehicle may not be driven faster than the tires' SS.

The vehicle's speed should always be determined by the posted speed limit and traffic and road conditions, not the tire's SS.

The following table indicates the maximum permissible speed for each SS.

М	130 km/h (81 mph)
Q	160 km/h (100 mph)
Т	190 km/h (118 mph)
Н	210 km/h (130 mph)

V	240 km/h (149 mph)
W	270 km/h (168 mph)
Υ	300 km/h (186 mph)

∕ WARNING

- The wheel and tire sizes for your Volvo are specified to meet stringent stability and handling requirements. Unapproved wheel/tire size combinations can negatively affect your vehicle's stability and handling.
- Any damage caused by installation of unapproved wheel/tire size combinations will not be covered by your new vehicle warranty. Volvo assumes no responsibility for death, injury, or expenses that may result from such installations.

Related information

Tires (p. 528)

Uniform Tire Quality Grading

ALL PASSENGER VEHICLE TIRES MUST CONFORM TO FEDERAL SAFETY REQUIRE-MENTS IN ADDITION TO THESE GRADES.

Quality grades can be found, where applicable, on the tire sidewall between the tread shoulder and maximum section width. For example:

Treadwear 200 Traction AA Temperature A

TREADWEAR

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course. For example, a tire graded 150 would wear one and one half (1 ½) times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use, however, and many depart significantly from the norm due to variation in driving habits, maintenance practices and differences in road characteristics and climate.

TRACTION

The traction grades, from highest to lowest, are AA, A, B, and C, as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.

The traction grade assigned to this tire is based on braking (straight-ahead) traction tests and is not a measure of cornering (turning) traction.

TEMPERATURE

The temperature grades are A (the highest), B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a minimum level of performance that all passenger vehicle tires must meet under the Federal Motor Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

Λ

WARNING

The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, under-inflation, or excessive loading, either separately or in combination, can cause heat buildup and tire failure.

- Tires (p. 528)
- Tire sidewall designations (p. 532)

Checking tire pressure

Correct inflation pressure helps improve driving stability, save fuel and increase the service life of the tires.

Tire pressure decreases over time, which is normal. Tire pressure also varies depending on the ambient temperature. Driving on under-inflated tires could cause the vehicle to overheat and lead to damage. Tire pressure affects traveling comfort, road noise and driving characteristics.

Check the pressure in the tires every month. Use the recommended inflation pressure for cold tires for optimal tire performance and wear. Under-inflated or over-inflated tires could cause uneven tread wear.

Use an air pressure gauge and check the inflation pressure on all the tires, including the spare tire⁴, at least once a month and before long trips. Volvo strongly recommends buying a reliable air pressure gauge, as the automatic gauges provided at service stations may be inaccurate.

- Under-inflation is the most common cause of tire failure and may result in severe tire cracking, tread separation, or "blow-out," with unexpected loss of vehicle control and increased risk of injury.
- Under-inflated tires reduce the load carrying capacity of your vehicle.

Cold tires

Inflation pressure should be checked when the tires are cold.

The tires are considered to be cold when they have the same temperature as the surrounding (ambient) air.

This temperature is normally reached after the vehicle has been parked for at least 3 hours.

After driving for approximately 1.6 km (1 mile), the tires are considered to be warm. If you need to drive longer than that to inflate the tires, check and record the inflation pressure of the tires first and inflate accordingly when you arrive at the pump.

When the ambient temperature changes, so does the inflation pressure. A 10-degree temperature drop causes a corresponding drop in inflation pressure of 1 psi (7 kPa). Check the inflation pressure of the tires regularly and adjust to the correct pressure, which can be found on the vehicle's tire information placard or certification label.

If you check inflation pressure when the tires are warm, you should never release air. The tires become warm after driving and it is normal for warm tires to have an inflation pressure above the recommended pressure for cold tires. A warm tire with an inflation pressure equal to or under the recommended pressure for cold tires could be significantly under-inflated.

- Adjusting tire pressure (p. 536)
- Recommended tire pressure (p. 537)
- Tire pressure monitoring system* (p. 537)
- Tires (p. 528)

⁴ Not available in all models

Adjusting tire pressure

Tire pressure decreases over time, which is normal. The tire pressure must therefore be adjusted to maintain the recommended tire pressure.

Use the recommended inflation pressure for cold tires for optimal tire performance and wear.

i NOTE

To help prevent incorrect inflation pressure, pressure should be checked when the tires are cold. The tires are considered to be cold when they have reached the same temperature as the ambient temperature (about 3 hours after the vehicle was last driven). After driving for a few kilometers, the tires will warm up and the pressure will increase.

- 1. Remove the valve cap from the tire and press the air pressure gauge firmly onto the valve.
- Inflate to the recommended inflation pressure.

3. Screw the valve cap back on.

i NOTE

- After inflating a tire, always replace the valve cap to help prevent valve damage caused by gravel, dirt, etc.
- Use plastic valve caps only. Metal caps could corrode and become difficult to remove.
- Visually inspect the tire to make sure there are no nails or other embedded objects that could puncture the tire and cause air leakage.
- Check the sidewalls to make sure there are no gouges, cuts, bulges or other irregularities.
- Repeat this procedure for each tire, including the spare tire⁵.

i NOTE

If you have overfilled the tire, release air by pushing on the metal stem in the center of the valve. Then recheck the pressure with your tire gauge.

Some spare tires require higher inflation pressure than the other tires. Consult the tire inflation pressure table or the inflation pressure placard.

- Recommended tire pressure (p. 537)
- Checking tire pressure (p. 535)
- Inflate tires with the compressor included in the tire sealing system (p. 555)
- Approved tire pressure (p. 647)

⁵ Not available on all models

Recommended tire pressure

The tire pressure placard on the driver's side B pillar (between the front and the rear door) indicates tire pressure for different loads and speed conditions.



The placard specifies the designation for the factory-mounted tires on the vehicle, as well as load limits and inflation pressures.

Related information

- Checking tire pressure (p. 535)
- Approved tire pressure (p. 647)

Tire pressure monitoring system*

The tire pressure monitoring system, Tyre Pressure Monitoring System (TPMS), provides a warning symbol in the instrument panel if pressure is too low in one or more tires.

Symbol

Explanation

This symbol illuminates to indicate low inflation pressure.

If there is a system malfunction, the inflation pressure warning symbol will flash for approximately one minute and then glow steadily.

System description

The tire pressure monitoring system measures differences in rotational speed between the wheels through the ABS system to determine if the tires are properly inflated. If inflation pressure in a tire is too low, its diameter (and consequently its rotational speed) changes. By comparing the tires with each other, the system can determine if the pressure in one or more tires is too low.

General information about the tire pressure monitoring system

In the following description, the tire monitoring system is generally referred to as TPMS.

Each tire, including the spare tire (if provided)⁶, should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label. (If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label, you should determine the proper tire inflation pressure for those tires.)

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale when one or more of your tires is significantly under-inflated. Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure.

Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability. Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale.

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a mal-

⁶ Not available on all models

function, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended.

TPMS malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly.

Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

Messages in the instrument panel

If tire pressure is too low, the low tire pressure warning symbol is shown in the instrument panel along with a message.

- Tire pressure low Check tires, calibrate after fill
- Tire pressure system Temporarily unavailable
- Tire pressure system Service required

To keep in mind

 Always calibrate the system after changing wheels or adjusting tire pressure. See the tire

- pressure placard on the driver's side B pillar for Volvo-recommended tire pressures.
- If you switch to a tire of another size than the factory-mounted tires, the system must be calibrated for these tires to avoid false warnings.
- If a spare wheel⁷ is used, it is possible that the tire pressure monitoring system will not work correctly due to the differences between the wheels.
- The system does not replace the need for regular tire inspection and maintenance.
- It is not possible to deactivate the tire pressure monitoring system.

↑ WARNING

- Incorrect inflation pressure could lead to tire failure, which could cause the driver to lose control of the vehicle.
- The system cannot predict sudden tire damage.

Related information

- Recommended tire pressure (p. 537)
- Viewing tire pressure status in the center display* (p. 540)
- Action when warned of low tire pressure (p. 541)

Calibrating the tire pressure monitoring system* (p. 539)

538 *Option/accessory.

⁷ Not available on all models

Calibrating the tire pressure monitoring system*

In order for the tire pressure monitoring system, Tyre Pressure Monitoring System (TPMS), to function correctly, tire pressure reference values must be set correctly. This must be done each time the tires are changed or the tire pressure is adjusted.

For example, when driving with a heavy load or at high speeds (over 160 km/h (100 mph)), tire pressure should be adjusted to the Volvo-recommended tire pressure values. The system should then be recalibrated.

- 1. Switch off the ignition.
- Inflate the tires to the pressure indicated on the tire pressure placard on the driver's side B pillar.
- 3. Start the vehicle.
- 4. Open the Car status app in App view.



5. Tap **TPMS**.





NOTE

The car must be stationary when calibration is started.

- 6. Tap Calibrate.
- Tap **OK** to confirm that the tire pressure in all four tires has been checked and adjusted.

- 8. Run the car until calibration is complete.
 - Calibration is done when the vehicle is driving at a speed above 35 km/h (22 mph).
 - > When enough data has been collected for the system to detect low tire pressure, the color of the tire symbols in the center display will change from gray to green. The system will not provide any other confirmation that calibration has been completed.

If the car's ignition is switched off before calibration is complete, the tires in the center display change color from gray to green upon next start-up, even if calibration is not complete. Perform the calibration again and allow it to complete within the same operating cycle to ensure that the calibration is carried out correctly.

If start-up of calibration fails, the following message appears: Calibration unsuccessful. Try again..

(i) NOTE

Always remember to calibrate the Tire Pressure Monitoring System when the wheels have been changed or the tire inflation pressure has been corrected according to the tire pressure decal or tire inflation pressure table.

If correct reference values have not been set, the system cannot issue low tire pressure alerts correctly.

The vehicle must be stationary with the engine running to access the calibration button and to start the calibration process.

The exhaust gases contain carbon monoxide, which is invisible and odorless but very poisonous. For this reason, always perform the calibration procedure outdoors or in a workshop with exhaust gas evacuation equipment.

Related information

- Recommended tire pressure (p. 537)
- Adjusting tire pressure (p. 536)
- Viewing tire pressure status in the center display* (p. 540)
- Action when warned of low tire pressure (p. 541)
- Tire pressure monitoring system* (p. 537)

Viewing tire pressure status in the center display*

With the system for tire pressure monitoring, Tyre Pressure Monitoring System (TPMS), tire pressure status can be viewed in the center display.

Checking status

1. Open the Car status app in App view.



2. Tap **TPMS** to display the status of the tires.



Status indicator light

The graphic in the center display shows the status of each tire⁸.



Green tire:

 Inflation pressure is above the warning threshold.

Yellow tire:

 The tire's inflation pressure is too low. Stop and check/inflate the tire as soon as possible. Recalibrate the system after adjusting the tire pressure.

All tires yellow:

 The inflation pressure is too low in one or more tires. Stop and check/inflate the tires as soon as possible. Recalibrate the system after adjusting tire pressure.

All tires gray:

- Calibration in progress.
- Status unknown.

⁸ The illustration is generic. Layout may vary depending on vehicle model or software version.

The vehicle may need to be driven for a few minutes at a speed above 35 km/h (22 mph) to activate the system.

All tires gray and a message:

- Tire pressure system Temporarily unavailable. The indicator symbol will flash for about 1 minute and then glow steadily. The system is temporarily unavailable and will be activated momentarily.
- Tire pressure system Service required.
 The indicator symbol will flash for about 1 minute and then glow steadily. If the system is not working properly, contact a workshop⁹.

Related information

- Calibrating the tire pressure monitoring system* (p. 539)
- Action when warned of low tire pressure (p. 541)
- Tire pressure monitoring system* (p. 537)
- Vehicle status (p. 580)

Action when warned of low tire pressure

When the tire pressure monitoring system, Tyre Pressure Monitoring System (TPMS), detects low pressure in one or more of the vehicle's tires, the driver will be alerted that action is needed.



If the system's indicator symbol illuminates and the message **Tire pressure low** is displayed, check the tire pressure and inflate if necessary.

- 1. Switch off the ignition.
- Check the inflation pressure on all four tires using a tire pressure gauge.
- Inflate the tire to the correct pressure (see the tire pressure decal on the driver's side door pillar).
- Through calibration of the system via the center display after the tire pressure has been adjusted.

Please be aware that the indicator symbol will not go out until the low tire pressure has been corrected and the system has been recalibrated.

(i) NOTE

To help prevent incorrect inflation pressure, pressure should be checked when the tires are cold. The tires are considered to be cold when they have reached the same temperature as the ambient temperature (about 3 hours after the vehicle was last driven). After driving for a few kilometers, the tires will warm up and the pressure will increase.

(i) NOTE

- After inflating a tire, always replace the valve cap to help prevent valve damage caused by gravel, dirt, etc.
- Use plastic valve caps only. Metal caps could corrode and become difficult to remove.

↑ WARNING

- Incorrect inflation pressure could lead to tire failure, which could cause the driver to lose control of the vehicle.
- The system cannot predict sudden tire damage.

⁹ An authorized Volvo workshop is recommended.

Related information

- Recommended tire pressure (p. 537)
- Adjusting tire pressure (p. 536)
- Calibrating the tire pressure monitoring system* (p. 539)
- Viewing tire pressure status in the center display* (p. 540)
- Tire pressure monitoring system* (p. 537)
- Inflate tires with the compressor included in the tire sealing system (p. 555)

When changing wheels

The wheels can be changed, e.g. to switch to snow tires or spare tires. Follow the applicable instructions for removing and installing the wheel.

Changing to tires of another dimension Make sure that the tire dimension is approved for

use on the vehicle.

If you change to tires of another dimension, contact an authorized Volvo workshop to update the vehicle's software. A software update may be necessary when changing to tires of larger/ smaller dimensions or when changing to or from snow tires.

Related information

- Removing a wheel (p. 544)
- Installing a wheel (p. 546)
- Tool kit (p. 542)
- Snow tires (p. 549)
- Spare wheel (p. 547)
- Wheel bolts (p. 543)

Tool kit

Tools for e.g. towing or changing wheels are provided in the vehicle's cargo compartment.



The foam block under the cargo compartment floor contains the towing eyelet, the tire sealing system, the tool for removing plastic wheel bolt covers and the tool for removing the locking wheel holts

If the vehicle is equipped with a spare wheel*10, a jack, lug wrench, and a package with disposable gloves and a bag for the damaged wheel are also provided.

Related information

- When changing wheels (p. 542)
- Jack* (p. 543)

¹⁰ Not available on all models

Jack*

The jack can be used to lift the vehicle to e.g. change a wheel.



The illustration is generic - the design may vary.

! CAUTION

- When not in use, the jack* should be kept in its storage compartment under the cargo compartment floor.
- The jack provided with your vehicle is intended to be used only in temporary situations such as changing wheels in the event of a flat tire. Only the jack that came with your particular model should be used to lift the vehicle. If the vehicle needs to be lifted more frequently or for a prolonged period, using a garage jack or hoist is recommended. Always follow this device's instructions for use.

The jack needs to be cranked together to the correct position in order to fit.

Models with leveling control*

If the vehicle is equipped with the optional pneumatic suspension, it must be turned off before the vehicle is lifted on a jack.

Related information

• Tool kit (p. 542)

Wheel bolts

The wheel bolts hold the wheel in place on the wheel hub.

! CAUTION

The wheel bolts should be tightened to 140 Nm (103 ft. lbs.). Over-tightening or under-tightening could damage the threaded joints.

Only use rims that have been tested and approved by Volvo and are included in Volvo's original product range.

Use a torque wrench to check that the wheel bolts are tightened correctly.

Do not grease the wheel bolt threads.

The wheel bolts may need to be tightened again several days after a wheel change. Temperature fluctuations and vibrations can cause them to loosen slightly.

Locking wheel bolts*

A tool for removing the locking wheel bolts is located in the foam block under the cargo compartment floor.

Related information

- Removing a wheel (p. 544)
- Installing a wheel (p. 546)

Removing a wheel

Instructions for removing a wheel when changing wheels. Wheel changes must always be carried out correctly.

! CAUTION

- When not in use, the jack* should be kept in its storage compartment under the cargo compartment floor.
- The jack provided with your vehicle is intended to be used only in temporary situations such as changing wheels in the event of a flat tire. Only the jack that came with your particular model should be used to lift the vehicle. If the vehicle needs to be lifted more frequently or for a prolonged period, using a garage jack or hoist is recommended. Always follow this device's instructions for use.

! WARNING

- Apply the parking brake and put the gear selector in the Park (**P**) position.
- Block the wheels standing on the ground, use rigid wooden blocks or large stones.
- Check that the jack is not damaged, the threads are properly lubricated and it is free from dirt.
- Be sure the jack is on a firm, level, nonslippery surface and that it is upright and not leaning.
- The jack must correctly engage in the jack attachment.
- No objects should be placed between the base of the jack and the ground, or between the jack and the attachment bar on the vehicle.
- Never let anyone remain in the vehicle when it is raised on a jack.
- If a tire must be changed near passing traffic, make sure all passengers move to a safe location.
- Use a jack intended for the vehicle when changing a tire. For any other job, use stands to support the vehicle.
- Never crawl under or allow any part of your body to be extended under a vehicle supported by a jack.

- Turn on the vehicle's hazard warning flashers if a wheel change must be performed in an area with traffic.
- Apply the parking brake and put the gear selector in P.
 - For vehicles with **Leveling Control***: If the vehicle is equipped with pneumatic suspension, this must be switched off before the vehicle is lifted with the jack*.
- Take out the jack*, lug wrench* and tool for removing the plastic covers, which are stowed in the foam block.



Tool for removing the plastic covers on the wheel bolts.

 Place chocks in front of and behind the wheels that are still on the ground. For example, use heavy wooden blocks or large stones. Using the lug wrench*, screw the towing eye into place as far as possible according to the instructions.




(!) CAUTION

The towing eyelet must be screwed into the lug wrench* as far as possible.

- Remove the plastic covers from the wheel bolts using the designated tool.
- With the vehicle still on the ground, use the lug wrench/towing eye to loosen the wheel bolts ½-1 turn by pressing downward (counterclockwise).

8. When hoisting the vehicle, it is important that the jack* or garage lift arms are positioned on the designated points under the vehicle. The triangle markings on the plastic cover indicate where the jack attachment points/ lifting points are located. There are two jack attachment points on each side of the vehicle. There is a groove for the jack at each attachment point.



 Position the jack under the attachment point being used, ensuring that the surface is firm, flat and not slippery.

- 10. Crank it up until it is properly aligned and it is in contact with the vehicle's jack attachment point. Make sure the top of the jack (or the garage lift arms) is correctly positioned in the attachment point, with the bump on the top of the jack in the recess in the attachment point and the base positioned vertically under the attachment point.
 - 11. Turn the jack so that the crank is as far as possible from the side of the vehicle, which will position the jack's arms perpendicular to the vehicle's direction of movement.
 - 12. Raise the vehicle until the wheel to be changed can move freely. Unscrew the wheel bolts and lift off the wheel.

Related information

- Leveling control settings* (p. 435)
- When changing wheels (p. 542)
- Hoisting the vehicle (p. 583)
- Jack* (p. 543)
- Tool kit (p. 542)
- Installing a wheel (p. 546)

Installing a wheel

Instructions for installing a wheel during a wheel change.

(i) NOTE

The jack provided with your vehicle is intended to be used only in temporary situations such as changing wheels in the event of a flat tire. Only the jack that came with your particular model should be used to lift the vehicle. If the vehicle needs to be lifted more frequently or for a prolonged period, using a garage jack or hoist is recommended. Always follow this device's instructions for use.

WARNING

- Apply the parking brake and put the gear selector in the Park (P) position.
- Block the wheels standing on the ground. use rigid wooden blocks or large stones.
- Check that the jack is not damaged, the threads are properly lubricated and it is free from dirt.
- Be sure the jack is on a firm, level, nonslippery surface and that it is upright and not leaning.
- The jack must correctly engage in the iack attachment.
- No objects should be placed between the base of the jack and the ground, or between the jack and the attachment bar on the vehicle.
- Never let anyone remain in the vehicle when it is raised on a jack.
- If a tire must be changed near passing traffic, make sure all passengers move to a safe location.
- Use a jack intended for the vehicle when changing a tire. For any other job, use stands to support the vehicle.
- Never crawl under or allow any part of your body to be extended under a vehicle supported by a jack.

- 1. Clean the contact surfaces between the wheel and the wheel hub.
- 2. Lift the wheel into place. Tighten the wheel bolts securely.

Do **not** grease the wheel bolt threads.

- Lower the vehicle so that the wheel cannot rotate.
- Tighten the wheel bolts in a crisscross pattern (as shown in illustration). It is important that the wheel bolts are securely tightened.
 Tighten to a torque of 140 Nm (103 ft.lbs.).
 Use a torque wrench to check torque.



5. Press the plastic covers onto the wheel bolts.

The wheel bolts may need to be tightened again several days after a wheel change. Temperature fluctuations and vibrations can cause them to loosen slightly.

i NOTE

- After inflating a tire, always replace the valve cap to help prevent valve damage caused by gravel, dirt, etc.
- Use plastic valve caps only. Metal caps could corrode and become difficult to remove.

Related information

- Leveling control settings* (p. 435)
- When changing wheels (p. 542)
- Hoisting the vehicle (p. 583)
- Jack* (p. 543)
- Tool kit (p. 542)
- Removing a wheel (p. 544)

Spare wheel¹¹

The spare wheel is a Temporary spare and can be used to temporarily replace a punctured tire on one of the vehicle's regular wheels.

The spare tire is only intended for temporary use. Replace it with a normal wheel as soon as possible.

The driving characteristics of the vehicle change and ground clearance reduces when the spare wheel is used. Do not wash the vehicle in an automatic car wash while using the Temporary Spare.

The recommended tire pressure must be maintained regardless of at which position the temporary spare wheel is used on the vehicle.

If the spare wheel is damaged, a new one can be purchased from a Volvo retailer.

Current legislation prohibits the use of the "Temporary Spare" tire other than as a temporary replacement for a punctured tire. It must be replaced as soon as possible by a standard tire. Road holding and handling may be affected with the "Temporary Spare" in use. Do not drive faster than 80 km/h (50 mph).


¹¹ Not available on all models

↑ WARNING

- The vehicle must never be driven with more than one "Temporary spare" tire mounted.
- Driving with a spare wheel may alter the driving characteristics of the vehicle.
 Replace the spare wheel with a normal wheel as soon as possible.
- The spare wheel is smaller than the normal wheel, which affects the vehicle's ground clearance. Watch for high curbs and do not wash the vehicle in an automatic car wash when a spare wheel is mounted.
- Follow the manufacturer's recommended tire inflation pressure for the spare wheel.
- On all-wheel drive vehicles, the drive on the rear axle can be disconnected.
- If the spare wheel is mounted on the front axle, snow chains must not be used.
- The spare wheel must not be repaired.

! CAUTION

The vehicle must not be driven with wheels of different dimensions or with a spare tire other than the one that came with the vehicle. The use of different size wheels can seriously damage your vehicle's transmission.



This illustration is general. The shape and design of the foam block may vary depending on vehicle model.

The spare wheel is located in the spare wheel well with the outside of the wheel facing downward. The same bolt runs through both the spare wheel and foam block to hold them into place. The foam block contains all tools needed to change a wheel.

Related information

- When changing wheels (p. 542)
- Recommended tire pressure (p. 537)

Accessing the spare wheel

Follow these instructions regarding handling the spare wheel.

- 1. Lift the rear edge of the cargo compartment floor.
- 2. Unscrew the retaining bolt.
- 3. Lift out the foam block containing the tools.
- 4. Lift out the spare wheel.

Stowing a flat tire

- Take out the package containing the wheel bag from the foam block and put the wheel in the bag.
- Return the tools to their correct positions in the foam block and put the foam block back in the vehicle.
- Screw down the foam block with the retaining bolt and lower the cargo compartment floor.
- Put the flat tire in the trunk/cargo compartment.

Related information

Spare wheel (p. 547)

Snow tires

Snow tires are designed for winter driving.

Volvo recommends snow tires with specific dimensions. The tire dimensions vary depending on engine type. When driving with snow tires, the correct type of tires must be mounted on all four wheels.



NOTE

Contact a Volvo dealer for advice on the best choice of rims and tires.

Tips for changing snow tires

When switching between regular tires and snow tires, mark the tires according to which side they were mounted on, e.g. **L** for left and **R** for right.

Studded tires

Studded tires should be broken in by driving 500–1000 km (300–600 miles) slowly and gently to help the studs settle properly in the tires. This gives the tire, and especially the studs, a longer service life.



NOTE

Regulations regarding the use of studded tires vary from country to country.

Tread depth

Road conditions with ice, slush and low temperatures place considerably higher demands on tires than summer conditions. Volvo therefore recommends not driving on snow tires that have a tread depth of less than 4 mm (0.15 inch).

Related information

- When changing wheels (p. 542)
- Winter driving (p. 440)
- Tread wear indicator (p. 531)

Snow chains

Using snow chains and/or snow tires can help improve traction in winter driving conditions.

\triangle

WARNING

Use Volvo genuine snow chains or equivalent snow chains that are suitable for the vehicle model and the tire and wheel sizes. Only **one-sided** snow chains are permitted.

If uncertain about snow chains, Volvo recommends contacting an authorized Volvo workshop. Use of the wrong snow chains could cause serious damage to the vehicle and result in an accident.

(!) CAUTION

Snow chains can be used on the vehicle, with the following restrictions:

- Volvo recommends not using snow chains on wheel dimensions larger than 19 inches.
- Always follow the manufacturer's installation instructions carefully. Install chains as tightly as possible and retighten periodically.
- Only put snow chains on the front wheels (also applies to all-wheel drive vehicles).
- If accessory, aftermarket or "custom" tires and wheels with different dimensions than the original tires and wheels are used, snow chains in some cases may NOT be used. Sufficient distance between the chains and brakes, suspension and body components must be maintained.
- Check local regulations regarding the use of snow chains before installing.
- Never exceed the snow chain manufacturer's specified maximum speed limit.
 Under no circumstances should you exceed 50 km/h (30 mph).
- Avoid bumps, holes or sharp turns when driving with snow chains.

- Avoid driving on surfaces without snow as this wears out both the snow chains and the tires.
- The handling of the vehicle can be adversely affected when driving with chains. Avoid fast or sharp turns as well as locked wheel braking.
- Some types of strap-on chains affect brake components and therefore must NOT be used.

Consult a Volvo retailer for more information about snow chains.

Related information

• Winter driving (p. 440)

Tire sealing system¹²

The temporary tire sealing system can be used to seal a puncture in a tire or to check and adjust the pressure in the tire.

Models equipped with a spare wheel¹³ do not have the tire sealing system.

The tire sealing system consists of a compressor and a bottle containing sealing compound. The sealing functions as a temporary repair.

(i) NOTE

The sealing compound effectively seals tires with punctures in the tread but may not be able to fully seal tires with punctures in the sidewall. Do not use the tire sealing system on tires with large tears, cracks or similar damage.

i) NOTE

The compressor is intended for temporary tire sealing and is approved by Volvo.

Location

The tire sealing system is located in a foam block under the floor of the cargo compartment.



Sealing compound bottle

The sealing compound bottle must be replaced if its expiration date has passed (see the decal on the bottle). Handle the old bottle as hazardous waste.

The sealing compound bottle must be replaced after use. Volvo recommends contacting an authorized Volvo workshop for replacement.


Related information

- Using the tire sealing system (p. 551)
- Inflate tires with the compressor included in the tire sealing system (p. 555)
- Tires (p. 528)

Using the tire sealing system

Sealing a tire using the tire sealing system, the Temporary Mobility Kit (TMK).


Overview



- Electrical cable
- 2 Hose
- Air release valve
- Protective hose cover
- Speed limit sticker
- 6 Bottle holder (orange cover)
- Air pressure gauge

- Sealing compound bottle
- Switch

Connecting



(i) NOTE

Do not break the seal of the bottle before use. The seal is broken automatically when the bottle is screwed into place.

¹² Certain models only.

¹³ Not available on all models

™ WARNING

Please keep the following points in mind when using the tire sealing system:

- The sealing compound bottle (no. 8 in the illustration) contains 1) rubber latex, natural and 2) ethanediol. These substances are harmful if swallowed.
- The contents of this bottle may cause allergic skin reactions or otherwise be potentially harmful to the respiratory tract, the skin, the central nervous system, and the eyes.

Precautions:

- Keep out of reach of children.
- Do not ingest the contents.
- Avoid prolonged or repeated contact with the skin. Remove any clothing that has come into contact with sealant.
- Wash thoroughly after handling.

First aid:

- Skin: Wash affected areas of the skin with soap and water. Get medical attention if symptoms occur.
- Eyes: Flush with plenty of water for least 15 minutes, occasionally lifting the upper and lower eyelids. Get medical attention if symptoms occur.

- Inhalation: Move the exposed person to fresh air. If irritation persists, get medical attention.
- Ingestion: Do NOT induce vomiting unless directed to do so by medical personnel. Get medical attention.
- Disposal: Dispose of this material and its container at a hazardous or special waste collection point.

↑ WARNING

- Do not remove the bottle while the tire sealing system is being used.
- Do not remove the hose while the tire sealing system is being used.
- Turn on the vehicle's hazard warning flashers if the tire sealing system is to be used in an area with traffic.

If the puncture was caused by a nail or similar object, do not remove it. It will help seal the hole.

Peel off the speed limit sticker from the side
of the compressor. Affix the decal to a clearly
visible location on the windshield to remind
the driver not to exceed this speed limit. Do
not drive faster than 80 km/h (50 mph) while
using a tire that has been temporarily
repaired with the tire sealing system.

- Make sure the switch is in the 0 (Off) position and take out the electric cable and the hose.
- Unscrew the orange cover on the compressor and unscrew the cap on the sealing compound bottle.
- 5. Screw the bottle onto the bottle holder as far as possible.

The bottle and the bottle holder are equipped with catches to help prevent the sealing compound from leaking. Once the bottle is screwed into place into the bottle holder, it cannot be unscrewed. The bottle can only be removed by a workshop. Volvo recommends an authorized Volvo workshop.

⚠ WARNING

Do not unscrew the bottle. It is equipped with a catch to prevent leakage.

 Unscrew the tire's valve cap and screw the hose's valve connector as far as possible onto the valve.

Be sure the air release valve on the compressor's hose is completely closed.

7. Connect the electrical cable to the nearest 12 V outlet and start the vehicle

(i) NOTE

Make sure that none of the vehicle's other 12 V sockets are used while the compressor is running.



WARNING

Never leave children unattended in the vehicle while the engine is running.

Start the compressor by moving the switch to the I (On) position.

WARNING

Never stand next to a tire being inflated with the compressor. If cracks, bulges, etc. form on the tire, switch off the compressor immediately. The vehicle should not be driven. Call roadside assistance to have the vehicle towed to a workshop for inspection/replacement of the tire. Volvo recommends an authorized workshop.



(i) NOTE

When the compressor first starts, air pressure may temporarily increase up to 6 bar (88 psi) but should decrease again after approximately 30 seconds.

9 Inflate the tire for 7 minutes



(!) CAUTION

To help avoid overheating, the compressor should never be used for more than 10 minutes at a time.

10. Switch off the compressor and check the inflation pressure using the air pressure gauge. The inflation pressure should be between 1.8 bar (22 psi) and 3.5 bar (51 psi). If the inflation pressure is too high, use the air release valve to release air.

WARNING

If the bottle is not removed in the correct order, sealant could spill out.



WARNING

If pressure falls below 1.8 bar (22 psi), the hole in the tire may be too large. The vehicle should not be driven. Call roadside assistance to have the vehicle towed to a workshop for inspection/replacement of the tire. Volvo recommends an authorized workshop.

- 11. Switch off the compressor and remove the electrical cable.
- 12. Unscrew the hose from the tire's valve and screw the valve cap back on.
- 13. Put the protective hose cover onto the hose to help prevent leakage of any residual sealing compound. Return the equipment to the cargo compartment.

WHEELS AND TIRES

14. Immediately drive the vehicle at least 3 km (2 miles) at a maximum speed of 80 km/h (50 mph) to allow the sealing compound to seal the tire, and then recheck the inflation pressure.



During the tire's first revolution, some sealing compound may spray out of the puncture hole.

∕ WARNING

Before driving away, make sure that no one is near the vehicle who could be sprayed with sealing compound. Make sure no one is within 2 meters(7 feet) of the vehicle.

15. Rechecking the inflation pressure

Connect the hose to the tire's valve and screw the hose connector onto the valve as far as possible. The compressor must be switched off.

- 16. Check the inflation pressure on the air pressure gauge.
 - If the pressure is under 1.3 bar (19 psi), the tire is not sufficiently sealed. The vehicle should not be driven. Call roadside assistance to have the vehicle towed.
 - If the inflation pressure is higher than

 1.3 bar (19 psi), the tire must be inflated
 to the inflation pressure specified on the
 tire pressure decal on the driver's side
 door pillar (1 bar = 100 kPa = 14.5 psi). If
 the inflation pressure is too high, use the
 air release valve to release air.

i) NOTE

Replace the sealing compound bottle and hose after use. Volvo recommends having these replaced by an authorized Volvo workshop.

Check inflation pressure regularly.

Volvo recommends driving to the nearest authorized Volvo workshop to have the tire replaced/repaired. Inform the workshop that the tire contains sealing compound.

★ WARNING

After using the tire sealing system, the vehicle should not be driven farther than approximately 200 km (120 miles).

(i) NOTE

The compressor is an electric device. Follow local regulations for disposal.

- Recommended tire pressure (p. 537)
- Tire sealing system (p. 550)
- Inflate tires with the compressor included in the tire sealing system (p. 555)

Inflate tires with the compressor included in the tire sealing system

The vehicle's original tires can be inflated using the compressor in the tire sealing system.

- The compressor must be switched off. Make sure that the switch is in the 0 (Off) position and take out the electrical cable and the hose.
- Unscrew the tire's valve cap and screw the hose's valve connector as far as possible onto the valve.
 - Be sure the air release valve on the compressor's hose is completely closed.
- 3. Connect the electrical cable to the nearest 12 V outlet and start the vehicle.

Inhaling exhaust fumes could lead to serious injury. Never leave the engine running in an enclosed space or a space without sufficient ventilation.

Never leave children unattended in the vehicle while the engine is running.

4. Start the compressor by moving the switch to the I (On) position.

(!) CAUTION

Risk of overheating. The compressor should not be running for longer than 10 minutes at a time.

- Inflate the tire to the pressure specified on the tire pressure decal on the driver's side door pillar. If the inflation pressure is too high, use the air release valve to release air.
- 6. Switch off the compressor. Remove the hose and the electrical cable.
- 7. Screw the valve cap back onto the tire.

(i) NOTE

- After inflating a tire, always replace the valve cap to help prevent valve damage caused by gravel, dirt, etc.
- Use plastic valve caps only. Metal caps could corrode and become difficult to remove.

i NOTE

The compressor is an electric device. Follow local regulations for disposal.

- Recommended tire pressure (p. 537)
- Using the tire sealing system (p. 551)
- Tire sealing system (p. 550)

Determining the vehicle's permitted weight

Properly loading your vehicle will provide maximum return of vehicle design performance.

Weight designations

Before loading your vehicle, familiarize yourself with the following terms for determining your vehicle's weight ratings, with or without a trailer, from the vehicle's Federal/Canadian Motor Vehicle Safety Standards (FMVSS/CMVSS) label, and the vehicle's tire information placard:

Curb weight

The weight of the vehicle including a full tank of fuel and all standard equipment. It does not include passengers, cargo, or optional equipment.

Capacity weight

All weight added to the curb weight, including cargo and optional equipment. When towing, tow-bar weight is also part of cargo weight.

Permissible axle weight

The maximum allowable weight that can be carried by a single axle (front or rear). These numbers are shown on the Federal/Canadian Motor Vehicle Safety Standards (FMVSS/CMVSS) label. The total load on each axle must never exceed its maximum permissible weight.

Gross vehicle weight (GVW)

The vehicle's curb weight + cargo + passengers.

Steps for Determining Correct Load Limit

- Locate the statement "the combined weight of occupants and cargo should never exceed XXX kg or XXX lbs." on your vehicle's placard.
- Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- 3. Subtract the combined weight of the driver and passengers from XXX kg or XXX lbs.
- 4. The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the "XXX" amount equals 1400 lbs. and there will be five 150 lb. passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs. (1400 750 (5 x 150) = 650 lbs.)
- Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in Step 4.
- If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle.

♠ WARNING

- Exceeding the permissible axle weight, gross vehicle weight, or any other weight rating limits can cause tire overheating resulting in permanent deformation or catastrophic failure.
- Do not use replacement tires with lower load carrying capacities than the tires that were original equipment on the vehicle because this will lower the vehicle's GVW rating. Use only tires with the correct load carrying capacity. Consult your Volvo retailer for information.

Related information

• Loading recommendations (p. 564)

LOADING, STORAGE AND PASSENGER COM-PARTMENT


Passenger compartment interior

Overview of the passenger compartment interior and storage spaces.

Front seats



Storage compartment in the door panel and near the steering wheel, glove compartment and sun visors.



Storage compartments with cup holders, electrical outlets and USB ports in the tunnel console.

Rear seat

Second row of seats



Storage compartment in the door panel, cup holders* in the center seat's backrest, storage pocket* in the front seat's backrest and electrical outlets in the tunnel console.

Third row of seats*



Storage compartment and cup holders in the side panel and storage compartment between the seats.

MARNING

Store loose objects, such as cell phone, camera, remote control for extra equipment, etc., in the glove compartment or another compartment. Otherwise, these could injure people in the vehicle in the event of hard braking or a collision.

! CAUTION


Keep in mind that glossy surfaces can be easily scratched by e.g. metal objects. Do not place keys, phones or similar items on sensitive surfaces.

Related information

- Electrical outlets (p. 560)
- Using the glove compartment (p. 563)
- Sun visors (p. 564)
- Tunnel console (p. 559)
- Connecting a device via the USB port (p.492)

Tunnel console

The tunnel console is located between the front seats.



- Storage compartment with cover*. The cover can be opened/closed by pressing the handle.
- Storage compartment with a 12 V outlet and cup holders for the driver and passenger.
- Storage compartment and USB port under the armrest.
- Climate control panel for the rear seats* or storage compartment.

WARNING

Store loose objects, such as cell phone, camera, remote control for extra equipment, etc., in the glove compartment or another compartment. Otherwise, these could injure people in the vehicle in the event of hard braking or a collision.

NOTE

One of the sensors for the alarm* is located under the cup holder in the center console. Avoid placing coins, keys and other metal objects in the cup holder as this could trigger the alarm.

CAUTION

Keep in mind that glossy surfaces can be easily scratched by e.g. metal objects. Do not place keys, phones or similar items on sensitive surfaces.

- Passenger compartment interior (p. 558)
- Electrical outlets (p. 560)
- Climate system controls (p. 217)

Electrical outlets

There are two 12 V electrical outlets and one 120 V electrical outlet* in the tunnel console, and one 12 V electrical outlet* in the trunk/cargo compartment.

If a problem occurs with an electrical socket, contact a workshop - an authorized Volvo workshop is recommended.

12 V outlets



12 V outlet in the tunnel console, front seat.

The 12 V outlets can be used for devices intended for this such as MP3 players, coolers and cellular phones.



12 V outlet in the tunnel console, second row of seats.



12 V outlet in the cargo compartment*.

Electrical outlets in the tunnel console - rear seat*



Electrical outlet in the tunnel console, second row of seats.

The high-voltage outlet* can be used for devices intended for this, such as chargers, laptops, etc.

High-voltage outlet status indicator light

An LED¹ light on the outlet indicates its status:

¹ LED (Light Emitting Diode)

Status indicator light	Cause	Action	
Steady green light	The socket is providing electrical current to a connected device.	None.	
Flashing orange light	The socket's voltage converter is too hot (e.g. if the device draws too much current or if the temperature in the passenger compartment is very high).	Unplug the device, let the voltage converter cool down and plug in the device again.	
	The connected device is drawing too much current (at the moment or constantly) or is not functioning properly.	None. The device cannot be used in the socket.	
Indicator light off	The socket has not detected a device plugged into the socket.	Make sure the device is correctly plugged into the socket.	
	The socket is not active.	Make sure the vehicle's ignition is in at least mode I.	
	The socket has been active but has been deactivated.	Start the engine and/or charge the start battery.	

- Passenger compartment interior (p. 558)
- Using the electrical outlets (p. 562)

Using the electrical outlets

The 12 V outlet can be used for devices intended for this such as MP3 players, coolers and cellular phones.

The high-voltage outlet* can be used for devices intended for this, such as chargers, laptops, etc. The ignition must be in at least mode I for the outlets to supply current. The outlets will then be active as long as there is sufficient charge in the start battery.

If the engine is turned off and the vehicle is locked, the outlets will be deactivated. If the engine is turned off and the vehicle remains unlocked, the sockets will remain active for up to 7 minutes.

(i) NOTE

Bear in mind that using the electrical outlets when the engine is off could cause the starter battery to have too low of a charge level, which could limit other functionality.

Accessories connected to the electrical outlets can be activated even when the vehicle electrical system is off or if preconditioning is used. For this reason, disconnect plugs when they are not in use to prevent the starter battery from becoming discharged.

- Do not use accessories with large or heavy plugs – they could damage the outlet or come loose while you are driving.
- Do not use accessories that could cause disruptions to e.g. the vehicle's radio receiver or electrical system.
- Position the accessory so that there is no risk of it injuring the driver or passengers in the event of heavy braking or a collision.
- Pay attention to connected accessories as they can generate heat that could burn passengers or the interior.

Using 12 V outlets

- Remove the stopper (tunnel console) or fold down the cover (trunk/cargo compartment) over the socket and plug in the device.
- Unplug the device and put the stopper back in (tunnel console) or fold up the cover (trunk/cargo compartment) when the socket is not in use or left unattended.

(!) CAUTION

The maximum power is 120 W (10 A) per outlet.

Using high-voltage outlets

The ignition must be in at least mode I for outlets to supply current. The outlets will then be active as long as there is sufficient charge in the start battery.

- Slide down the cover over the outlet and plug in the device.
 - > The LED² light on the outlet will indicate its status.
- 2. The outlet is supplying electrical current when the light is glowing steadily green.
- Disconnect the device by pulling out the plug (do not pull on the cord).

Pull up the cover when the outlet is not in use or is left unattended.

(I) CAUTION

The maximum power is 150 W.

Do not attempt to alter or repair the high-voltage outlet on your own. Volvo recommends contacting an authorized Volvo workshop.

² LED (Light Emitting Diode)

WARNING

- Only use accessories that are not damaged or malfunctioning. The accessories must be designed for 120 V and 60 Hz, with plugs intended for the outlet. The accessories must be CE marked, UL marked or have an equivalent safety marking.
- New let outlets, plugs or accessories come into contact with water or another fluid. Do not touch or use the outlet if it appears damaged or has been in contact with water or another fluid.
- Do not connect power strips, adapters or extension cords to the outlet has this could cause the outlet's safety functions to malfunction.
- The outlet is equipped with a pet guard. Make sure that no one picks at or damages the outlet in such a way that the guard is disabled. Children should not be left unsupervised in the vehicle when the outlet is active.


Failure to follow the above could lead to severe or fatal electrical shocks.

Related information

- Electrical outlets (p. 560)
- Passenger compartment interior (p. 558)

Using the glove compartment

The glove compartment is located on the passenger side. The glove compartment can be used to store the Owner's Manual, maps, etc. There is also room for a pen and a card holder.



Glove compartment and opening button on the center console.


The glove compartment is opened by pressing the opening button in the center console.

Locking and unlocking the glove box

The glove compartment can be locked ("private locking") when the vehicle is left at a workshop, hotel, etc. When private locking is activated, the tailgate is also locked.

Using the glove box as a cooled area*

The glove compartment can be used to cool e.g. drinks or food. Cooling is possible when the climate system is active (i.e. when the ignition is in mode II or when the engine is running).



The illustration is generic - the design may vary.

- Activate cooling
- Deactivate cooling
- Activate or deactivate cooling by moving the control as far as possible toward the passenger compartment/glove compartment.

- Passenger compartment interior (p. 558)
- Private Locking (p. 264)

Sun visors

In the ceiling in front of the driver and front passenger, there are sun visors that can be lowered and angled to the side as necessary.



The illustration is generic - the design may vary.

The mirror lighting* comes on automatically when the cover is lifted up.

The mirror frame has a holder for e.g. cards or tickets.

Related information

Passenger compartment interior (p. 558)

Cargo compartment

The vehicle has a flexible cargo compartment that makes it possible to carry and secure large objects.

The cargo compartment capacity can be considerably increased by folding down the backrests in the second and third rows* of seats. To make loading and unloading easier, the rear section of the vehicle can be raised and lowered using the level control function*. Use the load anchoring eyelets or grocery bag holders to help secure objects in place, and the retractable cargo compartment cover* to help conceal objects in the cargo compartment.

The towing eyelet and tire sealing system, or the temporary spare tire*, are located under the cargo compartment floor.

Related information

- Loading recommendations (p. 564)
- Grocery bag holders (p. 566)
- Load anchoring eyelets (p. 567)
- Installing and removing the cargo compartment cover* (p. 567)

Loading recommendations

There are a number of things to consider when carrying loads in or on the vehicle.

Load-carrying capacity is determined by the vehicle's curb weight. The total weight of all passengers and any installed accessories reduces the vehicle's load-carrying capacity by the corresponding amount.

The vehicle's driving characteristics change depending on the weight and position of the load.

Loading in the trunk and cargo compartment

- Position objects so they are pressing against the rear seat backrests.
- Distribute the load evenly.
- Heavy objects should be positioned as low as possible. Avoid placing heavy objects on folded-down seat backrests.
- Cover sharp corners with a soft cloth or similar to help prevent damage to the upholstery.
- Use the load anchoring eyelets and tensioning straps or similar to secure all objects.

Λ

WARNING

In a head-on collision at a speed of 50 km/h (30 mph), an unsecured object weighing 20 kg (44 pounds) can reach a projectile weight equivalent to 1000 kg (2200 pounds).

⚠ WARNING

If objects are loaded higher than the upper edge of the side windows, leave a 10 cm (4 in.) space between the objects and the window. Objects placed closer to this could impede the function of the inflatable curtain concealed inside the headlining.

Always secure the load. Otherwise, it may shift during heavy braking and injure people in the vehicle.

Cover sharp edges and sharp corners with something soft.

Turn off the engine and apply the parking brake when loading/unloading long objects. Otherwise, it is possible for the load to reach the gear lever or gear selector and move it to a drive position – which could cause the vehicle to begin rolling.

Extra cargo space

The rear seat backrests can be folded down to increase cargo compartment space and simplify loading. If the rear seat backrests are folded

down, make sure that no objects loaded into the vehicle prevent the WHIPS system for the front seats from functioning correctly.

Raising/lowering the rear end of the vehicle*

The rear end of the vehicle can be lowered or raised for easier loading or to facilitate attaching a trailer*.

The controls for raising/lowering are located at the rear edge of the cargo compartment's right side panel.



Controls for raising/lowering the rear end of the vehicle.

The controls consist of two buttons — one button for lowering and one button for raising the rear end. Press and hold the relevant button until the desired height is reached.

The rear end of the vehicle cannot be raised higher than its normal height.

The rear end will return to the normal height when the vehicle begins driving.



NOTE

It is not possible to adjust the height of the vehicle's rear when one or more of the doors or the hood is open. This does not apply to the tailgate.

Make sure that no people, animals or objects are found under the vehicle when it is lowered. This could endanger life and cause damage to the vehicle or objects.

- Load anchoring eyelets (p. 567)
- Folding the second row backrests (p. 196)
- Roof loads and load carriers (p. 566)
- Leveling control* and suspension (p. 432)
- Weights (p. 641)

Roof loads and load carriers

Volvo-developed load carriers are recommended for carrying loads on the roof of the vehicle.

Volvo load carriers are specially designed to help prevent damage to your vehicle and help ensure maximum safety while driving. Volvo load carriers are available from authorized Volvo retailers.

Carefully follow the installation instructions provided with the load carriers.

- Check periodically to ensure that the load carriers and load are properly secured.
 Secure the load firmly using tie straps or similar.
- Distribute the load evenly throughout the load carriers. Place heavier cargo at the bottom of the load.
- The vehicle's wind resistance and fuel consumption increase with the size of the load.
- Drive smoothly. Avoid rapid acceleration, hard braking and fast cornering.

The vehicle's center of gravity and driving characteristics are altered by roof loads.

Follow the vehicle's specifications regarding weights and maximum permitted load.


Related information

- Loading recommendations (p. 564)
- Weights (p. 641)

Grocery bag holders

Grocery bag holders (hooks) help keep shopping bags in place and prevent them from falling over and spilling their contents in the cargo compartment.

On the sides of the cargo compartment



There are two fold-out holders in the side panels, one on each side of the cargo compartment.

! CAUTION

The grocery bag holders are only intended to hold weights up to 5 kg (11 lbs).

Under the floor hatch*3



There are two grocery bag holders and an elastic band⁴ in the hatch in the cargo compartment floor. The strap can be attached in four different positions.

Open the hatch to access the grocery bag holders. Use the provided elastic strap to secure shopping bags in a suitable position. Bags with handles of a suitable size can also be hung on the hooks.

Related information

- Loading recommendations (p. 564)
- Installing and removing the cargo net* (p. 571)
- Installing and removing the cargo compartment cover* (p. 567)
- Installing and removing the steel cargo grid* (p. 570)

Load anchoring evelets

The fold-out eyelets in the cargo compartment can be used to secure objects with straps, a net, etc.



WARNING

Hard, sharp and/or heavy objects in or protruding from the vehicle can cause injury in the event of hard braking.

Always secure large and heavy objects with a seat belt or cargo retaining straps.


Related information

- Loading recommendations (p. 564)
- Weights (p. 641)

Installing and removing the cargo compartment cover*

The cover can be rolled out to conceal objects in the cargo compartment.

Installing the cargo compartment cover



- Press the end piece on one side of the cover into the retaining bracket in the side panel of the cargo compartment.
- Then put the other end piece in the recess in the side panel on the opposite side.

- Push the end piece down on both sides, one at a time
 - > When a click is heard and the red marks. on each end piece are no longer visible, the cover is in place. Check that it is secure.

Removing the cargo compartment cover

In retracted position:

- 1. Press the button on one of the cover's ends and lift out that end.
 - For 7-seat models remove the third row seat belt latches from the hooks above the side panels.
- 2. Carefully lift the cover up and out.
 - > The other end will release automatically and the cover can then be lifted out of the cargo compartment.

- Operating the cargo compartment cover* (p.568)
- Loading recommendations (p. 564)

^{3 5-}seat models only.


⁴ Additional elastic straps can be ordered from a Volvo retailer.

Operating the cargo compartment cover*


The cover can be used in two positions: fully open to completely cover the cargo compartment or partially retracted to make it easier to reach further into the cargo compartment.

Fully open

1.



Hang the third-row seat belt latches in the hooks provided in the side panels.



- Grasp the handle and pull the cover out and above the side panels in the cargo compartment. Pull the cover to its end position.
- With the cover completely open (covering the cargo compartment), press the attaching pins at the end of the cover into the grooves on the side panels and release the cover slightly while pressing the handle lightly downward to hook the pins into the grooves.
 - > The cover will be secured in the fully open position.

5-seat models




- Grasp the handle and pull the cover out and above the side panels in the cargo compartment. Pull the cover to its end position.
- With the cover completely open (covering the cargo compartment), press the attaching pins at the end of the cover into the grooves on the side panels and release the cover slightly while pressing the handle lightly downward to hook the pins into the grooves.
 - > The cover will be secured in the fully open position.

Loading mode



- From the fully retracted position grasp the handle and pull the cover up and over the side panels in the cargo compartment. Pull to the end position and press the attaching pins at the end of the cover into the grooves in the side panels of the vehicle. (If the cover is already fully open, see next section.)
- From the fully open position grasp the handle and press the cover's attaching pins down into the grooves in the side panels and then release.
 - > Retract the cover until it stops in the partially retracted position.

If your hands are full:



- In the fully open position, push the cover's handle slightly upward with e.g. your elbow.
 - > The cover will retract until it stops in the partially retracted position.

To fully open the cover from the partially retracted position:

- Grasp the handle and pull the cover out as far as possible.
- 2. Let the cover retract slightly and press the handle slightly downward.
 - > The cover will be secured in the fully open position.

CAUTION

Do not place objects on top of the cargo compartment cover.

WARNING

In 7-seat models - never have a cargo compartment cover mounted when there are passengers in the rear seats. This could lead to serious injury in the event of a collision.

Retracting the cover

From the fully opened position:

Lift the cover's handle and pull it rearward to release the cover's attaching pins from the grooves. Let the cover retract.

From the partially retracted position:

Grasp the handle and pull the cover out of the groves to the fully open position. Lift the handle and pull it rearward to release the cover's attaching pins from the grooves. Let the cover retract.


Let the cover retract with its attaching pins above the side panels until it stops in the fully retracted position.

Related information

Installing and removing the cargo compartment cover* (p. 567)

Installing and removing the steel cargo grid*

The steel cargo grid prevents loads or pets in the cargo compartment from being thrown forward into the passenger compartment.



For safety reasons, the steel grid must always be installed and secured correctly.

MARNING

Under no circumstances may a person be in the cargo compartment when the vehicle is moving. Heavy braking or a collision could lead to serious injury.

The steel grid consists of the grid itself and two separate mounting brackets. Each of the mount-

ing brackets has a screw cover and two plastic sleeves for the grid.

$\mathbf{\Psi}$

WARNING

The steel cargo grid may only be used in the rear position described here. The ceiling attachment points behind the front seats are not intended to anchor the steel grid.

\triangle

WARNING

For safety reasons, the third-row seats⁵ must be folded down when the steel cargo grid is mounted in the vehicle.



CAUTION

The steel cargo grid and the cargo compartment cover cannot be mounted at the same time.

Installation

 Fold down the rear seats and lift in the steel grid through one of the rear doors or the tailgate. The curved (convex) side of the grid should face toward the cargo compartment and the hooks on each side of the grid should face upward. The mounting brackets and plastic sleeves are not needed in this step.




- 2. Press one of the grid's hooks into the larger hole in the ceiling attachment point (1).
 - Grasp the grid near the hook and pull/push it into the smaller hole (2).
 - > The hook is now secured in the attachment point.
- Repeat step 2 above to secure the other hook in the attachment point on the opposite side.



WARNING

Make sure the cargo grid's hooks are securely attached in the ceiling attachment points to help ensure the grid does not come loose.

^{5 7-}seat models only.



- Attach the mounting bracket's hook through the cargo anchoring eyelet near the floor of the cargo compartment and insert the threaded section of the bracket through the grid's lower attachment hole (1).
 - Slide the plastic sleeve onto the threaded section of the mounting bracket with the sleeve's flange turned upward and press it down through the hole. Screw the screw cover into place until its underside is approximately 5 mm from the grid (2).
- 5. Repeat step 4 for the opposite side.
- Center the grid and then tighten both mounting brackets, moving back and forth between them until the grid is securely in place.

Removing the cover

Remove the steel grid by performing the above steps in reverse order.

It can be a good idea to remove the mounting brackets before removing the plastic sleeves from the holes in the grid.

Related information

- Loading recommendations (p. 564)
- Load anchoring eyelets (p. 567)

Installing and removing the cargo net*

The cargo net helps prevent objects in the cargo compartment from entering the passenger compartment in the event of a sudden stop or hard braking.

The cargo net is attached at four points.



For safety reasons, the cargo net must always be mounted and secured according to the following description.

The net is made of strong nylon weave and can be attached in two different locations in the vehicle:

- Rear mounting behind the second row of seats.
- Front mounting behind the front seats.

Objects in the cargo compartment must always be securely anchored, even with a correctly installed cargo net.

Installing the cargo net

∴ WARNING

All of the cargo net's upper consoles, hooks and straps must be securely mounted and attached before the net is used.

Never use the net if it is damaged.

i NOTE


With front mounting, the cargo net is most easily installed via a rear door.

- Fold out the cargo net and make sure that the upper rod folds out and locks into position.
- Insert one of the net's hooks into the front or rear ceiling mounting point with the strap lock facing you.

 Insert the other upper hook into the ceiling mounting point on the opposite side. The telescopic spring-loaded hooks make mounting easier.


Make sure that the net's hooks are pushed forward as far as possible into their respective mounting points.

 Rear mounting: With the cargo net hooked into the rear ceiling mounting points, attach the net's straps into the front floor eyelets in the cargo compartment.



Rear mounting.

Front mounting: With the cargo net mounted in the front ceiling mounting points, hook the straps into the outer eyelets on the front seat rails behind the seats. Attaching the net is easier if the seat backrests are upright and the seats are moved slightly forward.



Front mounting.

Move the seat or backrest only until it touches the net. Moving it with too much force or applying too much pressure to the net could lead to damage.

! CAUTION

If a seat or backrest is pressed with too much force back against the cargo net, the net and its ceiling brackets could be damaged.

5. Pull the straps until the cargo net is taut.

Removing the cargo net

The cargo net can be easily removed and folded up.

- Loosen the cargo net by pressing the button on the strap locks on each side and pulling to allow some slack.
- 2. Press in the catches and release both of the strap hooks.
- 3. Unhook the upper hooks and remove the net from the ceiling mounting points.
- Press the red button on the rod so that it can be folded. Fold and roll up the net. Store the net in its case.

- Loading recommendations (p. 564)
- Load anchoring eyelets (p. 567)



Volvo's service program

To keep the vehicle as safe and reliable as possible, follow the Volvo service schedule specified in the Warranty and Maintenance Records Information booklet.

Volvo recommends having an authorized Volvo workshop perform service and maintenance. Volvo workshops have the staff, service literature and special tools to guarantee the highest quality of service.



CAUTION

To ensure the Volvo warranty is not invalidated, check and follow the Service and Warranty Booklet.

Introduction

The maintenance services contain several checks that require special instruments and tools and therefore must be performed by a qualified technician. To keep your Volvo in top condition, specify time-tested and proven Genuine Volvo Parts and Accessories.

The Federal Clean Air Act - U.S.

The Federal Clean Air Act requires vehicle manufacturers to furnish written instructions to the ultimate purchaser to assure the proper servicing and function of the components that control emissions. These services, which are listed in the "Warranty and Service Records Information"

booklet, are not covered by the warranty. You will be required to pay for labor and material used.

Maintenance

Your Volvo passed several major inspections before it was delivered to you, in accordance with Volvo specifications. The maintenance procedures outlined in the Warranty and Service Records Information booklet, many of which will positively affect your vehicle's emissions, should be performed as indicated. It is recommended that receipts for vehicle emission maintenance be retained in case questions arise concerning maintenance. Inspection and maintenance should also be performed anytime a malfunction is observed or suspected.

Applicable warranties - U.S./Canada

In accordance with applicable U.S. and Canadian regulations, the following list of warranties is provided.

- New Vehicle Limited Warranty
- Parts and Accessories Limited Warranty
- Corrosion Protection Limited Warranty
- Seat Belt and Supplemental Restraint Systems Limited Warranty
- Emission Design and Defect Warranty
- Emission Performance Warranty

These are federal warranties. Other warranties are provided as required by state/provincial law. Refer to your separate Warranty and Service

Records Information booklet for detailed information concerning each of the warranties.

Periodic maintenance helps minimize emissions



NOTE

- Refer to your Service and Warranty Booklet for a comprehensive service and maintenance schedule up to 240,000 km (150,000 miles). This program contains inspections and services necessary for the proper function of your vehicle and includes components that affect vehicle emissions.
- The Warranty and Service Records Information booklet also contains detailed information concerning the warranties that apply to your vehicle.

On-board Diagnostic System

OBD II is part of your vehicle's computerized engine management system. It stores diagnostic information about your vehicle's emission controls. It can light the Check Engine light (MIL) if it detects an emission control "fault." A "fault" is a component or system that is not performing within an expected range. A fault may be permanent or temporary. OBD II will store a message about any fault.

Emission inspection readiness How do states use OBD II for emission inspections?

Many states connect a computer directly to a vehicle's OBD II system. The inspector can then read "faults." In some states, this type of inspection has replaced the tailpipe emission test.

How can my vehicle fail OBD II emission inspection?

Your vehicle can fail OBD II emission inspection for any of the following reasons:

- If your Check Engine (MIL) light is lit, your vehicle may fail inspection.
- If your vehicle's Check Engine light was lit, but went out without any action on your part, OBD II will still have a recorded fault. Your vehicle may pass or fail, depending on the inspection practices in your area.
- If you had recent service that required disconnecting the battery, OBD II diagnostic information may be incomplete and "not ready" for inspection. A vehicle that is not ready may fail inspection.

How can I prepare for my next OBD II emission inspection?

 If your Check Engine (MIL) light is lit - or was lit but went out without service, have your

- vehicle diagnosed and, if necessary, serviced by a qualified Volvo technician.
- If you recently had service for a lit Check Engine light, or if you had service that required disconnecting the battery, a period of driving is necessary to bring the OBD II system to "ready" for inspection. Two halfhour trips of mixed stop-and-go/highway driving are typically needed to allow OBD II to reach readiness. Your Volvo retailer can provide you with more information on planning a trip.
- Maintain your vehicle in accordance with your vehicle's maintenance schedule.

Owner maintenance

Periodic maintenance requirements and intervals are described in your vehicle's Warranty and Service Records Information booklet.

The following points can be carried out between the normally scheduled maintenance services.

Each time the car is refueled:

- Check the engine oil level.
- Clean the windshield, windshield wipers, headlights, and taillights.

Monthly:

- Check cold tire pressure in all tires. Inspect the tires for wear.
- Check that engine coolant and other fluid levels are between the indicated "min" and "max" markings.
- Clean interior glass surfaces with a glass cleaner and soft paper towels.
- Wipe driver information displays with a soft cloth.
- Visually inspect battery terminals for corrosion. Corrosion may indicate a loose terminal connector, or a battery near the end of its useful service life. Consult your Volvo retailer for additional information.

As needed:

Wash the car, including the undercarriage, to reduce wear that can be caused by a buildup of dirt, and corrosion that can be caused by salt residues.

Clean leaves and twigs from air intake vents at the base of the windshield, and from other places where they may collect.



Complete service information for qualified technicians is available online for purchase or subscription at www.volvotechinfo.com.

Related information

- Vehicle status (p. 580)
- Scheduling service and repairs (p. 580)
- Connecting equipment to the vehicle's data link connector (p. 36)
- Technician certification (p. 37)
- Climate control system service (p. 586)
- Maintenance of the brake system (p. 411)
- Engine compartment overview (p. 587)

Data transfer between vehicle and workshop over Wi-Fi

Volvo workshops have a designated Wi-Fi network for secure data transfer between your vehicle and the workshop. Your visit to the workshop will be easier and more effective when diagnostics information and software can be transferred over the workshop's network.

When you arrive at the workshop, your technician can connect your vehicle to the workshop's Wi-Fi network to perform troubleshooting and download software. For this type of communication, the vehicle only connects to the workshop's network. The vehicle can only be connected to the designated workshop networks, not to any other network, e.g. your home network.

Manual connection to workshop Wi-Fi

Manual connection is usually performed by a service technician. Because the technician uses the buttons on your remote key to connect the vehicle, it is important that you bring a key with buttons when taking the vehicle in to a workshop. Pressing the lock button on the remote key three times will connect the vehicle to the workshop's Wi-Fi network.

When the car is connected to a Wi-Fi network, the symbol appears in the center display.

The vehicle may not be driven when it is connected to the workshop's networks and systems.

- Handling system updates via Download Center (p. 579)
- Scheduling service and repairs (p. 580)

Download Center

With the vehicle connected to the Internet¹, updates for a number of the vehicle's systems can be downloaded from the center display.



The **Download Center** app is started from the center display and makes it possible to:

- search for and update system software
- update Sensus Navigation* map data
- · download, update and delete apps.

Related information

- Handling system updates via Download Center (p. 579)
- Download apps (p. 466)
- Updating apps (p. 467)
- Deleting apps (p. 468)
- Internet-connected vehicle* (p. 507)
- Navigating in the center display's views (p. 117)

Handling system updates via Download Center

System updates are available for infotainment and Internet-related functions and systems in the vehicle. If system software updates are available, they can be downloaded all at once or separately.

Searching for update



In order for system updates to be possible, the vehicle must have an Internet connection².

System updates are handled through the **Download Center** app in the center dis-

play's App view. If no search for updates has been performed since the last time the infotainment system was started, a search will be initiated. No search will begin if a software download is in progress. A number in the **System updates** button shows how many updates are available. Tap the button to display a list of updates that can be installed in the vehicle. If an update is available, the message **New software updates** available will also be displayed in the center display's status field.

i) NOTE

Data downloading can affect other services such as transfer data, e.g. web radio. If the affect on other services is experienced as problematic, the download can be interrupted. Alternatively, it may be appropriate to switch off or cancel other services.

i NOTE

An update can be interrupted when the ignition is switched off and the vehicle is left.

However, the update does not have to be completed before the vehicle is left as the update is resumed the next time the vehicle is used.

Updating all system software

Select Install all at the bottom of the list.

To avoid displaying a list, select **Install all** via the **System updates** button.

Updating individual system software

 Select Install to choose the software you would like to download.

¹ There may be a charge for transmitting data over the Internet, depending on your service plan.

² There may be a charge for transmitting data over the Internet, depending on your service plan.

Canceling software download

 Tap the checkbox in the activity indicator that replaced the Install button when the download began.

Note that only a download can be cancelled. An installation cannot be cancelled once it has begun.

Deactivating the background search for software update

Automatic background searching for software updates is activated as the default factory setting, but the function can be deactivated.

- Tap **Settings** in the center display's Top view.
- Tap System → Download Center.
- 3. Tap to deselect Auto Software Update.

Related information

- Download Center (p. 579)
- Internet-connected vehicle* (p. 507)
- Navigating in the center display's views (p. 117)

Vehicle status

The vehicle's general status can be displayed in the center display along with the option to schedule service³.



The **Car status** app is started from the center display's App view and has four tabs:

- Messages status messages
- Status engine oil level check
- TPMS tire inflation pressure check
- Appointments appointment information and vehicle information³

Related information

- Handling messages saved from the instrument panel (p. 109)
- Checking and filling engine oil (p. 588)
- Tire pressure monitoring system* (p. 537)
- Scheduling service and repairs (p. 580)
- Sending vehicle information to the workshop (p. 582)
- Navigating in the center display's views (p. 117)

Scheduling service and repairs⁴

This service offers a convenient way to schedule service and workshop appoints directly from the vehicle.

When it is time for service, and in certain cases if the vehicle requires repairs, a message will be displayed in the instrument panel and at the top of the center display. The time for service is determined by how much time has elapsed, the number of hours the engine has run, or the distance driven since the last service.

To use the service

- Create a Volvo ID and register the Volvo ID to the vehicle.
- To select a Volvo retailer you would like to contact, go to www.volvocars.com and log in.
- To send and receive appointment information, the vehicle must be connected to the Internet⁵.

Book service

When you schedule service from your vehicle, the information is sent via your Internet connection⁵.

Submit an appointment request whenever you need service or when a message regarding the need for service or repairs has been displayed in

*Option/accessory.

³ Certain markets only.

⁴ Certain markets only.

⁵ There may be a charge for transmitting data over the Internet, depending on your service plan.

the instrument panel and at the top of the center display.



- 1. Open the Car status app from App view in the center display.
- Tap the **Appointments** button.
- Tap the Request appointment button.
- Check that your Volvo ID is correct.
- Make sure your preferred Workshop is correct.
- In the Tap to write information to the Workshop field, you can provide details on what you would like performed during the visit or other important information to your workshop.

- 7. Tap the Send appointment request button.
 - > You will receive an appointment suggestion to your vehicle within a couple of days⁶. You will also receive the same message via email and when you log in to www.volvocars.com.

On some markets, the message in the instrument panel indicating that the vehicle requires service will go out once the appointment request has been sent.

8. Tap Cancel request if you would like to cancel your request.

The appointment request contains information about your vehicle that helps the workshop plan for your visit.

The retailer will send you a digital appointment suggestion. Information about your retailer is also available in the vehicle so that you can contact your workshop at any time.

Accepting an appointment suggestion

When the vehicle has received an appointment suggestion, a message will be displayed at the top of the center display.

1. Tap the message.

For some markets, the system reminds you when an appointment time is approaching and the navigation system⁷ can also guide you to the workshop at the appointed time.

- Vehicle status (p. 580)
- Sending vehicle information to the workshop (p.582)
- Navigating in the center display's views (p. 117)
- Volvo ID (p. 26)
- Internet-connected vehicle* (p. 507)

^{2.} To accept the suggested appointment, tap Accept. To decline the suggested appointment, tap Send new proposal or Decline.

⁶ Timespan may vary depending on market.

⁷ For vehicles with Sensus Navigation*.

Sending vehicle information to the workshop⁸

Vehicle-related information can be sent at any time from the vehicle, e.g. if you schedule a visit to a workshop and would like to assist your workshop by providing additional basic information. Sending vehicle information is not the same as scheduling service.



- 1. Open the **Car status** app from App view in the center display.
- 2. Tap the Appointments button.
- 3. Tap the Send vehicle data button.
 - > A message confirming that vehicle-related information has been sent will appear at the top of the center display. You can cancel data transmission by tapping the checkbox in the activity indicator.

Information is sent via the vehicle's Internet connection⁹.

Vehicle information can be accessed by any retailer if they are provided with your vehicle identification number (VIN¹⁰).

Vehicle information contents

The most recently saved vehicle-related information will be sent (the last time the vehicle was turned on). This includes information regarding:

- service requirements
- time since last service was performed
- function status
- fluid levels
- mileage (odometer reading)
- Vehicle Identification Number (VIN¹⁰)
- software version
- diagnostic information.

Related information

- Scheduling service and repairs (p. 580)
- Vehicle status (p. 580)
- Navigating in the center display's views (p. 117)
- Internet-connected vehicle* (p. 507)

582 *Option/accessory.

⁸ Certain markets only.

⁹ There may be a charge for transmitting data over the Internet, depending on your service plan.

¹⁰ Vehicle Identification Number.

Hoisting the vehicle

When hoisting the vehicle, it is important to ensure the jack/vehicle hoist is correctly engaged in the designated attachment points under the vehicle.

For vehicles with self-leveling*, pneumatic suspension (if installed) must be turned off before the vehicle is lifted. Turning off the function in the center display.

⚠ WARNING


If the vehicle is lifted on a garage jack, the jack must be placed under one of the four lifting points. Make sure that the vehicle is correctly positioned on the jack and that it cannot slide off. Make sure the jack plate has a rubber pad to help keep the vehicle stable and prevent damage. Always use axle stands or similar.

(i) NOTE

Volvo recommends only using the jack intended for your specific vehicle model. If a jack other than that recommended by Volvo is used, follow the instructions included with the equipment.

The vehicle's ordinary jack is only intended to be used in temporary situations for short periods of time, such as when changing wheels in the event of a flat tire. If the vehicle needs to be lifted more frequently, or for a longer period of time than for a wheel change, a garage jack or hoist is recommended. Always follow the instructions for use provided with the equipment.

44



The triangles in the plastic covering indicate where the jack attachment points/lifting points (red areas) are located.

- Removing a wheel (p. 544)
- Jack* (p. 543)
- Leveling control settings* (p. 435)

Opening and closing the hood

To open the hood, pull the lever in the passenger compartment and then turn the handle under the hood.

Opening the hood



Pull the lever near the pedals to release the hood from its fully closed position.



Turn the handle under the front edge of the hood counterclockwise to release the catch and lift the hood.

Warning - hood not closed



When the hood is released, a warning symbol and graphic will be displayed in the instrument panel and an audible signal will sound. If the vehicle begins

to roll, the audible signal will be repeated several times.

(i) NOTE

If the warning symbol is illuminated or an audible warning signal sounds even though the hood is securely closed, consult a workshop - an authorized Volvo workshop is recommended.

Closing the hood

- 1. Press down the hood until it begins to close under its own weight.
- When the hood reaches the catch at the handle in the front edge of the vehicle, press down on the hood to close it completely.

⚠ WARNING

Risk of injury! When closing, make sure that the hood is completely unobstructed and that no one can be injured.

Make sure the hood locks securely after closing. It must audibly lock on both sides.



Hood not completely closed. The illustration is generic - details may vary according to vehicle model.

∢∢



Hood completely closed. The illustration is generic - details may vary according to vehicle model.

↑ WARNING

Never drive with the hood open!

If there are any indications while driving that the hood is not completely closed, stop immediately and close it securely.

Related information

- Engine compartment overview (p. 587)
- Door and seat belt reminders (p. 51)

Climate control system service

Service and repairs on the air conditioning system should only be done by an authorized workshop.

Troubleshooting and repairs

The air conditioning system contains a fluorescent tracer substance. Ultraviolet light is used to search for leaks in the system.

Volvo recommends contacting an authorized Volvo workshop.

Vehicles with R134a refrigerant



WARNING

The air conditioning system contains the refrigerant R134a under pressure. Service and repairs to the system should only be done by an authorized workshop.

Related information

Volvo's service program (p. 576)

Replacing a windshield with headup display*

Vehicles with a head-up display have a special type of windshield that meets the requirements for displaying projected information.

Volvo recommends contacting an authorized Volvo workshop for assistance replacing the windshield. The correct type of replacement windshield must be used in order for the head-up display to function properly.


Related information

- Head-up display* (p. 144)
- Cleaning the head-up display* (p. 616)

*Option/accessory.

Engine compartment overview

This overview shows some service-related components.



The layout of the engine compartment may vary depending on model and engine variant.

- 1 Coolant expansion tank
- Brake fluid reservoir (located on the driver's side)
- Washer fluid filler pipe¹¹
- 4 Fusebox
- 6 Air filter
- Engine oil filler pipe

Bear in mind that the cooling fan (located at the front of the engine compartment behind the radiator) may start or continue running automatically up to about 6 minutes after the engine is turned off.

Always entrust engine washing to a workshop – an authorized Volvo workshop is recommended. If the engine is hot, there is a risk of fire.

. WARNING

The ignition system works with extremely high and dangerous voltages. The vehicle electrical system should always be in ignition mode ${\bf 0}$ when work in being performed in the engine compartment.


Do not touch any spark plugs or ignition coils when the vehicle electrical system is in ignition mode II or when the engine is warm.

Related information

- Opening and closing the hood (p. 585)
- Filling washer fluid (p. 632)
- Refilling coolant (p. 590)
- Fuses in the engine compartment (p. 605)
- Checking and filling engine oil (p. 588)
- Ignition modes (p. 407)

Engine oil

For the recommended service intervals and warranties to be applied, an approved engine oil must be used.



Volvo recommends:



¹¹ Fill the washer fluid at regular intervals, e.g. when refueling.

If the engine oil is not checked regularly and the level becomes low, this could cause serious engine damage.

1

CAUTION

To satisfy the requirements for the engine's service intervals, all engines are factory-filled with a specially adapted synthetic engine oil. Great care has been put into the choice of oil, with consideration given to service life, startability, fuel consumption and environmental impact.

For the recommended service intervals to apply, an approved engine oil must be used. Only use the prescribed oil grade to top off or change the oil. Otherwise, there is a risk of the vehicle's service life, startability, fuel consumption and environmental impact being affected.

Failure to use engine oil of the prescribed grade and viscosity could cause damage to engine-related components. Volvo Car Corporation disclaims warranty liability for such type of damage.

Volvo recommends entrusting oil changes to an authorized Volvo workshop.

Volvo uses different systems to warn if the oil level is too low/high or the oil pressure is low. On engine variants with an oil pressure sensor, a

warning symbol is displayed in the instrument panel when oil pressure is low on engine variants with an oil level sensor, the marning symbol in the instrument panel and display messages are used to alert the driver. Some engine variants have both systems. Contact a Volvo retailer for more information.

Change the engine oil and oil filter according to the schedule specified in the Warranty and Maintenance Records Information booklet. Oils of a higher grade than that specified may be used. If the vehicle is driven in adverse conditions, Volvo recommends using an oil with a higher grade than that specified.

Related information

- Checking and filling engine oil (p. 588)
- Engine oil specifications (p. 644)

Checking and filling engine oil

The engine oil level is monitored by an electronic oil level sensor.



Filler pipe¹².

It may be necessary to top up engine oil between regularly scheduled services.

No action is necessary with regard to engine oil level until a message appears in the instrument panel.





If this symbol is shown together with the message Engine oil level Service required, visit a workshop - an authorized Volvo workshop is recommended. The oil level may be too high.

CAUTION



If this symbol is shown together with a message about low oil level, for example Engine oil level low Refill 1 liter, fill only with the indi-

cated volume, e.g. 1 liter (1 quart).

WARNING

Do not spill oil on the hot exhaust pipes as this could cause a fire.

Viewing oil level in the center display

The oil level can be viewed using the electronic oil level gauge in the center display once the vehicle has been started. The oil level should be checked regularly.



- Open the Car status app from App view in the center display.
- 2. Tap Status to display the oil level.



Oil level graphic in the center display.



The system cannot directly detect changes when the oil is filled or drained. The vehicle must have been driven approximately 30 km (20 miles) and have been stationary 5 minutes on a level surface and with the engine off before the correct oil level will be displayed.

¹² Engines with an electronic oil level sensor do not have a dipstick.

(i

(i) NOTE

If the conditions for measuring oil level are not properly fulfilled (time after engine shutdown, vehicle inclination, ambient temperature, etc.) the message **No value available** will be shown in the center display. This does **not** mean that anything is wrong in the vehicle systems.

Related information

- Engine oil (p. 587)
- Engine oil specifications (p. 644)
- Ignition modes (p. 407)
- Vehicle status (p. 580)

Refilling coolant

Coolant helps keep the combustion engine at the right operating temperature. The heat transferred from the engine to the coolant can be used to warm the passenger compartment.

When refilling coolant, follow the instructions on the package. Never fill the cooling system with only water. The risk of freezing is increased with too low or too high amounts of coolant.

If there is coolant under the vehicle, smoke from the cooling system, or if more than 2 liters (about 2 quarts) of coolant has been added to the system, there could be something wrong with the cooling system and starting the vehicle could damage the engine. Call a tow truck and do not attempt to start the engine.



WARNING

The coolant may be very hot. Never unscrew the cap when the coolant is hot. If coolant must be filled, unscrew the expansion tank cap slowly to relieve overpressure.



Coolant expansion tank.







- Lift the rubber strip by pressing it inward into the engine compartment.
- Remove the plastic cover by folding out the catch and lifting the cover upward.
- Unscrew the expansion tank cap and fill coolant as needed. The level should be between the MIN and MAX marks on the expansion tank.

! CAUTION

- Mix the coolant with water of acceptable quality. If you are unsure of the quality of the water, use a Volvo-recommended premixed coolant.
- Make sure the coolant mixture is 50% water and 50% coolant.
- Only use coolants with corrosion protection recommended by Volvo.
- To help ensure sufficient corrosion protection in the system, only use new coolant when replacing larger components in the cooling system.
- Never run the engine unless the cooling system is properly filled. An improperly filled cooling system could lead to high temperatures and cracks in the cylinder heads.
- High levels of chlorine, chlorides and other salts may cause corrosion in the cooling system.

Related information

- Engine compartment overview (p. 587)
- Coolant specifications (p. 645)

Replacing bulbs

The bulbs in the halogen headlights can be changed without the help of a workshop.

Halogen headlights are not available on all models and markets. Contact a Volvo retailer for more information.

LED¹³ bulbs must be replaced by a workshop. An authorized Volvo workshop is recommended.



NOTE

For information on lights not mentioned in this article, contact a Volvo dealer or a certified Volvo service technician.

The headlight bulbs can be replaced without the assistance of a workshop, but before a bulb can be replaced, the plastic cover over the headlight needs to be removed.

The low beam lights will be accessible when the headlight's round rubber cover has been removed.

The bulbs of the turn signals, high beam and daytime running lights/parking lights are accessible once the rectangular headlight cover has been removed. If you are experiencing problems with any lights other than light bulbs, contact a workshop¹⁴. If there is a problem with an LED¹³ light, the entire lamp unit will normally need to be replaced.

⚠ WARNING

The vehicle electrical system must be in ignition mode **0** when bulbs are replaced.

! CAUTION

Never touch the bulb glass with your bare fingers. Grease and oils from your fingers vaporize in the heat and will leave a deposit on the reflector, which may damage it.

(i) NOTE

If the error message persists after the defective bulb has been replaced, we recommend a visit to an authorized Volvo workshop.

(i) NOTE

Exterior lighting such as headlights and taillights may develop temporary condensation on the inside of the lens. This is normal. All exterior lighting is designed to resist this. Condensation is normally vented out of the lamp housing once the light has been lit for some period of time.

(i) NOTE

Bulbs for active curve lighting* contain traces of mercury and should therefore always be submitted to a certified Volvo service technician.

Related information

- Location of exterior lights (p. 594)
- Removing the plastic cover to replace bulbs (p. 593)
- Removing the rectangular headlight cover (p. 593)
- Replacing the low beam headlight bulbs (p. 595)
- Replacing the high beam headlight bulbs (p. 595)
- Replacing daytime running lights/front parking light bulbs (p. 596)

- Replacing front turn signal bulbs (p. 597)
- Bulb specifications (p. 597)

592 *Option/accessory.

¹⁴ An authorized Volvo workshop is recommended.

¹³ LED (Ligth Emitting Diode)

Removing the plastic cover to replace bulbs

The headlight bulbs can be replaced without the assistance of a workshop, but before a bulb can be replaced, the plastic cover over the headlight needs to be removed.





- Lift the rubber strip by pressing it inward into the engine compartment.
- Release the pins in the plastic cover's four clips by pressing them down with a screw-driver or similar object and remove the covering.

Put the cover back in place in the reverse order.


Related information

- Replacing bulbs (p. 591)
- Replacing the low beam headlight bulbs (p. 595)
- Replacing the high beam headlight bulbs (p. 595)
- Replacing daytime running lights/front parking light bulbs (p. 596)
- Replacing front turn signal bulbs (p. 597)
- Bulb specifications (p. 597)

Removing the rectangular headlight cover

Most of the bulbs in the headlight housing can be accessed when the rectangular cover is removed.

Before the rectangular cover can be removed, the plastic covering over the headlight must be removed.



Left headlight.

- Undo the four screws of the cover using a Torx tool, dimension T20 (1). Do not undo these completely; 3-4 turns is enough.
- Push the cover to the side.
- Remove the cover.

Put the cover back in place in the reverse order.

Related information

- Replacing bulbs (p. 591)
- Replacing the low beam headlight bulbs (p. 595)
- Replacing the high beam headlight bulbs (p. 595)
- Replacing daytime running lights/front parking light bulbs (p. 596)
- Replacing front turn signal bulbs (p. 597)
- Bulb specifications (p. 597)

Location of exterior lights


The vehicle's exterior lighting consists of several different bulbs. LED¹⁵ bulbs must be replaced by a workshop. An authorized Volvo workshop is recommended.

Front bulbs (vehicles with halogen headlights)



- Low beams
- High beams
- 3 Daytime running light/parking light
- Turn signal
- Front fog light/cornering illumination* (LED¹⁵)

Rear bulbs



- 1 Brake light (LED¹⁵)
- Parking light (LED)
- Backup light¹⁶
- Parking light (LED)
- Turn signal (LED)
- 6 Fog light (LED)
- Rrake light central, high-mounted (LED)

Related information

- Replacing bulbs (p. 591)
- Bulb specifications (p. 597)
- Lighting panel and controls (p. 154)

594 *Option/accessory.

¹⁵ LED (Light Emmitting Diod)

¹⁶ Contact a workshop for replacement – an authorized Volvo workshop is recommended.

Replacing the low beam headlight bulbs

The low beam bulbs in the halogen headlights can be changed without the help of a workshop.

(!) CAUTION

Never touch the bulb glass with your bare fingers. Grease and oils from your fingers vaporize in the heat and will leave a deposit on the reflector, which may damage it.



Left headlight.

- 1. Remove the round low beam rubber cover from the headlight housing.
- 2. Remove the connector from the bulb.
- 3. Remove the bulb by pressing it slightly upward and then pulling it out.

- 4. Insert the new bulb in the socket. The bulb's guiding pin should point straight up.
- 5. Press the connector into place.
- 6. Put the round rubber cover back in place.

Related information

- Location of exterior lights (p. 594)
- Removing the plastic cover to replace bulbs (p. 593)
- Removing the rectangular headlight cover (p. 593)
- Bulb specifications (p. 597)

Replacing the high beam headlight bulbs

The high beam bulbs in the halogen headlights can be changed without the help of a workshop.

Before the lamp can be replaced, the rectangular headlight cover must be removed.

! CAUTION

Never touch the bulb glass with your bare fingers. Grease and oils from your fingers vaporize in the heat and will leave a deposit on the reflector, which may damage it.



Left headlight.

- 1. Remove the bulb by turning the bulb holder upward and then pulling it straight out.
- 2. Carefully pry the plastic sleeve by the connector's locking lug to release it.

- Remove the connector from the bulb.
 - 4. Replace the bulb.
 - Position the bulb in the socket and turn it downward.

Related information

- Location of exterior lights (p. 594)
- Removing the plastic cover to replace bulbs (p. 593)
- Removing the rectangular headlight cover (p. 593)
- Bulb specifications (p. 597)

Replacing daytime running lights/ front parking light bulbs

The daytime running light/parking light bulbs in the halogen headlights can be changed without the help of a workshop.


Before the lamp can be replaced, the rectangular headlight cover must be removed.

i NOTE

Daytime running lights/parking lights are easier to reach if the high beam headlight bulbs are removed. The high beam headlights are mounted above and to the side of the daytime running lights/parking lights. Remove the high beam headlight bulb by turning the bulb holder upward and then pulling it straight out.

(!) CAUTION

Never touch the bulb glass with your bare fingers. Grease and oils from your fingers vaporize in the heat and will leave a deposit on the reflector, which may damage it.



Left headlight.

- 1. Pull the daytime running light/parking light bulb holder straight out.
- 2. Remove the bulb by pulling it straight out.
- Replace the bulb.
- Position the bulb holder in the socket and push it into place.
- If the high beam bulb holder has come loose, position it in the socket and turn downward.

- Location of exterior lights (p. 594)
- Removing the plastic cover to replace bulbs (p. 593)
- Removing the rectangular headlight cover (p. 593)
- Bulb specifications (p. 597)

Replacing front turn signal bulbs

The turn signal bulbs in the halogen headlights can be changed without the help of a workshop.

Before the lamp can be replaced, the rectangular headlight cover must be removed.



Left headlight.

- 1. Press the retaining catches together and pull the bulb holder straight out.
- 2. The bulb holder and bulb must be replaced as one unit.
- 3. Position the bulb holder in the socket and push it into place.

Related information

- Location of exterior lights (p. 594)
- Removing the plastic cover to replace bulbs (p. 593)

- Removing the rectangular headlight cover (p. 593)
- Bulb specifications (p. 597)

Bulb specifications

The following specifications apply to the bulbs in the halogen headlights.

If you are experiencing problems with any other lights, contact a workshop¹⁷.

Function	W ^A	Туре
Low beams	55	H11
High beams	65	H9
Front turn signal	24	PY24W
Daytime running light/ parking light, front	21/5	W21/5W

A Watt

- Location of exterior lights (p. 594)
- Replacing bulbs (p. 591)

Start battery

The vehicle has a single-pole electrical system that uses the chassis and engine mount as conductors.

The start battery is used to start the electrical system and power the starter motor and other electrical equipment in the vehicle.

The start battery should only be replaced by a workshop¹⁸.

The vehicle has a voltage-regulated alternating current generator.

The starter battery is a 12 V battery, designed for the carbon dioxide reducing functions Start/Stop and regenerative charging, and to support the functionality of the car's different systems.

The service life and performance of the start battery are affected by factors such as driving style, driving conditions, climate, battery discharges, number of starts, etc.

- Never disconnect the start battery while the engine is running.
- Make sure the cables to the start battery are correctly connected and the clamps are securely tightened.

- Batteries generate hydrogen gas, which is flammable and explosive.
- Do not connect the jumper cable to any part of the fuel system or to any moving parts. Avoid touching hot manifolds.
- Battery fluid contains sulfuric acid. Do not allow battery fluid to contact eyes, skin, fabrics or painted surfaces.
- If contact occurs, flush the affected area immediately with water. Obtain medical help immediately if eyes are affected.
- Never expose the battery to open flame or electric spark. Do not smoke near the battery. Failure to follow the instructions for jump starting can lead to injury.

Connection points

↑ WARNING


PROPOSITION 65 WARNING

Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the state of California to cause cancer and reproductive harm. Wash hands after handling.

Use the vehicle's connection points in the engine compartment to connect an external start battery or battery charger.

The battery terminals on the car's starter battery in the luggage/cargo area must **not** be used.

If the start battery is being charged, the support battery will also be charged.



- 1 Positive connection point
- Negative connection point

¹⁷ An authorized Volvo workshop is recommended.

¹⁸ An authorized Volvo workshop is recommended.

! CAUTION

Only a modern battery charger with controlled charge voltage should be used to charge the starter battery and support battery. The rapid charging function should not be used as this could damage the battery.

! CAUTION

Failure to observe the following could cause the infotainment energy save mode to temporarily stop working and/or a message in the driver's display regarding the state of charge of the starter battery may be temporarily incorrect after an external starter battery or battery charger has been connected:

The negative battery terminal of the vehicle's starter battery must never be used to connect an external starter battery or battery charger – only the vehicle's negative charging point should be used as a grounding point.

(i) NOTE

If the starter battery becomes discharged too many times, it will shorten its service life.

The service life of the starter battery is affected by several factors, such as driving conditions and climate. The starting capacity of the battery reduces gradually over time. The battery must therefore be recharged if the vehicle is not used or a long period of time or if it is only driven short distances. Severe cold further limits the starting capacity.

To keep the starter battery in a good condition, the vehicle should be driven at least 15 minutes per week or the battery should be connected to a battery charger with automatic trickle charging.

A starter battery that is always kept fully charged has the maximum service life.

Location



The start battery is located in the cargo compartment.

⚠ WARNING

If the starter battery is disconnected, the function for automatic opening and closing must be reset to function correctly. A reset is required in order for the pinch protection to work.

Specifications

Battery	H7 AGM	H8 AGM
Voltage (V)	12	12
Cold start capacity ^A - CCA ^B (A)	800	850

4◀

Battery	H7 AGM	H8 AGM
Dimensions, L×W×H	315×175×190 mm (12.4×6.9×7.5 inches)	353×175×190 mm (13.9×6.9×7.5 inches)
Capacity (Ah)	80	95

A According to EN standard.

Volvo recommends that batteries are replaced by an authorized Volvo workshop.

Jump starting using another battery (p. 447)



When replacing the starter battery or support battery, an AGM¹⁹ battery must be installed.

(!) CAUTION

If replacing the starter battery, make sure you replace it with a battery with the same cold start capacity and type as the original battery (see the decal on the battery).



The size of the starter battery should conform to the dimensions of the original battery.

- Battery symbols (p. 602)
- Support battery (p. 601)

B Cold Cranking Amperes.

¹⁹ Absorbed Glass Mat

Support battery

In addition to the start battery, vehicles equipped with the Start/Stop function also have a support battery.

Vehicles with the Start/Stop function are equipped with two 12-volt batteries – a heavy-duty start battery and a support battery that provides extra current during the Start/Stop function's start sequence.



The support battery is located in a box next to the spring strut in the engine compartment.

(i) NOTE

- The higher the current consumption in the vehicle, the more the alternator has to work and the batteries have to be charged = increased fuel consumption.
- When the starter battery capacity has dropped below the lowest permissible level, the Start/Stop function is disengaged.

When the Start/Stop function is temporarily reduced due to high current consumption:

 The engine will auto-start, even if the driver does not lift their foot from the brake pedal.

The support battery does not normally require more service than the start battery. If you have any questions or concerns, consult a workshop – an authorized Volvo workshop is recommended.

! CAUTION

If the following is not observed, the Start/ Stop function may temporarily stop working after connection of an external starter battery or battery charger:

The negative battery terminal of the vehicle's starter battery must never be used to connect an external starter battery or battery charger – only the vehicle's negative charging point should be used as a grounding point.

[4

NOTE

If the starter battery is discharged to the extent that the vehicle does not have normal electrical functions and the engine must then be jump-started with an external battery or a battery charger, the Start/Stop function may remain activated. If the Start/Stop function shortly thereafter auto-stops the engine, there is a huge risk that auto-start of the engine will fail due to insufficient battery capacity since the battery had not had time to recharge.

If the vehicle has been jump-started or if there has not been enough time for the battery to be charged with a battery charger, it is advisable to temporarily deactivate the Start/Stop function until the battery has been recharged by the vehicle. At an ambient temperature of about +15°C (about 60°F), the battery must be charged by the vehicle for at least one hour. At lower ambient temperatures, the charging time can increase to 3-4 hours. It is advisable to charge the battery with an external battery charger.

Specifications

	Voltage (V)	12
•	Cold start capacity ^A - CCA ^B (A)	170

²⁰ Absorbed Glass Mat.

Dimensions, L×W×H	150×90×130 mm (5.9×3.5×5.1 inches)
Capacity (Ah)	10

A According to EN standard.

1

. CAUTION

When replacing the starter battery or support battery, an AGM^{20} battery must be installed.

Related information

- Start battery (p. 598)
- Start/Stop function (p. 428)
- Battery symbols (p. 602)

Battery symbols

There are warning symbols and information on the batteries.



Wear protective goggles.



See the Owner's Manual for additional information.



Keep batteries away from children.



Batteries contain corrosive acid.

B Cold Cranking Amperes.



Avoid smoking, open flames, and/or sparks.



Risk of explosion.



Recycle properly.



A used start battery or backup battery contains lead and must be recycled in an environmentally responsible manner.

Related information

- Start battery (p. 598)
- Support battery (p. 601)

Fuses and fuseboxes

All electrical functions and components are protected by a number of fuses in order to protect the vehicle's electrical system from damage by short circuiting or overloading.

★ WARNING

Never use a foreign object or a fuse with a higher amperage than that specified to replace a fuse. This could cause significant damage to the electrical system and possibly lead to a fire.

If any electrical component or function is not responding, the component may have blown a fuse due to temporary overload. If the same fuse blows repeatedly, there may be a problem with the component. Volvo recommends contacting an authorized Volvo workshop to have the component checked.

Location of fuseboxes



The illustration is generic - appearance may vary according to vehicle model.

- Engine compartment
- 2 Under the glove compartment
- Trunk/cargo compartment

- Replacing fuses (p. 604)
- Fuses in the cargo compartment (p. 611)
- Fuses in the engine compartment (p. 605)
- Fuses under the glove compartment (p. 608)

Replacing fuses

All electrical functions and components are protected by a number of fuses in order to protect the vehicle's electrical system from damage by short circuiting or overloading.

- 1. Refer to the fuse diagram to locate the fuse.
- 2. Pull out the fuse and examine it from the side to determine if the curved metal wire in the fuse is intact.
- 3. If the wire is broken, replace the fuse with a new fuse of the same color and amperage.

⚠ WARNING

Never use a foreign object or a fuse with a higher amperage than that specified to replace a fuse. This could cause significant damage to the electrical system and possibly lead to a fire.

↑ WARNING


Contact an authorized Volvo workshop for assistance replacing fuses not listed in the Owner's Manual. If performed incorrectly, significant damage can be caused to the electrical system.

- Fuses and fuseboxes (p. 603)
- Fuses in the cargo compartment (p. 611)

- Fuses in the engine compartment (p. 605)
- Fuses under the glove compartment (p. 608)

Fuses in the engine compartment

The fuses in the engine compartment help protect electrical components such as engine and brake functions.



MAINTENANCE AND SERVICE

• Fuse pliers are provided on the inside of the fuse box cover to assist in removing and inserting fuses.

There are also spaces for several extra fuses in the fusebox.

Positions

There is a decal with a diagram of the locations of the fuses on the inside of the cover.

- Fuses 1-13, 18-30, 35-37 and 46-54 are "Micro" fuses.
- Fuses 14-17, 31-34 and 38-45 are "MCase" fuses and should only be replaced by a workshop²¹.

	Function	A ^A
0	-	-
2	-	-
3	-	-
4	Ignition coils (gasoline); spark plugs (gasoline)	15
6	Oil pump solenoid; A/C magnetic coupling; heated oxygen sensor, center (gasoline); heated oxygen sensor, rear (diesel)	15

	Function	A ^A
6	Vacuum regulators; valve; valve for power pulse (diesel)	7.5
7	Engine control module; actuator; throttle unit; EGR valve (diesel); turbo position sensor (diesel); turbocharger valve (gasoline)	20
8	Engine control module	5
9	-	-
10	Solenoids (gasoline); valve; Engine cooling system thermo- stat (gasoline); EGR cooling pump (diesel); glow control module (diesel)	10
1	Spoiler shutter control module; Radiator shutter control module; Relay windings for power pulse (diesel)	5
12	Heated oxygen sensor, front; Heated oxygen sensor, rear (gasoline)	15
13	Engine control module	20
14	Starter motor	40

	Function	A ^A
1	Starter motor	Shunt
16	Fuel filter heater (diesel)	30
1	-	-
13	-	-
19	-	-
20	-	-
3	-	-
22	-	-
23	-	-
24	12 V outlet in tunnel console, front	15
25	12 V outlet in tunnel console between rear seats	15
26	12 V outlet in trunk/cargo compartment*	15
2	-	-
28	-	-
29	-	-

Option/accessory.

²¹ An authorized Volvo workshop is recommended.

	Function	A ^A
30	-	-
3	Heated windshield*, left side	Shunt
32	Heated windshield*, left side	40
33	Headlight washers*	25
34	Windshield washer	25
35	Transmission control module	15
<u>36</u>	Horn	20
37	Alarm siren*	5
333	Brake system control module (valves, parking brake)	40
39	Wipers	30
40	Rear window washer	25
4	Heated windshield*, right side	40
42		20
43	Brake system control module (ABS pump)	40
4	-	-
45	Heated windshield*, right side	Shunt


	Function	A ^A
46	Fed when ignition is on: engine control module, transmission components, electrical power steering, central electrical module, brake system control module	5
4	_	-
48	Right-side headlight	7.5
	Right-side headlight, some models with LED ^B	15
49	-	ı
50	-	-
5	Battery connection control mod- ule	5
52	Airbags	5
53	Left-side headlight	7.5
	Left-side headlight, some models with LED ^B	15
54	Accelerator pedal sensor	5

- Fuses and fuseboxes (p. 603)
- Replacing fuses (p. 604)

A Ampere B LED (Light Emitting Diode)

Fuses under the glove compartment

Fuses under the glove compartment provide protection for e.g. electrical outlets, displays and door modules.



Fuse pliers are provided on the inside of the fuse box cover to assist in removing and inserting fuses.

There are also spaces for several extra fuses in the distribution box in the engine compartment.

Positions

- Fuses 1, 3-21, 23-36, 39-53 and 55-59 are "Micro" fuses.
- Fuses 2-22, 37-38 and 54 are "MCase" fuses and should only be replaced by a workshop²².

	Function	A ^A
0	-	-
2	Electrical outlet in tunnel console between rear seats*	30
3	-	-
4	Movement sensor*	5
6	Media player	5
6	Instrument panel	5
7	Center console buttons	5
8	Sun sensor	5

	Function	AA
9	-	-
10	-	-
1	Steering wheel module	5
12	Module for start knob and parking brake controls	5
B	Heated steering wheel* module	15
14	-	-
1	-	-
16	-	-
1	-	-
18	Climate system control module	10
19	-	-
20	Data link connector OBD-II	10
3	Center display	5
22	Climate system blower module (front)	40
23	USB HUB	5

	Function	A ^A
24	Instrument lighting; Interior lighting; Rearview mirror auto-dim function*; Rain and light sensors*; Rear tun- nel console keypad, rear seat*; Power front seats*; Rear door con- trol panels; Climate system blower module left/right	7.5
25	Control module for driver support functions	5
20	Panoramic roof with sun curtain*	20
2	Head-up display*	5
28	Passenger compartment lighting	5
29	-	-
30	Ceiling console display (seat belt reminder/front passenger side airbag indicator)	5
3	-	-
32	Humidity sensor	5
33	Door module in right-side rear door	20
34	Fuses in the trunk/cargo compartment	10

²² An authorized Volvo workshop is recommended.

MAINTENANCE AND SERVICE

44

	Function	A ^A
35	Control module for Internet-con- nected vehicle; Control module for Volvo On Call	5
36	Door module in left-side rear door	20
37	Audio control module (amplifier) (certain models only)	40
33	Climate system blower module (rear)*	40
39	Multi-band antenna module	5
40	Front seat massage function*	5
4	-	-
42	Rear window wiper	15
43	Fuel pump control module	15
4	-	-
45	-	-
46	Driver's seat heating	15
4	Front passenger's seat heating	15
48	Coolant pump	10
49	-	-


	Function	A ^A
50	Door module in left-side front door	20
5 1	Active chassis control module*	20
52	-	_
53	Sensus control module	10
54	-	_
5 5	_	-
56	Door module in right-side front door	20
3	-	_
58	TV* (certain markets only)	5
5 9	Primary fuse for fuses 53 and 58	15

A Ampere

- Fuses and fuseboxes (p. 603)
- Replacing fuses (p. 604)

Fuses in the cargo compartment

The fuses in the cargo compartment help protect electrical components such as the power seats*, airbags and seat belt tensioners.



The fuse box is located under the storage compartment on the right-hand side.

Fuse pliers are provided on the inside of the fuse box cover to assist in removing and inserting fuses.

There are also spaces for several extra fuses in the distribution box in the engine compartment.

Positions

- Fuses 13-17 and 21-36 are "Micro" fuses.
- Fuses 1-12, 18-20 and 37 are "MCase" fuses and should only be replaced by a workshop²³.

	пор .	
	Function	A ^A
0	Heated rear window	30
2	-	-
3	Pneumatic suspension* compressor	40
4	Rear auxiliary electric heater (right-hand side)*	30
6	-	-
6	Rear auxiliary electric heater (left-hand side)*	30
7	-	-
8	Control module for reduction of nitrous oxides (diesel)	30
9	Power tailgate*	25
10	Power front passenger seat*	20
•	Towbar* control module	40

	Function	A ^A
12	Seat belt tensioner module (right side)	40
13	Internal relay windings	5
14	Control module for reduction of nitrous oxides (diesel)	15
1	Foot movement detection module for opening the power tailgate*	5
16	USB hub/accessory port	-
1	Module for electrically folding third- row seats*	20
18	Towbar* control module	25
19	Power driver seat*	20
20	Seat belt tensioner module (left side)	40
2	Park Assist Camera*	5
22	-	-
23	-	-
24	-	-
25	-	-

		- 4
	Function	A ^A
20	Control module for airbags and seat belt tensioners	5
20	_	-
28	Heated rear seat (left side)*	15
29	-	-
30	Blind Spot Information (BLIS)*; Exterior reverse signal control mod- ule	5
3	-	_
32	Modules for seat belt tensioners	5
33	Emissions system actuator (gasoline, certain engine variants)	5
34	-	-
35	All Wheel Drive (AWD) control module*	15
<u>36</u>	Heated rear seat (right side)*	15
37	-	-

A Ampere

²³ An authorized Volvo workshop is recommended.

MAINTENANCE AND SERVICE

- Fuses and fuseboxes (p. 603)
- Replacing fuses (p. 604)

Cleaning the interior

Only use cleaning agents and car care products recommended by Volvo. Clean regularly and treat stains immediately for best results. It is important to vacuum before using a cleaning agent.

! CAUTION

- Some colored clothing (for example, dark jeans and suede garments) may stain the upholstery. If this occurs, it is important to clean and treat these parts of the upholstery as soon as possible.
- Never use strong solvents such as washer fluid, gasoline, mineral spirit or concentrated alcohol to clean the interior as this can damage the upholstery as well as other interior materials.
- Never spray cleaning agent directly onto components that have electrical buttons and controls. Wipe instead with a damp cloth with cleaning agent.
- Sharp objects and Velcro can damage the car's textile upholstery.

Related information

- Cleaning the center display (p. 615)
- Cleaning fabric upholstery and ceiling liner (p. 617)
- Cleaning the seat belt (p. 617)

- Cleaning floor mats and inlay mats (p. 617)
- Cleaning leather upholstery (p. 618)
- Cleaning the leather steering wheel (p. 619)
- Cleaning interior plastic, metal and wood surfaces (p. 620)

Cleaning the center display

Marks, stains, finger smudges etc. on the center display may affect its performance and readability. Clean the screen regularly with a microfiber cloth.



To clean the center display:

- Turn off the center display by pressing and holding the Home button.
- Wipe the screen clean with the microfiber cloth provided or use another microfiber cloth of similar quality. Wipe the screen with a clean, dry microfiber cloth using small, circular motions. If necessary, moisten the cloth slightly.
- 3. Reactivate the display by pressing the Home button briefly.

(I) CAUTION

The microfiber cloth must be free of sand and dirt when cleaning the center display.

(!) CAUTION

When cleaning the center display, apply only light pressure to the screen. Pressing too hard could damage the screen.

! CAUTION

Do not spray liquid or corrosive chemicals directly onto the center display. Do not use window cleaners, cleaning agents, aerosol sprays, solvents, alcohol, ammonia or detergents that contain abrasives.

Never use abrasive cloths, paper towels or tissue paper, as these may scratch the center display.

Related information

- Cleaning the interior (p. 615)
- Cleaning fabric upholstery and ceiling liner (p. 617)
- Cleaning the seat belt (p. 617)
- Cleaning floor mats and inlay mats (p. 617)
- Cleaning leather upholstery (p. 618)

- Cleaning the leather steering wheel (p. 619)
- Cleaning interior plastic, metal and wood surfaces (p. 620)

Cleaning the head-up display*

Carefully wipe the glass covering the head-up display unit with a clean and dry microfiber cloth. If necessary, the cloth may be slightly moistened.

Never use strong stain removers. For difficult cleaning conditions, a special cleaning agent can be purchased at a Volvo retailer.

Related information

- Activating and deactivating the head-up display* (p. 146)
- Head-up display* (p. 144)

Option/accessory.

Cleaning fabric upholstery and ceiling liner

Only use cleaning agents and car care products recommended by Volvo. Clean regularly and treat stains immediately for best results. It is important to vacuum before using a cleaning agent.

Fabric upholstery and ceiling liner

Never scrape or rub a stain, as this could damage the upholstery. Never use strong stain removers, as this could change the color of the upholstery.

Use soapy water or a similar detergent. For more difficult stains caused by oil, ice cream, shoe polish, etc., use a stain remover. Consult with your Volvo retailer.

Related information

- Cleaning the interior (p. 615)
- Cleaning the center display (p. 615)
- Cleaning the seat belt (p. 617)
- Cleaning floor mats and inlay mats (p. 617)
- Cleaning leather upholstery (p. 618)
- Cleaning the leather steering wheel (p. 619)
- Cleaning interior plastic, metal and wood surfaces (p. 620)

Cleaning the seat belt

Only use cleaning agents and car care products recommended by Volvo. Clean regularly and treat stains immediately for best results. It is important to vacuum before using a cleaning agent.

Seat belts

Use water and a synthetic soap solution. Specially designed textile cleaning agents are available for purchase at Volvo retailers. Make sure the belt is dry before it is retracted.

Related information

- Cleaning the interior (p. 615)
- Cleaning the center display (p. 615)
- Cleaning fabric upholstery and ceiling liner (p. 617)
- Cleaning floor mats and inlay mats (p. 617)
- Cleaning leather upholstery (p. 618)
- Cleaning the leather steering wheel (p. 619)
- Cleaning interior plastic, metal and wood surfaces (p. 620)

Cleaning floor mats and inlay mats

Only use cleaning agents and car care products recommended by Volvo. Clean regularly and treat stains immediately for best results. It is important to vacuum before using a cleaning agent.

Inlay mats and floor mats

Remove the inlay mats to clean the floor mats and inlay mats separately. Use a vacuum to remove dust and dirt. Each inlay mat is secured into place with pins.

Remove the inlay mat by grasping the inlay mat at each pin and lifting the mat straight up.

Put the inlay mat back into place by pressing it in at each pin.

™ WARNING

- Never use more than one inlay mat at a time on the driver's floor. If any other type of floor mat is used, remove the original mat from the driver's seat floor before driving. All types of mats must be securely anchored in the attachment points in the floor. Make sure the floor mat does not impede the movement of the brake pedal or accelerator pedal in any way, as this could be a serious safety hazard.
- Volvo's floor mats are specially manufactured for your vehicle. They must be properly secured in the attachment points in the floor to help ensure they cannot slide and become trapped under the pedals.

After vacuuming, a specially designed textile cleaning agent should be used to remove stains on floor mats. Floor mats should be cleaned with products recommended by Volvo retailers.

Related information

- Cleaning the interior (p. 615)
- Cleaning the center display (p. 615)
- Cleaning fabric upholstery and ceiling liner (p. 617)
- Cleaning the seat belt (p. 617)
- Cleaning leather upholstery (p. 618)

- Cleaning the leather steering wheel (p. 619)
- Cleaning interior plastic, metal and wood surfaces (p. 620)

Cleaning leather upholstery

Only use cleaning agents and car care products recommended by Volvo. Clean regularly and treat stains immediately for best results. It is important to vacuum before using a cleaning agent.

Leather upholstery*

Volvo's leather upholstery is treated to protect its original appearance. Over time, sunlight, grease, dirt, etc. could break down the protective layer. This could result in scratches and cracking.

Leather upholstery is a natural product that changes and acquires a beautiful patina over time. Regular cleaning and treatments are required to preserve the qualities and color of the leather. Volvo offers a comprehensive product, Volvo Leather Care Kit/Wipes, for cleaning and treating leather upholstery that, when used as directed, preserves the leather's protective coating.

For best results, Volvo recommends cleaning and applying protective cream one to four times a year (or more as needed). Volvo Leather Care Kit 951 0251 and Volvo Leather Softener 943 7429 are available for purchase at Volvo retailers.

Option/accessory.

Cleaning the leather upholstery

- 1. Apply the leather cleaner to a damp sponge and squeeze it until the cleaner foams.
- 2. Move the sponge in circular motions to apply the foam to the stain.
- Dampen the stain thoroughly with the sponge. Let the sponge absorb the stain and do not rub.
- 4. Dry the stain using a soft towel and let the leather dry completely.

Protecting the leather upholstery

- Apply a small amount of leather protector to a cloth and then apply the protector to the leather using light circular movements.
- 2. Let it dry for approximately 20 minutes.

Protecting the leather upholstery makes it better able to withstand sunlight's harmful UV rays.

Related information

- Cleaning the interior (p. 615)
- Cleaning the center display (p. 615)
- Cleaning fabric upholstery and ceiling liner (p. 617)
- Cleaning the seat belt (p. 617)
- Cleaning floor mats and inlay mats (p. 617)
- Cleaning the leather steering wheel (p. 619)
- Cleaning interior plastic, metal and wood surfaces (p. 620)

Cleaning the leather steering wheel

Only use cleaning agents and car care products recommended by Volvo. Clean regularly and treat stains immediately for best results. It is important to vacuum before using a cleaning agent.

Leather steering wheel

Leather needs to breathe. Never cover the leather steering wheel with a plastic protector. Volvo Leather Care Kit 951 0251 and Leather Softener 943 7429 are recommended for cleaning the leather steering wheel. First, remove dirt, dust, etc. with a damp sponge or cloth.

(<u>I</u>) C

CAUTION

Sharp objects such as rings could damage the leather on the steering wheel.

If there are stains on the steering wheel:

Type 1(ink, wine, coffee, milk, sweat or blood)

 Use a soft cloth or sponge. Wipe the steering wheel using a solution of 5% ammonia. For blood stains, mix approximately 2 dl(1 cup) of water with 25 g (one ounce) of salt and wipe the stain.

Type 2(grease, oil, sauces or chocolate)

- 1. Same procedure as for Type 1 stains.
- 2. Finish by wiping the wheel with an absorbent paper or towel.

Type 3(dry dirt or dust)

- 1. Remove the dirt/dust using a soft brush.
- 2. Same procedure as for Type 1 stains.

- Cleaning the interior (p. 615)
- Cleaning the center display (p. 615)
- Cleaning fabric upholstery and ceiling liner (p. 617)
- Cleaning the seat belt (p. 617)
- Cleaning floor mats and inlay mats (p. 617)
- Cleaning leather upholstery (p. 618)
- Cleaning interior plastic, metal and wood surfaces (p. 620)

Cleaning interior plastic, metal and wood surfaces

Only use cleaning agents and car care products recommended by Volvo. Clean regularly and treat stains immediately for best results.

Interior plastic, metal and wood surfaces

A lightly dampened microfiber cloth is recommended for cleaning interior details and surfaces. These cloths are available for purchase at Volvo retailers.

Never scrape or rub a stain. Never use strong stain removers.

! CAUTION

Do not use solvent containing alcohol to clean the instrument panel glass.

(!) CAUTION

Keep in mind that glossy surfaces can be easily scratched. Wipe these surfaces with a clean and dry microfiber cloth using small, circular motions. If necessary, moisten the cloth lightly with clean water.

Related information

- Cleaning the interior (p. 615)
- Cleaning the center display (p. 615)

- Cleaning fabric upholstery and ceiling liner (p. 617)
- Cleaning the seat belt (p. 617)
- Cleaning floor mats and inlay mats (p. 617)
- Cleaning leather upholstery (p. 618)
- Cleaning the leather steering wheel (p. 619)

Cleaning the exterior

The vehicle should be washed as soon as it becomes dirty. This makes the vehicle easier to clean because dirt does not attach as strongly. It also reduces the risk of scratches and keeps the vehicle looking new. Wash the vehicle in a car wash or garage with an oil separator. Use a car washing detergent.

- Cleaning the exterior (p. 620)
- Polishing and waxing (p. 621)
- Hand washing (p. 621)
- Automatic car washes (p. 623)
- High-pressure washing (p. 624)
- Cleaning the wiper blades (p. 624)
- Cleaning exterior plastic, rubber and trim components (p. 625)
- Cleaning rims (p. 626)
- Corrosion protection (p. 626)

Polishing and waxing

Polish and wax the vehicle when the paint is matte or to provide extra protection. The vehicle does not need to be polished until it is at least a year old. However, it can be waxed during the first year. Do not polish or wax the vehicle in direct sunlight. The surface of the vehicle should not be warmer than approximately 45 °C (113 °F).

- Wash and dry the vehicle very carefully before polishing or waxing. Remove asphalt and tar stains with asphalt remover or paint thinner. More stubborn stains can be removed with a grinding paste designed for vehicle paint.
- Use polish first and then liquid or paste wax.
 Follow the instructions on the package carefully. Many products contain both polish and wax.
- A wide range of polymer-based waxes can be purchased today. These waxes are easy to use and produce a long-lasting, high-gloss finish that protects the bodywork against oxidation, road dirt and fading.

(!) CAUTION

Avoid waxing and polishing plastic and rubber.

If using degreaser on plastic and rubber, only rub (if necessary) with slight pressure. Use a soft sponge.

Polishing glossy trim moldings can wear away or damage the glossy surface layer.

Polish containing abrasives must not be used.

(!) CAUTION

Only use paintwork treatments recommended by Volvo. Other treatments, such as preservation, sealing, protection, luster sealing or similar, could damage the paintwork. Paintwork damage caused by such treatments are not covered by Volvo's warranty.

Related information

- Cleaning the exterior (p. 620)
- Hand washing (p. 621)
- Automatic car washes (p. 623)
- High-pressure washing (p. 624)
- Cleaning the wiper blades (p. 624)
- Cleaning exterior plastic, rubber and trim components (p. 625)
- Cleaning rims (p. 626)
- Corrosion protection (p. 626)

Hand washing

The vehicle should be washed as soon as it becomes dirty. This makes the vehicle easier to clean because dirt does not attach as strongly. It also reduces the risk of scratches and keeps the vehicle looking new. Wash the vehicle in a car wash or garage with an oil separator. Use a car washing detergent.

Hand washing

Keep the following points in mind when washing the vehicle:

- Avoid washing the vehicle in direct sunlight.
 This could cause the detergent or wax to dry out and become abrasive.
- Remove bird droppings from paintwork as soon as possible. They contain chemicals that affect and discolor paint very quickly. Use e.g. soft paper or a sponge soaked in lots of water. Consult an authorized Volvo workshop for assistance removing discoloration.
- Hose down the underbody, including the wheel housings and bumper.
- Hose down the entire vehicle and remove any loose dirt, droppings etc. to reduce the risk of scratches from washing. Do not spray directly onto locks.
- If necessary, use cold degreaser on heavily soiled surfaces. Note that in such cases the surfaces must not be hot from the sun.

••

MAINTENANCE AND SERVICE

- Wash using a sponge, car washing detergent and plenty of lukewarm water.
 - Clean the wiper blades with lukewarm soap solution or car washing detergent.
 - Dry the vehicle using a clean, soft chamois or a squeegee. Try not to let drops of water dry in strong sunlight. This could cause water drying stains that may need to be polished out.
 - In areas with heavy industrial emissions, more frequent washing of the vehicle's exterior is recommended.
 - Tar spots from asphalt may remain even after washing. Use a tar remover to remove these spots after washing the vehicle.

MARNING

Always entrust engine washing to a workshop. If the engine is hot, there is a risk of fire.

(!) CAUTION

Dirty headlights do not work as well. Clean them regularly, e.g. when refueling.

Do not use corrosive cleaners. Use water and a non-abrasive sponge.

(i) NOTE

Exterior lighting such as headlights and taillights may develop temporary condensation on the inside of the lens. This is normal. All exterior lighting is designed to resist this. Condensation is normally vented out of the lamp housing once the light has been lit for some period of time.

! CAUTION

- Make sure that the panoramic roof and sun shade are closed before washing the vehicle.
- Never use abrasive polishing agents on the panoramic roof.
- Never use wax on the rubber seals around the panoramic roof.

! CAUTION

Remember to remove dirt from the drain holes in the doors and sills after washing the vehicle.

- Cleaning the exterior (p. 620)
- Polishing and waxing (p. 621)
- Automatic car washes (p. 623)
- High-pressure washing (p. 624)

- Cleaning the wiper blades (p. 624)
- Cleaning exterior plastic, rubber and trim components (p. 625)
- Cleaning rims (p. 626)
- Corrosion protection (p. 626)

Automatic car washes

The vehicle should be washed as soon as it becomes dirty. This makes the vehicle easier to clean because dirt does not attach as strongly. It also reduces the risk of scratches and keeps the vehicle looking new.

Automatic car washes

An automatic car wash is a fast and easy way to keep your vehicle clean, but it does not reach all areas of the vehicle. For best results, Volvo recommends hand washing your vehicle or supplementing automatic car washes with a hand wash.



NOTE

Volvo recommends not washing the vehicle in an automatic car wash during the first few months; the paintwork on new vehicles takes some time to fully harden.



CAUTION

Before driving the vehicle into a car wash, deactivate the Automatic Braking when Stationary and Automatic Parking Brake Application functions. If the functions are not deactivated, the brake system will seize when the vehicle is stationary and the vehicle will not be able to roll.

! CAUTION

For automatic car washes in which the vehicle is pulled forward on rolling wheels:

- Before washing the vehicle, make sure that the automatic rain sensor is deactivated. If it is not deactivated and inadvertently starts, the wiper arms could be damaged.
- To help prevent damage from the automatic car wash machinery, make sure that the door mirrors are folded in, antennas retracted or removed, and any auxiliary lights secured.
- 3. Drive into the automatic car wash.
- Turn off the "Automatic Braking when Stationary" function using the switch in the tunnel console.
- Turn off the "Automatic Parking Brake Application" function in the center display's Top view.
- Turn off the engine by turning the start knob in the tunnel console clockwise.
 Hold the knob in position for at least 2 seconds.

The vehicle is now ready for the automatic car wash.

- Cleaning the exterior (p. 620)
- Polishing and waxing (p. 621)
- Hand washing (p. 621)
- High-pressure washing (p. 624)
- Cleaning the wiper blades (p. 624)
- Cleaning exterior plastic, rubber and trim components (p. 625)
- Cleaning rims (p. 626)
- Corrosion protection (p. 626)

High-pressure washing

The vehicle should be washed as soon as it becomes dirty. This makes the vehicle easier to clean because dirt does not attach as strongly. It also reduces the risk of scratches and keeps the vehicle looking new. Wash the vehicle in a car wash or garage with an oil separator. Use a car washing detergent.

High-pressure washing

If washing the vehicle with a high-pressure wash, use sweeping movements and keep the nozzle at least 30 cm (13 in.) from the vehicle. Do not spray directly onto locks.

Related information

- Cleaning the exterior (p. 620)
- Polishing and waxing (p. 621)
- Hand washing (p. 621)
- Automatic car washes (p. 623)
- Cleaning the wiper blades (p. 624)
- Cleaning exterior plastic, rubber and trim components (p. 625)
- Cleaning rims (p. 626)
- Corrosion protection (p. 626)

Cleaning the wiper blades

The vehicle should be washed as soon as it becomes dirty. This makes the vehicle easier to clean because dirt does not attach as strongly. It also reduces the risk of scratches and keeps the vehicle looking new. Wash the vehicle in a car wash or garage with an oil separator. Use a car washing detergent.

Wiper blades

Asphalt, dust and salt residue on wiper blades, as well as insects, ice etc. on the windshield, shorten the service life of wiper blades.

When cleaning, put the wiper blades in the service position.

\mathbf{i}

NOTE

Wash the wiper blades and windshield regularly with a lukewarm soap solution or vehicle shampoo. Do not use strong solvents.

- Cleaning the exterior (p. 620)
- Polishing and waxing (p. 621)
- Hand washing (p. 621)
- Automatic car washes (p. 623)
- High-pressure washing (p. 624)
- Cleaning exterior plastic, rubber and trim components (p. 625)

- Cleaning rims (p. 626)
- Corrosion protection (p. 626)


Cleaning exterior plastic, rubber and trim components

The vehicle should be washed as soon as it becomes dirty. This makes the vehicle easier to clean because dirt does not attach as strongly. It also reduces the risk of scratches and keeps the vehicle looking new. Wash the vehicle in a car wash or garage with an oil separator. Use a car washing detergent.

Exterior plastic, rubber and trim components

A special cleaning agent available from Volvo retailers is recommended for the cleaning and care of colored plastic parts, rubber and trim components, e.g. glossy trim. Follow the usage instructions for the cleaning agent carefully.

Avoid using car washing detergents with a pH value lower than 3.5 or higher than 11.5. Doing so could result in the discoloring of anodized aluminum surfaces* (as shown in the illustrations below). Abrasive polishing agents are not recommended for these areas (as shown in the illustrations below).



Components that should be washed with a cleaning product with a pH value between 3.5 and 11.5.

(!) CAUTION

Avoid waxing and polishing plastic and rubber.

If using degreaser on plastic and rubber, only rub (if necessary) with slight pressure. Use a soft sponge.

Polishing glossy trim moldings can wear away or damage the glossy surface layer.

Polish containing abrasives must not be used.

! CAUTION

Avoid washing the vehicle with cleaner with a pH value below 3.5 or above 11.5. This could cause discoloration of anodized aluminum components like the roof rail and around the side windows.

Never use metal polishing agent on anodized aluminum components. This could cause discoloration and destroy the surface treatment.

- Cleaning the exterior (p. 620)
- Polishing and waxing (p. 621)
- Hand washing (p. 621)
- Automatic car washes (p. 623)
- High-pressure washing (p. 624)
- Cleaning the wiper blades (p. 624)
- Cleaning rims (p. 626)
- Corrosion protection (p. 626)

Cleaning rims

The vehicle should be washed as soon as it becomes dirty. This makes the vehicle easier to clean because dirt does not attach as strongly. It also reduces the risk of scratches and keeps the vehicle looking new. Wash the vehicle in a car wash or garage with an oil separator. Use a car washing detergent.

Rims

Only use rim cleaning products recommended by Volvo.

Strong rim cleaning agents could damage the surface and stain the chromed aluminum rims.

Related information

- Cleaning the exterior (p. 620)
- Polishing and waxing (p. 621)
- Hand washing (p. 621)
- Automatic car washes (p. 623)
- High-pressure washing (p. 624)
- Cleaning exterior plastic, rubber and trim components (p. 625)
- Cleaning rims (p. 626)
- Corrosion protection (p. 626)

Corrosion protection

Your vehicle is constructed with effective protection against corrosion.

Corrosion protection for the body consists of modern metallic protective coatings on the sheet metal, a high-quality painting process, corrosion-protected and minimized metal overlap, and shielding plastic components, abrasion protection and supplemental rust inhibitor in exposed areas. In the chassis, exposed components of the wheel suspension are made of corrosion-resistant cast aluminum.

Inspection and maintenance

The corrosion protection does not normally require maintenance, but keeping the vehicle clean is always a good way to further reduce the risk of corrosion. The use of strong alkaline or acidic cleaning fluids should always be avoided on shiny body components. Any stone chips in the paint should be touched up as soon as they are discovered.

- Cleaning the exterior (p. 620)
- Polishing and waxing (p. 621)
- Hand washing (p. 621)
- Automatic car washes (p. 623)
- High-pressure washing (p. 624)
- Cleaning the wiper blades (p. 624)

- Cleaning exterior plastic, rubber and trim components (p. 625)
- Cleaning rims (p. 626)

Paintwork

The paintwork consists of multiple layers. It is an important part of the vehicle's corrosion protection and therefore needs to be checked regularly.

The most common types of paint damage are minor stone chips, scratches and damage to e.g. the edges of fenders, doors and bumpers. To help prevent corrosion, paint damage should be rectified immediately.

Related information

- Touching up minor paint damage (p. 627)
- Color codes (p. 628)

Touching up minor paint damage

The paintwork is an important part of the vehicle's corrosion protection and therefore needs to be checked regularly. The most common types of paint damage are minor stone chips, scratches and damage to e.g. the edges of fenders, doors and bumpers.

When repairing paint damage, the vehicle must be clean, dry and have a temperature above 15 °C (60 °F).

Touching up minor paint damage

To help prevent corrosion, paint damage should be rectified immediately.

i) N

NOTE

When repairing paintwork, it must be clean, dry and at a temperature of at least 15°C.

Materials that might be needed


- Primer²⁴ special adhesive primer is available in a spray can for e.g. plastic-covered bumpers.
- Base coat and clear coat available in spray cans or as a touch-up pen/stick²⁵.
- Masking tape.
- Fine-grain sandpaper²⁴.

If the damage has not reached all the way down to the metal, then touch-up paint can be applied immediately after the surface has been cleaned.



NOTE

Make sure the surface is clean and dry before performing any touch-ups to the paint. The surface temperature should be at least 15 $^{\circ}$ C (60 $^{\circ}$ F).



²⁴ If required.

²⁵ Follow the instructions on the packaging for the touch-up pen/stick carefully.

MAINTENANCE AND SERVICE

- Place a strip of masking tape over the damaged surface. Pull the tape off so that any loose flakes of paint adhere to it.
 - If the damage goes down to the bare metal, you may need to use primer first. If the paint damage is on a plastic surface, an adhesive primer should be used for better results. Spray the primer into the lid of the spray can and brush on thinly.
 - Light sanding with a very fine-grained sandpaper or similar may be required before painting (e.g. if there are uneven edges).
 Clean the area carefully and let it dry.
 - Thoroughly mix the primer and apply it with a small brush, toothpick or similar. When the primer is dry, apply one or more coats of paint and then a clear coat, letting the paint dry between each application.

If there is a longer scratch, follow the same procedure as above, but first mask off the surrounding area to protect the undamaged paint.

Touch-up pens and spray paints are available at Volvo retailers.



NOTE

If the stone chip has not gone down to the bare metal and an undamaged coat of paint remains, apply base coat and clear coat immediately after cleaning the surface.

Related information

- Paintwork (p. 627)
- Color codes (p. 628)


Color codes

Color code

The color code label is located on the left door pillar and is visible when the left front door is opened.



Sample color code (1): US models.



Sample color code (1): Canadian models.

It is important to use the right color.


Related information

- Paintwork (p. 627)
- Touching up minor paint damage (p. 627)

Changing rear window wipers

The wiper blades help remove water from the windshield and rear window. Along with the washer fluid, they clean the glass and help improve visibility while driving. The windshield and rear window wiper blades can be replaced.

Changing rear window wipers



Lift the wiper arm from the window and pull the lower section of the blade to the right.

1. Grasp the center of the wiper blade and lift it from the window to the stop position.

i NOTE

When the wiper arm is halfway folded out, it will stop in a locking position that helps prevent the arm from falling back onto the rear window. The wiper arm must be pulled past the locking position stop in order to change the wiper blade.

- Agrip the lower part of the blade and pull to the right until the blade loosens from the arm.
- Press the new wiper blade until it clicks into place. Check to make sure the blade is securely in place.
- 4. Fold the wiper arm back toward the window.

! CAUTION

Check the blades regularly. Neglected maintenance shortens the life of the blades.

Related information

- Using the rain sensor (p. 181)
- Using the windshield and headlight washers (p. 183)
- Using automatic rear window wiping when backing up (p. 185)

>


MAINTENANCE AND SERVICE

- Heated windshield washer nozzles* (p. 181)
- Using the rain sensor's memory function (p. 182)
- Using the rear window wiper/washer (p. 184)
- Filling washer fluid (p. 632)
- Windshield wipers in the service position (p. 631)
- Replacing windshield wiper blades (p. 630)
- Using the windshield wipers (p. 180)

Replacing windshield wiper blades


The wiper blades help remove water from the windshield and rear window. Along with the washer fluid, they clean the glass and help improve visibility while driving. The windshield and rear window wiper blades can be replaced.

Replacing wiper blades





- Service position is activated/deactivated via the function view in the center display when the car is stationary and the windshield wipers are not on. Press the button on the wiper blade attachment and pull the wiper blade straight out, parallel with the wiper arm.
- Slide in a new wiper blade until it clicks into place.
- 3. Check to make sure the blade is securely in place.
- Press the wiper blade back against the windshield.



Wiper blades come in varying lengths.

*Option/accessory.

(i)

NOTE

The wiper blades are different lengths. The blade on the driver's side is longer than the one on the passenger side.

Related information

- Using the rain sensor (p. 181)
- Using the windshield and headlight washers (p. 183)
- Using automatic rear window wiping when backing up (p. 185)
- Heated windshield washer nozzles* (p. 181)
- Using the rain sensor's memory function (p. 182)
- Using the rear window wiper/washer (p. 184)
- Filling washer fluid (p. 632)
- Windshield wipers in the service position (p. 631)
- Changing rear window wipers (p. 629)
- Using the windshield wipers (p. 180)

Windshield wipers in the service position

The windshield wiper blades must be in the service (vertical) position when performing certain operations, e.g. replacing the blades.



Windshield wipers in the service position.

The windshield wipers must be in the service position when replacing, washing or lifting the blades (e.g. to scrape ice or snow from the windshield).

<u>(!)</u>

CAUTION

Before placing the wipers in service position, ensure that they have not frozen to the windshield.

Activating/deactivating service position

The service position can be activated/deactivated when the vehicle is stationary and the windshield wipers are switched off. Service position is activated/deactivated via Function view in the center display:



Tap the Wiper Service
Position button. The indicator light in the button will illuminate when service position is activated. The windshield wipers will move to the vertical position when service position is

activated. To deactivate the service position, tap **Wiper Service Position** once. The indicator light in the button will go out when service position is deactivated.

MAINTENANCE AND SERVICE

- The wiper blades will also move out of service position if:
 - The windshield wipers are turned on.
 - The windshield washers are turned on.
 - The rain sensor is activated.
 - The vehicle begins moving.

(CAUTION

If the wiper arms in service position are raised from the windshield, they must be folded back against the windscreen before activating wiping, washing or rain sensor as well as before departure. This is to prevent scratching the paint on the hood.


Related information

- Using the rain sensor (p. 181)
- Using the windshield and headlight washers (p. 183)
- Using automatic rear window wiping when backing up (p. 185)
- Heated windshield washer nozzles* (p. 181)
- Using the rain sensor's memory function (p. 182)
- Using the rear window wiper/washer (p. 184)
- Filling washer fluid (p. 632)
- Replacing windshield wiper blades (p. 630)

- Changing rear window wipers (p. 629)
- Using the windshield wipers (p. 180)

Filling washer fluid

Washer fluid is used to keep the headlights, windshield and rear window clean. Washer fluid containing anti-freeze should be used in very cold weather (below-freezing temperatures).



Fill washer fluid into the reservoir with the blue cover. The reservoir is used for the windshield washer, tailgate window washer and headlight washer*



NOTE

When there is approximately 1 liter (1 qt) of washer fluid remaining, the message **Washer fluid Level low, refill** and the symbol will be displayed in the instrument panel.

*Option/accessory.

Recommended grade: Washer fluid recommended by Volvo, with frost protection during cold weather and temperatures below the freezing point.

! CAUTION

Use Volvo's original washer fluid or an equivalent fluid with the recommended pH value between 6 and 8, diluted as recommended, e.g. in a 1:1 solution with pH-neutral water.

(!) CAUTION

Use washer fluid with anti-freeze when temperatures are below the freezing point to help keep the pump, reservoir and hoses from freezing.

Volume:

- Vehicles **with** headlight washing: 5.5 liters (5.8 qts).
- Vehicles **without** headlight washing: 3.5 liters (3.7 qts).


- Using the rain sensor (p. 181)
- Using the windshield and headlight washers (p. 183)
- Using automatic rear window wiping when backing up (p. 185)

- Heated windshield washer nozzles* (p. 181)
- Using the rain sensor's memory function (p. 182)
- Using the rear window wiper/washer (p. 184)
- Windshield wipers in the service position (p. 631)
- Replacing windshield wiper blades (p. 630)
- Changing rear window wipers (p. 629)
- Using the windshield wipers (p. 180)

Type designations

The decals in the vehicle contain information such as chassis number, type designation, color code, etc.

Location of decals



The illustration is general and details may vary depending on market and model.



(a) Vehicle Emission Control Information. US models. Your Volvo is designed to meet all applicable emission standards, as evidenced by the certification label on the underside of the hood. For further information regarding these regulations, please consult your Volvo retailer.



(b) Vehicle Emission Control Information. Canadian models. Your Volvo is designed to meet all applicable emission standards, as evidenced by the certification label on the underside of the hood. For further information regarding these regulations, please consult your Volvo retailer.



2 Vehicle Identification Number (VIN). The VIN plate is located on the top left surface of the dashboard. The Vehicle Identification Number (VIN) should always be quoted in all correspondence concerning your vehicle with the retailer and when ordering parts.



3 Tire inflation pressures. This label indicates the correct inflation pressures for the tires that were on the vehicle when it left the factory.



☑ Federal Motor Vehicle Safety Standards
(FMVSS) specifications (USA) and Ministry of
Transport (CMVSS) standards (Canada). Your
Volvo is designed to meet all applicable safety
standards, as evidenced by the certification label
on the driver's side B-pillar (the structural member at the side of the vehicle, at the rear of the
driver's door opening). This label also includes
codes for paint color, etc. For further information
regarding these regulations, please consult your
Volvo retailer. U.S. models have the upper decal;
Canadian models have the lower one.

44



5 Engine oil. This label contains the recommended engine oil specifications.



6 Decal A/C. Refrigerant R134a.




The decals shown in the Owner's Manual do not claim to be exact reproductions of those found in the vehicle. The purpose is to show approximately how they look and about where they are located on the vehicle. The information that applies for your vehicle in particular is found on the decal on the vehicle.

Related information

• Air conditioning specifications (p. 646)

Dimensions

The vehicle's length, height, etc. are shown in the table.



	Dimensions	mm	inches
Α	Ground clearance ^A	227	8.9
В	Wheelbase	2984	117.5
С	Length	4950	194.9
D	Load length, floor,	2040	80.3
	folded backrest	1260 ^B	49.6 ^B
Е	Load length, floor	1220 ^C	48.0 ^C
		554 ^D	21.8 ^D

	Dimensions	mm	inches
F	Height	1776	69.9
G	Load height	816	32.1
Н	Wheel track, front ^E	1665 ^F	65.6 ^F
		1673 ^G	65.9 ^G
	Wheel track, front ^H	1668 ^F	65.7 ^F
		1676 ^G	66.0 ^G

	Dimensions	mm	inches
I	Wheel track, rear ^E	1667 ^F	65.6 ^F
		1675 ^G	65.9 ^G
	Wheel track, rear ^H	1671 ^F	65.8 ^F
		1679 ^G	66.1 ^G
J	Load width, floor	1192	46.9

44

	Dimensions	mm	inches
K	Width	1923 ^l	75.7 ^l
		1931 ^J	76.0 ^J
		1958 ^K	77.1 ^K
L	Width incl. rearview mirrors	2140	84.3
М	Width incl. folded rearview mirrors	2008	79.1

A tcurb weight + 2 people. Varies slightly depending on tire dimensions, chassis, etc.)
 From the second row of seats in 7-seat models.*

Related information

• Weights (p. 641)

^C Vehicles with 5 seats.

D Vehicles with 7 seats.

E Vehicles without pneumatic suspension.

F Vehicles with 18 and 19-inch wheels.

G Vehicles with 20, 21 and 22-inch wheels.

H Vehicles with pneumatic suspension.

Chassis width.

J Width for vehicles with 18 and 19-inch wheels.

K Width for vehicles with 20, 21 and 22-inch wheels.

Weights

The following table lists important weight data for your vehicle.

Category	USA	Canada	
		(lbs)	(kg)
Gross vehicle weight	7-seat, AWD (All Wheel Drive)	6060	2750
Gross venicie weight	Other models	6005	2725
Capacity weight	7-seat	1210	550
Capacity weight	Other models	1100	500
Downingible avia weights fromt	7-seat, AWD (All Wheel Drive)	2885	1310
Permissible axle weights, front	Other models	2865	1300
Permissible axle weights, rear		3280	1490
Curb weight	7-seat	4430-4650	2040-2140
Curb weight	5-seat	4270-4520	2000-2080
Max. roof load		220	100

! CAUTION

 When loading the vehicle, the maximum gross vehicle weight and permissible axle weights may not be exceeded.

- Type designations (p. 636)
- Towing capacity and tongue weight (p. 642)

Towing capacity and tongue weight

Towing capacity and tongue weight are shown in the tables below.

Category	USA	Canada	
		(lbs)	(kg)
	Without brakes:	1650	750
Max. trailer weights	With brakes (AWD):	5000	2250
	With brakes (FWD):	4000	1800
Max. tongue weight	AWD:	500	225
wax. torigue weight	FWD:	400	180

! CAUTION

The maximum trailer weights listed are only applicable for altitudes up to 3280 ft (1,000 m) above sea level. With increasing altitude the engine power and therefore the car's climbing ability are impaired because of the reduced air density, so the maximum trailer weight has to be reduced accordingly. The weight of the car and trailer must be reduced by 10% for every further 3280 ft (1,000 m) (or part thereof).

Related information

- Type designations (p. 636)
- Weights (p. 641)

- Driving with a trailer (p. 449)
- Trailer Stability Assist* (p. 451)

Option/accessory.

Engine specifications

Engine specifications (output, etc.) for each engine variant are shown in the table below. The specifications for Special Edition vehicles may

(i) NOTE

Not all engines are available on all markets.

Engine	Engine code ^A	Output	Output	Torque	Torque	Number of cylinders
T5 / T5 AWD	B4204T23	(kW/rps) 187/92	(hp/rpm) 250/5500	(Nm/rps) 350/25-80	(ft. lbs./rpm) 258/1500-4800	4
T6 AWD	B4204T27	235/95	316/5700	400/37-90	295/2200-5400	4

A The engine code, component and manufacturer serial numbers can be found on the engine.

- Type designations (p. 636)
- Engine oil specifications (p. 644)
- Coolant specifications (p. 645)

Engine oil specifications

Fully synthetic engine oil of at least ACEA A5/B5 must be used. Lower oil grades may not offer the same fuel economy, engine performance or engine protection.



General

See the Service and warranty booklet for information about oil change intervals.




This vehicle is delivered from the factory with synthetic oil.

Do not use oil additives.

Oil viscosity

The wrong oil viscosity can shorten engine service life during normal use. SAE 5W-30 provides good fuel economy and engine protection. See the viscosity chart.



Viscosity chart

Extreme driving conditions

Volvo's VCC RBS0-2AE/SAE 0W20 oil is recommended for extreme conditions.

Oil volume

The oil volume for the engine is:				
Liter (approx.) 5.6				
US qts (approx.)	5.9			

Related information

- Type designations (p. 636)
- Checking and filling engine oil (p. 588)

• Engine oil (p. 587)

Coolant specifications

Recommended grade: Volvo-recommended coolant diluted with 50% water. See package. Consult a Volvo retailer if you have any questions.

Do not mix different types of antifreeze as this could pose a health risk.

Related information

Refilling coolant (p. 590)

Transmission fluid specifications

Under normal driving conditions, the transmission fluid will not need to be changed during its service life. However, it may need to be changed if the vehicle is driven frequently in adverse driving conditions.

Automatic transmission

Prescribed transmission fluid:	AW1

Brake fluid specifications

The medium in the hydraulic brake system is called brake fluid and is used to transfer braking force from e.g. pressure on the brake pedal via a master brake cylinder to one or more slave cylinders, which in turn act on a mechanical brake.

Recommended grade: Volvo Original Dot 4 class 6 or equivalent.



NOTE

Changing or filling brake fluid should be entrusted to an authorized Volvo workshop.

Related information

• Engine compartment overview (p. 587)

Fuel tank volume

The fuel tank's refillable volume is shown in the table below.

	All models
Liter (approx.)	71
US gallons (approx.)	18.8

Related information

- Refueling (p. 442)
- Octane rating (p. 443)

Air conditioning specifications

The climate system in the vehicle uses a freonfree R134a refrigerant. For information regarding the refrigerant, refer to the decal located on the inside of the hood.

The prescribed grades and volumes for fluids and lubricants in the air conditioning system are shown in the tables below.

A/C Decal

Decal for R134a



Refrigerant

Vehicles with R134a refrigerant

Weight	Prescribed grade
750 g (1.65 lbs)	R134a
1000 g ^A (2.20 lbs ^A)	

A Vehicles with A/C for the third row of seats*

The air conditioning system contains the refrigerant R134a under pressure. Service and repairs to the system should only be done by an authorized workshop.

Compressor oil

Volume	Prescribed grade
60 ml (2.03 fl. oz.)	PAG SP-A2
80 ml ^A (2.71 fl. oz. ^A)	

A Vehicles with A/C for the third row of seats*.

Evaporator

(!) CAUTION

The A/C system evaporator must never be repaired or replaced with a previously used evaporator. The new evaporator must be certified and labeled in accordance with SAE J2842.

Related information

Climate control system service (p. 586)

Option/accessory.

Approved tire pressure

The following tire pressures are recommended by Volvo for your vehicle. Refer to the tire infla-

tion placard for information specific to the tires installed on your vehicle at the factory.

Tire dimensions	Cold tire pressure for up to seven people (depending on number of seats)		
	Front	Rear	
	psi (kPa)	psi (kPa)	
235/60 R18	38 (260)	38 (260)	
235/55 R19			
275/45 R20			
275/40 R21			
275/35 R22			
Temporary spare tire	60 (420)	60 (420)	
T125/80 R18			

Related information

- Type designations (p. 636)
- Checking tire pressure (p. 535)

1, 2, 3 ...

4WD 423

A

ABS	
anti-lock brakes	409
AC (Air conditioning)	233
ACC - Adaptive Cruise Control 293 297, 298, 299, 300, 302, 303, 304,	
Accessories and extra equipment installation	35 36
Accessory installation warning	36
Active Bending Lights	161
Adapting driving characteristics	270, 423
Adaptive Cruise Control 293, 296	007
298, 299, 300, 302, 303, 304, change cruise control functionality function manage speed pass radar sensor set time interval troubleshooting	305, 307

Airbag	52
activation/deactivation	56
driver's side	53
passenger side	53, 56
Air bag, see Airbag	52
Air conditioning	233
Air conditioning, fluid volume and grade	646
Air distribution air vents changing defrosting recirculation table showing options	212 212, 213 212 225 224 214
Air quality allergy and asthma passenger compartment filter	209, 210 210 211
Air recirculation	224
Alarm deactivating	266 267
Allergy and asthma-inducing substant	ces 210
All Wheel Drive, AWD	423
All Wheel Drive (AWD)	423
All Wheel Drive (four-wheel drive)	423
Android Auto	496, 498
Antenna location	255

Apple CarPlay	493,	49
Approach lighting		164
Apps		46
Assistance at risk of collision 372, 373, 374,		,
Audio and media		464
Audio system HD digital radio SiriusXM® Satellite radio	476, 477,	478 478
Auto-climate		223
Auto hold		41
Auto-hold brakes activate and deactivate after collision		418 418 41
Automatic car wash		623
Automatic engine stop auto-stop		428
Automatic high beam		159
Automatic locking		259
Automatic relocking	239,	252
Automatic Speed Limiter	280, 282,	283
Automatic transmission kickdown oil Trailer		418 422 648 448

B Backrest front seat, adjusting 188, 189, 192, 193, 194 rear seat, adjusting 200, 201 rear seat, folding 196, 201, 202 Battery 447 jump-start Maintenance 598 598 start 601 support symbols on the battery 602 warning symbols 602 346, 347, 348, 349 BLIS Blower adjusting 228, 229 air distribution 212 air vents 213 Bluetooth 491 connect 509 connecting vehicle to Internet 498 phone settings 507 580 Book service and repair Booster cushions 71 Brake assist after collision 417

Brake fluid	
grade	645
Brake functions	408
Brake light	163
Brakes anti-lock brakes, ABS	409 409
automatic when stationary Brake Assist System, BAS brake lights brake system emergency brake lights handbrake Maintenance on salted roads	415 410 163 408 163 411 411
on wet roads	410
brake system fluid	645
Camera sensor	342
Camera unit	329
Capacity weight	556, 641
Cargo compartment attachment points	564 567

cargo net

	electrical outl Lighting	et			560,	562 166
Са	rgo compartm	ent cover			567,	568
car	go net					571
Са	r wash	620, 621,	623,	624,	625,	626
Ca	talytic convert	er				445
	recovery					453
CD	player					489
Се	II phone, see F	Phone				499
Се	nter console					559
Се	nter display					
	change appea	arance				133
	cleaning					615
	climate contro	ols				217
	Function view	/				124
	keyboard					128
	messages			142,	143,	144
	operation		114,	117,	121,	126
	overview					111
	settings			134,	135,	136
	switch off and	d change vo	olume)		133
	symbols in sta	atus bar				126
	views					117
Се	ntral locking					255
Ch	ange of owne	r				136
Ch	anging a whee	el				542
Ch	ecking engine	oil level				589

Child restraints booster cushions convertible seats infant seats integrated booster cushion ISOFIX/LATCH anchors lower attachment points	63, 65 71 69 67 76 74 74
recalls and registration	65
top tether anchors	72
Child safety	63
Child safety locks	257
City Safety 333, 334, 336	, 337, 342, 344
City Safety in crossing traffic	339, 340
City Safety when evasive maneu ted	ver preven- 341
Cleaning automatic car wash	617, 619, 620 623
car wash 620, 621, 623 center display Seat belts	, 624, 625, 626 615 617
textile upholstery upholstery 615, 617 wheels	615, 617, 618 , 618, 619, 620 626
Cleaning wheels	626
Cleaning wiper blades	624
Clean Zone	209
Clean Zone Interior Package	210

Climate	206
auto-regulation	223
blower control	228, 229
perceived temperature	207
Sensors	207
temperature control	230, 231, 232
voice control	208
zones	206
Climate controls	217
center display	217
rear seat	217
Climate system	206, 217
Refrigerant	646
repairs	586
Clock, setting	94
Collision	42, 47, 52, 61
Collision warner	
detection of pedestrians	337
radar sensor	324
Collision warning	333, 345
Color code, paintwork	628
Color codes	628
Compass	459, 460
calibration	460
Condensation in headlights	621, 623,
S	624, 625

Connecting vehicle to Internet	
No connection or poor conr	
via a mobile device (WiFi)	509
via mobile device (Bluetooth	*
via vehicle's modem	510
Connect phone	499
Contact information	26
Convertible seats	69
coolant	645
Coolant, filling	590
Cooling system	
overheating	446
Cornering illumination	162
Corner Traction Control	272
Corrosion protection	626
Covering	
cargo compartment	568
Crash, see Collision	42
Crash event data	33
Cross Traffic Alert - CTA 35	1, 352, 353, 354
Cruise control	284, 285
manage speed	285, 286
temporary deactivation	287, 288
turn off	288
CTA - Cross Traffic Alert 35	1, 352, 353, 354
Curb weight	641

CZIP (Clean Zone Interior Packa	age) 210	power folding resetting	175 175	E	
		Driveline		ECO climate	426
D		transmission	417	ECO mode activate with function button	426 428
Data recording	33	Drive mode changing Driver Alert Control	423 425 360	Economical driving Electrical outlet	426, 438 560
transferring between vehicle shop	and work- 578	operation	361, 362	use	562
Data sharing	514	Driver Alert Control limitations	362	Electrical system	598
Daytime running lights	156	Driver performance	92, 93	Electric parking brake	411
Decals		Driver profile	139	Electronic immobilizer	250
location of	636	edit	141	emergency brake lights	163
Defrosting	225	select	140	Emission inspection readiness	576
Detection of cyclist	337	Driver support system	270	Engine	
Dimensions	639	Driving	446	overheating	446
Dipstick, electronic	588	cooling system with a trailer	449	start Start/Stop	404 428
Direction of rotation	530	Driving economy	438	turn off	406
Disengaging the shiftlock	421	Driving through standing water	441	Engine braking, automatic	437
Display lighting	167	driving with a trailer		Engine compartment	
Distance Alert limitations	289, 290, 291 292	towball load towing capacity	642 642	coolant engine oil	590 587
DivX®	490			overview	587
Door mirrors	173, 175			Engine drag control	272
compass	459, 460			Engine oil	587
dimming outer	174 173, 175			filling	588

filter	587	Four-C	432	Fuses	
grade and volume	644	Front seat		below the glove compartment	608
Engine shutdown	406	blower	228	general	603
Engine specifications	643	climate	217	in engine compartment	605 611
Engine temperature high	446	heating temperature ventilation	219, 220 230 221	in the cargo compartment replacing	604
Environment	27	Front seat manual	188		
Error messages Adaptive Cruise Control see Messages and symbols	307 307, 322	Front seats, power adjusting passenger seat fi	189	Gasoline grade	442
0 ,	,	seat	195	Gauge	112
Error messages in BLIS	350	adjusting seat	189	fuel gauge	89
Ethanol content max. 10% by volume	442	Lumbar support massage	194 192, 193	Gear indicator	422
Exterior dimensions	639	memory function	190, 191	Gear selector positions	
Exterior diffierisions	039	multifunction control	192, 193, 194	automatic transmission	418
		Side bolsters	194	Glass	
F		FSC, environmental labeling	23	laminated/reinforced	170
<u> </u>		Fuel	442	Glove compartment	563
Federal Clean Air Act	576	Travel Link service	483	Gracenote®	489
Ferry transport	432	Fuel filling	442	Grocery bag holders	566
Flat tire	550	Fuel gauge	89	Gross vehicle weight	641
Flooded road	441	Fuel requirements	442, 443	GSI - Gear shift indicator	422
Fluids, volumes	632, 646	Fuel tank		Guide lines for Park Assist Camera	386
Fluids and oils	645, 646	volume	646	adide lines for Fark 76515t Gamera	000
Fog lights		Fuse box	603		
front	161				
rear	162				

H		Hill Start Assist	416	Inflatable curtain	60
Handbrake	411, 412	Hill Start Assist (HSA)	416	Inflatable Curtain	60
		Hoisting the vehicle	583	Inflating tires	555
Hand wash	621	HomeLink®	456	Inflation pressure	
Hard disk		programming	457	adjusting	536
space	516	use	458	Checking	535
Hazard warning flashers	164	HomeLink® remote control		recommended	537
HDC	437	programmable	456	Inflation pressure monitoring	537
HD radio	472	Home safe lighting	164	action	541
Headlights		Honk	203	Status	540
cover	593	Hood, opening	585	Inflation pressure table	647
Head restraint	198	Horn	203	Information display	84, 88
Head-up display	144			Infotainment (Audio and media)	464
activate and deactivate	146			Instrument cluster	84
cleaning	616	1		settings	88
replacing windshield	586	IAQS (Interior Air Quality System)	210	Instrument illumination	167
settings	146			Instrument lighting	167
Heated washer nozzles	181	IC (Inflatable Curtain)	60	Instrument panel	
Heating		ID, Volvo	26	App menu	104, 105
Seats	219, 220	Identification number	38	messages	106
steering wheel windows	222, 223 226, 227	Ignition mode	407, 408	Instruments and controls	82
	,	Immobilizer	250	Instruments overview	
Height adjustment	432, 435	Electronic immobilizer	250	left-hand drive vehicle	82
high beams	158, 159	Indicator symbols	95	Integrated booster cushion	76
High engine temperature	446	Individual drive mode	423	folding down	78
Hill Descent Control activate with function button	436, 437, 438 438	Infant seats	67	folding up	77

		l
IntelliSafe driver support	28	Keyless locking/unlocking
Interior Air Quality System	210	settings
, ,	180	touch-sensitive surfac
Intermittent wiping		Key tag
Internet, see Internet-connected vehic		, 0
Internet-connected vehicle	507	
book service and repair	580	1
No connection or poor connection	512	-
send car data	582 579	Labels
system updates		location of
iPod®, connecting	492	Laminated glass
ISOFIX/LATCH anchors	74	Lamps
		changing
		location
J		specifications
	F 40	Trailer
Jack	543	Lane Keeping Aid
Jump-start	447	operation
		Lane Keeping Aid (LKA)
K		Language
Key	237	Leather upholstery, clean
Keyboard	128, 131	Leveling control
change language	131	settings
		License agreement

settings		254
touch-sensitive surface	es .	251
Key tag		237
L		
Labels		
location of		636
Laminated glass		170
Lamps		
changing		591
location		594
specifications		597
Trailer		452
Lane Keeping Aid		
operation		365
Lane Keeping Aid (LKA)	362, 364, 365	,
	367,	369
Language		134
Leather upholstery, cleaning	ng instructions	618
Leveling control		432
settings		435
License agreement	98,	517
Lifting tools		543

ight bulbs, specifications			597
ight control		154,	167
ighting			
Active Bending Lights			161
approach lighting			164
automatic high beam			159
automatic lighting controls,	passen	ger	
compartment			165
brake lights			163
controls	154,	165,	167
cornering illumination			162
daytime running lights			156
display lighting			167
emergency brake lights			163
front fog lights			161
Hazard warning flashers			164
high beams		158,	159
home safe lighting			164
in passenger compartment		165,	167
instrument illumination			167
instrument lighting			167
light bulbs, specifications			597
light locations			594
low beams			157
position lights			156
rear fog light			162
settings			155
Turn signals			160
•			

Lighting, replacing bulbs	591
daytime running lights/front parkir	0
lights	596
front turn signals	597
high beams	595
low beams remove plastic cover	595 593
removing rectangular cover	593
Limp home	417
'	
Load anchoring eyelets cargo compartment	567
Load anchoring hooks	566
Load carriers	566
Load index	532
Loading	
general	564
load anchoring eyelets	567
long load	565
Lock indication	236
setting	237
Locking/unlocking	
Tailgate	241, 254
Locking wheel bolts	543
Locks	
Locking	239
unlocking	239

Low battery charge level	
start battery	447
Low beams	157
Lower the rear end	565
Low oil level	588
Low-speed driving	435
activate with function button	436

M

Maintenance	576
corrosion protection	626
Max. axle weight	641
Max. roof load	641
Media player compatible file formats voice control	485, 486, 487 514, 515 150
Messages and symbols Adaptive Cruise Control Collision warner with auto-bra	307 ake 344
Messages in BLIS	350
Messages in display handling saved	106, 142 107, 143 109, 144
Mileage	89

Misting	
condensation in headlights	620, 623
Mood lighting	166, 167

N

Net	
cargo compartment	571

Occupant safety	43
Occupant weight sensor	56
Octane rating	443
Oil, see also Engine oil	644
On-board diagnostics	576
On-board Diagnostic socket	36
Option/accessory	21
Outside temperature gauge	94
Overheating	446, 449
Owner's information	16
OWNER'S MANUAL	21
environmental labeling	23
in cellular phone	20
in the center display	17, 18

P

eel	203
	628
touch-up	627, 628
g	177
	170
	176, 179
	178
ot 393, 394	, 397, 400, 401
,	/
389,	391, 392
	389
nitations	389
393, 394, 397	, 398,
	400, 401
393, 394, 398,	400, 401
	398
	394, 397
ages	401
93, 394	, 397,
398,	400, 401
	414
	touch-up 9 ot 393, 394 398, 384, 385, 386 389, nitations 393, 394, 397 393, 394, 398, ages 393, 394, 394

Parking Assist function	379, 380,		382, 380,	
Parking brake activate and deact automatic activatio Low battery charge	n			411 412 413 414
Passenger compartme	ent filter			211
Passenger compartment center console electrical outlet glove compartment sun visor				558 559 560 563 564
Passenger compartme	ent lighting		165,	167 165
Passing assistance		302,	303,	319
personal information (Privacy Po	licy)		34
Phone changing to another connect connect automatic connect manually delete disconnect phone call text message			503,	504
voice control				149

Pilot Assist	309, 312, 313, 3 317, 319, 3	314, 315, 20, 321, 322
pass	011,010,0	319
pinch protect	tion	170 171
PIN code		511
Polishing		621
Position light	ts	156
Power		643
Power folding	g door mirrors	175
Power panor	amic roof	176
Power save r	mode	447
Power seats		189
Power tailgat	te	259
Power windo pinch pro		171, 172 170
Pressure was	sh	624
Privacy Policy	у	34
Private lockir activation	ng /deactivation	26 ² 265
PROPOSITIO	N 65 WARNING	447

R

Radar sensor	296, 324
limitations	325
Radar unit	324
Radio	468
changing radio waveband and ra	adio sta-
tion	469
HD radio	472
RBDS	472
search radio station	470
settings	471
	76, 477, 478
start	469
voice control	150
Radio favorites	471
Rain sensor	181, 182
Rain sensor's memory function	182
Raise the rear end	565
Rear camera 384, 385, 386, 38	88, 389,
	391, 392
Rear door	
sun shade	173
Rear seat	
adjusting backrest tilt	200
blower	229
climate	217
folding backrest	196, 202

getting in/getting head restraint heating moving forward/re temperature		1 2 1	20 · 198 220 198 23 ·
Rear sensors	379, 380, 381		
Rearview/door mirror dimming heating interior		1	74 227 73
Rearview mirror dimming			73 74
Rear window heating washers wipers		184, 1 184, 1	
Recalls			45
Recommendations w	hen driving	4	139
Recommendations w	hen loading	5	6
Recovery		4	155
Red Key settings			246 247
Refrigerant climate system			586 646
Refueling filling fuel filler door, fue	el flap		142 141

Remote immobilizer	250
Remote key battery replacement connecting to driver pro	237 242 file 141
detachable key blade	248
loss Range	246 241
Remote updates	579
Reporting safety defects	44
Resetting door mirrors	175
Resetting settings change of owner Driver profile	137 136 141
Resetting trip odometer	92
Road Sign Information limitations operation	355, 356, 357 359 356, 357, 358, 359
Road trip	439
Roll Stability Control	271
Roof load, max. weight	641
RSC (Roll Stability Control)	271
Run-off Mitigation	371, 372

Safety	42
pregnancy	43
Safety belt, see Seat belt	47
Safety defects, reporting	44
Safety mode	61
starting/moving	62
Sealing compound	550
Seat, see Seats	188
Seat belt reminder	51
Seat belts	47
Automatic locking retractor/Eme	ergency
locking retractor	65
buckling/unbuckling	48
pregnancy	43
seat belt reminder	51
seat belt tensioner	50
securing child restraint systems	67, 69, 71
Seat belt tensioner	50
resetting	51
Seats	
heating	219, 220
manual front seat	188
memory function front seat	190, 191
power front seats	189
ventilation	221
whiplash protection	46

Sensors	011
air quality climate	211 207
Sensus	201
connection and entertainmen	t 30
Sensus Navigation	357
Service position	631
Service program	576
Set time interval	291
settings Categories contextual resetting settings menu	137 138 135 137 137
Shiftlock	421
deactivate	421
Side airbag	60
Side Impact Protection System	60
SIM card	511
SIPS (Side Impact Protection Sys	stem) 60
Sirius Satellite radio Travel link	480
SiriusXM® Satellite radio traffic information	476, 477, 478
Slippery conditions	440
Slippery road conditions	440

Software updates			33
Sound settings phone		464,	505 506
playing media text message		486,	487 505
Spare tire		547,	548
Speed camera			359
Speed Limiter getting started shut down temporary deactiva	276, 279, tion	280,	283 277 279 278
Speed symbols, tires			532
Spin control			272
Stability and traction cooperation	ontrol system	272, 273,	
Stability system			272
Stains	615, 617, 618,	619,	620
Start/Stop deactivate Driving limitations			428 430 428 430
Start and lock system			
type designations			250
Start battery overload		447,	598 447
Start engine			404

Starting the engine		Sunroof		Temperature	
after a collision	62	pinch protection	170	adjusting	230, 231, 232
Start the vehicle	404	Sun shade		perceived	207
Steel cargo grid	570	panoramic roof	176, 179	Temporary spare	
Steering assistance at risk of colli	-	pinch protection	170	spare tire	547
sion 370, 371, 372, 373, 374, 3	375, 376, 378	rear door	173	Temporary tire sealing system	
Steering assistance at risk of rear	end col-	Sun visor	564	execution, checking	551
lision	375, 376	mirror lighting	166	Inflating tires	555 550
Steering power level, see Steering	g wheel	Support battery	601	overview	550
resistance	270	Symbols		sealing compound	550
Steering resistance at risk of head	d-on colli-	indicator symbols	95	Terms and conditions	
sion	373, 374	Symbols and messages		services	34
Steering wheel	203	Adaptive Cruise Control	307	users	514
heating	222, 223	center display's status bar Collision warner with auto-brake	126 344	Tire dimensions	532, 542
keypad	203			Tire pressure decal	537
paddle	203	Symbols and messages for Assistant risk of collision	e at 378	Tire pressure monitoring	00.
steering wheel adjustment	203			calibrating	539
Steering wheel keypad	203	system updates	579	Tires	528
Steering wheel paddles	419			direction of rotation	530
Steering wheel resistance, speed-	-depend-	т		glossary of terms	531
ent	270	1		inflation pressure table	647
Stone chips and scratches	627, 628	Tailgate		mounting	546
Stop/start function	428	locking/unlocking	241, 254	pressure	647
Storage compartments	558	open/close with foot movement	263	removal	544
center console	559	power	259	rotation specifications	529 532, 647
glove compartment	563	unlocking from inside	257	storage	528
sun visor	564	Technician certification	37	tire pressure monitoring	537

tire sealing	550
Tread depth	549
tread wear indicator	531
winter tires	549
Tire sealing system	551
Tire tread	531
Tools	542
Top tether anchors (child restraint sys	5-
tems)	72
Total airing function	237, 255
Towbar	448
removable, attaching, installing, mo	ount-
ing	448
removable, removing, detaching	448
Towing	453
Towing capacity and towball load	642
Towing eyelet	454
TPMS - Tire Pressure Monitoring Sys	tem 537
Traction control	272
Traffic information	471
Trailer	451
driving with a trailer	449
Lamps	452
swaying	451
Trailer Stability Assist	451
trailer	451

Trailer stabilizer	272
Trailer towing trailer hitch	448
Transmission automatic	417 418
Transmission fluid grade	645
Travel Link Fuel Notifications Sports weather	480 483 482 484 481
Tread depth	531, 549
Tread wear indicator	531
Trip computer	89, 91
Trip odometer	89
Trip odometer resetting	92
Trip statistics	92
Troubleshooting Adaptive Cruise Control	305
Troubleshooting the camera sensor	330
TSA - Trailer Stability Assist	272, 451
Tunnel detection	157
Turn off engine	406
Turn signals	160

Type approval radar system		
U		
Uniform Tire Qu	uality Grading	534
Units		134
Unknown vehic	le component	268
Unlocking settings with key bla USB socket for c	de onnecting media	240 249 492
Vehicle care leather upho	620, 621, 623, 624 olstery	, 625, 626 618
Vehicle Event D	ata	33
Vehicle function in the cente		124
Vehicle key hat	low	242

Vehicle modem

settings

Vehicle recovery

connecting vehicle to Internet

Vehicle status inflation pressure		80 40	parking brake applied seat belt reminder	97 97	Wheels and tires Load index and speed symbol	532
Vehicle upholstery	615, 617, 618, 619, 62	20	starter battery not charging	97	Whiplash protection	46
Vehicle weight	64	41	WARNING	97	Whiplash Protection System	46
Ventilation Seats	212, 2 ⁻ 22	13 21	Warning sound parking brake	414	WHIPS (Whiplash Protection System) Wi-Fi	46
Video settings	490, 49 49	92 91	warning symbols Warning symbols	97	connecting vehicle to Internet delete network	509 513
Voice control	14	47	safety	42	sharing Internet connection, tethering	0.
climate phone		08 49	Warranties Washer	576	hotspot technology and security	511 513
radio and media settings		50 50	Headlights rear window	183 184, 185	Window sun shade	173
VOL mark		28	washer fluid, filling Windshield	632 183	Windows and glass	170
Volvo ID create and registe		26 27	Washer fluid Washer nozzles, heated	632 181	Windshield heating projected image	226 144, 146
			Waxing Waxing	621	Windshield washing	183
Warring light		_	Weights Curb weight	641	Windshield wipers rain sensor	180 181, 182
Warning light Adaptive Cruise Constability and traction		96 72	Wheel bolts locking	543 543	Winter driving Winter tires	440 549
Warning lights airbags SRS	,	97	Wheels cleaning mounting	626 546	Winter wheels Wiper blade	549
alternator does no brake system error low oil pressure	. (97 97 97	removal Snow chains	544 549	replacing 6 service position	629, 630 631

