

S-Class

Operator's Manual



Symbols

Registered trademarks:

- BabySmart[™] is a registered trademark of the Siemens Automotive Corp.
- Bluetooth® is a registered trademark of the Bluetooth SIG Inc.
- DTS is a registered trademark of DTS, Inc.
- Dolby and MLP are registered trademarks of Dolby Laboratories.
- ESP® and PRE-SAFE® are registered trademarks of Daimler AG.
- HomeLink[®] is a registered trademark of Prince, a Johnson Controls Company.
- iPod® and iTunes® are registered trademarks of Apple Inc., registered in the USA and in other countries.
- Logic 7[®] is a registered trademark of Harman International Industries. Incorporated.
- Microsoft[®] is a registered trademark of the Microsoft Corporation in the USA and in other countries.
- SIRIUS and associated brands are registered trademarks of SIRIUS XM Radio
- HD Radio and associated brands are registered trademarks of the iBiquity Digital Corporation.
- Windows Media[®] is a registered trademark of the Microsoft Corporation in the USA and in other countries.
- Gracenote® is a registered trademark of Gracenote, Inc.
- ZagatSurvey[®] and associated brands are registered trademarks of Zagat.

In this Operator's Manual, you will find the following symbols:

↑ WARNING

Warning notes draw your attention to hazards that endanger your health or life, or the health or life of others.

- These warning notes draw your attention to hazards that could cause damage to your vehicle.
- 1 This symbol indicates useful instructions or further information that could be helpful to you.
- This symbol designates an instruction you must follow.
- Several consecutive symbols indicate an instruction with several
- ▶ Page This symbol tells you where you can find further information on a topic.
- $\triangleright \triangleright$ This symbol indicates a warning or an instruction that is continued on the next page.
- Display This font indicates a display message in the multifunction display/COMAND display.

Parts of the software in the vehicle are subject to copyright according to © 2005 The FreeType Project http://www.freetype.org. All rights reserved.



Welcome to the world of Mercedes-Benz

Before you drive off, please familiarize yourself with your vehicle and read this manual, especially the safety and warning notes. This will help you to obtain the maximum pleasure from your vehicle and avoid endangering yourself and others.

The equipment or model designation of your vehicle may differ according to:

- model
- order
- · country variant
- availability

Mercedes-Benz is constantly updating its vehicles to the state of the art.

Mercedes-Benz therefore reserves the right to introduce changes in the following areas:

- design
- · equipment
- · technical features

Therefore, you cannot base any claims on the illustrations or text content in this Operator's Manual.

The following are integral components of the vehicle:

- · Operator's Manual
- Service Booklet
- Equipment-dependent supplements

Keep these documents in the vehicle at all times. When you sell the vehicle, always pass the documents on to the new owner.

The technical documentation team at Daimler AG wishes you safe and pleasant motoring.

Mercedes-Benz USA, LLC

Mercedes-Benz Canada, Inc.

A Daimler Company



Index 4	At a glance 33
Introduction	Safety
	Opening/closing 77
	Seats, steering wheel and mirrors 101
	COMAND 115
	Lights and windshield wipers 275
	Climate control
	Driving and parking 301
	On-board computer and displays 371
	Stowing and features 431

Maintenance and care 455

Breakdown assistance 471

Wheels and tires 489

Technical data 519



1, 2, 3	Adaptive Highbeam Assist
115 V socket 442	Display message 404
12 V socket	Function/notes 280
see Sockets	Switching on/off (on-board
	computer) 386
4ETS	Additional speedometer 386
see ETS/4ETS (Electronic	Additives (engine oil) 528
Traction System)	Address
4MATIC (permanent four-wheel	Entering (example) 153
drive)	see Address book
4MATIC off-road system 346	Address book
	Calling up 205
A	Connecting a call 208
ABC	Creating an entry 206
see Active Body Control (ABC)	Deleting an entry 207
ABS (Anti-lock Braking System)	Entering characters 132
Display message	Entry as a home address 178
Function/notes 69	Importing contacts 204
Important safety notes	Introduction 203
Warning lamp 423	Starting route guidance 208
Activating/deactivating cooling	Voice tag 208
with air dehumidification	Air bags
Active Blind Spot Assist	Display message 399
Activating/deactivating (on-	Front air bag (driver, front
board computer)	passenger) 48
Function/information 364	Important safety notes 46
Active Body Control (ABC)	PASSENGER AIRBAG OFF
Display message	indicator lamp 50
Function/notes	Safety guidelines 45
Active Driving Assistance package . 363	Side impact air bag 48
Active Lane Keeping Assist	Window curtain air bag 49
Activating/deactivating (on-	Air-conditioning system
board computer)	see Climate control
Display message 411	Air distribution
Function/information	Setting 295
Active Light System	Setting (COMAND) 266
Display message	Air filter (display message) 408
Active multicontour seat 108, 272	Airflow
Active service system PLUS	Setting 295
see ASSYST PLUS service interval	Setting (COMAND) 266
display	AIRMATIC
ADAPTIVE BRAKE 73	Display message 409
Adaptive Damping System (ADS) 344	Function/notes 343
	Air pressure
	see Tire pressure
	Air vents
	Glove box 299
	lmportant safety notes 298

Rear 29	99 A u	thorized Mercedes-Benz Center	
Setting 29	98	see Qualified specialist workshop	
Setting the center air vents 29	98 AL	JTO lights	
Setting the side air vents	9	Display message	403
Alarm system		see Lights	
see ATA (Anti-Theft Alarm system)	Αu	tomatic engine start (ECO start/	
Alertness Assistant		op function)	307
see ATTENTION ASSIST		tomatic engine switch-off (ECO	
Alternative route 17		art/stop function)	307
Ambient light setting (COMAND) 26		tomatic headlamp mode	277
AMG menu (on-board computer) 37		tomatic transmission	
Anti-lock Braking System		Automatic drive program	314
see ABS (Anti-lock Braking System)		Changing gear	
Anti-Theft Alarm system		DIRECT SELECT lever	
see ATA (Anti-Theft Alarm system)		Display message	417
Anti-theft system		Driving tips	
ATA (Anti-Theft Alarm system)	75	Emergency running mode	
Ashtray 44		Kickdown	
Assistance menu (on-board		Manual drive program	
computer) 38	33	Problem (malfunction)	
ASSYST PLUS		Program selector button	
see ASSYST PLUS service interval		Pulling away	305
display		Shift ranges	
ATA (Anti-Theft Alarm system)		Starting the engine	305
	75	Steering wheel paddle shifters	314
Function 7	75	Transmission position display	312
Switching off the alarm		Transmission positions	312
ATTENTION ASSIST		tomatic transmission	
Activating/deactivating 38	34 e n	nergency mode	317
Display message 40		tostore	213
Function/notes 35	56	see Station memory (radio)	
Audio	Αl	JX (audio)	
Radio mode 2	11	Notes/socket	239
Audio database		Switching to	239
see MUSIC REGISTER	Αl	JX (video)	
Audio DVD		Setting the picture	240
Mode, switching to 22	21	Setting the volume and sound	246
Pause function 22	23	Showing/hiding the menu	246
Playback options 22	28	Switching to	246
Safety notes 22	20		
Setting the audio format 22	27 B		
Stop function 22	23	ck button	119
Audio format, setting			113
Audio DVD 22	27 Ба	see Lumbar support	
Rear Seat Entertainment System 25	58		125
Video DVD 24		g hook	
Audio menu (on-board computer) 37		lance, adjustingdispersions	
	ра	nie a Diuisen suuna system	10/



BAS (Brake Assist System)	70	Brake Assist System	
Basic settings		see BAS (Brake Assist System)	
see Settings		Brake fluid	
BAS PLUS (Brake Assist System		Display message	396
PLUS)	70	Notes	528
Bass, setting	135	Brake fluid level	461
Battery (SmartKey)		Brake lamps	
Checking	82	Display message	402
Important safety notes	82	Brakes	
Replacing	82	ABS	69
Battery (vehicle)		BAS	70
Charging	480	BAS PLUS	
Display message		Brake fluid (notes)	528
Important safety notes		1) 0	389
Jump starting	481	1 1 10 11	327
Belt		0 1	329
see Seat belts		Important safety notes	327
Bird's-eye view (navigation)	184	Maintenance	328
Blind		Warning lamp	422
see Roller sunblind		Breakdown	
Blind Spot Assist		see Flat tire	
Activating/deactivating	385	see Towing away	
/	360	Breakdown assistance	
see Active Blind Spot Assist		see Mercedes-Benz Contact	
	527	Brightness, setting (TV, video)	240
Bluetooth®		Bulbs	
Activating/deactivating	147	see Changing bulbs	
Authorizing a device (registering)	148		
Conditions (general)	147	C	
Conditions (telephone)	195	California	
Connecting another mobile phone .	197	Important notice for retail	
	147	customers and lessees	29
De-authorizing (de-registering) a		Call	۷,
	149	Accepting/ending/rejecting	100
External authorization (general)	149	see Telephone	177
External authorization (telephone) .	197	Calling up a malfunction	
General information	147	see Display messages	
	193	· · ·	201
Receiving vCards	204	Call lists	201
Searching for devices	148		205
Settings	147	. , .	209
Telephone basic menu	198		209
Telephony	195	Opening and selecting an entry Saving an entry in the address	209
Telephony notes	193	-	210
Bluetooth® interface		book Capacities	210
Telephony	193		
• •		see Technical data	



Car		Removing/ejecting (Rear Seat	
see Vehicle		Entertainment System)	251
Care		Safety notes	220
Carpets	469	Selecting a media type	224
Car wash		Selecting a track	224
Display		Sound settings (balance, bass,	
Exterior lights		fader, treble)	135
Gear or selector lever		Cell phone	
Matte finish		see Mobile phone	
Night View Assist Plus		Center console	38
Notes		Central locking	
Paint		Automatic locking feature	
Plastic trim		(COMAND)	264
Power washer		Locking/unlocking (SmartKey)	
Rear view camera		Changing batteries (remote	. , 0
Roof lining		control, headphones)	247
Seat belt		Changing bulbs	217
Seat cover		High-beam headlamps (vehicles	
Sensors		with halogen daytime running	
Steering wheel		lamps)	284
Tail pipes		High-beam headlamps (vehicles	207
Trim pieces		with LED daylight lamps)	284
Washing by hand		Important safety notes	282
Wheels		Overview of bulb types	283
Windows		Changing direction	200
Wiper blades		Announcement phase	166
Wooden trim		Change of direction phase	167
Cargo tie down rings		Preparation phase	166
Car pool lanes		Character bar	129
Car wash (care)		Characters	129
Category	+00		130
Satellite radio	210	Entering Entering (address book, phone	130
CD	210		122
	220	book)	132
Copy protection		Entering (navigation)	129
Fast forward/fast rewind		Child-proof locks	4.4
General information		Important safety notes Rear doors	
Inserting (loading (Boar Seet	220	Children	. 07
Inserting/loading (Rear Seat	25.1		40
Entertainment System)		In the vehicle	
Mode, switching to		Restraint systems	. 62
Multisession		Child seat	
Notes on discs	229	LATCH-type (ISOFIX) child seat	
Operating the player/changer	070	anchors	
(on-board computer)		Special seat belt retractor	
Pause function		Top Tether	
Playback options	228	Cigarette lighter	440
Player/changer operation			
(COMAND)	220		

Olimeta control		Menu overview	101
Climate control	201		
	291	Remote control	125
	265	Switching on/off	133
Controlling automatically		System settings	143
Controlling centrally (COMAND)		COMAND controller	118
Cooling with air dehumidification	293	COMAND display	
Cooling with air dehumidification		Cleaning instructions	
(COMAND)	267	Folding in and swiveling	124
Defrosting the windows	296	Setting	143
Defrosting the windshield	296	COMAND operating system	118
Important safety notes	290	Combination switch	279
Indicator lamp	293	Compass function	188
Main menu		Conference connection	201
Maximum cooling	296	Consumption statistics (on-board	
Overview of systems	290	computer)	376
Problems with cooling with air		Contrast, setting (TV, video)	240
dehumidification	293	Convenience closing feature	
Problem with the rear window		Convenience opening feature	
defroster	297	Convenience telephone	
Rear compartment (COMAND)	268	Importing contacts	204
Rear control panel	291	Convenience telephony	
Refrigerant	528	Introduction	193
Setting the air distribution	295	Coolant (engine)	
Setting the airflow	295	Checking the level	460
Setting the airflow (COMAND)		Display message	
Setting the air vents	298	Notes	
Setting the footwell temperature		Temperature (on-board computer) .	
(COMAND)	268	Temperature gauge	
Setting the temperature	294	Cooling	0, _
Switching air-recirculation mode		see Climate control	
on/off	297	Copy protection (CD/DVD)	229
Switching on/off	292	Cornering light function	/
Switching residual heat on/off	298	Display message	401
Switching the rear window		Function/notes	
heating on/off	297	Cruise control	200
Coat hooks		Cruise control lever	331
Cockpit		Deactivating	
Overview	. 34	Display message	
see Instrument cluster		Driving system	
Color, setting (TV, video)	240	Function/notes	
COMAND			
At a glance (overview)	118	Important safety notesLIM indicator lamp	
Back button	119	Setting a speed	
Basic functions	133	Storing and maintaining current	332
Components	118		331
Display	121	speed	551
Example of operation	128		
Function buttons	119		
e anotion bactorio	Information	on Provided by:	
	9 =	ROCESS	

Cup holder		Destination memory (navigation)	
Center console	437	Deleting an entry	181
Important safety notes	437	Entering/saving your home	
Rear compartment	437	address	156
Customer Assistance Center (CAC)		Previous destinations	181
Customer Relations Department		Dialing a number (telephone)	200
•		Digital speedometer	376
D		Digital TV	
Dashboard		see TV	
see Cockpit		DIRECT SELECT lever	
Data		see Automatic transmission	
see Technical data		Display	
Data carrier		Selecting the design	143
MUSIC REGISTER	230	Settings	143
Data medium	250	Display (cleaning instructions)	467
Audio DVD	228	Displaying the arrival time	172
CD/DVD		Displaying the distance to the	
MP3		destination	172
Date format, setting		Display messages	
		Calling up (on-board computer)	388
Day design, setting	143	Driving systems	408
Daytime running lamp mode		Engine	404
see Daytime running lamps		General notes	388
Daytime running lamps	403	Hiding (on-board computer)	388
Display message	403	Lights	401
Switching on/off (on-board	205	Safety systems	389
computer)		Service interval display	462
Switching on/off (switch) DEF	2//	SmartKey	419
	221	Tires	415
Adding		Vehicle	417
Display message	408	Distance	
Delayed switch-off	262	see Navigation, route overview	
Exterior lighting (COMAND)		Distance display (on-board	
Interior lighting (COMAND)	203	computer)	383
Destination (navigation)	170	Distance recorder	376
Displaying information	172	see Odometer	
Entering a destination by address	153	see Trip odometer	
Entering a destination using the	140	Distance warning (warning lamp)	428
map	160	DISTRONIC PLUS	
Entering an intermediate stop	161	Deactivating	340
Entering a point of interest	162	Display message	413
Saving	179	Displays in the multifunction	
Selecting from the destination	150	display	339
memory	159	Driving tips	340
Selecting from the list of last	150	Function/notes	332
destinations	159	Important safety notes	



Setting the specified minimum	Active Driving Assistance	
distance 338		363
Warning lamp 428	Active Lane Keeping Assist 3	367
Dolby Digital 136	AIRMATIC	343
Doors	ATTENTION ASSIST	356
Automatic locking (switch) 86	Blind Spot Assist	360
Central locking/unlocking	Cruise control	330
(SmartKey) 78	Display message	408
Control panel 40	DISTRONIC PLUS	332
Display message 418	Driving Assistance package 3	360
Emergency locking 88	HOLD function	342
Emergency unlocking 87	Lane Keeping Assist	362
Important safety notes 85	Night View Assist Plus	357
Opening (from inside) 86		350
Power closing feature 87		347
Drinking and driving 326	Rear view camera	354
Drinks holder	Driving tips	
see Cup holder	Automatic transmission 3	313
Drive program	Brakes 3	327
Automatic 314	Break-in period	302
Manual 316	DISTRONIC PLUS 3	340
Driver's door	Downhill gradient	327
see Doors	Drinking and driving	326
Driver's seat		276
see Seats		330
Driving abroad	Driving on flooded roads 3	329
Mercedes-Benz Service 463	Driving on wet roads	329
Symmetrical low beam 276	Exhaust check	327
Driving Assistance package 360	Fuel 3	326
Driving safety systems		326
ABS (Anti-lock Braking System) 69	Hydroplaning	329
ADAPTIVE BRAKE 73	Icy road surfaces	330
BAS (Brake Assist System) 70	Limited braking efficiency on	
BAS PLUS (Brake Assist System	salted roads	328
PLUS) 70	Pedals	326
Electronic brake force distribution 73	Snow chains	493
ESP® (Electronic Stability	Symmetrical low beam	276
Program) 71	Wet road surface	327
ETS/4ETS (Electronic Traction	DVD	
System) 72	Changer 2	220
Important safety information 69	Copy protection	229
Overview	Fast forward/fast rewind	225
PRE-SAFE® Brake 73	Handling	189
Driving systems		220
Active Blind Spot Assist 364	Landia (Landia (Dana Cant	
Active Body Control		251
200, 20		229



Removing/ejecting (Rear Seat	Engine	
Entertainment System) 251	Check Engine warning lamp	427
Selecting a media type 224	Display message	
Selecting a track 224	ECO start/stop function	
Sound settings (balance, bass,	Emergency starting	485
fader, treble)	Engine number	
DVD audio	Irregular running	
Operation using the on-board	Starting problems	309
computer 379	Starting the engine with the	
·	SmartKey	305
E	Starting with KEYLESS-GO	305
EAOV ENTRY (Switching off	323
EASY-ENTRY feature	Engine electronics	
Activating (COMAND)	Problem (malfunction)	309
Function/notes 110	Engine emergency stop	487
EASY-EXIT feature	Engine oil	
Activating (COMAND)	Adding	459
Crash-responsive	Additives	
Function/notes	Checking the oil level	457
EBD (electronic brake force	Checking the oil level using the	
distribution)	dipstick	458
Display message	Checking the oil level using the	
Function/notes	on-board computer	458
ECO function	Display message	406
ECO start/stop function	Filling capacity	524
Deactivating/activating	Notes about oil grades	527
General information	Notes on oil level/consumption	457
Electrical fuses	Temperature (on-board computer) .	379
see Fuses Electronic brake force distribution	Viscosity	528
	Entering the frequency	212
see EBD (electronic brake force	Entry	
distribution)	Deleting	131
Electronic Stability Program	Saving	133
see ESP® (Electronic Stability Program)	ESP® (Electronic Stability	
Electronic Traction System	Program)	
see ETS/4ETS (Electronic	Deactivating/activating	384
Traction System)	Deactivating/activating (notes)	72
Emergency release	Display message	389
Driver's door	ETS/4ETS	72
Trunk 91, 92	Function/notes	
Vehicle	Important safety information	71
Emergency spare wheel	Warning lamp	424
Storage location	ETS/4ETS (Electronic Traction	
Emergency Tensioning Devices	System)	
Function	Exhaust check	327
Safety guidelines	Exhaust tail pipe (cleaning	
Emissions purification Service and warranty information 28	instructions)	467



Exterior lighting		Fuel	
see Exterior lighting		Additives	526
Exterior mirror parking position		Displaying the current	
Adjusting (COMAND)	262	consumption	376
Exterior mirrors		Displaying the range	376
Adjusting	111	Driving tips	
Dipping (automatic)	112	Fuel gauge	
Folding in/out (automatically)	112	Important safety notes	525
Folding in/out (electrically)	112	Premium-grade unleaded gasoline .	525
Out of position (troubleshooting)	112	Problem (malfunction)	320
Storing settings (memory		Refueling	317
function)	113	Specifications	
Storing the parking position	113	Tank content/reserve fuel	
Eyeglasses compartment	433	Fuel filler flap, opening/closing	
Lycalusses compartment	400	Fuel filter (display message)	408
F		Fuel level	400
r		Calling up the range (on-board	
Factory setting (reset function)	150	computer)	376
Fader, setting	135	Fuel tank	3/0
Fast forward		Capacity	524
Audio mode (CD, DVD, MP3)	225		
Rear Seat Entertainment System	255	Problem (malfunction)	
Video DVD		Fuses	119
Fast rewind			104
Audio mode (CD, DVD, MP3)	225	Allocation chart	
Rear Seat Entertainment System	255	Before changing	
Video DVD		Dashboard fuse box	
Favorites (COMAND)	120	Engine emergency stop	487
Filler cap		Fuse box in the engine	407
see Fuel filler flap		compartment	487
First-aid kit	472	Fuse box in the rear compartment.	
Flat tire	–	Important safety notes	485
Changing a wheel/mounting the			
spare wheel	473	G	
MOExtended run-flat system	477	Garage door opener	
Preparing the vehicle	473	Clearing the memory	453
Raising the vehicle	474	Notes	450
Floormat		Opening/closing the garage door	
Freeway information		Programming (button in the rear-	100
Front fog lamps		view mirror)	451
	402	Gasoline	
Display message Switching on/off		Gear indicator (on-board	010
	2/0	computer)	379
Front-passenger seat	105	Gear or selector lever (cleaning	0/7
Adjusting from the driver's seat	105	guidelines)	468
Adjusting from the rear	105	Genuine Mercedes-Benz parts	520
compartment	105		
Front windshield		Glove box	
see Windshield		GPS reception	131
6		ALER	

Gracenote Media Database	226	HOLD function Display message Function/notes	
		Home	0 12
Handbrake		see Home address	
see Parking brake		Home address	
Harman/kardon® Logic 7®		Entering and saving	156
surround sound system		Selecting from the destination	
see Surround sound (harman/		memory	159
kardon® surround sound system)		Hood	
Hazard warning lamps		Closing	457
HD Radio™		Display message	418
Heading up (navigation)	184	Opening	456
Headlamp cleaning system		Hydroplaning	329
Notes	529		
Headlamps	4/4	1	
Adding fluid to cleaning system		Ignition lock	
Cleaning system (function)		see Key positions	
Fogging up	281	Immobilizer	75
see Automatic headlamp mode		Incident (traffic report)	
Headphones Changing batteries	217	Indicator lamps	17
Changing batteries Function overview	142	see Warning and indicator lamps	
Indicator lamp	143	Indicators	
Selecting a screen	142	see Turn signals	
Switching on/off	142	Insect protection on the radiator	457
Head restraints	172	Instrument cluster	
Adjusting	106	Overview	. 35
Adjusting (electrically)	106	Warning and indicator lamps	. 36
Adjusting (rear)	107	Instrument lighting	
NECK-PRO	106	see Instrument cluster lighting	
NECK-PRO luxury	106	Interface (USB, iPod®)	
see NECK-PRO head restraints/		see Media Interface	
NECK-PRO luxury head restraints		Interior lighting	
Heating		Ambient light (COMAND)	263
see Climate control		Automatic control	282
High-beam headlamps		Interior lighting	263
Changing bulbs (vehicles with		Manual control	282
halogen daytime running lamps)	284	Overview	281
Changing bulbs (vehicles with LED		Reading lamp	281
daylight lamps)	284	see Interior lighting	
Display message	402	Intermediate stop	
Switching Adaptive Highbeam		Deleting	162
Assist on/off		Entering	161
Switching on/off		iPod [®]	
Hill start assist	306	Alphabetical track selection Connecting to the Media	237
		Interface	234



Selecting a category/playlist 23	6 Lights	
Supported variants		277
	•	280
J		401
laak		276
Jack Storage leastion 47	Fog lamps	278
Storage location		279
Using		279
Jump starting (engine) 40	High-beam neadlamps	279
V	0	276
К		277
Key		276
see SmartKey	8 - 1	278
KEYLESS-GO	Switching Adaptive Highbeam	
Convenience closing feature 9		386
Locking 7		
Start/Stop button 30		
Starting the engine 30		385
Unlocking 7		
Key positions	lamps on/off (switch)	
KEYLESS-GO 30		279
SmartKey 30		
Kickdown	see Interior lighting	100
Driving tips		403
Manual drive program 31		331
	_	335
L		432
Lamps		264
see Warning and indicator lamps	Locking	204
Lane-change assistant	see Central locking	
see Blind Spot Assist	Locking (doors)	
Lane detection (automatic)	Automatic	86
see Lane Keeping Assist	Emergency locking	
Lane Keeping Assist	From inside (central locking	
Activating/deactivating 38	5 hutton)	86
Display message 41	1 Locking centrally	
Function/information	2 see Central locking	
Lap time (RACETIMER) 38	Uncking verification signal (on-	
LATCH-type (ISOFIX) child seat	board computer)	386
anchors 6	5 Logic 7 [®] (Harman Kardon [®]	
Letter bar	surround sound system)	
see Character bar	see 3D sound (Harman Kardon®	
License plate lamp (display	surround sound system)	
message)	2	
Lighting		
see Lights		



Low-beam headlamps		Display message	396
Display message	401	Downloading destinations	
Setting for driving abroad		(COMAND)	
(symmetrical)	276	Emergency call	444
Switching on/off	277	Important safety notes	443
Lubricant additives		Locating a stolen vehicle	450
see Additives		MB info call button	446
Lumbar support		Remote vehicle locking	449
Adjusting		Roadside Assistance button	
Lumbar support (COMAND)	269	Search & Send	
		Self-test	
M		System	
M+S tires	492	Vehicle remote unlocking	449
Maintenance	.,_	Mechanical key	
see ASSYST PLUS service interval		Function/notes	
display		Unlocking the driver's door	. 87
Malfunction message		Media Interface	000
see Display messages		Active partition	
Malfunctions relevant to safety		Alphabetical track selection	237
Reporting	. 31	Connecting an external audio	004
Map (navigation)		source	
Adjusting the scale	182	Connection options	
Arrival time/distance to the		iPod®	
destination	185	Mode	
City model		Notes on USB devices	
Display		Playback options	
Geo-coordinate display	186	Selecting categories	
Heading		Selecting folders	
Information in the display	185	Selecting music files	
Map settings	182	Selecting playlists	
Moving	183	Switching to	
North orientation	184	USB mass storage device	233
Notes	182	Media list	004
Point of interest symbols		Audio mode (CD, DVD, MP3)	
Road display	185	Video DVD	
Saving the crosshair position	183	Memory card (audio)	
Setting to the vehicle destination	183	Memory function	113
Topographical map	186	Menu item	407
Map display (also see navigation)		Selecting	126
Traffic reports	174	Message memory (on-board	000
Massage function (PULSE)		computer)	388
Matte finish (cleaning		Messages	
instructions)	465	see Display messages	001
mbrace		Microphone, switching on/off	201
Automatic retrieval of vehicle data			
(service due date)	449		
Call priority			



Mirrors		Playback options	233
see Exterior mirrors		Switching to	230
see Rear-view mirror	I	Music search	225
see Vanity mirror	I	Music storage	
Mobile phone		see MUSIC REGISTER	
Menu (on-board computer)	382 I	Mute	134
Modifying the programming			
(SmartKey)		N	
MOExtended run-flat system	477	Navigation	
MP3		Adjusting the volume of the	
Bit/sampling rates		navigation announcements	134
Copyright		Alternative route	171
Data medium		Basic settings	152
Fast forward/fast rewind		Blocking a route section affected	102
File systems		by a traffic jam	171
Formats		Compass function	188
Mode, switching to		Destination memory	178
Notes	228	Displaying destination	170
Operating	379	information (arrival time, distance	
Pause function		to destination)	172
Playback options		Entering/saving your home	1/2
Safety notes		address	156
Selecting a media type	224	Entering a destination	153
Selecting a track	224	Entering a destination by address	153
Sound settings (balance, bass,		Entering a destination by address Entering a destination using the	155
fader, treble)	135	map	160
Multicontour seat		Entering an intermediate stop	161
Front	270	Entering a point of interest	162
Rear compartment	108	Entering characters (character	102
Multifunction display		bar)	129
Function/notes	374	Freeway information	187
Lane recommendations	169	General notes	
Multifunction steering wheel		GPS reception	
Adjusting the volume	134	Installing map software	188
Operating the on-board computer .	373	Lane recommendation	167
Overview	. 37	Off-road/off-map (off-road	107
Using the telephone	199	destination)	173
Multisession CD	228	On-board computer	
Music files		Previous destinations	181
Recording	226	Repeating announcements	170
Music Register		Route guidance	166
Copying music data	230	Route overview	172
MUSIC REGISTER		Safety notes	150
Deleting all music files	232	Selecting a destination from the	100
Deleting individual music files		destination memory	159
Disk space information		Selecting a destination from the	,
Folder functions	232	list of last destinations	159
General notes	230 Information F		,
6		ALER	

Selecting your home address 159	On-board computer
Setting route options (avoiding:	AMG menu 379
highways, toll roads, tunnels,	Assistance menu 383
ferries) 152	Audio menu 378
Setting the route type (short	Displaying a service message 462
route, fast route, dynamic route or	Display messages 388
economic route) 152	DISTRONIC PLUS 339
Showing/hiding the menu 152	Important safety notes
Starting route calculation 156	Menu overview 375
Switching announcements on/off . 170	Message memory 388
Switching to 151	Navigation menu 377
Traffic report 174	Operating video DVD 379
Troubleshooting 192	Operation 373
NECK-PRO head restraints	RACETIMER 380
Operation 55	Service menu 385
Resetting after being triggered 56	Settings menu
NECK-PRO luxury head restraints	Standard display 376
Operation 55	Telephone menu
Resetting after being triggered 56	Trip menu 376
Night View Assist Plus	Opening height restriction for
Activating/deactivating 357	trunk lid 265
Cleaning 467	Operating system
Display message 408	see On-board computer
Function/notes 357	Outside lighting
Problem (malfunction) 360	Delayed switch-off (COMAND) 263
North orientation (navigation) 184	Outside temperature display 373
Notes on breaking-in a new	Overhead control panel 39
vehicle 302	Override feature
Number keypad 129	Rear side windows 67
	Own address (navigation)
0	see Home address
Occupant Classification System	P
(OCS)	
Faults 54	Paint code number 521
Operation 50	Paintwork (cleaning instructions) 465
System self-test 53	Panic alarm 68
Occupant safety	Panorama roof with power tilt/
Children in the vehicle 62	sliding panel
System overview 44	Opening/closing 97
Octane number (fuel) 525	Problem (malfunction) 100
Odometer 376	Resetting
see Trip odometer	Panorama sliding sunroof
Off-road	Important safety notes
Oil	Parcel net
see Engine oil	Parking
	Important safety notes



Position of exterior mirror, front-		List	164
passenger side		ZAGAT® survey service	164
Rear view camera	354	Power closing feature	. 87
see PARKTRONIC		Power washers	
Parking aid		Power windows	
Parking Guidance	350	see Side windows	
see Exterior mirrors		PRE-SAFE® (Preventive occupant	
see PARKTRONIC		safety system)	
Parking brake		Display message	396
Display message	392	Operation	
Electric parking brake		PRE-SAFE® Brake (vehicles with	. 00
Parking Guidance		DISTRONIC PLUS)	
Display message	412	•	307
Important safety notes		Display message	
Parking position		Function/notes	
Exterior mirrors (COMAND)	262	Switching on/off	
PARKTRONIC		Warning lamp	420
Deactivating/activating	349	Preventive occupant safety	
Driving system		system	
Function/notes		see PRE-SAFE® (Preventive	
Problem (malfunction)		occupant safety system)	
Range of the sensors		Previous destinations (navigation)	
Warning display		Product information	
PASSENGER AIRBAG OFF indicator	340	Programmable button	
lamp	50	Program selector button	314
Pause function	. 50	Pulling away (automatic	
	222	transmission)	305
Audio mode (CD, DVD, MP3)		PULSE	
Rear Seat Entertainment System		see Massage function (PULSE)	
Video DVD			
Pedals	320	Q	
Permanent four-wheel drive		Qualified specialist workshop	21
see 4MATIC (permanent four-		Qualified specialist workshop	. 31
wheel drive)		D	
Phone book	005	R	
Calling up		RACETIMER (on-board computer)	380
Creating an entry		Radar sensor system	
Deleting an entry		Activating/deactivating	387
Entering characters		Display message	411
Introduction		Radiator cover	457
Picture settings (TV, video)		Radio	
Plastic trim (cleaning instructions)	468	HD Radio™	215
Playback options		Selecting a station 212,	
Audio mode (CD, DVD, MP3)	228	Sound settings (balance, bass,	0, 0
Point of interest (navigation)		fader, treble)	135
Assigning a category	163	Storing stations	
Entering	162	Switching on	
Entering a point of interest using		Switching wavebands	
the map	165	on Provided by:	- 12
6			

Radio-controlled devices		Redialing (telephone)	200
(installing)		Refueling	
Read-aloud function	174	Fuel gauge	35
Reading lamp	281	Important safety notes	317
Real-time traffic reports	174	Refueling process	319
Rear compartment		see Fuel	
Activating/deactivating climate		Remote control	
control	292	Garage door opener	450
Setting the air distribution	295	Remote operation	
Setting the airflow	295	Selecting a screen (Rear Seat	
Setting the air vents		Entertainment System)	140
Setting the temperature	294	Switching a screen on/off (Rear	
Rear fog lamp		Seat Entertainment System)	140
Display message	402	Reporting	
Switching on/off		Malfunctions relevant to safety	31
Rear seat		Reserve (fuel tank)	
Adjusting	104	see Fuel	
Rear Seat Entertainment System		Reserve fuel	
Adjusting the sound settings	248	Display message	407
Audio mode (CD, DVD, MP3)	250	Warning lamp	428
AUX mode		see Fuel	
Changing batteries (remote		Reset function	150
control, headphones)	247	Resetting (factory settings)	150
Changing the picture format		Residual heat (climate control)	298
Components/overview		Restraint system	
Headphones (cordless)	142	see SRS (Supplemental Restraint	
Multiple users		System)	
Overview of picture settings		Reversing lamps (display	
Remote control			403
Screen		Road map	
Setting the audio format	258	see Map	
System settings		Roadside Assistance (breakdown)	29
Using headphones	248	Roller blind	
Using the main loudspeaker		see Roller sunblind	
Video DVD mode		Roller sunblind	
Rear seats		Panorama roof with power tilt/	
Overview	42	sliding panel	97
Rear view camera		Rear side windows	
Cleaning instructions	467	Rear window	439
Function/notes	354	Rear window (COMAND)	261
Rear-view mirror	112	Roller sunblind of the panorama	
Rear window blind	439	roof with power tilt/sliding panel	
see Rear window roller sunblind		Operating (front roller sunblind)	98
see Roller sunblind		Operating (rear roller sunblind)	
Rear window defroster		Roof carrier	
Problem (malfunction)	297	Roof lining and carpets (cleaning	
Rear window heating			469
Constability and faff		- ,	
	297		

Roof load (maximum)	530	Screen	
Route		Selecting for remote control (Rear	
see Route guidance (navigation) Route (navigation)		Seat Entertainment System) Switching on/off (Rear Seat	140
Displaying the distance to the		Entertainment System)	126
destination	172	see Display	
Route overview	172	SD memory card	
Selecting an alternative route	171	Loading	221
Setting route options (avoiding:		Seat belts	
highways, toll roads, tunnels,		Adjusting the driver's and front-	
ferries)	152	passenger seat belt	. 60
Setting the route type (short		Adjusting the height	
route, fast route, dynamic route or		Automatic comfort-fit feature	. 62
economic route)	152	Belt force limiters	. 61
Starting calculation	156	Cleaning	469
Route guidance		Correct usage	
Canceling	169	Emergency Tensioning Devices	
Continuing		Fastening	
Destination reached		Important safety guidelines	
Lane recommendations	167	Releasing	
Off-road		Safety guidelines	
Traffic reports	174	Special seat belt retractor	
Route guidance (navigation)		Switching belt adjustment on/off	
Route guidance (on-board		(on-board computer)	386
computer)	377	Warning lamp	
Route information		Warning lamp (function)	
see Dynamic route guidance/TMC		Seats	
, , , , , , , , , , , , , , , , , , , ,		Active multicontour seat 108,	272
S		Adjusting (electrically)	104
		Adjusting (rear compartment)	104
Safety		Adjusting lumbar support	108
Children in the vehicle		Adjusting the head restraint	106
Child restraint systems	. 62	Cleaning the cover	469
Occupant Classification System	50	Correct driver's seat position	102
(OCS)	. 50	Important safety notes	103
Overview of occupant safety		Multicontour seat	108
systems	. 44	Seat heating problem	109
Safety notes	000	Seat ventilation problem	109
Audio CD/DVD and MP3 mode		Selecting (COMAND)	270
Operating safety		Storing settings (memory	
Video DVD mode	240	function)	113
Safety systems		Switching seat heating on/off	108
see Driving safety systems	0.4.6	Switching seat ventilation on/off	109
SatRadio		Selecting stations (radio)	
Displaying information		Using station presets	212
Registering		Using station search	212
Selecting a category	218	Sending DTMF tones	203
		Sensors (cleaning instructions)	467



Service		Problem (malfunction)	
see ASSYST PLUS service interval		Resetting	95
display		Sliding sunroof	
Service interval display		Important safety notes	95
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	462	Opening/closing	96
Hiding service messages	462	Problem (malfunction)	100
Notes	462	Resetting	97
Service messages	462	see Panorama roof with power	
Service menu (on-board computer) .	385	tilt/sliding panel	
Service products		SmartKey	
Brake fluid	528	Changing the battery	82
Capacities	524	Changing the programming	
Coolant (engine)		Checking the battery	
DEF special additives		Convenience closing feature	
Engine oil		Convenience opening feature	
Fuel		Display message	
Important safety notes		Door central locking/unlocking	
Refrigerant (air-conditioning		Important safety notes	
system)	528	Loss	
Washer fluid		Mechanical key	
Setting a station (radio)	027	Positions (ignition lock)	
Via manual frequency entry	212	Problem (malfunction)	
Settings	212	Starting the engine	
Display	143	SMS message	,00
Menu overview	121	see Text message	
On-board computer			193
Picture (COMAND)		Socket	+70
Picture (Rear Seat Entertainment	240		142
System)	240	Sockets	+42
	135		441
Sound settings	143		+4 1 442
System settings	143		+42 442
Setting the language COMAND	140		
	149		135
Rear Seat Entertainment System		Sounds	
Setting the night design	143	see Sound settings	
Setting the text reader speed	145	Sound settings	405
Setting the vehicle level	345		135
Setting the volume		0 1	135
Telephone calls		,	248
Video AUX			136
Side impact air bag	48		135
Side marker lamp (display		Spare wheel	
message)	403	Storage location 4	172
Side windows		see Emergency spare wheel	
Convenience closing feature		Specialist workshop	31
Convenience opening feature		Speech control	
Important safety information		see Voice Control System	
Opening/closing		ded by:	

Speed, controlling		Storing stations (radio)	
see Cruise control		Automatically	213
Speed Limit Assist		Stowage compartments	
see Speed Limit Assist		Armrest (under)	433
Speedometer		Cup holders	437
Activating/deactivating the		Door	433
additional speedometer	386	Eyeglasses compartment	433
Digital		Glove box	432
In the Instrument cluster		Important safety information	432
Selecting the unit of		Parcel net	435
measurement	386	Rear	
see Instrument cluster		Rear seat backrest	434
SPLITVIEW	122	Rear seats (between)	434
SRS (Supplemental Restraint		Stowage well	436
System)		Stowage well beneath the trunk	
Display message	397	floor	436
Introduction		Summer opening	
Warning lamp		see Convenience opening feature	
Warning lamp (function)		Summer tires	492
Standing lamps		Sun visor	
Display message	402	Supplemental Restraint System	
Switching on/off		see SRS (Supplemental Restraint	
Starting (engine)		System)	
Station memory		Surround sound	
Steering (display message)		see 3D sound (Harman Kardon®	
Steering wheel		surround sound system)	
Adjusting (electrically)	110	Surround sound (harman/	
Button overview		kardon® surround sound system)	
Buttons (on-board		Notes	136
computer)	373	Switching on/off	136
Important safety notes		Suspension tuning	
Paddle shifters		Active Body Control	346
Steering wheel heating		AIRMATIC	344
Storing settings (memory		Switching air-recirculation mode	•
function)	113	on/off	297
Steering wheel (cleaning		Switching between picture	_,,
instructions)	468	formats (TV, video)	240
Steering wheel heating		Switching between summer time	
Switching on/off	110	and standard time	144
Steering wheel paddle shifters	314	Switching off the alarm (ATA)	
Stop function		Switching the hands-free	
Audio DVD	223	microphone on/off	201
Rear Seat Entertainment System		Switching wavebands (radio)	
Video DVD		System settings	
Stopwatch (RACETIMER)		Bluetooth [®]	147
Storing stations		Date	
Manually	213	Language	



Programmable button (COMAND)	120	Ending an active call	201
Text reader speed	145	Entering a number	200
Time	144	External authorization	
Time zone	144	(Bluetooth®)	197
Voice Control System	145	Function restrictions	194
,		General notes	193
Т		Keypad	120
		Menu (on-board computer)	382
Tachometer	373	Number from the phone book	383
Tail lamps		Operating options	194
Display message	402	Overview of functions	201
Tank		Reception and transmission	201
see Fuel tank		volume	199
Tank content		Redialing 200,	
Fuel gauge	. 35	Rejecting/ending a call	
Technical data		Rejecting a call	199
Notes	520	Rejecting or accepting a waiting	177
Tires/wheels	514		201
Vehicle data	530	call	
TELEAID		Safety notes	193
Automatic retrieval of vehicle data		Sending DTMF tones	203
(service due date)	449	Switching hands-free microphone	004
Call priority	447	on/off	201
Display message		Toggling	201
Downloading destinations	0,0	Using the telephone	199
(COMAND)	447	see Bluetooth®	
Emergency call		see Call lists	
Important safety notes		Television	
Locating a stolen vehicle	450	see TV	
MB info call button	446	Temperature	
Remote vehicle locking	449	Coolant	372
Roadside Assistance button	445	Coolant (on-board computer)	379
		Engine oil (on-board computer)	379
Search & Send		Outside temperature	373
Self-test	444	Setting (climate control)	294
System		Setting (COMAND)	265
Vehicle remote unlocking	449	Theft deterrent locking system	
Telephone		Immobilizer	. 75
Accepting/ending a call	199	Tilt/sliding sunroof	
Accepting a call	382	see Sliding sunroof	
Adjusting the volume for calls	134	Time	
Basic menu (Bluetooth®		Setting summer/standard time	144
interface)	198	Setting the format	144
Calling (outgoing call)	200	•	144
Calling voicemail	201	Setting the time	
Conference connection	201	Setting the time date format	144
Connecting a mobile phone		Setting the time zone	144
	195	Timing (RACETIMER)	380
De-authorizing a mobile phone	198		



Tiredness assistant		Maximum permissible tire	
see ATTENTION ASSIST		pressure (definition)	512
Tire pressure		Maximum tire load	504
Calling up (on-board computer)	497	Maximum tire load (definition)	512
Checking manually	497	Optional equipment weight	
Display message	415	(definition)	512
Maximum	496	PSI (pounds per square inch)	
Notes	495	(definition)	512
Recommended	493	Replacing	513
Tire pressure monitoring system		Service life	
Function/notes	497	Sidewall (definition)	512
Restarting	499	Speed rating (definition)	511
Warning lamp	429	Storing	514
Tires		Structure and characteristics	
Aspect ratio (definition)	512	(definition)	510
Average weight of the vehicle		Temperature	506
occupants (definition)	511	TIN (Tire Identification Number)	
Bar (definition)	510	(definition)	513
Characteristics	510	Tire bead (definition)	512
Checking	491	Tire pressure (definition)	512
Definition of terms	510	Tire pressures (recommended)	511
Direction of rotation	514	Tire size (data)	514
Display message	415	Tire size designation, load-bearing	
Distribution of the vehicle		capacity, speed rating	
occupants (definition)	513	Tire tread	491
DOT, Tire Identification Number		Tire tread (definition)	512
(TIN)	509	Total load limit (definition)	513
DOT (Department of		Traction	505
Transportation) (definition)	510	Traction (definition)	513
GAWR (Gross Axle Weight Rating)		Tread wear	505
(definition)	511	Uniform Tire Quality Grading	
GVW (Gross Vehicle Weight)		Standards	505
(definition)	511	Uniform Tire Quality Grading	
GVWR (Gross Vehicle Weight		Standards (definition)	
Rating) (definition)	511	Unladen weight (definition)	
Important safety notes	490	Wear indicator (definition)	
Increased vehicle weight due to		Wheel rim (definition)	511
optional equipment (definition)	511	see Flat tire	
Kilopascal (kPa) (definition)		Tonal properties	
Labeling (overview)	506	see Sound settings	
Load bearing index (definition)	513	Top Tether	. 65
Load index		Towing	
Load index (definition)	512	Important safety guidelines	
Maximum loaded vehicle weight		Installing the towing eye	
(definition)	511	Removing the towing eye	
Maximum load on a tire		With the rear axle raised	484
(definition)	512	Towing away	
		With both axles on the ground	484



Tow-starting	Type identification plate
Emergency engine starting 485	see Vehicle identification plate
Important safety notes 483	
Track	U
Selecting (CD, DVD, MP3) 224	linio alcin a
Traffic Announcements (TA)	Unlocking
Switching off 134	Emergency unlocking
Traffic jam function 171	From inside the vehicle (central
Traffic jam message	unlocking button)
see Dynamic route guidance/TMC	
Traffic reports	see Media Interface
Real-time traffic report 177	V
Switching on/off 174	V
Transmission	Vanity mirror (in sun visor) 438
see Automatic transmission	Vehicle
Transporting the vehicle 485	Correct use 31
Treble, adjusting (sound) 135	Data acquisition 32
Trim pieces (cleaning instructions) . 468	Display message 417
Trip computer (on-board	Equipment 28
computer) 376	Individual settings 385
Trip meter	Limited Warranty 32
see Trip odometer	Loading 500
Trip odometer	Locking (in an emergency) 88
Calling up 376	Locking (SmartKey) 79
Resetting (on-board computer) 377	Lowering 477
Trunk	Maintenance 29
Emergency release 91, 92	Parking for a long period 325
Important safety guidelines	Pulling away 305
Limiting the opening angle 265	Raising 474
Locking separately 91	Reporting problems 31
Opening/closing (automatically	Towing away 483
from inside) 90	Transporting 485
Opening/closing (automatically	Unlocking (in an emergency) 87
from outside) 90	Unlocking (SmartKey) 79
Trunk lid	Vehicle data 530
Display message 418	Vehicle battery
Opening/closing 88	see Battery (vehicle)
Power closing feature 87	Vehicle data 530
Trunk lid opening height	see Technical data
restriction 265	Vehicle dimensions 530
Turn signals	Vehicle emergency locking 88
Display message 401	Vehicle identification number
Switching on/off	see VIN
TV	Vehicle identification plate 521
Automatic picture shutoff	
Picture settings 240	



Vehicle level		W	
Active Body Control (ABC)	345		004
AIRMATIC	343	Waiting call	201
Display message	410	Warning and indicator lamps	
Vehicle level (display message)	409	ABS	423
Vehicle tool kit	472	Brakes	422
Video		Check Engine	
see Video DVD		Cruise control	
Video AUX		Distance warning	
Setting the picture	240	DISTRONIC PLUS	
Video DVD		ESP®	424
Automatic picture shutoff	240	ESP® OFF	425
DVD menu		Fuel tank	
Fast forward/rewind		LIM (DISTRONIC PLUS)	
Function restrictions		Overview	. 36
Interactive content	245	PASSENGER AIRBAG OFF	
Notes on discs	240	indicator lamp	. 50
Operation	240	Reserve fuel	428
Operation using the on-board		Seat belt	420
computer	379	SRS	426
Pause function		Tire pressure monitor	429
Playing conditions		Warranty	521
Rear Seat Entertainment System		Washer fluid	
Safety notes	240	Display message	418
Selecting	242	see Windshield washer system	
Selecting a film/title	243	Weather Band	
Selecting a scene/chapter		Searching for a channel	214
Setting the audio format		Switching on	214
Setting the language	245	Wheel bolt tightening torque	477
Setting the picture	240	Wheel chock	474
Showing/hiding the control menu.	241	Wheels	
Showing/hiding the menu		Changing a wheel	473
Stop function		Checking	491
Subtitles		Cleaning	465
Switching to		Important safety notes	490
VIN		Interchanging/changing	513
Voice Control System		Mounting a wheel	476
Settings	145	Removing a wheel	476
Volume, adjusting		Storing	514
COMAND	134	Tightening torque	477
Headphones	142	Wheel size/tire size	514
Navigation messages	134	Window curtain air bag	
Using the remote control (Rear		Display message	398
Seat Entertainment System)	140	Operation	
Tout Entertainment Oyotom,		Windows	
		Cleaning	466
		see Side windows	



Windshield	
Defrosting	296
Infrared reflective	454
Windshield washer system	461
Notes	529
Windshield wipers	
Problem (malfunction)	286
Replacing the wiper blades	285
Switching on/off	285
Winter driving	
Important safety notes	492
Slippery road surfaces	330
Snow chains	493
Winter operation	
Radiator cover	457
Winter tires	
M+S tires	492
Wiper blades	
Cleaning	466
Important safety notes	285
Wooden trim (cleaning	
instructions)	468



Product information

Mercedes-Benz recommends that you use genuine Mercedes-Benz parts, conversion parts and accessories that have been approved for the type of vehicle.

Mercedes-Benz tests genuine parts as well as conversion parts and accessories which have been specifically approved for your vehicle for their reliability, safety and suitability. Despite ongoing market research, Mercedes-Benz is unable to assess other parts. Therefore, Mercedes-Benz accepts no responsibility for the use of such parts in Mercedes-Benz vehicles, even if they have been independently or officially approved. The use of non-approved parts could affect your vehicle's operating safety. Mercedes-Benz therefore recommends that you use genuine Mercedes-Benz parts, conversion parts and accessories that have been approved for the type of vehicle. Genuine Mercedes-Benz parts, approved conversion parts and accessories are available from any authorized Mercedes-Benz Center. Here, you will receive advice about permissible technical modifications, and the parts will be professionally installed.

Operator's Manual

Notes on the Operator's Manual

This Operator's Manual contains a great deal of helpful information. We urge you to read it carefully and familiarize yourself with the vehicle before driving.

For your own safety and longer service life of the vehicle, we urge you to follow the instructions and warnings contained in this Operator's Manual. Ignoring them could result in damage to the vehicle or personal injury to you or others. Vehicle damage caused by failure to follow instructions is not covered by the Mercedes-Benz Limited Warranty.

Vehicle equipment

This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions. The equipment in your vehicle may therefore differ from that shown in the descriptions and illustrations. All the systems found in your vehicle are listed in the original purchase agreement of your vehicle. Should you have any questions concerning equipment and operation, please consult an authorized Mercedes-Benz Center. The Operating Instructions and the

Maintenance Booklet are important documents and should be kept in the vehicle.

Service and vehicle operation

Service and literature

Your vehicle is covered under the terms of the warranties printed in the Service and Warranty Information booklet. Your authorized Mercedes-Benz Center will exchange or repair any defective parts originally installed in the vehicle in accordance with the terms of the following warranties:

- New Vehicle Limited Warranty
- · Emission Systems Warranty
- Emission Performance Warranty
- California, Connecticut, Maine, Massachusetts, New York, Pennsylvania, Rhode Island and Vermont Emission Control Systems Warranty
- State Warranty Enforcement Laws (Lemon Laws)



Information for customers in California

Under California law you may be entitled to a replacement of your vehicle or a refund of the purchase price or lease price, if after a reasonable number of repair attempts Mercedes-Benz USA, LLC and/or its authorized repair or service facilities fail to fix one or more substantial defects or malfunctions in the vehicle that are covered by its express warranty. During the period of 18 months from original delivery of the vehicle or the accumulation of 18 000 miles (approximately 29 000 km) on the odometer of the vehicle, whichever occurs first, a reasonable number of repair attempts is presumed for a retail buyer or lessee if one or more of the following occurs:

- (1) the same substantial defect or malfunction results in a condition that is likely to cause death or serious bodily injury if the vehicle is driven, that defect or malfunction has been subject to repair two or more times, and you have directly notified Mercedes-Benz USA, LLC in writing of the need for its repair.
- (2) the same substantial defect or malfunction of a less serious nature than category (1) has been subject to repair four or more times and you have directly notified Mercedes-Benz in writing of the need for its repair.
- (3) the vehicle is out of service by reason of repair of the same or different substantial defects or malfunctions for a cumulative total of more than 30 calendar days.

Please send your written notice to: Mercedes-Benz USA, LLC Customer Assistance Center One Mercedes Drive Montvale, NJ 07645-0350

Maintenance

The Service and Warranty Booklet describes all the necessary maintenance work which should be done at regular intervals.

Always have the Service and Warranty Booklet with you when you bring the vehicle to an authorized Mercedes-Benz Center. The service advisor will record every service for you in the Service and Warranty Booklet.

Roadside Assistance

The Mercedes-Benz Roadside Assistance Program offers technical help in the event of a breakdown. Calls to the toll-free Roadside Assistance Hotline are answered by our agents 24 hours a day, 365 days a year.

1-800-FOR-MERCedes(1-800-367-6372) (USA)

1-800-387-0100 (Canada)

For additional information, refer to the Mercedes-Benz Roadside Assistance Program brochure (USA) or the "Roadside Assistance" section in the Service and Warranty booklet (Canada). You will find both in your vehicle literature portfolio.

Change of address or change of ownership

In the event of a change of address, please send us the "Change of Address Notice" found in the Service and Warranty Information Booklet, or simply call the Mercedes-Benz Customer Assistance Center (in the USA) at the hotline number 1-800-FOR-MERCedes(1-800-367-6372) or Customer Service Center (in Canada) at 1-800-387-0100. This will assist us in contacting you in a timely manner should the need arise.

If you sell your Mercedes, please leave the entire literature in the vehicle so that it is available to the next owner.



If you bought this vehicle used, be sure to send in the "Notice of Purchase of Used Car" found in the Service and Warranty Information Booklet, or call the Mercedes-Benz Customer Assistance Center (in the USA) at

1-800-FOR-MERCedes(1-800-367-6372) or Customer Service (in Canada) at 1-800-387-0100.

Vehicle operation outside the USA and Canada

If you plan to operate your vehicle in foreign countries, please be aware that:

- service facilities or replacement parts may not be readily available.
- unleaded fuel for vehicles with a catalytic converter may not be available. Leaded fuel may cause damage to the catalytic converter.
- the fuel may have a considerably lower octane rating. Unsuitable fuel can cause engine damage.

Some Mercedes-Benz models are available for delivery in Europe through our European Delivery Program. For details, consult an authorized Mercedes-Benz Center or write to one of the following addresses.

In the USA

Mercedes-Benz USA, LLC European Delivery Department One Mercedes Drive Montvale, NI 07645-0350

In Canada

Mercedes-Benz Canada, Inc. **European Delivery Department** 98 Vanderhoof Avenue Toronto, Ontario M4G 4C9

Operating safety

Safety notes



↑ WARNING

Work improperly carried out on electronic components and associated software could cause them to cease functioning. Because the vehicle's electronic components are interconnected, any modifications made may produce an undesired effect on other systems. Electronic malfunctions could seriously impair the operating safety of your vehicle.

Contact an authorized Mercedes-Benz Center for repairs or modifications to electronic components.

Other improper work or modifications on the vehicle could also have a negative impact on the operating safety of the vehicle.

Some safety systems only function when the engine is running. You should therefore never turn off the engine while driving.



↑ WARNING

Heavy blows against the vehicle underbody or tires/wheels may cause serious damage and impair the operating safety of your vehicle. Such blows can be caused, for example, by running over an obstacle, road debris or a pothole.

If you feel a sudden significant vibration or ride disturbance, or you suspect that damage to your vehicle has occurred:

- turn on your hazard warning flashers.
- slow down carefully.
- drive with caution to an area which is a safe. distance from the road.

Inspect the vehicle underbody and tires/ wheels for possible damage. If the vehicle appears unsafe, have it towed to the nearest authorized Mercedes-Benz Center or other qualified maintenance or repair facility for further inspection or repairs.



Qualified specialist workshop

An authorized Mercedes-Benz Center is a qualified specialist workshop. It has the necessary specialist knowledge, tools and qualifications to correctly carry out the work required on your vehicle. This is especially the case for work relevant to safety.

Observe the notes in the service booklet. Always have the following work carried out at an authorized Mercedes-Benz Center:

- · work relevant to safety
- · service and maintenance work
- repair work
- · alterations, installation work and modifications
- work on electronic components

Proper use

↑ WARNING

There are various warning stickers affixed to your vehicle. Their purpose is to alert you and others to various dangers. Therefore, do not remove any warning stickers unless the sticker clearly states that you may do so. If you remove any warning stickers, you or others could fail to recognize certain dangers and be injured.

The proper use of the vehicle requires that you familiarize yourself with the following information and rules:

- safety notes in this Operator's Manual
- technical data in this Operator's Manual
- · traffic rules and regulations
- laws and safety standards pertaining to motor vehicles

Problems with your vehicle

If you should experience a problem with your vehicle, particularly one that you believe may affect its safe operation, we urge you to

contact an authorized Mercedes-Benz Center immediately to have the problem diagnosed and rectified. If the problem is not resolved to your satisfaction, please discuss the problem again with a Mercedes-Benz Center or contact us at one of the following addresses.

In the USA

Customer Assistance Center Mercedes-Benz USA, LLC One Mercedes Drive Montvale, NJ 07645-0350

In Canada

Customer Relations Department Mercedes-Benz Canada, Inc. 98 Vanderhoof Avenue Toronto, Ontario M4G 4C9

Reporting malfunctions relevant to safety

For the USA only:

The following text is reproduced as required of all manufacturers according to Title 49, Code of U.S. Federal Regulations, Part 575 pursuant to the National Traffic and Motor Vehicle Safety Act of 1966.

Reporting safety defects

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Mercedes-Benz USA, LLC.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Mercedes-Benz USA, LLC.



To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to: http://www.safercar.gov; or write to: Administrator, NHTSA Headquarters, 1200 New Jersey Avenue, SE, West Building, Washington, DC 20590.

You can also obtain additional information about vehicle safety from:

http://www.safercar.gov.

- for use in arbitration of disputes that involve Daimler AG, its affiliates or its sales and service organizations
- as otherwise required or permitted by law.

Please observe the mbrace¹ purchase agreement for further details on the recording and transfer of data by this system.

Limited Warranty

I Follow the instructions in this manual about the proper operation of your vehicle as well as about possible vehicle damage. Damage to your vehicle that arises from culpable contraventions against these instructions are not covered either by Mercedes-Benz Limited Warranty or by the New or Used-Vehicle Warranty of Daimler AG.

Data stored in the vehicle

Information about electronic data acquisition in the vehicle

(Including notice pursuant to California Code § 9951)

Your vehicle records electronic data. If your vehicle is equipped with mbrace¹, data is transmitted in the event of an accident.

This information helps, for example, to test vehicle systems after an accident and to continually improve vehicle safety.

Daimler AG can access this data and submit it:


- for safety research or vehicle diagnosis purposes
- with the consent of the vehicle owner
- on the instruction of prosecuting authorities

¹ The system is called TELE AID in Canada.



Cockpit	34
Instrument cluster	3
On-board computer and COMAND	37
Center console	38
Overhead control panel	39
Door control panel	40
Rear seats	42

Cockpit




	Function	Page
1	Steering wheel paddle shifters	314
2	Combination switch	279
3	Cruise control lever	331
4	Horn	
(5)	Instrument cluster	35
6	DIRECT SELECT lever	310
9	Control panel for: Vehicle level Suspension tuning PARKTRONIC Swiveling the COMAND display COMAND display brightness Instrument lighting	343 344 347 124 124
	moti ament nghting	124

	Pol	8.10-4355-31
	Function	Page
8	Overhead control panel	39
9	Automatic climate control	290
10	Ignition lock Start/Stop button	303 303
11)	Adjusts the steering wheel Steering wheel heating	109 110
12	Electric parking brake	324
(13)	On-board diagnostics socket	
14)	Opens the hood	456
15	Night View Assist Plus	357
16	Light switch	276



Instrument cluster

Displays




D54	32.	020	10.31

	Function	Page
1	Coolant temperature	372
2	Fuel gauge	
3	PARKTRONIC	347
4	Multifunction display Speedometer	374
5	Transmission position	312
6	Tachometer	373
7	Drive program	314
8	Parking Guidance	350

	Function	Page
9	Unit of measurement for the speedometer	386
10	Outside temperature	373
11)	Additional speedometer	386
12	HOLD function □ PRE-SAFE® Brake	342 73
(13)	Adaptive Highbeam Assist Lane Keeping Assist or Active Lane Keeping Assist ATTENTION ASSIST	280 362, 367 356



Warning and indicator lamps




254.32-9201-3	1	
---------------	---	--

	Function	Page
1	Turn signal	279
2	Electric parking brake (red) [PARK] (USA only) [PD] (Canada only)	422
3	Electric parking brake (yellow) PARK (USA only) (P) (Canada only)	422
4	Seat belt	420
5	ESP®	424
6	Distance warning	428
7	Brakes BRAKE (USA only) (①) (Canada only)	422

Function	Page
ESP® OFF	424
Tire pressure monitor	429
Diesel engine: preglow	305
Check engine	427
ABS	423
SRS	426
High-beam headlamps	279
Reserve fuel	428
	ESP® OFF Tire pressure monitor Diesel engine: preglow Check engine ABS SRS High-beam headlamps



On-board computer and COMAND




	Function	Page
1	Back or deactivates the Voice Control System	
2	Selects a menu Selects a function or scrolls through lists OK Confirms selection or fades out display messages	375 375
3	Multifunction display	374
4	Rejects or ends a call Exits phone book/redial memory Makes or accepts a call Switches to the redial memory Adjusts the volume or operates RACETIMER on AMG	382 382
	vehicles	380

₩ Mute

	Function	Page
5	Switches on the Voice Control System; see the separate operating instructions	
6	Swivels the COMAND display Adjusts the brightness of the instrument lighting and the COMAND display	124
7	COMAND display	121
8	CD and DVD player/ changer	220
9	COMAND controller and COMAND function buttons	118, 119



Center console



	Function	Page
1	Function button for the radio and CD/DVD/SD card	119
2	Back button	119
3	Hazard warning lamps	279
4	Lumbar support Multicontour seat	269 270
5	Function button for the telephone and navigation system	151
6	Switches COMAND on/off	133

	Function	Dogo
	runction	Page
7	Adjusts the volume	134
8	Programmable button	120
9	Telephone keypad	120
10	Rear window roller sunblind	439
11)	Retracts the rear seat head restraints	107
12	Selects the drive program	314
13	COMAND controller	118



Overhead control panel



	Function	Page
1	Eyeglasses compartment	433
2	M Switches the left-hand reading lamp on/off	281
3	Switches the rear interior lighting on/off	282
4	Switches the front interior lighting on/off	282
5	Opens/closes the sliding sunroof Opens/closes the panorama roof with power tilt/sliding panel and roller sunblinds	96 97
6	system) SOS button (mbrace	444
7	Switches the automatic interior lighting control on/off	282


	Function	Page
8	Extends/retracts the rear roller sunblind of the panorama roof with power tilt/sliding panel	97
9	Mand reading lamp on/off	281
10	Rear-view mirror	
11)	Buttons for the garage door opener	451
12	Microphone for mbrace (emergency call system), telephone and the Voice Control System ²	

² Observe the additional operating instructions.



Door control panel

Front



	Function	Page
1	Opens the door	86
2	Unlocks/locks the vehicle	86
3	Adjusts the seat electrically	104
4	M 1 2 3 Memory function Adjusts the front- passenger seat from the driver's seat	113 105
5		108 109
6	Adjusts and folds the exterior mirrors in/out electrically	111

	Function	Page
7	Opens/closes the side windows Opens/closes the roller sunblinds in the rear side windows	92
	side willdows	93
8	Opens the trunk lid Vehicles with trunk lid remote closing feature:	90
	opens/closes the trunk lid	90
9	Override feature for the controls in the rear compartment	67





	Function	Page
1	Adjusts the front- passenger seat from the rear	105
2	M 1 2 3 Memory function	113
3	Adjusts the seat electrically	104
4	Opens the door	86
5	Roller sunblind	439
6	Operates the rear roller sunblind of the panorama roof with power tilt/sliding panel from the rear	98

	Function	Page
7	Opens/closes the side windows Opens/closes the roller sunblinds in the rear side windows	92 93
8	Adjusts seat heating Adjusts seat ventilation	108



Rear seats



	Function	Page
1	Cup holder underneath the rear seat armrest	437
2	Cup holder in the rear seat armrest	437
3	Control panel for multicontour seat in the rear compartment	108
4	Stowage compartment in the rear seat armrest	434
5	Stowage box in the seat backrest	434



Useful information	44
Occupant safety	44
Children in the vehicle	62
Panic alarm	68
Driving safety systems	68
Theft deterrent locking systems	



Useful information

- i This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions.
- Please read the information on qualified specialist workshops (> page 31).

Occupant safety

Overview of occupant safety

In this section, you will learn the most important facts about the restraint system components of the vehicle.

The restraint system consists of:

- · seat belts
- · child restraint systems
- LATCH-type (ISOFIX) child seat anchors Additional protection is provided by:
- SRS (Supplemental Restraint System)
- NECK-PRO head restraints/NECK-PRO luxury head restraints
- PRE-SAFE®
- Air bag system components with:
- PASSENGER AIR BAG OFF indicator lamp
- front-passenger seat with Occupant Classification System (OCS)

The different air bag systems work independently of each other. The protective functions of the system work in conjunction with each other. Not all air bags are deployed in an accident.

MARNING

Modifications to or work improperly conducted on restraint system components or their wiring, as well as tampering with

interconnected electronic systems, can lead to the restraint systems no longer functioning as intended.

Air bags or Emergency Tensioning Devices (ETDs), for example, could deploy inadvertently or fail to deploy in accidents although the deceleration threshold for air bag deployment is exceeded. Therefore, never modify the restraint systems. Do not tamper with electronic components or their software.

i See "Children in the vehicle" (▷ page 62) for more information on infants and children traveling with you in the vehicle and restraints for infants and children

SRS (Supplemental Restraint System)

Introduction

SRS consists of:

- the SRS warning lamp
- air bags
- air bag control unit (with crash sensors)
- Emergency Tensioning Devices
- · belt force limiters

SRS reduces the risk of occupants coming into contact with the vehicle's interior in the event of an accident. It can also reduce the effect of the forces to which occupants are subjected during an accident.

SRS warning lamp

SRS functions are checked regularly when you switch on the ignition and when the engine is running. Therefore, malfunctions can be detected in good time.

The SRS warning lamp in the instrument cluster lights up when the ignition is switched on. It goes out no later than a few seconds after the engine is started.



The SRS components are in operational readiness when the SRS warning lamp is not lit while the engine is running.

↑ WARNING

The SRS self-check has detected a malfunction if the SRS warning lamp:

- · does not come on at all
- fails to go out approximately 4 seconds after the engine was started
- comes on after the engine was started or while driving

For your safety, Mercedes-Benz strongly recommends that you have the system checked as soon as possible at an authorized Mercedes-Benz Center. Otherwise the SRS may not be activated when it is needed in an accident, which could result in serious or fatal injury. The SRS might also deploy unexpectedly and unnecessarily which could also result in injury.

In addition, improper work on the SRS creates a risk of rendering the SRS inoperative or causing unintended air bag deployment. Work on the SRS must therefore only be performed by qualified technicians. Contact an authorized Mercedes-Benz Center.

If it is necessary to modify an air bag system to accommodate a person with disabilities. contact an authorized Mercedes-Benz Center for details. USA only: Call our Customer Assistance Center at 1-800-FOR-MERCedes (1-800-367-6372) for details.

Safety guidelines for seat belts, **Emergency Tensioning Devices (ETDs)** and air bags



↑ WARNING

• Damaged seat belts or seat belts that have been subjected to stress in an accident must be replaced. Their anchoring points must also be checked. Only use seat belts

- installed or supplied by an authorized Mercedes-Benz Center.
- Air bags and pyrotechnic Emergency Tensioning Devices (ETDs) contain perchlorate material, which may require special handling and regard for the environment. Check your national disposal guidelines. California residents, see www.dtsc.ca.gov/HazardousWaste/ Perchlorate/index.cfm.
- Air bags and ETDs are designed to function on a one-time-only basis. An air bag or ETD that has deployed must be replaced. PRE-SAFE® has electrically operated reversible belt tensioners in addition to the pyrotechnic ETDs.
- Do not pass seat belts over sharp edges. They could tear.
- Do not make any modification that could change the effectiveness of the seat belts.
- Do not bleach or dye seat belts as this may severely weaken them. In a crash they may not be able to provide adequate protection.
- No modifications of any kind may be made to any components or wiring of the SRS.
- Do not change or remove any component or part of the SRS.
- Do not install additional trim material, seat covers, badges, etc. to the:
 - padded steering wheel boss
 - front-passenger air bag cover
 - outer side of front seat bolsters
 - side trim next to the rear seat backrest
 - roof lining trim
- Do not install additional electrical/ electronic equipment on or near SRS components and wiring.
- Keep area between air bags and occupants free of objects (e.g. packages, purses, umbrellas, etc.).
- Do not hang items such as coat hangers from the coat hooks or handles over the door. These items may be thrown around in the vehicle and cause head and other



injuries when the window curtain air bag is deployed.

- Air bag system components will be hot after an air bag has inflated. Do not touch them.
- Never place your feet on the instrument panel, dashboard, or on the seat. Always keep both feet on the floor in front of the seat.
- Improper repair work on the SRS creates a risk of rendering the SRS inoperative or causing unintended air bag deployment. Work on the SRS must therefore only be performed by qualified technicians. Contact an authorized Mercedes-Benz Center.
- For your protection and the protection of others, when scrapping the air bag unit or ETD, our safety instructions must be followed. These instructions are available from any authorized Mercedes-Benz Center.
- Given the considerable deployment speed, required inflation volume, and the material of the air bags, there is the possibility of abrasions or other, potentially more serious injuries resulting from air bag deployment.

If you sell your vehicle, Mercedes-Benz strongly recommends that you inform the subsequent owner that the vehicle is equipped with SRS. Also, refer them to the applicable section in the Operator's Manual.

Air bags

Important safety notes



↑ WARNING

Air bags are designed to reduce the incidence of injuries and fatalities in certain situations:

- frontal impacts (driver's and frontpassenger front air bags)
- side impacts (side impact air bags and window curtain air bags)
- rollover (window curtain air bags)

However, no system available today can completely eliminate injuries and fatalities.

When the air bags are deployed, a small amount of powder is released. The powder generally does not constitute a health hazard and does not indicate that there is a fire in the vehicle. In order to prevent potential breathing difficulties, you should leave the vehicle as soon as it is safe to do so. If you have any breathing difficulty but cannot get out of the vehicle after the air bag inflates, then get fresh air by opening a window or door.

↑ WARNING

To reduce the risk of injuries during front air bag inflation, the driver and front-passenger must always be seated correctly and have their seat belts fastened accordingly.

For maximum protection in the event of a collision, you must always be in the normal seat position with your back against the backrest. Fasten your seat belt and make sure that it is correctly positioned on your body. Since the air bag inflates with considerable speed and force, a proper seating position and correct positioning of the hands on the steering wheel will help to keep you at a safe distance from the air bag. Occupants who are not wearing their seat belt, are not seated

• Sit with the seat belt properly fastened in a position that is as upright as possible with your back against the seat backrest.

inflates with great force instantaneously:

properly or are too close to the air bag can be seriously injured or killed by an air bag as it

. Move the driver's seat as far back as possible, still permitting proper operation of vehicle controls. The distance from the center of the driver's chest to the center of the air bag cover on the steering wheel must be at least 10 inches (25 cm) or more. You should be able to accomplish this by adjusting the seat and steering wheel. If you have any difficulties, please contact an authorized Mercedes-Benz Center.



- Do not lean your head or chest close to the steering wheel or dashboard.
- Only hold the steering wheel by the rim. Placing hands and arms inside the rim can increase the risk and potential severity of hand/arm injury when the driver front air bag inflates.
- Adjust the front-passenger seat as far back as possible from the dashboard when the seat is occupied.
- · Occupants, especially children, should never place their bodies or lean their heads in the area of the door where the side impact air bag inflates. This could result in serious injuries or death should the side impact air bag be deployed. Always sit as upright as possible, wear the seat belt properly and use an appropriately sized child restraint, infant restraint or booster seat recommended for the size and weight of the child.

Failure to follow these instructions can result in severe injuries to you or other occupants. If you sell your vehicle, it is important that you make the buyer aware of this safety information. Be sure to give the buyer this Operator's Manual.

↑ WARNING

Accident research shows that the safest place for children in an automobile is in a rear seat. There is a possibility for a side impact air bagrelated injury if occupants, especially children, are not properly seated or restrained when next to a side impact air bag which needs to deploy rapidly in a side impact in order to do its job.

To help avoid the possibility of injury, please follow these guidelines:

Occupants, especially children, should never place their bodies or lean their heads in the area of the door where the side impact air bag inflates. This could result in serious injuries or death should

- the side impact air bag be deployed.
- (2) Always sit as upright as possible, wear the seat belt properly and use an appropriately sized infant restraint, toddler restraint, or booster seat recommended for the size and weight of the child. and for children 12 years old and under, use an appropriately sized infant restraint, toddler restraint, or booster seat recommended for the size and weight of the child.
- (3)Always wear seat belts properly.

If you believe that, even with the use of these guidelines, it would be safer for your rear seat occupants to have the rear mounted side impact air bags deactivated, then deactivation can be carried out upon your written request at an authorized Mercedes-Benz Center at an additional cost.

Please contact an authorized Mercedes-Benz Center or call the Customer Assistance Center (in the USA) at 1-800-FOR-MERCedes (1-800-367-6372), or Customer Service (in Canada) at 1-800-387-0100 for details.

The air bags are only deployed if the air bag control unit detects the need for deployment. Only in the event of such a situation will they provide their supplemental protection.

The driver and passenger should always wear their seat belts. Otherwise, it is not possible for the air bags to provide their supplemental protection.

In the event of other types of impacts and impacts below air bag deployment thresholds, the air bags will not deploy. The driver and passengers will then be protected to the extent possible by a properly fastened seat belt. A properly fastened seat belt is also needed to provide the best possible protection in a rollover.

Air bags provide additional protection; they are not, however, a substitute for seat belts. All vehicle occupants must fasten their seat



belts regardless of whether your vehicle is equipped with air bags or not.

It is important for your safety and that of your passenger to have deployed air bags replaced and to have any malfunctioning air bags repaired. This will help to make sure the air bags continue to perform their protective function for the vehicle occupants in the event of a crash.

Front air bags

The front air bags increase protection for the driver's and front-passenger's head and chest.



Driver's air bag ① deploys in front of the steering wheel; front-passenger front air bag ② deploys in front of and above the glove box.

They are deployed:

- in the event of certain frontal impacts
- if the system determines that air bag deployment can offer additional protection to that provided by the seat belt
- · if the seat belt is fastened
- independently of other air bags in the vehicle

If the vehicle overturns, the front air bags are generally not deployed unless the system detects high vehicle deceleration in a longitudinal direction.

Your vehicle has adaptive, two-stage front air bags. In the event of a collision, the air bag control unit evaluates the vehicle deceleration. In the first deployment stage,

the front air bag is filled with enough propellant gas to reduce the risk of injuries. The front air bag is fully deployed if a second deployment threshold is exceeded within a few milliseconds.

The deployment of the front-passenger front air bag is also influenced by the weight category of the front passenger, which is determined by the Occupant Classification System (OCS) (> page 50).

The lighter the passenger side occupant, the higher the vehicle deceleration rate required (predicted at the start of the impact) for second stage inflation of the front-passenger front air bag. In the second stage, the front air bags are inflated with the maximum amount of propellant gas available.

The front air bags are not deployed in situations where a low impact severity is predicted. You will then be protected by the fastened seat belt.

The front-passenger front air bag will only deploy if:

- the system, based on the OCS weight sensor readings, detects that the frontpassenger seat is occupied.
- the Pass air Bag indicator lamp in the center console is not lit, (> page 50).
- the air bag control unit predicts a high impact severity.

Side impact air bags

\triangle

↑ WARNING

The pressure sensors for side impact air bag control are located in the doors. Do not modify any components of the doors or door trim panels including, for example, the addition of door speakers.

Improper repair work on the doors or the modification or addition of components to the doors create a risk of rendering the side impact air bags inoperative or causing unintended air bag deployment. Work on the doors must therefore only be performed by




qualified technicians. Contact an authorized Mercedes-Benz Center.

↑ WARNING

Only use seat covers which have been tested and approved by Mercedes-Benz for your vehicle model. Using other seat covers may interfere with or prevent the deployment of the side impact air bags. Contact an authorized Mercedes-Benz Center for availability.

When deployed, the side impact air bags offer additional protection for the thorax of the vehicle occupants on the side of the vehicle on which the impact occurs. However, they do not protect the:

- head
- neck
- arms



Front side impact air bags (1) and rear side impact air bags (2) deploy next to the outer seat cushions.

The side impact air bags are deployed:

- on the side on which an impact occurs
- at the start of an accident with a high rate of lateral vehicle deceleration or acceleration, e.g. in a side impact
- independently of seat belt use
- · independently of the front air bags
- independently of the ETDs

If the vehicle overturns, the side impact air bags are generally not deployed. They are deployed if the system detects high vehicle


deceleration or acceleration in a lateral direction and determines that side impact air bag deployment can offer additional protection to that provided by the seat belt. Side impact air bags will not deploy in side impacts which do not exceed the system's preset deployment thresholds for lateral acceleration/deceleration. You will then be protected by the fastened seat belt.

If the OCS detects that the front-passenger seat is not occupied and the front-passenger seat belt is not fastened (the belt tongue is not engaged in the seat belt buckle), the side impact air bag on the front-passenger side will not deploy. The side impact air bag on the front-passenger side will deploy if the frontpassenger seat belt is fastened, regardless of whether the front-passenger seat is occupied or not.

Window curtain air bags

The window curtain air bags enhance the level of protection for the head, but not chest or arms, of the vehicle occupants on the side of the vehicle on which the impact occurs.

The window curtain air bags are integrated into the side of the roof frame and deploy in the area from the A-pillar to the C-pillar.



Window curtain air bags (1) are deployed:

- on the side on which an impact occurs
- at the start of an accident with a high rate of lateral vehicle deceleration or acceleration, e.g. in a side impact



- regardless of whether the front-passenger seat is occupied
- independently of seat belt use
- if the vehicle overturns and the system determines that window curtain air bag deployment can offer additional protection to that provided by the seat belt
- independently of the front air bags

Window curtain air bags ① will not deploy in impacts with deceleration rates which do not exceed the system's preset deployment thresholds for vehicle deceleration or acceleration. You will then be protected by the fastened seat belt.

Occupant Classification System (OCS)

How the occupant classification system works

The Occupant Classification System (OCS) categorizes the occupant on the front-passenger seat by means of a weight sensor. The front-passenger front air bag is deactivated automatically for certain weight categories. The PASS AIR BAGOTI indicator lamp shows you the current status. If the PASS AIR BAGOTI indicator lamp is illuminated, the front-passenger front air bag is deactivated.

The system does not deactivate:

- the side impact air bag
- the window curtain air bag
- the Emergency Tensioning Devices

To be classified correctly, the front passenger must sit:

- with the seat belt fastened correctly
- in a position that is as upright as possible with their back against the seat backrest
- · with their feet on the floor

If the front-passenger's weight is transferred to another object in the vehicle (e.g. by leaning on armrests), OCS may not be able to approximate the occupant's weight category.

If the front-passenger seat, the seat cover or the seat cushion are damaged, have the necessary repair work carried out at an authorized Mercedes-Benz Center.

For safety reasons, Mercedes-Benz recommends that you only use seat accessories which have been approved by Mercedes-Benz.

Both the driver and the passenger should always use the PASS AIR BAG III indicator lamp as an indication of whether or not the passenger is properly positioned.

↑ WARNING

If the ASS AIR BAG III indicator lamp lights up when an adult or someone larger than a small individual is in the front-passenger seat, have the front passenger reposition himself or herself in the seat until the ASS AIR BAG III indicator lamp goes out.

In the event of a collision, the air bag control unit will not allow front-passenger front air bag deployment when the OCS has classified the front-passenger seat occupant as weighing as much as or less than a typical 12-month-old child in a standard child restraint or if the front-passenger seat is classified as being empty.

When the OCS senses that the front-passenger seat occupant is classified as being up to or less than the weight of a typical 12-month-old child in a standard child restraint, the Pass AIR BAG indicator lamp will illuminate when the engine is started and remain illuminated, indicating that the front-passenger front air bag is deactivated.

When the OCS senses that the front-passenger seat is classified as being empty, the passanger seat is classified as being empty, the passanger indicator lamp will illuminate when the engine is started and remain illuminated, indicating that the front-passenger front air bag is deactivated.

When the OCS senses that the frontpassenger seat occupant is classified as being heavier than the weight of a typical 12month-old child seated in a standard child



restraint or as being a small individual (such as a young teenager or a small adult), the PASS AIR BAG OFF Indicator lamp will illuminate for approximately 6 seconds when the engine is started and then, depending on occupant weight sensor readings from the frontpassenger seat, remain illuminated or go out. With the Pass AIR BAG indicator lamp illuminated, the front-passenger front air bag is deactivated. With the PASS AIR BAG OFF indicator lamp out, the front-passenger front air bag is activated.

When the OCS senses that the frontpassenger seat occupant is classified as an adult or someone larger than a small individual, the Pass AIR BAG OFF indicator lamp will illuminate for approximately 6 seconds when the engine is started and then go out, indicating that the front-passenger front air bag is activated.

If the PASS AIR BAG OFF indicator lamp is illuminated, the front-passenger front air bag is deactivated and will not be deployed.

If the Pass air Bag indicator lamp is not illuminated, the front-passenger front air bag is activated and will be deployed:

- in the event of certain frontal impacts
- if impact exceeds a preset deployment threshold
- independently of the side impact air bags If the front-passenger front air bag is deployed, the rate of inflation will be influenced by:
- the rate of vehicle deceleration as assessed by the air bag control unit
- the front passenger's weight category as identified by OCS

For further information, see "Air bag display messages" (⊳ page 399).

↑ WARNING

According to accident statistics, children are safer when properly restrained on the rear seats than on the front-passenger seat. Thus, we strongly recommend that children be

placed in the rear seats whenever possible. Regardless of seating position, children 12 years old and under must be seated and properly secured in an appropriately sized child restraint system or booster seat recommended for the size and weight of the child.

The infant or child restraint system must be properly secured with the vehicle's seat belt, the seat belt and Top Tether strap, or lower anchors and Top Tether strap, fully in accordance with the child seat manufacturer's instructions.

Occupants, especially children, should always sit as upright as possible, wear the seat belt properly and use an appropriate sized infant restraint, toddler restraint, or booster seat recommended for the size and weight of the child.

Children can be killed or seriously injured by an inflating air bag. Note the following important information when circumstances require you to place a child in the frontpassenger seat:

- Your vehicle is equipped with air bag technology designed to deactivate the front-passenger front air bag in your vehicle when the system senses the weight of a typical 12-month-old child or less along with the weight of a standard appropriate child restraint on the front-passenger seat.
- A child in a rear-facing child restraint on the front-passenger seat will be seriously injured or even killed if the front-passenger front air bag inflates in a collision which could occur under some circumstances. even with the air bag technology installed in your vehicle. The only means to eliminate this risk completely is never to place a child in a rear-facing child restraint in the frontpassenger seat. We therefore strongly recommend that you always place a child in a rear-facing child restraint on the rear seat.
- If you install a rear-facing child restraint on the front-passenger seat, make sure the

PASS AIR BAG OFF indicator lamp is illuminated, indicating that the frontpassenger front air bag is deactivated. Should the PASS AIR BAG OFF indicator lamp not illuminate or go out while the restraint is installed, please check installation. Periodically check the Pass air Bag OFF indicator lamp while driving to make sure the pass air bag off indicator lamp is illuminated. If the Pass AIR BAG OFF indicator lamp goes out or remains out, do not transport a child on the front-passenger seat until the system has been repaired. A child in a rear-facing child restraint on the

front-passenger seat will be seriously injured or even killed if the front-passenger front air bag inflates.

- If you place a child in a forward-facing child restraint on the front-passenger seat:
 - move the seat as far back as possible
 - use the proper child restraint recommended for the age, size and weight of the child
- secure child restraint with the vehicle's seat belt according to the child seat manufacturer's instructions
- For children larger than a typical 12-monthold child, the front-passenger front air bag can be activated or deactivated.

If the driver's air bag deploys, this does not mean that the front-passenger front air bag also has to deploy.

The OCS may have detected that the seat:

- was empty or occupied by a person with a weight of up to or less than that of a typical 12-month-old child seated in a standard child restraint
- was occupied by a small individual, such as a young teenager or a small adult
- · was occupied by a child in a child restraint system, whose weight is greater than that of a typical 12-month-old child.

These are examples of when the OCS deactivates the front-passenger front air bag.

Deactivation takes place although the collision fulfills the criteria for deploying the driver's air bag.



If the SmartKey has been removed from the ignition lock or is in position **0**, indicator lamp PASS AIR BAG 1 does not light up.

♠ WARNING

If the red SRS " indicator lamp in the instrument cluster and the Pass air Bag OFF indicator lamp are lit at the same time, there is a malfunction in the OCS. The front passenger front air bag will be deactivated in this case. Have the system checked by qualified technicians as soon as possible. Contact an authorized Mercedes-Benz Center.

Only have the seat repaired or replaced at an authorized Mercedes-Benz Center.

In order to ensure proper operation of the air bag system and OCS:

- Sit with the seat belt properly fastened in a position that is as upright as possible with your back against the seat backrest.
- When seated, a passenger should not position him/herself in such a way as to cause the passenger's weight to be lifted from the seat cushion as this may result in the OCS being unable to correctly approximate the passenger's weight category.
- Read and observe all warnings in this chapter.



System self-test

The RASS AIR BAG OFF indicator lamp illuminates when you:

- turn the SmartKey to position 1 or 2 in the ignition lock
- press the KEYLESS-GO Start/Stop button once or twice

If an adult occupant is properly sitting on the passenger seat and the OCS classifies the occupant as an adult, the PASS AIR BAG DEP indicator lamp illuminates and goes out again after approximately 6 seconds.

If the seat is not occupied and the OCS classifies the front passenger seat as being unoccupied, the PASS AIR BAGGE indicator lamp will illuminate and not go out.

↑ WARNING

If the Passalr Bagoss indicator lamp does not illuminate, the system is not functioning. You must contact an authorized Mercedes-Benz Center before seating any child on the front passenger seat.

For more information, see "Problems with the Occupant Classification System" (> page 54).

↑ WARNING

Never place anything between seat cushion and child seat (e.g. a pillow), since it reduces the effectiveness of the OCS. The underside and rear side child restraint system must be placed entirely on the seat cushion and the backrest of the front-passenger seat backrest.

If necessary, adjust the tilt of the passenger seat backrest.

An incorrectly mounted child seat could cause injuries to the child in case of an accident, instead of increasing protection for the child.

Follow the manufacturer's instructions for installation of child restraint systems.



Problems with the occupant classification system

Problem The PASS AIR BAG OFF indicator lamp illuminates and remains illuminated. The person on the front-passenger seat:

· has the weight of a

typical adult

· has been determined by the system not to be a child.

Possible causes/consequences and ▶ Solutions

The OCS is malfunctioning.

- ▶ Have the OCS checked as soon as possible at an authorized Mercedes-Benz Center.
- ▶ Observe the additional display messages in the multifunction display (⊳ page 399).

↑ WARNING

If the 🎇 pass air bagom indicator lamp illuminates and remains illuminated when the weight of a typical adult or someone larger than a small individual has been detected on the passenger seat, the system then determines the occupant cannot be a child. Do not allow any occupant to use the passenger seat until the system has been repaired.

Problem

The PASS AIR BAG OFF indicator lamp does not illuminate and/or does not remain illuminated.

The front-passenger seat is:

- unoccupied
- · occupied with a weight up to or less than a typical 12month-old child in a standard child restraint system

Possible causes/consequences and ▶ Solutions

The OCS is malfunctioning.

- ▶ Make sure there is nothing between the seat cushion and the child seat.
- ▶ Check the installation of the child restraint system.
- ► Make sure that no objects are applying additional weight onto the seat.
- ► If the PASS AIR BAGOFF indicator lamp does not illuminate, have the OCS checked as soon as possible at an authorized Mercedes-Benz Center. Do not transport a child on the frontpassenger seat as long as the OCS is not functioning.
- ▶ Observe the additional display messages in the multifunction display (⊳ page 399).



♠ WARNING

If the 🥦 PASS AIR BAGOTT indicator lamp does not illuminate or remains out with the weight of a typical 12-month-old child in a standard child restraint or less, or is unoccupied, on the frontpassenger seat, do not transport a child on the front-passenger seat until the system has been repaired.



PRE-SAFE® (preventative occupant protection)

↑ WARNING

The PRE-SAFE® system reduces the impact of an accident on vehicle occupants, as long as their seat belts have been fastened correctly. Although your vehicle is equipped with a PRE-SAFE® system, the possibility of injury in the event of an accident cannot be ruled out. You should therefore always drive carefully and adapt your driving style to the prevailing road, weather and traffic conditions.

PRE-SAFE® takes preemptive measures to protect occupants in certain hazardous situations.

PRE-SAFE® intervenes:

- in emergency braking situations, e.g. if BAS is activated or, in vehicles with DISTRONIC PLUS, BAS PLUS intervenes powerfully
- if the radar sensor system detects an imminent danger of collision in certain situations (on vehicles with DISTRONIC PLUS)
- in critical driving situations, e.g. when physical limits are exceed and the vehicle understeers or oversteers severely

PRE-SAFE® takes the following measures depending on the hazardous situation detected:

- the front seat belts are pre-tensioned.
- it adjusts the seats if the front-passenger seat or the electrically adjustable outer seats in the rear are in unfavorable positions.
- vehicles with a multicontour seat or an active multicontour seat: the air pressure in the side bolsters on the seat cushion and the side bolsters on the backrest is increased.
- · vehicles with multicontour seats in the rear: the air pressure in the backrest side

- bolsters of the outer seats in the rear is increased.
- if the vehicle skids, the sliding sunroof/ panorama roof with power tilt/sliding panel and the side windows are closed so that only a small gap remains.

If the sliding sunroof, panorama roof with power tilt/sliding panel or a side window is obstructed during closing, the closing procedure is stopped. The obstructed sliding sunroof, panorama roof with power tilt/ sliding panel or side window opens again slightly.

If the hazardous situation passes without resulting in an accident, PRE-SAFE® slackens the belt pretensioning. The air pressure in the side bolsters on the multicontour seat/active multicontour seat is reduced again. All settings made by PRE-SAFE® can then be reversed.

If the seat belts are not released:

► Move the backrest back slightly, but only when the vehicle is stationary. The belt pretensioning is reduced and the locking mechanism is released.

↑ WARNING

Make sure that nobody can become trapped as you adjust the seat.

Make sure that there are no objects in the footwell or behind the seats when resetting the seats. There is a risk that the seats. and/or the objects could be damaged.

More information about seat-belt adjustment, a convenience function integrated into PRE-SAFE®, can be found in the "Seat-belt adjustment" section (⊳ page 60).

NECK-PRO head restraints/NECK-PRO luxury head restraints

NECK-PRO head restraints/NECK-PRO luxury head restraints increase protection of the driver's and front-passenger's head and



neck. In the event of a rear collision of a certain severity, the NECK-PRO head restraints/NECK-PRO luxury head restraints on the driver's and front-passenger seats are moved forwards and upwards. This provides better head support.

↑ WARNING

Do not attach any objects (e.g. a coat hanger) to the NECK-PRO head restraints / NECK-PRO luxury head restraints. Otherwise, the NECK-PRO head restraints/NECK-PRO luxury head restraints may not function properly and in the event of a rear-end collision may not offer the protection they are designed to provide.

↑ WARNING

Seat or head restraint covers can cause a malfunction when the NECK-PRO head restraints/NECK PRO luxury head restraints are activated or when the side impact air bags are deployed, or they can prevent this completely. The NECK-PRO head restraints/ NECK PRO luxury head restraints or side impact air bags can therefore not provide the intended protection. Do not use any seat or head restraint covers.

If the NECK-PRO head restraints/NECK-PRO luxury head restraints have been triggered in an accident, reset the NECK-PRO head restraints/NECK-PRO luxury head restraints on the driver's and front-passenger seats (⊳ page 56). Otherwise, the additional protection will not be available in the event of another rear-end collision, NFCK-PRO head restraints/NECK-PRO luxury head restraints that have been triggered are moved forwards and can no longer be adjusted.



/ WARNING

For your protection, drive only with properly positioned head restraints.

Adjust the head restraint so that it is as close to the head as possible and the center of the head restraint supports the back of the head at eye level. This will reduce the potential for

injury to the head and neck in the event of an accident or similar situation.

Resetting triggered NECK-PRO head restraints

Important safety notes



★ WARNING

For reasons of safety, have the NECK-PRO head restraints/NECK-PRO luxury head restraints checked at an authorized Mercedes-Benz Center after a rear-end collision.




↑ WARNING

When pushing back the NECK-PRO head restraint cushion, make sure your fingers do not become caught between the head restraint cushion and the cover. Failure to observe this could result in injuries.

NECK-PRO head restraints

1 Resetting the NECK-PRO head restraints requires a lot of strength. If you have difficulty resetting the NECK-PRO head restraints, have this work carried out at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.






- ▶ Press the base of the NECK-PRO head restraint cushion back in the direction of arrow (2) as far as it will go.
- ▶ Push the NECK-PRO head restraint cushion down into the guide in the direction of arrow (3) as far as it will go.
- ► Firmly fold the NECK-PRO head restraint cushion back in the direction of arrow (1) until it engages.
- ► Repeat this procedure for the second NFCK-PRO head restraint.

NECK-PRO luxury head restraints

1 If you have difficulty resetting the NECK-PRO luxury head restraints, have this work carried out at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.



- ▶ Remove resetting tool (1) from the vehicle tool kit in the trunk.
- ▶ Slide resetting tool ① into guide ② between the NECK-PRO luxury head restraint and the rear cover of the head restraint.
- ▶ Push resetting tool (1) downwards until you hear the head restraint deployment mechanism engage.
- ▶ Pull out resetting tool (1).
- ► Firmly press the NECK-PRO luxury head restraint cushion back (3) until it engages.

- Repeat this procedure for the second NECK-PRO luxury head restraint.
- ▶ Put resetting tool (1) back into the vehicle tool kit.

Seat belts

Important safety notes

The use of seat belts and infant and child restraint systems is required by law in all 50 states, the District of Columbia, the U.S. territories and all Canadian provinces.

Even where this is not the case, all vehicle occupants should have their seat belts fastened when the vehicle is in motion.

 For further information on infants and children traveling in the vehicle and on infant and child restraint systems, see "Children in the vehicle" (▷ page 62).

Always fasten your seat belt before driving off. Always make sure all of your passengers are properly restrained. You and your passengers should always wear seat belts.

Failure to wear and properly fasten and position your seat belt greatly increases your risk of injuries and their likely severity in an accident.

If you are ever in an accident, your injuries can be considerably more severe without your seat belt properly buckled. Without your seat belt buckled, you are much more likely to hit the interior of the vehicle or be ejected from it. You can be seriously injured or killed.

In the same crash, the possibility of injury or death is lessened if you are properly wearing your seat belt. The air bags can only protect as intended if the occupants are properly wearing their seat belts.

↑ WARNING

Never ride in a moving vehicle with the seat backrest in an excessively reclined position as this can be dangerous. You could slide under



the seat belt in a collision. If you slide under it, the seat belt would apply force at the abdomen or neck. That could cause serious or even fatal injuries. The seat backrest and seat belt provide the best restraint when the wearer is in a position that is as upright as possible and the seat belt is properly positioned on the body.

↑ WARNING

Never let more people ride in the vehicle than there are seat belts available. Make sure everyone riding in the vehicle is correctly restrained with a separate seat belt. Never use a seat belt for more than one person at a time.

↑ WARNING

Damaged seat belts or seat belts that have been subjected to stress in an accident must be replaced and their anchoring points must also be checked.

Only use seat belts which have been approved by Mercedes-Benz.

Do not make any modifications to the seat belts. This can lead to unintended activation of the ETDs or to their failure to activate when necessary.

Do not bleach or dye seat belts as this may severely weaken them. In a crash they may not be able to provide adequate protection.

Have all work carried out only by qualified technicians. Contact an authorized Mercedes-Benz Center.

Correct use of the seat belts

↑ WARNING

USE SEAT BELTS PROPERLY

· Seat belts can only work when used properly. Never wear seat belts in any other way than as described in this section, as

- that could result in serious injuries in the event of an accident.
- Each occupant should wear their seat belt at all times, because seat belts help reduce the likelihood of and potential severity of injuries in accidents, including rollovers. The integrated restraint system includes SRS (driver front air bag, front-passenger front air bag, side impact air bags, window curtain air bags for the side windows), Emergency Tensioning Devices, seat belt force limiters, and front seat knee bolsters. The system is designed to enhance the protection offered to properly belted

occupants in certain frontal (front air bags and ETDs) and side (side impact air bags, window curtain air bags, and ETDs) impacts which exceed preset deployment thresholds and in certain rollovers (window curtain air bags and ETDs).

 Never wear the shoulder belt under your arm, across your neck or off your shoulder. In a frontal crash, your body would move too far forward. That would increase the chance of head and neck injuries. The seat belt would also apply too much force to the ribs or abdomen, which could severely injure internal organs such as your liver or spleen.

Adjust the seat belt so that the shoulder section is located as close as possible to the middle of the shoulder. It should not touch the neck. Never pass the shoulder portion of the seat belt under your arm. For this purpose, you can adjust the height of the seat belt outlet.

- Position the lap belt as low as possible on your hips and not across the abdomen. If the lap belt is positioned across your abdomen, it could cause serious injuries in a crash.
- · Never wear seat belts over rigid or breakable objects in or on your clothing, such as eyeglasses, pens, keys etc., as these might cause injuries.



- Make sure the seat belt is always routed snugly. Take special care of this when wearing loose clothing.
- Never use a seat belt for more than one person at a time. Do not fasten a seat belt around a person and another person or other objects at the same time.
- Seat belts should not be worn twisted. In a crash, you would not have the full width of the seat belt to distribute impact forces.
 The twisted seat belt against your body could cause injuries.
- Pregnant women should also always use a lap-shoulder belt. The lap belt portion should be positioned as low as possible on the hips to avoid any possible pressure on the abdomen.
- Place the seat backrest in a position that is as upright as possible.
- Check your seat belt during travel to make sure it is properly positioned.
- Never place your feet on the instrument panel, dashboard, or on the seat. Always keep both feet on the floor in front of the seat.
- When using a seat belt to secure infant restraints, toddler restraints, or children in booster seats, always follow the child seat manufacturer's instructions.

↑ WARNING

Do not pass seat belts over sharp edges. They could tear.

Do not allow the seat belt to get caught in the door or in the seat adjustment mechanism. This could damage the seat belt.

Never attempt to make modifications to seat belts. This could impair the effectiveness of the seat belts.

Fastening seat belts

★ WARNING

According to accident statistics, children are safer when properly restrained on the rear

seats than on the front-passenger seat. Thus, we strongly recommend that children be placed in the rear seat whenever possible. Regardless of seating position, children 12 years old and under must be seated and properly secured in an appropriately sized child restraint system or booster seat recommended for the size and weight of the child. For additional information, see the "Children in the vehicle" section.

A child's risk of serious or fatal injuries is significantly increased if the child restraints are not properly secured in the vehicle and/or the child is not properly secured in the child restraint.



- ▶ Adjust the seat and move the backrest to an almost vertical position (> page 102).
- ▶ Pull the seat belt smoothly through belt sash guide ①.
- Without twisting it, guide the shoulder section of the seat belt across the middle of your shoulder and the lap section across your hips.



- ► Engage belt tongue ② in buckle ③. Seat-belt adjustment: if necessary, the driver's and front-passenger seat belts automatically adjust to the upper body (> page 60).
- ▶ If necessary, adjust the seat belt to the appropriate height (▷ page 60).
- ▶ If necessary, pull upwards on the shoulder section of the seat belt to tighten the belt across your body.

All seat belts except the driver's seat belt are equipped with a special seat belt retractor to securely fasten child restraint systems in the vehicle. For further information on special seat belt retractors, see (> page 64).

For more information about releasing the seat belt with release button ④, see "Releasing seat belts" (▷ page 60).

Seat belt adjustment

The seat-belt adjustment function adjusts the driver's and front-passenger seat belt to the upper body of the occupants.

The belt strap is tightened slightly when:

- you engage the belt tongue in the belt buckle and you then turn the SmartKey to position 2 in the ignition lock.
- the SmartKey is in position **2** in the ignition lock and you then engage the belt tongue in the buckle.

The seat-belt adjustment will apply a retraction force if any slack is detected between the occupant and the seat belt. Do not hold on to the seat belt tightly while it is adjusting. You can switch the seat-belt adjustment on and off in the on-board computer (> page 386).

The seat-belt adjustment is an integral part of the PRE-SAFE® convenience function. More information about PRE-SAFE® can be found in the "PRE-SAFE® (preventative occupant protection)" section (\triangleright page 55).

Belt height adjustment

You can adjust the seat belt height on the driver's seat and the front-passenger seat.



Adjust the height so that the upper part of the seat belt is routed across the center of your shoulder.

- ➤ To raise: slide the belt sash guide upwards. The belt sash guide engages in various positions.
- ► **To lower:** press and hold belt sash guide release (1).
- ► Slide the belt sash guide downwards.
- ► Release belt sash guide release ① and make sure that the belt sash guide has engaged.

The seat belts for the outer seats in the rear are adjusted automatically.

Releasing seat belts

- ▶ Press release button (4)(> page 59) and guide belt tongue (2) back towards belt sash guide (1).
- Make sure that the seat belt is fully rolled up. Otherwise, the seat belt or belt tongue will be trapped in the door or in the seat mechanism. This could damage the door, the door trim panel and the seat belt. Damaged seat belts can no longer fulfill their protective function and must be replaced. Consult an authorized Mercedes-Benz Center.



Belt warning for the driver and front passenger

Regardless of whether the driver and front passenger have fastened their seat belts already, the 🚁 seat belt warning lamp lights up for 6 seconds after every engine start. It then goes out if the driver and the front passenger have fastened their seat belts.

If the driver's seat belt is not fastened after the engine is started, an additional warning tone will sound. The warning tone goes out after approximately six seconds or once the driver's seat belt is fastened.

If the driver or front passenger have not fastened their seat belt after 6 seconds and the doors are closed, the (4) seat belt warning lamp lights up.

- until the driver or the front passenger have fastened their seat belts
- if a vehicle speed of 15 mph(25 km/h) is exceeded once, a warning tone with increasing intensity sounds additionally for a maximum of 60 seconds or until the driver or front passenger have fastened their seat belts.

If the driver or front passenger undo their seat belts during the journey, the ______ seat belt warning lamp lights up and the warning tone sounds again.

The warning tone ceases even if the driver or front passenger have still not fastened their seat belt after 60 seconds. The ** seat belt warning lamp stops flashing but continues to be lit.

Once the vehicle is stationary, the warning tone is reactivated and the seat belt warning lamp starts to flash again if the vehicle speed exceeds 15 mph(25 km/h) once.

The 🚁 seat belt warning lamp only goes out if:

 both the driver and the front passenger have fastened their seat belts. or

- the vehicle is stationary and a door is open.
- 1 For more information on the seat belt warning lamp, see "Warning and indicator lamps in the instrument cluster, seat belt" (> page 420).

Emergency Tensioning Devices, belt force limiters

The front seat belts and the outer seat belts in the rear are equipped with ETDs and seat belt force limiters.

The ETDs tighten the seat belts in an accident, pulling them close against the body.

The ETDs do not correct incorrect seat positions or incorrectly fastened seat belts.

The ETDs do not pull vehicle occupants back

towards the backrest.
Seat belt force limiters, when triggered, help

to reduce the peak force exerted by the seat belt on the vehicle occupant.

The seat belt force limiters for the front seats are synchronized with the front air bags. These take on a part of the deceleration force. Thus, the force exerted on the occupant is distributed over a greater area.

The ETDs can only be activated when:

- the ignition is switched on.
- the restraint systems are operational; see "SRS warning lamp" (▷ page 44).
- the belt tongue is engaged in the buckle on each of the lap-shoulder belts in the front.
- the front-passenger seat is occupied and the belt tongue is engaged in the buckle on the front-passenger side.

The ETDs on the outside seats in the rear compartment are triggered independently of the lock status of the seat belts.

The ETDs are triggered depending on the type and severity of an accident:

 if, in the event of a head-on or rear-end collision, the vehicle decelerates or accelerates rapidly in a longitudinal



direction during the initial stages of the impact

- if, in the event of a side impact, on the side opposite the impact the vehicle decelerates or accelerates rapidly in a lateral direction
- if, in certain situations where the vehicle overturns, the system determines that it can provide additional protection

If the air bags are deployed, you will hear a bang, and a small amount of powder may also be released. Only in rare cases will the bang affect your hearing. The powder that is released generally does not constitute a health hazard. The SRS warning lamp lights up.

♠ WARNING

Pyrotechnic Emergency Tensioning Devices that have been deployed must be renewed.

For your safety, when disposing of Emergency Tensioning Devices, always observe the safety instructions. These are available from any authorized Mercedes-Benz Center.

The PRE-SAFE® system has electrically operated reversible pre-tensioners that do not require replacement after activation.

If the front-passenger seat is not occupied, do not engage the seat belt tongue in the buckle on the frontpassenger seat. Otherwise, the Emergency Tensioning Device could be triggered in the event of an accident.

Automatic comfort-install feature

The front seat belts have an automatic comfort-install feature. In vehicles with a rear bench seat with electrically adjustable outer seats, the seat belts for the outer seats have an automatic comfort-install feature. The automatic comfort-install feature reduces the retraction force of the seat belts. This results in increased seat belt comfort.

Children in the vehicle

Child restraint systems

Important safety notes

We recommend that all infants and children be properly secured in an infant or child restraint system at all times while the vehicle is in motion.

The use of seat belts and infant and child restraint systems is required by law in all 50 states, the District of Columbia, the U.S. territories and all Canadian provinces.

Infants and children must always be seated in an appropriate infant or child restraint system recommended for the size and weight of the child. The infant or child restraint system must be properly secured in accordance with the manufacturer's instructions. All infant or child restraint systems must meet U.S. Federal Motor Vehicle Safety Standards 213 and 225 and Canadian Motor Vehicle Safety Standards 213 and 210.2.

An information label on the child restraint system indicates whether it meets these standards. This information is also provided in the installation instructions supplied with the child restraint system.

Always read and follow the manufacturer's instructions when using an infant or child restraint system or booster seat.

Observe all warning signs in the vehicle interior and on the infant or child restraint.



↑ WARNING

According to accident statistics, children are safer when properly restrained on the rear seats than on the front-passenger seat. Thus, we strongly recommend that children be placed in the rear seats whenever possible. Regardless of seating position, children 12 years old and under must be seated and properly secured in an appropriately sized child restraint system or booster seat recommended for the size and weight of the child.



The infant or child restraint system must be properly secured with the vehicle's seat belt, the seat belt and Top Tether strap, or lower anchors and Top Tether strap, fully in accordance with the child seat manufacturer's instructions.

Occupants, especially children, should always sit as upright as possible, wear the seat belt properly and use an appropriate sized infant restraint, toddler restraint, or booster seat recommended for the size and weight of the child.

Children can be killed or seriously injured by an inflating air bag. Note the following important information when circumstances require you to place a child in the frontpassenger seat:

- Your vehicle is equipped with air bag technology designed to deactivate the front-passenger front air bag in your vehicle when the system senses the weight of a typical 12-month-old child or less along with the weight of a standard appropriate child restraint on the front-passenger seat.
- A child in a rear-facing child restraint on the front-passenger seat will be seriously injured or even killed if the front-passenger front air bag inflates in a collision which could occur under some circumstances, even with the air bag technology installed in your vehicle. The only means to eliminate this risk completely is never to place a child in a rear-facing child restraint in the front-passenger seat. We therefore strongly recommend that you always place a child in a rear-facing child restraint on the rear
- If you install a rear-facing child restraint on the front-passenger seat, make sure the

 passalr Bac indicator lamp is illuminated, indicating that the front-passenger front air bag is deactivated. Should the
 passalr Bac indicator lamp not illuminate or go out while the restraint is installed, please check installation.

 Periodically check the
 passalr Bac indicator lamp

indicator lamp while driving to make sure the passair bacon indicator lamp is illuminated. If the passair bacon indicator lamp goes out or remains out, do not transport a child on the front-passenger seat until the system has been repaired.

A child in a rear-facing child restraint on the front-passenger seat will be seriously injured or even killed if the front-passenger front air bag inflates.

- If you place a child in a forward-facing child restraint on the front-passenger seat:
 - move the seat as far back as possible
 - use the proper child restraint recommended for the age, size and weight of the child
 - secure child restraint with the vehicle's seat belt according to the child seat manufacturer's instructions
- For children larger than a typical 12-monthold child, the front-passenger front air bag can be activated or deactivated.

MARNING MARNING

Infants and small children should never share a seat belt with another occupant. During an accident, they could be crushed between the occupant and seat belt.

A child's risk of serious or fatal injuries is significantly increased if the child restraints are not properly secured in the vehicle and/or the child is not properly secured in the child restraint.

Children too big for a toddler restraint must ride in seats using regular seat belts. Position the shoulder belt across the chest and shoulder, not face or neck. A booster seat may be necessary to achieve proper seat belt positioning for children over 41 lb (18 kg) until they reach a height where a lap/shoulder belt fits properly without a booster.

When the child restraint is not in use, remove it from the vehicle or secure it with the seat belt to prevent the child restraint from



becoming a projectile in the event of an accident.

If an infant or child is traveling in the vehicle:

- ▶ Secure the infant or child with an appropriate infant or child restraint recommended for the child's age and weight.
- ▶ Make sure that the infant or child is properly secured at all times while the vehicle is in motion.

↑ WARNING

When leaving the vehicle, always remove the SmartKey from the ignition lock. Always take the SmartKey with you and lock the vehicle. Do not leave children unattended in the vehicle, even if they are secured in a child restraint system, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury. The children could:

- injure themselves on parts of the vehicle
- be seriously or fatally injured through excessive exposure to extreme heat or cold
- injure themselves or cause an accident with vehicle equipment that can be operated even if the SmartKev is removed from the ignition lock or removed from the vehicle, such as seat adjustment, steering wheel adjustment, or the memory function

If children open a door, they could injure other persons or get out of the vehicle and injure themselves or be injured by following traffic. Do not expose the child restraint system to direct sunlight. The child restraint system's metal parts, for example, could become very hot, and the child could be burned on these parts.

↑ WARNING

Do not carry heavy or hard objects in the passenger compartment or trunk unless they are firmly secured in place.

Unsecured or improperly positioned cargo increases a child's risk of injury in the event of

- · strong braking maneuvers
- · sudden changes of direction
- · an accident

Special seat belt retractor

All seat belts except the driver's seat belt are equipped with a special seat belt retractor. When activated, the special seat belt retractor ensures the seat belt will not slacken once the child restraint system has been secured.

Installing a child restraint system:

- ► Always comply with the manufacturer's installation instructions.
- ▶ Pull the seat belt smoothly from the inertia reel.
- ▶ Engage the seat belt tongue in the belt buckle.

Activating the special seat belt retractor:

belt retractor is enabled.

- ▶ Pull the seat belt out fully and let the inertia reel retract it again. While the seat belt is retracting, you should hear a ratcheting sound. The special seat
- ▶ Push down on the child restraint system to take up any slack.

Removing a child restraint system/ deactivating the special seat belt retractor:

- ► Always comply with the manufacturer's installation instructions.
- ▶ Press the seat belt release button and guide the belt tongue to the belt outlet. The special seat belt retractor is deactivated.

↑ WARNING

Never release the seat belt buckle while the vehicle is in motion, since the special seat belt retractor will be deactivated.



LATCH-type (ISOFIX) child seat anchors in the rear

↑ WARNING

Children that are too large for a child restraint must travel in seats using normal seat belts. Position shoulder belt across the chest and shoulder, not face or neck.

In order to attain the correct seating position for children weighing over 41 lb (18 kg), it may be necessary to use a booster seat until they reach a height where a normal lap/shoulder seat belt lies properly across their bodies without the need for a booster seat.

Install the child restraint system according to the manufacturer's instructions.

The child restraint system must be installed firmly on both brackets.


An incorrectly installed child restraint system can come loose in the event of an accident. causing the child to be severely or fatally injured.

Child restraint systems/child restraint retaining brackets that are damaged or have suffered damage due to an impact must be replaced.

LATCH-type (ISOFIX) is a standardized securing system for specially designed child restraint systems on the rear seats. Securing rings for two LATCH-type (ISOFIX) child restraint systems are installed on the left and right of the rear seats.

Secure non LATCH-type (ISOFIX) child restraint systems using the vehicle's seat belt system. Always install child restraint systems according to the manufacturer's instructions.

■ Vehicles with a center seat in the rear: when installing the LATCH-type (ISOFIX) child restraint system, make sure that the seat belt for the center seat does not get trapped. Otherwise, the seat belt could be damaged.



Installation instructions (1) indicate the installation location of securing rings (2).

- ▶ Move the backrest of the electrically adjustable rear seat to an upright position (⊳ page 104).
- ► Fold upholstery cover (3) and the Velcro fastener upwards.
- ► Turn installation aid (4) to a vertical position to prevent upholstery cover (3) from folding down.
- ▶ Install the LATCH-type (ISOFIX) child restraint systems on both securing rings (2). Comply with the manufacturer's instructions when installing the LATCHtype (ISOFIX) child restraint system.

↑ WARNING

Vehicles with rear power seats:

Never change the rear seat position after installing the child restraint. This could

- · damage the child restraint
- introduce undesirable slack or tension into the seat belt
- · loosen the child restraint
- misposition the child restraint

All of the above will lessen the effectiveness of the child restraint and thus increase the chance or severity of injury in an accident.

Top Tether

Top Tether provides an additional connection between the child restraint system secured




with ISOFIX and the rear seat. It helps reduce the risk of injury even further.

The Top Tether anchorage points are located in the rear compartment behind the head restraints.



- ► Vehicles with electrically adjustable rear seats: move the rear seat backrests to an upright position (⊳ page 104).
- ▶ Remove respective covering cap (1) of the Top Tether anchorage.
- ▶ Place covering cap (1) in a suitable place (e.g. in the glove box).



- ▶ Move the head restraint upwards.
- ▶ Route Top Tether belt (4) under the head restraint between the two head restraint bars.
- ► Hook Top Tether hook ③ of Top Tether belt (4) into Top Tether anchorage (2).

Ensure that:

- Top Tether hook (3) is hooked into Top Tether anchorage (2) as shown.
- Top Tether belt (4) is not twisted.
- Top Tether belt (4) can move freely between the rear seat backrest and the head restraint.
- ▶ Install the LATCH-type (ISOFIX) child restraint system with Top Tether. Comply with the manufacturer's installation instructions when doing so. Make sure that Top Tether belt (4) is tight.

The child restraint system with Top Tether belt (4) has been removed:

► Slide covering cap (1) onto Top Tether anchorage (2).

♠ WARNING

Vehicles with rear power seats:

Never change the rear seat position after installing the child restraint. This could

- · damage the child restraint
- introduce undesirable slack or tension into the seat belt
- · loosen the child restraint
- misposition the child restraint All of the above will lessen the effectiveness of the child restraint and thus increase the chance or severity of injury in an accident.

Child-proof locks

Important safety notes



↑ WARNING

Activate the child-proof locks for the rear doors and the override switch for the rear windows when children are traveling in the vehicle.



Children could injure themselves or others while the vehicle is in motion if, for example, they:

- open the doors
- open the side windows
- · adjust the seats
- operate the cigarette lighter

↑ WARNING

When leaving the vehicle, always remove the SmartKey from the ignition lock. Always take the SmartKey with you and lock the vehicle. Do not leave children unattended in the vehicle, even if they are secured in a child restraint system, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury. The children could:

- injure themselves on parts of the vehicle
- be seriously or fatally injured through excessive exposure to extreme heat or cold
- injure themselves or cause an accident with vehicle equipment that can be operated even if the SmartKey is removed from the ignition lock or removed from the vehicle, such as seat adjustment, steering wheel adjustment, or the memory function

If children open a door, they could injure other persons or get out of the vehicle and injure themselves or be injured by following traffic.

Do not expose the child restraint system to direct sunlight. The child restraint system's metal parts, for example, could become very hot, and the child could be burned on these parts.

Child-proof locks for the rear doors

↑ WARNING

Children could open a rear door from inside the vehicle. This could result in serious injuries or an accident. Therefore, when children ride in the rear always secure the rear doors with the child-proof locks.

You secure each door individually with the child-proof locks on the rear doors. A door secured with a child-proof lock cannot be opened from inside the vehicle. When the vehicle is unlocked, the door can be opened from the outside.



- ► To activate: press the child-proof lock lever up in the direction of arrow (1).
- ▶ Make sure that the child-proof locks are working properly.
- ► To deactivate: press the child-proof lock lever down in the direction of arrow (2).

Override feature for the rear side windows




↑ WARNING

When children ride on the vehicle's rear seats. activate the override switch. Otherwise, the children could be injured, e.g. by trapping themselves in the rear side window.

For the rear compartment, you can deactivate operation of:

- the rear side windows
- the cigarette lighter in the rear
- · adjustment of the front-passenger seat from the rear compartment
- the sunblinds:
 - in the roof
 - of the rear window
 - of the rear side windows





▶ To activate/deactivate: press button ①. If indicator lamp ② is lit, the rearcompartment functions are deactivated. The rear side windows can then only be operated using the switches on the driver's door. If indicator lamp ② is off, the functions are enabled. The rear side windows can be operated using the switches in the rear compartment.

Panic alarm



► To activate: press PANIC button ① for at least one second.

An alarm sounds and the exterior lighting flashes.

► To deactivate: press PANIC button ① again.

or

- ► Insert the SmartKey into the ignition lock. or
- ▶ Press the KEYLESS-GO Start/Stop button.

The KEYLESS-GO key must be in the vehicle.

1 USA only:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

The product label with FCC ID and IC certification number can be found in the battery case of the SmartKey.

1 Canada only:

This device complies with RSS-Gen of Industry Canada. Operation is subject to the following two conditions:

- 1. This device may not cause interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

The product label with FCC ID and IC certification number can be found in the battery case of the SmartKey.

Driving safety systems

Driving safety systems overview

In this section, you will find information about the following driving safety systems:

- ABS (Anti-lock Braking System)
- BAS (Brake Assist System)
- BAS PLUS (Brake Assist System Plus*)
- ESP® (Electronic Stability Program)
- EBD (**E**lectronic **B**rake force **D**istribution)



- ADAPTIVE BRAKE
- PRF-SAFF[®] Brake

Important safety notes

↑ WARNING

The following factors increase the risk of accidents:

- · Excessive speed, especially in turns
- · Wet and slippery road surfaces
- Following another vehicle too closely

The driving safety systems described in this section cannot reduce these risks or prevent the natural laws of physics from acting on the vehicle. They cannot increase braking or steering efficiency beyond that afforded by the condition of the vehicle brakes and tires or the traction afforded.

Only a safe, attentive, and skillful driver can prevent accidents.

The capabilities of a vehicle equipped with the driving safety systems described in this section must never be exploited in a reckless or dangerous manner which could jeopardize the user's safety or the safety of others.

Always adjust your driving style to the prevailing road and weather conditions and keep a safe distance to other road users and objects on the street.

If a driving system malfunctions, other driving safety systems may also switch off. Observe indicator and warning lamps that may come on as well as messages in the multifunction display that may appear.

↑ WARNING

HYBRID vehicles: It is imperative that you read the HYBRID Supplemental Operating Instructions included in your vehicle literature portfolio. You may otherwise not receive all necessary safety information and warning for the operation of your vehicle.

Please note that the driving safety systems described only work as effectively as possible when there is adequate contact between the tires and the road surface. Pay particular attention to the information regarding tires, recommended minimum tire tread depths etc. in the "Wheels and tires" section (> page 490).

In wintry driving conditions, always use winter tires (M+S tires) and if necessary, snow chains. Only in this way will the driving safety systems described in this section work as effectively as possible.

ABS (Anti-lock Braking System)

Important safety notes



ABS regulates brake pressure in such a way that the wheels do not lock when you brake. This allows you to continue steering the vehicle when braking.

ABS works from a speed of about 5 mph(8 km/h) upwards, regardless of roadsurface conditions. ABS works on slippery surfaces, even when you only brake gently.



↑ WARNING

If the ABS malfunctions, other driving systems such as the BAS or the ESP® are also switched off. Observe indicator and warning lamps that may come on as well as messages in the multifunction display that may appear. If the ABS malfunctions, the wheels may lock during hard braking, reducing the steering capability and extending the braking distance.

The warning lamp in the instrument cluster lights up when the ignition is switched on. It goes out when the engine is running.

Braking

If ABS intervenes when braking, you will feel a pulsing in the brake pedal.



- ► If ABS intervenes: continue to depress the brake pedal with force until the braking situation is over.
- ► To make a full brake application: depress the brake pedal with full force.

The pulsating brake pedal can be an indication of hazardous road conditions, and functions as a reminder to take extra care while driving.

↑ WARNING

Do not pump the brake pedal. Use firm, steady brake pedal pressure instead. Pumping the brake pedal defeats the purpose of the ABS and significantly reduces braking effectiveness.

BAS (Brake Assist System)

① Observe the "Important safety notes" section (▷ page 69).

BAS operates in emergency braking situations. If you depress the brake pedal quickly, BAS automatically boosts the braking force, thus shortening the stopping distance.

 Keep the brake pedal firmly depressed until the emergency braking situation is over.
 ABS prevents the wheels from locking.

The brakes will function as usual once you release the brake pedal. BAS is deactivated.

⚠ WARNING

If the BAS malfunctions, the brake system still functions, but without the additional brake boost available that the BAS would normally provide in an emergency braking maneuver. Therefore, the braking distance may increase.

BAS PLUS (Brake Assist System Plus)

BAS PLUS is only available in vehicles equipped with DISTRONIC PLUS.

① Observe the "Important safety notes" section (▷ page 69).

At speeds above approximately 4 mph (7 km/h), BAS PLUS assists you when braking in hazardous situations and uses the radar sensor system to evaluate the traffic conditions.

1 This device has been approved by the FCC as a "Vehicular Radar System". The radar sensor system is intended for use in an automotive radar system only. Removing, altering or tampering with the device will void any warranties, and is not permitted by the FCC. Do not tamper with, alter, or use in any non-approved way.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

With the help of the radar sensor system, BAS PLUS can detect obstacles that are in the path of your vehicle for an extended period of time.

At speeds up to approximately 40 mph (70 km/h), BAS PLUS can also detect stationary obstacles, for example stopped or parked vehicles.

Should you approach an obstacle and BAS PLUS has detected a risk of collision, BAS PLUS calculates the braking force necessary to avoid a rear-end collision.

- At speeds up to approximately 20 mph(30 km/h): should you apply the brakes forcefully, BAS PLUS will automatically increase the braking force to a level suitable for the traffic conditions.
- At speeds up to approximately
 20 mph(30 km/h): should you apply the brakes, BAS PLUS is activated. Braking is performed as late as possible.

If BAS PLUS demands particularly high braking force, preventative passenger protection measures (PRE-SAFE®) are activated simultaneously.

 Keep the brake pedal depressed until the emergency braking situation is over.
 ABS prevents the wheels from locking.



The brakes will work normally again if:

- you release the brake pedal.
- there is no longer any danger of a rear-end collision.
- no obstacle is detected in front of your vehicle.

BAS PLUS is then deactivated.

For BAS PLUS to assist you when driving, the radar sensor system must be switched on and operational, see "Radar sensor system" in the index.

↑ WARNING

BAS PLUS cannot always clearly identify objects and complex traffic situations. BAS PLUS cannot intervene in these cases.

There is a risk of an accident. Always pay careful attention to the traffic situation and be ready to brake.

In particular, the detection of obstacles can be impaired if there is:

- dirt on the sensors or anything else covering the sensors
- snow or heavy rain
- interference by other radar sources
- the possibility of strong radar reflections, for example in parking garages
- a narrow vehicle traveling in front, e.g. a motorbike
- a vehicle traveling in front on a different line

MARNING

BAS PLUS does not react:

- to people or animals
- · to oncoming vehicles
- to crossing traffic
- in curves

As a result, BAS PLUS cannot intervene in critical situations. There is a risk of an accident. Always pay careful attention to the traffic situation and be ready to brake.

Following damage to the front end of the vehicle, have the configuration and operation

of the radar sensors checked at a qualified specialist workshop. This also applies to collisions at low speeds where there is no visible damage to the front of the vehicle.

If BAS PLUS is not available due to a malfunction in the radar sensor system, the brake system remains available with full brake boosting effect and BAS.

ESP® (Electronic Stability Program)

Important safety notes

See the "Important safety notes" section
 (▷ page 69).

If ESP® detects that the vehicle is deviating from the direction desired by the driver, one or more wheels are braked to stabilize the vehicle. If necessary, the engine output is also modified to keep the vehicle on the desired course within physical limits. ESP® assists the driver when pulling away on wet or slippery roads. ESP® can also stabilize the vehicle during braking.

If ESP® intervenes, the ESP® warning lamp flashes in the instrument cluster.

↑ WARNING

Under no circumstances should you deactivate ESP® when the ESP® warning lamp in the instrument cluster flashes. Proceed as follows:

- when driving off, apply as little throttle as possible.
- while driving, ease up on the accelerator pedal.
- adapt your speed to suit the prevailing road and weather conditions.

Failure to observe these guidelines could cause the vehicle to skid. ESP® cannot prevent accidents resulting from excessive speed.

■ The ignition must be switched off if the vehicle is being towed with the front or rear



axle raised. Otherwise, ESP® may intervene and damage the brake system.

- Do not tow vehicles with 4MATIC with the front or rear axle raised.
- 1 Only use wheels with the recommended tire sizes. Only then will ESP® function properly.

ETS/4ETS (Electronic Traction System)



↑ WARNING

Observe "Important safety notes" (⊳ page 68).

Traction control is part of ESP®.

Traction control brakes the drive wheels individually if they spin. This enables you to pull away and accelerate on slippery surfaces, for example if the road surface is slippery on one side. On vehicles with 4MATIC, more drive torque is also transferred to the wheel or wheels with traction.

Traction control remains active if you deactivate FSP®.

Deactivating/activating ESP®

Observe the "Important safety notes" section (⊳ page 69).



♠ WARNING

ESP® should not be deactivated during normal driving other than in the circumstances described below. Disabling the system will reduce vehicle stability in driving maneuvers.

Do not deactivate ESP® when the emergency or spare wheel is mounted.



↑ WARNING

S 63 AMG: ESP® should not be deactivated during normal driving.

Deactivating the system results in the following:

- no restriction to the engine torque
- loss of system-supported traction control

"ESP OFF" is designed for driving on closed tracks when the vehicle's own oversteering and understeering characteristics are desired and requires an extremely qualified and experienced driver who is able to handle these critical driving situations.

You could lose control of your vehicle and cause an accident.

Beware of these limits if you deactivate ESP®.

Do not deactivate ESP® when the emergency or spare wheel is mounted.

ESP® is activated automatically when the engine is started.

1 Vehicles with ECO start/stop function: the ECO start/stop function switches the engine off automatically when the vehicle comes to a stop. The engine starts automatically when the driver wants to pull away again. ESP® remains in its previously selected status. Example: if ESP® was deactivated before the engine was switched off, ESP® remains deactivated when the engine is switched on again.

It may be best to deactivate ESP® in the following situations:

- · when using snow chains
- in deep snow
- · on sand or gravel



↑ WARNING

Switch on ESP® immediately if one of the previously stated conditions is no longer met. Otherwise, ESP® cannot stabilize the vehicle if it begins to lurch or when a wheel spins.



When you deactivate ESP®:

- ESP® no longer improves driving stability.
- the engine's torque is no longer limited and the drive wheels can spin. The spinning of the wheels results in a cutting action, which provides better grip.
- · traction control is still activated.
- ESP® still provides support when you brake.

If ESP® is deactivated and one or more wheels start to spin, the ESP® warning lamp in the instrument cluster flashes. In such situations, ESP® will not stabilize the vehicle.

▶ To deactivate:(> page 384). The ESP® OFF warning lamp in the instrument cluster lights up.

↑ WARNING

When the ESP® OFF warning lamp is lit, ESP® is deactivated.

If the ESP® warning lamp and the ESP® OFF warning lamp remain lit, ESP® is not available due to a malfunction.

When ESP® is deactivated or not operational, vehicle stability in standard driving maneuvers is reduced.

Adapt your speed and driving to the prevailing road conditions and to the non-operating status of the ESP®.

- Avoid spinning the driven wheels for an extended period with ESP® deactivated. You could otherwise damage the drivetrain.
- ► To activate:(> page 384). The ESP® OFF warning lamp in the instrument cluster goes out.

EBD (electronic brake force distribution)

Observe the "Important safety notes" section (⊳ page 69).

EBD monitors and controls the brake pressure on the rear wheels to improve driving stability while braking.



↑ WARNING

If EBD has malfunctioned, the braking system remains available with full brake boosting effect. However, the rear wheels can still lock. e.g. under full braking. This could cause you to lose control of your vehicle and cause an accident. You should therefore adapt your driving style to the different handling characteristics.

▶ Observe the notes on warning and indicator lamps (⊳ page 423) as well as display messages (⊳ page 392).

ADAPTIVE BRAKE

ADAPTIVE BRAKE enhances braking safety and offers increased braking comfort. In addition to the braking function, ADAPTIVE BRAKE also has the HOLD function (⊳ page 342) and hill start assist (⊳ page 306). For further information, see Driving tips (⊳ page 327).

PRE-SAFE® Brake

PRE-SAFE® Brake is only available in vehicles with DISTRONIC PLUS.

 Observe the "Important safety notes" section (⊳ page 69).

PRE-SAFE® Brake can help you to minimize the risk of a frontal collision with a vehicle ahead or reduce the effects of such a collision. If PRE-SAFE® Brake has detected a risk of collision, you will be warned visually and acoustically as well as by automatic braking. PRE-SAFE® Brake cannot prevent a collision without your intervention.

At speeds above approximately 4 mph (7 km/h), this function warns you when you are rapidly approaching the vehicle in front. An intermittent warning tone will



then sound and the distance warning lamp in the instrument cluster will light up.

▶ Brake immediately in order to increase the distance from the vehicle in front.

► Take evasive action provided it is safe to do

If the driver and front passenger have their seat belt fastened. PRE-SAFE® Brake can also brake the vehicle automatically at speeds from approximately 4 mph (7 km/h) to approximately 124 mph (200 km/h).

Due to the nature of the system, particularly complicated driving conditions may cause unnecessary warnings or the unnecessary intervention of PRE-SAFE® Brake. To stop the braking action, you can either depress the accelerator pedal further, activate kickdown or release the brake pedal.

The braking action of PRE-SAFE® Brake is ended automatically if:

- you maneuver to avoid the obstacle.
- there is no longer any danger of a rear-end collision.
- there is no longer an obstacle detected in front of your vehicle.
- 1 USA only: this device has been approved by the FCC as a "Vehicular Radar System". The radar sensor system is intended for use in an automotive radar system only. Removing, altering or tampering with the device will void any warranties, and is not permitted by the FCC. Do not tamper with, alter, or use in any non-approved way. Any unauthorized modification to this device could void the user's authority to operate the equipment.
- this device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:
 - 1. This device may not cause interference, and

2. this device must accept any interference received, including interference that may cause undesired operation of the device.

Removal, tampering, or altering of the device will void any warranties, and is not permitted. Do not tamper with, alter, or use in any non-approved way.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

With the help of the radar sensor system, PRE-SAFE® Brake can detect obstacles that are in front of your vehicle for an extended period of time.

At speeds up to approximately 40 mph (70 km/h), PRE-SAFE® Brake can also react to stationary obstacles, for example stopped or parked vehicles.

If you approach an obstacle and PRE-SAFE® Brake detects a risk of collision, the system will initially alert you both visually and acoustically. If you do not brake or take evasive action, the system will warn you by automatically braking the vehicle gently. If there is an increased risk of collision, preventative passenger protection measures (PRE-SAFE®) are activated (▷ page 55). If the risk of collision remains at speeds of over 20 mph(30 km/h) and you do not brake, take evasive action or accelerate significantly, the vehicle may perform automatic braking up to emergency braking. Automatic emergency braking is not performed until immediately prior to an accident that can no longer be avoided.



↑ WARNING

Even if PRE-SAFE® Brake slows the vehicle before an imminent rear-end collision, the system cannot avert a collision without the intervention of the driver. There is a risk of an accident. Brake according to the situation or take evasive action. Delayed intervention by the driver can lead to an accident.



↑ WARNING

PRE-SAFE® Brake cannot always detect complex traffic situations properly. In these cases, PRE-SAFE(R) Brake may:

- give an unnecessary warning and then brake the vehicle
- neither give a warning nor intervene

There is a risk of an accident. Always pay particular attention to the traffic situation and be ready to brake, especially if PRE-SAFE(R) Brake warns you. Terminate the intervention in a non-critical driving situation.

In particular, the detection of obstacles can be impaired if there is:

- dirt on the sensors or anything else covering the sensors
- · snow or heavy rain
- interference by other radar sources
- the possibility of strong radar reflections, for example in parking garages
- a narrow vehicle traveling in front, e.g. a motorbike
- a vehicle traveling in front on a different line

↑ WARNING

PRE-SAFE® Brake does not react:

- to people or animals
- to oncoming vehicles
- · to crossing traffic
- in curves

As a result, PRE-SAFE® Brake cannot intervene in critical situations. There is a risk of an accident. Always pay careful attention to the traffic situation and be ready to brake.

In order to maintain the appropriate distance to the vehicle in front and thus prevent a collision, you must apply the brakes yourself. ▶ To activate/deactivate: activate or deactivate PRE-SAFE® Brake in the onboard computer (⊳ page 384). After activation, the 5! symbol is displayed on the left in the instrument cluster.

For PRE-SAFE® Brake to assist you when driving, the radar sensor system must be switched on (⊳ page 387) and operational. Following damage to the front end of the vehicle, have the configuration and operation of the radar sensors checked at a qualified specialist workshop. This also applies to collisions at low speeds where there is no visible damage to the front of the vehicle.

Theft deterrent locking systems

Immobilizer

The immobilizer prevents your vehicle from being started without the correct SmartKey. When leaving the vehicle, always take the SmartKey with you and lock the vehicle. The engine can be started by anyone with a valid SmartKey that is left inside the vehicle.

- ▶ To activate with the SmartKey: remove the SmartKey from the ignition lock.
- ▶ To activate with KEYLESS-GO: switch the ignition off and open the driver's door.
- ▶ To deactivate: switch on the ignition.
- 1 The immobilizer is always deactivated when you start the engine.

ATA (Anti-Theft Alarm system)


A visual and audible alarm is triggered if the alarm system is armed and you open:

- the vehicle with the mechanical key
- the trunk lid
- the hood



The alarm is not switched off, even if you close the open door that has triggered it, for example.

- i If the alarm stays on for more than 30 seconds, the emergency call system mbrace (USA only) or TELE AID (Canada only) initiates a call to the Customer Assistance Center automatically. The emergency call system initiates the call provided that:
 - you have subscribed to the mbrace/ TELE AID service.
 - the mbrace/TELE AID service has been activated properly.
 - the required mobile phone, power supply and GPS are available.



- ➤ To arm: lock the vehicle with the SmartKey or KEYLESS-GO.
 Indicator lamp (1) flashes. The alarm
 - system is armed after approximately 30 seconds.
- ► To deactivate: unlock the vehicle with the SmartKey or KEYLESS-GO.
- ➤ To stop the alarm using the SmartKey: insert the SmartKey into the ignition lock. The alarm is switched off.

or

► Press the or button on the SmartKey.

The alarm is switched off.

➤ To stop the alarm using KEYLESS-GO: grasp the outside door handle. The SmartKey must be outside the vehicle. The alarm is switched off.

01

Press the Start/Stop button on the dashboard. The SmartKey must be inside the vehicle.

The alarm is switched off.



Useful information	
SmartKey	78
Doors	85
Trunk	88
Side windows	92
Sliding sunroof	95

Useful information

- 1 This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- Please read the information on qualified specialist workshops (⊳ page 31).

SmartKey

Important safety notes

↑ WARNING

When leaving the vehicle, always remove the SmartKey from the ignition lock. Always take the SmartKey with you and lock the vehicle. Do not leave children unsupervised in the vehicle, even if they are secured in a child restraint system, and do not give them access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury. They could:

- injure themselves on vehicle parts
- be seriously or fatally injured by extreme heat or cold
- injure themselves or have an accident with vehicle equipment that may still be in operation even after the SmartKey has been removed from the ignition, such as the seat adjustment, steering wheel adjustment or memory function.

If children open a door, they could cause severe or even fatal injury to other persons; if they get out of the vehicle, they could injure themselves when doing so or be seriously or even fatally injured by any passing traffic.

Do not expose the child restraint system to direct sunlight. The child restraint system's metal parts, for example, could become very hot, and a child could be burned on these parts.

/ WARNING

If a key ring is too heavy or too large, the weight acting on the key could cause it to turn in the ignition lock or catch on the steering wheel. This could cause the engine to be switched off suddenly. You could lose control of the vehicle and cause an accident. Do not attach any heavy or large key rings to the key that is inserted in the ignition.

General notes

If you cannot lock or unlock the vehicle with the SmartKey, either the battery in the SmartKey is discharged, the SmartKey is faulty or the starter battery is discharged.

- ► Check the battery in the SmartKey and replace it if necessary (⊳ page 82).
- ▶ Unlock the driver's door using the mechanical key (⊳ page 87).
- ► Lock the vehicle (> page 88).
- ► Have the starter battery and the battery contacts checked at a qualified specialist workshop.

If the SmartKey is faulty, contact Roadside Assistance or a qualified specialist workshop.

SmartKey functions

General notes



1 USA only:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.



Any unauthorized modification to this device could void the user's authority to operate the equipment.

The Product label with FCC ID and IC certification number can be found in the battery case of the SmartKey.

1 Canada only:

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

- 1. This device may not cause interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation of the device.


Any unauthorized modification to this device could void the user's authority to operate the equipment.

The Product label with FCC ID and IC certification number can be found in the battery case of the SmartKey.

Locking and unlocking centrally

The SmartKey centrally locks/unlocks:

- · the doors
- · the trunk lid
- the fuel filler flap



- ① Locks the vehicle
- ② [3] Unlocks the trunk lid
- 3 Unlocks the vehicle

When unlocking, the turn signals flash once. When locking, they flash three times.

When it is dark, the surround lighting also comes on if it is activated in COMAND (> page 264).

If you activate the acoustic locking confirmation function, you will hear the following, depending on the date of production of the vehicle:

- an acoustic signal when locking or
- one acoustic signal when unlocking and three when locking.

The audible signal can be activated and deactivated using the on-board computer (> page 386).

▶ To unlock centrally: press the button.

If you do not open the vehicle within approximately 40 seconds of unlocking:

- the vehicle is locked again.
- the theft deterrent locking system is armed again.
- ▶ To lock centrally: press the 😈 button.

KEYLESS-GO

General notes

① USA only:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

The Product label with FCC ID and IC certification number can be found in the battery case of the SmartKey.

1 Canada only:



This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.


Any unauthorized modification to this device could void the user's authority to operate the equipment.

The Product label with FCC ID and IC certification number can be found in the battery case of the SmartKey.

Important notes on the use of KEYLESS-GO

- The KEYLESS-GO key can be used like a conventional key.
- You can combine KEYLESS-GO functions with those of a conventional key, e.g. unlock with KEYLESS-GO and lock with the button.
- Always carry your KEYLESS-GO key on your person.
- Do not keep the KEYLESS-GO key together with:
 - electronic devices, e.g. a mobile phone or another key
 - metallic objects, e.g. coins or metal foil. This can affect the functionality of KEYLESS-GO.
- When locking and unlocking using KEYLESS-GO, the distance between the SmartKey and the corresponding door handle must not exceed 3 ft (1 m).
- If the vehicle is parked for more than 72 hours, the KEYLESS-GO function is deactivated. Pull the outer door handle and switch on the ignition to reactivate the KEYLESS-GO function.
- If the KEYLESS-GO key is removed from the vehicle, it is possible that the system may not recognize the SmartKey. The vehicle

- can then not be locked or started using KEYLESS-GO.
- If the KEYLESS-GO key has been removed from the vehicle, e.g. if a passenger leaves the vehicle with a KEYLESS-GO key:
 - if the start/stop button is pressed or if an attempt is made to lock the vehicle with the locking button on the outer door handle, the Key Not Detected message appears in the multifunction display
 - when the engine is running, the red Key Not Detected message appears in the multifunction display as you pull away.
 Find the KEYLESS-GO key and change its position in the vehicle. Carry the KEYLESS-GO key in your shirt pocket, for example.
- If you have started the engine with the Start/Stop button, you can switch it off again by:
 - pressing the Start/Stop button again
 - inserting the KEYLESS-GO key into the ignition lock if the vehicle is stationary and the automatic transmission is in park position P.
- You could unlock the vehicle by mistake if the distance between the KEYLESS-GO key and the vehicle is less than 3 ft (1 m) and:
 - an exterior door handle is hit by a water jet
 or
 - you clean an exterior door handle.
- Bear in mind that the engine can be started by any of the vehicle occupants if there is a KEYLESS-GO key in the vehicle.





- ➤ To unlock the vehicle: pull the door handle.
- ► To lock the vehicle: touch sensor surface ①.
- ► Convenience closing feature: touch recessed sensor surface ② for an extended period (> page 94).

If you pull on the handle of the trunk lid, only the trunk of the vehicle is unlocked.

Changing the settings of the locking system

You can change the setting of the locking system in such a way that only the driver's door and the fuel filler flap are unlocked. This is useful if you frequently travel on your own.

- ► To change the setting: press and hold down the and buttons simultaneously for approximately six seconds until the battery check lamp (> page 82) flashes twice.
- 1 If the setting of the locking system is changed within the signal range of the vehicle, pressing the or button locks or unlocks the vehicle.

The SmartKey now functions as follows:

- ► To unlock the driver's door: press the button once.
- ► To unlock centrally: press the button twice.
- ► To lock centrally: press the 🕡 button.

The KEYLESS-GO function is changed as follows:

- ► To unlock the driver's door: pull the door handle on the driver's door.
- ➤ To unlock centrally: pull the door handle on the front-passenger door or on the rear doors.
- ► To lock centrally: touch the outer sensor surface on one of the door handles.

Restoring the factory settings

▶ Press the and buttons simultaneously for approximately six seconds until the battery check lamp flashes twice.

Mechanical key

General notes

If you use the mechanical key to unlock and open the driver's door or the trunk lid, the anti-theft alarm system will be triggered (> page 75).

There are several ways to turn off the alarm:

► To turn the alarm off with the SmartKey: press the or button on the SmartKey.

OI

- ► Insert the SmartKey into the ignition lock. or
- ► To deactivate the alarm with KEYLESS-GO: press the Start/Stop button in the ignition lock. The SmartKey must be in the vehicle.

or

Lock or unlock the vehicle using KEYLESS-GO. The SmartKey must be outside the vehicle.

Removing the mechanical key





▶ Push release catch ① in the direction of the arrow and at the same time, remove mechanical key ② from the SmartKey.

SmartKey battery

Important safety notes

Have the batteries changed at a qualified specialist workshop.

MARNING

Batteries contain toxic substances.

Swallowing batteries can lead to serious health issues or death.

Keep batteries out of the reach of children. Seek medical attention immediately if a battery is swallowed.

↑ WARNING

The SmartKey batteries contain perchlorate material, which may require special handling and regard for the environment. Observe government disposal guidelines. California residents, see www.dtsc.ca.gov/HazardousWaste/Perchlorate/index.cfm.

Checking the battery



► Press the or button.

The battery is working properly if battery check lamp (1) lights up briefly

If battery check lamp ① does not light up briefly during the test, the battery is discharged.

- ► Changing the battery (> page 82)
- 1 You can obtain the battery at a qualified specialist workshop.
- i If the SmartKey battery is checked within the signal reception range of the vehicle, pressing the or or button locks or unlocks the vehicle.

Changing the battery

You require a CR 2025 3 V cell battery.

► Take the mechanical key out of the SmartKey (> page 81).



- ► Press mechanical key ② into the opening in the SmartKey in the direction of the arrow until battery tray cover ① opens. When doing so, do not hold cover ① shut.
- ► Remove battery tray cover ①.



- ► Repeatedly tap the SmartKey against your palm until battery ③ falls out.
- ► Insert the new battery with the positive terminal facing upwards. Use a lint-free cloth to do so.



- ► Make sure that the surface of the battery is free from lint, grease and all other forms of contamination.
- ► Insert the front tabs of battery tray cover ① and then press to close it.
- ► Insert the mechanical key into the SmartKey.
- ► Check the function of all SmartKey buttons on the vehicle.



Problems	with t	he Smar	tKey
----------	--------	---------	------

Problem	Possible causes/consequences and ▶ Solutions
You cannot lock or unlock the vehicle using the SmartKey.	 The SmartKey battery is discharged or nearly discharged. ▶ Try again to lock/unlock the vehicle using the remote control function of the SmartKey. Point the tip of the SmartKey at the driver's door handle from close range and press the
	The SmartKey is faulty. ► Lock (> page 87) or unlock (> page 88) the vehicle using the mechanical key. ► Have the SmartKey checked at a qualified specialist workshop.
You can no longer lock or unlock the vehicle using KEYLESS-GO.	 KEYLESS-GO is in standby mode because the vehicle has not been unlocked for an extended period. ▶ Pull the door handle twice and then insert the SmartKey into the ignition lock.
	There is interference from a powerful source of radio waves. ▶ Lock/unlock the vehicle using the remote control function of the SmartKey. Point the tip of the SmartKey at the driver's door handle from close range and press the
	 There is a malfunction with KEYLESS-GO. ▶ Lock/unlock the vehicle using the remote control function of the SmartKey. Point the tip of the SmartKey at the driver's door handle from close range and press the
You have lost a SmartKey.	 ▶ Have the SmartKey deactivated at a qualified specialist workshop. ▶ Report the loss immediately to the vehicle insurers. ▶ If necessary, have the locks changed as well.



Problem	Possible causes/consequences and ▶ Solutions
You have lost the mechanical key.	 Report the loss immediately to the vehicle insurers. If necessary, have the locks changed as well.
The engine cannot be started using the SmartKey.	The on-board voltage is too low. ▶ Remove the SmartKey and reinsert it into the ignition lock. ▶ Start the engine within 30 seconds of inserting the SmartKey in the ignition lock. ▶ Repeat if necessary. If the engine does not start after several attempts: ▶ Check the starter battery and charge it if necessary (▷ page 478). or ▶ Jump-start the vehicle (▷ page 481). or ▶ Consult a qualified specialist workshop.
The engine cannot be started using KEYLESS-GO. The SmartKey is in the vehicle.	A door is open. Therefore, the SmartKey cannot be detected as easily.▶ Close the door and try to start the vehicle again.
	There is interference from a powerful source of radio waves. ▶ Start your vehicle with the SmartKey in the ignition lock.

Doors

Important safety notes



↑ WARNING

When leaving the vehicle, always remove the SmartKey from the ignition lock. Always take the SmartKey with you and lock the vehicle. Do not leave children unsupervised in the vehicle, even if they are secured in a child restraint system, and do not give them access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury. They could:

- injure themselves on vehicle parts
- be seriously or fatally injured by extreme heat or cold
- injure themselves or have an accident with vehicle equipment that may still be in

operation even after the SmartKey has been removed from the ignition, such as the seat adjustment, steering wheel adjustment or memory function.

If children open a door, they could cause severe or even fatal injury to other persons; if they get out of the vehicle, they could injure themselves when doing so or be seriously or even fatally injured by any passing traffic. Do not expose the child restraint system to

direct sunlight. The child restraint system's metal parts, for example, could become very hot, and a child could be burned on these parts.



↑ WARNING

Do not carry heavy or hard objects in the passenger compartment unless they are firmly secured in place.

Unsecured or improperly positioned cargo increases a child's risk of injury in the event of:

- · strong braking maneuvers
- sudden changes of direction
- an accident

Unlocking and opening doors from inside

You can open a door from inside the vehicle even if it has been locked. You can only open the rear doors from inside the vehicle if they are not secured by the child-proof locks (⊳ page 67).

Only open the door when the traffic situation permits.

If the vehicle was previously locked with the SmartKey or with KEYLESS-GO, opening the vehicle from the inside will activate the antitheft alarm system. Switch off the alarm (⊳ page 75).




▶ Pull door handle ②. If the door is locked, locking knob (1) pops up. The door is unlocked and can be opened.

Centrally locking and unlocking the vehicle from the inside

You can centrally lock or unlock the vehicle from the inside.

The central locking/unlocking button does not lock or unlock the fuel filler flap.

1 You cannot unlock the vehicle centrally from the inside if the vehicle has been locked with the SmartKey or KEYLESS-GO.



- ▶ To unlock: press button (1).
- ► To lock: press button ②. If the front-passenger door is closed, the vehicle locks.

You can open a front door from inside the vehicle even if it has been locked. Only open the door when the traffic situation permits. If the vehicle has been locked with the central locking button:

- and the SmartKey is set to its factory setting, the entire vehicle is unlocked if a front door is opened from the inside
- and the SmartKey is set to an individual setting, only the front door that is opened from inside the vehicle is unlocked.

If the vehicle has been locked centrally with the SmartKey or with KEYLESS-GO, it is not unlocked when the release button for the central locking is used.

Automatic locking feature

The vehicle locks automatically when the ignition is switched on and the wheels of the



vehicle are turning at a speed of more than 9 mph (15 km/h).

You could therefore be locked out when:

- the vehicle is being pushed.
- the vehicle is being towed.
- the vehicle is being tested on a dynamometer.

You can switch off the automatic locking function via COMAND (> page 264).

Power closing feature

The power closing feature pulls the doors and trunk lid into their locks automatically even if they are only partly closed.

↑ WARNING

To prevent possible personal injury, always keep hands and fingers away from the door or trunk opening when closing a door or the trunk lid. Be especially careful when small children are around.

If danger threatens, pull the inside or outside door handle, or pull the trunk lid handle.

To prevent personal injury, never activate the closing assist mechanism by tampering with the door or trunk lid latch.



★ WARNING

Only drive with the doors closed. Otherwise, one or more of the doors could open while the vehicle is in motion, putting you and/or others at risk.



/ WARNING

Make sure the trunk lid is closed when the engine is running and while driving. Among other dangers, deadly carbon monoxide (CO) gases may enter the vehicle interior resulting in unconsciousness and death.

▶ Power closing feature (doors): push the door past the first detent position of the lock.

The power closing feature will pull the door fully closed.

▶ Power closing feature (trunk lid): lightly push the trunk lid closed.


The power closing feature will pull the trunk lid fully closed.

Unlocking the driver's door (mechanical key)

If the vehicle can no longer be unlocked with the SmartKey, use the mechanical key.

If you use the mechanical key to unlock and open the driver's door, the anti-theft alarm system will be triggered (⊳ page 75).

- ► Take the mechanical key out of the SmartKey (⊳ page 81).
- ▶ Insert the mechanical key into the lock of the driver's door as far as it will go.



- Firmly turn the mechanical key counterclockwise as far as it will go to position 1 and hold it in this position.
- ▶ Pull the door handle quickly. The locking knob pops up. The door is unlocked.
- ► Turn the mechanical key back and remove
- ▶ Pull the door handle again.
- ▶ Insert the mechanical key into the SmartKey.



Locking the vehicle

If the vehicle can no longer be locked with the SmartKey, you can lock it by taking the following steps. If the central locking in the vehicle is malfunctioning, you cannot lock the trunk.

- ▶ Press down the locking knobs on the open rear doors.
- ▶ Close the rear doors.
- ▶ Open the front-passenger door.
- ▶ Close the driver's door and the trunk lid.
- ▶ Press down the locking knob of the driver's door inside the vehicle.
- ▶ Press down the locking knob of the open front-passenger door.
- Make sure that you have the SmartKey on your person and that it has not been left in the vehicle.
- ► Close the front-passenger door.
- ▶ Make sure that the doors and the trunk are locked.
- If you lock the vehicle as described above, the fuel filler flap is not locked. The antitheft alarm system is not armed.

Trunk

Important safety notes

Do not leave the SmartKey in the trunk. You could otherwise lock yourself out.

↑ WARNING

When leaving the vehicle, always remove the SmartKey from the ignition lock. Always take the SmartKey with you and lock the vehicle. Do not leave children unsupervised in the vehicle, even if they are secured in a child restraint system, and do not give them access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury. They could:

- · injure themselves on vehicle parts
- be seriously or fatally injured by extreme heat or cold
- injure themselves or have an accident with vehicle equipment that may still be in operation even after the SmartKey has been removed from the ignition, such as the seat adjustment, steering wheel adjustment or memory function.

If children open a door, they could cause severe or even fatal injury to other persons; if they get out of the vehicle, they could injure themselves when doing so or be seriously or even fatally injured by any passing traffic.

Do not expose the child restraint system to direct sunlight. The child restraint system's metal parts, for example, could become very hot, and a child could be burned on these parts.



♠ WARNING

Do not carry heavy or hard objects in the passenger compartment or trunk unless they are firmly secured in place.

Unsecured or improperly positioned cargo increases a child's risk of injury in the event of

- strong braking maneuvers
- · sudden changes of direction
- · an accident



WARNING

Make sure the trunk lid is closed when the engine is running and while driving. Among other dangers, deadly carbon monoxide (CO)



gases may enter the vehicle interior resulting in unconsciousness and death.

The trunk lid swings upwards when opened. Therefore, make sure that there is sufficient clearance above the trunk lid.

You can limit the opening angle of the trunk lid. This could be useful, for example, if there is insufficient space above the trunk lid. You can switch the Trunk Opening-height Restriction function on or off via COMAND (⊳ page 265).

To open the trunk lid completely, a minimum clearance of 5.90 ft (1.80 m) above the ground is necessary.

Vehicles without trunk lid remote closing feature: the trunk lid can be:

- opened and closed manually from outside
- · opened automatically from outside
- opened automatically from inside
- · locked separately
- · unlocked with the mechanical key
- opened with the emergency release button

Vehicles with trunk lid remote closing feature: the trunk lid can be:

- opened and closed manually from outside
- opened and closed automatically from outside
- · opened and closed automatically from inside
- locked separately
- · unlocked with the mechanical key
- opened with the emergency release button

Opening and closing manually

Opening

▶ Press the button on the SmartKey.




P88.50-2911-31

- ▶ Pull handle ①.
- ▶ Raise the trunk lid.

Closing

↑ WARNING

To prevent possible personal injury, always keep hands and fingers away from the trunk opening when closing the trunk lid. Be especially careful when small children are around.



- ▶ Pull the trunk lid down using recess (1).
- ▶ If necessary, lock the vehicle with the button on the SmartKey (⊳ page 78) or with KEYLESS-GO (⊳ page 79).
- 1 If a KEYLESS-GO kev is detected in the trunk, the trunk lid cannot be locked and then opens again.



Opening/closing automatically from outside

Important safety notes



↑ WARNING

Make sure the trunk lid is closed when the engine is running and while driving. Among other dangers, deadly carbon monoxide (CO) gases may enter the vehicle interior resulting in unconsciousness and death.

■ The trunk lid swings upwards when opened. Therefore, make sure that there is sufficient clearance above the trunk lid.

To open the trunk lid completely, a minimum clearance of 5.90 ft (1.80 m) above the ground is necessary.

Opening

You can open the trunk lid using the SmartKey.

▶ Press and hold the 💢 button on the SmartKey until the trunk lid opens.

Closing



↑ WARNING

Monitor the closing procedure carefully to make sure no one is in danger of being injured. To prevent possible personal injury, always keep hands and fingers away from the trunk opening when closing the trunk lid. Be especially careful when small children are around. To stop the closing procedure, do one of the following:

- Press button (3) on the SmartKey.
- Press the remote trunk opening/closing switch (on the driver's door).
- · Press the trunk closing switch.
- Press the KEYLESS-GO locking/closing switch.
- · Pull the trunk lid handle.

Even with the SmartKey removed from the starter switch or the SmartKey with KEYLESS-GO removed from the vehicle, the remote trunk opening/closing switch can be operated. Therefore, do not leave children unattended in the vehicle, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury.

You can close the trunk lid automatically by using the closing button³ or locking button⁴.



- ▶ To close: press closing button (1) in the trunk lid.
- ▶ To close and lock simultaneously: Press locking button (2) in the trunk lid.
- If you leave a KEYLESS-GO key in the trunk, the trunk lid will not lock.

Opening/closing automatically from the inside



↑ WARNING

Maintain sight of the area around the rear of the vehicle while operating the trunk lid with the door mounted switch. Monitor the closing procedure carefully to make sure no one is in danger of being injured.

To interrupt the closing procedure, release the door mounted remote trunk opening/ closing switch again.

- ³ For vehicles with the trunk lid remote closing feature only.
- ⁴ For vehicles with the trunk lid remote closing feature and KEYLESS-GO only.




Even with the SmartKey removed from the starter switch or the SmartKey with KEYLESS-GO removed from the vehicle, the remote trunk opening/closing switch can be operated. Therefore, do not leave children unattended in the vehicle, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury.

↑ WARNING

Make sure the trunk lid is closed when the engine is running and while driving. Among other dangers, deadly carbon monoxide (CO) gases may enter the vehicle interior resulting in unconsciousness and death.

You can open and close the trunk lid from the driver's seat when the vehicle is stationary and unlocked.




- ► **To open:** press remote operating switch for trunk lid (1) until the trunk lid opens.
- ► To close: press remote operating switch for trunk lid ① until the trunk lid is closed.

Locking the trunk separately

You can lock the trunk separately. If you then unlock the vehicle centrally, the trunk remains locked and cannot be opened.

- ► Close the trunk lid.
- ► Take the mechanical key out of the SmartKey (> page 81).



- ► Insert the mechanical key into the trunk lid lock as far as the stop.
- ► Turn the mechanical key clockwise from position 1 to position 2.
- ► Remove the mechanical key.
- ► Insert the mechanical key into the SmartKey.


Unlocking the trunk (mechanical key)

■ The trunk lid swings upwards when opened. Therefore, make sure that there is sufficient clearance above the trunk lid.

If the trunk cannot be unlocked with the SmartKey or KEYLESS-GO, use the mechanical key.

If you use the mechanical key to unlock and open the trunk lid, the anti-theft alarm system will be triggered (> page 75).

- ► Take the mechanical key out of the SmartKey (> page 81).
- ► Insert the mechanical key into the trunk lid lock as far as the stop.





- ► Turn the mechanical key counter-clockwise from position 1 as far as it will go to position 2.
 - The trunk is unlocked.
- ► Turn the mechanical key back to position 1 and remove it.
- ▶ Insert the mechanical key into the SmartKey.

Trunk emergency release

You can open the trunk lid from inside the vehicle with the emergency release button.



▶ Briefly press emergency release button (1).

The trunk lid unlocks and opens.

The trunk lid can be unlocked and opened with the trunk lid emergency release when the vehicle is stationary or while driving.

Trunk lid emergency release light:

- emergency release button (1) flashes for 30 minutes after the trunk lid is opened.
- emergency release button (1) flashes for 60 minutes after the trunk lid is closed.

The trunk lid emergency release does not open the trunk lid if the battery is disconnected or discharged.

Side windows

Important safety notes



↑ WARNING

When opening or closing the door windows, make sure that there is no danger of anyone being harmed by the opening/closing procedure.

The door windows are equipped with automatic operation and the anti-entrapment feature. If in automatic mode a door window encounters an obstruction that blocks its path, the anti-entrapment feature will stop the door window and open it slightly.

The door windows operate differently when the switch is pulled. See the "Problems with door windows" section for details.

The closing of the door windows can be immediately halted by releasing the switch or, if the switch was pulled past the resistance point and released, by either pressing or pulling the respective switch.

Activate the override switch when children are riding in the back seats of the vehicle. The children may otherwise injure themselves, e.g. by becoming trapped in the door window opening.




↑ WARNING

Do not keep any part of your body up against the window pane when opening a window. The downward motion of the pane may pull that part of your body down between the window pane and the door frame and trap it there. If there is a risk of entrapment, release the switch and pull it to close the window.



Opening and closing the side windows



- 1) Front left
- (2) Front right
- ③ Rear right
- (4) Rear left

The switches for all side windows are located on the driver's door. There is also a switch on each door for the corresponding side window. The switches on the driver's door take precedence.

- 1 The side windows cannot be operated from the rear when the override feature for the side windows is activated (⊳ page 67).
- ► Turn the SmartKey to position 1 or 2 in the ignition lock.
- ▶ To open: press the corresponding switch.
- ► To close: pull the corresponding switch.
- i) If you press the switch beyond the point of resistance, an automatic opening/closing process is started in the corresponding direction. You can stop automatic operation by operating the switch again.
- You can continue to operate the side windows after you switch off the engine or remove the SmartKey. This function is available for up to five minutes or until the driver's or front-passenger door is opened.

Sunblinds on the rear side windows

- ► To close fully: pull the corresponding switch when the side window is closed.
- ► To open fully: press the corresponding switch.
- 1 You can use the switches on the rear doors to close the rear roller sunblinds for the opposite side.

Convenience opening feature

You can ventilate the vehicle before you start driving. To do this, the key is used to carry out the following functions simultaneously:

- unlock the vehicle
- open the side windows
- open the roller sunblinds on the rear side windows
- open the sliding sunroof or the panorama roof with power tilt/sliding panel and the roller sunblinds
- switch on the seat ventilation for the driver's seat
- 1 The convenience opening feature can only be operated using the SmartKey. The SmartKey must be close to the driver's door handle
- ▶ Point the tip of the SmartKey at the driver's door handle.
- ▶ Press and hold the button until the side windows and the sliding sunroof or the panorama roof with power tilt/sliding panel are in the desired position.

If one of the sunblinds is closed, the sunblind will open first.

- The roller sunblinds of the panorama roof with power tilt/sliding panel and the roller sunblinds on the rear side windows are opened at the same time.
- ▶ Press and hold the button again until the side windows and the sliding sunroof or



the panorama roof with power tilt/sliding panel are in the desired position.

► To interrupt convenience opening: release the button.

Convenience closing

General notes

When you lock the vehicle, you can simultaneously:

- close the side windows
- close the sliding sunroof or the panorama roof with power tilt/sliding panel

On vehicles with roller sunblinds, you can then close the roller sunblinds.

1 The roller sunblinds of the panorama roof with power tilt/sliding panel and the roller sunblinds on the rear side windows are closed at the same time.

↑ WARNING

When closing the door windows and the sliding sunroof or panorama roof with power tilt/sliding panel, make sure that there is no danger of anyone being harmed by the closing procedure.

If potential danger exists, proceed as follows:

Release the button to stop the closing procedure. To open, press and hold the button. To continue the closing procedure after making sure that there is no danger of anyone being harmed by the closing procedure, press and hold the button.

Vehicles with KEYLESS-GO:

- Release the sensor surface on the outside door handle to stop the closing procedure.
- Immediately pull on the same outside door handle and hold firmly. The door windows and the sliding sunroof or panorama roof with power tilt/sliding panel will open for as long as the door handle is held but the door is not opened.

Using the SmartKey


- 1 The SmartKey must be close to the driver's door handle.
- Point the tip of the SmartKey at the driver's door handle.
- ▶ Press and hold the button until the side windows and the sliding sunroof or the panorama roof with power tilt/sliding panel are fully closed.
- Make sure that all the side windows and the sliding sunroof or panorama roof with power tilt/sliding panel are closed.

On vehicles with roller sunblinds:

- ▶ Press the button again until the roller sunblinds close.
- ► To interrupt convenience closing: release the button.

Using KEYLESS-GO

The KEYLESS-GO key must be outside the vehicle. All the doors must be closed.



- ► Touch recessed sensor surface ① on the door handle until the side windows and the sliding sunroof or the panorama roof with power tilt/sliding panel are fully closed.
- 1 Make sure you only touch recessed sensor surface (1).



- Make sure that all the side windows and the sliding sunroof or panorama roof with power tilt/sliding panel are closed.
- ► To interrupt convenience closing: release recessed sensor surface (1) on the door handle.

On vehicles with roller sunblinds:

- ▶ Touch the recessed sensor surface on the door handle again until the roller sunblinds close.
- ▶ To interrupt the roller sunblind closing procedure: pull the exterior door handle and hold it firmly.

Resetting the side windows

You must reset each side window if:

- · a side window cannot be closed automatically
- · a side window opens again slightly after being closed manually
- Close all the doors.
- ► Turn the SmartKey to position 1 or 2 in the ignition lock.
- ▶ Pull the corresponding switch on the door control panel until the side window is completely closed. (▷ page 93)
- ► Hold the switch for an additional second.

If the side window opens again slightly:

- ▶ Immediately pull the corresponding switch on the door control panel until the side window is completely closed (⊳ page 93).
- ▶ Hold the switch for an additional second.
- ▶ If the corresponding side window remains closed after the button has been released, the side window has been reset correctly. If this is not the case, repeat the steps above again.

Problems with the side windows

Problem: a side window cannot be closed because it is blocked by objects, e.g. leaves in the window guide.

- Remove the objects.
- ► Close the side window.

Problem: a side window cannot be closed and you cannot see the cause.



↑ WARNING

Closing the side windows with increased force or without the anti-entrapment feature could lead to serious or even fatal injury. Make sure that nobody can become trapped when closing the side windows.

If a side window is obstructed during closing and reopens again slightly:

▶ Immediately after the window blocks, pull the corresponding switch again until the side window has closed.

The side window is closed with increased force.

If a side window is obstructed again during closing and reopens again slightly:

▶ Immediately after the window blocks, pull the corresponding switch again until the side window has closed.

The side window is closed without the antientrapment feature.



↑ WARNING

Pulling and holding the switch to close the door window immediately after it had been blocked two times will cause the door window to close without the anti-entrapment feature for as long as you hold the switch.

Sliding sunroof

Important safety notes

Your vehicle may be equipped with a sliding sunroof or a panorama roof with power tilt/ sliding panel. In the following section, the



term "sliding sunroof" refers to both types of sliding sunroof.

↑ WARNING

When opening or closing the sliding sunroof, make sure that there is no danger of anyone being harmed by the opening/closing procedure.

The sliding sunroof is equipped with automatic operation and the anti-entrapment feature. If the movement of the sliding sunroof is blocked during the closing procedure, the sliding sunroof will stop and open slightly.

The sliding sunroof operates differently when the sliding sunroof switch is pressed and held. See the "Problems with the sliding sunroof" section for more details.

The opening/closing procedure of the sliding sunroof can be immediately halted by releasing the sliding sunroof switch or, if the sliding sunroof switch was moved past the resistance point and released, by moving the sliding sunroof switch in any direction.

↑ WARNING

The sliding sunroof is made out of glass. In the event of an accident, the glass may shatter. This may result in an opening in the roof.

In a vehicle rollover, occupants not wearing their seat belts or not wearing them properly may be thrown out of the opening. Such an opening also presents a potential for injury for occupants wearing their seat belts properly, as entire body parts or portions of them may protrude from the passenger compartment.

- Only open the sliding sunroof if it is free of snow and ice. Otherwise, malfunctions may occur.
 - Do not allow anything to protrude from the sliding sunroof. Otherwise, the seals could be damaged.
- If the weather can change abruptly. It could start to rain or snow. Make sure that the sliding sunroof is closed when you leave the vehicle. The vehicle electronics can be

- damaged if water enters the vehicle interior.
- 1 Resonance noises can occur in addition to the usual airflow noises when the sliding sunroof is open. They are caused by minor pressure fluctuations in the vehicle interior. Change the position of the sliding sunroof or open a side window slightly to reduce or eliminate these noises.

Operating the sliding sunroof

Opening and closing

1 You can continue to operate the sliding sunroof after switching off the engine or removing the SmartKey from the ignition lock. This function is available for up to five minutes or until the driver's or front-passenger door is opened.



Overhead control panel

- 1 To raise
- (2) To open
- 3 To close/lower
- ► Turn the SmartKey to position 1 or 2 in the ignition lock.
- ▶ Press or pull the switch in the corresponding direction.
- i If you press the switch beyond the point of resistance, an automatic opening/closing process is started in the corresponding direction. You can stop automatic operation by operating the switch again.



When raising the roof, automatic operation is only available if the sliding sunroof is in the closed position.

When opening the roof, automatic operation is only available if the sliding sunroof is not raised.

The sun protection cover automatically opens along with the sliding sunroof. You can open or close the sun protection cover manually when the sliding sunroof is raised or closed.


Resetting

Reset the sliding sunroof if it does not move smoothly.

- ► Turn the SmartKey to position 2 in the ignition lock.
- ► Raise the sliding sunroof fully at the rear (> page 96).
- ► Keep the switch pressed for another second.
- ► Make sure that the sliding sunroof can be fully opened and closed again (> page 96).
- ► If this is not the case, repeat the steps above again.
- If the sliding sunroof still cannot be opened or closed fully after resetting, contact a qualified specialist workshop.

Operating the panorama roof with power tilt/sliding panel

Opening and closing



Overhead control panel

- ① To raise
- ② To open
- 3 To close/lower

The panorama roof with power tilt/sliding panel can only be operated when the roller sunblind is open.

- i) If the front roller sunblind is closed, it opens first when the panorama roof with power tilt/sliding panel is raised.
- ► Turn the SmartKey to position 1 or 2 in the ignition lock.
- ▶ Push or pull the switch in the corresponding direction.
- i) If you press the switch beyond the point of resistance, an automatic opening/closing process is started in the corresponding direction. You can stop automatic operation by operating the switch again.

Operating the sunblinds for the panorama roof with power tilt/sliding panel

General notes

The roller sunblinds shield the vehicle interior from sunlight. The front roller sunblind can only be opened and closed when the



panorama roof with power tilt/sliding panel is closed. The front and rear roller sunblinds can be operated individually.

Operating the front roller sunblind

↑ WARNING

When opening or closing the front roller sunblind, make sure no one is in danger of being injured by the opening or closing procedure.

The front roller sunblind is equipped with automatic operation and the anti-entrapment feature. If the movement of the front roller sunblind is blocked during the closing procedure, the front roller sunblind will stop and retract slightly.

The opening or closing of the front roller sunblind can be immediately halted by releasing the roof panel switch or, if the roof panel switch was moved past the resistance point and released, by moving the roof panel switch in any direction.



Overhead control panel

- 1 To open
- 2 To open
- 3 To close
- ► Turn the SmartKey to position 1 or 2 in the ignition lock.
- ▶ Press or pull the switch in the corresponding direction.
- 1 If you press the switch beyond the point of resistance, an automatic opening/ closing process is started in the

corresponding direction. You can stop automatic operation by operating the switch again.

Operating the rear roller sunblind

Operating from the front

↑ WARNING

When opening or closing the rear roller sunblind, make sure no one is in danger of being injured by the opening or closing procedure.

The rear roller sunblind is equipped with automatic operation and the anti-entrapment feature. If the movement of the rear roller sunblind is blocked during the closing procedure, the rear roller sunblind will stop and retract slightly.

The opening and closing of the rear roller sunblind can be immediately halted by pressing the sunblind switch again.



Overhead control panel

- ▶ To open or close: press button (1). The rear roller sunblind opens or closes fully.
- ▶ To stop: press button (1) again.
- 1 You must first open or close the rear roller sunblind fully before you can move it in the other direction.

Operating from the rear compartment



↑ WARNING

When opening or closing the rear roller sunblind, make sure no one is in danger of



being injured by the opening or closing procedure.

The rear roller sunblind is equipped with automatic operation and the anti-entrapment feature. If the movement of the rear roller sunblind is blocked during the closing procedure, the rear roller sunblind will stop and retract slightly.

The opening or closing of the rear roller sunblind can be immediately halted by releasing the sunblind switch or, if the sunblind switch was moved past the resistance point and released, by pressing or pulling the sunblind switch again.



Door control panel in rear

- ➤ To open/close manually: press or pull switch ① to the point of resistance and hold it until the rear roller sunblind has reached the desired position.
- ► To open/close fully: press or pull switch ① beyond the point of resistance and release it.
- 1 You can stop automatic operation by operating the switch again.

Resetting the panorama roof with power tilt/sliding panel or the front roller sunblind

Reset the panorama roof with power tilt/ sliding panel or the roller sunblinds if the panorama roof with power tilt/sliding panel or the roller sunblinds do not move smoothly.

■ Do not open the panorama roof with power tilt/sliding panel until it has been

- reset correctly. The panorama roof with power tilt/sliding panel can otherwise be locked in the open position.
- ► Turn the SmartKey to position 1 or 2 in the ignition lock.
- ► Pull the switch repeatedly to the point of resistance in the direction of arrow (3)(> page 97) until the panorama roof with power tilt/sliding panel is fully closed.
- ► Keep the switch pulled for an additional second.
- ▶ Pull the switch in the direction of arrow (3)(> page 98) repeatedly until the front roller sunblind is closed.
- Keep the switch pulled for an additional second.
- Make sure that the panorama roof with power tilt/sliding panel (▷ page 97) and the front roller sunblind (▷ page 98) can be fully opened again.
- ▶ If this is not the case, repeat the steps above again.

Resetting the rear sunblind



Door control panel in rear

- ► Turn the SmartKey to position 1 or 2 in the ignition lock.
- ▶ Pull switch ① repeatedly until the rear roller sunblind is fully closed.
- ► Keep switch ① pulled for an additional second.



- ► Make sure that the rear roller sunblind can be opened fully again (> page 98).
- ► If this is not the case, repeat the steps above again.

Problems with the sliding sunroof

Your vehicle may be equipped with a sliding sunroof or a panorama roof with power tilt/sliding panel. In the following section, the term "sliding sunroof" refers to both types of sliding sunroof.

Problem: the sunroof cannot be closed and you cannot see the cause.

↑ WARNING

You could be severely or even fatally injured when closing the sliding sunroof with increased closing force or if the antientrapment feature is deactivated. Make sure that nobody can become trapped when closing the sliding sunroof.

If the sliding sunroof is obstructed during closing and reopens again slightly:

▶ Immediately after the sliding sunroof blocks, pull the switch in the overhead control panel down to the point of resistance and hold it until the sliding sunroof is closed.

The sliding sunroof is closed with increased force.

If the sliding sunroof is obstructed again during closing and reopens again slightly:

▶ Immediately after the sliding sunroof blocks, pull the switch in the overhead control panel down to the point of resistance and hold it until the sliding sunroof is closed.

The sliding sunroof is closed without the anti-entrapment feature.

↑ WARNING

Pressing and holding the sliding sunroof switch to close the sliding sunroof immediately after it had been blocked two times will cause the sliding sunroof to close without the anti-entrapment feature for as long as you hold the switch.

If the sliding sunroof still cannot be opened or closed as a result of a malfunction, contact a qualified specialist workshop.



Useful information	102
Correct driver's seat position	102
Seats	103
Steering wheel	109
Mirrors	111
Memory function	113

Useful information

- i) This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions.
- Please read the information on qualified specialist workshops (> page 31).

Correct driver's seat position



Observe the safety guidelines on seat adjustment (\triangleright page 103).

- ► Check whether you have adjusted seat ③ properly.
 - Electrical seat adjustment (> page 104) When adjusting the seat, make sure:
 - you are as far away from the driver's air bag as possible.
 - you are sitting in a normal upright position.

- · you can fasten the seat belt properly.
- you have moved the backrest to an almost vertical position.
- you have set the seat cushion angle so that your thighs are gently supported.
- you can depress the pedals properly.
- ► Check whether the head restraint is adjusted properly (> page 106).

When doing so, make sure that you have adjusted the head restraint so that the back of your head is supported at eye level by the center of the head restraint.

Observe the safety guidelines on steering wheel adjustment (> page 109).

► Check whether steering wheel ① is adjusted properly.

Adjusting the steering wheel electrically (> page 110)

When adjusting the steering wheel, make sure:

- you can hold the steering wheel with your arms slightly bent.
- you can move your legs freely.
- you can see all the displays in the instrument cluster clearly.

Observe the safety guidelines for seat belts (> page 57).

► Check whether you have fastened seat belt ② properly (▷ page 59).

The seat belt should:

- fit snugly across your body
- be routed across the middle of your shoulder
- be routed in your pelvic area across the hip joints
- ▶ Before starting off, adjust the rear-view mirror and the exterior mirrors
 (▷ page 111) in such a way that you have a good view of road and traffic conditions.
- ➤ Vehicles with a memory function: save the seat, steering wheel and exterior mirror settings (> page 113).



Seats

Important safety notes



↑ WARNING

In order to avoid possible loss of vehicle control, all seat, head restraint, steering wheel and rear view mirror adjustments, as well as fastening of seat belts, must be done before setting the vehicle in motion.



↑ WARNING

Do not adjust the driver's seat while driving. Adjusting the seat while driving could cause the driver to lose control of the vehicle.

Never travel in a moving vehicle with the seat backrest in an excessively reclined position as this can be dangerous. You could slide under the seat belt in a collision. If you slide under it, the seat belt would apply force at the abdomen or neck. This could cause serious or fatal injuries. The seat backrest and seat belts provide the best restraint when the wearer is in a position that is as upright as possible and seat belts are properly positioned on the body.

↑ WARNING

Your seat belt must be adjusted so that you can correctly fasten your seat belt.

Observe the following points:

- adjust the seat backrest until your arms are slightly angled when holding the steering wheel.
- · adjust the seat to a comfortable seating position that still allows you to reach the accelerator/brake pedal safely. The position should be as far back as possible with the driver still able to operate the controls properly.
- · adjust the head restraint so that it is as close to the head as possible and the center

- of the head restraint supports the back of the head at eye level.
- never place hands under the seat or near any moving parts while a seat is being adjusted.

Failure to do so could result in an accident and/or serious personal injury.



↑ WARNING

The electrically adjustable seats can be operated at any time. Therefore, do not leave children unattended in the vehicle, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury.



↑ WARNING

According to accident statistics, children are safer when properly restrained in the rear seating positions than in the front seating position. Thus, we strongly recommend that children be placed in the rear seats whenever possible. Regardless of seating position, children 12 years old and under must be seated and properly secured in an appropriately sized infant restraint, toddler restraint, or booster seat recommended for the size and weight of the child. For additional information, see "Children in the vehicle".

A child's risk of serious or fatal injuries is significantly increased if the child restraints are not properly secured in the vehicle and/ or the child is not properly secured in the child restraint.



↑ WARNING

For your protection, drive only with properly positioned head restraints.

Adjust the head restraint so that it is as close to the head as possible and the center of the head restraint supports the back of the head at eve level. This will reduce the potential for injury to the head and neck in the event of an accident or similar situation.




Do not drive the vehicle without the seat head restraints. Head restraints are intended to help reduce injuries during an accident.

- To avoid damage to the seats and the seat heating, observe the following information:
 - keep liquids from spilling on the seats. If liquid is spilled on the seats, dry them as soon as possible.
 - if the seat covers are damp or wet, do not switch on the seat heating. The seat heating should also not be used to dry the seats.
 - clean the seat covers as recommended; see the "Interior care" section.
 - do not transport heavy loads on the seats. Do not place sharp objects on the seat cushions, e.g. knives, nails or tools. The seats should only be occupied by passengers, if possible.
 - when the seat heating is in operation, do not cover the seats with insulating materials, e.g. blankets, coats, bags, seat covers, child seats or booster seats.
- When you move the seats, make sure that there are no objects in the footwell or behind the seats. Otherwise, you could damage the seats and the objects.
- 1 The head restraints in the front seats are equipped with the NECK-PRO system. For this reason, it is not possible to remove the head restraints from the front seats.

For design reasons, the rear-compartment head restraints cannot be removed.

Please contact an authorized Mercedes-Benz Center for more information.

Adjusting the seats




- 1 Head restraint height
- ② Seat height
- ③ Seat cushion angle
- 4 Seat cushion length
- Seat fore-and-aft adjustment
- 6 Backrest angle
- 1 If PRE-SAFE® has been activated, the front-passenger seat and the electrically adjustable rear seats are moved into a more favorable position.
- 1 You can store the seat settings using the memory function (▷ page 113).
- 1 To ensure the largest possible range of seat settings, certain seat adjustment functions will automatically activate other seat adjustment functions.
- 1 Depending on the seat fore-and-aft setting, the head restraint height is adjusted automatically.

Adjusting the rear seat electrically

You can only adjust the outer seats in the rear electrically.





- 1 Seat cushion angle
- ② Backrest angle
- ③ Folding the head restraint up or back
- 4 Head restraint angle
- Seat fore-and-aft adjustment

Adjusting the front-passenger seat from the driver's seat

↑ WARNING

When adjusting the front passenger seat, make sure the seat, if occupied, is as far from the front passenger front air bag as possible. Otherwise, the passenger could be seriously or even fatally injured in the event of an accident or braking maneuver.

Make sure no one is caught or injured while the seat is being adjusted.

Even with the SmartKey or SmartKey with KEYLESS-GO removed from the starter switch or the SmartKey with KEYLESS-GO removed from the vehicle, the power seats can be operated. Therefore, do not leave children unattended in the vehicle, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury.

Do not move the front-passenger seat fully forwards if there are objects in the parcel net in the front-passenger footwell. The objects could otherwise be damaged.

You can use the seat switches on the driver's side to adjust the front-passenger seat.



► To activate/deactivate: press button ①.

If the indicator lamp in button ① is lit, you can access the following functions for the front-passenger seat:

- seat adjustment
- seat heating/ventilation
- · memory function

Adjusting the front-passenger seat from the rear

↑ WARNING

When adjusting the front passenger seat, make sure the seat, if occupied, is as far from the front passenger front air bag as possible.

Otherwise, the passenger could be seriously or even fatally injured in the event of an accident or braking maneuver.

Make sure no one is caught or injured while the seat is being adjusted.


Even with the SmartKey or SmartKey with KEYLESS-GO removed from the starter switch or the SmartKey with KEYLESS-GO removed from the vehicle, the power seats can be operated. Therefore, do not leave children unattended in the vehicle, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury.

Do not move the front-passenger seat fully forwards if there are objects in the parcel net in the front-passenger footwell. The objects could otherwise be damaged.



You can use the override button to disable this function (⊳ page 67).

The button is located in the rear door on the front-passenger side.



- 1) To select the front-passenger seat or rearcompartment seat
- ② Seat height
- (3) Head restraint height
- 4 Backrest angle
- (5) Seat fore-and-aft adjustment
- ▶ To select the front-passenger seat: press button (1).

The front-passenger seat is selected if the indicator lamp in the button lights up.

- ► Adjust the front-passenger seat with buttons (2), (3), (4) and (5).
- ► To select the rear-compartment seat: press button (1).

The rear-compartment seat is selected again.

Adjusting the head restraints

Adjusting the head restraint height electrically

► To adjust the head restraint height: slide the switch for head restraint adjustment (⊳ page 104) up or down in the direction of the arrow.

Adjusting the NECK-PRO head restraints

Adjusting



▶ Pull or push the bottom of NECK-PRO head restraint (1).

Resetting

The NECK-PRO head restraints are moved forwards in the event of a rear collision in the direction of travel and have to be reset afterwards (⊳ page 56).


Adjusting NECK-PRO luxury head restraints

Adjusting



↑ WARNING

When folding back the side cushions, do not hold the area between the side cushion and the cushion holder. There is a danger of becoming trapped.



You can adjust side bolsters (1) of the NECK-PRO luxury head restraints individually.



- ► To adjust the side bolsters of the head restraint: push or pull side bolsters (1) into the desired position.
- ► To move forwards and backwards: pull or push the NECK-PRO luxury head restraints in the direction of arrow (2).

Resetting

The NECK-PRO luxury head restraints are moved forwards in the event of a rear collision in the direction of travel and have to be reset afterwards (⊳ page 56).

Rear seat head restraints



↑ WARNING

For safety reasons, always drive with the rear head restraints in the upright position when the rear seats are occupied.

Keep the area around head restraints clear of articles (e.g. clothing) to not obstruct the folding operation of the head restraints.

Make sure the rear seat head restraints engage when placing them upright manually. Otherwise their protective function cannot be ensured.

The back of the head will not be supported in the event of a collision. That could cause serious or even fatal injuries. Rear seat occupants can be seriously injured or killed.

Folding back the rear seat head restraints from the front



- ▶ Make sure that the SmartKey is in position 1 or 2 in the ignition lock.
- ▶ Press button (1).

Folding the rear seat head restraints into position electrically (outer head restraints)

- ▶ Press and hold button (1) until the head restraints have folded into position.
- f a rear-seat passenger inserts the seat belt into the buckle, the head restraint on the corresponding outer seat folds up automatically.

Folding the rear seat head restraints into position manually

Only the center rear seat head restraint can be folded into position manually.



▶ Pull the head restraint up until it engages.


Adjusting the luxury head restraints in the rear compartment



♠ WARNING

When folding back the side cushions, never reach between the side cushion and the mounting post. You could otherwise be trapped.





You can adjust side bolsters ① of the luxury head restraint individually.


- ➤ To adjust the side bolsters of the head restraint: push or pull side bolsters ① into the desired position.
- ➤ To adjust the head restraint angle: hold the head restraint by the upper edge and slide it forwards or back in the direction of arrow ②.

Adjusting the multicontour seat

You can adjust the multicontour seat using COMAND (▷ page 270).

Adjusting the multicontour seat in the rear compartment

You can use the buttons on the center console to adjust the multicontour seats for the outer seats in the rear compartment.



- ► To select a rear-compartment seat: push or pull rocker switch ① or ⑦ forwards or backwards.
 - The indicator lamp in the selected button lights up briefly.
- ➤ To adjust the side bolsters of the seat backrest: push or pull rocker switch ⑥ forwards or backwards.
- ➤ To adjust the backrest contour: push or pull rocker switch ⑤ forwards or backwards.
- ➤ To adjust the position of the backrest contour: push or pull rocker switch ④ forwards or backwards.
- ➤ To activate/deactivate the gentle massage function: push or pull rocker switch (3) forwards or backwards.
- ► To activate/deactivate the strong massage function: push or pull rocker switch (2) forwards or backwards.

Adjusting the active multicontour seat

You can adjust the active multicontour seat using COMAND (▷ page 272).

1 If PRE-SAFE® has been activated, the air pressure in the air chambers (the side bolsters of the seat cushion and backrest) of the multicontour seat or active multicontour seat is increased.

Adjusting the lumbar support

You can adjust the lumbar support using COMAND (▷ page 269).

Switching the seat heating on/off

Switching on/off

The three red indicator lamps in the button indicate the heating level you have selected.



f the battery voltage is too low, the seat heating may switch off.



The system automatically switches down from level 3 to level 2 after approximately eight minutes.

The system automatically switches down from level 2 to level 1 after approximately ten minutes.

The system automatically switches off approximately 20 minutes after it is set to level 1.

- ▶ Make sure that the SmartKey is in position 2 in the ignition lock.
- ► To switch on: press button (1) repeatedly until the desired heating level is set.
- ▶ To switch off: press button (1) repeatedly until all the indicator lamps go out.

Problems with the seat heating

The seat heating has switched itself off prematurely. The vehicle's electrical system voltage is too low because too many electrical consumers are switched on.

▶ Switch off electrical consumers which you do not need, such as the rear window defroster or interior lighting.

Switching the seat ventilation on/off

Switching on/off

The three blue indicator lamps in the buttons indicate the ventilation level you have selected.

f the battery voltage is too low, the seat ventilation may switch off.



- ▶ Make sure that the SmartKey is in position 2 in the ignition lock.
- ▶ To switch on: press button (1) repeatedly until the desired ventilation level is set.
- 1 You can open the side windows and the sliding sunroof using the "Convenience opening" feature (⊳ page 93). The seat ventilation of the driver's seat automatically switches to the highest level.
- ▶ To switch off: press button (1) repeatedly until all the indicator lamps go out.

Problems with the seat ventilation

The seat ventilation has switched off prematurely. The vehicle's electrical system voltage is too low because too many electrical consumers are switched on.

 Switch off electrical consumers which you do not need, such as the rear window defroster or interior lighting.

Steering wheel

Important safety notes


↑ WARNING

Do not adjust the steering wheel while driving. Adjusting the steering wheel while driving could cause the driver to lose control of the vehicle.



The electrical steering wheel adjustment feature can be operated at any time. Therefore, do not leave children unattended in the vehicle, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury.

Adjusting the steering wheel




- 1) To adjust the steering wheel position (fore-and-aft adjustment)
- (2) To adjust the steering wheel height
- 1 Other topics:
 - EASY-ENTRY/EXIT feature (⊳ page 110)
 - storing settings (> page 113)
 - · operating the on-board computer (⊳ page 373)

Steering wheel heating

Switching on/off

The steering-wheel heating heats the leather areas of the steering wheel.



- ▶ Make sure that the SmartKey is in position 2 in the ignition lock.
- ▶ To switch on/off: turn the lever in the direction of arrow (1) or (2). Indicator lamp (3) lights up or goes out.

Vehicles without KEYLESS-GO: when you remove the SmartKey from the ignition lock, the steering wheel heating is deactivated. Vehicles with KEYLESS-GO: when you switch off the ignition and open the driver's door, the steering wheel heating is deactivated.

- The steering wheel heating is deactivated when the temperature in the vehicle interior is higher than 86 °F (30 °C).
- 1 The steering wheel heating is switched off automatically after about 24 minutes.

EASY-ENTRY/EXIT system

Important safety notes

The EASY-ENTRY/EXIT feature makes getting in and out of your vehicle easier.

You can activate and deactivate the EASY-ENTRY/EXIT feature using COMAND (⊳ page 262).



↑ WARNING

You must make sure no one can become trapped or injured by the moving steering wheel and driver's seat when the EASY-ENTRY/EXIT feature is activated.



To stop steering wheel and seat movement, do one of the following:

- move the seat adjustment switch.
- move the steering column adjustment switch.
- press one of the memory function position buttons or memory button M.

Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Children could open the driver's door and unintentionally activate the EASY-ENTRY/ EXIT feature. This could result in an accident and/or serious personal injury.

↑ WARNING

Let the system complete the adjustment procedure before setting the vehicle in motion. All steering wheel adjustment must be completed before setting the vehicle in motion. Driving off with the steering wheel still adjusting could cause the driver to lose control of the vehicle.

■ Do not activate the EASY-ENTRY/EXIT feature, if the seat backrest is reclined too far backwards. This can damage the front or rear seats. You must first move the backrest to a vertical position.

Position of the steering wheel and the driver's seat when the EASY-ENTRY/ **EXIT** feature is active

The steering wheel tilts upwards and the driver's seat moves backwards if you:

- remove the SmartKey from the ignition lock
- open the driver's door when the SmartKey is in the ignition lock or KEYLESS-GO is in position 1
- 1 The steering wheel only moves upwards if it has not already reached the upper end stop. The driver's seat only moves backwards if it is not already in the rearmost position.

Position of the steering wheel and the driver's seat for driving

If you insert the SmartKey into the ignition lock with the driver's door closed, depending on the setting, the position of the steering wheel and the driver's seat will be changed to the previously set position.

The last position of the steering wheel or seat is stored if:

- · the ignition is switched off or
- the setting is stored with the memory function.

Crash-responsive EASY-EXIT feature

If the crash-responsive EASY-EXIT feature is triggered in an accident, the steering column will move upwards when the driver's door is opened. This occurs irrespective of the position of the SmartKey in the ignition lock. This makes it easier to exit the vehicle and rescue the occupants.

The crash-responsive EASY-EXIT feature is only operational if the EASY-EXIT/ENTRY feature is activated in the on-board computer.

Mirrors

Exterior mirrors

Adjusting the exterior mirrors



↑ WARNING

Exercise care when using the passenger-side exterior rear view mirror. The mirror surface is convex (outwardly curved surface for a wider field of view). Objects in mirror are closer than they appear. Check your interior rear view mirror and glance over your shoulder before changing lanes.

The exterior mirrors are automatically heated if the rear window defroster is switched on and the outside temperature is low.





- ▶ Make sure that the SmartKey is in position 1 or 2 in the ignition lock.
- ▶ Press button ② for the right-hand exterior mirror or button (3) for the left-hand exterior mirror.
 - The indicator lamp lights up in the button that has been pressed.
- ▶ Press adjustment button (1) up, down, to the right or to the left until the exterior mirror is set to a position that provides you with a good overview of traffic conditions.

Folding the exterior mirrors in or out electrically



- ► Make sure that the SmartKey is in position 1 or 2 in the ignition lock.
- ▶ Briefly press button (1). Both exterior mirrors fold in or out.
- Make sure that the exterior mirrors are always folded out fully while the vehicle is in motion, as they may otherwise vibrate.

Folding the exterior mirrors in or out automatically

When the "Automatic mirror folding" function is activated in COMAND (▷ page 262):

- the exterior mirrors fold in automatically as soon as you lock the vehicle from the outside.
- the exterior mirrors fold out again automatically as soon as you unlock the vehicle and then open the driver's or frontpassenger door.
- The mirrors do not fold out if they have been folded in manually.

Exterior mirror out of position

If an exterior mirror has been pushed out of position, proceed as follows:

▶ Press the mirror-folding button (⊳ page 112) repeatedly until you hear the mirrors engage in position.

The mirror housing is engaged again and you can adjust the exterior mirrors as usual (⊳ page 111).

Automatic anti-glare mirrors

↑ WARNING

If incident light from headlamps is prevented from striking the sensor in the rear-view mirror, for instance, by luggage piled too high in the vehicle, the mirror's automatic antiglare function will not operate.

Incident light could then blind you. This may distract you from the traffic conditions and, as a result, you may cause an accident.

The rear-view mirror and the exterior mirror on the driver's side automatically go into antiglare mode if the ignition is switched on and incident light from headlamps strikes the sensor in the rear-view mirror.

The mirrors do not go into anti-glare mode if reverse gear is engaged or the interior lighting is switched on.



Parking position for the exterior mirror on the front-passenger side

Setting and storing the parking position

You can position the front-passenger side exterior mirror in such a way that you can see the rear wheel on that side as soon as you engage reverse gear. You can store this position.



- ► Make sure that the vehicle is stationary and that the SmartKey is in position 2 in the ignition lock.
- ► Press button ③ for the exterior mirror on the front-passenger side.
- ► Engage reverse gear.

 The exterior mirror on the front-passenger side moves to the preset parking position.
- ► Use adjustment button ② to adjust the exterior mirror to a position that allows you to see the rear wheel and the curb. The parking position is stored.
- If you shift the transmission to another position, the exterior mirror on the frontpassenger side returns to the driving position.
- 1 You can also store the parking position using memory button **M** 1.
 - ► Make sure that the SmartKey is in position 2 in the ignition lock.
 - ► With the exterior mirror on the frontpassenger side activated, use adjustment button ② to adjust the exterior mirror to a position which

- allows you to see the rear wheel and the curb.
- ▶ Press memory button M ① and one of the arrows on adjustment button ② within three seconds. The parking position is stored if the

If the mirror moves out of position, repeat the steps.

exterior mirror does not move.

Calling up a stored parking position setting

- ► Turn the SmartKey to position 2 in the ignition lock.
- ▶ Adjust the exterior mirror on the frontpassenger side with the corresponding button (▷ page 111).
- ► Engage reverse gear.

 The exterior mirror on the front-passenger side moves to the stored parking position.

The exterior mirror on the front-passenger side moves back to its original position:

- as soon as you exceed a speed of 9 mph (15 km/h).
- about ten seconds after you have disengaged reverse gear
- if you press button 4 for the exterior mirror on the driver's side

Memory function

Storing settings

With the memory function, you can store up to three different settings, e.g. for three different people.

The following settings are stored as a single memory preset:

- seat, backrest, head restraint position and contour of the backrest in the lumbar region
- active multicontour seat: activated/ deactivated



- multicontour seat: the side bolsters of the seat cushion and the backrest as well as the contour of the backrest in the lumbar and shoulder regions
- · driver's side: steering wheel position
- driver's side: position of the exterior mirrors on the driver's and front-passenger sides

↑ WARNING

Do not activate the memory function while driving. Activating the memory function while driving could cause the driver to lose control of the vehicle.



- ► Adjust the seat (> page 104).
- ► On the driver's side, adjust the steering wheel (▷ page 110) and the exterior mirrors (▷ page 111).
- ▶ Press memory button M and then press storage position button 1, 2 or 3 within three seconds until you hear an acknowledgment tone. The settings are stored in the selected

Calling up a stored setting

storage position.

- ▶ Press and hold the relevant storage position button 1, 2 or 3 until the seat, steering wheel and exterior mirrors are in the stored position.
- If you release the storage position button, the seat, steering wheel and mirror setting functions stop immediately. The

multicontour seat setting or lumbar support adjustment is still carried out.

Useful information	110
Introduction	116
At a glance	118
System settings	143
Navigation	150
Telephone	193
Audio	21
Video	240
Rear Seat Entertainment System	240
Vehicle	260



Useful information

- 1 This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- Please read the information on qualified specialist workshops (⊳ page 31).

Introduction

Operating safety

General notes



/ WARNING

Vehicles with HYBRID: ensure that you read the "HYBRID" supplement. You may otherwise fail to recognize dangers.

↑ WARNING

Making alterations to electronic components can cause malfunctions.

Radio, satellite radio, amplifier, DVD changer, navigation module, phone and voice control are networked together. If one component is not functional or if it has been incorrectly removed/replaced, this could impair the operation of other components.

This could seriously jeopardize the operational safety of your vehicle.

We recommend that you always have maintenance work on electronic components carried out at an authorized Mercedes-Benz Center.



↑ WARNING

In order to avoid distraction which could lead to an accident, the driver should enter system settings while the vehicle is at a standstill, and operate the system only when permitted by road, weather and traffic conditions.

Bear in mind that at a speed of just 30mph (approximately 50km/h), your car covers a distance of 44 feet (approximately 14 m) every second.

COMAND supplies you with information to help you select your route more easily and guide you conveniently and safely to your destination. For safety reasons, we encourage the driver to stop the vehicle in a safe place before answering or placing a call, or consulting the COMAND screen to read navigational maps, instructions, or downloaded information.

↑ WARNING

While the navigation system provides directional assistance, the driver must remain focused on safe driving behavior, especially attention to traffic and street signs, and should utilize the system's audio cues while driving.

The navigation system does not supply any information on stop signs, yield signs, traffic regulations or traffic safety rules. Their observance always remains in the driver's personal responsibility. DVD maps do not cover all areas nor all routes within an area.

- 1 Canada only: This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:
 - 1. This device may not cause interference, and
 - 2. this device must accept any interference received, including interference that may cause undesired operation of the device.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

- **1) USA only:** This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - 1. This device may not cause harmful interference, and



2. this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

↑ WARNING

Change or modification not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.

↑ WARNING

This equipment complies with FCC radiation exposure limits set forth for uncontrolled equipment and meets the FCC radio frequency (RF) Exposure Guidelines in Supplement C to OET65.

This equipment has very low levels of RF energy that is deemed to comply without maximum permissive exposure evaluation (MPE). But it is desirable that it should be installed and operated with at least 8 inches (20 cm) and more between the radiator and a person's body (excluding extremities: hands, wrists, feet and legs.)

Correct use

Observe the following information when using COMAND:

- the safety notes in this manual
- · all road traffic regulations

- Work improperly carried out on electronic components or systems (e.g. radio, DVD changer) and associated software could cause them to cease functioning. Even systems that have not been modified could be affected because the electronic systems are connected. Electronic malfunctions can seriously jeopardize the operational safety of your vehicle.
- 1 Only have repairs or changes to electronic components carried out at a qualified specialist workshop which has the necessary specialist knowledge and tools to carry out the work required. Daimler recommends that you use an authorized Mercedes-Benz Center for this purpose. In particular, work relevant to safety or on safety-related systems must be carried out at a qualified specialist workshop.
- 1 Protection against theft: this device is equipped with technical provisions to protect it against theft. Further information on protection against theft can be obtained from an authorized Mercedes-Benz Center.

Function restrictions

For safety reasons, some COMAND functions are restricted or unavailable while the vehicle is in motion. You will notice this, for example, because you will either not be able to select certain menu items or because COMAND will display a message to this effect.

To protect the integrated hard drive against damage, COMAND deactivates it at very high temperatures. The following functions will be temporarily unavailable:

- Navigation
- Voice Control System
- · Address book
- MUSIC REGISTER



At a glance

COMAND operating system

Overview



	Function	Page
1	COMAND display	122
2	COMAND controller and function buttons	118
3	Telephone keypad	120

Components of COMAND

COMAND consists of:

- $\bullet \ \ the \ \ COMAND \ \ display/SPLITVIEW$
- the DVD changer
- the COMAND controller
- the COMAND function buttons

- the telephone keypad
- connections in the glove box (USB, additional USB, jack plug and iPod[®] connection)
- a remote control for the front passenger and for use with the Rear Seat Entertainment System
- two sets of cordless headphones for the Rear Seat Entertainment System
- cordless headphones for the front passenger
- two screens (Rear Seat Entertainment System)
- CD/DVD drive (Rear Seat Entertainment System)
- audio/video connections on the screen (Rear Seat Entertainment System)
- audio/video connections on the drive (Rear Seat Entertainment System)

You can use COMAND to operate the following main functions:

- the navigation system
- the audio function with radio and satellite radio modes, disk (audio CD/DVD and MP3 mode), memory card (MP3 mode), MUSIC REGISTER, Bluetooth® audio, Media Interface and audio AUX
- the telephone and the address book
- the video function with video DVD and video AUX modes
- the system settings

You can call up the main functions:

- using the corresponding function buttons or
- using the main function bar in the COMAND display

COMAND controller

You can use the COMAND controller to select the menu items in the COMAND display.

You can call up menus or lists, scroll through menus or lists and exit menus or lists.





The COMAND controller can be:

- pressed briefly or pressed and held 🔊
- turned clockwise or counter-clockwise
- slid left or right ←⊙→
- slid forwards or back ↑○↓
- slid diagonally


In the instructions, operating sequences are described as follows:

- ► Press the DISC button.

 Audio mode is activated.
- Select Audio by sliding ♣ and turning ♠ ○ ♪ the COMAND controller and press ♠ to confirm.

The audio menu appears.

Back button




- Back button
- ► To exit the menu: press back button ① briefly.

COMAND changes to the next higher menu level in the current operating mode.

- 1 You can also exit a menu by sliding ←○→ or ↑○↓ the COMAND controller.
- ▶ To switch to the basic display: press and hold back button ①.
 COMAND changes to the basic display of the current operating mode.

Function buttons

The COMAND function buttons allow you to select a main function directly.



- 1) Function button for roller sunblind
- ② Function button for radio and CD/DVD or SD card
- 3 Back button
- 4) Lumbar support/multicontour seat
- 5 Function button for telephone and navigation system
- 6 On/off button for COMAND
- (7) Volume control

Example:

► To select the radio or CD menu directly: press DISC RADIO button ② once or twice.



Assigning the programmable button (favorites)



① Programmable button

You can assign the following predefined functions to the * programmable button:

- ECO: you can activate or deactivate the ECO start/stop function.
- Massage, Driver's Seat: you can switch the massage function for the driver's seat on and off.
- Massage, Front Passenger's Seat: you can switch the massage function for the front-passenger seat on and off.
- Massage, Driver's and Front
 Passenger's Seat: you can switch the
 massage function for the driver's and front passenger seats on and off.
- Display OFF: you can switch the COMAND display off or on.
- Tow-away Alarm: you can arm or deactivate the tow-away alarm.
- Interior Motion Sensor: you can arm or deactivate the interior motion sensor.
- Tow-away Alarm and Interior Motion Sensor: you can arm or deactivate the towaway alarm and the interior motion sensor.
- Repeat Navigation Command: you can have the most recent recommendation by the navigation system repeated.
- ► To assign the programmable button: select Vehicle by sliding • and turning

- **()** the COMAND controller and press **(b)** to confirm.
- ► Select System and press ⑤ to confirm.
- ► Select Favorites Button and press ⑤ to confirm.

The list of predefined functions appears.

The • dot in front of the list entry indicates the current setting.

- ➤ To change the setting: turn () the COMAND controller and select the desired function.
- ► To store the setting and exit the menu: press ⑤ the COMAND controller.

Telephone keypad



- 1 Telephone keypad
- ② Folding cover




COMAND display

Display overview

The COMAND display shows the function currently selected and its associated menus. The COMAND display is divided into several areas.

The radio display is shown in the example.



- 1) Status bar
- 2 To call up the audio menu
- (3) Main function bar
- 4 Display/selection window
- (5) Radio menu bar
- 6 Air-conditioning function bar

Status bar (1) shows the current settings for radio and telephone operation.

The main functions navigation, audio, telephone and video feature additional menus. This is indicated by triangle ②. The following table lists the available menu items.

Main function bar (3) allows you to call up the desired main function.

In the example, the Audio main function is set to radio mode and display/selection window (4) is active.

Radio menu bar (5) allows you to operate the radio functions.

The air-conditioning functions can be operated in air-conditioning function bar **(6)**.

Menu overview

The table lists the menus available after calling up the main navigation, audio, telephone, video or system function in the main function bar.



Navi	Audio	Telephone	Video	Vehicle
Mode	FM/AM radio		Video DVD	ECO
Map orientation	Sat radio		AUX	Multicontour seat/lumbar settings
Point of interest symbols on the map	Disc		Video off	Rear window blind
Traffic symbols on the map	Memory card			EASY-ENTRY/ EXIT system
Text information on map	MUSIC REGISTER			Exterior lighting delayed switch-off
▼ Topographical map	Media Interface			Interior lighting delayed switch-off
City view	USB			Ambient lighting
✓ Freeway information	Rear			Automatic mirror fold-in function
✓ Volume reduction	AUX			✓ Locator lighting
SIRIUS service	Audio off			Automatic locking
Map version				✓ Interior motion sensor
				✓ Tow-away alarm
				✓ Trunk lid opening height restriction

SPLITVIEW

SPLITVIEW allows you to simultaneously use different COMAND functions on the front-passenger side and on the driver's side.

Depending on the viewing angle of the display (from the driver's seat or from the frontpassenger seat), you will see two different displays.




For example, the "Navi" function can be used from the driver's side while the "Video" function is used on the front-passenger side. Use the remote control to operate COMAND from the front-passenger side with SPLITVIEW.

Please bear the following in mind

- Your vehicle may be equipped with SPLITVIEW, depending on its date of production. The use of SPLITVIEW is currently not permitted in the following states: AL, AZ, CO, IL, LA, MA, MD, NH, PA, VA, VT, WA, WI, and WV or in the Canadian provinces of Manitoba, Newfoundland, New Brunswick, and Prince Edward Island. It is the driver's responsibility to observe ALL regional legally prescribed regulations. If your vehicle is registered in a state or province in which SPLITVIEW is not approved, this function must be deactivated. Please contact an authorized specialist dealer to check whether SPLITVIEW is approved in your state or province.
- Volume adjustment for the cordless headphones can be carried out on the headphones. Before putting on the headphones, make sure that the volume has not been set too high.
- The remote control can be used for the volume adjustment of corded headphones.
- You can only use media from the driver's and front-passenger sides separately if the media are from different sources. Example: on the driver's side, an audio CD is being played by the DVD changer. This means that on the front-passenger side, the DVD changer cannot be used to play a different disc type, for instance a video DVD. However, other media can be used at the same time on the front-passenger side, including radio, memory card, MUSIC REGISTER, Media Interface, USB or AUX.
- If you use the same medium on both sides, settings for this medium can be carried out from either side.

- There must be intervisibility between the headphones and the display so that COMAND can optimally transmit music and speech via the infrared signal on the frontpassenger's headphones. For this reason, please also observe that the headphones have left and right sides, and use them correctly.
- Only entertainment functions, i.e. audio and video, can be used separately via SPLITVIEW.
- The multifunction steering wheel can only be used for functions which relate to the driver's side.

Switching SPLITVIEW on/off



P82.87-2557-31

- ➤ To switch on SPLITVIEW: select Vehicle from the main function bar by turning (○) the COMAND controller and press (○) to confirm. The "Vehicle" menu appears.
- ► Select SPLITVIEW ON. SPLITVIEW symbol ① appears in the display, and display ② switches to SPLITVIEW OFF.
- ► To switch off SPLITVIEW: select Vehicle from the main function bar by turning () the COMAND controller and press () to confirm.

The "Vehicle" menu appears.

- Select SPLITVIEW OFF.Display ② switches to SPLITVIEW ON.
- 1 If COMAND has already been switched on, you can also use the remote control to



switch SPLITVIEW on and off (\triangleright page 125).

The SPLITVIEW screen remains on for approximately 30 minutes after the SmartKey has been turned to position **0** in the ignition lock. After this time or after the SmartKey has been removed, the settings on the front-passenger side are saved for approximately 30 minutes longer. After this period, reactivation on the front-passenger side means that the settings from the driver's side will be used.

Cordless headphones for the front passenger

There are different cordless headphones for the front passenger and the rear compartment.




The cordless headphones for the front passenger can be identified by SPLITVIEW symbol ① on the headband.

The cordless headphones for the front passenger cannot be used in the rear compartment. Equally, the headphones for the rear compartment cannot be used by the front passenger.

Swiveling the COMAND display and setting the brightness


You can swivel the COMAND display⁵. The buttons are located beside the COMAND display.

Swiveling



- 1 To swivel the display to the left
- ② To swivel the display to the right

Setting the brightness



- Brightness of the instrument cluster lighting
- ② Brightness of the COMAND display

Brighter or dimmer:

- ► Turn control ① or ② clockwise or counterclockwise.
- 1 If Night View Assist Plus is activated, only the brightness of the multifunction display is adjusted with control (1).

Display design

When the default settings are selected, the display automatically switches between day design and night design.

You can change these settings using COMAND (▷ page 143).



Cleaning instructions

I Do not touch the COMAND display. The display has a very sensitive high-gloss surface; there is a risk of scratching. If you have to clean the screen, however, use a mild cleaning agent and a soft, lint-free cloth.

The display must be switched off and have cooled down before you start cleaning. Clean the display screen, when necessary, with a commercially available microfiber cloth and cleaning agent for TFT/LCD displays. Then, dry the surface with a dry microfiber cloth. Avoid using alcoholic thinners, gasoline or abrasive cleaning agents. These could damage the display surface. Do not apply pressure to the display surface when cleaning it, as this could cause irreversible damage.

Remote control

Overview

You can use the remote control to operate the COMAND display, SPLITVIEW and either one of the rear-compartment screens.



- ① To switch the screen on/off (Rear Seat Entertainment System only)
- ② To switch the button lighting on/off
- ③ To select the screen for remote control operation (COMAND, SPLITVIEW, L REAR and REAR R can be selected)
- 4) To select a menu or menu item
- (5) To confirm a selection or setting
- 6 Mute
- To adjust the volume (for corded headphones only)
- ® COMAND: to set the station, skip track, fast forward/rewind, for example. Rear Seat Entertainment System: skip track, fast forward/rewind



- COMAND: to select a station from presets, select a track, enter directly, enter a phone number, for example. Rear Seat Entertainment System: to select a track, enter directly
- 10 To exit a menu (back)
- ▶ Point the remote control at the corresponding screen and execute the functions by pressing the corresponding buttons.
- 1 The remote control's function may be restricted depending on the angle at which it is pointed at the respective screen.

Selecting the screen for the remote control

► Turn thumbwheel ③ until the desired display is highlighted in the window.

Switching the screen on/off (Rear Seat Entertainment System only)

If the SmartKey is in the ignition lock in position **0** or **1** or if the SmartKey is not in the ignition lock, the rear screens will switch off after 30 minutes. Before the screens switch off, they show a message to this effect.

You can switch the screens back on. However, this will discharge the starter battery.

- Point the remote control at the rearcompartment screen which has been selected for remote operation.
- Press button ① on the remote control. The respective rear screen switches on or off.
- 1 You can only switch the screens on using the remote control if the ignition is switched on.

Switching the button lighting on/off

▶ Press button ② on the remote control. Depending on the previous status, the button lighting is switched on or off. 1 If you do not use the remote control for about 15 seconds, the button lighting switches off automatically.

Mute

▶ Press button ⑥ on the remote control. The sound is switched on/off.

Adjusting the volume

This function is available for SPLITVIEW and for the Rear Seat Entertainment System in conjunction with corded headphones.

▶ Press one of buttons ⑦ on the remote control.

The volume of the currently selected audio or video source changes.

For COMAND, you can also adjust the volume for phone calls and navigation messages.

Selecting a menu/menu item and confirming your selection



Functions with the ⋈ and ⋈ button

You can use the remote control to execute the same functions as the COMAND control panel.

Mode	Function
Audio mode	Selects a station using the station search function (▷ page 212)
	Selects a track by skipping to a track (▷ page 224)
	Fast forward/rewind (⊳ page 225)
Video mode	Selects a scene or chapter (video DVD mode) (⊳ page 243)
	Fast-forward/rewind (video DVD mode) (⊳ page 242)

Functions of the number keypad

You can use the remote control to execute the same functions as the COMAND control panel.

Mode	Function
Audio mode	Selects stations via the station presets (⊳ page 212)
	Sets stations by entering the frequency manually (⊳ page 212)
	Stores stations manually (⊳ page 213)
	Selects a track (⊳ page 224)
	Selects a data medium via the media list (⊳ page 224)
Telephone mode	Telephone number entry (⊳ page 200)
Character entry	Enters characters (direct entry) (⊳ page 130)

Operating COMAND


Selecting a main function

Initial situation

You would like to change from the telephone menu to the vehicle settings, for example.

- ► Slide **†** the COMAND controller and switch to the main function bar.
- ► Select Vehicle in the main function bar by turning 【◎】 the COMAND controller and press ⑤ to confirm.


The "Vehicle" menu appears.



- ① "Vehicle" menu
- ② Display/selection window



Calling up the menu of a main function



- 1 To call up the audio menu
- ② Main function bar

If one of the main functions navigation, audio, telephone or video is switched on,

triangle ① appears next to the entry. You can now select an associated menu.


The following example illustrates how to call up the audio menu.

► Press the BADIO function button.

or

Select Audio in the main function bar by sliding ↑ ○ the COMAND controller and press ७ to confirm.

The Audio menu appears.



- ① Current audio operating mode
- ② Main function bar
- 3 Audio menu

The • dot indicates the current audio mode.


► Select another audio mode, e.g. Radio, by turning (○) the COMAND controller and press (●) to confirm.

Selecting a menu item

The following example describes how to select a station from the station presets in radio mode.

- ► Press the DISC function button.

The station preset memory appears.



- Selection bar
- ➤ Select a station by turning 【◎】 the COMAND controller and press ⑤ to confirm.

The station is set.

Example of operation


Initial situation

You would like to switch from the vehicle function to the radio function and select a station from the station list, for example.

The following operating example describes how to:

- · call up the audio function
- · switch on radio mode
- · set a station.





P82.87-3324-31

Calling up the audio function

► Select Audio in the main function bar by sliding **↑** ⊚ and turning **↓** ⊚ **↓** the COMAND controller and press (b) to confirm. The basic display of the current audio operating mode, e.g. audio CD, appears.




Switching to radio mode Option 1

- ► Press the BADIO function button. The radio display appears.
- Repeated pressing of this function button switches between radio and the most recently active audio source.

Option 2


► Select Audio again by sliding • ○ the COMAND controller and press (5) to confirm.

The Audio menu appears.



- Current audio operating mode
- ② Main function bar
- 3 Audio menu
- ▶ Press ⑤ the COMAND controller and confirm Radio.

The radio basic display appears with the waveband last selected.



▶ To set the station: if the display/selection window is activated in the radio display, turn 【◎】 or slide ←◎→ COMAND controller.

Entering characters in navigation mode (entering a city)

General information

Character entry is explained in the following sections using NEW YORK as an example for entering a city.

If you want to use the address entry menu (⊳ page 153) to enter a city, a street or a house number, for example, COMAND provides either a list with a character bar (option 1) or a selection list (option 2).



You can enter the characters using either the character bar or the number keypad. In the selection list, you select an entry to copy it to the address entry menu.

Option 1: city list with character bar

► Call up the city list with character bar (> page 153).

The alphabetically sorted city list shows the first available entries.



ABCDEFGHIJKLMNOPQRSTUVWXYZ.ok

→ /-'., & 1234567890 CLR

P82.87-5444-31

Entering characters using the character bar



P82.87-5445-31

- ① N character entered by user
- ② ANTICOKE characters automatically added by COMAND
- 3 List entry that most closely resembles the current entry by the user
- 4 To switch to the selection list
- To delete an entry
- 6 Characters not currently available
- (7) Characters currently available

- ® Currently selected character
- Oharacter bar
- 10 To cancel an entry
- 11 List

The list (1) shows all available town names beginning with N. The list entry that is best suited to previous user entries is always highlighted in the first position (3), NANTICOKE in the example.

All characters that have been entered are displayed in black, the letter N in the example ①. The letters that are added automatically by COMAND are displayed in gray ②, ANTICOKE in the example.

Character bar ① shows the letters still available for selection in black ⑦. These can be selected; in the example, the letter ① is highlighted ⑧. Which characters remain available depends on the characters already entered by the user and on the data stored in the digital map. Characters that are no longer available are shown in gray ⑥.

► Select E, W, space, Y in order and confirm each with .



P82.87-5446-31

Entering characters using the number keypad

The character appears at the bottom of the display when the key is pressed. The first available letter is highlighted.



You see which characters you can enter with that key. Each time the key is pressed, the next character is selected.

Example: key 6 ::

- press once = M
- press twice = N
- press three times = O
- ► Wait until the character display goes out. The entries matching your input are shown in the list.
- ► Enter E, W, space, Y with the corresponding keys.
- 1 The space is entered using number key 0.

Further functions in the list with character bar

- ► To delete an entry: select c and press and hold the COMAND controller until the entire entry has been deleted.
- ► To switch the character set: select

 and press to confirm.
- ► To cancel an entry: select the ⇒ symbol in the bottom left of the character bar and press (*) to confirm.

or

- ► Press the <u></u> back button. The address entry menu appears.
- ➤ To accept the first list entry: press and hold ⑤ the COMAND controller until the address entry menu appears.

 The accepted list entry is shown there.

Calling up the list as a selection list

Select the desired city from the selection list. If there are several entries for a city or if several cities of the same name are stored, then ok is highlighted in the character bar.

▶ Press ⑤ the COMAND controller.

It is also possible to switch the city list to the selection list at any time during character input.

Slide the COMAND controller repeatedly until the city list appears as a selection list.

or

Option 2: city list as selection list

COMAND either shows the selection list automatically or you can call up the selection list from the list with character bar.

The example shows the selection list after the city NEW YORK has been entered. The entry is highlighted automatically.



P82.87-5447-31

► Confirm NEW YORK with COMAND controller .

The address entry menu appears. You can now enter a street, for example.



P82.87-5608-31



1 You will find further information in the "Destination entry" section (▷ page 153).

Entering characters in the address and the phone book

Introduction

The following section describes how to enter characters in the phone book/address book when creating a new entry.

Creating a new entry in the phone book

► Call up the input menu with data fields (> page 206).



P82.87-5449-31

Phone book: input menu with data fields

- (1) Selected data field with cursor
- ② Character bar

Creating a new entry in the address book

► Call up the input menu with data fields (> page 206).



P82.87-2142-31

Input menu with data fields

- (1) Selected data field with cursor
- ② Character bar

Entering characters

The example describes how to enter the surname Schulz.

Select S by turning () and sliding () the COMAND controller and press () to confirm.

S is entered into the data field. All characters are shown in black and can always be selected in the character bar.

The character bar offers characters corresponding to the respective data field (letters or digits).



P82.87-5404-31

- To switch the character bar to uppercase/lower-case letters
- ② To switch the character bar from upper/ lower-case letters to digits
- ③ To change the language of the character bar
- 4 To delete a character/an entry
- ► Select C and confirm by pressing ⑤ the COMAND controller.

The letter c is added to S in the data field.

- ▶ Repeat the process until the name has been entered in full.
- ► To enter a phone number: select the digits one by one in the corresponding data field by turning 【◎】 and sliding ♠ ♣ the COMAND controller and press ⑤ to confirm.

Switching data fields

If you want to enter a first name after you have entered a surname, for example, proceed as follows to switch between the data fields:



Option 1

- ► Select or in the character bar and press to confirm.
 - The input menu shows the data field selected.



P82.87-5405-31

- (1) Cursor in the next data field
- 2 To store an entry
- ③ ↑ and ↓ icons to select a data field

Option 2

- ► Slide ↑ the COMAND controller repeatedly until the character bar disappears.
- ► Select the data field by sliding ○ and press ⑤ to confirm.

Storing an entry

► Select ok in the character bar by turning () the COMAND controller and press to confirm.

The entry is stored in the address book.

Further functions available in the character bar

- ► To switch the character bar to upper/ lower-case characters: select ABC or abc and press (*) to confirm.
- ➤ To switch the character set: select
 and press ⑤ to confirm.
 The character set switches between upper/lower-case letters and digits.

- ➤ To change the language of the character bar: select and press to confirm.
- ► Select the language by turning 【○】 the COMAND controller and press ⑤ to confirm.
- ► To reposition the cursor within the data field: select ← or → and press ७ to confirm.



P82.87-5406-31

- (1) Cursor (repositioned)
- ② ← and → icon to reposition the cursor
- ▶ Delete the character/entry (> page 207).

Basic functions of COMAND

Switching COMAND on/off

- ► Press the ON function button on the center console.
- i If you switch off COMAND, playback of the current audio or video source will also be switched off. You cannot switch off COMAND while making a call via COMAND. You can also make phone calls using the buttons on the multifunction steering wheel when COMAND is switched off (▷ page 373).



Mute

Switching audio and video sources on/off

- ▶ Press the 🐧 button on the multifunction steering wheel.
 - The sound from the respective audio or video source is switched on or muted.
- When the sound is off, the system displays the ☆ symbol in the status line. When you change the audio or video source, or adjust the volume, sound automatically switches on again.
- 1 Even if the sound is switched off, you will still hear traffic and navigation system announcements.

Switching off Traffic program and navigation announcements completely

- ▶ Traffic program: press the 📉 button until the TA message disappears from the status bar of the display.

 A confirmation tone sounds.
- ► Navigation announcements: during an announcement, press the 🖫 button on the multifunction steering wheel.

Switching Traffic program and navigation announcements on again

► Traffic program: press and hold down the

□ button until the □ display appears in the status bar.

A confirmation tone sounds.

- ▶ Navigation messages: select the symbol in the navigation menu bar and press ⑤ to confirm.
- The navigation announcements are activated again if you switch COMAND off and on again or start a new route guidance.

Adjusting the volume

Adjusting the volume for the audio or video source



► To adjust: turn thumbwheel (1).

or

▶ Press the + or - button on the multifunction steering wheel. The volume of the currently selected audio or video source changes.

You can also adjust the volume for the following:

- · traffic announcements
- · navigation announcements
- phone calls
- Voice Control System (see the separate operating instructions)

Adjusting the volume for navigation announcements

During a navigation announcement:

► Turn thumbwheel ①.

or

▶ Press the + or - button on the multifunction steering wheel.

Adjusting the volume for phone calls

You can adjust the volume for hands-free mode during a telephone call.

► Turn thumbwheel ①.

or

► Press the + or - button on the multifunction steering wheel.



Adjusting the sound settings


Calling up the sound menu

You can make various sound settings for the different audio and video sources. This means that it is possible to set more bass for radio mode than for audio CD mode, for example. You can call up the respective sound menu from the menu of the desired mode.

The example describes how to call up the sound menu in radio mode.

► Press the DISC function button.

The radio display appears. You will hear the last station played on the last waveband.




Select Sound by sliding ○ ■ and turning ¶○ ■ the COMAND controller and press ⑤ to confirm.

You can now set the treble and bass or the balance and fader for radio mode.

Adjusting treble and bass

► Select Treble or Bass in the sound menu by turning 【◎】 the COMAND controller and press ⑤ to confirm.

An adjustment scale appears.



P82.87-3251-31

To set the treble

- Last setting selected
- ② Current setting
- ► Select a setting by turning 【◎】 the COMAND controller and press ⑤ to confirm.


The setting is stored and you exit the menu.

Adjusting balance and fader

With the Balance function, you can control whether the sound is louder on the driver's or front-passenger side.

The Fade function is used to control whether the sound is louder in the front or the rear of the vehicle.

▶ Select Balance/Fader in the sound menu by turning () and press () to confirm.



- ① Current setting
- Select a setting by sliding ↑ ↓ or ← → the COMAND controller and press ⑤ to confirm.

The setting is stored and you exit the menu.



Surround sound

General information

If your vehicle is equipped with the harman/kardon® Logic 7® surround sound system, you can set the optimum surround sound for every passenger.

The harman/kardon[®]Logic 7[®] surround sound system is available for the following operating modes:

- radio (FM only)
- · satellite radio
- audio CD
- audio DVD (MLP, dts, PCM and Dolby Digital audio formats)
- MP3 (including SD memory card)
- Media Interface
- video DVD (PCM, dts and Dolby Digital audio formats)
- AUX

Because some DVDs contain both stereo and multichannel audio formats, it may be necessary to set the audio format (> page 227).

- 1 The Logic7® ON function enables playback of, e.g. stereo recordings with a surround sound experience for every passenger. It enables optimum playback of music and films on CD, audio DVD or video DVD with multichannel audio formats, such as MLP, dts or Dolby Digital. This results in sound characteristics like those intended by the sound engineer when the original was recorded.
- i) If you select LOGIC7® OFF, the sound system plays the tracks as stored on the medium. Due to the design of the passenger compartment, an optimum audio experience cannot be guaranteed for all passengers.
- i Discs which support the audio formats mentioned have the following logos:



Dolby Digital




dts

Switching surround sound on/off

Example: switching on surround sound for radio mode


► Press the DISC function button.

The radio display appears. You will hear the last station played on the last waveband.



- Select Sound by sliding ♣ and turning ♠ the COMAND controller and press ♠ to confirm.
- ► Select 3D Sound and press ⑤ to confirm.





P82.87-3253-31

- ① Current setting
- ► Select the Logic7® ON or Logic7® OFF setting by turning 【◎】 the COMAND controller and press ⑤ to confirm.

 Depending on your selection, surround sound is switched on or off and the menu is exited.
- ► To exit the menu without saving: press the ____ back button or slide ← _ + the COMAND controller.
- i Please bear the following in mind:
 For an optimum audio experience on all seats when Logic7® is switched on, balance and fader should be set to the center of the passenger compartment.

You will achieve the best sound results by playing high-quality audio and video DVDs. MP3 tracks should have a bit rate of at least 128 kbit/s.

Surround-sound playback does not function for mono signal sources, such as AM radio mode.

If radio reception is poor, e.g. in a tunnel, you should switch off Logic 7®, as it may otherwise switch between stereo and mono and cause temporary sound distortions.

On some stereo recordings, the sound characteristics may differ from conventional stereo playback.

Bang & Olufsen sound system

Vehicles with a Bang & Olufsen sound system: There are two settings available with True ImageTM sound technology:

reference

This setting provides a crisp, clear, luxury high-end sound setting for a studio atmosphere in your vehicle.

• 3D Sound

This setting enables a wide-ranging sound experience for playing music and videos.

The Sound Mode function can be used to optimize the selected sound setting for one seat. The settings left, all and right can be selected.

The Bang & Olufsen sound system provides the following operating modes:

- radio (FM only)
- audio CD
- audio DVD (MLP, dts, PCM and Dolby Digital audio formats)
- MP3
- Media Interface
- video DVD (PCM, dts and Dolby Digital audio formats)
- AUX

Because some DVDs contain both stereo and multichannel audio formats, it may be necessary to set the audio format (> page 227).

Discs which support the audio formats mentioned have the following logos:



Dolby® Digital





dts™



MLP™

Selecting settings for the Bang & Olufsen sound system

Calling up the selection menu

- ▶ Select Sound.
- ► Highlight Bang & Olufsen.
- ▶ Press 🔊.

A selection menu appears.

A • dot in front of an entry indicates the current setting.

Selecting the setting for True Image™

- ► Turn () or slide ○ and highlight reference or 3D. Sound.
- ▶ Press 🔊.

Selecting sound mode

- ► Select Sound Mode in the selection menu.
- ► Turn 🕻 🔾 or slide 🛊 🔾 🛊 and highlight left, all or right.
- ▶ Press 🔊.
- ▶ To exit the menu: press the 🛨 back button beside the COMAND controller.

or

- ▶ Slide ← ∅ →.
- 1 Please bear the following in mind:

You will achieve the best sound results on your Bang & Olufsen sound system by playing high-quality audio DVDs and CDs. MP3 tracks should have a bit rate of at least

224 kbit/s.

When playing using an iPod[®], the bit rate should also be at least 224 kbit/s.

For optimum playback quality:

► Deactivate the EQ setting on the iPod®.

Surround-sound playback does not function for mono signal sources, such as the medium wave range (MW) in radio mode.

On some stereo recordings, the sound characteristics may differ from conventional stereo playback.

Rear Seat Entertainment System

Components


Overview

The Rear Seat Entertainment System comprises:

- two screens for the rear behind the frontseat head restraints
- two remote controls
- a CD/DVD drive
- AUX jacks on both screens (display AUX) and on the CD/DVD drive (drive AUX)
- two sets of cordless headphones



Rear-compartment screens





- Socket for corded headphones
- ② V jack for video signal
- ③ L jack for audio signal, left
- 4 R jack for audio signal, right
- ⑤ Rear compartment screen

You can connect an additional set of corded headphones to each rear-compartment screen. The connection socket is for headphones with 3.5 mm stereo jack plugs and an impedance of 32 ohms.



Remote control

Overview



- 1) To switch the screen on/off
- 2 To switch the button lighting on/off
- ③ To select the screen for remote control operation (COMAND, SPLITVIEW, L REAR and REAR R can be selected)
- (4) To select a menu or menu item
- To confirm a selection or setting
- To switch sound on/off (for corded headphones)
- To adjust the volume (for corded headphones)
- To skip; fast-forward/fast-rewind
- To select a track; direct entry
- 10 To exit a menu (back)

Selecting the screen for the remote control

You can use the remote control to operate one of the two rear screens at a time. To do so, you must switch the remote control to the desired screen.

- ► To select the left-hand screen: turn thumbwheel ③ until "L REAR" is highlighted in the window.
- ► To select the right-hand screen: turn thumbwheel ③ until "REAR R" is highlighted in the window.

Switching the screen on/off

If the SmartKey in the ignition lock is in position **0** or **1** or if the SmartKey is not in the ignition lock, the rear screens will switch off after 30 minutes. Before the screens switch off, they show a message to this effect.

You can switch the screens back on. However, this will discharge the starter battery.

- Point the remote control at the rearcompartment screen which has been selected for remote operation.
- Press button ① on the remote control. The respective rear screen switches on or off.
- i) You can only switch the screens on using the remote control if the ignition is switched on.

Switching the button lighting on/off

- ► Press button ② on the remote control.

 Depending on the previous status, the button lighting is switched on or off.
- 1 If you do not use the remote control for about 15 seconds, the button lighting switches off automatically.

Switching the sound on/off (corded headphones only)


► Press button ⑥ on the remote control. The sound is switched on/off.



Selecting a menu/menu item and confirming your selection

CD/DVD drive and AUX jacks

The CD/DVD drive is located in the center behind the front seats.



- ① CD/DVD slot
- 2 AUX, right-hand (R) jack for audio signal
- 3 AUX, left-hand (L) jack for audio signal
- ④ AUX, jack for video signal (V)
- ⑤ CD/DVD eject button

The AUX jacks shown are for the AUX drive. Identical jacks can be found on the right-hand side of the rear-compartment screens (AUX display), (▷ page 139).

Cordless headphones

Overview

The cordless headphones for the rear compartment can be recognized by the "DIGITAL AUDIO" inscription on the battery compartment cover and by the fact that there is no SPLITVIEW symbol (\triangleright page 122)(\triangleright page 122).



- 1 Volume control
- 2) To select a screen for the headphones
- 3 Battery compartment cover
- (4) To switch the cordless headphones on/off
- (5) Indicator lamp with various displays (▷ page 143)
- ▶ Gently pull both sides of the headphones out and adjust the fit of the headphones by pulling the headband in the direction of the arrow.

Switching the cordless headphones on/ off

▶ Press button ④. Depending on the previous status, the headphones are switched on or off. To save the battery, the headphones are switched off automatically if they do not receive a signal within three minutes.

Adjusting the volume of the headphones

► Turn volume control ① until you have reached the desired volume.

ilf you have connected corded headphones to a rear-compartment screen, you can adjust the volume by pressing buttons ⑦ on the remote control (▷ page 125).

Selecting a screen for the headphones

► Move push slider ② to L (left-hand screen) or R (right-hand screen).



Indicator lamp displays

The indicator lamp displays the following possible stati for the batteries and headphones:

Display	Status
Green	The batteries are fine.
Red	The batteries are almost discharged.
Continuou sly lit either green or red	The headphones are switched on and connected to a screen.
Flashes either green or red	The headphones are searching for the connection to a screen.
No display (dark)	The headphones are switched off or the batteries are discharged.

Connecting additional headphones

You can connect an additional set of corded headphones to each rear-compartment screen (> page 139).

Changing batteries

Batteries are required for the remote control and for the two sets of cordless headphones. Changing batteries (> page 247)

System settings

Display settings

Switching the display on/off

- ➤ Select Vehicle by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- ➤ Select Display OFF by turning �� the COMAND controller and press ७ to confirm.

Display design

Your COMAND display features optimized designs for operation during daytime and night-time hours. You can customize the design to suit your personal preferences by manually selecting day or night design or opt for an automatic setting.

- ➤ Select Vehicle by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- ► Select System by turning () the COMAND controller and press to confirm.
- ► Select Display and press 🔊 to confirm.
- ► Select Day Mode, Night Mode or Automatic by turning () the COMAND controller and press () to confirm.

The • icon indicates the current setting.

Design	Explanation
Day Mode	The display is set permanently to day design.
Night Mode	The display is set permanently to night design.
Automatic	The display design changes depending on the brightness around the vehicle.

1 In the Automatic setting, COMAND evaluates the readings from the automatic vehicle light sensor and switches between the display designs automatically.



Time settings


General information

If COMAND is equipped with a navigation system and has GPS reception, COMAND automatically sets the time and date. You can also adjust the time yourself in 30-minute increments, but the date cannot be changed.

- i If you set the time in 30-minute increments, any time zone settings and settings for changing between summer and standard time are lost (▷ page 144).
- The following navigation system functions require the time, time zone and summer/ standard time to be set correctly in order to work properly:
 - route guidance on routes with timedependent traffic guidance
 - · calculation of expected time of arrival

Setting the time

- ► Select Vehicle in the main function bar by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- ► Select System by turning () the COMAND controller and press to confirm.
- ► Select Time by turning 【◎】 the COMAND controller and press ⑧ to confirm.
- ► Select Time and press ⑤ to confirm.



- Setting the time
- Current date (set automatically by COMAND)

► Set the time by turning **()** the COMAND controller and press **(b)** to confirm.

Setting the time/date format

- ► Select Vehicle in the main function bar by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- ► Select System by turning 【○】 the COMAND controller and press ⑤ to confirm.
- ► Select Time by turning 【◎】 the COMAND controller and press ⑧ to confirm.
- ▶ Select Format and press ⑤ to confirm.
 The symbols show the current settings.

Abbreviation	Meaning
DD/MM/YYYY	Day/Month/Year (date format)
HH/MM	Hours/Minutes (time format)
You can set the 24-hour or the AM/PM	

► Set the format by turning 【○】 the COMAND controller and press ⑤ to confirm.

format.

Setting the time zone and switching between summer and standard time

- ► Select Vehicle in the main function bar by turning () the COMAND controller and press () to confirm.
- ➤ Select System by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- ► Select Time by turning () the COMAND controller and press () to confirm.



- ➤ Select Time Zone and press ⑤ to confirm.

 You will see a list of time zones. The dot indicates the current setting.
- ➤ Select the time zone and press 🕲 to confirm.
- ► To switch automatic changeover on/
 off: select Automatic Daylight
 Savings Time or Automatic Daylight
 Savings Time by turning (○) the
 COMAND controller and press (●) to
 confirm.

The • dot indicates the current setting.

Text reader settings

Setting the text reader speed

- ➤ Select Vehicle by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- ► Select System and press 🔊 to confirm.
- ► Select Text Reader and press ⑤ to confirm.
- ► Select Set text reader speed and press ⑤ to confirm.
 - A list appears. The dot indicates the current setting.
- ➤ Select a setting by turning 【◎】 the COMAND controller and press ⑤ to confirm.


Voice Control System settings

Opening/closing the help window

In addition to the audible instructions, the help window will show you other information during voice control operation and the individualization process.

- ► Select Vehicle in the main function bar by turning (○) the COMAND controller and press (●) to confirm.
- ► Select System by turning **(**) the COMAND controller and press **(** to confirm.
- ➤ Select Voice Control by turning (○) the COMAND controller and press (to confirm.
- ► Select Help Window and press ⑤ to confirm.

You have switched the help window on \checkmark or off \square .



Individualization

Introduction

You can use the individualization function to fine tune the Voice Control System to your voice and therefore improve voice recognition. This means that other users' voices will not be recognized as easily. For this reason this function can be switched off. Individualization comprises two parts and takes approximately 5 minutes. It consists of training the system to recognize a certain number of digit sequences and voice commands.

Starting new individualization

Individualization can only be started when the vehicle is stationary. Before starting, switch off all devices or functions which could interfere, such as the radio or the navigation system. After starting the session, the system



guides you through the training with spoken instructions.

- ► Select Vehicle in the main function bar by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- ► Select System by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- ► Select Voice Control and press ⑤ to confirm.
- ► Select Start New Individualization and press ⑤ to confirm.

You see and hear a prompt asking whether you would like further information.

► Select Yes or No and press ⑤ to confirm. If you select No, the first part of individualization begins. You will be asked whether you would like to train digits or voice commands.

If you select Yes, you will see and hear information on the individualization process. The first part of individualization then begins automatically.

► To close the display: press 🐿 the COMAND controller.

You will be asked whether you would like to train digits or voice commands.



P82.86-9970-31

At the end of the first part, a prompt will appear asking whether you wish to begin the second part.

► Select Yes or No and press ⑤ to confirm. If you select No, individualization will be canceled. The data from the first part is stored automatically.

If you select Yes, the second part will begin.

Individualization is completed at the end of the second part. You will see a message to this effect. The data from the second part is stored automatically.



P82.86-9971-31

Canceling the first or second part of individualization

- ► Confirm Cancel by pressing ⑤ the COMAND controller.

 A prompt appears asking whether you really wish to cancel.
- ► Select Yes or No and press ⑤ to confirm. If you select Yes, individualization will be canceled. The data from the part during which you exited is not stored.

If you select No, the current part begins again.

Deleting existing individualization data

- ➤ Select Vehicle by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- ► Select System and press ⑤ to confirm.
- ► Select Voice Control and press ⑤ to confirm.
- Select Delete Individualization and press to confirm.
 A prompt appears asking whether you really wish to delete.



► Select Yes or No and press ⑤ to confirm. If you select No, the process will be aborted. If you select Yes, the individualization is deleted. You will see a message to this effect.

Bluetooth® settings

General information about Bluetooth®

Bluetooth® technology is the standard for short-range wireless data transmission of up to approximately 10 meters. Bluetooth® allows, for example, the exchange of vCards. Bluetooth® is a registered trademark of Bluetooth Special Interest Group (SIG) Inc.



P82.86-9790-31

Requirements for a Bluetooth® connection

You can connect mobile phones and notebooks to COMAND.

To do so, the following conditions need to be met:

- Bluetooth®-capable devices, e.g. mobile phones, must comply with a certain profile in order to be connected to COMAND.
 Every Bluetooth® device has its own specific Bluetooth® name.
- Bluetooth[®] must be activated in COMAND and on the respective Bluetooth[®] device; see the separate operating instructions.
- the Bluetooth[®] device must be "visible" to COMAND in order for COMAND to find and display it. For the setting procedures, please see the operating instructions for the Bluetooth[®] device.

Once a mobile phone has been connected, reception and transmission volume may change.

Activating/deactivating Bluetooth®

- ► Select Vehicle in the main function bar by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- ➤ Select System by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- ➤ Select Bluetooth by turning 【○】 the COMAND controller and press ⑤ to confirm.
- ► Select Bluetooth activated and press to confirm.

This switches $Bluetooth^{\otimes}$ on $\overline{ }$ or off \square .

Connecting Bluetooth® devices

General information

Before using your Bluetooth® device with COMAND for the first time, you will need to connect it.

Connecting comprises:

- searching for a Bluetooth® device
- subsequently authorizing it
- 1 A maximum of 15 devices can be available for selection from the device list.


More detailed information on suitable mobile phones and on connecting Bluetooth®-capable mobile phones to COMAND can be found on the Internet at http://

www.mbusa-mobile.com. Or call the Mercedes-Benz Customer Assistance Center on 1-800-FOR-MERCedes(1-800-367-6372) (for the USA) or Customer Relations on 1-800-387-0100 (for Canada).



Searching for Bluetooth® devices

- ► Activate Bluetooth® (> page 147).
- ► Select Vehicle in the main function bar by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- ➤ Select System by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- ➤ Select Bluetooth by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- ► Select Search for Bluetooth Devices and press ⑤ to confirm.
- ► Select Update and press ⑤ to confirm. COMAND searches for Bluetooth® devices within range. After a short while, the Bluetooth® device list appears.



P82.86-9972-31

Example of display: Bluetooth® device list

- ① Currently connected and authorized device (✓ icon)
- ② Device not within range but previously authorized (g, appears in gray)
- Newly detected device in range, not yet authorized


The Bluetooth® device list shows all devices within range and all previously authorized devices, whether or not they are in range.

If the Bluetooth® device list is already full, you will be requested to de-authorize a device. If COMAND does not detect your Bluetooth® device, external authorization may be necessary (> page 149).

Authorizing a Bluetooth® device (registering)

- In the Bluetooth® device list, select not yet authorized device ③ by turning 【◎】 the COMAND controller.
- Select Options by sliding ⊙→ the COMAND controller and press ⑤ to confirm.
- ► Select Authorize and press 🔊 to confirm. or
- ► Press ⑤ to confirm the selected device.

 The input menu for the passcode appears.



P82.87-5754-31

The passcode is any one to sixteen-digit number combination which you can choose yourself. You must enter the same number combination in COMAND and in the Bluetooth® device to be authorized (see mobile phone operating instructions).

- 1 Some mobile phones require a passcode with four or more digits.
- i If you want to reauthorize a device following de-authorization (⊳ page 149), you can select a different passcode.
- ► To enter a passcode in COMAND: press the number keys in sequence.
 - ok can be selected after the first number has been entered.

or

Select the digits one by one by turning
 ↓ the COMAND controller and press
 to confirm.



► To confirm an entry in COMAND: select ok using the COMAND controller and press ⑤ to confirm.

or

- ► Select **SEND** on the telephone keypad.
- ► Enter the same passcode into the Bluetooth® device (see the operating instructions for the respective device). The device is authorized.

External authorization

If COMAND does not detect your Bluetooth® device, this may be due to particular security settings on your Bluetooth® device. In this case, you can test if your Bluetooth® device can find COMAND. The Bluetooth® device name of COMAND is "MB Bluetooth".

- ► Select Update.
- Select Options by sliding ⊙→ the COMAND controller and press ⑤ to confirm.
- ► Select External Authorization and press ⑤ to confirm.
- ► Start the Bluetooth® scan process on the Bluetooth® device (see separate operating instructions of the respective device).
- ► Select COMAND ("MB Bluetooth").
- 1 The order in which the passkey is entered depends on the mobile phone.
- ► Enter the passkey on the Bluetooth® device when prompted.
- ► Confirm the Do you want to authorize XX? question in COMAND with Yes.
- ► Enter the passkey in COMAND.

Displaying the details of a Bluetooth® device

In the Bluetooth® device list, select the desired device by turning 【◎】 the COMAND controller.

- ➤ Select Options by sliding ⊙→ the COMAND controller and press ⑤ to confirm.
- Select Details and press to confirm. The detailed display for this device appears.
- ► To close the detailed view: turn 【◎】 or slide ←◎→ the COMAND controller.

De-authorizing (de-registering) a Bluetooth® device

Mercedes-Benz USA, LLC recommends deauthorization in both COMAND and the Bluetooth® device, e.g. the mobile phone. Subsequent authorization may otherwise fail.

- ► In the Bluetooth® device list, select the authorized device by turning 【◎】 the COMAND controller.
- ➤ Select Options by sliding ○→ the COMAND controller and press ⑤ to confirm.
- ► Select De-authorize and press ⑤ to confirm.
 - A prompt appears asking whether you really wish to de-authorize this device.
- ➤ Select Yes or No and press ⑤ to confirm.

 If you select Yes, the authorization for the device will be revoked.
 - If you select No, the process will be aborted.
- i) If a Bluetooth® device has been deauthorized and is out of range, when a new search is carried out it will not appear in the Bluetooth® device list.

System language settings

This function allows you to determine the language for the menu displays and the navigation messages. The selected language affects the characters available for entry. When you set the system language, the language of the Voice Control System will



change accordingly. If the selected language is not supported by the Voice Control System, "English" will be selected.

- ► Select Vehicle by turning 🕻 🔾 🕽 the COMAND controller and press (5) to confirm.
- ► Select System and press ⑤ to confirm.
- ► Select Language and press (5) to confirm. The list of languages appears. The • dot indicates the current setting.
- ► Select the language by turning 【◎】 the COMAND controller and press (5) to confirm.

COMAND loads the selected language and sets it.

Reset function

You can reset COMAND to the factory settings. Amongst other things, this will delete all personal data (e.g. station presets, address book entries, entries in the destination memory and in the list of previous destinations in the navigation system). Resetting is recommended before selling or transferring ownership of your vehicle, for example.

- ► Select Vehicle in the main function bar by turning () the COMAND controller and press (5) to confirm.
- ► Select System by turning 🕻 🔾 🕽 the COMAND controller and press (5) to confirm.
- ► Select Reset and press ⑤ to confirm. A prompt appears asking whether you wish to reset.
- ► Select Yes or No and press (5) to confirm. If you select No, the process will be aborted. If you select Yes, another prompt appears asking whether you really wish to reset.
- ► Select Yes or No and press 🔊 to confirm. If you select Yes, a message will be shown. COMAND is reset and restarted.

If you select No, the process will be aborted.

Navigation

Introduction

Safety notes



♠ WARNING

For safety reasons, only enter a destination when the vehicle is stationary. When the vehicle is in motion, a passenger should enter the destination. Study manual and select route before driving.

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle is covering a distance of 44 feet (approximately 14 m) every second.

COMAND calculates the route to the destination without taking account of the following:

- Traffic lights
- · Stop and right-of-way-signs
- Lane merging
- · Parking or stopping prohibited areas
- Other road and traffic rules and regulations
- · Narrow bridges

↑ WARNING

COMAND may give incorrect navigation commands if the data in the digital map does not correspond with the actual road/traffic situation. Digital maps do not cover all areas nor all routes within an area. For example, if the traffic routing has been changed or the direction of a one-way road has been reversed.

For this reason, you must always observe applicable road and traffic rules and regulations during your journey. Road and traffic rules and regulations always have priority over the navigation commands generated by the system.



♠ WARNING

Navigation announcements are intended to direct you while driving without diverting your attention from the road and driving.

Please always use this feature instead of consulting the map display for directions. Looking at the icons or map display can distract you from traffic conditions and driving, and increase the risk of an accident.

General information

Operational readiness of the navigation system

The navigation system must determine the position of the vehicle before first use or whenever operational status is restored. Therefore, you may have to drive for a while before precise route guidance is possible.

GPS reception

Correct functioning of the navigation system depends, amongst other things, on GPS reception. In certain situations, GPS reception may be impaired, there may be interference or there may be no reception at all, e.g. in tunnels or parking garages.

Entry restriction

On vehicles for certain countries, there is a restriction on entering data.

The restriction is active from a vehicle speed of over approximately 3 mph (5 km/h). As soon as speed falls below approximately 2 mph (3 km/h), the restriction becomes inactive.

When the restriction is active, certain entries cannot be made. This will be indicated by the fact that certain menu items are grayed out and cannot be selected.

The following functions, for example, may therefore not be available while the vehicle is in motion:

- entering the destination city and street
- entering a destination via the map


- · entering points of interest in the vicinity of a city or via a name search
- · editing entries
- using the number keypad for direct entry

Switching to navigation mode

► Press the TEL function button once or twice.

٥r

► Select Navi in the main function bar by sliding ♠ ○ and turning **(** ○ **)** the COMAND controller and press (5) to confirm. In both cases, you will see the map either with or without the menu shown.



P82.87-3256-31

Map showing the menu; route guidance inactive

(1) Current vehicle position



Map without the menu; route guidance inactive

- Current vehicle position
- (2) Map orientation selected
- (3) Map scale selected

"Route guidance active" means that you have entered a destination and that COMAND has calculated the route. The display then shows



the route, changes of direction and lane recommendations. Navigation announcements guide you to your destination.

"Route guidance inactive" means that no destination has been entered and that no route has been calculated.

Showing/hiding the menu

- ► To hide the menu: slide + the COMAND controller over the map.
 - The Full Screen menu item is shown.
- ► Confirm the Full Screen menu item shown by pressing .
 - The map can be seen in the full-screen display.
- ➤ To show the menu: press ⑤ the COMAND controller when the map is shown in full-screen.

Basic settings

Route mode

Setting route type and route options

You can select the following route types:

- Fast Route: COMAND calculates the route with the shortest (minimized) journey time.
- Dynamic Route: same route type as Fast Route. In addition, COMAND takes traffic reports into account during route guidance⁶. Thus, the navigation system is able to guide you around a blocked section, for example. If a faster route is determined due to a received RDS-TMC traffic announcement, the navigation system changes the route. If possible, it will bypass blocked roads.

- Eco Route: the ECO route is an economical route that takes traffic announcements into account (see dynamic route).
- Short Route: COMAND calculates the route with the shortest possible (minimized) route distance.


In addition to route types, route options can also be set.

You can select the following route options:

- Use Carpool Lanes
- Minimize highways
- Minimize Toll Roads
- Minimize Tunnels
- Minimize Ferries
- Minimize Motorail Trains

If you select route options with a tick, the corresponding types of roads will be avoided in the route guidance where possible.

- ► To activate navigation mode: press the TEL | NAMI | function button once or twice.
- ► To show the menu: press ⑤ the COMAND controller.
- ► Select Navi in the main function bar by sliding t ⊚ and turning t ⊚ the COMAND controller and press to confirm.
- ► Select Mode and press ⑤ to confirm.



- ① To select the route type
- ② To set route options
- ➤ Select a route type and press ⑤ to confirm.
 The ⑥ icon indicates the current setting.
- 6 Traffic reports are not available in all countries.



- ► Select the route option(s) and press 🔊 to confirm.
 - The route options are switched on **✓** or off \square , depending on the previous status.
- If you change the route type and/or the route options while route guidance is active (the route has been calculated), COMAND will calculate a new route.

If you change the route type and/or the route options while route guidance is inactive (no destination has been entered yet), COMAND uses the new setting for the next route guidance.

The route calculated may, for example, include ferry connections, even if the Minimize Ferries route option is switched on.

In some cases, e.g. when calculating particularly long routes, COMAND may not be able to take all the selected route options into account. A note then appears in the COMAND display.

► To exit the menu: slide ← ○ → the COMAND controller.

Destination entry

Introduction to destination entry



↑ WARNING

For safety reasons, only enter a new destination when the vehicle is stationary. You could otherwise be distracted from the traffic conditions, cause an accident and injure yourself and others.

The following destination entry options are available:

- entering a destination by address
- entering a destination from the destination memory
- entering a destination from the list of last destinations
- entering a destination using the map

- entering an intermediate stop
- entering a point of interest

Entering a destination by address

Introduction

When entering an address as the destination, you have the following options:

- entering the state/province, city/ZIP code and street
- entering the state/province, city/zip code and center
- entering the state/province, city/zip code, street and house number
- entering the state/province, city/zip code, street and intersection
- entering the state/province, street, city and house number
- entering the state/province, street, house number and city
- entering the state/province, street, intersection and city
- 1 You can only enter those cities, streets, zip codes etc. that are stored in the digital map. This means that for some countries, you cannot enter zip codes, for example.

Example: entering an address

The following is a step-by-step example of how to enter an address. The destination address is as follows:

New York (state)

New York City

40 Broadway

You can of course enter any country, city, street and house number desired and enter, for example, your home address (My address).

Calling up the address entry menu

- ▶ To activate navigation mode: press the TEL function button once or twice.
- ▶ To show the menu: press ⑤ the COMAND controller.



- ► Select Destination by turning �① ♪ the COMAND controller and pressing ⑤ to confirm.
- ► Select Address Entry and press ⑤ to confirm.

The address entry menu appears. If you have previously entered a destination, this will be shown in the display.



P82.87-5566-31

Address entry menu

Depending on the sequence in which you enter the address and on the data status of the digital map, some menu items may not be available at all or may not yet be available. Example: after you have entered the state/

province, the No., Center, Intersection, Save and Start menu items are not yet available; the Zip Code menu item is not available if the digital map does not contain ZIP codes.

Selecting a state/province

► Select State/Prov. in the address entry menu by turning () the COMAND controller and press () to confirm.

A menu with the available lists appears. The state/province in which the vehicle is located is selected by default.

- Last States/Provinces
- States (U.S.)
- Provinces (Canada)
- ➤ To select a list: turn () the COMAND controller and press () to confirm.

 The list of selected states/provinces appears.
- ➤ To select a state/province: turn � ♪ the COMAND controller and press ⑤ to confirm.

The address entry menu appears again. The state/province selected has now been entered.

Entering the city

► Select City in the address entry menu by turning (○) the COMAND controller and press (●) to confirm.

You will see the city list either with the character bar (option 1) or as a selection list (option 2).

Option 1: city list with character bar

► Enter NEW YORK CITY. Instructions for entering characters can be found in the "Entering characters in navigation mode (entering a city)" section (> page 129).



P82.87-5446-31

Option 2: city list as selection list



	Back	NEW YORK	^
		NEW YORK MILLS	
		NEWARK	
		NEWARK VALLEY	
		NEWBRIDGE	
		NEWBURG	
		NEWBURGH	
		NEWBURGH JUNCTION	
- 1			

P82.87-5447-31

City list

- ► Select an entry by turning 🕻 🔾 🕽 the COMAND controller.
- ► Irrespective of the option, press 🔊 to confirm your selection. The address entry menu appears again. The city has now been entered.

Entering a street name

► Select Street in the address entry menu by turning **(** ○ **)** and sliding **+** ○ **↓** the COMAND controller and press (5) to confirm.

You will see the street list either with the character bar (option 1) or as a selection list (option 2).

Option 1: street list with character bar

► Enter BROADWAY. Instructions for entering characters using city input as an example can be found in the "Entering characters in navigation mode (entering a city)" section (⊳ page 129).



P82.87-5454-31

Option 2: street list as selection list



P82.87-5455-31

Street list

- ► Select a street by turning **(**) the COMAND controller and press (5) to confirm.
- ▶ Irrespective of the option, press ⑤ to confirm your selection. The address entry menu appears again. The street has now been entered.

Entering the house number

It is not possible to enter a house number until a street has been entered.

► Select No. in the address entry menu by turning **(** ○ **)** and sliding **1** ○ **1** the COMAND controller and press (5) to confirm.


The character bar appears.

- ▶ Enter a house number. Instructions for entering characters using city input as an example can be found in the "Entering" characters in navigation mode (entering a city)" section (⊳ page 129).
- ► Confirm the entry with 🔊. The address entry menu appears again. The house number has now been entered

Ambiguity of city names

If several cities share the same name, you can also directly input or select a street name. COMAND then selects the city where the respective street is found.





P82.87-3657-31

- ► Enter a city as described above (> page 153).
- ▶ Select ALL.
- ▶ Enter or select the street name.
- ► Select the appropriate city.

If you know the city well, you can continue directly after selecting the city from the list.

Starting route calculation

You can now have COMAND calculate the route to the address entered or save the address first, e.g. as your home address (My address) (▷ page 156).

COMAND checks whether the destination is unambiguous. If the destination is ambiguous, further information is requested to define the destination unambiguously, e.g. an area of city or a zip code.



P82.87-5567-31

Address entry menu with destination address

- (1) Destination address
- ② To start route calculation

► In the address entry menu, confirm Start by pressing ⑤.

If no other route has been calculated, route calculation starts immediately (Option 1). If another route has already been calculated (route guidance is active), a prompt appears (option 2).

Option 1 – no route guidance active: route calculation starts. While route calculation is in progress, an arrow will indicate the direction to your destination. Below this, you will see a message, e.g. Fast route is being calculated.

Once the route has been calculated, route guidance begins. If the vehicle is traveling on a non-digitized road, the system displays the linear distance to the destination, the direction of the destination and the Street Unknown message. In this case, the display will be grayed out.

Option 2 – route guidance is already active: if route guidance is already active, a prompt will appear asking whether you wish to terminate the currently active route guidance.

► Select Yes or No and press ⑤ to confirm. If you select Yes, COMAND will stop route guidance and start route calculation for the new destination.

If you select No, COMAND will continue with the active route guidance.

Route calculation takes a certain amount of time. The time depends on the distance from the destination, for example. COMAND calculates the route using the digital map data.

The calculated route may differ from the ideal route, e.g. due to roadwork or incomplete map data. Please also refer to the notes about the digital map (> page 188).

Entering and saving your home address

You can either enter your home address for the first time (option 1) or edit a previously stored home address (option 2).



- ▶ Option 1: enter the address, e.g. a city, street and house number (> page 153).
- ➤ Once you have entered the address, select Save in the address entry menu by turning (○) and sliding (○) the COMAND controller and press (○) to confirm.
- ► Select Save as "My Address" and press ⑤ to confirm.

COMAND stores your home address as My Address in the destination memory.

► Option 2: proceed as described under "Option 1".

A prompt appears asking whether the current home address should be overwritten.

► Select Yes and press ® to confirm.

After selecting Yes, the Save successful message appears.


Entering a ZIP code

Entering a ZIP code will delete a previously entered city.

➤ Select Zip Code in the address entry menu by turning 【◎】 and sliding ♠ ◎ ♣ the COMAND controller and press ⑤ to confirm.

You see the list of zip codes with the character bar.

▶ Enter a ZIP code. Instructions for entering characters using city input as an example can be found in the "Entering characters in navigation mode (entering a city)" section (> page 129).



P82.86-9993-31

- ① Digits entered by the user
- ② Digits automatically added by the system
- 3 List entry most closely resembling the characters entered so far
- To switch to the list without the character bar
- (5) To delete the entire entry: press and hold; to delete the last character: press briefly
- 6 Available characters
- (7) Selected character
- (8) Unavailable characters
- Character bar
- (10) To cancel an entry
- (11) List
- ► Confirm the entry with 🔊.

If COMAND is able to assign the ZIP code unambiguously to a specific address, the address entry menu appears again. The ZIP code appears in place of the city's name. If COMAND cannot assign the ZIP code unambiguously to a specific address, the address entry menu also appears again. The ZIP code is automatically entered. For a more precise location, you can now enter, for example, the street, a city, a center or a POI.

► Start route calculation (> page 156).

Entering a center

Entering a center will, for example, delete a previously entered street.

► Select Center (center) in the address entry menu by turning 【◎】 and sliding ↑ ◎ ↓ the



COMAND controller and press **(b)** to confirm.

You will see the center list either with the character bar (option 1) or as a selection list (option 2).

Option 1: center list with character bar

▶ Enter a center. Instructions for entering characters using city input as an example can be found in the "Entering characters in navigation mode (entering a city)" section (▷ page 129).



P82.87-5460-31

Option 2: center list as selection list



P82.87-5461-31

- ➤ Select a center by turning 【◎】 the COMAND controller.
- ► Irrespective of the option, press ⑤ to confirm your selection.

 The address entry menu appears again. The center selected has been entered.
- ► Start route calculation (> page 156).

Entering an intersection name

Entering an intersection will delete a previously entered house number.

► Select Intersection (intersection) in the address entry menu by turning 【◎】 and sliding ↑ ◎ ↓ the COMAND controller and press ⑤ to confirm.

You will see the intersection list either with the character bar (option 1) or as a selection list (option 2).

Option 1: intersection list with character bar

► Enter an intersection. Instructions for entering characters using city input as an example can be found in the "Entering characters in navigation mode (entering a city)" section (> page 129).



P82.87-2103-3

- ① List entry most closely resembling the characters entered so far
- 2) List
- ③ Character bar

Option 2: intersection list as selection list



P82.87-2478-31



- ► Select an intersection by turning 【◎】 the COMAND controller.
- ► Irrespective of the option, press ⑤ to confirm your selection.

 The address entry menu appears again. The intersection selected has been entered.
- ▶ Start route calculation (▷ page 156).

Selecting a destination from the destination memory (e.g. My address)

Introduction

The destination memory always contains an entry named "My address". You may wish to assign your home address to this entry, for example (▷ page 156), and select it for route guidance. This entry is always located at the top of the list in the destination memory.


- ► To activate navigation mode: press the TEL | function button once or twice.
- ► To show the menu: press 🔊 the COMAND controller.
- ► Select Destination in the navigation system menu bar by turning 【◎】 the COMAND controller and pressing ⑤ to confirm.
- ► Select From Memory and press ⑤ to confirm.
- ► Select My Address by turning () the COMAND controller.
- ► Irrespective of the option, press ⑤ to confirm your selection.

 "My address" has been entered.
- ► To start route calculation: select Start and press ⑤ to confirm.

Entering a destination from the list of last destinations

► To activate navigation mode: press the TEL | INDICATE | INDIC

- ► To show the menu: press ⑤ the COMAND controller.
- ► Select Destination in the navigation system menu bar by turning 【◎】 the COMAND controller and pressing ⑤ to confirm.
- ► Select From Last Destinations and press ⑤ to confirm.



P82.87-2108-31

"Last destinations" list

- 1 Last destination
- ► Select the desired destination by turning () the COMAND controller and pressing to confirm.

The destination address selected has been entered.

- ► To start route calculation: select Start and press ⑤ to confirm.
 - Once the route has been calculated, route guidance begins (▷ page 166).
- 1 Further information on the "Last destinations" memory can be found on (> page 181).
- ► To navigate to another street in the same city or to another house number



on the same street: call up an address destination from the last destinations.

- Select Change by turning () and sliding
 the COMAND controller and press
 to confirm.
 All destination entry functions are
 - All destination entry functions are available.
- ► Edit/enter the destination as described for destination entry (> page 153).

Entering a destination using the map

Calling up the map

- ► To activate navigation mode: press the TEL | function button once or twice.
- ► To show the menu: press 🕲 the COMAND controller.
- ➤ Select Destination in the navigation system menu bar by turning 【○】 the COMAND controller and pressing ⑤ to confirm.
- ► Select Via Map and press ⑤ to confirm. You see the map with the crosshair.



P82.86-9977-31

- (1) Current vehicle position
- ② Crosshair
- (3) Details of the crosshair position
- 4 Map scale selected

Display ③ depends on the settings selected in "Map information in the display" (> page 185). The current street name can be shown, provided the digital map contains the necessary data, or the coordinates of the crosshair if the geo-coordinate display is

switched on and the GPS signal is strong enough.

Moving the map and selecting the destination

- ► To scroll the map: slide ← 🔾 →, † 🔾 ↓ or 📜 🕻 the COMAND controller.
- ➤ To set the map scale: as soon as you turn (○) the COMAND controller, the scale bar appears.
- ➤ Turn 【◎】 until the desired scale is set. Turning clockwise zooms out from the map; turning counter-clockwise zooms in.
- ➤ To select a destination: press ⑤ the COMAND controller once or several times. You will see either the address entry menu with the destination address or, if COMAND is unable to assign a unique address, a selection list.



MERCEDES DR
MERCEDES-BENZ USA
DEPIERO'S FARM
DEPIERO'S FARM
GRAND AVE W
CRAIG RD

P82.87-2109-31

Select a destination by turning 【○】 the COMAND controller and press ⑤ to confirm.

If the destination is within the limits of the digital map, COMAND attempts to assign the destination to the map.

If the destination can be assigned, you will see the address entry menu with the address of the destination. If not, you will see the entry Destination from Map.

➤ To start route calculation: select Start and press ⑤ to confirm.



Entering an intermediate stop

Introduction

When route guidance is active, you can enter an intermediate stop. Intermediate stops can be predefined destinations from the following categories that COMAND offers for selection:

- Mercedes-Benz Service Center
- Hospital
- Gas Station
- · Parking Lot
- Restaurant

However, you can also enter destinations other than the predefined ones. To do this select the menu item **Other**.

You can use the intermediate stop function to influence route guidance to the main destination. When you have reached your intermediate stop, COMAND automatically recalculates the route to the main destination

Entering predefined destinations

- ► To activate navigation mode: press the TEL | Indicate | Indica
- ➤ To show the menu: press ⑤ the COMAND controller.
- ► Select Destination in the navigation system menu bar by turning 【○】 the COMAND controller and pressing ⑤ to confirm.
- ► Select Stopover and press ⑤ to confirm.

Option 1: no intermediate stop has been entered yet.

► Select a category; see option 2.

Option 2: an intermediate stop has already been entered.

► Select Change Stopover and press ⑤ to confirm.

➤ To select a category: select a category by turning 【◎】 the COMAND controller and pressing ⑤ to confirm.

COMAND first searches in the selected category for destinations along the route. If there are no destinations available there, COMAND searches for destinations within a radius of up to 100 km of the vehicle position.

If COMAND finds destinations, a list appears on the right-hand side of the display. The currently selected point of interest is highlighted on the left-hand side of the map.

The intermediate stops are listed according to increasing distance from the current vehicle position. They are displayed in the form of a name and their position in relation to the route and your direction of travel.

If COMAND does not find any destinations, you will see a message to this effect.

- ► Confirm **OK** by pressing **⑤**.
- ► Select a different category.
- Select the intermediate stop by turning
 ↓ ♪ the COMAND controller and pressing
 to confirm.
- ► To start route calculation: select Start and press 🕲 to confirm.

Entering another destination as an intermediate stop

- ► To activate navigation mode: press the TEL | MANI | function button once or twice.
- ► To show the menu: press 🔊 the COMAND controller.
- ➤ Select Destination in the navigation system menu bar by turning 【○】 the COMAND controller and pressing ⑤ to confirm.
- ► Select Stopover and press ⑤ to confirm.
- ► Select Other and press ⑤ to confirm.



► Select Address Entry, From Memory, From Last Destinations or From POIs.

Selection	Step
Address Entry	► Enter a destination by address (> page 153).
From Memory	► Select a destination from the destination memory (> page 159).
From Last Destinations	► Select a destination from the list of last destinations (> page 159).
From POIs	► Enter a point of interest (> page 162).

➤ To start route calculation: once you have entered a destination, select Start and press ⑤ to confirm.

Deleting an intermediate stop

If an intermediate stop has already been entered, you can delete it.

- ► To activate navigation mode: press the TEL | function button once or twice.
- ► To show the menu: press ⑤ the COMAND controller.
- ➤ Select Destination in the navigation system menu bar by turning 【◎】 the COMAND controller and pressing ⑤ to confirm.
- ► Select Stopover and press 🔊 to confirm.

► Select Delete Stopover and press ⑤ to confirm.

COMAND deletes the intermediate stop and recalculates the route to the main destination.

Entering a point of interest

Initiating point of interest entry

- ► To activate navigation mode: press the TEL | function button once or twice.
- ► To show the menu: press 🔊 the COMAND controller.
- ► Select Destination in the navigation system menu bar by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- ► Select From POIs and press ® to confirm.
 A menu appears.

Entering a point of interest in the vicinity of the destination

Entering a point of interest in the vicinity of the destination is only possible when route guidance is active.

- ► Select Destination Area from the menu and press (*) to confirm.
- ► Continue with assigning the point of interest category (> page 163).

Entering a point of interest in the vicinity of the current position

- ► Select Current Position and press ⑤ to confirm.
- ► Continue with assigning the point of interest category (> page 163).



Entering a point of interest in the vicinity of a specific city

Option 1

- ► Select Other City in the menu and press ⑤ to confirm.
- ► If desired, select the state/province (> page 153).
- ➤ To enter a city: select City and press ⑤ to confirm.
 - Proceed as described in the "Entering a city" section (▷ page 153).
- ► After entering the city, select the point of interest category (▷ page 163).

Option 2

- ► Enter an address in the address entry menu, e.g. a city, street and house number (> page 153).
- ► Select POI and press ⑤ to confirm.
- ► Select the point of interest category (> page 163).

Entering a point of interest using name search

This function allows you to access all the points of interest available on the digital map.

- ► Select By Name from the menu and press ⑤ to confirm.
 - You will see a list of further selection options.
- ► Select the desired option and press ⑤ to confirm.
- ► Enter the name using the character bar.

Entering a point of interest using the phone number search

This function gives you access to all points of interest that have a phone number.

► Select By Telephone Number and press ⑤ to confirm.

You will see a list of phone numbers.

► Enter the phone number using the character bar.

Assigning a point of interest category

Introduction

The categories and points of interest available depend on the distance from the vehicle position you have set for the point of interest.

- point of interest in the vicinity of the destination:
- Alphabetically sorted categories, as well as points of interest in the vicinity of the target destination and sorted by distance are available.
- point of interest in the vicinity of the current position:
 - Alphabetically sorted categories are available, as well as points of interest in the vicinity of the vehicle position arranged by distance.
- point of interest within a given city:
 If you have entered only the state/province and the city, the system will return alphabetically sorted categories and points of interest within the city limits.
 - If you have entered more than the state/ province and the city, the system will return alphabetically sorted categories and points of interest sorted by distance, all in the vicinity of the address you entered.
- point of interest using name search:
 An alphabetically sorted list of all points of interest is available.
 - The list sorts points of interest with the same name and in the same category according to distance, starting with those nearest to you.

Selecting a category

Select a main category by turning (○) the COMAND controller.



- ► Confirm the entry with ⑤.

 If the selected main category does not contain any sub-categories, the point of interest list appears.
 - If the selected main category contains subcategories, a list of the subcategories appears with the input speller.
- ➤ Select a category by turning 【◎】 the COMAND controller.
- ► Confirm the entry with ⑤.

 The point of interest list appears. It contains the points of interest available in the sub-category that are within the search radius.
- 1 Search radius means: COMAND searches within a radius of 100 km.
 - If COMAND does not find any points of interest within this radius, it extends its search range to approximately 200 km. If COMAND finds one point of interest within this radius, it finishes the search.
- i If you select the ALL list item, the point of interest list contains all points of interest for all subcategories in the Restaurant main category which lie within the search radius.

Point of interest list

Introduction

The illustration below shows an example of the point of interest list for the Restaurant main category in the vicinity of the current position.

- 1 Depending on the point of interest selected, COMAND uses different reference points in determining the linear distance to the destination:
 - vicinity of current position: the linear distance is the distance of the point of

- interest from the current vehicle position.
- vicinity of destination: the linear distance is the distance from the destination entered to the point of interest.

Selecting a point of interest

- ► Select a point of interest by turning 【○】 the COMAND controller and press ⑤ to confirm.
 - The complete address of the point of interest selected is shown.
- ► To start route calculation: select Start and press (*) to confirm.
- ► To store an address in the destination memory: select Save and press ⑤ to confirm. You can now select storage options (> page 179).
- ► To show the detailed view: select Details and press (5) to confirm.
- ▶ To make a call: select Call and press ⑤ to confirm (only available if the point of interest contains a telephone book entry and a telephone is connected to COMAND). COMAND switches to telephone mode (▷ page 199).
- ► To call up the map: select Map and press ⑤ to confirm.
- ➤ You can move the map and select the destination (> page 160).

ZAGAT® Survey service

Entries with the Z icon contain additional ZAGAT information. ZAGAT rates restaurants, for instance, in regard to the quality of the food, furnishing, service, and provides an average pricing level as well as a general description.





P82.87-2118-31

Select the entry with the Z icon by turning

 ↓ the COMAND controller and press


 to confirm.

The ZAGAT evaluations appear.



P82.87-2119-31

- 1 ZAGAT ratings
- ② To display details
- ► To show a description: select Details and press 🕙 to confirm.



P82.87-2120-31

ZAGAT example description

Selecting a point of interest using the map

You can select points of interest that are available in the selected (visible) section of the map.

- ► To activate navigation mode: press the TEL function button once or twice.
- ► To show the menu: press 🕲 the COMAND controller.



P82.87-5516-31

- (1) Highlighted point of interest
- ► Slide ○ the COMAND controller forwards and thereby activate the display window. The map with highlighted point of interest (1) is shown.
- ➤ To highlight the next point of interest: select Next in the menu bar by turning (○) and sliding → ← the COMAND controller and press (5) to confirm.
- ➤ To highlight the previous point of interest: select Previous in the menu bar by turning (○) and sliding → ← the COMAND controller and press (●) to confirm.
- ► To display details of a point of interest: select Details in the menu bar by turning (○) and sliding → ← the COMAND controller and press (*) to confirm.



Route guidance

General notes

↑ WARNING

COMAND calculates the route to the destination without taking into account the following, for example:

- · Traffic lights
- · Stop and right-of-way signs
- · Lane merging
- Parking or stopping prohibited areas
- · Other road and traffic rules and regulations
- Narrow bridges

COMAND may give incorrect navigation commands if the data in the digital map does not correspond with the actual road / traffic situation. For example, if the traffic routing has been changed or the direction of a oneway road has been reversed.

For this reason, you must always observe applicable road and traffic rules and regulations during your journey. Road and traffic rules and regulations always have priority over the navigation commands generated by the system.

Route guidance begins once a route has been calculated (⊳ page 156).

COMAND guides you to your destination by means of navigation commands in the form of audible navigation announcements and route guidance displays.

The route guidance displays can only be seen if the display is switched to navigation mode.

If you do not follow the navigation announcements or if you leave the calculated route, COMAND automatically calculates a new route to the destination.

If the digital map contains the corresponding information, the following applies:

 when selecting a route, COMAND tries to avoid roads that only have limited access,

- e.g. roads closed to through traffic and nonresidents.
- roads that have time restrictions (e.g. closed on Sundays and public holidays) are avoided for route guidance.

Change of direction


Introduction

Changes of direction have three phases:

- · preparation phase
- announcement phase
- · change-of-direction phase

Preparation phase

COMAND prepares you for the upcoming change of direction. Based on the example display below, the change of direction is announced with a message. You see the fullscreen map.



P82.87-2122-31

Example display: preparation phase

- Next road
- ② Route
- (3) Current vehicle position (the tip of the triangle indicates the vehicle's direction of travel)
- (4) Current road

The display in (4) depends on the setting selected under "Text information on the map" (⊳ page 185).

Announcement phase


COMAND announces the imminent change of direction. With reference to the following example display, the announcement is given



before the change of direction with the request Please turn right in 900 ft.

The announced distance to the next change of direction depends on the type of road and its permissible speed limit.

The display is now split into two sectors. In the left half, you see the normal map view. The right half shows an enlarged section of the area around the intersection (Crossing Zoom) or a 3D image of the road's course with the route indicating the next maneuver.




P82.87-2123-31

Example display: announcement phase

- Next road
- ② Point at which the change of direction takes place (light blue dot, shown in both the left and right displays)
- ③ Graphic representation of the distance to the next change of direction
- 4 Change of direction (turn right here)
- 5 Distance to the next change of direction
- Route (highlighted in blue, shown in both the left and right displays)
- 1 The filled-in section of visual display for distance 3 gets shorter, the nearer you get to the announced change of direction.

Change-of-direction phase

COMAND announces the imminent change of direction. In the example, the Now turn right announcement is made 100 ft. before the change of direction. The display is split into two halves, as in the announcement phase.



P82.87-2124-31

Example display: change-of-direction phase

- Current vehicle position: the tip of the triangle indicates the vehicle's direction of travel
- ② Graphic representation of the distance to the next change of direction
- 3 Distance to the next change of direction

Once the change of direction is completed, COMAND automatically switches back to fullscreen display.

Lane recommendations

Overview

required.

On multilane roads, COMAND can display lane recommendations for the next change of direction. The corresponding data must be available in the digital map.

COMAND displays lane recommendations (a), based on the next two changes of direction. The number of lanes applies to the point at which the next change of direction is





P82.87-3779-31

Example display

- ① Point of the next change in direction (light blue circle)
- ② Point of the change of direction after next
- ③ Next change of direction (in this case, turn off to the right)
- ④ Graphic representation of the distance to the next change of direction
- 5 Distance to the next change of direction
- O Possible lane (light blue)
- Recommended lane (dark blue)
- 8 Lane not recommended (gray)
- Current vehicle position: the tip of the triangle indicates the vehicle's direction of travel
- The multifunction display also shows lane recommendations. Only the recommended lanes are displayed here. (▷ page 377).



Display and description of lane recommendations

The colors used in the lane recommendation display vary depending on whether day or night design is switched on.

Lane	Day design	Night design
Recommended lane ⑦ In this lane, you will be able to complete the next two changes of direction without changing lanes.	Dark blue	Light blue
Possible lane (6) In this lane, you will only be able to complete the next change of direction without changing lanes.	Light blue	Dark blue
Lane not recommended (8) In this lane, you will not be able to complete the next change of direction without changing lane.	Gray	Gray

Display in the multifunction display


The lane recommendations are also shown in the multifunction display. You will find further information in the "On-board computer" section (> page 377).

Using car pool lanes

COMAND displays car pool lanes if you have selected this option in the route options (> page 152).

If this is the case, COMAND checks whether there are any car pool lanes on the route. If there are, they are taken into account during route calculation. Route guidance will then include car pool lanes.

Car pool lanes may only be used under certain conditions. Please observe the relevant legal requirements.



Example: display, car pool lane

- 1) Identification marking on the road
- 2 Identification marking in COMAND

Canceling or continuing route guidance

Canceling route guidance

- ► To activate navigation mode: press the TEL | NAMI | function button once or twice.
- ► To show the menu: press 🔊 the COMAND controller.
- ► Select Destination in the navigation system menu bar by turning 【○】 the COMAND controller and press ⑤ to confirm.



► Select Cancel Route Guidance and press to confirm.

Continuing route guidance

- ▶ To activate navigation mode: press the TEL function button once or twice.
- ▶ To show the menu: press 🔊 the COMAND controller.
- ► Select **Destination** in the navigation system menu bar by turning 🕻 🔾 🕽 the COMAND controller and press (5) to confirm.
- ► Select Continue Route Guidance and press (5) to confirm. COMAND calculates the route.

Destination or area of destination reached

When you reach your destination, COMAND displays a checkered flag and route guidance is automatically ended.

For certain points of interest (e.g. airports), the Destination Reached display is shown as well as the checkered flag.

Navigation announcements

Repeating navigation announcements



↑ WARNING

Navigation announcements are intended to direct you while driving without diverting your attention from the road and driving.

Please always use this feature instead of consulting the map display for directions. Looking at the icons or map display can distract you from traffic conditions and driving, and increase the risk of an accident.

1 Audible navigation announcements are muted during a telephone call.

If you have missed an announcement, you can call up the current announcement at any time.

- ▶ To show the menu: press ⑤ the COMAND controller.
- ► In the navigation menu bar, confirm RPT with 🖲.

Switching navigation announcements on/off

▶ To switch off: during the announcement, press the 🙀 button on the multifunction steering wheel.

You will briefly see the message: The driving instructions have been muted.

- ► To switch on: press ⑤ the COMAND controller.
- ▶ In the 🕦 navigation menu bar, press 🔊 to confirm.
- 1 COMAND automatically switches the navigation announcements back on when:
 - you have a new route calculated.
 - you start the engine again after having left the vehicle.

Reducing volume during a navigation announcement

The volume of an active audio or video source can be automatically reduced during a navigation announcement.

- ► Select Navi in the main function bar by sliding **↑** ○ and turning **↓** ○ **↓** the COMAND controller and press (5) to confirm.
- ► Select Audio Fadeout and press (5) to confirm.

The function is switched on $\mathbf{\nabla}$ or off \square , depending on the previous status.

Setting the volume manually

► Set the volume during a navigation announcement.

or

▶ In the map display when the menu is shown, select)) and adjust the volume.



Avoiding a section of the route blocked by a traffic jam

This function blocks a section of the route ahead of you. You can set the length of the blocked route section. If possible, COMAND calculates a detour around the blocked section of the route.

- ► To activate navigation mode: press the TELL NAME function button once or twice.
- ► To show the menu: press 🔊 the COMAND controller.
- ► Select Route in the navigation system menu bar by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- ► Select Detour and press ⑤ to confirm.
- ► To block a section of the route: select More or Less repeatedly and confirm using ⑤ until the desired section has been selected.
- The total length of the section that can be blocked is defined by the digital map. The menu items are available accordingly.
- ➤ To start route calculation: select Start and press ⑤ to confirm.
- ▶ To delete the blocked section: select Delete while the message is shown and press ⑤ to confirm. COMAND calculates the route without the block.


Selecting an alternative route

With the "Alternative route" function, routes other than the original one can be calculated.

- ► To activate navigation mode: press the TEL | Indicate | Indica
- ► To show the menu: press 🔊 the COMAND controller.
- ► Select Route in the navigation system menu bar by turning 【◎】 the COMAND controller and press ⑤ to confirm.

► Select Alternative Route and press to confirm.

You see the selected route. The display now shows a split-screen view. On the left-hand side, one or more alternative routes are shown from start to destination. The current route is highlighted dark blue; other alternative routes appear light blue.



- ① Distance, expected arrival time and expected journey duration
- (2) Displays incidents which are on the route
- ③ Displays the selected route settings
- ► To select the next or previous alternative route: select Next or Previous and press ⑤ to confirm.

 Possible alternative routes are shown in the following order: Current Route, Fast Route, Eco Route, Short Route and Alternative Route.
- ➤ To select the original route: select Back a corresponding number of times and press to confirm.
- ➤ To start route guidance using the selected alternative route: select Start and press ⑤ to confirm.

 COMAND accepts the alternative route.
- 1 The change of route mode in the alternative route menu only applies to the current route guidance. For example, if the original route was a short route, the next route will also be calculated as a short route. This is also the case if a dynamic route is selected in the alternative route menu.



Displaying destination information

Prerequisite: you have entered a destination (> page 153) and possibly an intermediate stop (> page 161).

- ► To activate navigation mode: press the TEL | INDICATE | INDIC
- ► To show the menu: press ⑤ the COMAND controller.

Destination information is displayed.

If a telephone number is entered for the address displayed, you can also select and call the number using COMAND.


- ► To call the destination: select the telephone number using the COMAND controller and press 🔊 to confirm.
- ► To close the destination information: slide ← ○ → the COMAND controller or press the 🛨 back button.

Route overview

You can use the overview of the route to move along the route section by section and to see details of the route sections.

You have entered a destination (▷ page 153) or a point of interest (▷ page 162) and possibly an intermediate stop (▷ page 161).

- ► To activate navigation mode: press the TEL MANI function button once or twice.
- ► To show the menu: press 🔊 the COMAND controller.
- ► Select Route in the navigation system menu bar by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- ➤ Select Route Info and press ⑤ to confirm.



P82.87-5583-31

Example display: route overview

(1) Marked route sections

At the top of the display, you will see information about the highlighted route section, for example the distance to be driven on the road and road designation. The highlighted route section is marked in white with a red border on the map.

- ➤ To view the next or previous route section: select Next or Previous and press ⑤ to confirm.
- 1 If the first or last route section is highlighted, you cannot select Previous or Next.
- ► To zoom in or out of the map: select ⓐ or ⓐ and press ⓑ to confirm.
- ► To close the route overview: select Back and press ⑤ to confirm.

Where am I?

You can view your current position whether or not route guidance has been interrupted.

- Current position
- (2) Next intersection or exit
- (3) Most recent intersection or exit
- (4) Current street
- ► To activate navigation mode: press the TEL function button once or twice.
- ► To show the menu: press ⑤ the COMAND controller.



- ► Select Position in the navigation system menu bar by turning () the COMAND controller and press (5) to confirm.
- ► Select Where am I? and press (5) to confirm.

Off-road

Important safety note




↑ WARNING

The COMAND navigation system may direct you to off-road routes that your vehicle may not be capable of traversing through without damaging your tires, wheels or vehicle. It is the driver's sole responsibility to determine the suitability of the route. Off-road routes may be of varying conditions and their appropriateness for use may be affected by various factors such as time of day, time of vear and immediate weather conditions that cannot be judged or taken into consideration by the COMAND system.

Route guidance to a destination that is not on a digitized road

COMAND can guide you to destinations which are within the area covered by the digital map, but which are not themselves recorded on the map.

These destinations are known as off-road destinations, which you can enter using the map, for example. In these cases, COMAND guides you for as long as possible with navigation announcements and displays on roads known to the system.



Example display: route guidance to an off-road destination

- (1) Off-road destination
- (2) Off-road route section (dashed blue)
- (3) Current vehicle position (the tip of the triangle indicates the vehicle's direction of travel)
- 4) Off-road (no street names available)

If the vehicle reaches an area which is not part of the digital map, the display appears as a split-screen view. On the right-hand side, an arrow appears which points to off-road destination (1). You will hear the announcement: "Please follow the arrow on the display".

Route guidance from an off-road location to a destination

If the vehicle position is within the area covered by the digital map, but the map does not contain any information about that location, the vehicle is in an off-road location. COMAND is also able to guide you to a destination even from an off-road location.

At the start of the route guidance, you will see the Street unknown message, an arrow and the distance to the destination. The direction arrow shows the linear direction to the actual destination.

The continuous blue line on the map starts at the street which you left last.

As soon as the vehicle is back on a road known to the system, route guidance continues in the usual way.



Off-road during route guidance

Due to roadworks, for example, there may be differences between the data on the digital map and the actual course of the road.

In such cases, the system will temporarily be unable to locate the vehicle position on the digital map and thus considers the vehicle to be in an off-road position.

In the display, you will see the **Street unknown** message, an arrow and the distance to the destination. The arrow shows the compass heading to the last road you were driving on.

As soon as the system can assign the vehicle position to the map again, route guidance continues in the usual way.

Route guidance on roads that are not completely digitalized

COMAND attempts to avoid roads that have not been completely digitalized. If the vehicle's position or the destination is located in an area that has not been completely digitalized, then no active route guidance is performed. Instead, the map shows a dashed route along the roads and the target direction is shown with an arrow. You hear the announcement: "You will enter an area, where turn-by-turn guidance can not be provided. Please follow the arrow on the display". Once these roads have been left, regular route guidance is resumed.

Traffic reports

Prerequisite

1 The SatRadio mode described below requires optional satellite radio equipment and a subscription to SIRIUS XM Satellite Radio Traffic Message Service. Further details on SatRadio are available in the "SatRadio" section (⊳ page 216).

COMAND can receive traffic reports via SatRadio and incorporate them in the

navigation system. Traffic messages and map symbols can then be shown in the COMAND display.

COMAND uses high quality traffic data. Nevertheless, there may be differences between the traffic reports received and the actual road and traffic conditions.

Switching traffic reports on/off

- ► To switch on: set the route type to Dynamic Route⁷(> page 152).
- ➤ To switch off: select the Fast Route or Short Route route type (> page 152).
- i COMAND calculates a new route if you change the route type setting with route guidance active. If you change the route type setting when route guidance is inactive, COMAND uses the new setting for the next route guidance.

Real-time traffic reports on the map

COMAND can show certain traffic incidents on the map. The incidents are shown on the map at a scale from 1/16 mi to 20 mi.

▶ Set the map scale (> page 182).



P82.87-3662-3

- (1)(2) Icon display for the section of route affected
- (3) Icon for incident on the route
- 4 Current position and direction of travel
- Map scale





COMAND uses corresponding icons to highlight the entire section of the affected route, regardless of how long the incident actually is. The icons are placed on the side of the road affected by the incident.



Icon for real-time traffic reports

Icon	Description	Traffic reports in the map display
•	Warning (red)	A warning appears, for example, relating to lost cargo.
\diamondsuit	Caution (yellow)	A warning appears, for example, relating to roadwork that does not affect the flow of traffic.
&	Slow-moving traffic	This appears at the beginning of a traffic jam (average speed 25 - 45 mph) if route guidance is active and the route leads through an area of congested traffic. Yellow car icons may appear in conjunction with this icon.
>	Traffic jam on the route	This appears at the beginning of a traffic jam (average speed 5 - 20 mph) if route guidance is active and the route leads through an area of congested traffic. Red car icons may appear in conjunction with this icon.
0	Blocked route section on the route	Appears at the beginning of a blocked route section if route guidance is active and the route leads through the blocked section. The XXXX icons may appear in conjunction with this icon.
Yellow line with arrows	Incidents	Possible traffic blocks (e.g. roadwork) Appears on the side of the road affected (direction of travel)
Green line with arrows	Unimpeded traffic flow	No delays Only appears on the side of the road (direction of travel) on which traffic flow is unimpeded
	Slow-moving traffic (stop/start traffic) (yellow vehicle)	High volume of traffic, average speed 40 – 72 km/h (25 – 45 mph). In order to indicate the volume of traffic, more than one symbol may appear.
A	Traffic jam on the route (stop/start traffic) (red vehicle)	Very high volume of traffic, average speed 8 – 32 km/h (5 – 20 mph).
XXXX	Blocked route section	Unusable section of road. In order to indicate the length of the blocked section, more than one symbol may appear.



Displaying real-time traffic reports

- ► If necessary, switch to navigation mode and show the menu (> page 152).
- ► Select Traffic in the navigation system menu bar by turning (○) the COMAND controller and press (b) to confirm.

If you see the No traffic messages. message:

This means that:

- no traffic reports have been received yet.
- no traffic reports are available.
- ▶ To cancel the search: select Cance.
- ► To close the message window: select OK.

If there are any traffic reports, a list is shown. The content of the list varies depending on whether route guidance is active or not.


List of traffic reports



P82.87-5602-31

➤ To show the traffic report list: select Display All Messages by turning () the COMAND controller and press () to confirm.

The list shows all the roads, areas or regions for which traffic reports are available.




P82.87-5607-31

- 1) State or province recognition
- (2) Road affected
- 1 A traffic report may refer to an area or a region, e.g. if visibility is impaired due to fog.
- ► To read a traffic report: select a road, an area or a region.
- ➤ To show a traffic report: select a road, an area or a region and press ⑤ to confirm.

 You will find an example of a traffic report below.
- ► To exit the list: slide ← → the COMAND controller once or several times.

Example: traffic report



P82.87-5603-31

- (1) Country code
- ② Road, area or region affected by traffic reports
- ③ Direction
- (4) Report 1 of 8 for the road affected
- (5) Last exit/intersection before the affected route section starts



- 6 Report text
- First exit/intersection after the affected route section ends
- ► To scroll within a report or to access the next report: turn () the COMAND controller.
- ► To return to the list of messages: press
 ⑤ or slide ← → the COMAND controller.

Showing icon information



P82.87-5589-31

Example display

- Affected section of freeway
- 2 Icon for an event
- ➤ To show the next/previous incident: select Next or Previous (if available) and press ⑤ to confirm.
- ► To show the detailed view: select Details and press ⑤ to confirm.
- ► To scroll the map: select Map and press ⑤ to confirm.

You can move the map (> page 160) to enable further traffic reports to be displayed.

Destination memory

Home address (My address)

Entering the home address via address entry

► Enter the home address as a destination, e.g. as a city, street and house number (> page 153). Then, save the home address without starting route guidance (⊳ page 156).

Adopting an address book entry as a home address

- ► To activate navigation mode: press the TEL | function button once or twice.
- ► To show the menu: press ⑤ the COMAND controller.
- ➤ Select Destination in the navigation system menu bar by turning 【○】 the COMAND controller and press ⑤ to confirm.
- ► Select From Memory and press ⑤ to confirm.
- ► Slide ★ ⊚ the COMAND controller repeatedly until the destination memory list appears as a selection list.



P82.87-5409-31

- Select My Address by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- 1 If you have not yet entered any characters, the My Address entry is automatically highlighted in the selection list.

If no home address has been stored yet, you can now assign an address book entry. If a home address already exists, it is displayed and you can alter it.

ilf you select New Entry, you are also offered the option of entering the home address for the first time. You can then



save the home address without starting route guidance.

- ➤ To enter the home address for the first time: select Assign Address Book Entry and press ⑤ to confirm.
- ➤ Select Home or Work and press ⑤ to confirm.
- ► To change the home address: select Change and press (*) to confirm.
- ► Select Assign Address Book Entry and press (*) to confirm.
- i If you select New Entry, you are also offered the option of changing the home address by entering an address. You can then save the home address without starting route guidance.
- Select Home or Work and press to confirm.
 In both cases, you will see the address book either with the character bar or as a selection list
- ► To select an address book entry: proceed as described in the "Searching for an address book entry" section (> page 205).
- ► To confirm the selection: press ⑤ the COMAND controller.

 If no home address has been stored, COMAND saves the entry. You will see a

COMAND saves the entry. You will see a message and then the address menu with the selected address. **Start** is highlighted automatically.

If a home address has already been stored, you will see a prompt asking you whether the My Address entry should be overwritten.

► Select Yes or No and press ⑤ to confirm. If you select Yes, COMAND overwrites the destination. You will see a message and then the address menu with the selected address. Start is highlighted automatically.

If you select No, the list will reappear.

Selecting the home address for route guidance

▶ Proceed as described in the "Selecting a destination from the destination memory" section (▷ page 159).

Storing a destination in the destination memory

Note

This function also stores the destination in the address book.

After destination entry

- The destination has been entered and is shown in the address entry menu (▷ page 156).

You can now select storage options.

During route guidance

- ► To show the menu: press 🔊 the COMAND controller.
- Select Destination in the navigation system menu bar by turning 【○】 the COMAND controller and press ⑤ to confirm.
- ► Select Save Destination and press ⑤ to confirm.

You can now select storage options.

From the list of previous destinations

- ► To show the menu: press 🔊 the COMAND controller.
- Select Destination in the navigation system menu bar by turning 【○】 the COMAND controller and press ⑤ to confirm.
- ► Select From Last Destinations and press ⑤ to confirm.

The list of last destinations appears.




► Select a destination by turning 【◎】 the COMAND controller and press (8) to confirm.

The destination address is shown.

► Select Save and press 🖲 to confirm. You can now select storage options.

Selecting storing options

- ▶ To save the destination without a name: select Save without Name and press (5) to confirm.
 - COMAND stores the destination in the destination memory and uses the address as the destination name.
- ▶ To save the destination as My address: select Save as "My Address" and press (b) to confirm.
 - COMAND stores the destination in the destination memory as My Address. If the entry already contains navigable data (symbol (♠)), a prompt appears asking you whether the entry should be overwritten.
- ► Select Yes or No and press ⑤ to confirm. If you select Yes, the entry is overwritten. If you select No, the process will be aborted.
- ► To save the destination with a name: select Save with Name and press ® to confirm.
- ► Select a category, e.g. Home, and press 🔊 to confirm.
 - The input menu appears with data fields and the character bar.



Example display: saving a destination with a name

- (1) Selected data field with cursor
- (2) Character bar
- ▶ Proceed as described under "Entering characters using the character bar" in the "Entering characters in navigation mode (entering a city)" section (⊳ page 153).
- ▶ Then, select ok and press to confirm. COMAND stores the destination under the name entered.

Assigning a destination to an address book entry

An address with complete address data that is suitable for navigation can be assigned to a pre-existing address book entry. You can then later start route guidance to this address straight from the address book (⊳ page 208).

- ► Select Assign Address Book Entry and press (5) to confirm.
- ► Select a category, e.g. Home, and press 🔊 to confirm.

You will see the address book either with the character bar or as a selection list.

▶ To select an address book entry: proceed as described in the "Searching for

an address book entry" section (⊳ page 205).

COMAND stores the data if the address book entry selected does not yet contain navigable address data.

If the selected address book entry already contains navigable address data, a prompt



will appear asking whether you wish to overwrite the existing data.

► Select Yes or No and press ⑤ to confirm.

If you select Yes, COMAND stores the data.

Deleting a destination or the home address from the destination memory

- ► To activate navigation mode: press the TEL | function button once or twice.
- ► To show the menu: press 🔊 the COMAND controller.
- ➤ Select Destination in the navigation system menu bar by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- ► Select From Memory and press 🖲 to confirm.
 - You will see the destination memory list either with the character bar (option 1) or as a selection list (option 2).
- ▶ Option 1: destination memory list with character bar: proceed as described in the "Entering characters using the character bar" section (▷ page 129).
- ➤ Option 2: destination memory list as selection list: select a destination by turning 【◎】 the COMAND controller and press ⑤ to confirm.
 - You see the address data of the selected entry.
- ► Select Delete and press ⑤ to confirm.

 A prompt appears asking whether you wish to delete the destination.
- ► Select Yes or No and press ⑤ to confirm. If you select Yes, COMAND deletes the destination. You will see a message to this effect.

If you select No, the process is aborted.

i If the navigable address data for the destination being deleted is also assigned to an address book entry, COMAND will also delete this data from there. If the

corresponding address book entry does not contain any further data, such as telephone numbers, COMAND deletes the entire address book entry.

Previous destinations

Introduction

COMAND automatically stores the previous destinations for which the route calculation has been started. If the memory is full, COMAND deletes the oldest destination. You can also save a destination from the list of previous destinations in the destination memory. It will be stored there permanently.

Storing a destination permanently in the destination memory

▶ Proceed as described in the "From the list of previous destinations" section (> page 179).

Storing the vehicle position in the list of previous destinations

- ► To activate navigation mode: press the TEL | function button once or twice.
- ► To show the menu: press 🔊 the COMAND controller.
- ► Select Position in the navigation system menu bar by turning {◎} the COMAND controller and press (*) to confirm.
- Select Store Vehicle Position and press to confirm.
 COMAND stores the current vehicle position as a destination in the list of previous destinations.



Storing the crosshair position in the list of previous destinations

Route guidance not active

A crosshair appears on the map if you have moved the map manually. You can store the crosshair position as a destination in the list of previous destinations.

- ► To show the menu: press 🔊 the COMAND controller.
- ► Select Position in the navigation system menu bar by turning (○) the COMAND controller and press (a) to confirm.
- ► Select Save Crosshair Position and press ⑤ to confirm.

Route guidance is active

- Select Destination in the navigation system menu bar by turning 【○】 the COMAND controller and press ⑤ to confirm.
- ► Select Save Destination and press ⑤ to confirm.

Deleting one of the previous destinations

- ► To activate navigation mode: press the TEL function button once or twice.
- ► To show the menu: press 🔊 the COMAND controller.
- Select Destination in the navigation system menu bar by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- ► Select From Last Destinations and press ⑤ to confirm.

 The list of last destinations appears.
- Select the desired destination and press
 to confirm.
 The destination address appears.

- ► Select Delete and press ⑤ to confirm.

 A prompt appears asking whether the entry should be deleted.
- ► Select Yes or No and press ⑤ to confirm. If you select Yes, the entry is deleted. If you select No, the process is aborted.

Map operation and settings

Note

Company logos displayed on the map are trademarks of the respective companies and used solely for the purpose of indicating the location of these companies. The use of such logos on the map does not indicate approval of, support of or advertising by these companies for the navigation system itself.

Setting the map scale

- ► To hide the menu: slide ○ the COMAND controller and, when the Full screen menu item is shown, press .
- ► To call up the scale bar: as soon as you turn () the COMAND controller, scale bar (3) appears.
- ► Turn 【◎】 until the desired scale is set.



- (1) Set map scale as a number with unit
- ② Currently set map scale as indicated by the needle on the scale bar
- ③ Scale bar


Unit of measurement ① in the COMAND display depends on the selection made for the instrument cluster.



Moving the map

Showing the crosshair

- ➤ To hide the menu: slide ↑ the COMAND controller and, when the Full screen menu item is shown, press .



P82.86-9977-31

Map with crosshair

- (1) Current vehicle position
- (2) Crosshair
- (3) Details of the crosshair position
- (4) Map scale selected

Display ③ may be the name of a street, for example, provided the digital map contains the necessary data. Or it may show the geocoordinate position of the crosshair if the Geo-coordinates display is switched on (> page 186).

Hiding the crosshair and centering the map on the vehicle position or destination

► Press the <u></u> back button.

The crosshair disappears and the map is set to the vehicle position.

or

Set the map to the vehicle position; see the explanation below.

Setting the map to the vehicle position, intermediate stop or destination position

Centering the map on the vehicle position

- ► To show the menu: press 🔊 the COMAND controller.
- ► Select Position in the navigation system menu bar by sliding • and turning 【○】 the COMAND controller and press ⑤ to confirm.
- Select Vehicle Position Map and press
 to confirm or, if the crosshair is shown, press the back button.
 This hides the crosshair.

Centering on an intermediate stop

This function requires that a route to an intermediate stop has been calculated.

- ► To show the menu: press ⑤ the COMAND controller.
- ► Select Position in the navigation system menu bar by sliding • and turning • the COMAND controller and press to confirm.
- ► Select Stopover Map and press 🖲 to confirm.

The crosshair is centered on the destination.

Centering on the destination

This function requires that a route to a destination has been calculated.

- ➤ To show the menu: press ⑤ the COMAND controller.
- Select Position in the navigation system menu bar by sliding ○ ↓ and turning 【○】 the COMAND controller and press ⑤ to confirm.
- ► Select Destination Map and press ⑤ to confirm.

The crosshair is centered on the destination.



Map display

Setting the map orientation



P82.86-9978-31

Map orientation

① Current map orientation

The following display modes are possible:

- (1) North orientation (the map view is displayed so that north is always up).
- Orientation in direction of travel (the map is displayed so that the direction of travel is always up; the orange point of the icon points north).
- Bird's-eye view (the map is displayed so that the direction of travel is always up; the map projection reproduces the curvature of the earth and the orange point of the icon points north).
- 3D map (the map is displayed in the direction of travel with elevation and terrain modeling. The orange point of the icon points north).




P82.86-9979-31

Example display: Bird's-eye view

- ① Current crosshair position
- ② Current map orientation
- ► To show the menu: press 🔊 the COMAND controller.

- ➤ Select Navi in the main function bar by sliding ♠ and turning ♣ ♪ the COMAND controller and press ७ to confirm.
- ► Select Map Orientation and press ⑤ to confirm.
 - A dot indicates the current setting.



P82.87-5568-31

- ► Select North Up, Heading Up, Bird'seye View or 3-D Map by turning (○) the COMAND controller and press (○) to confirm
- ► To exit the menu: slide ← → the COMAND controller.

The map orientation changes accordingly.

Setting the point of interest icons in the map

You can set the points of interest you wish to have displayed as symbols on the map. Points of interest are, for example, gas stations, hotels, cinemas and restaurants.

The following settings are possible:

- Standard Symbols
 Symbol display determined by the factory settings.
- Personal Symbols
 You can determine the symbols yourself.
- No Symbols
 The map does not show any symbols.
- ► To show the menu: press ⑤ the COMAND controller.



- Select Navi in the main function bar by sliding t⊙ and turning t⊙ the COMAND controller and press to confirm.
- ► Select POI Symbols on Map and press to confirm.
- ► Select Standard Symbols, Personal Symbols or No Symbols.

 If you select Personal Symbols, the list of points of interest appears.
- ► To switch the icon display on/off: select a point of interest by turning 【○】 the COMAND controller and press ⑤ to confirm.

Depending on the previous state of the symbols, they will either be shown ✓ or hidden □. You can switch on the symbol displays for more than one point of interest.

- 1 The list shows all symbols that are contained on the digital map across all countries. However, not all points of interest are available in all countries. As a result, certain point of interest symbols may not be displayed on the map, even if the symbol display is switched on.
- ► To exit the menu: press the 🛨 back button.

Map information in the display

Showing text information

During route guidance, you can have map information displayed at the bottom edge of the display.

- ► To show the menu: press ⑤ the COMAND controller.
- ► Select Navi in the main function bar by sliding ♠ and turning ♣ ♪ the COMAND controller and press ⑤ to confirm.

 The main area is active.
- ► Select Navi again and press ⑤ to confirm.

 The navigation menu opens.

- ► Select Text Information on Map and press ⑤ to confirm.
 - A dot indicates the current setting.
- ➤ Select Arrival Time/Distance, Current Street, Geo-Coordinates or None and press ⑤ to confirm.
- ➤ To exit the menu: slide ← → the COMAND controller.

Arrival time/distance to the destination



Arrival time/distance display switched on

- (1) Icon for destination
- (2) Distance to the destination
- (3) Icon for estimated time of arrival
- (4) Estimated time of arrival

You can only see this display during route guidance. While scrolling the map (▷ page 183), you will see additional data, e.g. road names, depending on the crosshair position, if the digital map supports this data.

Road display



P82.86-9987-31

Road display active

 Road names or numbers, e.g. for highways



Geo-coordinate display



P82.86-9988-31

Geo-coordinate display active

- ① Current height above average sea level, rounded
- ② Current vehicle position: latitude coordinates
- ③ Current vehicle position: longitude coordinates
- Wumber of GPS satellites currently being used

There must be sufficient GPS reception for all displays to be shown. If this is not the case, the display will be grayed out. Height display ① may vary from the actual value, because the navigation system uses the GPS signals for the calculation.

While scrolling the map (> page 183), you will see the geo-coordinates of the crosshair position. Height display ① and number of satellites used ④ are not displayed.

"None" menu option



P82.87-3775-31

Display switched off

- (1) Current map orientation
- i During the "Move map" function you can see additional information depending on the position of the crosshair, such as a road name, if the digital map supports this data.

Switching the topographical map on/ off

The topographical map uses different colors to depict elevation. The color key generally reflects the topography's dominant vegetation or the ground's perceived color when seen from the air, for example:

- · green for lowland
- · yellow or brown for hills
- gray or white for mountains
- ► To show the menu: press 🔊 the COMAND controller.
- ► Select Navi in the main function bar by sliding t and turning (○) the COMAND controller and press (to confirm.
- ► Select Topographical Map and confirm with ⑤.

Depending on the previous state, switch the option on \checkmark or off \square .

Switching the city model on/off

When the city model is switched on, the map shows buildings as 3D models.

1 The city model is only shown in the "3D map" map orientation.

It is available for map scales 50 m and 100 m.

The data required for displaying buildings is not available for all cities.

- ➤ To show the menu: press ⑤ the COMAND controller.
- ► Select Navi in the main function bar by sliding ○ and turning ○ the COMAND controller and press to confirm.
- ► Select City (3D) and press ⑤ to confirm. Depending on the previous state, switch the option on ✓ or off □.





P82.87-3217-31

- 1 Hills
- ② Buildings
- ③ Important buildings

Showing the map data version

- ► To show the menu: press 🔊 the COMAND controller.
- ► Select Navi in the main function bar by sliding ↑ and turning 【 】 the COMAND controller and press ⑤ to confirm.
- ► Select Map Version and press 🔊 to confirm.

The map data version number is shown. Information about new versions of the digital map can be obtained from an authorized Mercedes-Benz Center.

Traffic information on the map

If you subscribe to the SIRIUS XM Satellite Radio Traffic Message Service, traffic information can be displayed on the map. You can select three categories for the display.

- ► To switch the displays on/off: press the COMAND controller to show the menu.
- ► Select Navi in the main function bar by sliding ○ and turning ○ the COMAND controller and press to confirm.
- ► SelectTraffic Information On Map and press ⑤ to confirm.
- ▶ Select a category and press ⑤ to confirm. Depending on the previous state, switch the option on or off □.

Mode
Map Orientation
POI Symbols On Map
Traffic Information On Map

Text Information On Map

Topographic Map
Highway Information
Read Traffic Messages Aut

P82.87-3771-31

• Traffic incidents

Road sections are illustrated with a yellow line and arrows.

Warning messages or traffic incidents are represented on the map by appropriate symbols and/or yellow/red arrows. Explanation of symbols (> page 174).

• Speed & Flow

Road sections are represented by yellow or red car icons.

Green arrows: free-flowing traffic

Yellow car icons: congested traffic, average speed 25 - 45 mph

Red car icons: traffic jam, average speed 5 – 20 mph

Free Flow

Road sections are illustrated with a green line and arrows.

Additional settings

Freeway information

When driving on highways, you can have the nearest gas stations, rest areas, etc., as well as your current distance from them, shown on the right-hand side of the display.

- ► To activate navigation mode: press the TEL | NAVI | function button once or twice.
- ► To show the menu: press 🐿 the COMAND controller.



- ► Select Navi in the main function bar by sliding ○ and turning ○ the COMAND controller and press to confirm.
- ► Select Highway Information and press ⑤ to confirm.
 - Depending on the previous state, switch the option on $\mathbf{\nabla}$ or off \square .

SIRIUS XM service

Displaying SIRIUS XM service information

You can display the SIRIUS XM service information.

- ► To show the menu: press 🔊 the COMAND controller.
- ► Select Navi in the main function bar by sliding ↑ and turning 【 】 the COMAND controller and press ⑤ to confirm.
- ► Select SIRIUS Service and press ⑤ to confirm.

Registering for the SIRIUS XM traffic report service

- ► Call the traffic report provider's phone number shown on the screen.
- 1 You can also have the satellite service activated online. To do so, visit the SIRIUS XM Radio website at

http://www.sirius.com (USA) or http://www.siriuscanada.com (Canada).

Once the connection has been established:

Follow the instructions of the operator. The activation process may take up to ten minutes.

If registration is not included when purchasing the system, your credit card details will be required to activate your account.

Compass function

You can display the current compass direction heading in which the front of the vehicle is facing.



P82.87-2960-31

- (1) Current compass heading
- ② geo-coordinates

In the compass view, you can see the current direction of travel, the current height above sea level and the coordinates of the vehicle position, for example.

- ► To activate navigation mode: press the TEL | function button once or twice.
- ► To show the menu: press ⑤ the COMAND controller.
- Select Position in the navigation system menu bar by sliding ○ • and turning 【○】 the COMAND controller and press ⑤ to confirm.
- ► Select Compass and press 🖲 to confirm.
- ► To exit the display: confirm Back by pressing ⑤ or press the 🖆 button.

Installing new map software

The digital maps generated by the map software become outdated in the same way as conventional road maps. Optimum route guidance can only be provided by the navigation system in conjunction with the most up-to-date map software. Information about new map software versions can be obtained from an authorized Mercedes-Benz Center.



You can install new map software yourself which, depending on the scope, may consist of one or more DVDs.

The installation process can take between 10 and 120 minutes, depending on the scope of the map software. If the radio is switched on before you start the installation process. you can still adjust the volume. You can also use COMAND to operate automatic climate control and to cancel the process. Other functions are not operational. If possible, carry out the installation when the vehicle is stationary. The DVD read speed is higher when the vehicle is stationary than when it is in motion, so less time is required. If the starter battery is not sufficiently charged, COMAND may end the process automatically in order to protect the battery. Therefore, let the engine idle during the installation process.

↑ WARNING

Never leave the engine running in enclosed spaces. The exhaust gases contain toxic carbon monoxide. Breathing in exhaust fumes is a health hazard and can lead to unconsciousness or death.

Displaying information on the map version currently in use

- ▶ To activate navigation mode: press the function button once or twice.
- ▶ To show the menu: press (*) the COMAND controller.
- ► Select Navi in the main function bar by sliding ⊙

 and turning

 the COMAND controller and press (b) to confirm.
- ► Select Map Version and press ⑤ to confirm.

Notes on handling DVDs

- Only hold DVDs by the edge.
- · Handle DVDs carefully to prevent reading
- · Avoid getting scratches, fingerprints and dust on DVDs.

- · Use a commercially-available cleaning cloth to clean discs. When cleaning CDs. you should wipe in straight lines from the center outwards rather than in a circular motion.
- Place DVDs back in their cases after use.
- Protect DVDs from heat and direct sunlight.

Map software copy protection

Map software for COMAND is subject to a charge. The map software has just one activation code which is usable in one vehicle only, and is not transferable. You can obtain the six-digit activation code from your authorized Mercedes-Benz Center. If you have lost the activation code, or if COMAND does not accept the activation code that you have received, contact your authorized Mercedes-Benz Center.

Your vehicle is supplied with map software at the factory. Depending on the country, map software for your region is either pre-installed (Europe/USA) or the map software is supplied as a DVD (all other countries). You do not require an activation code for the map software that is provided with your vehicle.

If the map software on your vehicle has been installed at the factory and you wish to reinstall it, this also does not necessitate entry of the activation code.

Installation process

▶ Load the map software DVD in the DVD drive (⊳ page 220). COMAND checks the DVD and shows a corresponding message in the display.

Map software is not compatible with the navigation system

You will see a message that the map software cannot be installed.

- ▶ To confirm the message: press 🔊. COMAND eiects the DVD.
- Take the DVD out of the slot.
- ▶ Insert a DVD which is compatible with the vehicle's navigation system.



Map software is not compatible with the current system software

You will see a message that the system software and the map software are not compatible.

- ► To confirm the message: press . COMAND ejects the DVD.
- ▶ Take the DVD out of the slot.
- ► Have the system software updated at an authorized Mercedes-Benz Center.

The map software cannot be installed until the system software has been updated.

Map software compatible with the navigation system and the current system software

COMAND checks whether the map data on the DVD is already installed.

Map data is already installed

You will see a message that the map data is already installed and a prompt will appear asking you whether you wish to continue with the map software installation.

- Select Yes or No.
 If you select Yes, the existing map data is overwritten.
 - If you select No, COMAND automatically ejects the DVD and the installation of the map software is canceled.
- ▶ Take the DVD out of the slot.

Map data is not installed yet

In the display, you will see a comparison of the version statuses of the map software DVD and the map software installed in COMAND. A prompt then appears asking whether the map software installation should be carried out.

- ► Select Yes or No.

 If you select Yes, the map data is installed.

 If you select No, COMAND automatically ejects the DVD and the installation of the map software is canceled.
- ▶ Take the DVD out of the slot.

If an activation code is required for the map software, a prompt appears in the display requesting the code to be entered.



P82.87-5638-31

► Enter the activation code and confirm the entry with **ok**.

The map software is installed.

If you enter an incorrect activation code, the prompt to enter the activation code appears again. If the activation code is entered incorrectly three times, the prompt asking you to enter the activation code appears after a time delay. The time delay increases every time the activation code is entered incorrectly, from five minutes up to a maximum of five hours.

Installing map data

Just before the copying process starts, COMAND restarts the system.

While the installation is running, you will see a message to this effect and a progress bar.

- ► To cancel the installation process: eject the DVD.
- ▶ Take the DVD out of the slot.
- 1 If you interrupt the installation process, the navigation system will not be operational. You can continue an interrupted installation process at a later date.
- ► Installation process with multi-DVD map data: once the content of the first DVD has been installed, a message appears



prompting you to insert the second DVD. Follow the instructions on the display.

► To allow the installation to run to the end without Canceling: take no further action.

When the installation process is successfully completed, you will see a message to this effect.

- ► To confirm the message: press . COMAND ejects the DVD.
- ➤ Take the DVD out of the slot. The installation is complete.

When the installation process is not successfully completed, you will see a message to this effect.

- ► To confirm the message: press . COMAND ejects the DVD.
- ► Take the DVD out of the slot.



Problems with	h the	navigation	system
---------------	-------	------------	--------

Problem	Possible causes/consequences and ▶ Solutions
COMAND is unable to continue route guidance after the journey has been interrupted.	Route guidance is canceled if you interrupt the journey for more than two hours. "Interrupting the journey" refers to stopping the vehicle and switching off COMAND. "Continuing route guidance" refers to switching COMAND back on and driving on. ▶ Continue route guidance (▷ page 169). COMAND determines the vehicle's position. Depending on the driving situation, this may take some time. Route guidance may be restricted during the determination of the vehicle's location. When positioning is complete, route guidance is resumed with navigation announcements and route guidance displays.
COMAND is unable to determine the vehicle's position.	COMAND has to redetermine the position of the vehicle if the vehicle has been transported (e.g. by ferry, by motorail or after towing). Start the vehicle and pull away. COMAND determines the vehicle's position. Depending on the driving situation, this may take some time. Route guidance may be restricted during the determination of the vehicle's location. When positioning is complete, route guidance is resumed with navigation announcements and route guidance displays.
The Navigation function unavailable message appears.	COMAND has an integrated hard drive on which the digital map is stored. To protect the hard drive from damage, COMAND switches it off at very high temperatures. The navigation system will then be temporarily unavailable. Let the vehicle and COMAND cool down. To hide the message: switch COMAND off and then on again. If an area of the hard disk has a malfunction, COMAND can no longer access the map data in this area, for example when calculating a route. To hide the message: switch COMAND off and then on again. The navigation system will be operational again until it has to access the faulty area of the hard drive once more. The message will then reappear. Consult an authorized Mercedes-Benz Center.



Problem	Possible causes/consequences and ▶ Solutions
You see a message informing you that the DVD containing the digital map is incompatible with the system software.	 The DVD containing the digital map cannot be used for the update. ▶ To confirm the message: press ⑤ the COMAND controller. ▶ Eject the DVD. ▶ Have the system software updated at an authorized Mercedes-Benz Center.
The installation of the map software has failed.	The DVD is dirty or scratched. ▶ Clean the DVD. ▶ Restart installation.
	There is overheating due to excessive temperatures in the vehicle interior. ► Wait until the vehicle interior has cooled down. ► Restart installation.
	COMAND's integral hard drive is faulty. Consult an authorized Mercedes-Benz Center.

Telephone

General notes

Introduction

COMAND, in conjunction with a Bluetooth®capable mobile phone, enables you to make calls via the Bluetooth® interface.

Using the Bluetooth® interface and a suitable mobile phone, you can use the hands-free system, import contacts from the mobile phone and receive vCards.

More detailed information on suitable mobile phones and on connecting Bluetooth®capable mobile phones to COMAND can be found on the Internet at

http://www.mbusa-mobile.com. Or call the Mercedes-Benz Customer Assistance Center on

1-800-FOR-MERCedes(1-800-367-6372) for the USA or on 1-800-387-0100 for Canada.

Safety notes

↑ WARNING

A driver's attention to the road must always be his/her primary focus when driving. For your safety and the safety of others, we recommend that you pull over to a safe location and stop before placing or taking a telephone call. If you choose to use the mobile phone while driving, please use the handsfree device and only use the mobile phone when weather, road, and traffic conditions permit. Some jurisdictions prohibit the driver from using a cellular mobile phone while driving a vehicle.

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle is covering a distance of 44 feet (approximately 14 m) every second.



Call disconnection while the vehicle is in motion

A call may be disconnected if:

- there is insufficient network coverage in certain areas.
- you move from one transmitter/receiver area (cell) into another and no channels are
- you use a SIM card which is not compatible with the network available.
- you are using a mobile phone with "Twincard" and the mobile phone with the second SIM card is already logged into the network.

Operating options

You can operate the telephone by:

- using the COMAND controller: turn 🕻 🔘 🕽 . slide ← ∅ → or 1 ∅ ↓.
 - press 🖲.
- the or button on the telephone keypad on the center console
- the or button on the multifunction steering wheel
- using the Voice Control System (see the separate Voice Control System operating instructions)

Unless otherwise indicated, the descriptions and illustrations in this section refer to COMAND and the telephone keypad. This also means that to carry out the functions described here, you must always be in the Telephone menu. The fastest way to access the Telephone menu is to press the TEL NAVI function button.

Function restrictions

You will not be able to use the telephone, will no longer be able to use the telephone, or you may have to wait before using it, in the following situations:

- when the mobile phone is switched off
- when the "Bluetooth®" function is switched off in COMAND
- when the "Bluetooth®" function is switched off on the mobile phone
- if the mobile phone is not logged into a mobile phone network
- The telephone automatically tries to log on to a network. If no network is available, vou will not be able to make a "911" emergency call. If you attempt to make an outgoing call, the NO SERVICE message will appear for a short while.
- if you remove the SmartKey from the ignition lock during an active conversation in hands-free mode, the conversation may be continued for up to 30 minutes. After that time, it will be interrupted.

You can prevent this interruption by switching to "private call" ("private mode") on the mobile phone before deactivating COMAND (see mobile phone operating instructions). If you wish to switch off COMAND during an active conversation in hands-free mode, the following message will appear: You cannot shut off COMAND until you have finished your telephone call

911 emergency call



↑ WARNING

The 911 emergency call system is a public service. Using it without due cause is a criminal offense.

The following requirements must be fulfilled for a 911 emergency call:

- the mobile phone must be switched on.
- · a network must be available.



- a valid and operational SIM card must be inserted in the mobile phone.
- the mobile phone is connected to COMAND via Bluetooth®.

If you cannot make an emergency call, you must arrange rescue measures yourself.

- ► Enter numbers using the number keypad (> page 200).
- ► Press the button.
 The telephone makes the connection.
- ► Wait for the emergency call center to respond and then describe the emergency.
- i) If no SIM card has been inserted in a GSM phone or if there is no service available for a CDMA phone, the NO SERVICE message appears in COMAND. In this case, an emergency call can only be transmitted via the mobile phone itself and not via COMAND.

Telephony via the Bluetooth® interface

Conditions

On the mobile phone

For telephony via COMAND's Bluetooth[®] interface, a Bluetooth[®]-capable mobile phone is required.

1 Not all mobile phones available on the market are equally suitable. More detailed information on suitable mobile phones and on connecting Bluetooth®-capable mobile phones with COMAND can be found on the Internet at

http://www.mbusa-mobile.com. Or call the Mercedes-Benz Customer Assistance Center on

1-800-FOR-MERCedes(1-800-367-6372) (for the USA) or Customer Relations on 1-800-387-0100 (for Canada).

The battery of the mobile phone should always be kept sufficiently charged in order to prevent malfunctions.

In preparation for telephoning via the Bluetooth® interface, you should check the following items on your mobile phone (see the mobile phone operating instructions):

- ► Hands-Free Profile
 The mobile phone must support HandsFree Profile 1.0 or above.
- ① Certain displays and functions (e.g. signal strength display, conference connection) are available, depending on the supported version of the Hands-Free Profile.
- ▶ Bluetooth® visibility
 On certain mobile phones, the device itself must be made "visible" for other devices, as well as activating the Bluetooth® function (see the mobile phone operating instructions).
- ▶ Bluetooth® device name
 Every Bluetooth® device has its own
 Bluetooth® device name. This device name
 is freely definable, but can be identical for
 all devices from the same manufacturer. It
 is therefore recommended that you change
 this name so that you can easily recognize
 your mobile phone (see the mobile phone
 operating instructions).
- ► Switch on the mobile phone and enter the PIN when prompted to do so (see the mobile phone operating instructions).
- ► Activate Bluetooth[®] functions and, where necessary, Bluetooth[®] visibility on the mobile phone (see the mobile phone operating instructions).

In COMAND

► Activate the Bluetooth® function in COMAND (▷ page 147).

Connecting a mobile phone

General information

Before using your mobile phone with COMAND for the first time, you will need to connect it.



When you authorize a new mobile phone, it is connected automatically.

Connecting comprises:

- searching for a Bluetooth[®]-capable mobile phone
- subsequently authorizing it You can connect up to 15 mobile phones.

Searching for a mobile phone

- ► To call up the telephone menu: press the TEL function button once or twice.
- ► Select Data/Connections in the telephone basic menu by sliding • and turning 【○ 】 the COMAND controller and press ⑤ to confirm.
- ► Select Bluetooth Telephones and press ⑤ to confirm.
- Select Update and press to confirm. COMAND searches for Bluetooth® telephones within range and adds them to the Bluetooth® telephone list.

The duration of the search depends on the number of Bluetooth[®] telephones within range and their characteristics.



P82.87-3135-31

Example of display: Bluetooth® telephones list

- ① Currently connected and authorized mobile phone
- ② Mobile phone not within range but previously authorized (symbol appears in gray)
- Newly detected mobile phone in range, not yet authorized


The Bluetooth® telephones list shows all mobile phones within range and all previously authorized mobile phones, whether or not they are in range.

1 If the Bluetooth® telephones list is already full, you will be requested to de-authorize a mobile phone (▷ page 198). If COMAND does not find your mobile phone, external authorization (▷ page 197) may be necessary.

Authorizing (registering) a mobile phone

- ➤ Select Options by sliding ⊙→ the COMAND controller and press ⑤ to confirm.
- ► Select Authorize and press ⑤ to confirm. or
- ▶ Press ⑤ to confirm the selected mobile phone.

The input menu for the passcode appears.



The passcode is any one to sixteen-digit number combination which you can choose yourself. You must enter the same number combination in COMAND and in the Bluetooth®-capable mobile phone (see the operating instructions of the mobile phone).

 Some mobile phones require the input of a four-digit passcode or longer number combinations.



If you want to reauthorize a mobile phone following de-authorization, you can select a different passcode.

- ► To enter a passcode in COMAND: press the number keys in sequence.
 - ok is available for selection after the first number has been entered.

or

- Select the digits one by one by turning
 ↓ the COMAND controller and press
 to confirm.
- ► To confirm an entry in COMAND: select

 ok using the COMAND controller and press ⑤ to confirm.

or

- ► Select **SEND** on the telephone keypad.
- ► Now enter the same passcode in the mobile phone.

To make entries on the mobile phone: if the Bluetooth® connection is successful, you will be requested to enter the passcode (see mobile phone operating instructions).

- ► Enter the same passcode on the mobile phone that you entered in COMAND.
- 1 After entering the passcode, you may also need to enter a confirmation in your mobile phone to connect calls. Please check your mobile phone display.

If the Error during authorization process message appears on the COMAND display, you may have exceeded the allowed time. Repeat the procedure.

The mobile phone is connected to COMAND (authorized). You can now make phone calls using the COMAND hands-free system.

External authorization

If COMAND does not detect your mobile phone, this may be due to particular security settings on your mobile phone. In this case, you can test if your mobile phone can find COMAND. The Bluetooth® device name of COMAND is MB Bluetooth.

Observe the following: some mobile phones require that you reconnect to COMAND after you have entered the passcode (see the mobile phone operating instructions). The mobile phone cannot otherwise be authorized.

- ► Press the TEL function button on the COMAND controller once or twice.
- ► Select Data/Connections in the telephone basic menu by sliding ① and turning the COMAND controller and press to confirm.
- ► Select Bluetooth Telephones and press ⑤ to confirm.
- ► Select Update.
- Select Options by sliding ⊙→ and press ⑤ to confirm.
- ► Select External Authorization and press ⑤ to confirm.
- Start the Bluetooth® search on the mobile phone (see the mobile phone operating instructions).
- ➤ Select COMAND (MB Bluetooth) on the mobile phone.
- The order in which the passkey is entered depends on the mobile phone.
- ► Enter the passkey on the mobile phone when prompted.
- ► Confirm the Do you want to authorize XX? question in COMAND with Yes.
- ► Enter the passkey in COMAND.

Connecting another mobile phone

If you have authorized more than one mobile phone, you can switch between the individual phones.

- 1 You can only switch to another authorized phone if you are not currently making a call.
- ► Select the mobile phone in the Bluetooth® telephones list by turning 【◎】 the



COMAND controller and press **(*)** to confirm.

The selected mobile phone is searched for and connected if it is within Bluetooth® range and if Bluetooth® is activated.

Only one mobile phone can be connected at any one time. The currently connected mobile phone is indicated by the • dot in the Bluetooth® telephones list (> page 195).

Displaying details

- ► Select Data/Connections in the telephone basic menu by sliding ① and turning � ↑ the COMAND controller and press ⑤ to confirm.
- ► Select Bluetooth Telephones and press ⑤ to confirm.
- ► Select the desired mobile phone in the Bluetooth[®] telephones list.
- ► Select Options by sliding ⊙→ and press ⑤ to confirm.
- ► Select Details and press ⑤ to confirm.

 The following information concerning the selected mobile phone is shown:
 - Bluetooth® name
 - Bluetooth[®] address
 - equipment class, e.g. telephone, computer
 - availability
 - · authorization status
- ► To close the detailed view: turn 🕻 🔾 or slide 🗢 the COMAND controller.

De-registering (de-authorizing) a mobile phone

Mercedes-Benz USA, LLC recommends deauthorizating in both COMAND and the mobile phone. Subsequent authorization may otherwise fail.

- ► To call up the telephone menu: press the TEL | function button once or twice.
- ► Select Data/Connections in the telephone basic menu by sliding • and turning • the COMAND controller and press to confirm.
- ► Select Bluetooth Telephones and press to confirm.
- ► Select the desired mobile phone in the Bluetooth® telephones list.
- ► Select Options by sliding ○→ and press ⑤ to confirm.
- ► Select De-authorize and press ⑤ to confirm.
 - A prompt appears asking whether you really wish to de-authorize this device.
- ► Select Yes or No.

 If you select Yes, the device will be deleted from the Bluetooth® telephones list.


 If you select No. the process will be aborted.
- Before re-authorizing the mobile phone, you should also delete the device name MB Bluetooth from your mobile phone's Bluetooth® list.

Basic telephone menu (Bluetooth® interface)

► To call up the telephone menu: press the TEL | function button once or twice.

If the mobile phone is ready for use, the following display appears:





P82.87-3064-31

Example display: telephone basic menu (Bluetooth® interface)

- 1 Network provider icon
- ② Signal strength of mobile phone network
- (3) Receiver icon or
- (4) To display the COMAND phone book
- To display call lists
- Character bar with characters for phone number entry
- Bluetooth® name of the currently connected mobile phone
- 1 Displays 1 and 2 are shown, depending on the mobile phone connected.

Bars ② display the current signal strength of the mobile phone network. If all bars are filled, you have optimum reception. If all bars are empty, there is very poor reception or none at all.

Reception and transmission volume


Once the mobile phone has been authorized, you can optimize the transmission and reception volume settings. Find information on the optimal setting for your mobile phone on the Internet at

http://www.mbusa-mobile.com. Or call the Mercedes-Benz Customer Assistance Center on

1-800-FOR-MERCedes(1-800-367-6372) (for

the USA) or Customer Relations on 1-800-387-0100 (for Canada).

- 1 Incorrect settings may have a significant impact on the quality of calls.
- ► Press the TEL function button.
- ► Select Data/Connections in the telephone basic menu by sliding ① and turning 【 ① the COMAND controller and press ⑤ to confirm.
- Select Bluetooth Telephones and press to confirm.
- ► Select an authorized mobile phone from the list by turning 【◎】.
- Select Options by sliding ⊙→ and press ⑤ to confirm.
- ► Select Reception Volume or Transmission Volume and press ⑤ to confirm.



D02 07 2120 2

► To set the volume on scale: select by sliding t ○ I the COMAND controller and press ⑤ to confirm.

Telephone operation

Incoming call

Rejecting or accepting a call

When there is an incoming call, you see a corresponding window in the display.





P82.87-2844-31

► To reject: select Reject by turning 【○】 the COMAND controller and press ⑤ to confirm.

or

- Press the button on the telephone keypad or on the multifunction steering wheel.
- ► To accept: confirm Accept by pressing .

or

► Press the button on the telephone keypad.

or

► Press the or w{ button on the multifunction steering wheel.

Once you have accepted the call, you can use hands-free mode. The call volume can be adjusted (> page 134). For more information, see the "Functions available during a call" section (> page 201).

The display shows the phone number or the name and phone number (if the entry is stored in the address book) or shows the Unknown (phone number withheld) message.

i) You can also accept a call as described above when COMAND is showing the display of a different main application. The display switches to the telephone display after a call is accepted using the COMAND controller or the telephone keypad. After the call is finished, you see the display of the previous main application again.

Making a call

Entering a telephone number using the telephone keypad

- ► Call up the telephone basic menu (> page 198).
- ► Enter all the digits of the phone number using the telephone keypad.
- ► To make a call: press the button on the telephone keypad or on the multifunction steering wheel.

Entering a telephone number using the telephone basic menu

- ► Call up the telephone basic menu (> page 198).
- ► To make a call: select SEND from the telephone basic menu and press ⑤ to confirm.

or

Press the button on the telephone keypad or on the multifunction steering wheel.

Redialing

- ► Call up the telephone basic menu (> page 198).
- ► Press the button on the telephone keypad.

or

- ► Select SEND from the telephone basic menu and press ⑤ to confirm.

 In both cases, the calls dialed list appears. The most recently dialed number is at the top.
- ➤ To select a call: select an entry by turning (○) the COMAND controller and press to confirm.



The redialing function is also available using the on-board computer (▷ page 383).

Calling voicemail

This function is only available if it is supported by the mobile phone network provider.

You can only call voicemail if the voicemail number is stored as preset 1 on the SIM card.

► Press and hold the 1 button on the telephone keypad.

or

► Use the COMAND controller to select 1 and confirm until dialing commences.

Connecting a call to an entry in a call list or in the COMAND phone book

► Open a call list and select an entry (> page 209).

or

► Call up the COMAND phone book and select an entry (> page 205).

Functions available during a call

Overview



Telephone operation with a single call

- Person you are calling
- ② Icon for active telephone connection
- 3 NEW to call other parties⁸
- To switch hands-free microphone on/off

- (5) To send DTMF tones (not possible with all mobile phones)
- (6) To end a call

Switching the hands-free microphone on/ off

This function is also available during an active phone call.

- ➤ To call up the telephone basic menu (> page 198).
- ➤ To switch off: select Mike OFF and press ⑤ to confirm.

or

- ▶ Press the ဩ button on the multifunction steering wheel.

 If the microphone is switched off, the display shows the ⊗ symbol and the The microphone is turned OFF message appears for a short period.
- ► To switch on: select Mike ON and press ⑤ to confirm.

or

▶ Press the 🐧 button on the multifunction steering wheel.

The symbol disappears. You will briefly see the The microphone is ON message.

Ending an active call

► Select in the telephone basic menu and press to confirm.

or

Press the button on the telephone keypad or on the multifunction steering wheel.

Call waiting, toggling and conference connections with several people

These functions are only available if they are supported by the mobile phone network provider. Furthermore, they are only available if the mobile phone supports HFP 1.5 or higher.

⁸ This function is only available if the telephone supports HFP1.5 and above.



You can be called by more than one person (call waiting) while you are making a telephone call. In the same way, you can call another party while already on the phone with someone.

You can either toggle between these two conversations or interconnect them to create a conference call.

You can simultaneously switch back and forth between two parties or conduct a conference call with up to five others.

Call Waiting9

If you are on the telephone and you receive another call, the call waiting display will appear. You also hear a tone.

► To reject: select Reject and press ⑤ to confirm.

or

- Press the button on the telephone keypad or on the multifunction steering wheel.
- ► To accept: select Accept and press ⑤ to confirm.

or

► Press the button on the telephone keypad or on the multifunction steering wheel.

This will put the active call on hold. You now have two calls. The accepted call is active and the first call is on hold.

If your mobile phone does not support HFP 1.5 or above, then the call which was active is canceled as soon as the second call is accepted.

Calling additional parties

You can call a second person while on the phone with someone else. This action puts the previous call on hold.

► Select NEW from the telephone basic menu and press ⑤ to confirm.

or

- ► Select **SEND** on the telephone keypad.
- ► Enter the phone number manually (> page 200) or via the phone book
 - (\triangleright page 208) or from the call lists (\triangleright page 209).

Switching between two parties (toggling)

If you have added another party to your previously active call, the telephone menu then looks like this:



Active party

- 2 Party on hold
- ► To switch to the other party: select ② by turning � う the COMAND controller and press ⑤ to confirm.

٥r

► Select **SEND** on the telephone keypad.

or

▶ Press the button on the multifunction steering wheel.

Interconnecting to create a conference

You can interconnect calls which are active and those which are on hold. This permits several parties to hear one another and speak with one another.

⁹ This function is only available if Call Waiting has been activated on the mobile phone.





- Active party
- 2 Party on hold
- ③ To interconnect parties by creating a conference connection
- ➤ To interconnect parties by creating a conference connection: select Conference③ by turning 【◎】 the COMAND controller and press ⑤ to confirm.

Sending DTMF tones

This function is not supported by all mobile phones.

Answering machines or other devices can be controlled by DTMF tones, e.g. for remote query functions.

If you would like to listen to the messages on your answering machine, for example, select the corresponding number.

Select DTMF from the telephone basic menu during a conversation.



- ① To transmit individual characters using the character bar
- ② To transmit a phone book entry as a character string
- ► To transmit individual characters: once a connection has been established to the answer phone, select the desired characters in the character bar and press to confirm.

or

- ➤ To send a phone book entry as a DTMF sequence: select Name by turning () the COMAND controller and press () to confirm.
- ► Select the desired phone book entry and press ⑤ to confirm.

The entry is sent as a DTMF character string.

- ► To switch back to the call display: select —.
- 1 You can also send DTMF tones by pressing the corresponding button on the telephone keypad or using the Voice Control System (see the separate operating instructions).

Using the phone book and address book

The COMAND phone book is an extract of those entries from the address book which contain at least one telephone number.



The address book organizes and stores entries that are entered from different sources (mobile phone, SD memory card, Bluetooth® import, COMAND phone book, navigation). You can use these entries to make telephone calls and for navigation.


Importing contacts automatically

If a mobile phone is connected to COMAND via the Bluetooth[®] interface, the contacts (phone book entries) of the mobile phone are automatically imported into COMAND's phone book.

Depending on the mobile phone, this process may take some time. Depending on the mobile phone used, only the phone book entries in the mobile phone or these entries and the phone book entries from the SIM card are imported.

The automatically imported contacts (phone book entries) can be recognized in COMAND by the symbol. They are only available in COMAND if the corresponding mobile phone is connected to COMAND via the Bluetooth® interface.

Importing contacts manually



P82.87-3085-31

The stored phone book and the vCards remain in COMAND, even if you use COMAND with another mobile phone. The entries can be viewed without a mobile phone. For this reason, delete the phone book before selling or transferring ownership of your vehicle.

Existing contact data can be imported from the memory card manually.

- ► To import data: load the memory card.
- ► Select Data/connections in the telephone basic menu by sliding • and turning • the COMAND controller and press to confirm.
- ► Select Download Contacts and press ⑤ to confirm.
- ► Select From Memory Card and press ⑤ to confirm.
- ► Select Add or Overwrite and press ⑤ to confirm.

If the data has been imported, the Import successful message is displayed.

If the COMAND phone book memory is full, this message appears in the display:
Memory full. Contacts could not be imported completely.

1 After the data has been imported, COMAND has to process it. The entries are only visible in the address/phone book when this is completed.

Receiving vCards via Bluetooth®

You can receive vCards from devices (such as a PC) which support the transmission of vCards via Bluetooth®.

This requires the device to be authorized in COMAND. PCs must be authorized via the Bluetooth[®] device list (⊳ page 147). Received vCards are imported into the address book.

Please bear the following in mind:

- Bluetooth® must be activated in COMAND and on the Bluetooth® device (> operating instructions of the device).
- the Bluetooth® device must be able to send vCards via Bluetooth® (▷ operating instructions of the device).
- the Bluetooth® device in the vehicle must be switched on.




- If you switch to another main function, e.g. navigation, while receiving vCards, the reception of vCards will be terminated.
- ► Select Data/Connections in the telephone basic menu by sliding ① and turning 【 ① the COMAND controller and press ⑤ to confirm.
- ► Select Download Contacts and press ⑤ to confirm.
- ► Select Via Bluetooth and press ⑤ to confirm.

This interrupts the Bluetooth® connection between COMAND and your active mobile phone. In turn, COMAND is ready to receive vCards from another Bluetooth® device.

► Start data transfer on the external Bluetooth device (> operating instructions of the device).

The data on the vCards is automatically transferred to the address book. The number of vCards received is displayed.



P82.87-2006-31

► To cancel reception: press 🔊.

or

Calling up contacts/details

You can call up contacts with the list or by using the character bar.



P82.87-3101-31

Phone book/address book basic display

- ① List
 - Entry with navigable data
 - Entry with voice tag; see the separate operating instructions for the Voice Control System
 - Address book entry
 - Mobile phone entry
 - SIM card entry
 - Entry imported via Bluetooth®
 - Entry imported via memory card
 - Entry with multiple phone numbers
- ② Two-line character bar
 - To change the language of the characters
 - To select the character set
 - c To delete your selection
 - $\begin{tabular}{ll} \hline {\tt ok} & {\tt To~confirm~your~selection} \end{tabular}$
 - Back

Calling up contacts from a list

- Phone book: select Name in the telephone basic menu by sliding I and turning
 I the COMAND controller and press
 to confirm.
- Address book: select Data/Connections in the telephone basic menu by sliding * and turning * * the COMAND controller and press * to confirm.
- ► Select Address Book and press 🔊 to confirm.



► To switch from the character bar to the list: slide ↑ ○ the COMAND controller until the character bar is hidden.

or

- ► Select ok .
- ► To call a contact: select by sliding t ↓ or turning (○) the COMAND controller and press ⑤ to confirm.
- 1 The phone book is also available via the on-board computer (⊳ page 383).

Calling up contacts using the character bar

- Phone book: select Name in the telephone basic menu by sliding + and turning
 the COMAND controller and press
 to confirm.
- ► Address book: select Data/Connections in the telephone basic menu by sliding ♣ and turning ♣ ↑ the COMAND controller and press ७ to confirm.
- ► Select Address Book and press ⑤ to confirm.
- ► To select a character: select by sliding

 • • • the COMAND controller and

 press to confirm. Repeat this procedure

 until COMAND automatically switches over

 to the list.

You determine the first letter of the entry you are looking for with the first character you enter. If there are similar entries, the next character which is different will be displayed and offered for selection.

1 You can also use the telephone number keypad to enter characters.

Creating new contacts/changing contacts

In certain countries, this function stops being available from a vehicle speed of more than approximately 3 mph (5 km/h). As soon as the speed falls below

- approximately 2 mph (3 km/h), the function becomes available again.
- 1 You can enter address data directly into the address book. If you store contacts in the phone book, these are also saved in the address book.
- Automatically imported contacts cannot be edited. They have to be saved first before being copied to the COMAND address book.



P82.87-3063-31

- ► Call up the contact (> page 205)¹⁰.
- Select Options by sliding ⊙→ and turning (○) the COMAND controller and press to confirm.
- ► Select New Entry or Edit and press ⑤ to confirm.

The input menu with data fields appears.



P82.87-5851-31

- ① Entry mark (cursor)
- ② Data field
- Two-line character bar
 To select the language

¹⁰ Only available with the "Change contact" function.



... To select the character set

ABC / abc To select uppercase and
lowercase letters

- **★** Back
- c To delete your selection
- ok To confirm your selection
- 4 Preset phone category
- ▶ Enter the respective data in the data fields.
- ► To enter data in the data field: select the respective characters from character bar (3).
- ► To move the cursor in the data field: select the respective characters from character bar (3).
- ➤ To change data fields: slide t ⊚ the COMAND controller until the character bar is hidden.
- ► Slide ○ the COMAND controller and press ⑤ to confirm.

or

- ▶ Press **↓** in the character bar.
- ➤ To cancel data entry: select the symbol in the character bar and press to confirm.

If one of the data fields contains data, a prompt will appear asking whether you wish to store the entry.

► To save data entry: select the ok symbol in the character bar and press to confirm.

The entry is created in the phone book and in the address book.

Deleting contacts



P82.87-3084-31

- ► To delete a group of contacts: select Data/Connections in the telephone basic menu by sliding ○ • and turning • the COMAND controller and press • to confirm.
- ► Select Delete Contacts and press ⑤ to confirm

You can select and delete the following types of contact here:

- Internal Contacts
- Imported from Memory Card
- Imported via Bluetooth
- Delete All
- Confirm the selection by pressing .
 A prompt appears asking whether the data should be deleted.
- ► Select Yes and press 🔊 to confirm.
- ► To delete an individual contact: select the entry (> page 205).
- Select Options by sliding ⊙→ the COMAND controller and press ⑤ to confirm.
- ➤ Select Delete and press ⑤ to confirm.

 A prompt appears asking whether the data should be deleted.
- ► Select Yes and press 🔊 to confirm.
- Automatically imported contacts cannot be deleted (> page 204).



Calling a number stored in an entry

Using the phone book

- Select Name in the telephone basic menu by sliding ⊙→ and turning (○) the COMAND controller and press (○) to confirm.
- ► Call up the contact (> page 205).
- ► Contact with multiple telephone numbers (with the symbol): press .

or

- ▶ Press SEND on the telephone keypad. A list of all telephone numbers is opened.
- ▶ Press 🔊.

or

- ► Press **SEND** on the telephone keypad. The number is dialed.
- ► Contact with one telephone number (without the symbol): press .

or

- ► Press **SEND** on the telephone keypad. The number is dialed.
- You can also use the phone book in the on-board computer to make a call (▷ page 383).

Using the address book

- ► Select Data/Connections in the telephone basic menu by sliding ① and turning the COMAND controller and press to confirm.
- ► Select Address Book and press ⑤ to confirm.
- ► Call contact (▷ page 205) and press ⑤ to confirm.

Starting route guidance to an entry

- This function is available as soon as you have stored a destination in the destination memory (⊳ page 179). COMAND also stores the destination in the address book with the complete navigable address data. In this case, navigation can be started without any further data input. If the contact entry contains a postal address, e.g. as a result of importing a vCard, the system can also navigate to this address. If the data is incomplete or unclear, COMAND asks the user to enter the relevant address data. After the entry has been completed and navigation has been started, COMAND replaces the existing address with the navigable address if necessary.
- Search for an address book entry using the symbol.
- ► Confirm the entry by pressing ⑤. Telephone numbers and addresses are displayed.
- Select the address data field.
- ▶ Press the COMAND controller.

or

- ➤ Select Options by sliding ○→ the COMAND controller and press ⑤ to confirm.
- ► Select Navigate and press ⑤ to confirm.
- ► Select Start and press 🐿 to confirm.

Voice tags

1 Voice tags are entered via the Voice Control System; see the separate operating instructions for the Voice Control System.

Adding or changing a voice tag

1 You can add one voice tag per address book entry.



- Search for an address book entry with or without a voice tag () symbol).
- Select Options by sliding ⊙→ and turning (○) the COMAND controller and press to confirm.
- ➤ Select Voice Name and press ⑤ to confirm.
- Select Add or Edit and press ® to confirm. Subsequent operation is voice-controlled. The Voice Control System guides you through the menus.

Deleting a voice tag

- Search for an address book entry with a voice tag.
- Select Options by sliding ⊙→ and turning
 1 the COMAND controller and press
 to confirm.
- ► Select Voice Name and press ⑤ to confirm.
- ► Select Delete and press ⑤ to confirm.

 A deletion prompt appears.

Listening to a voice tag

- Search for an address book entry with a voice tag.
- Select Options by sliding ⊙→ and turning
 1 the COMAND controller and press
 to confirm.
- ► Select Voice Name and press ⑤ to confirm.
- ► Select Listen and press ⑤ to confirm. You will hear the voice tag.

Using call lists

Introduction

COMAND displays calls received (including missed calls) and made during phone operation in lists.

1 The respective menu item can only be selected if calls have already been made or

received in COMAND or if the call lists have been imported from the telephone.


Opening the call list and selecting an entry

- ► To call up the telephone menu: press the TEL | function button.
- ► Select Call lists in the telephone basic menu by sliding • and turning 【○】 the COMAND controller and press ⑤ to confirm.

A menu appears.

- ► Select Calls received or Calls Dialed and press ⑤ to confirm.

 The corresponding list appears.
- 1 The list of calls made can also be opened by pressing the SEND button in the menu or on the telephone keypad as long as no phone numbers have been entered in the basic menu. The list of calls made can also be opened in the on-board computer.



P82.87-3110-31

Example display: list of calls made

- To close the list
- (2) Telephone number/name if known
- (3) To call up options (e.g. save)
- ► Select an entry by sliding • the COMAND controller.
- ▶ To dial a phone number: press the button.

or

▶ Press 🖲 to confirm.



Incoming calls which you could not or did not want to answer are marked with a symbol in front of the name or phone number.

Storing a phone number which has not yet been stored

Introduction

For incoming calls from a person who is not in the address book, COMAND displays the phone number in the call list. You can save this entry.

Storing as a new entry in the address book

- ▶ Open a call list and select an entry (> page 209).
- Select Options by sliding ⊙→ the COMAND controller and press to confirm.
- ► Select Save Number and press ⑤ to confirm.
- ► Select New Entry and press ⑤ to confirm.
- ► Select a category for the number, e.g. Home, and press 🖲 to confirm.
- ► Select a category for the phone, e.g. Cellular Phone Number, and press ⑤ to confirm.

Number category	Display (phone book and address book)
Not Classified	No symbol
Home	⊕
Work	#

Phone category	Display (phone book and address book)
Not Classified	No symbol
Mobile Phone	
Pager	

Phone category	Display (phone book and address book)
Car	
Landline	
Preferred	

- i) If you have not entered the phone number in a number and telephone category, the con will appear in the display.
- ► Select Next (save) and press ⑤ to confirm.

An input menu with data fields is shown. The data field for the telephone number is filled in automatically.



P82.87-3125-3

- Data fields for surname, first name and company
- ② Number category
- 3 Phone category
- 4 The data field for the telephone number is filled in automatically.
- (5) Two-line character bar
- ▶ Proceed as described under "Entering characters" in the "Entering characters in the address and phone books" section (> page 132).



Adding a phone number to an address book entry

- ➤ Open a call list and select an entry (> page 209).
- Select Options by sliding ⊙→ the COMAND controller and press ⑤ to confirm.
- ► Select Save Number and press ⑤ to confirm.
- ► Select Add and press ⑤ to confirm.

 The search menu for address book entries appears.
- ▶ Search for the desired entry (> page 205).
- ▶ Press (5) when you have finished searching.
- ► Select a category for the number, e.g. Home, and press ⑤ to confirm.
- ► Select a category for the phone, e.g. Cellular Phone Number, and press ⑤ to confirm.
- ► Select Next (save) and press ⑤ to confirm.

COMAND stores the data if there are fewer than five numbers assigned to the entry you are searching for.

You will see a message to this effect. If five numbers are stored for the entry you are searching for, a prompt will appear asking whether you wish to overwrite one of the existing numbers.

► Select Yes or No and press ⑤ to confirm. If you select Yes, a selection list with the five existing numbers appears.

If you select No, the process will be aborted.

► Select the number to be overwritten in the list by turning () the COMAND controller and press () to confirm.

COMAND overwrites the selected number with the new data.

Audio

Radio mode

General information

 Portable electronic devices in the vehicle may seriously impair radio reception.

Switching to radio mode

Option 1

Press DISC the function button. The radio display appears. You will hear the last station played on the last waveband.

Option 2

Select Audio in the main function bar by sliding ↑ ○ and turning 【○】 the COMAND controller and press ⑤ to confirm. If radio mode was the last mode selected,

it will now be active.

If another audio mode is switched on, you

If another audio mode is switched on, you can now switch to radio mode in the audio menu.

► Select Audio by sliding to the COMAND controller and pressing to confirm.


The audio menu appears.



Example display: audio menu

- (1) Current audio operating mode
- ② Main function bar
- 3 Audio menu
- ➤ Select FM/AM radio by turning (◎) the COMAND controller and press (◎) to confirm.





P82.87-5569-31


Example display, FM radio

- 1 Display window with station settings
- ② Frequency of the selected station
- (3) Name of the selected station
- 4 Display bar for frequency setting
- (5) Sound settings
- Waveband
- (7) Station information
- ® Preset functions
- Radio functions

Switching wavebands

► Select FM, AM or WB in the radio display by sliding ○ • and turning 【○】 the COMAND controller and press ⑤ to confirm.

Waveband submenu is opened.



P82.87-5571-31

- The waveband submenu (the dot shows the waveband currently set)
- ► Select a waveband and press ⑤ to confirm. You will hear the last station played on the selected waveband.

Selecting a station

Selecting a station using the station search function

➤ Turn 【◎】 or slide ←◎→ the COMAND controller while the display/selection window in the radio display is active.

Station search scans up or down and stops at the next station found.

Using the multifunction steering wheel

- ► Press or to select the Audio menu.
- ▶ Press ▲ or ▼ briefly.

Selecting stations via the station presets

- Quick setting: press a number key, e.g.
 ²/_{ABC}
 .
- ▶ Directly in the station presets: select Presets by sliding ○ • and turning (○) the COMAND controller and press ⑤ to confirm.

or

- ► Press ⑤ the COMAND controller when the display/selection window is active.

 The station preset memory appears. The
 - dot indicates under which preset the currently selected station is stored.
- ► Select a station by turning 【◎】 and pressing ⑤ to confirm or press a number key, e.g. ________.

Using the multifunction steering wheel

- ► Press or to select the Audio menu.
- ▶ Press ▲ or ▼ briefly.

Selecting stations by entering the frequency manually

- ▶ Option 1: press the * + button.
- ▶ Option 2: select Radio in the radio display by sliding ○ * and turning (○) the COMAND controller and press * to confirm.



- ► Select Enter Frequency and press ⑤ to confirm.
 - Irrespective of the option chosen, an input menu will appear.
- Enter a frequency using the number keys. COMAND tunes in to the frequency entered.

Waveband	Frequency
AM (MF)	530 – 1700 kHz
FM (VHF)	87.7 - 107.9 MHz
WB (Weather Band)	Weather report channels

- You can only enter currently permitted numbers.
- 1 If you enter a frequency in the FM or AM wavebands which is outside the frequency range, COMAND tunes in to the next lower frequency.

Storing stations

Storing stations manually


There are twenty presets available for the FM and AM wavebands.

- ▶ Quick save: press and hold a number key,
 e.g. 2
 nuntil you hear a tone.
 The station is stored.
- ► Directly in the station presets: press ⑤ the COMAND controller when the display/ selection window is active.

or

▶ Select Presets by sliding ○ ♣ and turning 【○】 the COMAND controller and press ⑤ to confirm.

In both cases, the station presets appear. The • dot indicates under which preset the currently selected station is stored.



P82.87-5572-31

Example display: station presets

 Select a preset by turning (○) the COMAND controller and press and hold
 until you hear a tone.
 The station is stored under the preset.

Storing stations automatically

This function automatically stores stations with adequate reception under the presets. The search starts at the lowest frequency. COMAND stores any stations found, beginning with preset 1. The storing process ends once the highest frequency has been reached or once ten stations have been found. Any stations stored manually under the presets will be lost. COMAND may not occupy all memory slots when storing.

➤ Option 1: press ⑤ the COMAND controller when the display/selection window is active.

The station preset memory appears.


- ► Option 2: select Presets by sliding ↓ and turning 【○】 the COMAND controller and press ⑤ to confirm.
 - The station preset memory appears.
- ▶ Irrespective of the option, select
 Autostore and press ⑤ to confirm.
 In both cases, COMAND searches for
 stations that can be received. You will see
 a message to this effect. The available
 stations are automatically stored in the
 preset positions.
- ► To cancel storing: select Cancel and press ⑤ to confirm.



Weather Band

Switching on

- Select the currently set waveband FM or AM by sliding ○ ↓ and turning 【○ 】 the COMAND controller and press ⑤ to confirm.
- ► Select WB from the menu and press ⑤ to confirm.



P82.87-5573-31

- 1 Display window with the channel setting
- ② Currently received channel
- (3) Channel list
- (4) Weather Band switched on
- Sound settings

Searching for a channel

➤ Quick select: turn () or slide ← ○ → the COMAND controller while the display/ selection window is active.
Channel search scans up or down and

Channel search scans up or down and stops at the next channel found.


Using the multifunction steering wheel

- ► Press or to select the Audio menu.
- ▶ Press 🛕 or 🔻.

Selecting a channel from the channel list

► Select Channel by sliding ○ ♣ and turning ♣ the COMAND controller and press
 to confirm.

The channel list appears.



P82.87-5574-31

Select a channel by turning 【◎】 the COMAND controller and press ⑤ to confirm.


or

Press a number key on the telephone keypad, e.g. 4, at any time.

Displaying station information

This function is only available for analog FM and digital AM/FM programs (HD Radio). Information relevant to the current station is shown below the main function bar.

Select Radio in the radio display by sliding ○ ■ and turning 【○】 the COMAND controller and press ⑤ to confirm.



P82.87-5570-31

➤ Select Show Station Info by sliding

③ I and turning 【 ③ I the COMAND

controller and press ⑤ to confirm.

Depending on the previous status, switch

Show Station Info on ✓ or off □.



Displaying program information

This function is only available for analog FM and digital AM/FM programs (HD Radio). Information relevant to the current station is shown in the display window.

► Select Info in the radio display by sliding
○ ■ and turning 【○ 】 the COMAND controller and press ⑤ to confirm. Information on the currently selected station is displayed. The contents and purpose of the information depend on the HD Radio station.

HD Radio

Important notes

The "HD Radio" section provides detailed information on the following:

- special functions available exclusively for HD Radio when compared with analog AM and FM radio
- · selecting an HD Radio station
- displaying program information
- Optional HD Radio equipment is required to make use of the HD Radio functions described here. Registration is not required.
- 1 HD Radio functions offer:
 - digital transmission on the same wavebands as analog AM/FM. The analog AM/FM stations remain in the same position when selecting a station.
 - the ability to broadcast several program streams over a single AM/FM frequency (e.g. HD1, HD2 etc.)
 - clear, interference free reception
 - on FM stations: CD quality sound; on AM stations: analog FM station sound quality
 - a wide range of data services, text-based information – name of artist, name of song etc. – on the display.

For further information on HD Radio, visit **http://www.hdradio.com**.


1 Please note that sub-programs and program information shown in the illustrations are dependent on the program broadcast by the respective radio station. The program contents may vary. The sub-programs and programs shown in the illustrations in this manual may therefore differ from the sub-programs and programs broadcast by radio stations.

Switching on HD Radio

1 As HD Radio stations are broadcast in the AM/FM wavebands, operating HD Radio is very similar to operating analog AM/FM radio. This section describes only those functions that differ from standard FM radio functions.

Operating analog FM/AM radio is described in the "Radio" section (> page 211).

You can deactivate HD Radio for the selected frequency in the radio submenu.



- ► Select Audio in the main function bar by sliding ○ and turning ○ the COMAND controller and press to confirm.
- Select FM/AM Radio by sliding ★ the COMAND controller and press * to confirm.

The audio menu appears.


▶ Select Radio by sliding to the COMAND controller and press to confirm.
HD Radio is deactivated if the check box is empty.



You hear the analog program of this frequency.

As soon as you change to another HD Radio frequency, the HD Radio is reactivated.

HD Radio display



- Display/selection window with frequency display
- (2) Preset number
- 3 Name of the selected station with HD icon and program number
- (4) Station frequency
- Sound settings
- (6) FM, AM or WB radio
- (7) Program information
- (8) Station presets
- (9) Radio functions

Switching wavebands

See "Switching wavebands" in the radio mode section (▷ page 212).

Selecting a station

You can select an HD Radio station in the same way as selecting a standard FM radio station. After setting an HD Radio frequency, you will briefly hear the analog station until the digital data has been decoded. You will then be listening to digital radio and be able to switch to a sub-program (-HD2).

See "Selecting stations" in the Radio mode section (▷ page 212).

Storing stations

See "Storing stations" in the Radio mode section (▷ page 213).

Displaying program information

- Select Audio in the main function bar by sliding ↑ ○ and turning 【○】 the COMAND controller and press ⑤ to confirm.
- ► Select Audio by sliding ○ the COMAND controller and pressing ⑤ to confirm.

 The audio menu appears.
- ► Select HD Radio by sliding ○ the COMAND controller and press ⑤ to confirm.
- Select Info in the HD Radio display by sliding ↑ ○ the COMAND controller and press ⑤ to confirm. Information on the currently selected station is displayed. The contents and purpose of the information depend on the

Satellite radio

HD Radio station.

Important notes

This section provides detailed information on the following topics:

- selecting a channel and program category
- · memory functions
- · sound settings
- 1 The satellite radio mode described below requires optionally available satellite radio equipment and registration with a satellite radio provider.
- Note that the categories and channels shown in the illustrations depend on the program content offered by the provider. The program contents may vary. The illustrations and descriptions in these operating instructions may therefore differ from the channels and categories offered by the provider.




Satellite radio mode may be temporarily unavailable or interrupted for a variety of reasons. These reasons include environmental or topographical conditions as well as other issues beyond the control of Mercedes-Benz USA, LLC. Operation may also be impaired in certain locations (e.g. tunnels, multi-storey car parks or within as well as close to buildings).

i SIRIUS XM Radio offers more than 130 digital-quality radio channels providing 100% commercial-free music, sport, news and entertainment.

SIRIUS XM Radio employs a fleet of highperformance satellites to broadcast around the clock throughout the USA and Canada. The satellite radio program is available for a monthly fee. Details are available from the SIRIUS XM Service Center and at http://www.sirius.com (USA) or http://www.siriuscanada.com (Canada).

Registering satellite radio

- ▶ Select Audio in the main function bar by sliding ↑ and turning 【○】 the COMAND controller and press ⑤ to confirm.
- ► Select Sat. Radio and press ⑤ to confirm.



Service information screen

- ① Provider's phone number (SIRIUS XM)
- ② SIRIUS XM ID of your satellite receiver
- ► Call the phone number of your satellite radio provider shown on the screen.

1 You can also have the satellite service activated online. To do so, visit the SIRIUS XM Radio website at

http://www.sirius.com (USA) or http://www.siriuscanada.com (Canada).

Once the connection has been established:

- ► Follow the instructions of the service staff. The activation process may take up to ten minutes. If the activation is completed successfully, the No Service message appears in the display, followed by the satellite radio main menu.
- If registration is not included when purchasing the system, your credit card details will be required to activate your account.

If the satellite receiver is not installed or is not installed correctly, the Device not available message will appear.

Switching on satellite radio mode

Notes

Important notes on registration, see "Registering satellite radio" (> page 217).

Switching on satellite radio mode

- ► Select Audio in the main function bar by sliding ♠ and turning ♣ ♠ the COMAND controller and press ⑤ to confirm. If satellite radio mode was the last mode selected, it will now be active.
 - If another audio mode is switched on, you can now switch to satellite radio mode in the audio menu.
- ► Select Audio by sliding to the COMAND controller and pressing to confirm.


 The audio menu appears.
- ► Select Sat. Radio and press 🐿 to confirm.

The No Service message appears when starting up or if no signal is being received.



If the satellite receiver is not installed or is not installed correctly, the Device not available message will appear.

Once COMAND receives the signal, the satellite radio display appears. The station last selected is played.



P82.87-3303-31

Satellite radio main menu

- 1) Satellite radio main display
- Preset
- (3) Channel name
- 4) Selected category/channel number
- (5) Sound settings
- (6) Category list
- ⑦ Channel information (in brief)
- (8) Channel information (in detail)
- (9) Channel preset list
- (10) SatRadio menu

Channel information \bigcirc can be viewed in detail (\triangleright page 220).

Changing the category

Satellite radio stations are sorted into various categories. You can choose between the different categories, such as news/talk shows, sports or country, if they are available. The category list is sorted alphabetically.

Selecting a category

- ➤ To call up the category list: select Category by turning 【○】 the COMAND controller and press ⑤ to confirm. The category list appears.
- ➤ To select a category: select a category by turning () the COMAND controller and pressing to confirm.

The category selected is shown in the display. You hear the station last selected for this category.

The All Channels category is at the top of the category list. This category is sorted by channel number and allows you to browse all available channels.

Selecting a channel

Channel search

➤ Turn 【◎】 or slide ←◎→ the COMAND controller while the display/selection window in the SatRadio display is active. COMAND searches in both directions (ascending and descending) and stops at the next channel found in the selected category.

Using the multifunction steering wheel

- ► Press or to select the Audio menu.
- ▶ Press and hold or .

SatRadio menu

Select Sat. Radio in the submenu bar by turning (○) the COMAND controller and press to confirm.

The SatRadio menu appears.

Entering channel numbers directly Option 1

▶ Press the ★ + button. An input menu appears.



Option 2

- Select Sat. Radio in the submenu bar by turning {◎} the COMAND controller and press ⑤ to confirm.
- ► Select Enter Channel and press ⑤ to confirm.

 An input menu appears.
- ➤ To enter a channel: irrespective of the option, press the corresponding number keys on the control panel one after the other.

COMAND sets the selected channel.

1 You can only select currently permitted digits.

Selecting a channel from the SatRadio channel list

- ► Select Sat. Radio in the submenu bar by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- ➤ Select Channel List and press ⑤ to confirm.

 The channel list appears.
- ► Select a channel by turning 【○】 the COMAND controller and press ⑤ to confirm.

Memory functions Storing channels

1 There are ten presets available.

- Ihere are ten presets available.
- ► Press ⑤ the COMAND controller when the display/selection window is active.

or

Select Presets in the submenu bar by turning 【○】 the COMAND controller and press ⑤ to confirm.
In both cases, the channel presets appear.

In both cases, the channel presets appear
The • dot in front of a preset position
indicates that the currently selected
channel is stored there.

➤ Select a preset by turning 【◎】 the COMAND controller and press and hold ⑤ until you hear a tone.

or

Press and hold a number button, e.g. 4, until you hear a tone.
The channel is stored under the preset.

Storing channels automatically

This function automatically stores channels with adequate reception in the preset memory. Channels stored manually in the preset memory will be overwritten.

- ▶ Option 1: press ⑤ the COMAND controller when the display/selection window is active.
- Select Autostore in the presets by turning
 ↓ the COMAND controller and press
 to confirm.
- ▶ Option 2: select Presets in the submenu bar by sliding • and turning • to confirm.
- ▶ Select Autostore and press ⑤ to confirm. In both cases, COMAND searches for channels that can be received. You will see a message to this effect. The available channels are automatically stored in the preset positions.
- ► To cancel storing: select Cancel and press (*) to confirm.

Selecting a channel from the preset list

- ➤ To call up the channel list: select
 Presets by turning 【◎】 the COMAND
 controller and press ⑧ to confirm.
 The channel preset list appears.
- ➤ To set a channel: select a preset by turning 【◎】 the COMAND controller and press ⑤ to confirm.

or

▶ Press a number key, e.g. **4**.



Using the multifunction steering wheel

- ▶ Press or to select the Audio menu.
- ▶ Press ▲ or ▼ briefly.

Displaying information

- ► Select Info in the submenu bar by turning **♦** the COMAND controller and press to confirm.
 - Information on the currently received program is displayed.
- ▶ To return to the SatRadio main display: slide ← ∅ → the COMAND controller.

Displaying service information

The provider's customer service center is available by phone at any time to answer any general questions or questions on the versions available.

- ► Select Sat. Radio in the submenu bar by turning () the COMAND controller and press (5) to confirm.
- ► Select Service and press ⑤ to confirm. The provider's details appear.
- ► To return to the SatRadio main display: slide ← ○ → the COMAND controller.

Channel list updates

When receiving a new channel list, the display shows the Updating channel... message.

The station last selected is switched to mute until the update has been completed. Satellite radio mode is not available during this process.

Once the update has been completed, the satellite radio main menu appears. The station last selected is played.

Sound settings

You will find details on the sound settings in the "At a glance" section (⊳ page 135).

Audio CD/DVD and MP3 mode

Important safety notes

★ WARNING

COMAND is classified as a Class 1 laser product. You must not open the casing. If you open the casing, or if the casing is faulty or damaged, there is a risk of exposure to invisible laser radiation. This may damage your eyes, or those of others.

COMAND does not contain any parts that can be serviced by the user. For safety reasons, all maintenance work must be carried out by qualified aftersales technicians.

↑ WARNING

Only when the vehicle is stationary should you:


- load a disc
- · eject a disc

There is a risk of being distracted from the road and traffic conditions if this is done while the vehicle is in motion.

Inserting/ejecting CDs/DVDs

DVD changer

The DVD changer has a fixed magazine with six trays.



Magazine tray status (3):

- Indicator lamp off: magazine tray is empty.
- Indicator lamp constantly lit: magazine tray is loaded.



- ► To load a single magazine tray: press respective button ③.
- ► Remove any CD/DVD which may be in slot ①.
- ► Wait until the indicator lamp for button ③ which has been pressed flashes quickly.
- ▶ Insert the CD/DVD to be loaded into slot ①.

If the CD/DVD has been inserted properly and it is a permissible type, the last CD/DVD loaded will be played.

► To load all six magazine trays: press button ②.

The DVD changer checks the load status of all magazine trays and switches to the first empty tray.

- ► Wait until the indicator lamp for the respective button flashes quickly.
- ► Insert a disc into slot ①.

 The DVD changer switches to the next empty magazine tray.
- Repeat the last two steps until all trays are loaded.
 If the CD/DVD has been inserted properly and it is a permissible type, the last CD/ DVD loaded will be played.
- If you remove one disc while playing another disc, the DVD changer interrupts playback. Playback continues once the disc has been removed.
- ► To remove a disc: press respective button ③.
- ► Remove the CD/DVD from slot ①.

 If the CD/DVD is not removed from slot ①, it will be automatically drawn in again after a short while.
- ➤ To remove all discs: press button ④.

 The DVD changer ejects the CD/DVD from the tray currently in use.

- ► Remove the CD/DVD from slot ①.

 The DVD changer switches to the next loaded magazine tray and ejects the CD/DVD.
- ► Repeat the last step until the magazine is empty.

Loading and removing SD cards

1 Not all SD memory cards are designed for the temperatures which may be reached in the vehicle.

Due to the wide range of SD cards available on the market, Mercedes-Benz cannot guarantee playback for all brands of SD memory card.



- ➤ To load an SD card: press the SD card into slot ①. The tapered side must point towards the right.

 If the SD card contains MP3 tracks, COMAND will play them back.
- ► To remove the SD card: press the SD card into slot ① as far as it will go and then release it again.
- ▶ Pull out the card.

Activating audio CD/DVD or MP3 mode

Option 1

► Insert a CD/DVD (▷ page 220) or an SD card (▷ page 221) or connect a USB device (▷ page 233).

COMAND loads the medium inserted and starts to play it.



Option 2

- ► Press the DISC function button once or twice.
- ➤ Select an audio medium from the media list (> page 224).

Option 3

► Select Audio in the main function bar by sliding • ○ and turning • ○ • the COMAND controller and press • to confirm.

The last active audio source is now activated

If another audio source is switched on, you can now switch to disc mode in the audio menu.

The audio menu appears.

► Select Disc, Memory Card, MUSIC REGISTER, Media Interface or USB and press (*) to confirm.

This switches to the desired audio source.

➤ Select an audio medium from the media list (> page 224).

Example display: audio CD mode




P82.87-3305-31

- 1) Disc type
- (2) Track number
- ③ Disc number
- 4 Disc name (only if stored on the disc)
- (5) Track name (only if stored on the disc)
- 6 Track time

- Traphic time and track display
- (8) Sound settings
- Ourrent playback option
- Media selection
- 11) Music search
- Recording (saving) music
- (3) CD functions

Example display: audio DVD mode




P82.87-3306-31

- ① Disc type
- Track name
- ③ Disc number
- 4 Disc name (only if stored on the disc)
- (5) Track time
- (6) Graphic time and track display
- (7) Sound settings
- (8) Current playback option
- Media selection
- (10) Music search
- (11) Stop function
- Pause function
- (2) Pause function
- (13) Audio DVD mode



Example display: MP3 mode



P82.87-3307-31

- ① Disc type
- ② Disc number
- 3 File or track name (ID3 tags)
- 4 Disc or directory name
- (5) Current playback option
- 6 Track time
- Traphic time and track display
- Sound settings
- Media selection
- (10) Music search
- (II) Artist (ID3 tags)
- (12) MP3 functions

Pause function

In audio CD/DVD and MP3 mode

Only in audio DVD mode

- ► To pause playback: switch on audio DVD mode (> page 221).
- ► Select by sliding and turning the COMAND controller and press to confirm.

The 🔃 display changes to 🕨.

► To continue playback: select and press to confirm.

Playback continues from the point where it was interrupted. The display changes to .

Stop function

This function is only available in audio DVD mode.

- ▶ Switch on audio DVD mode (▷ page 221).
- ► To interrupt playback: select by sliding and turning to the COMAND controller and press to to confirm.

The display changes to . Impremains highlighted.

► To continue playback: select and press to confirm.
Playback continues from the point where it was interrupted.

► To stop playback: while playback is interrupted, select again and press to confirm.

or

- ▶ Select and confirm by pressing twice in rapid succession.
 ▶ is highlighted.




Selecting CD/audio DVD/MP3 discs

Selecting via the media list

▶ In CD/audio DVD and MP3 mode: select Media by sliding ○ ↓ or turning 【○】 the COMAND controller and press ⑤ to confirm.

The media list appears. The • dot indicates the currently selected medium.



Media list

The media list shows the discs currently available

Media list (when equipped with a DVD changer)

Magazine trays, positions 1 to 6: readable data media are audio CDs, MP3 CDs or MP3 DVDs, audio DVDs and video DVDs.

Memory card, position 7

MUSIC REGISTER, position 8

Media Interface, position 9

USB, position 10

1 If a disc cannot be read, an entry appears after the display in the magazine tray.

Equipped with a single DVD drive

DVD drive, position 1: readable data media are audio CDs, MP3 CDs or MP3 DVDs, audio DVDs and video DVDs.

Memory card, position 2

MUSIC REGISTER, position 3

Media Interface, position 4

USB, position 5

- ► Select the data medium by turning 【○】 the COMAND controller and press ⑤ to confirm.
- If you select a video DVD, the system switches to video DVD mode (▷ page 240).

Selecting a track using the number keypad

Press a number button, e.g. 4 , when the display/selection window is active.
The medium at the corresponding position in the media list is loaded and then played.

Selects a track

Selecting by skipping to a track

➤ To skip forwards or back to a track: slide

← ○ → or turn 【 ○ 】 the COMAND controller
when the display/selection window is active.

The skip forward function skips to the next track.

Skipping backwards restarts the current track (if it has been playing for more than 8 seconds) or starts the previous track (if the current track has only been playing for a shorter time).

If you activate the Medium Mix or Track List Mix playback option (MP3 mode only), the track order is random.

- ➤ On the multifunction steering wheel: switch COMAND to audio CD, audio DVD or MP3 mode (> page 221).
- ► Press or to select the Audio menu.
- ▶ Press the or button on the multifunction steering wheel.



Selecting by track list

- In audio mode, select Search by sliding ○ I or turning (○) the COMAND controller and press (*) to confirm.
- ► Select Current Track List.

or

- Press the COMAND controller in audio mode when the display/selection window is active.
- Select the track by turning 【◎】 and press ⑤ to confirm.
- in MP3 mode, the list shows all the tracks in alphabetical order.
- ➤ On the multifunction steering wheel: switch COMAND to audio CD, audio DVD or MP3 mode (> page 221).
- ► Press or to select the Audio menu.
- ▶ Press and hold the ▲ or ▼ button until the desired track has been reached.

If you hold down or , the system runs through the list more quickly. Not all audio drives or data carriers support this function.

If track information is stored on the audio drive or data storage device, the multifunction display shows the number and name of the track.

Selecting a track using the number keypad

- ► Press the * + button on the number keypad.
 - A numerical entry field appears. The number of positions offered corresponds to the number of tracks on the CD/DVD. Only numbers that correspond to a track number on the CD/DVD can be entered.
- ► Enter the desired track number using the number keys.

Fast forward/rewind

While the display/selection window is active, slide ←⊙→ and hold the COMAND controller until the desired position has been reached.

Music search

You can use the following characteristics to search music:

- Keyword search
- Playlist
- Artists
- Albums
- Tracks
- Genres
- Year
- ▶ In audio mode, select Search by sliding ○ ▶ or turning 【○】 the COMAND controller and press ⑤ to confirm. A selection list appears.

For the search, the media inserted is scanned and the music track data is stored in a COMAND database. A medium that has already been scanned is not scanned again if another search is carried out. The scanning process may take some time for media with a large capacity. The search can be carried out after the scanning process is finished.

Selecting a folder

This function is only available in MP3 mode.

- ► Switch on MP3 mode (> page 221).
- Select Search by sliding ■ and turning 【○】 the COMAND controller and press ⑤ to confirm.
- Select Folder by sliding ■ and turning ¶○ ■ the COMAND controller and press ⑤ to confirm.

You will see the tracks in the folder.





Select a track by turning 【◎】 and press ⑤ to confirm.

The track is played and the corresponding folder is now the active folder.

Copying music files from audio CDs to the hard disk

Audio files can be copied from CD to COMAND's hard disk.

- Select Audio by sliding and turning the COMAND controller and press to confirm.
- ➤ Switch on CD/audio DVD or MP3 mode (> page 221).
- ► Select a medium (> page 224). The audio CD is played.
- ► To copy all music tracks: select REC by sliding • and turning (○) and confirm with ⑤.



P82.87-3667-31

- Audio source
- ② Destination
- 3 Total length of all tracks from the audio source

- 4 Title selection
- To start the copying process
- Name of the copied data
- ⑦ Cancel procedure without copying files
- Media position in the media list
- Select START by sliding ↓ and turning 【○】 and confirm with ⑤.

All music tracks from the audio CD are copied to COMAND's MUSIC REGISTER as MP3 files.

➤ To copy individual music tracks: select Track Select. by sliding ○ • and turning • and confirm with •.

The track list appears.

- ► Select individual tracks by turning 【◎】 and confirm with ⑤.
- ► Select START by turning 【◎】 and confirm with ⑤.

The selected music tracks from the audio CD are copied to COMAND's MUSIC REGISTER as MP3 files.

If the audio CD contains CD text or Gracenote® data, this will be used for naming when the tracks are copied. The data is then copied to the MUSIC REGISTER in the following structure: artist/album/track. The copied titles can then be selected and played using the music search in the MUSIC REGISTER.

► To delete music files:(> page 233).

Gracenote Media Database

Introduction

This function is only available in audio CD mode.

There is a version of the music recognition software from Gracenote[®], Emeryville, California, USA on the hard disk. You will recognize this by the logo which can be seen in the bottom right-hand corner of certain audio displays.





Many audio CDs contain CD text. COMAND uses the information contained therein to display the artist, album and track name.

If the audio CD does not contain any CD text information, COMAND can use the Gracenote Media Database to identify unknown audio tracks when running in audio CD mode. This is only possible if the relevant information is saved in the Gracenote Media Database and if the "Gracenote Media Database" function is activated.

If this is the case, COMAND will display the corresponding data such as artist, album and track name in the relevant displays and lists. If COMAND accesses the Gracenote Media Database when reading an audio CD, you will see the following message:



P82.87-3079-31

Selecting Gracenote® data to be displayed

If the inserted CD does not contain any Gracenote® data, the Gracenote Media Database menu item is shown in gray and cannot be selected.

- ▶ Switch on audio CD mode (▷ page 221).
- ► Select CD by sliding ↓ and turning 【○】 the COMAND controller and press ⑤ to confirm.
- ► Select Gracenote Media Database by turning 【◎】 the COMAND controller and press ⑤ to confirm.

 Switch the function on 🗹 or off □.

Updating Gracenote® music recognition technology and the Gracenote Media Database

The digital data on the Gracenote Media Database becomes obsolete due to the release of new CDs. Optimum functionality can only be attained with up-to-date Gracenote® music recognition technology. Information about new versions can be obtained from an authorized Mercedes-Benz Center.

You can have your music recognition software updated there with a DVD, or you can update it yourself.

1 The Gracenote Media Database is updated in conjunction with the navigation system's digital map (▷ page 188).

Setting the audio format

You can only set the audio format in audio DVD mode. The number of audio formats available depends on the DVD. The content of an audio DVD is called an "album", and this can be divided into up to nine groups. A group can contain music in different sound qualities (stereo and multichannel formats, for example), or bonus tracks. Each group can contain up to 99 tracks. If an audio DVD only contains one audio format, the "Group" menu item(s) cannot be selected.

- ► Switch on audio DVD mode (> page 221).
- Select DVD-A by sliding ♣ and turning ♠ the COMAND controller and press ♠ to confirm.



► Select Group by turning 【◎】 and press ⑤ to confirm.

The list of available groups appears. The

- dot indicates the group currently selected.
- ► To exit the menu: slide + ① → the COMAND controller or press the 🛨 button.

Playback options

The following options are available to you:

• Normal Track Sequence

The tracks are played in the normal order (e.g. track 1, 2, 3, etc.).

In MP3 mode, the track order is determined by the order in which the tracks are written to the MP3 data carrier when it is created. Alphabetical order is the most common. Once all the tracks in a folder have been played, the tracks in the next folder are played.

• Medium Mix

All the tracks on the medium are played in random order (e.g. track 3, 8, 5 etc.).

- Track List Mix (MP3 mode only)
 All the tracks that are listed in the current track list are played in random order.
- ► To select options: switch on audio CD/ DVD or MP3 mode (> page 221).
- ► Select CD, DVD-A or MP3 by sliding ♣ and turning � ♪ the COMAND controller and press ⑤ to confirm.

The options list appears. The • dot indicates the option selected.

Select an option by turning 【◎】 and press ⑤ to confirm.

The option is switched on. For all options except "Normal track sequence", you will see a corresponding display in the display/ selection window. See the example of the display in audio CD mode (▷ page 221).

1 The "Normal track sequence" option is automatically selected when you change the medium you are currently listening to or when you select a different medium. If an option is selected, it remains selected after COMAND is switched on or off.

Notes on MP3 mode

Permissible discs

- · CD-R and CD-RW
- DVD+R and DVD+RW
- DVD-R and DVD-RW
- · SD memory card:
- USB stick
- iPod®
- MP3 player

Permissible file systems

- ISO 9660/Joliet standard for CDs
- UDF for audio and video DVDs
- FAT16 or FAT32 for storage media

Multisession CDs

For multisession CDs, the content of the first session determines how COMAND will process the CD. COMAND plays only one session and gives priority to the audio CD session.

If possible, use COMAND to play only CDs which have been written in one session.

File structure of a data carrier

When you create a disc with compressed music files, the tracks can be organized in folders. A folder may also contain subfolders. A disc can contain a maximum of 255 folders. Each folder can contain a maximum of 255 tracks and 255 subfolders.

The disc may contain no more than eight directory levels. Files beyond the eighth level will not be recognized by the system.

Track and file names

When you create a disc with compressed music files, you can assign names to the tracks and folders.

COMAND uses these names accordingly for the display. Folders which contain data other



than MP3 or WMA tracks are not displayed by COMAND.

If MP3 or WMA files are stored in the root directory itself, the root directory will also be treated as a folder. COMAND will then show the name of the root directory as the folder name.

You must observe the following when assigning track names:

- track names must have at least 1 character.
- track names must have the extension "mp3" or "wma".
- there must be a full stop between the track name and the extension.

Example of a correct track name: "Track 1.mp3".

1 COMAND does not support ID3 tags.

Permissible formats

COMAND supports the following formats:

 Microsoft Windows Media Audio V2, V7, V8 and V9 (WMA)

Permissible bit and sampling rates

COMAND supports **MP3** files of the following types:

- fixed and variable bit rates from 32 kbit/s to 320 kbit/s
- sampling rates of 8 kHz to 48 kHz COMAND supports WMA files of the following types:
- fixed bit rates from 5 kbit/s to 384 kbit/s
- sampling rates of 8 kHz to 48 kHz

COMAND does **not** support **WMA** files of the following types:

- DRM (Digital Rights Management) encrypted files
- 1 Only use tracks with a bit rate of at least 128 kbit/s and a sampling rate of at least 44.1 kHz. Lower rates can cause a noticeable deterioration in quality. This is especially the case if you have activated a surround sound function.

Notes on copyright

MP3 or WMA tracks that you create or play back are generally subject to copyright protection in accordance with the applicable international and national regulations.

In many countries, reproductions, even for private use, are not permitted without the prior consent of the copyright holder.

Make sure that you know about the applicable copyright regulations and that you comply with these.

If you own these rights yourself, e.g. for your own compositions and recordings, or if the copyright holder has granted you permission, these restrictions do not apply.

Notes on CDs/DVDs

Discs with copy protection are not compatible with the audio CD standard and therefore may not be able to be played by COMAND.

There may be playback problems when playing copied discs. There is a wide range of data carriers, disc-writing software and writers available. This variety means that there is no guarantee that the system will be able to play discs that you have copied vourself.

There may be playback problems if you play CDs that you have copied yourself with a storage capacity of more than 700 MB. CDs of this type do not conform to the currently applicable standards.

- On many DVD audio discs, the last track does not contain any music and COMAND then switches to the next disc. This is normal system behavior and does not mean that there is a malfunction.
- Do not affix stickers or labels to the discs.
 They could peel off and damage the drive.
 The drive is designed to hold discs which comply with the EN 60908 standard.
 Therefore, you can only use discs with a maximum thickness of 1.3 mm.

If you insert thicker discs, e.g. those that contain data on both sides (DVD on one side and audio data on the other), they cannot be ejected and can damage the drive.

Do not use discs with a diameter of 8 cm, even with an adapter. Only use round discs with a diameter of 12 cm.

COMAND is able to play back audio CDs in multichannel audio format.

MUSIC REGISTER

General notes


You can store music files in MP3 or WMA format in the MUSIC REGISTER. The memory has a capacity of approximately 7 GB.

Retain the original music files in a secure location. An error in COMAND might result in the loss of the music files stored in the MUSIC REGISTER. Mercedes-Benz is not liable for any loss of data.

Switching to MUSIC REGISTER

- ▶ Select Audio in the main function bar by sliding ♠ and turning ♣ ♠ the COMAND controller and press ♠ to confirm.

 If MUSIC REGISTER was the last mode selected, it is now switched on.
 - If another audio source is switched on, you can now switch on the MUSIC REGISTER in the audio menu.
- ► Select Music Register and press ⑤ to confirm.



P82.87-3080-31

Example display: MUSIC REGISTER

- 1) Type of data carrier: MUSIC REGISTER
- (2) Track number
- (3) Track name
- (4) Track time
- (5) Graphic time and track display
- Current playback settings (no symbol for "Normal track sequence")
- Sound settings
- Media selection
- © Current folder
- (10) Search functions
- (1) Data carrier position in the media list
- (12) To call up the MUSIC REGISTER menu

Copying music data to the MUSIC REGISTER

Introduction

You can copy music files from discs in the DVD changer, the single DVD drive, the memory card or the COMAND USB, as long as they are in MP3 and/or WMA formats.

1 While copying, several functions will not be available. If this is the case, you will see a message to this effect.

1. Selecting a data medium

The audio menu appears.



- ➤ Select Music Register and press ® to confirm.
- ► Select Copy Music Files and press ⑤ to confirm.



P82.87-3081-31

- (1) Data medium selected
- ► To select a disc: slide † ↓ or turn 【 〕 and press ⑤ to confirm.

 The data medium is loaded.

2. Selecting music files

- ➤ Select All Music Files.

 This function copies all music files on the selected data carrier. The symbol in front of All Music Files is filled in.
- ► Select Continue.


 The copying menu appears.

Folders can also be selected individually.

► To select individual folders: select the corresponding folder by sliding • ○ • or turning • ○ • and press • to confirm.

A tick in front of the entry highlights the selection.

3. Starting the copying process



- ① To copy from a memory card
- ② To copy to the MUSIC REGISTER
- ③ Memory requirement, see "Calling up memory space info" (> page 232)
- (4) To start the copying process
- Solution
 Name of the data carrier from which data is being copied and storage location
- To cancel copying of music files
- 7 Data carrier position in the media list
- ► Select Start and press ⑤ to confirm.

 Copying begins. The progress bar indicates the status of the copying procedure.
- ► To exit without copying files: select Back and press ⑤ to confirm.
- Under no circumstances should you remove the memory card while you are copying data from it. This will generate unusable data in the MUSIC REGISTER.



- Progress bar
- 1 It may take some time for the copying process to be completed, depending on the



amount of data. The time required may vary depending on the data source. If there is not enough memory space, you will see a message to this effect.

► To cancel copying: select Cancel.

Music files are stored in the MUSIC

REGISTER up until the point of cancellation.

Deleting all music files

This function deletes all music files from the MUSIC REGISTER.

- The deletion procedure may take several minutes. In order to prevent malfunctions, do not use COMAND during this period.
- ► Select Music Register by sliding ↓ and turning 【○】 the COMAND controller and press ⑤ to confirm.
- ➤ Select Delete All Music Files and press ⑤ to confirm.

 A query appears. No is highlighted.

 If you select Yes, all music files are deleted.

 You see the Please wait... message.

 Then, you see the Deletion successful message.

If you select N_0 , the process will be aborted.

Calling up memory space info

- ► Select Music Register by sliding ③ * and turning 【 ⑤ 】 the COMAND controller and press ⑤ to confirm.
- ► Select Memory Information and press ⑤ to confirm.

The following is displayed:

- · storage capacity
- available memory
- · occupied memory
- · content (folders, tracks)

Folder functions

Introduction

You can view the content of the MUSIC REGISTER, change folder or track names and delete individual folders or tracks.

Calling up a folder

- ► Select Folder and press ⑤ to confirm.

 You see the contents of the current folder.
- ► To switch to the superordinate folder: select the icon and press to confirm.

The display changes to the next folder up.

Changing the folder/track name



P82.87-2176-31

- Folder selection symbol
- (2) Icon for music file
- ③ Current folder
- ► Select Music Register by sliding • and turning 1 the COMAND controller and press to confirm.
- ► Select a folder/track by turning 🕻 🔾 🤰.
- ► Select Options by sliding ⊙→ and press ⑤ to confirm.
- ► Select Edit and press ⑤ to confirm.



- ► Enter a name for the folder/track.
- ► To save the changes: select ok and press ⑤ to confirm.

Deleting folders/tracks

- ➤ Select Rename/Delete Files by sliding

 ③ and turning • the COMAND controller and press to confirm.
- ► Select the folder/track by turning 【◎】.
- Select Options by sliding ○→ and press
 ⑤ to confirm.
- ► Select Delete and press ⑤ to confirm. A query appears. No is highlighted. If you select Yes, the folders/tracks are deleted. You see the Please wait... message. Then, you see the Deletion Successful message.

If you select No, the process will be aborted.

Playback options

The following options are available:

- Normal Track Sequence
 The tracks are played in the normal order (e.g. track 1, 2, 3, etc.).
- Medium Mix

All the tracks on the medium are played in random order.

- Track List Mix (MP3 mode only)
 All the tracks that are listed in the current track list are played in random order.
- ► To select options: switch on the MUSIC REGISTER (> page 230).
- ► Select Music Register by sliding ↓ and turning 【○】 the COMAND controller and press ⑤ to confirm.
 - The options list appears. The dot indicates the option selected.
- ► Select an option and press ⑤ to confirm. The option is switched on. All options except Normal Track Sequence will be indicated by a corresponding icon in the display/selection window.

1 The Normal Track Sequence option is automatically selected when you change the disc you are currently listening to or when you select a different medium. If an option is selected, it remains selected after COMAND is switched on or off.

Media Interface mode

Connection options

Overview

You will find the connection sockets in the glove box.

Device-specific adapter cables are required to connect external devices to the Media Interface. These cables are included in the Media Interface scope of delivery.

1 Store individual parts in a safe place.
Only use genuine Mercedes-Benz connection cables.

You can connect the following data carriers to COMAND via the Media Interface:

- iPod®
- USB devices (USB sticks, USB hard drives, MP3 players)
- iPod® is a registered trademark of Apple Inc., Cupertino, California, USA.

Supported iPod® variants

The following are examples of supported iPod® variants:

- iPod® nano
- iPod® classic
- iPod® touch
- iPhone®

Supported USB devices

The following USB devices are supported:

- USB sticks (flash memory)
- USB hard drives requiring a startup/ permanent current of a maximum of



800 mA (it may be necessary to connect a separate power supply)

- · certain MP3 players
- The Media Interface supports USB storage media of "USB Device Subclass 6". Information concerning USB Device Subclass 6 is available from the equipment manufacturer.


For details and a list of supported devices, visit http://www.mbusa-mobile.com. Or call the Mercedes-Benz Customer Assistance Center at

1-800-FOR-MERCedes(1-800-367-6372) (for the USA) or Customer Relations at 1-800-387-0100 (for Canada).

Connecting an external device

1 Do not leave external devices in the vehicle as extreme temperatures (e.g. direct sunlight or extremely low outside temperatures) could cause them to malfunction (see the operating instructions for the respective device). Mercedes-Benz USA, LLC accepts no liability for damage to external devices.

Never connect more than one device at a time. You will otherwise not be able to operate the external device.



P82.60-6736-31

- ① 4-pin jack for 1/8 inch jack plug, e.g. for MP3 player (audio and video)
- ② iPod® plug
- ③ USB socket
- ④ Example of device, iPod®

➤ Connect the external device with suitable socket ①, ② or ③.

COMAND activates the device automatically for sockets ② and ③.

COMAND does not activate the device automatically for socket ①.



If you remove a device from sockets ② and ③, the No device connected message appears.

- 1 A connected iPod® or MP3 player should not be simultaneously operated via the Media Interface and the remote control (e.g. Bluetooth® remote control), as this may produce unpredictable results.
- Connecting a fully discharged iPod® or MP3 player can result in an extended initialization period.

Error messages appear while the device is being activated if:

- COMAND does not support the device connected.
- two devices are connected.
- the connected device consumes too much power.
- the Media Interface connection is faulty.
- Consult an authorized Mercedes-Benz Center if required.



Switching to Media Interface mode

General notes

In extreme cases, starting up individual functions can take up to several minutes – this depends on the external device and its content (e.g. video podcasts).

Only use the original software to save files on iPods or MP3 players. Otherwise, some or all functions may not be available.

Option 1

Connect an external device (▷ page 234). COMAND activates the device. Following this, the basic display appears if there are any playable files on the data carrier.

or

- ▶ Select Audio in the main function bar by sliding ♠ and turning ♣ ♠ the COMAND controller and press ♠ to confirm.

 If you had previously selected Media Interface mode, this will now be activated. If another audio source is switched on, you can now switch to Media Interface mode in the audio menu.

The audio menu appears.

► Select Media Interface and press ⑤ to confirm.

Option 2

The audio menu appears.

► Select Media Interface and press ⑤ to confirm.


Option 3

► In the media list, (> page 224) turn (○) the COMAND controller to select the entry

under the corresponding position and press (*) to confirm.

COMAND activates the connected device. You will see a message to this effect. The basic display then appears.

If no device is connected, you will see the Media Interface entry instead of a device name.



P82.87-5907-31

Example display: iPod mode

- 1) Data medium type
- (2) Track number
- ③ Track name
- 4 Graphic time display
- Track time
- (6) Graphic track display
- Current playback settings (no symbol for "Normal track sequence")
- (8) Sound settings
- Media list
- (i) Album name (if available)
- (11) Categories, playlists and/or folders
- ② Artist (if available)
- ® Playback options

Type of device ① connected is indicated by the corresponding symbol for iPod, MP3 player or USB mass storage device.

ilf the device connected does not contain any playable tracks, a message appears to this effect.



Selecting music files

Note

COMAND displays the data stored on the iPod®, MP3 player or USB mass storage device according to the filing structure used in the respective medium.

Selecting by skipping to a track

- ➤ To skip forwards or back to a track: turn 【◎】 the COMAND controller when the display/selection window is active.

 The skip forward function skips to the next track. The skip back function skips to the beginning of the current track if the track has been playing for more than eight seconds. If the track has been playing for less than eight seconds, it skips to the start of the previous track. If you have selected a playback option other than Normal Track Sequence, the track sequence is random.
- ▶ On the multifunction steering wheel: switch on Media Interface mode (▷ page 234).
- ► On the multifunction steering wheel, press the or button to select the Audio menu.
- ▶ On the multifunction steering wheel, press▲ or ▼ to select a track.

Selecting using the number keypad

- ▶ To make an entry: press the ★ + button.

 An input menu appears. The number of characters available for input depends on the number of tracks that can currently be selected.
- ► To enter a track number: press a number key, e.g. 7 poss.
 - The digit is entered in the first position in the input line.
- COMAND will ignore and not display an invalid digit.
- ► Enter more numbers if desired. The selected track is played.

Fast forward/rewind

- While the display/selection window is active, slide ←⊙→ and hold the COMAND controller until the desired position has been reached.
- 1 On an iPod®, fast rewind only functions within the current track.

Selecting a category/playlist/folder

iPod® and certain MP3 players

For an iPod[®] or MP3 player, you can select tracks using categories or folders.

Depending on the device connected, the following categories may be available, for example:

- Current tracklist
- Playlists (e.g. All)
- Artists
- Albums
- Tracks
- Podcasts
- Genres
- Composers
- Audiobooks
- 1 Some playback categories contain the entry All. If this entry has been selected, the entire content of the category selected will be played.

USB devices

For USB mass storage devices, you can select both folders as well as any existing playlists. COMAND can also display the album name and artist (metadata) during playback, if this information has been entered into the system.

Playlists are indicated in the display by a special icon. When you open the playlist, the corresponding tracks are displayed and playback begins once a track is selected. You can now select Category Mix instead of Random Folder as a playback option.



For USB mass storage devices, you can choose to display the metadata contained in the tags of the encoded music data, or to display the file and directory names during playback.

- ► To display the album and artist name: select Media Interface in the basic display by sliding • and turning the COMAND controller and press to confirm.
- ► Select Display Metadata and press ⑤ to confirm.

Selecting a category and opening a folder

- ► Press ⑤ the COMAND controller when the display/selection window is active.
- Select Folder by sliding + and turning
 1 the COMAND controller and press
 to confirm.

You will see the available categories or the folder content (e.g. other folders). The display's status bar shows the selected category or the folder name.

- 1 The Music menu item is not available until the device has been activated.

You will see the content of the selected category or selected folder.

- i If the data needs to be read from the connected device, the Please wait... message appears.
- ▶ If necessary, repeat this step until the tracks in the desired folder/album appear.
- ► Select the track by turning 【○】 the COMAND controller and press ⑤ to confirm.

The track is played.

- ► To select one folder higher: select the icon and confirm with .
- 1 The 'icon is always shown at the top of the respective folder.

Playing back the contents of a category or folder

- ▶ Press ⑤ the COMAND controller for longer than two seconds.

The content of the category or folder selected is played in accordance with the playback option (▷ page 238) selected.

Alphabetical track selection

iPod® and MP3 players

This function is available for alphabetically sorted categories and folders. This function is not available for albums or playlists, for example.

Select a category, e.g. Artists, by turning
 ↓ the COMAND controller and press
 to confirm.

The available artists are displayed.

▶ Press the corresponding number key once or several times to select the first letter of the artist's name (e.g. for an artist beginning with the letter "C", press number key are three times).

The available letters are listed at the lower edge of the display.

After a message, the first entry in the list which matches the letter entered is highlighted.

- If no corresponding entry exists, the last entry corresponding to a previous letter is highlighted instead.
- For iPods® and MP3 players, the quality of the search results is highly dependent on the version and language variant of the software (e.g. iTunes® version) used to populate the device.

USB mass storage device

This function is available for alphabetically sorted directories. This function is not available for albums or playlists, for example.



► In a directory, press the corresponding number key once or several times to select the first letter of the artist's name (e.g. for an artist beginning with the letter "C", press number key 2 three times).

The available letters are listed at the lower edge of the display.

If the directory only contains folders, COMAND searches for folders. After a message, the first entry which matches the letter entered is shown at the top of the list. If no entry matches the entered letter, the first item in the list is the last entry to correspond to a selection.

Selecting an active partition (USB mass storage devices only)

You can select this function for USB mass storage devices when the storage device is partitioned. Up to four partitions (primary or logical; FAT format) are supported.

- 1 The Windows formatting program supports FAT partitioning up to 32 GB as standard.
- ► Select Media Interface in the basic display by sliding • and turning • the COMAND controller and press to confirm.
- ► Select Select Active Partition and press ⑤ to confirm.

Playback options

The following options are available:

- Normal Track Sequence
 - Normal track sequence: you hear the tracks in their normal order (e.g. numerical or alphabetical).
- Random Tracks
 - All the tracks on the medium are played in random order.
- Category MixorRandom Folder (for USB devices if Folder has been selected)

- The tracks in the currently active category or folder, including any subfolders, are played in random order.
- For USB devices, the random playlists offer a maximum of 300 tracks chosen at random.
- ► To select a playback option: select
 Media Interface in the basic display by
 sliding ③ and turning • the COMAND
 controller and press ⑤ to confirm.
 The options list appears. The dot
 indicates the option selected.
- ▶ Select an option and press 🔊 to confirm.

Separate USB connection

In addition to the USB connection on the Media Interface, there is another USB connection in the glove box. This connection can also be used to play audio files.

Electrical consumption at this connection must not exceed a continuous current of 500 mA. If the electrical consumption is higher, use a separate source to provide power for the USB device (e.g. 12 V power supply).

- ► Select USB and press ⑤ to confirm.

Notes on USB devices

Data formats

The following data formats are supported:

- MP3: CBR, VBR (up to 320 kbit/s)
- WMA: CBR, VBR (up to 320 kbit/s)



Notes on USB devices

- In order to keep the initialization time to a minimum, store only music data on a USB device.
- Approximately 10,000 tracks are supported. Multiple partitions should be used for larger numbers of tracks.
- · Do not use USB extension leads or adapters. They can impair functionality.
- A background search of the USB device is performed and any playlists found are shown in a separate category in addition to the folders. Initialization of larger USB mass storage devices containing a large number of files may take several minutes.
- DRM (Digital Rights Management) protected files are not supported by the Media Interface.

Audio AUX mode

Notes on audio AUX mode

You can connect an external audio source (AUX) to COMAND. The socket for this is located in the glove box.

If COMAND is equipped with a Media Interface, external audio sources are connected using the corresponding cable set. An AUX socket is not provided.

1 You can find more information on the Internet at http://www.mercedesbenz.com/connect and in the "Media Interface mode" section (⊳ page 233).

Activating audio AUX mode

When you connect an external audio source, audio AUX is not selected automatically.

► Select Audio in the main function bar by sliding ♠ ○ and turning **(** ○ **)** the COMAND controller and press (5) to confirm.

► Select AUX using 【◎】 and press ⑧ to confirm.

The audio AUX menu appears. The medium in the external audio source is played, if the source is connected and playback selected.



P82.87-5610-31

Please see the respective operating instructions for how to operate the external audio source.

You will find details on volume (▷ page 134) and sound (⊳ page 135) settings in the "At a glance" section.



↑ WARNING

External audio sources may have different volumes, which can mean that system messages such as traffic announcements and navigation system announcements are much louder. If necessary, please deactivate the system messages or adjust their volume manually.

Increasing the volume

In some cases, the volume of the AUX device may be quieter or louder, or the usual maximum possible volume cannot be reached. On some devices, it is possible to adjust the volume separately. In this case, start at a medium volume and increase it gradually. This enables you to determine whether the system is able to play tones at high volume without distorting them.



Video

General information

Automatic picture shutoff

If the vehicle is traveling faster than approximately 3 mph (5 km/h) and video DVD mode is activated, the picture is deactivated automatically.

The video picture is only shown if the selector lever is in the **P** position.

When the selector lever is moved from the **P** position, the In order not to distract the driver, the picture is faded out while the vehicle is in motion. message appears.

As soon as the vehicle speed falls below approximately 3 mph (5 km/h), the picture is reactivated.

Basic settings

Picture settings

Adjusting the brightness, contrast or color

- ▶ Press ⑤ the COMAND controller to show the menu.
- ► Select Video by sliding ⊙ + and turning **♦** the COMAND controller and press to confirm.
- ► Select DVD-V and press (5) to confirm.
- ► Select Brightness, Contrast or Color by turning () the COMAND controller and press (5) to confirm.

Changing the picture format

- ▶ Press ⑤ the COMAND controller to show the menu.
- ► Select Video by sliding ⊙ and turning **♦** the COMAND controller and press (b) to confirm.

- ► Select Video DVD and press (*) to confirm.
- ► Select DVD-V and press ⑤ to confirm. The DVD-V menu appears. The

 dot in front of a menu item indicates the current setting.
- ► Select Auto, 16:9 optimized, 4:3 or Widescreen and press (5) to confirm.
- ► Select a setting by turning **()** the COMAND controller and press (5) to confirm.

Video DVD mode

Safety notes



♠ WARNING

COMAND is classified as a Class 1 laser product. You must not open the casing. If you open the casing, or if the casing is faulty or damaged, there is a risk of exposure to invisible laser radiation. This may damage your eyes, or those of others.

COMAND does not contain any parts that can be serviced by the user. For safety reasons, all maintenance work must be carried out by qualified aftersales technicians.

Only when the vehicle is stationary should you:

- load a disc
- · eject a disc

There is a risk of being distracted from the road and traffic conditions if this is done while the vehicle is in motion.

Notes about discs

There may be playback problems when playing copied discs. There are a large variety of discs, DVD authoring software, writing software and writers available. This variety means that there is no guarantee that the system will be able to play discs that you have copied yourself.



- Do not affix stickers or labels to the discs, as they could peel off and damage COMAND. Stickers can cause the disc to bend, which can result in read errors and disc recognition problems.
- II COMAND is designed to accommodate discs which comply with the EN 60908 standard. You can therefore only use discs with a maximum thickness of 1.3 mm. If you insert thicker discs, e.g. those that

contain data on both sides (DVD on one side and audio data on the other), they cannot be ejected and can damage COMAND.

Use round discs with a diameter of 12 cm. Do not use discs with a diameter of 8 cm, even with an adapter.

DVD playback conditions

If video DVDs do not conform to the NTSC or PAL TV standards, they may create picture, sound or other problems during playback. COMAND can play back video DVDs produced according to the following standards:

- region code 1 or region code 0 (no region code)
- If you insert a video DVD with a different region code, you will see a message to this effect.
- PAL or NTSC standard

You will generally find the relevant details either on the DVD itself or on the DVD case.

1 COMAND is set to region code 1 at the factory. This setting can be changed at an authorized Mercedes-Benz Center. This will allow you to play video DVDs with a different region code, provided that they are produced in accordance with the PAL or NTSC standard. The region code can be changed up to five times.

Function restrictions

Depending on the DVD, it is possible that certain functions or actions will be temporarily blocked or may not function at all. As soon as you try to activate these functions or actions, you will see the \bigcirc symbol in the display.

Inserting and removing DVDs

► Proceed as described in the "Inserting and ejecting CDs and DVDs" section (> page 220).

Activating video DVD mode

Option 1

► Insert a video DVD. COMAND loads the medium inserted and starts to play it.

Option 2

► Select Video in the main function bar by sliding • ○ and turning 【○】 the COMAND controller and press ⑤ to confirm.

Video DVD mode is switched on.

Hiding/showing the navigation menu

- ► To show: turn 【◎】 or slide ↑◎↓ the COMAND controller.
- 1 This function is not available while the DVD's own menu (> page 244) is being displayed.
- ► To hide: slide t ⊚ the COMAND controller.

or

▶ Wait for approximately eight seconds.





P82.87-2178-31

Navigation menu displayed

- 1 Data medium type
- (2) Current track
- ③ Current scene
- 4 Track time
- (5) To show the menu


Showing/hiding the menu

This function is not available while the DVD's own menu (▷ page 244) is being displayed.

► To show: press ⑤ the COMAND controller.

or

- ► Select Menu while the navigation menu is shown and press ⑤ to confirm.
- ➤ To hide: slide ↑ the COMAND controller and confirm Full Screen by pressing ⑤.



P82 87-3213-31

Menu shown

- (1) Video DVD options
- (2) Pause function
- 3 Stop function
- (4) Full-screen function

- ⑤ Media selection
- Sound settings

Fast forward/rewind

Slide ←⊙→ and hold the COMAND controller until the desired position has been reached.

You see the navigation menu.

Selecting a video DVD

- ► Press ⑤ the COMAND controller to show the menu.
- ► Select Media by sliding • and turning • the COMAND controller and press
 • to confirm.

The media list appears. The • dot indicates the current medium being played. Video DVDs are indicated by the PVDY icon.



P82.87-5559-31

- ① DVDV symbol for a video DVD
- ② Video DVD currently playing
- ➤ Select DVD-V by turning () the COMAND controller and press () to confirm.

 COMAND loads the video DVD and starts playback.
- i If you select a CD, an audio DVD or an MP3 medium, you switch to the respective audio mode. You can find further information about the media list on (▷ page 224).



Stop function

- ▶ Press ⑤ the COMAND controller to show the menu.
- ► To interrupt playback: select by turning () the COMAND controller and press (5) to confirm.

The display changes to . The video image is hidden.

► To continue playback: select and press (5) to confirm. Playback continues from the point where it was interrupted.

► To stop playback: while playback is interrupted, select again and press (b) to confirm.

or

- ▶ During playback, confirm by pressing twice in quick succession. Selection is at .
- ► To restart playback: confirm ► by pressing (5). Playback restarts from the beginning.

Pause function

- ▶ Press 🔊 the COMAND controller to show the menu.
- ► To pause: select by turning () the COMAND controller and press 🐿 to confirm.

The display changes to .

► To continue playback: select and press (5) to confirm. The menu is hidden.

Selecting a scene/chapter

If the film is divided into scenes or chapters, you can select them directly while the film is running, or skip forwards step-by-step. Some DVDs do not permit this at certain points (e.g. during the opening credits).

It may also be possible to select the scene/ chapter from within the menu stored on the DVD.

- ► To skip forwards or back: turn 🕻 🔾 🕽 or slide ← ○ → the COMAND controller. The control menu (⊳ page 241) appears for approximately eight seconds.
- ▶ On the multifunction steering wheel: switch on video DVD mode in COMAND (⊳ page 241).
- ▶ Use the or button to select the Audio menu.
- ▶ Press or to select a scene/ chapter.

If you press and hold ▲ or ▼ for an extended period, rapid scroll begins.


Selecting a film/title

This function is only available if the DVD is divided into several films/tracks. If the DVD contains several films, these can be selected directly. A film can be selected either when the DVD is being played back or when it is stopped.

The film can also be selected from the menu on the DVD itself.

- ▶ Press ⑤ the COMAND controller to show the menu.
- ► Select DVD-V by turning () the COMAND controller and press (5) to confirm.
- ► Select DVD Functions and press 🔊 to confirm.

A menu appears.





- ► Select Title Selection by turning 【◎】 the COMAND controller and press (8) to confirm.
- ► Select a film/title and press (*) to confirm.

DVD menu

Calling up the DVD menu

The DVD menu is the menu stored on the DVD itself. It is structured in various ways according to the individual DVD and permits certain actions and settings.

In the case of multi-language DVDs, for example, you can set the language in the DVD menu.

- ▶ Press ⑤ the COMAND controller to show the menu.
- ► Select DVD-V in the menu by turning 【◎】 the COMAND controller and press (5) to confirm.
- ► Select DVD Functions and press ⑤ to confirm
- ► Select Menu and press ⑤ to confirm. The DVD menu appears.

Selecting menu items in the DVD menu

- ► Select a menu item by sliding ○ or turning ← ⊙ → the COMAND controller and press (5) to confirm. The menu appears.
- Menu items that cannot be selected are grayed out.



► To reconfirm your selection: confirm Select by pressing .

COMAND executes the action.

Make a selection from the further options, if necessary.

COMAND then switches back to the DVD menu.

1 Depending on the DVD, it is possible that the Back (to the movie), Play, Stop, or Go up menu item may not be operative or operative only at certain points of the DVD. To indicate this, the symbol is shown in the display.

Stopping a film or skipping to the beginning or end of a scene

- ▶ Select any menu item from the DVD menu. The menu appears.
- ► To stop the film: select the Stop menu item and press (b) to confirm.
- ▶ To skip to the end of a scene: select the ▶ menu item and press ७ to confirm.
- ▶ To skip to the beginning of a scene: select the

 menu item and press

 to confirm.

Moving up one level in the DVD menu

▶ Press the 🛨 back button.

or

▶ Select the corresponding menu item in the DVD menu and press (5) the COMAND controller to confirm.

or

- ▶ Select any menu item in the DVD menu and press (5) the COMAND controller to confirm.
- ► Select Go up and press (*) to confirm.

Back to the film

▶ Press the 🛨 back button repeatedly until you see the movie.

or

- ▶ Select the corresponding menu item from the DVD menu.
- ► Select the Back (to the movie) menu item in the menu and press (5) to confirm.



Setting the language and audio format

This function is not available on all DVDs. If it is available, you can set the DVD menu language, the audio language or the audio format. The number of settings is determined by the DVD content. It is possible that the settings may also be accessed in the DVD menu (> page 244).

- ► Press ⑤ the COMAND controller to show the menu.
- ► Select DVD-V in the menu by turning (○) the COMAND controller and press (to confirm.
- ► Select DVD Functions and press ⑤ to confirm.
- Select Audio Language and press to confirm.
 In both cases, a menu appears after a few seconds. The dot in front of an entry indicates the currently selected language.
- ➤ Select a setting by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- ► To exit the menu: slide ← ○→ the COMAND controller.

Subtitles and camera angle

These functions are not available on all DVDs. The number of subtitle languages and camera angles available depends on the content of the DVD. It is possible that the settings may also be accessed in the DVD menu (> page 244).

- ► Press ⑤ the COMAND controller to show the menu.
- ► Select DVD-V in the menu by turning 【◎】 the COMAND controller and press ⑤ to confirm.

- ► Select DVD Functions and press ⑤ to confirm.
- ▶ Select Subtitles or Camera angle and press ⑤ to confirm.
 In both cases, a menu appears. The dot in front of an entry indicates the current
- ► Select a setting by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- ► To exit the menu: slide ← () → the COMAND controller.

Interactive content

setting.

DVDs can contain interactive content (e.g. a video game). In a video game, for example, you may be able to influence events by selecting and triggering actions. The type and number of actions depend on the DVD.

- Select an action by sliding ↑ ↓ or ← → the COMAND controller and press ⑤ to execute it.
- A menu appears and the first entry, Select, is highlighted.
- ▶ Press ⑤ the COMAND controller.

AUX video mode

AUX jacks

An external video source (video AUX) can be connected to COMAND via the media interface (⊳ page 233) using the AUX jacks in the glove box.

1 In vehicles with a rear view camera, the video AUX jack cannot be used for external video sources.



Switching to video AUX mode

- ► Select Video in the main function bar by sliding **↑** ○ and turning **१** ○ **1** the COMAND controller and press (5) to confirm. If video AUX mode was the last mode selected, it will now be active. If another video source is switched on, you can now switch to video AUX mode in the
 - video menu
- ► Select Video and press ⑤ to confirm.
- ► Select AUX and press (5) to confirm. The video AUX menu appears. You will hear and see the content of the external video source if it is connected and switched to playback.

For details on how to operate the external video source, see the respective device's operating instructions.

Showing/hiding the menu

- ► To show: press 🔊 the COMAND controller
- ► To hide: slide ○ the COMAND controller and confirm Full screen by pressing .

Volume and sound settings

You will find details on volume (⊳ page 134) and sound (⊳ page 135) settings in the "At a glance" section.



↑ WARNING

External video sources may have different volumes, which can mean that system messages such as traffic announcements and navigation system announcements are much louder. If necessary, please deactivate the system messages or adjust their volume manually.

1 In some cases, the volume of the AUX device may be quieter or louder, or the usual maximum possible volume cannot be reached. On some devices, it is possible to adjust the volume separately. In this case, start at a medium volume and increase it

gradually. This enables you to determine whether the system is able to play the music at high volume without distorting it.

Rear Seat Entertainment System

General information

Important safety notes



♠ WARNING

The RSE CD/DVD player is a Class 1 laser product. There is a danger of invisible laser radiation when you open or damage the cover. Do not remove the cover. The RSE CD/DVD player does not contain any parts which can be serviced by the user. For safety reasons, have any necessary service work performed by qualified personnel.



♠ WARNING

The driver should not wear a Rear Seat Entertainment headset while operating the vehicle under any circumstances. The use of a headset while driving the vehicle could drastically impair the ability to react to audible traffic conditions (e.g. emergency sirens from police/fire/ambulance, another car's horn, etc.).



↑ WARNING

When not in use, headsets or external video sources should be stored in a safe location (e.g. one of the vehicle's storage compartments) so that they are not loose within the passenger compartment during braking, vehicle maneuvers or a traffic accident. Objects moving within the passenger compartment could cause serious personal injury to vehicle occupants.



↑ WARNING

Due to a potential choking hazard, wired headset usage by children should only occur with adult supervision.



Changing batteries

Batteries are required for the remote control and for the two sets of cordless headphones.


↑ WARNING

Keep the batteries out of the reach of children. Consult a doctor immediately if a child should swallow a battery. Do not dismantle, short-circuit or burn a battery.

Environmental note

Dispose of discharged batteries in an environmentally responsible manner.

On the remote control



- (1) Battery tray
- ② Catch tab
- ③ Battery tray cover

- 4 Retaining lugs
- (5) Batteries

The remote control contains 2 type AAA, 1.5 V batteries.

- ► To open the battery compartment: remove battery compartment cover (3) on the back of the remote control.
- ▶ To do so, press down retaining lug (2) and take off battery tray cover (3).
- ▶ Remove discharged batteries (5) from the tray.
- ▶ Insert the new batteries. Observe the polarity markings on the batteries and battery tray when doing so. Left-hand battery: the positive pole (+) must face upwards.

Right-hand battery: the positive pole (+) must face downwards.

► To close the battery compartment: insert battery compartment cover (3) starting with retaining lugs 4 into the battery compartment and allow catch tab (2) to engage in place.

On the cordless headphones

The battery compartment cover is located on the left headphone.



(1) Battery tray cover

The wireless headphones contain 2 type AAA, 1.5 V batteries.

► To open the battery compartment: flip battery compartment cover (1) upwards. As you do so, hold the left-hand side of the



headphones as shown to prevent the batteries from falling out.

- ► Remove the discharged batteries from the tray.
- ▶ Insert the new batteries. Observe the polarity markings on the batteries and battery tray when doing so. Left-hand battery: The positive pole (+) must face upwards.

Right-hand battery The positive pole (+) must face downwards.

➤ To close the battery compartment:

press battery compartment cover
downwards until it engages into place.

If the batteries have been inserted
correctly, the indicator lamp will light up
green when the headphones are switched
on.

Basic functions

Using headphones

Vehicles intended for sale in the USA are equipped with cordless headphones. Corded headphones are available for the Canadian and other markets.

You can use the cordless headphones supplied and/or up to two sets of corded headphones connected to the corresponding jack of the rear-compartment screens (> page 139).

You will find information on the following topics in the "Cordless headphones" section (> page 142).

- Switching the cordless headphones on/off
- Adjusting the volume of the headphones
- Selecting a screen for the headphones

Using the main loudspeakers

This function is available in conjunction with COMAND.

You can use the vehicle loudspeakers to listen to a disc inserted in the rear-compartment drive. To do so, at least one of

the rear-compartment screens must be set to disc mode.

- ► To set operation via the main loudspeakers: press the RADIO function button on the center console once or twice.
- ► Select Audio by sliding t the COMAND controller and press ७ to confirm.

 The Audio menu appears.
- ► Select Rear by turning () the COMAND controller and press () to confirm.
- 1 The headphones' volume setting does not affect the main loudspeakers.

Adjusting the sound settings

You can select the sound settings in the audio CD/DVD/MP3, video DVD and AUX modes.

- Switch on an audio operating mode (e.g. audio CD mode).
- ► Select Treble or Bass using the buttons on the remote control and press the button to confirm. An adjustment scale appears.
- ► Select a setting using the buttons and press the button to confirm.

Multiple users

Simultaneous use of the rearcompartment disc drive

The two rear-compartment screens can be operated almost entirely independently from one another. However, there can be a conflict in some menus if the two screens are used simultaneously.

If the rear-compartment disc drive is being used for both screens simultaneously, selecting certain menus or settings on one of the screens also affects the other screen.

The following functions affect both screens:

- · changing playback options
- selecting a track (from a track list or folder)
- using the play, pause and stop functions
- fast forwarding/rewinding or scrolling



- calling up the DVD menu and navigating within it
- setting the language, subtitles and camera angle
- calling up interactive DVD content The following functions affect only one screen:
- audio and video functions as well as picture settings
- switching between full screen and the menu

Switching between operating modes

When you exit an operating mode (e.g. audio CD mode), the current setting is saved. If you call up this operating mode again later, there are two possibilities:

- the operating mode has been changed on the other screen.
- the operating mode has not been changed. In the first case, the operating mode appears as it is on the other screen.

In the second case, the setting appears on the screen as it was when you last exited the operating mode.

Picture settings

Overview

You can select these settings in video DVD and AUX mode. Instructions for AUX mode are detailed later (▷ page 258).

Adjusting the brightness, contrast and color

- ► Switch on video DVD mode (▷ page 241).
- ▶ To show the menu: press the ⊚k button on the remote control.

or

- ► Select Menu while the navigation menu (▷ page 241) is shown and press the ⊚ button to confirm.
- ► In both cases, select Video DVD using the ▼ ▶ buttons and press the

 ok button to confirm.

- ► Select Brightness, Contrast, Color or Auto using the

 Two buttons and press
 to confirm.

 An adjustment scale appears.
- ► Select a setting using the buttons and press the button to confirm.

Changing the picture format

▶ To show the menu: press the ⊙ button on the remote control.

or

- Select Menu while the navigation menu (▷ page 241) is shown and press the ow button to confirm.
- ► Select Video DVD using the ▼ buttons and press the

 ok button to confirm.

The symbol in front of the Auto, 16:9 Optimized, 4:3 or Widescreen menu item indicates the format currently set.

► Select a format using the buttons and press the w button to confirm.

System settings

Note


You can adjust almost all system settings individually for each screen without affecting the other screen. You make these settings using the remote control.

Selecting the display language

▶ Select System using the ▲ ▼ buttons on the remote control and press the ⊛ button to confirm.

You see the system menu on the selected rear screen.





P82.87-4932-31

- ► Select Settings using the ▼ button and confirm with the ⊚k button.
- ▶ Select Language using the ▶ whittons and press the who button to confirm.

 The list of languages appears. The dot indicates the current setting.
- ▶ Select a language using the ▲ ▼ buttons and press the ⋈ button to confirm.

 The Rear Seat Entertainment System activates the respective language.

Switching the display design

- ► Select Settings using the ▼ button and confirm with the (ok) button.

The
icon indicates the current setting.

Design	Explanation
Day Mode	The display is set permanently to day design.
Night Mode	The display is set permanently to night design.
Automatic	The display design changes depending on the vehicle instrument cluster illumination.

Setting the brightness

- ► Select Settings using the ▼ button and confirm with the (or) button.
- ► Select Brightness using the
 buttons and press the
 button to confirm.
 A scale appears.
- ▶ Adjust the brightness using the ▲ ▼ buttons and press the ⊛ button to confirm. The brightness bar moves up or down. The picture becomes lighter or darker in accordance with the scale.

Showing/hiding the picture

- ► To hide the picture: select Display OFF in the system menu using the

 buttons on the remote control and press the
 button to confirm.

 The picture is hidden.
- ► To display the picture: press the ok button.

Audio CD/DVD and MP3 mode

Safety note

MARNING

The RSE CD/DVD player is a Class 1 laser product. There is a danger of invisible laser radiation when you open or damage the cover. Do not remove the cover. The RSE CD/DVD player does not contain any parts which can be serviced by the user. For safety reasons, have any necessary service work performed by qualified personnel.

General notes

You will find information on the following topics in the Audio section:

- notes on CDs/DVDs (> page 229)
- notes on MP3 mode (▷ page 228)
- notes on copyright (⊳ page 229)



Inserting a CD/DVD

The CD/DVD drive is located in the center behind the front seats.



- 1) Disc slot
- ② Eject button

The CD/DVD drive is a single disc drive. If there is already a disc inserted, this must be eiected before another is inserted.

▶ Insert a disc into the disc slot. The printed side of the disc must face upwards. If neither side of the disc is printed, the side you wish to play must face downwards.

The CD/DVD drive draws in the disc.



P82.87-5596-31

The CD/DVD drive plays the disc:

- if it has been inserted correctly and is a permissible disc, and
- after you have switched on disc mode (audio CD/audio DVD/MP3 mode)

Data on an MP3 CD first needs to be loaded by the drive. Loading may take some time, depending on the number of folders and tracks.

Removing a CD/DVD

- ▶ Press the △ eject button. The drive ejects the disc.
- ▶ Take the disc out of the slot. If you do not take the disc out of the slot, the drive will draw it in again automatically after a short while.

Switching to audio CD, audio DVD or MP3 mode

- ▶ Insert a CD/DVD (> page 251). The Rear Seat Entertainment System loads the inserted disc.
- ► Select Disc in the menu using the ▲ **| | |** buttons on the remote control and press the (ok) button to confirm. The corresponding mode is switched on. The Rear Seat Entertainment System plays the disc.
- 1 Variable bit rates in MP3 tracks can result in the elapsed time shown being different to the actual elapsed time.

Selects a track

Selecting by skipping to a track

► To skip forwards or backwards to a track: press the or button on the remote control.

or

▶ Press the 🖂 or 🕪 button. The skip forward function skips to the next track.

Skipping backwards restarts the current track (if it has been playing for more than eight seconds) or starts the previous track (if the current track has only been playing for a shorter time).

If you have selected the Track List Mix or Random Folder playback options, the track order is random.



Selecting by track list

In audio CD mode, the track list contains all tracks on the disc currently playing.

In audio DVD mode, the track list contains all tracks in the currently active group; see "Setting the audio format" (> page 227).

In MP3 mode, the track list shows all tracks in the currently active folder as well as the folder structure, allowing you to select any track on the MP3 CD.

► Select Track List (audio CD/DVD mode) or Folder (MP3 mode) using the ▼ ● buttons on the remote control and press the ⓒ button to confirm.

or

- Press the ox button when the display/ selection window is selected.
 The track list appears. The odot indicates the current track.
- ► Select a track using the ▲ or ▼ button and press the ∞ button to confirm.

Making a selection by entering the track number directly

► Press the 🗶 button on the remote control.

The track entry display appears.

Example: track 2

► Press the 2ABC number key.

Example: track 12

- ► Press the corresponding number buttons in rapid succession.
- 1 It is not possible to enter numbers that exceed the number of tracks on the CD or in the currently active folder.
- Wait for approximately three seconds after making the entry. You will hear the track which has been entered. The corresponding basic menu then reappears.

Fast forward/rewind

► With the display/selection window active, press the or button on the remote control repeatedly until you reach the desired position.

or

▶ Press and hold the 🖂 or ▶ы button until the desired position is reached.

Selecting a folder

This function is only available in MP3 mode.

► Select Folder in MP3 mode using the ▼ ▶ buttons on the remote control and press the ∞ button to confirm.

or

► Press the ox button when the display/ selection window is selected. The folder content appears.



P82.87-2516-31

- 1 Folder selection symbol
- ② Current folder name
- ③ Track symbol
- ► To switch to the superordinate folder: select icon ① using the ▲ ▼ buttons on the remote control and press the ⊛ button to confirm.

The display shows the next folder up.





P82.87-2517-31

- Folder selection symbol
- (2) Folder icon
- ▶ Select a folder using the or using the or using the button and press the wo button to confirm. You will see the tracks in the folder.
- ▶ Select a track using the ▲ or ▼ button and press the ∞ button to confirm. The track is played and the corresponding folder is now the active folder.

Pause function

This function is only available in audio DVD mode.

- ► To pause playback: select II using the ▼ ► buttons on the remote control and press the button to confirm.

 The II display changes to ►.

Stop function

This function is only available in audio DVD mode.

- To interrupt playback: select using the ▼ ▶ buttons on the remote control and press the ∞ button to confirm.

 The display changes to ▶.
- ► To stop playback: while playback is interrupted, select ☐ again and press the ⓒ button to confirm.

 Playback stops and returns to the beginning of the DVD. ☐ is highlighted.
- ► To restart playback: select ► and press the button to confirm. Playback starts from the beginning of the DVD.

Setting the audio format

Further information on audio formats is available in the "Audio" section (> page 227).

- ▶ Select DVD-A using the ▼ ▶ buttons on the remote control and press the ∞ button to confirm.

- ► To exit the menu: press the or ► button.

Playback options

Further information on playback options is available in the "Audio" section (> page 228).



- ► Select CD, DVD-A or MP3 using the ▼ buttons on the remote control and press the button to confirm. The options list appears. The dot indicates the option currently selected.

The option is switched on. All options except Normal Track Sequence will be indicated in the display/selection window.

If you change the disc, the Normal Track Sequence option is activated automatically. If an option is selected, it remains selected after the Rear Seat Entertainment System is switched on or off.

Switching track information on/off (MP3 mode only)

If the function is switched on, folder and track names are displayed.

If the function is switched off, disc and file names are displayed.

- ▶ Select MP3 using the ▼ buttons on the remote control and press the ∞ button to confirm.
- ► Select Show Track Information using the buttons and press the button to confirm.

The function is switched on $\mathbf{\nabla}$ or off \square , depending on the previous status.

Video DVD mode

General notes

Here you will find further information on the following topics:

- safety notes (▷ page 220)
- notes on DVDs (⊳ page 240)

DVD playback conditions

Playback problems may occur when playing copied discs. There is a large variety of discs, DVD authoring software, writing software and writers available. This variety means that there is no guarantee that the Rear Seat Entertainment System will be able to play video DVDs that you have copied yourself. You will find further information in the "Video" chapter (▷ page 241). Information regarding COMAND also applies to the Rear Seat Entertainment System.

Function restrictions

Depending on the DVD, it is possible that certain functions or actions described in this section will be temporarily blocked or may not function at all. As soon as you try to activate these functions or actions, you will see the Symbol in the display.

Inserting and removing a CD/DVD

▶ Proceed as described in the "Audio CD/ DVD and MP3 mode" section (▷ page 220).

Activating video DVD mode

▶ Insert a video DVD.

The Rear Seat Entertainment System loads the disc.

If disc mode was the last mode selected, it will now be active.

If it was not, switch on video DVD mode as described in the following instruction.


- ► Select Disc in the menu using the

 ▲ buttons on the remote control and press the w button to confirm. If the video DVD fulfills the playback criteria, the film either starts automatically or the menu stored on the DVD appears. If the DVD menu appears, you must start the film manually.
- ► Select the corresponding menu item in the DVD menu.



Hiding/showing the navigation menu

- ► To show: press the or button on the remote control.
- ► To hide: press the ▲ or ▼ button.
- ▶ Wait for approximately eight seconds.



P82.87-2518-31

Navigation menu


- 1 Data medium type
- (2) Current track
- (3) Current scene
- (4) Track time
- 5 To show the menu

Showing/hiding the menu

► To show: press the ⊙k button on the remote control.

or

- ► Select Menu while the navigation menu is shown and press the **(ok)** button to confirm.
- ► To hide: press the button and confirm Full Screen by pressing the button.



P82.87-5604-31

Menu system

- 1 Video DVD options
- Pause function
- 3 Stop function
- (4) To set the treble
- (5) To set the bass

Fast forward/rewind

▶ Press and hold the 🏻 or 🕞 button on the remote control until the desired position has been reached.

You see the navigation menu.

Pause function

► To show the menu: press the ⊚k button on the remote control.

10

- ► Select Menu while the navigation menu is shown and press the (ox) button to confirm.
- ► To pause playback: select II and press the ⊙ button to confirm. The II display changes to ►.



Stop function

▶ To show the menu: press the ⊙s button on the remote control.

or

- ► Select Menu while the navigation menu is shown and press the (or button to confirm.

- ► To stop playback: while playback is interrupted, select again and press the button to confirm.

 Playback stops and returns to the beginning of the DVD. is highlighted.
- ► To restart playback: select ► and press the ເ button to confirm.

 Playback starts from the beginning of the DVD.

Selecting a scene/chapter

Note

Further information on this function is available in the "Video" section (> page 243).

Skipping forwards/backwards

▶ Press the ◀ or ▶ button on the remote control.

or

► Press the Idal or IDAL button.

The control menu appears for approximately eight seconds.

Selecting a scene/chapter directly

The examples illustrate how to select scene/chapter 5.

- ▶ **Option 1:** while the film is playing, press the ★ button on the remote control.
- Press a corresponding number key, e.g. 5JKL.
- ▶ Option 2: while the film is playing, press the

 button on the remote control and show the menu.
- ► Select Video DVD and press the ⊚ button to confirm.
- ► Select DVD Functions and press the ok button to confirm.
- ► Select Scene Selection and press ⊚k to confirm.
- ▶ Press ▲ or ▼ to select number 5 and press the ⊛ button to confirm.
 In both cases, playback will begin from the fifth scene/chapter after a brief pause.

Selecting a film/title


Note

Further information on this function is available in the "Video" section (> page 243).

Option 1

- ▶ Press the ⊚ button on the remote control and show the menu.
- ► Select Video DVD and press the

 on the remote control to confirm.



P82.87-2520-31



- ► Select DVD Functions and press the ⊚k button to confirm.
- ► Select Title Selection and press ⊚ to confirm.
- ► To call up the selection list: press the OK button.
- ► Select a film/track.

Option 2:

Example: selecting film 2

► Press the 2ABC button.

After a brief pause, the second film is played.

DVD menu

Note

You will find further information on the DVD menu in the "Video" section (▷ page 240).

To call up the DVD menu

- ▶ Press the ⊙x button on the remote control and show the menu.
- ➤ Select Video DVD and press the ⊚k button on the remote control to confirm.
- ► Select DVD Functions and press the ⊚k button to confirm.
- ► Select Menu and press

 to confirm. The DVD menu appears.

Selecting menu items in the DVD menu

► Select a menu item using the

▲ ▼ ● buttons on the
remote control and press the

button to
confirm.

A menu appears.

 Menu items which cannot be selected are shown in gray.



P82.87-2521-31

- ▶ If available, additional options can now be selected.
 The Rear Seat Entertainment System then

switches back to the DVD menu.

Stopping a film or skipping to the beginning or end of a scene

- ► Select any menu item from the DVD menu. The menu appears.
- ► To stop the film: select the Stop menu item and press the s button on the remote control to confirm.
- ► To skip to the end of a scene: select the
 ►► menu item and press the
 ►► button to confirm.
- ► To skip to the beginning of a scene: select the <a> menu item and press the <a> button to confirm.

Moving up one level in the DVD menu

▶ Option 1: press the 🛨 back button on the remote control or select the corresponding menu item in the DVD menu.



- ▶ Option 2: select any menu item in the DVD menu.
- ► Select the Go up menu item in the menu and press the (or button to confirm.

Back to the film

- ▶ Option 1: press the 🔄 back button on the remote control repeatedly until you see the film or select the corresponding menu item in the DVD menu.
- ▶ Option 2: select any menu item in the DVD menu and press the (i) button to confirm.
- ▶ Select the Back (to the movie) menu item in the menu and press the ⊚ button to confirm.

Setting the audio format

This function is not available on all DVDs. If it is available, you can set the audio language or the audio format. The number of settings is determined by the DVD content. It is possible that the settings may also be accessed from the DVD menu.

- ▶ Press the ⊚ button on the remote control and show the menu.
- ► Select Video DVD and press the ⊚ button on the remote control to confirm.
- ► Select DVD Functions and press the ⊚k button to confirm.
- ► Select Audio Language and press the ⊚ button to confirm.

A menu appears after a short while. The

- dot in front of an entry indicates the currently selected language.
- ▶ Select a language using the ▲ or ▼ button and press the ♠ button to confirm.
- ► To exit the menu: press the or ► button.

Subtitles and camera angle

These functions are not available on all DVDs. The number of subtitle languages and camera angles available depends on the content of the DVD. It is possible that the settings may also be accessed from the DVD menu.

- ▶ Press the ⊚ button on the remote control and show the menu.
- ► Select Video DVD and press the ⊙ button on the remote control to confirm.
- ► Select DVD Functions and press the ⊚ button to confirm.
- ► Select Subtitles or Camera Angle and press the

 button to confirm.

 In both cases, a menu appears after a few seconds. The

 dot in front of an entry indicates the current setting.
- ► Select the setting using the a or button and press the button to confirm.
- ► To exit the menu: press the or ► button.

Interactive content

DVDs can also contain interactive content (e.g. a video game). In a video game, you may be able to influence events by selecting and triggering actions. The type and number of actions depend on the DVD.

- - A menu appears and the first entry, Select, is highlighted.
- ▶ Press the (oK) button.

AUX mode

Introduction

You can connect one external video source to each of the displays of the Rear Seat Entertainment System (AUX display) and also one external video source to the rear-seat CD/DVD drive (AUX drive) with a sound and video signal.



Please see the corresponding operating instructions for information on how to operate the external video source.

For further details about external video sources, please consult an authorized Mercedes-Benz Center.

Connecting AUX equipment

AUX drive

The AUX drive jacks are located on the CD/DVD drive on the right next to the CD/DVD eject button (> page 258).

Displaying AUX

The AUX display jacks are on the side of the screen (⊳ page 139).

Audio and video connection

- Insert the audio plugs for the left and right signals into the corresponding L and R jacks.
- ▶ Insert the video plug into the **V** jack.

Activating AUX mode

AUX drive

- ► Select AUX in the menu using the

 ■ buttons on the remote
 control and press the button to confirm.
 The AUX menu appears.
- ► Select Source from the AUX menu and press the ⓒ button to confirm.
- ► Select Disk Drive Aux and press the ⊚ button to confirm.

You will hear and see the content of the external video source if it is connected to the CD/DVD drive and switched to playback. If no video image is available from the AUX source connected, you will see an audio menu.

Displaying AUX

- ➤ Select the screen to which the external video source is connected using the remote control (▷ page 125).
- ► Select Source from the AUX menu and press the (ok) button to confirm.
- ► Select Display Aux and press the ok button to confirm.

You will see and hear the content of the video source if it is switched to playback. If no video image is available from the AUX source connected, you will see an audio menu.

Selecting the active COMAND source

- ► Select Source from the AUX menu and press the (ox) button to confirm.
- ► Select COMAND and press the ⊙ button to confirm.

The audio or video mode selected in COMAND is transmitted to the Rear Seat Entertainment System.

Operation with an active COMAND source

You can transfer an audio or video mode selected in COMAND to the Rear Seat Entertainment System.

- 1 If you subsequently switch modes in COMAND, the new source will not be transmitted to the Rear Seat Entertainment System.
- ► To switch on the function in COMAND: switch on the desired audio mode in COMAND or show the menu in video DVD mode.
- ▶ Select the menu item at the bottom left, e.g. CD in audio CD mode, by sliding ○ •



and turning $\P \bigcirc \P$ the COMAND controller and press \P to confirm.

- ► Select Active Source for Rear and press ⑤ to confirm.
 - In the status bar at the top, you will see the headphones icon and the concording icon for the source that has been switched on.
- ► To switch off the function in COMAND: switch on the desired audio mode in COMAND or show the menu in video DVD mode.
- ► Select the menu item at the bottom left, e.g. CD in audio CD mode, by sliding ↓ and turning 【○ 】 the COMAND controller and press ⑤ to confirm.
- ► Select Rear OFF® and press ® the COMAND controller to confirm.

Adjusting the brightness, contrast or color

- ► Select Source in the rear-compartment screen and press the (button on the remote control to confirm.
- ► Select Brightness, Contrast or Color and press the ⊚ button to confirm.

 An adjustment scale appears.
- ► Select a setting using the or button and press the button to confirm.

Changing the picture format

- ► Select Source in the AUX menu and press the ox button on the remote control to confirm.
- ► Select Display Aux or Disk Drive Aux and press the **(a)** button to confirm.

Vehicle

Vehicle functions


General notes

In this menu, you can set the following vehicle functions:

- ECO
- multicontour seat settings
- · rear window blind
- EASY-ENTRY/EXIT feature
- · exterior lighting delayed switch-off
- · interior lighting delayed switch-off
- ambient lighting
- automatic folding mirror
- · locator lighting
- · automatic locking feature
- trunk lid opening height restriction

You can open the "Vehicle" menu in one of two ways.

Opening the "Vehicle" menu from the main area in the center of the display



- P82.87-3144-3
- (1) "Vehicle" menu item
- (2) Main area
- Select Vehicle in the main function bar by sliding ←⊙→ and turning 【○】 the COMAND controller and press ⑤ to confirm.
 - Main area (2) is active.
- Select the individual vehicle functions by sliding ← ○ → or turning 【 ○ 】 the COMAND controller and press ⑤ to confirm.



Opening from the "Vehicle" menu

TA	ECO Off	4
Navi	Multi-function contour seat settings	Ī
ECC	Rear window blind Extended	l
	Easy entry/exit Off	l
	Exterior lighting delayed switch-off 0 secs.	l
4	Interior lighting delayed switch-off 0 secs.	l
	Ambient lighting SOLAR 1	l
Syste	□ Automatic mirror folding	l
LO	□ Locator lighting	

P82.87-5561-31

► Select Vehicle in the main function bar by sliding ← ⊙ → and turning **(** ⊙ **)** the COMAND controller and press (5) to confirm.

The "Vehicle" submenu opens.


▶ Select the individual vehicle functions in the menu by sliding ← ○ → or turning 【 ○ 】 the COMAND controller and press (5) to confirm.

In the next section, it is the first procedure that is always described.

Switching the ECO function on/off

The ECO start/stop function switches the engine off automatically if the vehicle is stopped under certain conditions. When pulling away again, the engine starts automatically (> page 306). You can switch the ECO start/stop function on and off using COMAND.

If you switch the ECO start/stop function off using COMAND, the function is switched on again automatically when you switch the ignition off and on again.



► To switch the ECO start/stop function on/off: select Vehicle in the main function bar by sliding +⊙ + and turning **t**⊚**5** the COMAND controller and press to confirm.


The main area is active.

► Select the ECO function by sliding + ⊙ → or turning () the COMAND controller and press 🖲 to confirm.

The ECO start/stop function is switched on and off alternately.

Extending/retracting the rear window blind

- Make sure that the rear window blind can move freely. Otherwise, the blind or other objects could be damaged.
- 1 The rear window blind is deactivated at temperatures below -20 °C.



► To extend/retract the rear window **blind:** select Vehicle in the main function bar by sliding ←⊙→ and turning **(**⊙**)** the




COMAND controller and press **(*)** to confirm.

The main area is active.

► Select the Rear Window Sunshade function by sliding ← ○→ or turning 【 ○】 the COMAND controller and press ⑤ to confirm.

Activating/deactivating the automatic folding mirror function

In the Automatic Mirror Folding menu, you can set the exterior mirrors so that they automatically fold in when the vehicle is locked.



► To activate/deactivate automatic mirror folding: select Vehicle in the main function bar by sliding ← ○ → and turning 【 ○ 】 the COMAND controller and press to confirm.

The main area is active.

Select the Automatic Mirror Folding function by sliding ←⊙→ or turning 【○】 the COMAND controller and press ⑤ to confirm.

Setting the EASY-ENTRY/EXIT feature

↑ WARNING

Make sure that nobody can become trapped when you activate the EASY-ENTRY/EXIT feature.

If there is a risk of entrapment by the steering column, move the steering wheel adjustment


lever or press the position button of the memory function.

If there is a risk of entrapment by the seat, you can also cancel the adjustment procedure by moving the switch for seat adjustment. The steering column and driver's seat stop moving immediately.

Never leave children unsupervised in the vehicle. They could open the driver's door and thereby unintentionally activate the EASY-ENTRY/EXIT feature and become trapped.

You can make a setting in COMAND so that the steering wheel swings upwards and/or the driver's seat moves backwards before you get into the vehicle. You can make the following settings:

- OFF: the function is switched off.
- Steering Column: the steering wheel swings upwards.
- Steering Column and Seat: the steering wheel swings upwards and the driver's seat moves backwards.



➤ To set the EASY-ENTRY/EXIT feature: select Vehicle in the main function bar by sliding ← ○ → and turning 【 ○ 】 the



COMAND controller and press (5) to confirm.

The main area is active.

dot.

- ► Select the Easy-Entry/Exit Feature menu by sliding ←⊙→ or turning 【⊙】 the COMAND controller.
 - The EASY-ENTRY/EXIT feature menu. appears. The current setting is indicated by
- ► Select **Setting** by sliding ○ or turning **♦** The COMAND controller. The selected setting is indicated by a •

Setting the interior/exterior lighting delayed switch-off time

Interior lighting: you can set whether and for how long you wish the interior lighting to remain on in the dark after you have removed the SmartKey from the ignition lock.

Exterior light: you can set whether and for how long you want the exterior lighting to remain on in the dark after the doors have been closed. The exterior lighting automatically switches off after the switch-off delay has elapsed.

You may select from the following settings:

- 0 seconds: delayed switch-off is deactivated.
- 15, 30, 45, 60 seconds: delayed switch-off is activated.
- 1 You can reactivate this function by opening a door within one minute. If none of the doors are opened after the SmartKey is removed from the ignition lock or if a door is not closed after it has been opened, the exterior lights switch off after 60 seconds.



P82.87-3124-31

- ▶ To set the interior/exterior lighting delayed switch-off time: select Vehicle in the main function bar by sliding ← ⊙ → and turning () the COMAND controller and press (5) to confirm.
 - The main area is active.
- ▶ Select the Interior Lighting Delayed Shut-off/Exterior Lighting Delayed Shut-off menu by sliding or turning () the COMAND controller.

The interior/exterior lighting delayed switch-off time menu appears. The current setting is indicated by a • dot.

► Select **Setting** by sliding • ○ • or turning **C** ○ **5** the COMAND controller.


The selected setting is indicated by a • dot.

Setting the ambient light

You can make the following settings:

- SOLAR (yellow interior lighting)
- **NEUTRAL** (white interior lighting)
- POLAR (blue interior lighting)
- Brightness of the interior lighting on a scale of 0 (off) to 5 (bright)





- ► To set the ambient lighting: select Vehicle in the main function bar by sliding ← → and turning 【 】 the COMAND controller and press ⑤ to confirm.

 The main area is active.
- ► Select the Ambient Lighting menu by sliding ← → or turning (○) the COMAND controller.
 - The ambient lighting menu appears. The current setting is indicated by a dot.
- ➤ Select **Setting** by sliding ★ ↓ or turning ↓ ↓ the COMAND controller.


 The selected setting is indicated by a dot.

Switching locator lighting on/off

If you switch on the locator lighting, the following come on in the dark after you have unlocked the vehicle using the remote control:

- the parking lamps
- the tail lamps
- the license plate lamp
- the front fog lamps
- the entry lamps in the exterior mirror

The locator lighting switches off again when you open the driver's door. If you do not open the driver's door, the locator lighting switches off automatically after 40 seconds.




- ► To switch locator lighting on/off: select Vehicle in the main function bar by sliding ← ○ → and turning 【 ○ 】 the COMAND controller and press ② to confirm. The main area is active.
- ► Select the Locator Lighting function by sliding ← → or turning 【 】 the COMAND controller and press ⑤ to confirm.

Switching the automatic locking feature on/off

You can use this function to activate or deactivate the automatic central locking feature. If the automatic locking feature is activated, your vehicle will lock centrally from a speed of approximately 15 km/h.

You will find further information about the automatic locking feature in the "Automatic locking feature" section (▷ page 86).



► To switch the automatic locking feature on/off: select Vehicle in the main function bar by sliding ← → and



turning $\P \bigcirc \P$ the COMAND controller and press \P to confirm.

The main area is active.

► Select the Automatic Locking function by sliding ← ○ → or turning 【 ○ 】 the COMAND controller and press ⑤ to confirm.

Activating/deactivating the trunk lid opening height restriction



- ► To activate/deactivate the trunk lid opening height restriction: select Vehicle in the main function bar by sliding → and turning () the COMAND controller and press () to confirm.

 The main area is active.
- ► Select the Trunk Opening-height
 Restriction function by sliding ← → or
 turning 【 】 the COMAND controller and
 press ⑤ to confirm.

Automatic climate control

Introduction to automatic climate control

You can operate automatic climate control using COMAND or the buttons on the upper section of the center console (▷ page 291). Several special automatic climate control functions can only be adjusted using COMAND.

You can access the automatic climate control menu via the air-conditioning function bar.

To do so, make certain that the SmartKey is in position 2 in the ignition lock.



P82.87-2748-31

Air-conditioning function bar

- 1 To set the temperature, left
- ② To set the air distribution, left
- (3) To set the airflow, left
- 4 Climate control main menu(▷ page 266)
- (5) To set the airflow, right
- (6) To set the air distribution, right
- 7) To set the temperature, right

Setting the temperature

You can set the temperature separately for the driver's and front-passenger side.

► Select left temperature display ① or right temperature display ⑦ in the air-conditioning function bar by turning 【◎】 the COMAND controller and press ⑧ to confirm.



P82.87-2749-31



- ► To adjust the temperature: slide + + or turn (○) the COMAND controller.
- ► To confirm the selection: press 🔊 the COMAND controller.

Setting the air distribution

You can set the air distribution separately for the driver's and front-passenger side.

Select left air distribution ② or right air distribution ⑥ by turning 【◎】 the COMAND controller and press ⑤ to confirm.




- Directs air through the defroster vents

 Directs air through the center and side
 air vents
- Directs air through the footwell vents
- Directs air through the center, side and footwell vents
- Directs air through the defroster and footwell vents
- Directs air through the defroster, center, side and footwell vents
- Directs air through the defroster, center and side air vents
- Controls air distribution automatically
- ► To adjust the air distribution: turn () the COMAND controller.
- ► To confirm the selection: press 🐿 the COMAND controller.

Setting the airflow

You can set the airflow separately for the driver's and front-passenger side.

Select left airflow ③ or right airflow ⑤ by turning 【◎】 the COMAND controller and press ⑤ to confirm.



- ► To adjust the airflow: slide + + or turn
 (○) the COMAND controller.
- ► To confirm the selection: press 🔊 the COMAND controller.


Climate control main menu

COMAND allows you to set additional functions which cannot be selected using the control panel in the center console. Call up these functions using the climate control main menu.

➤ To open the climate control main menu: select the AC climate control symbol in the air-conditioning function bar by turning (○) the COMAND controller and press (○) to confirm.

The climate control menu opens.





Climate control main menu

You can:

- · switch cooling with dehumidification on or off (Acoff)
- control climate control centrally (Mono)
- adjust the Footwell Temperature
- set the Airflow for the air vents
- operate the Rear air conditioning from the front

Switching cooling with air dehumidification on/off

Cooling is operational when the engine is running, and cools according to the selected interior temperature for the vehicle. Cooling also dehumidifies the air inside the vehicle and, thereby, prevents the windows from fogging up.

↑ WARNING

If you switch off cooling with dehumidification, the vehicle will not be cooled and the air not dehumidified in warm weather conditions. The windows can mist up faster. This could result in your no longer being able to observe the traffic conditions properly and you may cause an accident.

- 1 Condensation may collect on the underside of the vehicle when the cooler is operating.
- ▶ Select the climate control main menu in the air-conditioning function bar by turning

- **♦** the COMAND controller and press to confirm.
- The climate control menu opens.
- ► To switch on: select Acoff and press .
- ► To switch off: select Acoff and press . A tick appears.



Controlling climate control centrally

You can use the Mono function to set all the air-conditioning zones in the vehicle to the same settings. If the Mono function is switched on and you adjust climate control on the driver's side, these changes will also be made in all the air-conditioning zones.

- ▶ Select the climate control main menu in the air-conditioning function bar by turning
- the COMAND controller and press
- (b) to confirm.

The climate control menu opens.

► Select Mono and press 🔊. A tick appears when the function is selected.



The Mono function is automatically switched off if you:



- change settings for automatic climate control on the front-passenger side using COMAND
- press one of the rocker switches to operate automatic climate control on the frontpassenger side
- press one of the rocker switches on the rear-compartment control panel

Adjusting the footwell temperature


You can use the Footwell Temperature function to set the temperature difference between the footwell and the rest of the vehicle interior.

1 This setting is quite effective in automatic mode, especially at low outside temperatures.

The greater the value you set, the higher the temperature in the footwell.

- Select the climate control main menu in the air-conditioning function bar by turning () the COMAND controller and press
 to confirm.
 - The climate control menu opens.
- ► Select Footwell Temperature and press .

A scale appears.



- ► To change the temperature difference:
- slide ↑ ↓ or turn 【 】.
- ► To confirm your selection: press 🔊.

Setting the blower settings for the air vents

This function allows you to determine the way the air is blown through the air vents in automatic mode.


You can select:

- Focused (high blower setting)
- Medium (standard setting)
- Diffuse (low blower setting)
- 1 This setting is quite effective in automatic mode, especially at high outside temperatures.

If the vehicle has become very warm and the automatic air conditioning is cooling the interior, the blower settings are briefly canceled.

- ► Select the climate control main menu in the air-conditioning function bar by turning
 - the COMAND controller and press to confirm.
 - The climate control menu opens.
- ► Select Airflow and press ⑤.
 A menu appears.

The current setting is indicated by a • dot.



P82.86-8840-31

- ► To change the airflow: slide t ↓ or turn
 (○).
- ► To confirm your selection: press 🐿.

Operating the rear-compartment airconditioning system from the front

The rear-compartment air-conditioning system is operated in the same way as



climate control for the driver and front passenger.

Switching on operation of the rearcompartment air conditioning from the front

The climate control menu opens.


Select Rear نونر and press .

Rear appears in the main menu on the airconditioning function bar. The rearcompartment air-conditioning system can
be controlled from the front.

Main menu for the rear-compartment airconditioning system

In the main menu for the rear-compartment air-conditioning system, you can:

- switch back to front-compartment climate control operation
- switch off the rear-compartment air conditioning
- switch automatic mode for the rearcompartment air conditioning on/off
- ➤ To open the main menu: select the climate control main menu in the air conditioning function bar and press .



The current setting is indicated by a • dot.

To switch back to operation of the rearcompartment air-conditioning system from the front:

► In the climate control main menu, select Front Climate Control and press ⑤. The air-conditioning function bar shows the climate control settings for the driver and front passenger.

To switch off the rear-compartment air conditioning:

► In the climate control main menu, select Rear Climate Control OFF and press ⑤.

To switch on automatic mode for the rearcompartment air conditioning:

► In the climate control main menu, select Rear Automatic and press ⑤.

Automatic mode for the rear-compartment air-conditioning system is switched on.

Seats

Lumbar supports

The lumbar support in the backrest of the driver's and front-passenger seats can be adjusted to provide optimum support for your back.

► To select the seat: press the function button.

The main area of the COMAND display is active. A scale appears.



P82.87-2841-31



- ▶ To move to the lower menu bar: select by sliding t the COMAND controller and press 🔊 to confirm.
- **1** When you press the function button, the previously adjusted seat is active.
- ► To adjust the lumbar support: select by sliding ← → or turning 【 】 the COMAND controller and press ⑤ to confirm.

Multicontour seat

1 Information about the components and operating principles of COMAND can be found on (⊳ page 118).

The contour of the driver's seat and frontpassenger seat backrests can be individually adjusted to provide optimum support for your back. This is achieved by controlling the pressure in the air chambers in the multicontour seat.

The adjustments are made using the COMAND display.

When you adjust the multicontour seat, you may hear the air being pumped in or released.

You can adjust the following air cushions:

- seat side bolsters
- · seat backrest side bolsters
- backrest curvature in the lumbar region
- backrest curvature in the upper back region
- ▶ Make sure that the SmartKey is in position2 in the ignition lock.
- ▶ Press the <a> function button.

Selecting the seat

You must first select the seat for which you wish to make adjustments.

- ► Press the function button. The main area is active.
- ▶ To move to the lower menu bar: select by sliding t ○ the COMAND controller and press (*) to confirm.



P82.87-2842-31

➤ To select a seat: select by sliding ← ○ → or turning 【 ○ 】 the COMAND controller and press ⑤ to confirm.

Exiting a menu

There are several ways of exiting the menu for the multicontour seat:

▶ Press the <a> function button again.

or

▶ Press any function button.

or

 Select another main function from the basic menu.

Display values

Two values are displayed on the setting scale if you adjust the multicontour seat:

- red: this is the desired value which you specify when making the setting.
- white: this is the current value. It is changed gradually until it reaches the desired value.

Adjusting the seat side bolsters

This function allows you to adjust the air cushions in the seat side bolsters.

- ► Select the seat (▷ page 270).
- Select Seat Sides by sliding ← → or turning 【 ○ 】 the COMAND controller and press ⑤ to confirm.
 A scale appears.






Adjusting the seat backrest side bolsters

This function allows you to adjust the air cushions in the seat backrest side bolsters.

- ► Select the seat (> page 270).
- Select Seatb. Sides by sliding ← → or turning 【 】 the COMAND controller and press ⑤ to confirm.
 A scale appears.



Select Setting by sliding ↑ ○ ↓ or turning
 ↓ ○ ↓ the COMAND controller and press
 to confirm.


Adjusting the backrest curvature in the lumbar region

This function allows you to adjust the air cushions in the lumbar region of the backrest.

- ► Select the seat (> page 270).
- Select Lumbar by sliding ←⊙→ or turning
 the COMAND controller and press
 to confirm.

A crosshair appears. You can make two settings:

- **Vertical:** to move the point of greatest lumbar support up or down
- Horizontal: to adjust the amount of support



P82.87-3169-31

➤ Select **Setting** by sliding • ○ • or turning • ○ • the COMAND controller and press • to confirm.

Adjusting the backrest curvature in the upper back region

This function allows you to adjust the air cushions in the upper back region of the backrest.

- ► Select the seat (> page 270).
- Select Shoulders by sliding ← → or turning () the COMAND controller and press) to confirm.

A scale appears.





Resetting adjustments

You can reset the seat settings to the factory settings.

- ▶ Select the seat (▷ page 270).
- ➤ Select Reset All by sliding ← → or turning (○) the COMAND controller and press (●) to confirm.

Active multicontour seat

The dynamic function of the active multicontour seat automatically adapts the side bolsters of the backrest to your current driving style.

- ▶ Select the seat (▷ page 270).
- Select Dynamic Seat by sliding ← ○→ or turning (○) the COMAND controller and press (○) to confirm.
- ► To confirm your selection: press . A scale appears.

You can select:

- 0: Off
- 1: Level 1
- 2: Level 2



P82.87-3173-31

Select Setting by sliding ↑ ○ ↑ or turning
 ↑ the COMAND controller and press
 ★ to confirm.

Massage function (PULSE)


The massage function helps you to prevent muscle tension on long journeys.

- ► Select the seat (> page 270).

A list appears.

You can select different types of massage function:

- 0: OFF
- 1: Slow and Gentle
- 2: Slow and Vigorous
- 3: Fast and Gentle
- 4: Fast and Vigorous
- ► To confirm your selection: press 🔊.



P82.87-3175-31



Select Setting by sliding ↑ ○ ↑ or turning
 ↑ the COMAND controller and press
 ★ to confirm.

The massage function runs for approximately 6 to 20 minutes, depending on the setting.

Uploading/downloading data

With this function, you can transfer COMAND data from one system (vehicle) to another system (vehicle). You can use either a USB stick or an SD card as temporary storage.

You can only transfer the complete transferable data record.

The following data is included in the complete transferable data record:

- navigation destination memory and last destination
- · address book entries
- audio station/video channel presets
- · system settings

Display
Time
Text reader
Linguatronic
Language
Favourites butto
Bluetooth
Upload/downloa
Reset
Copy data to storage medium
Import data from storage medium

P82.87-3345-31

Copying data to a storage medium

- ► Insert an SD card into the SD card slot or
- ► Insert a USB stick into the socket on the side in the glove box.
- ► Select Vehicle in the main function bar by turning 【○】 the COMAND controller and press ⑤ to confirm.
 - The "Vehicle" menu appears.
- ► Select System and press ⑤ to confirm.

- ► Select Upload/Download Data and press ⑤ to confirm.
- ► Select Copy Data to Storage Medium and press ⑤ to confirm.
- ► Select the storage medium to which the data should be copied.
- ➤ Select Start Copying.

 COMAND checks whether the storage medium has enough storage capacity. If there is enough storage capacity, the data is copied to the storage medium.
- ► If there is not enough storage capacity, remove the storage medium. Make more storage space available on the storage medium. Then, try to copy the COMAND data to the storage medium again.
- ▶ Remove the storage medium.

Transferring data to another system (vehicle)

- Insert/connect the storage medium (SD card or USB stick) with the saved data into/to the relevant interface.
- ► Select Vehicle in the main function bar by turning 【◎】 the COMAND controller and press ⑤ to confirm.

The "Vehicle" menu appears.

- ► Select System and press ⑤ to confirm.
- ► Select Upload/Download Data and press ⑤ to confirm.
- ► Select Import Data from Storage Medium and press ⑤ to confirm.
- ► Select Start Data Import.

 A prompt appears, asking whether the COMAND data should be overwritten.
- Press Yes to confirm that the data saved in COMAND should be overwritten.
 COMAND imports the data and restarts the system.

or

▶ Press No to cancel the import process.





Useful information	
Exterior lighting	
Interior lighting	28
Replacing bulbs	28
Windshield winers	



Useful information

- This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions.
- Please read the information on qualified specialist workshops (> page 31).

Exterior lighting

Important safety notes

For reasons of safety, Mercedes-Benz recommends that you drive with the lights switched on even during the daytime. In some countries, operation of the headlamps varies due to legal requirements and self-imposed obligations.

Information about driving abroad

Converting to symmetrical low beam when driving abroad: switch the headlamps to symmetrical low beam in countries in which traffic drives on the opposite side of the road to the country where the vehicle is registered. This prevents glare to oncoming traffic. Symmetrical lights do not illuminate as large an area of the edge of the road.

Have the headlamps converted at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center, as close to the border as possible before driving in these countries.

Converting to asymmetrical low beam after returning: have the headlamps converted back to asymmetrical low beam at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center, as soon as possible after crossing the border again.

Light switch

Operation

Depending on the date of manufacture of your vehicle, the **A** or **AUTO** symbol for the automatic headlamp mode/daytime running lamps is located on the light switch.



- 1 +P Left-hand standing lamps
- 2 P ← Right-hand standing lamps
- 3 0 Lights off/daytime running lamps
- 4 Automatic headlamp mode/daytime running lamps
- Parking lamps, license plate and instrument cluster lighting
- 6 D Low-beam/high-beam headlamps
- 7 D Front fog lamps 11
- 8 0 Rear fog lamp

The turn signals, high-beam headlamps and the high-beam flasher are operated using the combination switch (▷ page 279).

Switch off the parking lamps and standing lamps when you leave the vehicle. This prevents the battery from discharging.

The exterior lighting (except the parking/ standing lamps) switches off automatically if you:

- remove the SmartKey from the ignition lock
- open the driver's door with the SmartKey in position 0

If you hear a warning tone when you leave the vehicle, the lights may still be switched on.

 $^{{11 \}atop \text{Only vehicles with Bi-Xenon headlamps without the Intelligent Light System are equipped with front fog lamps.}$



- ► Turn the light switch to **0** or **A**. or
- ▶ If the rear fog lamp is switched on: press the light switch in to the stop.

Low-beam headlamps

- ➤ To switch on the low-beam headlamps: turn the SmartKey in the ignition lock to position 2 or start the engine.
- ► Turn the light switch to ☑.

 The ☑. indicator lamp on the light switch lights up.
- ► To switch off the low-beam headlamps: turn the light switch to ______.

Daytime running lamps

Daytime running lamps in Canada

The daytime running lamps function is required by law in Canada. It cannot therefore be deactivated.

► Turn the light switch to **0** or **A**. With the engine running: depending on the ambient light, the daytime running lamps or the low-beam headlamps are switched on. When the low-beam headlamps are activated, the [500€] indicator lamp on the light switch lights up.

When the engine is running and the vehicle is stationary or if the electronic parking brake is applied: if you move the selector lever from a drive position to **P**, the daytime running lamps/low-beam headlamps go out after three minutes.

When the engine is running, the vehicle is stationary and in high ambient light brightness: if you turn the light switch to [300], the daytime running lamps and the parking lamps are switched on.

If the engine is running and you turn the light switch to , the manual settings take precedence over the daytime running lamps.

Daytime running lamps in the USA

In the USA, the daytime running lamps are deactivated upon delivery from the factory.

- ► To activate the daytime running lamps: activate the daytime running lamps function in the on-board computer (> page 385).
- ► Turn the light switch to **0** or **A**. With the engine running: depending on the ambient light, the daytime running lamps or the low-beam headlamps are switched on. When the low-beam headlamps are activated, the 500 indicator lamp on the

If the engine is running and you turn the light switch to \bigcirc or \bigcirc , the manual settings take precedence over the daytime running lamps.

Automatic headlamp mode

light switch lights up.

► To switch on automatic headlamp mode: turn the light switch to A.

SmartKey in position 1 in the ignition lock: the parking lamps are switched on or off automatically depending on the brightness of the ambient light.

With the engine running: depending on the brightness of the ambient light, the daytime running lamps ¹² or the parking lamps and low-beam headlamps are switched on or off automatically.

When the low-beam headlamps are switched on, the [505] indicator lamp on the light switch lights up.



If the light switch is set to A, the low-beam headlamps will not come on automatically if it is foggy. This could endanger you and others. Therefore, turn the light switch to

In fog.

¹² Only if daytime running lamps have been activated via the on-board computer.



The automatic headlamp feature is only an aid. The driver is responsible for the vehicle's lighting at all times.

♠ WARNING

When it is dark or foggy, turn the light switch quickly from A to D. Otherwise, the headlamps could switch off temporarily and you could cause an accident.

Front fog lamps

MARNING

If you suspect that driving conditions will be foggy, turn the light switch to D before you start your journey. Otherwise, your vehicle may not be visible and you could endanger vourself and others.

↑ WARNING

In low ambient lighting or foggy conditions, only switch from position A to W with the vehicle at a standstill in a safe location. Switching from A to D will briefly switch off the headlamps. Doing so while driving in low ambient lighting conditions may result in an accident.

- ▶ To switch on the front fog lamps: turn the SmartKey in the ignition lock to position 2 or start the engine.
- ► Turn the light switch to or or light. If the light switch is set to **A**, you cannot switch on the fog lamps.
- ▶ Pull the light switch out to the first detent. The green indicator lamp on the light switch lights up.
- ► To switch off the front fog lamps: press the light switch in as far as it will go. The green indicator lamp on the light switch goes out.

Rear fog lamp

- ▶ To switch on the rear fog lamp: turn the SmartKey in the ignition lock to position 2 or start the engine.
- ► Turn the light switch to 🗊 or 💢 (vehicles with front fog lamps), or turn the light switch to (vehicles without front fog lamps). If the light switch is set to A, you cannot switch on the rear fog lamp.
- ▶ Turn the light switch to 🗊 . If the light switch is set to [505], you cannot switch on the rear fog lamp.
- ▶ Pull the light switch out to the second stop (vehicles with front fog lamps) or pull it out to the stop (vehicles without front fog lamps).

The yellow 0 indicator lamp on the light switch lights up.

▶ To switch off the rear fog lamp: press the light switch in as far as it will go. The yellow 0 indicator lamp on the light switch goes out.


Headlamp cleaning system

The headlamps are cleaned automatically if the "Wipe with washer fluid" function is operated ten times while the lights are on and the engine is running (▷ page 285). When you switch off the ignition, the automatic headlamp cleaning system is reset and counting is resumed from 0.



Combination switch

Turn signals



- 1 High-beam headlamps
- ② Right turn signal
- ③ High-beam flasher
- 4 Left turn signal
- ➤ To indicate briefly: press the combination switch briefly to the pressure point in the direction of arrow ② or ④.

The corresponding turn signal flashes three times.

► To indicate: press the combination switch beyond the pressure point in the direction of arrow ② or ④.

High-beam headlamps

- ➤ To switch on the high-beam headlamps: turn the SmartKey in the ignition lock to position 2 or start the engine.
- ► Turn the light switch to <a> □.
- ▶ Press the combination switch beyond the pressure point in the direction of arrow (1).

The indicator lamp in the instrument cluster lights up.

► To switch off the high-beam headlamps: move the combination switch back to its normal position.

The indicator lamp in the instrument cluster goes out.

High-beam flasher

- ► To switch on: turn the SmartKey in the ignition lock to position 1 or 2 or start the engine.
- ▶ Pull the combination switch in the direction of arrow (3).

Hazard warning lamps



The hazard warning lamps automatically switch on if:

- an air bag is deployed.
- the vehicle is slowed down severely from a speed of over 45 mph(70 km/h) and comes to a halt.
- ► To switch on the hazard warning lamps: press button ①.

All turn signals flash. If you now switch on a turn signal using the combination switch, only the turn signal lamp on the corresponding side of the vehicle will flash.

► To switch off the hazard warning lamps: press button (1).

The hazard warning lamps are deactivated automatically if the vehicle returns to a speed of over 6 mph(10 km/h) after a full application of the brakes.

1 The hazard warning lamps still operate if the ignition is switched off.



Cornering light function



The cornering light function improves the illumination of the road over a wide angle in the direction you are turning, enabling better visibility in tight bends, for example. It can only be activated when the low-beam headlamps are switched on.

Active:

- if you are driving at speeds below 25 mph (40 km/h) and switch on the turn signals or turn the steering wheel.
- if you are driving at speeds between 25 mph (40 km/h) and 45 mph (70 km/h) or turn the steering wheel.

Not active: if you are driving at speeds above 25 mph (40 km/h) or switch off the turn signal or turn the steering wheel to the straight-ahead position.

The cornering light function may remain lit for a short time, but is automatically switched off after no more than three minutes.

Adaptive Highbeam Assist

You can use this function to set the headlamps to change between low beam and high beam automatically. The system recognizes vehicles with their lights on, either approaching from the opposite direction or traveling in front of your vehicle, and consequently switches the headlamps from high beam to low beam.

The system automatically adapts the lowbeam headlamp range depending on the distance to the other vehicle. Once the system no longer detects any other vehicles, it reactivates the high-beam headlamps.

The system's optical sensor is located behind the windshield near the overhead control panel.





- ➤ To activate: activate the Adaptive Highbeam Assist function using the onboard computer (> page 386).
- ► Turn the light switch to 🔼.
- Press the combination switch beyond the pressure point in the direction of arrow ① (▷ page 279).

If it is dark and the light sensor activates the low-beam headlamps, the indicator lamp in the instrument cluster lights up.

If you drive faster than approximately 28 mph (45 km/h):

the headlamp range is set automatically depending on the distance between the vehicle and other road users.

If you drive faster than approximately 35 mph (55 km/h) and no other road users are identified:



the high-beam headlamps are switched on automatically. The Dindicator lamp in the instrument cluster also lights up.

When you drive slower than approximately 30 mph (45 km/h) or if other road users are identified or if the roads are sufficiently illuminated:

the high-beam headlamps are switched off automatically. The D indicator lamp in the instrument cluster goes out. The indicator lamp in the instrument cluster stays on.

► To deactivate: move the combination switch back to its normal position.

The indicator lamp in the instrument cluster goes out.

↑ WARNING

The Adaptive Highbeam Assist is only an aid intended to support you while driving. The driver is and remains responsible for proper vehicle lighting in accordance with the prevailing light, sight and traffic conditions.

The system may be impaired or unavailable when

- visibility is poor, e.g. due to snow, rain, fog, or heavy spray
- the optical sensor area of the windshield is dirty, fogged up, or covered by a sticker for example

The system cannot recognize the following road users:

- Road users without a lighting system of their own, e.g. pedestrians
- Road users with dim lighting of their own, e.g. cyclists
- Road users whose lighting is obstructed, e.g. road users behind a guardrail
- In some seldom cases, even road users with a lighting system of their own may be recognized too late or not at all.

The automatic high-beam headlamps will then not be deactivated or it will be activated in spite of preceding or oncoming road users.

This could endanger you and/or others and cause an accident. Always pay close attention to the traffic situation and switch off the high beam manually if necessary.

Headlamps fogged up on the inside

The headlamps may fog up on the inside if there is high atmospheric humidity.


► Drive with the headlamps switched on. The level of moisture diminishes, depending on the length of the journey and the weather conditions (humidity and temperature).

If the level of moisture does not diminish:

► Have the headlamps checked at a qualified specialist workshop.

Interior lighting

Overview of interior lighting



Front overhead control panel

- ① Switches the left-hand reading lamp on/off
- ② Switches the rear interior lighting on/off
- Switches the front interior lighting on/off
- Switches the automatic interior lighting control on/off
- Switches the right-hand reading lamp on/off





Rear-compartment overhead control panel

- Reading lamp
- ② Press T consecutively: to switch the reading lamp and interior lighting on to switch only the reading lamp on to switch the reading lamp off
- (3) Interior lighting

Interior lighting control

Important notes

In order to prevent the vehicle's battery from discharging, the interior lighting functions are automatically deactivated after some time except for when the SmartKey is in position 2 in the ignition lock.

Automatic interior lighting control

▶ To switch on/off: press the button. The OFF indicator lamp shows whether the automatic interior lighting control is deactivated (indicator lamp on) or activated (indicator lamp off).

The interior lighting automatically switches on if you:

- · unlock the vehicle
- · open a door
- remove the SmartKey from the ignition lock

The interior light is activated for a short while when the SmartKey is removed from the ignition lock. You can activate this delayed switch-off using COMAND (⊳ page 263).

Manual interior lighting control

- ▶ To switch the front interior lighting on/ off: press the 🔀 button.
- ▶ To switch the rear interior lighting on/ off: press the 🛅 button.
- ▶ To switch the reading lamps on/off: press the Yambutton.

Replacing bulbs

Important safety notes

Xenon bulbs

If your vehicle is equipped with Xenon bulbs, you can recognize this by the following: the cone of light from the Xenon bulbs moves from the top to the bottom and back again when you start the engine. For this to be observed, the lights must be switched on before starting the engine.

↑ DANGER

Xenon bulbs carry a high voltage. You could get an electric shock and be seriously or even fatally injured if you touch the electric contacts on Xenon bulbs. Therefore, never remove the cover from Xenon bulbs.

Do not change Xenon bulbs yourself, but have them replaced at a qualified specialist workshop which has the necessary specialist knowledge and tools to carry out the work required.

Mercedes-Benz recommends that you use an authorized Mercedes-Benz Center for this purpose. In particular, work relevant to safety or on safety-related systems must be carried out at a qualified specialist workshop.

Bulbs and lamps are an important aspect of vehicle safety. You must therefore make sure that these function correctly at all times. Have the headlamp setting checked regularly.



Other bulbs

There are bulbs other than the Xenon bulbs that you cannot replace. Replace only the bulbs listed (▷ page 283). Have the bulbs that you cannot replace yourself changed at a qualified specialist workshop.

Mercedes-Benz recommends that you use an authorized Mercedes-Benz Center for this purpose. In particular, work relevant to safety or on safety-related systems must be carried out at a qualified specialist workshop.

If you require assistance changing bulbs, consult a qualified specialist workshop.

Do not touch the glass tube of new bulbs with your bare hands. Even minor contamination can burn into the glass surface and reduce the service life of the bulbs. Always use a lint-free cloth or only touch the base of the bulb when installing.

Only use bulbs of the correct type.

If the new bulb still does not light up, consult a qualified specialist workshop.

Bulbs and lamps are an important aspect of vehicle safety. You must therefore make sure that these function correctly at all times. Have the headlamp setting checked regularly.

↑ WARNING

Bulbs and lamps can be very hot. You should therefore allow them to cool down before you change them. Otherwise, you could be burned if you touch them.

Keep bulbs out of the reach of children. Otherwise, they could damage the bulbs, for example, and injure themselves.

Never use a bulb which has been dropped. Such a bulb may break or even explode and injure you.

Halogen bulbs are pressurized and can explode when you change them, particularly if they are very hot. You should therefore wear eye protection and gloves when you are changing them.

Overview: changing bulbs/bulb types

You can change the following bulbs. The bulb type can be found in the legend.



Bi-Xenon headlamps (vehicles with halogen daytime running lamps)

1 High-beam spot lamp: H7 55 W




Bi-Xenon headlamps (vehicles with LED daytime running lamps)

- ① High-beam spot lamp¹³: H11 55 W
- ② Infrared light (Night View Assist Plus): H11 55 W

¹³ Due to their location, have the bulbs in the left-hand headlamp changed at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.

Changing the front bulbs

High-beam spot lamp (vehicles with halogen daytime running lamps)



- ► Switch off the lights.
- ▶ Open the hood.
- ► Turn housing cover ① counter-clockwise and pull it out.
- ► Turn bulb holder ② counter-clockwise and pull it out.
- ► Take the bulb out of bulb holder ②.
- ► Insert the new bulb into bulb holder ②.
- ► Insert bulb holder ②.


 Left-hand headlamp: cable outlet ③ must be pointing up and to the right.

 Pict band headlamp: cable outlet ④ must

Right-hand headlamp: cable outlet ③ must be pointing down and to the left.

- ► Turn bulb holder ② clockwise. Handle ④ of bulb holder ② is horizontal.
- ► Align housing cover ① and turn it clockwise until it engages.

High-beam spot lamp (vehicles with LED-daytime running lamps)/infrared light (Night View Assist Plus)



Due to their location, have the bulbs in the left-hand headlamp changed at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.

- ► Switch off the lights.
- ▶ Open the hood.
- ► Turn housing cover ① counter-clockwise and pull it out.
- ► Turn bulb holder ② counter-clockwise and pull it out.
- ▶ Push the two detents on the right and left of bulb holder ② and pull the bulb from bulb holder ②.
- ► Insert the new bulb into bulb holder ② until it engages.
- ▶ Insert bulb holder ② into the guide in the headlamp. Cable outlet ③ must be pointing down and to the right.
- ► Turn bulb holder ② clockwise.

 Cable outlet ③ must be pointing down and to the left.
- ► Align housing cover ① and turn it clockwise until it engages.




Windshield wipers

Switching the windshield wipers on/ off

♠ WARNING

Wiper blades are components that are subject to wear and tear. Replace the wiper blades twice a year, preferably in the spring and fall. Otherwise the windshield will not be wiped properly. As a result, you may not be able to observe surrounding traffic conditions and could cause an accident.

- Do not operate the windshield wipers when the windshield is dry, as this could damage the wiper blades. Moreover, dust that has collected on the windshield can scratch the glass if wiping takes place when the windshield is dry.
- If the windshield wipers leave smears on the windshield after the vehicle has been washed in an automatic car wash, wax or other residues may be the reason for this. Clean the windshield using washer fluid after washing the vehicle in an automatic car wash.



Combination switch

- Windshield wipers off
- ••• Intermittent wipe, low¹⁴
- •••• Intermittent wipe, high 15
- Continuous wipe, slow

- 5 Continuous wipe, fast
- ⑥ Single wipe/ Ѿ To wipe the windshield using washer fluid
- ▶ Switch on the ignition.
- ▶ Turn the combination switch to the corresponding position.
- Intermittent wiping with rain sensor: due to optical influences and the windshield becoming dirty in dry weather conditions, the windshield wipers may be activated inadvertently. This could then damage the windshield wiper blades or scratch the windshield.

For this reason, you should always switch off the windshield wipers in dry weather.

In the ••• or •••• position, the appropriate wiping frequency is set automatically according to the intensity of the rain. In the **••••** position, the rain sensor is more sensitive than in the first position, causing the windshield wipers to wipe more frequently.

Replacing the wiper blades

Important safety notes



↑ WARNING

For safety reasons, switch off the windshield wipers and remove the key from the ignition lock before changing the wiper blades (vehicles with KEYLESS-GO: make sure that the on-board electronics are in state 0). Otherwise, the wiper motor could be switched on suddenly and cause injury.

- I To avoid damaging the wiper blades, make sure that you touch only the wiper arm of the wiper.
- Never open the hood if a windshield wiper arm has been folded away from the windshield.

¹⁵ Rain sensor set to high sensitivity.



¹⁴ Rain sensor set to low sensitivity.

Never fold a windshield wiper arm without a wiper blade back onto the windshield.

Hold the windshield wiper arm firmly when you change the wiper blade. If you release the windshield wiper arm without a wiper blade and it falls onto the windshield, the windshield may be damaged by the force of the impact.

Mercedes-Benz recommends that you have the wiper blades replaced by a qualified specialist workshop, e.g. at an authorized Mercedes-Benz Center.

Always position the windshield wiper arms vertically before folding them away from the windshield. By doing so, you will avoid damage to the hood.

Replacing the wiper blades

Moving the wiper blades to a vertical position

Vehicles without KEYLESS-GO

- ► Turn the SmartKey to position 1 or 2 in the ignition lock.
- ➤ Set the windshield wipers to position —.
- ► When the wiper arms have reached a vertical position, turn the SmartKey to position **0** and remove it from the ignition lock.

Vehicles with KEYLESS-GO

- ► Switch off the engine.
- ▶ Remove your foot from the brake pedal.
- ► Set the windshield wipers to position —.
- ► Press the Start/Stop button repeatedly until the windshield wipers start.
- When the wiper arms have reached a vertical position, press the Start/Stop button.

Removing the wiper blades

- Fold the wiper arm away from the windshield until it engages.
- Set the wiper blade at right angles to the wiper arm.



Remove the wiper blade from the retaining pin on the wiper arm in the direction of the arrow.

Installing the wiper blades

- ▶ Push the new wiper blade onto the retaining pin on the wiper arm in the opposite direction to the arrow.
 Make sure that the wiper blade slides fully
 - onto the retaining pin on the wiper arm.
- ► Turn the wiper blade parallel to the wiper arm.
- ► Fold the wiper arm back onto the windshield.

Problems with the windshield wipers

The windshield wipers are obstructed

Leaves or snow, for example, may be obstructing the windshield wiper movement. The wiper motor has been deactivated.

► For safety reasons, you should remove the SmartKey from the ignition lock.

or

- ► Switch off the engine using the Start/Stop button and open the driver's door.
- ▶ Remove the cause of the obstruction.
- ▶ Switch the windshield wipers back on.



The windshield wipers are inoperative

The windshield wiper drive is malfunctioning.

- ➤ Select another wiper speed on the combination switch.
- ► Have the windshield wipers checked at a qualified specialist workshop.

The spray nozzles are misaligned

The windshield washer fluid from the spray nozzles no longer hits the center of the windshield. The spray nozzles are misaligned.

► Have the spray nozzles adjusted at a qualified specialist workshop.





Useful information	290
Overview of climate control systems	290
Operating the climate control sys-	
tem	292
Setting the air vents	298

Useful information

- 1 This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- Please read the information on qualified specialist workshops (⊳ page 31).

Overview of climate control systems

Important safety notes

↑ WARNING

Severe conditions (e.g. strong air pollution) may require replacement of the filter before its scheduled replacement interval. A clogged filter will reduce the air volume to the interior and the windows could fog up, impairing visibility and endangering you and others. Have a blocked filter replaced at a Mercedes-Benz Center as soon as possible.

/ WARNING

Follow the recommended settings for heating and cooling given on the following pages. Otherwise, the windows could fog up, impairing visibility and endangering you and others.

The automatic climate control controls the temperature and the humidity in the vehicle interior and filters undesirable substances from the air.

The automatic climate control is only operational when the engine is running¹⁶. Optimum operation is only achieved if you drive with the side windows and sliding sunroof/panorama roof with power tilt/ sliding panel closed.

You can also set some automatic climate control functions via COMAND (⊳ page 265).

- Ventilate the vehicle for a brief period during warm weather, e.g. using the convenience opening feature (⊳ page 93). This will speed up the cooling process and the desired vehicle interior temperature will be reached more quickly.
- 1 The integrated filter can filter out most particles of dust and completely filters out pollen. A clogged filter reduces the amount of air supplied to the vehicle interior. For this reason, you should always observe the interval for replacing the filter, which is specified in the Service Booklet. As it depends on environmental conditions, e.g. heavy air pollution, the interval may be shorter than stated in the Service Booklet.
- 1 It is possible that the blower may be activated automatically 40 minutes after the SmartKey is removed. The vehicle is then ventilated for 30 minutes to dry the air-conditioning system.

¹⁶ The residual heat function can only be activated/deactivated if the ignition is switched off.



Automatic climate control panel





P83.40-4385-31

Front control panel

- (1) Sets climate control to automatic mode, left (▷ page 293)
- ② Sets the temperature, left (⊳ page 294)
- ③ Sets the airflow, left (⊳ page 295)
- ④ Defrosts the windshield (▷ page 296)
- ⑤ Activates/deactivates air-recirculation mode (▷ page 297)
- (6) Switches climate control on /off(> page 292)
- ⑦ Switches the residual heat function on/off(▷ page 298)
- Switches the rear window defroster on/off (⊳ page 297)
- Sets the airflow, right (▷ page 295)
- Sets the temperature, right (⊳ page 294)
- (1) Sets climate control to automatic mode, right (▷ page 293)

Rear control panel

- (12) Sets the temperature, left (> page 294)
- (3) Sets the air distribution, left (▷ page 295)
- (4) Sets the airflow (> page 295)
- (5) OFF Switches rear-compartment climate control off (▷ page 292) AUTO Sets rear-compartment climate control to automatic mode (▷ page 293) MAN Sets rear-compartment climate control to manual mode (▷ page 293)
- **(i)** Sets the air distribution, right (▷ page 295)
- (7) Sets the temperature, right (> page 294)



Notes on using climate control

Below, you can find a number of notes and recommendations to help you use climate control optimally.

- Activate climate control using the **AUTO** rocker switch. The indicator lamp in the AUTO rocker switch lights up.
- Set the temperature to 72 °F (22 °C).
- Only use the "defrosting" function briefly until the windshield is clear again.
- Only use "air-recirculation" mode briefly, e.g. if there are unpleasant outside odors or when in a tunnel. The windows could otherwise fog up as, in air-recirculation mode, no fresh air is drawn into the vehicle.
- Use the residual heat function if you want to heat or ventilate the vehicle interior when the ignition is switched off. The "residual heat" function can only be activated or deactivated with the ignition switched off.

Operating the climate control system

Activating/deactivating climate control

Important information



↑ WARNING

When the climate control system is deactivated, the outside air supply and circulation are also deactivated. Only choose this setting for a short time. Otherwise the windows could fog up, impairing visibility and endangering you and others.

Switch on climate control primarily using the **AUTO** rocker switch (⊳ page 293).

Switching the front climate control on/ off using the front control panel

- ► Turn the SmartKey to position 2 in the ignition lock.
- ► To activate: press the OFF rocker switch up or down.
 - The indicator lamp in the rocker switch goes out. The previously selected settings come into effect again.
- ► To deactivate: press the OFF rocker switch up or down.

The indicator lamp in the rocker switch lights up.

Switching the rear-compartment climate control on/off using the front control panel

- ► Turn the SmartKey to position 2 in the ignition lock.
- ► Activate the نزنر rear compartment function via COMAND (⊳ page 268). The rear-compartment climate control can be controlled via the front control panel using the نزنر rear compartment function.
- ► To activate: press the OFF rocker switch up or down.
 - The indicator lamp in the rocker switch goes out. The previously selected settings come into effect again.
- ▶ To deactivate: press the OFF rocker switch up or down.
 - The indicator lamp in the rocker switch lights up.



Switching the rear-compartment climate control on/off using the rear control panel

- ► Turn the SmartKey to position 2 in the ignition lock.
- ► To switch on: press rocker switch (15)(⊳ page 291) up or down and select AUTO.

or

- ▶ Press rocker switch (15)(> page 291) up or down and select MAN.
- ► To switch off: press rocker switch (15)(⊳ page 291) up or down and select OFF.

Activating/deactivating cooling with the air dehumidification function

Important information

The cooling with air dehumidification function is only available when the engine is running. The air inside the vehicle is cooled and dehumidified according to the temperature selected.

↑ WARNING

If you switch off the cooling function, the vehicle will not be cooled when weather conditions are warm. The windows can fog up more quickly. Window fogging may impair visibility and endanger you and others.

Condensation may drip from the underside of the vehicle when it is in cooling mode. This is normal and not a sign that there is a malfunction.

You can activate or deactivate the cooling with air dehumidification function via COMAND (⊳ page 267).

The cooling with air dehumidification function uses refrigerant R134a. This coolant does not contain chlorofluorocarbons, and therefore does not damage the ozone layer.

Problems with the cooling with air dehumidification function

If you can no longer switch on the cooling with air dehumidification function via COMAND, the cooling with air dehumidification function is switched off due to a malfunction.

► Consult a qualified specialist workshop.

Setting climate control to automatic



↑ WARNING

If you switch off the cooling function, the vehicle will not be cooled when weather conditions are warm. The windows can fog up more quickly. Window fogging may impair visibility and endanger you and others.

In automatic mode, the set temperature is maintained automatically at a constant level. The system automatically regulates the temperature of the dispensed air, the airflow and the air distribution.

Automatic mode will achieve optimal operation if cooling with air dehumidification is also activated. If desired, cooling with air dehumidification can be deactivated.

Controlling the front climate control using the front control panel

- ► Turn the SmartKey to position 2 in the ignition lock.
- ► Set the desired temperature.
- ► To switch on: press the AUTO rocker switch up or down.

The indicator lamp in the **AUTO** rocker switch lights up.



► To deactivate: press the ∰ rocker switch up or down.

The indicator lamp in the AUTO rocker switch goes out.

or

► Set the air distribution using COMAND (> page 266).

The indicator lamp in the **AUTO** rocker switch goes out.

Controlling the rear-compartment climate control automatically using the front control panel

- ► Turn the SmartKey to position 2 in the ignition lock.
- Activate the נינע rear compartment function via COMAND (⊳ page 268).
 Rear-compartment climate control can be controlled via the front control panel using the נינען rear compartment function.
- ▶ Set the desired temperature.
- ► To switch on: press rocker switch AUTO up or down.

The indicator lamp in the **AUTO** rocker switch lights up.

► To deactivate: press the ∰ rocker switch up or down.

The indicator lamp in the AUTO rocker switch goes out.

or


- ► Set the air distribution using COMAND (▷ page 266).

 The indicator lamp in the AUTO rocker switch goes out.
- ① To return to the standard display, activate the front climate control function via COMAND (> page 268).
- 1 The rear display changes to the standard display automatically after five seconds.

Controlling the rear-compartment climate control automatically using the rear control panel

- ► Turn the SmartKey to position 2 in the ignition lock.
- ▶ Set the desired temperature.
- To activate: press rocker switch (⁵) up or down and select AUTO(▷ page 291).
- ► To deactivate: press rocker switch (5) up or down and select MAN or OFF(> page 291).

Setting the temperature



Climate control climate zones

You can select different temperature settings for the driver's and front-passenger sides as well as for the left and right sides of the rear compartment and the footwells.

Setting the front-compartment temperature using the front control panel

- ► Turn the SmartKey to position 2 in the ignition lock.
- ignition lock.

 ► To increase/reduce: press the ▼▲

rocker switch up or down.

- Only change the temperature setting in small increments. Start at 72 °F (22 °C).
- You can also use COMAND to set the temperature (▷ page 265).



Setting the temperature in the rear compartment using the front control panel

- ► Turn the SmartKey to position 2 in the ignition lock.
- ► Activate the نزنر rear compartment function via COMAND (⊳ page 268). The rear-compartment climate control can be controlled via the front control panel using the نزنر rear compartment function.
- ► To increase/reduce: press the ▼▲ rocker switch up or down. Only change the temperature setting in small increments. Start at 72 °F (22 °C).
- 1 To return to the standard display, activate the front climate control function via COMAND (⊳ page 268).
- The rear display changes to the standard display automatically after five seconds.

Setting the temperature in the rear compartment using the rear control panel

- ► Turn the SmartKey to position 2 in the ignition lock.
- ▶ To increase/reduce: press rocker switch (12) or (17) up or down (⊳ page 291). Only change the temperature setting in small increments. Start at 72 °F (22 °C).

Setting the footwell temperature

The footwell temperature can be set via COMAND (⊳ page 268).

Setting the air distribution

Air distribution settings

The air distribution can be set individually for the driver's and front-passenger sides.



Directs air through the defroster vents



Directs air through the center and side air vents

- Directs the airflow through the footwell air vents
- Directs air through the center, side and footwell vents
- Directs air through the defroster and footwell vents
- Directs air through the defroster, center, side and footwell vents
- Directs air through the defroster, center and side air vents
- Sets the air distribution to automatic

Setting the air distribution in the front/ rear compartment using COMAND

The air distribution can be set using COMAND (⊳ page 266).

Setting the rear-compartment air distribution using the rear control panel

- ► Turn the SmartKey to position 2 in the ignition lock.
- ▶ Press rocker switch (③) or (⑥) up or down repeatedly (⊳ page 291) until the desired air distribution symbol is shown in the display.

Setting the airflow

Setting the front-compartment airflow using the front control panel

You can select different airflow settings for the driver's and front-passenger sides as well as for the rear compartment.

You can also use COMAND to set the airflow (⊳ page 266).

- ► Turn the SmartKey to position 2 in the ignition lock.
- ► To increase/reduce: press the S rocker switch up or down.



Setting the rear-compartment airflow using the front control panel

- ► Turn the SmartKey to position 2 in the ignition lock.
- Pactivate the نزنر rear compartment function via COMAND (▷ page 268).

 The rear-compartment climate control can be controlled via the front control panel using the نزنر rear compartment function.
- ► To increase/reduce: press the street witch up or down.

Setting the rear-compartment airflow using the rear control panel

- ► Turn the SmartKey to position 2 in the ignition lock.
- ► To increase/reduce: press rocker switch

 (4) up or down (> page 291).

Defrosting the windshield

You can use this function to defrost the windshield or to defrost the inside of the windshield and the side windows.

- 1 You should only select the defrosting function until the windshield is clear again.
- ► Turn the SmartKey to position 2 in the ignition lock.
- ► To switch on: press the 🍿 rocker switch up or down.

The indicator lamp in the rocker switch lights up.

The climate control system switches to the following functions:

- cooling with air dehumidification on
- high airflow 17
- high temperature 17
- air distribution to the windshield and front side windows
- · air-recirculation mode off

► To deactivate: press the 🍿 rocker switch up or down.

The indicator lamp in the rocker switch goes out. The previously selected settings come into effect again. The cooling with air dehumidification function remains on. Air-recirculation mode remains deactivated.

or

- ► Press the ▼▲ rocker switch up or down. or
- ▶ Press the 😽 rocker switch up or down.

MAX COOL maximum cooling

The MAX COOL function is only available in vehicles for the USA.

MAX COOL is only operational when the engine is running.

The MAX COOL function is activated automatically:

- if climate control is set to automatic (AUTO) on both sides
- if additional cooling is used

The display shows MAX COOL.

This is the quickest way to cool the vehicle interior when the sliding sunroof and the side windows are closed.

Defrosting the windows

Windows fogged up on the inside

- Activate the cooling with air dehumidification function via COMAND (▷ page 267).
- ► Activate automatic mode **AUTO**.
- ▶ If the windows continue to fog up, activate the defrosting function (▷ page 296).
- 1 You should only select this setting until the windshield is clear again.

¹⁷ Depending on the outside temperature.



Windows fogged up on the outside

- ▶ Switch on the windshield wipers.
- Activate automatic climate control.
- 1 You should only select this setting until the windshield is clear again.

Rear window defroster

Activating/deactivating



↑ WARNING

Any accumulation of snow and ice should be removed from the rear window before driving. Visibility could otherwise be impaired, endangering you and others.

The rear window defroster has a high current draw. You should therefore switch it off as soon as the window is clear as it only switches off automatically after several minutes.

If the battery voltage is too low, the rear window defroster may switch off.

- ► Turn the SmartKey to position 2 in the ignition lock.
- ▶ Press the TERFAR rocker switch up or down. The indicator lamp in the TEEPER rocker switch lights up or goes out.

Problems with the rear window defroster

The rear window defroster has deactivated itself prematurely or cannot be activated.

► Switch off any consumers that are not required, e.g. reading lamps or interior lighting.

When the battery is sufficiently charged. the rear window defroster is activated again automatically.

Activating/deactivating airrecirculation mode

You can deactivate the flow of fresh air if unpleasant odors are entering the vehicle from outside. The air already inside the vehicle will then be recirculated.



Fogged windows impair visibility, endangering you and others. If the windows begin to fog on the inside, switching off the air recirculation mode immediately should clear interior window fogging. If interior window fogging persists, make sure the air conditioning is activated, or press the wax button.

- ► Turn the SmartKey to position 2 in the ignition lock.
- ▶ To activate: press the 🖘 rocker switch up or down.
 - The indicator lamp in the rocker switch lights up.
- Air-recirculation mode is activated automatically at high outside temperatures. The indicator lamp in the rocker switch is not lit when automatic air-recirculation mode is activated.

Outside air is added after about 30 minutes.

- ▶ To deactivate: press the 🖘 rocker switch up or down. The indicator lamp in the rocker
- Air-recirculation mode deactivates automatically:

switch goes out.

- · after approximately five minutes if outside temperatures are less than about 41 °F (5 °C)
- after approximately five minutes if cooling with air dehumidification is deactivated
- after approximately 30 minutes if outside temperatures are over about 41 °F (5 °C)



Activating/deactivating the residual heat function

It is possible to make use of the residual heat of the engine to continue heating the stationary vehicle for up to 30 minutes after the engine has been switched off. The heating time depends on the temperature that has been set.

- 1 The blower will run at a low speed regardless of the airflow setting.
- 1 If you activate the residual heat function at high temperatures, only the ventilation will be activated. The blower runs at medium speed.
- ► Turn the SmartKey to position **0** in the ignition lock or remove it.
- ► To activate: press the REST rocker switch up or down.

The indicator lamp in the **REST** rocker switch lights up.

- ► To deactivate: press the REST rocker switch up or down.

 The indicator lamp in the REST rocker switch goes out.
- Residual heat is deactivated automatically:
 - after about 30 minutes
 - · when the ignition is switched on
 - · if the battery voltage drops
 - if the coolant temperature is too low

Setting the air vents

Important safety notes




When operating the climate control, the air that enters the passenger compartment through the air vents can be very hot or very cold (depending on the set temperature). This could cause burns or frostbite to unprotected skin in the immediate area of the air vents.

Always keep sufficient distance between unprotected parts of the body and the air vents. If necessary, use the air distribution adjustment to direct the air to air vents in the vehicle interior that are not in the immediate area of unprotected skin.

In order to ensure the direct flow of fresh air through the air vents into the vehicle interior, please observe the following notes:

- keep the air intake grille on the hood free of blockages, such as ice, snow or leaves
- never cover the air vents or air intake grille in the vehicle interior.
- For virtually draft-free ventilation, adjust the sliders of the air vents to the center position.


Setting the center air vents



- Fixed center air vent
- (2) Center air vent, right
- 3 Center vent thumbwheel, right
- 4 Center vent thumbwheel, left
- ⑤ Center air vent, left
- ► To open/close: turn thumbwheels ③ and ④ up or down.



Setting the side air vents




- ► To open/close: turn thumbwheel ③ up or down.
- 1 Side window defroster vent 1 is never completely shut, even if side air vent 2 is shut.

Setting the glove box air vent

When automatic climate control is activated, the glove box can be ventilated, for instance to cool its contents. The level of airflow depends on the airflow and air distribution settings.

I Close the air vent when heating the vehicle.


At high outside temperatures, open the air vent and activate the "cooling with air dehumidification" function. Otherwise, temperature-sensitive items stored in the glove box could be damaged.



- ► To open: turn thumbwheel ① counterclockwise from position 3 to position 2.
- ► To close: turn thumbwheel ① clockwise from position ② to position ③.

Setting the rear-compartment air vents

Setting the center vents in the rear compartment



- (1) Rear-compartment air vent, left
- (2) Rear-compartment air vent, right
- ③ Rear-compartment air vent thumbwheel, right
- Rear control panel for automatic climate control
- S Rear-compartment air vent thumbwheel, left
- ► To open/close: turn thumbwheel ③ or ⑤ to the right or left.
- i) In vehicles without rear-compartment airconditioning system: close the rearcompartment air vents when heating mode is activated, as no warm air flows through the rear vents in the basic heating setting.



Setting the B-pillar air vents



- ① B-pillar air vent
- ② Thumbwheel for B-pillar air vent
- ► To open/close: turn thumbwheel ② to the left or right.

Useful information	302
Breaking-in notes	302
Driving	302
Automatic transmission	310
Refueling	317
Parking	323
Driving tips	326
Driving systems	330

Useful information

- 1 This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- Please read the information on qualified specialist workshops (⊳ page 31).

Breaking-in notes

The first 1000 miles (1500 km)

The more you look after the engine when it is new, the more satisfied you will be with its performance in the future.

- Drive at varying vehicle speeds and engine speeds for the first 1000 miles (1500 km) for this reason.
- · Avoid overstraining the vehicle during this period, e.g. driving at full throttle.
- · Change gear in good time, at the latest when the tachometer needle is $^{2}/_{3}$ of the way to the red area in the tachometer display.
- Do not manually shift to a lower gear to brake the vehicle.
- If possible, do not depress the accelerator pedal past the point of resistance (kickdown).
- Only select shift ranges 3, 2 or 1 when driving slowly, e.g. in mountainous terrain.
- If possible, drive in drive program **E** (in AMG vehicles in drive program C) for the first 1000 miles (1500 km).

After 1000 miles (1500 km), you can increase the engine speed gradually and bring the vehicle up to full speed.

Additional breaking-in notes for AMG vehicles:

- do not drive faster than 85 mph (140 km/h) in the first 1000 miles (1500 km).
- only allow the engine to reach a maximum engine speed of 4500 rpm briefly.
- · change gear in good time.
- 1 You should also observe these notes on running in if the engine or parts of the drive train on your vehicle have been replaced.
- Always observe the respective speed restrictions.

Driving

Important safety notes

↑ WARNING

Make sure absolutely no objects are obstructing the pedals' range of movement. Keep the driver's footwell clear of all obstacles. If there are any floormats or carpets in the footwell, make sure the pedals still have sufficient clearance.

During sudden driving or braking maneuvers the objects could get caught between the pedals. You could then no longer brake or accelerate. This could lead to accidents and injury.



↑ WARNING

On slippery road surfaces, never downshift in order to obtain braking action. This could result in drive wheel slip and reduced vehicle control. Your vehicle's ABS will not prevent this type of loss of control.



↑ WARNING

It is dangerous to shift the automatic transmission out of parking position **P** or neutral position N if the engine speed is higher than idle speed. If your foot is not firmly on the brake pedal, the vehicle could accelerate quickly forward or in reverse. You



could lose control of the vehicle and hit someone or something. Only shift into gear when the engine is idling normally and when your right foot is firmly on the brake pedal.

↑ WARNING

HYBRID vehicles: It is imperative that you read the HYBRID Supplemental Operating Instructions included in your vehicle literature portfolio. You may otherwise not receive all necessary safety information and warning for the operation of your vehicle.

Warm up the engine quickly. Do not use the engine's full performance until it has reached operating temperature.


Only shift the automatic transmission to the desired drive position when the vehicle is stationary.

Where possible, avoid spinning the drive wheels when pulling away on slippery roads. You could otherwise damage the drive train.

■ S 63 AMG: at low engine oil temperatures below 68 °F (+20 °C), the maximum engine speed is restricted in order to protect the engine. To protect the engine and maintain smooth engine operation, avoid driving at full throttle when the engine is cold.

SmartKey positions

SmartKey



- To remove the SmartKey
- 1 Power supply for some consumers, such as the windshield wipers
- 2 Ignition (power supply for all consumers) and drive position
- 3 To start the engine
- 1 The SmartKey can be turned in the ignition lock even if it is not the correct SmartKey for the vehicle. The ignition is not switched on. The engine cannot be started.

KEYLESS-GO

General information

Vehicles with KEYLESS-GO are equipped with a SmartKey featuring an integrated KEYLESS-GO function and a detachable Start/Stop button.

The Start/Stop button must be inserted into the ignition lock and the SmartKey must be in the vehicle.


Pressing the Start/Stop button several times in succession corresponds to the different SmartKey positions in the ignition lock. This is only the case if you are not depressing the brake pedal.

If you depress the brake pedal and press the Start/Stop button, the engine starts immediately.


The Start/Stop button can be removed from the ignition lock. Then, you can insert the SmartKey into the ignition lock.



1 You do not have to remove the Start/Stop button from the ignition lock when you leave the vehicle. However, you should always take the SmartKey with you when leaving the vehicle. The vehicle can be started with the Start/Stop button and the electrical equipment can be operated while the SmartKey is in the vehicle.



- (1) Start/Stop button
- (2) Ignition lock
- ▶ Insert Start/Stop button (1) into ignition lock (2).
- 1 When you insert Start/Stop button (1) into ignition lock (2), the system requires a detection time of approximately two seconds before you can use Start/Stop button (1).



Start/Stop button

- ③ USA only
- 4 Canada only

- ▶ Position 0: if Start/Stop button (1) has not yet been pressed, this corresponds to the SmartKey being removed from the ignition.
- ▶ Position 1: press Start/Stop button ①. You can now activate the windshield wipers, for example.
- 1 If you then open the driver's door when in this position, the power supply is deactivated.
- ► Position 2 (ignition): press Start/Stop button (1) twice.
- 1 If you press Start/Stop button (1) once when in this position and the driver's door is open, the power supply is deactivated again.

As soon as the ignition is switched on, all the indicator lamps in the instrument cluster light up. If an indicator lamp does not go out after the engine is started or if it lights up while the vehicle is in motion, see (⊳ page 422).

Starting the engine

Important safety notes

↑ WARNING

Inhalation of exhaust gas is hazardous to your health. All exhaust gas contains carbon monoxide (CO), and inhaling it can cause unconsciousness and possible death.

Do not run the engine in confined areas (such as a garage) which are not properly ventilated. If you think that exhaust gas fumes are entering the vehicle while driving, have the cause determined and corrected immediately. If you must drive under these conditions, drive only with at least one window fully open at all times.

- Do not depress the accelerator pedal when starting the engine.
- 1 Vehicles with a gasoline engine: the catalytic converter is preheated for up to



30 seconds after a cold start. The sound of the engine may change during this time.

Automatic transmission

- ▶ Shift the transmission to position **P**. The transmission position display in the multifunction display shows P.
- 1 You can also start the engine when the transmission is in position N.

Starting procedure with the SmartKey

- To start the engine using the SmartKey instead of KEYLESS-GO, pull the Start/ Stop button out of the ignition lock.
- ▶ To start a gasoline engine: turn the SmartKey to position 3 in the ignition lock (⊳ page 303) and release it as soon as the engine is running.
- ▶ To start a diesel engine: turn the SmartKey to position 2 in the ignition lock (⊳ page 303).
 - The more preglow indicator lamp in the instrument cluster lights up.
- ▶ When the 700 preglow indicator lamp goes out, turn the SmartKey to position 3 (⊳ page 303) and release it as soon as the engine is running.
- 1 You can start the engine without preglow if the engine is warm.

Using KEYLESS-GO to start the engine

↑ WARNING

As long as the SmartKey is in your vehicle, the vehicle can be started. Therefore, never leave children unattended in the vehicle, as they could otherwise accidentally start the engine. When leaving the vehicle, always take the

SmartKey with you and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury.

- The Start/Stop button can be used to start the vehicle manually without inserting the SmartKey into the ignition lock. The Start/Stop button must be inserted into the ignition lock and the SmartKey must be in the vehicle. This mode for starting the engine operates independently of the ECO start/stop automatic engine start function.
- ▶ Depress the brake pedal and keep it depressed.
- ▶ To start a gasoline engine: press the Start/Stop button (⊳ page 303) once. The engine starts.
- ▶ To start a diesel engine: press the Start/ Stop button (⊳ page 303) once. Preglow is activated and the engine starts.
- 1 If the engine is warm, the preglow time is shortened.

Pulling away

Automatic transmission



↑ WARNING

It is dangerous to shift the automatic transmission out of parking position **P** or neutral position N if the engine speed is higher than idle speed. If your foot is not firmly on the brake pedal, the vehicle could accelerate quickly forward or in reverse. You could lose control of the vehicle and hit someone or something. Only shift into gear when the engine is idling normally and when your right foot is firmly on the brake pedal.

- t is only possible to shift the transmission from position P to the desired position if you depress the brake pedal. Only then is the parking lock released. If you do not depress the brake pedal, you can move the DIRECT SELECT lever but the parking lock remains engaged.
- ▶ Depress the brake pedal and keep it depressed.
- ▶ Shift the transmission to position **D** or **R**.



- ► Release the brake pedal.
- ► Carefully depress the accelerator pedal. The electric parking brake (> page 324) is automatically released.

The red PARK (USA only) or ((©) (Canada only) indicator lamp in the instrument cluster goes out.

The vehicle locks centrally once you have pulled away. The locking knobs in the doors drop down.

You can open the doors from the inside at any time.

You can also deactivate the automatic locking feature (> page 264).

Upshifts take place at higher engine speeds after a cold start. This helps the catalytic converter to reach its operating temperature more quickly.

Hill start assist

Hill start assist helps you when pulling away forwards or in reverse on an uphill gradient. It holds the vehicle for a short time after you have removed your foot from the brake pedal. This gives you enough time to move your foot from the brake pedal to the accelerator pedal and depress it before the vehicle begins to roll.

⚠ WARNING

Never leave the vehicle when it is held by hill start assist. After approximately one second, hill start assist will no longer brake your vehicle and it could roll away.

- ► Take your foot off the brake pedal.
- Once you have taken your foot off the brake pedal, the vehicle is held for around one second.
- ► Pull away.

Hill start assist will not function if:

- you are pulling away on a level road or a downhill gradient.
- the transmission is in position N.

- the electric parking brake is applied.
- ESP® is malfunctioning.

ECO start/stop function

General information

The ECO start/stop function is only available for the S 63 AMG.

The ECO start/stop function is only available in drive program **C**.

The ECO start/stop function switches the engine off automatically when the vehicle stops moving.

The engine starts automatically when the driver wants to pull away again. The ECO start/stop function thereby helps you to reduce the fuel consumption and emissions of your vehicle.

The ECO start/stop function is activated each time the engine is switched on. If all the requirements are fulfilled for automatic engine switch-off (▷ page 307), the green ECO ECO symbol is shown in the multifunction display and Stop/Start active appears. If not all of the requirements are fulfilled, the ECO ECO symbol is shown in yellow and Stop/Start inactive appears.

If the ECO start/stop function is deactivated (> page 307), the **ECO** symbol is not shown.

MARNING

If the engine is switched off and the ECO symbol is shown in green in the multifunction display, the engine has been switched off automatically. All of the vehicle's systems remain active. If you open the door, unfasten your seat belt or remove your foot from the brake pedal, the engine will automatically start. The vehicle may begin moving. You could suffer serious or even fatal injury or cause an accident resulting in injury or death.

Never leave the vehicle while the ECO symbol in the multifunction display is shown in green



or yellow. Always secure the vehicle against rolling away before leaving it.

Always switch the ignition off and take the key with you when leaving the vehicle.

Automatic engine switch-off

The ECO start/stop function switches the engine off automatically if the vehicle is braked to a standstill and the brake remains depressed with the transmission in position **D** or **N**.

1 You can still activate the HOLD function when the vehicle is stationary, even if the engine has been switched off automatically. It is then not necessary to continue applying the brakes during the automatic stop phase. When you depress the accelerator pedal, the engine starts automatically and the braking effect of the HOLD function is deactivated. Depress the accelerator pedal carefully, as the engine must be started first.

The engine is only switched off if:

- the outside temperature is within the range which is suitable for the system.
- the engine is at normal operating temperature.
- the set temperature for the vehicle interior has been reached.
- the battery is sufficiently charged.
- the system detects that the windshield is not fogged up when the air-conditioning system is switched on.
- the hood is closed.
- no engine-relevant diagnostics are active.
- the driver's door is closed and the seat belt is fastened.

Automatic engine start

The engine is started automatically if you:

- release the brake pedal when HOLD is not activated and the transmission is in position **D** or **N**
- shift the transmission to position R
- depress the accelerator pedal
- switch off the ECO start/stop function or switch to drive program S or M
- unfasten your seat belt or open the driver's door

The engine is also started automatically if:

- the vehicle starts to roll.
- the brake system requires this.
- the system detects moisture on the windshield when the air-conditioning system is switched on.
- the temperature in the vehicle interior deviates from the set range.
- the charge level of the battery is too low.

Deactivating/activating the ECO start/ stop function

General information

You can deactivate and activate the ECO start/stop function using COMAND (⊳ page 261).

1 You can also use the programmable button (> page 120) to activate and deactivate the ECO start/stop function if you have assigned this function to the button.

Deactivating

- ▶ Deactivate the ECO start/stop function using COMAND (▷ page 261):

 The ECO ECO symbol goes out and the Stop/Start deactivated display message is shown in the multifunction display.
- If drive program **S** or **M** has been selected, the ECO start/stop function is always deactivated.



Activating

- ► Activate the ECO start/stop function using COMAND (▷ page 261).

 The ECO ECO symbol and the Stop/
 Start active display message are shown in the multifunction display.
 - If not all conditions for automatic engine switch-off are fulfilled (▷ page 307), the Stop/Start inactive message appears.
- 1 If you activate the ECO start/stop function in drive program S or M, drive program C is selected automatically.



Problem	Possible causes/consequences and ▶ Solutions
The engine does not start. The starter motor can be heard.	 There is a malfunction in the engine electronics. There is a malfunction in the fuel supply. ▶ Before attempting to start the engine again, turn the SmartKey in the ignition back to position 0 or press the Start/Stop button repeatedly until all indicator lamps in the instrument cluster go out. ▶ Try to start the engine again (▷ page 304). Avoid excessively long and frequent attempts to start the engine as these will drain the battery. If the engine does not start after several attempts: ▶ Consult a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.
The engine does not start. You cannot hear the starter motor.	The on-board voltage is too low because the battery is too weak or discharged. ▶ Jump-start the vehicle (▷ page 481). If the engine does not start despite attempts to jump-start it: ▶ Consult a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.
	 The starter motor was exposed to a thermal load that was too high. ▶ Allow the starter motor to cool down for approximately two minutes. ▶ Try to start the engine again. If the engine still does not start: ▶ Consult a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.



Problem	Possible causes/consequences and ▶ Solutions
Vehicles with a gasoline engine: The engine is not running smoothly and is misfiring.	There is a malfunction in the engine electronics or a mechanical component of the engine management system. ▶ Only depress the accelerator pedal slightly. ▶ Have the cause rectified immediately at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center. Otherwise, non-combusted fuel may get into the catalytic converter and damage it.
The coolant temperature gauge shows a value above 248 °F (120 °C).	The coolant level is too low. The coolant is too hot and the engine is no longer being cooled sufficiently. ▶ Stop as soon as possible and allow the engine and the coolant to cool down. ▶ Check the coolant level (▷ page 460). Observe the warning notes as you do so and add coolant if necessary.

Automatic transmission

Important safety notes



It is dangerous to shift the automatic transmission out of parking position **P** or neutral position N if the engine speed is higher than idle speed. If your foot is not firmly on the brake pedal, the vehicle could accelerate quickly forward or in reverse. You could lose control of the vehicle and hit someone or something. Only shift into gear when the engine is idling normally and when your right foot is firmly on the brake pedal.

↑ WARNING

Keep in mind that turning off the engine alone only will shift the automatic transmission into neutral position N automatically.

Always shift the automatic transmission into park position P before turning off the engine. Otherwise the vehicle could roll away which could result in an accident and/or serious personal injury.


/ WARNING

HYBRID vehicles: It is imperative that you read the HYBRID Supplemental Operating Instructions included in your vehicle literature portfolio. You may otherwise not receive all necessary safety information and warning for the operation of your vehicle.

DIRECT SELECT lever

Overview of transmission positions

The DIRECT SELECT lever is on the right of the steering column.



- P Park position with parking lock
- R Reverse gear



N Neutral

D Drive

1 The DIRECT SELECT lever always returns to its original position. The current transmission position P, R, N or D appears in the transmission position display (⊳ page 312) in the multifunction display.

Engaging park position P

- ▶ Push the DIRECT SELECT lever in the direction of arrow P.
- The automatic transmission shifts automatically into park position P if you open the driver's door when the vehicle is stationary or driving at very low speed, and the transmission is in position **D** or **R**.
- If the engine speed is too high or the vehicle is moving, do not shift the automatic transmission directly from **D** to R, from R to D or directly to P. The automatic transmission could otherwise be damaged.

Engaging reverse gear R

- I Only shift the automatic transmission to **R** when the vehicle is stationary.
- 1 The ECO start/stop function is not available when reverse gear is engaged. For further information on the ECO start/ stop function, see (⊳ page 306).
- ▶ When the vehicle is stationary, depress the brake pedal.
- ▶ Push the DIRECT SELECT lever up past the first point of resistance.

Neutral N with ECO start/stop function activated

The ECO start/stop function switches the engine off automatically if the vehicle is braked to a standstill when in neutral N and the brake is still depressed.

For further information on the ECO start/stop function (⊳ page 306).

Shifting to neutral N

- ▶ When the vehicle is stationary, depress the brake pedal.
- ▶ Push the DIRECT SELECT lever up or down to the first point of resistance.

If the engine has been switched off, the automatic transmission automatically switches to N.

Remaining in neutral N

If the automatic transmission is to remain in neutral N, e.g. for washing the vehicle in car washes with a towing device, please observe the following instructions:



♠ WARNING

When leaving the SmartKey in the starter switch, do not leave children unattended in the vehicle. It is possible for children to switch on the ignition which could result in unsupervised use of vehicle equipment. Unsupervised use of vehicle equipment could result in an accident and/or serious personal injury.

Using the SmartKey:

- make sure that the ignition is switched on.
- when the vehicle is stationary, depress the brake pedal and keep it depressed.
- shift to neutral N.
- release the brake pedal.
- · if applied, release the electric parking brake.
- switch off the ignition and leave the SmartKey in the ignition lock.

Using KEYLESS-GO:

- make sure that the ignition is switched on.
- when the vehicle is stationary, depress the brake pedal and keep it depressed.
- engage park position P.
- release the brake pedal.



- remove the Start/Stop button from the ignition lock.
- insert the SmartKey into the ignition lock.
- switch on the ignition.
- depress the brake pedal and keep it depressed.
- shift to neutral N.
- release the brake pedal.
- if applied, release the electric parking brake.
- switch off the ignition and leave the SmartKey in the ignition lock.

Transmission position D with ECO start/stop function activated


The ECO start/stop function switches the engine off automatically if the vehicle is braked to a standstill when in transmission position **D** and the brake is still depressed. For further information on the ECO start/stop function (▷ page 306).

Shifting to transmission position D

- ► When the vehicle is stationary, depress the brake pedal.
- ▶ Push the DIRECT SELECT lever down past the first point of resistance.

Transmission position display

The current transmission position is shown in the multifunction display.



P54.32-8501-31

- 1 The arrows in the transmission position display show how and into which transmission positions you can change using the DIRECT SELECT lever.
- If the transmission position display in the multifunction display is not working, you should pull away carefully to check whether the desired transmission position is engaged. Ideally, you should select transmission position **D** and drive program **E** (drive program **C** on AMG vehicles) or **S**. Do not restrict the shift range.

Transmission positions

Р

Park position

Do not shift the transmission into position **P** unless the vehicle is stationary. The parking lock should not be used as a brake when parking. In addition to engaging the parking lock, you must always apply the electric parking brake to secure the vehicle.

If the vehicle electronics are malfunctioning, the transmission may be locked in position **P**. Have the vehicle electronics checked at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center, immediately.

R

Reverse gear

Only shift the transmission to **R** when the vehicle is stationary.

1 Transmission position





Neutral

Do not shift the transmission to N while driving. The transmission could otherwise be damaged. No power is transmitted from the

engine to the drive wheels.

Releasing the brakes will allow you to move the vehicle freely, e.g. to push it or tow it.

If ESP® is deactivated or faulty: only shift the transmission to position N if the vehicle is in danger of skidding, e.g. on icy roads.

Rolling in neutral N can damage the drive train.



Drive

The automatic transmission changes gear automatically. All forward gears are available.

Changing gear

The automatic transmission shifts to the individual gears automatically when it is in transmission position **D**. This automatic gearshifting behavior is determined by:

- · a shift range restriction, if selected
- the selected drive program

E/S or, for AMG vehicles, **C/S/M**(⊳ page 314)

- the position of the accelerator pedal
- the road speed

Driving tips

Kickdown

Use kickdown for maximum acceleration.

- ▶ Vehicles for USA except AMG vehicles: fully depress the accelerator pedal. The transmission shifts to a lower gear depending on the engine speed.
- ► Vehicles for Canada except AMG vehicles: depress the accelerator pedal beyond the pressure point. The transmission shifts to a lower gear depending on the engine speed.

Rocking the vehicle free

Rocking the vehicle free by shifting back and forth between transmission positions **D** and R can help to free a vehicle that has become stuck in mud or snow. The engine management system of the vehicle limits shifting back and forth between transmission positions **D** and **R** to a maximum speed of 5 mph (9 km/h). To shift back and forth between transmission positions **D** and **R**, move the selector lever up and down beyond the pressure point.

Working on the vehicle



♠ WARNING

When working on the vehicle, engage the electronic parking brake and shift the automatic transmission into park position P. Otherwise the vehicle could roll away which could result in an accident and/or serious personal injury.



Program selector button

General information

The program selector button influences:

- the drive program
- the AIRMATIC (▷ page 343) or ABC
 (▷ page 345) suspension settings
- the engine management



Program selector button



Program selector button on AMG vehicles


In AMG vehicles, drive program **E** is called drive program **C**.

E Economy C Controlled Efficiency	Comfortable, economical driving
S Sport	Sporty driving style
M Manual	Manual gearshifting

for further information on the automatic drive program, see (> page 314). **AMG vehicles:** only change from automatic drive program **C** or **S** to manual drive program **M** when the vehicle is stationary.

- ► Press program selector button ①
 repeatedly until the letter for the desired
 gearshift program appears in the
 multifunction display.
- 1 When the engine is started, the automatic transmission always switches to automatic drive program **E** (drive program **C** in AMG vehicles).

Steering wheel paddle shifters



- 1 Left-hand steering wheel paddle shifter
- ② Right-hand steering wheel paddle shifter

You can restrict or derestrict the shift range by using the steering wheel paddle shifters. You can change gear yourself by using the steering wheel paddle shifters in the manual drive program.

Automatic drive program

Drive program **E** (drive program **C** on AMG vehicles) is characterized by the following:

- the vehicle pulling away more gently in forward and reverse gears, unless the accelerator pedal is depressed fully
- increased sensitivity. This improves driving stability on slippery road surfaces, for example
- the automatic transmission shifting up sooner. This results in the vehicle being



driven at lower engine speeds and the wheels being less likely to spin

Drive program **S** is characterized by the following:

- · sporty engine settings
- the vehicle pulling away in first gear
- the automatic transmission shifting up later
- the fuel consumption possibly being higher as a result of the later automatic transmission shift points

Shift ranges

Introduction

When the automatic transmission is in position **D**, it is possible to restrict or derestrict the shift range (▷ page 315).

The shift range selected is shown in the multifunction display. The automatic transmission shifts only as far as the selected gear.

Shift range

3

You can use the engine's braking effect.



To use the braking effect of the engine on downhill gradients and for driving:

- on steep mountain roads
- · in mountainous terrain
- · in arduous conditions



To use the braking effect of the engine on extremely steep downhill gradients and on long downhill stretches

Restricting the shift range

- Pull the left-hand steering wheel paddle shifter.
 - The automatic transmission shifts down one gear and restricts the shift range to the relevant gear.
- If the engine exceeds the maximum engine speed when shifting down, the automatic transmission protects against engine damage by not shifting down.
- 1 If the maximum engine speed for the shift range is reached and you continue to accelerate, the automatic transmission shifts up in order to prevent the engine from overrevving, even if the shift range is restricted.

Derestricting the shift range

► Pull the right-hand steering wheel paddle shifter.

The shift range is derestricted.

Clearing the shift range restriction

▶ Pull and hold the right-hand steering wheel paddle shifter until **D** is shown again in the multifunction display.

The automatic transmission shifts from the current shift range directly to **D**.

Selecting the ideal shift range

▶ Pull the left-hand steering wheel paddle shifter and hold it in position.

The automatic transmission shifts to the gear which allows optimum acceleration and deceleration. To do this, the automatic transmission shifts down one or more gears.



Manual drive program

Switching on the manual drive program

The manual drive program is only available for AMG vehicles.

Manual drive program ${\bf M}$ is different from drive program ${\bf S}$ with regard to spontaneity, responsiveness and smoothness of gear changes.

Manual drive program \mathbf{M} can be selected using the program selector button. In manual drive program \mathbf{M} , you can change gear yourself using the steering wheel paddle shifters if the transmission is in position \mathbf{D} . The gear currently selected and engaged is shown in the multifunction display.


▶ Press the program selector button (> page 314) repeatedly until M appears in the multifunction display.

Upshifting

- In manual drive program M, the automatic transmission does not shift up automatically even when the engine limiting speed for the current gear is reached. When the engine limiting speed is reached, the fuel supply is cut to prevent the engine from overrevving. Always make sure that the engine speed does not reach the red area of the tachometer. There is otherwise a risk of engine damage.
- ▶ Pull the right-hand steering wheel paddle shifter (▷ page 314).

 The automatic transmission shifts up to the next gear.

Before the engine speed reaches the red area, an upshift indicator appears in the multifunction display.



- (1) Gear indicator
- ② Upshift indicator

Downshifting

- ► Pull the left-hand steering wheel paddle shifter (▷ page 314). The automatic transmission shifts down to the next gear.
- 1 If you brake the vehicle or stop without shifting down, the automatic transmission will shift down to a gear that will allow the vehicle to accelerate or pull away again.
- For maximum acceleration, pull the lefthand steering wheel paddle shifter until the transmission selects the optimum gear for the current speed.

Kickdown

(i) Kickdown is not possible in manual drive program M.

Switching off the manual drive program

▶ Press the program selector button (▷ page 314) repeatedly until C or S appears in the multifunction display.



Problems with the transmission		
Problem	Possible causes/consequences and ▶ Solutions	
The transmission has problems shifting gear.	The transmission is losing oil. ► Have the transmission checked at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center, immediately.	
The acceleration ability is deteriorating. The transmission no longer changes gear.	The transmission is in emergency mode. It is only possible to shift into second gear and reverse gear. ▶ Stop the vehicle. ▶ Shift the transmission to position P. ▶ Switch off the engine. ▶ Wait at least 10 seconds before restarting the engine. ▶ Shift the transmission to position D or R. If D is selected, the transmission shifts into second gear; if R is selected, the transmission shifts into reverse gear. ▶ Have the transmission checked at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center, immediately.	

Transfer case

This section is only valid for vehicles with 4wheel drive (4MATIC). Power is always transmitted to both axles.

- Performance tests may only be carried out on a 2-axle dynamometer. The brake system or transfer case could otherwise be damaged. Contact a qualified specialist workshop for a performance test. Mercedes-Benz recommends that you use an authorized Mercedes-Benz Center for this purpose.
- To prevent ESP® from intervening, the ignition must be switched off (SmartKey or the Start/Stop button in position **0** or **1**) if:
 - the electric parking brake is being tested on a brake dynamometer.
 - the vehicle is being towed with only one axle raised (not permitted for vehicles with 4MATIC).

The brake system could otherwise be damaged.

Refueling

Important safety notes



↑ WARNING

Gasoline and diesel fuels are highly flammable and poisonous. They burn violently and can cause serious injury.

Never allow sparks, flames or smoking materials near gasoline or diesel fuel!

Turn off the engine before refueling.

Whenever you are around gasoline or diesel fuel, avoid inhaling fumes and any skin or clothing contact. Extinguish all smoking materials.

Direct skin contact with fuels and the inhalation of fuel vapors are damaging your health.



↑ WARNING

Overfilling of the fuel tank may create pressure in the system which could cause a gas discharge. This could cause the gasoline to spray back out when removing the fuel pump nozzle, which could cause personal injury.

↑ WARNING

Hybrid vehicles: be sure to read the "HYBRID" supplement. Otherwise, you could fail to recognize dangers.

↑ WARNING

Do not fill diesel tanks with gasoline. Do not mix diesel fuel with gasoline. Otherwise the fuel system and engine could be damaged. In addition, the vehicle could catch fire.

- Do not use gasoline to refuel vehicles with a diesel engine. Do not use diesel to refuel vehicles with a gasoline engine. Even a small quantity of the wrong fuel will damage the fuel system and engine.
- Do not switch on the ignition if you accidentally refuel with the wrong fuel. Otherwise, the fuel will enter the fuel lines. Notify a qualified specialist workshop and have the fuel tank and fuel lines drained completely.

Gasoline

Fuel grade

- You should only refuel with unleaded premium-grade gasoline as this avoids damaging the catalytic converter. If engine running problems are apparent, have the cause checked immediately and repaired. Excess unburned fuel can otherwise enter the catalytic converter, leading to overheating and possibly causing a fire.
- Use a filter when refueling from a fuel can. Otherwise, the fuel lines and/or injection

- system could be blocked by particles from the fuel can.
- Only refuel with premium-grade unleaded gasoline with a specified minimum octane number of 91 (average value of 96 RON/ 86 MON).

You will usually find information about the fuel grade on the pump. If you cannot find the label on the pump, ask the staff for assistance.

You can find more information under "Fuel" (⊳ page 525), or by contacting an authorized Mercedes-Benz Service Center or visiting http://www.mbusa.com (USA) only).

Diesel

Fuel grade

Only refuel with ULTRA-LOW SULFUR DIESEL FUEL (ULSD, 15 ppm SULFUR MAXIMUM). Using other diesel fuels could result in increased wear and damage to the engine and/or exhaust system.

Never refuel with marine diesel or heating oil.

Do not mix these fuels with diesel fuels and do not use any special additives, as this may result in damage.

- Use a filter when adding fuel from a fuel can. Otherwise, the fuel lines and/or the fuel injection system could be blocked by particles from the fuel can.
- Usually, you will find information about the fuel grade on the pump. If you cannot find the label on the gasoline pump, ask the gas station staff.

You can find more information under "Fuel" (⊳ page 525), or by contacting an authorized Mercedes-Benz Service Center or visiting http://www.mbusa.com (USA only).



Low outside temperatures

Do not use gasoline to refuel vehicles with a diesel engine. Never mix diesel with gasoline or kerosene, as this may result in damage to the engine or fuel system.


Diesel fuel with improved cold flow properties is available during the winter months. Further information on fuel properties can be obtained from oil companies, e.g. at gas stations.

Refueling

Fuel filler flap

The fuel filler flap is unlocked or locked automatically when you open or close the vehicle with the SmartKey or using KEYLESS-GO.

The position of the fuel filler cap is displayed in the instrument cluster ____. The arrow next to the filling pump indicates the side of the vehicle.



- 1) To open the fuel filler flap
- 2 To insert the fuel filler cap
- 3 Tire pressure table
- 4 Fuel type

Opening

- Switch off the engine.
- ► Remove the SmartKey from the ignition lock.

- KEYLESS-GO: open the driver's door. This switches the ignition to position **0**, which corresponds to having removed the SmartKey. The driver's door can be closed again.
- ► Press the fuel filler flap in the direction of arrow ①.

The fuel filler flap opens slightly.

- ▶ Open the fuel filler flap.
- ► Turn the fuel filler cap counter-clockwise and remove it.
- ▶ Insert the fuel filler cap into the holder bracket on the inside of filler flap (2).
- Completely insert the pump nozzle into the filler neck and refuel.
- ➤ Only fill the tank until the pump nozzle switches off.
- Overfilling the fuel tank could damage the fuel system.

Closing

- Replace the fuel filler cap and turn it clockwise. The fuel filler cap audibly engages.
- ► Close the fuel filler flap.
- i If you drive with the fuel filler cap open, the reserve fuel warning lamp flashes. In addition, the □□ Check Engine warning lamp may light up. A message appears in the multifunction display (▷ page 407). For further information on warning and indicator lamps in the instrument cluster, see (▷ page 427).
- Close the fuel filler flap before locking the vehicle. A locking pin otherwise prevents the fuel filler flap from closing after the vehicle has been locked.



Problems with fuel and the fuel tank	
Problem	Possible causes/consequences and ▶ Solutions
Fuel is leaking from the vehicle.	
The fuel filler flap cannot be opened.	The fuel filler flap is not unlocked. or The SmartKey battery is discharged. ▶ Unlock the vehicle (▷ page 78). or ▶ Unlock the vehicle using the mechanical key (▷ page 81).
	The fuel filler flap is unlocked, but the opening mechanism is jammed. ▶ Consult a qualified specialist workshop.
The engine will not start.	The fuel tank of a vehicle with a diesel engine has been run completely dry. ▶ Refuel the vehicle with at least 5.3 US qt (5 liters) of diesel. ▶ Turn the ignition on for at least 10 seconds (▷ page 303). ▶ Start the engine continuously for up to 10 seconds until it runs smoothly. or ▶ Start the engine via the touch-start function. To do this, turn the SmartKey to position 3 (▷ page 303) in the ignition lock and then release it immediately. If the engine does not start: ▶ Turn the ignition on again for approximately 10 seconds (▷ page 303). ▶ Start the engine again continuously for up to 10 seconds until it runs smoothly. or ▶ Start the engine again via the touch-start function. If the engine does not start after three attempts:
	► Consult a qualified specialist workshop.



DEF

Important notes on use

To function properly, BlueTEC exhaust gas aftertreatment must be operated with the reducing agent DEF. Adding DEF is one of the tasks performed during maintenance. Under normal operating conditions, a tank of DEF lasts until the next service due date.

When the DEF supply has almost run out, the Check Additive See Operator's Manual message is shown in the multifunction display.

When the DEF supply sinks to a minimum level, the Remaining Starts: 16 message is shown in the multifunction display.

When the Remaining Starts: 16 message is shown in the multifunction display, you can start the engine 16 more times. If DEF is not added, it is then not possible to start the engine again. Fill the DEF tank with about 1 gal (3.8 I) DEF or have the DEF tank refilled at a qualified specialist workshop.

Use the special DEF refill bottle when filling between maintenance intervals. Contact an authorized Mercedes-Benz Center with any questions or, if necessary, contact Roadside Assistance (⊳ page 29).

Further information about BlueTEC exhaust gas aftertreatment and DEF is available at any authorized Mercedes-Benz Center.

Adding DEF



Make sure

- DEF does not come into contact with skin. eyes, or clothing
- to keep DEF out of the reach of children

If you and/or others have come into contact with DEF:

- If DEF has gotten into contact with eyes, flush with plenty of water immediately and seek medical help.
- Clean affected skin immediately with plenty of water.
- If DEF was swallowed, rinse mouth immediately with plenty of water and drink plenty of water. Consult a physician.



↑ WARNING

If you open the DEF tank cap at high temperatures, ammonia vapors can be released.

Ammonia vapors have a pungent odor and are particularly irritating to:

- skin
- · mucous membranes

You may experience a burning sensation in your eyes, nose and throat, as well as coughing and watering of the eyes.

Do not inhale any ammonia vapors that may be released. Only refill the DEF tank in well ventilated areas.

I Only use DEF that complies with ISO 22241. Do not add any special additives to DEF and do not thin DEF with water. This could destroy the BlueTEC exhaust gas aftertreatment.

If the outside temperature is lower than -11 °C, damage may occur when topping up. If DEF is frozen and there is an active warning indicator, topping up may not be possible. Park the vehicle in a warmer place, e.g. in a garage, until DEF has become fluid again. Filling is then possible again. Alternatively, have the DEF tank refilled at a qualified specialist workshop.

Rinse surfaces that have come into contact with DEF immediately with water or remove DEF using a damp cloth and cold water. If the DEF has already crystallized,



use a sponge and cold water to clean it. DEF residues crystallize after time and contaminate the affected surfaces.


- DEF is not a fuel additive and must not be added to the fuel tank. If DEF is added to the fuel tank, this can lead to engine damage.
- 1 If you are adding between maintenance intervals, add approximately 1 gallon (3.8 I) of DEF to the DEF tank. One gallon (3.8 I) of DEF is approximately 2 DEF refill bottles. Then, have the DEF supply checked and filled completely if necessary. For this purpose, Mercedes-Benz recommends a qualified specialist workshop.

Further information on DEF (▷ page 527). The filler neck for DEF is located under the "Minispare" emergency spare wheel in the trunk floor.


- ▶ Switch off the ignition.
- ▶ Open the trunk.
- ▶ Lift up the trunk floor (▷ page 436).



- ► Turn the "Minispare" emergency spare wheel fastening in the direction of the arrow and remove it.
- ► Remove the "Minispare" emergency spare wheel.



► Turn DEF cap ① counter-clockwise and remove it.



► Turn DEF filler cap ② counter-clockwise and open it. Filler cap ② is secured with a plastic strap.



- ► Unscrew the covering cap from DEF refill bottle ③.
- ▶ Place DEF refill bottle ③ on the filler neck as shown and screw on clockwise handtight.
- Only screw on the DEF refill bottle handtight. It could otherwise be damaged.



- ▶ Press DEF refill bottle (3) down. The DEF tank is filled. This may take up to one minute.
- 1 If the DEF refill bottle is no longer pressed down, the filling process stops and the partially emptied bottle can be removed.
- ▶ Release DEF refill bottle ③.
- ► Turn DEF refill bottle ③ counter-clockwise and remove it.
- ▶ Place DEF filler cap (2) on the filler neck and turn it clockwise.



- ▶ Insert DEF cap (1) as shown and turn it clockwise as far as it will go.
- ▶ Place the "Minispare" emergency spare wheel in the emergency spare wheel well above the DEF tank.
- ▶ Insert the "Minispare" emergency spare wheel fastening and tighten clockwise.
- ► Fold the trunk floor down.
- ▶ Close the trunk lid.
- ▶ Drive at a speed above 10 mph (16 km/h). The Check Additive See Operator's Manual message goes out after approximately one minute.
- 1 If the Check Additive See Operator's Manual message remains shown in the multifunction display, add an additional bottle of DFF.
- 1 Then, have the DEF supply checked at a qualified specialist workshop and completely refilled if necessary.

Parking

Important safety notes



↑ WARNING

Do not park this vehicle in areas where combustible materials can come into contact with the hot exhaust system. Combustible materials, such as grass, hay or leaves could be ignited by the hot exhaust system and cause a vehicle fire. Do not park the vehicle on dry grassland or harvested grain fields.

Unintended vehicle movement can cause serious personal injury or damage to the vehicle or the vehicle drivetrain. To reduce such risks, always do the following before turning off the engine and leaving the vehicle:

- keep your right foot on the brake pedal.
- engage the electric parking brake.
- shift the automatic transmission into park position P.
- slowly release the brake pedal.
- when parked on an incline, always turn the front wheels towards the road curb.
- turn the SmartKey in the ignition lock to position **0** and remove the SmartKey from the ignition lock, or press the KEYLESS-GO Start/Stop button.
- take the SmartKey with you and lock the vehicle when leaving.

Switching off the engine

Important safety notes



↑ WARNING

Do not turn off the engine before the vehicle has come to a complete stop. With the engine not running, there is no power assistance for the brake and steering systems. In this case, it is important to keep in mind that a considerably higher degree of effort is necessary to brake and steer the vehicle.



↑ WARNING

Keep in mind that turning off the engine alone only will shift the automatic transmission into neutral position N automatically.

Always shift the automatic transmission into park position P before turning off the engine. Otherwise the vehicle could roll away which could result in an accident and/or serious personal injury.

1 If you cannot turn off the engine as described here, see "Engine emergency stop" (> page 487).

Vehicles with automatic transmission

- ► Apply the electric parking brake.
- ▶ Shift the transmission to position **P**.

Using the SmartKey

- ► Turn the SmartKey to position 0 in the ignition lock and remove it. The immobilizer is activated.
- 1 If you turn off the engine with the SmartKey and then remove it from the ignition lock or open a front door, the automatic transmission shifts to P automatically.

Using KEYLESS-GO

- ▶ Press the Start/Stop button (▷ page 303). The engine stops and all the indicator lamps in the instrument cluster go out.
- **1** When the driver's door is closed, this corresponds to SmartKey position 1. When the driver's door is open, it corresponds to SmartKey position **0** or "SmartKey removed".
- 1 If you use the Start/Stop button to switch off the engine, the automatic transmission shifts to N automatically. If you then open the driver's or front-passenger door, the automatic transmission shifts to P.
- 1 In an emergency, the engine can be turned off while the vehicle is in motion by

pressing and holding the Start/Stop button for three seconds. This function operates independently from the ECO start/stop automatic engine switch-off function.


Electric parking brake

General information



↑ WARNING

When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Children could release the parking brake and/or shift the automatic transmission out of park position P. either of which could result in an accident and/or serious personal injury.



Applying/releasing manually

- ► To apply: press handle (1). The red PARK (USA only) or (P) (Canada only) indicator lamp in the instrument cluster lights up.
- 1 The electric parking brake can also be applied when the SmartKey is removed.
- ▶ To release: switch on the ignition.
- ▶ Pull handle ①. The red PARK (USA only) or (P) (Canada only) indicator lamp in the instrument cluster goes out.
- 1 The electric parking brake cannot be released unless the SmartKey is in position



1 in the ignition lock or if the ignition has been switched on using the Start/Stop button.

Engaging the electric parking brake automatically

The electric parking brake is automatically applied if HOLD or DISTRONIC PLUS brakes the vehicle until it is stationary and at least one of the following conditions is fulfilled:

- the engine is switched off.
- the driver's door is open and the seat belt is not fastened.
- the hood is released.
- the trunk lid is opened while the automatic transmission is in position R.
- the vehicle is stationary for a lengthy period.

The red PARK (USA only) or (Canada only) indicator lamp in the instrument cluster lights up.

i In addition to the electric parking brake, P may also be engaged automatically.

Releasing the electric parking brake automatically

The electric parking brake is released automatically when the following conditions are simultaneously fulfilled:

- the engine is running.
- the automatic transmission is in position
 D or R.
- the hood is closed.
- your seat belt is fastened.
- you depress the accelerator pedal.

If the automatic transmission is in position **R**, the trunk lid must be closed.

If your seat belt is not fastened, the following conditions must be fulfilled to automatically release the electric parking brake:

- the driver's door is closed.
- you shift out of **P** or you have previously driven faster than 3 km/h.
- you have shifted out of P or you have previously driven faster than 2 mph (3 km/h).

Emergency braking

The vehicle can also be braked during an emergency using the electric parking brake.

- ▶ While driving, push handle ① of the electric parking brake (▷ page 324).
- 1 The vehicle is braked as long as you keep the handle of the electric parking brake pressed. The longer the electric parking brake handle is depressed, the greater the braking force.

During braking:

- a warning tone sounds.
- the Please Release Parking Brake message appears.
- the red PARK (USA only) or ((E)) (Canada only) indicator lamp in the instrument cluster lights up.

When the vehicle has been braked to a standstill, the electric parking brake is engaged.

Parking the vehicle for a long period

If you leave the vehicle parked for longer than four weeks, the battery may be damaged by exhaustive discharge.

- ► Connect a trickle charger.
- 1 You can obtain information about trickle chargers from a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.



If you leave the vehicle parked for longer than six weeks, the vehicle may suffer damage as a result of lack of use.

► Visit a qualified specialist workshop and seek advice.

Driving tips

General driving tips

Important safety notes



↑ WARNING

Always remember that you must concentrate primarily on driving the vehicle. The driver's concentration must always be directed primarily at road traffic. For your own safety and that of others, we recommend that you stop the vehicle at a safe place and in accordance with the traffic conditions before making or accepting a phone call.

Comply with all legal requirements if you use the telephone while driving. Use the handsfree system and only use the telephone when road, weather and traffic conditions permit. In some jurisdictions, it is forbidden for drivers to use mobile phones while driving.

Only operate COMAND (Cockpit Management and Data System) in compliance with all legal requirements and when the road, weather and traffic conditions permit. You may otherwise not be able to observe the traffic conditions. endangering yourself and others.

Remember that your vehicle covers a distance of 44 feet (approximately 14 m) a second when it is traveling at only 30 mph (approximately 50 km/h).

Drive sensibly - save fuel

Observe the following tips to save fuel:

- ▶ The tires should always be inflated to the recommended tire pressure.
- ► Remove unnecessary loads.
- ▶ Remove roof racks when they are not needed.

- ▶ Warm up the engine at low engine speeds.
- Avoid frequent acceleration or braking.
- ▶ Have all maintenance work carried out as indicated by the service intervals in the Service Booklet or by the service interval display.

Fuel consumption also increases when driving in cold weather, in stop-and-go traffic and in mountainous terrain.

Drinking and driving



↑ WARNING

Drinking and driving and/or taking drugs and driving are very dangerous combinations. Even a small amount of alcohol or drugs can affect your reflexes, perceptions and judgment.

The possibility of a serious or even fatal accident are greatly increased when you drink or take drugs and drive.

Do not drink or take drugs and drive or allow anyone to drive who has been drinking or taking drugs.

Pedals



↑ WARNING

Make sure absolutely no objects are obstructing the pedals' range of movement. Keep the driver's footwell clear of all obstacles. If there are any floormats or carpets in the footwell, make sure that the pedals still have sufficient clearance.

During sudden driving or braking maneuvers, the objects could get caught between the pedals. You could then no longer brake or accelerate. This could lead to accidents and iniurv.

Rolling with the engine switched off



↑ WARNING

There is no power assistance for the steering and the brake when the engine is not running.



Steering and braking requires significantly more effort and you could lose control of the vehicle and cause an accident as a result.

Do not turn off the engine while the vehicle is in motion.

Exhaust check



↑ WARNING

Inhalation of exhaust gas is hazardous to your health. All exhaust gas contains carbon monoxide (CO), and inhaling it can cause unconsciousness and possible death.

Do not run the engine in confined areas (such as a garage) which are not properly ventilated. If you think that exhaust gas fumes are entering the vehicle while driving, have the cause determined and corrected immediately. If you must drive under these conditions, drive only with at least one window fully open at all times.

Certain engine systems are designed to keep the level of poisonous components in exhaust fumes within legal limits.

These systems only work at peak efficiency when they are maintained exactly in accordance with the manufacturer's specifications. For this reason, all work on the engine must be carried out only by qualified and authorized Mercedes-Benz technicians.

The engine settings must not be changed in any circumstances. Furthermore, all specific service work must be carried out at regular intervals and in accordance with the Mercedes-Benz service requirements. Details can be found in the Service Booklet.

Brakes

Important safety notes



↑ WARNING


On slippery road surfaces, never downshift in order to obtain braking action. This could result in drive wheel slip and reduced vehicle control. Your vehicle's ABS will not prevent this type of loss of control.



↑ WARNING

Make sure that you do not endanger other road users when you apply the brakes.

Downhill gradients



When you take advantage of the engine braking effect, a drive wheel may not turn for some time, e.g. on a slippery road surface. This could cause damage to the drive train. This type of damage is not covered by the Mercedes-Benz warranty.

Heavy and light loads



↑ WARNING

Depressing the brake pedal constantly results in excessive and premature wear to the brake pads.

It may also cause the brakes to overheat, seriously impairing their effectiveness. It may then not be possible to stop the vehicle in sufficient time to avoid an accident.

If the brakes have been subjected to a heavy load, do not stop the vehicle immediately, but drive on for a short while. This allows the airflow to cool the brakes more quickly.

Wet roads



★ WARNING

After driving in heavy rain for some time without applying the brakes or through water deep enough to wet brake components, the first braking action may be somewhat reduced. You have to depress the brake pedal



more firmly. Maintain a safe distance from vehicles in front.

After driving on a wet road or having the vehicle washed, brake firmly while paying attention to the traffic conditions. This will warm up the brake discs, thereby drying them more quickly and protecting them against corrosion.

Limited braking performance on salt treated roads

↑ WARNING

The layer of salt on the brake discs and the brake pads/linings may cause a delay in the braking effect, resulting in a significantly longer braking distance, which could lead to an accident.

To avoid this danger, you should:

- · occasionally brake carefully, without putting other road users at risk, when you are driving on salted roads. This helps to remove any salt that may have started to build up on the brake discs and the brake pads/linings.
- maintain a greater distance to the vehicle ahead and drive with particular care.
- carefully apply the brakes at the end of a trip and immediately after commencing a new trip, so that salt residues are removed from the brake discs.

Servicing the brakes

Center.

If the red brake warning lamp lights up in the instrument cluster and you hear a warning tone while the engine is running, the brake fluid level may be too low. Observe additional warning messages in the multifunction display.

The brake fluid level may be too low due to brake pad wear or leaking brake lines. Have the brake system checked immediately. This work should be carried out at an authorized Mercedes-Benz

All checks and maintenance work on the brake system must be carried out at a qualified specialist workshop. This work should be carried out at an authorized Mercedes-Benz Center.

Have the brake pads replaced and the brake fluid renewed at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.

♠ WARNING

If brake pads or brake fluid other than those recommended are used, the braking properties of the vehicle can be degraded to an extent that safe braking is substantially impaired. This could result in an accident.

- Vehicles with 4MATIC: function or performance tests may only be carried out on a 2-axle dynamometer. If you are planning to have the vehicle tested on such a dynamometer, contact an authorized Mercedes-Benz Center to obtain further information first. Otherwise, you could damage the drive train or the brake system.
- Vehicles with 4MATIC: as the ESP® system operates automatically, the engine and the ignition must be switched off (SmartKey in position **0** or **1** in the ignition lock or Start/Stop button in position **0** or 1) when the electric parking brake is being tested on a brake dynamometer.

Braking maneuvers triggered automatically by ESP® may seriously damage the brake system.

- Vehicles with 4MATIC: as the ESP® system operates automatically, the engine and the ignition system must be switched off (SmartKey in position 0 or 1 in the ignition lock or Start/Stop button in position 0 or 1) when:
 - · testing the electric parking brake on a brake dynamometer.
 - you intend to have the vehicle towed with one of the axles raised.



Braking maneuvers triggered automatically by ESP® may seriously damage the brake svstem.

If your brake system is subject only to moderate loads, you should test the functionality of your brakes at regular intervals by pressing firmly on the brake pedal at high speeds. This improves the grip of the brake pads.



/ WARNING

Make sure that you do not endanger other road users when you apply the brakes.

You can find a description of Brake Assist (BAS) on (▷ page 70) or of BAS PLUS on (⊳ page 70).

High-performance brake system for **AMG** vehicles

The high-performance brake system is installed only on the S 63 AMG and S 65 AMG.

↑ WARNING

New vehicle brake pads and discs, and replacement brake pads and discs may take several hundred miles of driving until they provide optimum braking efficiency. Until that time, you may need to use increased brake pedal pressure while braking. Please be aware of this and adjust your driving and braking accordingly during this break-in period.

Excessive high-demand braking will cause correspondingly high brake wear. Please be attentive to the brake warning lamp in the instrument cluster and brake condition messages in the multifunction display. Especially for high performance driving, it is important to maintain and have the brake system checked regularly.

The high-performance brake system is designed for heavy loads. This may lead to noise when braking. This will depend on:

- speed
- · braking force
- environmental conditions, such as temperature and humidity

The wear of individual components of the brake system, such as the brake pads/linings or brake discs, depends on the individual driving style and operating conditions. For this reason, it is impossible to state a mileage that will be valid under all circumstances. An aggressive driving style will lead to high wear. You can obtain further information about this from your authorized Mercedes-Benz Center.

Driving on wet roads

Hydroplaning

If water has accumulated to a certain depth on the road surface, there is a danger of hydroplaning occurring, even if:

- you drive at low speeds.
- the tires have adequate tread depth.

For this reason, in the event of heavy rain or in conditions in which hydroplaning can occur you must drive in the following manner:

- reduce your speed
- · avoid ruts
- brake carefully

Driving on flooded roads

Do not drive through flooded areas. Check the depth of any water before driving through it. Drive slowly through standing water. Otherwise, water may enter the vehicle interior or the engine compartment. This can damage the electronic components in the engine or the automatic transmission. Water can also be drawn in



by the engine's air suction nozzles and this can cause engine damage.

Winter driving

General notes



↑ WARNING

If the vehicle becomes trapped in snow, ensure that snow is kept away from the exhaust pipe and from around the vehicle as long as the engine is running. Otherwise, poisonous carbon monoxide (CO) may enter the vehicle, resulting in loss of consciousness and even death.

To assure sufficient fresh air ventilation, open a window slightly on the side of the vehicle not facing the wind.

At the onset of winter, have your vehicle winterproofed at a qualified specialist workshop, e.g. at an authorized Mercedes-Benz Center.

Observe the notes in the "Winter operation" section (⊳ page 492).

Driving with summer tires

Observe the notes in the "Winter operation" section (⊳ page 492).

Slippery road surfaces



♠ WARNING

The outside temperature indicator is not designed to serve as an ice-warning device and is therefore unsuitable for that purpose. Indicated temperatures just above the freezing point do not guarantee that the road surface is free of ice. The road may still be icy, especially in wooded areas or on bridges.



↑ WARNING

On slippery road surfaces, never downshift in order to obtain braking action. This could result in drive wheel slip and reduced vehicle control. Your vehicle's ABS will not prevent this type of loss of control.

Drive particularly carefully on slippery road surfaces. Avoid sudden acceleration, steering and braking maneuvers. Do not use cruise control or DISTRONIC PLUS.

If the vehicle threatens to skid or cannot be stopped when moving at low speed:

- ▶ Shift the transmission to position **N**.
- for more information on driving with snow chains, see (⊳ page 493).



↑ WARNING

Make sure that you do not endanger other road users when you apply the brakes.

Driving systems

Cruise control

Important safety notes

Cruise control maintains a constant road speed for you. It brakes automatically in order to avoid exceeding the set speed. On long and steep downhill gradients, especially if the vehicle is laden, you must select shift range 1, 2 or 3 in good time. By doing so, you will make use of the braking effect of the engine, which relieves the load on the brake system and prevents the brakes from overheating and wearing too quickly.

Use cruise control only if road and traffic conditions make it appropriate to maintain a steady speed for a prolonged period. You can set any road speed above 20 mph (30 km/h).



↑ WARNING

The cruise control is a convenience system designed to assist the driver during vehicle operation. The driver is and must always remain responsible for the vehicle's speed and for safe brake operation.




Only use the cruise control if the road, traffic, and weather conditions make it advisable to travel at a constant speed.

- The use of the cruise control can be dangerous on winding roads or in heavy traffic because conditions do not allow safe driving at a constant speed.
- The use of the cruise control can be dangerous on slippery roads. Rapid changes in tire traction can result in wheel spin and loss of control.
- Deactivate the cruise control when driving in fog.

The "Resume" function should only be operated if the driver is fully aware of the previously set speed and wishes to resume this particular preset speed.

Cruise control lever



- 1) To switch on or to increase the speed
- (2) To switch on or to reduce the speed
- ③ To deactivate cruise control
- (4) To switch on with the current speed or with the last stored speed

When you activate cruise control, the stored speed is shown in the multifunction display for five seconds and is indicated in the speedometer by a triangle. The speedometer dial lights up between the set speed and the maximum speed.

Storing and maintaining the current speed

You can store the current speed if you are driving faster than 20 mph (30 km/h).

- ► Accelerate the vehicle to the desired speed.
- ► Briefly press the cruise control lever up (1) or down (2).
- ▶ Remove your foot from the accelerator pedal.
 - Cruise control is activated. The vehicle automatically maintains the speed.
- 1 Cruise control may be unable to maintain the stored speed on uphill gradients. The stored speed is resumed when the gradient evens out. Cruise control maintains the stored speed on downhill gradients by automatically applying the brakes.

Storing the current speed or calling up the last stored speed

↑ WARNING

The set speed stored in memory should only be set again if prevailing road conditions and legal speed limits permit. Possible acceleration or deceleration differences arising from returning to the preset speed could cause an accident and/or serious injury to you and others.

- ▶ Briefly pull the cruise control lever towards you (4).
- ► Remove your foot from the accelerator pedal.

The first time cruise control is activated, it stores the current speed or regulates the speed of the vehicle to the previously stored speed.



Setting a speed



↑ WARNING

Keep in mind that it may take a brief moment until the vehicle has made the necessary adjustments.

Increase or decrease the set vehicle speed to a value that the prevailing road conditions and legal speed limits permit. Otherwise, sudden and unexpected acceleration or deceleration of the vehicle could cause an accident and/ or serious injury to you and others.

- ▶ Press the cruise control lever up (1) for a higher speed or down (2) for a lower speed.
- ► Keep the cruise control lever pressed until the desired speed is reached.
- ▶ Release the cruise control lever. The new speed is stored.
- 1 Cruise control is not deactivated if you depress the accelerator pedal. For example, if you accelerate briefly to overtake, cruise control adjusts the vehicle's speed to the last speed stored after you have finished overtaking.

Making adjustments in 1 mph (Canada: 1 km/h) increments

▶ Briefly press the cruise control lever to the pressure point, up (1) for a higher speed or down (2) for a lower speed. The last speed stored is increased or reduced.

Making adjustments in 5 mph (Canada: 10 km/h) increments

► Briefly press the cruise control lever beyond the pressure point, up (1) for a higher speed or down (2) for a lower speed. The last speed stored is increased or reduced.

Deactivating cruise control

There are several ways to deactivate cruise control:

► Briefly press the cruise control lever forwards (3).

or

▶ Brake.

Cruise control is automatically deactivated if:

- you engage the electric parking brake.
- you are driving below 20 mph (30 km/h).
- ESP® intervenes or you deactivate ESP®.
- you shift the transmission to position N while driving.

If cruise control is deactivated, you will hear a warning tone. You will see the Cruise Control Off message in the multifunction display for approximately five seconds.

1 The last speed stored is cleared when you switch off the engine.

DISTRONIC PLUS

Important safety notes

DISTRONIC PLUS regulates the speed and automatically helps you maintain the distance to the vehicle detected in front. It brakes automatically in order to avoid exceeding the set speed.

On long and steep downhill gradients, especially if the vehicle is laden, you must select shift range 1, 2 or 3 in good time. By doing so, you will make use of the braking effect of the engine, which relieves the load on the brake system and prevents the brakes from overheating and wearing too quickly. If a slower-moving vehicle is detected in front. DISTRONIC PLUS causes your vehicle to brake and maintain a preset distance to the vehicle in front.

♠ WARNING

HYBRID vehicles: It is imperative that you read the HYBRID Supplemental Operating



Instructions included in your vehicle literature portfolio. You may otherwise not receive all necessary safety information and warning for the operation of your vehicle.

↑ WARNING

The DISTRONIC PLUS requires familiarity with its operational characteristics. We strongly recommend that you review the following information carefully before operating the system.

↑ WARNING

When DISTRONIC brakes, the brake pedal is pulled back (i.e. operated automatically). The area around the pedal must not be blocked by obstacles:

- do not place any objects in the footwell.
- ensure that floormats and carpets are fixed securely. In particular, do not place several floormats on top of one another.
- do not place your foot under the brake pedal, as it could become trapped.

Non-compliance could lead you to cause an accident in which you and/or others could be seriously injured.

♠ WARNING

The DISTRONIC PLUS is a convenience system. Its speed adjustment reduction capability is intended to make cruise control more effective and usable when traffic speeds vary. It is not however, intended to, nor does it, replace the need for extreme care.

The responsibility for the vehicle's speed, distance to the preceding vehicle and, most importantly, brake operation to ensure a safe stopping distance, always remains with the driver.

The DISTRONIC PLUS cannot take street and traffic conditions into account.

Complex driving situations are not always fully recognized by the DISTRONIC PLUS. This could result in wrong or missing distance warnings.

If you want DISTRONIC PLUS to assist you, the radar sensor system must be activated (▷ page 387) and operational.

If there is no vehicle driving in front of you, DISTRONIC PLUS functions like cruise control at a speed range between 20 mph (Canada: 30 km/h) and 120 mph (Canada: 200 km/h). If a vehicle is driving in front of you, it functions at a speed range between 0 mph (0 km/h) and 120 mph (Canada: 200 km/h).

Do not use DISTRONIC PLUS while driving on roads with steep gradients.

As DISTRONIC PLUS transmits radar waves. it can resemble the radar detectors of the responsible authorities. You can refer to the applicable section in the Operator's Manual if there are any questions concerning this.



USA only:

This device has been approved by the FCC as a "Vehicular Radar System". The radar sensor is intended for use in an automotive radar system only. Removal, tampering, or altering of the device will void any warranties, and is not permitted by the FCC. Do not tamper with, alter, or use in any non-approved way.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

↑ WARNING

The DISTRONIC PLUS adaptive cruise control is not a substitute for active driving involvement. It does not react to pedestrians or on stationary objects, nor does it recognize or predict the curvature and lane layout or the movement of preceding vehicles. The DISTRONIC PLUS can only apply a maximum of 40% of the vehicle's braking power.

The DISTRONIC PLUS may not detect narrow vehicles possibly driving in front of you, such as motorcycles and vehicles driving in an offset formation.

It is the driver's responsibility at all times to be attentive to the road, weather and traffic



conditions. Additionally, the driver must provide the steering, braking and other driving inputs necessary to remain in control of the vehicle.

High-frequency sources such as toll stations, speed measuring systems etc. can cause the DISTRONIC PLUS system to temporarily cease functioning.

↑ WARNING

The DISTRONIC PLUS cannot take road and traffic conditions into account. Only use the DISTRONIC PLUS if the road, weather and traffic conditions make it advisable to travel at a constant speed.

↑ WARNING

Use of the DISTRONIC PLUS can be dangerous on slippery roads. Rapid changes in tire traction can result in wheel spin and loss of control.

The DISTRONIC PLUS does not function in adverse sight and distance conditions. Do not use the DISTRONIC PLUS during conditions of fog, heavy rain, snow or sleet.

↑ WARNING

The DISTRONIC PLUS cannot take weather conditions into account. Switch off the DISTRONIC PLUS or do not switch it on if:

- roads are slippery or covered with snow or ice. The wheels could lose traction while braking or accelerating, and the vehicle could skid.
- the DISTRONIC PLUS system sensor covers are dirty or visibility is diminished due to snow, rain or fog, for example. The distance control system functionality could be impaired.

Always pay attention to surrounding traffic conditions even while the DISTRONIC PLUS is switched on. Otherwise, you may not be able to recognize dangerous situations until it is too late. This could cause an accident in which you and/or others could be injured.

↑ WARNING

The "Resume" function should only be operated if the driver is fully aware of the previously set speed and wishes to resume this particular preset speed.

↑ WARNING

Your undivided attention to street and traffic conditions is necessary at all times whether DISTRONIC PLUS is active or not.

The use of DISTRONIC PLUS can be dangerous on winding roads or in heavy traffic because conditions do not allow safe driving at a constant speed.

DISTRONIC PLUS does not react to stationary objects on the road (for example, a vehicle stopped in traffic or an abandoned vehicle). DISTRONIC PLUS likewise does not react to oncoming vehicles.

Deactivate DISTRONIC PLUS:

- when changing to the right lane, if the vehicles in the left lane are driving slower
- · when driving into a filter lane or an expressway exit
- in complex driving situations, for example in construction sites on an expressway In these situations DISTRONIC PLUS will maintain the set speed if it is not deactivated. DISTRONIC PLUS is intended only for maintaining a set speed and a set distance from the objects moving in front of the vehicle.

↑ WARNING

An intermittent warning sounds and the distance warning lamp in the instrument cluster is illuminated if the DISTRONIC PLUS system calculates that the distance to the vehicle ahead and your vehicle's current speed indicate that the DISTRONIC PLUS will not be capable of slowing the vehicle sufficiently to maintain the preset following distance, which creates a danger of a collision.



Immediately brake the vehicle to increase your distance to the preceding vehicle. The warning sound is intended as a final caution in which you should intercede with your own braking inputs to avoid a potentially dangerous situation. Do not wait for the operation of the warning signal to intercede with your own braking. This will result in potentially dangerous emergency braking which will not always result in an impact being avoided.

Tailgating increases the risk of an accident.

DISTRONIC PLUS brakes your vehicle with a maximum deceleration of 13 ft/s 2 (4 m/s 2). This is equivalent to approximately 40 % of your vehicle's maximum possible deceleration.


You need to brake yourself to prevent a collision. DISTRONIC PLUS brakes the vehicle to restore the set distance from the vehicle ahead or the set speed.

↑ WARNING

If you do not receive visual or acoustic warning signals during a critical traffic situation, DISTRONIC PLUS has either not recognized the collision risk, has been deactivated or is malfunctioning.

Remember, whether or not DISTRONIC PLUS is operating, it is ultimately always the drivers responsibility to apply the brakes in order to control the vehicle and avoid a collision.

Cruise control lever



- 1) To store the current speed or a higher speed
- (2) To store the current speed or a lower speed
- (3) To deactivate DISTRONIC PLUS
- (4) To store the current speed or to call up the last stored speed
- (5) To set the specified minimum distance

Switching on DISTRONIC PLUS, storing the current speed and maintaining it

Important safety notes



↑ WARNING

The vehicle can be braked when DISTRONIC PLUS is activated. For this reason, deactivate DISTRONIC PLUS if the vehicle is to be set in motion by other means (e.g. in a car wash or by towing).

In order to activate DISTRONIC PLUS, the following conditions must be fulfilled:

- the engine must be started. It may take up to two minutes after pulling away before DISTRONIC PLUS is operational.
- the electric parking brake must be released.
- ESP® must be activated but not intervening.
- the transmission must be in position **D**.
- the hood must be closed.



- the driver's door must be closed when you shift from P to D or your seat belt must be fastened.
- the front-passenger door and rear doors must be closed.
- the vehicle must not skid.

Activating while driving

When driving at speeds below 20 mph (30 km/h), you can only activate DISTRONIC PLUS if the vehicle in front has been detected. and is shown in the multifunction display. If the vehicle in front is no longer detected and shown, DISTRONIC PLUS is deactivated and a warning tone sounds.

- ▶ Briefly pull the cruise control lever towards you (4), or briefly press up (1) or down (2). DISTRONIC PLUS is selected.
- ► Keep the cruise control lever pressed up (1) or down (2) until the desired speed is set.
- ▶ Remove your foot from the accelerator pedal.
 - Your vehicle adapts its speed to that of the vehicle in front, but only up to the desired stored speed.
- f you do not fully release the accelerator pedal, the DISTRONIC PLUS Override message is shown in the multifunction display. The set distance to a slowermoving vehicle in front will then not be maintained. You will be driving at the speed you determine by the position of the accelerator pedal.

Activating when driving towards a stationary vehicle

If the vehicle in front of you is stationary, you can only activate DISTRONIC PLUS once your vehicle is stationary as well.

- ▶ Briefly pull the cruise control lever towards you (4), or briefly press up (1) or down (2). DISTRONIC PLUS is selected.
- 1 DISTRONIC PLUS can only be activated at under 20 mph (30 km/h) if a vehicle in front

- has been detected. Therefore, the DISTRONIC PLUS distance display in the instrument cluster should be activated (⊳ page 383).
- ► Keep the cruise control lever pressed up (1) or down (2) until the desired speed is set.
- 1 You can use the cruise control lever to set the stored speed and the control on the cruise control lever to set the specified minimum distance (⊳ page 338).

Pulling away

- ▶ If the vehicle in front pulls away: remove your foot from the brake pedal.
- ▶ Briefly pull the cruise control lever towards you (4).

or

▶ Accelerate briefly.

Your vehicle pulls away and adapts its speed to that of the vehicle in front.

Driving

If there is no vehicle in front, DISTRONIC PLUS operates in the same way as cruise control.

If a slower-moving vehicle is detected in front, DISTRONIC causes your vehicle to brake. This maintains the preset distance to the vehicle in front.

If DISTRONIC PLUS detects a faster-moving vehicle in front, it increases the driving speed of your vehicle, but only up to the desired speed you have stored.

↑ WARNING

If you depress the brake, DISTRONIC PLUS is deactivated unless your vehicle is stationary. DISTRONIC PLUS then no longer brakes your vehicle. In such cases, control the distance from vehicles travelling in front with the brake alone. You could otherwise cause an accident and thereby injure yourself and others. The driver remains fully responsible for the vehicle's distance from other vehicles, the



speed being driven and for braking in good time.

Changing lanes

If you wish to change to the passing lane (in left-hand-drive vehicles, the passing lane is the left-hand lane). DISTRONIC PLUS supports you if:

- you are driving faster than 40 mph (60 km/h).
- . DISTRONIC PLUS is maintaining the distance to a vehicle in front.
- you switch on the appropriate turn signals.
- DISTRONIC PLUS does not detect a danger of collision.

If these conditions are met, your vehicle is accelerated. Acceleration will be interrupted if changing lanes takes too long or if the distance between your vehicle and the vehicle in front becomes too small.

↑ WARNING

DISTRONIC PLUS and Active Blind Spot Assist are only aids designed to assist driving.

They do not relieve you of the responsibility of paying attention. The driver remains fully responsible for the vehicle's distance from other vehicles, the vehicle's speed and for braking in good time. Always pay attention to traffic conditions and your surroundings. Otherwise, you may fail to recognize dangers in time, cause an accident and injure yourself and others.

Stopping



♠ WARNING

Never get out of the vehicle when DISTRONIC PLUS is activated.

DISTRONIC PLUS must also never be operated, activated or deactivated by a passenger or from outside the vehicle.

DISTRONIC PLUS does not replace the electric parking brake and must not be used for parking.

The DISTRONIC PLUS braking effect is canceled and the vehicle can start moving if:

- DISTRONIC PLUS is deactivated using the cruise control lever.
- · you accelerate.
- there is a malfunction in the system or an interruption in the power supply, e.g. battery failure.
- the electrical system in the engine compartment, the battery or the fuses are tampered with.
- the battery is disconnected.

If you wish to leave the vehicle or park it, deactivate DISTRONIC PLUS and secure the vehicle against rolling away.

If DISTRONIC PLUS detects that the vehicle in front is stopping, it brakes your vehicle until it is stationary.

Once your vehicle is stationary, it remains stationary and you do not need to depress the brake.

- **1** After a time, the electric parking brake secures the vehicle and relieves the service brake.
- 1 Depending on the specified minimum distance, your vehicle will come to a standstill at a sufficient distance behind the vehicle in front. The specified minimum distance is set using the control on the cruise control lever.

Setting a speed



↑ WARNING

Keep in mind that it may take a brief moment until the vehicle has made the necessary adjustments.

Increase or decrease the set vehicle speed to a value that the prevailing road conditions and legal speed limits permit. Otherwise, sudden and unexpected acceleration or deceleration of the vehicle could cause an accident and / or serious injury to you and others.



- ► Press the cruise control lever up ① for a higher speed or down ② for a lower speed.
- ► Keep the cruise control lever pressed until the desired speed is reached.
- ► Release the cruise control lever. The new speed is stored. DISTRONIC PLUS is activated and adjusts the vehicle's speed to the new speed stored.

Making adjustments in 1 mph (Canada: 1 km/h) increments

▶ Briefly press the cruise control lever to the pressure point, up ① for a higher speed or down ② for a lower speed.

The last speed stored is increased or reduced.

Making adjustments in 5 mph (Canada: 10 km/h) increments

▶ Briefly press the cruise control lever beyond the pressure point, up ① for a higher speed or down ② for a lower speed. The last speed stored is increased or reduced.

Storing the current speed or calling up a stored speed

↑ WARNING

The set speed stored in memory should only be set again if prevailing road conditions and legal speed limits permit. Possible acceleration or deceleration differences arising from returning to the preset speed could cause an accident and/or serious injury to you and others.

- ▶ Briefly pull the cruise control lever towards you ④.
- ► Remove your foot from the accelerator pedal.


DISTRONIC PLUS is activated. The first time it is activated, the current speed is stored. Otherwise, it sets the vehicle cruise speed to the previously stored value.

Sets the specified minimum distance

You can set the specified minimum distance for DISTRONIC PLUS by varying the time span between one and two seconds. With this function, you can set the minimum distance that DISTRONIC PLUS keeps to the vehicle in front, dependent on vehicle speed. You can see this distance in the multifunction display (> page 339).

↑ WARNING

It is up to the driver to exercise discretion to select the appropriate setting given road conditions, traffic, driver's preferred driving style and applicable laws and driving recommendations for safe following distance.




► To increase: turn control ② in direction ③.

DISTRONIC PLUS then maintains a greater distance between your vehicle and the vehicle in front.

- ▶ To decrease: turn control ② in direction ①. DISTRONIC PLUS then maintains a shorter distance between your vehicle and the vehicle in front.
- Make sure that you maintain a sufficient and safe distance from the vehicle in front. Adjust the distance to the vehicle in front if necessary.



DISTRONIC PLUS displays in the speedometer



When you switch on DISTRONIC PLUS, triangle (2) shows the stored speed.

• For design reasons, the speed displayed in the speedometer may differ slightly from the speed set for DISTRONIC PLUS.

If DISTRONIC PLUS detects a vehicle in front, the speedometer dial lights up between speed of the vehicle in front ① and stored speed ②.

DISTRONIC PLUS displays in the multifunction display


General notes

You can select the distance display in the Assistance menu (▷ page 383) of the onboard computer.

Display when DISTRONIC PLUS is deactivated

► Select the Distance Display function using the on-board computer (> page 383).

When DISTRONIC PLUS is deactivated, you will see the following in the multifunction display:




- ① Symbol for activated PRE-SAFE® Brake
- (2) Vehicle in front, if detected
- ③ Distance indicator, current distance to the vehicle in front
- ④ Specified minimum distance to the vehicle in front; adjustable
- Own vehicle

Display when DISTRONIC PLUS is activated

► Select the Distance Display function using the on-board computer (> page 383).


You will see the stored speed for about five seconds when you activate DISTRONIC PLUS. After this time, you will see the following in the multifunction display while DISTRONIC PLUS is activated:



- ① DISTRONIC PLUS activated
- 2 Own vehicle
- ③ Specified minimum distance to the vehicle in front; adjustable
- (4) Vehicle in front, if detected



Deactivating DISTRONIC PLUS



There are several ways to deactivate DISTRONIC PLUS:

▶ Briefly press the cruise control lever forwards ①.

۸r

▶ Brake, unless the vehicle is stationary.

When you deactivate DISTRONIC PLUS, the DISTRONIC PLUS Off message is shown in the multifunction display for approximately five seconds.

- 1 The last speed stored remains stored until you switch off the engine.
- DISTRONIC PLUS is not deactivated if you depress the accelerator pedal. If you accelerate to overtake, DISTRONIC PLUS adjusts the vehicle's speed to the last speed stored after you have finished overtaking.

DISTRONIC PLUS is automatically deactivated if:

- you engage the electric parking brake or if the vehicle is automatically secured with the electric parking brake.
- you are driving slower than 15 mph (25 km/h) and there is no vehicle in front, or if the vehicle in front is no longer detected.
- ESP® intervenes or you deactivate ESP®.
- the transmission is in the P, R or N position.
- you switch off the radar sensor system (> page 387).

- you pull the cruise control lever towards you in order to pull away and the frontpassenger door or one of the rear doors is open.
- the vehicle has skidded.

If DISTRONIC PLUS is deactivated, you will hear a warning tone. The DISTRONIC PLUS Off message is shown in the multifunction display for approximately five seconds.

↑ WARNING

The DISTRONIC PLUS switches off and releases the brakes when the vehicle decelerates below the minimum speed of 20 mph (30 km/h) by operation of the system unless the DISTRONIC PLUS detects a vehicle directly ahead of you. At that time the driver must apply the brakes in order to reduce vehicle speed further or bring it to a stop.

Tips for driving with DISTRONIC PLUS

Important safety notes

The following contains descriptions of certain road and traffic conditions in which you must be particularly attentive. In such situations, brake if necessary. DISTRONIC PLUS is then deactivated.

\triangle

The DISTRONIC PLUS works to maintain the speed selected by the driver unless a moving obstacle proceeding directly ahead of it in the same travel direction is detected (e.g. following another vehicle ahead of you at your set distance).

This means that:

- Your vehicle can pass another vehicle after you have changed lanes.
- While in a sharp turn or if the preceding vehicle is in a sharp turn, the DISTRONIC PLUS could lose sight of the preceding vehicle. Your vehicle could then accelerate to the previously selected speed.



The DISTRONIC PLUS regulates only the distance between your vehicle and those directly ahead of it. It may not register stationary objects in the road, e.g.:

- a stopped vehicle in a traffic jam
- · a disabled vehicle
- an oncoming vehicle


The driver must always be alert, observe all traffic and intercede as required by means of steering or braking the vehicle.



↑ WARNING


The DISTRONIC PLUS should not be used in snowy or icy road conditions.

Cornering, going into and coming out of a bend




The ability of DISTRONIC PLUS to detect vehicles when cornering is limited. Your vehicle may brake unexpectedly or late.

Vehicles traveling on a different line




DISTRONIC PLUS may not detect vehicles traveling on a different line. The distance to the vehicle in front will be too short.

Other vehicles changing lane



DISTRONIC PLUS has not detected the vehicle cutting in yet. The distance to this vehicle will be too short.


Narrow vehicles



DISTRONIC PLUS has not yet detected the vehicle in front on the edge of the road, because of its narrow width. The distance to the vehicle in front will be too short.




Obstructions and stationary vehicles



DISTRONIC PLUS does not brake for obstacles or stationary vehicles. If, for example, the detected vehicle turns a corner and reveals an obstacle or stationary vehicle, DISTRONIC PLUS will not brake for these.

Crossing vehicles



DISTRONIC PLUS may mistakenly detect vehicles that are crossing your lane. Activating DISTRONIC PLUS at traffic lights with crossing traffic, for example, could cause your vehicle to pull away unintentionally.

HOLD function

General notes

The HOLD function can assist the driver in the following situations:

- when pulling away, especially on steep slopes
- when maneuvering on steep slopes
- · when waiting in traffic

The vehicle is kept stationary without the driver having to depress the brake pedal.

The braking effect is canceled and the HOLD function deactivated when you depress the accelerator pedal to pull away.

↑ WARNING

HYBRID vehicles: It is imperative that you read the HYBRID Supplemental Operating Instructions included in your vehicle literature portfolio. You may otherwise not receive all necessary safety information and warning for the operation of your vehicle.

Activation conditions

You can activate the HOLD function if:

- the vehicle is stationary.
- the driver's door is closed or your seat belt is fastened.
- the electric parking brake is released.
- the hood is closed.
- the transmission is in position R, N or D.
 The trunk lid must be closed in position R.
- · DISTRONIC PLUS is deactivated.

Activating the HOLD function

- Make sure that the activation conditions are met.
- ▶ Depress the brake pedal.



 Quickly depress the brake pedal further until HOLD display 1 appears in the instrument cluster.

The HOLD function is activated. You can release the brake pedal.



1 If depressing the brake pedal the first time does not activate the HOLD function, wait briefly and then try again.

♠ WARNING

The vehicle's brakes are applied when the HOLD function is activated. For this reason. deactivate the HOLD function if the vehicle is to be set in motion by other means (e.g. in a car wash or by towing).

Deactivating the HOLD function

The HOLD function is deactivated automatically if:

- you accelerate and the transmission is in position D or R.
- you shift the transmission to position P.
- you apply the brakes again with a certain amount of pressure until HOLD disappears from the instrument cluster.
- you secure the vehicle using the electric parking brake.
- you activate DISTRONIC PLUS.
- 1 After a time, the electric parking brake secures the vehicle and relieves the service brake.



♠ WARNING

Never get out of the vehicle when the HOLD function is activated.

The HOLD function must never be operated or deactivated by a passenger or from outside the vehicle.

The HOLD function does not replace the electric parking brake and must not be used for parking.

The braking effect of the HOLD function is canceled and the vehicle could roll away if:

- the HOLD function is deactivated by depressing the accelerator pedal or the brake pedal.
- there is a malfunction in the system or an interruption in the power supply, e.g. battery failure.

- the electrical system in the engine compartment, the battery or the fuses are tampered with.
- the battery is disconnected.

AIRMATIC

Vehicle level

Important safety notes

Your vehicle regulates its height automatically. All-round self-leveling ensures the best possible suspension and constant ground clearance, even with a laden vehicle. When you drive fast, the vehicle is lowered automatically to improve driving safety and to reduce fuel consumption.

The following vehicle levels are possible on vehicles without 4MATIC:

- normal
- raised: the vehicle is raised by about 1.00 in (25 mm) when compared with the normal
- lowered: the vehicle is lowered by about 0.60 in (15 mm) when compared with the normal level

The following vehicle levels are possible on vehicles with 4MATIC:

- normal: in Comfort mode, the vehicle is raised by about 0.40 in (10 mm) when compared with Sport mode
- raised: in Comfort mode, the vehicle is raised by about 0.60 in (15 mm) and in Sport mode by about 1.00 in (25 mm) when compared with normal level
- lowered: the vehicle is lowered by about 0.40 in (10 mm) when compared with the normal level

The "Normal" and "Raised" vehicle levels can be set manually.



The "Lowered" vehicle level is set automatically:

- in vehicles without 4MATIC at speeds above 60 mph (100 km/h)
- in vehicles with 4MATIC at speeds above 50 mph (80 km/h)

Setting the vehicle level

Select the "Normal" setting for normal road surfaces and "Raised" for driving with snow chains or on particularly poor road surfaces. Your selection remains stored even if you remove the SmartKey from the ignition lock.

↑ WARNING

To help avoid personal injury, keep hands and feet away from wheel housing area, and stay away from under the vehicle when lowering the vehicle chassis.



Setting raised level

► Start the engine.

If indicator lamp ② is not lit:

► Press button ①.
Indicator lamp ② lights up. The vehicle height is adjusted to raised level.

The Vehicle rising message appears in the multifunction display.

The "Raised level" setting is canceled if you:

- drive at speeds above approximately 75 mph (120 km/h)
- drive about 3 minutes at speeds above 50 mph (80 km/h)

The "Raised level" remains active when you are not driving within these speed ranges.

Setting the normal level

Start the engine.

If indicator lamp ② is lit:

Press button ①. Indicator lamp ② goes out. The vehicle is adjusted to normal level.

Suspension tuning

General notes

The Adaptive Damping System (ADS) automatically controls the calibration of the dampers and springs.

The damping is tuned individually to each wheel and depends on:

- · your driving style, e.g. sporty
- the road surface condition, e.g. bumps
- your individual selection, i.e. sports or comfort

Your selection remains stored even if you remove the SmartKey from the ignition lock.



Sports tuning

The firmer suspension tuning in Sport mode ensures even better contact with the road. Select this mode when employing a sporty driving style, e.g. on winding country roads.

▶ If indicator lamp ② is not lit: press button ①.

Indicator lamp ② lights up. Sports suspension tuning is selected.



The AIRMATIC SPORT message appears in the multifunction display.

Comfort tuning

In Comfort mode, the driving characteristics of your vehicle are more comfortable. Select this mode if you prefer a more comfortable driving style, but also when driving fast on straight roads, e.g. highways.

▶ If indicator lamp ② is lit: press button ①.

Indicator lamp ② goes out. Comfort tuning is selected.

The AIRMATIC COMFORT message appears in the multifunction display.

Active Body Control (ABC)

Vehicle level

Your vehicle automatically adjusts its ride height to improve driving safety and reduce fuel consumption.

Depending on the vehicle height that has been set, the vehicle automatically adjusts its height dependent on the current speed. As speed increases, the vehicle is lowered by up to 0.6 in (15 mm). As the speed is reduced, the vehicle is raised up to the set vehicle height.

↑ WARNING

The vehicle is lowered when the engine is switched off. Therefore, make sure that nobody is in the vicinity of the wheel housing or under the vehicle when you switch off the engine. Otherwise, limbs could become trapped.

■ The vehicle is lowered when the engine is switched off. Make sure when parking that you position your vehicle so that it does not make contact with the curb as the vehicle is lowered. Your vehicle could otherwise be damaged. • For AMG vehicles: when the engine is switched off, the vehicle is lowered by approx. 0.4 in (10 mm).


Setting the vehicle level

Select the "Normal" setting for normal road surfaces and "Raised" for driving with snow chains or on particularly poor road surfaces.

MARNING

To help avoid personal injury, keep hands and feet away from wheel housing area, and stay away from under the vehicle when lowering the vehicle chassis.

Your selection remains stored even if you remove the SmartKey from the ignition lock.



Setting raised level

▶ Start the engine.

If indicator lamp (2) is not lit:

► Press button ①.
Indicator lamp ② lights up. The vehicle height is adjusted to raised level.

Setting the normal level

▶ Start the engine.

If indicator lamp ② is lit:

Press button ①. Indicator lamp ② goes out. The vehicle is adjusted to normal level.




Suspension tuning

The electronically controlled ABC suspension system works continuously. This improves driving safety and comfort.

The ABC suspension system is tuned individually to each wheel and depends on:

- your driving style, e.g. sporty
- the road surface condition, e.g. bumps
- your individual selection, i.e. sports or comfort
- the vehicle load

Your selection remains stored even if you remove the SmartKey from the ignition lock.



Sports tuning

The firmer suspension tuning in Sport mode ensures even better contact with the road. Select this mode if you prefer a firmer suspension tuning.

▶ If indicator lamp ② is not lit: press button ①.

Indicator lamp ② lights up. You have selected the suspension for a sporty driving style.

The ABC Active Body Control SPORT message appears in the multifunction display.

Comfort tuning

In Comfort mode, the driving characteristics of your vehicle are more comfortable. Select this mode if you prefer a more comfortable driving style.

▶ If indicator lamp ② is lit: press button (1).

Indicator lamp ② goes out. You have selected the suspension for a comfortable driving style.

The ABC Active Body Control COMFORT message appears in the multifunction display.

4MATIC (permanent four-wheel drive)

4MATIC ensures that all four wheels are permanently driven. Together with ESP®, it improves the traction of your vehicle whenever a drive wheel spins due to insufficient grip.

↑ WARNING

If a drive wheel is spinning due to insufficient traction:

- While driving off, apply as little throttle as possible.
- While driving, ease up on the accelerator pedal.
- Adapt your speed and driving style to the prevailing road conditions.

Failure to observe these guidelines could cause the vehicle to skid.

The 4MATIC cannot prevent accidents resulting from excessive speed.

- Never tow the vehicle with one axle raised. This may damage the transfer case. Damage of this sort is not covered by the Mercedes-Benz Limited Warranty. All wheels must remain either on the ground or be fully raised. Observe the instructions for towing the vehicle with all wheels in full contact with the ground.
- i In wintry driving conditions, the maximum effect of 4MATIC can only be achieved if you use winter tires (M+S tires), with snow chains if necessary.



PARKTRONIC

Important safety notes



↑ WARNING

The PARKTRONIC is a supplemental system. It is not intended to, nor does it replace, the need for extreme care. The responsibility during parking and other critical maneuvers always remains with the driver.



↑ WARNING

Make sure no persons or animals are in or near the area in which you are parking/ maneuvering. Otherwise, they could be injured.


PARKTRONIC is an electronic parking aid with ultrasonic sensors. It indicates visually and audibly the distance between your vehicle and an object.

PARKTRONIC is activated automatically when you:

- switch on the ignition
- shift the transmission to position D, R or N
- release the electric parking brake

PARKTRONIC is deactivated at speeds above 11 mph (18 km/h). It is reactivated at lower speeds.

PARKTRONIC monitors the area around your vehicle using six sensors in the front bumper and four sensors in the rear bumper.




(1) Sensors in the front bumper, left-hand side (example)


Range of the sensors

General notes

The sensors must be free of dirt, ice and slush; otherwise they may not function correctly. Clean the sensors regularly, taking care not to scratch or damage them (⊳ page 467).



Side view



Top view

Front sensors

Center	Approximately 40 in (approximately 100 cm)
Corners	Approximately 24 in (approximately 60 cm)

Rear sensors

Center	Approximately 48 in (approximately 120 cm)
Corners	Approximately 32 in (approximately 80 cm)



When parking, pay particular attention to objects above or below the sensors, such as flower pots or trailer drawbars.

PARKTRONIC does not detect such objects when they are in the immediate vicinity of the vehicle. You could damage the vehicle or the objects.

The sensors may not detect snow and other objects that absorb ultrasonic waves.

Ultrasonic sources such as an automatic car wash, the compressed-air brakes on a truck or a pneumatic drill could cause PARKTRONIC to malfunction.

PARKTRONIC may not function correctly on uneven terrain.


Minimum distance

Center	Approximately 8 in (approximately 20 cm)
Corners	Approximately 8 in (approximately 20 cm)

If there is an obstacle within this range, the relevant warning displays light up and a warning tone sounds. If the distance falls below the minimum, the distance may no longer be shown.

Warning displays

The warning displays show the distance between the sensors and the obstacle. The warning display for the front area is in the instrument cluster. The warning display for the rear area is located on the headliner in the rear compartment.



Warning display for the front area

- ① Segments on the left-hand side of the vehicle
- ② Segments on the right-hand side of the vehicle
- ③ Segments showing operational readiness

The warning display for each side of the vehicle is divided into five yellow and two red segments. PARKTRONIC is operational if yellow segments showing operational readiness ③ light up.

The selected transmission position determines which warning display is active when the engine is running.

Transmission position	Warning display
D	Front area activated
R	Rear and front areas activated
N	If the electric parking brake is engaged: no areas are activated If the electric parking brake is released: rear and front areas are activated
P	No areas activated


One or more segments light up as the vehicle approaches an obstacle, depending on the vehicle's distance from the obstacle.

When the first red segment lights up, you hear an intermittent warning for about two seconds. From the second red segment, you



hear a continuous warning. This indicates that you have now reached the minimum distance.

Deactivating/activating PARKTRONIC



- 1) To deactivate/activate PARKTRONIC
- ② Indicator lamp

If indicator lamp ② lights up, PARKTRONIC is deactivated.

• PARKTRONIC is automatically activated when you turn the SmartKey to position 2 in the ignition lock.



Problems with PARKTRONIC

Problem Possible causes/consequences and ▶ Solutions Only the red segments PARKTRONIC has malfunctioned and has switched off. in the PARKTRONIC ▶ If problems persist, have PARKTRONIC checked at a qualified warning displays are lit. specialist workshop. You also hear a warning tone for approximately two seconds. PARKTRONIC is deactivated after approximately 20 seconds, and the indicator lamp in the PARKTRONIC button lights up. Only the red segments The PARKTRONIC sensors are dirty or there is interference. in the PARKTRONIC ► Clean the PARKTRONIC sensors (> page 467). warning displays are lit. ▶ Switch the ignition back on. PARKTRONIC is deactivated after The problem may be caused by an external source of radio or approximately 20 ultrasound waves. seconds. ▶ See if PARKTRONIC functions in a different location.

Parking Guidance

Important safety notes

Parking Guidance is an electronic parking aid with ultrasound. Ultrasound is used to measure the road on both sides of the vehicle. A suitable parking space is indicated by the parking symbol. You receive steering instructions when parking. You may also use PARKTRONIC (▷ page 347).

⚠ WARNING

Parking Guidance is merely an aid and may display parking spaces that are not suitable for parking, for example:

- no-parking areas
- parking spaces with unsuitable surfaces (road surface)

- driveways
- entrances and exits

Parking Guidance detects and measures potential parking spaces while driving past. Changes to the parking space after this point are not taken into account, for example if the vehicle in front of or behind the parking space changes position or objects in the parking space are moved.

Even when using Parking Guidance, you are still responsible for driving carefully. If you rely on Parking Guidance alone, you could cause an accident and injure yourself and others.

Safety always remains your responsibility and you must continue paying careful attention to your immediate surroundings when parking and maneuvering.



↑ WARNING

Objects located above the height range of Parking Guidance will not be detected when the parking space is measured. These objects are not taken into account when the parking procedure is calculated, e.g. overhanging loads, tail sections or loading ramps of goods vehicles. Under some circumstances, Parking Guidance might therefore issue steering instructions too soon. This may lead to a collision. For this reason, you should avoid using Parking Guidance in such situations.

↑ WARNING

Make sure that no persons or animals are in the maneuvering range. Otherwise, they could be injured.

Pay particular attention to low objects or objects with flat surfaces, such as trailer drawbars, posts, cross beams and curbs. These types of objects cannot be detected by Parking Guidance and may damage the vehicle.

When PARKTRONIC is deactivated, Parking Guidance is also unavailable.

Use Parking Guidance for parking spaces:

- that are parallel to the direction of travel
- · that are on straight roads, not bends
- that are on the same level as the road, i.e. not on the pavement, for example. Parking Guidance may not detect flat curbs

Parking tips:

- on narrow roads, drive past the parking space as close as possible.
- parking spaces that are littered, overgrown or partially occupied by trailer drawbars might be identified incorrectly or not at all.
- snowfall or heavy rain may lead to a parking space being measured inaccurately.
- pay attention to the PARKTRONIC (▷ page 348) warning messages during the parking procedure.

- when transporting a load which protrudes from your vehicle, you must not use Parking Guidance.
- never use Parking Guidance with snow chains or an emergency spare wheel installed.
- make sure that the tire pressures are always correct. This has a direct effect on the steering instructions.
- the way your vehicle is positioned in the parking space after parking is dependent on various factors. These include the position and shape of the vehicles parked in front and behind it and the conditions of the location. In some cases, Parking Guidance may guide you too far or not far enough into a parking space. In some cases, it may also lead you across or onto the curb. If necessary, cancel the parking procedure with Parking Guidance.
- If unavoidable, you should drive over obstacles such as curbs slowly and not at a sharp angle. Otherwise, you may damage the wheels or tires.

Detecting a parking space



- Detected parking space on the left
- ② Parking symbol
- ③ Detected parking space on the right

Parking Guidance is automatically activated when you drive forwards. The system is operational at speeds of up to approximately 22 mph (35 km/h). While in operation, the system independently locates and measures parking spaces on both sides of the vehicle. At speeds below 19 mph (30 km/h), you see white parking symbol (2) in the instrument cluster as a status indicator. Parking



Guidance only shows parking spaces on the passenger side in the default setting. Parking spaces on the driver's side are displayed as soon as the turn signal on the driver's side is activated. To park on the driver's side, you must leave the driver's side turn signal switched on until you have engaged reverse gear. If a parking space is detected, parking symbol ② changes to blue. Additionally, an arrow pointing right ③ or left ① is shown. Parking Guidance will only detect parking spaces:

- that are closed in at the back
- that are parallel to the direction of travel
- that are at least 5 ft (1.5 m) wide
- that are at least 4.3 ft (1.3 m) longer than your vehicle

A parking space is displayed while you are driving past it, and until you are approximately 50 ft (15 m) away from it.

Parking

The following instructions refer to parking in a space on the front-passenger side. To park in a space on the driver's side, mirror the instructions.


↑ WARNING

The Parking Guidance is only an aid and may not detect all obstacles. The Parking Guidance does not relieve you of the responsibility to pay attention. You are always responsible for safety and must continue to pay attention to your immediate surroundings when parking and maneuvering. Otherwise, you could endanger yourself and others.

- Stop the vehicle when the blue parking space symbol shows the desired parking space in the instrument cluster.
- ► Engage reverse gear.

 The multifunction display shows the message: Check surroundings Confirm with OK.
- ► Press OK on the multifunction steering wheel to confirm.


The display in the instrument cluster switches to Parking Guidance.



- (1) Green lane
- ② White bracket marking the target position
- ▶ Depending on the distance, you may have to reverse along the lane towards the parking space. This is indicated by green lane (1).

Continue backing up until you hear a tone. Stop; the parking position has been reached and is marked by white bracket ② with an arrow for the target position.






Steering tips


- 1) Red lane indicating the route the vehicle will take with the steering wheel in its current position
- (2) Yellow lane indicating the route the vehicle will take when you have turned the steering wheel in the required direction
- ▶ Turn the steering wheel while the vehicle is stationary until red lane (1) and yellow lane (2) overlap.
 - Lane (2) is then marked in green and you hear a tone. If the parking space is inside the area displayed, the end of the green lane is marked with a white bracket and an arrow showing the target position.

Backing up into a parking space




- 1) Lane turns green when the steering wheel is turned in the correct direction
- ► Keep the steering wheel in that position and reverse carefully.
- ▶ Stop as soon as you hear a tone. The vehicle has reached the position in which you need to countersteer.

Countersteering




- P54.65-3794-31
- 1) Red lane indicating the route the vehicle will take with the steering wheel in its current position
- (2) Yellow lane indicating the route the vehicle will take when you have turned the steering wheel in the required direction
- ► Turn the steering wheel while the vehicle is stationary until red lane (1) and yellow lane (2) overlap.
 - Lane (2) is then marked in green and you hear a tone. A white arrow and white bracket are shown to indicate the target position.

Driving to the final position



- (1) Lane turns green when the steering wheel is turned in the correct direction
- ► Keep the steering wheel turned in that direction and reverse carefully until you have reached the final position. The Parking Guidance finished message appears in the multifunction display and a tone sounds.





Final position

Depending on the size of the parking space, you may now be in an angled position in the parking space. If possible, Parking Guidance will guide you as far back as possible towards the rear limit of the parking space.

- ▶ Maneuver to the final position if necessary.
- ► Always observe the warning messages displayed by PARKTRONIC (▷ page 348).

Canceling Parking Guidance

▶ Press the PARKTRONIC button on the dashboard (⊳ page 349). Parking Guidance is canceled immediately and PARKTRONIC is deactivated.

Parking Guidance is canceled automatically if it is no longer possible to guide you into the parking space, or if a malfunction occurs. The parking space symbol goes out and a warning tone sounds. The Parking Guidance Canceled message appears in the multifunction display.

Rear view camera


Important safety notes

The rear view camera is an optical parking aid. It shows the area behind your vehicle in the COMAND display.

/ WARNING

Make sure that no persons or animals are in the maneuvering range. Otherwise, they could be injured.

The rear view camera is located in the handle strip of the trunk lid.



Rear view camera

View through the camera

The area behind the vehicle is displayed in a mirror-inverted manner, as in the rear-view mirror.



/ WARNING

The rear view camera is only an aid and may display obstacles

- · from a distorted perspective
- inaccurately
- may not display obstacles at all

The rear view camera does not relieve you of the responsibility to be cautious. Take care and pay careful attention. The rear view camera may not show objects which are

- very close to the rear bumper
- under the rear bumper
- above the trunk handle

You are responsible for safety at all times and must continue to pay attention to the immediate surroundings when parking and maneuvering. This includes the area behind, in front of, and beside the vehicle. Otherwise you could endanger yourself and/or others.



/ WARNING

The rear view camera will not function or will not fully function if:



- the trunk lid is open
- it is raining or snowing strongly or if it is foggy
- it is night or if you are parking/ maneuvering your vehicle in a very dark
- a very bright white light is affecting the camera
- the immediate vicinity is illuminated with fluorescent light (the display of the COMAND system can flicker)
- temperature changes abruptly, for example if you drive out of the cold into a heated garage (condensation on the lens)
- the camera lens is dirty or covered
- the rear of your vehicle is damaged In this case, have the position and the setting of the camera checked at a specialist workshop. Mercedes-Benz recommends that you consult a Mercedes-Benz Center for this purpose.

Do not use the rear view camera in these situations. You could otherwise injure yourself and other people and/or cause damage - including damage to your vehicle while parking/maneuvering.

Activating the rear view camera

- ▶ Make sure that the SmartKey is in position 2 in the ignition lock.
- ► Engage reverse gear. The area behind the vehicle is shown in the COMAND display with guide lines.

Guide lines in the COMAND display



♠ WARNING

Use of rear view camera can be dangerous if you are color-blind or have impaired color vision.

Only use rear view camera if you can see and distinguish all colored guidelines shown by rear view camera on the COMAND system display.


↑ WARNING

Please note that objects that do not touch the ground may appear to be further away than they actually are, for example:

- the bumper of a vehicle parked behind you
- the trailer drawbar
- the ball coupling of a trailer tow hitch
- · the rear end of a truck
- a slanted post

In such cases, you should not use the guide lines to judge the distance. You may misjudge the distance, which increases the risk of impacting the objects.

Even if the object you approach is directly on the ground, do not approach the object any closer than the red guide line.



Information in the COMAND display (example)

Guide lines (2) and (3) show the approximate distance to the rear area. Yellow guide line (2) indicates a distance of approximately 3 ft (1 m) and red guide line (3) indicates a distance of approximately 10 in (0.25 m). The distances only apply to objects that are at ground level. Blue guide lines (1) depict the width required for the vehicle. They are used to align the vehicle with the edge of the road, e.g. the curb.



ATTENTION ASSIST

Important safety notes

ATTENTION ASSIST helps you during long, monotonous journeys such as on freeways and interstate highways. It is active in the range between 50 mph (80 km/h) and 112 mph (180 km/h).

If ATTENTION ASSIST detects typical indicators of fatigue or increasing lapses in concentration on the part of the driver, it suggests you take a break.

↑ WARNING

ATTENTION ASSIST is only an aid and may detect your tiredness or lapses in concentration too late or not at all. It is not a substitute for a well-rested and attentive driver.


Fatigue may cause you to recognize hazardous situations too late, misjudge a situation or react more slowly. For this reason, make sure you feel rested before you begin driving and during your journey. Make sure that you take regular breaks in time, particularly on long journeys. Otherwise, you may fail to recognize dangers in time, cause an accident and injure yourself and others.

ATTENTION ASSIST assesses your level of fatigue or lapses in concentration by taking the following criteria into account:

- your personal driving style, e.g. steering characteristics
- driving conditions, e.g. time, driving time
 The functionality of ATTENTION ASSIST is restricted and warnings may be delayed or not occur at all:
- if the road condition is poor, e.g. if the surface is uneven or if there are potholes
- if there is a strong side wind
- if you have adopted a sporty driving style with high cornering speeds or high rates of acceleration

- if you predominantly drive at speeds under 50 mph (80 km/h) or over 112 mph (180 km/h)
- if you are currently using COMAND or making a telephone call with it
- if the time has been set incorrectly
- in active driving situations, such as when you change lanes or change your speed

Warning and display messages in the multifunction display



► Activate ATTENTION ASSIST using the onboard computer (▷ page 384). Symbol ① appears in the multifunction display.

If ATTENTION ASSIST is active, you will be warned no sooner than 20 minutes after your journey has begun. You will then hear an intermittent warning tone twice, and the Attention Assist: Time for a break? message appears in the multifunction display.

- ▶ If necessary, take a break.
- ► Press OK to confirm the message.

On long journeys, take regular breaks in good time to allow yourself to rest properly. If you do not take a break and ATTENTION ASSIST still detects typical indicators of fatigue or increasing lapses in concentration, you will be warned again after 15 minutes at the earliest. ATTENTION ASSIST is reset when you continue your journey and starts assessing your tiredness again if:

- you switch off the engine.
- you take off your seat belt and open the driver's door, e.g. for a change of drivers or to take a break.



Night View Assist Plus

Important safety notes

In addition to the illumination provided by the normal headlamps, Night View Assist Plus uses infrared light to illuminate the road. The Night View Assist Plus camera picks up the infrared light and shows a black-and-white image in the multifunction display. The image shown in the multifunction display corresponds to a road lit up by high-beam headlamps. This enables you to see the road's course and any obstacles in good time. If pedestrian recognition is activated, pedestrians recognized by the system are highlighted in the Night View Assist Plus display.

↑ WARNING

Night View Assist Plus is only an aid designed to assist driving. It is not a substitute for attentive driving. Do not rely solely on the Night View Assist Plus display. Continue to look through the windshield. You are responsible for safety and must drive in accordance with traffic conditions. You could otherwise put yourself and others in danger.

The system may be impaired or unavailable if:

- there is poor visibility, e.g. due to snow, rain, fog or heavy spray.
- the windshield is dirty, fogged up or covered, for instance by a sticker, in the vicinity of the camera.
- you are driving on bends, uphill gradients or downhill gradients.


Light from the headlamps of oncoming vehicles does not affect the Night View Assist Plus display in the multifunction display. This is also the case if you cannot switch on the high-beam headlamps due to oncoming traffic.

↑ WARNING

The Night View Assist Plus cannot record objects immediately in front of or next to the vehicle. When maneuvering, continue to look

through the windshield. Make sure no persons or animals are in the area in which you are maneuvering. You could otherwise injure them.

1 Infrared light is not visible to the human eye and therefore does not glare. Night View Assist Plus can therefore remain switched on even if there is oncoming traffic.



(1) Night View Assist Plus camera

Switching on Night View Assist Plus




You can only activate Night View Assist Plus if:

- the SmartKey is in position **2** in the ignition lock.
- it is dark.
- the light switch is in the A or position.
- reverse gear has not been engaged.



▶ Press button (1). The Night View Assist Plus display appears in the multifunction display.



P54.32-7708-31

- (1) Night View Assist Plus display
- (2) Pedestrian recognized
- (3) Framing
- 4 Symbol for active pedestrian recognition
- Speed display
- 1 The infrared lamps switch on automatically from a speed of about 6 mph (10 km/h). This means that you do not have the full visual range while the vehicle is stationary and cannot check whether Night View Assist Plus is working.

When you activate Night View Assist Plus, speed display (5) in the multifunction display changes. Speed display (5) is shown as a bar at the bottom edge of the multifunction display. This line is no longer available for basic menus. You have to deactivate Night View Assist Plus if you want to change a setting using the buttons on the multifunction steering wheel.

Pedestrian recognition

↑ WARNING

Pedestrian recognition may be impaired or inoperative if:

- pedestrians are partially or entirely obscured by objects, e.g. parked vehicles.
- the silhouette of the pedestrian in the Night View Assist Plus display is incomplete or

- interrupted, e.g. by powerful light reflections.
- pedestrians do not contrast with the surroundings.
- pedestrians are not standing upright, for example, if they are sitting, crouching or lying down.
- 1 Animals are not recognized by pedestrian recognition.

Night View Assist Plus is able to recognize pedestrians by typical characteristics, e.g. a silhouette in the shape of a person.

Pedestrian recognition is then switched on automatically if:

- Night View Assist Plus is activated.
- you are driving faster than 6 mph (10 km/h).
- the surroundings are dark, e.g. when driving outside built-up areas without street lighting.

If pedestrian recognition is active, symbol 4 appears. If pedestrians are recognized, they are framed (3) and thereby highlighted. If the pedestrian recognition system has brought a pedestrian to your attention, look through the windshield to evaluate the situation. The actual distance to objects and pedestrians cannot be gauged accurately by looking at a screen.

It may be the case that objects are highlighted as well as pedestrians.

Setting the brightness of the multifunction display





- ▶ To make brighter or dimmer: make sure that Night View Assist Plus is activated.
- ► Turn control (1) counter-clockwise or clockwise.

Fogged up or dirty windshield

If the windshield in front of the camera is fogged up or dirty on the inside or outside, the Night View Assist Plus display is affected.

♠ WARNING

Please do not forget that your primary responsibility is to drive the vehicle. A driver's attention to the road must always be his/her primary focus when driving. For your safety and the safety of others, stop before trying to remove window fogging or cleaning the windshield in front of the Night View Assist Plus camera.

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle is covering a distance of 44 feet (approximately 14 m) every second.

- ▶ To defrost: check the automatic air conditioning settings (⊳ page 296) and fold down the camera cover (⊳ page 467).
- ▶ To defrost the inside of the windshield: fold down the camera cover (⊳ page 467) and clean the windshield (⊳ page 466).



Problems with Night View Assist Plus

Problem	Possible causes/consequences and ▶ Solutions
The picture quality of Night View Assist Plus has deteriorated.	The windshield wipers are smearing the windshield. ▶ Replace the wiper blades (▷ page 285).
	The windshield is smeared after the vehicle has been cleaned in a car wash. ▶ Clean the windshield (▷ page 466).
	There is windshield chip damage in the camera's field of vision. ▶ Replace the windshield.
	The windshield is fogged up on the inside. ▶ Defrost the windshield (▷ page 296).
	The windshield is iced up. ▶ De-ice the windshield (▷ page 296).
	There is dirt on the inside of the windshield. ▶ Clean the inside of the windshield (▷ page 466).

Driving Assistance package

General notes

1 The Driving Assistance package is only available on vehicles with HYBRID.

The Driving Assistance package consists of DISTRONIC PLUS (⊳ page 332), Blind Spot Assist (⊳ page 360) and Lane Keeping Assist (⊳ page 362).

Blind Spot Assist

Important safety notes

Blind Spot Assist uses a radar sensor system to monitor the areas on both sides of your vehicle. It supports you from speeds of approximately 20 mph (30 km/h). A warning display in the exterior mirrors draws your attention to vehicles detected in the monitored area. If you then switch on the corresponding turn signal to change lane, you will also receive an optical and audible collision warning. Blind Spot Assist uses

sensors in the rear bumper for monitoring purposes.



♠ WARNING

Blind Spot Assist is only an aid designed to assist driving. It may fail to detect some vehicles and is no substitute for attentive driving.

Blind Spot Assist cannot detect road and traffic conditions. It may fail to detect narrow vehicles, such as motorcycles or bicycles, or may only detect them too late.

Monitoring may be affected by dirty sensors, strong spray or poor visibility caused by snow, rain or mist, for example. In this case, vehicles are detected late or not at all.

Always pay attention to traffic conditions and your surroundings. Otherwise, you may fail to recognize dangers in time, cause an accident and injure yourself and others.



USA only:




This device has been approved by the FCC as a "Vehicular Radar System". The radar sensor is intended for use in an automotive radar system only. Removal, tampering, or altering of the device will void any warranties, and is not permitted by the FCC. Do not tamper with, alter, or use in any non-approved way.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

For Blind Spot Assist to assist you when driving, the radar sensor system must be activated (> page 387) and operational.

Monitoring range of the sensors

Blind Spot Assist monitors the area shown in the figure up to 10 ft (3 m) behind and immediately adjacent to your vehicle.



MARNING

Blind Spot Assist monitors certain areas in the immediate vicinity of your vehicle. Vehicles that approach and drive past at high speeds are not detected. There is no display and no warning.

If the lanes are very wide, it may not be possible to monitor the complete width of the neighboring lane. For this reason, vehicles in the next lane may not be detected, especially if they are driving in a staggered formation.

This may be the case if vehicles are driving at that edge of their lane which is furthest away from your vehicle.

Always pay attention to traffic conditions and your surroundings. Otherwise, you may fail to recognize dangers in time, cause an accident and injure yourself and others.

If the lanes are narrow, vehicles driving in the lane beyond the lane next to your vehicle may be indicated, especially if the vehicles are not driving in the middle of their lane. This may be the case if the vehicles are driving on the inner side of their lane.

Due to the nature of the system:

- warnings may be issued in error when driving close to crash barriers or similar solid lane borders.
- warnings may be interrupted when driving alongside long vehicles, such as trucks, for a prolonged time.

The two sensors for Blind Spot Assist are integrated into the sides of the rear bumper. Make sure that the bumper is free from dirt, ice or slush around the sensors. The rear sensors must not be covered, for example by bicycle racks or overhanging loads. Following a severe impact or in the event of damage to the bumpers, have the function of the radar sensors checked at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center. Blind Spot Assist may otherwise not work properly.

Indicator and warning display



① Yellow indicator lamp/red warning lamp



When Blind Spot Assist is activated, indicator lamp (1) lights up yellow in the exterior mirrors up to a vehicle speed of 20 mph (30 km/h). When the vehicle speed exceeds 20 mph (30 km/h), the indicator lamp goes out and Blind Spot Assist is ready for use.

When your speed exceeds approximately 20 mph (30 km/h), warning lamp (1) lights up red on the corresponding side whenever a vehicle is detected in the blind spot monitoring range. This warning is always given when a vehicle enters the blind spot monitoring range from behind or from the side. When you are passing another vehicle, the warning is emitted only if the difference in speed is less than 7 mph (12 km/h).

The yellow indicator lamp goes out if reverse gear is engaged. In this event, Blind Spot Assist is no longer active.

The brightness of the indicator/warning lamps is adjusted automatically according to the ambient light.

/ WARNING

Blind Spot Assist is not active at speeds under approximately 20 mph (30 km/h). The indicator lamps in the exterior mirrors are yellow. Vehicles in the monitoring range are then not indicated.

Always pay attention to traffic conditions and your surroundings. Otherwise, you may fail to recognize dangers in time, cause an accident and injure yourself and others.

Collision warning

If a vehicle is detected in the monitoring range of Blind Spot Assist and you switch on the turn signal, a double warning tone sounds. Red warning lamp (1) flashes. If the turn signal remains on, detected vehicles are indicated by the flashing of red warning lamp (1). There are no further warning tones.

Switching on Blind Spot Assist

▶ Make sure that the radar sensor system (⊳ page 387) and Blind Spot Assist


- (▷ page 385) are activated in the on-board computer.
- ► Turn the SmartKey to position 2 in the ignition lock.

Warning lamps (1) light up red in the exterior mirrors for approximately 1.5 seconds and then turn yellow.

Lane Keeping Assist

Important safety notes

Lane Keeping Assist monitors the area in front of your vehicle by means of a camera at the top of the windshield. Lane Keeping Assist detects lane markings on the road and warns you before you leave your lane unintentionally.



(1) Lane Keeping Assist camera

If you have chosen the Display Unit Speed-/Odometer(⊳ page 386) function in the on-board computer and select km as the unit of measurement, Active Lane Keeping Assist is active from speeds of 60 km/h. If the mph display unit is selected, the assistance range begins at 40 mph.

/ WARNING

Lane Keeping Assist does not keep your vehicle in its lane. It is only an aid and may detect the lane markings on the road incorrectly or not at all.



The system may be impaired or may not function if:

- there is poor visibility, e.g. due to insufficient illumination of the road, or due to snow, rain, fog or spray.
- there is glare, e.g. from oncoming traffic, the sun, or reflection from other vehicles.
- the windshield is dirty, fogged up or covered, for instance by a sticker, in the vicinity of the camera.
- several or no lane markings for a single lane are present.
- the lane markings are worn away, dark or covered up, e.g. by dirt or snow.
- the distance to the vehicle in front is too small and the lane markings thus cannot be detected.
- the lane markings on the road are unclear, e.g. near roadworks.
- the lane markings change quickly, e.g. lanes branch off, cross one another or merge.
- the road is narrow and winding.

Lane Keeping Assist cannot detect road and traffic conditions. It is not a substitute for attentive driving. You are responsible for the vehicle's speed, braking in good time, and steering correctly. Always adapt your driving style to suit the prevailing road and weather conditions. Always pay attention to traffic conditions and your surroundings. Otherwise, you may fail to recognize dangers in time, cause an accident and injure yourself and others.

A warning can be given when a front wheel passes over a lane marking. It will warn you by means of intermittent vibration in the steering wheel for up to 1.5 seconds.

In order that you are warned only when necessary and in good time if you cross the lane marking, the system recognizes certain conditions and warns you accordingly.

The warning vibration occurs earlier if:

- you approach the outer lane marking on a bend.
- the road has very wide lanes, e.g. a freeway.
- the system recognizes solid lane markings. The warning vibration occurs later if:
- the road has narrow lanes.
- you cut the corner on a bend.

No warning vibration occurs if:

- you clearly and actively steer, brake or accelerate.
- you cut the corner on a sharp bend.
- a driving safety system intervenes, e.g. ABS, BAS or ESP[®].
- you switch on the turn signals. In this event, the warnings are suppressed for a certain period of time.

Switching on Lane Keeping Assist



► Activate Lane Keeping Assist using the onboard computer (▷ page 385).
Symbol ① appears in the multifunction display.

If your speed exceeds 40 mph (60 km/h) and lane markings are detected, symbol ① is shown in green. Lane Keeping Assist is ready for use.

Active Driving Assistance package

General notes

1 The Active Driving Assistance package is only available on vehicles without HYBRID.

The Active Driving Assistance package consists of DISTRONIC PLUS (▷ page 332),



Active Blind Spot Assist (▷ page 364) and Active Lane Keeping Assist (▷ page 367).

Active Blind Spot Assist

Important safety notes

Active Blind Spot Assist uses a radar sensor system to monitor the side areas of your vehicle which are in back of the driver. A warning display in the exterior mirrors draws your attention to vehicles detected in the monitored area. If you then switch on the corresponding turn signal to change lane, you will also receive an optical and audible collision warning. If a risk of lateral collision is detected, corrective braking may help you avoid a collision. To support the coursecorrecting brake application, Active Blind Spot Assist also uses the forward-facing radar sensor system. Active Blind Spot Assist supports you from speeds of approximately 20 mph (30 km/h).

↑ WARNING

Active Blind Spot Assist is only an aid, and may detect vehicles/obstacles incorrectly or not at all.

The system may be impaired or may not function if:

- there is poor visibility, e.g. due to snow, rain, fog or spray.
- the rear and/or front sensors are dirty.

Active Blind Spot Assist may not detect narrow vehicles, such as motorcycles or bicycles, or may only detect them too late. It cannot detect vehicles that are overtaken at a small distance and then enter the blind spot area.

Active Blind Spot Assist cannot detect road and traffic conditions. It is not a substitute for attentive driving. You are responsible for the vehicle's speed, braking in good time, and steering correctly. Always adapt your driving style to suit the prevailing road and weather conditions. Always pay attention to traffic conditions and your surroundings. Otherwise, you may fail to recognize dangers in time,

cause an accident and injure yourself and others.



USA only:


This device has been approved by the FCC as a "Vehicular Radar System". The radar sensor is intended for use in an automotive radar system only. Removal, tampering, or altering of the device will void any warranties, and is not permitted by the FCC. Do not tamper with, alter, or use in any non-approved way.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

For Active Blind Spot Assist to assist you when driving, the radar sensor system must be activated (⊳ page 387) and operational.

Monitoring area

Active Blind Spot Assist monitors the area shown in the figure up to 10 ft (3 m) behind and immediately adjacent to your vehicle. For this purpose, Active Blind Spot Assist uses radar sensors in the rear bumper.





/ WARNING

Active Blind Spot Assist monitors certain areas in the immediate vicinity of your vehicle. Vehicles that approach and drive past at high speeds are not detected. No visual nor



audible warnings are emitted and the system does not brake the vehicle to correct your course.

If the lanes are very wide, it may not be possible to monitor the complete width of the neighboring lane. For this reason, vehicles in the next lane may not be detected, especially if they are driving in a staggered formation. This may be the case if vehicles are driving at that edge of their lane which is furthest away from your vehicle.

Always pay attention to traffic conditions and your surroundings. Otherwise, you may fail to recognize dangers in time, cause an accident and injure yourself and others.

If the lanes are narrow, vehicles driving in the lane beyond the lane next to your vehicle may be indicated, especially if the vehicles are not driving in the middle of their lane. This may be the case if there are vehicles driving at the inner edge of their lanes.

Due to the nature of the system:

- warnings may be issued in error when driving close to crash barriers or similar solid lane borders.
- warnings may be interrupted when driving alongside long vehicles, such as trucks, for a prolonged time.

Two Active Blind Spot Assist radar sensors are integrated into the front and rear bumpers respectively. An additional radar sensor is located behind the cover in the radiator grill. Make sure that the sensor areas on the bumpers and the sensor cover in the radiator grill are free of dirt, ice and slush. The rear sensors must not be covered, for example by cycle racks or overhanging cargo. Following a severe impact or in the event of damage to the bumpers, have the function of the radar sensors checked at a qualified specialist workshop. Blind Spot Assist may otherwise not work properly.

Indicator and warning display



1 Yellow indicator lamp/red warning lamp

When Active Blind Spot Assist is activated, indicator lamp (1) lights up yellow in the exterior mirrors up to a vehicle speed of 20 mph (30 km/h). When the vehicle speed exceeds 20 mph (30 km/h), the indicator lamp goes out and Active Blind Spot Assist is ready for use.

When your speed exceeds approximately 20 mph (30 km/h), warning lamp (1) lights up red on the corresponding side whenever a vehicle is detected in the blind spot monitoring range. This warning is always given when a vehicle enters the blind spot monitoring range from behind or from the side. When you are passing another vehicle, the warning is emitted only if the difference in speed is less than 7 mph (12 km/h).

The yellow indicator lamp goes out if reverse gear is engaged. In this event, Active Blind Spot Assist is no longer active.

The brightness of the indicator/warning lamps is adjusted automatically according to the ambient light.

/ WARNING

Active Blind Spot Assist is not active at speeds lower than 20 mph (30 km/h). The indicator lamps in the exterior mirrors are yellow. Vehicles in the monitoring range are then not indicated.

Always pay attention to traffic conditions and your surroundings. Otherwise, you may fail to



recognize dangers in time, cause an accident and injure yourself and others.

Visual and audible collision warnings

If you switch on the appropriate turn signals and a vehicle is detected in the side monitoring range, you will receive a visual and acoustic collision warning. You will hear a double warning tone and red warning lamp ① flashes. If the turn signal remains on, vehicles detected are indicated by the flashing of red warning lamp ①. There are no further warning tones.

Course-correcting brake application

If Active Blind Spot Assist detects a risk of a lateral collision in the monitoring range, a course-correcting brake application is carried out. This is meant to assist you in avoiding a collision.

The course-correcting brake application is available in the range between 20 mph (30 km/h) and 120 mph (200 km/h).

If a course-correcting brake application occurs, red warning lamp ① flashes in the exterior mirror and the following is shown in the multifunction display, for example:



⚠ WARNING

Active Blind Spot Assist is only an aid designed to assist driving. It is not a substitute for attentive driving. In some cases, the course-correcting brake application is not sufficient to avoid a collision. In such a case, you must steer, brake or accelerate.

In very rare cases, the system may erroneously detect a danger of collision in the area of crash barriers or similar lane borders and apply the brakes. Active Blind Spot Assist does not detect all traffic situations and road

users. Always make sure that there is sufficient distance on the side for other traffic or obstacles. An inappropriate brake application may be interrupted at any time if you steer slightly in the opposite direction or accelerate.

You are responsible for driving at appropriate speeds, braking in good time, and steering correctly. Always adapt your driving style to suit the prevailing road and weather conditions. Always pay attention to traffic conditions and your surroundings. Otherwise, you may fail to recognize dangers in time, cause an accident and injure yourself and others.

There will be either no or only a weak coursecorrecting brake application if:

- there are vehicles or obstacles, e.g. crash barriers, located on both sides of your vehicle.
- a vehicle approaches you too closely at the side.
- you have adopted a sporty driving style with high cornering speeds.
- you clearly brake or accelerate.
- a driving safety system intervenes, e.g. ESP® or PRE-SAFE® Brake.
- ESP® is switched off.
- a loss of tire pressure or a defective tire is detected.

Switching on Active Blind Spot Assist

- Make sure that the radar sensor system (▷ page 387) and Active Blind Spot Assist (▷ page 385) are activated in the on-board computer.
- ► Turn the SmartKey to position 2 in the ignition lock.


Warning lamps ① light up red in the exterior mirrors for approximately 1.5 seconds and then turn yellow.



Active Lane Keeping Assist

Important safety notes

Active Lane Keeping Assist monitors the area in front of your vehicle by means of a camera at the top of the windshield. Active Lane Keeping Assist detects lane markings on the road and warns you before you leave your lane unintentionally. If you do not react to the warning, a lane-correcting application of the brakes can bring the vehicle back into the original lane.



1 Active Lane Keeping Assist camera

If you have selected the <code>Display Unit Speed-/Odometer(▷ page 386)</code> function in the on-board computer and select km as the unit of measurement, Active Lane Keeping Assist is active from speeds of 60 km/h. If the mph display unit is selected, the assistance range begins at 40 mph.

↑ WARNING

Active Lane Keeping Assist does not keep your vehicle in its lane. It is only an aid and may detect the lane markings on the road incorrectly or not at all.

The system may be impaired or may not function if:

- several or no lane markings for a single lane are present.
- there is poor visibility, e.g. due to insufficient illumination of the road, or due to snow, rain, fog or spray.
- there is glare, e.g. from oncoming traffic, the sun, or reflection from other vehicles.

- the windshield is dirty, fogged up or covered, for instance by a sticker, in the vicinity of the camera.
- the lane markings are worn away, dark or covered up, e.g. by dirt or snow.
- the distance to the vehicle in front is too small and the lane markings thus cannot be detected.
- the lane markings on the road are unclear, e.g. near roadworks.
- the lane markings change quickly, e.g. lanes branch off, cross one another or merge.
- the road is narrow and winding.

Active Lane Keeping Assist cannot detect road and traffic conditions. It is not a substitute for attentive driving. You are responsible for the vehicle's speed, braking in good time, and steering correctly. Always adapt your driving style to suit the prevailing road and weather conditions. Always pay attention to traffic conditions and your surroundings. Otherwise, you may fail to recognize dangers in time, cause an accident and injure yourself and others.

Warning vibration in the steering wheel

A warning can be given when a front wheel passes over a lane marking. You will be warned by means of intermittent vibration in the steering wheel for up to 1.5 seconds.

In order that you are warned only when necessary and in good time if you cross the lane marking, the system recognizes certain conditions and warns you accordingly.

The warning vibration occurs earlier if:

- you approach the outer lane marking on a bend.
- the road has very wide lanes, e.g. a freeway.
- the system recognizes solid lane markings. The warning vibration occurs later if:
- the road has narrow lanes.
- you cut the corner on a bend.



No warning vibration occurs if:

- you clearly and actively steer, brake or accelerate.
- you cut the corner on a sharp bend.
- a driving safety system intervenes, e.g. ABS, BAS or ESP[®].
- you switch on the turn signals. In this event, the warnings are suppressed for a certain period of time.

Lane-correcting brake application

If you leave your lane under certain circumstances the vehicle will brake briefly on one side. This is meant to assist you in bringing the vehicle back to the original lane. This function is available in the range between 40 mph and 120 mph (60 km/h to 200 km/h).

A lane-correcting brake application can only be made after driving over a solid, recognizable lane marking. Before this, a warning must be given by means of intermittent vibration in the steering wheel. In addition, a lane with lane markings on both sides must be recognized. The brake application also slightly reduces vehicle speed.

If a lane-correcting brake application occurs, the following, for example, appears in the multifunction display:



 A further lane-correcting brake application can only occur after your vehicle has returned to the original lane.

↑ WARNING

Active Lane Keeping Assist does not keep your vehicle in its lane. It is only an aid designed to assist driving. It is not a substitute for attentive driving. In some cases, the lane-

correcting brake application is not sufficient to bring your vehicle back to the original lane. In such cases, you must steer the vehicle yourself to ensure that it does not leave the lane.

Active Lane Keeping Assist does not detect road and traffic conditions. Always make sure that there is sufficient distance to the side for other traffic or obstacles. In rare cases, unclear markings or particular structures on the roadway can be recognized as solid lane markings. An inappropriate brake application, e.g. after intentionally driving over a solid lane marking, may be interrupted at any time by steering slightly in the opposite direction.

Active Lane Keeping Assist cannot take weather conditions into account.

You are responsible for the driving at appropriate speeds, braking in good time, and steering correctly. Always adapt your driving style to suit the prevailing road and weather conditions. Always pay attention to traffic conditions and your surroundings. Otherwise, you may fail to recognize dangers in time, cause an accident and injure yourself and others.

No lane-correcting brake application occurs if:

- you clearly and actively steer, brake or accelerate.
- you cut the corner on a sharp bend.
- you switch on the turn signals.
- a driving safety system intervenes, e.g. ESP®, PRE-SAFE® Brake or Active Blind Spot Assist.
- you have adopted a sporty driving style with high cornering speeds or high rates of acceleration.
- ESP[®] is switched off.
- the transmission is not in position **D**.
- a loss of tire pressure or a defective tire has been detected and displayed.



Active Lane Keeping Assist does not detect traffic situations or road users. An inappropriate brake application may be interrupted at any time if you:

- steer slightly in the opposite direction.
- use a turn signal.
- · clearly brake or accelerate.

A lane-correcting brake application is interrupted automatically if:

- a driving safety system intervenes, e.g. ESP[®], PRE-SAFE[®] Brake or Active Blind Spot Assist.
- lane markings can no longer be recognized.

Switching on Active Lane Keeping Assist



► Switch on Active Lane Keeping Assist using the on-board computer (> page 385). Symbol ① appears in the instrument cluster.

If your speed exceeds 40 mph (60 km/h) and lane markings are detected, symbol ① is shown in green. Active Lane Keeping Assist is ready for use.





Useful information	372
Important safety notes	372
Displays and operation	372
Menus and submenus	37
Display messages	388
Warning and indicator lamps in the	
instrument cluster	420

Useful information

- 1 This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- 1 Please read the information on qualified specialist workshops (▷ page 31).

Important safety notes

You will find an illustration of the instrument cluster in the "At a glance" section (⊳ page 35).

↑ WARNING

A driver's attention to the road and traffic conditions must always be his/her primary focus when driving.

For your safety and the safety of others, selecting features through the multifunction steering wheel should only be done by the driver when traffic and road conditions permit it to be done safely.

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle is covering a distance of 44 feet (approximately 14 m) every second.

/ WARNING

No messages will be displayed if either the instrument cluster or the multifunction display is inoperative.

As a result, you will not be able to see information about your driving conditions, such as

- speed
- outside temperature
- warning/indicator lamps

- malfunction/warning messages
- · failure of any systems

Driving characteristics may be impaired.

If you must continue to drive, do so with added caution. Contact an authorized Mercedes-Benz Center as soon as possible.



/ WARNING

HYBRID vehicles: It is imperative that you read the HYBRID Supplemental Operating Instructions included in your vehicle literature portfolio. You may otherwise not receive all necessary safety information and warning for the operation of your vehicle.



↑ WARNING

Malfunction and warning messages are only indicated for certain systems and are intentionally not very detailed. The malfunction and warning messages are simply a reminder with respect to the operation of certain systems. They do not replace the owner's and/or driver's responsibility to maintain the vehicle's operating safety. Have all required maintenance and safety checks performed on the vehicle. Bring the vehicle to an authorized Mercedes-Benz Center to address the malfunction and warning messages.

Displays and operation

Coolant temperature display



↑ WARNING

Driving when your engine is overheated can cause some fluids which may have leaked into the engine compartment to catch fire. You could be seriously burned.

Steam from an overheated engine can cause serious burns which can occur just by opening the engine hood. Stay away from the engine if you see or hear steam coming from it.

Stop the vehicle in a safe location away from other traffic. Turn off the engine, get out of the



vehicle and do not stand near the vehicle until the engine has cooled down.

The coolant temperature gauge is in the instrument cluster on the left-hand side. Under normal operating conditions and with the specified coolant level, the coolant temperature may rise to 248 °F (120 °C).

If the coolant temperature is too high a display message is shown.

If the coolant temperature rises above 248 °F(120 °C), do not drive any further as this could damage the engine.

Tachometer

The red band in the tachometer indicates the engine's overrevving range.

Do not drive in the overrevving range, as this could damage the engine.

The fuel supply is interrupted to protect the engine when the red band is reached.

Outside temperature display

The outside temperature display is in the multifunction display (⊳ page 374).

↑ WARNING

The outside temperature indicator is not designed to serve as an ice-warning device and is therefore unsuitable for that purpose. Indicated temperatures just above the freezing point do not guarantee that the road surface is free of ice. The road may still be icy, especially in wooded areas or on bridges.

Changes in the outside temperature are displayed after a short delay.

Operating the on-board computer

The on-board computer is activated as soon as you turn the SmartKey to position 2 in the ignition lock.

You can control the multifunction display and the settings in the on-board computer using the buttons on the multifunction steering wheel.



Multifunction display (1)





Rejects or ends a call Exits phone book/redial memory



Makes or accepts a call Switches to the redial memory



Adjusts the volume or operates the RACETIMER in AMG vehicles




Mute

(1)

(3)

Switches on the Voice Control System; see the separate operating instructions







- ① Menu bar
- ② Description field

Multifunction display


Values and settings as well as display messages are shown in the multifunction display.



Menus and submenus

Menu overview

The number of menus shown depends on the optional equipment in the vehicle.



	Function
1	Trip menu (⊳ page 376)
2	Navi menu (navigation instructions) (⊳ page 377)
3	Audio menu (⊳ page 378)
4	AMG menu in AMG vehicles (⊳ page 379)
5	Telephone menu (> page 382)
6	DriveAssist menu (⊳ page 383)
7	 Service menu (▷ page 385) calls up display messages (▷ page 388) checks the tire pressure electronically (▷ page 497) calls up the service due date (▷ page 462) oil level check (▷ page 457)
8	Settings menu (⊳ page 385)



Trip menu

Standard display




▶ Press and hold the button on the steering wheel until the Trip menu with odometer ① and trip odometer ② is shown.

Trip computer "From start" or "From reset"

The values in the From Start submenu are calculated from the start of a journey, while the values in the From Reset submenu are calculated from the last time the submenu was reset (> page 377).

- ► Press the or button on the steering wheel to select the Trip menu.
- ▶ Press the or button to select From Start or From Reset.



Trip computer "From start" (example)

- 1 Distance
- ② Time
- 3 Average speed
- 4 Average fuel consumption

The From Start trip computer is reset automatically if:


- the ignition has been switched off for more than four hours.
- 999 hours have been exceeded.
- 9,999 miles have been exceeded.

When 9,999 hours or 99,999 miles have been exceeded, the trip computer is automatically reset From Reset.

Displaying the range and current fuel consumption

- ► Press the or button on the steering wheel to select the Trip menu.
- ► Press the ▲ or ▼ button to select Range.

The current fuel consumption 18 and the approximate range are displayed.



P54.32-7515-31

The approximate range that can be covered depends on the fuel level and your current driving style. If there is only a small amount of fuel left in the fuel tank, the display shows a vehicle being refueled instead of the range.

Digital speedometer

- ► Press the or button on the steering wheel to select the Trip menu.
- ▶ Press ▲ or ▼ to select the digital speedometer.



¹⁸ Not AMG vehicles.



(1) Digital speedometer

Resetting values

You can reset the values of the following functions:

- Trip odometer
- Trip computer "From start"
- Trip computer "From reset"
- ▶ Press the **I** or **I** button on the steering wheel to select the Trip menu.
- ▶ Press the ▲ or ▼ button to select the function that you wish to reset.
- ▶ Press OK .



Resetting the trip odometer (example)

► Press ▼ to select Yes and press OK to confirm.


Navigation menu

Displaying navigation instructions

In the Navi menu, the multifunction display shows navigation instructions. Further information (⊳ page 150).

- ► Activate COMAND (> page 133).
- ▶ Press the ◀ or ▶ button on the steering wheel to select the Navi menu.

Route guidance inactive



- Direction of travel
- ② Current road

Route guidance active

No change of direction announced



- Distance to the destination
- ② Symbol for "follow the road's course"
- 3 Distance to the next change of direction
- (4) Current road

Change of direction announced without a lane recommendation



- 1) Road into which the change of direction
- ② Symbol for change of direction
- (3) Distance to change of direction and visual distance display


When a change of direction has been announced, you will see visual distance



display (3) next to the symbol for the change of direction (2). This decreases in size as you approach the announced change of direction.

Change of direction announced with a lane recommendation

Lane recommendations are only displayed if the relevant data is available on the digital



- (1) Road into which the change of direction leads
- ② Symbol for change of direction
- 3 Distance to change of direction and visual distance display
- (4) Lane recommendation

On multiple-lane roads, COMAND can provide lane recommendation (4) for the next change of direction. Lanes may be added during a change of direction.



P54.32-6516-31

- 1 Uninterrupted lane
- 2 New lane during a change of direction
- (3) Lane recommended for the change of direction

Other status indicators of the navigation system

- 🛛 : you have reached the destination or an intermediate destination.
- New route : COMAND is calculating the new route.
- Direction of Dest. Off map or Direction of Dest. Off mapped road: the vehicle position is outside the area of the digital map (off-map position).
- Direction of Dest. No Route: no route could be calculated to the selected destination.

Audio menu

Selecting a radio station

 SIRIUS XM satellite radio acts like a. normal radio.

For more information on satellite radio operation, see the separate operating instructions.

- ► Switch on COMAND and select Radio (⊳ page 211).
- ▶ Press the or ▶ button on the steering wheel to select the Audio menu.



- (1) Memory slot (only if the station is stored)
- ② Station
- ③ Waveband



- ► To select a stored station: briefly press the a or button.
- ► To select a station using station search 19: press and briefly hold the or ▼ button.
- ► Press OK to stop the station search function at the desired station.

Operating audio player or audio media

Audio data from various audio devices or media can be played, depending on the equipment installed in the vehicle.

- ► Switch on COMAND and select the audio device or audio medium (▷ page 220).
- ► Press the or button on the steering wheel to select the Audio menu.



P54.32-6271-31

- CD player display (example)
- ① Current track
- ② Medium (disc number only for DVD changer)

If you press and hold the or button, the rapid scrolling speed is increased. Not all audio devices or media support this function.

If track information is stored on the audio device or medium, the multifunction display will show the number and name of the track. The current track does not appear in audio AUX mode (**Aux**iliary audio mode: external audio source connected).

Operating video DVD

- ► Switch on COMAND and select Video DVD (▷ page 240).
- ► Press the or button on the steering wheel to select the Audio menu.



P54.32-6272-31

- ① Current scene
- ② Medium (disc number only for DVD changer)
- ► To select the next or previous scene: briefly press the or button.


AMG menu in AMG vehicles

AMG displays

► Press or on the steering wheel to select the AMG menu.

¹⁹ Only if no station list is received.





P54.32-8658-31

- Gear indicator
- ② Upshift indicator
- 3 Engine oil temperature
- 4 Coolant temperature

Upshift indicator UP ② indicates that the engine has reached the overrevving range when in the manual gearshift program. Upshift indicator UP ② fades out other messages until you have shifted up.

When the engine oil temperature is below

80 °C, the oil temperature is shown in blue. Avoid driving at full engine output during this time.

 S 63 AMG: additionally, the status of the ECO start/stop function (▷ page 306) will be displayed.

RACETIMER

Displaying and starting RACETIMER

↑ WARNING

The RACETIMER feature is only for use on roads and in conditions where high speed driving is permitted. Racing on public roads is prohibited under all circumstances. The driver is and must always remain responsible for following posted speed limits.

You can use the RACETIMER to store lap times.

When RACETIMER is displayed, you cannot adjust the volume using the + and - buttons on the steering wheel.

- ▶ Press or on the steering wheel to select the AMG menu.
- ► Press the ▲ button repeatedly until the RACETIMER is shown.



P54 32-8460-3

- (1) Gear indicator
- ② Seconds indicator
- ③ RACETIMER
- 4 Lap

You can start the RACETIMER when the engine is running or if the SmartKey is in position 2 in the ignition lock.

- ► To start: press the + button to start the RACETIMER.
- ➤ To display the intermediate time: press the — button to show the intermediate time.

The intermediate time is displayed for five seconds.

► **To stop:** press the + button to stop the RACETIMER.

The RACETIMER interrupts timing when you stop the vehicle and turn the SmartKey to position 1 in the ignition lock. When you turn the SmartKey to position 2 or 3 and then press the + button, timing is continued.

Storing the lap time and starting a new lap

It is possible to store a maximum of sixteen laps.




► Press the ___ button on the steering wheel to show the intermediate time during timing.

The intermediate time is displayed for five seconds.

▶ Press the ___ button again within five seconds.

The displayed intermediate time is stored as a lap time.

Timing starts for a new lap. The new lap is timed from when the intermediate time is called up.



- P34.3
- (1) Gear indicator
- ② RACETIMER
- (3) Fastest lap time (best lap)

Resetting the current lap

- ► Press the + button on the steering wheel to stop the RACETIMER.
- ▶ Press to reset the lap time to "0".

Deleting all laps

You cannot delete individual stored laps.

- ► Press the + button on the steering wheel to stop the RACETIMER.
- ▶ Press and hold the ___ button for a minimum of three seconds.
- ► Press the + button to start the RACETIMER.
 All laps are deleted.

or

- ► Press the + button on the steering wheel to stop the RACETIMER.
- ► Press the OK button.

 Reset Race Timer appears in the multifunction display.



P54.32-6277-3


► Press the ▼ button to select Yes and press the OK button to confirm.

All laps are deleted.

Overall evaluation

This function is shown if you have stored at least one lap and stopped the RACETIMER.

- ► Press or on the steering wheel to select the AMG menu.
- ► Press the button repeatedly until the overall evaluation is shown.



P54.32-8947-31

- 1) RACETIMER overall evaluation
- 2 Total time driven
- 3 Top speed
- 4 Distance covered
- ⑤ Average speed




Lap evaluation

This function is only available if you have stored at least two laps and have stopped the RACETIMER.

- ► Press or on the steering wheel to select the AMG menu.
- ▶ Press the button repeatedly until the lap evaluation is shown.
 Each lap is shown in a separate submenu.

The fastest lap is indicated by flashing symbol 1.



- 1) Lap
- 2 Lap time
- ③ Top speed during lap
- 4 Lap length
- ⑤ Average lap speed
- ▶ Press the or button to select a different lap evaluation.

Telephone menu

Introduction

You can establish a Bluetooth® connection to COMAND (▷ page 195).

↑ WARNING

A driver's attention to the road must always be his/her primary focus when driving. For your safety and the safety of others, we recommend that you pull over to a safe location and stop before placing or taking a telephone call. If you choose to use the telephone while driving, please use the handsfree device and only use the telephone when weather, road and traffic conditions permit.

Some jurisdictions prohibit the driver from using a mobile phone while driving a vehicle. Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle is covering a distance of 44 feet (approximately 14 m) every second.

- ► Switch on the mobile phone and COMAND (▷ page 133).
- Press the or button on the steering wheel to select the Telephone menu.

You will see one of the following display messages in the multifunction display:

- Telephone Ready or the name of the network provider: the mobile phone has found a network and is ready to receive.
- No Service: no network is available, or the mobile phone is searching for a network.

Accepting a call

If someone calls you when you are in the Telephone menu, a display message appears in the multifunction display, for example:



P54.32-6280-31

Press the button on the steering wheel to accept an incoming call.

If you are not in the Telephone menu, you can still accept a call.

Rejects or ends a call

▶ Press the button on the steering wheel.

If you are not in the Telephone menu, you can still reject or end a call.



Dialing a number from the phone book

You can use the mobile phone to enter new telephone numbers into the phone book (see COMAND) (> page 203). If your mobile phone is operational, you can select and dial a number from the phone book at any time.

When you establish a Bluetooth® connection to COMAND, COMAND reads in the phone book of the mobile phone. This can take some time.

While the on-board computer reads in the SIM card:

- you can dial a telephone number from the redial list (Calls dialed list).
- you can dial a telephone number from the telephone book stored in COMAND.
- the multifunction display shows the Reading data... display message below the phone book entries.

When the multifunction display shows the **Updating data...** display message, COMAND has finished importing data. The multifunction display then shows all the phone book entries in COMAND and the mobile phone.

- ► Press the or button on the steering wheel to select the Telephone menu.
- ► Press the ▲, ▼ or OK button to call up the phone book.
- ► Press the ▲ or ▼ button to select the desired name.

To scroll rapidly, press and hold the ▼ or ▲ button for longer than one second. After skipping eight entries, the rapid scroll speeds up.

Rapid scrolling stops when you release the button or reach the end of the list.

▶ If only one telephone number is stored for a name: press the or ok button to start dialing.

or

- ▶ If there is more than one number for a particular name: press the or OK button to display the numbers.
- ▶ Press the or button to select the number you want to dial.
- ► Press the or OK button to start dialing.

or

▶ If you do not want to make a call: press the or button.

Redialing

The on-board computer saves the last names or numbers dialed in the redial memory (Calls Dialed list).

- ► Press the or button on the steering wheel to select the Telephone menu.
- ▶ Press the button to switch to the redial memory.
- ► Press the or button to select the desired name or number.

To scroll rapidly, press and hold the ▼ or ▲ button for longer than one second.

► Press the or OK button to start dialing.

or

▶ If you do not want to make a call: press the or button.

Assistance menu

Showing the distance display

This function is only available with DISTRONIC PLUS.



- ▶ Press the or button on the steering wheel to select the DriveAssist menu.
- ► Press the ▲ or ▼ button to select Distance Display.
- ► Press OK .

The DISTRONIC PLUS distance display (▷ page 339) appears in the multifunction display.

Deactivating/activating ESP®

↑ WARNING

Under no circumstances should you deactivate ESP® when the ESP® warning lamp in the instrument cluster flashes. Proceed as follows:

- when driving off, apply as little throttle as possible.
- while driving, ease up on the accelerator pedal.
- adapt your speed to suit the prevailing road and weather conditions.

Failure to observe these guidelines could cause the vehicle to skid. ESP® cannot prevent accidents resulting from excessive speed.

For further information about ESP^{\otimes} , see (\triangleright page 71).

- ► Start the engine.
- ▶ Press or ▶ on the steering wheel to select the DriveAssist menu.
- ► Press the ▲ or ▼ button to select ESP.
- ► Press the OK button.
- ► To deactivate: press OK again.

 The warning lamp in the instrument cluster comes on.

↑ WARNING

When the ESP® OFF warning lamp is lit, ESP® is deactivated.

If the SP® warning lamp and the SP® OFF warning lamp remain lit, ESP® is not available due to a malfunction.

When ESP® is deactivated or not operational, vehicle stability in standard driving maneuvers is reduced.

Adapt your speed and driving to the prevailing road conditions and to the non-operating status of the ESP[®].

► To activate: press OK again.

The warning lamp in the instrument cluster goes out.

Activating/deactivating PRE-SAFE® Brake

PRE-SAFE® Brake is only available in vehicles with DISTRONIC PLUS.

- ▶ Press the or button on the steering wheel to select the DriveAssist menu.
- ▶ Press or to select PRE-SAFE Brake.
- ► Press OK.

 The current selection is displayed.
- ► To activate/deactivate: press OK again.

When PRE-SAFE® Brake (▷ page 73) is activated, the multifunction display shows the □ symbol as long as the HOLD function is not activated (▷ page 342).

Activating/deactivating ATTENTION ASSIST

This function is not available in HYBRID vehicles.

- ▶ Press the or button on the steering wheel to select the DriveAssist menu.
- ▶ Press the or button to select Attention Assist.



- ► Press OK.

 The current selection is displayed.
- ► To activate/deactivate: press OK again.

When ATTENTION ASSIST (▷ page 356) is activated, the ➡ symbol appears in the multifunction display when the ignition is on.

Activating/deactivating Blind Spot Assist

You can use the Blind Spot Assist function to activate or deactivate Blind Spot Assist (▷ page 360) or Active Blind Spot Assist (▷ page 364).

- ► Press or on the steering wheel to select the DriveAssist menu.
- ► Press or to select Blind Spot Assist.
- ► Press OK.

 The current selection is displayed.
- ► To activate/deactivate: press OK again.

Activating/deactivating Lane Keeping Assist

You can use the Lane Keeping Assist function to activate / deactivate Lane Keeping Assist (▷ page 362) or Active Lane Keeping Assist (▷ page 367).

- ► Press the or button on the steering wheel to select the DriveAssist menu.
- ► Press the ▲ or ▼ button to select Lane Keeping Assist.
- ► Press OK.

 The current selection is displayed.
- ► To activate/deactivate: press OK again.

If Lane Keeping Assist or Active Lane keeping Assist is activated, the multifunction display shows the symbol when the ignition is switched on.

Service menu

In the Service menu you can:

- call up display messages (⊳ page 388)
- check the tire pressure electronically (▷ page 497)
- call up the service due date (> page 462)
- check the oil level (> page 457)

Settings menu

Introduction

The Settings menu can be used for:

- switching the daytime running lamps on/ off
- switching Adaptive Highbeam Assist on/ off
- showing or hiding the additional speedometer
- selecting the units for speed and distance
- switching the belt adjustment on/off
- activating/deactivating the radar sensor system

Switching the daytime running lamps on/off

This function is not available in Canada. If you have activated the Daytime Running Light function and the light switch is in the O or A position, the daytime running lamps are switched on automatically when the engine is running.

In the dark, the following also light up:

- the parking lamps
- the tail lamps
- the license plate lamp
- the side marker lamps

If you turn the light switch to a different position, the corresponding lights are switched on. If you switch off the daytime running lamps at night, make sure that the light switch is set to or A.

The factory setting is On.



- ► Press the ◀ or ▶ button on the steering wheel to select the Settings menu.
- ▶ Press the or button to select Day Running Lights.
- ▶ Press the OK button to confirm.
- ► To activate/deactivate: press OK again.

Switching Adaptive Highbeam Assist on/off

- ► Press the or button on the steering wheel to select the Settings menu.
- ▶ Press the ▼ or ▲ button to select Adapt. High-beam Asst..
- ▶ Press the OK button to confirm.
- ► To activate/deactivate: press OK again.

Switching the additional speedometer on or off

An additional digital speedometer can be shown in the multifunction display.

Vehicles with a kilometer speedometer: the digital speedometer has mph units.

Vehicles with a miles speedometer: the digital speedometer has km/h units.

- ► Press the or button on the steering wheel to select the Settings menu.
- ► Press ▲ or ▼ to select Add. Speedometer.
- ► Press the OK button to confirm.
- ► Press the OK button to save the setting.

Selecting the unit of measurement for distance

The Display Unit Speed-/Odometer: function allows you to choose whether certain displays appear in kilometers or miles.

The selected unit of measurement for distance applies to:

- the analog speedometer
- the digital speedometer in the Trip menu
- the odometer and the trip odometer
- the trip computer
- the navigation instruction in the Navi menu
- DISTRONIC PLUS
- ASSYST PLUS service interval display

The digital speedometer shows alternative speed units (> page 386).

- ▶ Press the or button on the steering wheel to select the Settings menu.
- ► Press the ▲ or ▼ button to select Units.
- ▶ Press the OK button to confirm.
- ► Press the OK button to save the setting. The unit switches between km/h and mph.

Switching the belt adjustment on/off

For further information on belt adjustment (> page 60).

- ▶ Press the or button on the steering wheel to select the Settings menu.
- ► Press the ▲ or ▼ button to select Belt Adjustment.
- ► Press the OK button to confirm.
- ► To activate/deactivate: press OK again.

Activating/deactivating the acoustic locking verification signal

If you activate the Acoustic Lock Feedb. function, an audible signal sounds depending on the vehicle's date of manufacture:

- when locking
 or
- once when unlocking and three times when locking



- ▶ Press the or button on the steering wheel to select the Settings menu.
- ▶ Press the or button to select Acoustic Lock Feedb.
- ▶ Press the OK button to confirm.
- ► To activate/deactivate: press OK again.

Activating/deactivating the radar sensor system

The following systems are switched off when the radar sensor system is deactivated:

- DISTRONIC PLUS (> page 332)
- BAS PLUS (⊳ page 70)
- PRE-SAFE[®] Brake (▷ page 73)
- Blind Spot Assist (> page 360)
- Active Blind Spot Assist (> page 364)
- i USA only: This device has been approved by the FCC as a "Vehicular Radar System". The radar sensor is intended for use in an automotive radar system only. Removal, tampering, or altering of the device will void any warranties, and is not permitted by the FCC. Do not tamper with, alter, or use in any non-approved way.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

1 Canada only:

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

- ▶ Press the or button on the steering wheel to select the Settings menu.
- ▶ Press or to select Radar sensors.
- ▶ Press the OK button to confirm.
- ► To activate/deactivate: press OK again.



Display messages

General notes



♠ WARNING

All categories of messages contain important information which should be taken note of and, where a malfunction is indicated, addressed as soon as possible at an authorized Mercedes-Benz Center.

Failure to repair the condition noted may cause damage not covered by the Mercedes-Benz Limited Warranty, or result in property damage or personal injury.

Display messages appear in the multifunction display.

Display messages with graphic displays may be shown in simplified form in the Operator's Manual and may differ from the messages shown in the multifunction display.

Please respond in accordance with the display messages and follow the additional notes in this Operator's Manual.

Certain display messages are accompanied by an audible warning tone or a continuous tone.

When you stop and park the vehicle, please observe the notes on the HOLD function (\triangleright page 342) and parking (\triangleright page 323).

Hiding display messages

You can hide some display messages with a low priority.

▶ Press the OK or 🛨 button on the steering wheel to hide the display message. The display message is cleared.

Display messages with a low priority are shown in either yellow or white.

Display messages with a high priority are shown in red.

You cannot hide display messages of the highest priority. The multifunction display shows these messages continuously until the causes for the messages have been remedied.

Message memory

The on-board computer saves certain display messages. You can call up the display messages in the message memory.

- ▶ Press the ◀ or ▶ button on the steering wheel to select the Service menu. If there are display messages, the multifunction display shows, for example, 2 messages.
- ▶ Press the ▲ or ▼ button to select the entry, e.g. 2 messages.
- ► Confirm with OK.
- ▶ Press the ▲ or ▼ button to scroll through the display messages.

When the ignition is switched off, all display messages are deleted apart from some highpriority display messages. Once the causes of the high-priority display messages have been rectified, the corresponding display messages are also deleted.



Safety systems

Display messages



Currently Unavailable See Oper. Manual

Possible causes/consequences and ▶ Solutions



ABS (Anti-lock Braking System), ESP® (Electronic Stability Program), BAS (Brake Assist), PRE-SAFE®, the HOLD function and hill start assist are temporarily unavailable.

BAS PLUS and PRE-SAFE® Brake may also have failed.

In addition, the \P , \P and \P warning lamps light up in the instrument cluster.

The self-diagnosis function might not be complete, for example. ATTENTION ASSIST²⁰ is deactivated.

The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example.

► Carefully drive a suitable distance making slight steering movements at a speed above 12 mph (20 km/h). If the display message disappears, the functions mentioned above are available again.

If the display message continues to be displayed:

- ▶ Drive on carefully.
- ► Visit a qualified specialist workshop.

♠ Risk of accident

ABS, ESP®, BAS, PRE-SAFE®, the HOLD function and hill start assist are temporarily unavailable.

BAS PLUS and PRE-SAFE® Brake may also have failed.


In addition, the \P , \P and \P warning lamps light up in the instrument cluster.

For example, the on-board voltage may be insufficient.

ATTENTION ASSIST²⁰ is deactivated.

The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example.

Drive on carefully. If the display message disappears, the functions mentioned above are available again.





Possible causes/consequences and ▶ Solutions Display messages If the display message continues to be displayed: ▶ Drive on carefully. ▶ Visit a qualified specialist workshop. (ABS) ABS, ESP®, BAS, PRE-SAFE®, the HOLD function and hill start Inoperative See assist are unavailable due to a malfunction. Oper. Manual BAS PLUS and PRE-SAFE® Brake may also have failed. The BRAKE (USA only)/ (1) (Canada only), [], [and warning lamps in the instrument cluster also light up. The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example. ATTENTION ASSIST²⁰ is deactivated. ▶ Drive on carefully. ▶ Visit a qualified specialist workshop immediately. Risk of accident ESP®, BAS, PRE-SAFE®, the HOLD function and hill start assist are Current1v temporarily unavailable. Unavailable See Oper. Manual BAS PLUS and PRE-SAFE® Brake may also have failed. In addition, the 🗐 and 🐉 warning lamps light up in the instrument cluster. The self-diagnosis function might not be complete, for example. ATTENTION ASSIST²⁰ is deactivated. The brake system continues to function normally, but without the functions listed above. ► Carefully drive a suitable distance making slight steering movements at a speed above 12 mph (20 km/h). If the display message disappears, the functions mentioned above are available again.






► Visit a qualified specialist workshop.

If the display message continues to be displayed:

▶ Drive on carefully.

Display messages	Possible causes/consequences and ▶ Solutions
	Risk of accident If the display message is shown and the warning lamp flashes at the same time, the Electronic Traction System is deactivated. Otherwise, the brakes on the drive wheels could overheat. Let the brakes cool down until the display message disappears and the warning lamp goes out. The Electronic Traction System is activated again.
Inoperative See Oper. Manual	Risk of accident ESP®, BAS, PRE-SAFE®, the HOLD function and hill start assist are unavailable due to a malfunction. BAS PLUS and PRE-SAFE® Brake may also have failed. In addition, the and warning lamps light up in the instrument cluster. ATTENTION ASSIST ²⁰ is deactivated. The brake system continues to function normally, but without the functions listed above. Drive on carefully. Visit a qualified specialist workshop.
System Inoperative	Risk of accident ESP®, BAS, PRE-SAFE®, the HOLD function and hill start assist are unavailable due to a malfunction. BAS PLUS and PRE-SAFE® Brake may also have failed. In addition, the and and also have failed. In addition, the and and arrive warning lamps light up in the instrument cluster. ATTENTION ASSIST ²⁰ is deactivated. Drive on carefully. Visit a qualified specialist workshop.





Display messages Possible causes/consequences and ▶ Solutions **EBD** EBD (electronic brake force distribution), ABS, ESP®, BAS, PRE-SAFE®, the HOLD function and hill start assist are unavailable due Inoperative See to a malfunction. Oper. Manual BAS PLUS and PRE-SAFE® Brake may also have failed. In addition, the 📳, 🐉 and 📵 warning lamps light up in the instrument cluster and a warning tone sounds. ATTENTION ASSIST²⁰ is deactivated. The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example. ▶ Drive on carefully. ▶ Visit a qualified specialist workshop immediately. The brake pads/linings have reached their wear limit. ► Visit a qualified specialist workshop. Check Brake Pad Wear The red PARK (USA only)/ (P) (Canada only) indicator lamp PARK (USA flashes and a warning tone sounds. only) (Canada You are driving with the electric parking brake applied. only) ► Release the electric parking brake. Please Release Parking Brake ▶ Pull away carefully (▷ page 324). The red PARK (USA only)/ (Canada only) indicator lamp flashes and a warning tone sounds. You are making an emergency stop using the electric parking brake (⊳ page 324). ▶ After the emergency stop: release the electric parking brake





lever.

Possible causes/consequences and ▶ Solutions Display messages The red PARK (USA only) / (P) (Canada only) indicator lamp flashes, the yellow PARK (USA only) / (P) (Canada only) warning lamp lights up and a warning tone sounds. The electric parking brake is malfunctioning and the braking effect is restricted. While the vehicle is in motion: ▶ Release the electric parking brake handle. While the vehicle is stationary: ▶ Switch off the ignition and turn it back on. ► Release the electric parking brake. If the display message continues to be displayed: ▶ Shift the transmission to **P**. ▶ Use the folding wheel chock (> page 474) from the vehicle tool kit to secure the vehicle against rolling away. ► Consult a qualified specialist workshop. The yellow PARK (USA only) / (P) (Canada only) warning lamp PARK (USA lights up. Additionally, the red PARK (USA only)/ (Canada only) (Canada only) indicator lamp may light up. only) The electric parking brake is malfunctioning. Parking Brake See To release: Oper. Manual ▶ Pull the electric parking brake handle. ▶ Pull away carefully. ► Visit a qualified specialist workshop. To apply: ▶ Switch off the ignition. ▶ Pull the electric parking brake lever for at least ten seconds, until the display message disappears. If the display message continues to be displayed: ▶ Shift the transmission to P. ▶ Use the folding wheel chock (> page 474) from the vehicle tool kit to secure the vehicle against rolling away. ► Consult a qualified specialist workshop.



Display messages	Possible causes/consequences and ▶ Solutions
	The red PARK (USA only) / (Canada only) indicator lamp lights up.
	The power supply for the electric parking brake was interrupted.
	► Pull the electric parking brake handle.
	or Pull away carefully.
	or
	► Pull the electric parking brake handle until the display message disappears.
	The red PARK (USA only)/ ((Canada only) indicator lamp flashes and the yellow PARK (USA only)/ ((Canada only) warning lamp lights up.
	The electric parking brake is malfunctioning.
	Switch off the ignition and turn it back on.Engage or release the electric parking brake.
	or
	► Pull away carefully.
	► Visit a qualified specialist workshop.
	The yellow PARK (USA only)/ (P) (Canada only) warning lamp lights up. The red PARK (USA only)/ (P) (Canada only) indicator lamp flashes for approximately 10 seconds after the electric parking brake has been applied or released. It then goes out or remains lit.
	The electric parking brake is malfunctioning, e.g. because of overvoltage or undervoltage.
	► Pull away carefully.
	➤ Visit a qualified specialist workshop.
	If there is overvoltage or undervoltage:
	Remove the cause for the overvoltage or undervoltage, e.g. by charging the battery or restarting the engine.
	► Switch the ignition off and on, and then engage or release the electric parking brake.
	If this does not release the electric parking brake:
	Do not drive on.
	Consult a qualified specialist workshop.



Possible causes/consequences and ▶ Solutions Display messages The yellow PARK (USA only) / (P) (Canada only) warning lamp lights up. The red PARK (USA only) / (P) (Canada only) indicator lamp flashes for approximately 10 seconds after the electric parking brake has been applied or released. It then goes out or remains lit. The electric parking brake has overheated. ▶ Allow the vehicle to cool down. Do not engage or release the electric parking brake during this time. ▶ Use the folding wheel chock (> page 474) from the vehicle tool kit to secure the vehicle against rolling away. ▶ When the vehicle has cooled down: switch the ignition off and on again, then engage or release the electric parking brake. The yellow PARK (USA only) (Canada only) warning lamp PARK (USA lights up. The red PARK (USA only) / (Canada only) indicator (Canada lamp flashes for approximately 10 seconds after the electric parking brake has been applied or released. It then goes out or only) remains lit. Parking Brake The electric parking brake is malfunctioning. Inoperative ▶ Switch the ignition off and on, and then engage the electric parking brake. If it is not possible to engage the electric parking brake: ▶ Shift the transmission to P. ▶ Use the folding wheel chock (> page 474) from the vehicle tool kit to secure the vehicle against rolling away. ► Consult a qualified specialist workshop. The red PARK (USA only) / (Canada only) indicator lamp lights PARK (USA up. onlv) (P)) (Canada You attempted to release the electric parking brake while the only) ignition was switched off. Turn On the ▶ SmartKey: turn the SmartKey to position 1 in the ignition lock. Ignition to ► **KEYLESS-GO:** switch on the ignition. Release the



Parking Brake

Display messages Possible causes/consequences and ▶ Solutions There is a malfunction in the system. The brake system continues BRAKE (USA to operate normally. only) (Canada ▶ Drive on carefully. only) ► Visit a qualified specialist workshop. Service See Oper. Manua 1 BRAKE (USA There is not enough brake fluid in the brake fluid reservoir. only) (Canada Additionally, the red BRAKE (USA only)/ ((1)) (Canada only) only) warning lamp lights up in the instrument cluster and a warning Check Brake Fluid tone sounds. Leve1 ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances. ► Engage the electric parking brake. ► Consult a qualified specialist workshop. ▶ Do not add brake fluid. This will not rectify the malfunction.

Driving with the message Check Brake Fluid Level displayed can result in an accident. Have your brake system checked immediately.

Do not add brake fluid before checking the brake system. Overfilling the brake fluid reservoir can result in spilling brake fluid on hot engine parts and the brake fluid catching fire. You can be seriously burned.

Display messages	Possible causes/consequences and ▶ Solutions
Tele Aid Inoperative	USA only: one or more of the main functions in the mbrace system are malfunctioning. Canada only: one or more of the main functions of the TELEAID system are malfunctioning. ► USA only: have the mbrace system checked at a qualified specialist workshop. ► Canada only: have the TELEAID system checked at a qualified specialist workshop.
PRE-SAFE Inoperative See Oper. Manual	



Possible causes/consequences and ▶ Solutions

PRE-SAFE Functions Currently Limited See Operator's Manual

PRE-SAFE® Brake is temporarily inoperative if:

- the DISTRONIC PLUS cover in the radiator grill is dirty.
- the sensors in the bumpers are dirty.
- its function is impaired due to heavy rain or snow.
- the radar sensor system is temporarily inoperative, e.g. due to electromagnetic radiation emitted by nearby TV or radio stations or other sources of electromagnetic radiation.
- the system is outside the operating temperature range.
- the on-board voltage is too low.

PRE-SAFE® Brake is operational again and the display message disappears if:

- the dirt (e.g. slush) drops away while the vehicle is in motion.
- the system detects that the sensors are fully available again.
- the system is within the operating temperature range.

If the display message continues to be displayed:

- ► Clean the DISTRONIC PLUS cover in the radiator grill (> page 467).
- ► Clean the bumpers (> page 467).
- ► Restart the engine.
- ► Wait until the battery is sufficiently charged.

PRE-SAFE Function Limited See Oper. Manual

PRE-SAFE® Brake is defective. BAS PLUS or the distance warning signal may also have failed.

► Visit a qualified specialist workshop.



SRS Malfunction Service Required

⚠ Risk of injury

There is a malfunction in the SRS (Supplemental Restraint System). The 🔭 warning lamp also lights up in the instrument cluster.

► Visit a qualified specialist workshop.



Possible causes/consequences and ▶ Solutions



Front Left SRS Malfunction Service Required or Front Right SRS Malfunction Service Required

SRS has malfunctioned at the front on the left or right. The warning lamp also lights up in the instrument cluster.

► Visit a qualified specialist workshop.



Rear Left SRS Malfunction Service Required or Rear Right SRS Malfunction Malfunction Service Required

SRS has malfunctioned at the rear on the left or right. The warning lamp also lights up in the instrument cluster.

▶ Visit a qualified specialist workshop.



Rear Center SRS Malfunction Service Required

SRS has malfunctioned at the rear center. The yearning lamp also lights up in the instrument cluster.

▶ Visit a qualified specialist workshop.



Left Side Curtain Airbag Malfunction Service Required or Right Side Curtain Airbag Malfunction Service Required

♠ Risk of injury

There is a malfunction in the left-hand and/or right-hand window curtain air bag. The y warning lamp also lights up in the instrument cluster.

► Visit a qualified specialist workshop.

↑ WARNING

In the event a malfunction of the SRS is indicated as outlined above, the SRS may not be operational.

For your safety, we strongly recommend that you contact an authorized Mercedes-Benz Center immediately to have the system checked. Otherwise the SRS may not be activated when needed in an accident, which could result in serious or fatal injury, or it might deploy unexpectedly and unnecessarily which could also result in injury.



Possible causes/consequences and ▶ Solutions

Front Passenger Airbag Enabled See Oper. Manual

The front-passenger air bag is enabled during the journey, even though:

- a child, a small adult or an object weighing less than the system's weight threshold is located on the front-passenger seat.
- the front-passenger seat is unoccupied.

The system may detect objects or forces applying additional weight on the seat.

- ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.
- ► Engage the parking brake.
- ► Switch off the ignition.
- ▶ Open the front-passenger door.
- Remove the child and the child restraint system from the frontpassenger seat.
- ▶ If necessary, secure the child in a child restraint system on a suitable rear seat.
- ► Make sure that there are no objects on the seat adding to the weight.

The system may otherwise detect the additional weight and interpret the seat occupant's weight as greater than it actually is.

► Keep the seat unoccupied, close the front-passenger door and switch on the ignition.

Observe the 2 pass AIR BAC [\square] (\triangleright page 50) indicator lamp and the multifunction display and check the following:

Seat unoccupied and ignition switched on:

- the PASS AIR BAG indicator lamp must light up and remain lit.

 When the indicator lamp is on, OCS (▷ page 50) has deactivated the front-passenger air bag.
- the Front Passenger Airbag Enabled See Oper. Manual or Front Passenger Airbag Disabled See Oper. Manual display messages must not appear in the multifunction display. Wait for a period of at least 60 seconds until the necessary system checks have been completed and to make sure that the display messages do not appear in the multifunction display.

If the conditions are not fulfilled, the system is not operating correctly.

▶ Visit a qualified specialist workshop immediately.



↑ WARNING

If the PASS AIR BAG IN indicator lamp remains off even after performing the above corrective steps, do not have any children 12 years old and under and other small individuals use the front-passenger seat until the system has been repaired.

Display messages

Possible causes/consequences and ▶ Solutions

Front Passenger Airbag Disabled See Oper. Manual The front-passenger air bag is deactivated during the journey even though an adult or a person larger than a certain size is occupying the front-passenger seat. If additional forces are applied to the seat, the system may interpret the occupant's weight as lower than it actually is.

- ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.
- ► Engage the parking brake.
- ▶ Switch off the ignition.
- ► Have the occupant get out of the vehicle.
- Keep the seat unoccupied, close the front-passenger door and switch on the ignition.

Seat unoccupied and ignition switched on:

- the PASS AIR BAG indicator lamp must light up and remain lit.

 When the indicator lamp is on, OCS (▷ page 50) has deactivated the front-passenger air bag.
- the Front Passenger Airbag Enabled See Oper. Manual or Front Passenger Airbag Disabled See Oper. Manual display messages must not appear in the multifunction display. Wait for a period of at least 60 seconds until the necessary system checks have been completed and to make sure that the display messages do not appear in the multifunction display.

If these conditions are fulfilled, the front-passenger seat can be occupied again. Whether the PASS AIR BAG III indicator lamp remains lit or goes out depends on how OCS classifies the occupant.

If the conditions are not fulfilled, the system is not operating correctly.

▶ Visit a qualified specialist workshop immediately.

★ WARNING

If the PASS AIR BAG III indicator lamp remains lit with an adult occupant on the front-passenger seat even after performing the above corrective steps, do not have any passenger use the front-passenger seat until the system has been repaired.



Lights

1 Display messages about LEDs:

This display message will only appear if all LEDs have failed.

Display messages	Possible causes/consequences and ▶ Solutions
Check Left Cornering Light or Check Right Cornering Light	The left or right-hand cornering light is defective. ► Check whether you are permitted to change the bulb yourself (> page 282). or ► Visit a qualified specialist workshop.
Check Left Low Beam or Check Right Low Beam	The left or right-hand low-beam headlamp is defective. ► Check whether you are permitted to change the bulb yourself (> page 282). or ► Visit a qualified specialist workshop.
Check Rear Left Turn Signal or Check Rear Right Turn Signal	The rear left-hand or rear right-hand turn signal is defective. ▶ Check whether you are permitted to change the bulb yourself (▷ page 282). or ▶ Visit a qualified specialist workshop.
Check Front Left Turn Signal or Check Front Right Turn Signal	The front left-hand or front right-hand turn signal is defective. ▶ Check whether you are permitted to change the bulb yourself (▷ page 282). or ▶ Visit a qualified specialist workshop.
Check Left Mirror Turn Signal or Check Right Mirror Turn Signal	The turn signal in the left-hand or right-hand exterior mirror is defective. ▶ Check whether you are permitted to change the bulb yourself (▷ page 282). or ▶ Visit a qualified specialist workshop.



Display messages Possible causes/consequences and ► Solutions The high-mounted brake lamp is faulty. -<u>Ö</u>-► Check whether you are permitted to change the bulb yourself Check Center Brake (⊳ page 282). Lamp ▶ Visit a qualified specialist workshop. The left or right-hand tail lamp/brake lamp is defective. -<u>Ö</u>-▶ Check whether you are permitted to change the bulb yourself Check Left Tail (⊳ page 282). and Brake or Lamp or Check Right ► Visit a qualified specialist workshop. Tail and Brake Lamp The left or right-hand high beam is defective. -<u>'</u>Ö:-► Check whether you are permitted to change the bulb yourself Check Left High (⊳ page 282). Beam or Check Right or High Beam ► Visit a qualified specialist workshop. The left or right-hand license plate lamp is defective. <u>-Ö</u>-► Check whether you are permitted to change the bulb yourself Check Left License (⊳ page 282). Plate Lamp or Check Right License ► Visit a qualified specialist workshop. Plate Lamp The left-hand or right-hand front fog lamp is defective. -<u>Ö</u>-► Check whether you are permitted to change the bulb yourself Check Left Fog (⊳ page 282). Lamp or Check Right or Fog Lamp ► Visit a qualified specialist workshop. The left-hand or right-hand rear fog lamp is defective. -<u>Ö</u>-► Check whether you are permitted to change the bulb yourself Check Rear Left (⊳ page 282). Fog Lamp or Check or Rear Right Fog Lamp ► Visit a qualified specialist workshop. The front left or front right parking or standing lamp is defective. ► Check whether you are permitted to change the bulb yourself Check Front Left (⊳ page 282). Parking Lamp or Check Front ► Visit a qualified specialist workshop. Right Parking Lamp



Display messages	Possible causes/consequences and ▶ Solutions
Check Left Reverse Lamp or Check Right Reverse Lamp	The left or right-hand backup lamp is defective. ▶ Check whether you are permitted to change the bulb yourself (▷ page 282). or ▶ Visit a qualified specialist workshop.
Check Front Left Sidemarker Lamp or Check Front Right Sidemarker Lamp	The left or right front side marker lamp is defective. ► Check whether you are permitted to change the bulb yourself (> page 282). or ► Visit a qualified specialist workshop.
Check Rear Left Sidemarker Lamp or Check Rear Right Sidemarker Lamp	The rear left or right side marker lamp is defective. ▶ Check whether you are permitted to change the bulb yourself (▷ page 282). or ▶ Visit a qualified specialist workshop.
Check Left Daytime Running Light or Check Right Daytime Running Light	The left or right-hand daytime running lamp is defective. ► Check whether you are permitted to change the bulb yourself (▷ page 282). or ► Visit a qualified specialist workshop.
Active Headlamps Inoperative	The active light function is defective. ▶ Visit a qualified specialist workshop.
Malfunction See Oper. Manual	The exterior lighting is defective. ▶ Visit a qualified specialist workshop.
AUTO Lamp Function Inoperative	 The light sensor is defective. Visit a qualified specialist workshop. USA only: Switch off the daytime running lamps in the on-board computer (▷ page 385). Switch the lights on and off using the light switch.



Display messages	Possible causes/consequences and ▶ Solutions
Please Switch Off Lights	The lights are still switched on when you leave the vehicle. A warning tone also sounds. ▶ Turn the light switch to o or A. or ▶ If the rear fog lamp is switched on: press the light switch in to the stop.
Adaptive High-beam Assist inoperative	Adaptive Highbeam Assist is defective. ▶ Visit a qualified specialist workshop.

Display messages Possible causes/consequences and ▶ Solutions The coolant level is too low. Add coolant, observing the warning notes when doing so (▷ page 460). If coolant needs to be added more often than usual, have the engine coolant system checked at a qualified specialist workshop.

MARNING

Do not spill antifreeze on hot engine parts. Antifreeze contains ethylene glycol which may burn if it comes into contact with hot engine parts. You could be seriously burned.

■ The coolant level is too low. Avoid making long journeys with too little coolant in the cooling system. The engine will otherwise be damaged.

The display messages and the corresponding symbol that indicate that the coolant level is too low must not be ignored.





Coolant Low Stop Vehicle Turn Engine Off

Possible causes/consequences and ▶ Solutions

The coolant is too hot.

- ▶ Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions.
- ► Make sure that the air supply to the engine radiator is not blocked, e.g. by snow, slush or ice.
- Wait until the display message disappears before restarting the engine. Otherwise, there is a risk of engine damage.
- ▶ Pay attention to the coolant temperature display.
- ▶ If the temperature increases again, visit a qualified specialist workshop immediately.

The poly-V-belt may have torn.

- Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions.
- ▶ Open the hood.
- ► Check whether the poly-V-belt is torn.

If the poly-V-belt is torn:

- Do not continue driving. The engine could otherwise overheat.
- ► Consult a qualified specialist workshop.

If the poly-V-belt is not damaged:

- ► Wait until the display message disappears before restarting the engine. Otherwise, there is a risk of engine damage.
- ▶ Pay attention to the coolant temperature display.
- ► Visit a qualified specialist workshop.

⚠ WARNING

Driving when your engine is overheated can cause some fluids which may have leaked into the engine compartment to catch fire. You could be seriously burned.

Steam from an overheated engine can cause serious burns which can occur just by opening the engine hood. Stay away from the engine if you see or hear steam coming from it.

Stop the vehicle in a safe location away from other traffic. Turn off the engine, get out of the vehicle and do not stand near the vehicle until the engine has cooled down.

If the coolant temperature exceeds 248 °F(120 °C) do not continue driving. The engine will otherwise be damaged.



Display messages	Possible causes/consequences and ▶ Solutions
≈ €≈	The engine fan is defective. ▶ At coolant temperatures under 248 °F (120 °C), drive to the next qualified specialist workshop. ▶ Avoid subjecting the engine to heavy loads, e.g. driving in mountainous terrain, and stop-and-go traffic.
	The battery is not being charged. Possible causes are: • a defective alternator • a torn poly-V-belt • a malfunction in the electronics ▶ Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions. ▶ Open the hood. ▶ Check whether the poly-V-belt is torn. If the poly-V-belt is torn: ■ Do not continue driving. The engine could otherwise overheat. ▶ Consult a qualified specialist workshop. If the poly-V-belt is not damaged: ▶ Visit a qualified specialist workshop.
Check Engine Oil at Next Refueling	Vehicles with an oil dipstick: the oil level has dropped to the minimum level. ► Check the engine oil level at the latest when next refueling (▷ page 457). ► If necessary, add engine oil (▷ page 459). ► If engine oil needs to be added more often than usual, have the engine checked at a qualified specialist workshop.
Check Engine Oil Level (Add 1 quart) (USA only)Check Engine Oil Level (Add 1 Liter) (Canada only)	 Vehicles without an oil dipstick: the engine oil level is too low. ▶ Check the oil level (▷ page 457). ▶ If necessary, add engine oil (▷ page 457). ▶ If engine oil needs to be added more often than usual, have the engine checked at a qualified specialist workshop.

Information on approved engine oils can be obtained from any qualified specialist workshop or on the Internet at http://www.mbusa.com (USA only).



■ The oil level is too low. Avoid long journeys with too little engine oil. There is a risk of engine damage.


The display messages and the corresponding symbol that indicate that the oil level is too low must not be ignored.

Display messages	Possible causes/consequences and ▶ Solutions
Engine Oil Level Low Stop Vehicle Turn Engine Off	 Vehicles without an oil dipstick: the engine oil level is too low. There is a risk of engine damage. ▶ Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions. ▶ Apply the parking brake. ▶ Add engine oil (▷ page 459) and check the oil level (▷ page 457).
Engine Oil Level Too High	Vehicles without an oil dipstick: you have added too much engine oil. There is a risk of damage to the engine or to the catalytic converter. ▶ Have the excess oil siphoned off at a qualified specialist workshop. Observe the legal requirements.
Engine Oil Level Cannot Be Measured	Vehicles without an oil dipstick: the measuring system is defective. ▶ Visit a qualified specialist workshop.
Reserve Fuel	The fuel level has dropped into the reserve range. ▶ Refuel at the nearest gas station.
	There is only a very small amount of fuel in the fuel tank. ▶ Refuel at the nearest gas station without fail.
Gas Cap Loose	The fuel system pressure is too low. The fuel filler cap is not closed correctly or the fuel system is leaking. ▶ Check that the fuel filler cap is correctly closed. If the fuel filler cap is not correctly closed: ▶ Close the fuel filler cap. If the fuel filler cap is correctly closed:
	► Visit a qualified specialist workshop.
Ultra Low-sulfur Diesel Fuel Only	Vehicles with a diesel engine: the fuel level has fallen below the reserve range. ▶ Refuel at the nearest gas station. ▶ Only use commercially available vehicular ULTRA-LOW SULFUR HIGHWAY DIESEL FUEL (ULSD, 15 ppm SULFUR MAXIMUM).



Display messages	Possible causes/consequences and ▶ Solutions
Replace Air Filter	Vehicles with a diesel engine: the engine air filter is dirty and must be replaced. ▶ Visit a qualified specialist workshop.
Check Fuel Filter	Vehicles with a diesel engine: there is water in the fuel filter. The water must be drained off. ▶ Visit a qualified specialist workshop.
Check Additive See Oper. Manual	The DEF tank is empty. ► Have the DEF tank filled as soon as possible at a qualified specialist workshop (> page 321).
Remaining Starts:	The DEF level has fallen to a minimum. ▶ Have the DEF tank filled immediately at a qualified specialist workshop. (> page 321)

Driving systems	
Display messages	Possible causes/consequences and ▶ Solutions
Attention Assist: Pause!	Based on specific criteria, ATTENTION ASSIST ²¹ has determined that the driver is tired or paying less attention. A warning tone also sounds. ▶ If necessary, take a break. During long journeys, take regular breaks in good time so you get enough rest.
Attention Assist Inoperative	ATTENTION ASSIST ²¹ has failed. ▶ Visit a qualified specialist workshop.
Night View Assist Inoperative	Night View Assist Plus is defective. ▶ Visit a qualified specialist workshop.





Display messages	Possible causes/consequences and ▶ Solutions
Night View Assist Currently Unavailable	The temperature of the camera is too high. ➤ Wait until you see the Night View Assist Available Again display message. You can also: ➤ Fold the camera cover down (> page 467). ➤ Adjust the air distribution of the automatic air conditioning upwards.
Night View Assist Lights Must Be Set to AUTO or ON	A condition for activating Night View Assist Plus has not been fulfilled. ▶ Turn the light switch to ▲ or 赵.
Night View Assist Not In Reverse Gear	A condition for activating Night View Assist Plus has not been fulfilled. ▶ Shift the transmission to P, N or D.
Night View Assist Lights ON or AUTO, Not in R Gear	A condition for activating Night View Assist Plus has not been fulfilled. ▶ Turn the light switch to A or D. ▶ Shift the transmission to P, N or D.
Night View Assist Only When It Is Dark	You have attempted to activate Night View Assist Plus in the daytime. Night View Assist Plus can only be activated when it is dark.
Vehicle Rising	Your vehicle is adjusting to the level you have selected.
Vehicle Rising Please Wait Briefly	The vehicle level is too low when the vehicle is stationary. A warning tone also sounds. ▶ Do not pull away. The vehicle level is set when the display message disappears.
STOP Car Too Low	You have pulled away while the vehicle level is still too low. AIRMATIC sets the vehicle to the selected level after a short period. ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. ▶ Apply the electric parking brake.



▶ Wait until the display message disappears before pulling away.

Possible causes/consequences and ▶ Solutions Display messages AIRMATIC is defective. A warning tone also sounds. ▶ Do not drive faster than 50 mph (80 km/h). ▶ Make only slight steering movements. Otherwise, the front fender or the tires could be damaged if the steering movement is too large. ▶ Listen for scraping sounds. ▶ Pull over and stop the vehicle safely, paying attention to road and traffic conditions, and select a higher vehicle level. Depending on the malfunction, it may be possible to raise the vehicle. ► Visit a qualified specialist workshop. The AIRMATIC function is restricted. The vehicle's handling Malfunction 5 4 1 characteristics may be affected. ▶ Do not drive faster than 50 mph (80 km/h). ► Visit a qualified specialist workshop. **ABC** The ABC (Active Body Control) vehicle level is too low. Malfunction Stop ▶ Pull over and stop the vehicle safely as soon as possible, paying Vehicle attention to road and traffic conditions. After a few seconds, the vehicle level is adjusted and the display message disappears. The vehicle is leaking oil. The display message is shown continuously. ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances. ▶ Notify a qualified specialist workshop or breakdown service. The display message is shown continuously. ABC is malfunctioning. ▶ Do not drive faster than 50 mph (80 km/h). ▶ Make only slight steering movements. Otherwise, the front fender or the tires could be damaged if the steering movement is too large. ► Listen for scraping sounds. ► Visit a qualified specialist workshop.



Display messages	Possible causes/consequences and ▶ Solutions
ABC Vehicle Rising Please Wait Briefly	The ABC vehicle level is too low when the vehicle is stationary. ▶ Do not pull away. The vehicle level is set when the display message disappears.
ABC Malfunction	The ABC function is restricted. The vehicle's handling characteristics may be affected. ▶ Do not drive faster than 50 mph (80 km/h). ▶ Visit a qualified specialist workshop.
HOLD Off	The HOLD function is deactivated. The vehicle is skidding. A warning tone also sounds. ▶ Reactivate the HOLD function later (▷ page 342).
	The HOLD function is deactivated. When the brake pedal is firmly depressed, an activation condition is not fulfilled. A warning tone also sounds. ▶ Check the activation conditions for the HOLD function (▷ page 342).
Radar Sensors Deactivated See Oper. Manual	The radar sensor system is deactivated. ➤ Switch on the radar sensor system (▷ page 387).
Lane Keeping Assist Currently Unavailable. See Operator's Manual or Lane Keeping Assist Currently Unavailable. See Operator's Manual	Lane Keeping Assist or Active Lane Keeping Assist is deactivated and temporarily inoperative if: • the windshield is dirty in the camera's field of vision. • visibility is impaired due to heavy rain, snow or fog. • there are no lane markings for a longer period. • the lane markings are worn, dark or covered, for example by dirt or snow. Lane Keeping Assist or Active Lane Keeping Assist is operational again and the display message disappears if: • the dirt (e.g. slush) drops away while the vehicle is in motion. • the system recognizes that the camera is fully operational again. If the display message continues to be displayed: ▶ Clean the windshield.
Lane Keeping Assist Inoperative or Active Lane Keeping Assist Inoperative	Lane Keeping Assist or Active Lane Keeping Assist is defective. ▶ Visit a qualified specialist workshop.



Display messages	Possible causes/consequences and ▶ Solutions
Blind Spot Assist Currently	Blind Spot Assist or Active Blind Spot Assist is temporarily inoperative if:
Unavailable See Oper. Manual or Active Blind Spot Assist Currently Unavailable See Oper. Manual	 the sensors are dirty. its function is impaired due to heavy rain or snow. the radar sensor system is outside the operating temperature range. the radar sensor system is temporarily inoperative, e.g. due to electromagnetic radiation emitted by nearby TV or radio stations or other sources of electromagnetic radiation.
	The yellow indicator lamps also light up in the exterior mirrors. Blind Spot Assist or Active Blind Spot Assist is operational again and the display message disappears if:
	 the dirt (e.g. slush) drops away while the vehicle is in motion. the system detects that the sensors are fully available again. the radar sensor system is back within the operating temperature range.
	If the display message continues to be displayed: ▶ Clean the sensors (▷ page 467). ▶ Restart the engine.
Blind Spot Assist Inoperative or Active Blind Spot Assist Inoperative	Blind Spot Assist or Active Blind Spot Assist is defective. The yellow ▲ indicator lamps also light up in the exterior mirrors. ► Visit a qualified specialist workshop.
Parking Guidance Inoperative	Parking Guidance is malfunctioning (▷ page 350). ▶ Restart the engine. If the display message continues to be displayed: ▶ Visit a qualified specialist workshop.



Display messages	Possible causes/consequences and ▶ Solutions
Parking Guidance Canceled	Parking Guidance has been deactivated because: • the vehicle is skidding. • the sensors are dirty. • a malfunction has occurred. ▶ Reactivate Parking Guidance later (▷ page 350). If the parking space symbol is not displayed in the multifunction display when you are driving at a speed of less than 19 mph (30 km/h): ▶ Clean the sensors (▷ page 467). ▶ Restart the engine. If the parking space symbol is still not displayed in the multifunction display when you are driving at a speed of less than 19 mph (30 km/h): ▶ Visit a qualified specialist workshop.
	Parking Guidance has been deactivated because you are no longer following the recommended path. ▶ Park again and, while doing so, observe the display messages in the multifunction display.
Parking Guidance Finished	The vehicle is parked. A warning tone also sounds. The display message disappears automatically.
DISTRONIC PLUS Off	DISTRONIC PLUS has been deactivated (\triangleright page 332). If it was deactivated automatically, a warning tone also sounds.
DISTRONIC PLUS Available Again	DISTRONIC PLUS is operational again after having been temporarily unavailable. You can now reactivate DISTRONIC PLUS (▷ page 332).



Display messages	Possible causes/consequences and ▶ Solutions
DISTRONIC PLUS Currently Unavailable See Operator's Manual	DISTRONIC PLUS is deactivated and is temporarily inoperative if: • the DISTRONIC PLUS cover in the radiator grill is dirty. • its function is impaired due to heavy rain or snow. • the sensors in the bumpers are dirty. • the radar sensor system is temporarily inoperative, e.g. due to electromagnetic radiation emitted by nearby TV or radio stations or other sources of electromagnetic radiation. • the system is outside the operating temperature range. • the on-board voltage is too low. A warning tone also sounds. DISTRONIC PLUS is operational again and the display message disappears if: • the dirt (e.g. slush) drops away while the vehicle is in motion. • the system detects that the sensors are fully available again. • the system is within the operating temperature range. If the display message continues to be displayed: ▶ Clean the DISTRONIC PLUS cover in the radiator grill (▷ page 467). ▶ Clean the bumpers (▷ page 467). ▶ Restart the engine.
DISTRONIC PLUS Inoperative	DISTRONIC PLUS is defective. BAS PLUS (Brake Assist PLUS) and PRE-SAFE® Brake may be inoperative as well. A warning tone also sounds. ▶ Visit a qualified specialist workshop.
DISTRONIC PLUS Override	You have depressed the accelerator pedal. DISTRONIC PLUS is no longer controlling the speed of the vehicle. ▶ Take your foot off the accelerator pedal.
DISTRONIC PLUS mph	An activation condition for DISTRONIC PLUS is not fulfilled. ▶ Check the activation conditions for DISTRONIC PLUS (▷ page 332).



Display messages	Possible causes/consequences and ▶ Solutions
Cruise Control Inoperative	Cruise control is defective. A warning tone also sounds. ▶ Visit a qualified specialist workshop.
Cruise Control	A condition for activating cruise control has not been fulfilled. You attempted to save a speed of less than 20 mph (30 km/h). ▶ If the situation allows, drive faster than 20 mph (30 km/h) and save the speed. ▶ Check the activation conditions for cruise control (▷ page 330).

Tires



/ WARNING

Do not drive with a flat tire. A flat tire affects the ability to steer or brake the vehicle. You may lose control of the vehicle. Continued driving with a flat tire will cause excessive heat build-up and possibly a fire.



↑ WARNING

Follow recommended tire inflation pressures.

Do not underinflate tires. Underinflated tires wear excessively and/or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.

Display messages	Possible causes/consequences and ▶ Solutions
Tire pressures Displayed After Driving A Few Minutes	The tire pressure monitor is measuring the tire pressure. ▶ Drive on. The tire pressures appear in the multifunction display after you have been driving for a few minutes.
Tire Pressure Monitor Inoperative	The tire pressure monitor is defective. ▶ Visit a qualified specialist workshop.
Tire Pressure Monitor Inoperative No Wheel Sensors	The wheels mounted do not have a suitable tire pressure sensor. The tire pressure monitor is deactivated. ▶ Mount wheels with suitable tire pressure sensors. The tire pressure monitor is activated automatically after driving for a few minutes.



Display messages	Possible causes/consequences and ▶ Solutions
Check Tires	 Risk of accident The tire pressure in one or more tires has dropped significantly. The wheel position is displayed in the multifunction display. A warning tone also sounds. ▶ Stop the vehicle without making any sudden steering or braking maneuvers. Pay attention to the traffic conditions as you do so. ▶ Correct the tire pressure (▷ page 497). ▶ If necessary, change a wheel (▷ page 513).
Caution Tire Defect	
Tire Pressure Please Rectify	The tire pressure is too low in at least one of the tires or the tire pressure difference between the wheels is too great. ▶ Check the tire pressures at the next opportunity. If necessary, correct the tire pressure (▷ page 497). ▶ Restart the tire pressure monitor (▷ page 499).
Wheel sensor(s) Missing	There is no signal from the tire pressure sensor of one or several wheels. The pressure of the affected tire is not displayed in the multifunction display. ▶ Have the defective tire pressure sensor replaced at a qualified specialist workshop.
Tire Pressure Monitor Currently Unavailable	Due to a source of radio interference, no signals can be received from the wheel sensors. The tire pressure monitor is temporarily malfunctioning. ▶ Drive on. The tire pressure monitor restarts automatically as soon as the problem has been solved.
Tire Press. Warning Caution Tire Malfunction	



Display messages	Possible causes/consequences and ▶ Solutions
(!)	
Check Tire Pressure	The tire pressure in one or more tires has dropped significantly.
	► Stop the vehicle without making any sudden steering or braking maneuvers. Pay attention to the traffic conditions as you do so.
	▶ If necessary, change a wheel (> page 513).
	► Check the tire pressure. If necessary, correct the tire pressure (> page 497).
(!)	The tire pressure is too low in at least one of the tires or the tire pressure difference between the wheels is too great.

correct the tire pressure (⊳ page 497).

► Check the tire pressures at the next opportunity. If necessary,

Pressure

Correct Tire


Vehicle	
Display messages	Possible causes/consequences and ▶ Solutions
Shift to P or N to Start Engine	You have attempted to start the engine with the transmission in position R or D . ▶ Shift the transmission to position P or N .
Auxiliary Battery Malfunction (White display message)	The auxiliary battery for the automatic transmission is no longer being charged. ▶ Visit a qualified specialist workshop.
Auxiliary Battery Malfunction (Red display message)	The auxiliary battery for the automatic transmission is discharged. If there is a malfunction in the vehicle's electrical system, you may not be able to change the transmission position. Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances. Consult a qualified specialist workshop.
Apply Brake to Shift from 'P'	You have attempted to move the transmission selector lever to position D , R or N without depressing the brake pedal. ▶ Depress the brake pedal.
Door Open Vehicle Not in Park	The driver's door is open and the transmission is in position R , N or D . ▶ Shift the transmission to position P . ▶ Apply the electric parking brake.



Display messages	Possible causes/consequences and ▶ Solutions
Service Required Do Not Shift Gears	You cannot change the transmission position due to a malfunction. A warning tone also sounds. If transmission position D is selected: ▶ Drive to a qualified specialist workshop without shifting the transmission from position D . If transmission position R , N or P is selected: ▶ Notify a qualified specialist workshop or breakdown service.
Only Shift to Position P When Vehicle Is Stationary	 The vehicle is moving. ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. ▶ Shift the transmission to position P.
	The trunk lid is open. ▶ Close the trunk lid.
	
	At least one door is open. ▶ Close all the doors.
Power Steering Malfunction See Oper. Manual	
Check Washer Fluid	The washer fluid level in the washer fluid reservoir has dropped below the minimum. ▶ Add washer fluid (▷ page 461).



SmartKey Display messages Possible causes/consequences and ▶ Solutions You have put the wrong SmartKey in the ignition lock. ▶ Use the correct SmartKey. Key Does Not Belong to Vehicle The SmartKey is in the ignition lock. ▶ Remove the SmartKey. Take Your Key From Ignition The SmartKey needs to be replaced. ► Visit a qualified specialist workshop. Obtain a New Key The batteries of the KEYLESS-GO key are discharged. ► Change the batteries (> page 82). Replace Key Battery The display message is shown for a maximum of 60 seconds and is only a reminder. Don't Forget Your You have opened the driver's door with the engine switched off. Key The KEYLESS-GO key is not in the ignition lock. ▶ Remember to take the KEYLESS-GO key with you when you leave the vehicle. The KEYLESS-GO key is not in the vehicle. A warning tone also sounds. Key Not Detected



If the engine is switched off, you can no longer lock the vehicle centrally or start the engine.

- ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.
- ► Engage the electric parking brake.
- ▶ Locate the KEYLESS-GO key.

The KEYLESS-GO key is not detected while the engine is running because there is interference from a strong source of radio waves.

A warning tone also sounds.

- ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.
- ► Engage the electric parking brake.
- ▶ Operate the vehicle with the SmartKey in the ignition lock.



Lock Vehicle

Display messages	Possible causes/consequences and ▶ Solutions
Key Not Detected (White display message)	The KEYLESS-GO key cannot be detected at present. ➤ Change the location of the key with the KEYLESS-GO functions in the vehicle. If the KEYLESS-GO key is still not detected: ➤ Operate the vehicle with the SmartKey in the ignition lock.
Key Detected In Vehicle	The KEYLESS-GO key has been detected inside the vehicle during locking. ▶ Remove the KEYLESS-GO key from the vehicle.
Remove 'Start' Button and Insert Key	 KEYLESS-GO is temporarily malfunctioning or is defective. ▶ Insert the SmartKey into the ignition lock and turn it to the desired position. ▶ Visit a qualified specialist workshop.
Close Doors to	At least one door is open. A warning tone also sounds. ▶ Close all doors and lock the vehicle again.

Warning and indicator lamps in the instrument cluster

Seat belt **Problem** Possible causes/consequences and ▶ Solutions * The seat belt warning lamp reminds the driver and front passenger to fasten their seat belts. After starting the engine, the red seat ► Fasten your seat belt (> page 57). belt warning lamp lights up for six seconds. * After starting the The driver's seat belt is not fastened. engine, the red seat ► Fasten your seat belt (> page 57). belt warning lamp lights The warning tone ceases. up. In addition, a warning tone sounds for up to six seconds.



Problem



The red seat belt warning lamp lights up after the engine starts, as soon as the driver's or the front-passenger door is closed.

Possible causes/consequences and ▶ Solutions

The driver or front passenger has not fastened their seat belt.

► Fasten your seat belt (> page 57). The warning lamp goes out.

There are objects on the front-passenger seat.

▶ Remove the objects from the front-passenger seat and stow them in a secure place.

The warning lamp goes out.



The red seat belt warning lamp flashes and an intermittent audible warning sounds.

The driver or front passenger has not fastened their seat belt. In addition, you are driving faster than 15 mph (25 km/h) or you have briefly driven faster than 15 mph (25 km/h).

► Fasten your seat belt (> page 57). The warning lamp goes out and the intermittent warning tone ceases.

Risk of injury

There are objects on the front-passenger seat. In addition, you are driving faster than 15 mph (25 km/h) or you have briefly driven faster than 15 mph (25 km/h).

▶ Remove the objects from the front-passenger seat and stow them in a secure place.

The warning lamp goes out and the intermittent warning tone ceases.



Safety systems

Problem

Possible causes/consequences and ▶ Solutions

BRAKE (USA only)

(Canada only)

The red brake system warning lamp comes on while the engine is running. A warning tone also sounds.

There is not enough brake fluid in the brake fluid reservoir.

- ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.
- ► Engage the electric parking brake.
- ► Consult a qualified specialist workshop immediately.
- ▶ Observe the additional display messages in the multifunction display.

Do not add brake fluid. This will not rectify the malfunction.

WARNING

Driving with the brake warning lamp illuminated can result in an accident. Have your brake system checked immediately if the brake warning lamp stays on. Do not add brake fluid before checking the brake system.

Overfilling the brake fluid reservoir can result in spilling brake fluid on hot engine parts and the brake fluid catching fire. You can be seriously burned.



Problem

Possible causes/consequences and ▶ Solutions



The yellow ABS warning lamp is lit while the engine is running.



ABS (Anti-lock Brake System) is deactivated due to a malfunction. BAS (Brake Assist), BAS PLUS, ESP® (Electronic Stability Program), PRE-SAFE®, PRE-SAFE® Brake, the HOLD function and hill start assist are therefore also deactivated, for example.

The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example.

ATTENTION ASSIST²² is deactivated.

- Observe the additional display messages in the multifunction display.
- ▶ Drive on carefully.
- ▶ Visit a qualified specialist workshop.



The yellow ABS warning lamp is lit while the engine is running.

ABS is temporarily unavailable. BAS, BAS PLUS, ESP $^{\$}$, EBD (electronic brake force distribution), PRE-SAFE $^{\$}$,

PRE-SAFE® Brake, the HOLD function, hill start assist are therefore also deactivated, for example.

Self diagnosis is not yet complete or the on-board voltage may be insufficient, for example.

The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example.

ATTENTION ASSIST²² is deactivated.

► Carefully drive a suitable distance making slight steering movements at a speed above 12 mph (20 km/h).

The functions mentioned above are available again when the warning lamp goes out.

If the warning lamp is still on:

- Observe the additional display messages in the multifunction display.
- ► Drive on carefully.
- ► Visit a qualified specialist workshop.



Problem



The yellow ABS warning lamp is lit while the engine is running. A warning tone also sounds.

Possible causes/consequences and ▶ Solutions

EBD is faulty. Therefore, ABS, BAS, BAS PLUS, ESP®, PRE-SAFE®, PRE-SAFE® Brake, the HOLD function and hill start assist are also unavailable, for example.

The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example.

ATTENTION ASSIST²² is deactivated.

- ▶ Observe the additional display messages in the multifunction display.
- ▶ Drive on carefully.
- ► Visit a qualified specialist workshop.





The red brake warning lamp, the yellow ESP® and ESP® OFF warning lamps and the yellow ABS warning lamp are lit while the engine is running.

ABS and ESP® are faulty. Other systems, e.g. BAS, BAS PLUS, EBD, PRE-SAFE®, PRE-SAFE® Brake, the HOLD function and hill start assist, are also not available due to a malfunction.

The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example.

ATTENTION ASSIST²² is deactivated.

- ▶ Observe the additional display messages in the multifunction display.
- ▶ Drive on carefully.
- ▶ Visit a qualified specialist workshop.



The yellow ESP® warning lamp flashes while the vehicle is in motion.

ESP® or traction control has intervened because there is a risk of skidding or at least one wheel has started to spin.

Cruise control or DISTRONIC PLUS is deactivated.

- ▶ Only depress the accelerator pedal as far as necessary when pulling away.
- ▶ Ease off the accelerator pedal while the vehicle is in motion.
- ▶ Adapt your driving style to suit the road and weather conditions.
- ▶ Do not deactivate ESP®.

Exceptions: (⊳ page 71).




Problem Possible causes/consequences and ▶ Solutions Sée Sée The yellow ESP® OFF ESP® is deactivated. ESP® will not stabilize the vehicle if it starts warning lamp is lit while to skid or if a wheel starts to spin. the engine is running. ▶ Reactivate ESP[®]. Exceptions: (⊳ page 71). ▶ Adapt your driving style to suit the road and weather conditions. If ESP® cannot be activated: ► Have ESP[®] checked at a qualified specialist workshop. P OFF Risk of accident The yellow ESP® and ESP®, BAS, BAS PLUS, PRE-SAFE®, PRE-SAFE® Brake, the HOLD ESP® OFF warning function and hill start assist are not available due to a malfunction. lamps are lit while the ESP® will not stabilize the vehicle if it starts to skid or if a wheel engine is running. starts to spin. The brake system continues to function normally, but without the functions listed above. ATTENTION ASSIST²² is deactivated. ▶ Observe the additional display messages in the multifunction

► Visit a qualified specialist workshop.

display.

▶ Drive on carefully.





Problem



The yellow ESP® and ESP® OFF warning lamps are lit while the engine is running.

Possible causes/consequences and ▶ Solutions

ESP®, BAS, PRE-SAFE®, the HOLD function and hill start assist are temporarily unavailable.

BAS PLUS and PRE-SAFE® Brake may also have failed.

ESP® will not stabilize the vehicle if it starts to skid or if a wheel starts to spin.

Self diagnosis is not yet complete.

The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example.

ATTENTION ASSIST²² is deactivated.

▶ Carefully drive a suitable distance making slight steering movements at a speed above 12 mph (20 km/h). The functions mentioned above are available again when the warning lamp goes out.

If the warning lamp is still on:

- ▶ Observe the additional display messages in the multifunction display.
- ▶ Drive on carefully.
- ► Visit a qualified specialist workshop.

PARK (USA only)

(Canada only)

The red indicator lamp for the electric parking brake flashes and/or the yellow warning lamp for the electric parking brake lights up. The electric parking brake is temporarily malfunctioning or defective.


▶ Observe the additional display messages in the multifunction display.



The red SRS warning lamp is lit while the engine is running.

The restraint systems are malfunctioning. The air bags or ETDs may either be triggered unintentionally or, in the event of an accident, not be triggered at all.

- ▶ Drive on carefully.
- ▶ Visit a qualified specialist workshop immediately.





↑ WARNING

In the event a malfunction of the SRS is indicated as outlined above, the SRS may not be operational.

For your safety, we strongly recommend that you contact an authorized Mercedes-Benz Center immediately to have the system checked. Otherwise the SRS may not be activated when needed in an accident, which could result in serious or fatal injury, or it might deploy unexpectedly and unnecessarily which could also result in injury.

Engine

Problem

The yellow Check Engine warning lamp lights up while the engine is running.

Possible causes/consequences and ▶ Solutions

There may be a malfunction, for example:

- in the engine management
- in the fuel injection system
- in the exhaust system
- in the ignition system (for vehicles with a gasoline engine)
- in the fuel system

The emission limit values may be exceeded and the engine may be running in emergency mode.

- ▶ Have the vehicle checked as soon as possible at a qualified specialist workshop.
- 1 In some states, you are required by law to immediately visit a qualified specialist workshop as soon as the yellow Check Engine warning lamp lights up. If in doubt, check whether such legal regulations apply in the state/province in which you are currently driving.

Vehicles with a diesel engine: the fuel tank has been run dry (⊳ page 320).

▶ Start the engine three to four times after refueling. If the yellow Check Engine warning lamp goes out, emergency running mode is canceled. The vehicle need not be checked.



Problem Possible causes/consequences and ▶ Solutions The yellow reserve fuel The fuel system pressure is too low. The fuel filler cap is not closed warning lamp flashes correctly or the fuel system is leaking. while the vehicle is in ▶ Observe the additional display messages in the multifunction motion. display. In addition, the | 1 ▶ Check that the fuel filler cap is correctly closed. yellow Check Engine ▶ If the fuel filler cap is not correctly closed: close the fuel filler warning lamp may light up. ▶ If the fuel filler cap is closed: visit a qualified specialist workshop. The fuel level has dropped into the reserve range. The yellow reserve fuel warning lamp lights up ▶ Refuel at the nearest gas station. while the engine is running.

Driving systems

Problem

The red distance warning lamp lights up while the vehicle is in motion. A warning tone also sounds.

Possible causes/consequences and ▶ Solutions



The warning is issued if you approach a stationary vehicle or a vehicle driving ahead of you at too high a speed.

- ▶ Be prepared to brake immediately.
- ▶ Pay careful attention to the traffic situation. You may have to brake or take evasive action.

More information about DISTRONIC PLUS (▷ page 332) and PRE-SAFE® Brake (⊳ page 73).



Tires

Problem



Possible causes/consequences and ▶ Solutions



USA only:

The yellow tire pressure monitor warning lamp (pressure loss/ malfunction) is lit.

Canada only:

The yellow tire pressure monitor warning lamp (pressure loss) is lit.



The tire pressure monitor has detected a loss of pressure in at least one of the tires.

- ▶ Stop the vehicle without making any sudden steering or braking maneuvers. Pay attention to the traffic conditions as you do so.
- ▶ Observe the additional display messages in the multifunction display.
- ▶ Check the tire pressure. If necessary, correct the tire pressure (⊳ page 497).
- ▶ If necessary, change a wheel (▷ page 513).



USA only:

The yellow tire pressure monitor warning lamp (pressure loss/ malfunction) flashes for 60 seconds and then remains lit.

The tire pressure monitor is faulty.

- ▶ Observe the additional display messages in the multifunction
- ► Visit a qualified specialist workshop.



↑ WARNING

Each tire, including the spare (if provided), should be checked at least every two weeks when cold and inflated to the pressure recommended by the vehicle manufacturer on the Tire and Loading Information placard on the driver's door B-pillar or, if available, the tire pressure label on the inside of the fuel filler flap. If your vehicle has tires of a different size than the size indicated on the Tire and Loading Information placard or the tire pressure label, you should determine the proper tire pressure for those tires.

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale when one or more of your tires are significantly underinflated. Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly underinflated tire causes the tire to overheat and can lead to tire failure.

Underinflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability. Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if underinflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale.

USA only:

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the telltale will flash for approximately 1 minute and then remain continuously illuminated. This sequence will be repeated every time



the vehicle is started as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended.

TPMS malfunctions may occur for a variety of reasons, including the installation of incompatible replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly. Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.



Useful information	432
Loading guidelines	432
Stowage areas	432
Features	437

Useful information

- 1 This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- 1 Please read the information on qualified specialist workshops (⊳ page 31).

Loading guidelines



↑ WARNING

Always fasten items being carried as securely as possible. Use cargo tie-down rings and fastening materials appropriate for the weight and size of the load.

In an accident, during hard braking or sudden maneuvers. loose items will be thrown around inside the vehicle. This can cause injury to vehicle occupants unless the items are securely fastened in the vehicle.

To help avoid personal injury during a collision or sudden maneuver, exercise care when transporting cargo. Do not pile luggage or cargo higher than the seat backrests.

The trunk is the preferred place to carry objects.

Never drive a vehicle with the trunk open. Deadly carbon monoxide (CO) gases may enter vehicle interior resulting in unconsciousness and death.

The handling characteristics of a laden vehicle are dependent on the distribution of the load within the vehicle. For this reason. you should observe the following notes when transporting a load:

 when transporting a load, never exceed the maximum permissible gross vehicle weight or the gross axle weight rating of the

- vehicle (including occupants). The values are specified on the vehicle identification plate on the B-pillar of the driver's door.
- position heavy loads as far forwards as possible and as low down in the trunk as possible.
- the load must not protrude above the upper edge of the seat backrests.
- always place the load against the rear seat backrests.
- always place the load behind unoccupied seats if possible.
- secure the load with sufficiently strong and wear-resistant tie down, pad sharp edges for protection.

Stowage areas

Stowage compartments

Important safety notes



↑ WARNING

To help avoid personal injury during a collision or sudden maneuver, exercise care when storing objects in the vehicle. Put luggage or cargo in the trunk if possible.

Do not pile luggage or cargo higher than the seat backrests.

Keep compartment lids closed. This will help to prevent stored objects from being thrown about and injuring vehicle occupants during

- braking
- · vehicle maneuvers
- · an accident

Stowage compartments in the front


Glove box

1 Depending on the vehicle's equipment, you will find the following installed in the glove box: an audio and video AUX jack, a USB socket or Media Interface, a universal interface for portable audio equipment, e.g. for an iPod or USB device, and a bracket for




a remote control (see the COMAND section in this Operator's Manual).

The glove box can be ventilated
 (▷ page 299).



- ▶ To open: press button (1).
- ► To close: fold glove box flap ② upwards until it engages.

The glove box can only be locked and unlocked using the mechanical key.



- 1 Glove box unlocked
- 2 Glove box locked

Eyeglasses compartment



▶ To open: press marking (1).

Stowage compartment under the armrest

- 1 The

 Roadside Assistance call button and (▷ page 445) and the

 MB Info call button are located (▷ page 446) in the stowage compartment under the armrest.
- 1 In the stowage compartment, there is a partition which can be used to divide up the stowage compartment.



► **To open:** press button ① and fold the armrest to the left or right.

Stowage compartments in the doors

↑ WARNING

Keep the door storage compartments closed while vehicle is in motion. Failure to do so may cause the seat belt to catch at the rear and prevent proper positioning of the seat belt.



► To open: pull cover ① upwards.



Coat hook

The coat hooks are located on the left and right in the headliner in the rear compartment.

Only hang light loads on the coat hooks. Do not place a load of more than 6.6 lbs (3 kg) on the coat hooks.



- ► To open: press coat hook ①.

 The coat hooks fold out.
- ► To close: press coat hook ① until it engages.

Stowage compartments in the rear

Stowage compartment in the rear seat armrest

- Do not sit or lean your bodyweight on the armrests when they are folded out as you could damage them.
- I Close the cover of the stowage compartment before folding the rear seat armrest back into the seat backrest.



Vehicles without a control panel in the rear seat armrest

- ▶ To open: fold down the seat armrest.
- ▶ Pull handle ① and fold the armrests upwards.



Vehicles with a control panel in the rear seat armrest

► To open: press button ① and fold up the armrest.

Stowage box between the rear seats



► To open: pull handle ① backwards in the direction of the arrow.

Stowage box in the rear seat backrest

■ Do not sit or lean your bodyweight on the armrests when they are folded out as you could damage them.





- ▶ To open: fold down the rear seat armrest.
- ▶ Pull handle (1) and fold down cover (2).
- 1 It will be easier to open the cover when the rear seats are in the basic position.

Stowage pockets

↑ WARNING

Storage bags are intended for storing lightweight items only.

Heavy objects, objects with sharp edges or fragile objects may not be transported in the storage bag. In an accident, during hard braking, or sudden maneuvers, they could be thrown around inside the vehicle and cause injury to vehicle occupants.

Storage bags cannot protect transported goods in the event of an accident.

Storage bags are located in the rear compartment on the driver's and frontpassenger seat backrests.

Parcel nets

↑ WARNING

Parcel nets are intended for storing lightweight items only, such as road maps, mail, etc.

Heavy objects, objects with sharp edges, or fragile objects may not be transported in the parcel nets. In an accident, during hard braking, or sudden maneuvers, they could be thrown around inside the vehicle and cause injury to vehicle occupants.

Parcel nets cannot protect transported goods in the event of an accident.

Parcel nets are located in the front-passenger footwell and on the left and right-hand sides of the trunk.

Securing cargo

Cargo tie-down rings

Observe the following notes on securing loads:

- · secure the load using the cargo tie down rings.
- do not use elastic straps or nets to secure a load, as these are only intended as an anti-slip protection for light loads.
- do not route tie downs across sharp edges or corners.
- pad sharp edges for protection.


There are four cargo tie down rings in the trunk.



Bag hooks

I The bag hook can bear a maximum load of 6.6 lbs (3 kg). Do not use it to secure a load.





▶ Pull bag hook ② down by tab ①.

Stowage well under the trunk floor

Stowage well

You can store a suitcase in the stowage well underneath the front section of the trunk floor.


Fold down the suitcase handle before closing the trunk. You could otherwise damage the trunk lid.



- 1 Trunk floor
- ② Stowage well for suitcases

Rear stowage compartment

In the S 600 model, you can fold the rear part of the trunk floor forwards.



- 1 Stowage well
- ② Stowage compartment

Roof carrier

Important safety notes



♠ WARNING

Only use roof racks approved by Mercedes-Benz for your vehicle model to avoid damage to the vehicle.

Follow the manufacturer's installation instructions. Otherwise, an improperly attached roof rack system or its load could become detached from the vehicle.

Do not exceed the maximum roof load of 220 lb (100 kg).

Take into consideration that when the roof rack is loaded, the handling characteristics are different from those when operating the vehicle without the roof rack loaded.

Mercedes-Benz recommends that you only use roof carriers that have been tested and approved for Mercedes-Benz vehicles. This helps to prevent damage to the vehicle.


Position the load on the roof carrier in such a way that the vehicle will not sustain damage even when it is in motion.



Depending on the vehicle equipment, ensure that when the roof carrier is installed you can:

- raise the sliding sunroof fully
- open the panorama roof with power tilt/ sliding panel fully
- open the trunk lid fully

Attaching the roof carrier



- ▶ Open covers (1) carefully in the direction of the arrow.
- ► Fold covers (1) upwards.
- ▶ Only secure the roof carrier to the anchorage points under covers (1).
- ▶ Observe the manufacturer's installation instructions.

Features

Cup holders

Important safety notes

♠ WARNING

In order to help prevent spilling liquids on vehicle occupants and/or vehicle equipment, only use containers that fit into the cup holder. Use lids on open containers and do not fill containers to a height where the contents, especially hot liquids, could spill during braking, vehicle maneuvers, or in an accident. Liquids spilled on vehicle occupants may cause serious personal injury. Liquids spilled on vehicle equipment may cause

damage not covered by the Mercedes-Benz Limited Warranty.

When not in use, keep the cup holder closed. An open cup holder may cause injury to you or others when contacted during braking, vehicle maneuvers, or in an accident.

Keep in mind that objects placed in the cup holder may come loose during braking, vehicle maneuvers, or in an accident and be thrown around in the vehicle interior. Objects thrown around in the vehicle interior may cause an accident and/or serious personal injury.

Cup holder in the front-compartment center console

You can remove the cup holder to clean it. Clean with clear, lukewarm water only.



- ▶ To open: press marking (1).
- ► To remove: slide catch (2) back and pull the cup holder upwards.
- ▶ To insert: insert the cup holder and slide catch (2) forwards.

Cup holder in the rear seat armrest

- Do not sit on or support your body weight on the rear seat armrest when it is folded down, as you could otherwise damage it.
- I Close the cup holder before folding the rear seat armrest up. Otherwise, the cup holder could be damaged.





Vehicles without multicontour seats in the rear compartment



Vehicles without Rear Seat Entertainment System



Vehicles with Rear Seat Entertainment System


- ▶ Fold down the rear seat armrest.
- ▶ **To open:** press the front of cup holder (1). Cup holder (1) extends automatically.
- ▶ To close: slide the cup holder back until it engages.

Sun visors

Overview of sun visors

↑ WARNING

Do not use the vanity mirror while driving. Keep the vanity mirrors in the sun visors closed while the vehicle is in motion. Reflected glare can endanger you and others.



- 1) Mirror light
- ② Bracket
- 3 Retaining clip, e.g. for a car park ticket
- (4) Vanity mirror
- (5) Mirror cover

Vanity mirror in the sun visor

Mirror light (1) only functions if the sun visor is clipped into retainer (2) and mirror cover (5) has been folded up.

Glare from the side

- ► Fold down the sun visor.
- ▶ Pull the sun visor out of retainer ②.
- ▶ Swing the sun visor to the side.



Rear window roller sunblind

Important safety notes

★ WARNING

When leaving the vehicle, always remove the SmartKey from the ignition lock. Always take the SmartKey with you and lock the vehicle. Do not leave children unattended in the vehicle, even if they are secured in a child restraint system, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury. The children could:

- injure themselves on parts of the vehicle
- be seriously or fatally injured through excessive exposure to extreme heat or cold
- injure themselves or cause an accident with vehicle equipment that can be operated even if the SmartKev is removed from the ignition lock or removed from the vehicle, such as seat adjustment, steering wheel adjustment, or the memory function

If children open a door, they could injure other persons or get out of the vehicle and injure themselves or be injured by following traffic. Do not expose the child restraint system to direct sunlight. The child restraint system's metal parts, for example, could become very hot, and the child could be burned on these

parts.

↑ WARNING


When adjusting a roller sunblind, the roller blind moves up or down. You might become trapped in the process.

In the event of danger, briefly press the button for the roller sunblind to change the roller blind's direction of movement.

Extending/retracting from the driver's seat

Make sure that the roller sunblind can move freely. Otherwise, the roller sunblind or other objects could be damaged.

At temperatures below -4 °F (-20 °C), the roller sunblind cannot be operated.



- ► To extend or retract: briefly press button (1).
 - The roller sunblind fully extends or fully
- ▶ To stop: briefly press button (1) again. The roller sunblind stops briefly and moves back into the out-of-use position.

Extending/retracting from the rear

The switch is located on the rear door control panel.



Extending

- ▶ Pull switch (1) up and release it. The roller sunblind extends fully.
- ▶ To stop: press switch (1) down briefly. The roller sunblind stops briefly and then retracts again.




Retracting

- ▶ Press switch (1) down past the point of resistance and release it. The roller sunblind retracts fully.
- ▶ To stop: pull switch (1) up. The roller sunblind stops briefly and then extends again.

Ashtray

Ashtray in the front-compartment center console



- ▶ To open: slide cover (1) forwards until it engages.
- ▶ To remove insert: hold insert (3) by the ribbing at the sides and lift it up (2) and out.
- ► To re-install the insert: press insert ③ into the holder until it engages.
- ▶ To close: press cover (1) briefly at the front.

The cover moves back.

Ashtray in the rear-compartment center console

The ashtrays are located in the rear doors.



- ► To open: lift up cover ②.
- ▶ To remove the insert: press open cover (2) past the stop. Insert (1) pops out of the holder.
- ▶ Lift insert (1) up and out.
- ▶ To install the insert: install insert (1) from above into the holder and press down into the holder until it engages.

Cigarette lighter



♠ WARNING

When leaving the vehicle, always remove the SmartKey from the ignition lock. Always take the SmartKey with you and lock the vehicle. Do not leave children unattended in the vehicle, even if they are secured in a child restraint system, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury. The children could:

- injure themselves on parts of the vehicle
- be seriously or fatally injured through excessive exposure to extreme heat or cold
- injure themselves or cause an accident with vehicle equipment that can be operated even if the SmartKey is removed from the ignition lock or removed from the vehicle, such as seat adjustment, steering wheel adjustment, or the memory function



If children open a door, they could injure other persons or get out of the vehicle and injure themselves or be injured by following traffic.

Do not expose the child restraint system to direct sunlight. The child restraint system's metal parts, for example, could become very hot, and the child could be burned on these parts.

↑ WARNING

Never touch the heating element or sides of the lighter; they are extremely hot. Hold the knob only.

Make sure any children traveling with you do not injure themselves or start a fire with the hot cigarette lighter.



Center console, front

- ► Turn the SmartKey to position 2 in the ignition lock.
- ▶ To open: slide cover (1) forwards until it engages.
- ▶ Press in cigarette lighter ②. Cigarette lighter (2) will pop out automatically when the heating element is red-hot.
- ▶ To close: press cover (1) briefly at the front.

The cover moves back.



Center console, rear compartment

▶ Press in cigarette lighter (1). Cigarette lighter (1) will pop out automatically when the heating element is red-hot.

12 V sockets

Points to observe before use

The sockets can be used for accessories, e.g. lamps or mobile phone chargers with a maximum current draw of 180 W (15 A). If you use the sockets for long periods when the engine is switched off, the battery may discharge.

- ► Turn the SmartKey to position 1 in the ignition lock.
- 1 An emergency cut-out ensures that the on-board voltage does not drop too low. If the on-board voltage is too low, the power to the sockets is automatically cut. This ensures that there is sufficient power to start the engine.



Socket in the glove box



- ▶ Open the glove box (▷ page 432).
- ▶ Lift up the cover of socket ①.

Socket in the rear-compartment center console



Example: vehicles with the smoker's package

▶ Lift up the cover of socket (1).

Socket in the trunk



▶ Lift up the cover of socket (1).

115 V power socket



↑ WARNING


The 115V AC socket operates at high voltage. Use the 115V AC socket in the vehicle with the same caution and prudence that you exercise when using power outlets at home. Keep any fluids away from the 115V AC socket. Do not clean the socket with fluids or tapered objects. Keep the 115V AC socket cover in the closed position, when not in use. Otherwise, you could suffer an electric shock and be seriously or even fatally injured.

/ WARNING

Any device that you connect must have a suitable plug and meet U.S. standards. Never pull at a cable to disconnect a plug from a 115 V AC power socket. Never use a damaged connection cable. The 115 V AC power socket must never be connected to another 115 V AC power source. Do not use a converter with an earthed plug for the 115 V AC power socket. This could cause serious injury to you and/or other people.

↑ WARNING

If the 115V AC socket is damaged or torn out of the trim, do not use or touch the 115V AC socket. Using a 115V AC socket that is damaged or torn out of the trim could cause serious personal injury to you and/or others.



115 V socket (1) provides an alternating voltage of 115 V, so that small electronic devices can be connected. These devices,



such as games consoles, chargers and laptops, together should not consume more than a maximum of 150 W.

Requirements for operation of these devices:

- the plug of the electronic device must be inserted fully into 115 V power socket (1).
- the maximum wattage of the device to be connected must not exceed 150 W.
- the on-board power supply is within a permissible volt range.
- the 12 V socket in the trunk is operational (> page 441).
- ► Open flap ③.
- ► Insert the plug of the electronic device into 115 V power socket ①.
 Indicator lamp ② lights up.
 If indicator lamp ② does not light up, consult the section on malfunctions.
- ► To turn off: disconnect the plug from 115 V power socket ①.

Ensure that you do not pull on the cord.

► Close flap ③.

Possible causes of malfunction:

- the on-board power supply is not within a permissible volt range.
- the temperature of the DC/AC converter is temporarily too high.
- some small electronic devices have a constant nominal power of less than 150 W, but a very high inrush current.
 These devices will not work. If you connect such a device, 115 V power socket ① will not supply it with power.

If indicator lamp ② still does not light up, contact a specialist workshop, e.g. an authorized Mercedes-Benz Center.

mbrace

Important safety notes

A license agreement must exist in order to activate the mbrace service. Ensure that your system is activated and ready for use, and press the •• MB Info call button to register. If any of the steps mentioned is not carried out, the system may not be activated.

If you have questions about the activation, contact one of the following telephone assistance services:

- USA: Mercedes-Benz Customer Assistance Center under 1-888-990-9007
- Canada: Customer Service at 1-888-923-8367

Shortly after successfully registering with the mbrace service, a user ID and password will be sent to you by post. You can use this password to log in to the mbrace section under "Owners Online" at http://www.mbusa.com²³.

The mbrace system is available if:

- it has been activated and is operational.
- the corresponding mobile phone network is available for transmitting data to the Customer Center.
- a service subscription is available.
- the starter battery is sufficiently charged.
- ① Determining the location of the vehicle on a map is only possible if there is sufficient GPS reception and the vehicle position can be forwarded to the Customer Center.

The mbrace system

The mbrace system provides different services, e.g.:

- automatic and manual emergency call
- Roadside Assistance call
- MB Info call



To adjust the volume during an mbrace call, proceed as follows:

▶ Press the + or - button on the multifunction steering wheel.

or

► Use the volume controller of COMAND (> page 119).

You can find further information and a description of all available features under "Owners Online" at http://www.mbusa.com²⁴.

System self-test

After you have switched on the ignition, the system carries out a self-diagnosis.

↑ WARNING

A malfunction in the system has been detected if one of the following conditions occurs:

- the indicator lamp in the SOS button does not light up during the system selfdiagnosis.
- the indicator lamp in the Roadside
 Assistance button does not light up during
 the system self-diagnosis.
- The indicator lamp in the information button does not light up during self-diagnosis of the system.
- the indicator lamp in the SOS button,

 Roadside Assistance button or information button continues to be lit red after the system self-diagnosis.
- The Tele Aid Inoperative or Tele Aid Not Activated message appears in the multifunction display after the system selftest.

If a malfunction is indicated as outlined above, the system may not operate as expected. In the event of an emergency, assistance must be summoned by other means. Have the system checked at the nearest authorized Mercedes-Benz Center or contact the following service hotlines:

- USA: Response Center under 888-990-9007
- Canada: Customer Service at 1-888-923-8367

Emergency call

Important safety notes

A license agreement must exist in order to activate the mbrace service. Ensure that your system is activated and ready for use, and press the •• MB Info call button to register. If any of the steps mentioned is not carried out, the system may not be activated.

If you have questions about the activation, contact one of the following telephone assistance services:

- USA: Mercedes-Benz Customer Assistance Center under 1-888-990-9007
- Canada: Customer Service at 1-888-923-8367

An emergency call is dialed automatically if an air bag or Emergency Tensioning Device is triggered.

1 An mbrace emergency call that has been initiated automatically cannot be terminated by the customer.

An emergency call can also be initiated manually.

As soon as the emergency call has been initiated, the indicator lamp in the SOS button flashes. The Connecting Call message appears on the multifunction display.

The COMAND display shows the Emergency Call Activated message. The audio output is muted.



Once a connection has been established, the Call Connected message appears in the multifunction display.

The COMAND display shows the **Emergency** Call Activated message.

All important information on the emergency is transmitted, for example:

- · current location of the vehicle (as determined by the GPS system)
- vehicle identification number
- information on the type of emergency
- 1 If the Emergency Call Activated message appears in the COMAND display, you cannot use other COMAND functions.

Shortly after the emergency call has been initiated, a voice connection is automatically established between the Mercedes-Benz Customer Assistance Center and the vehicle occupants. If the vehicle occupants respond, the Mercedes-Benz Customer Assistance Center attempts to get more information on the emergency.

f no vehicle occupant answers, an ambulance is immediately sent to the vehicle.

↑ WARNING


If the indicator lamp in the SOS button is flashing continuously and no voice connection to the Mercedes-Benz Customer Assistance Center was established, then the mbrace system could not initiate an emergency call (e.g. the relevant cellular phone network is not available).

The message Call Failed appears in the multifunction display for approximately 10 seconds.

Should this occur, assistance must be summoned by other means.

1 During an emergency call, the Bluetooth® connection on the phone is canceled automatically. After making the emergency call, the connection is automatically re-established.

Making an emergency call



- ▶ To initiate an emergency call manually: press cover (1) briefly to open it.
- ▶ Press SOS button ② briefly. The indicator lamp in SOS button (2) flashes until the emergency call is concluded.
- ▶ Wait for a voice connection to the Mercedes-Benz Customer Assistance Center.
- ► After the emergency call is ended, close cover (1).



↑ WARNING

If you feel in any way in jeopardy when in the vehicle (e.g. smoke or fire in the vehicle, vehicle in a dangerous road location), please do not wait for voice contact after you have pressed the SOS button. Carefully leave the vehicle and move to a safe location. The Mercedes-Benz Customer Assistance Center will automatically contact local emergency officials with the vehicle's approximate location if they receive an automatic SOS signal and cannot make voice contact with the vehicle occupants.

Roadside Assistance button

▶ Open the stowage compartment under the armrest (⊳ page 433).





▶ Press and hold Roadside Assistance button ① for more than two seconds.

This initiates a call to the Mercedes-Benz Customer Assistance Center. The indicator lamp in Roadside Assistance button ① flashes while the call is active. The Connecting Call message appears in the multifunction display and the COMAND display. The audio output is muted.

If a connection can be established, the Call Connected message appears in the multifunction display and in the COMAND display.

If a cellular phone network is available and there is sufficient GPS reception, the mbrace system transmits data to the Mercedes-Benz Customer Assistance Center, for example:

- current location of the vehicle
- vehicle identification number
- The multifunction display and COMAND display show that an mbrace call is active. You can change to the navigation menu by pressing the button during the call, for example.

Voice output is not available.

A voice connection is established between the Mercedes-Benz Customer Assistance Center and the vehicle occupants.

▶ Describe the type of assistance needed.

The Mercedes-Benz Customer Assistance Center either sends a qualified Mercedes-Benz technician or organizes for your vehicle to be transported to the nearest authorized Mercedes-Benz Center. You may be charged for services such as repair work and/or towing. Further details are available in your mbrace manual.

- 1 The mbrace system failed to initiate a Roadside Assistance call if:
 - the indicator lamp in Roadside Assistance button (1) is flashing continuously.
 - no voice connection to the Mercedes-Benz Customer Assistance Center was established.

This may be because the corresponding mobile phone network is not available.

The Call Failed message appears in the multifunction display.

The COMAND display shows the Call could not be connected! message. Press (*) to confirm the message.

▶ To end a call: press the button on the multifunction steering wheel.

or

Press the corresponding button for ending a phone call on the COMAND telephone keypad.

MB Info call button

▶ Open the stowage compartment under the armrest (> page 433).



▶ Press and hold MB Info call button ① for more than two seconds.

This initiates a call to the Mercedes-Benz Customer Assistance Center. The indicator lamp in MB Info call button ① flashes while



the connection is being established. The Connecting Call message appears in the multifunction display. The COMAND display shows the Information Call Activated message. The audio output is muted.

If a connection can be established, the Call Connected message appears in the multifunction display.

The COMAND display shows the Information Call Activated message.

If a cellular phone network is available and there is sufficient GPS reception, the mbrace system transmits data to the Mercedes-Benz Customer Assistance Center, for example:

- · current location of the vehicle
- vehicle identification number
- 1 The COMAND display shows that an mbrace call is active. You can change to the navigation menu by pressing the TEL NAVI button during the call, for example.

Voice output is not available.

A voice connection is established between the Mercedes-Benz Customer Assistance Center and the vehicle occupants. You can obtain information on how to operate your vehicle's systems, on the location of the nearest authorized Mercedes-Benz Center, and on further products and services offered by Mercedes-Benz USA.

Further details on the mbrace system can be found under **http://www.mbusa.com**²⁵. Log in under "Owners Online".

- 1 The mbrace system failed to initiate an MB Info call if:
 - the indicator lamp in MB Info call button ① is flashing continuously.
 - no voice connection to the Mercedes-Benz Customer Assistance Center was established.

This may be because the corresponding mobile phone network is not available.

The Call Failed message appears in the multifunction display.

The COMAND display shows the Call could not be connected! message. Press ® to confirm the message.

► To end a call: press the button on the multifunction steering wheel.

or

Press the corresponding button for ending a phone call on the COMAND telephone keypad.

Call priority

When service calls are active, e.g. Roadside Assistance or MB Info calls, an emergency call can still be initiated. In this case, an emergency call will take priority and override all other active calls.

The indicator lamp of the respective button flashes until the call is ended. An emergency call can only be terminated by the Mercedes-Benz Customer Assistance Center. All other calls can be ended by pressing the button on the multifunction steering wheel or the corresponding button for ending a telephone call on the COMAND telephone keypad.

Downloading destinations in COMAND

- The components and operating principles of COMAND can be found on (▷ page 118).
- 1 You can only use the Destination Download function if the vehicle is equipped with a navigation system.

Destination Download gives you access to a database with over 15 million points of interest (POIs)/important destinations that can be downloaded onto the navigation system of your vehicle. If you know the destination, you can download the address or obtain the location of points of interest



(POIs)/important destinations in the surrounding area.

You are prompted to confirm route guidance to the address entered.

Slide ←◎→ and turn 【◎】 the COMAND controller to select Yes and confirm by pressing ⑤.

The system calculates the route and subsequently starts the route guidance with the address entered.

- 1 If you select No, the address can be stored in the address book.
- 1 The Destination Download function is available if the corresponding mobile phone network is available and data transfer is possible.

Route Assistance

This service is part of the mbrace PLUS Package and cannot be purchased separately.

1 You can also use the Route Assistance function if your vehicle is not equipped with a navigation system.

Within the framework of this service, you receive a professional and reliable form of navigation support without having to leave your vehicle.

The customer service representative determines a suitable driving route based on your current vehicle position and the desired destination and guides you live through the current sections of the route.

Search & Send

Points to observe before use

1 To use Search & Send, your vehicle must be equipped with mbrace and a navigation system. You must also have an mbrace service subscription.

"Search & Send" is a destination entry service. A destination which is determined by Google Maps® or Yahoo Local Maps® can be forwarded directly to your vehicle's navigation system using TELEAID.

Specifying and sending the destination address

- Information about specific commands such as address entry or sending an address can be found on (either of) the website(s). Each website works differently and is subject to change.
- ➤ Go to either http:// www.maps.google.com or http:// www.maps.yahoo.com and enter a destination address in the entry field.
- Press the relevant button on the website to send the destination address to the e-mail address of your mbrace account.
- ► When the "Send" dialog window appears: In the relevant field, enter the e-mail address which you specified when activating your mbrace account.
- ► Click on "Send".

Calling up destination addresses

- Press the MB Info call button to load the destination address to your vehicle's navigation system.
 - A display message appears, asking whether navigation should be started.
- ► Slide ← → and turn 【 】 the COMAND controller to select Yes and confirm by pressing ⑤.

The system calculates the route and subsequently starts the route guidance with the address entered.

- 1 If you select No, the address can be stored in the address book.
- 1 If you have sent more than one destination address, you have to make an info call to load each individual address.
- Destination addresses are loaded in the same order as the order in which they were sent. If you own multiple Mercedes-Benz vehicles with mbrace and activated mbrace accounts:



Each destination address sent can be accessed by every vehicle which is connected with the relevant e-mail address.

Vehicle remote opening

If you have unintentionally locked your vehicle (e.g. the SmartKey is still in the vehicle) and a replacement SmartKey is not available, the vehicle can be opened by a Mercedes-Benz Customer Assistance Center.

The vehicle can be opened remotely up to four days after the ignition was last switched off.

- ► Contact the following service hotlines:
 - USA: Mercedes-Benz Customer Assistance Center under 1-800-FOR-MERCedes(1-800-367-6372) or 1-888-990-9007
 - Canada: Customer Service at 1-888-923-8367

You will be asked for your password.

- Return to your vehicle at the time agreed upon with the Mercedes-Benz Customer Assistance Center.
- ► Pull the trunk lid handle for at least 20 seconds until the indicator lamp in the SOS button (> page 444) flashes.

 The Connecting Call message appears on the multifunction display.

Alternatively, the vehicle can also be opened via the Internet or an iPhone in the "Owners Online" section using your ID number and password²⁶.

Vehicle remote unlocking is only possible if the corresponding mobile phone network is accessible.

The SOS button flashes and the Connecting Call message appears in the multifunction display to confirm that the command for vehicle remote unlocking has been received.

If you pull the trunk handle for more than 20 seconds before receiving authorization

for remote unlocking, you must wait 15 minutes before you can pull the trunk lid handle again.

Vehicle remote closing

If you forget to lock your vehicle but are no longer in the vicinity of the vehicle, it can be locked for you by the Mercedes-Benz Customer Assistance Center.

The vehicle can be locked remotely up to four days after the ignition was last switched off.

- ► Contact the following service hotlines:
 - USA: Mercedes-Benz Customer Assistance Center under 1-800-FOR-MERCedes(1-800-367-6372) or 1-888-990-9007
 - Canada: Customer Service at 1-888-923-8367

You will be asked for your PIN.

The next time you are in your vehicle and switch on the ignition, the Tele Aid Doors Locked Remotely message appears in the multifunction display.

Alternatively, the vehicle can also be locked via the Internet or an iPhone in the "Owners Online" section using your ID number and password.

1 The vehicle valet locking feature is available when the relevant mobile phone network is available and data connection is possible.

Automatic vehicle data retrieval for the service due date

Your vehicle comes with a function which improves the servicing of the vehicle considerably. Shortly before the service due date, mbrace sends important vehicle maintenance information to the Mercedes-Benz Customer Assistance Center. The Mercedes-Benz Customer Assistance Center then informs your authorized Mercedes-Benz Service Center of the work required. This



happens automatically and does not require any action from the driver. This function allows the Mercedes-Benz Center to improve appointment planning significantly and ensures that your vehicle receives the best service possible.

 The "Automatic retrieval of vehicle data for the service due date" function is only available if the relevant mobile phone network is available and a data connection is possible.

Service for recovering a stolen vehicle

If your vehicle has been stolen:

- ▶ Notify the police. The police will issue a numbered incident report.
- ▶ This number will be forwarded to the Mercedes-Benz Customer Assistance Center together with your PIN. The Mercedes-Benz Customer Assistance Center then attempts to locate the mbrace system. The Mercedes-Benz Customer Assistance Center contacts you and the local law enforcement agency if the vehicle is located. However, only the law enforcement agency is informed of the location of the vehicle.
- 1 If the anti-theft alarm system is active for longer than 30 seconds, mbrace automatically informs the Mercedes-Benz Customer Assistance Center.

Garage door opener

Important safety notes

The HomeLink® garage door opener integrated in the rear-view mirror allows you to operate up to three different door and gate systems.

- Certain garage door drives are incompatible with the integrated garage door opener. If you have difficulty programming the integrated garage door opener, contact an authorized Mercedes-Benz Center or call one of the following telephone hotlines:
 - USA: Mercedes-Benz Customer Assistance Center at 1-800-FOR-MERCedes
 - Canada: Customer Service at 1-800-387-0100

↑ WARNING

Before programming the integrated remote control to a garage door opener or gate operator, make sure people and objects are out of the way of the device to prevent potential harm or damage. When programming a garage door opener, the door moves up or down. When programming a gate operator, the gate opens or closes.

Do not use the integrated remote control with any garage door opener that lacks safety stop and reverse features as required by U.S. federal safety standards (this includes any garage door opener model manufactured before April 1, 1982). A garage door that cannot detect an object - signaling the door to stop and reverse - does not meet current U.S. federal safety standards.

When programming a garage door opener, park vehicle outside the garage.

Do not run the engine while programming the integrated remote control. Inhalation of exhaust gas is hazardous to your health. All exhaust gas contains carbon monoxide (CO), and inhaling it can cause unconsciousness and possible death. All exhaust gas contains carbon monoxide (CO), and inhaling it can cause unconsciousness and possible death.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:



- 1. This device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

FCC ID: CB2HMIHL4

1 Canada only:

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

- 1. This device may not cause interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation of the device.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

IC: 279B-HMIHI 4

Programming the integrated garage door opener on the rear-view mirror

Programming



↑ WARNING

Only press the transmitter button on the integrated garage door opener if there are no persons or objects present within the sweep of the garage door. People could otherwise be injured by the movement of the door.



Integrated garage door opener on the rear-view mirror

Garage door remote control (5) is not part of this integrated garage door opener.

- 1 To achieve the best result, insert new batteries in garage door remote control (5) before programming.
- ▶ Before programming for the first time, clear the memory of the integrated garage door opener (⊳ page 453).
- ► Turn the SmartKey to position 2 in the ignition lock.
- ▶ Press and hold one of transmitter buttons (2) to (4) on the integrated garage door opener. Indicator lamp (1) starts to flash yellow after a short period.
- 1 Indicator lamp (1) flashes yellow immediately after the transmitter button has been stored for the first time. If the transmitter button has already been programmed, indicator lamp (1) does not flash yellow until 10 seconds have elapsed.
- ▶ Release the transmitter button.
- ▶ Point transmitter button (6) of garage door remote control (5) towards the transmitter buttons on the rear-view mirror at a distance of 2 to 8 inches (5 to 20 cm).
- 1 The distance required between garage door remote control (5) and the integrated garage door opener depends on the system of the garage door drive. You might require several attempts. You should test every



position for at least 25 seconds before trying another position.

- ► Press and hold transmitter button ⑥ on garage door remote control ⑤ until indicator lamp ① lights up green.

 Programming is complete if indicator lamp ① lights up or flashes green.
- ▶ Release transmitter button ②, ③ or ④ on the integrated garage door opener and the transmitter button on garage door remote control ⑥.

If indicator lamp 1 lights up red:

- Repeat the programming procedure for the transmitter button. When doing so, vary the distance between the garage door remote control and the rear-view mirror.
- If the indicator lamp flashes green after successful programming, the garage door system is operating on a rolling code. After programming, you must synchronize the garage door opener integrated in the rearview mirror with the receiver of the garage door system.

Synchronizing the rolling code

Your vehicle must be within range of the garage or gate opener drive. Make sure that neither your vehicle nor any persons/objects are present within the sweep of the door or gate.

Observe the safety notes when performing the rolling code synchronization.

- ► Turn the SmartKey to position 2 in the ignition lock.
- ► Press the programming button of the door or gate drive (see the door or gate drive operating instructions, e.g. under "Programming of additional remote controls").
- 1 You now normally have 30 seconds to initiate the next step.
- ▶ Press the previously programmed transmitter button of the HomeLink[®]

integrated garage door opener repeatedly in succession until the door opens. The rolling code synchronization is then complete.

Notes on programming the remote control

Canadian radio frequency laws require a "break" (or interruption) of the transmission signals after broadcasting for a few seconds. These signals may not therefore last long enough for the integrated garage door opener to recognize the signal during programming. Comparable with Canadian law, some U.S. garage door openers also have a built-in "interruption".

If you live in Canada or have difficulties programming the garage door opener (regardless of where you live) when using the programming steps (see above), proceed as follows:

- ▶ Press and hold one of transmitter buttons ② to ④ of the integrated garage door opener. Indicator lamp ① starts to flash yellow after a short period.
- ► Release the transmitter button.
- ▶ Press transmitter button ⑥ of the garage door remote control and hold for two seconds, then release for two seconds, then press again and hold for two seconds.
- ▶ Repeat this sequence on transmitter button ⑥ of the garage door remote control until indicator lamp ① is green. Repeat the process if indicator lamp ① turns red.
- Continue with the other programming steps (see above).

Problems when programming

If you are experiencing problems programming the integrated garage door opener on the rear-view mirror, take note of the following instructions:

 check the transmission frequency of garage door remote control (5) (usually



found on the reverse side of the remote control).

The integrated garage door opener is compatible with devices that can be operated with units in a frequency range of 280 to 390 MHz.

- change the batteries in garage door remote control (5). This increases the probability that garage door remote control (5) will send a strong and precise signal to the integrated garage door opener on the rearview mirror.
- · when programming, hold garage door remote control (5) at different distances and angles from the transmitter button that you are programming. Try different angles at a distance between 2 and 12 inches (5 to 30 cm) or the same angle at varying distances.
- if another remote control for the same garage door drive is available, repeat the same programming steps with this remote control. Before you perform the steps of the operation, make sure that there are new batteries in the garage door remote control.
- note that some remote controls only transmit for a limited amount of time (the indicator lamp on the remote control goes out). Press the remote control button again before it stops transmitting.
- align the antenna cable of the garage door opener unit. This can improve signal reception/transmission.

Opening/closing the garage door

Once programmed, the integrated garage door opener will assume the function of the garage door system's remote control. Please also read the operating instructions for the garage door system.

- ► Turn the SmartKey to position 2 in the ignition lock.
- ▶ Press transmitter button (2), (3) or (4) in the overhead control panel that you have programmed to operate the garage door. Garage door system with a fixed code: indicator lamp (1) lights up green. Garage door system with a rolling code: indicator lamp (1) flashes green.
- 1 The transmitter will transmit a signal for as long as the transmitter button is being pressed. After a maximum of ten seconds, transmission is terminated and indicator lamp (1) flashes yellow. Press the transmitter button again, if necessary.

Clearing the memory of the integrated garage door opener on the rear-view mirror

- ► Turn the SmartKey to position 2 in the ignition lock.
- ▶ Press transmitter buttons ② and ④. The indicator lamp lights up yellow.
- ▶ Press and hold transmitter buttons (2) and (4) until the indicator lamp turns green.
- Make sure that you clear the memory of the integrated garage door opener before selling the vehicle.

Floormat on the driver's side



♠ WARNING


Whenever you are using a floormat, make sure there is enough clearance and that the floormat is securely fastened.

The floormat should always be securely fastened using the fastening equipment. Before driving off, check that the floormat is

securely in place and adjust it if necessary. A loose floormat could slip and hinder proper functioning of the pedals.

Do not place several floormats on top of each other as this may impair pedal movement.






- ▶ Slide the seat backwards.
- ➤ To install: place the floormat in the footwell.
- ▶ Press studs ① onto retainers ②.
- ► To remove: pull the floormat off retainers ②.
- ▶ Remove the floormat.


Infrared reflective windshield

The infrared reflecting glass prevents the vehicle interior from becoming too hot. It also blocks radio waves up into the gigahertz range.



Vehicles without Night View Assist Plus

- ① Areas permeable to radio waves (to the left and right of the rain sensor cover)
- (2) Rain sensor cover
- (3) Areas permeable to radio waves



Vehicles with Night View Assist Plus

- Area permeable to radio waves (to the left of the rain sensor cover)
- ② Rain sensor cover
- 3 Areas permeable to radio waves

In order to operate radio-controlled equipment, e.g. toll recording systems, areas ① or ③ on the windshield are permeable to radio waves. In these areas, you can install radio-controlled systems.

These areas can best be seen from outside the vehicle by observing the light reflected off the windshield.



Useful information	456
Engine compartment	456
Maintenance	462
Care	463

Useful information

- 1 This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- 1 Please read the information on qualified specialist workshops (⊳ page 31).

Engine compartment

Hood

Opening the hood



♠ WARNING

Do not pull the release lever while the vehicle is in motion. Otherwise, the hood could be forced open by passing air flow.

This could cause the hood to come loose and injure you and/or others.



↑ WARNING

Hybrid vehicles: be sure to read the "HYBRID" supplement. Otherwise, you could fail to recognize dangers.



↑ WARNING

Do not open the hood when the engine is overheated. You could be seriously injured. Observe the coolant temperature gauge to determine whether the engine may be overheated. If you see flames or smoke coming from the engine compartment, move away from the vehicle. Wait until the engine has cooled. If necessary, call the fire department.



There is a risk of injury if the hood is open, even if the engine is not running.

Some engine components can become very

To avoid the risk of burns, only touch those components described in the Operator's Manual and observe the relevant safety notes.



↑ WARNING

To help prevent personal injury, stay clear of moving parts when the hood is open and the engine is running.

The radiator fan may continue to run for approximately 30 seconds or may even restart after the engine has been turned off. Stay clear of fan blades.



MARNING

Vehicles with gasoline engine:

The engine is equipped with a transistorized ignition system. Because of the high voltage it is dangerous to touch any components (ignition coils, spark plug sockets, diagnostic socket) of the ignition system

- · with the engine running
- · while starting the engine
- · when the ignition is switched on and the engine is turned manually



↑ WARNING

Vehicles with diesel engine:

The engine is equipped with a high-voltage electronic control unit for the injection system. Because of the high voltage it is dangerous to touch any components of the injection system (injectors, electrical wires)

- · with the engine running
- · while starting the engine
- · when the ignition is switched on
- ▶ Make sure that the windshield wipers are switched off.



MARNING

The windshield wipers and wiper linkage could be set in motion.



When the hood is open, you or others could be injured by the wiper linkage.

Make sure that the windshield wipers are switched off. Remove the SmartKey or make sure that no ignition position has been selected with KFYLESS-GO, All indicator lamps must be off in the instrument cluster.



- ▶ Pull release lever (1) for the hood. The hood is released.
- Make sure that the windshield wipers are not folded away from the windshield. You could otherwise damage the windshield wipers or the hood.



▶ Pull hood catch handle ② outwards from the radiator grill as far as it will go and lift the hood from underneath by the radiator grill.

Once you have lifted the hood about 15 inches (40 cm), it is automatically opened the rest of the way and held open by the gas-filled struts.

Do not lift the hood by hood catch handle (2). The handle may otherwise be damaged.

Closing the hood

↑ WARNING

When closing the hood, use extreme caution not to catch hands or fingers. Be careful that you do not close the hood on anyone.

Make sure the hood is securely engaged before driving off. Do not continue driving if the hood can no longer engage after an accident, for example. The hood could otherwise come loose while the vehicle is in motion and injure you and/or others.

- Lower the hood and let it fall from a height of approximately 8 inches (20 cm).
- ► Check that the hood has engaged properly. If the hood can be raised slightly, it is not properly engaged. Open it again and close it with a little more force.

Radiator

1 Vehicles with a diesel engine: do not cover the radiator, for example with a winter front or bug cover. Otherwise, the readings of the on-board-diagnostic system may be inaccurate. Some of these readings are required by law and must be accurate at all times.

Engine oil

Notes on the oil level



↑ WARNING

Hybrid vehicles: ensure that you read the "HYBRID" supplement. You may otherwise fail to recognize dangers.


Depending on the driving style, the vehicle consumes up to 0.9 US gts. (0.8 I) of oil over a distance of 600 miles (1000 km). The oil




consumption may be higher than this when the vehicle is new or if you frequently drive at high engine speeds.

Checking the oil level using the oil dipstick

On vehicles with a 12-cylinder engine, the oil level can be checked using the on-board computer. On all other models, the dipstick must be used to check the engine oil level.



Example: vehicles with a gasoline engine



Example: vehicles with 4MATIC

- ▶ Park the vehicle on a level surface. To check the oil level with the engine at operating temperature, switch the engine off and wait for approximately five minutes.
- ▶ Pull oil dipstick ① out of the dipstick guide tube.
- ▶ Wipe off oil dipstick ①.

- ► Slowly slide oil dipstick ① into the guide tube to the stop, and take it out again. If the level is between MIN mark ③ and MAX mark ②, the oil level is correct.
- ► If the fuel level has sunk to MIN mark ③ or below, add 0.55 to 1.1 US qt (0.5 to 1.0 l) engine oil.

Checking the oil level using the onboard computer

On vehicles with a 12-cylinder engine, the oil level can be checked using the on-board computer. On all other models, the dipstick must be used to check the engine oil level.

- ▶ Park the vehicle on a level surface. To check the oil level with the engine at normal operating temperature, switch the engine off and wait for approximately five minutes.
- Make sure that the SmartKey is in position2 in the ignition lock.
- ► Press the or button to select the Service menu.
- ► Press the ▼ or ▲ button to select Engine Oil Level.
- ► Press the OK button.

The multifunction display shows the following message: Engine Oil Level Measuring Now Measurement correct only if vehicle level.

The measurement takes a few seconds. You will see one of the following messages in the multifunction display:

- Engine Oil Level OK
- Add 1.0 l Engine Oil At Next Refueling
- Add 1.5 1 Engine Oil At Next Refueling
- Add 2.0 1 Engine Oil At Next Refueling
- ► Add oil if necessary.

If the engine is at normal operating temperature and the Engine 0il Level



Reduce Oil Level message appears, the engine oil level is too high.

- ► Have excess oil siphoned off.
- Do not add too much oil. Adding too much oil can result in damage to the engine or the catalytic converter. Have excess oil siphoned off.

If the For Engine Oil Level Ignition Must be On message appears:

► Turn the SmartKey to position 2 in the ignition lock.

If the Need More Time to Check Engine Oil Level message appears:

► If the engine is at normal operating temperature: repeat the measurement after about five minutes.

If the engine is not at normal operating temperature (e.g. if the engine was only started briefly): repeat the measurement after about 30 minutes.

If the Engine Oil Level Not When Engine On message appears:

- ► Switch off the engine.
- ▶ If the engine is at normal operating temperature: wait about five minutes before carrying out the measurement. If the engine is not at normal operating temperature, e.g. if the engine was only started briefly: wait about 30 minutes before carrying out the measurement.
- 1 If you wish to cancel the measurement, press the <u>solution</u> button on the multifunction steering wheel.

Adding engine oil

↑ WARNING

If engine oil comes into contact with hot engine parts, it may ignite and you could burn yourself. Do not spill any engine oil on hot engine parts.

When adding oil, take care not to spill any. If oil enters the soil or waterways, it is harmful to the environment.

Use only engine oils and oil filters that have been approved for vehicles equipped with a service system. A list of the engine oils and oil filters tested and approved in accordance with the Mercedes-Benz Specifications for Service Products can be called up by visiting http://www.mbusa.com (USA only). More information about tested and approved

Damage to the engine or exhaust system is caused by the following:

engine oils and oil filters is available from any authorized Mercedes-Benz Center.

- using engine oils and oil filters which have not been specifically approved for the service system.
- replacing the engine oil or oil filter after the replacement interval required by the service system has elapsed
- · using engine oil additives.
- Do not add too much oil. If the oil level is above the "max" mark on the dipstick, too much oil has been added. This can lead to damage to the engine or the catalytic converter. Have excess oil siphoned off.



Example: engine oil cap



- ► Turn cap ① counterclockwise and remove it.
- ► Add engine oil.

Vehicles with oil level measurement function in the on-board computer: observe the information in the on-board computer when doing so. Vehicles with oil dipstick: if the oil level is at or below the MIN mark on the oil dipstick,

add 0.55 to 1.1 US qt (0.5 to 1.0 l) engine oil.

- ► Replace cap ① on the filler neck and turn clockwise.
 - Ensure that the cap locks into place securely.
- ► Check the oil level again with the oil dipstick (▷ page 458) or the on-board computer (▷ page 458).

Further information on engine oil (▷ page 527).

Checking and adding other service products

Checking the coolant level

Only check the coolant level when the vehicle is on a level surface and the engine has cooled down.

- ► Turn the SmartKey to position
 2 (▷ page 303) in the ignition lock.
 On vehicles with KEYLESS-GO, press the Start/Stop button twice (▷ page 303).
- ► Check the coolant temperature display in the instrument cluster. The coolant temperature must be below


158 °F (70 °C).

↑ WARNING

In order to avoid any potentially serious burns:

 use extreme caution when opening the hood if there are any signs of steam or coolant leaking from the cooling system, or

- if the coolant temperature display indicates that the coolant is overheated.
- do not remove the pressure cap on the coolant reservoir if the coolant temperature is above 158 °F (70 °C). Allow the engine to cool down before removing the cap. The coolant reservoir contains hot fluid and is under pressure.
- using a rag, slowly turn the cap approximately ¹/₂ turn to relieve excess pressure. If opened immediately, scalding hot fluid and steam will be blown out under pressure.
- do not spill antifreeze on hot engine parts.
 Antifreeze contains ethylene glycol which may burn if it comes into contact with hot engine parts.



- Slowly turn cap ① half a turn counterclockwise and allow excess pressure to escape.
- ► Turn cap ① further counter-clockwise and remove it.
 - If the coolant is at the level of marker bar (3) in the filler neck when cold, there is enough coolant in coolant expansion tank (2).

If the coolant is approximately 0.6 in (1.5 cm) above marker bar ③ in the filler neck when warm, there is enough coolant in coolant expansion tank ②.



- ▶ If necessary, add coolant that has been tested and approved by Mercedes-Benz.
- Replace cap ① and turn it clockwise as far as it will go.

For further information on coolant, see (> page 529).

Windshield washer system and headlamp cleaning system


The washer fluid reservoir is used for both the windshield washer system and the headlamp cleaning system.

• Vehicle components and their service products must match. You should, therefore, only use products that have been tested and approved by Mercedes-Benz. Information on tested and approved products can be obtained at any authorized Mercedes-Benz Center or on the Internet at http://www.mbusa.com (USA only).

↑ WARNING

Washer solvent/antifreeze is highly flammable. Do not spill washer solvent/antifreeze on hot engine parts, because it may ignite and burn. You could be seriously burned.

- At temperatures below freezing: always fill the washer fluid reservoir with a mix of water and windshield washer concentrate (e.g. MB WinterFit). There is otherwise a risk of damaging the windshield washer system/headlamp cleaning system.
- I Only use washer fluid concentrate which is suitable for plastic lenses. Unsuitable washer fluid concentrate could damage the plastic lenses of the headlamps.
- Do not add distilled or de-ionized water to the washer fluid container. Otherwise, the level sensor may be damaged.
- Add windshield washer concentrate, e.g. MB SummerFit, to the washer fluid all year round.



Example: washer fluid reservoir

- Mix the windshield washer fluid in a container beforehand.
- ► At temperatures above freezing: fill the washer fluid reservoir with a mix of water and windshield washer concentrate (e.g. MB SummerFit).
- ▶ At temperatures below freezing: fill the washer fluid reservoir with a mix of water and windshield washer concentrate (e.g. MB WinterFit). Adapt the mixing ratio to the outside temperature. For information on the mixing ratio (> page 529).
- ▶ To open: pull cap (1) upwards by the tab.
- ► Add the premixed washer fluid.
- ► To close: press cap ① onto the filler neck until it engages.


Brake fluid level

If you notice that the brake fluid level in the brake fluid reservoir has fallen to the MIN mark or less, check the brake system immediately for leaks. Also check the thickness of the brake linings. Contact a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center immediately.

Do not add brake fluid. This does not correct the error.

Only check the brake fluid level when the vehicle is stationary and on a level surface.





The brake fluid level is correct if it is between MIN marking ② and MAX marking ① on the brake fluid reservoir.

Maintenance

Service interval display

Service messages

Information on the type of service and service intervals (see separate Service Booklet).

You can obtain further information from an authorized Mercedes-Benz Center or at http://www.mbusa.com (USA only).

The service interval display informs you of the next service due date.

If a service due date has been exceeded, you also hear an acoustic signal.

The multifunction display shows a service message for a few seconds, e.g.

Next service A due in .. days Service A due Service A overdue by .. days

The letter indicates how much time the workshop will require to carry out the service work. The letters displayed range from A for a short service duration to H for a long service duration.

The service interval display does not take into account any periods of time during which the battery is disconnected.

Maintaining the time-dependent service schedule:

► Note down the service due date displayed in the multifunction display before disconnecting the battery.

or

- ► Subtract the battery disconnection periods from the service date shown on the display after reconnecting the battery.
- 1 The service interval display does not provide any information regarding the engine's oil level. Observe the notes on the engine oil level (▷ page 457).

Hiding a service message

► Press the ☐ or OK button on the steering wheel.

Displaying service messages

- ▶ Switch on the ignition.
- ▶ Press or on the steering wheel to select the Service menu.
- ▶ Press or to select the ASSYST PLUS submenu and press OK to confirm. The service due date appears in the multifunction display.

Please bear the following in mind

Resetting service interval display

If the qualified specialist workshop, e.g. a Mercedes-Benz Center, carried out the maintenance work, the service interval display will be reset.

Further information, on maintenance for example, can be obtained at an authorized Mercedes-Benz Center or directly from Mercedes-Benz.

If the service interval display has been reset unintentionally, have the setting corrected at a Mercedes-Benz Center.

Have service work carried out as described in the Service Booklet. This may otherwise



lead to increased wear and damage to the major assemblies or the vehicle.

Driving abroad

An extensive Mercedes-Benz Service network is also available in other countries. You can obtain further information from any authorized Mercedes-Benz Center.

Care

Notes on care

Regular care of your vehicle is a condition for retaining the quality in the long term. Use care products and cleaning agents

recommended and approved by Mercedes-Benz.

↑ WARNING

Many cleaning products can be hazardous. Some are poisonous, others are flammable. Always follow the instructions on the particular container. Always open your vehicle's doors or windows when cleaning the inside.

Never use fluids or solvents that are not designed for cleaning your vehicle.

Always lock away cleaning products and keep them out of reach of children.

- I For cleaning your vehicle, do not use any of the following:
 - dry, rough or hard cloths
 - · abrasive cleaning agents
 - solvents
 - cleaning agents containing solvents Do not scrub.

Do not touch the surfaces or protective films with hard objects, e.g. a ring or ice scraper. You could otherwise scratch or damage the surfaces and protective film.

Environmental note

Dispose of empty packaging and cleaning cloths in an environmentally responsible manner.

Do not park the vehicle for an extended period straight after cleaning it, particularly after having cleaned the wheels with wheel cleaner. Wheel cleaners could cause increased corrosion of the brake discs and brake pads/linings. For this reason, you should drive for a few minutes after cleaning. Braking heats the brake discs and the brake pads/linings, thus drying them. The vehicle can then be parked.

Exterior care

Automatic car wash



↑ WARNING

Braking efficiency is reduced after washing the vehicle. This could cause an accident. For this reason, you must drive particularly carefully after washing the vehicle until the brakes have dried.



↑ WARNING

The vehicle is braked when the HOLD function or DISTRONIC PLUS is activated. Therefore. deactivate the HOLD function and DISTRONIC PLUS before the vehicle is washed in an automatic car wash.

You can wash the vehicle in an automatic car wash from the very start.

Never clean your vehicle in a Touchless Automatic Car Wash as these use special cleaning agents. These cleaning agents can damage the paintwork or plastic parts.

If the vehicle is very dirty, pre-wash it before cleaning it in an automatic car wash.

In car washes with a towing mechanism, make sure that the automatic transmission is in transmission position N, otherwise the vehicle could be damaged.



- Vehicles with a SmartKey:
 - Do not remove the SmartKey from the ignition lock. Do not open the driver's door or front-passenger door when the engine is switched off. Otherwise, the automatic transmission selects park position **P** automatically and locks the wheels. You can prevent this by shifting the automatic transmission to N beforehand
- Vehicles with KFYLESS-GO: Do not open the driver's door or frontpassenger door when the engine is switched off. Otherwise, the automatic transmission selects park position P automatically and locks the wheels.

Observe the following to make sure that the automatic transmission stays in position N:

- ▶ Make sure the vehicle is stationary and the ignition is switched off.
- ► Turn the SmartKey to position 2 (⊳ page 303) in the ignition lock. Use the SmartKey instead of the Start/ Stop button on vehicles with KEYLESS-GO.
- ▶ Depress and hold the brake pedal.
- ▶ Shift the automatic transmission to position N.
- ► Release the brake pedal.
- ► Release the electric parking brake.
- ▶ Switch off the ignition and leave the SmartKey in the ignition lock.
- Make sure that:
 - the side windows and the sliding sunroof are fully closed.
 - the ventilation/heating is switched off (the OFF button has been pressed).
 - the windshield wiper switch is in position 0.

Otherwise, the vehicle might be damaged.

After using an automatic car wash, wipe off wax from the windshield and the wiper blades. This will prevent smears and reduce wiping noises caused by residue on the windshield.

Washing by hand

Carefully remove all deposits of road salt as soon as possible when driving in winter.

Also, clean the insides of the wheels when washing the underbody of the vehicle.

- ▶ Do not use hot water and do not wash the vehicle in direct sunlight.
- ▶ Use a soft car sponge for cleaning.
- ▶ Use a gentle cleaning agent, e.g. a Mercedes-Benz approved car shampoo.
- ▶ Wash down the vehicle with a gentle water
- ▶ Do not point the water jet directly at the air inlets.
- ▶ Use plenty of water and rinse the sponge frequently.
- ▶ Rinse the vehicle with clean water and dry it thoroughly with a chamois.
- ▶ Do not allow the cleaning agent to dry on the paintwork.

Power washers

↑ WARNING

Do not use power washers with circular-jet nozzles (dirt grinders) to clean your vehicle, in particular the tires. You could otherwise damage the tires and cause an accident.

Always maintain a distance of at least 11.8 in (30 cm) between the vehicle and the power washer nozzle. Information about the correct distance is available from the equipment manufacturer.

Move the power washer nozzle around when cleaning your vehicle.

Do not aim directly at any of the following:

- tires
- door gaps, roof gaps, joints etc.
- · electrical components
- batterv
- · connectors
- lights
- seals



- trim elements
- ventilation slots

Damaged seals or electrical components can lead to leaks or failures.

Cleaning the wheels

- Do not use acidic wheel cleaning products to remove brake dust. This could damage wheel bolts and brake components.
- Do not park the vehicle for an extended period straight after cleaning it, particularly after having cleaned the wheels with wheel cleaner. Wheel cleaners could cause increased corrosion of the brake discs and brake pads/linings. For this reason, you should drive for a few minutes after cleaning. Braking heats the brake discs and the brake pads/linings, thus drying them. The vehicle can then be parked.

Cleaning the paintwork

Scratches, corrosive deposits, areas affected by corrosion and damage caused by inadequate care cannot always be completely repaired. In such cases, visit a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.

- ► Remove impurities immediately, where possible, whilst avoiding rubbing too hard.
- Soak insect remains with insect remover and rinse off the treated areas afterwards.
- ► Soak bird droppings with water and rinse off the treated areas afterwards.
- ► Remove coolant, brake fluid, tree resin, oils, fuels and greases by rubbing gently with a cloth soaked in petroleum ether or lighter fluid.
- ▶ Use tar remover to remove tar stains.
- ▶ Use silicone remover to remove wax.
- ! Do not affix:
 - stickers
 - films
 - magnetic plates or similar items

to painted surfaces. You could otherwise damage the paintwork.

If water no longer forms "beads" on the paint surface, use the paint care products recommended and approved by Mercedes-Benz. This is the case approximately every three to five months, depending on the climate conditions and the care product used. If dirt has penetrated the paint surface or the paint has become dull, the paint cleaner recommended and approved by Mercedes-Benz should be used.

Do not use these care products in the sun or on the hood while the hood is hot.

Use a suitable touch-up stick, e.g. MB Touch-Up Stick, to correct smaller areas of paint damage quickly and provisionally.

Matte finish care

If your vehicle has a clear matte finish, observe the following instructions in order to avoid damage to the paintwork due to incorrect care.

These notes also apply to light alloy wheels with a clear matte finish.

- Never polish the vehicle or the light alloy wheels. Polishing causes the finish to shine.
- The following may cause the paint to become shiny and thus reduce the matte effect:
 - Vigorous rubbing with unsuitable materials.
 - Frequent use of car washes.
 - Washing the vehicle in direct sunlight.
- Never use paint cleaner, buffing or polishing products, or gloss preserver, e.g. wax. These products are only suitable for high-gloss surfaces. Their use on vehicles with matte finish leads to considerable surface damage (shiny, spotted areas).



Always have paintwork repairs performed at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.

- Do not use wash programs with a hot wax treatment under any circumstances.
- 1 The vehicle should preferably be washed by hand using a soft sponge, car shampoo and plenty of water.
- 1 Use only insect remover and car shampoo from the range of recommended and approved Mercedes-Benz care products.

Cleaning the windows

↑ WARNING

Before cleaning the windshield or wiper blades, switch off the windshield wipers and remove the SmartKey from the ignition lock. On vehicles with KEYLESS-GO, press the Start/Stop button repeatedly until all indicator lamps in the instrument cluster have gone out. The windshield wipers could otherwise move and injure you.

- I Only fold the windshield wipers away from the windshield when vertical. Otherwise, you will damage the hood.
- ▶ Clean the inside and outside of the windows with a damp cloth and a cleaning agent that is recommended and approved by Mercedes-Benz.
- Do not use dry cloths, abrasive products, solvents or cleaning agents containing solvents to clean the inside of the windows. Do not touch the insides of the windows with hard objects, e.g. an ice scraper or ring. There is otherwise a risk of damaging the windows.
- Clean the water drainage channels of the windshield and the rear window at regular intervals. Deposits such as leaves, petals and pollen may under certain circumstances prevent water from draining away. This can lead to corrosion damage and damage to electronic components.

Cleaning the wiper blades



↑ WARNING

Before cleaning the windshield or wiper blades, switch off the windshield wipers and remove the SmartKey from the ignition lock. On vehicles with KEYLESS-GO, press the Start/Stop button repeatedly until all indicator lamps in the instrument cluster have gone out. The windshield wipers could otherwise move and injure you.

- I Only fold the windshield wipers away from the windshield when vertical. Otherwise, you will damage the hood.
- Do not pull the wiper blade. Otherwise, the wiper blade could be damaged.
- Do not clean wiper blades too often and do not rub them too hard. Otherwise, the graphite coating could be damaged. This could cause wiper noise.
- ▶ Fold the wiper arms away from the windshield.
- ► Carefully clean the wiper blades with a damp cloth.
- ► Fold the windshield wipers back again before switching on the ignition.
- Hold the wiper arm securely when folding back. The windshield could be damaged if the wiper arm smacks against it suddenly.

Cleaning the exterior lighting

- ► Clean the plastic lenses of the exterior lights with a wet sponge and a mild cleaning agent, e.g. Mercedes-Benz car shampoo or cleaning cloths.
- I Only use cleaning agents or cleaning cloths which are suitable for plastic light lenses. Unsuitable cleaning agents or cleaning cloths could scratch or damage the plastic light lenses.




Cleaning the sensors



- ► Clean sensors ① of the driving systems with water, car shampoo and a soft cloth.
- When cleaning the sensors with a power washer, maintain a distance between the vehicle and the nozzle of the power washer of at least 11.8 in (30 cm). Information about the correct distance is available from the equipment manufacturer.

Cleaning the rear view camera



- ► Use clear water and a soft cloth to clean camera lens ①.
- Do not clean the camera lens and the area around the rear view camera with a power washer.

Cleaning the exhaust tail pipes

Impurities combined with the effects of road grit and corrosive environmental factors may cause flash rust to form on the surface. You can restore the original shine of the exhaust tail pipe by cleaning it regularly, especially in winter and after washing.

- Do not clean the exhaust tail pipes with alkaline-based cleaning agents, such as wheel cleaner.
- Clean the exhaust tail pipes with a chrome care product tested and approved by Mercedes-Benz.

Interior care

P54.65-3962-31

Cleaning the display

- ▶ Before cleaning the display, make sure that it is switched off and has cooled down.
- ► Clean the display surface using a commercially-available microfiber cloth and TFT/LCD display cleaner.
- ► Dry the display surface using a dry microfiber cloth.
- For cleaning, do not use any of the following:
 - alcohol-based thinner or gasoline
 - · abrasive cleaning agents
 - commercially-available household cleaning agents

These may damage the display surface. Do not put pressure on the display surface when cleaning. This could lead to irreparable damage to the display.

Cleaning Night View Assist Plus

Never clean the camera lens. When cleaning the field of vision of the driving systems, make sure that you do not spray glass cleaner on the camera lens. If the camera lens is dirty, visit a qualified specialist workshop.



↑ WARNING

Please do not forget that your primary responsibility is to drive the vehicle. A driver's attention to the road must always be his/her primary focus when driving. For your safety and the safety of others, stop before trying to remove window fogging or cleaning the window in front of the Night View Assist Plus

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle is covering a distance of 44 feet (approximately 14 m) every second.



▶ Fold down the camera cover by recess (1).



▶ Use a soft cloth to clean the windshield in front of camera (2).

Cleaning the plastic trim



↑ WARNING

When cleaning the steering wheel boss and dashboard, do not use cockpit sprays or cleaning agents containing solvents. Cleaning agents containing solvents cause the surface to become porous, and as a result, plastic parts may break away and be thrown around the interior when an air bag is deployed, which may result in severe injuries.

- Do not affix the following to plastic surfaces:
 - stickers
 - films
 - scented oil bottles or similar items You can otherwise damage the plastic.
- Do not allow cosmetics, insect repellent or sunscreen to come into contact with the plastic trim. This maintains the high-quality look of the surfaces.
- ▶ Wipe the plastic trim with a damp, lint-free cloth, e.g. a microfiber cloth.
- ▶ Heavy soiling: use car care and cleaning products recommended and approved by Mercedes-Benz.

The surface may change color temporarily. Wait until the surface is dry again.

Cleaning the steering wheel and gear or selector lever

► Thoroughly wipe with a damp cloth or use leather care agents that have been recommended and approved by Mercedes-Benz.

Cleaning genuine wood and trim elements

- ▶ Wipe the wooden trim and trim pieces with a damp, lint-free cloth, e.g. a microfiber cloth.
- ▶ Heavy soiling: use car care and cleaning products recommended and approved by Mercedes-Benz.
- Do not use solvent-based cleaning agents such as tar remover, wheel cleaners. polishes or waxes. There is otherwise a risk of damaging the surface.



Do not use chrome polish on trim pieces. The trim pieces have a chrome look but are mostly made of anodized aluminum and can lose their shine if chrome polish is used. Use a damp, lint-free cloth instead when cleaning the trim pieces. If the chrome-plated trim pieces are very dirty, you can use a chrome polish. If you are unsure as to whether the trim pieces are chrome-plated or not, consult an authorized Mercedes-Benz Center.

Cleaning the seat covers

- Do not use microfiber cloths to clean genuine leather, artificial leather or Alcantara® covers. If used often, these can damage the cover.
- Observe the following when cleaning:
 - clean genuine leather covers carefully with a damp cloth and then wipe the covers down with a dry cloth. Make sure that the leather does not become soaked. It may otherwise become rough and cracked. Only use leather care agents that have been tested and approved by Mercedes-Benz. You can obtain these from a qualified specialist workshop, e.g. a Mercedes-Benz Service center.
 - · clean artificial leather covers with a cloth moistened with a solution containing 1% detergent (e.g. dish washing liquid).
 - clean cloth covers with a microfiber cloth moistened with a solution containing 1% detergent (e.g. dish washing liquid). Rub carefully and always wipe entire seat sections to avoid leaving visible lines. Leave the seat to dry afterwards. Cleaning results depend on the type of dirt and how long it has been there.
 - clean Alcantara® covers with a damp cloth. Make sure you wipe entire seat sections to avoid leaving visible lines.

1 Note that regular care is essential to ensure that the appearance and comfort of the covers is retained over time.

Cleaning the seat belts

- ▶ Use clean, lukewarm water and soap solution.
- Do not clean the seat belts using chemical cleaning agents. Do not dry the seat belts by warming them above 176 °F (80 °C) or placing them in direct sunlight.



↑ WARNING

Do not bleach or dye seat belts as this may severely weaken them. In a crash, they may not be able to provide adequate protection.

Cleaning the headliner and carpets

- ▶ Roof lining: use soft brushes or dry shampoo if it is particularly dirty.
- ► Carpets: use carpet and textile cleaners that have been approved and recommended by Mercedes-Benz.





Useful information	472
Where will I find?	472
Flat tire	473
Battery	478
Jump-starting	481
Towing and tow-starting	483
Fuses	485


Useful information

- 1 This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions.
- Please read the information on qualified specialist workshops (> page 31).

Where will I find ...?

First-aid kit

▶ Open the trunk lid.




- ▶ Release strap (1).
- ► Remove first-aid kit ② from the parcel net.
- 1 Check the expiration date on the first-aid kit at least once a year. Replace the contents if necessary, and replace missing contents.

Vehicle tool kit

The vehicle tool kit can be found in the stowage well under the trunk floor.

▶ Lift the trunk floor up (▷ page 436).




- 1 Folding wheel chock
- 2 Vehicle tool kit tray cover
- ③ Vehicle tool kit
- 4 Jack

"Minispare" emergency spare wheel

The "Minispare" emergency spare wheel can be found in the stowage well under the trunk floor.

▶ Lift the trunk floor up (▷ page 436).



- ► Turn stowage tray ③ counter-clockwise and remove together with vehicle tool kit tray ②.
- ► Remove "Minispare" emergency spare wheel (1).

For further information on changing a wheel and mounting the spare wheel, see (> page 473).



Flat tire

Preparing the vehicle

Your vehicle may be equipped with a "Minispare" emergency spare wheel or MOExtended tires (tires with run-flat properties) (⊳ page 477).

- 1 Vehicle preparation is not necessary on vehicles with MOExtended tires.
- ► Stop the vehicle as far away as possible from traffic on solid, non-slippery and level ground.
- ▶ Switch on the hazard warning lamps.
- ► Engage the electric parking brake manually (⊳ page 324).
- ▶ Bring the front wheels into the straightahead position.
- ▶ Move the DIRECT SELECT lever to P.
- ▶ Switch off the engine.
- ▶ Vehicles without KEYLESS-GO: remove the SmartKey from the ignition lock.
- ▶ Vehicles with KEYLESS-GO: open the driver's door.

The on-board electronics have status 0, which is the same as the SmartKey having been removed.

- ▶ Vehicles with KEYLESS-GO: remove the Start/Stop button from the ignition lock (⊳ page 303).
- ▶ All occupants must get out of the vehicle. Make sure that they are not endangered as they do so.
- ▶ Make sure that no one is near the danger area while a wheel is being changed. Anyone who is not directly assisting in the wheel change should, for example, stand behind the barrier.
- ▶ Get out of the vehicle. Pay attention to traffic conditions when doing so.
- ▶ Close the driver's door.

Changing a wheel and mounting the spare wheel

Preparing the vehicle

↑ WARNING

The wheel and tire size of the emergency spare wheel/spare wheel may differ to that of the damaged wheel. When using an emergency spare wheel/spare wheel the handling characteristics of the vehicle may change.

Adapt your style of driving accordingly.

Never operate the vehicle with more than one emergency spare wheel/spare wheel that differs in size.

Only use an emergency spare wheel/spare wheel of a differing size briefly and do not switch off ESP®.

When using an emergency spare wheel, you must not exceed the maximum speed of 50 mph (80 km/h).

↑ WARNING

Have the emergency spare wheel/spare wheel replaced with a new wheel as soon as possible at a qualified specialist workshop which has the necessary specialist knowledge and tools to carry out the work required. Mercedes-Benz recommends that you use an authorized Mercedes-Benz Center for this purpose. In particular, work relevant to safety or on safety-related systems must be carried out at a qualified specialist workshop.

1 Vehicles without a spare wheel emergency spare wheel are not equipped with a tire-change tool kit at the factory. For more information on which tools are required to perform a wheel change on your vehicle, e.g. wheel chock, lug wrench or alignment bolt, consult an authorized Mercedes-Benz Center.



- Prepare the vehicle as described (⊳ page 473).
- ▶ Remove the following items (depending on the vehicle's equipment) from the stowage well under the trunk floor:
 - the emergency spare wheel or spare wheel
 - wheel bolts for the spare wheel/ emergency spare wheel
 - the vehicle tool kit
 - the folding wheel chock
 - the jack
- ► Secure the vehicle to prevent it from rolling away.

Securing the vehicle to prevent it from rolling away

↑ WARNING

Only jack up the vehicle on level ground or on slight inclines/declines. The vehicle could otherwise fall off the jack and injure you or others.

If your vehicle is equipped with a wheel chock, it can be found in the vehicle tool kit (⊳ page 472).

The folding wheel chock is an additional securing measure to prevent the vehicle from rolling away, for example when changing a wheel.









- ► Fold both plates upwards ①.
- ▶ Fold out lower plate ②.
- ► Guide the lugs on the lower plate fully into the openings in base plate (3).



Securing the vehicle on level ground

▶ On level ground: place chocks or other suitable items under the front and rear of the wheel that is diagonally opposite the wheel you wish to change.



Securing the vehicle on slight downhill gradients

▶ On downhill gradients: place chocks or other suitable items in front of the wheels of the front and rear axle.

Raising the vehicle



♠ WARNING

When jacking up the vehicle, only use the jack which has been specifically approved by Mercedes-Benz for your vehicle.

The jack is designed exclusively for jacking up the vehicle at the jacking points built into both sides of the vehicle. The jack saddle must be



placed centrally under the jacking point. The jack must always be vertical when in use, especially on inclines or declines.

The jack is intended only for lifting the vehicle briefly for wheel changes. It is not suited for performing maintenance work under the vehicle. To help avoid personal injury, use the jack only to lift the vehicle during a wheel change.

Never get beneath the vehicle while it is supported by the jack. Keep hands and feet away from the area under the lifted vehicle. Always lower the vehicle onto sufficient capacity jackstands before working under the vehicle.


Always firmly engage the parking brake and block the wheels with wheel chocks or other sizable objects before raising the vehicle with the jack. Do not disengage the parking brake while the vehicle is raised.

Make sure that the ground on which the vehicle is standing and where you place the jack is solid, level and not slippery. If necessary, use a large underlay. On slippery surfaces, such as tiled floors, you should use a non-slip underlay, for example a rubber mat. Do not use wooden blocks or similar objects as a jack underlay. Otherwise, the jack may

capacity if it is not at its full height. Never start the engine when the vehicle is raised.

not be able to achieve its load-bearing

Also observe the notes on the jack.



▶ Using lug wrench (1), loosen the bolts on the wheel you wish to change by about one full turn. Do not unscrew the bolts completely.

The jacking points for the jack are located behind the wheel housings of the front wheels and in front of the wheel housings of the rear wheels (arrows).




P40.10-5912-31

↑ WARNING

The jack is designed exclusively for jacking up the vehicle at the jacking points. The jack saddle must be placed centrally under the jacking point.


If you do not position the jack correctly in the jacking point, the vehicle can fall off the jack and seriously or fatally injure you or others.

I The jack is designed exclusively for jacking up the vehicle at the jacking points. Otherwise, your vehicle could be damaged.



▶ Position jack ③ at jacking point ②.





P40.10-5216-31

- ▶ Make sure that the base of the jack is positioned directly under the jacking point.
- ► Turn crank (4) clockwise until jack (3) sits completely on jacking point (2) and the base of the jack lies evenly on the ground.
- ▶ Turn crank (4) until the tire is raised a maximum of 1.2 inches (3 cm) off the ground.

Removing a wheel



- ► Unscrew the uppermost wheel bolt completely.
- ► Screw alignment bolt (1) into the thread instead of the wheel bolt.
- ▶ Unscrew the remaining wheel bolts fully.
- Do not place wheel bolts in sand or on a dirty surface. The bolt and wheel hub threads could otherwise be damaged when you screw them in.
- ▶ Remove the wheel.

Mounting a new wheel



↑ WARNING

Always replace wheel bolts that are damaged or rusted.

Never apply oil or grease to wheel bolts.

Damaged wheel hub threads should be repaired immediately. Do not continue to drive under these circumstances! Contact an authorized Mercedes-Benz Center or call Roadside Assistance.

Incorrect wheel bolts or improperly tightened wheel bolts can cause the wheel to come off. This could cause an accident. Make sure to use the correct wheel bolts.



↑ WARNING


Only use genuine Mercedes-Benz wheel bolts. Other wheel bolts may come loose.

Do not tighten the wheel bolts when the vehicle is raised. Otherwise, the vehicle could fall off the jack.



↑ WARNING

Make sure to use the original length wheel bolts when remounting the original wheel after it has been repaired.



Wheel bolts for:

- (1) All alloy wheels and the "Minispare" emergency spare wheel for alloy wheels
- (2) "Minispare" emergency spare wheel for steel wheels
- Always use wheel bolts (1) to fit the "Minispare" emergency spare wheel with



light-alloy wheel. Using other wheel bolts when fitting the "Minispare" emergency spare wheel with light-alloy wheel could damage the brake system.

Always use wheel bolts ② to fit the "Minispare" emergency spare wheel with steel wheel. Using other wheels when fitting the "Minispare" emergency spare wheel with steel wheel could damage the brake system.


- ► Clean the wheel and wheel hub contact surfaces.
- I To prevent damage to the paintwork, hold the wheel securely against the wheel hub while screwing in the first wheel bolt.



- ► Slide the emergency spare wheel onto the alignment bolt and push it on.
- ► Tighten the wheel bolts until they are finger-tight.
- ► Unscrew the alignment bolt.
- Tighten the last wheel bolt until it is fingertight.

Lowering the vehicle

- ► Turn the crank of the jack counterclockwise until the vehicle is once again standing firmly on the ground.
- ▶ Place the jack to one side.



➤ Tighten the wheel bolts evenly in a crosswise pattern in the sequence indicated (① to ⑤). The tightening torque must be 110 lb-ft (150 Nm).

⚠ WARNING

Have the tightening torque checked immediately after a wheel is changed. The wheels could come loose if they are not tightened to a torque of 110 lb/ft (150 Nm).

- ➤ Turn the jack back to its initial position and store it together with the rest of the tirechange tool kit in the stowage well under the trunk floor.
- When you are driving with the emergency spare wheel mounted, the tire pressure monitoring system cannot function reliably. Only restart the tire pressure monitoring system when the defective wheel has been replaced with a new wheel. All mounted wheels must be equipped with functioning sensors and the defective wheel should no longer be in the vehicle.

MOExtended tires (tires with run-flat properties)

MOExtended tires (tires with run-flat properties) allow you to continue driving your vehicle even if one or more tires are entirely deflated.

MOExtended tires may only be used in conjunction with the activated tire pressure



loss warning system or with the activated tire pressure monitoring system.

The maximum permissible distance which can be driven in run-flat mode depends on the load in the vehicle. You can drive 50 miles (80 km) if the vehicle is partially laden and 18 miles (30 km) if it is fully laden.

The maximum permissible distance which can be driven in run-flat mode is counted from the moment the tire pressure loss warning appears in the multifunction display.

You must not exceed a maximum speed of 50 mph (80 km/h).

↑ WARNING

The handling characteristics of your vehicle deteriorate in run-flat mode, for example:

- · when cornering
- when braking
- when accelerating rapidly

Adapt your driving style accordingly and avoid sudden changes in direction and sudden acceleration, as well as driving over obstacles (i.e. curbs, potholes), and driving off-road. This is particularly the case when the vehicle is heavily laden.

The maximum permissible distance that can be driven in run-flat mode depends to a large extent on the loads placed on the vehicle. It can be shorter due to high speeds, a heavy load, sudden changes in direction, the road surface condition, outside temperature, etc., or further if you drive carefully and conservatively.

Do not continue to drive in run-flat mode if:

- · you hear banging noises.
- the vehicle starts to shake.
- · you see smoke and smell rubber.
- ESP® is intervening constantly.
- there are tears in the sidewalls of the tire.

After driving in run-flat mode, you must have the wheel(s) checked for damage at a qualified specialist workshop which has the necessary specialist knowledge and tools to

carry out the work required. The defective tire must be replaced in every case.

Mercedes-Benz recommends that you use an authorized Mercedes-Benz Center for this purpose. In particular, work relevant to safety or on safety-related systems must be carried out at a qualified specialist workshop.

When replacing one or all tires, make sure that you only use tires marked MOExtended and of the specified size for the vehicle.

Battery

Important safety notes

In order for the battery to achieve the maximum possible service life, it must always be sufficiently charged.

Have the battery checked regularly at a qualified specialist workshop, such as an authorized Mercedes-Benz Center.

Adhere to the service intervals indicated in the service booklet or ask a qualified specialist workshop, such as an authorized Mercedes-Benz Center.

Have the battery charge checked more frequently if you use the vehicle mainly for short trips or if you leave it standing idle for a lengthy period.

Only replace a battery with a battery that has been recommended by Mercedes-Benz.

Consult an authorized Mercedes-Benz Center if you wish to leave your vehicle parked for a long period of time.



♠ WARNING

Hybrid vehicles: be sure to read the "HYBRID" supplement. Otherwise, you could fail to recognize dangers.



↑ WARNING

Comply with safety precautions and take protective measures when handling batteries.





Risk of explosion



Fire, naked flames and smoking are prohibited when handling the battery. Avoid creating sparks.



Battery acid is caustic. Avoid contact with the skin, eyes or clothing.

Wear suitable protective clothing, in particular gloves, an apron and a face mask.

Immediately rinse acid splashes off with clean water. Consult a doctor if necessary.



Wear eye protection.



Keep children away.



Observe this Operator's Manual.



Environmental note



Batteries contain dangerous substances. It is against the law to dispose of them with the household rubbish. They must be collected separately and recycled to protect the environment.



Dispose of batteries in an environmentally friendly manner. Return discharged batteries to a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center, or to a special

collection point for old batteries.



↑ WARNING

Failure to follow these instructions can result in severe injury or death.

Never lean over batteries while connecting. You might get injured.

Battery fluid contains sulfuric acid. Do not allow this fluid to come in contact with eyes, skin or clothing. In case it does, immediately flush affected area with water and seek medical help if necessary.

A battery will also produce hydrogen gas, which is flammable and explosive. Keep flames or sparks away from battery, avoid improper connection of jumper cables, smoking etc.



↑ WARNING

Do not place any metal objects on the battery as this could result in a short circuit.

Use leak-proof batteries only to avoid the risk of acid burns in the event of an accident.

Take care that you do not become statically charged, e.g. by wearing synthetic clothing or rubbing against textiles. For this reason, you also should not pull or push the battery over carpets or other synthetic materials.

Never touch the battery first. First, touch the outside body of the vehicle in order to release any possible electrostatic charges.

Do not rub the battery with rags or cloths. The battery could explode if touched due to electrostatic charge or due to spark formation.

Before working on the battery, e.g. loosening the battery terminals, switch off the engine and remove the SmartKey from the ignition. On vehicles with KEYLESS-GO, make sure that the ignition is switched off. Check that all the indicator lamps in the instrument cluster are off. You may otherwise destroy electronic components, such as the alternator.



Like other batteries, the vehicle battery may discharge over time if you do not use the vehicle. In this case have the battery checked at a qualified specialist workshop, such as an authorized Mercedes-Benz Center. You can also charge the battery with a charger recommended by Mercedes-Benz, Contact an authorized Mercedes-Benz Center for more information.

The battery and the cover of the positive terminal clamp must be installed securely during operation.

Temove the SmartKey if you park the vehicle and do not require any electrical consumers. The vehicle will then use very little energy, thus conserving battery power.

Mercedes-Benz recommends that you do not carry out work on batteries yourself, e.g. removing or charging. Always have this work performed at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.

Charging the battery

↑ WARNING

Never charge a battery still installed in the vehicle unless a battery charger unit approved by Mercedes-Benz is being used. Gases may escape during charging and cause explosions that may result in paint damage, corrosion or personal injury.

A battery charger unit specially adapted for Mercedes-Benz vehicles and tested and approved by Mercedes-Benz is available as an accessory. It permits the charging of the battery in its installed position. Contact an authorized Mercedes-Benz Center for further information and availability.

Charge the battery in accordance with the separate instructions for the battery charger.

/ WARNING

There is a risk of acid burns during the charging process due to the gases which escape from the battery. Do not lean over the battery during the charging process.

Battery acid is caustic. Avoid contact with the skin, eyes or clothing.

- I Only charge the installed battery with a battery charger which has been tested and approved by Mercedes-Benz. These battery chargers allow the battery to be charged while still installed.
- I Only use battery chargers with a maximum charging voltage of 14.8 V.
- I Only charge the battery using the jumpstarting connection point.

The jump-starting connection point is in the engine compartment (⊳ page 481).

- ▶ Open the hood (▷ page 456).
- ► Connect the battery charger to the positive terminal and earth point in the same order as when connecting the donor battery in the jump-starting procedure (⊳ page 481).
- ► Read the battery charger's operating instructions before charging the battery.



Jump-starting



↑ WARNING

Failure to follow these directions will cause damage to the electronic components, and can lead to a battery explosion and severe injury or death.

Never lean over batteries while connecting or jump starting. You might get injured.

Battery fluid contains sulfuric acid. Do not allow this fluid to come in contact with eyes, skin or clothing. In case it does, immediately flush affected area with water, and seek medical help if necessary.

A battery will also produce hydrogen gas, which is flammable and explosive. Keep flames or sparks away from battery, avoid improper connection of jumper cables, smoking, etc.

Attempting to jump start a frozen battery can result in it exploding, causing personal injury. Read all instructions before proceeding.



↑ WARNING

Hybrid vehicles: be sure to read the "HYBRID" supplement. Otherwise, you could fail to recognize dangers.

Avoid repeated and lengthy starting attempts. Otherwise, non-combusted fuel may damage the catalytic converter²⁷ and create a risk of fire.

Do not use a rapid-charging device to start the engine.

Make sure the jumper cables are not damaged.

Make sure the jumper cables are not touching any other metal objects when they are connected to the battery.

If your vehicle's battery is discharged, the engine can be jump-started from another vehicle or from a second battery using jumper cables.

Observe the following points:


- ▶ The battery is not accessible in all vehicles. If the other vehicle's battery is not accessible, jump-start the vehicle using a second battery or a jump-starting device.
- ▶ Only jump-start the vehicle when the engine is cold and the catalytic converter system has cooled down²⁸.
- ▶ Do not start the engine if the battery is frozen. Let the battery thaw first.
- ▶ Jump-starting may only be performed from batteries with a nominal voltage of 12 V.
- ▶ Only use jumper cables which have a sufficient cross-section and insulated terminal clamps.
- ▶ Make sure that the jumper cables cannot come into contact with parts, such as the pulley or the fan. These parts move when the engine is started and while it is running.
- ▶ If the battery is fully discharged, leave the battery that is being used to jump-start connected for a few minutes before attempting to start. This charges the empty battery a little.
- Jumper cables and further information about jump-starting can be obtained from any authorized Mercedes-Benz Center, for example.

²⁸ Only vehicles with a gasoline engine.



²⁷ Only vehicles with a gasoline engine.

- ▶ Make sure that the two vehicles do not touch.
- ▶ Secure the vehicle by applying the electric parking brake.
- ▶ Shift the transmission to position **P**.
- ▶ Switch off all electrical consumers (e.g. radio, blower, etc.).
- ▶ Open the hood (▷ page 456).



Position number (5) identifies the charged battery of the other vehicle or an equivalent jump-starting device.

- ▶ Remove the cover from positive terminal ①.
- ► Connect positive terminal ① on your vehicle to positive terminal ② of donor battery ⑤ using the jumper cable, beginning with your own battery.
- ▶ Start the engine of the donor vehicle and run it at idling speed.
- ► Connect negative terminal ③ of donor battery ⑤ to earth point ④ of your vehicle using the jumper cable, connecting the jumper cable to donor battery ⑤ first.
- ► Start the engine.
- ▶ Allow the engine to run for a few minutes before disconnecting the jumper cable.
- ▶ First, remove the jumper cable from earth point ④ and negative terminal ③, then from positive terminal ① and positive terminal ②, each time disconnecting from the battery on your own vehicle first.
- ► Have the battery checked at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center. The jump-starting procedure is not a standard operating state; therefore, have the battery checked.



Towing and tow-starting

Important safety notes



↑ WARNING

Hybrid vehicles: be sure to read the "HYBRID" supplement. Otherwise, you could fail to recognize dangers.

↑ WARNING

If you tow the vehicle, you must use a rigid towing bar if:

- the engine is not running.
- there is a brake system malfunction.
- there is a malfunction in the power supply or the vehicle's electrical system.

The power assistance for the steering and the brake force booster do not work when the engine is not running. You will need more force to steer and brake, you may have to depress the brake pedal with maximum force. Before towing away, make sure that the steering can be moved and is not locked. If you tow or tow-start another vehicle, its

weight must not exceed the maximum permissible gross vehicle weight of your vehicle.

↑ WARNING

The vehicle is braked when the HOLD function or DISTRONIC PLUS is activated. Therefore. deactivate HOLD and DISTRONIC PLUS if the vehicle is to be towed.

It is better to have the vehicle transported than to have it towed.

You may only tow the vehicle a maximum distance of 30 miles (50 km). A towing speed of 30 mph (50 km/h) must not be exceeded.

For towing distances over 30 miles (50 km), the vehicle must loaded onto a transporter.

I Make sure that the electric parking brake is released. If the electric parking brake is faulty, visit a qualified specialist workshop.

- I Only secure the tow rope or tow bar at the towing eyes. Otherwise, the vehicle could be damaged.
- Do not use the towing eye for recovery, as this could damage the vehicle. If in doubt, recover the vehicle with a crane.
- When towing, pull away slowly and smoothly. If the tractive power is too high, the vehicles could be damaged.
- Do not tow with sling-type equipment. This could damage the vehicle.
- When towing vehicles with KEYLESS-GO, use the key instead of the Start/Stop button. Otherwise, the automatic transmission may shift to position P when the driver's or front-passenger door are opened, which could lead to damage to the transmission.

The automatic transmission must be in position **N** when the vehicle is being towed. The battery must be connected and charged. Otherwise, you:

- cannot turn the SmartKey to position 2 in the ignition lock
- cannot shift the automatic transmission to position N
- 1 Before the vehicle is towed, switch off the automatic locking feature (⊳ page 264). You could otherwise be locked out when pushing or towing the vehicle.

Installing/removing the towing eye

Installing the towing eye

Remove the towing eye from the vehicle tool kit (⊳ page 472).



↑ WARNING

The exhaust tail pipe may be hot. You could burn yourself if you touch the tail pipe. Be particularly careful when removing the rear cover.



The mountings for the removable towing eyes are located in the bumpers. They are at the front and at the rear, under the covers.





- ▶ Press the mark on cover (1) inwards in the direction of the arrow.
- ► Take cover (1) off the opening.
- ▶ Screw the towing eye in clockwise to the stop and tighten it.

Removing the towing eye

- ▶ Loosen the towing eye and unscrew it.
- ▶ Attach cover (1) to the bumper and press until it engages.
- ▶ Place the towing eye in the vehicle tool kit.

Towing the vehicle with the rear axle raised

Only possible on vehicles without 4MATIC.

When towing your vehicle with the rear axle raised, it is important that you observe the safety instructions (⊳ page 483).

I The ignition must be switched off if you are towing the vehicle with the rear axle raised. Intervention by ESP® could otherwise damage the brake system.

- ► Switch on the hazard warning lamps (⊳ page 279).
- ► Turn the SmartKey to position **0** in the ignition lock and remove the SmartKey from the ignition lock.
- ▶ When leaving the vehicle, take the SmartKey or the KEYLESS-GO key with you.

Towing a vehicle with both axles on the ground

When having your vehicle towed, observe the important safety notes (⊳ page 483).

↑ WARNING

The power assistance for the steering and the brake force booster do not work when the engine is not running. You will then need much more effort to brake and steer the vehicle. Adapt your style of driving accordingly.

The automatic transmission automatically shifts to position **P** when you open the driver's or front-passenger door or when you remove the SmartKey from the ignition lock. In order to ensure that the automatic transmission stays in position N when towing the vehicle, you must observe the following points:

- ▶ Make sure that the vehicle is stationary and the SmartKey in the ignition lock is in position 0.
- ► Turn the SmartKey to position 2 in the ignition lock.

On vehicles with KEYLESS-GO, use the key instead of the Start/Stop button (⊳ page 303).

- ▶ Depress and hold the brake pedal.
- ▶ Shift the automatic transmission to position N.
- ► Release the brake pedal.
- ► Release the electric parking brake.
- ► Leave the SmartKey in position 2 in the ignition lock.



Transporting the vehicle

The towing eye can be used to pull the vehicle onto a trailer or transporter for transporting purposes.

- ► Turn the SmartKey to position 2 in the ignition lock.
- ▶ Shift the automatic transmission to position N.

As soon as the vehicle is loaded:

- ▶ Prevent the vehicle from rolling away by applying the electric parking brake.
- ▶ Shift the automatic transmission to position P.
- ► Turn the SmartKey to position **0** in the ignition lock and remove the SmartKey from the ignition lock.
- Secure the vehicle.
- I Only lash the vehicle down by the wheels or wheel rims, not by parts of the vehicle such as axle or steering components. Otherwise, the vehicle could be damaged.

Notes for 4MATIC vehicles

Vehicles with 4MATIC must not be towed with either the front or the rear axle raised. as doing so will damage the transmission.

If the vehicle has transmission damage or damage to the front or rear axle, have it transported on a transporter or trailer.

In the event of damage to the electrical system

If the battery is defective, the automatic transmission will be locked in position P. To shift the automatic transmission to position N, you must provide power to the vehicle's electrical system in the same way as when jump-starting (▷ page 481).

Have the vehicle transported on a transporter or trailer.

Tow-starting (emergency starting)

■ Vehicles with automatic transmission must not be started by tow-starting. This could otherwise damage the transmission.

Fuses

Important safety notes

The fuses in your vehicle serve to close down faulty circuits. If a fuse blows, all the components on the circuit and their functions stop operating.

↑ WARNING

Only use fuses approved by Mercedes-Benz with the specified amperage for the system in question and do not attempt to repair or bridge a blown fuse. Using other than approved fuses or using repaired or bridged fuses may cause an overload leading to a fire, and/or cause damage to electrical components and/or systems. Have the cause determined and remedied by an authorized Mercedes-Benz Center

Blown fuses must be replaced with fuses of the same rating, which you can recognize by the color and value. The fuse ratings are listed in the fuse allocation chart. An authorized Mercedes-Benz Center will be happy to advise you.

If a fuse has blown, contact a breakdown service or an authorized Mercedes-Benz Center.

If the newly inserted fuse also blows, have the cause traced and rectified at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.

Only use fuses that have been approved for Mercedes-Benz vehicles and which have the correct fuse rating for the system concerned. Otherwise, components or systems could be damaged.



Before changing a fuse

- ► Park the vehicle and apply the electric parking brake.
- ► Switch off all electrical consumers.
- ► Remove the SmartKey from the ignition lock.

The fuses are located in various fuse boxes:

- fuse box on the right and left-hand sides of the dashboard
- · fuse box in the rear
- fuse box in the engine compartment on the left-hand side of the vehicle, when viewed in the direction of travel
- fuse box in the engine compartment on the right-hand side of the vehicle, when viewed in the direction of travel

The fuse allocation chart is in the vehicle document wallet.

Dashboard fuse box

There is a fuse box located on both the driver's side and the front-passenger side.

■ Do not use a pointed object such as a screwdriver to open the cover in the dashboard. You could damage the dashboard or the cover.



Driver's side illustrated


- ► To open: pull cover ① outwards in the direction of the arrow and remove it.
- ► **To close:** clip in cover ① on the front of the dashboard.
- ► Fold cover ① inwards until it engages.

Fuse box in the rear

The fuse box is behind the armrest in the rear.



- ▶ To open: fold down the armrest.
- Pull handle ① on the trim behind the rear seat armrest up in the direction of the arrow.
- ► Fold down trim ②.




- ► Loosen cover (4) with a suitable object (3).
- ► Remove cover ④ upwards in the direction of the arrow.
- I The cover must be seated properly, otherwise moisture or dirt could impair the function of the fuses.



Fuse box in the engine compartment

Fuse box on the left in the direction of travel


▶ Open the hood (> page 456).



- ► Remove any existing moisture from the fuse box using a dry cloth.
- ► AMG vehicles: remove the control unit above the fuse box.
- ► To open: undo screws ① with an Allen key.
- ► Remove bracket ③.
- ► Remove cover ②.
- ► **To close:** check whether the rubber seal is lying correctly in cover (2).
- ▶ Put cover ② back in position.
- ► Replace bracket ③.
- ► Tighten screws ① using an Allen key.
- I The cover must be seated properly, otherwise moisture or dirt could impair the function of the fuses.
- ► Close the hood (> page 457).

Fuse box on the right in the direction of travel

▶ Open the hood (> page 456).



- ► Remove any existing moisture from the fuse box using a dry cloth.
- ► To open: open clamps ②.
- ► Remove cover ② upwards.
- ► **To close:** check whether the rubber seal is lying correctly in cover ②.
- ▶ Put cover ② back in position.
- ► Fold down cover ① and close clamps ②.
- The cover must be seated properly, otherwise moisture or dirt could impair the function of the fuses.
- ► Close the hood (> page 457).

Engine emergency off


If the engine cannot be switched off as described, observe the following procedure:

- ► Take the fuse allocation chart out of the vehicle document wallet.
- ► Search for "Emergency engine shutdown" in the fuse allocation chart.
- ► Remove the fuses listed under "Emergency engine shutdown".





Useful information	490
Important safety notes	490
Operation	490
Winter operation	492
Tire pressure	493
Loading the vehicle	500
Maximum load rating	504
Uniform Tire Quality Grading	
Standards	505
Tire labeling	506
Definition of terms for tires and	
loading	510
Changing a wheel	513
Wheel and tire combinations	514



Useful information

- 1 This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- Please read the information on qualified specialist workshops (⊳ page 31).

Important safety notes

Consult an authorized Mercedes-Benz Center if you require information on approved and recommended tires and wheels for summer and winter operation. Advice on purchasing and caring for tires is also available there.

♠ WARNING

Replace rims or tires with the same designation, manufacturer and type as shown on the original part. For further information contact an authorized Mercedes-Benz Center. If incorrectly sized rims and tires are mounted, the wheel brakes or suspension components can be damaged. Also, the operating clearance of the wheels and the tires may no longer be correct.

/ WARNING

Worn, old tires can cause accidents. If the tire tread is worn to minimum tread depth, or if the tires have sustained damage, replace them.

When replacing rims, only use genuine Mercedes-Benz wheel bolts specified for the particular rim type. Failure to do so can result in the bolts loosening and possibly an accident.

Retreaded tires are not tested or recommended by Mercedes-Benz, since previous damage cannot always be

recognized on retreads. The operating safety of the vehicle cannot be assured when such tires are used.



↑ WARNING

If you feel a sudden significant vibration or ride disturbance, or you suspect that possible damage to your vehicle has occurred, you should turn on the hazard warning flashers, carefully slow down, and drive with caution to an area which is a safe distance from the road. Inspect the tires and the vehicle underbody for possible damage. If the vehicle appears unsafe, have the vehicle towed to the nearest authorized Mercedes-Benz Center or tire dealer for repairs.



↑ WARNING

Do not drive with a flat tire. A flat tire affects the ability to steer or brake the vehicle. You might lose control of the vehicle. Continued driving with a flat tire or driving at high speed with a flat tire will cause excessive heat buildup and possibly a fire.

 Further information about Tires and wheels can be obtained from any authorized Mercedes-Benz Center.

Operation

Notes on driving

- If the vehicle is heavily laden, check the tire pressures and correct them if necessary.
- · When parking your vehicle, make sure that the tires do not get deformed by the curb or other obstacles. If it is necessary to drive over curbs, speed humps or similar elevations, try to do so slowly and at an obtuse angle. Otherwise, the tires, particularly the sidewalls, can get damaged.



Notes on regularly inspecting wheels and tires

♠ WARNING

Regularly check the tires for damage. Damaged tires can cause tire inflation pressure loss. As a result, you could lose control of your vehicle.

Worn, old tires can cause accidents. If the tire tread is worn to minimum tread depth, or if the tires have sustained damage, replace them.

- Regularly check the wheels and tires of your vehicle for damage (e.g. cuts, punctures, tears, bulges on tires and deformation or cracks or severe corrosion. on wheels) at least once a month, as well as after driving off-road or on rough roads. Damaged wheels can cause a loss of tire pressure.
- Regularly check the tire tread depth and the condition of the tread across the whole width of the tire (⊳ page 491). If necessary, turn the front wheels to full lock in order to inspect the inner side of the tire surface.
- All wheels must have a valve cap to protect the valve against dirt and moisture. Do not mount anything onto the valve (such as tire pressure monitoring systems) other than the standard valve cap or other valve caps approved by Mercedes-Benz for your vehicle.
- Regularly check the pressure of all the tires including the emergency spare wheel or the spare wheel, particularly prior to long trips, and correct the pressure as necessary (⊳ page 493).

Tire tread




★ WARNING

Although the applicable federal motor vehicle safety laws consider a tire to be worn when the tread wear indicators (TWI) become visible at approximately $\frac{1}{16}$ in (1.6 mm), we recommend that you do not allow your tires to wear down to that level. As tread depth approaches $\frac{1}{8}$ in (3 mm), the adhesion properties on a wet road are sharply reduced. Depending upon the weather and/or road surface (conditions), the tire traction varies widely.

Do not use tires that are excessively worn as the tire traction on wet road surfaces decreases significantly when the tread depth is less than $^{1}/_{8}$ inch (3 mm).

Tread wear indicators (TWI) are required by law. Six indicators are positioned on the tire tread. They become visible as soon as a tread depth of approximately $\frac{1}{16}$ inch (1.6 mm) has been reached. If this is the case, the tire is so worn that it must be replaced.

The recommended tread depth for summer tires is at least ¹/₈ inch (3 mm). The recommended tread depth for winter tires is at least $\frac{1}{6}$ inch (4 mm).



Bar marking 1 for tread wear is integrated into the tire tread.

Notes on selecting, mounting and replacing tires

- Only mount tires and wheels of the same type and make.
- Only mount tires of the correct size onto the wheels.
- After mounting new tires, run them in at moderate speeds for the first 60 miles



(100 km) as they only reach their full performance after this distance.

- · Do not use tires that are excessively worn as the tire traction on wet road surfaces. decreases significantly when the tread depth is less than $\frac{1}{8}$ inch (3 mm).
- Replace the tires after six years at the latest, regardless of wear. This also applies to the spare wheel/emergency spare wheel.

The service life of tires depends on the following factors amongst other things:

- · driving style
- tire pressure
- mileage

MOExtended tires (tires with run-flat properties)

MOExtended tires (tires with run-flat properties) allow you to continue driving your vehicle even if one or more tires are entirely deflated.

MOExtended tires may be used only in conjunction with the activated tire pressure loss warning system or the activated tire pressure monitoring system and only on wheels specifically tested by Mercedes-Benz. You will find notes on driving with MOExtended tires in the "Breakdown assistance" section (⊳ page 477).

Winter operation

Please bear the following in mind

At the onset of winter, have your vehicle winterproofed at a qualified specialist workshop, e.g. at an authorized Mercedes-Benz Center.

Observe the notes in the "Changing a wheel" section (⊳ page 513).

Driving with summer tires

At temperatures below 45 °F (+7 °C), the elasticity of summer tires and therefore also traction and braking capability are reduced considerably – equip your vehicle with M+S tires. Using summer tires at very cold temperatures could cause tears to form, thereby damaging the tires permanently. Mercedes-Benz cannot accept responsibility for this type of damage.

M+S tires

At temperatures below 45 °F(+7 °C), use winter tires or all-season tires. Both types of tire are identified by the M+S marking. Only winter tires bearing the A snowflake symbol in addition to the M+S marking provide the best possible grip in wintry road conditions. Only these tires will allow driving safety systems such as ABS and ESP® to function optimally in winter, as these tires have been designed specifically for driving on snow.

Use M+S tires of the same make and tread on all wheels to maintain safe handling characteristics.

/ WARNING

M+S tires with a tread depth of less than ¹/₆ inch (4 mm) must be replaced immediately. They are no longer suitable for use in winter.

Always observe the maximum permissible speed specified for the M+S tires you have mounted.

Once you have mounted the winter tires:

- ► Check the tire pressures (> page 497).
- ▶ Restart the tire pressure monitor (⊳ page 497).



♠ WARNING

If you use your spare wheel when M+S tires are mounted on the other wheels, be aware that the difference in tire characteristics



impairs cornering ability and reduces driving stability. Adapt your driving style accordingly. Have the spare wheel replaced by a normal wheel with an M+S tire at the nearest Mercedes-Benz Center.

Snow chains

For safety reasons, Mercedes-Benz recommends that you only use snow chains which have been specially approved for your vehicle by Mercedes-Benz, or are of a corresponding standard of quality.

- You must drive at raised vehicle level if snow chains have been mounted. The vehicle could otherwise be damaged.
- There is not enough space for snow chains on some wheel sizes. Observe the information under "Tires and wheels" in the "Technical Data" section to avoid damage to the vehicle or the wheels.
- Only use snow chains when driving on roads completely covered by snow. Do not exceed the maximum permissible speed of 30 mph (50 km/h). Remove the snow chains as soon as possible when you are no longer driving on snow-covered roads.
- Local regulations may restrict the use of snow chains. Applicable regulations must be observed if you wish to mount snow chains.
- Snow chains must not be mounted on emergency spare wheels.

If you intend to mount snow chains, please bear the following points in mind:

- you may not attach snow chains to all wheel-tire combinations; see the information under "Wheel and tire combinations" in the "Wheels and tires" section.
- mount snow chains only in pairs and only to the rear wheels. Observe the manufacturer's installation instructions.

- If snow chains are mounted on the front wheels, the snow chains could grind against the bodywork or components of the chassis. This could result in damage to the vehicle or the tires.
- Vehicles with steel wheels: if you wish to mount snow chains on steel wheels, make sure that you remove the respective wheels' hubcaps first. The hubcaps may otherwise be damaged.
- (1) You may wish to deactivate ESP®(▷ page 71) when pulling away with snow chains mounted. This way you can allow the wheels to spin in a controlled manner, achieving an increased driving force (cutting action).

Tire pressure

Tire pressure specifications



↑ WARNING

Follow recommended tire inflation pressures. Do not underinflate tires. Underinflated tires wear excessively and/or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.

Do not overload the tires by exceeding the specified load limit as indicated on the Tire and Loading Information placard on the driver's door B-pillar. Overloading the tires can overheat them, possibly causing a blowout. Overloading the tires can also result in handling or steering problems, or brake failure.


The recommended tire pressures for the tires mounted at the factory can be found on the labels described here.



Option 1) **Tire and Loading Information placard** on the B-pillar on the driver's side of the vehicle (▷ page 500).

The Tire and Loading Information placard contains the recommended tire pressures for cold tires on a fully loaded vehicle and for the maximum permissible vehicle speed.

i) The specifications given on the following Tire and Loading Information placard are examples. Tire pressure specifications are vehicle-specific and may deviate from the data shown here. The tire pressures applicable to your vehicle can be found on the Tire and Loading Information placard on your vehicle.




Recommended tire pressures

Option 2) **Tire pressure table** on the inside of the fuel filler flap.


The tire pressure table contains the recommended pressures for cold tires for various operating conditions, i.e. differing load and speed conditions.

Specifications shown in the examples of tire pressure tables are for illustration purposes only. Tire pressure specifications are vehicle-specific and may deviate from the data shown here. Tire pressure specifications applicable to your vehicle are located in your vehicle's tire pressure table.




Example: tire pressure table for all tires approved ex-works for this vehicle

If a tire size precedes a tire pressure, the tire pressure information following is only valid for that tire size. The load conditions "partially laden" and "fully laden" are defined in the table for different numbers of passengers and amounts of luggage. The actual number of seats may differ.



Example: tire pressure table with tire dimensions Some tire pressure tables show only the rim diameters instead of the full tire size, e.g. **R18**. The rim diameter is part of the tire size and can be found on the tire sidewall (> page 507).





If the tire pressures have been set to the lower values for lighter loads and/or lower road speeds, the pressures should be reset to the higher values:

- if you want to drive with an increased load and/or
- if you want to drive at higher road speeds.
- The tire pressures for increased loads and/or higher road speeds, shown in the tire pressure table, may have a negative effect on driving comfort.

Option 3) The tire pressure for the emergency/collapsible spare wheel (depending on vehicle equipment) can be found:

- printed in yellow on the rim of the emergency/collapsible spare wheel
- in the "Wheel and tire combinations" section (⊳ page 514) in this manual
- on the Tire and Loading Information placard on the B-pillar on the driver's side.

If the tire pressure is not set correctly, this can lead to an excessive build up of heat and a sudden loss of pressure.

For further information, consult a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.

Important notes on tire pressure



↑ WARNING

Should the tire pressure drop repeatedly:

- check the tire for foreign bodies.
- check whether the wheel is losing air or the valve is leaking.
- make sure that only a valve cap approved by Mercedes-Benz is used on the tire valve.

Tire pressures that are too low have a negative effect on vehicle safety, which could lead you to cause an accident.

To test tire pressure, use a suitable tire pressure gauge. The outer appearance of a tire does not permit any reliable conclusion about the tire pressure. On vehicles equipped with the electronic tire pressure monitoring system, the tire pressure can be checked using the on-board computer.

The tire temperature and pressure increase when the vehicle is in motion. This is dependent on the driving speed and the load. Therefore, you should only correct tire pressures when the tires are cold.

The tires are cold:

- if the vehicle has been parked without direct sunlight on the tires for at least three hours and
- if the vehicle has not been driven more than 1 mile (1.6 km).

The tire temperature changes depending on the outside temperature, the vehicle speed and the tire load. If the tire temperature changes by 18 °F (10 °C), the tire pressure changes by approximately 10 kPa (0.1 bar/ 1.5 psi). Take this into account when checking the pressure of warm tires and only correct the tire pressure if it is too low for the current operating conditions. If you check the tire pressure when the tires are warm, the resulting value will be higher than if the tires were cold. This is normal. Do not reduce the tire pressure to the value specified for cold tires. The tire pressure would otherwise be too low.



Observe the recommended tire pressures for cold tires

- on the Tire and Loading Information placard on the B-pillar on the driver's side,
- in the tire pressure table on the inside of the fuel filler flap,
- printed in yellow on the rim of the emergency/collapsible spare wheel (depending on vehicle equipment).

Underinflated or overinflated tires

Underinflated tires



↑ WARNING

Follow recommended tire inflation pressures. Do not underinflate tires. Underinflated tires. wear excessively and/or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Underinflated tires can:

- wear excessively and/or unevenly
- · adversely affect fuel economy
- · fail from being overheated
- · adversely affect handling

Overinflated tires



↑ WARNING

Follow recommended tire inflation pressures. Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.

Overinflated tires can:

- · adversely affect handling
- wear excessively and/or unevenly
- · be more likely to become damaged

- adversely affect ride comfort
- increase stopping distance

Maximum tire pressure



↑ WARNING

Never exceed the maximum tire inflation pressure. Follow recommended tire inflation pressures.

Do not underinflate tires. Underinflated tires wear excessively and/or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.



- (1) Maximum permitted tire pressure (example)
- 1 The actual values for tires are specific to each vehicle and may deviate from the values in the illustration.

When adjusting the tire pressures always observe the recommended tire pressure for your vehicle (⊳ page 493).



Checking the tire pressures

Important safety notes

★ WARNING

Follow recommended tire inflation pressures. Do not underinflate tires. Underinflated tires wear excessively and/or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.

Do not overload the tires by exceeding the specified load limit as indicated on the Tire and Loading Information placard on the driver's door B-pillar. Overloading the tires can overheat them, possibly causing a blowout. Overloading the tires can also result in handling or steering problems, or brake failure.

Check the tire pressure at least once a month. Only check and correct tire pressures when the tires are cold (⊳ page 493).

Checking tire pressure manually

To determine and set the correct tire pressure, proceed as follows:

- ▶ Remove the valve cap of the tire that is to be checked.
- ▶ Press the tire pressure gauge securely onto the valve.
- ▶ Read the tire pressure and compare it with the recommended value on the Tire and Loading Information placard on the B-pillar on the driver's side of your vehicle.
- ▶ If necessary, increase the tire pressure to the recommended value (⊳ page 493).
- ▶ If the tire pressure is too high, release air by pressing down the metal pin in the valve using the tip of a pen, for example. Then

- check the tire pressure again using the tire pressure gauge.
- Screw the valve cap onto the valve.
- ▶ Repeat these steps for the other tires.

Tire pressure monitor

Important safety notes

If a tire pressure monitor system is installed, the vehicle's wheels have sensors that monitor the tire pressures in all four tires. The tire pressure monitor warns you when the pressure drops in one or more of the tires. The tire pressure monitor only functions if the correct wheel electronics units are installed on all wheels.

The tire pressure monitor has a yellow warning lamp in the instrument cluster for indicating pressure loss/malfunctions (USA) or pressure loss (Canada). Whether the warning lamp flashes or lights up indicates whether a tire pressure is too low or the tire pressure monitoring system is malfunctioning:

- if the warning lamp is lit continuously, the tire pressure on one or more tires is significantly too low. The tire pressure monitor is not malfunctioning.
- USA only: if the warning lamp flashes for 60 seconds and then remains lit constantly, the tire pressure monitor is malfunctioning.



↑ WARNING

Each tire, including the spare (if provided), should be checked at least once a month when cold and inflated to the pressure recommended by the vehicle manufacturer on the Tire and Loading Information placard on the driver's door B-pillar or the tire pressure label on the inside of the fuel filler flap. If your vehicle has tires of a different size than the size indicated on the Tire and Loading Information placard or the tire pressure label, you should determine the proper tire pressure for those tires.



As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale when one or more of your tires are significantly underinflated. Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly underinflated tire causes the tire to overheat and can lead to tire failure. Underinflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability.

Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if underinflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale.

USA only:

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will be repeated every time the vehicle is started as long as the malfunction exists.

When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of incompatible replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly. Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

1 USA only:

If the tire pressure monitor is malfunctioning, it may take more than 10 minutes for the tire pressure warning lamp to inform you of the malfunction by flashing for 60 seconds and then remaining lit.

When the malfunction has been rectified, the tire pressure warning lamp goes out after driving for a few minutes.

Information on tire pressures is displayed in the multifunction display. After a few minutes of driving, the current tire pressure of each tire is shown in the multifunction display.

- 1 The tire pressure values indicated by the on-board computer may differ from those measured at a gas station with a pressure gauge. The tire pressures shown by the onboard computer refer to those measured at sea level. At high altitudes, the tire pressure values indicated by a pressure gauge are higher than those shown by the on-board computer. In this case, do not reduce the tire pressures.
- 1 The operation of the tire pressure monitor can be affected by interference from radio transmitting equipment (e.g. radio headphones, two-way radios) that may be being operated in or near the vehicle.
- **1** USA only:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

1 Canada only:

This device complies with the RSS-210 of Industry Canada. Operation is subject to the following two conditions:



- 1. This device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

Checking tire pressure electronically

- ▶ Make sure that the SmartKey is in position **2** (⊳ page 303) in the ignition lock.
- ▶ Press the ◀ or ▶ button on the steering wheel to select the Service
- ▶ Press the 🛕 or 🔻 button to select Tire Pressure.
- ▶ Press the OK button. The current tire pressure for each wheel will be displayed in the multifunction display.

If the vehicle has been parked for longer than 20 minutes, the Tire Pressures Displayed After Driving A Few Minutes message appears in the display.

After a teach-in period, the tire pressure monitor automatically recognizes new wheels or new sensors. If a clear allocation of the tire pressure values to the individual wheels is not possible, the Tire Pressure Monitor Active message is shown instead of the tire pressure display. The tire pressures are already being monitored.

1 If a spare wheel/emergency spare wheel is mounted, the system may continue to show the tire pressure of the wheel that has been removed for a few minutes. If this occurs, note that the value displayed for the position where the spare tire is mounted is not the same as the spare wheel/emergency spare wheel's current tire pressure.

Tire pressure monitor warning messages

If the tire pressure monitor detects a significant pressure loss on one or more tires. a warning message is shown in the multifunction display. A warning tone also sounds and the tire pressure warning lamp lights up in the instrument cluster.

Each tire that is affected by a significant loss of pressure is highlighted with a color. If the Correct Tire Pressure message appears in the multifunction display:

- ► Check the tire pressure on all four wheels and correct it if necessary.
- If the wheel positions on the vehicle are interchanged, the tire pressures may be displayed for the wrong positions for a short time. This is rectified after a few minutes of driving, and the tire pressures are displayed for the correct positions.

Restarting the tire pressure monitor



↑ WARNING

It is the driver's responsibility to set the tire pressure to the recommended cold tire pressure. Underinflated tires affect the ability to steer or brake the vehicle. You might lose control over the vehicle.

When you restart the tire pressure monitor, all existing warning messages are deleted and the warning lamps go out. The monitor uses the currently set tire pressures as the reference values for monitoring.

The tire pressure monitor must be restarted when you set the tire pressure to a new value (as a result of changed drive or load characteristics, for example). The tire pressure monitor then monitors the new tire pressure values.

the tire Canada only: in most cases, the tire pressure monitor recognizes the new reference values automatically. However,



you can also define reference values manually as described here.

Restart the tire pressure monitor after you have set the tire pressure to the value recommended for the desired driving situation (⊳ page 493). Only correct tire pressures on cold tires. Comply with the recommended tire pressures on the Tire and Loading Information placard on the B-pillar on the driver's side. Additional tire pressure values for driving at high speeds or with heavy loads can be found in the tire pressure table on the inside of the fuel filler flap.

- ▶ Make sure that the tire pressure is correct on all four wheels.
- ▶ Make sure that the SmartKey is in position 2 in the ignition lock.
- ▶ Press the ◀ or ▶ button on the steering wheel to select the Service menu.
- ▶ Press the ▲ or ▼ button to select Tire Pressure.
- ▶ Press the OK button. The multifunction display shows the current tire pressure of the individual tires or the Tire Pressures Displayed After Driving A Few Minutes message.
- ▶ Press the ▼ button. The Use Current Pressures As New Reference Values message appears in the multifunction display.

If you wish to confirm the restart:

► Press the OK button. The Tire Pressure Monitor Restarted message appears in the multifunction display.

After driving for a few minutes, the system checks whether the current tire pressures are within the specified range. The new tire pressures are then accepted as reference values and monitored.

If you wish to cancel the restart:

▶ Press the 🛨 button.

The tire pressure values stored at the last restart will continue to be monitored.

Loading the vehicle

Instruction labels for tires and loads

↑ WARNING

Do not overload the tires by exceeding the specified load limit as indicated on the Tire and Loading Information placard on the driver's door B-pillar. Overloading the tires can overheat them, possibly causing a blowout. Overloading the tires can also result in handling or steering problems, or brake failure.

Two instruction labels on your vehicle show the maximum possible load.

- (1) The Tire and Loading Information placard on the B-pillar on the driver's side. The Tire and Loading Information placard shows the maximum permissible number of occupants and the maximum permissible vehicle load. It also contains details of the tire sizes and corresponding pressures for tires mounted at the factory.
- (2) The vehicle identification plate is on the B-pillar on the driver's side. The vehicle identification plate informs you of the gross vehicle weight rating. It is made up of the vehicle weight, all vehicle occupants, the fuel and the cargo. You can also find information about the maximum gross axle weight rating on the front and rear axle.

The maximum gross axle weight rating is the maximum weight that can be carried by one axle (front or rear axle). Never exceed the maximum load or the maximum gross axle weight rating for the front or rear axle.





① B-pillar, driver's side

Maximum permissible gross vehicle weight rating

i) The specifications shown on the Tire and Loading Information placard in the illustration are examples. The maximum permissible gross vehicle weight rating is vehicle-specific and may differ from that in the illustration. You can find the valid maximum permissible gross vehicle weight rating for your vehicle on the Tire and Loading Information placard.

	TIRE (RENSEIGNEMENT	RMATION ET LE CHARGEMENT	
W.	SEATING CAPACITY NOMBRE DE SIÈGES	OT . 7 FRONT 2	MIDDLE 3 REAR MILIEU 3 ARRIÈRE 2
	weight of occupants and des occupants et des march		I XXXX kg or XXXX lbs.* passer XXXX kg ou XXXX lb.*
TIRE PNEU	SIZE TAILLE	COLD TIRE PRESSURE PRESSION DES PNEUS À FROID	SEE OWNERS MANUAL FOR ADDITIONAL INFORMATIONS
FRONT AVANT	255/40 ZR18 99YXL	200 KPA, 29 PSI	
REAR ARRIÈRE	285/35 ZR18 101YXL	200 KPA, 29 PSI	
SPARE	175/55-18 95P	420 KPA, 60 PSI	


P40.00-2131-31

► The Tire and Loading Information placard gives you details on maximum permissible gross vehicle weight rating ①: "The gross weight of occupants and luggage must never exceed XXX kilograms or XXX pounds."

The gross weight of all vehicle occupants, cargo, luggage and trailer load/noseweight (if applicable) must not exceed the specified value.

Number of seats

1 The specifications shown on the Tire and Loading Information placard in the illustration are examples. The number of seats is vehicle-specific and can differ from the details shown. The number of seats in your vehicle can be found on the Tire and Loading Information placard.



P40.00-2132-31

Maximum number of seats ① determines the maximum number of occupants allowed to travel in the vehicle. This information can be found on the Tire and Loading Information placard.

Determining the correct load limit

Step-by-step instructions

The following steps have been developed as required of all manufacturers under Title 49, Code of U.S. Federal Regulations, Part 575 pursuant to the "National Traffic and Motor Vehicle Safety Act of 1966".

- ➤ Step 1: Locate the statement "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs." on your vehicle's Tire and Loading Information placard.
- ► Step 2: Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- ► Step 3: Subtract the combined weight of the driver and passengers from XXX kilograms or XXX lbs.



- ▶ Step 4: The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the "XXX" amount equals 1400 lbs and there will be five 150 lbs passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs (1400 750 (5 x 150) = 650 lbs).
- ▶ Step 5: Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in step 4.
- ▶ Step 6 (if applicable): If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle (▷ page 504).



Example: step 1 to 3

The following table shows examples on how to calculate total and cargo load capacities with varying seating configurations and number and size of occupants. The following examples use a load limit of 1500 lbs. **This is for illustration purposes only.** Make sure you are using the actual load limit for your vehicle stated on the vehicle's Tire and Loading Information placard (\triangleright page 501).

		Example 1	Example 2	Example 3
Step 1	Combined maximum weight of occupants and cargo (data from the Tire and Loading Information placard)	1500 lbs (680 kg)	1500 lbs (680 kg)	1500 lbs (680 kg)

		Example 1	Example 2	Example 3
Step 2	Number of people in the vehicle (driver and occupants)	5	3	1
	Distribution of the occupants	Front: 2 Rear: 3	Front: 1 Rear: 2	Front: 1
	Weight of the occupants	Occupant 1: 150 lbs (68 kg) Occupant 2: 180 lbs (82 kg) Occupant 3: 160 lbs (73 kg) Occupant 4: 140 lbs (63 kg) Occupant 5: 120 lbs (54 kg)	Occupant 1: 200 lbs (91 kg) Occupant 2: 190 lbs (86 kg) Occupant 3: 150 lbs (68 kg)	Occupant 1: 150 lbs (68 kg)
	Gross weight of all occupants	750 lbs (340 kg)	540 lbs (245 kg)	150 lbs (68 kg)



		Example 1	Example 2	Example 3
Step 3	Permissible cargo and trailer load/ noseweight (maximum gross vehicle weight rating from the Tire and Loading Information placard minus the gross weight of all occupants)	1500 lbs (680 kg) - 750 lbs (340 kg) = 750 lbs (340 kg)	1500 lbs (680 kg) - 540 lbs (245 kg) = 960 lbs (435 kg)	1500 lbs (680 kg) - 150 lbs (68 kg) = 1350 lbs (612 kg)

The higher the weight of all the occupants, the smaller the maximum load for luggage. Further information can be found under "Towing a trailer" (> page 504).

Vehicle identification plate

Even if you have calculated the total load carefully, you should still make sure that the gross vehicle weight rating and the gross axle weight rating are not exceeded. Details can be found on the vehicle identification plate on the B-pillar on the driver's side (> page 500).

Gross vehicle weight: the gross weight of the vehicle, all passengers, cargo and trailer load/noseweight (if applicable) must not exceed the permissible gross vehicle weight.

Gross axle weight rating: the maximum permissible load that can be carried by one axle (front or rear axle).

To ensure that your vehicle does not exceed the maximum permissible values (gross vehicle weight and maximum gross axle weight rating), have your loaded vehicle (including driver, occupants, cargo, and full trailer load if applicable) weighed on a suitable vehicle weighbridge.

Trailer load/noseweight

The trailer load/noseweight affects the gross weight of the vehicle. If a trailer is attached, the trailer load/noseweight is included in the load along with occupants and luggage. The trailer load/noseweight is usually

approximately 10% of the gross weight of the trailer and its load.

Your Mercedes-Benz has been designed primarily to carry passengers and their luggage. Mercedes-Benz does not recommend towing a trailer with your vehicle.

Maximum load rating

Λ

Do not overload the tires by exceeding the specified load limit as indicated on the Tire and Loading Information placard on the driver's door B-pillar. Overloading the tires can overheat them, possibly causing a blowout. Overloading the tires can also result in handling or steering problems, or brake failure.




1 The actual values for tires are specific to each vehicle and may deviate from the values in the illustration.

Maximum tire load ① is the maximum permitted weight for which the tire is approved.

Further information on tire loads (⊳ page 506).

Uniform Tire Quality Grading Standards

Overview of Tire Quality Grading Standards



The Uniform Tire Quality Grading is a U.S. Government requirement. Their purpose is to provide drivers with consistent and reliable information regarding tire performance. Tire manufacturers are required to grade tires using three performance factors: tread wear ①, tire traction ②, and temperature resistance ③. Although not a Government of Canada requirement, all tires made for sale in

North America have these grades branded on the sidewall.

The actual values for tires are vehiclespecific and may deviate from the values in the illustration.

Where applicable, the tire grading information can be found on the tire sidewall between the tread shoulder and maximum tire width.

For example:

Tread wear	Traction	Temperature
200	AA	А

All passenger car tires must conform to the statutory safety requirements in addition to these grades.

Tread wear

The tread wear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified U.S. government course. For example, a tire graded 150 would wear one and one-half times as well on the government course as a tire graded 100.

The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm, due to variations in driving habits, service practices and differences in road characteristics and climate conditions.

Traction

↑ WARNING

The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

The traction grades, from highest to lowest, are AA, A, B, and C. Those grades represent



the tire's ability to stop on a wet surface as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.

↑ WARNING

If ice has formed on the road, tire traction will be substantially reduced. Under such weather conditions, drive, steer and brake with extreme caution.

The safe speed on a wet, snow covered or icy road is always lower than on dry road surfaces.

You should pay special attention to road conditions when temperatures are around the freezing point.

Mercedes-Benz recommends a minimum tire tread depth of ¹/₆ in (4 mm) for all four winter tires (> page 492) to maintain normal driving characteristics in winter. Winter tires can reduce the braking distance on snow covered surfaces in comparison to summer tires. Stopping distance, however, is still considerably greater than when the road is not covered with ice or snow. Take appropriate care when driving.

Avoid wheelspin. This can lead to damage to the drive train.

Temperature

♠ WARNING

The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause excessive heat build-up and possible tire failure.


The temperature grades are A (the highest), B, and C. These represent the tire's resistance to the generation of heat and its ability to dissipate heat when tested under

controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

Tire labeling

Tire labeling overview

The following markings are on the tire in addition to the tire name (sales designation) and the manufacturer's name:




- 1) Uniform tire Quality Grading Standard (⊳ page 511)
- (2) DOT, Tire Identification Number (⊳ page 509)
- (3) Maximum tire load (▷ page 504)
- (4) Maximum tire pressure (▷ page 496)
- Manufacturer
- (6) Tire material (▷ page 510)



- 7 Tire size designation, load-bearing capacity and speed rating (⊳ page 507)
- (9) Tire name
- Tire data is vehicle-specific and may deviate from the data in the example.

Tire size designation, load-bearing capacity and speed rating



- 1 Tire width
- ② Nominal aspect ratio in %
- ③ Tire code
- (4) Rim diameter
- (5) Load bearing index
- Speed rating
- Tire data is vehicle-specific and may deviate from the data in the example.

General: depending on the manufacturer's standards, the size imprinted in the tire wall may not contain any letters or may contain one letter that precedes the size description.

If there is no letter preceding the size description (as shown above): these are passenger vehicle tires according to European manufacturing standards.

If "P" precedes the size description: these are passenger vehicle tires according to U.S. manufacturing standards.

If "LT" precedes the size description: these are light truck tires according to U.S. manufacturing standards.

If "T" precedes the size description: these are compact emergency spare wheels at high tire pressure, to be used only temporarily in an emergency.

Tire width: tire width (1) shows the nominal tire width in millimeters.

Nominal aspect ratio: aspect ratio (2) is the size ratio between the tire height and the tire width and is shown in percent. The aspect ratio is calculated by dividing the tire width by the tire height.

Tire code: tire code (3) specifies the tire type. "R" represents radial tires. "D" represents diagonal tires, "B" represents diagonal radial tires.

Optionally, tires with a maximum speed of over 149 mph(240 km/h) may have "ZR" in the size description depending on the manufacturer (e.g. 245/40 ZR 18).

Rim diameter: rim diameter (4) is the diameter of the bead seat, not the diameter of the rim flange. The rim diameter is specified in inches (in).

Load bearing index: load bearing index (5) is a numerical code which specifies the maximum load-bearing capacity of a tire.



↑ WARNING

The tire load rating must always be at least half of the GAWR of your vehicle. Otherwise, sudden tire failure may be the result which could cause an accident and/or serious injury to you or others.

Always replace rims and tires with rims and tires having the same specifications (designation, manufacturer and type) as shown on the original part.



↑ WARNING

Do not overload the tires by exceeding the specified load limit as indicated on the Tire and Loading Information placard on the driver's door B-pillar. Overloading the tires can overheat them, possibly causing a blowout. Overloading the tires can also result



in handling or steering problems, or brake failure.

Example:

The load bearing index 91 is equivalent to a maximum load of 1356 lbs (615 kg) that the tire can carry. For further information on the maximum tire load in kilograms and pounds, see (⊳ page 504).

For further information on the load bearing index, see Load index (⊳ page 509).

Speed rating: speed rating (6) specifies the approved maximum speed of the tire.

/ WARNING

Even when permitted by law, never operate a vehicle at speeds greater than the maximum speed rating of the tires.

Exceeding the maximum speed for which tires are rated can lead to sudden tire failure, causing loss of vehicle control and possibly resulting in an accident and/or serious personal injury and possible death, for you and for others.

Regardless of the speed rating always observe the speed limits. Drive carefully and adapt your driving style to the traffic conditions.

Summer tires

Index	Speed rating
Q	Up to 100 mph (160 km/h)
R	Up to 106 mph (170 km/h)
S	Up to 112 mph (180 km/h)
T	Up to 118 mph (190 km/h)
Н	Up to 130 mph (210 km/h)
V	Up to 149 mph (240 km/h)
W	Up to 168 mph (270 km/h)
Υ	Up to 186 mph (300 km/h)

Summer tires					
Index Speed rating					
ZRY	Up to 186 mph (300 km/h)				
ZR(Y)	Above 186 mph (300 km/h)				
ZR	Above 149 mph (240 km/h)				

- Optionally, tires with a maximum speed of over 149 mph (240 km/h) may have "ZR" in the size description depending on the manufacturer (e.g. 245/40 ZR 18). The service specifications consist of load bearing index (5) and speed rating (6).
- If the size description of your tire includes "ZR" and there are no service specifications, ask the tire manufacturer in order to find out the maximum speed. If a service specification is available, the maximum speed is limited according to the speed rating in the service specification. Example: 245/40 ZR 18 97 Y. In this example, "97 Y" is the service specification. The letter "Y" represents the speed rating and the maximum speed of the tire is limited to 186 mph (300 km/h).
- Every tire that has a maximum speed above 186 mph (300 km/h) must have "ZR" in the size description and the service specification must be given in brackets. Example: 275/40 ZR 18 (99 Y). The speed rating "(Y)" shows that the maximum speed of the tire is above 186 mph (300 km/h). Ask the tire manufacturer to find out the maximum speed.

All-weather tires and winter tires Index Speed rating Up to 100 mph (160 km/h) $\Omega M + S^{29}$

Up to 118 mph (190 km/h)



T M+S²⁹

All-weather tires and winter tires					
Index Speed rating					
H M+S ²⁹	Up to 130 mph (210 km/h)				
V M+S ²⁹	Up to 149 mph (240 km/h)				

identification offer the driving characteristics of winter tires. Winter tires have, in addition to the M+S identification, the snow flake symbol on the tire sidewall. Tires with this identification fulfill the requirements of the Rubber Manufacturers Association (RMA) and the Rubber Association of Canada (RAC) regarding the tire traction on snow and have been especially developed for driving on snow.

An electronic speed limiter prevents your vehicle from exceeding the following speeds:

- 130 mph (210 km/h):
 - All vehicles (except AMG vehicles)
- 155 mph (250 km/h):
 - S 63 AMG
 - S 65 AMG
- 186 mph (300 km/h):
 - S 63 AMG (Performance Package)
 - S 63 AMG with increased top speed
 - S 65 AMG with increased top speed

The speed rating of tires mounted at the factory may be higher than the maximum speed that the electronic speed limiter permits.

Make sure that your tires have the required speed rating as specified in the "Tires" section (▷ page 514), e.g. if you buy new tires.

Further information about reading tire data can be obtained from any qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.

Load index



1 Tire data is vehicle-specific and may deviate from the data in the example.

In addition to the load bearing index, load index ① may be imprinted after the letters that identify speed index ⑥ (▷ page 507) on the sidewall of the tire.

- If no specification is given: no text (as in the example above), represents a standard load (SL) tire
- XL or Extra Load: represents a reinforced tire
- · Light load: represents a light load tire
- C, D, E: represents a load range that depends on the maximum load that the tire can carry at a certain pressure

DOT, Tire Identification Number (TIN)

U.S. tire regulations prescribe that every manufacturer of new tires or retreader has to imprint a TIN in or on the sidewall of each tire produced.





The TIN is a unique identification number. The TIN enables the tire manufacturers to inform purchasers of recalls and other safety-relevant matters. It makes it possible for the purchaser to easily identify the affected tires. The TIN is made up of manufacturer identification code ②, tire size ③, tire type code ④ and manufacturing date ⑤.

1 Tire data is vehicle-specific and may deviate from the data in the example.

DOT (Department of Transportation): tire symbol ① indicates that the tire complies with the requirements of the U.S. Department of Transportation.

Manufacturer identification code:


manufacturer identification code ② provides details on the tire manufacturer. New tires have a code with two symbols. Retreaded tires have a code with four symbols. Further information about retreaded tires (> page 490).

Tire size: identifier ③ describes the tire size.

Tire type code: tire type code ④ can be used by the manufacturer as a code to describe specific characteristics of the tire.

Date of manufacture: date of manufacture (5) provides information about the age of a tire. The first and second positions represent the week of manufacture, starting with "01" for the first calendar week. Positions three and four represent the year of manufacture. For example, a tire that is marked with "3208", was manufactured in week 32 in 2008.

Tire characteristics



1 Tire data is vehicle-specific and may deviate from the data in the example.

This information describes the tire cord and the number of layers in sidewall ① and under the tread ②.

Definition of terms for tires and loading

Tire ply composition and material used

Describes the number of plies or the number of layers of rubber-coated fabric in the tire tread and sidewall. These are made of steel, nylon, polyester and other materials.

Bar

Metric unit for tire pressure. There are 14.5038 pounds per square inch (psi) to 1 bar; there are 100 kilopascals (kPa) to 1 bar.

DOT (Department of Transportation)

DOT marked tires fulfill the requirements of the United States Department of Transportation.



Normal occupant weight

The number of occupants the vehicle is designed to seat, multiplied by 68 kilograms (150 lbs).

Uniform Tire Quality Grading Standards

A uniform standard to grade the quality of tires with regards to tread quality, tire traction and temperature characteristics. Ratings are determined by tire manufacturers using U.S. government testing procedures. The ratings are molded into the sidewall of the tire.

Recommended tire pressure

The recommended tire pressure applies to the tires mounted at the factory.

The Tire and Loading Information placard contains the recommended tire pressures for cold tires on a fully loaded vehicle and for the maximum permissible vehicle speed.

The tire pressure table contains the recommended tire pressures for cold tires under various operating conditions, i.e. differing load and speed conditions.

Increased vehicle weight due to optional equipment

This is the combined weight of all standard and optional equipment available for the vehicle, regardless of whether it is actually installed on the vehicle or not.

Rim

This is the part of the wheel on which the tire is mounted.

GAWR (Gross Axle Weight Rating)

The GAWR is the maximum permissible axle weight. The actual load on an axle must never exceed the gross axle weight rating. The gross axle weight rating can be found on the vehicle identification plate on the B-pillar on the driver's side.

Speed rating

The speed rating is part of the tire identification. It specifies the speed range for which the tire is approved.

GVW (Gross Vehicle Weight)

The gross vehicle weight comprises the weight of the vehicle including fuel, tools, the spare wheel, accessories installed, occupants, luggage and the drawbar noseweight, if applicable. The gross vehicle weight must not exceed the gross vehicle weight rating GVWR as specified on the vehicle identification plate on the B pillar on the driver's side.

GVWR (Gross Vehicle Weight Rating)

The GVWR is the maximum permissible gross weight of a fully loaded vehicle (the weight of the vehicle including all accessories, occupants, fuel, luggage and the drawbar noseweight, if applicable). The gross vehicle weight rating is specified on the vehicle identification plate on the B-pillar on the driver's side.

Maximum loaded vehicle weight

The maximum weight is the sum of the curb weight of the vehicle, the weight of the accessories, the total load limit and the weight of the optional equipment installed at the factory.



Kilopascal (kPa)

Metric unit for tire pressure. 6.9 kPa is the equivalent of 1 psi. Another unit for tire pressure is bar. There are 100 kilopascals (kPa) to 1 bar.

Load index

In addition to the load bearing index, the load index may also be imprinted on the sidewall of the tire. This specifies the load bearing capacity more precisely.

Curb weight

The weight of a vehicle with standard equipment including the maximum capacity of fuel, oil and coolant. It also includes the airconditioning system and optional equipment if these are installed in the vehicle, but does not include passengers or luggage.

Maximum load rating

The maximum load rating in kilograms or pounds is the maximum weight for which a tire is approved.

Maximum permissible tire pressure

Maximum permissible tire pressure for one tire.

Maximum load on one tire

Maximum load on one tire. This is calculated by dividing the maximum axle load of one axle by two.

PSI (pounds per square inch)

A standard unit of measure for tire pressure.

Aspect ratio

Relationship between tire height and tire width in percent.

Tire pressure

This is pressure inside the tire applying an outward force to each square inch of the tire's surface. The tire pressure is specified in pounds per square inch (psi), in kilopascal (kPa) or in bar. The tire pressure should only be corrected when the tires are cold.

Tire pressure of cold tires

The tires are cold:

- if the vehicle has been parked without direct sunlight on the tires for at least three hours and
- if the vehicle has not been driven more than 1 mile (1.6 km).

Tread

The part of the tire that comes into contact with the road.

Bead

The tire bead ensures that the tire sits securely on the wheel. There are several steel wires in the bead to prevent the tire from coming loose from the wheel rim.

Sidewall

The part of the tire between the tread and the bead.

Weight of optional extras

The combined weight of those optional extras that weigh more than the replaced standard part and more than 2.3 kilograms (5 lbs).



These optional extras, such as highperformance brakes, level control, a roof rack or a high-performance battery, are not included in the curb weight and accessory weight.

TIN (Tire Identification Number)

This is a unique identifier which can be used by a tire manufacturer to identify tires, for example for a product recall, and thus identify the purchasers. The TIN is made up of the manufacturer's identity code, tire size, tire type code and the manufacturing date.

Load bearing index

The load bearing index (also load index) is a code that contains the maximum load bearing capacity of a tire.

Traction

Traction is the result of friction between the tires and the road surface.

Treadwear indicators

Narrow bars (tread wear bars) that are distributed over the tire tread. If the tire tread is level with the bars, the wear limit of $\frac{1}{16}$ in (1.6 mm) has been reached.

Occupant distribution

The distribution of occupants in a vehicle at their designated seating positions.

Total load limit

Rated cargo and luggage load plus 68 kilograms (150 lbs) times the vehicle's designated seating capacity.

Changing a wheel

Flat tire

The "Breakdown assistance" section (⊳ page 473) contains information and notes on how to deal with a flat tire. It also provides instructions on changing a wheel or mounting the spare wheel/emergency spare wheel.

Interchanging the wheels

Rotate front and rear wheels only if the tires are of the same dimension.

If your vehicle is equipped with mixed-size tires (different tire dimensions front vs. rear), tire rotation is not possible.

↑ WARNING

Have the tightening torque checked after changing a wheel. The wheels could come loose if they are not tightened to a torque of 110 lb-ft (150 Nm).

Only use genuine Mercedes-Benz wheel bolts specified for your vehicle's rims.

The wear patterns on the front and rear tires differ, depending on the operating conditions. Rotate the wheels before a clear wear pattern has formed on the tires. Front tires typically wear more on the shoulders and the rear tires. in the center.

If your vehicle's tire configuration allows, you can rotate the wheels according to the intervals in the tire manufacturer's warranty book in your vehicle documents. If this is not available, the tires should then be replaced every 3000 to 6000 miles

(5000 to 10,000 km), or earlier if the tire wear requires this. Do not change the direction of wheel rotation.

Clean the contact surfaces of the wheel and the brake disc thoroughly every time a wheel is interchanged. Check the tire pressures. Information on changing a wheel and mounting the spare wheel (⊳ page 473).



On vehicles equipped with a tire pressure monitor, electronic components are located in the wheel.

Tire-mounting tools should not be used near the valve. This could damage the electronic components.

Always have the tires changed at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.

Direction of rotation

Tires with a specified direction of rotation have additional benefits, e.g. if there is a risk of hydroplaning. You will only gain these benefits if the correct direction of rotation is maintained.

An arrow on the sidewall of the tire indicates its correct direction of rotation.

You may mount a spare wheel/emergency spare wheel against the direction of rotation. Observe the time restriction on use as well as the speed limit specified on the spare wheel/ emergency spare wheel.

Storing wheels

Store wheels that are not being used in a cool, dry and preferably dark place. Protect the tires from oil, grease, gasoline and diesel.

Cleaning the wheels



↑ WARNING

Do not use power washers with circular-jet nozzles (dirt grinders) to clean your vehicle, in particular the tires. You could otherwise damage the tires and cause an accident.

Wheel and tire combinations

Please bear the following in mind

For safety reasons, Mercedes-Benz recommends that you only use Tires and wheels which have been approved by Mercedes-Benz specifically for your vehicle.

These tires have been specially adapted for use with the control systems, such as ABS or ESP®, and are marked as follows:

- MO = Mercedes-Benz Original
- MOE = Mercedes-Benz Original Extended (tires featuring run-flat characteristics)
- MO1 = Mercedes-Benz Original (only certain AMG tires)

Mercedes-Benz Original Extended tires may only be used on wheels that have been specifically approved by Mercedes-Benz.

Only use tires, wheels or accessories tested and approved by Mercedes-Benz. Certain characteristics, e.g. handling, vehicle noise emissions or fuel consumption, may otherwise be adversely affected. In addition, when driving with a load, tire dimension variations could cause the tires to come into contact with the bodywork and axle components. This could result in damage to the tires or the vehicle.

Mercedes-Benz accepts no liability for damage resulting from the use of tires, wheels or accessories other than those tested and approved.

Further information about tires, wheels and approved combinations can be obtained from any authorized Mercedes-Benz Center.

1 The Tire and Load Information placard with the recommended tire pressures is attached to the B-pillar on the driver's side. Further information about driving at high speeds or driving with vehicle loads that are lighter than the maximum vehicle load can be found in the tire pressure table on the inside of the fuel filler flap. Check tire pressures regularly, and only when the tires are cold. Comply with the maintenance recommendations of the tire manufacturer in the vehicle document wallet



For further information on the recommended tire inflation pressure and on tire pressures for specific driving conditions, see (> page 493).

- 1 Notes on the vehicle equipment always equip the vehicle:
 - with tires of the same size on a given axle (left/right)
 - with the same type of tires at a given time (summer tires, winter tires, MOExtended tires)
- 1 On the following pages, you can find information on approved wheel rims and tire sizes for equipping your vehicle with winter tires. Winter tires are not available ex factory as standard equipment or optional extras.

If you want to equip your vehicle with approved winter tires, it may be necessary to obtain wheel rims in the corresponding size, as the size of the approved winter tires may differ from the standard tires. This is dependent on the model and the equipment installed at the factory.

The tires and wheel rims, as well as further information, can be obtained at a qualified specialist workshop, e.g. at an authorized Mercedes-Benz Center.

- ① Overview of abbreviations used in the following tire tables:
 - · BA: both axles
 - FA: front axle
 - · RA: rear axle

In the following table, the wheel/tire combinations are allocated to the vehicle models through variants, e.g. V1, V2 etc.:

V1	S 550 ³⁰
V2	S 350 BlueTEC 4MATIC, S 550 4MATIC ³⁰

V3	S 600
V4	AMG vehicles

1 Not all wheel and tire combinations are available from the factory for all countries.



Tires						
	Summer tires	Alloy wheels	V1	V2	V3	V4
ВА	255/45 R18 99 Y MOExtended ³¹	8.5 J x 18 H2 Wheel offset: 1.69 in (43 mm)	•	•	•	-
FA	255/45 R18 99 Y MOExtended ³¹	8.5 J x 18 H2 Wheel offset: 1.69 in (43 mm)	•	_	•	_
RA	275/45 R18 103 Y MOExtended ^{31, 32}	9.5 J x 18 H2 Wheel offset: 1.69 in (43 mm)				
ВА	255/40 R19 100 Y XL	8.5 J x 19 H2 Wheel offset: 1.69 in (43 mm)	•	•	•	-
FA	255/40 R19 100 Y XL	8.5 J x 19 H2 Wheel offset: 1.69 in (43 mm)	•	-	•	-
RA	275/40 R19 101 Y ³²	9.5 J x 19 H2 Wheel offset: 1.69 in (43 mm)				
FA	255/40 ZR 19 XL	8.5 J x 19 H2 Wheel offset: 1.69 in (43 mm)	-	-	_	•
RA	275/40 ZR 19 XL ³²	9.5 J x 19 H2 Wheel offset: 1.69 in (43 mm)				
ВА	255/35 ZR 20 XL ³²	8.5 J x 20 H2 Wheel offset: 1.69 in (43 mm)	•	•	•	-
FA	255/35 ZR 20 XL	8.5 J x 20 H2 Wheel offset: 1.69 in (43 mm)	•	-	•	•
RA	275/35 ZR 20 XL ³²	9.5 J x 20 H2 Wheel offset: 1.69 in (43 mm)				

	All-weather tires	Alloy wheels	V1	V2	V3	V4
ВА	255/45 R18 99 H M+S	8.5 J x 18 H2 Wheel offset: 1.69 in (43 mm)	•	•	•	-
FA	255/45 R18 99 H M+S	8.5 J x 18 H2 Wheel offset: 1.69 in (43 mm)	•	-	•	-
RA	275/45 R18 103 H M+S ³²	9.5 J x 18 H2 Wheel offset: 1.69 in (43 mm)				

³¹ MOExtended tires (tires with run-flat properties) only in combination with an activated tire pressure monitor.

³² Use of snow chains is not permitted. Observe the notes in the "Snow chains" section.



	All-weather tires	Alloy wheels	V1	V2	V3	V4
ВА	255/40 R19 100 V XL M+S	8.5 J x 19 H2 Wheel offset: 1.69 in (43 mm)	•	•	•	-
FA	255/40 R19 100 V XL M+S	8.5 J x 19 H2 Wheel offset: 1.69 in (43 mm)	•	-	•	-
RA	275/40 R19 101 V M+S ³²	9.5 J x 19 H2 Wheel offset: 1.69 in (43 mm)				

	Winter tires	Alloy wheels	V1	V2	V3	V4
BA	255/45 R18 99 V M+S 🔏 ³³	8.5 J x 18 H2 Wheel offset: 1.69 in (43 mm)	•	•	•	-
ВА	255/40 R19 100 V XL M+S 🛕 ³³	8.5 J x 19 H2 Wheel offset: 1.69 in (43 mm)	•	•	•	•
FA	255/40 R19 100 V XL M+S 🛕	8.5 J x 19 H2 Wheel offset: 1.69 in (43 mm)	-	-	-	•
RA	275/40 R19 105 V XL M+S 🛕 ³²	9.5 J x 19 H2 Wheel offset: 1.69 in (43 mm)				

"Minispare" emergency spare wheel ³²					
Tires	Wheels	V1	V2	V3	V4
T 155/70 R19 113 M Tire pressure: 420 kPa (4.2 bar/ 61 psi)	4.5 B x 19 H2 Wheel offset: 1.38 in (35 mm)	•	•	•	•

1 The specified tire pressure is printed in yellow on the emergency/collapsible spare wheel.

³³ Only fine-link snow chains are permitted.



³² Use of snow chains is not permitted. Observe the notes in the "Snow chains" section.



Useful information	520
Notes on technical data	520
Genuine Mercedes-Benz parts	520
Warranty	521
Identification plates	521
Service products and capacities	522
Vehicle data	530

Useful information

- This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions.
- Please read the information on qualified specialist workshops (> page 31).

Notes on technical data

The data stated here specifically refers to a vehicle with standard equipment. Consult an authorized Mercedes-Benz Center for the data for all vehicle variants and trim levels.

Genuine Mercedes-Benz parts

All Mercedes-Benz Centers maintain a supply of genuine Mercedes-Benz parts for necessary service and repair work. In addition, strategically located parts delivery centers provide for quick and reliable parts service.

There are more than 300,000 different genuine Mercedes-Benz parts available for Mercedes-Benz models.

Genuine Mercedes-Benz parts are subject to strict quality control. Each part has been specially developed, manufactured or selected for Mercedes-Benz vehicles and fine-tuned for them.

Therefore, only genuine Mercedes-Benz parts should be used.

Driving safety may be impaired if nonapproved parts, tires and wheels or safetyrelevant accessories are used.

This could lead to malfunctions in safetyrelevant systems, e.g. the brake system. This could cause you to lose control of your vehicle and cause an accident.

For this reason, Mercedes-Benz recommends that you use genuine Mercedes-Benz parts or parts of equal quality. Only use tires, wheels and accessories that have been specifically approved for your vehicle.

- Air bags and Emergency Tensioning Devices, as well as control units and sensors for these restraint systems may be installed in the following areas of your vehicle:
 - doors
 - door pillars
 - door sills
 - seats
 - dashboard
 - instrument cluster
 - center console

Do not install accessories such as audio systems in these areas. Do not carry out repairs or welding. You could impair the operating efficiency of the restraint systems.

Have aftermarket accessories installed at a qualified specialist workshop. Mercedes-Benz recommends that you use an authorized Mercedes-Benz Center for this purpose.

P Environmental note

Daimler AG also supplies reconditioned major assemblies and parts which are of the same quality as new parts. They are covered by the same Limited Warranty entitlements as new parts.

Always specify the vehicle identification number (VIN) (▷ page 521) and the engine



number (⊳ page 522) when ordering genuine Mercedes-Benz parts.

Warranty

The Service and Warranty Information booklet contains detailed information about the warranties covering your vehicle.

Your authorized Mercedes-Benz Center will exchange or repair any defective parts originally installed in the vehicle in accordance with the terms of the following warranties:

- New Vehicle Limited Warranty
- Emission System Warranty
- Emission Performance Warranty
- California, Connecticut, Maine, Massachusetts, New York, Pennsylvania, Rhode Island and Vermont Emission Control Systems Warranty
- State Warranty Enforcement Laws (Lemon Laws)

Replacement parts and accessories are covered by the Mercedes-Benz Parts and Accessories warranties. You can obtain information about this from any authorized Mercedes-Benz Center.

Should you lose your Service and Warranty Information booklet, have an authorized Mercedes-Benz Center arrange for a replacement. It will be mailed to you.

Identification plates

Vehicle identification plate with vehicle identification number (VIN) and paint code number



➤ Open the driver's door.
You will see vehicle identification plate ①.



Example: vehicle identification plate (USA only)

- ② VIN
- 3 Paint code



Example: vehicle identification plate (Canada only)

- VIN
- (3) Paint code



1 The data shown on the identification plate is example data. This data is different for every vehicle and can deviate from the data shown here. You can find the data applicable to your vehicle on the vehicle's identification plate.

Vehicle identification number (VIN)

The vehicle identification number (VIN) can be found in the following locations:


- on the vehicle identification plate (⊳ page 521)
- at the lower edge of the windshield (⊳ page 522)

In addition to being stamped on the vehicle identification plate, the vehicle identification number (VIN) is also stamped onto the vehicle body. It is under the trim behind the rear seat armrest.



- ▶ Fold down the rear seat armrest.
- ▶ Open the trim. You will see vehicle identification number (VIN) (1).

Engine number



- Emission control information plate, including the certification of both federal and Californian emissions standards
- (2) Engine number (stamped into the crankcase)
- (3) VIN (on the lower edge of the windshield)

Service products and capacities

Important safety notes

Service products include the following:

- fuels (e.g. gasoline, diesel)
- · additives for exhaust gas aftertreatment (DEF)
- lubricants (e.g. engine oil, transmission oil)
- coolant
- · brake fluid
- · windshield washer fluid

Vehicle components and their respective lubricants must match. You should therefore only use products that have been tested and approved by Mercedes-Benz.

Information on tested and approved products can be obtained at a Mercedes-Benz Center or on the Internet at http:// www.mbusa.com (USA only).

↑ WARNING

Comply with all valid regulations with respect to handling, storing and disposing of service fluids. Otherwise, you could endanger persons or the environment.



Keep service fluids out of the reach of children.

For health reasons, you should prevent service fluids from coming into direct contact with your skin or clothing.

If a service fluid is swallowed, contact a physician immediately.



Capacities			
	Model	Capacity	Fuel, coolant, lubricants, etc.
Engine oil and filter	S 550 ³⁴ S 550 4MATIC ³⁴ S 63 AMG	9.0 US qt (8.5 I)	Approved engine oils
	S 600 S 65 AMG	9.5 US qt (9.0 I)	
	S 350 BlueTEC 4MATIC	8.5 US qt (8.0 I)	
Cooling system	S 550 ³⁴ S 550 4MATIC ³⁴	Approximately 14.5 US qt (13.7 I)	MB 325.0 or MB 326.0 anticorrosion/ antifreeze
	S 600	Approximately 15.3 US qt (14.5 I)	
	S 63 AMG	Approximately 12.2 US qt (11.5 l)	
	S 65 AMG	Approximately 14.7 US qt (13.9 l)	
	S 350 BlueTEC 4MATIC	Approximately 12.0 US qt (11.4 l)	
Tank capacity	S 550 ³⁴ S 550 4MATIC ³⁴ S 350 BlueTEC 4MATIC	21.9 US gal (83.0 l)	Gasoline engines: premium-grade unleaded gasoline (at least 91 octane, average value
	S 600 S 63 AMG S 65 AMG	23.8 US gal (90.0 I)	between 96 RON/ 86 MON) Diesel engines: ULTRA-LOW
Reserve	All models except AMG vehicles	2.9 US gal (11.0 l)	SULFUR HIGHWAY DIESEL FUEL (ULSD,
	AMG vehicles	3.7 US gal (14.0 l)	maximum sulfur content 15 ppm)



	Model	Capacity	Fuel, coolant, lubricants, etc.
DEF tank	S 350 BlueTEC 4MATIC	6.6 US gal (25.0 I)	DEF in accordance with ISO 22241
Windshield/ headlamp cleaning system	All models	6.9 US qt (6.5 I)	MB windshield washer concentrate ³⁵ (▷ page 529) Mixing ratio for washer fluid (▷ page 529)

Fuel

Important safety notes



♠ WARNING

Gasoline and diesel fuels are highly flammable and poisonous. They burn violently and can cause serious injury.

Never allow sparks, flames or smoking materials near gasoline or diesel fuel! Turn off the engine before refueling.

Whenever you are around gasoline or diesel fuel, avoid inhaling fumes and any skin or clothing contact. Extinguish all smoking materials.

Direct skin contact with fuels and the inhalation of fuel vapors are damaging your health.

Premium-grade unleaded gasoline

- I To ensure the longevity and full performance of the engine, only premiumgrade unleaded gasoline may be used. If there is no premium-grade unleaded gasoline available and regular-grade unleaded gasoline may be used; please observe the following precautions:
 - only fill the fuel tank to half full with regular-grade unleaded gasoline and fill

the rest with premium-grade unleaded gasoline as soon as possible.

- do not drive at the maximum speed.
- avoid sudden acceleration.
- if the vehicle is carrying a light load, e.g. two passengers without luggage, do not allow the engine to rev above 3,000 rpm.
- if the vehicle is fully loaded or is being operated in mountainous terrain, do not depress the accelerator pedal further than $\frac{2}{3}$ of the pedal travel.

Fuel requirements

Gasoline engines

Use only premium-grade unleaded gasoline. The octane number should be at least 91. Details can be found on the gas pump. The octane number is the average value of the Research Octane Number (RON) and the Motor Octane Number (MON): (RON + MON) / 2, also known as knock resistance. Reformulated Gasoline (RFG) and/or unleaded gasoline with additives can be used if the concentration of the additives in the fuel does not exceed 10%, e.g.:

- Ethanol
- TAMF
- ETBE

³⁵ Mixed with water or premixed washer fluid with antifreeze protection.



- IPA
- TBA

For MTBE, the concentration should not exceed 15%.

The concentration of methanol in gasoline including other additives must not exceed 3%. Using mixtures of methanol and ethanol is not permitted. Gasohol, a mixture of 10% ethanol and 90% unleaded gasoline, can be used.

All of these mix fuels must fulfill the fuel requirements, e.g.:

- · knock resistance
- · boiling point
- vapor pressure

Diesel engines - important safety notes

- Only use commercially available ULTRA-LOW SULFUR DIESEL FUEL (ULSD, 15 ppm MAXIMUM SULFUR) that meets the ASTM D975 standard. Failure to use ULTRA-LOW SULFUR DIESEL FUEL (ULSD) can severely damage the vehicle's exhaust gas aftertreatment system.
- Do not fill the tank with gasoline. Do not blend diesel fuel with gasoline or kerosene. Otherwise, the fuel system and the engine could be damaged.

To prevent malfunctions, diesel fuel with improved flow characteristics is available in the winter months. Check with your gas station.

Information on the fuel grade can usually be found on the gas pump. If the information cannot be found on the gas pump, ask the gas station personnel. For further information, consult an authorized Mercedes-Benz Center or go to the Internet site http://www.mbusa.com (USA only).

Diesel engines – fuels containing biodiesel (FAME [fatty acid methyl ester])

Mercedes-Benz USA approves the use of B5 (ULSD with a maximum of up to five percent by volume biodiesel) for all diesel engines

with common rail direct injection (CDI) and BlueTEC.

Pure biodiesel and diesel fuels that have a higher percentage of biodiesel, e.g. B20, can damage the fuel system and the engine and are therefore not approved.

For further information, please ask the gas station personnel. The label on the gas pump must indicate clearly that the B5 biodiesel blend fulfills the ULSD standard. If the label is not clear, do not refuel the vehicle.

Do not refuel your vehicle with fuels unless they have been approved by Mercedes-Benz.

Additives in gasoline

One of the main problems of poor fuel quality is the forming of deposits that are caused during the gasoline combustion process.

Mercedes-Benz recommends that you use fuel brands that have the additives.

If you use fuels without these additives for an extended period of time, there may be a buildup of carbon deposits, especially on the inlet valves and in the combustion chamber.

This could lead to engine problems, e.g.:

- longer engine warm-up phase
- uneven idle
- engine noise
- misfiring
- loss of power

Carbon deposits may form if the availability of gasoline with relevant additives is insufficient (in certain regions). In this case, Mercedes-Benz recommends the use of additives that have been approved for Mercedes-Benz vehicles.

Consult an authorized Mercedes-Benz Center or go to the Internet site

http://www.mbusa.com (USA only) for a list of approved products. Observe the instructions for use on the product label.

Do not mix other fuel additives with fuel. This causes unnecessary costs and could damage the engine.



■ Do not refuel with low-grade fuel and do not use fuel additives that are not tested and approved for Mercedes-Benz vehicles. Damage to or malfunctions of the fuel system may otherwise occur.

DEF

Important safety notes

for BlueTEC vehicles only.

DEF is a non-flammable, non-toxic, colorless, odorless and water-soluble fluid.

Rinse surfaces that have come into contact with DEF immediately with water or remove DEF using a damp cloth and cold water. If the DEF has already crystallized, use a sponge and cold water to clean it. DEF residues crystallize after time and contaminate the affected surfaces.

High outside temperatures

If DEF heats up to over 122 °F (50 °C) for extended periods, e.g. as a result of direct sunlight on the DEF reservoir, DEF can decompose. Ammonia vapors develop as a result.

↑ WARNING

When opening the filler cap of the DEF tank ammonia gas vapors may escape. Refill DEF in a well ventilated area only. Ammonia gas vapors have a pungent odor and are particularly irritating for your skin, mucous membranes, and eyes. Inhaling ammonia gas vapors will cause burning eyes, nose, and throat, as well as coughing and watering eyes.

Low outside temperatures

DEF freezes at a temperature of approximately 12 °F (-11 °C). The vehicle is equipped with a DEF preheating system when it leaves the factory. Winter operation is therefore also guaranteed at temperatures below 12 °F (-11 °C).

Additives

Only use DEF in accordance with ISO 22241. Do not use additives with DEF and do not dilute DEF with water. This may destroy the BlueTEC exhaust gas aftertreatment system.

Purity

Assuring the purity of DEF is particularly important with respect to avoiding malfunctions in the exhaust gas aftertreatment system.

If DEF is pumped out of the DEF tank, e.g. during repair work, it must not be returned to the tank. The purity of the fluid can no longer be guaranteed.

- Impurities in DEF (e.g. due to other service products, cleaning agents or dust) lead to:
 - increased emission values
 - damage to the catalytic converter
 - engine damage
 - malfunctions in the BlueTEC exhaust gas aftertreatment system

Engine oil

Please bear the following in mind

The engine oils are matched to the performance of Mercedes-Benz engines and service intervals. You should therefore only use engine oils and oil filters that are approved for vehicles with maintenance systems.

For a list of approved engine oils and oil filters, consult an authorized Mercedes-Benz Center or go to the Internet site http://www.mbusa.com (USA only).

Never use engine oil or an oil filter of a specification other than is necessary to fulfill the prescribed service intervals. Do not change the engine oil or oil filter in order to achieve longer replacement



intervals than those prescribed. You could otherwise cause engine damage or damage to the exhaust gas aftertreatment.

Follow the instructions in the service interval display regarding the oil change. Otherwise, you may damage the engine and the exhaust gas aftertreatment.

The table shows which engine oils have been approved for your vehicle.

Model	Engine model	MB Approval
S 550 ³⁶ S 550 4MATIC ³⁶	278	229.5
S 600	275	
S 63 AMG	157	229.5 ³⁷
S 65 AMG	275	
S 350 BlueTEC 4MATIC	642	228.51, 229.31, 229.51

MB approval is indicated on the oil containers.


Additives

Do not use any additives in the engine oil. This could damage the engine.

Engine oil viscosity

Viscosity describes the flow characteristics of a fluid. If an engine oil has a high viscosity, this means that it is thick; a low viscosity means that it is thin.

Select an engine oil with an SAE (viscosity) classification suitable for the prevailing outside temperatures. The following table shows the correct SAE classification to be used. The low-temperature characteristics of engine oils can deteriorate significantly, e.g. as a result of aging, soot and fuel deposits. It is therefore strongly recommended that you carry out regular oil changes using an approved engine oil with the appropriate SAE classification.



Refrigerant of the air-conditioning system

The air-conditioning system is filled with R134a refrigerant and a special PAG lubricant

Never use refrigerant R 12 (CFC) or mineral lubricants. Otherwise, you could damage the air-conditioning system.

Brake fluid



↑ WARNING

Over a period of time, the brake fluid absorbs moisture from the air; this lowers its boiling point.

If the boiling point of the brake fluid is too low, vapor pockets may form in the brake system when the brakes are applied hard (e.g. when driving downhill). This would impair braking efficiency.

You should have the brake fluid renewed at regular intervals. The brake fluid change intervals can be found in the Service Booklet.

Only use brake fluid approved by Mercedes-Benz. Information about approved brake

³⁷ Restriction: only SAE 0W-40 or SAE 5W-40 engine oils may be used.



³⁶ BlueEFFICIENCY

fluids can be obtained from any authorized Mercedes-Benz Center or on the Internet at http://bevo.mercedes-benz.com.

Coolant

Important safety notes

The coolant is a mixture of water and antifreeze/corrosion inhibitor. It performs the following tasks:

- corrosion protection
- · antifreeze protection
- raising the boiling point

The engine cooling system is filled at the factory with coolant that contains an antifreeze/corrosion inhibitor that ensures protection down to approximately -35 °F (-37 °C).

- I Only add coolant that has been premixed with the desired antifreeze protection. Otherwise, the engine could be damaged. Further information on coolants and on filling can be found in the Mercedes-Benz Specifications for Service Products, MB Approval 310.1, e.g. on the Internet at http://bevo.mercedes-benz.com. You can also consult an authorized Mercedes-Benz Center.
- Always use a suitable coolant mixture, even in countries where high temperatures prevail.

Otherwise, the engine cooling system is not sufficiently protected from corrosion and overheating.

If the coolant has antifreeze protection down to -35 °F (-37 °C), the boiling point of the coolant under operating conditions is approximately 266 °F (130 °C).

Your vehicle has a range of aluminum components. Aluminum components in the engine make it necessary to use antifreeze/ corrosion inhibitor coolant that has been specifically formulated to protect the aluminum parts. Using other antifreeze/

corrosion inhibitors without these characteristics affects the service life.

The coolant must be used throughout the year in order to maintain the necessary corrosion protection and to provide protection from overheating. In the Service Booklet, you can find information on the intervals for renewal.

The renewal interval is determined by the coolant type and the engine cooling system design. The renewal interval in the Service Booklet is only valid if the coolant is renewed or filled up with Mercedes-Benz approved products. Therefore, only use MB 325.0 or 326.0 anticorrosion/antifreeze or another Mercedes-Benz approved product of the same specification.

Information on other products with the same specifications that are approved by Mercedes-Benz can be obtained at an authorized Mercedes-Benz Center or on the Internet at http://bevo.mercedes-benz.com. The coolant is checked at every maintenance interval at an authorized Mercedes-Benz

Center. The antifreeze/corrosion inhibitor concentration in the engine cooling system should:

- be at least 50%. This will protect the engine cooling system against freezing down to approximately -35 °F (-37 °C).
- not exceed 55% (antifreeze protection to -49 °F [-45 °C]); otherwise, heat will not dissipate as effectively.

If the coolant level is too low, MB 325.0 or 326.0 anticorrosion/antifreeze should be added. Have the engine cooling system checked for possible leaks.

Windshield/headlamp cleaning system

↑ WARNING

Washer solvent/antifreeze is highly flammable. Do not spill washer solvent/ antifreeze on hot engine parts, because it may ignite and burn. You could be seriously burned.

Use MB SummerFit windshield washer concentrate at temperatures above freezing:

► Mix 1 part MB SummerFit with 100 parts water.

Use MB WinterFit windshield washer concentrate at temperatures below freezing:

- At temperatures down to 14 °F(- 10 °C): mix 1 part MB WinterFit with 2 parts water.
- ► At temperatures down to 4 °F(- 20 °C): mix 1 part MB WinterFit with 1 part water.
- ► At temperatures down to 20.2 °F(- 29 °C): mix 2 parts MB WinterFit with 1 part water.
- Only SummerFit and WinterFit can be mixed. Otherwise, the jets could become blocked.

Vehicle data

For the specified vehicle data, please note that:

- The heights specified may vary due to:
 - tires
 - load
 - condition of the suspension
 - optional equipment

All models		
Vehicle length	206.7 in (5250 mm)	
Vehicle width including exterior mirrors	83.5 in (2120 mm)	
Vehicle height	58.2 in (1479 mm)	
Wheelbase	124.6 in (3165 mm)	
Front track	63.0 in (1600 mm)	
Rear track	63.2 in (1606 mm)	

All models	
Turning circle	40.0 ft (12.20 m)
Maximum roof load	Maximum 220 lb (100 kg)
Maximum trunk load	Maximum 220 lb (100 kg)

S 550 4MATIC BlueEFFICIENCY		
Short wheelbase		
Vehicle length 200.8 in (5100 mm)		
Wheelbase 119.5 in (3035 mm		
Turning circle	38.7 ft (11.80 m)	
Long wheelbase		
Vehicle length	206.7 in (5250 mm)	
Wheelbase	124.6 in (3165 mm)	
Turning circle 40.0 ft (12.20 m)		

S 63 AMG S 65 AMG	
Vehicle length	206.8 in (5252 mm)
Vehicle height	58.7 in (1490 mm)
Turning circle	40.1 ft (12.22 m)







Publication details

Internet

Further information about Mercedes-Benz vehicles and about Daimler AG can be found on the following websites:

http://www.mbusa.com (USA only) http://www.mercedes-benz.ca (Canada only)

Editorial office

Not to be reprinted, translated or otherwise reproduced, in whole or in part, without the written permission of Daimler AG.



Order no. 6515 2369 13 Part no. 221 584 24 82 Edition A 2012

