

SLK Operator's Manual





Order no. 6515 3314 13 Part no. 172 584 23 81 Edition B 2012

SLK Operator's Manual

Symbols

Registered trademarks:

- Bluetooth[®] is a registered trademark of Bluetooth SIG Inc.
- DTS is a registered trademark of DTS, Inc.
- Dolby and MLP are registered trademarks of DOLBY Laboratories.
- BabySmart[™], ESP[®] and PRE-SAFE[®] are registered trademarks of Daimler AG.
- HomeLink[®] is a registered trademark of Prince.
- iPod[®] and iTunes[®] are registered trademarks of Apple Inc.
- Logic 7[®] is a registered trademark of Harman International Industries.
- Microsoft[®] and Windows media[®] are registered trademarks of Microsoft Corporation.
- SIRIUS is a registered trademark of Sirius XM radio Inc.
- HD Radio is a registered trademark of iBiquity Digital Corporation.
- Gracenote[®] is a registered trademark of Gracenote, Inc.
- ZAGATSurvey[®] and related brands are registered trademarks of ZagatSurvey, LLC.

In this Operator's Manual, you will find the following symbols:

Warning notes draw your attention to hazards that endanger your health or life, or the health or life of others.

- Notes on material damage alert you to dangers that could lead to damage to your vehicle.
- 1 This symbol indicates useful instructions or further information that could be helpful to you.

This symbol designates an instruction you must follow.

►

- Several consecutive symbols indicate an instruction with several steps.
- (▷ page) This symbol tells you where you can find further information on a topic.
- ▷▷ This symbol indicates a warning or an instruction that is continued on the next page.
- Display This font indicates a display message in the multifunction display/COMAND display.

Parts of the software in the vehicle are protected by copyright [©] 2005 The FreeType Project http://www.freetype.org. All rights reserved.

Publication details

Internet

Further information about Mercedes-Benz vehicles and about Daimler AG can be found on the following websites:

http://www.mbusa.com (USA only) http://www.mercedes-benz.ca (Canada only)

Editorial office

Not to be reprinted, translated or otherwise reproduced, in whole or in part, without the written permission of Daimler AG.

As at 07.09.2011

Welcome to the world of Mercedes-Benz

Before you drive off, please familiarize yourself with your vehicle and read this manual, especially the safety and warning notes. This will help you to obtain the maximum pleasure from your vehicle and avoid endangering yourself and others.

The equipment or model designation of your vehicle may differ according to:

- model
- order
- country variant
- availability

Mercedes-Benz is constantly updating its vehicles to the state of the art.

Mercedes-Benz therefore reserves the right to introduce changes in the following areas:

- design
- equipment
- technical features

The equipment in your vehicle may therefore differ from that shown in the descriptions and illustrations.

The following are integral components of the vehicle:

- Operator's Manual
- Maintenance Booklet
- Equipment-dependent supplements

Keep these documents in the vehicle at all times. If you sell the vehicle, always pass the documents on to the new owner.

The technical documentation team at Daimler AG wishes you safe and pleasant motoring.

Mercedes-Benz USA, LLC

Mercedes-Benz Canada, Inc.

A Daimler Company



Contents

At a glance 25	
Safety 35	
Opening/closing 67	
Seats, steering wheel and mirrors 91	
Lights and windshield wipers 103	
Climate control 115	
Driving and parking 129	
On-board computer and displays 179	
Stowage and features 241	
Maintenance and care 259	
Breakdown assistance 273	
Wheels and tires 293	
Technical data 321	

Index	. 4
Introduction	20

Index

1, 2, 3 ...

12 V s	socket
--------	--------

see Sockets

Α

ABS (Anti-lock Braking System)
Display message 200
Function/notes 56
Important safety notes 56
Warning lamp 230
Activating/deactivating cooling
with air dehumidification 121
Active service system PLUS
see ASSYST PLUS service interval
display
ADAPTIVE BRAKE
Additional speedometer 192
Additives (engine oil) 327
Air bags
Display message 211
Front air bag (driver, front
passenger) 39
Head bag 41
Important safety notes 38
Knee bag 40
PASSENGER AIR BAG OFF
indicator lamp 42
Safety guidelines 37
Side impact air bag 40
Air-conditioning system
see Climate control
AIRGUIDE
Air pressure
see Tire pressure
AIRSCARF
Problem (malfunction) 96
Setting the vents 127
Switching on/off
Air vents
Important safety notes 126
Setting
Setting the AIRSCARF vents
Setting the center air vents 126
Setting the side air vents
Switching AIRSCARF on/off

Alarm system	
see ATA (Anti-Theft Alarm system)	
Alertness Assistant	
see ATTENTION ASSIST	
Ambient lighting (on-board	
computer)	192
AMG menu (on-board computer)	195
Anti-lock Braking System	.,.
see ABS (Anti-lock Braking System)	
Anti-Theft Alarm system	
see ATA (Anti-Theft Alarm system)	
Ashtray	247
Assistance menu (on-board	247
-	190
computer) ATA (Anti-Theft Alarm system)	190
Activating/deactivating	. 65
Function	
Switching off the alarm	. 65
ATTENTION ASSIST	101
Activating/deactivating	191
Display message	219
Function/notes	176
Audio menu (on-board computer)	188
Audio system	
see separate operating instructions	
Authorized Mercedes-Benz Center	
see Qualified specialist workshop	
Authorized workshop	
see Qualified specialist workshop	
AUTO lights	
Display message	216
see Lights	
Automatic engine start (ECO start/	
stop function)	136
Automatic engine switch-off (ECO	
start/stop function)	135
Automatic headlamp mode	106
Automatic transmission	
Automatic drive program	143
Changing gear	141
Display message	224
Driving tips	141
Emergency running mode	146
Kickdown	142
Manual drive program	144
Problem (malfunction)	146
Program selector button	142

Pulling away	134
Releasing the parking lock	
manually	146
Selector lever	140
Shift ranges	143
Starting the engine	133
Steering wheel paddle shifters	142
Transmission position display	140
Transmission positions	141
Automatic transmission	
emergency mode	146

В

Back support
see Lumbar support
Backup lamp
Changing bulbs 112
Display message 215
BAS (Brake Assist System) 57
Basic settings
see Settings
BAS PLUS (Brake Assist System
PLUS)
Battery (SmartKey)
Checking 71
Important safety notes 71
Replacing 71
Battery (vehicle)
Charging
Display message 218
Important safety notes 282
Jump starting
Belt
see Seat belts
Bottle holder 246
Brake Assist System
see BAS (Brake Assist System)
Brake fluid
Display message 206
Notes 327
Brake fluid level 263
Brake lamps
Display message 214
Brakes
ABS 56
BAS 57
BAS PLUS 57

Brake fluid (notes)	327
Display message	200
Driving tips	153
High-performance brake system	154
Important safety notes	153
Maintenance	154
Parking brake	150
Warning lamp	229
Breakdown	
see Flat tire	
see Towing away/tow-starting	
Dulles	

Bulbs

see Changing bulbs

С

California	
Important notice for retail	
customers and lessees	21
Calling up a malfunction	
see Display messages	
Capacities	
see Technical data	
Car	
see Vehicle	
Care	
Carpets 2	71
1	65
	69
	86
	70
Interior 2	69
Matte finish 2	67
Notes 2	65
Paint 2	67
Plastic trim 2	.69
	66
	71
8	270
	270
Sensors 2	.69
	70
8	69
	270
•	66
	266
	.68

Wiper blades	268
Wooden trim	270
Car wash (care)	265
CD player/CD changer (on-board	
computer)	188
Center console	
Lower section	31
Upper section	30
Central locking	
Automatic locking (on-board	
computer)	193
Locking/unlocking (SmartKey)	68
Changing bulbs	
High-beam headlamps	111
Important safety notes	109
Low-beam headlamps	111
Overview of bulb types	110
Parking lamps	112
Removing/replacing the cover	
(front wheel arch)	111
Reversing lamps	112
Standing lamps (front)	112
Turn signals (front)	112
Children	
In the vehicle	53
Restraint systems	53
Child seat	
Special seat belt retractor	55
Cigarette lighter	247
Cleaning	
Mirror turn signal	268
Climate control	
Air-conditioning system	117
Automatic climate control (dual-	
zone)	119
Controlling automatically	122
Cooling with air dehumidification	121
Defrosting the windshield	124
Important safety notes	116
Indicator lamp	122
Maximum cooling	124
Notes on using automatic climate	
control	120
Notes on using the air-	
conditioning system	118
Overview of systems	116
Problems with cooling with air	
-	122

Problem with the rear window	
defroster	125
Setting the air distribution	123
Setting the airflow	123
Setting the air vents	126
Setting the temperature	122
Switching air-recirculation mode	
on/off	125
Switching on/off	121
Switching residual heat on/off	125
Switching the rear window	
defroster on/off	124
Switching the ZONE function on/	
off	123
Cockpit	
Overview	. 26
see Instrument cluster	
Collapsible spare wheel	
Inflating	280
see Emergency spare wheel	
COMAND	
see separate operating instructions	
Combination switch	107
Consumption statistics (on-board	
computer)	185
computer) Convenience closing feature	
Convenience closing feature	
Convenience closing feature Convenience opening feature	
Convenience closing feature Convenience opening feature see Opening/closing the side	
Convenience closing feature Convenience opening feature see Opening/closing the side windows (all)	
Convenience closing feature Convenience opening feature see Opening/closing the side windows (all) Coolant (engine) Checking the level Display message	. 81
Convenience closing feature Convenience opening feature see Opening/closing the side windows (all) Coolant (engine) Checking the level	262
Convenience closing feature Convenience opening feature see Opening/closing the side windows (all) Coolant (engine) Checking the level Display message	. 81 262 216
Convenience closing feature Convenience opening feature see Opening/closing the side windows (all) Coolant (engine) Checking the level Display message Filling capacity Notes Temperature (on-board computer) .	. 81 262 216 328
Convenience closing feature Convenience opening feature see Opening/closing the side windows (all) Coolant (engine) Checking the level Display message Filling capacity Notes Temperature (on-board computer) . Temperature gauge	. 81 262 216 328 327
Convenience closing feature Convenience opening feature see Opening/closing the side windows (all) Coolant (engine) Checking the level Display message Filling capacity Notes Temperature (on-board computer) . Temperature gauge Warning lamp	. 81 262 216 328 327 195
Convenience closing feature Convenience opening feature see Opening/closing the side windows (all) Coolant (engine) Checking the level Display message Filling capacity Notes Temperature (on-board computer) . Temperature gauge	. 81 262 216 328 327 195 181
Convenience closing feature Convenience opening feature see Opening/closing the side windows (all) Coolant (engine) Checking the level Display message Filling capacity Notes Temperature (on-board computer) . Temperature gauge Warning lamp Cooling see Climate control	. 81 262 216 328 327 195 181 235
Convenience closing feature Convenience opening feature see Opening/closing the side windows (all) Coolant (engine) Checking the level Display message Filling capacity Notes Temperature (on-board computer) . Temperature gauge Warning lamp Cooling see Climate control Cornering light (display message)	. 81 262 216 328 327 195 181 235
Convenience closing feature Convenience opening feature see Opening/closing the side windows (all) Coolant (engine) Checking the level Display message Filling capacity Notes Temperature (on-board computer) . Temperature gauge Warning lamp Cooling see Climate control	. 81 262 216 328 327 195 181 235
Convenience closing feature Convenience opening feature see Opening/closing the side windows (all) Coolant (engine) Checking the level Display message Filling capacity Notes Temperature (on-board computer) . Temperature gauge Warning lamp Cooling see Climate control Cornering light (display message) Cornering light function Function/notes	. 81 262 216 328 327 195 181 235
Convenience closing feature Convenience opening feature see Opening/closing the side windows (all) Coolant (engine) Checking the level Display message Filling capacity Notes Temperature (on-board computer) . Temperature gauge Warning lamp Cooling see Climate control Cornering light (display message) Cornering light function	262 216 328 327 195 181 235 213
Convenience closing feature Convenience opening feature see Opening/closing the side windows (all) Coolant (engine) Checking the level Display message Filling capacity Notes Temperature (on-board computer) . Temperature gauge Warning lamp Cooling see Climate control Cornering light (display message) Cornering light function Function/notes Crash-responsive emergency lighting	262 216 328 327 195 181 235 213
Convenience closing feature Convenience opening feature see Opening/closing the side windows (all) Coolant (engine) Checking the level Display message Filling capacity Notes Temperature (on-board computer) . Temperature gauge Warning lamp Cooling see Climate control Cornering light (display message) Cornering light function Function/notes Crash-responsive emergency lighting Cruise control	. 81 262 216 328 327 195 181 235 213 108 109
Convenience closing feature Convenience opening feature see Opening/closing the side windows (all) Coolant (engine) Checking the level Display message Filling capacity Notes Temperature (on-board computer) . Temperature gauge Warning lamp Cooling see Climate control Cornering light (display message) Cornering light function Function/notes Crash-responsive emergency lighting Cruise control lever	. 81 262 216 328 327 195 181 235 213 108 109 156
Convenience closing feature Convenience opening feature see Opening/closing the side windows (all) Coolant (engine) Checking the level Display message Filling capacity Notes Temperature (on-board computer) . Temperature gauge Warning lamp Cooling see Climate control Cornering light (display message) Cornering light function Function/notes Crash-responsive emergency lighting Cruise control	. 81 262 216 328 327 195 181 235 213 108 109

Driving system	
Function/notes	156
Important safety notes	156
Setting a speed	157
Storing and maintaining current	
speed	157
Cup holder	245
Customer Assistance Center (CAC)	. 24
Customer Relations Department	. 24

D

Dashboard	
see Cockpit	
Data	
see Technical data	
Daytime running lamps	
Display message	215
Switching on/off (on-board	
computer)	192
Switching on/off (switch)	105
Dealership	
see Qualified specialist workshop	
Delayed switch-off	
Exterior lighting (on-board	
computer)	193
Interior lighting	193
Diagnostics connection	
Digital speedometer	186
Display (cleaning instructions)	269
Display messages	
Calling up (on-board computer)	199
Driving systems	219
Engine	216
General notes	199
Hiding (on-board computer)	199
KEYLESS-GO	226
Lights	213
Safety systems	200
Service interval display	264
SmartKey	226
Tires	222
Vehicle	224
Distance display (on-board	
computer)	190
Distance recorder	185
see Odometer	
see Trip odometer	

Distance warning (warning lamp) 2 DISTRONIC PLUS	37
Deactivating 1	66
Display message 2	20
Displays in the multifunction	
display 1	65
Driving tips 1	66
	58
Important safety notes 1	58
Setting the specified minimum	
distance 1	64
Warning lamp 2	37
Doors	
Automatic locking (on-board	
computer) 1	93
Automatic locking (switch)	75
Central locking/unlocking	
(SmartKey)	68
Control panel	33
Display message 2	24
Emergency locking	76
Emergency unlocking	76
	74
Opening (from inside)	75
Drinking and driving 1	52
Drinks holder	
see Cup holder	
Drive program	
Automatic 1	43
Display 1	40
	44
SETUP (on-board computer) 1	96
Driver's door	
see Doors	
Driver's seat	
see Seats	
Driving abroad	
Mercedes-Benz Service 2	65
Symmetrical low beam 1	04
Driving lamps	
see Daytime running lamps	
Driving on flooded roads 1	55
Driving safety systems	
	56
ADAPTIVE BRAKE	62
- (57
BAS PLUS (Brake Assist System	

	-

	Electronic brake force distribution ESP [®] (Electronic Stability	62
		58
	Program)	50
	ETS (Electronic Traction System)	- /
	Important safety information	56
	Overview	56
	PRE-SAFE [®] Brake	62
Driv	ving systems	
		176
		156
		219
		158
	Dynamic handling package	168
	HOLD function	168
	Parking Guidance	173
		170
Driv	ving tips	
	Automatic transmission	141
		153
	Break-in period	130
	DISTRONIC PLUS	166
		153
	Drinking and driving	152
		104
		155
	0	155
		155
		153
		152
		152
		155
		155
	Limited braking efficiency on	155
		154
		154
		152 297
		- / .
	5	104
		153
		188
		189
Dyr	namic handling package	
	Function/notes	168

Ε

EASY-ENTRY feature	
Activating/deactivating	94
Function/notes	97
EASY-EXIT feature	
Crash-responsive	98
Function/notes	97
Switching on/off 1	94
EBD (electronic brake force	
distribution)	
Display message 2	202
Function/notes	62
ECO start/stop function	
<u> </u>	36
	35
	35
Electrical fuses	
see Fuses	
Electronic brake force distribution	
see EBD (electronic brake force	
distribution)	
Electronic Stability Program	
see ESP [®] (Electronic Stability Progran	n)
Electronic Traction System	
see ETS (Electronic Traction System)	
Emergency release	
Emergency release Driver's door	76
Emergency release	79
Emergency release Driver's door Trunk Vehicle	
Emergency release Driver's door Trunk Vehicle Emergency spare wheel	79 76
Emergency release Driver's door Trunk Vehicle Emergency spare wheel Storage location	79 76 274
Emergency release Driver's door Trunk Vehicle Emergency spare wheel Storage location	79 76
Emergency release Driver's door Trunk Vehicle Emergency spare wheel Storage location	79 76 274 275
Emergency release Driver's door Trunk Vehicle Emergency spare wheel Storage location Stowing Emergency Tensioning Devices Function	79 76 274 275 52
Emergency release Driver's door Trunk Vehicle Emergency spare wheel Storage location Stowing Emergency Tensioning Devices Function Safety guidelines	79 76 274 275
Emergency release Driver's door Trunk Vehicle Emergency spare wheel Storage location Stowing Emergency Tensioning Devices Function Safety guidelines Emissions control	79 76 274 275 52 37
Emergency release Driver's door Trunk Vehicle Emergency spare wheel Storage location Stowing Emergency Tensioning Devices Function Safety guidelines Emissions control Service and warranty information	79 76 274 275 52
Emergency release Driver's door Trunk Vehicle Emergency spare wheel Storage location Stowing Emergency Tensioning Devices Function Safety guidelines Emissions control Service and warranty information Engine	79 76 274 275 52 37 20
Emergency release Driver's door Trunk Vehicle Emergency spare wheel Storage location Stowing Z Emergency Tensioning Devices Function Safety guidelines Emissions control Service and warranty information Engine Check Engine warning lamp	79 76 274 275 52 37 20 234
Emergency release Driver's door Trunk Vehicle Emergency spare wheel Storage location Stowing Emergency Tensioning Devices Function Safety guidelines Emissions control Service and warranty information Engine Check Engine warning lamp Display message	79 76 274 275 52 37 20 234 216
Emergency release Driver's door Trunk Vehicle Emergency spare wheel Storage location Stowing 2 Emergency Tensioning Devices Function Safety guidelines Emissions control Service and warranty information Engine Check Engine warning lamp Display message ECO start/stop function	79 76 274 275 52 37 20 234 216 135
Emergency release Driver's door Trunk Vehicle Emergency spare wheel Storage location Stowing 2 Emergency Tensioning Devices Function Safety guidelines Emissions control Service and warranty information Engine Check Engine warning lamp Display message ECO start/stop function	79 76 274 275 52 37 20 234 216 135 324
Emergency release Driver's door Trunk Vehicle Emergency spare wheel Storage location Stowing 2 Emergency Tensioning Devices Function Safety guidelines Emissions control Service and warranty information Engine Check Engine warning lamp Display message ECO start/stop function Irregular running	79 76 274 275 52 37 20 234 216 135 324 138
Emergency release Driver's door Trunk Vehicle Emergency spare wheel Storage location Stowing Z Emergency Tensioning Devices Function Safety guidelines Emissions control Service and warranty information Engine Check Engine warning lamp Display message ECO start/stop function Irregular running Jump-starting	79 76 274 275 52 37 20 234 216 135 324 138 285
Emergency release Driver's door Trunk Vehicle Emergency spare wheel Storage location Stowing Z Emergency Tensioning Devices Function Safety guidelines Emissions control Service and warranty information Siglay message Display message ECO start/stop function Irregular running Jump-starting Starting problems	79 76 274 275 52 37 20 234 216 135 324 138 285 138
Emergency release Driver's door Trunk Vehicle Emergency spare wheel Storage location Stowing Z Emergency Tensioning Devices Function Safety guidelines Emissions control Service and warranty information Service and warranty information Engine Check Engine warning lamp Display message ECO start/stop function Irregular running Jump-starting Starting problems Starting the engine with the key	79 76 274 275 52 37 20 234 216 135 324 138 285

Switching off	150
Tow-starting (vehicle)	289
Engine electronics	
Problem (malfunction)	138
Engine oil	
Adding	262
Additives	327
Checking the oil level	261
Checking the oil level using the	201
dipstick	261
Display message	218
Filling capacity	327
Notes about oil grades	326
Notes on oil level/consumption	261
Temperature (on-board computer) .	195
Viscosity	327
ESP [®] (Electronic Stability	327
Program)	107
AMG menu (on-board computer)	196
Deactivating/activating (AMG	()
vehicles)	. 60
Deactivating/activating (notes;	
except AMG vehicles)	
Display message	200
ETS	
Function/notes	
Important safety information	
Warning lamp	231
ETS (Electronic Traction System)	
Exhaust check	153
Exhaust tail pipe (cleaning	
instructions)	269
Exterior lighting	
see Lights	
Exterior mirrors	
Adjusting	
Dipping (automatic)	
Folding in/out (automatically)	
Folding in/out (electrically)	. 99
Folding in when locking (on-board	
computer)	195
Out of position (troubleshooting)	. 99
Storing settings (memory	
function)	100
Storing the parking position	100
Eyeglasses compartment	243

F

Filler cap	
see Fuel filler flap	
First-aid kit	274
Flat tire	
Changing a wheel/mounting the	
spare wheel	276
MOExtended run-flat system	281
Preparing the vehicle	275
Raising the vehicle	277
see Emergency spare wheel	
Floormat	257
Front fog lamps	106
Display message	214
Switching on/off	106
Front windshield	
see Windshield	
Fuel	
Additives	326
Consumption statistics	185
Displaying the current	
consumption	185
Displaying the range	185
Driving tips	152
Fuel gauge	
Grade (gasoline)	325
Important safety notes	325
Premium-grade unleaded gasoline .	325
Problem (malfunction)	149
Refueling	146
Tank content/reserve fuel	325
Fuel filler flap, opening/closing	147
Fuel level	
Calling up the range (on-board	
computer)	185
Fuel tank	
Capacity	325
Problem (malfunction)	149
Fuse allocation chart (vehicle tool	
kit)	274
Fuses	
Allocation chart	290
Before changing	290
Fuse box in the engine	
compartment	290
Fuse box in the trunk	290
Important safety notes	289

Index

G

Garage	door	opener
--------	------	--------

257
254
257
255
195
270
322
242

Н

Handbrake	
see Parking brake	
Hazard warning lamps	108
Head bags	
Display message	209
Operation	. 41
Headlamp cleaning system	
Notes	328
Headlamps	
Adding fluid to cleaning system	263
Cleaning system (function)	107
Fogging up	108
see Automatic headlamp mode	
Head level heating (AIRSCARF)	. 96
Head restraints	
Adjusting	. 95
see NECK-PRO head restraints	
Heating	
see Climate control	
High-beam headlamps	
Changing bulbs	111
Display message	214
Switching on/off	107
Hill start assist	134
HOLD function	
Display message	219
Function/notes	168
Hood	
Closing	261
Display message	224
Opening	260

Hydroplaning	155
I	
Ignition lock	
see Key positions	
Immobilizer	. 64
Indicator lamps	
see Warning and indicator lamps	
Indicators	
see Turn signals	
Instrument cluster	
Overview	
Settings	
Warning and indicator lamps	
Instrument cluster lighting	180
Instrument lighting	
see Instrument cluster lighting	
Interior lighting	109
Automatic control	109
Delayed switch-off (on-board	
computer)	193
Emergency lighting	109
Manual control	109
Overview	109
Reading lamp	109
Setting the brightness of the	
ambient lighting (on-board	100
computer)	192

Jack

Storage location	274
Using	277
Jump starting (engine)	285
Jump starting (engine)	28

Κ

Кеу

see SmartKey

KEYLESS-GO

Convenience closing feature	81
Display message	226
Locking	69
Start/Stop button	131
Starting the engine	133
Unlocking	69

131
131
142
145
. 40

L

Lamps	
see Warning and indicator lamps	
Lap time (RACETIMER)	196
License plate lamp (display	
message)	214
Light function, active	
Display message	215
Lighting	
see Lights	
Lights	
Activating/deactivating the	
interior lighting delayed switch-off.	193
Automatic headlamp mode	106
Cornering light function	108
Display message	213
Driving abroad	104
Fog lamps	106
Hazard warning lamps	108
High beam flasher	107
High-beam headlamps	107
Light switch	104
Low-beam headlamps	105
Rear fog lamp	106
Setting the brightness of the	
ambient lighting (on-board	
computer)	192
Standing lamps	104
Switching the daytime running	
lamps on/off (on-board	
computer)	192
Switching the daytime running	
lamps on/off (switch)	105
Switching the exterior lighting	
delayed switch-off on/off (on-	
board computer)	193

Switching the surround lighting on/off (on-board computer)	193
Turn signals	107
see Changing bulbs	107
see Interior lighting	
Light sensor (display message)	216
Locking	
see Central locking	
Locking (doors)	
Automatic	75
Emergency locking	
From inside (central locking	
button)	75
Locking centrally	
see Central locking	
Locking verification signal (on-	
board computer)	194
Low-beam headlamps	
Changing bulbs	111
Display message	213
Setting for driving abroad	
(symmetrical)	104
Switching on/off	105
Luggage cover	
see Trunk partition	
Lumbar support	95

Μ

M+S tires			
MAGIC SKY CONTROL			
Maintenance			
see ASSYST PLUS service interval			
display			
Malfunction message			
see Display messages			
Manual transmission			
Engaging reverse gear	139		
Gear lever	139		
Pulling away	133		
Shift recommendation	139		
Starting the engine	133		
Matte finish (cleaning			
instructions)	267		
mbrace			
Call priority	252		
Display message	207		

12	Index

Downloading destinations
(0.01.1.1.0.)

(COMAND)	252
Emergency call	249
Important safety notes	248
Locating a stolen vehicle	254
MB info call button	251
Remote vehicle locking	254
Roadside Assistance button	251
Search & Send	253
Self-test	249
System	249
Vehicle remote unlocking	253
Mechanical key	
Function/notes	. 70
Locking vehicle	. 76
Unlocking the driver's door	. 76
Memory card (audio)	188
Memory function	100
Message memory (on-board	
computer)	199
Messages	
see Display messages	
Mirrors	
see Exterior mirrors	
see Rear-view mirror	
see Vanity mirror	
Mobile phone	
Menu (on-board computer)	189
see Phone	
Modifying the programming	
(SmartKey)	. 70
MOExtended run-flat system	281
MP3	
Operation	188
see separate operating instructions	
Multifunction display	
Function/notes	183
Permanent display	192
Multifunction steering wheel	
Operating the on-board computer .	181
Overview	. 29

Ν

•••	21/10	TOTION	٩.
1.1	avi	gatior	
		3	

Menu (on-board computer)	186
On-board computer	186
see separate operating instructions	
Neck level heating	
see AIRSCARF	
NECK-PRO head restraints	
Operation	47
Resetting after being triggered	48
Notes on breaking-in a new	
vehicle	130

Occupant Classification System	
(OCS)	
Faults	. 46
Operation	. 42
System self-test	. 45
Occupant safety	
Children in the vehicle	. 53
System overview	. 36
OCS	
Faults	. 46
Operation	. 42
System self-test	. 45
Odometer	185
see Trip odometer	
Oil	
see Engine oil	
On-board computer	
AMG menu	195
Assistance menu	190
Audio menu	188
Convenience submenu	194
Displaying a service message	264
Display messages	199
DISTRONIC PLUS	165
Factory settings submenu	195
Important safety notes	180
Instrument cluster submenu	191
Lighting submenu	192
Menu overview	184
Message memory	199
Navigation menu	186
Operation	181

RACETIMER	196	
Service menu	191	
Settings menu	191	
Standard display	185	
Telephone menu	189	
Trip menu	185	
Vehicle submenu	193	
Video DVD operation	189	
Operating safety		
Diagnostics connection	23	
Operating system		
see On-board computer		
Outside temperature display	181	
Overhead control panel	32	

Ρ

Paint code number	323
Paintwork (cleaning instructions)	267
Panic alarm	. 55
Parcel net	244
Parking	149
Important safety notes	149
Parking brake	150
Position of exterior mirror, front-	
passenger side	100
see PARKTRONIC	
Parking aid	
Parking Guidance	173
see Exterior mirrors	
see PARKTRONIC	
Parking brake	
Display message	202
Electric parking brake	150
Parking Guidance	
Display message	220
Important safety notes	173
Parking lamps (changing bulbs)	112
PARKTRONIC	
Deactivating/activating	172
Driving system	170
Function/notes	170
Important safety notes	170
Problem (malfunction)	173
Range of the sensors	170
Warning display	171
PASSENGER AIR BAG OFF indicator	
lamp	. 42

Pedals	152
Pivoting draft stop	
see AIRGUIDE	
Plastic trim (cleaning instructions) .	269
Power washers	266
Power windows	
see Side windows	
PRE-SAFE [®] (Preventive occupant	
safety system)	
Display message	207
Operation	. 47
PRE-SAFE [®] Brake	
Activating/deactivating	190
Display message	208
Function/notes	. 62
Warning lamp	237
Product information	. 20
Program selector button	142
Pulling away	
Automatic transmission	134
Manual transmission	133

Q

Qualified specialist workshop 23

R

RACETIMER (on-board computer)	196
Radar sensor system	
Activating/deactivating	194
Display message	220
Radio	
Selecting a station	188
see separate operating instructions	
Reading lamp	109
Rear fog lamp	
Display message	215
Switching on/off	106
Rear lamps	
see Lights	
Rear-view mirror	
Anti-glare (manual)	. 98
Dipping (automatic)	. 99
Rear window defroster	
Problem (malfunction)	125
Switching on/off	124

4	Inde

Refueling	
Fuel gauge	. 27
Important safety notes	146
Refueling process	147
see Fuel	
Releasing the parking lock	
manually (automatic	
transmission)	146
Remote control	
Garage door opener	254
Programming (garage door	
opener)	255
Reserve (fuel tank)	
see Fuel	
Reserve fuel	
Display message	219
Warning lamp	234
see Fuel	
Residual heat (climate control)	125
Restraint system	
see SRS (Supplemental Restraint	
System)	
Reverse gear	
Engaging (automatic	
transmission)	140
Engaging (manual transmission)	139
Reversible floor panel (trunk)	244
Roadside Assistance (breakdown)	. 21
Roof	
Display message	225
Important safety notes	
Opening/closing (with roof	
switch)	. 84
Opening/closing (with SmartKey)	
Problem (malfunction)	
Relocking	
Roof carrier	245
Roof lining and carpets (cleaning	
guidelines)	271
Roof switch	
Route (navigation)	
see Route guidance (navigation)	
Route guidance (navigation)	186
S	

S

Safety	
Children in the vehicle 53	
Child restraint systems 53	
Occupant Classification System	
(OCS) 42	
Overview of occupant safety	
systems	
Safety systems	
see Driving safety systems	
Seat belts	
Adjusting the driver's and front-	
passenger seat belt	
Belt force limiters	
Cleaning 270	
Correct usage 49	
Emergency Tensioning Devices 52	
Fastening 50	
Important safety guidelines 48	
Releasing 51	
Safety guidelines 37	
Special seat belt retractor 55	
Switching belt adjustment on/off	
(on-board computer) 194	
Warning lamp 228	
Warning lamp (function) 51	
Seats	
Adjusting (electrically) 94	
Adjusting (manually)	
Adjusting the 4-way lumbar	
support	
Adjusting the head restraint	
Cleaning the cover 270	
Correct driver's seat position	
Important safety notes	
Seat heating problem	
Storing settings (memory	
function) 100	
Switching AIRSCARF on/off	
Switching seat heating on/off	
Sensors (cleaning instructions) 269	
Service Center	
see Qualified specialist workshop	
Service interval display	
Displaying service messages	
Hiding service messages 264	

Notes 264	
Service messages 264	
Service menu (on-board computer) . 191	
Service products	S
Brake fluid 327	S
Coolant (engine) 327	
Engine oil 326	S
Fuel 325	
Important safety notes	
Washer fluid	
Settings	
Factory (on-board computer) 195	
On-board computer 191	
Setting the air distribution 123	
Setting the airflow 123	
SETUP (on-board computer) 196	S
Side impact air bag 40	
Side marker lamp (display	
message) 215	
Side windows	S
Convenience closing feature	S
Important safety information	
Opening/closing (all) 80	
Opening/closing (front) 80	
Problem (malfunction) 82	
Resetting 82	S
SmartKey	
Changing the battery 71	
Changing the programming 70	
Checking the battery 71	S
Convenience opening feature	S
Display message 226	
Door central locking/unlocking 68	S
Important safety notes	S
Loss 73	
Mechanical key 70	
Opening/closing the roof	
Positions (ignition lock) 131	
Problem (malfunction) 73	
Starting the engine 133	
Snow chains	
Sockets	
Center console 248	
Points to observe before use 247	
Under the armrest 248	S
Spare wheel	S
Notes/data 318	S

64	Storage location	274
64	Stowing	275
91	see Emergency spare wheel	
	Specialist workshop	. 23
27	Speed, controlling	
27	see Cruise control	
26	Speedometer	
25	Activating/deactivating the	
24	additional speedometer	192
28	Digital	186
	In the Instrument cluster	. 27
95	Segments	181
91	Selecting the unit of	
23	measurement	191
23	see Instrument cluster	
96	SPORT handling mode	
40	Activating/deactivating (AMG	
	vehicles)	
15	Warning lamp	232
	SRS (Supplemental Restraint	
81	System)	
80	Display message	208
80	Introduction	
80	Warning lamp	
82	Warning lamp (function)	. 36
82	Standing lamps	
	Changing bulbs	112
71	Display message	215
70	Switching on/off	104
71	Starting (engine)	132
81	Station	
26	see Radio	0.0 E
68	Steering (display message)	225
68	Steering wheel	07
73 70	Adjusting (electrically)	
	Adjusting (manually) Button overview	
84 31	Buttons (on-board	29
73	computer)	181
33	Cleaning	270
97	Important safety notes	
. 77	Paddle shifters	
48	Storing settings (memory	142
40	function)	100
48	Steering wheel paddle shifters	142
10	Stopwatch (RACETIMER)	196
18	Stowage areas	242
		- 12

16	Inde
	III ac

Stowage	compartments	

Armrest (front)	243
Armrest (under)	243
Center console	243
Cup holders	245
Door	244
Eyeglasses compartment	243
Glove box	242
Important safety information	242
Parcel net	244
Rear wall	244
Summer opening	
see Convenience opening feature	
Summer tires	296
Sun visor	246
Supplemental Restraint System	
see SRS (Supplemental Restraint	
System)	
Surround lighting (on-board	
computer)	193
Switching air-recirculation mode	
on/off	125
Switching off the alarm (ATA)	. 65

Т

Tachometer	181
Tail lamps	
Display message	214
see Lights	
Tank	
see Fuel tank	
Tank content	
Fuel gauge	27
Technical data	
Notes	322
Tires/wheels	316
Vehicle data	329
TELEAID	
Call priority	252
Display message	207
Downloading destinations	
(COMAND)	252
Emergency call	249
Important safety notes	248
Locating a stolen vehicle	254
MB info call button	251
Remote vehicle locking	254

		Roadside Assistance button	251
:	243	Search & Send	253
	243	Self-test	249
	243	System	249
	245	Vehicle remote unlocking	253
	244	Telephone	200
	243	Accepting a call	189
	242	Display message	225
	242	Menu (on-board computer)	189
	242	Number from the phone book	190
· · ·		-	
	244	Redialing	190
		Rejecting/ending a call	190
		Temperature	
	296	Coolant	181
	246	Coolant (on-board computer)	195
		Engine oil (on-board computer)	195
		Outside temperature	181
		Setting (climate control)	122
		Theft deterrent systems	
	193	ATA (Anti-Theft Alarm system)	. 65
		Immobilizer	. 64
	125	Time	
	65	see Separate Operator's Manual	
		Timing (RACETIMER)	196
		Tiredness assistant	
		see ATTENTION ASSIST	
••	181	Tire pressure	
		Calling up (on-board computer)	301
	214	Checking manually	301
		Display message	222
		Maximum	300
		Notes	299
		Recommended	297
	27	Tire pressure monitoring system	271
		Function/notes	301
(322		303
	316	Restarting	
	329	Warning lamp	238
	/	Tires	
	252	Aspect ratio (definition)	314
	207	Average weight of the vehicle	
••••	207	occupants (definition)	313
	252	Bar (definition)	312
	252 249	Characteristics	312
		Checking	295
	248	Definition of terms	312
	254 251	Direction of rotation	316
1	761		~ ~ ~
	257	Display message	222

Distribution of the vehicle	
occupants (definition)	315
DOT, Tire Identification Number	
(TIN)	311
DOT (Department of	
Transportation) (definition)	312
GAWR (Gross Axle Weight Rating)	
(definition)	313
GVW (Gross Vehicle Weight)	
(definition)	313
GVWR (Gross Vehicle Weight	
Rating) (definition)	313
Important safety notes	294
Increased vehicle weight due to	
optional equipment (definition)	313
Kilopascal (kPa) (definition)	314
Labeling (overview)	309
Load bearing index (definition)	315
Load index	311
Load index (definition)	314
Maximum loaded vehicle weight	
(definition)	313
Maximum load on a tire	
(definition)	314
Maximum permissible tire	
pressure (definition)	314
Maximum tire load	307
Maximum tire load (definition)	314
Optional equipment weight	
(definition)	314
PSI (pounds per square inch)	
(definition)	314
Replacing	315
Service life	295
Sidewall (definition)	314
Speed rating (definition)	313
Storing	316
Structure and characteristics	0.4.0
(definition)	312
Temperature	308
TIN (Tire Identification Number)	015
(definition)	315
Tire bead (definition)	314
Tire pressure (definition)	314
Tire pressures (recommended)	313
Tire size (data)	316
Tire size designation, load-bearing	200
capacity, speed rating	309

Tire tread	295
Tire tread (definition)	314
Total load limit (definition)	315
Traction	308
Traction (definition)	315
Tread wear	308
Uniform Tire Quality Grading	
Standards	307
Uniform Tire Quality Grading	007
Standards (definition)	313
Unladen weight (definition)	314
Wear indicator (definition)	315
Wheel rim (definition)	313
see Flat tire	0.0
Towing	
Important safety guidelines	287
Installing the towing eye	287
Removing the towing eye	288
With the rear axle raised	288
Towing away	200
With both axles on the ground	288
Tow-starting	
Emergency engine starting	289
Important safety notes	287
Installing the towing eye	287
Removing the towing eye	288
Transmission	
see Automatic transmission	
see Manual transmission	
Transporting the vehicle	289
Trim pieces (cleaning instructions).	270
Trip computer (on-board	
computer)	185
Trip meter	
see Trip odometer	
Trip odometer	
Calling up	185
Resetting (on-board computer)	186
Trunk	
Emergency release	. 79
Important safety notes	. 77
Locking separately	
Opening (automatically from	
outside)	. 78
Trunk lid	
Display message	
Opening/closing	. 77

0	Index
8	Inde/

Trunk	k pa	rtiti	on

Display message	225	
General notes	. 85	
Opening/closing	. 85	
Turn signals		
Changing bulbs (front)	112	
Display message	213	
Switching on/off	107	
Type identification plate		
see Vehicle identification plate		

U

Unlocking

Emergency unlocking	76
From inside the vehicle (central	
unlocking button)	75

V

Vanity mirror (in the sun visor) Vehicle	246
Correct use	. 23
Data acquisition	
Display message	224
Emergency unlocking	
Equipment	
Individual settings	191
Limited Warranty	. 24
Loading	
Locking (in an emergency)	. 76
Locking (SmartKey)	. 68
Lowering	281
Maintenance	. 21
Parking for a long period	151
Pulling away	133
Raising	277
Reporting problems	. 23
Towing away	287
Tow-starting	287
Transporting	289
Unlocking (in an emergency)	. 76
Unlocking (SmartKey)	. 68
Vehicle data	329
Vehicle battery	
see Battery (vehicle)	
Vehicle data	329
Vehicle dimensions	329

Vehicle emergency locking	. 76
Vehicle identification number	
see VIN	
Vehicle identification plate	323
Vehicle tool kit	274
Video (DVD)	189
VIN	323

W

Warning and indicator lamps	
ABS	230
Brakes	229
Check Engine	234
Coolant	235
Distance warning	237
DISTRONIC PLUS	237
ESP [®]	231
ESP [®] OFF	232
Fuel tank	234
Overview	. 28
PASSENGER AIR BAG OFF	
indicator lamp	. 42
Reserve fuel	234
Seat belt	228
SPORT handling mode	232
SRS	233
Tire pressure monitor	238
Warranty	323
Washer fluid	
Display message	226
Wheel bolt tightening torque	281
Wheel chock	276
Wheels	
Changing a wheel	276
Checking	295
Cleaning	266
Important safety notes	294
Interchanging/changing	315
Mounting a new wheel	279
Removing a wheel	279
Storing	316
Tightening torque	281
Wheel size/tire size	316
Windows	
Cleaning	268
see Side windows	

Index

Wind screen	
Inserting and removing	. 86
Preparing for installation	
see AIRGUIDE	
Windshield	
Defrosting	124
Windshield washer fluid	
see Windshield washer system	
Windshield washer system	263
Notes	328
Windshield wipers	020
Problem (malfunction)	114
Replacing the wiper blades	113
Switching on/off	113
Winter driving	110
Important safety notes	296
Slippery road surfaces	155
Snow chains	297
Winter tires	271
M+S tires	296
Wiper blades	270
-	268
Cleaning	113
Important safety notes	113
Wooden trim (cleaning	
instructions)	270
Workshop	
see Qualified specialist workshop	

Product information

Mercedes-Benz recommends that you use genuine Mercedes-Benz parts, conversion parts and accessories that have been approved for the type of vehicle.

Mercedes-Benz tests genuine parts as well as conversion parts and accessories which have been specifically approved for your vehicle for their reliability, safety and suitability. Despite ongoing market research, Mercedes-Benz is unable to assess other parts. Therefore, Mercedes-Benz accepts no responsibility for the use of such parts in Mercedes-Benz vehicles, even if they have been independently or officially approved. The use of non-approved parts could affect your vehicle's operating safety. Mercedes-Benz therefore recommends that you use genuine Mercedes-Benz parts, conversion parts and accessories that have been approved for the type of vehicle. Genuine Mercedes-Benz parts, approved conversion parts and accessories are available from any authorized Mercedes-Benz Center. Here, you will receive advice about permissible technical modifications, and the parts will be professionally installed.

Operator's Manual

Notes on the Operator's Manual

This Operator's Manual contains a great deal of helpful information. We urge you to read it carefully and familiarize yourself with the vehicle before driving.

For your own safety and longer service life of the vehicle, we urge you to follow the instructions and warnings contained in this Operator's Manual. Ignoring them could result in damage to the vehicle or personal injury to you or others. Vehicle damage caused by failure to follow instructions is not covered by the Mercedes-Benz Limited Warranty.

Vehicle equipment

This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of going to print. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions. The equipment in your vehicle may therefore differ from some of the descriptions or illustrations.

The original purchase agreement lists all systems installed in your vehicle.

Contact an authorized Mercedes-Benz Center if you have any questions about equipment or operation.

The Operator's Manual and the Maintenance Booklet are important documents and should be kept in the vehicle.

Service and vehicle operation

Service and literature

Your vehicle is covered under the terms of the warranties printed in the Service and Warranty Information booklet. Your authorized Mercedes-Benz Center will exchange or repair any defective parts originally installed in the vehicle in accordance with the terms of the following warranties:

- New Vehicle Limited Warranty
- Emission Systems Warranty
- Emission Performance Warranty
- California, Connecticut, Maine, Massachusetts, New York, Pennsylvania, Rhode Island and Vermont Emission Control Systems Warranty
- State warranty enforcement laws (lemon laws)

Information for customers in California

Under California law you may be entitled to a replacement of your vehicle or a refund of the purchase price or lease price, if after a reasonable number of repair attempts Mercedes-Benz USA, LLC and/or its authorized repair or service facilities fail to fix one or more substantial defects or malfunctions in the vehicle that are covered by its express warranty. During the period of 18 months from original delivery of the vehicle or the accumulation of 18 000 miles (approximately 29 000 km) on the odometer of the vehicle, whichever occurs first. a reasonable number of repair attempts is presumed for a retail buyer or lessee if one or more of the following occurs:

- the same substantial defect or malfunction results in a condition that is likely to cause death or serious bodily injury if the vehicle is driven, that defect or malfunction has been subject to repair two or more times, and you have directly notified Mercedes-Benz USA, LLC in writing of the need for its repair.
- (2) the same substantial defect or malfunction of a less serious nature than category (1) has been subject to repair four or more times and you have directly notified Mercedes-Benz in writing of the need for its repair.
- (3) the vehicle is out of service by reason of repair of the same or different substantial defects or malfunctions for a cumulative total of more than 30 calendar days.

Please send your written notice to: Mercedes-Benz USA, LLC Customer Assistance Center One Mercedes Drive Montvale, NJ 07645-0350

Maintenance

The Service and Warranty Booklet describes all the necessary maintenance work which should be done at regular intervals.

Always have the Service and Warranty Booklet with you when you bring the vehicle to an authorized Mercedes-Benz Center. The service advisor will record every service for you in the Service and Warranty Booklet.

Breakdown assistance

The Mercedes-Benz Roadside Assistance Program offers technical help in the event of a breakdown. Calls to the toll-free Roadside Assistance Hotline are answered by our agents 24 hours a day, 365 days a year.

1-800-FOR-MERCedes(1-800-367-6372) (USA)

1-800-387-0100 (Canada)

For additional information, refer to the Mercedes-Benz Roadside Assistance Program brochure (USA) or the "Roadside Assistance" section in the Service and Warranty booklet (Canada). You will find both in your vehicle literature portfolio.

Change of address or change of ownership

If you sell your Mercedes, please leave the entire literature in the vehicle so that it is available to the next owner.

Vehicle operation outside the USA and Canada

If you plan to operate your vehicle in foreign countries, please be aware that:

- service facilities or replacement parts may not be readily available.
- unleaded fuel for vehicles with a catalytic converter may not be available. Leaded fuel

22 Introduction

may cause damage to the catalytic converter.

• the fuel may have a considerably lower octane rating. Unsuitable fuel can cause engine damage.

Some Mercedes-Benz models are available for delivery in Europe through our European Delivery Program. For details, consult an authorized Mercedes-Benz Center or write to one of the following addresses.

In the USA

Mercedes-Benz USA, LLC European Delivery Department One Mercedes Drive Montvale, NJ 07645-0350

In Canada

Mercedes-Benz Canada, Inc. European Delivery Department 98 Vanderhoof Avenue Toronto, Ontario M4G 4C9

Operating safety

Safety notes

MARNING

Work improperly carried out on electronic components and associated software could cause them to cease functioning. Because the vehicle's electronic components are interconnected, any modifications made may produce an undesired effect on other systems. Electronic malfunctions could seriously impair the operating safety of your vehicle.

Contact an authorized Mercedes-Benz Center for repairs or modifications to electronic components.

Other improper work or modifications on the vehicle could also have a negative impact on the operating safety of the vehicle.

Some safety systems only function when the engine is running. You should therefore never turn off the engine while driving.

Heavy blows against the vehicle underbody or tires/wheels may cause serious damage and impair the operating safety of your vehicle. Such blows can be caused, for example, by running over an obstacle, road debris or a pothole.

If you feel a sudden significant vibration or ride disturbance, or you suspect that damage to your vehicle has occurred:

- turn on your hazard warning flashers.
- slow down carefully.
- drive with caution to an area which is a safe distance from the road.

Inspect the vehicle underbody and tires/ wheels for possible damage. If the vehicle appears unsafe, have it towed to the nearest authorized Mercedes-Benz Center or other qualified maintenance or repair facility for further inspection or repairs.

Declarations of conformity

Vehicle components which receive and/or transmit radio waves

USA: "The wireless devices of this vehicle comply with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) These devices may not cause harmful interference, and 2) These devices must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."

Canada: "The wireless devices of this vehicle comply with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) These devices may not cause interference, and (2) These devices must accept any interference, including interference that may cause undesired operation of the device."

Diagnostics connection

MARNING

If you connect equipment to the diagnostics connection, it can affect the operation of the vehicle systems. This can impair the operating safety of your vehicle while driving. There is a risk of accident.

Do not connect any equipment to the diagnostics connection.

▲ WARNING

Loose equipment or equipment cables that are connected to the diagnostics connection can obstruct the area around the pedals. The equipment or the cables could get between the pedals in the event of sudden braking or acceleration. As a result, the movement of the pedals may be impaired. There is a risk of accident.

Do not attach any equipment or cables in the driver footwell.

If the engine is switched off and equipment on the diagnostics connection is used, the starter battery may discharge.

The diagnostics connection is only intended for the connection of diagnostic equipment at a qualified specialist workshop.

Connecting equipment to the diagnostics connection can, for example, lead to emissions monitoring information being reset. This may lead to the vehicle failing to meet the requirements of the next emissions test during the main inspection.

Qualified specialist workshop

An authorized Mercedes-Benz Center is a qualified specialist workshop. It has the

necessary specialist knowledge, tools and qualifications to correctly carry out the work required on your vehicle. This is especially the case for work relevant to safety.

Observe the notes in the Maintenance Booklet.

Always have the following work carried out at an authorized Mercedes-Benz Center:

- work relevant to safety
- service and maintenance work
- repair work
- alterations, installation work and modifications
- work on electronic components

Correct use

▲ WARNING

There are various warning stickers affixed to your vehicle. Their purpose is to alert you and others to various dangers. Therefore, do not remove any warning stickers unless the sticker clearly states that you may do so.

If you remove any warning stickers, you or others could fail to recognize certain dangers and be injured.

When driving your vehicle observe the following information:

- the safety notes in this manual
- the "Technical data" section in this manual
- traffic rules and regulations
- laws and safety standards pertaining to motor vehicles

Problems with your vehicle

If you should experience a problem with your vehicle, particularly one that you believe may affect its safe operation, we urge you to contact an authorized Mercedes-Benz Center immediately to have the problem diagnosed and rectified. If the problem is not resolved to your satisfaction, please discuss the problem again with a Mercedes-Benz Center or contact us at one of the following addresses.

In the USA

Customer Assistance Center Mercedes-Benz USA, LLC One Mercedes Drive Montvale, NJ 07645-0350

In Canada

Customer Relations Department Mercedes-Benz Canada, Inc. 98 Vanderhoof Avenue Toronto, Ontario M4G 4C9

Limited Warranty

Follow the instructions in this manual about the proper operation of your vehicle as well as about possible vehicle damage. Damage to your vehicle that arises from culpable contraventions against these instructions is not covered either by the Mercedes-Benz Limited Warranty or by the New or Used-Vehicle Warranty.

Data stored in the vehicle

Information about electronic data acquisition in the vehicle

(Including notice pursuant to California Code § 9951)

Your vehicle records electronic data. If your vehicle is equipped with mbrace¹, data is transmitted in the event of an accident.

This information helps, for example, to test vehicle systems after an accident and to continually improve vehicle safety. Daimler AG can access this data and submit it:

- for safety research or vehicle diagnosis purposes
- with the consent of the vehicle owner
- on the instruction of prosecuting authorities
- for use in arbitration of disputes that involve Daimler AG, its affiliates or its sales and service organizations
- as otherwise required or permitted by law.


Please observe the mbrace¹ purchase agreement for further details on the recording and transfer of data by this system.

Cockpit	26	
Instrument cluster	27	
Multifunction steering wheel		S
Center console	30	gland
Overhead control panel	32	60
Door control panel	33	At a

26 Cockpit

Cockpit

At a glance



	Function	Page
1	Steering wheel paddle shifters	142
2	Cruise control lever	156
3	Instrument cluster	27
4	Horn	
5	PARKTRONIC warning display	170
6	Overhead control panel	32
7	Climate control systems	116
8	Ignition lock Start/Stop button	131 131


	Function	Page
9	Adjusts the steering wheel manually	96
10	Adjusts the steering wheel electrically	96
(11)	Combination switch	107
(12)	Electric parking brake	150
(13)	Diagnostics connection	23
(14)	Opens the hood	260
(15)	Light switch	104

Instrument cluster 27

3

Tachometer


Displays and controls



181

At a glance


At a glance



	Function	Page
1	ED Low-beam headlamps	105
2	ED High-beam headlamps	107
3	ESP [®]	231
4	Electric parking brake (red) PARK (USA only) (Canada only)	229
5	() Electric parking brake (yellow)	229
6	Distance warning	237
7	↓ ↓ Turn signals	107
8	(!) Tire pressure monitor	238
9	SRS	233

	Function	Page
(10)	🛃 Seat belt	228
(11)	SPORT SPORT handling mode in AMG vehicles	232
(12)	Coolant	235
(13)	0≢ Rear fog lamp	106
(14)	₽ Front fog lamps	106
(15)	Engine Check	234
(16)	Reserve fuel	234
(17)	ESP [®] OFF	231
(18)	() ABS	230
(19)	Brakes	229
	brake (USA only)	
	(Canada only)	

Multifunction steering wheel




	Function	Page		Function
1	Multifunction display	183	5	
2	Audio/COMAND display; see the separate operating instructions			Selects a menu Selects a subme
3	Switches on the Voice Control System; see the separate operating			Scrolls through OK Confirms a sele Hides display m
0	instructions		6	
(4)	Rejects or ends a call Exits phone book/redial memory	189		Back Switches off the Control System separate operat instructions
	Makes or accepts a call Switches to the redial memory + - Adjusts the volume			
	Mute			

Function	Page
Selects a menu	181
Selects a submenu or	
scrolls through lists	181
OK	
Confirms a selection	181
Hides display messages	199
Back	181
Switches off the Voice Control System; see the separate operating	

30 Center console


Center console

Center console, upper section



	Function	Page	
1	Audio system/COMAND; see the separate operating instructions		
2	₩ Seat heating	95	
3	I AIRSCARF	96	
4		170	
(5)	ECO ECO start/stop function (AMG vehicles)	135	

	Function	Page
6	Azard warning lamps	108
7	□FF indicator lamp	42
8	ESP [®]	58
9	Dynamic handling package with sports mode	168



	Function	Page		Function	Page
(10)	Stowage compartment	242	(14)	Roof switch cover	83
	Ashtray Cigarette lighter Power socket	247 247 247	(15)	Audio/COMAND controller; see the separate operating instructions	
(11)	Selector lever	140	(16)	$\begin{bmatrix} f_{E,M}^{S_{\lambda}} \end{bmatrix}$ Selects the drive	
(12)	Stowage compartment Cup holders	243 245		program <u>M</u> Selects the drive program (AMG vehicles)	142 142
(13)	Stowage compartment	242		pro8.4 (7.1	. 12

Overhead control panel

lighting on/off

CONTROL

Operates MAGIC SKY

资 Switches the right-

👼 Switches the

control on/off

hand reading lamp on/off

automatic interior lighting

3

4

(5)

At a glance

				3 4 5 3 6 -8 PB:	2.00-2781-31
	Function	Page		Function	Page
1	置 Switches the left-		6	Eyeglasses compartment	243
	hand reading lamp on/off	109	7	🖌 Button for MB Info call	
2	\Im Switches the interior			(mbrace system)	251

109

88

109

109

8

9

(10)

(11)

Rear-view mirror

opener

system)

Buttons for the garage door

ℝ Roadside Assistance

SOS button (mbrace

button (mbrace system)


98

257

251

At a glance

P72.10-3818-31



2) (3

	steering wheel	100
5	D Folds the exterior	
	mirrors in/out	9

Door control panel

1)

	Function	Page
6	Selects the right exterior mirror	98
7	Opens/closes the right side window	80
8	Opens/closes the left side window	80
9	Adjusts the exterior mirrors	98
10	Selects the left exterior mirror	98

Useful information	36	
Occupant safety	36	
Children in the vehicle	53	
Panic alarm	55	
Driving safety systems	56	ţ
Driving safety systems Theft deterrent locking system	64	afe
		Š

Useful information

Safety

This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.

 Please read the information on qualified specialist workshops (▷ page 23).

Occupant safety

Overview of occupant safety

In this section, you will learn the most important facts about the restraint system components of the vehicle.

The restraint system consists of:

- seat belts
- child restraint systems

Additional protection is provided by:

- SRS (Supplemental Restraint System)
- NECK-PRO head restraints
- Air bag system components with:
 - PASSENGER AIR BAG ON/OFF indicator lamp²
 - front-passenger seat with Occupant Classification System (OCS)

The different air bag systems work independently of each other. The protective functions of the system work in conjunction with each other. Not all air bags are deployed in an accident.

MARNING

Modifications to or work improperly conducted on restraint system components or their wiring, as well as tampering with interconnected electronic systems, can lead to the restraint systems no longer functioning as intended.

Air bags or Emergency Tensioning Devices (ETDs), for example, could deploy inadvertently or fail to deploy in accidents although the deceleration threshold for air bag deployment is exceeded. Therefore, never modify the restraint systems. Do not tamper with electronic components or their software.

● See "Children in the vehicle" (▷ page 53) for more information on infants and children traveling with you in the vehicle and restraints for infants and children.

SRS (Supplemental Restraint System)

Introduction

SRS consists of:

- the 💽 SRS warning lamp
- air bags
- air bag control unit (with crash sensors)
- Emergency Tensioning Devices
- belt force limiters

SRS reduces the risk of occupants coming into contact with the vehicle's interior in the event of an accident. It can also reduce the effect of the forces to which occupants are subjected during an accident.

SRS warning lamp

SRS functions are checked regularly when you switch on the ignition and when the engine is running. Therefore, malfunctions can be detected in good time.

The SRS warning lamp in the instrument cluster lights up when the ignition is switched on. It goes out no later than a few seconds after the engine is started.

² The PASSENGER AIR BAG ON indicator lamp has no function. When switching on the ignition, it lights up briefly and then goes out again.

The SRS components are in operational readiness if the SRS warning lamp is not lit while the engine is running.

The SRS self-check has detected a malfunction if the **SRS** indicator lamp:

- does not light up at all
- does not go out after approximately four seconds after the engine is started
- comes on after the engine was started or while driving.

For your safety, Mercedes-Benz strongly recommends that you have the system checked as soon as possible at an authorized Mercedes-Benz Center. SRS may otherwise fail to activate when it is needed in the event of an accident, which could lead to serious or fatal injuries. SRS might also be activated unexpectedly and unnecessarily, which could also result in injury.

In addition, work carried out improperly on SRS may render SRS inoperative or cause unintended air bag deployment. Work on the SRS system should only be carried out by qualified specialist personnel. Consult an authorized Mercedes-Benz Center.

If it is necessary to modify an air bag system to accommodate a person with disabilities, contact an authorized Mercedes-Benz Center for details. USA only: for further information contact our Customer Assistance center at 1-800-FOR-MERCedes (1-800-367-6372).

Safety guidelines for seat belts, Emergency Tensioning Devices (ETDs) and air bags

MARNING №

• Damaged seat belts or seat belts that have been subjected to stress in an accident must be replaced. Their anchoring points must also be checked. Only use seat belts installed or supplied by an authorized Mercedes-Benz Center.

- Air bags and pyrotechnic Emergency Tensioning Devices (ETDs) contain perchlorate material, which may require special handling and regard for the environment. Check your national disposal guidelines. California residents, see
 www.dtsc.ca.gov/HazardousWaste/ Perchlorate/index.cfm.
- Air bags and ETDs are designed to function on a one-time-only basis. An air bag or ETD that has deployed must be replaced.
- Do not pass seat belts over sharp edges. They could tear.
- Do not make any modification that could change the effectiveness of the seat belts.
- Do not bleach or dye seat belts as this may severely weaken them. In a crash they may not be able to provide adequate protection.
- No modifications of any kind may be made to any components or wiring of the SRS.
- Do not change or remove any component or part of the SRS.
- Do not install additional trim material, seat covers, badges, etc. over the steering wheel hub, front-passenger front air bag cover, outer sides of the seat backrests, door trim panels, or door frame trims.
- Do not install additional electrical/ electronic equipment on or near SRS components and wiring.
- Keep area between air bags and occupants free of objects (e.g. packages, purses, umbrellas, etc.).
- Air bag system components will be hot after an air bag has inflated. Do not touch them.
- Never place your feet on the instrument panel, dashboard, or on the seat. Always keep both feet on the floor in front of the seat.
- Improper repair work on the SRS creates a risk of rendering the SRS inoperative or causing unintended air bag deployment.
 Work on the SRS must therefore only be

performed by qualified technicians. Contact an authorized Mercedes-Benz Center.

- For your protection and the protection of others, when scrapping the air bag unit or ETD, our safety instructions must be followed. These instructions are available from any authorized Mercedes-Benz Center.
- Given the considerable deployment speed, required inflation volume, and the material of the air bags, there is the possibility of abrasions or other, potentially more serious injuries resulting from air bag deployment.

If you sell your vehicle, Mercedes-Benz strongly recommends that you inform the subsequent owner that the vehicle is equipped with SRS. Also, refer them to the applicable section in the Operator's Manual.

Air bags

Important safety notes

MARNING

Air bags are designed to reduce the incidence of injuries and fatalities in certain situations:

- frontal impacts (driver's and frontpassenger front air bags and knee bags)
- side impacts (side impact air bags and head bags)
- rollover (head bags)

However, no system available today can completely eliminate injuries and fatalities. When the air bags are deployed, a small amount of powder is released. The powder generally does not constitute a health hazard and does not indicate that there is a fire in the vehicle. In order to prevent potential breathing difficulties, you should leave the vehicle as soon as it is safe to do so. If you have any breathing difficulty but cannot get out of the vehicle after the air bag inflates, then get fresh air by opening a window or door.

In order to reduce the potential danger of injuries caused during the deployment of the front air bags, the driver and front passenger must always be correctly seated and wear their seat belts.

For maximum protection in the event of a collision, you must always be in the normal seat position with your back against the backrest. Fasten your seat belt and make sure that it is correctly positioned on your body.

As the air bag inflates with considerable speed and force, a proper seating position and correct positioning of the hands on the steering wheel will help to keep you at a safe distance from the air bag. Occupants who are not wearing their seat belt, are not seated properly or are too close to the air bag can be seriously injured or killed by an air bag, as it inflates with great force instantaneously:

- sit with the seat belt fastened correctly and in a position that is as upright as possible with your back against the backrest.
- move the driver's seat as far back as possible, still permitting proper operation of vehicle controls. The distance from the center of the driver's chest to the center of the air bag cover on the steering wheel must be at least 10 inches (25 cm). You should be able to accomplish this by adjusting the seat and steering wheel. If you have any difficulties, please contact an authorized Mercedes-Benz Center.
- do not lean your head or chest close to the steering wheel or dashboard.
- only hold the steering wheel on the outside. Placing hands and arms inside the rim of the steering wheel can increase the risk and potential severity of hand/arm injuries if the air bag inflates.
- adjust the front-passenger seat as far back as possible from the dashboard when the seat is occupied.
- occupants, especially children, should never place their bodies or lean their heads in the area of the door where the side

impact air bag and/or head bag inflates. This could result in serious or fatal injuries should the side impact air bag and/or head bag be deployed. Always sit as upright as possible, wear the seat belt properly and use an appropriately sized infant restraint, toddler restraint or booster seat recommended for the size and weight of the child.

Failure to follow these instructions can result in severe injuries to you or other occupants.

If you sell your vehicle, it is important that you make the buyer aware of this safety information. Be sure to give the buyer this Operator's Manual.

MARNING

If the side impact air bag and/or head bag is deployed in the event of a side impact and the front passenger, especially a child, is not properly seated or restrained when next to a side impact air bag/head bag, injuries are possible due to the rapid inflation of the side impact air bag/head bag.

To help avoid the possibility of injury, please follow these guidelines:

- (1) Always sit as upright as possible, and use the seat belts properly. Make sure that children 12 years old and under use an appropriately sized child restraint, infant restraint or booster seat recommended for the size and weight of the child.
- (2) Always wear seat belts properly.

The air bags are only deployed if the air bag control unit detects the need for deployment. Only in the event of such a situation will they provide their supplemental protection.

The driver and passenger should always wear their seat belts. Otherwise, it is not possible for the air bags to provide their supplemental protection.

In the event of other types of impacts and impacts below air bag deployment

thresholds, the air bags will not deploy. The driver and passengers will then be protected to the extent possible by a properly fastened seat belt. A properly fastened seat belt is also needed to provide the best possible protection in a rollover.

Air bags provide additional protection; they are not, however, a substitute for seat belts. All vehicle occupants must fasten their seat belts regardless of whether your vehicle is equipped with air bags or not.

It is important for your safety and that of your passenger to have deployed air bags replaced and to have any malfunctioning air bags repaired. This will help to make sure the air bags continue to perform their protective function for the vehicle occupants in the event of a crash.

Front air bags

The front air bags increase protection for the driver's and front-passenger's head and chest.



- 1) Driver's air bag
- (2) Front-passenger front air bag
- ③ Front-passenger knee bag
- (4) Driver's knee bag

Driver's air bag (1) deploys in front of the steering wheel; front-passenger front air bag (2) deploys in front of and above the glove box.

Safety

They are deployed:

- · in the event of certain frontal impacts
- if the system determines that air bag deployment can offer additional protection to that provided by the seat belt
- if the seat belt is fastened
- independently of other air bags in the vehicle

If the vehicle overturns, the front air bags are generally not deployed. If the system detects high vehicle deceleration in a longitudinal direction, the front air bags are deployed.

Your vehicle has adaptive, two-stage front air bags. In the event of a collision, the air bag control unit evaluates the vehicle deceleration. In the first deployment stage, the front air bag is filled with enough propellant gas to reduce the risk of injuries. The front air bag is fully deployed if a second deployment threshold is exceeded within a few milliseconds.

The deployment of the front-passenger front air bag is also influenced by the weight category of the front passenger, which is determined by the Occupant Classification System (OCS) (\triangleright page 42).

The lighter the passenger-side occupant, the higher the vehicle deceleration rate required (predicted at the start of the impact) for second stage inflation of the front-passenger front air bag. In the second stage, the front air bags are inflated with the maximum amount of propellant gas available.

The front air bags are not deployed in situations where a low impact severity is predicted. You will then be protected by the fastened seat belt. The front-passenger front air bag will only deploy if:

- the system, based on the OCS weight sensor readings, detects that the frontpassenger seat is occupied.
- the PARENE OF A indicator lamp in the center console is not lit, (▷ page 42).
- the air bag control unit predicts a high impact severity.

Knee bags

MARNING

Observe "Important safety notes" (▷ page 38).

Knee bags provide increased protection for the driver and front passenger against the risk of:

- knee injuries
- thigh injuries
- lower leg injuries

Driver's knee bag (4) (> page 39) deploys underneath the steering column and frontpassenger knee bag (3) (> page 39) underneath the glove box. They deploy together with the front air bags. They are designed to operate together with the front air bags in frontal impacts if certain thresholds are exceeded. The knee bags operate at best in conjunction with correctly positioned and fastened seat belts.

Side impact air bags

The pressure sensors for side impact air bag control are located in the doors. Do not modify any components of the doors or door trim panels including, for example, the addition of door speakers.

Improper repair work on the doors or the modification or addition of components to the doors create a risk of rendering the side impact air bags inoperative or causing unintended air bag deployment. Work on the

Safety

doors must therefore only be performed by qualified technicians. Contact an authorized Mercedes-Benz Center.

MARNING

Only use seat covers which have been tested and approved by Mercedes-Benz for your vehicle model. Using other seat covers may interfere with or prevent the deployment of the side impact air bags. Contact an authorized Mercedes-Benz Center for availability.

When deployed, the side impact air bags offer additional protection for the thorax of the vehicle occupants on the side of the vehicle on which the impact occurs. However, they do not protect the:

- head
- neck
- arms



Side impact air bags (1) deploy next to the outer seat cushions.

Side impact air bags (1) are deployed:

- on the side on which an impact occurs
- at the start of an accident with a high rate of lateral vehicle deceleration or acceleration, e.g. in a side impact
- depending on whether the seat belt is being used
- independently of the front air bags
- independently of the ETDs

If the vehicle overturns, the side impact air bags are generally not deployed. Exception: if

the system detects high vehicle deceleration or acceleration in a lateral direction and determines that deployment can offer additional protection to that provided by the seat belt.

Side impact air bags will not deploy in side impacts which do not exceed the system's preset deployment thresholds for lateral acceleration/deceleration. You will then be protected by the fastened seat belt.

The side impact air bag on the frontpassenger side will not deploy under the following conditions:


- the OCS detects that the front-passenger seat is not occupied.
- the front-passenger seat belt is not fastened.

The side impact air bag on the frontpassenger side will deploy if the frontpassenger seat belt is fastened, regardless of whether the front-passenger seat is occupied or not.

Head bags

Observe "Important safety notes" (▷ page 38).

Head bags enhance the level of protection for the head, but not the chest or arms, of the vehicle occupants in the front of the vehicle on the side on which the impact occurs.



Head bags ① deploy in the area of the side windows at the front. They are deployed:

- at the start of an accident with a high rate of lateral vehicle deceleration or acceleration, e.g. in a side impact
- on the side on which an impact occurs
- on the driver's side and passenger side, in the event of a vehicle rollover and if the system determines that air bag deployment can offer the vehicle occupants additional protection to that provided by the seat belt
- independently of the use of the seat belt
- independently of the front air bags

Head bags ① will not deploy in side impacts which do not exceed the system's preset deployment thresholds for lateral acceleration/deceleration. You will then be protected by the fastened seat belt.

The head bag on the front-passenger side will not deploy under the following conditions:

- the OCS detects that the front-passenger seat is not occupied.
- the front-passenger seat belt is not fastened.

The head bag on the front-passenger side will deploy if the front-passenger seat belt is fastened, regardless of whether the frontpassenger seat is occupied or not.

Occupant Classification System (OCS)

How the Occupant Classification System works

The Occupant Classification System (OCS) categorizes the occupant on the front-passenger seat using a weight sensor. The front-passenger front air bag and the front-passenger knee bag are deactivated automatically for certain weight categories. The current status. When the current status. When the current status when the front-passenger front air bag and the front-passenger front air bag and the front-passenger knee bag are deactivated.

The system does not deactivate:

- the side impact air bag
- the front-passenger head bag
- the Emergency Tensioning Devices

To be classified correctly, the front passenger must sit:

- with the seat belt fastened correctly
- in a position that is as upright as possible with their back against the seat backrest
- · with their feet on the floor

If the front-passenger's weight is transferred to another object in the vehicle (e.g. by leaning on armrests), OCS may not be able to approximate the occupant's weight category.

If the front-passenger seat, the seat cover or the seat cushion are damaged, have the necessary repair work carried out at an authorized Mercedes-Benz Center.

For safety reasons, Mercedes-Benz recommends that you only use seat accessories that have been approved by Mercedes-Benz.

Both the driver and the front passenger should always use the reference indicator lamp as an indication of whether or not the front passenger is properly positioned.

If the ASSENGER AIR BAG OFF indicator lamp illuminates when an adult or someone larger than a small individual is in the front-passenger seat, have the front passenger reposition himself or herself in the seat until the ASSENGER AIR BAG OFF indicator lamp goes out.

In the event of a collision, the air bag control unit will not allow front-passenger front air bag and front-passenger knee bag deployment when the OCS has classified the front-passenger occupant as weighing as much as or less than a typical 12 month old child in a standard child restraint or if the front-passenger seat is classified as being unoccupied.

Safety

When the OCS senses that the frontpassenger seat occupant is classified as being up to or less than the weight of a typical 12-month-old child in a standard child restraint, the RAG OFF indicator lamp will illuminate when the engine is started and remain illuminated. This indicates that the front-passenger front air bag and the front-passenger knee bag are deactivated.

When the OCS senses that the frontpassenger seat is classified as being empty, the <u>PASSENGER AIR BAG OFF indicator</u> lamp will illuminate when the engine is started and remain illuminated. This indicates that the front-passenger front air bag and the front-passenger knee bag are deactivated.

When the OCS senses that the frontpassenger seat occupant is classified as being heavier than the weight of a typical 12month-old child seated in a standard child restraint or as being a small individual (such as a young teenager or a small adult), the PASSENGER AIR BAG OFF indicator lamp will illuminate for approximately 6 seconds when the engine is started. Depending on occupant weight sensor readings from the seat, it will then remain illuminated or go out. If the *B* PASSENGER AIR BAG OFF indicator lamp is illuminated, the front-passenger front air bag and the frontpassenger knee bag are deactivated. If the PASSENGER AIR BAG OFF indicator lamp is not illuminated, the front-passenger front air bag and the front-passenger knee bag are activated.

When the OCS senses that the frontpassenger seat occupant is classified as an adult or someone larger than a small individual, the <u>Star</u> PASSENGER AIR BAG OFF indicator lamp will illuminate for approximately six seconds when the engine is started and then go out. This indicates that the front-passenger front air bag and the front-passenger knee bag are activated. If the RASSENGER AIR BAG OFF indicator lamp is illuminated, the frontpassenger front air bag and the frontpassenger knee bag are deactivated and are not deployed.

If the PASSENGER AIR BAG OFF indicator lamp is not illuminated, the frontpassenger front air bag and the frontpassenger knee bag are activated and are deployed:

- in certain front impacts
- independently of the side impact air bag and head bag
- if the impact has exceeded a predetermined threshold value for deployment

If the front-passenger front air bag is deployed, the rate of inflation will be influenced by:

- the rate of vehicle deceleration as assessed by the air bag control unit
- the front passenger's weight category as determined by the OCS

For further information, see "Air bag display messages" (▷ page 211).

MARNING

Children under 12 years must be secured correctly in a suitable infant or child restraint system or booster seat suitable for the size and weight of the child.

The infant or child restraint must be properly secured with the vehicle's seat belt fully in accordance with the child seat manufacturer's instructions.

Occupants, in particular children, must sit as upright as possible, fasten the seat belt correctly and use a suitable infant restraint system, child restraint system or booster seat suitable for the size and weight of the child.

Children can be seriously or even fatally injured by an air bag deploying.

Observe the following information:

- Your vehicle is equipped with air bag technology designed to deactivate the front-passenger front air bag and the frontpassenger knee bag in your vehicle when the system senses the weight of a typical 12-month-old child or less along with the weight of a standard appropriate child restraint on the front-passenger seat.
- A child in a rear-facing child restraint system on the front-passenger seat will be seriously injured or even killed if the frontpassenger front air bag inflates in a collision despite the air bag technology installed in your vehicle, which could occur under some circumstances.
- If you must install a rearward-facing child restraint on the front-passenger seat, make sure the Second PASSENGER AIR BAG OFF indicator lamp is illuminated, indicating that the front-passenger front air bag and front-passenger knee bag are deactivated. If the Second PASSENGER AIR BAG OFF indicator lamp does not light up or goes out when a rearward-facing child restraint system is installed, please check installation. Periodically check the 🔀 PASSENGER AIR BAG OFF indicator lamp while driving to make sure the PASSENGER AIR BAG OFF indicator lamp is illuminated. If the 🔀 PASSENGER AIR BAG OFF indicator lamp goes out or remains out do not carry a child on the front-passenger seat.
- A child in a rearward-facing child restraint system on the front-passenger seat will be seriously injured or even killed if the frontpassenger air bag is deployed.

- When securing a child in a child restraint system on the front-passenger seat, you must:
- move the front-passenger seat as far back as possible
- use a child restraint system that is suitable for the age, size and weight of the child
- observe the manufacturer's installation instructions in order to install and secure the child restraint system correctly.
- For children larger than the typical 12month-old child, the front-passenger front air bag may or may not be activated.

If the driver's air bag deploys, this does not mean that the front-passenger front air bag will also deploy.

The OCS may have detected that the seat:

- is either empty or occupied by a person with a weight up to that of a typical twelvemonth-old child seated in a standard child restraint
- is occupied by a small individual, such as a young teenager or a small adult
- is occupied by a child in a child restraint system, whose weight is greater than that of a typical twelve-month-old child.

These are examples of when the OCS deactivates the front-passenger front air bag and front-passenger knee bag. Deactivation takes place although the collision fulfills the criteria for deploying the driver's air bag.



If the SmartKey has been removed from the ignition lock or is in position **0**,

Safety

 PARE BASE
 OFF 2000

 Indicator lamp (1) does not light

 up.

The ON PRESENT indicator lamp has no function. It lights up briefly when the ignition is switched on and then goes out again.

MARNING

If the red 💽 SRS warning lamp in the instrument cluster and the 🔀 PASSENGER AIR BAG OFF indicator lamp light up simultaneously, the OCS is malfunctioning. The front-passenger front air bag and the front-passenger knee bag will be deactivated in this case. Have the system checked as soon as possible by qualified technicians. Consult an authorized Mercedes-Benz Center.

Only have the seat repaired at an authorized Mercedes-Benz Center.

In order to ensure correct operation of the air bag system and OCS:

- sit with the seat belt fastened correctly and in a position that is as upright as possible with your back against the backrest.
- while seated, an occupant should not position themselves in such a way as to cause their weight to be lifted from the seat cushion as this may result in OCS being unable to correctly assess the occupant's weight category.
- read and observe all warnings in this section.

System self-test

The **PASSAGE** of the part of t

- turn the SmartKey to position 1 or 2 in the ignition lock
- press the KEYLESS-GO Start/Stop button once or twice

If an adult occupant is sitting properly on the front-passenger seat and the OCS classifies the occupant as an adult, the research of the occupant as a dult, the resear

If the seat is not occupied and the OCS classifies the front passenger seat as being unoccupied, the reaction of the indicator lamp will illuminate and not go out.

If the PASSENGER AIR BAG OFF indicator lamp does not illuminate, the system is not functioning. Consult an authorized Mercedes-Benz Center before seating a child on the front-passenger seat.

For more information, see "Problems with the Occupant Classification System" (> page 46).

Never place anything between seat cushion and child seat (e.g. a pillow), since it reduces the effectiveness of the OCS. The underside and rear side child restraint system must be placed entirely on the seat cushion and the backrest of the front-passenger seat backrest.

If necessary, adjust the tilt of the passenger seat backrest.

An incorrectly mounted child seat could cause injuries to the child in case of an accident, instead of increasing protection for the child. Follow the manufacturer's instructions for installation of child restraint systems.

46 Occupant safety

Problems with the Occupant Classification System

Problem	Possible causes/consequences and Solutions
The MARKEN GFFSF indicator lamp illuminates and remains illuminated. The person on the front-passenger seat:	 The OCS is malfunctioning. Have the OCS checked as soon as possible at an authorized Mercedes-Benz Center. Observe the additional display messages in the multifunction display (▷ page 211).
 has the weight of a typical adult has been determined by the system not to 	

MARNING

be a child

If the *PASSENGER AIR BAG OFF* indicator lamp illuminates and remains illuminated when the weight of a typical adult or an individual that is the size of a typical adult has been detected on the front-passenger seat, do not allow any occupant to use the front-passenger seat until the system has been repaired.

Problem	Possible causes/consequences and Solutions
 The MERGEN OFF ALL OF	 The OCS is malfunctioning. Make sure there is nothing between the seat cushion and the child seat. Check the installation of the child restraint system. Make sure that no objects are applying additional weight onto the seat. If the present of the provided of the child on the front-passenger seat as long as the OCS is not functioning. Observe the additional display messages in the multifunction display (▷ page 211).

If the ASSENGER AIR BAG OFF indicator lamp does not illuminate or remains out with the weight of a typical 12-month-old child in a standard child restraint or less, or is unoccupied, on the front-passenger seat, do not transport a child on the front-passenger seat until the system has been repaired.

PRE-SAFE[®] (preventative occupant protection)

 AMG vehicles do not include the PRE-SAFE[®] system.

The PRE-SAFE[®] system reduces the impact of an accident on vehicle occupants, as long as their seat belts have been fastened correctly. Although your vehicle is equipped with a PRE-SAFE[®] system, the possibility of injury in the event of an accident cannot be ruled out. You should therefore always drive carefully and adapt your driving style to the prevailing road, weather and traffic conditions.

PRE-SAFE[®] takes preemptive measures to protect occupants in certain hazardous situations.

 $\mathsf{PRE}\text{-}\mathsf{SAFE}^{\texttt{R}}$ intervenes:

- if BAS intervenes, e.g. in emergency braking situations
- if BAS PLUS intervenes powerfully on vehicles with DISTRONIC PLUS
- if, on vehicles with DISTRONIC PLUS, the radar sensor system detects an imminent danger of collision in certain situations
- in critical driving situations, e.g. when physical limits are exceeded and the vehicle understeers or oversteers severely

PRE-SAFE[®] takes the following measures depending on the hazardous situation detected:

- the seat belts are pre-tensioned.
- on vehicles with memory function for the front-passenger seat: the front-passenger seat is adjusted if it is in an unfavorable position.
- if the vehicle skids, the side windows are closed so that only a small gap remains.

If the hazardous situation passes without resulting in an accident, PRE-SAFE[®] slackens the belt pretensioning. All settings made by PRE-SAFE[®] can then be reversed.

If the seat belts are not released:

Move the backrest or seat back slightly, but only when the vehicle is stationary. The belt pretensioning is reduced and the locking mechanism is released.

Make sure that nobody can become trapped as you adjust the seat.

Make sure that there are no objects in the footwell or behind the seats when resetting the seats. There is a risk that the seats and/or the objects could be damaged.

More information about seat-belt adjustment, a convenience function integrated into PRE-SAFE[®], can be found in the "Seat-belt adjustment" section (> page 51).

NECK-PRO head restraints

The NECK-PRO head restraints increase protection to the driver's and front passenger's head and neck. To this end, the NECK-PRO head restraints on the driver's and front-passenger seats are moved forwards and upwards in the event of a rear-end collision of a certain severity. This provides better head support.

Do not secure any objects (e.g. coat hangers) on the NECK-PRO head restraints. Otherwise, the NECK-PRO head restraints may not function properly, or in the event of a rear-end collision may not be able offer the level of protection they are designed to provide.

Seat or head restraint covers can cause a malfunction when the NECK-PRO head restraints are activated or when the side impact air bags are deployed, or they can prevent this completely. The NECK-PRO head restraints or side impact air bags can therefore not provide the intended protection. Do not use any seat or head restraint covers.

Safety

If the NECK-PRO head restraints have been triggered in an accident, reset the NECK-PRO head restraints on the driver's and front-passenger seat (▷ page 48). Otherwise, the additional protection will not be available in the event of another rear-end collision. You can recognize when NECK-PRO head restraints have been triggered by the fact that they have moved forwards and can no longer be adjusted.

MARNING

For your protection, drive only with properly positioned head restraints.

Adjust the head restraint so that it is as close to the head as possible and the center of the head restraint supports the back of the head at eye level. This will reduce the potential for injury to the head and neck in the event of an accident or similar situation.

Resetting triggered NECK-PRO head restraints

MARNING

For safety reasons, have the NECK-PRO head restraints checked at an authorized Mercedes-Benz Center after a rear-end collision.

When pushing back the NECK-PRO head restraint cushion, make sure your fingers do not become caught between the head restraint cushion and the cover. Failure to observe this could result in injuries.

Resetting the NECK-PRO head restraints requires a lot of strength. If you have difficulty resetting the NECK-PRO head restraints, have this work carried out at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.



- Tilt the top of the NECK-PRO head restraint cushion forwards in the direction of arrow 1.
- Push the NECK-PRO head restraint cushion down in the direction of arrow (2) as far as it will go.
- Firmly push the NECK-PRO head restraint cushion back in the direction of arrow (3) until the cushion engages.
- Repeat this procedure for the second NECK-PRO head restraint.

Seat belts

Important safety notes

The use of seat belts and infant and child restraint systems is required by law in all 50 states, the District of Columbia, the U.S. territories and all Canadian provinces.

Even where this is not the case, all vehicle occupants should have their seat belts fastened when the vehicle is in motion.

● For further information on infants and children traveling in the vehicle and on infant and child restraint systems, see "Children in the vehicle" (> page 53).

MARNING

Always fasten your seat belt before driving off. Always make sure your passenger is properly restrained. You and your passenger should always wear seat belts.

Failure to wear and properly fasten and position your seat belt considerably increases

your risk of injuries and their likely severity in an accident.

If you are ever in an accident, your injuries could be considerably more severe if you have not fastened your seat belt correctly. If you do not fasten your seat belt, you are much more likely to collide with parts of the vehicle interior or be ejected from it. This may result in serious or fatal injury.

In the same crash, the possibility of serious or fatal injury is considerably reduced if you wear your seat belt properly. The air bags can only offer the intended protection if the occupants are wearing their seat belts properly.

MARNING

Never ride in a moving vehicle with the seat backrest in an excessively reclined position as this can be dangerous. You could slide under the seat belt in a collision. If you slide under it, the seat belt would apply force at the abdomen or neck. That could cause serious or even fatal injuries. The seat backrest and seat belt provide the best restraint when the wearer is in a position that is as upright as possible and the seat belt is properly positioned on the body.

MARNING

Never let more people ride in the vehicle than there are seat belts available. Make sure everyone riding in the vehicle is correctly restrained with a separate seat belt. Never use a seat belt for more than one person at a time.

MARNING

Damaged seat belts or seat belts that have been subjected to stress in an accident must be replaced and their anchoring points must also be checked.

Only use seat belts which have been approved by Mercedes-Benz.

Do not make any modifications to the seat belts. This can lead to unintended activation

of the ETDs or to their failure to activate when necessary.

Do not bleach or dye seat belts as this may severely weaken them. In a crash they may not be able to provide adequate protection.

Have all work carried out only by qualified technicians. Contact an authorized Mercedes-Benz Center.

Correct use of the seat belts

WARNING USE SEAT BELTS PROPERLY

- Seat belts can only work when used properly. Never wear seat belts in any other way than as described in this section, as that could result in serious injuries in the event of an accident.
- Each occupant should wear their seat belt. at all times, because seat belts help reduce the likelihood of and potential severity of injuries in accidents, including rollovers. The integrated restraint system includes SRS (driver front air bag, knee bags, frontpassenger front air bag, side impact air bags, head air bags), Emergency Tensioning Devices (ETDs) and seat belt force limiters. The system is designed to enhance the protection offered to properly belted occupants in certain frontal (front air bags, knee bags and ETDs) and side (side impact air bags, head air bags and ETDs) impacts which exceed preset deployment thresholds.
- Never wear the shoulder belt under your arm, across your neck or off your shoulder. In a frontal crash, your body would move too far forward. That would increase the chance of head and neck injuries. The seat belt would also apply too much force to the ribs or abdomen, which could severely injure internal organs such as your liver or spleen.

Adjust the seat belt so that the shoulder section is located as close as possible to

the middle of the shoulder (it should not touch the neck).

- Position the lap belt as low as possible on your hips and not across the abdomen. If the lap belt is positioned across your abdomen, it could cause serious injuries in a crash.
- Never wear seat belts over rigid or breakable objects in or on your clothing, such as eyeglasses, pens, keys etc., as these might cause injuries.
- Make sure the seat belt is always fitted snugly. Take special care of this when wearing loose clothing.
- Never use a seat belt for more than one person at a time. Do not fasten a seat belt around a person and another person or other objects at the same time.
- Seat belts should not be worn twisted. In a crash, you would not have the full width of the seat belt to distribute impact forces. The twisted seat belt against your body could cause injuries.
- Pregnant women should also always use a lap-shoulder belt. The lap belt portion should be positioned as low as possible on the hips to avoid any possible pressure on the abdomen.
- Place the seat backrest in a position that is as upright as possible.
- Check your seat belt during travel to make sure it is properly positioned.
- Never place your feet on the instrument panel, dashboard, or on the seat. Always keep both feet on the floor in front of the seat.
- When using a seat belt to secure infant restraints, toddler restraints, or children in booster seats, always follow the child seat manufacturer's instructions.

Do not pass seat belts over sharp edges. They could tear.

Do not allow the seat belt to get caught in the door or in the seat adjustment mechanism. This could damage the seat belt.


Never attempt to make modifications to seat belts. This could impair the effectiveness of the seat belts.

Fastening seat belts

MARNING

Children 12 years old and under must be seated and properly secured in an appropriately sized infant restraint, child restraint system, or booster seat recommended for the size and weight of the child. For additional information, see the "Children in the vehicle" section.

A child's risk of serious or fatal injuries is significantly increased if the child restraints are not properly secured in the vehicle and/ or the child is not properly secured in the child restraint.



- ► Adjust the seat and move the backrest to an almost vertical position (▷ page 92).
- Pull the seat belt smoothly through belt loop ①.
- Without twisting it, guide the shoulder section of the seat belt across the middle

Safety

of your shoulder and the lap section across your hips.

- ► Engage belt tongue ② in buckle ③.
- If necessary, pull upwards on the shoulder section of the seat belt to tighten the belt across your body.

The seat belt on the front-passenger side is equipped with a special seat belt retractor to securely fasten a child restraint system in the front-passenger seat. For further information about special seat belt retractors, see (> page 55).

For more information about releasing the seat belt with release button (4), see "Releasing seat belts" (\triangleright page 51).

Seat belt adjustment

 AMG vehicles do not include the seat-belt adjustment function.

The seat-belt adjustment function adjusts the driver's and front-passenger seat belt to the upper body of the occupants.

The belt strap is tightened slightly when:

- you engage the belt tongue in the belt buckle and you then turn the SmartKey to position **2** in the ignition lock.
- the SmartKey is in position **2** in the ignition lock and you then engage the belt tongue in the buckle.

The seat-belt adjustment will apply a retraction force if any slack is detected between the occupant and the seat belt. Do not hold on to the seat belt tightly while it is adjusting. You can switch the seat-belt adjustment on and off in the on-board computer (▷ page 194).

The seat-belt adjustment is an integral part of the PRE-SAFE[®] convenience function. More information about PRE-SAFE[®] can be found in the "PRE-SAFE[®] (preventative occupant protection)" section (\triangleright page 47).

Releasing seat belts

- Press release button ④(▷ page 50) and guide belt tongue ② back towards belt loop ①.
- Make sure that the seat belt is fully rolled up. Otherwise, the seat belt or belt tongue will be trapped in the door or in the seat mechanism. This could damage the door, the door trim panel and the seat belt. Damaged seat belts can no longer fulfill their protective function and must be replaced. Visit a qualified specialist workshop.

Belt warning for the driver and front passenger

Regardless of whether the driver's and frontpassenger seat belts have already been fastened, the 🚁 seat belt warning lamp will light up for six seconds each time the engine is started. It then goes out if the driver and the front passenger have fastened their seat belts.

If the driver's seat belt is not fastened when the engine is started, an additional warning tone will sound. The warning tone goes out after approximately six seconds or once the driver's seat belt is fastened.

If after six seconds the driver's or frontpassenger seat belt is not fastened and the doors are closed, the 🛵 seat belt warning lamp will remain lit:

- until the driver's or front passenger's seat belt is fastened
- once the vehicle has exceeded a speed of 15 mph (25 km/h), in addition a warning tone will sound with increasing intensity for up to 60 seconds or until the driver's or front-passenger seat belt is fastened.

If the driver or front passenger unfastens their seat belt during the journey, the **____** seat belt warning lamp lights up and the warning tone sounds again.

52 Occupant safety

The warning tone ceases after 60 seconds even if the driver or front passenger has still not fastened their seat belt. The 🚁 seat belt warning lamp stops flashing, but remains lit.

once the vehicle has exceeded a speed of 15 mph (25 km/h).

The 🗼 seat belt warning lamp will not go out until:

• both the driver and the front passenger have fastened their seat belts.

or

- the vehicle is stationary and a door is open.

Emergency Tensioning Devices, belt force limiters

The seat belts are equipped with ETDs and seat belt force limiters.

The ETDs tighten the seat belts in an accident, pulling them close against the body.

The ETDs do not correct incorrect seat positions or incorrectly fastened seat belts.

The ETDs do not pull vehicle occupants back towards the backrest.

Seat belt force limiters, when triggered, help to reduce the peak force exerted by the seat belt on the vehicle occupant.

The seat belt force limiters are synchronized with the front air bags, which take on a part of the deceleration force. Thus, the force exerted on the occupant is distributed over a greater area.

The ETDs can only be activated when:

- the ignition is switched on.
- the restraint systems are operational; see "SRS warning lamp" (▷ page 36).

- the belt tongue is engaged in the buckle on each of the three-point seat belts.
- the front-passenger seat is occupied and the belt tongue is engaged in the buckle on the front-passenger side.

The ETDs are triggered depending on the type and severity of an accident:

- if, in the event of a head-on or rear-end collision, the vehicle decelerates or accelerates rapidly in a longitudinal direction during the initial stages of the impact
- if, in the event of a side impact, the vehicle is subjected to high lateral acceleration/ deceleration
- if, in certain situations where the vehicle overturns, the system determines that it can provide additional protection

If the air bags are deployed, you will hear a bang, and a small amount of powder may also be released. Only in rare cases will the bang affect your hearing. The powder that is released generally does not constitute a health hazard. The SRS warning lamp lights up.

MARNING

Pyrotechnic ETDs that were activated must be replaced.

For your safety, when disposing of the pyrotechnic ETDs always follow our safety instructions. These are available at any authorized Mercedes-Benz Center.

I f the front-passenger seat is not occupied, do not engage the seat belt tongue in the buckle on the frontpassenger seat. Otherwise, the Emergency Tensioning Device could be triggered in the event of an accident.

Safety

Children in the vehicle

Child restraint systems

Important safety notes

We recommend that all infants and children be properly secured in an infant or child restraint system at all times while the vehicle is in motion.

The use of seat belts and infant and child restraint systems is required by law in all 50 states, the District of Columbia, the U.S. territories and all Canadian provinces.

Infants and children must always be seated in an appropriate infant or child restraint system recommended for the size and weight of the child. The infant or child restraint system must be properly secured with a three-point seat belt in accordance with the manufacturer's instructions. All infant or child restraint systems must comply with U.S. Federal Motor Vehicle Safety Standards 213 and 225 and Canadian Motor Vehicle Safety Standards 213 and 210.2.

An information label on the child restraint system indicates whether it meets these standards. This information is also provided in the installation instructions supplied with the child restraint system.

Always read and follow the manufacturer's instructions when using an infant or child restraint system or booster seat.

Observe all warning signs in the vehicle interior and on the infant or child restraint.

Children 12 years old and under must be seated and properly secured in an appropriate infant restraint, toddler restraint, or booster seat recommended for the size and weight of the child.

The infant or child restraint system must be correctly secured using the vehicle's seat belt in complete accordance with the child seat manufacturer's instructions.

Occupants, in particular children, must sit as upright as possible, fasten the seat belt

correctly and use a suitable infant restraint system, child restraint system or booster seat suitable for the size and weight of the child. Children can be seriously or even fatally injured by an air bag deploying. Observe the following information:

- Your vehicle is equipped with air bag technology designed to deactivate the front-passenger front air bag in your vehicle when the system senses the weight of a typical 12-month-old child or less along with the weight of a standard appropriate child restraint on the passenger seat.
- A child in a rearward-facing child restraint system on the front-passenger seat could be seriously injured or even killed if the front-passenger air bag inflates in a collision despite the air bag technology installed in your vehicle, which could occur under some circumstances.
- · If you install a rearward-facing child restraint on the front-passenger seat, make sure that the S PASSENGER AIR BAG OFF indicator lamp is illuminated, indicating that the front-passenger front air bag is deactivated. Should the PASSENGER AIR BAG OFF indicator lamp not illuminate or go out while a rearwardfacing child restraint system is installed, please check installation. Periodically check the 🔀 PASSENGER AIR BAG OFF indicator lamp while driving to make sure it is illuminated. If the 🔀 PASSENGER AIR BAG OFF indicator lamp goes out or remains out, do not transport a child on the front-passenger seat.
- A child in a rearward-facing child restraint system on the front-passenger seat can be seriously injured or even killed if the frontpassenger air bag is deployed.

- When securing a child in a child restraint system on the front-passenger seat, you must:
 - move the front-passenger seat as far back as possible
 - use a child restraint system that is suitable for the age, size and weight of the child
 - observe the manufacturer's installation instructions in order to install and secure the child restraint system correctly.
- For children larger than the typical 12month-old child, the front-passenger front air bag may or may not be activated.

▲ WARNING

Infants and small children should never share a seat belt with another occupant. In the event of an accident, they could be crushed between the occupant and seat belt.

A child's risk of serious or fatal injuries is significantly increased if the child restraints are not properly secured in the vehicle and/ or the child is not properly secured in the child restraint.

Children that are too large for a child restraint must travel in seats using normal seat belts. Position the shoulder belt across the chest and shoulder, not face or neck. A booster seat may be necessary to achieve proper seat belt positioning for children over 41 lb (18 kg) until they reach a height where a lap-shoulder belt fits properly without a booster.

When the child restraint is not in use, remove it from the vehicle or secure it with the seat belt to prevent the child restraint from becoming a projectile in the event of an accident.

If an infant or child is traveling in the vehicle:

 Secure the infant or child with an appropriate infant or child restraint recommended for the child's age and weight.

Make sure that the infant or child is properly secured at all times while the vehicle is in motion.

MARNING

When leaving the vehicle, always remove the SmartKey from the ignition lock. Always take the SmartKey with you and lock the vehicle. Do not leave children unattended in the vehicle, even if they are secured in a child restraint system, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury. The children could:

- injure themselves on parts of the vehicle
- be seriously or fatally injured through excessive exposure to extreme heat or cold
- injure themselves or cause an accident with vehicle equipment that can be operated even if the SmartKey is removed from the ignition lock or removed from the vehicle, such as seat adjustment, steering wheel adjustment, or the memory function

If children open a door, they could injure other persons or get out of the vehicle and injure themselves or be injured by following traffic.

Do not expose the child restraint system to direct sunlight. The child restraint system's metal parts, for example, could become very hot, and the child could be burned on these parts.

Do not carry heavy or hard objects in the passenger compartment unless they are firmly secured in place.

Unsecured or improperly positioned cargo increases a child's risk of injury in the event of:

- strong braking maneuvers
- sudden changes of direction
- an accident

Special seat belt retractor

The seat belt on the front-passenger side is equipped with a special seat belt retractor. When activated, the special seat belt retractor ensures the seat belt will not slacken once the child restraint system has been secured.

Installing a child restraint system:

- Always comply with the manufacturer's installation instructions.
- ▶ Pull the seat belt smoothly from the inertia reel.
- Engage the seat belt tongue in the belt buckle.

Activating the special seat belt retractor:

- Pull the seat belt out fully and let the inertia reel retract it again. While the seat belt is retracting, you should hear a ratcheting sound. The special seat belt retractor is enabled.
- Push down on the child restraint system to take up any slack.

Removing a child restraint system/ deactivating the special seat belt retractor:

- ► Always comply with the manufacturer's installation instructions.
- ▶ Press the seat belt release button and guide the belt tongue to the belt outlet. The special seat belt retractor is deactivated.

WARNING

Never release the seat belt buckle while the vehicle is in motion, since the special seat belt retractor will be deactivated.

Panic alarm



- ► To activate: press PANIC button (1) for at least one second. An alarm sounds and the exterior lighting flashes.
- ► To deactivate: press PANIC button (1) again.

or

▶ Insert the SmartKey into the ignition lock.

or

- ▶ Press the KEYLESS-GO Start/Stop button. The KEYLESS-GO key must be in the vehicle.
- USA only:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and

2. this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

The product label with FCC ID and IC certification number can be found in the battery case of the SmartKey.

Canada only:

This device complies with RSS-Gen of Industry Canada. Operation is subject to the following two conditions:

Safety

1. This device may not cause interference, and

2. this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

The product label with FCC ID and IC certification number can be found in the battery case of the SmartKey.

Driving safety systems

Driving safety systems overview

In this section, you will find information about the following driving safety systems:

- ABS (Anti-lock Braking System)
- BAS (Brake Assist System)
- BAS PLUS (Brake Assist System Plus)
- ESP[®] (Electronic Stability Program)
- EBD (Electronic Brake force Distribution)
- ADAPTIVE BRAKE
- PRE-SAFE[®] Brake

Important safety notes

MARNING

The following factors increase the risk of accidents:

- Excessive speed, especially in turns
- Wet and slippery road surfaces
- Following another vehicle too closely

The driving safety systems described in this section cannot reduce these risks or prevent the natural laws of physics from acting on the vehicle. They cannot increase braking or steering efficiency beyond that afforded by the condition of the vehicle brakes and tires or the traction afforded.

Only a safe, attentive, and skillful driver can prevent accidents.

The capabilities of a vehicle equipped with the driving safety systems described in this section must never be exploited in a reckless or dangerous manner which could jeopardize the user's safety or the safety of others.

Always adjust your driving style to the prevailing road and weather conditions and keep a safe distance to other road users and objects on the street.

If a driving system malfunctions, other driving safety systems may also switch off. Observe indicator and warning lamps that may come on as well as messages in the multifunction display that may appear.

Please note that the driving safety systems described only work as effectively as possible when there is adequate contact between the tires and the road surface. Pay particular attention to the information regarding tires, recommended minimum tire tread depths etc. in the "Wheels and tires" section (▷ page 294).

In wintry driving conditions, always use winter tires (M+S tires) and if necessary, snow chains. Only in this way will the driving safety systems described in this section work as effectively as possible.

ABS (Anti-lock Braking System)

Important safety notes

Observe the "Important safety notes" section (▷ page 56).

ABS regulates brake pressure in such a way that the wheels do not lock when you brake. This allows you to continue steering the vehicle when braking.

ABS works from a speed of about 5 mph (8 km/h) upwards, regardless of road-surface conditions. ABS works on slippery surfaces, even if you only brake gently.

If the ABS malfunctions, other driving systems such as the BAS or the ESP[®] are also switched off. Observe indicator and warning lamps that may come on as well as messages in the multifunction display that may appear.

If the ABS malfunctions, the wheels may lock during hard braking, reducing the steering capability and extending the braking distance.

The () warning lamp in the instrument cluster lights up when the ignition is switched on. It goes out when the engine is running.

Brakes

If ABS intervenes when braking, you will feel a pulsing in the brake pedal.

- If ABS intervenes: continue to depress the brake pedal vigorously until the braking situation is over.
- To make a full brake application: depress the brake pedal with full force.

The pulsating brake pedal can be an indication of hazardous road conditions, and functions as a reminder to take extra care while driving.

▲ WARNING

Do not pump the brake pedal. Use firm, steady brake pedal pressure instead. Pumping the brake pedal defeats the purpose of the ABS and significantly reduces braking effectiveness.

BAS (Brake Assist System)

Observe the "Important safety notes" section (▷ page 56).

BAS operates in emergency braking situations. If you depress the brake pedal quickly, BAS automatically boosts the braking force, thus shortening the stopping distance.

Keep the brake pedal firmly depressed until the emergency braking situation is over. ABS prevents the wheels from locking. The brakes will function as usual once you release the brake pedal. BAS is deactivated.

If the BAS malfunctions, the brake system still functions, but without the additional brake boost available that the BAS would normally provide in an emergency braking maneuver. Therefore, the braking distance may increase.

BAS PLUS (Brake Assist System Plus)

BAS PLUS is only available in vehicles equipped with DISTRONIC PLUS.

 Observe the "Important safety notes" section (▷ page 56).

BAS PLUS assists you when braking in a hazardous situation at speeds of over 20 mph (30 km/h), and uses the radar sensor system to assess traffic conditions.

This device has been approved by the FCC as a "Vehicular Radar System". The radar sensor is intended for use in an automotive radar system only. Removing, altering or tampering with the device will void any warranties, and is not permitted by the FCC. Do not tamper with, alter, or use in any non-approved way.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

With the help of the radar sensor system, BAS PLUS can detect obstacles that are in the path of your vehicle for an extended period of time.

BAS PLUS can also react to stationary obstacles, e.g. stopped or parked vehicles, at speeds of up to approximately 40 mph (70 km/h).

Should you approach an obstacle and BAS PLUS has detected a risk of collision, BAS PLUS calculates the braking force necessary to avoid a rear-end collision. Should you apply the brakes forcefully, BAS PLUS can automatically increase the braking force to a level suitable for the traffic conditions.

If BAS PLUS demands particularly high braking force, preventative passenger protection measures (PRE-SAFE[®]) are activated simultaneously.

Safety

 Keep the brake pedal depressed until the emergency braking situation is over.
 ABS prevents the wheels from locking.

The brakes will work normally again if:

- you release the brake pedal.
- there is no longer any danger of a rear-end collision.
- no obstacle is detected in front of your vehicle.

BAS PLUS is then deactivated.

For BAS PLUS to assist you when driving, the radar sensor system must be switched on and operational; see "Radar sensor system" in the index.

BAS PLUS cannot always clearly identify objects and complex traffic situations. BAS PLUS cannot intervene in these cases.

There is a risk of an accident. Always pay careful attention to the traffic situation and be ready to brake.

In particular, the detection of obstacles can be impaired if there is:

- dirt on the sensors or anything else covering the sensors
- snow or heavy rain
- interference by other radar sources
- the possibility of strong radar reflections, for example in parking garages
- a narrow vehicle traveling in front, e.g. a motorbike
- a vehicle traveling in front on a different line

BAS PLUS does not react:

- to people or animals
- to oncoming vehicles
- to crossing traffic
- in curves

As a result, BAS PLUS cannot intervene in critical situations. There is a risk of an accident. Always pay careful attention to the traffic situation and be ready to brake.

Following damage to the front end of the vehicle, have the configuration and operation of the radar sensors checked at a qualified specialist workshop. This also applies to collisions at low speeds where there is no visible damage to the front of the vehicle.

If BAS PLUS is not available due to a malfunction in the radar sensor system, the brake system remains available with full brake boosting effect and BAS.

ESP® (Electronic Stability Program)

Important safety notes

See the "Important safety notes" section
 (▷ page 56).

If ESP[®] detects that the vehicle is deviating from the direction desired by the driver, one or more wheels are braked to stabilize the vehicle. If necessary, the engine output is also modified to keep the vehicle on the desired course within physical limits. ESP[®] assists the driver when pulling away on wet or slippery roads. ESP[®] can also stabilize the vehicle during braking.

If ESP[®] intervenes, the ESP[®] warning lamp flashes in the instrument cluster.

Under no circumstances should you deactivate ESP[®] when the ESP[®] warning lamp in the instrument cluster flashes. Proceed as follows:

- when driving off, apply as little throttle as possible.
- while driving, ease up on the accelerator pedal.
- adapt your speed to suit the prevailing road and weather conditions.

Failure to observe these guidelines could cause the vehicle to skid. ESP[®] cannot prevent accidents resulting from excessive speed.

■ The ignition must be switched off if the vehicle is being towed with the front or rear axle raised. Otherwise, ESP[®] may intervene and damage the brake system.

Only use wheels with the recommended tire sizes. Only then will ESP[®] function properly.

ETS (Electronic Traction System)

 Observe the "Important safety notes" section (▷ page 56).

Traction control is part of ESP[®].

If the drive wheels spin, traction control brakes them individually. This enables you to pull away and accelerate on slippery surfaces, for example if the road surface is slippery on one side.

Traction control remains active if you deactivate ESP[®].

Deactivating/activating ESP[®] (except AMG vehicles)

▲ WARNING

ESP[®] should not be deactivated during normal driving other than in the circumstances described below. Disabling

the system will reduce vehicle stability in driving maneuvers.

Do not deactivate $\mathsf{ESP}^{\texttt{®}}$ when the emergency or spare wheel is mounted.

ESP[®] is activated automatically when the engine is started.

It may be best to deactivate ESP[®] in the following situations:

- when using snow chains
- in deep snow
- on sand or gravel

Switch on ESP[®] immediately if one of the previously stated conditions is no longer met. Otherwise, ESP[®] cannot stabilize the vehicle if it begins to lurch or when a wheel spins.

If you deactivate ESP®:

- ESP[®] no longer improves driving stability.
- engine torque is not limited and the drive wheels are able to spin. The spinning wheels produce a cutting effect for better traction.
- traction control is still activated.
- ESP[®] still provides support when you brake.

If ESP[®] is deactivated and one or more wheels start to spin, the ESP[®] warning lamp in the instrument cluster flashes. In such situations, ESP[®] will not stabilize the vehicle.



60 Driving safety systems

MARNING

When the series ESP® OFF warning lamp is lit, ESP® is deactivated.

If the 📻 ESP[®] warning lamp and the 😨 ESP[®] OFF warning lamp remain lit, ESP[®] is not available due to a malfunction.

When ESP[®] is deactivated or not operational, vehicle stability in standard driving maneuvers is reduced.

Adapt your speed and driving to the prevailing road conditions and to the non-operating status of the ESP[®].

Avoid spinning the driven wheels for an extended period with ESP[®] deactivated. You could otherwise damage the drivetrain.

Deactivating/activating ESP[®] (AMG vehicles)

Activating/deactivating SPORT handling mode

MARNING

The SPORT handling mode should not be switched on during normal driving.

Switching on the SPORT handling mode will result in the following:

- no restriction to the engine torque
- system supported traction control is limited

The SPORT handling mode is designed for driving on closed tracks when the vehicle's own natural oversteer and understeer characteristics are desired and requires a highly skilled and experienced driver able to handle these critical driving situations. You could lose control of your vehicle and cause an accident.

Please be aware of these limits when you switch on the SPORT handling mode.

Do not switch on the SPORT handling when a spare wheel is mounted.

ESP[®] is activated automatically when the engine is started.

Vehicles with ECO start/stop function: the ECO start/stop function switches the engine off automatically when the vehicle comes to a stop. The engine starts automatically when the driver wants to pull away again. ESP[®] remains in its previously selected status. Example: if ESP[®] was deactivated before the engine was switched off, ESP[®] remains deactivated when the engine is switched on again.

It may be best to activate SPORT handling mode in the following situations:

- when using snow chains
- · in deep snow
- on sand or gravel

MARNING

Switch off the SPORT handling mode and switch on the ESP[®] immediately if the aforementioned circumstances do not apply anymore. Otherwise the SPORT handling mode will only stabilize the vehicle to a limited extent when it is starting to skid or a wheel is spinning.

When SPORT handling mode is activated:

- ESP[®] only improves driving stability to a limited degree.
- engine torque is only restricted to a limited degree, and the drive wheels are able to spin. The spinning wheels produce a cutting effect for better traction.
- traction control is still activated.
- ESP[®] still provides support when you brake firmly.

If SPORT handling mode is activated and one or more wheels start to spin, the 🛒 ESP[®] warning lamp in the instrument cluster flashes. ESP[®] only stabilizes the vehicle to a limited degree.



- ► To activate: briefly press button ①. The SPORT SPORT handling mode warning lamp in the instrument cluster lights up. The SPORT handling mode message appears in the multifunction display.
- ► To deactivate: briefly press button ①. The SPORT SPORT handling mode warning lamp in the instrument cluster goes out.

Deactivating/activating ESP®

▲ WARNING

The $\ensuremath{\mathsf{ESP}}^\ensuremath{^{\ensuremath{\mathbb{B}}}}$ should not be switched off during normal driving.

Disabling of the system will result in the following:

- no restriction to engine torque
- loss of system-supported traction control

"ESP[®] OFF" is designed for driving on closed tracks when the vehicle's natural oversteer and understeer characteristics are desired and requires a highly skilled and experienced driver able to handle these critical driving situations.

You could lose control of your vehicle and cause an accident.

Please be aware of these limits when you switch off the ESP[®].

Do not switch off the $\ensuremath{\mathsf{ESP}}^{\ensuremath{\texttt{B}}}$ when a spare wheel is mounted.

ESP[®] is activated automatically when the engine is started.

Vehicles with ECO start/stop function: the ECO start/stop function switches the engine off automatically when the vehicle comes to a stop. The engine starts automatically when the driver wants to pull away again. ESP[®] remains in its previously selected status. Example: if ESP[®] was deactivated before the engine was switched off, ESP[®] remains deactivated when the engine is switched on again.

It may be best to deactivate ESP[®] in the following situations:

- when using snow chains
- in deep snow
- on sand or gravel

Switch on ESP[®] immediately if one of the previously stated conditions is no longer met. Otherwise, ESP[®] cannot stabilize the vehicle if it begins to lurch or when a wheel spins.

If you deactivate ESP[®]:

- ESP[®] no longer improves driving stability.
- engine torque is no longer limited and the drive wheels are able to spin. The spinning wheels produce a cutting effect for better traction.
- traction control is still activated.
- PRE-SAFE[®] is no longer available, nor is it activated if you brake firmly and ESP[®] intervenes.
- PRE-SAFE[®] Brake is no longer available, nor is it activated if you brake firmly and ESP[®] intervenes.
- $\mbox{-} \mbox{ESP}^{\mbox{\scriptsize \ensuremath{\mathbb{R}}}}$ still provides support when you brake firmly.

If ESP^{\circledast} is deactivated and one or more wheels start to spin, the $\fbox ESP^{\circledast}$ warning lamp in

62 Driving safety systems

the instrument cluster does not flash. In such situations, ESP[®] will not stabilize the vehicle.



The **OFF** message appears in the multifunction display.

MARNING

When the $\boxed{\mathbb{F}_{F}}$ ESP[®] OFF warning lamp is lit, ESP[®] is deactivated.

If the ESP® warning lamp and the

ESP[®] OFF warning lamp remain lit,

ESP[®] is not available due to a malfunction.

When ESP[®] is deactivated or not operational, vehicle stability in standard driving maneuvers is reduced.

Adapt your speed and driving to the prevailing road conditions and to the non-operating status of the ESP[®].

- Avoid spinning the driven wheels for an extended period with ESP[®] deactivated. You could otherwise damage the drivetrain.
- ► To activate: briefly press button ①. The ______ ESP[®] OFF warning lamp in the instrument cluster goes out. The _____ON message appears in the multifunction display.

EBD (electronic brake force distribution)

Observe the "Important safety notes" section (▷ page 56).

EBD monitors and controls the brake pressure on the rear wheels to improve driving stability while braking.

If EBD has malfunctioned, the braking system remains available with full brake boosting effect. However, the rear wheels can still lock, e.g. under full braking. This could cause you to lose control of your vehicle and cause an accident. You should therefore adapt your driving style to the different handling characteristics.

Observe the notes on warning and indicator lamps (▷ page 230) as well as display messages (▷ page 202).

ADAPTIVE BRAKE

ADAPTIVE BRAKE enhances braking safety and offers increased braking comfort. In addition to the braking function, ADAPTIVE BRAKE also has the HOLD function (▷ page 168) and hill start assist (▷ page 134). For further information, see Driving tips (▷ page 153).

PRE-SAFE[®] Brake

PRE-SAFE[®] Brake is only available in vehicles with DISTRONIC PLUS.

 Observe the "Important safety notes" section (▷ page 56).

PRE-SAFE[®] Brake can help you to minimize the risk of a frontal collision with a vehicle ahead or reduce the effects of such a collision. If PRE-SAFE[®] Brake has detected a risk of collision, you will be warned visually and acoustically as well as by automatic braking. $\mbox{PRE-SAFE}^{\circledast}$ Brake cannot prevent a collision without your intervention.

At speeds above approximately

20 mph (30 km/h), this function warns you when you are rapidly approaching the vehicle in front. An intermittent warning tone will then sound and the A distance warning lamp in the instrument cluster will light up.

Brake immediately in order to increase the distance from the vehicle in front.

or

 Take evasive action provided it is safe to do so.

At speeds of above approximately 20 mph (30 km/h), if the driver and front passenger have fastened their seat belts, PRE-SAFE[®] Brake can:

- brake the vehicle automatically at speeds up to approximately 124 mph (200 km/h)
- trigger preventative occupant protection measures (PRE-SAFE[®]) (▷ page 47)

Due to the nature of the system, particularly complicated driving conditions may cause unnecessary warnings or the unnecessary intervention of PRE-SAFE[®] Brake. To stop the braking action, you can either depress the accelerator pedal further, activate kickdown or release the brake pedal.

The braking action of PRE-SAFE[®] Brake is ended automatically if:

- your speed drops below approximately 9 mph (15 km/h).
- you maneuver to avoid the obstacle.
- there is no longer any danger of a rear-end collision.
- there is no longer an obstacle detected in front of your vehicle.

USA only: This device has been approved by the FCC as a "Vehicular Radar System". The radar sensor is intended for use in an automotive radar system only. Removing, altering or tampering with the device will void any warranties, and is not permitted by the FCC. Do not tamper with, alter, or use in any non-approved way.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

Canada only: This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

1. This device may not cause interference, and

2. this device must accept any interference received, including interference that may cause undesired operation of the device.

Removal, tampering, or altering of the device will void any warranties, and is not permitted. Do not tamper with, alter, or use in any non-approved way.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

With the help of the radar sensor system, PRE-SAFE[®] Brake can detect obstacles that are in front of your vehicle for an extended period of time.

At speeds up to approximately 40 mph (70 km/h), PRE-SAFE[®] Brake can also react to stationary obstacles, for example stopped or parked vehicles.

If you approach an obstacle and PRE-SAFE[®] Brake detects a risk of collision, the system will initially alert you both visually and acoustically. If you do not brake or take evasive action, the system will warn you by automatically braking the vehicle gently. If there is an increased risk of collision, preventative passenger protection measures (PRE-SAFE[®]) are activated (\triangleright page 47). If the risk of collision remains and you do not brake, take evasive action or accelerate significantly, the vehicle may perform automatic emergency braking. Automatic emergency braking is not performed until immediately prior to an accident that can no longer be avoided.

Even if PRE-SAFE[®] Brake slows the vehicle before an imminent rear-end collision, the system cannot avert a collision without the intervention of the driver. There is a risk of an accident. Brake according to the situation or take evasive action. Delayed intervention by the driver can lead to an accident.

MARNING

PRE-SAFE[®] Brake cannot always detect complex traffic situations properly.

In these cases, PRE-SAFE(R) Brake may:

- give an unnecessary warning and then brake the vehicle
- neither give a warning nor intervene

There is a risk of an accident. Always pay particular attention to the traffic situation and be ready to brake, especially if PRE-SAFE(R) Brake warns you. Terminate the intervention in a non-critical driving situation.

In particular, the detection of obstacles can be impaired if there is:

- dirt on the sensors or anything else covering the sensors
- · snow or heavy rain
- interference by other radar sources
- the possibility of strong radar reflections, for example in parking garages
- a narrow vehicle traveling in front, e.g. a motorbike
- a vehicle traveling in front on a different line

▲ WARNING

PRE-SAFE[®] Brake does not react:

- to people or animals
- · to oncoming vehicles
- to crossing traffic
- in curves

As a result, PRE-SAFE[®] Brake cannot intervene in critical situations. There is a risk of an accident. Always pay careful attention to the traffic situation and be ready to brake. In order to maintain the appropriate distance to the vehicle in front and thus prevent a collision, you must apply the brakes yourself.

► To activate/deactivate: activate or deactivate PRE-SAFE[®] Brake in the onboard computer (▷ page 190). The order of the symbol appears in the multifunction display as long as the HOLD function is not activated (▷ page 168).

On vehicles with Parking Guidance, the $\boxed{\mathbf{D}!}_{\mathbf{C}}$ symbol is displayed when **P** is engaged or is selected or if you drive faster than 22 mph (35 km/h).

For PRE-SAFE[®] Brake to assist you when driving, the radar sensor system must be switched on (\triangleright page 194) and be operational.

Following damage to the front end of the vehicle, have the configuration and operation of the radar sensors checked at a qualified specialist workshop. This also applies to collisions at low speeds where there is no visible damage to the front of the vehicle.

Theft deterrent locking system

Immobilizer

The immobilizer prevents your vehicle from being started without the correct SmartKey. When leaving the vehicle, always take the SmartKey with you and lock the vehicle. The engine can be started by anyone with a valid SmartKey that is left inside the vehicle.

- To activate with the SmartKey: remove the SmartKey from the ignition lock.
- To activate with KEYLESS-GO: switch the ignition off and open the driver's door.
- ► To deactivate: switch on the ignition.
- **1** The immobilizer is always deactivated when you start the engine.

In the event that the engine cannot be started when the starter battery is fully charged, the immobilizer may be faulty. Contact an authorized Mercedes-Benz Center or call 1-800-FOR-MERCedes (in USA) or 1-800-387-0100 (in Canada).

ATA (anti-theft alarm system)

A visual and audible alarm is triggered if the alarm system is armed and you open:

- a door
- the vehicle with the mechanical key
- the trunk lid
- the hood
- the glove box
- the stowage space under the armrest

The alarm is not switched off, even if you close the open door that has triggered it, for example.

If the alarm stays on for more than 30 seconds, the mbrace (USA only) or TELE AID (Canada only) emergency call system initiates a call to the Customer Assistance Center automatically. The emergency call system initiates the call provided that:

- you have subscribed to the mbrace/ TELE AID service.
- the mbrace/TELE AID service has been activated properly.
- the required mobile phone, power supply and GPS are available.



- To arm: lock the vehicle with the SmartKey or KEYLESS-GO. Indicator lamp ① flashes. The alarm system is armed after approximately 15 seconds.
- ► **To disarm:** unlock the vehicle with the SmartKey or KEYLESS-GO.
- ► To stop the alarm using the SmartKey: insert the SmartKey into the ignition lock. The alarm is switched off.

or

- Press the for for button on the SmartKey.
 The alarm is switched off.
- ► To stop the alarm using KEYLESS-GO: grasp the outside door handle. The SmartKey must be outside the vehicle. The alarm is switched off.

or

 Press the Start/Stop button on the dashboard. The SmartKey must be inside the vehicle.

The alarm is switched off.

Useful information	68
SmartKey	68
Doors	74
Trunk	77
Side windows	80
Roof	82

Useful information

This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.

 Please read the information on qualified specialist workshops (▷ page 23).

SmartKey

Important safety notes

MARNING

When leaving the vehicle, always remove the SmartKey from the ignition lock. Always take the SmartKey with you and lock the vehicle. Do not leave children unsupervised in the vehicle, even if they are secured in a child restraint system, and do not give them access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury. They could:

- · injure themselves on vehicle parts
- be seriously or fatally injured by extreme heat or cold
- injure themselves or have an accident with vehicle equipment that may still be in operation even after the SmartKey has been removed from the ignition, such as the seat adjustment, steering wheel adjustment or memory function.

If children open a door, they could cause severe or even fatal injury to other persons; if they get out of the vehicle, they could injure themselves when doing so or be seriously or even fatally injured by any passing traffic.

Do not expose the child restraint system to direct sunlight. The child restraint system's metal parts, for example, could become very hot, and a child could be burned on these parts.

MARNING

If a key ring is too heavy or too large, the weight acting on the key could cause it to turn in the ignition lock or catch on the steering wheel. This could cause the engine to be switched off suddenly. You may lose control of the vehicle and cause an accident. Do not attach any heavy or large key rings to the key that is inserted in the ignition.

General notes

If you cannot lock or unlock the vehicle with the SmartKey, either the battery in the SmartKey is discharged, the SmartKey is faulty or the starter battery is discharged.

- ► Check the battery in the SmartKey and replace it if necessary (▷ page 71).
- ► Unlock the driver's door using the mechanical key (▷ page 76).
- ► Lock the vehicle using the mechanical key (> page 76).
- Have the starter battery and the battery contacts checked at a qualified specialist workshop.

If the SmartKey is faulty, contact Roadside Assistance or a qualified specialist workshop.

SmartKey functions

The SmartKey centrally locks/unlocks:

- the doors
- the trunk lid
- the glove box
- the stowage compartment in the center console
- the fuel filler flap



- 1 Locks the vehicle
- ② 🗇 Unlocks the trunk lid
- (3) Unlocks the vehicle

When unlocking, the turn signals flash once. When locking, they flash three times.

When it is dark, the surround lighting also comes on if it is activated in the on-board computer (\triangleright page 193).

You can also set an audible signal to confirm that the vehicle has been locked. The audible signal can be activated and deactivated using the on-board computer (\triangleright page 194).

► To unlock centrally: press the button.

If you do not open the vehicle within approximately 40 seconds of unlocking:

- the vehicle is locked again.
- the theft deterrent locking system is armed again.
- ► To lock centrally: press the 🕞 button.

KEYLESS-GO

Important notes on the use of KEYLESS-GO

- Do not keep the KEYLESS-GO key together with:
 - electronic devices, e.g. a mobile phone or another key
 - metallic objects, e.g. coins or metal foil.

This can affect the functionality of KEYLESS-GO.

• Bear in mind that the engine can be started by any of the vehicle occupants if there is a KEYLESS-GO key in the vehicle.

Locking and unlocking centrally

You can start, lock or unlock the vehicle using KEYLESS-GO. To do this, you only need carry the SmartKey with you. You can combine the KEYLESS-GO functions with those of a conventional key, e.g. using KEYLESS-GO to unlock and pressing the _____ button to lock.

When locking and unlocking using KEYLESS-GO, the distance between the SmartKey and the corresponding door handle must not exceed 3 ft (1 m).

KEYLESS-GO checks whether a valid key is in the vehicle by periodically establishing a radio connection between the vehicle and the key. This happens:

- when the external door handles are touched
- when starting the engine
- while the vehicle is in motion



- To unlock the vehicle: touch the inner surface of the door handle.
- ► To lock the vehicle: touch sensor surface ①.
- ► Convenience closing feature: touch recessed sensor surface ② for an extended period (▷ page 81).

70 SmartKey

If you pull on the handle of the trunk lid, only the trunk of the vehicle is unlocked.

Changing the settings of the locking system

You can change the settings of the locking system so that when unlocking, only the driver's door, the lockable stowage compartments in the vehicle interior and the fuel filler flap are unlocked. This is useful if you frequently travel on your own.

- ► To change the setting: press and hold down the _____ and ____ buttons simultaneously for approximately six seconds until the battery check lamp flashes twice (> page 7 1).
- If the setting of the locking system is changed within the signal range of the vehicle, pressing the or button locks or unlocks the vehicle.

The SmartKey now functions as follows:

- ► To unlock centrally: press the button twice.
- ► To lock centrally: press the 🕞 button.

The KEYLESS-GO function is changed as follows:

- ► To unlock the driver's door: touch the inner surface of the door handle on the driver's door.
- To unlock centrally: touch the inner surface of the front-passenger door handle.
- To lock centrally: touch the outer sensor surface on one of the door handles.

Restoring the factory settings

Press the for and for approximately six seconds until the battery check lamp flashes twice.

Mechanical key

General notes

If the vehicle can no longer be locked or unlocked with the SmartKey, use the mechanical key.

If you use the mechanical key to unlock and open the driver's door or the trunk lid, the anti-theft alarm system will be triggered (> page 65).

There are several ways to turn off the alarm:

► To turn the alarm off with the SmartKey: press the on the SmartKey.

or

► Insert the SmartKey into the ignition lock.

or

► To deactivate the alarm with KEYLESS-GO: press the Start/Stop button in the ignition lock. The SmartKey must be in the vehicle.

or

 Lock or unlock the vehicle using KEYLESS-GO. The SmartKey must be outside the vehicle.

If you unlock the vehicle using the mechanical key, the fuel filler flap will not be unlocked automatically.

► To unlock the fuel filler flap: insert the SmartKey in the ignition lock.

Removing the mechanical key



SmartKey 71

Push release catch ① in the direction of the arrow and at the same time, remove mechanical key ② from the SmartKey.

SmartKey battery

Important safety notes

Have the batteries changed at a qualified specialist workshop.

MARNING

Batteries contain toxic substances.

Swallowing batteries can lead to serious health issues or death.

Keep batteries out of the reach of children. Seek medical attention immediately if a battery is swallowed.

The SmartKey batteries contain perchlorate material, which may require special handling and regard for the environment. Observe government disposal guidelines. California residents, see www.dtsc.ca.gov/ HazardousWaste/Perchlorate/ index.cfm.

Checking the battery



Press the g or g button. The battery is working properly if battery check lamp (1) lights up briefly

If battery check lamp (1) does not light up briefly during the test, the battery is discharged.

- ► Changing the battery (▷ page 71)
- You can obtain the battery at a qualified specialist workshop.

Replacing the battery

You require a CR 2025 3 V cell battery.

► Take the mechanical key out of the SmartKey (▷ page 70).



- Press mechanical key (2) into the opening in the SmartKey in the direction of the arrow until battery tray cover (1) opens. When doing so, do not hold cover (1) shut.
- ▶ Remove battery tray cover ①.



- Repeatedly tap the SmartKey against your palm until battery (3) falls out.
- Insert the new battery with the positive terminal facing upwards. Use a lint-free cloth to do so.

Opening/closing

72 SmartKey

- Make sure that the surface of the battery is free from lint, grease and all other forms of contamination.
- Insert the front tabs of battery tray cover ① and then press to close it.
- Insert the mechanical key into the SmartKey.
- Check the function of all SmartKey buttons on the vehicle.

Problems with the SmartKey

Problem	Possible causes/consequences and ► Solutions
You cannot lock or unlock the vehicle using the SmartKey.	 The SmartKey battery is discharged or nearly discharged. Try again to lock/unlock the vehicle using the remote control function of the SmartKey. Point the tip of the SmartKey at the driver's door handle from close range and press the
	 The SmartKey is faulty. Lock (▷ page 76) or unlock (▷ page 76) the vehicle using the mechanical key. Have the SmartKey checked at a qualified specialist workshop.
You can no longer lock or unlock the vehicle using KEYLESS-GO.	 There is interference from a powerful source of radio waves. Lock/unlock the vehicle using the remote control function of the SmartKey. Point the tip of the SmartKey at the driver's door handle from close range and press the <u>-</u>/<u>-</u> button.
	 There is a malfunction with KEYLESS-GO. Lock/unlock the vehicle using the remote control function of the SmartKey. Point the tip of the SmartKey at the driver's door handle from close range and press the/ button. Have KEYLESS-GO checked at a qualified specialist workshop. If this does not work: Check the SmartKey battery (▷ page 71) and replace it if necessary (▷ page 71). Lock (▷ page 76) or unlock (▷ page 76) the vehicle using the mechanical key.
You have lost a SmartKey.	 Have the SmartKey deactivated at a qualified specialist workshop. Report the loss immediately to the vehicle insurers. If necessary, have the locks changed as well.
You have lost the mechanical key.	 Report the loss immediately to the vehicle insurers. If necessary, have the locks changed as well.

74 Doors

Problem	Possible causes/consequences and ► Solutions
The engine cannot be started using the SmartKey.	 The on-board voltage is too low. Switch off non-essential consumers, e.g. seat heating or interior lighting, and try to start the engine again. If this does not work: Check the starter battery and charge it if necessary (▷ page 282). or Jump-start the vehicle (▷ page 285). or Consult a qualified specialist workshop.
The engine cannot be started using KEYLESS- GO. The SmartKey is in the vehicle.	 A door is open. Therefore, the SmartKey cannot be detected as easily. ▶ Close the door and try to start the vehicle again.
	There is interference from a powerful source of radio waves.▶ Start your vehicle with the SmartKey in the ignition lock.

Doors

Important safety notes

MARNING

When leaving the vehicle, always remove the SmartKey from the ignition lock. Always take the SmartKey with you and lock the vehicle. Do not leave children unsupervised in the vehicle, even if they are secured in a child restraint system, and do not give them access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury. They could:

- injure themselves on vehicle parts
- be seriously or fatally injured by extreme heat or cold
- injure themselves or have an accident with vehicle equipment that may still be in operation even after the SmartKey has been removed from the ignition, such as the seat adjustment, steering wheel adjustment or memory function.

If children open a door, they could cause severe or even fatal injury to other persons; if they get out of the vehicle, they could injure themselves when doing so or be seriously or even fatally injured by any passing traffic.

Do not expose the child restraint system to direct sunlight. The child restraint system's metal parts, for example, could become very hot, and a child could be burned on these parts.

Do not carry heavy or hard objects in the passenger compartment unless they are firmly secured in place.

Unsecured or improperly positioned cargo increases a child's risk of injury in the event of:

- strong braking maneuvers
- sudden changes of direction
- an accident

Unlocking and opening doors from the inside

You can open a door from inside the vehicle even if it has been locked.

Only open the door when the traffic situation permits.

If the vehicle was previously locked with the SmartKey or with KEYLESS-GO, opening the vehicle from the inside will activate the antitheft alarm system. Switch off the alarm (> page 65).



Pull door handle ②. If the door is locked, locking knob ① pops up The door is uplealed and eap handle.

up. The door is unlocked and can be opened.

When a door is opened, the side window on that side opens slightly. When the door is closed, the side window closes again.

The side windows will not open/close if the battery is discharged or if the side windows have iced up. It will then not be possible to close the door. Do not attempt to force the door closed. You could otherwise damage the door or the side window.


Centrally locking and unlocking the vehicle from the inside

You can centrally lock or unlock the vehicle from the inside.

The central locking/unlocking button does not lock or unlock the fuel filler flap or the

stowage compartments, such as the glove box.

You cannot unlock the vehicle centrally from the inside if the vehicle has been locked with the SmartKey or KEYLESS-GO.



- ► **To unlock:** press button (1).
- ► **To lock:** press button ②. If all the doors are closed, the vehicle locks.

You can open a door from inside the vehicle even if it has been locked. Only open the door when the traffic situation permits.

If the vehicle has been locked with the central locking button:


- and the SmartKey is set to its factory setting, the entire vehicle is unlocked if a door is opened from the inside
- and the SmartKey is set to an individual setting, only the door that is opened from inside the vehicle is unlocked.

Automatic locking feature

When the ignition is switched on and the wheels of the vehicle are turning at a speed of more than 9 mph (15 km/h), the vehicle locks automatically.

You could therefore be locked out when:

- the vehicle is being pushed.
- the vehicle is being towed.
- the vehicle is being tested on a dynamometer.



- ► **To deactivate:** press and hold button ① for about five seconds until a tone sounds.
- To activate: press and hold button (2) for about five seconds until a tone sounds.

If you press one of the two buttons and do not hear a tone, the relevant setting has already been selected.

You can also switch the automatic locking function on and off using the on-board computer (\triangleright page 193).

Unlocking the driver's door (mechanical key)

If the vehicle can no longer be unlocked with the SmartKey, use the mechanical key.

If you use the mechanical key to unlock and open the driver's door, the anti-theft alarm system will be triggered (\triangleright page 65).

- ► Take the mechanical key out of the SmartKey (▷ page 70).
- Insert the mechanical key into the lock of the driver's door as far as it will go.



 Turn the mechanical key counter-clockwise to position 1.
 The door is unlocked.


The door is unlocked.

- Turn the mechanical key back and remove it.
- Insert the mechanical key into the SmartKey.

Locking the vehicle (mechanical key)

If the vehicle can no longer be locked with the SmartKey, use the mechanical key.

- ▶ Open the driver's door.
- Close the front-passenger door and the trunk lid.
- ▶ Press the locking button (▷ page 75).
- Check whether the locking knob on the front-passenger door is still visible. Press down the locking knob by hand, if necessary.
- Close the driver's door.
- ► Take the mechanical key out of the SmartKey (▷ page 70).
- Insert the mechanical key into the lock of the driver's door as far as it will go.



- ► Turn the mechanical key clockwise as far as it will go to position 1.
- Turn the mechanical key back and remove it.
- Make sure that the doors and the trunk lid are locked.
- Insert the mechanical key into the SmartKey.

If you lock the vehicle as described above, the fuel filler flap is not locked. The antitheft alarm system is not armed.

Trunk

Important safety notes

Do not leave the SmartKey in the trunk. You could otherwise lock yourself out.

MARNING

When leaving the vehicle, always remove the SmartKey from the ignition lock. Always take the SmartKey with you and lock the vehicle. Do not leave children unsupervised in the vehicle, even if they are secured in a child restraint system, and do not give them access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury. They could:

- injure themselves on vehicle parts
- be seriously or fatally injured by extreme heat or cold
- injure themselves or have an accident with vehicle equipment that may still be in operation even after the SmartKey has been removed from the ignition, such as the seat adjustment, steering wheel adjustment or memory function.

If children open a door, they could cause severe or even fatal injury to other persons; if they get out of the vehicle, they could injure themselves when doing so or be seriously or even fatally injured by any passing traffic.

Do not expose the child restraint system to direct sunlight. The child restraint system's metal parts, for example, could become very hot, and a child could be burned on these parts.

MARNING

Do not carry heavy or hard objects in the passenger compartment or trunk unless they are firmly secured in place. Unsecured or improperly positioned cargo increases a child's risk of injury in the event of

- strong braking maneuvers
- sudden changes of direction
- an accident

Make sure the trunk lid is closed when the engine is running and while driving. Among other dangers, deadly carbon monoxide (CO) gases may enter the vehicle interior resulting in unconsciousness and death.

The trunk lid swings upwards when opened. Therefore, make sure that there is sufficient clearance above the trunk lid.

To open the trunk lid completely, a minimum clearance of 5.90 ft (1.80 m) above the ground is necessary.

The trunk lid can be:

- opened and closed manually from outside
- · opened automatically from outside
- locked separately
- unlocked with the mechanical key
- opened with the emergency release button

Opening and closing manually

Opening

You can only unlock the trunk lid when the vehicle is stationary and the roof is fully opened or closed.

▶ Press the \bigcirc button on the SmartKey.



- ▶ Pull handle ①.
- ▶ Raise the trunk lid.

Opening/closing

MARNING

Closing

To prevent possible personal injury, always keep hands and fingers away from the trunk opening when closing the trunk lid. Be especially careful when small children are around.



- ▶ Pull the trunk lid down using recess (1).
- ▶ If necessary, lock the vehicle with the **G** button on the SmartKey (▷ page 68) or with KEYLESS-GO (⊳ page 69).
- If a KEYLESS-GO key is detected in the trunk, the trunk lid cannot be locked and then opens again.

Opening automatically from the outside

Important safety notes

∧ WARNING

Make sure the trunk lid is closed when the engine is running and while driving. Among other dangers, deadly carbon monoxide (CO) gases may enter the vehicle interior resulting in unconsciousness and death.

The trunk lid swings upwards when opened. Therefore, make sure that there is sufficient clearance above the trunk lid.

To open the trunk lid completely, a minimum clearance of 5.90 ft (1.80 m) above the ground is necessary.

Opening

You can open the trunk lid automatically using the SmartKey or the handle in the trunk lid.

- ▶ Press and hold the S button on the SmartKey until the trunk lid opens.
- or
- ▶ When the trunk is unlocked, pull the trunk lid handle and let it go again immediately.

Locking the trunk separately

You can lock the trunk separately. If you then unlock the vehicle centrally, the trunk remains locked and cannot be opened.

- Close the trunk lid.
- ► Take the mechanical key out of the SmartKey (\triangleright page 70).



- Insert the mechanical key into the trunk lid lock as far as the stop.
- ► Turn the mechanical key clockwise from position 1 to position 2.
- ▶ Remove the mechanical key.
- Insert the mechanical key into the SmartKey.

Unlocking the trunk (mechanical key)

The trunk lid swings upwards when opened. Therefore, make sure that there is sufficient clearance above the trunk lid.

If the trunk cannot be unlocked with the SmartKey or KEYLESS-GO, use the mechanical key.

If you use the mechanical key to unlock and open the trunk lid, the anti-theft alarm system will be triggered (\triangleright page 65).

- ► Take the mechanical key out of the SmartKey (▷ page 70).
- Insert the mechanical key into the trunk lid lock as far as the stop.



- Turn the mechanical key counter-clockwise from position 1 as far as it will go to position 2 and pull the trunk lid handle. The trunk is unlocked.
- Turn the mechanical key back to position
 1 and remove it.
- Insert the mechanical key into the SmartKey.

Trunk emergency release

You can open the trunk lid from inside the vehicle with the emergency release button.



 Briefly press emergency release button ①.
 The trunk lid unlocks and opens.

The trunk lid can be unlocked and opened with the trunk lid emergency release when

with the trunk lid emergency release wher the vehicle is stationary or while driving.

Trunk lid emergency release light:

- emergency release button (1) flashes for 30 minutes after the trunk lid is opened
- emergency release button (1) flashes for 60 minutes after the trunk lid is closed.

The trunk lid emergency release does not open the trunk lid if the battery is disconnected or discharged.

Side windows

Important safety notes

MARNING

When opening or closing the door windows, make sure that there is no danger of anyone being harmed by the opening/closing procedure.

The front door windows are equipped with automatic operation and the anti-entrapment feature. If in automatic mode a front door window encounters an obstruction that blocks its path, the anti-entrapment feature will stop the door window and open it slightly. The door windows operate differently when

the switch is pulled. See the "Problems with door windows" section for more details.

The closing of the door windows can be immediately halted by releasing the switch or, if the switch was pulled past the resistance point and released, by pressing or pulling the respective switch.

If a door window encounters an obstruction that blocks its path in a circumstance where you are closing the windows by pressing and holding button on the SmartKey or by pressing and holding the lock button (vehicles with KEYLESS-GO) on an outside door handle, the anti-entrapment feature will not operate.

Opening and closing the side windows in the front

The switches for the front side windows are located on the driver's door. There is also a switch for the front-passenger side window on the front-passenger door.

The switches on the driver's door take precedence.



- 1 Left
- Right
- Turn the SmartKey to position 1 or 2 in the ignition lock.
- You can continue to operate the side windows after you switch off the engine. This function is available for up to five minutes or until the driver's or frontpassenger door is opened.
- **To open:** press the corresponding switch.
- ► **To close:** pull the corresponding switch.
- Automatic operation: press or pull the corresponding switch beyond the point of resistance.

The side window opens or closes fully.

To interrupt automatic operation: press or pull the corresponding switch again.

Opening and closing all side windows

Using the switch on the center console

You can use the switch on the center console to simultaneously open all the side windows, or to close them one after the other.

 Open the cover on the lower section of the center console.

The switch for all side windows is under the cover.



- ► To open all side windows: press switch ① as far as the point of resistance.
- ► To open all side windows fully: press switch ① beyond the point of resistance.
- If, after opening the windows, you then close a side window using the switch on the door control panel, the rear side windows will remain open. To close the rear side windows, you must pull the switch on the center console and hold it in position. All of the side windows will then close one after the other.
- ► To close all side windows: pull switch ①.

The rear side windows close after the front side windows.

 Make sure that all the side windows are fully closed.

When the roof is open, only the two front side windows can be operated using the switch on the center console.

With the SmartKey

▲ WARNING

Make sure that nobody can become trapped as you close the side windows.

Proceed as follows if there is a risk of entrapment:

- release the 🕞 button.
- press and hold the 😈 button until the side windows open again.

When the roof is closed and the trunk partition is open, the SmartKey can be used to open or close all side windows simultaneously:

- Make sure that the roof is closed (▷ page 84) and that the trunk partition is open (▷ page 85).
- Point the tip of the SmartKey at the driver's door handle.
- ► To interrupt the opening procedure: release the relea
- ► To close all side windows: press and hold the _____ button on the SmartKey until the side windows are fully closed.
- ► To interrupt the closing procedure: release the 🕞 button.

Convenience closing with KEYLESS-GO

When using the convenience closing feature, make sure that nobody can become trapped. Proceed as follows if there is a risk of entrapment:

- release the sensor surface on the door handle.
- pull the door handle immediately and hold it.

The side windows open.

The KEYLESS-GO SmartKey must be outside the vehicle. All the doors must be closed.



- Touch recessed sensor surface ① on the door handle until the side windows are fully closed.
- (1) Make sure you only touch recessed sensor surface (1).
- Make sure that all the side windows are closed.
- To interrupt convenience closing: release recessed sensor surface (1) on the door handle.

Resetting the side windows

You must reset each side window if a side window can no longer be closed fully.

- Close all the doors.
- Turn the SmartKey to position 1 or 2 in the ignition lock.
- Pull the corresponding switch on the door control panel until the side window is completely closed. (> page 80)
- ► Hold the switch for an additional second.

If the side window opens again slightly:

- Immediately pull the corresponding switch on the door control panel until the side window is completely closed (▷ page 80).
- ► Hold the switch for an additional second.
- If the corresponding side window remains closed after the button has been released, the side window has been reset correctly. If this is not the case, repeat the steps above again.

Problems with the side windows

Problem: a side window cannot be closed because it is blocked by objects, e.g. leaves in the window guide.

- Remove the objects.
- Close the side window.

Problem: a side window cannot be closed and you cannot see the cause.

MARNING

Closing the side windows with increased force or without the anti-entrapment feature could lead to serious or even fatal injury. Make sure that nobody can become trapped when closing the side windows.

If a side window is obstructed during closing and reopens again slightly:

Immediately after the window blocks, pull the corresponding switch again until the side window has closed. The side window is closed with increased force.

If a side window is obstructed again during closing and reopens again slightly:

Immediately after the window blocks, pull the corresponding switch again until the side window has closed. The side window is closed without the antientrapment feature.

MARNING

Pulling and holding the switch to close the door window immediately after it had been blocked two times will cause the door window to close without the anti-entrapment feature for as long as you hold the switch.

Roof

Important safety notes

For safety reasons, the roof can only be opened or closed when the vehicle is stationary.

Only drive with the roof fully open or closed.

If the roof does not open or close fully, the roof hydraulics are depressurized and the soft top is lowered:

- after about seven minutes if the ignition is switched on
- after about 15 seconds if the ignition is switched off

A warning tone sounds shortly beforehand. The symbol and the Retractable Roof Lowering message appears in the multifunction display.

Lock the roof again before driving on. Otherwise, the unlocked roof could open during the journey and cause you to lose control of your vehicle. You or other persons could be injured as a result.

▲ WARNING

Closing the roof manually is a complex, technically challenging procedure. Attempting to manually close the roof may cause damage to the roof and/or injury.

For this reason, the manual closing process should only be carried out at a qualified specialist workshop.

Never sit on the rear shelf or store heavy objects there. You will otherwise damage the roof and the rear shelf of your vehicle.

Do not forget that the weather can change abruptly. Make certain that the roof is closed when you leave the vehicle. The vehicle electronics can be damaged if water enters the vehicle interior.

When opening and closing the roof, make sure that:

- there is sufficient upward clearance, as the roof swings upwards.
- there is sufficient clearance behind the vehicle, as the trunk lid swings backwards beyond the bumper.
- the trunk is only loaded to below the trunk partition.

- the trunk partition is not pushed up by the load.
- the trunk partition is closed.
- the trunk lid is closed.
- the outside temperature is above +5 °F (-15 °C).

You could otherwise damage the roof, trunk and other parts of the vehicle.

Make sure that the roof and rear window are clean and dry before opening the roof. Otherwise, water or dirt could enter the vehicle interior or trunk.

Opening and closing with the roof switch

Important safety notes

▲ WARNING

Before operating the retractable hardtop (vario-roof), make sure there is no danger of anyone being injured by the moving parts (retractable hardtop, roof frame, and trunk lid).

Hands must never be placed near the roof frame, upper windshield area, hardtop, shelf behind roll bars, or trunk lid while the retractable hardtop is being raised or lowered. Serious personal injury may occur.

If potential danger exists, release the retractable hardtop switch or the $\begin{tabular}{c} \begin{tabular}{c} \begin{tabular$

retractable hardtop switch or press the or or button on the SmartKey to raise or lower the retractable hardtop away from the danger zone.

Opening and closing



- ► Close the trunk partition (▷ page 85).
- Close the trunk lid.
- Turn the SmartKey to position 2 in the ignition lock.
- Open the cover on the lower section of the center console.
 - Roof switch (1) is located under the cover.
- ► To open: pull roof switch ① until the roof has been fully retracted into the trunk and the Vario-Roof in Operation message disappears from the multifunction display. All of the side windows open.
- To close: press roof switch ① until the roof is fully closed and the Vario-Roof in Operation message disappears from the multifunction display. All of the side windows open.
- ► To close all side windows, pull the switch under the cover on the center console (▷ page 80).
- If you operate the roof switch and the Trunk partition Open message appears in the multifunction display, the trunk partition has not been closed correctly.

Opening and closing with the SmartKey

Important safety notes

MARNING

Before operating the retractable hardtop (vario-roof), make sure there is no danger of anyone being injured by the moving parts (retractable hardtop, roof frame, and trunk lid).

Hands must never be placed near the roof frame, upper windshield area, hardtop, shelf behind roll bars, or trunk lid while the retractable hardtop is being raised or lowered. Serious personal injury may occur. If potential danger exists, release the retractable hardtop switch or the \bigcirc or \bigcirc button on the SmartKey. This immediately interrupts the raising or lowering procedure. You can then operate the retractable hardtop switch or press the \bigcirc or \bigcirc button on the SmartKey to raise or lower the retractable hardtop away from the danger zone.

Opening and closing

- The SmartKey must be close to the driver's door handle.
- ► Close the trunk partition (▷ page 85).
- ► Close the trunk lid.
- Point the tip of the SmartKey at the driver's door handle.
- To open: press and hold the button on the SmartKey until the roof is fully opened. The roof and the rear side windows open.

The front side windows close.

- ► To interrupt the opening procedure: release the _____ button.
- ► To open the front side windows: press and hold the _____ button on the SmartKey again.

► To close: press and hold the ____ button on the SmartKey until the roof is fully closed.

The roof and the side windows close.

- ► To interrupt the closing procedure: release the 🕞 button.
- When the roof is closed and the trunk partition is open, the roof cannot be opened using the SmartKey functions. Instead, all side windows open or close simultaneously (▷ page 80). Additionally, the Trunk partition Open message appears in the multifunction display.

Locking the roof again

▲ WARNING

Stop the vehicle in a safe location or as soon as it is safe to do so and lock the retractable hardtop before continuing to drive. You could otherwise endanger yourself and others.

The roof is not locked when:

- the symbol and the Vario-Roof in Operation / Retractable Roof in Operation message appear in the multifunction display
- the symbol and the Retractable Roof Not Open/Close Completely appear in the multifunction display and a warning tone is heard
- you hear a warning tone for up to ten seconds when pulling away or while driving.

You can lock the roof again if it is not locked fully.

- Stop the vehicle immediately, paying attention to road and traffic conditions.
- Make sure that the SmartKey is in position
 2 in the ignition lock.
- ▶ Press the roof switch (▷ page 84).

Trunk partition

General notes

The trunk partition can be used to cover luggage and loads in the trunk.

- To avoid damaging the roof or luggage when folding back the roof, you should:
 - only load the trunk to below the trunk partition
 - not place any objects on or in front of the trunk partition
 - not place any objects on the cover behind the roll bars
 - not allow the cargo to push the trunk partition upwards

Opening and closing



- ► To close: pull back trunk partition ① by the handle in the direction of the arrow until it engages on both sides in the eyelets on the trunk sill.
- ► **To open:** grip the handle of trunk partition ①.
- Press the release button in the handle of trunk partition (1).
 Trunk partition (1) is released.
- Pull trunk partition ① up out of the eyelets on the trunk sill.
- Push trunk partition ① forwards against the direction of the arrow by the handle.

86 Roof

Problems with the roof

Problem	Possible causes/consequences and Solutions
The roof will not open or close.	The trunk partition is not closed and not properly engaged.► Close the trunk partition (▷ page 85).
	The trunk lid is open. ► Close the trunk lid (▷ page 77).
	The on-board voltage is too low. ► Leave the engine running.
	 The roof has been opened and closed several times in a row. The roof drive has been automatically deactivated. You can open and close the roof again after approximately ten minutes. Switch off the ignition and turn it back on. Repeat the opening or closing procedure.
	The automatic roof mechanism is faulty. ► Consult a qualified specialist workshop.

Wind screen

General notes

The wind screen offers protection from the wind when driving with the roof down.

▲ WARNING

You could lose control of the vehicle and injure yourself or others if you operate the wind screen while driving.

Install or remove the wind screen only when the vehicle is stationary.

MARNING

If you use the wind screen in darkness or in other conditions offering poor visibility, your view to the rear is further impaired. As a result of the visibility impairment, you could cause an accident and injure yourself or others.

For this reason, remove the wind screen as soon as it is dark or if your vision is otherwise restricted.

MARNING

If the wind screen is not correctly engaged, it may break free and thus obstruct traffic behind you or lead to an accident. Each time before driving with the roof down, check that the wind screen is properly engaged.

Install or remove the wind screen only when the roof is open. You could otherwise damage the wind screen or the vehicle interior.


The wind screen can be installed or removed from the driver's side or passenger side.

Perform operations involving the wind screen preferably on the side facing away from traffic, after you have stopped the vehicle, paying attention to road and traffic conditions.

Roof 87

Installing and removing the wind screen

Preparing for installation




Preparing for installation from the left side of the vehicle (example)

- 1 Wind screen
- Locked latch
- ③ Unlocked latch
- The following conditions must be fulfilled for installation:
 - unlocking buttons **R** and **L** point in the direction of travel.
 - latch ③ facing you is unlocked.
 - latch (2) facing away from you is locked.
- ► To unlock the latch: press unlocking button R or L on the locked latch.
- To lock the latch: push the unlocked latch upwards by hand until it engages.

Installing

- Stop the vehicle, paying attention to road and traffic conditions.
- ► Take the wind screen out of the trunk.




Installation from the left side of the vehicle (example)

- ▶ Prepare for installation (▷ page 87).
- Hold wind screen (1) at an angle and slide it with locked latch (2) in the direction of arrow (4) into the bracket of the opposite roll bar.
- Press wind screen (1) on the side of the vehicle facing you downwards in the direction of arrow (5) until it engages.
 Make sure that studs (6) and latch (3) fit into the respective brackets.
- Check whether wind screen (1) is fully inserted into all four brackets and is sitting securely.
- ► If this is not the case, remove wind screen ① again and repeat the steps above.

Removing

Stop the vehicle, paying attention to road and traffic conditions.



Removing from the left side of the vehicle (example)

 Press unlocking button L①. Meanwhile, pull wind screen ② on the side of the vehicle facing you upwards and tilt it.



Removing from the left side of the vehicle (example)

- Pull wind screen (2) out of the bracket of the opposite roll bar in the direction of the arrow.
- Secure wind screen (2) to the trunk floor by the rubber strips (▷ page 244).

AIRGUIDE

General notes

AIRGUIDE offers protection from the wind when driving with the roof down.

▲ WARNING

You could lose control of the vehicle and injure yourself or others if you operate AIRGUIDE while driving.

Only fold the AIRGUIDE discs out or in when the vehicle is stationary.


AIRGUIDE can only be positioned correctly by folding it in or out. AIRGUIDE cannot be dismantled. Do not try to remove AIRGUIDE from its anchorage. Otherwise, you could damage AIRGUIDE or the vehicle.

AIRGUIDE can be folded out or back in from the driver's side or passenger side.

Perform operations involving AIRGUIDE preferably on the side facing away from traffic, after you have stopped the vehicle, paying attention to road and traffic conditions.

Operating AIRGUIDE

Stop the vehicle, paying attention to road and traffic conditions.



Example: folding out from the left side of the vehicle

- ► To fold out AIRGUIDE: turn disk ① towards the center in the direction of the arrow as far as it will go.
- ▶ Repeat the process with disk ②.
- ► To fold in AIRGUIDE: turn disks ① and ② respectively back to the stop behind the roll bar.
- Disks (1) and (2) can be used independently of one another, for example if you are driving without a front passenger.

MAGIC SKY CONTROL

General notes

MAGIC SKY CONTROL is a glass roof, the transparency of which can be changed by applying electrical voltage.

MAGIC SKY CONTROL can be switched between darkened and transparent states.

MAGIC SKY CONTROL darkens automatically when you turn the SmartKey to position 0 in the ignition lock or remove the SmartKey.

Risk of electric shock

The electrical components of MAGIC SKY CONTROL are protected by a covering behind the overhead control panel.

The MAGIC SKY CONTROL control unit is marked with a yellow warning sticker that warns you of high voltage. The high-voltage cables are orange in color.

▲ DANGER

The MAGIC SKY CONTROL electrical system works at high voltage.

If the cover behind the overhead control unit is damaged or is removed, electrical components of MAGIC SKY CONTROL are exposed. These may be live. If you touch these components, you may get an electric shock and could be seriously or even fatally injured.

For this reason, never remove the cover behind the overhead control unit. Never touch parts of the electrical system (control unit, cables or cable connections).

Have all work on MAGIC SKY CONTROL carried out at a qualified specialist workshop.

Operating MAGIC SKY CONTROL



► Turn the SmartKey to position 1 or 2 in the ignition lock.

MAGIC SKY CONTROL switches to the status it was set to before the engine was switched off.

► To change the transparency: press button ①.

• At sub-zero temperatures, the change is slower and uneven. The entire process may take some time.

Useful information	
Correcting the driver's seat posi-	
tion	92
Seats	93
Steering wheel	96
Mirrors	98
Memory function	100

Useful information

- This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- Please read the information on qualified specialist workshops (▷ page 23).

Correcting the driver's seat position



Observe the safety guidelines on (\triangleright page 93).

Check whether you have adjusted seat 3 properly.

Manual seat adjustment (▷ page 94) Electrical seat adjustment (▷ page 94) When adjusting the seat, make sure:

- you are as far away from the driver's air bag as possible.
- you are sitting in a normal upright position.
- you can fasten the seat belt properly.

- you have moved the backrest to an almost vertical position.
- you have set the seat cushion angle so that your thighs are gently supported.
- you can depress the pedals properly.
- ► Check whether the head restraint is adjusted properly (▷ page 95). When doing so, make sure that you have adjusted the head restraint so that the back of your head is supported at eye level by the center of the head restraint.

Observe the safety guidelines on (▷ page 96).

 Check whether steering wheel (1) is adjusted properly.

Adjust the steering wheel manually (> page 97)

Adjust the steering wheel electrically (> page 97)

When adjusting the steering wheel, make sure:

- you can hold the steering wheel with your arms slightly bent.
- you can move your legs freely.
- you can see all the displays in the instrument cluster clearly.

Observe the safety guidelines on (> page 48).

 Check whether you have fastened seat belt (2) properly (> page 50).

The seat belt should:

- fit snugly across your body.
- be routed across the middle of your shoulder.
- be routed in your pelvic area across the hip joints
- Before starting off, adjust the rear-view mirror and the exterior mirrors
 (▷ page 98) in such a way that you have a good view of road and traffic conditions.
- ► Vehicles with memory function: save the seat, steering wheel and exterior mirror settings (> page 100).

Seats

Important safety notes

MARNING

In order to avoid possible loss of vehicle control, all seat, head restraint, steering wheel and rear view mirror adjustments, as well as fastening of seat belts, must be done before setting the vehicle in motion.

MARNING

Do not adjust the driver's seat while driving. Adjusting the seat while driving could cause the driver to lose control of the vehicle.

Never travel in a moving vehicle with the seat backrest in an excessively reclined position as this can be dangerous. You could slide under the seat belt in a collision. If you slide under it, the seat belt would apply force at the abdomen or neck. This could cause serious or fatal injuries. The seat backrest and seat belts provide the best restraint when the wearer is in a position that is as upright as possible and seat belts are properly positioned on the body.

Your seat belt must be adjusted so that you can correctly fasten your seat belt.

Observe the following points:

- adjust the seat backrest until your arms are slightly angled when holding the steering wheel.
- adjust the seat to a comfortable seating position that still allows you to reach the accelerator/brake pedal safely. The position should be as far back as possible with the driver still able to operate the controls properly.
- adjust the head restraint so that it is as close to the head as possible and the center

of the head restraint supports the back of the head at eye level.

 never place hands under the seat or near any moving parts while a seat is being adjusted.

Failure to do so could result in an accident and/or serious personal injury.

The electrically adjustable seats can be operated at any time. Therefore, do not leave children unattended in the vehicle, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury.

MARNING

Children 12 years old and under must be seated and properly secured in an appropriately sized infant restraint, child restraint system, or booster seat recommended for the size and weight of the child. For additional information, see the "Children in the vehicle" section.

A child's risk of serious or fatal injuries is significantly increased if the child restraints are not properly secured in the vehicle and/ or the child is not properly secured in the child restraint.

For your protection, drive only with properly positioned head restraints.

Adjust the head restraint so that it is as close to the head as possible and the center of the head restraint supports the back of the head at eye level. This will reduce the potential for injury to the head and neck in the event of an accident or similar situation.


Do not drive the vehicle without the seat head restraints. Head restraints are intended to help reduce injuries during an accident.

94 Seats

- do not spill any liquids on the seats. If liquid is spilled on the seats, dry them as soon as possible.
- if the seat covers are damp or wet, do not switch on the seat heating. The seat heating should also not to be used to dry the seats.
- clean the seat covers as recommended; see the "Interior care" section.
- do not transport heavy loads on the seats. Do not place sharp objects on the seat cushions, e.g. knives, nails or tools. The seats should only be occupied by passengers, if possible.
- when the seat heating is in operation, do not cover the seats with insulating materials, e.g. blankets, coats, bags, seat covers, child seats or booster seats.
- Make sure that there are no objects in the footwell or behind the seats when resetting the seats. There is a risk that the seats and/or the objects could be damaged.
- 1 The head restraints are equipped with the NECK-PRO system (▷ page 47). For this reason, it is not possible to remove the head restraints from the seats.

For more information, contact a qualified specialist workshop.

Adjusting the seats manually



Seat fore-and-aft adjustment

- Lift handle ① and slide the seat forwards or backwards.
- Release lever 1 again.
 Make sure that you hear the seat engage in position.


Backrest angle

- ▶ Relieve the pressure on the backrest.
- Pull handle (2) and adjust the backrest to the desired angle.
- Release handle (2) again.
 The backrest must audibly engage.

Seat height

 Pull handle ③ upwards or push it down repeatedly until the seat has reached the desired height.

Adjusting the seats electrically



- 1 Backrest angle
- Seat fore-and-aft adjustment
- ③ Seat cushion angle
- ④ Seat height
- You can store the seat settings using the memory function (▷ page 100).

Seats 95


Adjusting the head restraints



To raise/lower: push the head restraint upwards or pull it down into the desired position.

Adjusting the four-way lumbar support

You can adjust the contour of the seat backrests individually to provide optimum support for your back.



- ① To raise the backrest contour
- ② To soften the backrest contour
- ③ To lower the backrest contour
- ④ To harden the backrest contour

Switching the seat heating on/off

Switching on/off

MARNING

Repeatedly setting the seat heating to level **3** may result in excessive seat temperatures.

The health of passengers that have limited temperature sensitivity or a limited ability to react to excessively high temperatures may be affected or they may even suffer burn-like injuries. Therefore, do not use seat heating level **3** repeatedly.

The three red indicator lamps in the button indicate the heating level you have selected.

If the battery voltage is too low, the seat heating may switch off.



Driver's and front-passenger seat

The system automatically switches down from level **3** to level **2** after approximately five minutes.

The system automatically switches down from level **2** to level **1** after approximately ten minutes.

The system automatically switches off approximately 20 minutes after it is set to level **1**.

- Make sure that the SmartKey is in position
 1 or 2 in the ignition lock.
- ► To switch on: press button ① repeatedly until the desired heating level is set.
- To switch off: press button (1) repeatedly until all the indicator lamps go out.

Problems with the seat heating

The seat heating has switched itself off prematurely. The vehicle's electrical system voltage is too low because too many electrical consumers are switched on.

- Switch off electrical consumers that you do not need, such as the rear window defroster or interior lighting.
- Once the battery is sufficiently charged, switch on the seat heating again.

AIRSCARF

Switching on/off

MARNING

Very hot air can flow out of the AIRSCARF vents in the head restraints when AIRSCARF is in operation. This can cause burns on unprotected skin near the AIRSCARF vents. Lower the heating output in good time, when necessary.

The AIRSCARF function warms the head and neck area of vehicle occupants with warm air. The warm air flows out of the holes in the head restraints.

The three red indicator lamps in the button indicate the heating level you have selected.



- Make sure that the SmartKey is in position 2 in the ignition lock.
- ▶ **To activate:** press button ①. Three red indicator lamps in the button light up. The blower starts up after a preheating phase of seven seconds.
- Press button ① repeatedly until the desired heating level is set.
- To switch off: press button (1) repeatedly until all the indicator lamps go out.
- The blower continues running for seven seconds to cool down the heating elements.
- If the battery voltage is too low, AIRSCARF may switch off.

Problems with AIRSCARF

AIRSCARF has switched off prematurely or will not switch on. The vehicle's electrical system voltage is too low because too many electrical consumers are switched on.

- Switch off electrical consumers which you do not need, such as the rear window defroster or interior lighting.
- Switch on AIRSCARF again.

Steering wheel

Important safety notes


MARNING

Do not adjust the steering wheel while driving. Adjusting the steering wheel while driving could cause the driver to lose control of the vehicle.

The electrical steering wheel adjustment feature can be operated at any time.


Therefore, do not leave children unattended in the vehicle, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury.

Adjusting the steering wheel manually



- (1) Release lever
- ② To adjust the steering wheel height
- ③ To adjust the steering wheel position (fore-and-aft adjustment)
- Fold release lever ① down completely in the direction of the arrow. The steering column is unlocked.
- Adjust the steering wheel to the desired position.
- Push release lever (1) up completely. The steering column is locked.
- Check if the steering column is locked. When doing so, try to push the steering wheel up or down or try to move it in the fore-and-aft direction.

Adjusting the steering wheel electrically



- ① To adjust the steering wheel height
- To adjust the steering wheel position (fore-and-aft adjustment)
- 1 Related topics:
 - EASY-ENTRY/EXIT feature (▷ page 97)
 - Storing settings (▷ page 100)

EASY-ENTRY/EXIT feature

Important safety notes

The EASY-ENTRY/EXIT feature makes getting in and out of your vehicle easier.

You can activate and deactivate the EASY-ENTRY/EXIT feature in the on-board computer (\triangleright page 194).

You must make sure no one can become trapped or injured by the moving steering wheel when the easy-entry/exit feature is activated.

To stop steering wheel movement, move steering wheel adjustment stalk or press the memory position switch.

Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Children could open the driver's door and unintentionally activate the easy-entry/exit feature, which could result in an accident and/or serious personal injury.

98 Mirrors

Let the system complete the adjustment procedure before setting the vehicle in motion. All steering wheel adjustment must be completed before setting the vehicle in motion. Driving off with the steering wheel still adjusting could cause the driver to lose control of the vehicle.

Position of the steering wheel when the EASY-ENTRY/EXIT feature is active

The steering wheel swings upwards when you:

- remove the SmartKey from the ignition lock
- open the driver's door and KEYLESS-GO is in position 1
- open the driver's door and the SmartKey is in position **0** or **1** in the ignition lock
- The steering wheel only moves upwards if it has not already reached the upper end stop.

Position of the steering wheel for driving

The steering wheel is moved to the last selected position when:

- the driver's door is closed.
- you insert the SmartKey into the ignition lock.

or

• you press the Start/Stop button once on vehicles with KEYLESS-GO.

When you close the driver's door with the ignition switched on, the steering wheel is also automatically moved to the previously set position.

The last position of the steering wheel is stored after each manual setting or when you store the setting with the memory function (\triangleright page 100).

Crash-responsive EASY-EXIT feature

If the crash-responsive EASY-EXIT feature is triggered in an accident, the steering column will move upwards when the driver's door is opened. This occurs irrespective of the position of the SmartKey in the ignition lock. This makes it easier to exit the vehicle and rescue the occupants.

The crash-responsive EASY-EXIT feature is only operational after an accident if the EASY-EXIT/ENTRY feature is activated in the onboard computer.

Mirrors

Rear-view mirror

Rear-view mirror (manual anti-glare)



► Anti-glare mode: flick anti-glare lever ① forwards or back.

Exterior mirrors

Adjusting the exterior mirrors

MARNING

Exercise care when using the passenger-side exterior rear view mirror. The mirror surface is convex (outwardly curved surface for a wider field of view). Objects in mirror are closer than they appear. Check your interior rear view mirror and glance over your shoulder before changing lanes. The exterior mirrors are automatically heated if the rear window defroster is switched on and the outside temperature is low.



- Make sure that the SmartKey is in position
 1 or 2 in the ignition lock.
- Press button (2) for the right-hand exterior mirror or button (1) for the left-hand exterior mirror.
- Press adjustment button (3) up, down, or to the left or right until you have adjusted the exterior mirror to the correct position. You should have a good overview of traffic conditions.

Folding the exterior mirrors in or out electrically



- Make sure that the SmartKey is in position
 1 or 2 in the ignition lock.
- Briefly press button ①.
 Both exterior mirrors fold in or out.

Make sure that the exterior mirrors are always folded out fully while driving. They could otherwise vibrate.

Folding the exterior mirrors in or out automatically

If the "Fold in mirrors when locking" function is activated in the on-board computer (> page 195):

- the exterior mirrors fold in automatically as soon as you lock the vehicle from the outside.
- the exterior mirrors fold out again automatically as soon as you unlock the vehicle and then open the driver's or frontpassenger door.
- 1 If the exterior mirrors have been folded in manually, they do not fold out.

Exterior mirror out of position

If an exterior mirror has been pushed out of position, proceed as follows:

- Vehicles without electrically folding exterior mirrors: move the exterior mirror into the correct position manually.
- ► Vehicles with electrically folding exterior mirrors: press the mirror-folding button (▷ page 99) repeatedly until you hear the mirror engage in position. The mirror housing is engaged again and you can adjust the exterior mirrors as usual (▷ page 98).

Automatic anti-glare mirrors

MARNING

If incident light from headlamps is prevented from striking the sensor in the rear-view mirror, for instance, by luggage piled too high in the vehicle, the mirror's automatic antiglare function will not operate.

Incident light could then blind you. This may distract you from the traffic conditions and, as a result, you may cause an accident.

The rear-view mirror and the exterior mirror on the driver's side automatically go into antiglare mode if the ignition is switched on and

100 Memory function


incident light from headlamps strikes the sensor in the rear-view mirror.

The mirrors do not go into anti-glare mode if reverse gear is engaged or the interior lighting is switched on.

Parking position for the exterior mirror on the front-passenger side

Setting and storing the parking position

You can position the front-passenger side exterior mirror in such a way that you can see the rear wheel on that side as soon as you engage reverse gear. You can store this position.



- Make sure that the vehicle is stationary and that the SmartKey is in position 2 in the ignition lock.
- Press button (2) for the exterior mirror on the front-passenger side.
- Engage reverse gear. The exterior mirror on the front-passenger side moves to the preset parking position.
- ► Use adjustment button ③ to adjust the exterior mirror. You should see the rear wheel and the curb in the exterior mirror. The parking position is stored.
- If you shift the transmission to another position, the exterior mirror on the frontpassenger side returns to the driving position.

You can also store the parking position using memory button ${\bf M}$ (4).

- With the SmartKey in position 2 in the ignition lock and with the exterior mirror on the front-passenger side activated, use adjustment button (3) to adjust the exterior mirror. You should see the rear wheel and the curb in the exterior mirror on the front-passenger side.
- Press memory button M (4) and one of the arrows on adjustment button (3) within three seconds. The parking position is stored if the exterior mirror does not move.

Calling up a stored parking position setting

- ► Turn the SmartKey to position **2** in the ignition lock.
- Adjust the exterior mirror on the frontpassenger side with the corresponding button (▷ page 98).
- Engage reverse gear. The exterior mirror on the front-passenger side moves to the stored parking position.

The exterior mirror on the front-passenger side moves back to its original position:

- as soon as you exceed a speed of 6 mph (10 km/h)
- about ten seconds after you have disengaged reverse gear
- if you press button ① for the exterior mirror on the driver's side

Memory function

Storing settings


With the memory function, you can store up to three different settings, e.g. for three different people.

The following settings are stored as a single memory preset:

- seat and backrest position
- driver's side: steering wheel position
- driver's side: position of the exterior mirrors on the driver's and front-passenger sides

MARNING №

Do not activate the memory function while driving. Activating the memory function while driving could cause the driver to lose control of the vehicle.



- ► Adjust the seat (▷ page 94).
- On the driver's side, adjust the steering wheel (▷ page 97) and the exterior mirrors (▷ page 98).
- Press memory button M and one of the storage position buttons 1, 2 or 3 within three seconds.

The settings are stored in the selected preset position. A tone sounds when the settings have been completed.

Calling up a stored setting

- Press and hold the relevant storage position button 1, 2 or 3 until the seat, steering wheel and exterior mirrors are in the stored position.
- The setting procedure is interrupted as soon as you release the storage position button.

Useful information	
Exterior lighting	
Interior lighting	109
Replacing bulbs	109
Windshield wipers	113

Useful information

- This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- Please read the information on qualified specialist workshops (▷ page 23).

Exterior lighting

Important safety notes

For reasons of safety, Mercedes-Benz recommends that you drive with the lights switched on even during the daytime. In some countries, operation of the headlamps varies due to legal requirements and self-imposed obligations.

Information about driving abroad

To convert to symmetrical low beam when driving abroad: switch the headlamps to symmetrical low beam in countries in which traffic drives on the opposite side of the road from the country where the vehicle is registered. This prevents glare to oncoming traffic. Symmetrical lights do not illuminate as large an area of the edge of the road.

Vehicles with Bi-Xenon headlamps (Intelligent Light System)

Conversion to symmetrical low beam

Switch the headlamps to symmetrical low beam in countries in which traffic drives on the opposite side of the road from the country where the vehicle is registered. This prevents glare to oncoming traffic. Symmetrical lights do not illuminate as large an area of the edge of the road.

Have the headlamps converted at a qualified specialist workshop as close to the border as possible before driving in these countries.

Conversion to asymmetrical low beam after returning

Have the headlamps converted back to asymmetrical low beam at a qualified specialist workshop as soon as possible after crossing the border and returning to the original country.

Vehicles with halogen headlamps

Switching the headlamps to symmetrical low beam is not required in countries in which traffic drives on the opposite side of the road from the country where the vehicle is registered. Legal requirements are fulfilled even without switching.

Light switch

Operation

Depending on the date of manufacture of your vehicle, the **A** or **Auro** symbol for the automatic headlamp mode/daytime running lamps is located on the light switch.




Illustration: light switch with the **Auto** symbol for the automatic headlamp mode/daytime running lamps

- **1 →P** ∈ Left-hand standing lamps
- 2 **P**≤→ Right-hand standing lamps

- **3** Derking lamps, license plate and instrument cluster lighting
- 4 Automatic headlamp mode/daytime running lamps
- **5** Low-beam/high-beam headlamps
- ⑥ 0 Rear fog lamp
- ⑦ ₺ Front fog lamps³




Illustration: light switch with the **A** symbol for the automatic headlamp mode/daytime running lamps

1 →P*≡* Left-hand standing lamps

2 **P**≤→ Right-hand standing lamps

- **3** Soc Parking lamps, license plate and instrument cluster lighting
- [4] A Automatic headlamp mode/daytime running lamps
- **5** D Low-beam/high-beam headlamps
- ⑥ 0 Rear fog lamp
- ⑦ ₺ Front fog lamps³

The turn signals, high-beam headlamps and the high-beam flasher are operated using the combination switch (\triangleright page 107).

Switch off the parking lamps and standing lamps when you leave the vehicle. This prevents the battery from discharging.

The exterior lighting (except the parking/ standing lamps) switches off automatically if you:

- remove the SmartKey from the ignition lock
- open the driver's door with the SmartKey in position ${\bf 0}$

If you hear a warning tone when you leave the vehicle, the lights may still be switched on.

► Turn the light switch to **A** or **AUTO**.

Low-beam headlamps

- ➤ To switch on the low-beam headlamps: turn the SmartKey in the ignition lock to position 2 or start the engine.
- ► Turn the light switch to The Image: The Image

Daytime running lamps

Daytime running lamps in Canada

The daytime running lamps function is required by law in Canada. It cannot therefore be deactivated.

Turn the light switch to A or Auro. With the engine running: depending on the ambient light, the daytime running lamps or the low-beam headlamps are switched on. When the low-beam headlamps are switched on, the 100 indicator lamp in the instrument cluster lights up.

When the engine is running and the vehicle is stationary: if you move the selector lever from a drive position to **P**, the daytime running lamps/low-beam headlamps go out after three minutes.

When the engine is running, the vehicle is stationary and in high ambient light brightness: if you turn the light switch to $\boxed{=000}$, the daytime running lamps and the parking lamps are switched on.

If the engine is running and you turn the light switch to *D*, the manual settings take precedence over the daytime running lamps.

Daytime running lamps in the USA

In the USA, the daytime running lamps are deactivated upon delivery from the factory.

³ Only vehicles with front fog lamps have the fog lamps function.

- ► To activate the daytime running lamps: activate the daytime running lamps function in the on-board computer (▷ page 192).
- ► Turn the light switch to **A** or **Auro**. With the engine running: depending on the ambient light, the daytime running lamps or the low-beam headlamps are switched on. When the low-beam headlamps are switched on, the **D** indicator lamp in the instrument cluster lights up.

If the engine is running and you turn the light switch to 100% or 100%, the manual settings take precedence over the daytime running lamps.

Automatic headlamp mode

► To switch on automatic headlamp mode: turn the light switch to A or AUTO.

SmartKey in position **1** in the ignition lock: the parking lamps are switched on or off automatically depending on the brightness of the ambient light.

With the engine running: depending on the brightness of the ambient light, the daytime running lamps⁴ or the low-beam headlamps are switched on or off automatically.

When the low-beam headlamps are switched on, the D indicator lamp in the instrument cluster lights up.

▲ WARNING

If the light switch is set to **A** or **Auro**, the low-beam headlamps will not come on automatically if it is foggy. This could endanger you and others. Therefore, turn the light switch to **D** in fog.

The automatic headlamp feature is only an aid. The driver is responsible for the vehicle's lighting at all times.

Front fog lamps

Only vehicles with front fog lamps have the fog lamps function.

If you suspect that driving conditions will be foggy, turn the light switch to D before you start your journey. Your vehicle may otherwise not be visible and you could endanger yourself and others.

- To switch on the front fog lamps: turn the SmartKey in the ignition lock to position
 2 or start the engine.
- ► Turn the light switch to 🗊 or 🔺 or 🗛
- Press the 10 button.
 The green 10 indicator lamp in the instrument cluster lights up.
- ► To switch off the front fog lamps: press the \$\vec{s}\$D button. The green \$\vec{s}\$D indicator lamp in the instrument cluster goes out.
- If you switch the engine off (SmartKey in position 1 in the ignition lock) and then restart it, the previous fog lamp settings are restored.

Rear fog lamp

- ► To switch on the rear fog lamp: turn the SmartKey in the ignition lock to position 2 or start the engine.
- ► Turn the light switch to 🗊 or 🔺 or 🗚

If the light switch is set to **A** or **Auro**, the rear fog lamp only lights up if the lowbeam headlamps are on.

⁴ Only if daytime running lamps have been activated via the on-board computer.

- Press the <u>0</u>[‡] button.
 The yellow <u>0</u>[‡] indicator lamp in the instrument cluster lights up.

The yellow <u>O</u>[‡] indicator lamp in the instrument cluster goes out.


 If you switch the engine off (SmartKey in position 1 in the ignition lock) and then restart it, the previous rear fog lamp settings are restored.

Headlamp cleaning system

If the "Wipe with washer fluid" function is operated five times (▷ page 113) while the lights are on and the engine is running, the headlamps are cleaned automatically. When you switch off the ignition, the automatic headlamp cleaning system is reset and counting is resumed from 0.

Combination switch

Turn signals



- ① High-beam headlamps
- ② Right turn signal
- ③ High-beam flasher
- ④ Left turn signal

To indicate briefly: press the combination switch briefly to the pressure point in the direction of arrow (2) or (4). The corresponding turn signal flashes three

times. **To indicate:** press the combination switch

I o indicate: press the combination switch beyond the pressure point in the direction of arrow (2) or (4).

High-beam headlamps

- ► To switch on the high-beam headlamps: turn the SmartKey in the ignition lock to position 2 or start the engine.
- ► Turn the light switch to 🗊 or 🔺 or 🗚 or
- Press the combination switch beyond the pressure point in the direction of arrow (1).

In the **A** or **Auro** position, the highbeam headlamps are only switched on when it is dark and the engine is running.

The *indicator* lamp in the instrument cluster lights up when the high-beam headlamps are switched on.

► To switch off the high-beam headlamps: move the combination switch back to its normal position.

The **D** indicator lamp in the instrument cluster goes out.

High-beam flasher

- ► To switch on: turn the SmartKey in the ignition lock to position 1 or 2 or start the engine.
- ▶ Pull the combination switch in the direction of arrow ③.

Hazard warning lamps



The hazard warning lamps automatically switch on if:

- an air bag is deployed.
- the vehicle is slowed down rapidly from a speed of over 45 mph (70 km/h) and comes to a halt.
- ► To switch on the hazard warning lamps: press button ①.

All turn signals flash. If you now switch on a turn signal using the combination switch, only the turn signal lamp on the corresponding side of the vehicle will flash.

corresponding side of the vehicle will flash

► To switch off the hazard warning lamps: press button ①.

If the vehicle returns to a speed of over 6 mph (10 km/h) after a full application of the brakes, the hazard warning lamps are deactivated automatically.

 The hazard warning lamps still operate if the ignition is switched off.

Cornering light function



The cornering light function improves the illumination of the road over a wide angle in the direction you are turning, enabling better visibility in tight bends, for example. The cornering light function can only be activated when the low-beam headlamps are switched on.

Active:

- if you are driving at speeds below 25 mph (40 km/h) and switch on the turn signals or turn the steering wheel
- if you are driving at speeds between 25 mph (40 km/h) and 45 mph (70 km/h) and turn the steering wheel

Not active: if you are driving at speeds above 25 mph (40 km/h) or switch off the turn signals or turn the steering wheel to the straight-ahead position.

The cornering light function may remain lit for a short time, but is automatically switched off after no more than three minutes.

Headlamps fogged up on the inside

The headlamps may fog up on the inside if there is high atmospheric humidity.


Drive with the headlamps switched on. The level of moisture diminishes, depending on the length of the journey and the weather conditions (humidity and temperature).

If the level of moisture does not diminish:

 Have the headlamps checked at a qualified specialist workshop.

Interior lighting

Overview of interior lighting



Overhead control panel

- M Switches the left-hand reading lamp on/off
- ② Switches the automatic interior lighting control on/off
- ③ ★ Switches the right-hand reading lamp on/off
- ④ 🔄 Switches the interior lighting on/off

Interior lighting control

Important notes

In order to prevent the vehicle's battery from discharging, the interior lighting functions are automatically deactivated after some time except for when the SmartKey is in position **2** in the ignition lock.

The color and brightness of the ambient lighting may be set using the on-board computer (\triangleright page 192).

Automatic interior lighting control

► To switch on/off: press the _____ button. When the automatic interior lighting control is activated, the button is flush with the overhead control panel. The interior lighting automatically switches on if you:

- unlock the vehicle
- open a door
- remove the SmartKey from the ignition lock

The interior light is activated for a short while when the SmartKey is removed from the ignition lock. You can activate this delayed switch-off using the on-board computer (> page 193).

Manual interior lighting control

- ► To switch the interior lighting on/off: press the ____ button.
- ► To switch the reading lamps on/off: press the button.

Crash-responsive emergency lighting

The interior lighting is activated automatically if the vehicle is involved in an accident.

To switch off the crash-responsive emergency lighting: press the hazard warning lamp button.

or

 Lock and then unlock the vehicle using the SmartKey.

Replacing bulbs

Important safety notes

Xenon bulbs

Xenon bulbs carry a high voltage. You could get an electric shock and be seriously or even fatally injured if you touch the electric contacts on Xenon bulbs. Therefore, never remove the cover from Xenon bulbs.

Do not change the Xenon bulbs yourself, but have them replaced at a qualified workshop.

If your vehicle is equipped with Xenon bulbs, you can recognize this by the following: the cone of light from the Xenon bulbs moves from the top to the bottom and back again when you start the engine. For this to be observed, the lights must be switched on before starting the engine.

Bulbs and lamps are an important aspect of vehicle safety. You must therefore make sure that these function correctly at all times. Have the headlamp setting checked regularly.

Other bulbs

There are bulbs other than the Xenon bulbs that you cannot replace. Replace only the bulbs listed (\triangleright page 110). Have the bulbs that you cannot replace yourself changed at a qualified specialist workshop.

If you require assistance changing bulbs, consult a qualified specialist workshop.

Do not touch the glass tube of new bulbs with your bare hands. Even minor contamination can burn into the glass surface and reduce the service life of the bulbs. Always use a lintfree cloth or only touch the base of the bulb when installing.

Only use bulbs of the correct type. If the new bulb still does not light up, consult a qualified specialist workshop.

Bulbs and lamps are an important aspect of vehicle safety. You must therefore make sure that these function correctly at all times. Have the headlamp setting checked regularly.

₼ WARNING

Bulbs and lamps can become very hot. For this reason, allow them to cool down before changing them. Otherwise, you could burn yourself when you touch them.

Keep bulbs out of the reach of children. Otherwise, they could, for example, damage the bulbs and injure themselves.


Never use a bulb which has been dropped. Such a bulb may explode and injure you.

Halogen bulbs are pressurized and could explode when you change them, especially if

they are very hot. You should therefore wear eye protection and gloves when you are changing them.


Overview: changing bulbs/bulb types

You can change the following bulbs. The bulb type can be found in the legend.




Halogen headlamps

- ① Low-beam headlamp: H7 55 W
- ② High-beam headlamp: H7 55 W
- ③ Turn signal lamp: PY 21 W



Bi-Xenon headlamps (1) Cornering lamp: H7 55 W



Tail lamp ① Backup lamp: W 16 W

Changing the front bulbs


Removing and installing the cover in the front wheel housing

You must remove the cover from the front wheel housing before you can change the front bulbs.




- ► To remove: switch off the lights.
- ► Turn the front wheels inwards.
- ▶ Slide up cover ① and lift it out.
- ► To install: insert cover ① again and slide it downwards until it engages.

Low-beam headlamps (halogen headlamps)



- ▶ Remove the cover in the front wheel arch (▷ page 111).
- Turn housing cover ① counter-clockwise and pull it out.
- ▶ Press clamp ② upward.
- ▶ Pull out connector ③ with the bulb.
- ► Take the bulb out of connector ③.
- Attach the new bulb to connector (3) and insert it into the bracket of clamp (2).
 Make sure the bulb is positioned correctly.
- ▶ Press clamp (2) downward.
- Attach housing cover ① and turn it clockwise until it engages.
- ▶ Replace the cover in the front wheel arch (▷ page 111).

High-beam headlamps (halogen headlamps)/cornering lamps (Bi-Xenon headlamps)



Lights and windshield wipers


112 Replacing bulbs

- ► Switch off the lights.
- ▶ Open the hood.
- ► Turn housing cover ① counter-clockwise and pull it out.
- Push the bulb upwards by the holder, disconnect it and pull it out of bulb holder (2).
- Insert the new bulb into bulb holder ②, push it down and secure it in place.
- Attach housing cover ① and turn it clockwise until it engages.

Parking lamps/standing lamps (halogen headlamps)

Due to their location, have the bulbs in the side marker lamp changed at a qualified specialist workshop.


Turn signal lamp (halogen headlamps)




- ▶ Switch off the lights.
- Open the hood.
- Turn bulb holder ① counterclockwise and pull it out.
- ► Take the bulb out of bulb holder ①.
- ▶ Insert the new bulb into bulb holder ①.
- Insert bulb holder ① and turn it clockwise until it engages.

Changing the rear bulbs

Backup lamp



- Switch off the lights.
- Make sure the roof is closed.
- ▶ Open the trunk.
- ▶ Turn and pull out buffer stop ②.
- ▶ Unclip catch ① for side paneling ③.



- Reach upwards into side paneling ③, loosen and pull downwards until holder ④ of the backup lamp is easily accessible.
- Pull out bulb holder (4).
- ▶ Pull out the bulb.
- ▶ Insert the new bulb into bulb holder ④.
- ▶ Insert bulb holder ④ until it engages.
- ► Install side paneling ③ precisely.
- ▶ Clip in catch ① for side paneling ③.
- Push in and tighten buffer stop (2).

Windshield wipers 113

Windshield wipers

Switching the windshield wipers on/ off

Wiper blades are components that are subject to wear and tear. Replace the wiper blades twice a year, preferably in the spring and fall. Otherwise the windshield will not be wiped properly. As a result, you may not be able to observe surrounding traffic conditions and could cause an accident.

Do not operate the windshield wipers when the windshield is dry, as this could damage the wiper blades. Moreover, dust that has collected on the windshield can scratch the glass if wiping takes place when the windshield is dry.

If the windshield wipers leave smears on the windshield after the vehicle has been washed in an automatic car wash, wax or other residues may be the reason for this. Clean the windshield using washer fluid after washing the vehicle in an automatic car wash.



Combination switch

- 1 **0** Windshield wipers off
- **2** \cdots Intermittent wipe, low⁵
- **3** $\overline{)}$ Intermittent wipe, high⁶
- 4 Continuous wipe, slow
- ⁵ Rain sensor set to low sensitivity.
- ⁶ Rain sensor set to high sensitivity.

- 5 Continuous wipe, fast
- Single wipe/ To wipe the windshield using washer fluid
- Switch on the ignition.
- Turn the combination switch to the corresponding position.
- Vehicles with a rain sensor: if the windshield becomes dirty in dry weather conditions, the windshield wipers may be activated inadvertently. This could then damage the windshield wiper blades or scratch the windshield.

For this reason, you should always switch off the windshield wipers in dry weather.

In the ••• or •••• position, the appropriate wiping frequency is set automatically according to the intensity of the rain. In the •••• position, the rain sensor is more sensitive than in the ••• position, causing the windshield wipers to wipe more frequently.

Replacing the wiper blades

Important safety notes

For safety reasons, switch off the wipers and remove the SmartKey from the starter switch before replacing a wiper blade. Otherwise, the wiper motor could suddenly turn on and cause injury.

- To avoid damaging the wiper blades, make sure that you touch only the wiper arm of the wiper.
- Never open the hood if a windshield wiper arm has been folded away from the windshield.

Never fold a windshield wiper arm without a wiper blade back onto the windshield.

114 Windshield wipers

Hold the windshield wiper arm firmly when you change the wiper blade. If you release the windshield wiper arm without a wiper blade and it falls onto the windshield, the windshield may be damaged by the force of the impact.


Mercedes-Benz recommends that you have the wiper blades changed at a qualified specialist workshop.

Always position the windshield wiper arms vertically before folding them away from the windshield. By doing so, you will avoid damage to the hood.

Replacing the wiper blades


Removing the wiper blades

- Turn the SmartKey to position 1 or 2 in the ignition lock.
- Set the windshield wipers to position _____.
- When the wiper arms have reached a vertical position, turn the SmartKey to position **0** and remove it from the ignition lock.
- Fold the wiper arms away from the windshield.



- ▶ Press both release clips ②.
- ► Fold wiper blade ① in the direction of arrow ③ away from wiper arm ④.
- Remove wiper blade (1) in the direction of arrow (5).

Installing the wiper blades



- Position new wiper blade (1) with recess (6) on lug (5).
- Fold wiper blade ① in the direction of arrow ③ onto the wiper arm, until retaining clips ② engage in bracket ④.
- Make sure that wiper blade (1) is seated correctly.
- Fold the wiper arm back onto the windshield.

Problems with the windshield wipers

The windshield wipers are obstructed

Leaves or snow, for example, may be obstructing the windshield wiper movement. The wiper motor has been deactivated.

- ▶ Remove the cause of the obstruction.
- Switch the windshield wipers back on.

The windshield wipers are inoperative

The windshield wiper drive is malfunctioning.

- Select another wiper speed on the combination switch.
- Have the windshield wipers checked at a qualified specialist workshop.

Useful information	116
Overview of climate control sys- tems	116
Operating the climate control sys-	
tems	121
Setting the air vents	126

Useful information

- This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- Please read the information on qualified specialist workshops (▷ page 23).

Overview of climate control systems

Important safety notes

MARNING

Severe conditions (e.g. strong air pollution) may require replacement of the filter before its scheduled replacement interval. A clogged filter will reduce the air volume to the interior and the windows could fog up, impairing visibility and endangering you and others. Have a blocked filter replaced at a Mercedes-Benz Center as soon as possible.

MARNING

Follow the recommended settings for heating and cooling given on the following pages. Otherwise, the windows could fog up, impairing visibility and endangering you and others.

The air-conditioning system/automatic climate control controls the temperature and the humidity of the vehicle interior and filters undesirable substances from the air.


The air-conditioning system/automatic climate control is only operational when the engine is running.⁷ The system only works optimally when the side windows and the roof are closed.

Ventilate the vehicle for a brief period during warm weather. This will speed up the cooling process and the desired vehicle interior temperature will be reached more quickly.

1 The integrated filter can filter out most particles of dust and completely filters out pollen. A clogged filter reduces the amount of air supplied to the vehicle interior. For this reason, you should always observe the interval for replacing the filter, which is specified in the Maintenance Booklet. As it depends on environmental conditions, e.g. heavy air pollution, the interval may be shorter than stated in the Maintenance Booklet.


⁷ The residual heat function can only be activated/deactivated when the ignition is switched off.

Air-conditioning system control panel



Canada only

- (1) To set the temperature (\triangleright page 122)
- ② To activate/deactivate the residual heat function (▷ page 125)
- ③ To set the air distribution (\triangleright page 123)
- (4) To defrost the windshield (\triangleright page 124)
- ⑤ To activate/deactivate cooling with air dehumidification (▷ page 121)
- (6) To activate / deactivate air-recirculation mode (▷ page 125)
- ⑦ To set the airflow (\triangleright page 123)
- ⑧ To switch the rear window defroster on/off (▷ page 124)



USA only

- (1) To set the temperature (\triangleright page 122)
- ② To switch maximum cooling MAX COOL on/off (▷ page 124)

Climate control


118 Overview of climate control systems

- (3) To set the air distribution (\triangleright page 123)
- (4) To defrost the windshield (\triangleright page 124)
- ⑤ To activate/deactivate cooling with air dehumidification (▷ page 121)
- (6) To activate / deactivate air-recirculation mode (▷ page 125)
- \bigcirc To set the airflow (\triangleright page 123)
- (8) To switch the rear window defroster on/off (\triangleright page 124)

Notes on using the air-conditioning system

Below, you can find a number of notes and recommendations to help you use the airconditioning system optimally.

- Switch on climate control using the <u>A/C</u> button. The indicator lamp in the <u>A/C</u> button lights up.
- Set the temperature to 72 °F (22 °C).
- Recommendation for air distribution in winter: set the *r,i* and *r,i* settings.
 Recommendation for air distribution in summer: set the *r,i* setting.
- Only use the "defrosting" function briefly until the windshield is clear again.
- Only use "air-recirculation" mode briefly, e.g. if there are unpleasant outside odors or when in a tunnel. The windows could otherwise fog up as in air-recirculation mode no fresh air is drawn into the vehicle.




Canada only

- ① To set the temperature, left (\triangleright page 122)
- (2) To defrost the windshield (\triangleright page 124)
- ③ To switch the ZONE function on/off
- ④ To activate/deactivate cooling with air dehumidification (▷ page 121) To activate/deactivate the residual heat function (▷ page 125)
- (5) To switch the rear window defroster on/off (\triangleright page 124)
- \bigcirc To set the temperature, right (\triangleright page 122)
- ⑦ To activate/deactivate air-recirculation mode (▷ page 125)
- (8) To set the air distribution (\triangleright page 123)
- (9) To increase the airflow (\triangleright page 123)
- (10) To reduce the airflow (\triangleright page 123)
- (1) To switch climate control on/off (\triangleright page 121)
- To set climate control to automatic (> page 122)

Climate control

120 Overview of climate control systems



USA only

Climate control

- (1) To set the temperature, left (\triangleright page 122)
- (2) To defrost the windshield (\triangleright page 124)
- ③ To switch maximum cooling MAX COOL on/off (▷ page 124)
- ④ To activate / deactivate cooling with air dehumidification (▷ page 121)
- (5) To switch the rear window defroster on/off (\triangleright page 124)
- (6) To set the temperature, right (\triangleright page 122)
- ⑦ To activate/deactivate air-recirculation mode (▷ page 125)
- (8) To set the air distribution (\triangleright page 123)
- (9) To increase the airflow (\triangleright page 123)
- (1) To reduce the airflow (\triangleright page 123)
- (1) To switch climate control on/off (\triangleright page 121)
- ⑦ To set climate control to automatic (▷ page 122)

Notes on using 2-zone automatic climate control

The following contains instructions and recommendations to enable you to get the most out of your automatic climate control.

- Activate climate control using the Auro and $\boxed{A/C}$ buttons⁸/ $\boxed{A/C}{4cc}$ ⁹. The indicator lamps in the Auro and $\boxed{A/C}$ / $\boxed{A/C}{4cc}$ buttons light up.
- Set the temperature to 72 °F (22 °C).

- Only use the "defrosting" function briefly until the windshield is clear again.
- Only use "air-recirculation" mode briefly, e.g. if there are unpleasant outside odors or when in a tunnel. The windows could otherwise fog up as in air-recirculation mode no fresh air is drawn into the vehicle.
- Use the ZONE function to adopt the temperature settings on the driver's side for the front-passenger side and the rear

- 8 USA only.
- ⁹ Canada only.

compartment as well. The indicator lamp in the zone button goes out.

• Use the residual heat function if you want to heat or ventilate the vehicle interior when the ignition is switched off. The "residual heat" function can only be activated or deactivated with the ignition switched off.

Operating the climate control systems

Activating/deactivating climate control

Important information

MARNING

When the climate control system is switched off, the outside air supply and circulation are also switched off. Only choose this setting for a short time when the retractable hardtop (vario-roof) is closed. Otherwise, the windows could fog up, impairing visibility and endangering you and others.

 Activate climate control primarily using the auto button (▷ page 122).

Activating/deactivating

Air-conditioning system

- ► To activate: turn airflow control ⑦ (▷ page 117) clockwise to the desired position (except position 0).
- ► To deactivate: turn airflow control ⑦
 (▷ page 117) counter-clockwise to position
 0.

Dual-zone automatic climate control

- Turn the SmartKey to position 2 in the ignition lock.
- ► **To activate:** press the Auro button. The indicator lamp in the Auro button lights up. Airflow and air distribution are set to automatic mode.

or

- Press the OFF button. The indicator lamp in the OFF button goes out. The previously selected settings come into effect again.
- ► To deactivate: press the OFF button. The indicator lamp in the OFF button lights up.

Activating/deactivating cooling with air dehumidification

Important information

The cooling with air dehumidification function is only available when the engine is running. The air inside the vehicle is cooled and dehumidified according to the temperature selected.

If you switch off the cooling function, the vehicle will not be cooled when weather conditions are warm. The windows can fog up more quickly. Window fogging may impair visibility and endanger you and others.

Condensation may drip from the underside of the vehicle when it is in cooling mode. This is normal and not a sign that there is a malfunction.

Depending on the equipment level, the control panel has either the $\begin{bmatrix} A/C \\ HET \end{bmatrix}$ button or $\boxed{A/C}$ button.

• The cooling with air dehumidification function uses refrigerant R134a. This coolant does not contain chlorofluorocarbons, and therefore does not damage the ozone layer.

122 Operating the climate control systems

Activating/deactivating

► To switch on: press the A/C or A/C start button.

The indicator lamp in the A/C or A/C button comes on.

► To deactivate: press the A/C or A/C estructure button.

The indicator lamp in the $\boxed{A/C}$ or $\boxed{A/C}$ button goes off. The cooling with air dehumidification function has a delayed switch-off feature.

Problems with the cooling with air dehumidification function

If the $\boxed{A/C}$ or $\boxed{A/C}$ button is pressed, the indicator lamp in the button flashes three times or stays off. You can no longer switch on the cooling with air dehumidification function.

► Consult a qualified specialist workshop.

Setting climate control to automatic

MARNING

If you switch off the cooling function, the vehicle will not be cooled when weather conditions are warm. The windows can fog up more quickly. Window fogging may impair visibility and endanger you and others.

The "automatic climate control" function is only available in conjunction with automatic climate control.

In automatic mode, the set temperature is maintained automatically at a constant level. The system automatically regulates the temperature of the dispensed air, the airflow and the air distribution.

Automatic mode will achieve optimal operation if cooling with air dehumidification is also activated. If desired, cooling with air dehumidification can be deactivated.

- Turn the SmartKey to position 2 in the ignition lock.
- Set the desired temperature.
- ► To activate: press the AUTO button. The indicator lamp in the AUTO button lights up. Automatic air distribution and airflow are activated.
- ► To switch off: press the 🤃
- or
- Press the solution or solution. The indicator lamp in the Auro button goes out.

Setting the temperature

Air-conditioning system

- Turn the SmartKey to position 2 in the ignition lock.
- ► To increase/reduce: turn thumbwheel ① clockwise or counterclockwise (▷ page 117).

Only change the temperature setting in small increments. Start at 72 $^\circ\!\!F$ (22 $^\circ\!\!C$).

Dual-zone automatic climate control

Different temperatures can be set for the driver's and front-passenger sides.

- Turn the SmartKey to position 2 in the ignition lock.
- ► To increase/reduce: turn controls ① and ③ (▷ page 119) clockwise or counterclockwise.

Only change the temperature setting in small increments. Start at 72 $^{\circ}$ F (22 $^{\circ}$ C).

Setting the air distribution

Air distribution settings

Air-conditioning system

- Directs the airflow through the defroster vents
- **T** Directs the airflow through the footwell air vents
- Directs the airflow through the center and side air vents

You can also activate several air distribution settings simultaneously. To do this, press multiple air distribution buttons. The air is then directed through various vents.

Dual-zone automatic climate control

- Directs the airflow through the center and side air vents
- Directs the airflow through the footwell air vents
- Directs the airflow through the center and side air vents as well as the footwell air vents
- Directs the airflow through the defroster vents
- Directs the airflow through the defroster, center and side air vents.¹⁰
- Directs the airflow through the footwell and defroster vents
- Directs the airflow through the defroster, center and side air vents as well as the footwell air vents¹⁰
- Content of the air distribution setting, airflow is always directed through the side air vents. You can only close the side air vents, by fully closing the adjuster on the side air vents (▷ page 127).

Air-conditioning system

- Turn the SmartKey to position 2 in the ignition lock.
- Press one or more of the , , , ,
 buttons.
 The corresponding indicator lamp lights up briefly.

Dual-zone automatic climate control

- Turn the SmartKey to position 2 in the ignition lock.
- Press the justice button repeatedly until the desired symbol appears in the display.

Setting the airflow

Air-conditioning system

- Turn the SmartKey to position 2 in the ignition lock.
- ► To increase/reduce: turn thumbwheel
 ⑦ clockwise or counter-clockwise
 (▷ page 117).

Dual-zone automatic climate control

- Turn the SmartKey to position 2 in the ignition lock.

Switching the ZONE function on/off

This function is only available with automatic climate control.

► To switch on: press the ZONE button. The indicator lamp in the ZONE button lights up.

The temperature setting for the driver's side is not adopted for the front-passenger side.

Climate control

¹⁰ Canada only.

124 Operating the climate control systems

When the buttons or controls for temperature, airflow or air distribution are activated, the temperature setting for the driver's side is not adopted for the other climate control zones.

► To switch off: press the ZONE button. The indicator lamp in the ZONE button goes out.

The temperature setting for the driver's side is adopted for the front-passenger side.

Defrosting the windshield

You can use this function to defrost the windshield or to defrost the inside of the windshield and the side windows.

- You should only select the defrosting function until the windshield is clear again.
- Turn the SmartKey to position 2 in the ignition lock.
- ► To activate: press the max button. The indicator lamp in the max button lights up.

The climate control system switches to the following functions:

- · cooling with air dehumidification on
- high airflow¹¹
- high temperature¹¹
- air distribution to the windshield and front side windows
- air-recirculation mode off
- ► To switch off: press the @ button. The indicator lamp in the @ button goes out. The previously selected settings come into effect again. The cooling with air

dehumidification function remains on. Airrecirculation mode remains deactivated.

- or
- Press the Auro button¹². The indicator lamp in the WMX button goes out. Airflow and air distribution are set to automatic mode.

MAX COOL maximum cooling

The MAX COOL function is only available in vehicles for the USA.

MAX COOL is only operational when the engine is running.

When you activate MAX COOL, climate control switches to the following functions:

- maximum cooling
- maximum airflow
- · air-recirculation mode on
- ► To activate: press the MML button. The indicator lamp in the button lights up.
- ► To deactivate: press the Max button again.

The indicator lamp goes out. The previously selected settings come into effect again.

Rear window defroster

Activating/deactivating

Any accumulation of snow and ice should be removed from the rear window before driving. Visibility could otherwise be impaired, endangering you and others.

The rear window defroster has a high current draw. You should therefore switch it off as soon as the window is clear. Otherwise, the rear window defroster switches off automatically after several minutes.

¹¹ Depending on the outside temperature.

¹² Automatic climate control.

If the battery voltage is too low, the rear window defroster may switch off.

- Turn the SmartKey to position 2 in the ignition lock.
- Press the press the press the press the press the press the press button. The indicator lamp in the press button lights up or goes out.

Problems with the rear window defroster

If the indicator lamp in the <u>were</u> rear window defroster button flashes, the on-board voltage is too low or the roof is open. The rear window defroster has deactivated prematurely or cannot be activated.

 Switch off any consumers that are not required, e.g. reading lamps or interior lighting.

When the battery is sufficiently charged, the rear window defroster is activated again automatically.

or

 Close the roof. The rear window defroster can be activated again.

Activating/deactivating airrecirculation mode

You can deactivate the flow of fresh air if unpleasant odors are entering the vehicle from outside. The air already inside the vehicle will then be recirculated.

MARNING

Fogged windows impair visibility, endangering you and others. If the windows begin to fog on the inside, switching off the air recirculation mode immediately should clear interior window fogging. If interior window fogging persists, make sure the air conditioning is activated, or press the www. button.

- ► Turn the SmartKey to position 2 in the ignition lock.
- ► To activate: press the button. The indicator lamp in the button lights up.
- Air-recirculation mode is activated automatically at high outside temperatures. When air-recirculation mode is activated automatically, the indicator lamp in the solution is not lit.
 Outside air is added after about

30 minutes. ► To deactivate: press the button.

- ▶ To deactivate: press the button. The indicator lamp in the button goes out.
- Air-recirculation mode deactivates automatically:
 - after approximately five minutes at outside temperatures below approximately 41 °F (5 °C)
 - after approximately five minutes if cooling with air dehumidification is deactivated
 - after approximately 30 minutes at outside temperatures above approximately 41 °F (5 °C)

Activating/deactivating the residual heat function

It is possible to make use of the residual heat of the engine to continue heating the stationary vehicle for up to 30 minutes after the engine has been switched off. The heating time depends on the temperature that has been set.

Depending on the equipment level, the control panel has either the **REST** or the A/C button.

The "residual heat" function is only available in Canada.

1 The blower will run at a low speed regardless of the airflow setting.

Climate control

126 Setting the air vents

- If you activate the residual heat function at high temperatures, only the ventilation will be activated. The blower runs at medium speed.
- Turn the SmartKey to position 0 in the ignition lock or remove it.
- ► To activate: press the REST or A/C button. The indicator lamp in the REST or A/C REST or A/C REST or A/C REST
- ► To deactivate: press the REST or A/C button. The indicator lamp in the REST or A/C button goes off.

Climate control

- Residual heat is deactivated automatically:
 - after about 30 minutes
 - when the ignition is switched on
 - if the battery voltage drops
 - if the coolant temperature is too low

Setting the air vents

Important safety notes

MARNING

When operating the climate control, the air that enters the passenger compartment through the air vents can be very hot or very cold (depending on the set temperature). This could cause burns or frostbite to unprotected skin in the immediate area of the air vents. Always keep sufficient distance between unprotected parts of the body and the air vents. If necessary, use the air distribution adjustment to direct the air to air vents in the vehicle interior that are not in the immediate area of unprotected skin.


In order to ensure the direct flow of fresh air through the air vents into the vehicle interior, please observe the following notes:

• keep the air inlet grille on the hood and in the engine compartment on the front-

passenger side free of blockages, such as ice, snow or leaves.

- never cover the air vents or air intake grilles in the vehicle interior.
- You can tilt the adjuster for the air vents vertically or horizontally to alter the direction of the airflow.
- For optimal climate control in the vehicle, open the air vents completely and set the adjusters to the central position.


Setting the center air vents



- To open the center air vent
- 2 To close the center air vent
- ③ Center air vent, right
- ④ Center air vent, left
- ► To open the center air vent: turn the adjuster in center air vent ③ or ④ in the direction of the arrow to position 1.
- ► To close the center air vent: turn the adjuster in center air vent ③ or ④ in the direction of the arrow to position 2 until it engages.

Setting the air vents | 127

Setting the side air vents




- 1 To open the side air vent
- **2** To close the side air vent
- (3) Side window defroster vent
- ④ Side air vent
- ▶ To open the side air vent: turn the adjuster in side air vent ④ in the direction of the arrow to position 1.
- ► To close the side air vent: turn the adjuster in side air vent ④ in the direction of the arrow to position 2 until it engages.

AIRSCARF, setting the vents

₼ WARNING

When operating the climate control, the air that enters the passenger compartment through the air vents can be very hot or very cold (depending on the set temperature). This could cause burns or frostbite to unprotected skin in the immediate area of the air vents.

Always keep sufficient distance between unprotected parts of the body and the air vents. If necessary, use the air distribution adjustment to direct the air to air vents in the vehicle interior that are not in the immediate area of unprotected skin.



You can adjust the blower output of AIRSCARF vents (1) using the AIRSCARF button (\triangleright page 96).

Driving and parking

Useful information	130
Breaking-in notes	130
Driving	130
Manual transmission	139
Automatic transmission	140
Refueling	146
Parking	149
Driving tips	152
Driving systems	156

Useful information

This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.

 Please read the information on qualified specialist workshops (▷ page 23).

Breaking-in notes

The first 1,000miles (1,500 km)

The more you look after the engine when it is new, the more satisfied you will be with its performance in the future.

- You should therefore drive at varying vehicle and engine speeds for the first 1,000miles (1,500km).
- Avoid heavy loads, e.g. driving at full throttle, during this period.
- Change gear in good time, before the tachometer needle is $\frac{2}{3}$ of the way to the red area of the tachometer.
- Do not manually shift to a lower gear to brake the vehicle.

Vehicles with automatic transmission:

- Ideally, for the first 1,000 miles (1,500km) drive in drive program **C**.
- Do not manually shift to a lower gear to brake the vehicle.
- If possible, do not depress the accelerator pedal past the point of resistance (kickdown).
- Only select shift ranges **3**, **2** or **1** when driving slowly, e.g. in mountainous terrain.

After 1,000 miles (1,500km), you can increase the engine speed gradually and bring the vehicle up to full speed.

Additional breaking-in notes for AMG vehicles:

- do not drive faster than 85 mph (140 km/h) for the first 1,000 miles (1,500 km).
- only allow the engine to reach a maximum engine speed of 4,500 rpm briefly.
- change gear in good time.
- You should also observe these breakingin notes if the engine or parts of the drive train on your vehicle have been replaced.
- Always observe the respective speed limits.

AMG vehicles with rear axle locking differential

Your vehicle is equipped with a self-locking differential on the rear axle. To improve the protection of the differential on the rear axle, change the oil after a break-in distance of 2,000 miles (3,000 km). This oil change extends the service life of the differential. Have the oil change carried out at a qualified specialist workshop.

Driving

Important safety notes

Make sure absolutely no objects are obstructing the pedals' range of movement. Keep the driver's footwell clear of all obstacles. If there are any floormats or carpets in the footwell, make sure the pedals still have sufficient clearance.

During sudden driving or braking maneuvers the objects could get caught between the pedals. You could then no longer brake or accelerate. This could lead to accidents and injury.

Driving | 131

MARNING

On slippery road surfaces, never downshift in order to obtain braking action. This could result in drive wheel slip and reduced vehicle control. Your vehicle's ABS will not prevent this type of loss of control.

MARNING ▲

Manual transmission: Wait until the vehicle is stationary before removing the SmartKey from the starter switch. The vehicle cannot be steered when the SmartKey is removed from the starter switch.

MARNING

It is dangerous to shift the automatic transmission out of parking position ${\bf P}$ or neutral position ${\bf N}$ if the engine speed is higher than idle speed. If your foot is not firmly on the brake pedal, the vehicle could accelerate quickly forward or in reverse. You could lose control of the vehicle and hit someone or something. Only shift into gear when the engine is idling normally and when your right foot is firmly on the brake pedal.

Warm up the engine quickly. Do not use the engine's full performance until it has reached operating temperature.

Only shift the automatic transmission to the desired drive position when the vehicle is stationary.

Where possible, avoid spinning the drive wheels when pulling away on slippery roads. You could otherwise damage the drive train.

AMG vehicles: at low engine oil temperatures below 68 °F (+20 °C), the maximum engine speed is restricted in order to protect the engine. To protect the engine and maintain smooth engine operation, avoid driving at full throttle when the engine is cold.

SmartKey positions

SmartKey



- To remove the SmartKey
 Vehicles with automatic transmission: shift the transmission to position P
- 1 Power supply for some consumers, such as the windshield wipers
- Ignition (power supply for all consumers) and drive position
- 3 To start the engine

If the SmartKey is in position **0** in the ignition lock for an extended period of time, it can no longer be turned in the ignition lock. The steering is then locked. To unlock, remove the SmartKey and reinsert it into the ignition lock.

The steering is locked when you remove the SmartKey from the ignition lock.

The SmartKey can be turned in the ignition lock even if it is not the correct SmartKey for the vehicle. The ignition is not switched on. The engine cannot be started.

KEYLESS-GO

General information

Vehicles with KEYLESS-GO are equipped with a SmartKey featuring an integrated KEYLESS-GO function and a detachable Start/Stop button.

The Start/Stop button must be inserted into the ignition lock and the SmartKey must be in the vehicle.


132 Driving

Pressing the Start/Stop button several times in succession corresponds to the different SmartKey positions in the ignition lock. This is only the case if you are not depressing the brake pedal.

If you depress the brake pedal and press the Start/Stop button, the engine starts immediately.

The Start/Stop button can be removed from the ignition lock. Then, you can insert the SmartKey into the ignition lock.

• You do not have to remove the Start/Stop button from the ignition lock when you leave the vehicle. However, you should always take the SmartKey with you when leaving the vehicle. The vehicle can be started with the Start/Stop button and the electrical equipment can be operated while the SmartKey is in the vehicle.



- (1) Start/Stop button
- Ignition lock
- ► Insert Start/Stop button ① into ignition lock ②.
- When you insert Start/Stop button (1) into ignition lock (2), the system requires a detection time of approximately two seconds before you can use Start/ Stop button (1).



Start/Stop button

- ③ USA only
- ④ Canada only
- Position 0: if Start/Stop button 1 has not yet been pressed, this corresponds to the SmartKey being removed from the ignition.
- Position 1: press Start/Stop button ①.
 You can now activate the windshield wipers, for example.
- If you then open the driver's door when in this position, the power supply is deactivated.
- Position 2 (ignition): press Start/Stop button 1 twice.
- If you press Start/Stop button ① once when in this position and the driver's door is open, the power supply is deactivated again.

As soon as the ignition is switched on, all the indicator lamps in the instrument cluster light up. If an indicator lamp does not go out after the engine is started or if it lights up while the vehicle is in motion, see (\triangleright page 229).

Starting the engine

Important safety notes

Inhalation of exhaust gas is hazardous to your health. All exhaust gas contains carbon monoxide (CO), and inhaling it can cause unconsciousness and possible death.

Driving and parking

Do not run the engine in confined areas (such as a garage) which are not properly ventilated. If you think that exhaust gas fumes are entering the vehicle while driving, have the cause determined and corrected immediately. If you must drive under these conditions, drive only with at least one window fully open at all times.

Do not depress the accelerator pedal when starting the engine.

General information

- AMG vehicles: the exhaust flap of the exhaust system will be checked after every cold start. A resulting noise can be heard during this process.
- During a cold start, the engine runs at higher speeds to enable the catalytic converter to reach its operating temperature. The sound of the engine may change during this time.

Manual transmission

- Depress the brake pedal and keep it depressed.
- ► Fully depress the clutch pedal.
- ► Shift to neutral N.
- You can only start the engine when the clutch pedal is fully depressed.

Automatic transmission

- Shift the transmission to position P. The transmission position display in the multifunction display shows P.
- **1** You can also start the engine when the transmission is in position **N**.

Starting procedure with the SmartKey

To start the engine using the SmartKey instead of KEYLESS-GO, pull the Start/ Stop button out of the ignition lock. Turn the SmartKey to position 3 in the ignition lock (▷ page 131) and release it as soon as the engine is running.

Using KEYLESS-GO to start the engine

As long as the SmartKey is in your vehicle, the vehicle can be started. Therefore, never leave children unattended in the vehicle, as they could otherwise accidentally start the engine. When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury.

- The Start/Stop button can be used to start the vehicle manually without inserting the SmartKey into the ignition lock. The Start/Stop button must be inserted into the ignition lock and the SmartKey must be in the vehicle. This mode for starting the engine operates independently of the ECO start/stop automatic engine start function.
- Depress the brake pedal and keep it depressed.
- Press the Start/Stop button (▷ page 131) once. The engine starts.

Pulling away

Manual transmission

- Depress the brake pedal and keep it depressed.
- Fully depress the clutch pedal.
- ► Shift to either first gear or reverse gear **R**.
- ▶ Release the electric parking brake (▷ page 150).

- ▶ Release the brake pedal.
- Slowly release the clutch pedal and gently depress the accelerator pedal.

Change gear in good time and avoid spinning the wheels. You could otherwise damage the vehicle.

1 The vehicle locks centrally once you have pulled away. The locking knobs in the doors drop down.

You can open the doors from the inside at any time.

You can also deactivate the automatic locking feature (\triangleright page 193).

Automatic transmission

∧ WARNING

It is dangerous to shift the automatic transmission out of parking position ${\bf P}$ or neutral position ${\bf N}$ if the engine speed is higher than idle speed. If your foot is not firmly on the brake pedal, the vehicle could accelerate quickly forward or in reverse. You could lose control of the vehicle and hit someone or something. Only shift into gear when the engine is idling normally and when your right foot is firmly on the brake pedal.

- It is only possible to shift the transmission from position P to the desired position if you depress the brake pedal. Only then is the selector lever lock released.
- Depress the brake pedal and keep it depressed.
- ► Shift the transmission to position **D** or **R**.
- ▶ Release the brake pedal.
- ► Carefully depress the accelerator pedal. The electric parking brake (▷ page 150) is automatically released.

The red **PARK** (USA only) or (((Canada only) indicator lamp in the instrument cluster goes out.

The vehicle locks centrally once you have pulled away. The locking knobs in the doors drop down.

You can open the doors from the inside at any time.

You can also deactivate the automatic locking feature .

Upshifts take place at higher engine speeds after a cold start. This helps the catalytic converter to reach its operating temperature more quickly.

Hill start assist

Hill start assist helps you when pulling away forwards or in reverse on an uphill gradient. It holds the vehicle for a short time after you have removed your foot from the brake pedal. This gives you enough time to move your foot from the brake pedal to the accelerator pedal and to depress it before the vehicle begins to roll.

Never leave the vehicle when it is held by hill start assist. After approximately one second, hill start assist will no longer brake your vehicle and it could roll away.

- ► Take your foot off the brake pedal.
- Once you have taken your foot off the brake pedal, the vehicle is held for around one second.
- ▶ Pull away.

Hill start assist will not function if:

- you are pulling away on a level road or on a downhill gradient.
- on vehicles with automatic transmission, the transmission is in position **N**.
- the electric parking brake is applied.
- ESP[®] is malfunctioning.

Driving | 135

ECO start/stop function

Important safety notes

If the ECO symbol appears in the multifunction display when the engine is switched off, the engine was switched off automatically. However, all vehicle systems remain active. If you open the door, unfasten your seat belt or remove your foot from the brake pedal, the engine will automatically start. The vehicle may begin moving. There is a risk of an accident.

To prevent the vehicle from pulling away unintentionally, only remove your foot from the brake pedal if you want to drive on.

Do not leave the vehicle until you have switched off the ignition and secured the vehicle to prevent it from rolling away.

Always switch the ignition off and take the key with you when leaving the vehicle.

General notes

The ECO start/stop function is only available for the SLK 55 AMG.

The ECO start/stop function is only available in drive program **C**.

The ECO start/stop function switches the engine off automatically when the vehicle stops moving.

The engine starts automatically when the driver wants to pull away again. The ECO start/stop function thereby helps you to reduce the fuel consumption and emissions of your vehicle.

The system is operational if all conditions for automatic engine switch-off have been fulfilled (\triangleright page 135) and the **ECO** symbol is shown in the multifunction display. In addition, the **Stop/Start active** message is shown in the AMG menu in the multifunction display.

If not all conditions for automatic engine switch-off are fulfilled, the border of the ECO

symbol disappears in the multifunction display. In addition, the Stop/Start inactive message is shown in the AMG menu in the multifunction display.

If the ECO start/stop function is deactivated (> page 136), the ECO symbol and the Stop/Start active or Stop/Start inactive message are not shown.

If automatic cylinder shut-off is active in drive program C, the number of active cylinders 4 is also shown in the ECO symbol. This means that the engine is operating with four cylinders.

If cylinder shut-off is not active, the engine will operate with all eight cylinders. In this case, the number of active cylinders $\mathbf{8}$ is shown in the **ECO** symbol.

Automatic engine switch-off

The ECO start/stop function switches the engine off automatically if the vehicle is braked to a standstill and the brake remains depressed with the transmission in position **D** or **N**.

The engine is only switched off if:

- the vehicle is at a standstill.
- the outside temperature is within the range which is suitable for the system.
- the engine is at normal operating temperature.
- the battery is sufficiently charged.
- the system detects that the windshield is not fogged up when the air-conditioning system is switched on.
- the hood is closed.
- no engine-relevant diagnostics are active.
- the front door is closed and the seat belt is fastened.
- You can still activate the HOLD function when the vehicle is stationary, even if the engine has been switched off automatically. It is then not necessary to continue applying the brakes during the automatic stop phase. When you depress

the accelerator pedal, the engine starts automatically and the braking effect of the HOLD function is deactivated. Depress the accelerator pedal carefully, as the engine must be started first.

1 If you shift the transmission from **R** to **D**, the ECO start/stop function is available again once the ECO symbol reappears in the multifunction display.

Automatic engine switch-off can take place a maximum of three times consecutively. The automatic engine switch-off is then available again after the border of the ECO symbol appears in the multifunction display.

Automatic engine start

The engine starts automatically if:

- you deactivate the ECO start/stop function by pressing the ECO button.
- you switch to drive program S or M.
- you depress the accelerator pedal.
- the vehicle starts to roll.
- the brake system requires this.
- the system detects moisture on the windshield when the air-conditioning system is switched on.
- the charge level of the battery is too low.
- the driver's seat belt is removed or the driver's door is opened.
- \bullet you shift the transmission from position ${\bf D}$ to ${\bf R}.$
- you engage reverse gear R.
- you release the brakes when in transmission position D or N and when the HOLD function is not active.
- you steer the vehicle.
- Shifting the transmission to position P does not start the engine.

Deactivating/activating the ECO start/ stop function



Example: ECO button

- If indicator lamp (2) is off, the ECO start/ stop function has been deactivated manually or as the result of a malfunction. The engine will then not be switched off automatically when the vehicle stops.
- Each time the engine is started, the ECO start/stop function switches to the status (on or off) that was selected before switching off the engine.

Deactivating

- ▶ Press button ① in drive program **C**.
- or
- Switch to drive program S or M (> page 142).
 Indicator lamp (2) on button (1) and the ECO symbol in the multifunction display go out.

The Stop/Start active or Stop/Start inactive message in the AMG menu in the multifunction display goes out.

Activating

▶ Press button ①.

Indicator lamp (2) lights up. If drive program **S** or **M** is active, the automatic transmission switches to drive program **C**. If all conditions for automatic engine switch-off (\triangleright page 135) are fulfilled, the <u>ECO</u> symbol is shown in the multifunction display. In addition, the Stop/Start active message is shown in the AMG menu in the multifunction display.

If not all conditions for automatic engine switch-off (> page 135) are fulfilled, the Stop/Start inactive message will be shown in the AMG menu of the multifunction display and the frame around the ECO symbol fades out. If this is the case, the ECO start/stop function is not available.

138 Driving

Problems with the engine

Problem	Possible causes/consequences and Solutions
The engine does not start. The starter motor can be heard.	 There is a malfunction in the engine electronics. There is a malfunction in the fuel supply. Before attempting to start the engine again, turn the SmartKey in the ignition back to position 0 or press the Start/Stop button repeatedly until all indicator lamps in the instrument cluster go out. Try to start the engine again (▷ page 132). Avoid excessively long and frequent attempts to start the engine as these will drain the battery. If the engine does not start after several attempts: Consult a qualified specialist workshop.
The engine does not start. You cannot hear the starter motor.	 The on-board voltage is too low because the battery is too weak or discharged. Jump-start the vehicle (▷ page 285). If the engine does not start despite attempts to jump-start it: Consult a qualified specialist workshop. The starter motor was exposed to a thermal load that was too high. Allow the starter motor to cool down for approximately two minutes. Try to start the engine again. If the engine still does not start: Consult a qualified specialist workshop.
The engine is not running smoothly and is misfiring.	 There is a malfunction in the engine electronics or in a mechanical component of the engine management system. Only depress the accelerator pedal slightly. Otherwise, non-combusted fuel may get into the catalytic converter and damage it. Have the cause rectified immediately at a qualified specialist workshop.
The coolant temperature gauge shows a value above 248 °F (120 °C).	 The coolant level is too low. The coolant is too hot and the engine is no longer being cooled sufficiently. Stop as soon as possible and allow the engine and the coolant to cool down. Check the coolant level (▷ page 262). Observe the warning notes as you do so and add coolant if necessary.

Manual transmission | 139

Manual transmission

Important safety notes

The movement of the pedals must not be impaired in any way. Do not keep any objects in the driver's footwell. Make sure that floormats or carpets are correctly secured and that there is sufficient clearance for the pedals.

Do not place several floormats on top of one another.

Do not change down for additional engine braking on a slippery road surface. This could cause the drive wheels to lose their grip and the vehicle could skid. This could cause you to lose control of your vehicle and cause an accident.

MARNING

When working on the vehicle, engage the parking brake and shift the manual transmission into the **1st** gear or reverse **R**. The vehicle could otherwise roll away, which could result in an accident and/or serious personal injury.

When shifting between **5th** and **6th** gear, you should always push the gear lever all the way to the right. You could otherwise shift unintentionally into **3rd** or **4th** gear and damage the transmission.

If you shift down at too high a speed (transmission braking), this can cause the engine to overrev, leading to engine damage.

Never hold the vehicle stopped on a hill by using the clutch pedal. There is otherwise a risk of damaging the clutch.

Engaging reverse gear

- Only shift into reverse gear **R** when the vehicle is stationary. Otherwise, you could damage the transmission.
- Stop the vehicle.
- Depress the clutch pedal fully.
- Shift to neutral N.
- Move the gear lever firmly to the left beyond the point of resistance and then forwards.

Shift recommendation

The gearshift recommendations assist you in adopting an economical driving style. The recommended gear is shown in the multifunction display.



 Shift gear according to gearshift recommendation (1) shown in the

Gear lever



Gear lever R Reverse gear 1 to 6 Forward gears multifunction display of the instrument cluster.

Automatic transmission

Important safety notes

MARNING

It is dangerous to shift the automatic transmission out of parking position ${\bf P}$ or neutral position ${\bf N}$ if the engine speed is higher than idle speed. If your foot is not firmly on the brake pedal, the vehicle could accelerate quickly forward or in reverse. You could lose control of the vehicle and hit someone or something. Only shift into gear when the engine is idling normally and when your right foot is firmly on the brake pedal.

MARNING

Keep in mind that turning off the engine alone only will shift the automatic transmission into neutral position **N** automatically.

Always shift the automatic transmission into park position **P** before turning off the engine. Otherwise the vehicle could roll away which could result in an accident and/or serious personal injury.

Selector lever

Overview of transmission positions



Selector lever

- P Park position with selector lever lock
- R Reverse gear
- Neutral
- D Drive

Transmission position and drive program display



- (1) Transmission position display
- Drive program display

The current position of the selector lever is shown by the indicators next to the selector lever.

The indicators light up when the SmartKey is inserted into the ignition lock. The indicators go out when the SmartKey is removed from the ignition lock.

Transmission positions

P Park position

Do not shift the transmission into position $P(\triangleright$ page 149) unless the vehicle is stationary. The parking lock should not be used as a brake when parking. In addition to engaging the parking lock, you must always apply the parking brake to secure the vehicle.

The SmartKey can only be removed if the transmission is in position **P**. If the SmartKey is removed from the ignition lock, the selector lever is locked.

If the vehicle electronics are malfunctioning, the selector lever may be locked in position **P**. To release the selector lever lock, see "Releasing the parking lock manually" (> page 146).

Reverse gear

R

Only shift the transmission to **R** when the vehicle is stationary.

N Neutral

Do not shift the transmission to ${\bf N}$ while driving. The transmission could otherwise be damaged.

No power is transmitted from the engine to the drive wheels.

Releasing the brakes will allow you to move the vehicle freely, e.g. to push it or tow it.

If ESP[®] is deactivated or faulty: only shift the transmission to position **N** if the vehicle is in danger of skidding, e.g. on icy roads.

Rolling in neutral **N** can damage the drive train.

D Drive

The automatic transmission changes gear automatically. All forward gears are available.

Changing gear

The automatic transmission shifts to the individual gears automatically when it is in transmission position **D**. This automatic gearshifting behavior is determined by:

- a shift range restriction, if selected
- the selected drive program (▷ page 142)
- the position of the accelerator pedal
- the road speed

Driving tips

Double-clutch function

When shifting down, the double-clutch function is active regardless of the currently selected drive program. The double-clutch function reduces load change reactions and is conducive to a sporty driving style. The sound generated by the double-clutch function depends on the drive program selected.

Kickdown

Use kickdown for maximum acceleration.

Vehicles for USA (except AMG vehicles): fully depress the accelerator pedal.

The transmission shifts to a lower gear depending on the engine speed.

Vehicles for Canada and AMG vehicles: depress the accelerator pedal beyond the pressure point.

The transmission shifts to a lower gear depending on the engine speed.

Working on the vehicle

MARNING

When working on the vehicle, engage the electronic parking brake and shift the automatic transmission into park position **P**. Otherwise the vehicle could roll away which could result in an accident and/or serious personal injury.

Program selector button

General information

The program selector button allows you to choose between different driving characteristics.



Example: program selector button In AMG vehicles, drive program **E** is called drive program **C**.

E Economy C Controlled Efficiency	Comfortable, economical driving
S Sport	Sporty driving style
M Manual	Manual gear shifting

● For further information on the automatic drive program, see (> page 143).

Only change from automatic drive program ${f E}$ or ${f S}$ to manual drive program ${f M}$ when the vehicle is stationary.

- Press program selector button (1) repeatedly until the letter for the desired gearshift program appears in the multifunction display.
- When the engine is started, the automatic transmission always switches to automatic drive program E (drive program C in AMG vehicles).
- AMG vehicles: when in drive program C and with a small load demand, e.g. in city traffic or on a country road, the engine will automatically only operate with four cylinders. This reduces fuel consumption. Cylinder shut-off is inactive in drive programs S and M, so that the engine will operate with all eight cylinders.



- ① Left-hand steering wheel paddle shifter
- Right-hand steering wheel paddle shifter

In the automatic drive program, you can restrict or derestrict the shift range by using the steering wheel paddle shifters (> page 143).

In the manual drive program, you can change gear using the steering wheel paddle shifters or the selector lever (\triangleright page 144).

• You can only change gear with the steering wheel paddle shifters when the transmission is in position **D**.

Automatic drive program

Drive program **E** (drive program **C** on AMG vehicles) is characterized by the following:

- comfort-oriented engine and transmission settings
- optimal fuel consumption resulting from the automatic transmission shifting up sooner
- the vehicle pulling away more gently in forward and reverse gears, unless the accelerator pedal is depressed fully
- increased sensitivity. This improves driving stability on slippery road surfaces, for example
- the automatic transmission shifting up sooner. This results in the vehicle being driven at lower engine speeds and the wheels being less likely to spin

Drive program **S** is characterized by the following:

- sporty engine and transmission settings
- the vehicle pulling away in first gear
- the automatic transmission shifting up later
- the fuel consumption possibly being higher as a result of the later automatic transmission shift points

Shift ranges

Introduction

When the automatic transmission is in position **D**, it is possible to restrict or derestrict the shift range (▷ page 143). The shift range selected is shown in the multifunction display. The automatic transmission shifts only as far as the selected gear.

Shift range

- 3 You can use the engine's braking effect.
- 2 To use the braking effect of the engine on downhill gradients and for driving:
 - on steep mountain roads
 - in mountainous terrain
 - in arduous conditions
- 1 To use the braking effect of the engine on extremely steep downhill gradients and on long downhill stretches

Restricting the shift range

Press the selector lever to the left towards
 D-.

or

 Pull the left-hand steering wheel paddle shifter.

The automatic transmission shifts down one gear and restricts the shift range to the relevant gear.

- If the engine exceeds the maximum engine speed when shifting down, the automatic transmission protects against engine damage by not shifting down.
- If the maximum engine speed for the shift range is reached and you continue to accelerate, the automatic transmission shifts up in order to prevent the engine

Driving and parking

from overrevving, even if the shift range is restricted.

Derestricting the shift range

 Briefly press the selector lever to the right towards D+.

or

 Pull the right-hand steering wheel paddle shifter.

The shift range is derestricted.

Clearing the shift range restriction

 Press and hold the selector lever towards
 D+ until D is shown once more in the multifunction display.

or

Pull and hold the right-hand steering wheel paddle shifter until **D** is shown again in the multifunction display.

The automatic transmission shifts from the current shift range directly to $\ensuremath{\textbf{D}}.$

Selecting the ideal shift range

Press the selector lever to the left towards
 D- and hold it in position.

or

Pull the left-hand steering wheel paddle shifter and hold it in position. The automatic transmission shifts to the gear which allows optimum acceleration and deceleration. To do this, the automatic transmission shifts down one or more gears.

Manual drive program

Switching on the manual drive program

Manual drive program **M** is different from drive program **S** with regard to spontaneity, responsiveness and smoothness of gear changes. Manual drive program **M** can be selected using the program selector button. You can change gears using the steering wheel paddle shifters or the selector lever in manual drive program **M** if the transmission is in position **D**. The gear selected is shown in the multifunction display.

▶ Press the program selector button (▷ page 142) repeatedly until M appears in the multifunction display.

Upshifting

► Briefly press the selector lever to the right towards **D+**.

or

 Pull the right-hand steering wheel paddle shifter (> page 142).
 The automatic transmission shifts up to the next gear.

Vehicles with AMG engines

In manual drive program **M**, the automatic transmission does not shift up automatically even when the engine limiting speed for the current gear is reached. When the engine limiting speed is reached, the fuel supply is cut to prevent the engine from overrevving. Always make sure that the engine speed does not reach the red area of the tachometer. There is otherwise a risk of engine damage.

Before the engine speed reaches the red area, an upshift indicator will be shown in the AMG menu of the multifunction display.



- ① Gear indicator
- Upshift indicator
- Shift up a gear if the color in the multifunction display in the speedometer changes to red and the UP display message is shown.

Downshifting

- Briefly press the selector lever to the left towards D-.
- or
- Pull the left-hand steering wheel paddle shifter (▷ page 142).
 The automatic transmission shifts down to the next gear.
- If you brake the vehicle or stop without shifting down, the automatic transmission will shift down to a gear that will allow the vehicle to accelerate or pull away again.
- For maximum acceleration, push the selector lever to the left or pull and hold the left-hand steering wheel paddle shifter until the transmission shifts to the optimal gear for the current speed.

Kickdown

Vehicles with an AMG engine: it is not possible to use kickdown in manual drive program **M**.

You can also use kickdown for maximum acceleration in manual drive program **M**.

- Vehicles for USA: fully depress the accelerator pedal. The transmission shifts to a lower gear depending on the engine speed.
- Vehicles for Canada: depress the accelerator pedal beyond the pressure point.

The transmission shifts to a lower gear depending on the engine speed.

Switching off the manual drive program

Press the program selector button (> page 142) repeatedly until E (C in AMG vehicles) or S appears in the multifunction display. Driving and parking

Problems with the transmission

Problem	Possible causes/consequences and ► Solutions
The transmission has problems shifting gear.	 The transmission is losing oil. Have the transmission checked at a qualified specialist workshop immediately.
The acceleration ability is deteriorating. The transmission no longer changes gear.	 The transmission is in emergency mode. It is only possible to shift into second gear and reverse gear. Stop the vehicle. Shift the transmission to position P. Switch off the engine. Wait at least 10seconds before restarting the engine. Shift the transmission to position D or R. If D is selected, the transmission shifts into second gear; if R is selected, the transmission shifts into reverse gear. Have the transmission checked at a qualified specialist

Releasing the parking lock manually

In the event of an electrical malfunction, it is possible to release the selector lever lock manually to move it out of position **P**, e.g. if you wish to tow the vehicle away.



Do not use any sharp-edged objects to remove the selector lever gaiter from the center console. This could damage the selector lever gaiter.

- ► Apply the electric parking brake.
- Press the frame of selector level gaiter 1 together somewhat on the side edge at the back and hold with one hand (2).
- With the other hand, pry off the frame of selector level gaiter ① with a flat, blunt object (e.g. a screwdriver wrapped in cloth) at rear edge ③, pulling it up and out at the same time.
- Press release buttons ④ down and simultaneously move the selector lever out of position P.

The selector lever can now be moved freely until it is returned to position **P**.

Refueling

Important safety notes

Gasoline is highly flammable and poisonous. It burns violently and can cause serious personal injury.

Refueling | 147

Never allow sparks, flames or smoking materials near gasoline.

Turn off the engine before refueling.

Whenever you are around gasoline, avoid inhaling fumes and any skin or clothing contact.

Direct skin contact with fuels and the inhalation of fuel vapors are damaging to your health.

MARNING

Overfilling of the fuel tank may create pressure in the system which could cause a gas discharge. This could cause the gasoline to spray back out when removing the fuel pump nozzle, which could cause personal injury.

Do not use diesel to refuel vehicles with a gasoline engine. Even small amounts of the wrong fuel result in damage to the fuel system and engine.

Do not switch on the ignition if you accidentally refuel with the wrong fuel. Otherwise, the fuel will enter the fuel lines. Notify a qualified specialist workshop and have the fuel tank and fuel lines drained completely.

• Overfilling the fuel tank could damage the fuel system.


Take care not to spill any fuel on painted surfaces. You could otherwise damage the paintwork.

Use a filter when refueling from a fuel can. Otherwise, the fuel lines and/or injection system could be blocked by particles from the fuel can.

Further information on fuel and on fuel grades can be found in the "Fuel" section (▷ page 325).

Refueling

Fuel filler flap



Driving and parking

- ① Fuel filler flap
- To insert the fuel filler cap
- ③ Tire pressure table
- ④ Fuel type

The fuel filler flap is unlocked or locked automatically when you open or close the vehicle with the SmartKey or with KEYLESS-GO.

The position of the fuel filler cap right is displayed in the instrument cluster. The arrow next to the filling pump indicates the side of the vehicle.

Opening

- ▶ Switch off the engine.
- Remove the SmartKey from the ignition lock.
- KEYLESS-GO: open the driver's door. This corresponds to SmartKey position 0: "SmartKey removed".

The driver's door can be closed again.

- Press the fuel filler flap in marked area (1).
 Fuel filler flap (1) swings up.
- Turn the fuel filler flap counter-clockwise and remove it.
- Insert the fuel filler cap into the holder bracket on the inside of filler flap (2).

148 Refueling

- ► Completely insert the filler neck of the fuel pump nozzle into the tank and refuel.
- ► Only fill the tank until the pump nozzle switches off.

1 Do not add any more fuel after the pump stops filling for the first time. Otherwise, fuel may leak out.

Closing

- Replace the cap on the filler neck and turn clockwise until it engages audibly.
- ► Close fuel filler flap ①.

If you drive with the fuel filler cap open, reserve fuel warning lamp provide flashes. In addition, the check Engine warning lamp may light up. A message appears in the multifunction display (▷ page 219). For further information on warning and indicator lamps in the instrument cluster, see (▷ page 234).

Problems with fuel and the fuel tank

Problem	Possible causes/consequences and Solutions
Fuel is leaking from the vehicle.	 ▲ Risk of explosion or fire The fuel line or the fuel tank is defective. ▶ Turn the SmartKey to position 0 in the ignition lock immediately and remove it (▷ page 131). ▶ Do not restart the engine under any circumstances. ▶ Consult a qualified specialist workshop.
The fuel filler flap cannot be opened.	 The fuel filler flap cannot be unlocked using the button on the SmartKey. or The SmartKey battery is discharged. ► Unlock the vehicle using the mechanical key (▷ page 70). The fuel filler flap is unlocked, but the opening mechanism is jammed. ► Consult a qualified specialist workshop.

Driving and parking

Parking

Important safety notes

▲ WARNING

Do not park this vehicle in areas where combustible materials such as grass, hay or leaves can come into contact with the hot exhaust system. Do not park the vehicle on dry grassland or harvested grain fields. These materials could be ignited by the hot exhaust system and cause a vehicle fire.

Vehicle movement can cause serious personal injury or damage to the vehicle or the vehicle drivetrain. Therefore, always do the following before turning off the engine and leaving the vehicle:

- keep your right foot on the brake pedal.
- engage the parking brake.
- shift the manual transmission to **first** gear or reverse gear **R**.
- shift the automatic transmission to park position **P**.

- slowly release the brake pedal.
- when parked on an incline, always turn the front wheels towards the road curb.
- turn the SmartKey in the ignition lock to position **0** and remove the SmartKey from the ignition lock.
- take the SmartKey with you and lock the vehicle when leaving.

Manual transmission: Wait until the vehicle is stationary before removing the SmartKey from the starter switch. The vehicle cannot be steered when the SmartKey is removed from the starter switch.

Switching off the engine

Important safety notes

MARNING №

Do not turn off the engine before the vehicle has come to a complete stop. With the engine not running, there is no power assistance for the brake and steering systems. In this case, it is important to keep in mind that a considerably higher degree of effort is necessary to brake and steer the vehicle.

Vehicles with manual transmission

- ▶ Shift to either first gear or reverse gear **R**.
- Turn the SmartKey to position 0 in the ignition lock and remove it. The immobilizer is activated.
- ► Apply the electric parking brake.

Vehicles with automatic transmission

- ► Apply the electric parking brake.
- ▶ Shift the transmission to position **P**.

Using the SmartKey

- Turn the SmartKey to position 0 in the ignition lock and remove it. The immobilizer is activated.
- **1** The SmartKey can only be removed if the transmission is in position **P**.

Using KEYLESS-GO

- ▶ Press the Start/Stop button (▷ page 131). The engine stops and all the indicator lamps in the instrument cluster go out.
- When the driver's door is closed, this corresponds to SmartKey position 1. When the driver's door is open, it corresponds to SmartKey position 0 or "SmartKey removed".

If you attempt to switch off the engine while the selector lever is in a position other than **P**, a message appears in the multifunction display and you hear a tone.

Electric parking brake

General information

The electric parking brake performs a function test at regular intervals while the engine is switched off. The sounds that can be heard while this is occurring are normal.

▲ WARNING

When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Children could release the parking brake and/or shift the automatic transmission out of park position **P**, either of which could result in an accident and/or serious personal injury.



Applying/releasing manually

- ► To apply: press handle ①. The red PARK (USA only) or (⑦) (Canada only) indicator lamp in the instrument cluster lights up.
- The electric parking brake can also be applied when the SmartKey is removed.
- **To release:** switch on the ignition.
- Pull handle (1). The red PARK (USA only) or (9) (Canada only) indicator lamp in the instrument cluster goes out.
- The electric parking brake cannot be released unless the SmartKey is in position
 1 in the ignition lock or if the ignition has

been switched on using the Start/Stop button.

Applying automatically

Your vehicle's electric parking brake is applied automatically if DISTRONIC PLUS (vehicles with automatic transmission only) or the HOLD function stops your vehicle or is keeping your vehicle stationary. In addition, at least one of the following conditions must be fulfilled:

- the engine is switched off.
- the driver's door is open and the seat belt is not fastened.
- the vehicle is stationary for a lengthy period.

The red **PARK** (USA only) or (Canada only) indicator lamp in the instrument cluster lights up.

Releasing automatically

1 The electric parking brake can only be released automatically on vehicles with automatic transmission.

Your vehicle's electric parking brake is automatically released if all of the following conditions are met:

- the engine is running.
- the transmission is in position **D** or **R**.
- the seat belt has been fastened.
- you depress the accelerator pedal.

If the transmission is in position ${\bf R},$ the trunk lid must be closed.

If your seat belt is not fastened, the following conditions must be fulfilled to automatically release the electric parking brake:

- the driver's door is closed.
- you have shifted out of position P or you have previously driven faster than 2 mph (3km/h).

Emergency braking

The vehicle can also be braked during an emergency by using the electric parking brake.

- While driving, push handle ① of the electric parking brake (▷ page 150).
- The vehicle is braked as long as you keep the handle of the electric parking brake pressed. The longer the electric parking brake handle is depressed, the greater the braking force.

During braking:

- a warning tone sounds.
- the Please Release Parking Brake message appears.
- the red **PARK** (USA only) or **(P)** (Canada only) indicator lamp in the instrument cluster flashes.

When the vehicle has been braked to a standstill, the electric parking brake is engaged.

Parking the vehicle for a long period

If you leave the vehicle parked for longer than four weeks, the battery may be damaged by exhaustive discharge.

- Connect a trickle charger.
- You can obtain information about trickle chargers from a qualified specialist workshop.

If you leave the vehicle parked for longer than six weeks, the vehicle may suffer damage as a result of lack of use.

 Visit a qualified specialist workshop and seek advice.

Driving tips

General driving tips

Important safety notes

MARNING

Always remember that you must concentrate primarily on driving the vehicle. The driver's concentration must always be directed primarily at road traffic. For your own safety and that of others, we recommend that you stop the vehicle at a safe place and in accordance with the traffic conditions before making or accepting a phone call.

Comply with all legal requirements if you use the telephone while driving. Use the handsfree system and only use the telephone when road, weather and traffic conditions permit. In some jurisdictions, it is forbidden for drivers to use mobile phones while driving.

Only operate the audio system or COMAND (Cockpit Management and Data System) in compliance with all legal requirements and when the road, weather and traffic conditions permit. You may otherwise not be able to observe the traffic conditions, endangering yourself and others.

Remember that your vehicle covers a distance of 44 ft (approximately 14 m) a second when it is traveling at only 30 mph (approximately 50 km/h).

Drive sensibly - save fuel

Observe the following tips to save fuel:

- The tires should always be inflated to the recommended tire pressure.
- ▶ Remove unnecessary loads.
- ▶ Warm up the engine at low engine speeds.
- Avoid frequent acceleration or braking.
- Have all maintenance work carried out as indicated by the service intervals in the Maintenance Booklet or by the service interval display.

Fuel consumption also increases when driving in cold weather, in stop-and-go traffic and in mountainous terrain.

Drinking and driving

Drinking and driving and/or taking drugs and driving are very dangerous combinations. Even a small amount of alcohol or drugs can affect your reflexes, perceptions and judgment.

The possibility of a serious or even fatal accident are greatly increased when you drink or take drugs and drive.

Do not drink or take drugs and drive or allow anyone to drive who has been drinking or taking drugs.

Pedals

MARNING

Make sure absolutely no objects are obstructing the pedals' range of movement. Keep the driver's footwell clear of all obstacles. If there are any floormats or carpets in the footwell, make sure that the pedals still have sufficient clearance. During sudden driving or braking maneuvers, the objects could get caught between the pedals. You could then no longer brake or accelerate. This could lead to accidents and injury.

Rolling with the engine switched off

MARNING

There is no power assistance for the steering and the brake when the engine is not running.

Steering and braking requires significantly more effort and you could lose control of the vehicle and cause an accident as a result. Do not turn off the engine while the vehicle is in motion.

Driving tips | 153

Exhaust check

▲ WARNING

Inhalation of exhaust gas is hazardous to your health. All exhaust gas contains carbon monoxide (CO), and inhaling it can cause unconsciousness and possible death.

Do not run the engine in confined areas (such as a garage) which are not properly ventilated. If you think that exhaust gas fumes are entering the vehicle while driving, have the cause determined and corrected immediately. If you must drive under these conditions, drive only with at least one window fully open at all times.

Certain engine systems are designed to keep the level of poisonous components in exhaust fumes within legal limits.

These systems only work at peak efficiency if they are serviced exactly in accordance with the manufacturer's specifications. For this reason, all work on the engine should only be carried out by qualified and authorized Mercedes-Benz technicians.

The engine settings must not be changed under any circumstances. Furthermore, all specific service work must be carried out at regular intervals and in accordance with the Mercedes-Benz service requirements. Details can be found in the Maintenance Booklet.

Brakes

Important safety notes

M MARNING

On slippery road surfaces, never downshift in order to obtain braking action. This could result in drive wheel slip and reduced vehicle control. Your vehicle's ABS will not prevent this type of loss of control.

MARNING

Make sure that you do not endanger other road users when you apply the brakes.

Downhill gradients

• On long and steep gradients, you must reduce the load on the brakes by shifting early to a lower gear. This allows you to take advantage of the engine braking effect and helps avoid overheating and excessive wear of the brakes.

When you take advantage of the engine braking effect, a drive wheel may not turn for some time, e.g. on a slippery road surface. This could cause damage to the drive train. This type of damage is not covered by the Mercedes-Benz warranty.

Heavy and light loads

MARNING

Depressing the brake pedal constantly results in excessive and premature wear to the brake pads.

It may also cause the brakes to overheat, seriously impairing their effectiveness. It may then not be possible to stop the vehicle in sufficient time to avoid an accident.

If the brakes have been subjected to a heavy load, do not stop the vehicle immediately, but drive on for a short while. This allows the airflow to cool the brakes more quickly.

Wet roads

MARNING

After driving in heavy rain for some time without applying the brakes or through water deep enough to wet brake components, the first braking action may be somewhat reduced. You have to depress the brake pedal more firmly. Maintain a safe distance from vehicles in front.

After driving on a wet road or having the vehicle washed, brake firmly while paying attention to the traffic conditions. This will warm up the brake discs, thereby drying them more quickly and protecting them against corrosion.

154 Driving tips

Limited braking performance on salttreated roads

MARNING

The layer of salt on the brake discs and the brake pads/linings may cause a delay in the braking effect, resulting in a significantly longer braking distance, which could lead to an accident.

To avoid this danger, you should:

- occasionally brake carefully, without putting other road users at risk, when you are driving on salted roads. This helps to remove any salt that may have started to build up on the brake discs and the brake pads/linings.
- maintain a greater distance to the vehicle ahead and drive with particular care.
- carefully apply the brakes at the end of a trip and immediately after commencing a new trip, so that salt residues are removed from the brake discs.

Servicing the brakes

If the red brake warning lamp lights up in the instrument cluster and you hear a warning tone while the engine is running, the brake fluid level may be too low. Observe additional warning messages in the multifunction display.

The brake fluid level may be too low due to brake pad wear or leaking brake lines. Have the brake system checked immediately. This work should be carried out at a qualified specialist workshop.

All checks and maintenance work on the brake system must be carried out at a qualified specialist workshop. Consult a qualified specialist workshop to arrange this. Have brake pads installed and brake fluid replaced at a qualified specialist workshop.

MARNING

If brake pads or brake fluid other than those recommended are used, the braking

properties of the vehicle can be degraded to an extent that safe braking is substantially impaired. This could result in an accident.

As the ESP[®] system operates automatically, the engine and the ignition must be switched off (SmartKey in position **0** or **1** in the ignition lock) if the electric parking brake is being tested on a brake dynamometer (maximum 10 seconds).

Braking triggered automatically by ESP[®] may seriously damage the brake system.

If the brake system has only been subject to moderate loads, you should test the functionality of your brakes at regular intervals. To do so, press firmly on the brake pedal when driving at a high speed. This improves the grip of the brake pads.

MARNING

Make sure that you do not endanger other road users when you apply the brakes.

You can find a description of Brake Assist (BAS) on (\triangleright page 57).

High-performance brake system for AMG vehicles

The high-performance brake system is installed only on the SLK 55 AMG.

New vehicle brake pads and discs, and replacement brake pads and discs may take several hundred miles of driving until they provide optimum braking efficiency. Until that time, you may need to use increased brake pedal pressure while braking. Please be aware of this and adjust your driving and braking accordingly during this break-in period.

Excessive high-demand braking will cause correspondingly high brake wear. Please be attentive to the brake warning lamp in the instrument cluster and brake condition messages in the multifunction display. Especially for high performance driving, it is important to maintain and have the brake system checked regularly.

The high-performance brake system is designed for heavy loads. This may lead to noise when braking. This will depend on:

- speed
- braking force
- environmental conditions, such as temperature and humidity

The wear of individual components of the brake system, such as the brake pads/linings or brake discs, depends on the individual driving style and operating conditions.

For this reason, it is impossible to state a mileage that will be valid under all circumstances. An aggressive driving style will lead to high wear. You can obtain further information about this from your authorized Mercedes-Benz Center.

Driving on wet roads

Hydroplaning

If water has accumulated to a certain depth on the road surface, there is a danger of hydroplaning occurring, even if:

- you drive at low speeds.
- the tires have adequate tread depth.

For this reason, in the event of heavy rain or in conditions in which hydroplaning can occur, you must drive in the following manner:

- lower your speed.
- avoid ruts.
- brake carefully.

Driving on flooded roads

Do not drive through flooded areas. Check the depth of any water before driving through it. Drive slowly through standing water. Otherwise, water may enter the vehicle interior or the engine compartment. This can damage the electronic components in the engine or the automatic transmission. Water can also be drawn in by the engine's air suction nozzles and this can cause engine damage.

Winter driving

Important safety notes

If the vehicle becomes trapped in snow, ensure that snow is kept away from the exhaust pipe and from around the vehicle as long as the engine is running. Otherwise, poisonous carbon monoxide (CO) may enter the vehicle, resulting in loss of consciousness and even death.

To assure sufficient fresh air ventilation, open a window slightly on the side of the vehicle not facing the wind.

Have your vehicle winterproofed at a qualified specialist workshop at the onset of winter. Observe the notes in the "Winter operation" section (\triangleright page 296).

Driving with summer tires

Observe the notes in the "Winter operation" section (\triangleright page 296).

Slippery road surfaces

MARNING №

The outside temperature indicator is not designed to serve as an ice-warning device and is therefore unsuitable for that purpose.

Indicated temperatures just above the freezing point do not guarantee that the road surface is free of ice. The road may still be icy, especially in wooded areas or on bridges.

On slippery road surfaces, never downshift in order to obtain braking action. This could result in drive wheel slip and reduced vehicle

156 Driving systems

Driving and parking

control. Your vehicle's ABS will not prevent this type of loss of control.

Drive particularly carefully on slippery road surfaces. Avoid sudden acceleration, steering and braking maneuvers. Do not use cruise control.

If the vehicle threatens to skid or cannot be stopped when moving at low speed:

- Vehicles with manual transmission: shift to neutral.
- ► Vehicles with automatic transmission: shift the transmission to position N.

● For more information on driving with snow chains, see (▷ page 297).

MARNING

Make sure that you do not endanger other road users when you apply the brakes.

Driving systems

Cruise control

Important safety notes

Cruise control maintains a constant road speed for you. It brakes automatically in order to avoid exceeding the set speed. You must select a low gear in good time on long and steep downhill gradients, especially if the vehicle is laden. Select shift range **1**, **2** or **3** on vehicles with automatic transmission in order to use the engine's braking effect, which relieves the load on the brake system and prevents the brakes from overheating and wearing too quickly.

Use cruise control only if road and traffic conditions make it appropriate to maintain a steady speed for a prolonged period. You can store any road speed above 20 mph (30 km/h).

MARNING

The cruise control is a convenience system designed to assist the driver during vehicle

operation. The driver is and must always remain responsible for the vehicle's speed and for safe brake operation.

Only use the cruise control if the road, traffic, and weather conditions make it advisable to travel at a constant speed.

- The use of the cruise control can be dangerous on winding roads or in heavy traffic because conditions do not allow safe driving at a constant speed.
- The use of the cruise control can be dangerous on slippery roads. Rapid changes in tire traction can result in wheel spin and loss of control.
- Deactivate the cruise control when driving in fog.

The "Resume" function should only be operated if the driver is fully aware of the previously set speed and wishes to resume this particular preset speed.

Cruise control lever



- 1) To activate or increase speed
- To activate or reduce speed
- ③ To deactivate cruise control
- ④ To activate at the current speed/last stored speed

When you activate cruise control, the stored speed is shown in the multifunction display for five seconds. After that, it is permanently shown in the status indicator:

- USA only: e.g., CRUISE 55Miles
- Canada only: e.g. 🚯 90 Km/h

Storing and maintaining the current speed

You can store the current speed if you are driving faster than 20 mph (30 km/h).

- Accelerate the vehicle to the desired speed.
- ► Briefly press the cruise control lever up ① or down ②.
- Remove your foot from the accelerator pedal.

Cruise control is activated. The vehicle automatically maintains the stored speed.

Cruise control may be unable to maintain the stored speed on uphill gradients. The stored speed is resumed when the gradient evens out. Cruise control maintains the stored speed on downhill gradients by automatically applying the brakes.

(1) Vehicles with manual transmission:

- Always drive at adequate, but not excessive, engine speeds.
- Change gear in good time.
- If possible, do not shift down several gears at a time.

Storing the current speed or calling up the last stored speed

MARNING №

The set speed stored in memory should only be set again if prevailing road conditions and legal speed limits permit. Possible acceleration or deceleration differences arising from returning to the preset speed could cause an accident and/or serious injury to you and others.

- ▶ Briefly pull the cruise control lever towards you ④.
- Remove your foot from the accelerator pedal.

The first time cruise control is activated, it stores the current speed or regulates the

speed of the vehicle to the previously stored speed.

Setting a speed

Keep in mind that it may take a brief moment until the vehicle has made the necessary adjustments.

Increase or decrease the set vehicle speed to a value that the prevailing road conditions and legal speed limits permit. Otherwise, sudden and unexpected acceleration or deceleration of the vehicle could cause an accident and/ or serious injury to you and others.

- Driving and parking
- ▶ Press the cruise control lever up ① for a higher speed or down ② for a lower speed.
- To adjust the speed in 1 mph increments (1 km/h increments): briefly press the cruise control lever up ① or down ② to the pressure point. The last speed stored is increased or decreased every time the cruise control lever is pushed up ① or down ②.
- To adjust the speed in 5 mph increments (10 km/h increments): briefly press the cruise control lever up ① or down ② beyond the pressure point.

The last speed stored is increased or decreased every time the cruise control lever is pushed up ① or down ②.

Cruise control is not deactivated if you depress the accelerator pedal. For example, if you accelerate briefly to overtake, cruise control adjusts the vehicle's speed to the last speed stored after you have finished overtaking.

Deactivating cruise control

There are several ways to deactivate cruise control:

- Briefly press the cruise control lever forwards (3).
- or
- Brake.

Cruise control is automatically deactivated if:

- you engage the electric parking brake.
- you are driving at less than 20 mph (30 km/h)
- ESP[®] intervenes or you deactivate ESP[®].
- you shift into neutral in a vehicle with manual transmission while driving or depress the clutch pedal for longer than six seconds.
- on vehicles with manual transmission, you shift to a gear that is too high, and as a result the engine speed is too low.
- on vehicles with automatic transmission, you shift into position **N** while driving.

If cruise control is deactivated, you will hear a warning tone. You will see the Cruise Control Off message in the multifunction display for approximately five seconds.

When you switch off the engine, the last speed stored is cleared.

DISTRONIC PLUS

Important safety notes

DISTRONIC PLUS is not available on AMG vehicles.

DISTRONIC PLUS regulates the speed and automatically helps you maintain the distance to the vehicle detected in front. DISTRONIC PLUS brakes automatically so that the set speed is not exceeded.

On long and steep downhill gradients, especially if the vehicle is laden, you must select shift range **1**, **2** or **3** in good time. By doing so, you will make use of the braking effect of the engine, which relieves the load on the brake system and prevents the brakes from overheating and wearing too quickly.

If DISTRONIC PLUS detects a slower-moving vehicle in front, your vehicle is braked in order to maintain the preset distance to the vehicle in front.

MARNING

The DISTRONIC PLUS requires familiarity with its operational characteristics. We strongly recommend that you review the following information carefully before operating the system.

▲ WARNING

The DISTRONIC PLUS is a convenience system. Its speed adjustment reduction capability is intended to make cruise control more effective and usable when traffic speeds vary. It is not however, intended to, nor does it, replace the need for extreme care.

The responsibility for the vehicle's speed, distance to the preceding vehicle and, most importantly, brake operation to ensure a safe stopping distance, always remains with the driver.

The DISTRONIC PLUS cannot take street and traffic conditions into account.

Complex driving situations are not always fully recognized by the DISTRONIC PLUS. This could result in wrong or missing distance warnings.

If you want DISTRONIC PLUS to assist you, the radar sensor system must be activated (> page 194) and operational.

If there is no vehicle in front, DISTRONIC PLUS operates in the same way as cruise control in the speed range between 20 mph (Canada: 30 km/h) and 120 mph (Canada: 200 km/h). If a vehicle is driving in front of you, it operates in the speed range between 0 mph (0 km/h) and 120 mph (Canada: 200 km/h).

Do not use DISTRONIC PLUS while driving on roads with steep gradients.

As DISTRONIC PLUS transmits radar waves, it can resemble the radar detectors of the responsible authorities. You can refer to the relevant chapter in the Operator's Manual if questions are asked about this.

USA only:

This device has been approved by the FCC as a "Vehicular Radar System". The radar sensor is intended for use in an automotive radar system only. Removal, tampering, or altering of the device will void any warranties, and is not permitted by the FCC. Do not tamper with, alter, or use in any non-approved way.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

Canada only: This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

1. This device may not cause interference, and

2. this device must accept any interference received, including interference that may cause undesired operation of the device.

Removal, tampering, or altering of the device will void any warranties and is not permitted. Do not tamper with, alter, or use the device in any non-approved way.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

DISTRONIC PLUS distance is not a substitute for the active intervention of the driver. It does not detect pedestrians or stationary objects, nor can it detect, recognize or predict the road's course or the movements of vehicles in front. DISTRONIC PLUS can only brake the vehicle using 40% of the vehicle's maximum available brake force.

DISTRONIC PLUS may not detect narrow vehicles driving in front, e.g. motorcycles, or vehicles driving in the lane beyond the lane next to your vehicle, especially if the vehicles are not driving on the middle of their lane.

The driver must always pay careful attention to the road, weather and traffic conditions. The driver must drive, steer and brake in a manner which will allow him to always have control of the vehicle.

Sources of high-frequency radio waves, such as toll stations, speed-measuring radar, etc., can cause DISTRONIC PLUS to fail temporarily.

The DISTRONIC PLUS cannot take road and traffic conditions into account. Only use the DISTRONIC PLUS if the road, weather and traffic conditions make it advisable to travel at a constant speed.

Use of the DISTRONIC PLUS can be dangerous on slippery roads. Rapid changes in tire traction can result in wheel spin and loss of control.

The DISTRONIC PLUS does not function in adverse sight and distance conditions. Do not use the DISTRONIC PLUS during conditions of fog, heavy rain, snow or sleet.

The DISTRONIC PLUS cannot take weather conditions into account. Switch off the DISTRONIC PLUS or do not switch it on if:

- roads are slippery or covered with snow or ice. The wheels could lose traction while braking or accelerating, and the vehicle could skid.
- the DISTRONIC PLUS system sensor covers are dirty or visibility is diminished due to snow, rain or fog, for example. The distance control system functionality could be impaired.

Always pay attention to surrounding traffic conditions even while the DISTRONIC PLUS is switched on. Otherwise, you may not be able to recognize dangerous situations until it is

160 Driving systems

too late. This could cause an accident in which you and/or others could be injured.

MARNING

The "Resume" function should only be operated if the driver is fully aware of the previously set speed and wishes to resume this particular preset speed.

▲ WARNING

Your undivided attention to street and traffic conditions is necessary at all times whether DISTRONIC PLUS is active or not.

The use of DISTRONIC PLUS can be dangerous on winding roads or in heavy traffic because conditions do not allow safe driving at a constant speed.

DISTRONIC PLUS does not react to stationary objects on the road (for example, a vehicle stopped in traffic or an abandoned vehicle). DISTRONIC PLUS likewise does not react to oncoming vehicles.

Deactivate DISTRONIC PLUS:

- when changing to the right lane, if the vehicles in the left lane are driving slower
- when driving into a filter lane or an expressway exit
- in complex driving situations, for example in construction sites on an expressway

In these situations DISTRONIC PLUS will maintain the set speed if it is not deactivated. DISTRONIC PLUS is intended only for maintaining a set speed and a set distance from the objects moving in front of the vehicle.

An intermittent warning sounds and the distance warning lamp A in the instrument cluster is illuminated if the DISTRONIC PLUS system calculates that the distance to the vehicle ahead and your vehicle's current speed indicate that the DISTRONIC PLUS will not be capable of slowing the vehicle sufficiently to maintain the preset following

distance, which creates a danger of a collision.

Immediately brake the vehicle to increase your distance to the preceding vehicle. The warning sound is intended as a final caution in which you should intercede with your own braking inputs to avoid a potentially dangerous situation. Do not wait for the operation of the warning signal to intercede with your own braking. This will result in potentially dangerous emergency braking which will not always result in an impact being avoided.

Tailgating increases the risk of an accident.

MARNING

DISTRONIC PLUS brakes your vehicle with a maximum deceleration of 13 ft/s^2 (4 m/s²). This corresponds to approximately 40% of your vehicle's maximum braking force.

To avoid a collision, you must apply the brakes yourself. DISTRONIC PLUS brakes the vehicle just enough to restore the preset speed or the preset distance to the vehicle in front.

If you do not receive visual or acoustic warning signals during a critical traffic situation, DISTRONIC PLUS has either not recognized the collision risk, has been deactivated or is malfunctioning.

Remember, whether or not DISTRONIC PLUS is operating, it is ultimately always the drivers responsibility to apply the brakes in order to control the vehicle and avoid a collision.

Driving and parking

Cruise control lever



- ① To store the current speed or a higher speed
- ② To store the current speed or a lower speed
- ③ To deactivate DISTRONIC PLUS
- Storing the current speed or calling up the last stored speed
- (5) Setting the specified minimum distance

Switching on DISTRONIC PLUS, storing and maintaining the current speed

Important safety notes

▲ WARNING

The vehicle can be braked when DISTRONIC PLUS is activated. For this reason, deactivate DISTRONIC PLUS if the vehicle is to be set in motion by other means (e.g. in a car wash or by towing).

In order to activate DISTRONIC PLUS, the following conditions must be fulfilled:

- the engine must be started. It may take up to two minutes after pulling away before DISTRONIC PLUS is operational.
- the electric parking brake must be released.
- ESP[®] must be active, but not intervening.
- the transmission must be in position **D**.
- the hood must be closed.
- the driver's door must be closed when you shift from **P** to **D** or your seat belt must be fastened.

- the front-passenger door must be closed.
- the vehicle must not skid.

Activating while driving

When driving at speeds below 20 mph (30 km/h), you can only activate DISTRONIC PLUS if the vehicle in front has been detected and is shown in the multifunction display. If the vehicle in front is no longer detected and displayed, DISTRONIC PLUS switches off and a tone sounds.

- Briefly pull the cruise control lever towards you ④, or press it up ① or down ②.
 DISTRONIC PLUS is selected.
- Press the cruise control lever repeatedly up (1) or down (2) until the desired speed is set.
- Remove your foot from the accelerator pedal.

Your vehicle adapts its speed to that of the vehicle in front, but only up to the desired stored speed.

If you do not fully release the accelerator pedal, the DISTRONIC PLUS Passive message appears in the multifunction display. The set distance to a slowermoving vehicle in front will then not be maintained. You will be driving at the speed you determine by the position of the accelerator pedal.

Activating when driving towards a stationary vehicle

If the vehicle in front of you is stationary, you can only activate DISTRONIC PLUS once your vehicle is stationary as well.

- Briefly pull the cruise control lever towards you (4), or press it up (1) or down (2).
 DISTRONIC PLUS is selected.
- DISTRONIC PLUS can only be activated at under 20 mph (30km/h) if a vehicle in front has been detected. Therefore, the DISTRONIC PLUS distance display in the instrument cluster should be activated (▷ page 190).

162 Driving systems

 Press the cruise control lever repeatedly up (1) or down (2) until the desired speed is set.

You can use the cruise control lever to set the stored speed and the control on the cruise control lever to set the specified minimum distance (▷ page 164).

Pulling away

- If the vehicle in front pulls away: remove your foot from the brake pedal.
- Briefly pull the cruise control lever towards you (4).

or

 Accelerate briefly. Your vehicle pulls away and adapts its speed to that of the vehicle in front.

Driving

If there is no vehicle in front, DISTRONIC PLUS operates in the same way as cruise control.

If DISTRONIC PLUS detects that the vehicle in front has slowed down, it brakes your vehicle. In this way, the distance you have selected is maintained.

If DISTRONIC PLUS detects that the vehicle in front is driving faster, it accelerates your vehicle, but only up to the speed you have stored.

MARNING

If you depress the brake, DISTRONIC PLUS is deactivated unless your vehicle is stationary. DISTRONIC PLUS then no longer brakes your vehicle. In such cases, control the distance from vehicles travelling in front with the brake alone. You could otherwise cause an accident and thereby injure yourself and others. The driver remains fully responsible for the vehicle's distance from other vehicles, the speed being driven and for braking in good time.

Changing lanes

If you change to the passing lane, DISTRONIC PLUS supports you when:

- you are driving faster than 40mph (60 km/h).
- DISTRONIC PLUS is maintaining the distance to a vehicle in front.
- you switch on the appropriate turn signal.
- DISTRONIC PLUS does not detect a danger of collision.

If these conditions are fulfilled, your vehicle is accelerated. Acceleration will be interrupted if changing lanes takes too long or if the distance between your vehicle and the vehicle in front becomes too small.

When changing lanes, DISTRONIC PLUS monitors the left lane on left-hand drive vehicles and the right lane on right-hand drive vehicles.

DISTRONIC PLUS is only an aid designed to assist driving.

It is not a substitute for attentive driving. The driver remains fully responsible for the vehicle's distance from other vehicles, the vehicle's speed and for braking in good time. Always pay attention to traffic conditions and your surroundings. Otherwise, you may fail to recognize dangers in time, cause an accident and injure yourself and others.

Stopping

Never get out of the vehicle when DISTRONIC PLUS is activated.

DISTRONIC PLUS must also never be operated, activated or deactivated by a passenger or from outside the vehicle.

DISTRONIC PLUS does not replace the electric parking brake and must not be used for parking.

Driving and parking

The DISTRONIC PLUS braking effect is canceled and the vehicle can start moving if:

- DISTRONIC PLUS is deactivated using the cruise control lever.
- you accelerate.
- there is a malfunction in the system or an interruption in the power supply, e.g. battery failure.
- the electrical system in the engine compartment, the battery or the fuses are tampered with.
- the battery is disconnected.

If you wish to leave the vehicle or park it, deactivate DISTRONIC PLUS and secure the vehicle against rolling away.

If DISTRONIC PLUS detects that the vehicle in front is stopping, it brakes your vehicle until it is stationary.

Once your vehicle is stationary, it remains stationary and you do not need to depress the brake.

- After a time, the electric parking brake secures the vehicle and relieves the service brake.
- Depending on the specified minimum distance, your vehicle will come to a standstill at a sufficient distance behind the vehicle in front. The specified minimum distance is set using the control on the cruise control lever.

The electric parking brake automatically secures the vehicle if DISTRONIC PLUS is activated and:

- the driver's door is open and the driver's seat belt is unfastened.
- the hood is opened.
- a system malfunction occurs.
- the power supply is not sufficient.

If there is a malfunction in the vehicle electronics, a warning message may also appear in the multifunction display.

Brake Immediately

Immediately depress the brake pedal firmly until the warning message in the multifunction display goes out. DISTRONIC PLUS is deactivated.

Shift to 'P'

Shift the transmission to position P to prevent the vehicle from rolling away. DISTRONIC PLUS is deactivated. The warning message in the multifunction display disappears.

The horn will also sound at regular intervals if DISTRONIC PLUS is activated and you:

- switch the engine off, open the driver's door and remove your seat belt
- open the hood

The sounding of the horn alerts you to the fact that the vehicle has been parked while DISTRONIC PLUS is still activated. The sound becomes louder if you attempt to lock the vehicle. The vehicle is not locked until DISTRONIC PLUS is deactivated.

If the engine has been switched off, it cannot be started again until DISTRONIC PLUS has been deactivated.

Setting a speed

Keep in mind that it may take a brief moment until the vehicle has made the necessary adjustments.

Increase or decrease the set vehicle speed to a value that the prevailing road conditions and legal speed limits permit. Otherwise, sudden and unexpected acceleration or deceleration of the vehicle could cause an accident and/ or serious injury to you and others.

- Press the cruise control lever up 1 for a higher speed or down 2 for a lower speed.
- To adjust the speed in 1 mph increments (1 km/h increments): briefly

164 Driving systems

Driving and parking

press the cruise control lever up (1) or down (2) to the pressure point. The last speed stored is increased or decreased every time the cruise control lever is pushed up (1) or down (2).

To adjust the speed in 5 mph increments (10 km/h increments): briefly press the cruise control lever up ① or down ② beyond the pressure point.

The last speed stored is increased or decreased every time the cruise control lever is pushed up ① or down ②.

DISTRONIC PLUS is not deactivated if you depress the accelerator pedal. If you accelerate to overtake, DISTRONIC PLUS adjusts the vehicle's speed to the last speed stored after you have finished overtaking.

Storing the current speed or calling up a stored speed

₼ WARNING

The set speed stored in memory should only be set again if prevailing road conditions and legal speed limits permit. Possible acceleration or deceleration differences arising from returning to the preset speed could cause an accident and/or serious injury to you and others.

- Briefly pull the cruise control lever towards you (4).
- Remove your foot from the accelerator pedal.


DISTRONIC PLUS is activated. The first time it is activated, the current speed is stored. Otherwise, it sets the vehicle cruise speed to the previously stored value.

Setting the specified minimum distance

You can set the specified minimum distance for DISTRONIC PLUS by varying the time span between one and two seconds. With this function, you can set the minimum distance that DISTRONIC PLUS keeps to the vehicle in front, dependent on vehicle speed. You can see this distance in the multifunction display (> page 165).

▲ WARNING

It is up to the driver to exercise discretion to select the appropriate setting given road conditions, traffic, driver's preferred driving style and applicable laws and driving recommendations for safe following distance.



► To increase: turn control ② in direction
 ③.

DISTRONIC PLUS then maintains a greater distance between your vehicle and the vehicle in front.


► To decrease: turn control ② in direction ①.

DISTRONIC PLUS then maintains a shorter distance between your vehicle and the vehicle in front.

 Make sure that you maintain a sufficiently safe distance from the vehicle in front. Adjust the distance to the vehicle in front if necessary.

Driving systems | 165

DISTRONIC PLUS displays in the speedometer



When DISTRONIC PLUS is activated, one or two segments (2) in the set speed range light up.

• For design reasons, the speed displayed in the speedometer may differ slightly from the speed set for DISTRONIC PLUS.

If DISTRONIC PLUS detects a vehicle in front, segments (2) between speed of the vehicle in front (1) and stored speed (3) light up.

DISTRONIC PLUS displays in the multifunction display


General notes

You can select the distance display in the Assistance menu (\triangleright page 190) of the onboard computer.

Display when DISTRONIC PLUS is deactivated

 Select the Distance Display function using the on-board computer (> page 190).

When DISTRONIC PLUS is deactivated, you will see the following in the multifunction display:




- ① Symbol for activated PRE-SAFE[®] Brake
- Vehicle in front, if detected
- ③ Distance indicator, current distance to the vehicle in front
- ④ Specified minimum distance to the vehicle in front; adjustable
- 5 Own vehicle

Display when DISTRONIC PLUS is activated

 Select the Distance Display function using the on-board computer (> page 190).

You will see the stored speed for about five seconds when you activate DISTRONIC PLUS. After this time, you will see the following in the multifunction display while DISTRONIC PLUS is activated:



- 1 DISTRONIC PLUS activated
- Own vehicle
- ③ Specified minimum distance to the vehicle in front; adjustable
- ④ Vehicle in front, if detected

Deactivating DISTRONIC PLUS



There are several ways to deactivate DISTRONIC PLUS:

 Briefly press the cruise control lever forwards (1).

or

Brake, unless the vehicle is stationary.

When you deactivate DISTRONIC PLUS, the DISTRONIC PLUS Off message is shown in the multifunction display for approximately five seconds.

 The last speed stored remains stored until you switch off the engine.

DISTRONIC PLUS is automatically deactivated if:

- you engage the electric parking brake or if the vehicle is automatically secured with the electric parking brake
- you are driving slower than 15 mph (25km/h) and there is no vehicle in front, or if the vehicle in front is no longer detected.
- ESP[®] intervenes or you deactivate ESP[®].
- the transmission is in the **P**, **R** or **N** position.
- you switch off the radar sensor system (▷ page 194).
- you pull the cruise control lever towards you in order to pull away and the frontpassenger door is open.
- the vehicle has skidded.

If DISTRONIC PLUS is deactivated, you will hear a warning tone. The DISTRONIC PLUS

Off message is shown in the multifunction display for approximately five seconds.

DISTRONIC PLUS is deactivated and releases the brakes if the vehicle is slowed down to a speed below 20 mph (30km/h) by the system, provided that DISTRONIC PLUS does not detect a vehicle directly in front. At this point, the driver must apply the brakes in order to slow down further and bring the vehicle to a standstill.

Tips for driving with DISTRONIC PLUS

Important safety notes

The following contains descriptions of certain road and traffic conditions in which you must be particularly attentive. In such situations, brake if necessary. DISTRONIC PLUS is then deactivated.

MARNING

The DISTRONIC PLUS works to maintain the speed selected by the driver unless a moving obstacle proceeding directly ahead of it in the same travel direction is detected (e.g. following another vehicle ahead of you at your set distance).

This means that:

- Your vehicle can pass another vehicle after you have changed lanes.
- While in a sharp turn or if the preceding vehicle is in a sharp turn, the DISTRONIC PLUS could lose sight of the preceding vehicle. Your vehicle could then accelerate to the previously selected speed.

The DISTRONIC PLUS regulates only the distance between your vehicle and those directly ahead of it. It may not register stationary objects in the road, e.g.:


- a stopped vehicle in a traffic jam
- · a disabled vehicle
- an oncoming vehicle

The driver must always be alert, observe all traffic and intercede as required by means of steering or braking the vehicle.

WARNING


The DISTRONIC PLUS should not be used in snowy or icy road conditions.

Cornering, going into and coming out of a bend




The ability of DISTRONIC PLUS to detect vehicles when cornering is limited. Your vehicle may brake unexpectedly or late.

Vehicles traveling on a different line





DISTRONIC PLUS may not detect vehicles traveling on a different line. The distance to the vehicle in front will be too short.

Other vehicles changing lane




DISTRONIC PLUS has not detected the vehicle cutting in yet. The distance to this vehicle will be too short.





DISTRONIC PLUS has not yet detected the vehicle in front on the edge of the road, because of its narrow width. The distance to the vehicle in front will be too short.

Obstructions and stationary vehicles




DISTRONIC PLUS does not brake for obstacles or stationary vehicles. If, for

example, the detected vehicle turns a corner and reveals an obstacle or stationary vehicle, DISTRONIC PLUS will not brake for these.

Crossing vehicles





DISTRONIC PLUS may mistakenly detect vehicles that are crossing your lane. Activating DISTRONIC PLUS at traffic lights with crossing traffic, for example, could cause your vehicle to pull away unintentionally.

Dynamic handling package

General notes

The adjustable damping system adapts to the current driving conditions. The adjustment depends on whether you have selected sport or comfort mode. Your selection remains stored even if you remove the SmartKey from the ignition lock.



Sports tuning

The firmer setting of the suspension tuning in sports mode ensures even better contact with the road. Select this mode if you want more direct contact with the road when employing a sporty driving style, e.g. on winding country roads.

 If indicator lamp (1) is not lit: press button (2).

Indicator lamp (1) lights up. You have selected the suspension for a sporty driving style.

Comfort tuning

Select comfort mode if you prefer a more comfortable driving style.

 If indicator lamp (1) is lit: press button (2).

Indicator lamp (1) goes out. You have selected the suspension for a comfortable driving style.

HOLD function

General notes

The HOLD function can assist the driver in the following situations:

- when pulling away, especially on steep slopes
- when maneuvering on steep slopes
- when waiting in traffic

The vehicle is kept stationary without the driver having to depress the brake pedal.

The braking effect is canceled and the HOLD function deactivated when you depress the accelerator pedal to pull away.

Activation conditions

You can activate the HOLD function if:

- the vehicle is stationary.
- the engine is running.

- the driver's door is closed or your seat belt is fastened.
- the electric parking brake is released.
- the hood is closed.
- the selector lever is in position **D**, **R** or **N** on vehicles with automatic transmission.
- DISTRONIC PLUS is deactivated.

Activating the HOLD function

- Make sure that the activation conditions are met.
- Depress the brake pedal.
- ► Quickly depress the brake pedal further until HOLD appears in the multifunction display.

The HOLD function is activated. You can release the brake pedal.

1 If depressing the brake pedal the first time does not activate the HOLD function, wait briefly and then try again.

The vehicle's brakes are applied when the HOLD function is activated. For this reason, deactivate the HOLD function if the vehicle is to be set in motion by other means (e.g. in a car wash or by towing).

Deactivating the HOLD function

The HOLD function is deactivated automatically if:

- you accelerate. On vehicles with automatic transmission: only when the transmission is in position **D** or **R**.
- you shift the transmission to position **P** on vehicles with automatic transmission.
- you depress the brake pedal again with a certain amount of pressure until HOLD disappears from the multifunction display.
- you secure the vehicle using the electric parking brake.
- you activate DISTRONIC PLUS.

• After a time, the electric parking brake secures the vehicle and relieves the service brake.

Never get out of the vehicle when the HOLD function is activated.

The HOLD function must never be operated or deactivated by a passenger or from outside the vehicle.

The HOLD function does not replace the electric parking brake and must not be used for parking.

The braking effect of the HOLD function is canceled and the vehicle could roll away if:

- the HOLD function is deactivated by depressing the accelerator pedal or the brake pedal.
- there is a malfunction in the system or an interruption in the power supply, e.g. battery failure.
- the electrical system in the engine compartment, the battery or the fuses are tampered with.
- the battery is disconnected.

If you leave the vehicle or park it, deactivate the HOLD function and secure the vehicle against rolling away.

The electric parking brake automatically secures the vehicle if the HOLD function is activated and:

- the driver's door is open and the driver's seat belt is unfastened.
- the engine is switched off.
- the hood is opened.
- a system malfunction occurs.
- the power supply is not sufficient.

If there is a malfunction in the vehicle electronics, a warning message may also appear in the multifunction display.

Brake Immediately

 Immediately depress the brake pedal firmly until the warning message in the

170 Driving systems

multifunction display goes out. This deactivates the HOLD function.

In vehicles with automatic transmission: Shift to 'P'.

Shift the transmission to position P to prevent the vehicle from rolling away. The HOLD function is deactivated. The warning message in the multifunction display disappears.

A horn will also sound at regular intervals if the HOLD function is activated and you:

- switch the engine off, open the driver's door and remove your seat belt
- open the hood

The sounding of the horn alerts you to the fact that the vehicle has been parked while the HOLD function is still activated. If you attempt to lock the vehicle, the tone becomes louder. The vehicle is not locked until the HOLD function is deactivated.

 If the engine has been switched off, it cant be started again until the HOLD function has been deactivated.

PARKTRONIC

Important safety notes

MARNING

The PARKTRONIC is a supplemental system. It is not intended to, nor does it replace, the need for extreme care. The responsibility during parking and other critical maneuvers always remains with the driver.

MARNING


Make sure no persons or animals are in or near the area in which you are parking/ maneuvering. Otherwise, they could be injured.

PARKTRONIC is an electronic parking aid with ultrasonic sensors. It indicates visually and audibly the distance between your vehicle and an object. PARKTRONIC is activated automatically when you:

- switch on the ignition
- move the selector lever to position D, R or N on vehicles with automatic transmission
- · release the electric parking brake

PARKTRONIC is deactivated at speeds above 11 mph (18km/h). It is reactivated at lower speeds.

PARKTRONIC monitors the area around your vehicle using six sensors in the front and four sensors in the rear.




 Example: sensors in the front bumper, left-hand side

Range of the sensors


General notes

The sensors must be free of dirt, ice and slush. Otherwise, they may not function correctly. Clean the sensors regularly, taking care not to scratch or damage them (> page 269).



Side view

Driving systems | 171



Top view

Front sensors

Center	approximately 40in (approximately 100cm)
Corners	approximately 24in (approximately 60cm)

Rear sensors

Center	approximately 48in (approximately 120cm)
Corners	approximately 32in (approximately 80cm)

When parking, pay particular attention to objects above or below the sensors, such as flower pots or trailer drawbars.

PARKTRONIC does not detect such objects when they are in the immediate vicinity of the vehicle. You could damage the vehicle or the objects.

The sensors may not detect snow and other objects that absorb ultrasonic waves.

Ultrasonic sources such as an automatic car wash, the compressed-air brakes on a truck or a pneumatic drill could cause PARKTRONIC to malfunction.

PARKTRONIC may not function correctly on uneven terrain.


Minimum distance

Center	approximately 8in (approximately 20cm)
Corners	approximately 6in (approximately 15cm)

If there is an obstacle within this range, the relevant warning displays light up and a warning tone sounds. If the distance falls below the minimum, the distance may no longer be shown.

Warning displays

The warning displays show the distance between the sensors and the obstacle. The warning display for the front area is located on the dashboard above the center air vents. The warning display for the rear area is located between the roll bars.



Warning display for the front area

- Segments on the left-hand side of the vehicle
- ② Segments on the right-hand side of the vehicle
- ③ Segments showing operational readiness

The warning display for each side of the vehicle is divided into five yellow and two red segments. PARKTRONIC is operational if yellow segments showing operational readiness (3) light up.

The gear lever position or the transmission position of the automatic transmission and the direction in which the vehicle is rolling

172 Driving systems

determine which warning display is active when the engine is running. Manual transmission:

Gear lever position	Warning display
Forwards gear or Neutral	Front area activated
Reverse gear, or the vehicle is rolling backwards	Rear and front areas activated

Automatic transmission:

Transmission position	Warning display
D	Front area activated
R , N or the vehicle is rolling backwards	Rear and front areas activated
Р	No areas activated

One or more segments light up as the vehicle approaches an obstacle, depending on the vehicle's distance from the obstacle. From the:

- sixth segment onwards, you will hear an intermittent warning tone for approximately two seconds.
- seventh segment onwards, you will hear a warning tone for approximately two seconds. This indicates that you have now reached the minimum distance.

Deactivating/activating PARKTRONIC



Indicator lamp

To deactivate/activate PARKTRONIC

If indicator lamp (1) lights up, PARKTRONIC is deactivated. Parking Guidance is also deactivated.

 PARKTRONIC is automatically activated when you turn the SmartKey to position 2 in the ignition lock.

Problems with PARKTRONIC

Problem	Possible causes/consequences and Solutions	
Only the red segments in the PARKTRONIC warning displays are lit. You also hear a warning tone for approximately two seconds. PARKTRONIC is deactivated after approximately 20 seconds, and the indicator lamp in the PARKTRONIC button lights up.	 PARKTRONIC has malfunctioned and has switched off. ► If problems persist, have PARKTRONIC checked at a qualified specialist workshop. 	Driving and parking
Only the red segments in the PARKTRONIC warning displays are lit. PARKTRONIC is deactivated after approximately 20 seconds.	 The PARKTRONIC sensors are dirty or there is interference. ▶ Clean the PARKTRONIC sensors (▷ page 269). ▶ Switch the ignition back on. 	
	The problem may be caused by an external source of radio or ultrasound waves.▶ See if PARKTRONIC functions in a different location.	

Parking Guidance

Important safety notes

Parking Guidance is an electronic parking aid with ultrasound. Ultrasound is used to measure the road on both sides of the vehicle. A suitable parking space is indicated by the parking symbol. You receive steering instructions when parking. You may also use PARKTRONIC (⊳ page 170).

Parking Guidance is merely an aid and may display parking spaces that are not suitable for parking, for example:

- no-parking areas
- parking spaces with unsuitable surfaces (road surface)

driveways

• entrances and exits

Parking Guidance detects and measures potential parking spaces while driving past. Changes to the parking space after this point are not taken into account, for example if the vehicle in front of or behind the parking space changes position or objects in the parking space are moved.

Even when using Parking Guidance, you are still responsible for driving carefully. If you rely on Parking Guidance alone, you could cause an accident and injure yourself and others.

Safety always remains your responsibility and you must continue paying careful attention to your immediate surroundings when parking and maneuvering.

Objects located above the height range of Parking Guidance will not be detected when the parking space is measured. These objects are not taken into account when the parking procedure is calculated, e.g. overhanging loads, tail sections or loading ramps of goods vehicles. Under some circumstances, Parking Guidance might therefore issue steering instructions too soon. This may lead to a collision. For this reason, you should avoid using Parking Guidance in such situations.

MARNING

Make sure that no persons or animals are in the maneuvering range. Otherwise, they could be injured.

Pay particular attention to low objects or objects with flat surfaces, such as trailer drawbars, posts, cross beams and curbs. These types of objects cannot be detected by Parking Guidance and may damage the vehicle.

When PARKTRONIC is deactivated, Parking Guidance is also unavailable.

Use Parking Guidance for parking spaces:

- that are parallel to the direction of travel
- that are on straight roads, not bends
- that are on the same level as the road, i.e. not on the pavement, for example. Parking Guidance may not detect flat curbs

Parking tips:

- on narrow roads, drive past the parking space as close as possible.
- parking spaces that are littered, overgrown or partially occupied by trailer drawbars might be identified incorrectly or not at all.
- snowfall or heavy rain may lead to a parking space being measured inaccurately.
- pay attention to the PARKTRONIC (▷ page 171) warning messages during the parking procedure.

- when transporting a load which protrudes from your vehicle, you must not use Parking Guidance.
- never use Parking Guidance with snow chains or an emergency spare wheel mounted.
- make sure that the tire pressures are always correct. This has a direct effect on the steering instructions.
- the way your vehicle is positioned in the parking space after parking is dependent on various factors. These include the position and shape of the vehicles parked in front and behind it and the conditions of the location. In some cases, Parking Guidance may guide you too far or not far enough into a parking space. In some cases, it may also lead you across or onto the curb. If necessary, cancel the parking procedure with Parking Guidance.
- If unavoidable, you should drive over obstacles such as curbs slowly and not at a sharp angle. Otherwise, you may damage the wheels or tires.

Detecting a parking space



- ① Detected parking space on the left
- ② Parking symbol
- ③ Detected parking space on the right

Parking Guidance is automatically activated when you drive forwards. The system is operational at speeds of up to approximately 22 mph (35 km/h). While in operation, the system independently locates and measures

parking spaces on both sides of the vehicle. When driving at speeds below 19 mph (30 km/h), you will see parking symbol (2) as a status indicator in the instrument cluster. When a parking space has been detected, an arrow towards the right (3) or the left (1) also appears. Parking Guidance only displays parking spaces on the front-passenger side as standard. Parking spaces on the driver's side are displayed as soon as the turn signal on the driver's side is activated. To park on the driver's side, you must leave the driver's side turn signal switched on until you have engaged reverse gear.

Parking Guidance will only detect parking spaces:

- that are parallel to the direction of travel
- that are at least 5 ft (1.5 m) wide
- that are at least 4.3 ft (1.3 m) longer than vour vehicle

A parking space is displayed while you are driving past it, and until you are approximately 50 ft (15 m) away from it.

Parking

MARNING

The Parking Guidance is only an aid and may not detect all obstacles. The Parking Guidance does not relieve you of the responsibility to pay attention. You are always responsible for safety and must continue to pay attention to your immediate surroundings when parking and maneuvering. Otherwise, you could endanger yourself and others.

- ► Stop the vehicle when the parking space symbol shows the desired parking space in the instrument cluster.
- ► Vehicles with manual transmission: shift to reverse gear.

Vehicles with automatic transmission: shift into position R.

The following message appears in the multifunction display: Check vehicle surroundings Confirm with OK.

▶ Press the OK button on the multifunction steering wheel to confirm. The multifunction display switches to Parking Guidance.

Depending on your distance from the parking space, the **Please** reverse message appears in the multifunction display.



▶ If necessary, reverse towards the parking space. This is indicated by an arrow pointing backwards.

Continue backing up until you hear a tone. Stop – the parking position has been reached. The arrow is white.

The Please steer to the right or Please steer to the left message appears in the multifunction display.



▶ While the vehicle is stationary, turn the steering wheel in the specified direction

176 Driving systems

until the arrow is white and a warning tone sounds.

- ► To reverse into the parking space: maintain the steering wheel angle and reverse carefully.
- Stop as soon as you hear a warning tone, The vehicle has reached the position in which you need to countersteer.

The Please steer to the left or Please steer to the right message appears in the multifunction display.

- Countersteering: while the vehicle is stationary, turn the steering wheel in the specified direction until the arrow is white and a warning tone sounds.
- ► To reverse into the parking space: maintain the steering wheel angle and reverse carefully.
- Stop as soon as you hear a warning tone, at the latest when PARKTRONIC sounds the continuous warning tone. The Parking Guidance finished

message appears in the multifunction display and a warning tone sounds. You may be asked to steer in a different direction and then change gear. In this case, further displays in the multifunction display will direct you to the final position.

- ► Maneuver if necessary.
- ► Always observe the warning messages displayed by PARKTRONIC (▷ page 171).

Canceling Parking Guidance

 Press the PARKTRONIC button on the center console (> page 172).
 Parking Guidance is canceled immediately and PARKTRONIC is deactivated.

Parking Guidance is canceled automatically if it is no longer possible to guide you into the parking space, or if a malfunction occurs.

The parking space symbol goes out and a warning tone sounds. The Parking

Guidance Canceled message appears in the multifunction display.

ATTENTION ASSIST

Important safety notes

ATTENTION ASSIST helps you during long, monotonous journeys such as on freeways and interstate highways. It is active in the range between 50 mph (80 km/h) and 112 mph (180 km/h).

If ATTENTION ASSIST detects typical indicators of fatigue or increasing lapses in concentration on the part of the driver, it suggests you take a break.

ATTENTION ASSIST is only an aid and may detect your tiredness or lapses in concentration too late or not at all. It is not a substitute for a well-rested and attentive driver.

Fatigue may cause you to recognize hazardous situations too late, misjudge a situation or react more slowly. For this reason, make sure you feel rested before you begin driving and during your journey. Make sure that you take regular breaks in time, particularly on long journeys. Otherwise, you may fail to recognize dangers in time, cause an accident and injure yourself and others.

ATTENTION ASSIST assesses your level of fatigue or lapses in concentration by taking the following criteria into account:

• your personal driving style, e.g. steering characteristics

• driving conditions, e.g. time, driving time The functionality of ATTENTION ASSIST is restricted and warnings may be delayed or not occur at all:

- if the road condition is poor, e.g. if the surface is uneven or if there are potholes
- if there is a strong side wind
- if you have adopted a sporty driving style with high cornering speeds or high rates of acceleration

- if you are predominantly driving slower than 50 mph (80 km/h) or faster than 112 mph (180 km/h)
- if you are currently using COMAND or making a telephone call with it
- if the time has been set incorrectly
- in active driving situations, such as when you change lanes or change your speed

Warning and display messages in the multifunction display



► Activate ATTENTION ASSIST using the onboard computer (▷ page 191). Symbol ① appears in the multifunction display.

If ATTENTION ASSIST is active, you will be warned no sooner than 20 minutes after your journey has begun. You will then hear an intermittent warning tone twice, and the Attention Assist: Drowsiness Detected message appears in the multifunction display.

- ▶ If necessary, take a break.
- Press OK or to confirm the message.

On long journeys, take regular breaks in good time to allow yourself to rest properly. If you do not take a break, you will be warned again after 15 minutes at the earliest. The precondition for this is that ATTENTION ASSIST still detects typical indicators of fatigue or increasing lapses in concentration. ATTENTION ASSIST is reset when you continue your journey and starts assessing your tiredness again if:

- you switch off the engine.
- you take off your seat belt and open the driver's door, e.g. for a change of drivers or to take a break.

Useful information180Important safety notes180Displays and operation180Menus and submenus184Display messages199Warning and indicator lamps in the
instrument cluster228

179

Useful information

This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.

 Please read the information on qualified specialist workshops (▷ page 23).

Important safety notes

You will find an illustration of the instrument cluster in the "At a glance" section (▷ page 27).

MARNING

The driver's concentration must always be directed primarily at road traffic.

For your safety and the safety of others, selecting features through the multifunction steering wheel should only be done by the driver when traffic and road conditions permit it to be done safely.

Bear in mind that at a speed of only 30 mph (approximately 50 km/h), the vehicle covers a distance of 44 feet (approximately 14 m) per second.

MARNING

No messages will be displayed if either the instrument cluster or the multifunction display is inoperative.

As a result, you will not be able to see information about your driving conditions, such as

- speed
- outside temperature
- warning/indicator lamps

- malfunction/warning messages
- failure of any systems

Driving characteristics may be impaired.

If you must continue to drive, do so with added caution. Contact an authorized Mercedes-Benz Center as soon as possible.

▲ WARNING

Malfunction and warning messages are only indicated for certain systems and are intentionally not very detailed. The malfunction and warning messages are simply a reminder with respect to the operation of certain systems. They do not replace the owner's and/or driver's responsibility to maintain the vehicle's operating safety. Have all required maintenance and safety checks performed on the vehicle. Bring the vehicle to an authorized Mercedes-Benz Center to address the malfunction and warning messages.

Displays and operation

Instrument lighting

The brightness control knob is located on the bottom left of the instrument cluster (> page 27).

 Turn the brightness control knob clockwise or counter-clockwise.

Instrument cluster: if the light switch is set to **AUTO**, **EDC**, or **ED**, brightness control takes ambient light into account.

The light sensor in the instrument cluster automatically controls the brightness of the multifunction display.

In daylight, the displays in the instrument cluster are not illuminated.

Displays and switches in the vehicle interior: if the light switch is set to **Auro**, brightness control takes ambient light into account. If the light switch is set to **DOC** or **D**, brightness control does not take ambient light into account.

Coolant temperature display

M WARNING

Driving when your engine is overheated can cause some fluids which may have leaked into the engine compartment to catch fire. You could be seriously burned.

Steam from an overheated engine can cause serious burns which can occur just by opening the engine hood. Stay away from the engine if you see or hear steam coming from it.

Stop the vehicle in a safe location away from other traffic. Turn off the engine, get out of the vehicle and do not stand near the vehicle until the engine has cooled down.

The coolant temperature gauge is in the instrument cluster on the right-hand side. Under normal operating conditions and with the specified coolant level, the coolant temperature may rise to 248 °F (120 °C).

A display message is shown if the coolant temperature is too high.

If the coolant temperature is over 248 °F(120 °C), do not continue driving. The engine will otherwise be damaged.

Tachometer

The red band in the tachometer indicates the engine's overrevving range.

Do not drive in the overrevving range, as this could damage the engine.

The fuel supply is interrupted to protect the engine when the red band is reached.

Outside temperature display

The outside temperature display is in the multifunction display (\triangleright page 183).

The outside temperature indicator is not designed to serve as an ice-warning device and is therefore unsuitable for that purpose. Indicated temperatures just above the freezing point do not guarantee that the road surface is free of ice. The road may still be icy, especially in wooded areas or on bridges.

Changes in the outside temperature are displayed after a short delay.

Speedometer with segments

The segments in the speedometer indicate which speed range is available.

Cruise control (> page 156) activated:

The segments light up from the stored speed to the maximum speed.

DISTRONIC PLUS (▷ page 158) activated:

One or two segments in the set speed range light up.

DISTRONIC PLUS detects a vehicle in front: The segments between the speed of the vehicle in front and the stored speed light up.

Operating the on-board computer

Overview

The on-board computer is activated as soon as you turn the SmartKey to position **1** in the ignition lock.

You can control the multifunction display and the settings in the on-board computer using the buttons on the multifunction steering wheel.

182 Displays and operation

On-board computer and displays



- Multifunction display
- Switches on the Voice Control System; see the separate operating instructions
- ③ Right control panel
- ④ Left control panel
- ⑤ Back button

Left control panel



• Calls up the menu and menu bar

Press briefly:

- Scrolls in lists
- Selects a submenu or function
- In the Audio menu: selects a stored station, an audio track or a video scene
- In the Tel (telephone) menu: switches to the phone book and selects a name or telephone number

Press and hold:

- In the Audio menu: selects the previous/next station or selects an audio track or a video scene using rapid scrolling
- In the Tel (telephone) menu: starts rapid scrolling through the phone book
- OK Confirms a selection/display message
 - In the Tel (telephone) menu: switches to the telephone book and starts dialing the selected number
 - In the Audio menu: stops the station search function at the desired station

Right control panel

\square	 Rejects or ends a call Exits phone book/redial memory
P	Makes or accepts a callSwitches to the redial memory
+	• Adjusts the volume
¥	• Mute

Back button

Press briefly: Back Switches off the Voice Control System; see the separate operating instructions Hides display messages or calls up the last Trip menu function used Exits the telephone book/redial memory Press and hold: Calls up the standard display in the Trip menu

Multifunction display

Values and settings as well as display messages are shown in the multifunction display.



Example: multifunction display for automatic transmission

- 1 Transmission position
- Drive program
- ③ Description field
- ④ Menu bar

- (5) Outside temperature or speed (▷ page 192)
- 6 Time
- ► To show menu bar ④: press the or ► button on the steering wheel.

Menu bar ④ disappears after a few seconds.

Text field ③ shows the selected menu or submenu as well as display messages.

• You can set the time using Audio 20 or COMAND; see the separate Operating Instructions.

Vehicles with manual transmission: the clock and the outside temperature or speed are shown instead of transmission position (1) and drive program (2).


The following messages may appear in the multifunction display:

- t Shift recommendation (▷ page 139)
- ← P→ Parking Guidance (▷ page 173)
- CRUISE Cruise control (▷ page 156)
- Image: ATTENTION ASSIST (▷ page 176)
- HOLD HOLD function (▷ page 168)
- کاچ= PRE-SAFE[®] Brake (⊳ page 62)

Menus and submenus

Menu overview

The number of menus shown depends on the optional equipment in the vehicle.



Function

- ① Trip(⊳ page 185)menu
- Navi menu (navigation instructions) (> page 186)
- ③ Audio menu (⊳ page 188)
- ④ Tel menu (telephone) (▷ page 189)
- ⑤ DriveAssist menu (assistance) (▷ page 190)
- 6 Serv. (▷ page 191) menu
 - calling up display messages (▷ page 199)
 - tire pressure monitor (▷ page 301)
 - ASSYST PLUS service interval display (> page 264)
- ⑦ Settings menu (▷ page 191)
- ⑧ AMG menu in AMG vehicles (▷ page 195)

Depending on the audio system installed, the display messages in the Audio and Tel menus differ slightly. The examples given in this Operator's Manual apply to vehicles equipped with COMAND.

Menus and submenus | 185

Trip menu

Standard display



Press and hold the <u>steering</u> button on the steering wheel until the Trip (1) menu with trip odometer 1 and odometer 2 is shown. (2)

Trip computer "From start" or "From reset"

The values in the From Start submenu are calculated from the start of a journey, while the values in the From Reset submenu are calculated from the last time the submenu was reset (\triangleright page 186).

- Press the or button on the steering wheel to select the Trip menu.
- ► Press the ▲ or ▼ button to select From start or From reset.



Example: trip computer "From start"

- ① Distance
- 2 Time

- ③ Average speed
- ④ Average fuel consumption

The From Start trip computer is reset automatically when:

- the ignition has been switched off for more than four hours.
- 999 hours have been exceeded.
- 9999 miles have been exceeded.

When 9,999 hours or 99,999 miles have been exceeded, the trip computer is automatically reset From Reset.

Displaying the range and current fuel consumption

- Press the or button on the steering wheel to select the Trip menu.
- Press the or button to select the current fuel consumption and the approximate range (except for AMG vehicles).



- (1) Approximate range
- Current fuel consumption (not for AMG vehicles)

Approximate range (1) is calculated according to current driving style and the amount of fuel in the tank. If there is only a small amount of fuel left in the fuel tank, the display shows a vehicle being refueled $\boxed{}$ instead of range (1).

Digital speedometer

- Press the or button on the steering wheel to select the Trip menu.
- Press or to select the digital speedometer.



- ① Shift recommendation
- ② Digital speedometer
- If the gearshift recommendation is shown in the multifunction display, it is not shown in the status bar.

Further information on gearshift recommendations (\triangleright page 139).

Resetting values

You can reset the values of the following functions:

- trip odometer
- trip computer "From start"
- trip computer "From reset"
- Press the or button on the steering wheel to select the Trip menu.
- Press the or button to select the function that you wish to reset.
- ▶ Press OK.



Resetting the trip computer "From start" (example)

► Press ▼ to select Yes and press OK to confirm.


Navigation system menu

Displaying navigation instructions

In the Navi menu, the multifunction display shows navigation instructions. For more information, see the separate operating instructions.

- Switch on COMAND (see the separate operating instructions).
- Press the or button on the steering wheel to select the Navi menu.

Route guidance not active



- ① Direction of travel
- Current street

Route guidance active

No change of direction announced



- ① Distance to the destination
- Distance to the next change of direction
- ③ Current street
- ④ Symbol "follow the road's course"

Change of direction announced without a lane recommendation



- Road into which the change of direction leads
- ② Distance to change of direction and visual distance display
- ③ Symbol for change of direction

When a change of direction has been announced, you will see visual distance display (2) next to the symbol for the change of direction (3). This decreases in size as you approach the announced change of direction.

Change of direction announced with a lane recommendation

Lane recommendations are only displayed if the relevant data is available on the digital map.



- **On-board computer and displays**
- Road into which the change of direction leads
- Distance to change of direction and visual distance display
- ③ Lane recommendation
- ④ Symbol for change of direction

On multilane roads, lane recommendation ③ may be shown for the next change of direction. During the change of direction, additional lanes may be displayed.



Lane recommendation display (example)

- ① Uninterrupted lane
- New lane during a change of direction

188 Menus and submenus

Other status indicators of the navigation system

- 🕅 : you have reached the destination or an intermediate destination.
- New Route... or Calculating Route: a new route is being calculated.
- Off Map or Off Mapped Road: the vehicle position is outside the area of the digital map (off-map position).
- No Route: no route could be calculated to the selected destination.

Audio menu

Selecting a radio station

 SIRIUS XM satellite radio functions like a normal radio.

For more information on satellite radio operation, see the separate operating instructions.

You can only change the waveband and store new stations using Audio 20 or COMAND.

- Switch on Audio 20 or COMAND (see the separate operating instructions) and select Radio.
- Press the or button on the steering wheel to select the Audio menu.



- Waveband
- ② Station¹³

- ► To select a stored station: briefly press the ▲ or ▼ button.
- ► To select a station from the station list: press and briefly hold the ▲ or ▼ button.
- ► To select a station using station search¹⁴: press and briefly hold the or ▼ button.

Operating audio player or audio media

Audio data from various audio devices or media can be played, depending on the equipment installed in the vehicle.

- Switch on Audio 20 or COMAND and select the audio device or medium (see the separate operating instructions).
- Press the or button on the steering wheel to select the Audio menu.



CD changer display (example) ① Current title

- ► To select the next/previous track: briefly press the ▲ or ▼ button.
- To select a track from the track list (rapid scrolling): press and hold the

 or
 button until the desired track has been reached.

If you press and hold the button, the rapid scrolling speed is increased. Not all audio drives or data carriers support this function.

¹³ If the station has been stored, the memory position will also be displayed.¹⁴ Only if no station list is received.

If track information is stored on the audio device or medium, the multifunction display will show the number and name of the track. The current track does not appear in audio AUX mode (**Aux**iliary audio mode: external audio source connected).

Video DVD operation

- Switch on COMAND and select video DVD (see the separate operating instructions).
- Press the or button on the steering wheel to select the Audio menu.



DVD changer display (example) ① Current scene

- ► To select the next or previous scene: briefly press the or v button.
- ► To select a scene from the scene list (rapid scrolling): press and hold the
 ▲ or ▼ button until the desired scene has been reached.

Telephone menu

Introduction

You can establish a Bluetooth[®] connection to Audio 20 or to COMAND (see the separate operating instructions).

The driver's attention to the road must always be his/her primary focus when driving. For your safety and the safety of others, we recommend that you pull over to a safe location and stop before placing or taking a telephone call. If you choose to use the telephone while driving, please use the handsfree device and only use the telephone when road, weather and traffic conditions permit. Some jurisdictions prohibit the driver from using a mobile phone while driving a vehicle. Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle covers a distance of 44 feet (approximately 14 m) every second.

- Switch on the mobile phone and Audio 20 or COMAND (see the separate operating instructions).
- Press the or button on the steering wheel to select the Tel menu.

You will see one of the following display messages in the multifunction display:

- Telephone ready or the name of the network provider: the mobile phone has found a network and is ready to receive.
- Telephone No Service: no network is available, or the mobile phone is searching for a network.

Accepting a call

If someone calls you when you are in the **Tel** menu, a display message appears in the multifunction display, for example:



Press the button on the steering wheel to accept an incoming call.

If you are not in the Tel menu, you can still accept a call.

Rejecting or ending a call

 Press the button on the steering wheel.

If you are not in the Tel menu, you can still reject or end a call.

Dialing a number from the phone book

If your mobile phone is able to receive calls, you can search for and dial a number from the phone book in Audio 20 or COMAND.

- Press the or button on the steering wheel to select the Tel menu.
- ► Press the ▲, ▼ or OK button to call up the phone book.
- ► Press the ▲ or ▼ button to select the desired name.

To start scrolling rapidly, press and hold the ▲ or ▼ button for longer than one second. After a short time, the rapid scroll speeds up.

Rapid scrolling stops when you release the button or reach the end of the list.

If only one telephone number is stored for a name: press the OK button to start dialing.

or

- If there is more than one number for a particular name: press the or OK button to display the numbers.
- Press the or button to select the number you want to dial.
- ▶ Press the row or OK button to start dialing.

or

Redialing

The on-board computer saves the last names or numbers dialed in the redial memory.

- Press the or button on the steering wheel to select the Tel menu.
- Press the button to switch to the redial memory.
- ► Press the ▲ or ▼ button to select the desired name or number.
- Press the or OK button to start dialing.

or

► If you do not want to make a call: press the or button.

Assistance menu

Showing the distance display

This function is only available with DISTRONIC PLUS.

- Press the or button on the steering wheel to select the DriveAssist menu.
- ► Press the ▲ or ▼ button to select Distance Display.
- ▶ Press OK.

The DISTRONIC PLUS distance display (> page 165) appears in the multifunction display.

Activating/deactivating PRE-SAFE[®] Brake

PRE-SAFE[®] Brake is only available in vehicles with DISTRONIC PLUS.

- Press the or button on the steering wheel to select the DriveAssist menu.
- ▶ Press ▲ or ▼ to select PRE-SAFE Brake.
- ▶ Press OK. The current selection is displayed.
- ► To activate/deactivate: press OK again.

When PRE-SAFE[®] Brake (\triangleright page 62) is activated, the multifunction display shows


the $\boxed{\texttt{D}!}$ symbol as long as the HOLD function is not activated (\triangleright page 168).

Vehicles with Parking Guidance: if PARKTRONIC is activated and you are driving at a speed under 22 mph (35km/h) the P symbol for Parking Guidance is displayed instead of the Ster symbol.

Activating/deactivating ATTENTION ASSIST

- Press the or button on the steering wheel to select the DriveAssist menu.
- ► Press the ▲ or ▼ button to select Attention Asst..
- Press OK.
 The current selection is displayed.
- ► To activate/deactivate: press OK again.

When ATTENTION ASSIST (\triangleright page 176) is activated, the > symbol appears in the multifunction display when the ignition is on.



In the Serv. menu, you have the following options:

- calling up display messages (▷ page 199)
- checking the tire pressure electronically (> page 301)
- calling up a service due date (▷ page 264)

Settings menu

Introduction



On-board computer and displays

The Sett. menu can be used for:

- changing the instrument cluster settings
- changing the light settings
- changing the vehicle settings
- changing the convenience settings
- restoring the factory settings

Instrument cluster

Selecting the unit of measurement for distance

The Display Unit Speed-/Odometer:

function allows you to choose whether certain displays appear in kilometers or miles. The selected unit of measurement for distance applies to:

- digital speedometers in the Trip menu
- odometer and the trip odometer
- Trip computer
- current consumption and the range
- navigation instructions in the Navi menu
- DISTRONIC PLUS
- ASSYST PLUS service interval display
- Press the or button on the steering wheel to select the Sett. menu.
- ► Press the ▼ or ▲ button to select the Instr. Cluster submenu.
- ▶ Press OK to confirm.

192 Menus and submenus

Press the v or button to select the Display Unit Speed-/Odometer: function.

You will see the selected setting: km or miles.

▶ Press the OK button to save the setting.

Switching the additional speedometer on or off

Only vehicles with manual transmission have this function.

The Additional Speedometer function allows you to choose whether the status area of the multifunction display shows the speed in km/h (USA) or mph (Canada) instead of the outside temperature.

- Press the or button on the steering wheel to select the Settings menu.
- ► Press the ▼ or ▲ button to select the Instr. cluster submenu.
- ▶ Press the OK button to confirm.
- Press the ▼ or ▲ button to select the Additional Speedometer function. You will see the selected setting: On or Off.
- ▶ Press the OK button to save the setting.

Selecting the permanent display function

Only vehicles with automatic transmission have this function.

The **Permanent Display**: function allows you to choose whether the multifunction display always shows the outside temperature or the speed in km/h (USA) or mph (Canada).

- Press the or button on the steering wheel to select the Settings menu.
- ► Press the ▼ or ▲ button to select the Instr. cluster submenu.
- ▶ Press the OK button to confirm.

- ▶ Press the ▼ or ▲ button to select the Permanent display function. You will see the selected setting Outside Temperature or Speedometer [km/h]:.
- ▶ Press the OK button to save the setting.

Lights

Switching the daytime running lamps on/ off

This function is not available in Canada.

If you have activated the Daytime Running Lights: function and the light switch is in the A or Auro position, the daytime running lamps are switched on automatically when the engine is running.

Depending on the ambient light, the following will additionally light up:

- low-beam headlamps
- parking lamps
- tail lamps
- license plate lamp
- side marker lamps
- Press the or button on the steering wheel to select the Settings menu.
- Press the v or button to select the Light submenu.
- ▶ Press the OK button to confirm.
- Press the ▼ or ▲ button to select the Daytime running lights function. You will see the selected setting: on or off.
- ▶ Press the OK button to save the setting.

Setting the brightness of the ambient lighting

- Press the or button on the steering wheel to select the Settings menu.
- ► Press the ▼ or ▲ button to select the Lights submenu.
- ▶ Press the OK button to confirm.

- ► Press the ▼ or ▲ button to select Ambient light.
 - You will see the selected setting.
- ▶ Press the OK button to confirm.
- Press the v or button to adjust the brightness to any level from Off to Level 5 (bright).
- ► Press the OK or button to save the setting.

Activating/deactivating surround lighting and exterior lighting delayed switch-off

If you have activated the Lighting: function and the light switch is in the **A** or **Auro** position, the following functions are active when it is dark:

- **Surround lighting:** the exterior lighting remains lit for 40 seconds after unlocking with the key. The exterior lighting switches off when you open the driver's door.
- Exterior lighting delayed switch-off: the exterior lighting remains lit for 60 seconds after the engine is switched off. If you close all the doors, the exterior lighting goes off after 15 seconds.

If you activate the **Surround lighting**: function, the following light up depending on the vehicle's equipment:

- parking lamps
- front fog lamps
- low-beam headlamps
- daytime running lamps
- side marker lamps
- Press the or button on the steering wheel to select the Sett. menu.
- Press the v or button to select the Lights submenu.
- ▶ Press the OK button to confirm.
- ► Press the ▼ or ▲ button to select the Locator Lighting function. You will see the selected setting: on or off.
- ▶ Press the OK button to save the setting.

Deactivating delayed switch-off of the exterior lighting temporarily:

- Before leaving the vehicle, turn the SmartKey to position 0 in the ignition lock.
- ► Turn the SmartKey to position 2 in the ignition lock and back to position 0. The exterior lighting delayed switch-off is deactivated.

Delayed switch-off of the exterior lighting is reactivated the next time you start the engine.

Activating/deactivating the interior lighting delayed switch-off

If you activate the Interior lighting delay sw. off function, the interior lighting remains on for 20seconds after you remove the key from the ignition lock.

- Press the or button on the steering wheel to select the Settings menu.
- ► Press the ▼ or ▲ button to select the Light submenu.
- ▶ Press the OK button to confirm.
- Press the v or button to select the Interior lighting delay sw. off: function. You will see the selected setting: on or off.
- ▶ Press the OK button to save the setting.

Vehicle

Activating/deactivating the automatic door locking mechanism

If you select the Automatic Door Lock: function, the vehicle is centrally locked above a speed of around 9 mph (15km/h).

● For further information on the automatic locking feature, see (▷ page 75).

194 Menus and submenus

- Press the or button on the steering wheel to select the Settings menu.
- Press the v or button to select the Vehicle submenu.
- ▶ Press the OK button to confirm.
- Press the ▼ or ▲ button to select the Automatic door locks function. You will see the selected setting: on or off.
- ▶ Press the OK button to save the setting.

Activating/deactivating the acoustic locking verification signal

If you switch on the Acoustic Lock feedback function, an acoustic signal sounds when you lock the vehicle.

- Press the or button on the steering wheel to select the Settings menu.
- Press the v or button to select the Vehicle submenu.
- ▶ Press the OK button to confirm.
- ► Press the ▼ or ▲ button to select the Acoustic Lock feedback: function. You will see the selected setting: Activated or Deactivated.
- ▶ Press the OK button to save the setting.

Activating/deactivating the radar sensor system

The following systems are switched off when the radar sensor system is deactivated:

- DISTRONIC PLUS (▷ page 158)
- BAS PLUS (▷ page 57)
- PRE-SAFE[®] Brake (▷ page 62)
- Press the or button on the steering wheel to select the Sett. menu.
- Press the vertex or button to select the vehicle submenu.
- ▶ Press OK to confirm.

- Press the or button to select Radar Sensor (See Oper. Manual):. You will see the selected setting: Enabled or Disabled.
- ▶ Press the OK button to save the setting.

Convenience

Activating/deactivating the EASY-ENTRY/EXIT feature

You can use the Easy Entry/Exit: function to activate or deactivate the EASY ENTRY/EXIT feature (> page 97).

You must make sure no one can become trapped or injured by the moving steering wheel when the easy-entry/exit feature is activated.

To stop steering wheel movement, move steering wheel adjustment lever or press one of the memory position buttons.

Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Children could open the driver's door and unintentionally activate the easy-entry/exit feature, which could result in an accident and/or serious personal injury.

- Press the or button on the steering wheel to select the Settings menu.
- Press the v or button to select the Convenience submenu.
- ▶ Press the OK button to confirm.
- Press the v or button to select the Easy Entry/Exit: function. You will see the selected setting: on or off.
- ▶ Press the OK button to save the setting.

Switching the belt adjustment on/off

For further information on belt adjustment, see (\triangleright page 51).

Menus and submenus | 195

- Press the or button on the steering wheel to select the Sett. menu.
- Press the v or button to select the Convenience submenu.
- ▶ Press OK to confirm.
- Press the ▼ or ▲ button to select the Belt Adjustment function. You will see the selected setting: on or off.
- ▶ Press the OK button to save the setting.

Switching the fold-in mirrors when locking feature is on/off

If you switch on the Fold Mirrors in when Locking function, the exterior mirrors fold in when you lock the vehicle. If you unlock the vehicle and then open a door, the exterior mirrors fold out again.

If you have switched the function on and you fold the exterior mirrors in using the button on the door (\triangleright page 99), they will not fold out automatically. The exterior mirrors can then only be folded out using the button on the door.

- Press the or button on the steering wheel to select the Settings menu.
- ► Press the ▼ or ▲ button to select the Convenience submenu.
- ▶ Press the OK button to confirm.
- ► Press the ▼ or ▲ button to select the Fold mirrors in when locking: function.

You will see the selected setting: Enabled or Disabled.

▶ Press the OK button to save the setting.

Restoring the factory settings

For safety reasons, the Daytime Running Lights: function in the Lights submenu is only reset when the vehicle is stationary.

- Press the or button on the steering wheel to select the Sett. menu.
- ► Press the ▼ or ▲ button to select the Factory Setting submenu.
- Press the OK button to confirm.
 The Reset All Settings? message appears.
- ► Press the ▼ or ▲ button to select No or Yes.
- Press the OK button to confirm the selection.
 If you select Yes, the multifunction display shows a confirmation message.

AMG menu in AMG vehicles

AMG displays

Press the or button on the steering wheel to select the AMG menu.



- ① Digital speedometer
- Gear indicator
- ③ Upshift indicator
- ④ Engine oil temperature
- (5) Coolant temperature
- Status display of the ECO start/stop function (▷ page 135)

Upshift indicator UP ③ indicates that the engine has reached the overrevving range when in the manual gearshift program. Upshift indicator UP ③ fades out other messages until you have shifted up.

196 Menus and submenus

When the engine temperature is below 80 °C, the oil temperature gauge flashes. Avoid driving at full engine output during this time.

SETUP

SETUP shows the drive program, the ESP[®] (Electronic Stability Program) mode and the SPORT handling mode.

- Press the or button on the steering wheel to select the AMG menu.
- Press the button repeatedly until SETUP is displayed.



- ① Drive program (C/S/M)
- ESP[®] mode (ON/OFF) or SPORT handling mode (SPORT)

RACETIMER

Displaying and starting RACETIMER

MARNING

The RACETIMER feature is only for use on roads and in conditions where high speed driving is permitted. Racing on public roads is prohibited under all circumstances. The driver is and must always remain responsible for following posted speed limits.

You can use the RACETIMER to store lap times.

- Press the or button on the steering wheel to select the AMG menu.
- Press the button repeatedly until the RACETIMER is shown.

If RACETIMER is selected, the menu bar cannot be called up with the
 and
 buttons.



1 Lap

② RACETIMER

You can start the RACETIMER when the engine is running or if the SmartKey is in position **2** in the ignition lock.

► To start: press the OK button to start the RACETIMER.

Displaying the intermediate time



- Press the or button to select Interm. Time.
- Press the OK button to confirm. The intermediate time is displayed for five seconds.

Starting a new lap

▶ Press OK to confirm New Lap.



- ① RACETIMER
- (2) Fastest lap time (best lap)
- ③ Lap
- 1 It is possible to store a maximum of sixteen laps. Lap sixteen can only be finished with Finish Lap.

Stopping the RACETIMER

▶ Press the ____ button on the steering wheel.



▶ Press OK to confirm YES.

The RACETIMER interrupts timing when you stop the vehicle and turn the SmartKey to position **1** in the ignition lock. If you turn the SmartKey to position 2 or 3 and then press the OK button to confirm Start, timing is continued.

Resetting the current lap

- ▶ Stop the RACETIMER.
- ▶ Press the or button to select Reset Lap.
- ▶ Press OK to reset the lap time to "0".

Deleting all laps

If you switch off the engine, the RACETIMER is reset to "0" after 30 seconds. All laps are deleted.

You cannot delete individual stored laps. If you have stopped 16 laps, the current lap does not have to be reset.

- ▶ Reset the current lap.
- ▶ Press OK to confirm Reset. Reset Race Timer? appears in the multifunction display.



▶ Press the ▼ button to select Yes and press the OK button to confirm. All laps are deleted.

Overall statistics

This function is shown if you have stored at least one lap and stopped the RACETIMER.

- ▶ Press or on the steering wheel to select the AMG menu.
- ▶ Press the ▲ button repeatedly until the overall evaluation is shown.



198 Menus and submenus



- ① RACETIMER overall evaluation
- Total time driven
- ③ Average speed
- ④ Distance covered
- (5) Top speed

Lap statistics

This function is only available if you have stored at least two laps and have stopped the RACETIMER.

- Press the or button on the steering wheel to select the AMG menu.
- Press the button repeatedly until the lap evaluation is shown.
 Each lap is shown in a separate submenu.
 The fastest lap is indicated by flashing symbol (1).



- ① Lap
- 2 Lap time
- ③ Average lap speed
- ④ Lap length
- (5) Top speed during lap

► Press the ▲ or ▼ button to select a different lap evaluation.

General notes

All categories of messages contain important information which should be taken note of and, where a malfunction is indicated, addressed as soon as possible at an authorized Mercedes-Benz Center.

Failure to repair the condition noted may cause damage not covered by the Mercedes-Benz Limited Warranty, or result in property damage or personal injury.

Display messages appear in the multifunction display.

Display messages with graphic displays may be shown in simplified form in the Operator's Manual and may differ from the messages shown in the multifunction display.

Please respond in accordance with the display messages and follow the additional notes in this Operator's Manual.

Certain display messages are accompanied by an audible warning tone or a continuous tone.

Hiding display messages

You can hide some display messages with a low priority.

Press the OK or button on the steering wheel to hide the display message. The display message is cleared.

Display messages with a high priority are shown in red.

You cannot hide display messages of the highest priority. The multifunction display shows these messages continuously until the causes for the messages have been remedied.

Message memory


The on-board computer saves certain display messages. You can call up the display messages in the **message memory**.

- Press the or button on the steering wheel and select the Serv. menu. If there are display messages, the multifunction display shows, for example, 2 messages.
- ▶ Press the \land or \lor button to select the entry, e.g. 2 messages.
- ► Confirm with OK.
- ▶ Press the ▲ or ▼ button to scroll through the display messages.

When the ignition is switched off, all display messages are deleted, apart from some highpriority display messages. Once the causes of the high-priority display messages have been rectified, the corresponding display messages are also deleted.

Safety systems

Display messages



Possible causes/consequences and Solutions

▲ Risk of accident

ABS (Anti-lock Braking System), ESP[®] (Electronic Stability Program), BAS (Brake Assist), the HOLD function and hill start assist are temporarily unavailable.

BAS PLUS and PRE-SAFE[®] Brake may also have failed.

In addition, the 🛒, 👫 and 🔘 warning lamps light up in the instrument cluster.

The self-diagnosis function might not be complete, for example. ATTENTION ASSIST is deactivated.

The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example.

 Carefully drive a short distance on a suitable stretch of road, making slight steering movements at a speed above 12 mph (20 km/h).

If the display message disappears, the functions mentioned above are available again.

If the display message continues to be displayed:

- ► Drive on carefully.
- ► Visit a qualified specialist workshop.

▲ Risk of accident

ABS, $\mbox{ESP}^{\mbox{\scriptsize \$}},$ BAS, the HOLD function and hill start assist are temporarily unavailable.

BAS PLUS and PRE-SAFE[®] Brake may also have failed.

In addition, the $\fbox{}$, $\fbox{}$ and warning lamps light up in the instrument cluster.

For example, the on-board voltage may be insufficient.

ATTENTION ASSIST is deactivated.

The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example.

► Drive on carefully.

If the display message disappears, the functions mentioned above are available again.

If the display message continues to be displayed:

- ► Drive on carefully.
- ► Visit a qualified specialist workshop.

Display messages



Oper. Manual

Possible causes/consequences and ► Solutions

▲ Risk of accident

ABS, $\mbox{ESP}^{\mbox{\scriptsize \$}},$ BAS, the HOLD function and hill start assist are unavailable due to a malfunction.

BAS PLUS and PRE-SAFE[®] Brake may also have failed.

The BRAKE (USA only)/ (()) (Canada only), 📑 , 🧞

and () warning lamps in the instrument cluster also light up. The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example.

ATTENTION ASSIST is deactivated.

- ► Drive on carefully.
- ► Visit a qualified specialist workshop immediately.



Currently Unavailable See Operator's Manual **Risk of accident**

 $\mathsf{ESP}^{\texttt{B}},\mathsf{BAS},\mathsf{the}\,\mathsf{HOLD}\,\mathsf{function}\,\mathsf{and}\,\mathsf{hill}\,\mathsf{start}\,\mathsf{assist}\,\mathsf{are}\,\mathsf{temporarily}\,\mathsf{unavailable}.$

BAS PLUS and PRE-SAFE[®] Brake may also have failed.

In addition, the \fbox and \fbox warning lamps light up in the instrument cluster.

The self-diagnosis function might not be complete, for example. ATTENTION ASSIST is deactivated.

The brake system continues to function normally, but without the functions listed above.

 Carefully drive a short distance on a suitable stretch of road, making slight steering movements at a speed above 12 mph (20 km/h).

If the display message disappears, the functions mentioned above are available again.

- If the display message continues to be displayed:
- ► Drive on carefully.
- ► Visit a qualified specialist workshop.

/s	Display messages	Possible causes/consequences and Solutions
On-board computer and displays	Inoperative See Operator's Manual	 Risk of accident ESP[®], BAS, the HOLD function and hill start assist are unavailable due to a malfunction. BAS PLUS and PRE-SAFE[®] Brake may also have failed. In addition, the , and , warning lamps light up in the instrument cluster. ATTENTION ASSIST is deactivated. The brake system continues to function normally, but without the functions listed above. Drive on carefully. Visit a qualified specialist workshop.
On-b	EBD () Tinoperative See Operator's Manual	 Risk of accident EBD (electronic brake force distribution), ABS, ESP[®], BAS, the HOLD function and hill start assist are unavailable due to a malfunction. BAS PLUS and PRE-SAFE[®] Brake may also have failed. In addition, the , and , and warning lamps light up in the instrument cluster and a warning tone sounds. ATTENTION ASSIST is deactivated. The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example. Drive on carefully. Visit a qualified specialist workshop immediately.
	Check Brake Pad Wear	The brake pads/linings have reached their wear limit.Visit a qualified specialist workshop.
	PARK (USA only) (Canada only) Release Parking Brake	 The red PARK (USA only)/ (()) (Canada only) indicator lamp flashes and a warning tone sounds. A condition for automatic release of the electric parking brake is not fulfilled (▷ page 150). You are driving with the electric parking brake applied. ▶ Release the electric parking brake manually. The red PARK (USA only)/ (()) (Canada only) indicator lamp flashes and a warning tone sounds. You are making an emergency stop using the electric parking brake (▷ page 150).

(P)

Parking Brake See

Operator's Manual

(Canada

PARK (USA

only)

only)

Possible causes/consequences and > Solutions

The yellow 🜘 warning lamp lights up.

The electric parking brake is malfunctioning.

To apply:

- ► Switch the ignition off.
- ▶ Press the electric parking brake handle for at least ten seconds.
- ► Vehicles with manual transmission: engage first gear.
- ► Vehicles with automatic transmission: shift the transmission to P.
- Consult a qualified specialist workshop.

The yellow () warning lamp and the red PARK (USA only)/() (Canada only) indicator lamp light up.

The electric parking brake is malfunctioning.

To release:

- Switch off the ignition and turn it back on.
- ► Release the electric parking brake manually.

or

- ► Vehicles with manual transmission: release the electric parking brake using the automatic emergency release (▷ page 150).
- ▶ Vehicles with automatic transmission: release the electric parking brake automatically (▷ page 150).

If the yellow () warning lamp remains lit or continues to flash:

- ▶ Do not drive on.
- Consult a qualified specialist workshop.

olay messages	Possible causes/consequences and ► Solutions
	The red PARK (USA only)/ (Canada only) indicator lamp flashes and the yellow ((P) warning lamp lights up. The electric parking brake is malfunctioning.
	To release:
	► Switch off the ignition and turn it back on.
	► Release the electric parking brake manually.
	To apply:
	 Switch off the ignition and turn it back on. Apply the electric parking brake manually.
	If the red PARK (USA only)/ (P) (Canada only) indicator lamp continues to flash:
	► Do not drive on.
	► Secure the vehicle against rolling away (▷ page 276).
	Vehicles with manual transmission: engage first gear.
	Vehicles with automatic transmission: shift the transmission to P.
	Turn the front wheels towards the curb.
	 Consult a qualified specialist workshop.
	The yellow () warning lamp lights up. The red PARK (USA only)/ () (Canada only) indicator lamp flashes for about ten seconds after the electric parking brake has been applied or released. It then goes out or remains lit.
	The electric parking brake is malfunctioning.
	 Switch off the ignition and turn it back on. Apply the electric parking brake.
	If it is not possible to engage the electric parking brake:
	 Vehicles with manual transmission: engage first gear.
	 Vehicles with automatic transmission: shift the transmission to P.
	 Visit a qualified specialist workshop.
	If it is not possible to release the electric parking brake:
	► Release the electric parking brake automatically (▷ page 150).
	If the electric parking brake still cannot be released:
	 Consult a qualified specialist workshop.

Display messages	Possible causes/consequences and ► Solutions
	The yellow () warning lamp lights up. If you manually apply or release the electric parking brake, the red PARK (USA only)/ () (Canada only) indicator lamp flashes.
	The electric parking brake is malfunctioning. It is not possible to apply the electric parking brake manually.
	► Vehicles with manual transmission: switch off the ignition. The electric parking brake is applied automatically.
	You can release the electric parking brake using the automatic emergency release (▷ page 150).
	► Vehicles with automatic transmission: shift the transmission to P as the electric parking brake is not being applied automatically.
	 Visit a qualified specialist workshop.
	If you do not wish the electric parking brake to be applied, leave the ignition switched on, e.g. when washing the vehicle in an automatic car wash or when having the vehicle towed. Exception: when having the vehicle towed with the rear axle raised (▷ page 287).
PARK (USA only) (Canada only)	The yellow () warning lamp lights up. The red PARK (USA only)/ () (Canada only) indicator lamp flashes for about ten seconds after the electric parking brake has been applied or released. It then goes out or remains lit.
Pkg Brake Inoperative	The electric parking brake is malfunctioning, e.g. because of overvoltage or undervoltage.
	 Remove the cause for the overvoltage or undervoltage, e.g. by charging the battery or restarting the engine. Engage or release the electric parking brake.
	If it remains impossible to apply or release the electric parking brake:
	 Switch off the ignition and turn it back on. Engage or release the electric parking brake.
	If the electric parking brake still cannot be released:
	 Consult a qualified specialist workshop.

2	Display messages	Possible causes/consequences and Solutions
		 The display message is only shown while the vehicle is in motion. The yellow () warning lamp lights up and the red PARK (USA only)/ () (Canada only) indicator lamp flashes. It is not possible to apply the electric parking brake manually. Vehicles with manual transmission: engage first gear. Vehicles with automatic transmission: shift the transmission to P. Visit a qualified specialist workshop.
	PARK (USA only) (Canada only) Turn On the Ignition to Release the Parking Brake	 The red PARK (USA only)/ (P) (Canada only) indicator lamp lights up. You attempted to release the electric parking brake while the ignition was switched off. SmartKey: turn the SmartKey to position 1 in the ignition lock. KEYLESS-GO: switch on the ignition.
_	BRAKE (USA only) (Canada only) Brake Immediately	 A malfunction has occurred while the HOLD function or DISTRONIC PLUS is active. A tone may also sound at regular intervals. If you attempt to lock the vehicle, the tone becomes louder. You cannot start the engine. ▶ Paying attention to the traffic situation, immediately depress the brake pedal firmly and hold until the display message disappears. ▶ Prevent the vehicle from rolling away before you leave it (▷ page 276). You can restart the engine.
	BRAKE (USA only) (() (Canada only) Check Brake Fluid Level	 Risk of accident There is not enough brake fluid in the brake fluid reservoir. Additionally, the red ERAKE (USA only)/ (()) (Canada only) warning lamp lights up in the instrument cluster and a warning tone sounds. Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances. Apply the electric parking brake. Consult a qualified specialist workshop. Do not add brake fluid. This does not correct the malfunction.

On-board computer and displays

Driving with the message Check Brake Fluid Level displayed can result in an accident. Have your brake system checked immediately.

Do not add brake fluid before checking the brake system. Overfilling the brake fluid reservoir can result in spilling brake fluid on hot engine parts and the brake fluid catching fire. You can be seriously burned.

Display messages	Possible causes/consequences and ► Solutions
SOS Tele Aid Inoperative	 USA only: one or more of the main functions in the mbrace system are malfunctioning. Canada only: one or more of the main functions of the TELEAID system are malfunctioning. USA only: have the mbrace system checked at a qualified specialist workshop. Canada only: have the TELEAID system checked at a qualified specialist workshop.
PRE-SAFE Inoperative See Operator's Manual	 Risk of injury Important functions of PRE-SAFE[®] have failed. All other occupant safety systems, e.g. air bags, remain available. Visit a qualified specialist workshop immediately.

S	Display messages	Possible causes/consequences and Solutions
On-board computer and displays	PRE-SAFE Function Currently Limited See Oper. Manual	 ▶ Risk of accident PRE-SAFE® Brake is temporarily inoperative. Possible causes are: the DISTRONIC PLUS cover in the radiator trim is dirty function is impaired due to heavy rain or snow. the sensors in the bumpers are dirty. the radar sensor system is temporarily inoperative, e.g. due to electromagnetic radiation emitted by nearby TV or radio stations or other sources of electromagnetic radiation. AMG vehicles: ESP® is deactivated. the system is outside the operating temperature range. the on-board voltage is too low. If the display message does not disappear: Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Apply the electric parking brake. Clean the DISTRONIC PLUS cover in the radiator trim (▷ page 269). Clean the bumpers (▷ page 269). Restart the engine. AMG vehicles: reactivate ESP®(▷ page 60). If the system detects that the sensors are fully operational, the display message disappears. PRE-SAFE® Brake is operational again.
	PRE-SAFE Functions Limited See Operator's Manual	 Risk of accident PRE-SAFE[®] Brake is defective. BAS PLUS or the distance warning signal may also have failed. Visit a qualified specialist workshop.
	SRS Malfunction Service Required	 Risk of injury There is a malfunction in the SRS (Supplemental Restraint System). The restrict a warning lamp also lights up in the instrument cluster. Visit a qualified specialist workshop.

Front Left SRS Malfunction Service Required or Front Right Malfunction Service Required

Possible causes/consequences and Solutions

Risk of injury

SRS has malfunctioned at the front on the left or right. The warning lamp also lights up in the instrument cluster.

► Visit a qualified specialist workshop.

X

Left Side Curtain Airbag Malfunction Service Required or Right Side Curtain Airbag Malfunction Service Required

▲ Risk of injury

There is a malfunction in the left-hand or right-hand head bag. The 💽 warning lamp also lights up in the instrument cluster.

► Visit a qualified specialist workshop.

On-board computer and displays

MARNING №

In the event a malfunction of the SRS is indicated as outlined above, the SRS may not be operational.

For your safety, we strongly recommend that you contact an authorized Mercedes-Benz Center immediately to have the system checked. Otherwise the SRS may not be activated when needed in an accident, which could result in serious or fatal injury, or it might deploy unexpectedly and unnecessarily which could also result in injury.

Display messages	Possible causes/consequences and Solutions
Front Passenger Airbag Enabled See Operator's Manual	 The front-passenger air bag and front-passenger knee bag are enabled during the journey, even though: a child, a small adult or an object weighing less than the system's weight threshold is located on the front-passenger seat. or the front-passenger seat is unoccupied. The system may detect objects or forces applying additional weight on the seat. Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Apply the parking brake. Switch the ignition off. Open the front-passenger door. Remove the child and the child restraint system from the front-passenger seat. Make sure that there are no objects on the seat adding to the weight. The system may otherwise detect the additional weight and interpret the seat occupant's weight as greater than it actually
	 is. Keep the seat unoccupied, close the front-passenger door and switch on the ignition. Observe the multifunction display and check the following: Seat unoccupied and ignition switched on: the multifunction lamp is on, OCS (▷ page 42) has deactivated the front-passenger air bag and front-passenger knee bag. the following display messages must not appear in the multifunction display: Front Passenger Airbag Enabled See Operator's Manual or Front Passenger Airbag Disabled See Operator's Manual. Wait for a period of at least 60 seconds until the necessary system checks have been completed. Make sure that the display messages do not appear in the multifunction display. If these conditions are fulfilled, the front-passenger seat can be occupied again. Whether the multifunction lamp remains lit or goes out depends on how OCS classifies the occupant.

Display messages	Possible causes/consequences and ► Solutions
	If the conditions are not fulfilled, the system is not operating correctly.
	► Visit a qualified specialist workshop immediately.

If the matter performing the above corrective steps, do not have any children twelve years old and under and other small individuals use the front-passenger seat until the system has been repaired.

/s	Display messages	Possible causes/consequences and Solutions
On-board computer and displays	Front Passenger Airbag Disabled	The front-passenger air bag and front-passenger knee bag are deactivated during the journey, although:
	See Operator's Manual	• an adult or
		 a person larger than a certain size is occupying the front- passenger seat.
		If additional forces are applied to the seat, the system may interpret the occupant's weight as lower than it actually is.
d co		 Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.
boar		Apply the parking brake.Switch the ignition off.
Ę		Have the occupant get out of the vehicle.
0		Keep the seat unoccupied, close the front-passenger door and switch on the ignition.
		Observe the reserve $\log \log \log$
		 Seat unoccupied and ignition switched on: the main lit. When the indicator lamp is on, OCS (▷ page 42) has deactivated the front-passenger air bag and front-passenger knee bag. the following display messages must not appear in the
		multifunction display: Front Passenger Airbag Enabled See Operator's Manual or Front Passenger Airbag Disabled See Operator's Manual.
		Wait for a period of at least 60 seconds until the necessary system checks have been completed.
		Make sure that the display messages do not appear in the multifunction display.
		If these conditions are fulfilled, the front-passenger seat can be occupied again. Whether the reaction of the indicator lamp remains lit or goes out depends on how OCS classifies the occupant.
		If the conditions are not fulfilled, the system is not operating correctly.
		Visit a qualified specialist workshop immediately.

If the manager of the front-passenger seat even after performing the above corrective steps, do not have any passenger use the frontpassenger seat until the system has been repaired.

 Display messages about LEDs: This display message will only appear if all LEDs have failed. 		
Display messages	Possible causes/consequences and ► Solutions	
Check Left Cornering Light or Check Right Cornering Light	 The left or right-hand cornering light is defective. ► Check whether you are permitted to change the bulb yourself (▷ page 109). or ► Visit a qualified specialist workshop. 	
Check Left Low Beam or Check Right Low Beam	 The left or right-hand low-beam headlamp is defective. Check whether you are permitted to change the bulb yourself (▷ page 109). or Visit a qualified specialist workshop. 	
Check Rear Left Turn Signal or Check Rear Right Turn Signal	 The rear left-hand or rear right-hand turn signal is defective. ► Check whether you are permitted to change the bulb yourself (▷ page 109). or ► Visit a qualified specialist workshop. 	
Check Front Left Turn Signal or Check Front Right Turn Signal	 The front left-hand or front right-hand turn signal is defective. ► Check whether you are permitted to change the bulb yourself (▷ page 109). or ► Visit a qualified specialist workshop. 	
Check Left Mirror Turn Signal or Check Right Mirror Turn Signal	 The turn signal in the left-hand or right-hand exterior mirror is defective. ▶ Check whether you are permitted to change the bulb yourself (▷ page 109). or ▶ Visit a qualified specialist workshop. 	

Lights

Display messages	Possible causes/consequences and Solutions
· ☆ Check Center Brake Lamp	 The high-mounted brake lamp is faulty. ► Check whether you are permitted to change the bulb yourself (▷ page 109). or ► Visit a qualified specialist workshop.
· . Check Left Brake Lamp or Check Right Brake Lamp	 The left or right-hand brake lamp is defective. Check whether you are permitted to change the bulb yourself (▷ page 109). or Visit a qualified specialist workshop.
Check Left Tail and Brake Lamps or Check Right Tail and Brake Lamps	 The left or right-hand tail lamp/brake lamp is defective. Check whether you are permitted to change the bulb yourself (▷ page 109). or Visit a qualified specialist workshop.
Check Left High Beam or Check Right High Beam	 The left or right-hand high beam is defective. Check whether you are permitted to change the bulb yourself (▷ page 109). or Visit a qualified specialist workshop.
ेक्टे License Plate Lamp	 The license plate lamps are faulty. ► Check whether you are permitted to change the bulb yourself (▷ page 109). or ► Visit a qualified specialist workshop.
Check Left Fog Lamp or Check Right Fog Lamp	 The left-hand or right-hand front fog lamp is defective. Check whether you are permitted to change the bulb yourself (▷ page 109). or Visit a qualified specialist workshop.

Display messages	Possible causes/consequences and ► Solutions
Rear Fog Lamp	 The rear fog lamp is defective. ► Check whether you are permitted to change the bulb yourself (▷ page 109). or ► Visit a qualified specialist workshop.
Check Front Left Parking Lamp or Check Front Right Parking Lamp	 The front left or front right parking or standing lamp is defective. Check whether you are permitted to change the bulb yourself (▷ page 109). or Visit a qualified specialist workshop.
- 读 Backup Light	 The backup lamp is defective. Check whether you are permitted to change the bulb yourself (▷ page 109). or Visit a qualified specialist workshop.
Check Front Left Sidemarker Lamp or Check Front Right Sidemarker Lamp	 The left or right front side marker lamp is defective. Check whether you are permitted to change the bulb yourself (▷ page 109). or Visit a qualified specialist workshop.
Check Rear Left Sidemarker Lamp or Check Rear Right Sidemarker Lamp	 The rear left or right side marker lamp is defective. Check whether you are permitted to change the bulb yourself (▷ page 109). or Visit a qualified specialist workshop.
Check Left Daytime Running Light or Check Right Daytime Running Light	 The left or right-hand daytime running lamp is defective. Check whether you are permitted to change the bulb yourself (▷ page 109). or Visit a qualified specialist workshop.
Active Headlamps Inoperative	The active light function is defective.Visit a qualified specialist workshop.

Check Coolant

MARNING

Operator's Manual

Level See

Display messages	Possible causes/consequences and ► Solutions
· . Malfunction See Operator's Manual	The exterior lighting is defective.Visit a qualified specialist workshop.
· . AUTO Lamp Function Inoperative	The light sensor is defective.▶ Visit a qualified specialist workshop.
्र्क् Switch Off Lights	The lights are still switched on when you leave the vehicle. A warning tone also sounds. ► Turn the light switch to A or Auto.
Engine	
Display messages	Possible causes/consequences and ► Solutions
Check Coolant	The coolant level is too low.Add coolant, observing the warning notes when doing so

Do not spill antifreeze on hot engine parts. Antifreeze contains ethylene glycol which may burn if it comes into contact with hot engine parts. You could be seriously burned.

▶ If coolant needs to be added more often than usual, have the

engine coolant system checked at a qualified specialist

(⊳ page 262).

workshop.

I The coolant level is too low. Avoid making long journeys with too little coolant in the cooling system. The engine will otherwise be damaged.

The display messages and the corresponding symbol that indicate that the coolant level is too low must not be ignored.

Display messages	Possible causes/consequences and ► Solutions
₩	 The engine fan is defective. At coolant temperatures under 248 °F(120 °C), drive to the next qualified specialist workshop. Avoid subjecting the engine to heavy loads, e.g. driving in mountainous terrain, and stop-and-go traffic.
Coolant Stop car, switch engine off	 The coolant is too hot. Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions. Make sure that the air supply to the engine radiator is not blocked, e.g. by snow, slush or ice. Wait until the display message disappears before restarting the engine. Otherwise, the engine could be damaged. Pay attention to the coolant temperature display. If the temperature increases again, visit a qualified specialist workshop immediately.

Driving when your engine is overheated can cause some fluids which may have leaked into the engine compartment to catch fire. You could be seriously burned.

Steam from an overheated engine can cause serious burns which can occur just by opening the engine hood. Stay away from the engine if you see or hear steam coming from it.

Stop the vehicle in a safe location away from other traffic. Turn off the engine, get out of the vehicle and do not stand near the vehicle until the engine has cooled down.

If the coolant temperature is over 248 °F (120 °C), do not continue driving. The engine will otherwise be damaged.

S	Display messages	Possible causes/consequences and Solutions
On-board computer and displays		 The battery is not being charged. Possible causes are: a defective alternator a torn poly-V-belt a malfunction in the electronics Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions. Open the hood. Check whether the poly-V-belt is torn. If the poly-V-belt is torn: Do not continue driving. The engine could otherwise overheat. Consult a qualified specialist workshop. If the poly-V-belt is not damaged: Visit a qualified specialist workshop.
	Check Engine Oil At Next Refueling	 The engine oil level has dropped to the minimum level. A warning tone also sounds. Check the oil level when next refueling, at the latest (▷ page 261). If necessary, add engine oil (▷ page 262). Have the engine checked at a qualified specialist workshop if engine oil needs to be added more often than usual.

Information on approved engine oils can be obtained from any qualified specialist workshop or on the Internet at http://www.mbusa.com (USA only).

The oil level is too low. Avoid long journeys with too little engine oil. There is a risk of engine damage.

The display messages and the corresponding symbol that indicate that the oil level is too low must not be ignored.

Display messages	Possible causes/consequences and Solutions
Fuel Level	The fuel level has dropped into the reserve range.▶ Refuel at the nearest gas station.
	There is only a very small amount of fuel in the fuel tank.▶ Refuel at the nearest gas station without fail.
Gas Cap Loose	The fuel system pressure is too low. The fuel filler cap is not closed correctly or the fuel system is leaking.► Check that the fuel filler cap is correctly closed.
	If the fuel filler cap is not correctly closed:
	► Close the fuel filler cap.
	If the fuel filler cap is correctly closed:
	 Visit a qualified specialist workshop.

Driving systems	
Display messages	Possible causes/consequences and Solutions
Attention Assist: Drowsiness Detected	 Based on specific criteria, ATTENTION ASSIST has determined that the driver is tired or paying less attention. A warning tone also sounds. If necessary, take a break. During long journeys, take regular breaks in good time so you get enough rest.
Attention Assist Inoperative	ATTENTION ASSIST has failed.Visit a qualified specialist workshop.
HOLD	 The HOLD function is deactivated. the vehicle is skidding. A warning tone also sounds. ▶ Reactivate the HOLD function later (▷ page 168).
	 The HOLD function is deactivated. When the brake pedal is firmly depressed, an activation condition is not fulfilled. A warning tone also sounds. ▶ Check the activation conditions for the HOLD function (▷ page 168).

Display messages	Possible causes/consequences and Solutions
Radar Sensors Deactivated See Operator's Manual	 The radar sensor system is deactivated. ▶ Switch on the radar sensor system (▷ page 194).
Parking Guidance Inoperative	 Parking Guidance is malfunctioning (▷ page 173). ▶ Restart the engine. If the display message continues to be displayed: ▶ Visit a qualified specialist workshop.
Parking Guidance Canceled	 Parking Guidance is deactivated. Possible causes are: the vehicle is skidding. the sensors are dirty. a malfunction has occurred. A warning tone also sounds. Reactivate Parking Guidance later (▷ page 173). If the parking space symbol does not appear in the multifunction display at speeds below 19 mph (30 km/h): Clean the sensors (▷ page 269). Restart the engine. If the parking space symbol still does not appear in the multifunction display at speeds below 19 mph (30 km/h): Visit a qualified specialist workshop.
	 Parking Guidance has been deactivated because you are no longer following the recommended path. ▶ Park again and, while doing so, observe the display messages in the multifunction display.
Parking Guidance Parking Guidance Finished	The vehicle is parked. A warning tone also sounds. The display message disappears automatically.
DISTRONIC PLUS Off	DISTRONIC PLUS has been deactivated (\triangleright page 158). If it was deactivated automatically, a warning tone also sounds.
DISTRONIC PLUS Now Available	DISTRONIC PLUS is operational again after having been temporarily unavailable. You can now reactivate DISTRONIC PLUS (> page 158).

Display messages	Possible causes/consequences and ► Solutions
Display messages DISTRONIC PLUS Currently Unavailable See Operator's Manual	 DISTRONIC is deactivated and temporarily inoperative. Possible causes are: the DISTRONIC PLUS cover in the radiator trim is dirty function is impaired due to heavy rain or snow. the sensors in the bumpers are dirty. the radar sensor system is temporarily inoperative, e.g. due to electromagnetic radiation emitted by nearby TV or radio stations or other sources of electromagnetic radiation. the system is outside the operating temperature range. the on-board voltage is too low. A warning tone also sounds. If the display message does not disappear: Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Apply the electric parking brake. Clean the DISTRONIC PLUS cover in the radiator trim (▷ page 269).
	 ► Clean the bumpers (▷ page 269). ► Restart the engine. If the system detects that the sensors are fully operational, the display message disappears. DISTRONIC is operational again.
DISTRONIC PLUS Inoperative	 DISTRONIC PLUS is defective. BAS PLUS (Brake Assist PLUS) and PRE-SAFE[®] Brake may be inoperative as well. A warning tone also sounds. Visit a qualified specialist workshop.
DISTRONIC PLUS Passive	You have depressed the accelerator pedal. DISTRONIC PLUS is no longer controlling the speed of the vehicle. ► Remove your foot from the accelerator pedal.
DISTRONIC PLUS	 An activation condition for DISTRONIC PLUS is not fulfilled. ▶ Check the activation conditions for DISTRONIC PLUS (▷ page 158).

Display messages	Possible causes/consequences and Solutions
Cruise Control Inoperative	Cruise control is defective.A warning tone also sounds.► Visit a qualified specialist workshop.
Cruise Control mph	 A condition for activating cruise control has not been fulfilled. You have tried to store a speed below 20 mph (30 km/h), for example. If conditions permit, drive faster than 20 mph (30 km/h) and store the speed. Check the activation conditions for cruise control
	 Check the activation conditions for cruise control (▷ page 156).

Tires

On-board computer and displays

MARNING №

Do not drive with a flat tire. A flat tire affects the ability to steer or brake the vehicle. You may lose control of the vehicle. Continued driving with a flat tire will cause excessive heat build-up and possibly a fire.

∧ WARNING

Follow recommended tire inflation pressures.

Do not underinflate tires. Underinflated tires wear excessively and/or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.

Display messages	Possible causes/consequences and ► Solutions
Tire pressures will be displayed after driving a few minutes	 The tire pressure monitor is measuring the tire pressure. Drive on. The tire pressures appear in the multifunction display after you have been driving for a few minutes.
Tire Press. Monitor Inoperative	The tire pressure monitor is faulty.► Visit a qualified specialist workshop.
Tire Press. Monitor Inoperative No	The wheels mounted do not have a suitable tire pressure sensor. The tire pressure monitor is deactivated.
Wheel Sensors	 Mount wheels with suitable tire pressure sensors. The tire pressure monitor is activated automatically after driving for a few minutes.

Display messages	Possible causes/consequences and ► Solutions
Check Tires	 ▲ Risk of accident The tire pressure in one or more tires has dropped significantly. The wheel position is displayed in the multifunction display. A warning tone also sounds. Stop the vehicle without making any sudden steering or braking maneuvers. Pay attention to the traffic conditions as you do so. Correct the tire pressure (▷ page 301). If necessary, change a wheel (▷ page 315).
Caution Tire Malfunction	 ▲ Risk of accident The tire pressure in one or more tires has dropped suddenly. The wheel position is shown in the multifunction display. ▶ Stop the vehicle without making any sudden steering or braking maneuvers. Pay attention to the traffic conditions as you do so. ▶ If necessary, change a wheel (▷ page 315).
Correct Tire Pressure	 The tire pressure is too low in at least one of the tires, or the tire pressure difference between the wheels is too great. Check the tire pressures at the next opportunity. If necessary, correct the tire pressure (▷ page 301). Restart the tire pressure monitor (▷ page 303).
TirePress. Sensor(s)Missing	 There is no signal from the tire pressure sensor of one or several wheels. The pressure of the affected tire is not displayed in the multifunction display. Have the faulty tire pressure sensor replaced at a qualified specialist workshop.
Tire Press. Monitor Currently Unavail.	 Due to a source of radio interference, no signals can be received from the wheel sensors. The tire pressure monitor is temporarily malfunctioning. ▶ Drive on. The tire pressure monitor restarts automatically as soon as the problem has been solved.
Tire Press. Warning Caution Tire Malfunction	 ▲ Risk of accident The tire pressure in one or more tires has dropped suddenly. A warning tone also sounds. ▶ Stop the vehicle without making any sudden steering or braking maneuvers. Pay attention to the traffic conditions as you do so. ▶ If necessary, change a wheel (▷ page 315).

On-board computer and displays

Display messages	Possible causes/consequences and Solutions
Check Tire Pressure	 Risk of accident The tire pressure in one or more tires has dropped significantly. Stop the vehicle without making any sudden steering or braking maneuvers. Pay attention to the traffic conditions as you do so. If necessary, change a wheel (> page 315). Check the tire pressure. If necessary, correct the tire pressure (> page 301).
Correct Tire Pressure	 The tire pressure is too low in at least one of the tires, or the tire pressure difference between the wheels is too great. ▶ Check the tire pressures at the next opportunity. If necessary, correct the tire pressure (▷ page 301).
Vehicle	
Display messages	Possible causes/consequences and ► Solutions
Shift to 'P' or 'N', to Start Engine	You have attempted to start the engine with the transmission in position R or D . ► Shift the transmission to position P or N .
P Shift to 'P'	 A malfunction has occurred while the HOLD function or DISTRONIC PLUS is active. A tone may also sound at regular intervals. If you attempt to lock the vehicle, the tone becomes louder. You cannot start the engine. Shift the transmission to position P. You can restart the engine.
	The trunk lid is open.▶ Close the trunk lid.
	 Risk of accident The hood is open. Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Apply the electric parking brake.

► Close the hood.

At least one door is open.

► Close all the doors.

On-board computer and displays

Display messages	Possible causes/consequences and ► Solutions
Trunk Partition Open	The trunk partition is open.▶ Close the trunk partition (▷ page 85).
Power Steering Malfunction See Operator's Manual	 Risk of accident The power steering is malfunctioning. You will need to use more force to steer. A warning tone also sounds. Check whether you are able to apply the extra force required. If you are able to steer safely: carefully drive on to a qualified specialist workshop. If you are unable to steer safely: do not drive on. Contact the nearest qualified specialist workshop.
Phone No Service	 Your vehicle is outside the network provider's transmitter/ receiver range. ▶ Wait until the mobile phone operational readiness symbol appears in the multifunction display.
Decrease Speed	 You wanted to open the roof while the vehicle was in motion. Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Open the roof (▷ page 83).
Vario-Roof Lowering	 The roof is not fully opened or closed. The hydraulics are depressurized. ▶ Fully open or close the roof (▷ page 83).
Open/Close Vario- Roof Completely	 The roof is not locked. Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Push or pull the roof switch (▷ page 83) until the roof is fully open or closed.
Vario-Roof in Operation Please Wait	The on-board voltage is too low.▶ Start the engine.

Display messages	Possible causes/consequences and Solutions
	 The roof has been opened and closed several times in a row. The roof drive has been switched off automatically for safety reasons. You can open and close the roof again after approximately 10 minutes. ▶ Switch off the ignition and turn it back on. ▶ Repeat the opening or closing procedure (▷ page 83).
Check Washer Fluid	 The washer fluid level in the washer fluid reservoir has dropped below the minimum. ► Add washer fluid (> page 263).
SmartKey	
Display messages	Possible causes/consequences and Solutions
Key Does Not Belong to Vehicle	You have put the wrong SmartKey in the ignition lock. ► Use the correct SmartKey.
Take Your Key from Ignition	The SmartKey is in the ignition lock.▶ Remove the SmartKey.
Obtain a New Key	The SmartKey needs to be replaced.Visit a qualified specialist workshop.
Replace Key Battery	The batteries of the KEYLESS-GO key are discharged.▶ Change the batteries (▷ page 71).
Don't Forget Your Key	The display message is shown for a maximum of 60 seconds and is only a reminder. You have opened the driver's door with the engine switched off. The KEYLESS-GO key is not in the ignition lock.

The KEYLESS-GO key is not in the ignition lock.

▶ Remember to take the KEYLESS-GO key with you when you leave the vehicle.

Display messages	Possible causes/consequences and Solutions
Key Not Detected(red display message)	 The KEYLESS-GO key is not in the vehicle. A warning tone also sounds. If the engine is switched off, you can no longer lock the vehicle centrally or start the engine. Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Apply the electric parking brake. Locate the KEYLESS-GO key.
	 The KEYLESS-GO key is not detected while the engine is running because there is interference from a strong source of radio waves. A warning tone also sounds. Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Apply the electric parking brake. Operate the vehicle with the SmartKey in the ignition lock.
Key Not Detected(White display message)	 The KEYLESS-GO key cannot be detected at present. Change the location of the key with the KEYLESS-GO functions in the vehicle. If the KEYLESS-GO key is still not detected: Operate the vehicle with the SmartKey in the ignition lock.
Key Detect'd In Vehicle	 The KEYLESS-GO key has been detected inside the vehicle during locking. ▶ Remove the KEYLESS-GO key from the vehicle.
Remove 'Start' Button and Insert Key	 KEYLESS-GO is temporarily malfunctioning or is defective. A warning tone also sounds. Insert the SmartKey into the ignition lock and turn it to the desired position. Visit a qualified specialist workshop.
Close Doors to Lock Vehicle	At least one door is open. A warning tone also sounds.▶ Close all doors and lock the vehicle again.

	Warning and indicato	r lamps in the instrument cluster
•	Seat belts	
	Problem	Possible causes/consequences and Solutions
	After starting the engine, the red seat belt warning lamp lights up for six seconds.	 The seat belt warning lamp reminds the driver and front passenger to fasten their seat belts. ▶ Fasten your seat belt (▷ page 48).
	After starting the engine, the red seat belt warning lamp lights up. In addition, a warning tone sounds for up to six seconds.	 ▲ Risk of injury The driver's seat belt is not fastened. ▶ Fasten your seat belt (▷ page 48). The warning tone ceases.
	The red seat belt warning lamp lights up after the engine starts, as soon as the driver's	 ▲ Risk of injury The driver or front passenger has not fastened their seat belt. ▶ Fasten your seat belt (▷ page 48). The warning lamp goes out.
or the front-passeng door is closed.	or the front-passenger door is closed.	Risk of injury There are objects on the front-passenger seat. Remove the objects from the front-passenger seat and stow

- Remove the objects from the front-passenger seat and stow them in a secure place.
 - The warning lamp goes out.

Problem	Possible causes/consequences and Solutions
The red seat belt warning lamp flashes and an intermittent audible warning sounds.	 ▲ Risk of injury The driver or front passenger has not fastened their seat belt. In addition, you are driving faster than 15 mph (25 km/h) or you have briefly driven faster than 15 mph (25 km/h). ▶ Fasten your seat belt (▷ page 48). The warning lamp goes out and the intermittent warning tone ceases.
	Risk of injury There are objects on the front-passenger seat. In addition, you are driving faster than 15 mph (25 km/h) or you have briefly driven faster than 15 mph (25 km/h).
	 Remove the objects from the front-passenger seat and stow them in a secure place. The warning lamp goes out and the intermittent warning tone ceases.

Safety systems

Problem	Possible causes/consequences and ► Solutions
(USA only) (D) (Canada only) The red brake system warning lamp comes on while the engine is running. A warning tone also sounds.	 Risk of accident There is not enough brake fluid in the brake fluid reservoir. Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances. Apply the electric parking brake. Consult a qualified specialist workshop immediately. Observe the additional display messages in the multifunction display. Do not add brake fluid. This does not correct the malfunction.

Driving with the brake warning lamp illuminated can result in an accident. Have your brake system checked immediately if the brake warning lamp stays on. Do not add brake fluid before checking the brake system.

Overfilling the brake fluid reservoir can result in spilling brake fluid on hot engine parts and the brake fluid catching fire. You can be seriously burned.

/s	Problem	Possible causes/consequences and Solutions
On-board computer and displays	The yellow ABS warning lamp is lit while the engine is running.	 Risk of accident ABS (Anti-lock Brake System) is deactivated due to a malfunction. BAS (Brake Assist), BAS PLUS, ESP[®] (Electronic Stability Program), PRE-SAFE[®] Brake, the HOLD function and hill start assist are therefore also deactivated, for example. The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example. ATTENTION ASSIST is deactivated. Observe the additional display messages in the multifunction display. Drive on carefully. Visit a qualified specialist workshop.
	The yellow ABS warning lamp is lit while the engine is running.	 Risk of accident ABS is temporarily unavailable. BAS, BAS PLUS, ESP[®], EBD (electronic brake force distribution), PRE-SAFE[®] Brake, the HOLD function, hill start assist are therefore also deactivated, for example. Self-diagnosis is not yet complete or the on-board voltage may be insufficient, for example. The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example. ATTENTION ASSIST is deactivated. Carefully drive a short distance on a suitable stretch of road, making slight steering movements at a speed above 12 mph (20 km/h). The functions mentioned above are available again when the warning lamp goes out.
		 If the warning lamp is still on: Observe the additional display messages in the multifunction display. Drive on carefully. Visit a qualified specialist workshop.

Problem	Possible causes/consequences and Solutions
The yellow ABS warning lamp is lit while the engine is running. A warning tone also sounds.	 Risk of accident EBD is faulty. Therefore, ABS, BAS, BAS PLUS, ESP[®], PRE-SAFE[®], PRE-SAFE[®] Brake, the HOLD function and hill start assist are unavailable, for example. The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example. ATTENTION ASSIST is deactivated. Observe the additional display messages in the multifunction display. Drive on carefully. Visit a qualified specialist workshop.
BRAKE (USA only) (D) (Canada only) (D) (Canada only) (C) (Canada only) (C) (Canada only) (C) (C) (C) (C) (C) (C) (C) (C) (C) (C)	 Risk of accident ABS and ESP[®] are faulty. Therefore, BAS, BAS PLUS, EBD, PRE-SAFE[®] Brake, the HOLD function and hill start assist are also unavailable, for example. The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example. ATTENTION ASSIST is deactivated. Observe the additional display messages in the multifunction display. Drive on carefully. Visit a qualified specialist workshop.
The yellow ESP [®] warning lamp flashes while the vehicle is in motion.	 Risk of accident ESP[®] or traction control has intervened because there is a risk of skidding or at least one wheel has started to spin. Cruise control or DISTRONIC PLUS is deactivated. When pulling away, only depress the accelerator pedal as far as necessary. Ease off the accelerator pedal while the vehicle is in motion. Adapt your driving style to suit the road and weather conditions. Do not deactivate ESP[®]. For exceptions, see: (> page 58).

Problem	Possible causes/consequences and ► Solutions
The yellow ESP® OFF warning lamp is lit while the engine is running.	 Risk of accident ESP[®] is deactivated. ESP[®] will not stabilize the vehicle if it starts to skid or if a wheel starts to spin. Reactivate ESP[®]. For exceptions, see: (> page 58). Adapt your driving style to suit the road and weather conditions. If ESP[®] cannot be activated: Have ESP[®] checked at a qualified specialist workshop.
SPORT AMG vehicles only: The yellow SPORT handling mode warning lamp is lit while the engine is running.	 Risk of accident SPORT handling mode is activated. ESP[®] only stabilizes the vehicle in extreme situations. ESP[®] intervention may not be able to provide sufficient assistance in such situations and the vehicle may start to skid. Reactivate ESP[®]. Exceptions: (> page 58). If ESP[®] cannot be activated: Have ESP[®] checked at a qualified specialist workshop.
The yellow ESP [®] and ESP [®] OFF warning lamps are lit while the engine is running.	 Risk of accident ESP[®], BAS, BAS PLUS, PRE-SAFE[®] Brake, the HOLD function and hill start assist are not available due to a malfunction. ESP[®] will not stabilize the vehicle if it starts to skid or if a wheel starts to spin. The brake system continues to function normally, but without the functions listed above. ATTENTION ASSIST is deactivated. Observe the additional display messages in the multifunction display. Drive on carefully. Visit a qualified specialist workshop.

On-board computer and displays

Problem	Possible causes/consequences and ► Solutions
The yellow ESP [®] and ESP [®] OFF warning lamps are lit while the engine is running.	 Risk of accident ESP[®], BAS, the HOLD function and hill start assist are temporarily unavailable. BAS PLUS and PRE-SAFE[®] Brake may also have failed. ESP[®] will not stabilize the vehicle if it starts to skid or if a wheel starts to spin. Self-diagnosis is not yet complete. The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example. ATTENTION ASSIST is deactivated. Carefully drive a short distance on a suitable stretch of road, making slight steering movements at a speed above 12 mph (20 km/h). The functions mentioned above are available again when the warning lamp goes out. If the warning lamp is still on: Observe the additional display messages in the multifunction display. Drive on carefully. Visit a qualified specialist workshop.
 (USA only) (D) (Canada only) The red indicator lamp for the electric parking brake flashes and/or the yellow (D) warning lamp for the electric parking brake lights up. 	 The electric parking brake is temporarily malfunctioning or defective. ► Observe the additional display messages in the multifunction display.
The red SRS warning lamp is lit while the engine is running.	 Risk of injury The restraint systems are malfunctioning. The air bags or ETDs may either be triggered unintentionally or, in the event of an accident, not be triggered at all. Drive on carefully.

- Drive on carefully.
- ► Visit a qualified specialist workshop immediately.

MARNING

In the event a malfunction of the SRS is indicated as outlined above, the SRS may not be operational.

For your safety, we strongly recommend that you contact an authorized Mercedes-Benz Center immediately to have the system checked. Otherwise the SRS may not be activated when needed in an accident, which could result in serious or fatal injury, or it might deploy unexpectedly and unnecessarily which could also result in injury.

Engine Problem Possible causes/consequences and Solutions Щ. There may be a malfunction, for example: The yellow Check • in the engine management Engine warning lamp • in the fuel injection system lights up while the · in the exhaust system engine is running. • in the ignition system • in the fuel system The emission limit values may be exceeded and the engine may be running in emergency mode. ▶ Have the vehicle checked as soon as possible at a qualified specialist workshop. 1 In some states, you must immediately visit a qualified specialist workshop as soon as the yellow Check Engine warning lamp lights up. This is due to the legal requirements in effect in these states. If in doubt, check whether such legal regulations apply in the state in which you are currently driving. The fuel system pressure is too low. The fuel filler cap is not closed correctly or the fuel system is leaking. The yellow reserve fuel warning lamp flashes ► Observe the additional display messages in the multifunction while the vehicle is in display. motion. In addition, Check that the fuel filler cap is correctly closed. the **T** Check Engine ► If the fuel filler cap is not correctly closed: close the fuel filler warning lamp may light cap. up. ▶ If the fuel filler cap is closed: visit a qualified specialist workshop. The fuel level has dropped into the reserve range. The yellow reserve fuel Refuel at the nearest gas station. warning lamp lights up while the engine is running.

Problem	Possible causes/consequences and ► Solutions
علیہ The red coolant	The temperature sensor for the coolant temperature gauge is defective.
warning lamp lights up while the engine is running and the coolant temperature gauge is at the start of the scale.	The coolant temperature is no longer being monitored. There is a risk of engine damage if the coolant temperature is too high.
	 Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions. Do not continue driving under any circumstances. Apply the electric parking brake. Consult a qualified specialist workshop.

	Problem	Possible causes/consequences and Solutions
	The red coolant warning lamp comes on while the engine is running.	 The coolant level is too low. If the coolant level is correct, the airflow to the engine radiator may be blocked or the electric engine radiator fan may be malfunctioning. The coolant is too hot and the engine is no longer being cooled sufficiently. Observe the additional display messages in the multifunction display. Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions. Allow the engine and coolant to cool. Check the coolant level and add coolant (▷ page 262). Observe the warning notes. If you need to add coolant more often than usual, have the engine coolant system checked. Make sure that the air supply to the engine radiator is not blocked, e.g. by snow, slush or ice. At coolant temperatures under 248 °F(120 °C), drive to the next qualified specialist workshop. Avoid subjecting the engine to heavy loads, e.g. driving in mountainous terrain, and start/stop traffic.
	The red coolant warning lamp comes on while the engine is running. A warning tone also sounds.	 The coolant temperature has exceeded 248 °F (120 °C). The airflow to the engine radiator may be blocked or the coolant level may be too low. The engine is not being cooled sufficiently and may be damaged. Observe the additional display messages in the multifunction display. Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions. Allow the engine and coolant to cool. Check the coolant level and add coolant (▷ page 262). Observe the warning notes. If you need to add coolant more often than usual, have the engine coolant system checked. Make sure that the air supply to the engine radiator is not blocked, e.g. by snow, slush or ice. At coolant temperatures under 248 °F(120 °C), drive to the next qualified specialist workshop. Avoid subjecting the engine to heavy loads, e.g. driving in mountainous terrain, and start/stop traffic.

Driving systems

Driving when your engine is overheated can cause some fluids which may have leaked into the engine compartment to catch fire. You could be seriously burned.

Steam from an overheated engine can cause serious burns which can occur just by opening the engine hood. Stay away from the engine if you see or hear steam coming from it.

Stop the vehicle in a safe location away from other traffic. Turn off the engine, get out of the vehicle and do not stand near the vehicle until the engine has cooled down.

If the coolant temperature is over 248 °F (120 °C), do not continue driving. The engine will otherwise be damaged.

Driving systems		
Problem	Possible causes/consequences and Solutions	
The red distance warning lamp lights up while the vehicle is in motion. A warning tone also sounds.	 ▲ Risk of accident You are approaching a vehicle or a stationary obstacle in your line of travel at too high a speed. ▶ Be prepared to brake immediately. ▶ Pay careful attention to the traffic situation. You may have to brake or take evasive action. More information about DISTRONIC PLUS (▷ page 158) and PRE-SAFE[®] Brake (▷ page 62). 	

	Tires		
1	Problem	Possible causes/consequences and Solutions	
	(1) USA only: The yellow tire pressure monitor warning lamp (pressure loss/ malfunction) is lit. Canada only: The yellow tire pressure monitor warning lamp (pressure loss) is lit.	 ▲ Risk of accident The tire pressure monitor has detected a loss of pressure in at least one of the tires. ▶ Stop the vehicle without making any sudden steering or braking maneuvers. Pay attention to the traffic conditions as you do so. ▶ Observe the additional display messages in the multifunction display. ▶ Check the tire pressure. If necessary, correct the tire pressure (▷ page 301). ▶ If necessary, change a wheel (▷ page 315). 	
	(1) USA only: The yellow tire pressure monitor warning lamp (pressure loss/ malfunction) flashes for approximately one minute and then	 The tire pressure monitor is faulty. Observe the additional display messages in the multifunction display. Visit a qualified specialist workshop. 	

remains lit.

Each tire, including the spare (if provided), should be checked at least once every two weeks when cold and inflated to the pressure recommended by the vehicle manufacturer on the Tire and Loading Information placard on the driver's side B-pillar or the tire pressure label on the inside of the fuel filler flap. If your vehicle has tires of a different size than the size indicated on the Tire and Loading Information placard or, if available, the tire pressure label, you should determine the proper tire pressure for those tires.

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure indicator lamp when one or more of your tires are significantly underinflated. Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly underinflated tire causes the tire to overheat and can lead to tire failure.

Underinflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability. Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if underinflation has not reached the level to trigger illumination of the TPMS low tire pressure indicator lamp. USA only:

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the indicator lamp will flash for

approximately one minute and then remain continuously illuminated. This sequence will be repeated every time the vehicle is started as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended.

TPMS malfunctions may occur for a variety of reasons, including the installation of incompatible replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly. Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

Useful information

This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.

 Please read the information on qualified specialist workshops (▷ page 23).

Stowage areas

Stowage compartments

Important safety notes

∧ WARNING

To help avoid personal injury during a collision or sudden maneuver, exercise care when storing objects in the vehicle. Put luggage or cargo in the trunk if possible.


Keep compartment lids closed. This will help to prevent stored objects from being thrown about and injuring vehicle occupants during

- braking
- vehicle maneuvers
- an accident

Stowage compartments in the front


Glove box

 The glove box flap contains brackets for coins, pens, and credit and service cards.



- ► **To open:** pull handle ① and open glove box flap ②.
- ► To close: fold glove box flap ② upwards until it engages.

The glove box can be locked and unlocked using the key (> page 68) or using the mechanical key.



- To lock: insert the mechanical key into the lock and turn it 90° clockwise to position
 2.
- ► To unlock: insert the mechanical key into the lock and turn it 90° counter-clockwise to position 1.

Eyeglasses compartment



► **To open:** press marking ①.

Stowage compartment in the center console



- ► To open: briefly press the lower section of cover ①.
- ► To remove the insert: pull the left-hand side of the insert up and out.
- To install the insert: press the insert into the housing.
- Depending on the vehicle equipment, there may be an ashtray in the center console instead of a storage compartment.


Stowage compartment in front of the armrest



► To open: slide cover ① back.

Stowage compartment under the armrest


- Depending on the vehicle's equipment, a 12 V socket, a USB socket, and an AUX IN connection or Media Interface are installed in the stowage compartment. A Media Interface is a universal interface for mobile audio equipment, e.g. for an iPod[®] or MP3 player (see the separate COMAND operating instructions).
- The stowage compartment can be locked and unlocked centrally using the SmartKey (▷ page 68).



► To open: press button ① and raise armrest ②.

Stowage and features

Stowage compartments in the doors



In the door trim panel, there is a ruffled pocket ② with a storage slot ①.

Stowage space in the rear

Stowage box in the rear wall between the seats

A ruffled pocket is located on the rear wall between the seats.



1 Ruffled pocket

Stowage pockets

MARNING ★

Storage bags are intended for storing lightweight items only.

Heavy objects, objects with sharp edges or fragile objects may not be transported in the storage bag. In an accident, during hard braking, or sudden maneuvers, they could be thrown around inside the vehicle and cause injury to vehicle occupants.

Storage bags cannot protect transported goods in the event of an accident.

Storage bags are located in the rear compartment on the driver's and front-passenger seat backrests.

Parcel nets

▲ WARNING

Parcel nets are intended for storing lightweight items only, such as road maps, mail, etc.


Heavy objects, objects with sharp edges, or fragile objects may not be transported in the parcel nets. In an accident, during hard braking, or sudden maneuvers, they could be thrown around inside the vehicle and cause injury to vehicle occupants.

Parcel nets cannot protect transported goods in the event of an accident.


Parcel nets are located in the front-passenger footwell and on the rear wall behind the driver's seat.

Reversible floor panel in the trunk

Using the flat side of the reversible floor panel will give you a level trunk. If you turn the reversible floor panel over, you can transport objects, for example a drinks crate, on it.



- ► To turn over: pull up reversible floor panel ② using strap ①.
- Turn over reversible floor panel (2) and reinstall it.



Attached to the reversible floor panel are two flexible straps (2) that you can use to secure objects, for example draft stop (3) when reversible floor panel (1) has been turned over.

Roof carrier

Important safety notes

This vehicle is not designed to transport items on the roof. Roof carriers and other devices which are mounted on the roof that have not been specifically approved for this model by Mercedes-Benz must not be used as they could damage the vehicle and the retractable hardtop (vario-roof).

At the time of going to print, Mercedes-Benz does not offer any roof carrier or other roof-installed devices for this model.

This vehicle is not designed to transport any items on the trunk lid or to allow luggage carriers or equipment of any kind to be installed to the trunk lid. Otherwise the vehicle and the retractable hardtop could be damaged.

Features

Cup holders

Important safety notes

MARNING

In order to help prevent spilling liquids on vehicle occupants and/or vehicle equipment, only use containers that fit into the cup holder. Use lids on open containers and do not fill containers to a height where the contents, especially hot liquids, could spill during braking, vehicle maneuvers, or in an accident. Liquids spilled on vehicle occupants may cause serious personal injury. Liquids spilled on vehicle equipment may cause damage not covered by the Mercedes-Benz Limited Warranty.

y cause cedes-Benz older closed. njury to you

When not in use, keep the cup holder closed. An open cup holder may cause injury to you or others when contacted during braking, vehicle maneuvers, or in an accident.

Keep in mind that objects placed in the cup holder may come loose during braking, vehicle maneuvers, or in an accident and be thrown around in the vehicle interior. Objects thrown around in the vehicle interior may cause an accident and/or serious personal injury.

Cup holder in the front-compartment center console

You can remove the cup holder insert for cleaning. Clean with clear, lukewarm water only.



- ► To open: slide cover ② back.
- ► To remove the insert: slide catch ① inwards on both sides in the direction of the arrow.
- ▶ Remove the cup holder insert upwards.
- To re-install the insert: place the insert in the stowage space.
- Slide catch ① outwards in the direction of the arrow until it engages.

Bottle holder

MARNING

Do not transport heavy, sharp-edged, or fragile bottles in the bottle holder.

In the event of an accident, the bottle holder cannot secure a bottle sufficiently. You and/ or vehicle occupants could be injured.

Make sure that any bottles weighing more than 0.5 kg that are stored in the bottle holder rest on the vehicle floor. The bottle holder could otherwise be damaged.

The bottle holder is designed for bottles with a capacity of 25 fl. oz. (0.7 l) up to 54 fl. oz. (1.5 l).

The bottle holder does not secure the bottles; it merely prevents them from tipping over.




- Press the outer edge of button ① and slide in the direction of the arrow until the bottle fits into the opening.
- Insert the bottle into the bottle holder.

Sun visors

Overview of sun visors

Do not use the vanity mirror while driving. Keep the vanity mirrors in the sun visors closed while the vehicle is in motion. Reflected glare can endanger you and others.



- 1 Mirror light
- Bracket
- ③ Retaining strip, e.g. for a car park ticket
- ④ Vanity mirror
- (5) Mirror cover
- When driving at high speeds with the side window or roof open:

If you have inserted a car park ticket into retaining strip ③, make sure that it is not blown away by the wind.

Vanity mirror in the sun visor

Mirror light (1) only functions if the sun visor is clipped into retainer (2) and mirror cover
(5) has been folded up.

Glare from the side

- ► Fold down the sun visor.
- ▶ Pull the sun visor out of retainer ②.
- ▶ Swing the sun visor to the side.
- Slide the sun visor forwards and back as required.

Ashtray

Ashtray in the front-compartment center console



- ► To open: press the lower area of cover ①. The cover opens.
- ► To remove the insert: lift insert ③ up ② and out.
- ► To re-install the insert: press insert ③ into the holder until it engages.

Cigarette lighter

MARNING

When leaving the vehicle, always remove the SmartKey from the ignition lock. Always take the SmartKey with you and lock the vehicle. Do not leave children unattended in the vehicle, even if they are secured in a child restraint system, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury. The children could:

- injure themselves on parts of the vehicle
- be seriously or fatally injured through excessive exposure to extreme heat or cold
- injure themselves or cause an accident with vehicle equipment that can be operated even if the SmartKey is removed from the ignition lock or removed from the vehicle, such as seat adjustment, steering wheel adjustment, or the memory function

If children open a door, they could injure other persons or get out of the vehicle and injure themselves or be injured by following traffic.

Do not expose the child restraint system to direct sunlight. The child restraint system's metal parts, for example, could become very hot, and the child could be burned on these parts.

MARNING

Never touch the heating element or sides of the lighter; they are extremely hot. Hold the knob only.

Make sure any children traveling with you do not injure themselves or start a fire with the hot cigarette lighter.



- ► Turn the SmartKey to position 2 in the ignition lock.
- To open: push the lower section of cover (1). The ashtray opens.
- Press in cigarette lighter (2).
 Cigarette lighter (2) will pop out automatically when the heating element is red-hot.

12 V sockets

Points to observe before use

If you are using all sockets in the vehicle, make sure that you do not exceed the maximum current draw of 55 A. Otherwise, you will overload the fuses.

The sockets can be used for accessories with a maximum draw of 180 W (15 A).


Accessories include such items as lamps or chargers for mobile phones.

If you use the sockets for long periods when the engine is switched off, the battery may discharge.

► Turn the SmartKey to position 1 in the ignition lock.

1 An emergency cut-out ensures that the on-board voltage does not drop too low. If the on-board voltage is too low, the power to the sockets is automatically cut. This ensures that there is sufficient power to start the engine.

Socket under the armrest



- ▶ Open the stowage space under the armrest (▷ page 243).
- ▶ Lift up the cover of socket ①.

On vehicles without ashtrays or lighters, there is an additional socket in the center console.

Socket in the front-compartment center console



► To open: push the lower section of cover (1).

The stowage compartment opens.

▶ Lift up the cover of socket ②.

mbrace

Important safety notes

A license agreement must exist in order to activate the mbrace service. Ensure that your system is activated and ready for use, and press the **()** MB Info call button to register. If any of the steps mentioned is not carried out, the system may not be activated.

If you have questions about the activation, contact one of the following telephone assistance services:

- USA: Mercedes-Benz Customer Assistance Center under 1-800-FOR-MERCedes (1-800-367-6372) or 1-888-990-9007
- Canada: Customer Service at 1-888-923-8367

Shortly after successfully registering with the mbrace service, a user ID and password will be sent to you by mail. You can use this password to log in to the mbrace section under "Owners Online" at http://www.mbusa.com¹⁵.

Stowage and features

The mbrace system is available if:

- it has been activated and is operational.
- the corresponding mobile phone network is available for transmitting data to the Customer Center.
- a service subscription is available.
- the starter battery is sufficiently charged.
- Determining the location of the vehicle on a map is only possible if there is sufficient GPS reception and the vehicle position can be forwarded to the Customer Center.

The mbrace system

The mbrace system provides different services, e.g.:

- automatic and manual emergency call
- Roadside Assistance call
- MB Info call

To adjust the volume during an mbrace call, proceed as follows:

Press the + or - button on the multifunction steering wheel.

or

 Use the volume controller of the audio system/COMAND.

You can find further information and a description of all available features under "Owners Online" at http://www.mbusa.com¹⁶.

System self-test

After you have switched on the ignition, the system carries out a self-diagnosis.

A malfunction in the system has been detected if one of the following conditions occurs:

- the indicator lamp in the SOS button does not light up during the system selfdiagnosis.
- the indicator lamp in the Set Roadside Assistance button does not light up during the system self-diagnosis.
- The indicator lamp in the Ci information button does not light up during selfdiagnosis of the system.
- the indicator lamp in the SOS button,
 Roadside Assistance button or witton com/inues to be lit red after the system self-diagnosis.
- The Tele Aid Inoperative or Tele Aid Not Activated message appears in the multifunction display after the system selftest.

If a malfunction is indicated as outlined above, the system may not operate as expected. In the event of an emergency, assistance must be summoned by other means.

Have the system checked at the nearest authorized Mercedes-Benz Center or contact the following service hotlines:

- USA: Mercedes-Benz Customer Assistance Center under 1-800-FOR-MERCedes(1-800-367-6372) or 1-888-990-9007
- Canada: Customer Service at 1-888-923-8367

Emergency call

Important safety notes

A license agreement must exist in order to activate the mbrace service. Ensure that your system is activated and ready for use, and press the **S** MB Info call button to register. If any of the steps mentioned is

not carried out, the system may not be activated.

If you have questions about the activation, contact one of the following telephone assistance services:

- USA: Mercedes-Benz Customer Assistance Center under 1-800-FOR-MERCedes (1-800-367-6372) or 1-888-990-9007
- Canada: Customer Service at 1-888-923-8367

An emergency call is dialed automatically if an air bag or Emergency Tensioning Device is triggered.

An mbrace emergency call that has been initiated automatically cannot be terminated by the customer.

An emergency call can also be initiated manually.

As soon as the emergency call has been initiated, the indicator lamp in the SOS button flashes. The Connecting Call message appears on the multifunction display.

The audio output is muted.

Once a connection has been established, the Call Connected message appears in the multifunction display.

All important information on the emergency is transmitted, for example:

- current location of the vehicle (as determined by the GPS system)
- vehicle identification number
- information on the type of emergency

Shortly after the emergency call has been initiated, a voice connection is automatically established between the Mercedes-Benz Customer Assistance Center and the vehicle occupants. If the vehicle occupants respond, the Mercedes-Benz Customer Assistance Center attempts to get more information on the emergency.

If there is no response from the vehicle occupants, an ambulance is immediately sent to the vehicle.

If the indicator lamp in the SOS button is flashing continuously and there was no voice connection to the Response Center established, then the mbrace system could not initiate an emergency call (e.g. the relevant cellular phone network is not available).

The message Call Failed appears in the multifunction display for approximately 10 seconds.

Should this occur, assistance must be summoned by other means.

Making an emergency call



- To initiate an emergency call manually: press cover (1) briefly to open it.
- Press SOS button (2) briefly. The indicator lamp in SOS button (2) flashes until the emergency call is concluded.
- Wait for a voice connection to the Mercedes-Benz Customer Assistance Center.
- ► After the emergency call is ended, close cover (1).

▲ WARNING

If you feel at any way in jeopardy when in the vehicle (e.g. smoke or fire in the vehicle, vehicle in a dangerous road location), please do not wait for voice contact after you have pressed the SOS button. Carefully leave the vehicle and move to a safe location. The Response Center will automatically contact local emergency officials with the vehicle's approximate location if they receive an automatic SOS signal and cannot make voice contact with the vehicle occupants.

Roadside Assistance button



Press and hold Roadside Assistance button ① for more than two seconds. This initiates a call to the Mercedes-Benz Customer Assistance Center. The indicator lamp in Roadside Assistance button ① flashes while the call is active. The Connecting Call message appears in the multifunction display. The audio output is muted.

If a connection can be established, the Call Connected message appears in the multifunction display.

If a cellular phone network is available and there is sufficient GPS reception, the mbrace system transmits data to the Mercedes-Benz Customer Assistance Center, for example:

- current location of the vehicle
- vehicle identification number
- The display of the audio system or COMAND shows that an mbrace call is active. During the call, you can change to the navigation menu by pressing the NAVI button on COMAND, for example. Voice output is not available.

A voice connection is established between the Mercedes-Benz Customer Assistance Center and the vehicle occupants.

Describe the type of assistance needed.

The Mercedes-Benz Customer Assistance Center either sends a qualified Mercedes-Benz technician or organizes for your vehicle to be transported to the nearest authorized Mercedes-Benz Center. You may be charged for services such as repair work and/or towing. Further details are available in your mbrace manual.

- 1 The mbrace system failed to initiate a Roadside Assistance call if:
 - the indicator lamp in Roadside Assistance button (1) is flashing continuously.
 - no voice connection to the Mercedes-Benz Customer Assistance Center was established.

This may be because the corresponding mobile phone network is not available.

The Call Failed message appears in the multifunction display.

► To end a call: press the button on the multifunction steering wheel.

or

 Press the corresponding button for ending a phone call on the audio system or on COMAND.

MB Info call button



Press and hold MB Info call button ① for more than two seconds.

This initiates a call to the Mercedes-Benz Customer Assistance Center. The indicator lamp in MB Info call button ① flashes while the connection is being established. The Connecting Call message appears in the multifunction display. The audio output is muted.

If a connection can be established, the Call Connected message appears in the multifunction display.

If a cellular phone network is available and there is sufficient GPS reception, the mbrace system transmits data to the Mercedes-Benz Customer Assistance Center, for example:

- current location of the vehicle
- vehicle identification number
- The display of the audio system or COMAND shows that an mbrace call is active. During the call, you can change to the navigation menu by pressing the NAVI button on COMAND, for example.

Voice output is not available.

A voice connection is established between the Mercedes-Benz Customer Assistance Center and the vehicle occupants. You can obtain information on how to operate your vehicle's systems, on the location of the nearest authorized Mercedes-Benz Center, and on further products and services offered by Mercedes-Benz USA.

Further details on the mbrace system can be found under **http://www.mbusa.com**¹⁷. Log in under "Owners Online".

The mbrace system failed to initiate an MB Info call if:

- the indicator lamp in MB Info call button (1) is flashing continuously.
- no voice connection to the Mercedes-Benz Customer Assistance Center was established.

This may be because the corresponding mobile phone network is not available.

The Call Failed message appears in the multifunction display.

► To end a call: press the button on the multifunction steering wheel.

or

Press the corresponding button for ending a phone call on the audio system or on COMAND.

Call priority

When service calls are active, e.g. Roadside Assistance or MB Info calls, an emergency call can still be initiated. In this case, an emergency call will take priority and override all other active calls.

The indicator lamp of the respective button flashes until the call is ended. An emergency call can only be terminated by the Mercedes-Benz Customer Assistance Center. All other calls can be ended by pressing the button on the multifunction steering wheel or the corresponding button for ending a telephone call on the audio system or on COMAND.

If an mbrace call is initiated, audio output is muted. The mobile phone is no longer connected to COMAND. However, if you want to use your mobile phone, we recommend that you do this only when the vehicle is stationary and in a safe location.

Downloading destinations

- Information on the components and operating principles of COMAND can be found in the separate COMAND operating instructions.
- You can only use the Destination Download function if the vehicle is equipped with a navigation system.

17 USA only.

Destination Download gives you access to a database with over 15 million points of interest (POIs)/important destinations that can be downloaded onto the navigation system of your vehicle. If you know the destination, you can download the address or obtain the location of points of interest (POIs)/important destinations in the surrounding area.

You are prompted to confirm route guidance to the address entered.

- ► Select Yes with the or buttons on COMAND.
- Press the w button on COMAND to confirm.

The system calculates the route and subsequently starts the route guidance with the address entered.

If you select N0, the address can be stored in the address book.

1 The Destination Download function is available if the corresponding mobile phone network is available and data transfer is possible.

Route Assistance

This service is part of the mbrace PLUS Package and cannot be purchased separately.

You can also use the Route Assistance function if your vehicle is not equipped with a navigation system.

Within the framework of this service, you receive a professional and reliable form of navigation support without having to leave your vehicle.

The customer service representative determines a suitable driving route based on your current vehicle position and the desired destination and guides you live through the current sections of the route.

Search & Send

"Search & Send" is a destination entry service. You can find further information on "Search & Send" in the separate COMAND operating instructions.

Vehicle remote opening

If you have unintentionally locked your vehicle (e.g. the SmartKey is still in the vehicle) and a replacement SmartKey is not available, the vehicle can be opened by a Mercedes-Benz Customer Assistance Center.

The vehicle can be opened remotely up to four days after the ignition was last switched off.

- Contact the following service hotlines:
 - USA: Mercedes-Benz Customer Assistance Center at 1-800-FOR-MERCedes (1-800-367-6372) or 1-888-990-9007
 - Canada: Customer Service at 1-888-923-8367

You will be asked for your password.

- Return to your vehicle at the time agreed upon with the Mercedes-Benz Customer Assistance Center.
- Pull on the trunk lid handle for at least 20 seconds until the indicator lamp in the SOS button (▷ page 249) flashes. The Connecting Call message appears on the multifunction display.

Alternatively, the vehicle can also be opened via the Internet or an iPhone in the "Owners Online" section using your ID number and password¹⁸.

• Vehicle remote unlocking is only possible if the corresponding mobile phone network is accessible.

The SOS button flashes and the **Connecting Call** message appears in the multifunction display to confirm that the command for vehicle remote unlocking has been received.

Stowage and features

If you pull on the trunk handle for more than 20 seconds before receiving authorization for remote unlocking, you must wait 15 minutes before you can pull on the trunk lid handle again.

Vehicle remote closing

If you forget to lock your vehicle but are no longer in the vicinity of the vehicle, it can be locked for you by the Mercedes-Benz Customer Assistance Center.

The vehicle can be locked remotely up to four days after the ignition was last switched off.

- Contact the following service hotlines:
 - USA: Mercedes-Benz Customer Assistance Center under 1-800-FOR-MERCedes(1-800-367-6372) or 1-888-990-9007
 - **Canada:** Customer Service at 1-888-923-8367 You will be asked for your PIN.

The next time you are in your vehicle and switch on the ignition, the Tele Aid: Doors Locked by Remote message appears in the multifunction display.

Alternatively, the vehicle can also be locked via the Internet or an iPhone in the "Owners Online" section using your ID number and password.

 The vehicle valet locking feature is available when the relevant mobile phone network is available and data connection is possible.

Stolen vehicle recovery service

If your vehicle has been stolen:

- Notify the police.
 The police will issue a numbered incident report.
- This number will be forwarded to the Mercedes-Benz Customer Assistance Center together with your PIN. The Mercedes-Benz Customer Assistance Center then attempts to locate the mbrace

system. The Mercedes-Benz Customer Assistance Center contacts you and the local law enforcement agency if the vehicle is located. However, only the law enforcement agency is informed of the location of the vehicle.

If the anti-theft alarm system is active for longer than 30 seconds, mbrace automatically informs the Mercedes-Benz Customer Assistance Center.

Garage door opener

Important safety notes

The HomeLink[®] garage door opener integrated in the rear-view mirror allows you to operate up to three different door and gate systems.

- Certain garage door drives are incompatible with the integrated garage door opener. If you have difficulty programming the integrated garage door opener, contact an authorized Mercedes-Benz Center or call one of the following telephone hotlines:
 - USA: Mercedes-Benz Customer Assistance Center at 1-800-FOR-MERCedes
 - Canada: Customer Service at 1-800-387-0100

Before programming the integrated remote control to a garage door opener or gate operator, make sure people and objects are out of the way of the device to prevent potential harm or damage. When programming a garage door opener, the door moves up or down. When programming a gate operator, the gate opens or closes.

Do not use the integrated remote control with any garage door opener that lacks safety stop and reverse features as required by U.S. federal safety standards (this includes any garage door opener model manufactured before April 1, 1982). A garage door that cannot detect an object - signaling the door to stop and reverse - does not meet current U.S. federal safety standards.

When programming a garage door opener, park vehicle outside the garage.

Do not run the engine while programming the integrated remote control. Inhalation of exhaust gas is hazardous to your health. All exhaust gas contains carbon monoxide (CO), and inhaling it can cause unconsciousness and possible death. All exhaust gas contains carbon monoxide (CO), and inhaling it can cause unconsciousness and possible death.

USA only:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and

2. this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

FCC ID: CB2HMIHL4

Canada only:

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

1. This device may not cause interference, and

2. this device must accept any interference received, including interference that may cause undesired operation of the device.

Any unauthorized modification to this device could void the user's authority to operate the equipment.


IC: 279B-HMIHL4

Programming the integrated garage door opener on the rear-view mirror

Programming

MARNING

Only press the button on the integrated garage door opener if there are no persons or objects present within the sweep of the garage door. Persons could otherwise be injured as the door moves.



Integrated garage door opener on the rear-view mirror

Garage door remote control (5) is not part of the integrated garage door opener.

- ▶ Before programming for the first time, clear the memory of the integrated garage door opener (▷ page 257).
- Turn the SmartKey to position 2 in the ignition lock.
- Press and hold one of the buttons (2) to (4) on the integrated garage door opener.

After a short time, indicator lamp ① starts flashing yellow.

- Indicator lamp ① flashes yellow immediately the first time button ②, ③ or ④ is programmed. If the selected button has already been programmed, indicator lamp ① will only start flashing yellow at a rate of once a second after ten seconds have elapsed.
- ▶ Release button ②, ③ or ④.

256 Features

- Point remote control (5) at a distance of 2 to 8 inches (5 to 20 cm) at buttons (2) to (4) on the rear-view mirror.
- The required distance between remote control (5) and the integrated garage door opener depends on the garage door drive system. Several attempts might be necessary. You should test every position for at least 25 seconds before trying another position.
- Press and hold button (6) on remote control
 (5) until indicator lamp (1) lights up green.
 If indicator lamp (1) lights up green or
 flashes, then programming has been successful.
- Release button (6) on remote control (5) for the garage door drive system.

If indicator lamp (1) lights up red:

Repeat the programming procedure for the corresponding button on the rear-view mirror. When doing so, vary the distance between remote control (5) and the rearview mirror.

1 If the indicator lamp flashes green after successful programming, the garage door system is operating on a rolling code. After programming, you must synchronize the garage door opener integrated in the rearview mirror with the receiver of the garage door system.

Synchronizing the rolling code

Your vehicle must be within reach of the garage door or exterior gate drive. Make sure that neither your vehicle nor any persons/ objects are present within the sweep of the door or gate.

Observe the safety notes when performing the rolling code synchronization (> page 254).

- Turn the SmartKey to position 2 in the ignition lock.
- Press the programming button of the door or gate drive (see the door or gate drive

operating instructions, e.g. under "Programming of additional remote controls").

- Usually, you now have 30seconds to initiate the next step.
- Press previously programmed button (2),
 (3) or (4) of the integrated garage door opener until the door starts to move. The rolling code synchronization is then complete.

Notes on programming the remote control

Canadian radio frequency laws require a "break" (or interruption) of the transmission signals after broadcasting for a few seconds. Therefore, these signals may not last long enough for the integrated garage door opener. The signal is not recognized during programming. Comparable with Canadian law, some U.S. garage door openers are designed to "time-out" in the same manner. Proceed as follows:

- if you live in Canada
- if you have difficulties programming the garage door opener (regardless of where you live) when using the programming steps
- Press and hold one of buttons (2) to (4) on the integrated garage door opener. After a short time, indicator lamp (1) starts flashing yellow.
- Release the button.
- Press button (6) of garage door remote control (5) for two seconds, then release it for two seconds.
- ▶ Press button ⑥ again for two seconds.
- Repeat this sequence on button (6) of remote control (5) until indicator lamp (1) lights up green.
 If indicator lamp (1) turns red, repeat the process.
- Continue with the other programming steps (see above).

Problems when programming

If you are experiencing problems programming the integrated garage door opener on the rear-view mirror, take note of the following instructions:

• Check the transmitter frequency of garage door drive remote control (5). This can usually be found on the back of the remote control.

The integrated garage door opener is compatible with devices that have units which operate in the frequency range of 280 to 390MHz.

- Replace the batteries in garage door remote control (5). This increases the likelihood that garage door remote control (5) will transmit a strong and precise signal to the integrated garage door opener in the rear-view mirror.
- When programming, hold remote control (5) at varying distances and angles from the button that you are programming. Try various angles at a distance between 2 and 12 inches (5 to 30 cm) or at the same angle but at varying distances.
- If another remote control for the same garage door drive is available, repeat the same programming steps with this remote control. Before performing these steps, make sure that new batteries have been installed in garage door drive remote control (5).
- Note that some remote controls only transmit for a limited amount of time (the indicator lamp on the remote control goes out). Press button (6) on remote control
 (5) again before transmission ends.
- Align the antenna cable of the garage door opener unit. This can improve signal reception/transmission.

Opening/closing the garage door

After it has been programmed, the integrated garage door opener performs the function of the garage door system remote control.

Please also read the operating instructions for the garage door system.

- Turn the SmartKey to position 2 in the ignition lock.
- Press button (2), (3) or (4) that you have programmed to operate the garage door. Garage door system with a fixed code: indicator lamp (1) lights up green.

Garage door system with a rolling code: indicator lamp ① flashes green.

The transmitter will transmit a signal for as long as the button is pressed. The transmission is halted after a maximum of ten seconds and indicator lamp (1) flashes yellow. Press button (2), (3) or (4) again if necessary.

Clearing the memory of the integrated garage door opener on the rear-view mirror

- Turn the SmartKey to position 2 in the ignition lock.
- Press buttons (2) and (4).
 The indicator lamp lights up yellow.
- Press and hold buttons (2) and (4) until the indicator lamp turns green.
- Make sure that you clear the memory of the integrated garage door opener before selling the vehicle.


Floormat on the driver's side

MARNING

Whenever you are using a floormat, make sure there is enough clearance and that the floormat is securely fastened.

The floormat should always be securely fastened using the fastening equipment.

Before driving off, check that the floormat is securely in place and adjust it if necessary. A loose floormat could slip and hinder proper functioning of the pedals. Do not place several floormats on top of each other as this may impair pedal movement.



- ► Slide the seat backwards.
- To install: place the floormat in the footwell.
- ▶ Press studs ① onto retainers ②.
- ► **To remove:** pull the floormat off retainers ②.
- ► Remove the floormat.

Useful information

This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.

 Please read the information on qualified specialist workshops (▷ page 23).

Engine compartment

Hood

Opening the hood

MARNING

Do not pull the release lever while the vehicle is in motion. Otherwise, the hood could be forced open by passing air flow.

This could cause the hood to come loose and injure you and/or others.

MARNING

There is a risk of injury if the hood is open, even if the engine is not running.

Some engine components can become very hot.

To avoid the risk of burns, only touch those components described in the Operator's Manual and observe the relevant safety notes.

MARNING

To avoid injury, stay clear of moving parts when the hood is open and the engine is running.

The radiator fan may continue to run for approximately 30seconds or may even restart after the engine has been switched off. For this reason, you must not reach into the fan rotation area.

MARNING

The engine is equipped with a transistorized ignition system. Because of the high voltage, it is dangerous to touch any components (ignition coils, spark plug sockets, diagnostic socket) of the ignition system:

- with the engine running
- · while starting the engine
- when the ignition is switched on and the engine is turned manually
- Make sure that the windshield wipers are switched off.

MARNING

The windshield wipers and wiper linkage could be set in motion.

When the hood is open, you or others could be injured by the wiper linkage.

Make sure that the windshield wipers are switched off. Remove the SmartKey or make sure that no ignition position has been selected with KEYLESS-GO. All indicator lamps must be off in the instrument panel.



 Pull release lever (1) for the hood. The hood is released.

Make sure that the windshield wipers are not folded away from the windshield. You could otherwise damage the windshield wipers or the hood.



Reach into the gap, pull hood catch handle ② up and lift the hood.

Once you have lifted the hood about 15 inches (40cm), it is automatically opened the rest of the way and held open by the gas-filled struts.

Closing the hood

▲ WARNING

When closing the hood, use extreme caution not to catch hands or fingers. Be careful that you do not close the hood on anyone.

Make sure the hood is securely engaged before driving off. Do not continue driving if the hood can no longer engage after an accident, for example. The hood could otherwise come loose while the vehicle is in motion and injure you and/or others.

- Lower the hood and let it fall from a height of approximately 8 inches (20cm).
- Check that the hood has engaged properly. If the hood can be raised slightly, it is not properly engaged. Open it again and close it with a little more force.

Engine oil

Notes on the oil level

Depending on the driving style, the vehicle consumes up to 0.9 US qts (0.8 l) of oil over a distance of 600 miles (1,000 km). The oil consumption may be higher than this when the vehicle is new or if you frequently drive at high engine speeds.


AMG vehicles: before operation on race tracks, check the oil level and (> page 261) add oil if necessary (> page 262). Race track operation is only permitted with a maximum engine oil level.

Depending on the engine, the oil dipstick may be in a different location.

When checking the oil level:

- park the vehicle on a level surface.
- the engine should be switched off for approximately five minutes if the engine is at normal operating temperature.
- if the engine is not at normal operating temperature, e.g. if the engine was only started briefly: wait about 30 minutes before carrying out the measurement.

Checking the oil level using the oil dipstick



- Pull oil dipstick (1) out of the dipstick guide tube.
- ▶ Wipe off oil dipstick ①.
- Slowly slide oil dipstick ① into the guide tube to the stop, and take it out again. If the level is between MIN mark ③ and MAX mark ②, the oil level is correct.
- If the oil level is at or below MIN mark ③, add 0.55 US qt to 1.1 US qt (0.5 to 1.0 l) of engine oil.

Adding engine oil

▲ WARNING

If engine oil comes into contact with hot engine parts, it may ignite and you could burn yourself. Do not spill any engine oil on hot engine parts.

Environmental note

When adding oil, take care not to spill any. If oil enters the soil or waterways, it is harmful to the environment.

Only use engine oils and oil filters that have been approved for vehicles with a service system. You can obtain a list of the engine oils and oil filters tested and approved in accordance with the Mercedes-Benz Specifications for Service Products at any Mercedes-Benz Service center.

Damage to the engine or exhaust system is caused by the following:

- using engine oils and oil filters that have not been specifically approved for the service system
- replacing engine oil and oil filters after the interval for replacement specified by the service system has been exceeded
- using engine oil additives.

Do not add too much oil. adding too much engine oil can result in damage to the engine or to the catalytic converter. Have excess engine oil siphoned off.



Example: engine oil cap

- Turn cap ① counterclockwise and remove it.
- Add engine oil. If the oil level is at or below the MIN mark on the oil dipstick, add 0.55 US qt to 1.1 US qt (0.5 to 1.0 l) of engine oil.
- Replace cap 1 on the filler neck and turn clockwise.
 Ensure that the cap locks into place securely.
- Check the oil level again with the oil dipstick (▷ page 261).

Further information on engine oil $(\triangleright$ page 326).

Checking and adding other service products

Checking the coolant level


▲ WARNING

In order to avoid any potentially serious burns:

- use extreme caution when opening the hood if there are any signs of steam or coolant leaking from the cooling system, or if the coolant temperature display indicates that the coolant is overheated.
- do not remove the pressure cap on the coolant reservoir if the coolant temperature is above 158 °F (70 °C). Allow the engine to cool down before removing the cap. The coolant reservoir contains hot fluid and is under pressure.

Maintenance and care

- using a rag, slowly turn the cap approximately ¹/₂ turn to relieve excess pressure. If opened immediately, scalding hot fluid and steam will be blown out under pressure.
- do not spill antifreeze on hot engine parts. Antifreeze contains ethylene glycol which may burn if it comes into contact with hot engine parts.



- Park the vehicle on a level surface. Only check the coolant level when the vehicle is on a level surface and the engine has cooled down.
- Turn the SmartKey to position 2 in the ignition lock (▷ page 131).
 On vehicles with KEYLESS-GO, press the Start/Stop button twice (▷ page 131).
- Check the coolant temperature display in the instrument cluster.
 The coolant temperature must be below 158 °F (70 °C).
- Turn the SmartKey to position 0(▷ page 131) in the ignition lock.
- Slowly turn cap (2) half a turn counterclockwise to allow excess pressure to escape.
- ► Turn cap ② further counter-clockwise and remove it.

If the coolant is at the level of marker bar ③ in the filler neck when cold, there is enough coolant in coolant expansion tank ①.

If the coolant level is approximately 0.6 in (1.5 cm) above marker bar ③ in the filler


neck when warm, there is enough coolant in coolant expansion tank (1).

- If necessary, add coolant that has been tested and approved by Mercedes-Benz.
- Replace cap (2) and turn it clockwise as far as it will go.

For further information on coolant, see (\triangleright page 327).

Adding washer fluid to the windshield washer system/headlamp cleaning system

Washer solvent/antifreeze is highly flammable. Do not spill washer solvent/ antifreeze on hot engine parts, because it may ignite and burn. You could be seriously burned.



- ► **To open:** pull cap ① upwards by the tab.
- ► Add the premixed washer fluid.
- ► To close: press cap ① onto the filler neck until it engages.


The washer fluid reservoir is used for both the windshield washer system and the headlamp cleaning system.

Further information on windshield washer fluid/antifreeze (▷ page 328).

Brake fluid level

If the brake fluid level in the brake fluid reservoir has fallen to the MIN mark or below, check the brake system immediately for leaks. Also check the thickness of the brake linings. Visit a qualified specialist workshop immediately. Do not add brake fluid. This does not correct the malfunction.

Only check the brake fluid level when the vehicle is stationary and on a level surface.



If the brake fluid level is between MIN marking (2) and MAX marking (1) on the brake fluid reservoir, it is correct.

Maintenance

Service interval display

Service messages

Information on the type of service and service intervals (see separate Maintenance Booklet).

You can obtain further information from an authorized Mercedes-Benz Center or at http://www.mbusa.com (USA only).

The service interval display informs you of the next service due date.

If a service due date has been exceeded, you also hear an acoustic signal.

The multifunction display shows a service message for a few seconds, e.g.

Next service A due in .. days Service A due

Service A overdue by ... days

The letter indicates which service is due. A stands for a minor service and ${\bf B}$ for a major

service. A number or another letter may be displayed after the letter. This figure indicates any necessary additional maintenance work to be performed.

You can obtain further information from an authorized Mercedes-Benz Center.

The service interval display does not take into account any periods of time during which the battery is disconnected.

Maintaining the time-dependent service schedule:

Note down the service due date displayed in the multifunction display before disconnecting the battery.

or

Subtract the battery disconnection periods from the service date shown on the display after reconnecting the battery.

Hiding a service message

Press the or OK button on the steering wheel.

Displaying service messages

- Switch on the ignition.
- Press or on the steering wheel to select the Serv. menu.
- Press a or to select the ASSYST PLUS submenu and press OK to confirm. The service due date appears in the multifunction display.

Please bear the following in mind

Resetting service interval display

If the qualified specialist workshop, e.g. a Mercedes-Benz Center, carried out the maintenance work, the service interval display will be reset.

Further information, on maintenance for example, can be obtained at an authorized Mercedes-Benz Center or directly from Mercedes-Benz.

care

Maintenance and

 If the service interval display has been reset unintentionally, have the setting corrected at a Mercedes-Benz Center.
 Have service work carried out as described in the Maintenance Booklet. This may otherwise lead to increased wear and damage to the major assemblies or the vehicle.

Driving abroad

An extensive Mercedes-Benz Service network is also available in other countries. You can obtain further information from any authorized Mercedes-Benz Center.

Care

Notes on care

Regular care of your vehicle is a condition for retaining the quality in the long term.

Use care products and cleaning agents recommended and approved by Mercedes-Benz.

Many cleaning products can be hazardous. Some are poisonous, others are flammable. Always follow the instructions on the particular container. Always open your vehicle's doors or windows when cleaning the inside.

Never use fluids or solvents that are not designed for cleaning your vehicle.

Always lock away cleaning products and keep them out of reach of children.

For cleaning your vehicle, do not use any of the following:

- dry, rough or hard cloths
- · abrasive cleaning agents
- solvents
- cleaning agents containing solvents Do not scrub.

Do not touch the surfaces or protective films with hard objects, e.g. a ring or ice scraper. You could otherwise scratch or damage the surfaces and protective film.

♀ Environmental note

Dispose of empty packaging and cleaning cloths in an environmentally responsible manner.

Do not park the vehicle for an extended period straight after cleaning it, particularly after having cleaned the wheels with wheel cleaner. Wheel cleaners could cause increased corrosion of the brake discs and brake pads/linings. For this reason, you should drive for a few minutes after cleaning. Braking heats the brake discs and the brake pads/linings, thus drying them. The vehicle can then be parked.

Exterior care

Automatic car wash

Braking efficiency is reduced after washing the vehicle. This could cause an accident. For this reason, you must drive particularly carefully after washing the vehicle until the brakes have dried.

You can wash the vehicle in an automatic car wash from the very start.

Lock the car if you wash it in an automatic car wash. Otherwise, the vehicle might be damaged.

- It is preferable to use car washes with adjustable¹⁹ high-pressure precleaning. In car washes that use high water pressures, there is a risk that a small amount of water may leak into the vehicle.
- Never clean your vehicle in a Touchless Automatic Car Wash as these use special

¹⁹ Corresponds to the specification for the Cabriolet program.

266 Care

cleaning agents. These cleaning agents can damage the paintwork or plastic parts.

If the vehicle is very dirty, pre-wash it before cleaning it in an automatic car wash.

Make sure that the automatic transmission is in position **N** when washing your vehicle in a tow-through car wash. The vehicle could be damaged if the transmission is in another position.

- Make sure that:
 - the side windows and roof are completely closed.
 - the blower for the ventilation/heating is switched off (OFF button is depressed/ airflow control is turned to position 0).
 - the windshield wiper switch is at position **0**.

The vehicle could otherwise be damaged.

After using an automatic car wash, wipe off wax from the windshield and the wiper blades. This will prevent smears and reduce wiping noises caused by residue on the windshield.

Washing by hand

In some countries, washing by hand is only allowed at specially equipped washing bays. Observe the legal requirements in all countries concerned.

- Do not use hot water and do not wash the vehicle in direct sunlight.
- ▶ Use a soft sponge to clean.
- Use a mild cleaning agent, such as a car shampoo approved by Mercedes-Benz.
- Thoroughly hose down the vehicle with a gentle jet of water.
- Do not point the water jet directly towards the air inlet.
- Use plenty of water and rinse out the sponge frequently.

- Rinse the vehicle with clean water and dry thoroughly with a chamois.
- Do not let the cleaning agent dry on the paintwork.

When using the vehicle in winter, remove all traces of road salt deposits carefully and as soon as possible.

Power washers

▲ WARNING

Do not use power washers with circular-jet nozzles (dirt grinders) to clean your vehicle, in particular the tires. You could otherwise damage the tires and cause an accident.

Always maintain a distance of at least 11.8 in (30 cm) between the vehicle and the power washer nozzle. Information about the correct distance is available from the equipment manufacturer.

Move the power washer nozzle around when cleaning your vehicle.

Do not aim directly at any of the following:

- tires
- door gaps, roof gaps, joints, etc.
- electrical components
- battery
- connectors
- lights
- seals
- trim
- ventilation slots

Damaged seals or electrical components can lead to leaks or failures.

Do not use high-pressure cleaners if the tank recess is open while you clean it. This can cause damage to the seals or other components.

Cleaning the wheels

Do not use acidic wheel cleaning products to remove brake dust. This could damage wheel bolts and brake components. Do not park the vehicle for an extended period straight after cleaning it, particularly after having cleaned the wheels with wheel cleaner. Wheel cleaners could cause increased corrosion of the brake discs and brake pads/linings. For this reason, you should drive for a few minutes after cleaning. Braking heats the brake discs and the brake pads/linings, thus drying them. The vehicle can then be parked.

Cleaning the paintwork

Scratches, corrosive deposits, areas affected by corrosion and damage caused by inadequate care cannot always be completely repaired. In such cases, visit a qualified specialist workshop.

- Remove dirt immediately, where possible, while avoiding rubbing too hard.
- Soak insect remains with insect remover and rinse off the treated areas afterwards.
- Soak bird droppings with water and rinse off the treated areas afterwards.
- Remove coolant, brake fluid, tree resin, oils, fuels and greases by rubbing gently with a cloth soaked in petroleum ether or lighter fluid.
- ► Use tar remover to remove tar stains.
- ► Use silicone remover to remove wax.

Do not affix:

- stickers
- films
- magnetic plates or similar items

to painted surfaces. You could otherwise damage the paintwork.

If water no longer forms "beads" on the paint surface, use the paint care products recommended and approved by Mercedes-Benz. This is the case approximately every three to five months, depending on the climate conditions and the care product used. If the dirt has penetrated the paint surface or if the paintwork has become dull, then the paintwork should be cleaned. For cleaning, please use the paint cleaner recommend and approved by Mercedes Benz.

Do not use these care products in the sun or on the hood while the hood is hot.

Use a suitable touch-up stick, e.g. MB Touch-Up Stick, to repair slight damage to the paintwork quickly and provisionally.

Matte finish care

If your vehicle has a clear matte finish, observe the following instructions in order to avoid damage to the paintwork due to incorrect care.

These notes also apply to light alloy wheels with a clear matte finish.

- Never polish the vehicle or the light alloy wheels. Polishing causes the finish to shine.
- The following may cause the paint to become shiny and thus reduce the matte effect:
 - Vigorous rubbing with unsuitable materials.
 - Frequent use of car washes.
 - Washing the vehicle in direct sunlight.
- Never use paint cleaner, buffing or polishing products, or gloss preserver, e.g. wax. These products are only suitable for high-gloss surfaces. Their use on vehicles with matte finish leads to considerable surface damage (shiny, spotted areas).

Always have paintwork repairs carried out at a qualified specialist workshop.

- Do not use wash programs with a hot wax treatment under any circumstances.
- **1** The vehicle should preferably be washed by hand using a soft sponge, car shampoo and plenty of water.
- Use only insect remover and car shampoo from the range of recommended and approved Mercedes-Benz care products.

268 Care

Cleaning the windows

MARNING

Before cleaning the windshield or wiper blades, switch off the windshield wipers and remove the SmartKey from the ignition lock. On vehicles with KEYLESS-GO, press the Start/Stop button repeatedly until all indicator lamps in the instrument cluster have gone out. The windshield wipers could otherwise move and injure you.

Do not clean the rear window with the reatractable hardtop (vario-roof) in a position other than the fully raised and closed position. Otherwise, the retractable hardtop may move unexpectedly which may result in personal injury to you or others.

- Clean the inside and outside of the windows with a damp cloth and a cleaning agent that is recommended and approved by Mercedes-Benz.
- Do not use dry cloths, abrasive products, solvents or cleaning agents containing solvents to clean the inside of the windows. Do not touch the insides of the windows with hard objects, e.g. an ice scraper or ring. There is otherwise a risk of damaging the windows.
- Clean the water drainage channels of the windshield and the rear window at regular intervals. Deposits such as leaves, petals and pollen may under certain circumstances prevent water from draining away. This can lead to corrosion damage and damage to electronic components.

Cleaning the wiper blades

MARNING ∕

Before cleaning the windshield or wiper blades, switch off the windshield wipers and remove the SmartKey from the ignition lock. On vehicles with KEYLESS-GO, press the Start/Stop button repeatedly until all indicator lamps in the instrument cluster have gone out. The windshield wipers could otherwise move and injure you.

- Do not pull the wiper blade. Otherwise, the wiper blade could be damaged.
- Do not clean wiper blades too often and do not rub them too hard. Otherwise, the graphite coating could be damaged. This could cause wiper noise.
- Fold the wiper arms away from the windshield.
- Carefully clean the wiper blades with a damp cloth.
- Fold the windshield wipers back again before switching on the ignition.
- Hold the wiper arm securely when folding back. The windshield could be damaged if the wiper arm smacks against it suddenly.

Cleaning the exterior lighting


- Only use cleaning agents or cleaning cloths which are suitable for plastic light lenses. Unsuitable cleaning agents or cleaning cloths could scratch or damage the plastic light lenses.
- Clean the plastic lenses of the exterior lighting using a wet sponge and a mild cleaning agent, e.g. Mercedes-Benz car shampoo. Or clean the exterior lighting with cleaning cloths.

Cleaning the mirror turn signals

- Only use cleaning agents or cleaning cloths that are suitable for plastic lenses. Unsuitable cleaning agents or cleaning cloths could scratch or damage the plastic lenses of the mirror turn signals.
- Clean the plastic lenses of the mirror turn signals using a wet sponge and a mild cleaning agent, e.g. Mercedes-Benz car

shampoo. Cleaning cloths may be used as well.


Cleaning the sensors



- ► Clean sensors ① of the driving systems with water, car shampoo and a soft cloth.
- If you clean the sensors with a power washer, make sure that you keep a distance of at least 11.8 in (30 cm) between the vehicle and the power washer nozzle. Information about the correct distance is available from the equipment manufacturer.

Cleaning the exhaust pipes

Impurities combined with the effects of road grit and corrosive environmental factors may cause flash rust to form on the surface. You can restore the original shine of the exhaust tail pipe by cleaning it regularly, especially in winter and after washing.



 Clean the exhaust tail pipes with a chrome care product tested and approved by Mercedes-Benz.

Interior care

Cleaning the display

- Before cleaning the display, make sure that it is switched off and has cooled down.
- Clean the display surface using a commercially-available microfiber cloth and TFT/LCD display cleaner.
- Dry the display surface using a dry microfiber cloth.
- For cleaning, do not use any of the following:
 - alcohol-based thinner or gasoline
 - abrasive cleaning agents
 - commercially-available household cleaning agents

These may damage the display surface. Do not put pressure on the display surface when cleaning. This could lead to irreparable damage to the display.

Cleaning the plastic trim

When cleaning the steering wheel boss and dashboard, do not use cockpit sprays or cleaning agents containing solvents. Cleaning agents containing solvents cause the surface to become porous, and as a result, plastic parts may break away and be thrown around the interior when an air bag is deployed, which may result in severe injuries.

- Do not affix the following to plastic surfaces:
 - stickers
 - films

• scented oil bottles or similar items You can otherwise damage the plastic.

Do not allow cosmetics, insect repellent or sunscreen to come into contact with the plastic trim. This maintains the high-quality look of the surfaces.

270 Care

- Wipe the plastic trim with a damp, lint-free cloth, e.g. a microfiber cloth.
- Heavy soiling: use car care and cleaning products recommended and approved by Mercedes-Benz.

The surface may change color temporarily. Wait until the surface is dry again.

Cleaning the steering wheel and gear or selector lever

Thoroughly wipe with a damp cloth or use leather care agents that have been recommended and approved by Mercedes-Benz.

Cleaning genuine wood and trim elements

- Wipe the wooden trim and trim pieces with a damp, lint-free cloth, e.g. a microfiber cloth.
- ► Heavy soiling: use car care and cleaning products recommended and approved by Mercedes-Benz.
- Do not use solvent-based cleaning agents such as tar remover, wheel cleaners, polishes or waxes. There is otherwise a risk of damaging the surface.

Do not use chrome polish on trim pieces. The trim pieces have a chrome look but are mostly made of anodized aluminum and can lose their shine if chrome polish is used. Use a damp, lint-free cloth instead when cleaning the trim pieces.

If the chrome-plated trim pieces are very dirty, you can use a chrome polish. If you are unsure as to whether the trim pieces are chrome-plated or not, consult an authorized Mercedes-Benz Center.

Cleaning the seat covers

Do not use microfiber cloths to clean genuine leather, artificial leather or Alcantara® covers. If used often, these can damage the cover.

- Observe the following when cleaning:
 - clean genuine leather covers carefully with a damp cloth and then wipe the covers down with a dry cloth. Make sure that the leather does not become soaked. It may otherwise become rough and cracked. Only use leather care agents that have been tested and approved by Mercedes-Benz. You can obtain these from a qualified specialist workshop.
 - clean artificial leather covers with a cloth moistened with a solution containing 1% detergent (e.g. dish washing liquid).
 - clean cloth covers with a microfiber cloth moistened with a solution containing 1% detergent (e.g. dish washing liquid). Rub carefully and always wipe entire seat sections to avoid leaving visible lines. Leave the seat to dry afterwards. Cleaning results depend on the type of dirt and how long it has been there.
 - clean Alcantara® covers with a damp cloth. Make sure that you wipe entire seat sections to avoid leaving visible lines.
- Note that regular care is essential to ensure that the appearance and comfort of the covers is retained over time.

Cleaning the seat belts

- Use clean, lukewarm water and soap solution.
- Do not clean the seat belts using chemical cleaning agents. Do not dry the seat belts by heating at temperatures above 176 °F (80 °C) or in direct sunlight.

Do not bleach or dye seat belts as this may severely weaken them. In a crash, they may not be able to provide adequate protection.

Cleaning the headliner and carpets

- Headliner: use a soft brush or a cleaning agent recommended and approved by Mercedes-Benz to remove heavy soiling.
- Carpets: use the carpet and textile cleaning agents recommended and approved by Mercedes-Benz.

Useful information	274
Where will I find?	274
Flat tire	275
Battery	282
Jump-starting	285
Towing and tow-starting	287
Fuses	289

Useful information

- This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- Please read the information on qualified specialist workshops (▷ page 23).

Where will I find ...?

First-aid kit

Open the trunk lid.




- ► Lift the trunk floor up.
- ▶ Remove first-aid kit ①.
- Check the expiration date on the first-aid kit at least once a year. Replace the contents if necessary, and replace missing items.

Vehicle tool kit

The vehicle tool kit can be found in the stowage well under the trunk floor.

Vehicles with a TIREFIT kit: lift the trunk floor up.

- ► Lift the trunk floor up.
- ▶ Remove the collapsible spare wheel (▷ page 274).
- AMG vehicles: loosen the central screw of the bracket counter-clockwise and remove it together with the bracket.



- 1) Folding wheel chock
- Fuse allocation chart
- ③ Jack
- ④ Sheet for faulty wheel
- ⑤ Alignment bolt
- 6 Lug wrench
- ⑦ Towing eye
- (8) Valve extractor
- Tire inflation compressor


Collapsible spare wheel

Removing the collapsible spare wheel

The collapsible spare wheel can be found in the stowage well under the trunk floor.


AMG vehicles: the collapsible spare wheel is packed in a bag and secured to a bracket in the trunk.

Flat tire 275



Example

- Turn retaining screw (2) counter-clockwise and remove it.
- ▶ Remove collapsible spare wheel ①.



AMG vehicles

- ► AMG vehicles: loosen tensioning straps ① on both sides.
- ▶ Unhook retaining spring hooks ② and ③ tensioning strap ① from the bracket.
- Remove the bag with the collapsible spare wheel.
- Open the bag and remove the collapsible spare wheel.

For further information on changing a wheel and mounting the spare wheel, see (▷ page 275).

Stowing a used collapsible spare wheel

Take the following steps to stow a used collapsible spare wheel. Otherwise, the collapsible spare wheel will not fit in the trunk in the intended manner. Mercedes-Benz recommends that you have this work carried out at a qualified specialist workshop.

- Only place the collapsible spare wheel in the vehicle when it is dry. Otherwise, moisture may get into the vehicle.
- ► Unscrew the valve cap from the valve.
- ► If possible, unscrew the valve insert from the valve and release the air.
- Fully deflating the tire can take a few minutes.
- Screw the valve insert back into the valve.
- Screw the valve cap back on.
- Pull the protective sheet provided with the spare wheel over the collapsible spare wheel.
- Stow the collapsible spare wheel in the emergency spare wheel well under the trunk.
- Use the retaining screw to pierce the protective sheet and fasten the collapsible spare wheel in place.
- ► AMG vehicles: pull the bag over the collapsible spare wheel and close it.
- Place the bag with the collapsible spare wheel in the trunk.
- Hook in the retaining strap carabiners and lash the collapsible spare wheel to the bracket.

Flat tire

Preparing the vehicle

Your vehicle may be equipped with a collapsible spare wheel or MOExtended tires (tires with run-flat properties) (\triangleright page 281).

- Vehicle preparation is not necessary on vehicles with MOExtended tires.
- Stop the vehicle on solid, non-slippery and level ground, as far away as possible from traffic.
- Switch on the hazard warning lamps.

276 Flat tire

- ► Apply the electric parking brake manually (▷ page 150).
- Bring the front wheels into the straightahead position.
- ▶ Move the selector lever to position **P**.
- ► Switch off the engine.
- Vehicles without KEYLESS-GO: remove the SmartKey from the ignition lock.
- Vehicles with KEYLESS-GO: open the driver's door.
 The on-board electronics have status 0, which is the same as the SmartKey having been removed.
- ► Vehicles with KEYLESS-GO: remove the Start/Stop button from the ignition lock (▷ page 131).
- All occupants must get out of the vehicle. Make sure that they are not endangered as they do so.
- Make sure that no one is near the danger area while a wheel is being changed. Anyone who is not directly assisting in the wheel change should, for example, stand behind the barrier.
- Get out of the vehicle. Pay attention to traffic conditions when doing so.
- Close the driver's door.

Changing a wheel and mounting the spare wheel

Preparing the vehicle

When using a different size spare wheel or emergency spare wheel, do not exceed the maximum road speed of 50 mph (80 km/h)

MARNING

The wheel or tire size as well as the tire type of the spare wheel or emergency spare wheel and the wheel to be replaced may differ. Mounting an emergency spare wheel may severely impair the driving characteristics. There is a risk of an accident. To avoid hazardous situations:


- adapt your driving style accordingly and drive carefully.
- never install more than one spare wheel or emergency spare wheel that differs in size.
- only use a spare wheel or emergency spare wheel of a different size briefly.
- do not switch ESP[®] off.
- have a spare wheel or emergency spare wheel of a different size replaced at the nearest qualified specialist workshop.
 Observe that the wheel and tire dimensions as well as the tire type must be correct.
- Vehicles without a spare wheel or emergency spare wheel are not equipped with a tire-change tool kit at the factory. For more information on which tools are required to perform a wheel change on your vehicle, e.g. wheel chock, lug wrench or alignment bolt, consult an authorized Mercedes-Benz Center.
- Prepare the vehicle as described (> page 275).
- Remove the following items (depending on the vehicle's equipment) from the stowage well under the trunk floor:
 - emergency spare wheel
 - lug wrench
 - folding wheel chock
 - jack
 - alignment bolt
 - tire inflation compressor
- Secure the vehicle to prevent it from rolling away.

Securing the vehicle to prevent it from rolling away

If your vehicle is equipped with a wheel chock, it can be found in the vehicle tool kit (> page 274).

The folding wheel chock is an additional securing measure to prevent the vehicle from

rolling away, for example when changing a wheel.



- ► Fold both plates upwards ①.
- ▶ Fold out lower plate ②.
- Guide the lugs on the lower plate fully into the openings in base plate (3).



Securing the vehicle on level ground

On level ground: place chocks or other suitable items under the front and rear of the wheel that is diagonally opposite the wheel you wish to change.



Securing the vehicle on slight downhill gradients

On downhill gradients: place chocks or other suitable items in front of the wheels of the front and rear axle.

Raising the vehicle

If you do not position the jack correctly at the appropriate jacking point of the vehicle, the jack could tip over with the vehicle raised. There is a risk of injury.

Only position the jack at the appropriate jacking point of the vehicle. The base of the jack must be positioned vertically, directly under the jacking point of the vehicle.

The following must be observed when raising the vehicle:

- to raise the vehicle, only use the vehiclespecific jack that has been tested and approved by Mercedes-Benz. If used incorrectly, the jack could tip over with the vehicle raised.
- the jack is designed only to raise and hold the vehicle for a short time while a wheel is being changed. It is not suited for performing maintenance work under the vehicle.
- avoid changing the wheel on uphill and downhill slopes.
- before raising the vehicle, secure it from rolling away by applying the parking brake and inserting wheel chocks. Never disengage the parking brake while the vehicle is raised.
- the jack must be placed on a firm, flat and non-slip surface. On a loose surface, a large, load-bearing underlay must be used. On a slippery surface, a non-slip underlay must be used, e.g. rubber mats.
- do not use wooden blocks or similar objects as a jack underlay. Otherwise, the jack will not be able to achieve its loadbearing capacity due to the restricted height.

Breakdown assistance

278 Flat tire

- The maximum clearance between the underside of the tire and the ground must be 1.2 in (3 cm).
- never place your hands and feet under the raised vehicle.
- never lie under the raised vehicle.
- never start the engine when the vehicle is raised.
- never open or close a door or the trunk lid when the vehicle is raised.
- make sure that no persons are present in the vehicle when the vehicle is raised.




Using lug wrench (1), loosen the bolts on the wheel you wish to change by about one full turn. Do not unscrew the bolts completely.

The jacking points are located just behind the wheel housings of the front wheels and just in front of the wheel housings of the rear wheels (arrows).




Covers, front (example: vehicles with AMG equipment)


- Vehicles with AMG equipment: fold cover (2) upwards.
- The jack is designed exclusively for jacking up the vehicle at the jacking points. Otherwise, your vehicle could be damaged.



▶ Position jack ④ at jacking point ③.



AMG vehicles and vehicles with AMG equipment: to protect the vehicle body, the vehicle has covers next to the jacking points on the outer sills.



P40.10-5216-31

- Make sure that the base of the jack is positioned directly under the jacking point.
- ► Turn crank (5) clockwise until jack (4) sits completely on jacking point (3) and the base of the jack lies evenly on the ground.
- Turn handle (5) until the tire is 1.2 in (3 cm) from the ground at most.

Removing a wheel



- Unscrew the uppermost wheel bolt completely.
- Screw alignment bolt ① into the thread instead of the wheel bolt.
- ► Unscrew the remaining wheel bolts fully.
- Do not place wheel bolts in sand or on a dirty surface. The bolt and wheel hub threads could otherwise be damaged when you screw them in.
- ▶ Remove the wheel.

Mounting a new wheel

MARNING ▲

Oiled or greased wheel bolts or damaged wheel bolts/hub threads can cause the wheel bolts to come loose. As a result, you could lose a wheel while driving. There is a risk of accident.

Never oil or grease wheel bolts. In the event of damage to the threads, contact a qualified specialist workshop immediately. Have the damaged wheel bolts or hub threads replaced/renewed. Do not continue driving.

If you tighten the wheel bolts or wheel nuts when the vehicle is raised, the jack could tip over. There is a risk of injury.

Only tighten the wheel bolts or wheel nuts when the vehicle is on the ground.

Always pay attention to the instructions and safety notices in "Changing a wheel" (> page 315).

Only use wheel bolts that have been designed for the wheel and the vehicle. For safety reasons, Mercedes-Benz recommends that you only use wheel bolts which have been approved for Mercedes-Benz vehicles and the respective wheel.

Be sure to use the original-length wheel bolts when refitting the original wheel after it has been repaired.


- Clean the wheel and wheel hub contact surfaces.
- To prevent damage to the paintwork, hold the wheel securely against the wheel hub while screwing in the first wheel bolt.



- Slide the emergency spare wheel onto the alignment bolt and push it on.
- Tighten the wheel bolts until they are finger-tight.
- ▶ Unscrew the alignment bolt.
- ► Tighten the last wheel bolt until it is fingertight.
- ► Inflate the collapsible spare wheel (▷ page 280).

Inflating the collapsible spare wheel

Inflate the collapsible spare wheel using the tire inflation compressor before lowering the vehicle. The wheel rim could otherwise be damaged.



- ▶ Pull plug ④ out of the housing.
- ► Take the air hose out of the housing.
- Insert the yellow hose connector of the air hose into the guide in the housing and push it into the fixture until the hose connector engages.
- Remove the cap from the valve on the collapsible spare wheel.
- Screw air hose union nut (1) onto the valve.
- ► Make sure the tire inflation compressor's on/off switch (5) is set to OFF.
- ► Insert plug ④ into the socket of the cigarette lighter (▷ page 247) or into a 12 V power socket (▷ page 247) in your vehicle.
- Make sure that the SmartKey is in position 1 (▷ page 131) in the ignition lock.
- ▶ Press on/off switch (5) on the tire inflation compressor to **ON**.

The tire inflation compressor is switched on. The tire is inflated. The tire pressure is read at pressure gauge ③.

Do not operate the tire inflation compressor for longer than ten minutes at a time without a break. It may otherwise overheat.

The tire inflation compressor can be operated again once it has cooled down.

Inflate the tire to the specified tire pressure.

The specified tire pressure is printed on the yellow label of the emergency spare wheel.

- When the specified tire pressure has been reached, switch on/off switch (5) on the tire inflation compressor to OFF. The tire inflation compressor is switched off.
- ► Turn the SmartKey to position **0** in the ignition lock.
- If the tire pressure is higher than the specified pressure, press pressure release button (2) until the correct tire pressure has been reached.
- ► Unscrew air hose union nut ① from the valve.
- Screw the valve cap onto the collapsible spare wheel valve again.



Removing an air hose

- To remove the hose from the tire inflation compressor, push down the rocker switch on the hose connector and pull out the hose.
- Stow plug ④ and the air hose in the lower section of the compressor housing.
- Stow the tire inflation compressor in the vehicle.

Lowering the vehicle

≜ WARNING

Tire pressure that is too high or too low can lead to a blowout of the mounted emergency spare wheel/spare wheel, particularly when driving with a heavy load and increasing speed. There is a risk of accident.

Check the tire pressure of the emergency spare wheel or spare wheel and adjust it. When doing so, observe the specified tire pressure.

- Inflate the collapsible spare wheel using the tire inflation compressor before lowering the vehicle. The wheel rim could otherwise be damaged.
- Turn the crank of the jack counterclockwise until the vehicle is once again standing firmly on the ground.
- Place the jack to one side.



The wheels could work loose if the wheel nuts and bolts are not tightened to the specified tightening torque. There is a risk of accident. Have the tightening torque immediately checked at a qualified specialist workshop

after a wheel is changed.

- Tighten the wheel bolts evenly in a crosswise pattern in the sequence indicated (1 to (5)). The tightening torque must be 96 lb-ft (130 Nm).
- Turn the jack back to its initial position and store it together with the rest of the tire-

change tool kit in the stowage well under the trunk floor.

- Vehicles with AMG equipment: insert the cover into the outer sill.
- Place the damaged wheel in the protective covering (if available) from the tire-change tool kit, and stow it in the trunk.

The roof must be closed when doing so.

USA only: when you are driving with the emergency spare wheel mounted, the tire pressure monitoring system cannot function reliably. Only restart the tire pressure monitoring system when the defective wheel has been replaced with a new wheel.

All wheels mounted must be equipped with functioning sensors. The defective wheel should no longer be in the vehicle.

MOExtended tires (tires with run-flat properties)

With MOExtended tires (tires with run flat characteristics), you can continue to drive your vehicle even if there is a total loss of pressure in one or more tires.

MOExtended tires may only be used in conjunction with the activated tire pressure loss warning system or with the activated tire pressure monitoring system.

The driving distance in partially laden condition is approximately 50 miles (80 km), and approximately 18 miles (30 km) when fully loaded.

In addition to the vehicle load, the driving distance possible depends upon:

- speed
- road condition
- outside temperature

The driving distance possible in run-flat mode may be reduced by extreme driving conditions/maneuvers, or it can be increased through a moderate style of driving. The maximum permissible distance which can be driven in run-flat mode is counted from the moment the tire pressure loss warning appears in the multifunction display.

Do not exceed a vehicle speed of 50 mph (80 km/h).

MARNING

When driving in emergency mode, the driving characteristics deteriorate, e.g. when cornering, accelerating quickly and when braking. There is a risk of an accident.

Do not exceed the stated maximum speed. Avoid abrupt steering and driving maneuvers, and driving over obstacles (curbs, potholes, off-road). This applies in particular to a laden vehicle.

Stop driving in emergency mode if:

- you hear banging noises.
- the vehicle starts to shake.
- you see smoke and smell rubber.
- ESP[®] is intervening constantly.
- there are tears in the sidewalls of the tire.

After driving in emergency mode, have the wheel rims checked at a qualified specialist workshop with regard to their further use. The defective tire must be replaced in every case.

When replacing one or all tires, make sure that you only use tires marked MOExtended. Also ensure that they are of the specified size for the vehicle.

Battery

Important safety notes

In order for the battery to achieve the maximum possible service life, it must always be sufficiently charged.

Have the battery checked regularly at a qualified specialist workshop.

Observe the service intervals in the Maintenance Booklet or contact a qualified specialist workshop for more information. Have the battery charge level checked more frequently if you use the vehicle mainly for short trips or if you leave it standing idle for a lengthy period.

Only replace a battery with a battery that has been recommended by Mercedes-Benz.

Consult a qualified specialist workshop if you wish to leave your vehicle parked for a long period of time.

Comply with safety precautions and take protective measures when handling batteries.



Risk of explosion



Fire, naked flames and smoking are prohibited when handling the battery. Avoid creating sparks.



Battery acid is caustic. Avoid contact with the skin, eyes or clothing.

Wear suitable protective clothing, in particular gloves, an apron and a face mask.

Immediately rinse acid splashes off with clean water. Consult a doctor if necessary.



Wear eye protection.



Keep children away.



Observe this Operator's Manual.

Ψ Environmental note



Batteries contain dangerous substances. It is against the law to dispose of them with the household rubbish. They must be collected separately and recycled to protect the environment.



Dispose of batteries in an environmentally friendly manner. Take discharged batteries to a qualified specialist workshop or a special collection point for used batteries.

MARNING

Failure to follow these instructions can result in severe injury or death.

Never lean over batteries while connecting. You might get injured.

Battery fluid contains sulfuric acid. Do not allow this fluid to come in contact with eyes, skin or clothing. In case it does, immediately flush affected area with water and seek medical help if necessary.

A battery will also produce hydrogen gas, which is flammable and explosive. Keep flames or sparks away from battery, avoid improper connection of jumper cables, smoking etc.

MARNING

Do not place any metal objects on the battery as this could result in a short circuit.

Use leak-proof batteries only to avoid the risk of acid burns in the event of an accident.

Take care that you do not become statically charged, e.g. by wearing synthetic clothing or rubbing against textiles. For this reason, you also should not pull or push the battery over carpets or other synthetic materials.

Never touch the battery first. First, touch the outside body of the vehicle in order to release any possible electrostatic charges.

Do not rub the battery with rags or cloths. The battery could explode if touched due to electrostatic charge or due to spark formation.

Before working on the battery, e.g. loosening the battery terminals, switch off the engine and remove the SmartKey from the ignition. On vehicles with KEYLESS-GO, make sure that the ignition is switched off. Check that all the indicator lamps in the instrument cluster are off. You may otherwise destroy electronic components, such as the alternator.

Like other batteries, the vehicle battery may discharge over time if you do not use the vehicle. In this case, have the battery disconnected at a qualified specialist workshop. You can also charge the battery with a charger recommended by Mercedes-Benz. Contact a qualified specialist workshop for further information. The battery and the cover of the positive terminal clamp must be installed securely during operation.

• Remove the SmartKey if you park the vehicle and do not require any electrical consumers. The vehicle will then use very little energy, thus conserving battery power.

Mercedes-Benz recommends that you do not carry out work on batteries yourself, e.g. removing or charging. Have this work performed at a qualified specialist workshop.

Charging the battery

Never charge a battery still installed in the vehicle unless a battery charger unit approved by Mercedes-Benz is being used. Gases may escape during charging and cause explosions that may result in paint damage, corrosion or personal injury. A battery charger unit specially adapted for Mercedes-Benz vehicles and tested and approved by Mercedes-Benz is available as an accessory. It permits the charging of the battery in its installed position. Contact an authorized Mercedes-Benz Center for further information and availability.

Charge the battery in accordance with the separate instructions for the battery charger.

▲ WARNING

There is a risk of acid burns during the charging process due to the gases which escape from the battery. Do not lean over the battery during the charging process.

Battery acid is caustic. Avoid contact with the skin, eyes or clothing.

• Only charge the installed battery with a battery charger which has been tested and approved by Mercedes-Benz. These battery chargers allow the battery to be charged while still installed in the vehicle.

Only use battery chargers with a maximum charging voltage of 14.8 V.

Only charge the battery using the jumpstarting connection point.

The jump-starting connection point is in the engine compartment (\triangleright page 285).

- ▶ Open the hood (▷ page 260).
- Connect the battery charger to the positive terminal and ground point in the same order as when connecting the donor battery in the jump-starting procedure (▷ page 285).
- Read the battery charger's operating instructions before charging the battery.

Jump-starting

MARNING №

Failure to follow these directions will cause damage to the electronic components, and can lead to a battery explosion and severe injury or death.

Never lean over batteries while connecting or jump starting. You might get injured.

Battery fluid contains sulfuric acid. Do not allow this fluid to come in contact with eyes, skin or clothing. In case it does, immediately flush affected area with water, and seek medical help if necessary.

A battery will also produce hydrogen gas, which is flammable and explosive. Keep flames or sparks away from battery, avoid improper connection of jumper cables, smoking, etc.

Attempting to jump start a frozen battery can result in it exploding, causing personal injury. Read all instructions before proceeding.

Non-combusted fuel can collect in the exhaust system and ignite. There is a risk of fire. Avoid repeated and lengthy starting attempts.

Avoid repeated and lengthy starting attempts. Otherwise, the catalytic converter could be damaged by the non-combusted fuel.


Do not use a rapid charging device to start the vehicle. If your vehicle's battery is discharged, the engine can be jump-started from another vehicle or from a second battery using jumper cables. Observe the following points:

- The battery is not accessible in all vehicles. If the other vehicle's battery is not accessible, jump-start the vehicle using a second battery or a jump-starting device.
- You may only jump-start the vehicle when the engine and catalytic converter are cold.
- Do not start the engine if the battery is frozen. Let the battery thaw first.
- jump-starting may only be performed from batteries with a nominal voltage of 12 V.
- Only use jumper cables which have a sufficient cross-section and insulated terminal clamps.
- If the battery is fully discharged, leave the battery that is being used to jump-start connected for a few minutes before attempting to start. This charges the empty battery a little.
- Make sure that the two vehicles do not touch.

Make sure that:

- the jumper cables are not damaged.
- bare parts of the terminal clamp do not come into contact with other metal parts while the jumper cables are connected to the battery.
- the jumper cables cannot come into contact with parts such as the V-belt pulley or the fan. These parts move when the engine is started and while it is running.
- Secure the vehicle by applying the electric parking brake.
- ► Manual transmission: engage neutral.
- ► Automatic transmission: move the selector lever to position P.

- ▶ Switch off all electrical consumers (e.g. radio, blower, etc.).
- ▶ Open the hood (▷ page 260).



Position number (6) identifies the charged battery of the other vehicle or an equivalent jumpstarting device.

- ▶ Slide cover ① of positive terminal ② in the direction of the arrow.
- ► Connect positive terminal ② on your vehicle to positive terminal ③ of donor battery ⑥ using the jumper cable, beginning with your own battery.
- ▶ Start the engine of the donor vehicle and run it at idling speed.
- ► Connect negative terminal ④ of donor battery ⑥ to ground point ⑤ of your vehicle using the jumper cable, connecting the jumper cable to donor battery ⑥ first.
- ► Start the engine.
- ▶ Before disconnecting the jumper cables, let the engine run for several minutes.
- First remove the jumper cables from ground point (5) and negative terminal (4), then from positive terminal (2) and positive terminal (3), each time beginning at the contacts on your own vehicle first.
- ▶ Close cover ① of positive terminal ② after removing the jumper cables.
- ► Have the battery checked at a qualified specialist workshop.
- 1 Jump-starting is not considered to be a normal operating condition.
- Jumper cables and further information regarding jump starting can be obtained at any qualified specialist workshop.

Towing and tow-starting | 287

Towing and tow-starting

Important safety notes

MARNING

If you tow the vehicle, you must use a rigid towing bar if:

- the engine is not running.
- there is a brake system malfunction.
- there is a malfunction in the power supply or the vehicle's electrical system.

The power assistance for the steering and the brake force booster do not work when the engine is not running. You will need more force to steer and brake, you may have to depress the brake pedal with maximum force.

Before towing away, make sure that the steering can be moved and is not locked.

If you tow or tow-start another vehicle, its weight must not exceed the maximum permissible gross vehicle weight of your vehicle.

It is better to have the vehicle transported than to have it towed.

The vehicle can be towed a maximum of 30 miles (50km). The towing speed of 30 mph (50 km/h) must not be exceeded. If the vehicle has to be towed more than 30 miles (50km), the entire vehicle must be raised and transported.

Make sure that the electric parking brake is released. If the electric parking brake is faulty, visit a qualified specialist workshop.

• Only secure the tow rope or tow bar at the towing eyes. Otherwise, the vehicle could be damaged.

Do not use the towing eye for recovery, as this could damage the vehicle. If in doubt, recover the vehicle with a crane.

Drive slowly and smoothly when towing. Excessive tractive power could otherwise damage the vehicles.

- Do not tow with sling-type equipment. This could damage the vehicle.
- On vehicles with KEYLESS-GO, use the SmartKey instead of the Start/Stop button. Turn the SmartKey to position **2** in the ignition lock and shift the automatic transmission to **N**. Then, turn the SmartKey back to **0** and leave it in the ignition lock.

When towing a vehicle with an automatic transmission, the transmission must be in position N.

The battery must be connected and charged. Otherwise, you:

- cannot turn the SmartKey to position 2 in the ignition lock
- cannot shift the transmission to position
 N on vehicles with automatic transmission

Vehicles with automatic transmission: release the selector lever lock manually to move it out of position **P**(> page 146).

Switch off the automatic locking feature (▷ page 75) You could otherwise be locked out when pushing or towing the vehicle.

Installing/removing the towing eye

Installing the towing eye

► Remove the towing eye from the vehicle tool kit (▷ page 274).

The exhaust tail pipe may be hot. You could burn yourself if you touch the tail pipe. Be particularly careful when removing the rear cover.

The mountings for the removable towing eyes are located in the bumpers. They are at the front and at the rear, under the covers.





- ▶ Press the mark on cover (1) inwards in the direction of the arrow.
- ► Take cover (1) off the opening.
- ► Screw the towing eye in clockwise to the stop and tighten it.

Removing the towing eye

- ► Loosen the towing eye and unscrew it.
- ▶ Attach cover (1) to the bumper and press until it engages.
- Place the towing eye in the vehicle tool kit.

Towing the vehicle with the rear axle raised

When towing your vehicle with the rear axle raised, it is important that you observe the safety instructions (\triangleright page 287).



I The ignition must be switched off if you are towing the vehicle with the rear axle raised. Intervention by ESP[®] could otherwise damage the brake system.

- Switch on the hazard warning lamps (⊳ page 108).
- ► Turn the SmartKey to position **0** in the ignition lock and remove the SmartKey from the ignition lock.
- ▶ When leaving the vehicle, take the SmartKey or the KEYLESS-GO key with you.

Towing a vehicle with both axles on the ground

When having your vehicle towed, observe the important safety notes (\triangleright page 287).

MARNING

The power assistance for the steering and the brake force booster do not work when the engine is not running. You will then need much more effort to brake and steer the vehicle. Adapt your style of driving accordingly.

- Switch on the hazard warning lamps (⊳ page 108).
- **1** When towing with the hazard warning lamps switched on, use the combination switch as usual to signal a change of direction. In this case, only the turn signals for the desired direction flash. When the combination switch is reset, the hazard warning lamps start flashing again.
- ► Turn the SmartKey to position 2 in the ignition lock.
- ▶ When the vehicle is stationary, depress the brake pedal and keep it depressed.
- Vehicles with manual transmission: depress the clutch pedal.
- ▶ Shift to neutral.
- or
- ▶ Vehicles with automatic transmission: shift the automatic transmission to position N.
- Release the brake pedal.
- ▶ Release the parking brake.

Transporting the vehicle

The towing eye can be used to pull the vehicle onto a trailer or transporter for transporting purposes.

- Vehicles with manual transmission: shift to neutral.
- Vehicles with automatic transmission: turn the SmartKey to position 2 in the ignition lock.
- ► Move the selector lever to **N**.

As soon as the vehicle is loaded:

- Prevent the vehicle from rolling away by applying the parking brake.
- Vehicles with manual transmission: shift to first gear or reverse gear.
- ► Vehicles with automatic transmission: move the selector lever to P.
- Turn the SmartKey to position 0 in the ignition lock and remove the SmartKey from the ignition lock.
- Secure the vehicle.
- Only lash the vehicle down by the wheels or wheel rims, not by parts of the vehicle such as axle or steering components. Otherwise, the vehicle could be damaged.

Tow-starting (emergency starting)

When tow-starting your vehicle, it is important that you follow the safety instructions (\triangleright page 287).

Vehicles with automatic transmission must not be started by tow-starting. This could otherwise damage the transmission.

For further information on "Jump-starting" see (\triangleright page 285).

Before tow-starting the following conditions must be fulfilled:

- the battery is connected.
- the engine has cooled down.
- the catalytic converter has cooled down.

- Switch on the hazard warning lamps (▷ page 108).
- ▶ Install the towing eye (\triangleright page 287).
- Secure the rigid towing bar or the towing rope.
- Depress and hold the brake pedal.
- Turn the SmartKey to position 2 in the ignition lock.
- Depress the clutch pedal and keep it depressed.
- ► Shift to neutral.
- Release the brake pedal.
- ► Tow-start the vehicle.
- ▶ Shift to second gear.
- Release the clutch pedal slowly; do not depress the accelerator pedal while doing so.

The engine is started.

- Depress the clutch pedal and shift to neutral.
- Stop at a suitable place.
- Depress the parking brake.
- ▶ Remove the rigid towing bar or towing rope.
- Remove the towing eye (\triangleright page 288).
- Switch off the hazard warning lamps.

Fuses

Important safety notes

Only use fuses that have been approved for Mercedes-Benz vehicles and that have the correct fuse rating for the systems concerned. Do not attempt to repair or bridge faulty fuses. Using fuses that have not been approved or attempting to repair or bridge faulty fuses could cause the fuse to be overloaded and result in a fire. Have the cause traced and rectified at a qualified specialist workshop.

The fuses in your vehicle serve to close down faulty circuits. If a fuse blows, all the

290 Fuses

components on the circuit and their functions stop operating.

Blown fuses must be replaced with fuses of the same rating, which you can recognize by the color and value. The fuse ratings are listed in the fuse allocation chart.

If a newly inserted fuse also blows, have the cause traced and rectified at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.

• Only use fuses that have been approved for Mercedes-Benz vehicles and which have the correct fuse rating for the system concerned. Otherwise, components or systems could be damaged.

Before changing a fuse

- Park the vehicle and apply the electric parking brake.
- ▶ Switch off all electrical consumers.
- Remove the SmartKey from the ignition lock.

The fuses are located in various fuse boxes:

- fuse box in the engine compartment on the left-hand side of the vehicle, when viewed in the direction of travel
- fuse box in the trunk behind the partition trim

The fuse allocation chart is located in the vehicle tool kit (\triangleright page 274) in the stowage compartment under the trunk floor.

Fuse box in the engine compartment

Make sure that the windshield wipers are turned off.

/ WARNING

Make sure that the windshield wipers are switched off and that the SmartKey is removed from the ignition lock before you open the cover of the fuse box. Otherwise, the windshield wipers and the wiper rods above the cover could be set in motion. This could lead to you or others being injured by the wiper rods.

► Open the hood (▷ page 260).




- Remove any existing moisture from the fuse box using a dry cloth.
- ▶ **To open:** open clamps (1).
- ▶ Remove fuse box cover ② forwards.
- Make sure that no moisture can enter the fuse box when the cover is open.
- ► To close: check whether the rubber seal is lying correctly in cover ②.
- Insert cover (2) at the rear of the fuse box into the retainer.
- ▶ Fold down cover ② and close clamps ①.
- The cover must be seated properly, otherwise moisture or dirt could impair the function of the fuses.
- ▶ Close the hood (▷ page 261).

Fuse box in the trunk

The fuse box is located in the trunk behind the partition covering.

• Open the trunk (\triangleright page 77).



- ► **To open:** release cover ① on the right and left-hand sides with a flat object.
- ► Open cover ① downwards in the direction of the arrow.

294
294
294
296
297
304
307
307
309
312
315
316

Useful information

This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.

I Please read the information on qualified specialist workshops (▷ page 23).

Important safety notes

MARNING

If wheels and tires of the wrong size are used, the wheel brakes or suspension components may be damaged. There is a risk of accident. Always replace wheels and tires with those that fulfill the specifications of the original part (designation, manufacturer, model).

A flat tire severely impairs the driving, steering and braking characteristics of the vehicle. There is a risk of accident.

Tires without run-flat characteristics:

- do not drive with a flat tire.
- immediately replace the flat tire with your emergency spare wheel or spare wheel, or consult a qualified specialist workshop.

Tires with run-flat characteristics:

• pay attention to the information and warning notices on MOExtended tires (tires with run-flat characteristics).

Accessories that are not approved for your vehicle by Mercedes-Benz or are not being used correctly can impair the operating safety.

Before purchasing and using non-approved accessories, visit a qualified specialist workshop and inquire about:

- suitability
- legal stipulations
- factory recommendations

Information on the dimensions and types of wheels and tires for your vehicle can be found in the "Wheel/tire combinations" section (> page 316).

Information on air pressure for the tires on your vehicle can be found:

- on the vehicle's Tire and Loading Information placard on the B-pillar
- on the tire pressure label on the fuel filler flap
- in the "Tire pressure" section

Pay special attention to the country-specific requirements for tire approval. These requirements can stipulate a specific tire type for your vehicle. Furthermore, the use of certain tire types in certain regions and areas of operation can be highly beneficial. You can find further information regarding tires at specialist tire retailers, at qualified specialist workshops or at any authorized Mercedes-Benz Center.

• Further information on wheels and tires can be obtained at any qualified specialist workshop.

Operation

Notes on driving

- If the vehicle is heavily laden, check the tire pressures and correct them if necessary.
- When parking your vehicle, make sure that the tires do not get deformed by the curb or other obstacles. If it is necessary to drive over curbs, speed humps or similar elevations, try to do so slowly and at an obtuse angle. Otherwise, the tires, particularly the sidewalls, can get damaged.

Notes on regularly inspecting wheels and tires

▲ WARNING

Damaged tires can cause tire inflation pressure loss. As a result, you could lose control of your vehicle. There is a risk of accident.

Check the tires regularly for signs of damage and replace any damaged tires immediately.

- Regularly check the wheels and tires of your vehicle for damage (e.g. cuts, punctures, tears, bulges on tires and deformation or cracks or severe corrosion on wheels) at least once a month, as well as after driving off-road or on rough roads. Damaged wheels can cause a loss of tire pressure.
- Regularly check the tire tread depth and the condition of the tread across the whole width of the tire (> page 295). If necessary, turn the front wheels to full lock in order to inspect the inner side of the tire surface.
- All wheels must have a valve cap to protect the valve against dirt and moisture. Do not mount anything onto the valve (such as tire pressure monitoring systems) other than the standard valve cap or other valve caps approved by Mercedes-Benz for your vehicle.
- Regularly check the pressure of all the tires including the emergency spare wheel or the spare wheel, particularly prior to long trips, and correct the pressure as necessary (▷ page 297).

Tire tread

▲ WARNING

Insufficient tire tread will reduce tire traction. The tire is no longer able to dissipate water. This means that on wet road surfaces, the risk of hydroplaning increases, in particular where speed is not adapted to suit the driving conditions. There is a risk of accident. If the tire pressure is too high or too low, tires may exhibit different levels of wear at different locations on the tire tread. Thus, you should regularly check the tread depth and the condition of the tread across the entire width of all tires.

Minimum tire tread depth for:

- Summer tires: 1/8 in (3 mm)
- M+S tires: 1/6 in (4 mm)

For safety reasons, replace the tires before the legally prescribed limit for the minimum tire tread depth is reached.

Tread wear indicators (TWI) are required by law. Six indicators are positioned on the tire tread. They are visible once the tread depth is approximately $\frac{1}{16}$ in (1.6 mm). If this is the case, the tire is so worn that it must be replaced.



Bar marking ① for tread wear is integrated into the tire tread.

Notes on selecting, mounting and replacing tires

- Only mount tires and wheels of the same type and make.
- Only mount tires of the correct size onto the wheels.
- After mounting new tires, run them in at moderate speeds for the first 60 miles (100 km) as they only reach their full performance after this distance.

296 Winter operation

- Do not drive with tires which have too little tread depth, as this significantly reduces the traction on wet roads (hydroplaning).
- Replace the tires after six years at the latest, regardless of wear. This also applies to the spare wheel/emergency spare wheel.

The service life of tires depends on the following factors amongst other things:

- driving style
- tire pressure
- distance covered

MOExtended tires (tires with run-flat properties)

MOExtended tires (tires with run-flat properties) allow you to continue driving your vehicle even if one or more tires are entirely deflated.

MOExtended tires may be used only in conjunction with the activated tire pressure loss warning system or the activated tire pressure monitoring system and only on wheels specifically tested by Mercedes-Benz.

Notes on driving with MOExtended tires in the event of a flat tire can be found in the "Breakdown assistance" section (> page 281).

Winter operation

Please bear the following in mind

Have your vehicle winterproofed at a qualified specialist workshop at the onset of winter.

Observe the notes in the "Changing a wheel" section (> page 315).

Driving with summer tires

At temperatures below 45 °F (+7 °C), the elasticity of summer tires and therefore also the traction and braking capability are reduced considerably. Mount M+S tires on

your vehicle. Using summer tires at very cold temperatures could cause cracks to form, thereby damaging the tires permanently. Mercedes-Benz cannot accept responsibility for this type of damage.

M+S tires

At temperatures below 45 °F (+7 °C), use winter tires or all-season tires. Both types of tire are identified by the M+S marking.

Only winter tires bearing the A snowflake symbol in addition to the M+S marking provide the best possible grip in wintry road conditions. Only these tires will allow driving safety systems such as ABS and ESP[®] to function optimally in winter. These tires have been developed specifically for driving in snow.

Use M+S tires of the same make and tread on all wheels to maintain safe handling characteristics.

M+S tires with a tire tread depth of less than $\frac{1}{6}$ in (4 mm) are not suitable for use in winter and do not provide sufficient traction. There is a risk of an accident.

M+S tires with a tread depth of less than $\frac{1}{6}$ in (4 mm) must be replaced immediately.

Always observe the maximum permissible speed specified for the M+S tires you have mounted.

When you have mounted M+S tires:

- Check the tire pressures (\triangleright page 301).
- ► Vehicles for USA: restart the tire pressure monitor (▷ page 301).

Drive no faster than 50 mph (80 km/h) with the spare wheel or emergency spare wheel mounted.

MARNING

The wheel or tire size as well as the tire type of the spare wheel or emergency spare wheel and the wheel to be replaced may differ. Mounting an emergency spare wheel may severely impair the driving characteristics. There is a risk of an accident.

To avoid hazardous situations:

- adapt your driving style accordingly and drive carefully.
- never install more than one spare wheel or emergency spare wheel that differs in size.
- only use a spare wheel or emergency spare wheel of a different size briefly.
- ${\ensuremath{^\circ}}$ do not switch ${\ensuremath{\mathsf{ESP}}}^{\ensuremath{\mathbb{R}}}$ off.
- have a spare wheel or emergency spare wheel of a different size replaced at the nearest qualified specialist workshop.
 Observe that the wheel and tire dimensions as well as the tire type must be correct.

Snow chains

For safety reasons, Mercedes-Benz recommends that you only use snow chains that have been specially approved for your vehicle by Mercedes-Benz, or are of a corresponding standard of quality.

- On some tire sizes there is not enough space for snow chains. To avoid damage to the vehicle or tires, observe the "Wheel and tire combinations" section under "Tires and wheels".
- only use snow chains when driving on roads completely covered by snow. Do not exceed the maximum permissible speed of 30 mph (50 km/h). Remove the snow chains as soon as possible if you are driving on roads that are no longer snow-covered.
- local regulations may restrict the use of snow chains. Observe the appropriate regulations if you wish to mount snow chains.
- snow chains may not be mounted on the emergency spare wheel.

If you intend to mount snow chains, please bear the following points in mind:

- snow chains may not be mounted on all wheel/tire combinations. Permitted wheel/tire combinations (▷ page 316).
- mount snow chains only in pairs and only on the rear wheels. Observe the manufacturer's mounting instructions.
- If snow chains are mounted on the front wheels, the snow chains could grind against the bodywork or components of the chassis. This could result in damage to the vehicle or the tires.
- Vehicles with steel wheels: if you wish to mount snow chains on steel wheels, make sure that you remove the respective wheels' hubcaps first. The hubcaps may otherwise be damaged.

You may wish to deactivate ESP[®](▷ page 58) when pulling away with snow chains mounted. This way you can allow the wheels to spin in a controlled manner, achieving an increased driving force (cutting action).

Tire pressure

Tire pressure specifications

Tires with tire pressures that are too low or too high are associated with the following hazards:

- they can burst, in particular if the vehicle is heavily laden or when driven at high speeds.
- the tires can wear excessively and/or unevenly, which can severely impair tire traction.
- the driving, steering and braking characteristics may be severely impaired.

There is a risk of accident.

Follow recommended tire inflation pressures and check the pressure of all the tires including the spare wheel:

- · monthly, at least
- if the load changes
- before beginning a long journey
- under different operating conditions, e.g. off-road driving

If necessary, correct the tire pressure.

The recommended tire pressures for the tires mounted at the factory can be found on the labels described here.

Option 1) **Tire and Loading Information placard** on the B-pillar on the driver's side of the vehicle (\triangleright page 304).

The Tire and Loading Information placard contains the recommended tire pressures for cold tires on a fully loaded vehicle and for the maximum permissible vehicle speed.

 The specifications given on the following Tire and Loading Information placard are examples. Tire pressure specifications are vehicle-specific and may deviate from the data shown here. The tire pressures applicable to your vehicle can be found on the Tire and Loading Information placard on your vehicle.

200	TIRA		RMATION ET LE CHARGEMENT
	EATING CARACITY NOMER OF PLACES	and the second second	MODLE 3] BEAR MILEU 3] ADDRESS 7
TINE PNEU	SIZE DIMENSIONS	COLD TIRE PRESSURE PRESSION DES PNEUS À FROID	SPE OWNER'S MANUAL FOR
FRONT	255/40 ZR 18 99Y 31	200 KPA, 29 PSI	ADDITIONAL INFORMATION
REAR Arhiére	285/35 ZR18 1017 XL	200 KPA, 29 PSI	VOIR LE MANUEL DE L'USAGER
SHARE DE SECOURS	175/55-1895P	420 KPA, 60 PSI	POUR PILUS DE RENSIGNEMENTS

P40.00-2205-31


① Recommended tire pressures

Option 2) **Tire pressure table** on the inside of the fuel filler flap.

The tire pressure table contains the recommended pressures for cold tires for

various operating conditions, i.e. differing load and speed conditions.


() Specifications shown in the examples of tire pressure tables are for illustration purposes only. Tire pressure specifications are vehicle-specific and may deviate from the data shown here. Tire pressure specifications applicable to your vehicle are located in your vehicle's tire pressure table.



P40.00-2179-31

Example: tire pressure table for all tires permitted for this vehicle by the factory

If a tire size precedes a tire pressure, the tire pressure information following is only valid for that tire size. The load conditions "partially laden" and "fully laden" are defined in the table for different numbers of occupants and amounts of luggage. The actual number of seats may differ.



Example: tire pressure table with tire dimensions

Some tire pressure tables show only the rim diameters instead of the full tire size, e.g. **R18**. The rim diameter is part of the tire size

Tire pressure 299

and can be found on the tire sidewall (\triangleright page 309).



If the tire pressures have been set to the lower values for lighter loads and/or lower road speeds, the pressures should be reset to the higher values:

- if you want to drive with an increased load and/or
- if you want to drive at higher road speeds.
- The tire pressures for increased loads and/or higher road speeds, shown in the tire pressure table, may have a negative effect on driving comfort.

Option 3) The **tire pressure for the emergency/collapsible spare wheel** (depending on vehicle equipment) can be found:

- printed in yellow on the rim of the emergency/collapsible spare wheel
- in the "Wheel and tire combinations" section (▷ page 316) in this Operator's Manual
- on the Tire and Loading Information placard on the B-pillar on the driver's side.

If the tire pressure is not set correctly, this can lead to an excessive build up of heat and a sudden loss of pressure.

For more information, contact a qualified specialist workshop.

Important notes on tire pressure

If the tire pressure drops repeatedly, the wheel, valve or tire may be damaged. Tire pressure that is too low may result in a tire blow-out. There is a risk of an accident.

- Check the tire for foreign objects.
- Check whether the wheel is losing air or the valve is leaking.

If you are unable to rectify the damage, contact a qualified specialist workshop.

If you fit unsuitable accessories onto tire valves, the tire valves may be overloaded and malfunction, which can cause tire pressure loss. Due to their design, retrofitted tire pressure monitors keep the tire valve open. This can also result in tire pressure loss. There is a risk of an accident.

Only screw the standard valve cap or other valve caps approved by Mercedes-Benz for your vehicle onto the tire valve.

To test tire pressure, use a suitable tire pressure gauge. The outer appearance of a tire does not permit any reliable conclusion about the tire pressure. On vehicles equipped with the electronic tire pressure monitoring system, the tire pressure can be checked using the on-board computer.

The tire temperature and pressure increase when the vehicle is in motion. This is dependent on the driving speed and the load. Therefore, you should only correct tire pressures when the tires are cold.

The tires are cold:

- if the vehicle has been parked without direct sunlight on the tires for at least three hours and
- if the vehicle has not been driven further than 1 mile (1.6 km)

The tire temperature changes depending on the outside temperature, the vehicle speed and the tire load. If the tire temperature changes by 18 °F (10 °C), the tire pressure changes by approximately 10 kPa (0.1 bar/ 1.5 psi). Take this into account when checking the pressure of warm tires and only correct the tire pressure if it is too low for the current operating conditions. If you check the tire pressure when the tires are warm, the resulting value will be higher than if the tires were cold. This is normal. Do not reduce the tire pressure to the value specified for cold tires. The tire pressure would otherwise be too low.

Observe the recommended tire pressures for cold tires:

- on the Tire and Loading Information placard on the B-pillar on the driver's side
- in the tire pressure table on the inside of the fuel filler flap
- printed in yellow on the rim of the emergency/collapsible spare wheel (depending on vehicle equipment)

Underinflated or overinflated tires

Underinflation

₼ WARNING

Tires with pressure that is too low can overheat and burst as a consequence. In addition, they also suffer from excessive and/ or irregular wear, which can severely impair the braking properties and the driving characteristics. There is a risk of an accident. Avoid tire pressures that are too low in all the tires, including the spare wheel.

Underinflated tires may:

- wear quickly and unevenly
- have an adverse effect on fuel consumption
- overheat, leading to tire defects
- have an adverse effect on handling characteristics

Overinflation

▲ WARNING

Tires with excessively high pressure can burst because they are damaged more easily by road debris, potholes etc. In addition, they also suffer from irregular wear, which can severely impair the braking properties and the driving characteristics. There is a risk of an accident.

Avoid tire pressures that are too high in all the tires, including the spare wheel.

Overinflated tires may:

- have an adverse effect on handling characteristics
- wear quickly and unevenly
- · be more susceptible to damage
- have an adverse effect on ride comfort
- increase the braking distance

Maximum tire pressures

Never exceed the maximum permissible tire inflation pressure. Always observe the recommended tire pressure for your vehicle when adjusting the tire pressure (> page 297).



- Example: maximum permissible tire pressure
- **1** The actual values for tires are vehiclespecific and may deviate from the values in the illustration.

Tire pressure 301

Checking the tire pressures

Important safety notes

Observe the "Tire pressure information" section (\triangleright page 297).

Information on air pressure for the tires on your vehicle can be found:

- on the vehicle's Tire and Loading Information placard on the B-pillar
- on the tire pressure label on the fuel filler flap
- in the "Tire pressure information" section

Checking tire pressures manually

To determine and set the correct tire pressure, proceed as follows:

- Remove the valve cap of the tire that is to be checked.
- Press the tire pressure gauge securely onto the valve.
- Read the tire pressure and compare it with the recommended value on the Tire and Loading Information placard on the B-pillar on the driver's side of your vehicle.
- If necessary, increase the tire pressure to the recommended value (▷ page 297).
- If the tire pressure is too high, release air by pressing down the metal pin in the valve using the tip of a pen, for example. Then check the tire pressure again using the tire pressure gauge.
- Screw the valve cap onto the valve.
- ▶ Repeat these steps for the other tires.

Tire pressure monitor (USA only)

Important safety notes

It is the driver's responsibility to set the tire pressure to that recommended for cold tires which is suitable for the operating situation (\triangleright page 297). Note that the correct tire pressure for the current operating situation must first be taught-in to the tire pressure

monitor. If there is a substantial loss of pressure, the warning threshold for the warning message is aligned to the reference values taught-in. Restart the tire pressure monitor after adjusting the pressure of the cold tires (▷ page 303). The current pressures are saved as new reference values. As a result, a warning message will appear if the tire pressure drops significantly.

The tire pressure monitor does not warn you of an incorrectly set tire pressure. Observe the notes on the recommended tire pressure (> page 297).

The tire pressure monitor is not able to warn you of a sudden loss of pressure, e.g. if the tire is penetrated by a foreign object. In the event of a sudden loss of pressure, bring the vehicle to a halt by braking carefully. Avoid abrupt steering maneuvers.

If a tire pressure monitor system is installed, the vehicle's wheels have sensors that monitor the tire pressures in all four tires. The tire pressure monitor warns you if the pressure drops in one or more of the tires. The tire pressure monitor only functions if the correct sensors are installed to all wheels.

The tire pressure monitor has a yellow warning lamp in the instrument cluster for indicating pressure loss or a malfunction. Whether the warning lamp flashes or lights up indicates whether a tire pressure is too low or the tire pressure monitoring system is malfunctioning:

- if the warning lamp is lit continuously, the tire pressure on one or more tires is significantly too low. The tire pressure monitor is not malfunctioning.
- if the warning lamp flashes for around a minute and then remains lit constantly, the tire pressure monitor is malfunctioning.

▲ WARNING

Each tire, including the spare (if provided), should be checked at least once a month when cold and inflated to the pressure recommended by the vehicle manufacturer on the Tire and Loading Information placard on the driver's door B-pillar or the tire pressure label on the inside of the fuel filler flap. If your vehicle has tires of a different size than the size indicated on the Tire and Loading Information placard or the tire pressure label, you should determine the proper tire pressure for those tires.

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale when one or more of your tires are significantly underinflated. Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly underinflated tire causes the tire to overheat and can lead to tire failure. Underinflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability.

Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if underinflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale.

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate if the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the warning lamp will flash for approximately a minute and then remain continuously illuminated. This sequence will be repeated every time the vehicle is started as long as the malfunction exists.

When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of incompatible replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly. Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

If the tire pressure monitor is malfunctioning, it may take more than ten minutes for the tire pressure warning lamp to inform you of the malfunction by flashing for approximately one minute and then remaining lit.

When the malfunction has been rectified, the tire pressure warning lamp goes out after a few minutes of driving.

Information on tire pressures is displayed in the multifunction display. After a few minutes of driving, the current tire pressure of each tire is shown in the multifunction display.

The tire pressure values indicated by the on-board computer may differ from those measured at a gas station with a pressure gauge. The tire pressures shown by the onboard computer refer to those measured at sea level. At high altitudes, the tire pressure values indicated by a pressure gauge are higher than those shown by the on-board computer. In this case, do not reduce the tire pressures.

The operation of the tire pressure monitor can be affected by interference from radio transmitting equipment (e.g. radio headphones, two-way radios) that may be being operated in or near the vehicle.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and

2. this device must accept any interference received, including interference that may cause undesired operation of the device.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

Checking tire pressure electronically

- ► Make sure that the SmartKey is in position 2(▷ page 131) in the ignition lock.
- Press the or button on the steering wheel to select the Service menu.
- ► Press the ▲ or ▼ button to select Tire Pressure.
- Press the OK button. The current tire pressure for each wheel will be displayed in the multifunction display.

If the vehicle has been parked for longer than 20minutes, the Tire pressure will be displayed after driving a few minutes message appears.

After a teach-in period, the tire pressure monitor automatically recognizes new wheels or new sensors. As long as a clear allocation of the tire pressure values to the individual wheels is not possible, the **Tire Pressure Monitor Active** display message is shown instead of the tire pressure display. The tire pressures are already being monitored.

If a spare wheel/emergency spare wheel is mounted, the system may continue to show the tire pressure of the wheel that has been removed for a few minutes. If this occurs, note that the value displayed for the position where the spare tire is mounted is not the same as the spare wheel/emergency spare wheel's current tire pressure.

Tire pressure monitor warning messages

If the tire pressure monitor detects a significant pressure loss on one or more tires, a warning message is shown in the multifunction display. A warning tone also sounds and the tire pressure warning lamp lights up in the instrument cluster.

Each tire that is affected by a significant loss of pressure is highlighted with a color.

If the **Correct tire pressure** message appears in the multifunction display:

- Check the tire pressure on all four wheels and correct it if necessary.
- If the wheel positions on the vehicle are interchanged, the tire pressures may be displayed for the wrong positions for a short time. This is rectified after a few minutes of driving, and the tire pressures are displayed for the correct positions.

Restarting the tire pressure monitor

When you restart the tire pressure monitor, all existing warning messages are deleted and the warning lamps go out. The monitor uses the currently set tire pressures as the reference values for monitoring. In most cases, the tire pressure monitoring system recognizes the new reference values automatically.

However, you can also define reference values manually as described here:

Set the tire pressure to the value recommended for the corresponding driving situation on the vehicle's Tire and Loading Information placard on the driver's side B-pillar(▷ page 297).

Additional tire pressure values for driving at high speeds or with heavy loads can be found in the tire pressure table on the inside of the fuel filler flap.

- Make sure that the tire pressure is correct on all four wheels.
- Make sure that the SmartKey is in position
 2 in the ignition lock.
- Press the or button on the steering wheel to select the Service menu.
- ► Press the ▲ or ▼ button to select Tire Pressure.
- Press the OK button. The multifunction display shows the current tire pressure of the individual tires or the Tire pressure will be

displayed after driving a few minutes message.

 Press the volume button.
 The Use Current Pressures as New Reference Values message appears in the multifunction display.

If you wish to confirm the restart:

Press the OK button. The Tire Press. Monitor Restarted message appears in the multifunction display.

After driving for a few minutes, the system checks whether the current tire pressures are within the specified range. The new tire pressures are then accepted as reference values and monitored.

If you wish to cancel the restart:

Press the <u></u>button. The tire pressure values stored at the last restart will continue to be monitored.

Loading the vehicle

Instruction labels for tires and loads

MARNING


Overloaded tires can overheat, causing a blowout. Overloaded tires can also impair the steering and driving characteristics and lead to brake failure. There is a risk of accident. Observe the load rating of the tires. The load rating must be at least half of the GAWR of your vehicle. Never overload the tires by exceeding the maximum load.

Two instruction labels on your vehicle show the maximum possible load.

(1) The Tire and Loading Information placard is on the B-pillar on the driver's side. The Tire and Loading Information placard shows the maximum permissible number of occupants and the maximum permissible vehicle load. It also contains details of the tire sizes and corresponding pressures for tires installed at the factory.

(2) The vehicle identification plate is on the B-pillar on the driver's side. The vehicle identification plate informs you of the gross vehicle weight rating. It is made up of the vehicle weight, all vehicle occupants, the fuel and the cargo. You can also find information about the maximum gross axle weight rating on the front and rear axle.

The maximum gross axle weight rating is the maximum weight that can be carried by one axle (front or rear axle). Never exceed the maximum load or the maximum gross axle weight rating for the front or rear axle.



① B-pillar, driver's side

Maximum permissible load

 The specifications shown on the Tire and Loading Information placard in the illustration are examples. The maximum permissible load is vehicle-specific and may deviate from the data shown here. The maximum permissible load that applies for your vehicle can be found on your vehicle's Tire and Loading Information placard.



P40.00-2206-31

Specification for maximum permissible load ① is listed on the Tire and Loading Information placard: "The gross weight of occupants and luggage must not exceed XXX kg or XXX lbs."

The gross weight of all vehicle occupants, load, luggage and trailer load/noseweight (if applicable) must not exceed the specified value.

Number of seats

 The specifications shown on the Tire and Loading Information placard in the illustration are examples. The number of seats is vehicle-specific and can differ from the details shown. The number of seats in your vehicle can be found on the Tire and Loading Information placard.

6.9	RENSEIGNEMENT	DADING INFO	
	SEATING CARACITY NOMBRE DE PLACES	DIAL 7 FHONT 2	MIDDLE 3 REAR
The command a	anight of occupants and o	ange afmilie never excise	XXX Ag ou XXX
TIDE ENELI	SIZE DMSN6108S	INCLOTINE INTERSURE PRESSION DES INVELSA FROID	SEE OWNER'S MANUAL FOR
FIIDNO.	255/40 ZR 10 979 KL	200 KPA, 29 PS1	ADDITIONAL INFORMATION
REAR ARRIERE	205/205 ZRIN (D1YXL	200 (GVA, 29 PSI	VOIR LE MANUEL DE L'USAGER
SEARE De àecours	(75755-1875P	420 KML 30 PSI	POUR PLUS DE RENSIGNEMENTS

P40.00-2207-31

Maximum number of seats ① determines the maximum number of occupants allowed to travel in the vehicle. This information can be found on the Tire and Loading Information placard.

Determining the correct load limit

Step-by-step instructions

The following steps have been developed as required of all manufacturers under Title 49, Code of U.S. Federal Regulations, Part 575 pursuant to the "National Traffic and Motor Vehicle Safety Act of 1966".

- Step 1: Locate the statement "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs." on your vehicle's Tire and Loading Information placard.
- Step 2: Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- Step 3: Subtract the combined weight of the driver and passengers from XXX kilograms or XXX lbs.
- Step 4: The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the "XXX" amount equals 1400 lbs and there will be five 150 lbs passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs (1 400 - 750 (5 x 150) = 650 lbs).
- Step 5: Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in step 4.
- ▶ Step 6 (if applicable): If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle (▷ page 307).

Wheels and tires

Example: steps 1 to 3

The following table shows examples on how to calculate total and cargo load capacities with varying seating configurations and number and size of occupants. The following examples use a load limit of 1 500 lbs (680 kg). **This is for illustration purposes only.** Make sure you are using the actual load limit for your vehicle stated on your vehicle's Tire and Loading Information placard (▷ page 305).

		Example 1	Example 2
Step 1	Combined maximum weight of occupants and cargo (data from the Tire and Loading Information placard)	1500 lbs (680 kg)	1500 lbs (680 kg)

		Example 1	Example 2
Step 2	Number of people in the vehicle (driver and occupants)	1	2
	Weight of the occupants	Occupant 1: 175 lbs (80 kg)	Occupant 1: 175 lbs (80 kg) Occupant 2: 195 lbs) (88 kg
	Gross weight of all occupants	175 lbs (80 kg)	370 lbs (168 kg)
		Example 1	Example 2
Step 3	Permissible load and trailer load/noseweight (maximum permissible load rating from the Tire and Loading Information placard minus the gross weight of all occupants)	1500 lbs (680 kg) - 175 lbs (80 kg) = 1325 lbs (600 kg)	1500 lbs (680 kg) - 370 lbs (168 kg) = 1130 lbs (512 kg)

The higher the weight of all the occupants, the smaller the maximum load for luggage. Further information can be found under "Towing a trailer" (\triangleright page 307).

Vehicle identification plate

Even if you have calculated the total load carefully, you should still make sure that the gross vehicle weight rating and the gross axle weight rating are not exceeded. Details can be found on the vehicle identification plate on the B-pillar on the driver's side of the vehicle (\triangleright page 304). **Permissible gross vehicle weight:** the gross weight of the vehicle, all passengers, load and trailer load/noseweight (if applicable) must not exceed the permissible gross vehicle weight.

Gross axle weight rating: the maximum permissible weight that can be carried by one axle (front or rear axle).

To ensure that your vehicle does not exceed the maximum permissible values (gross vehicle weight and maximum gross axle weight rating), have your loaded vehicle (including driver, occupants, cargo, and full trailer load if applicable) weighed on a suitable vehicle weighbridge.

Trailer load/noseweight

The trailer load/noseweight affects the gross weight of the vehicle. If a trailer is attached, the trailer load/noseweight is included in the load along with occupants and luggage. The trailer load/noseweight is usually approximately 10% of the gross weight of the trailer and its load.

Your Mercedes-Benz has been designed primarily to carry passengers and their luggage. Mercedes-Benz does not recommend towing a trailer with your vehicle.

Maximum load rating

Do not overload the tires by exceeding the specified load limit. The maximum permissible load can be found on the vehicle's Tire and Loading Information placard on the B-pillar on the driver's side (> page 304).




1 The actual values for tires are vehiclespecific and may deviate from the values in the illustration.

Maximum tire load ① is the maximum permissible weight for which the tire is approved.

Uniform Tire Quality Grading Standards

Overview of Tire Quality Grading Standards



Uniform Tire Quality Grading Standards are U.S. government specifications. Their purpose is to provide drivers with uniform reliable information on tire performance data. Tire manufacturers have to grade tires using three performance factors: tread wear (1), tire traction (2), and heat resistance (3). All tires sold in North America are provided with the corresponding quality class mark on the sidewall of the tire, even though these regulations do not apply to Canada.

308 Uniform Tire Quality Grading Standards

The actual values for tires are vehiclespecific and may deviate from the values in the illustration.

Where applicable, the tire grading information can be found on the tire sidewall between the tread shoulder and maximum tire width.

For example:

Tread wear	Traction	Temperature
200	AA	А

All passenger car tires must conform to the statutory safety requirements in addition to these grades.

Tread wear

The tread wear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified U.S. government course. For example, a tire graded 150 would wear one and one-half times as well on the government course as a tire graded 100.

The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm, due to variations in driving habits, service practices and differences in road characteristics and climate conditions.

Traction

The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

The traction grades, from highest to lowest, are AA, A, B, and C. Those grades represent the tire's ability to stop on a wet surface as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.

The safe speed on a wet, snow covered or icy road is always lower than on dry road surfaces.

You should pay special attention to road conditions when temperatures are around the freezing point.

Mercedes-Benz recommends a minimum tread depth of ¼ in (4 mm) for all four winter tires (▷ page 296) to maintain normal driving characteristics in winter. Winter tires can reduce the braking distance on snow-covered surfaces in comparison with summer tires. Stopping distance, however, is still considerably greater than when the road is not covered with ice or snow. Take appropriate care when driving.

Avoid wheelspin. This can lead to damage to the drive train.

Temperature

▲ WARNING


The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause excessive heat build-up and possible tire failure.

The temperature grades are A (the highest), B, and C. These represent the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

Tire labeling

Tire labeling overview

The following markings are on the tire in addition to the tire name (sales designation) and the manufacturer's name:



- Uniform tire Quality Grading Standard (▷ page 313)
- ② DOT, Tire Identification Number (▷ page 311)
- ③ Maximum tire load (▷ page 307)
- ④ Maximum tire pressure (▷ page 300)
- ⑤ Manufacturer
- (i) Tire material (▷ page 312)
- ⑦ Tire size designation, load-bearing capacity and speed rating (▷ page 309)
- ⑧ Load index (▷ page 311)
- Tire name
- Tire data is vehicle-specific and may deviate from the data in the example.

Tire size designation, load-bearing capacity and speed rating



- 1 Tire width
- ② Nominal aspect ratio in %
- ③ Tire code
- ④ Rim diameter
- ⑤ Load bearing index
- 6 Speed rating
- **1** Tire data is vehicle-specific and may deviate from the data in the example.

General: depending on the manufacturer's standards, the size imprinted in the tire wall may not contain any letters or may contain one letter that precedes the size description.

If there is no letter preceding the size description (as shown above): these are passenger vehicle tires according to European manufacturing standards.

If "P" precedes the size description: these are passenger vehicle tires according to U.S. manufacturing standards.

If "LT" precedes the size description: these are light truck tires according to U.S. manufacturing standards.

If "T" precedes the size description: these are compact emergency spare wheels at high tire pressure, to be used only temporarily in an emergency.

Tire width: tire width ① shows the nominal tire width in millimeters.

Height-width ratio: aspect ratio ② is the size ratio between the tire height and tire width and is shown in percent. The aspect

Wheels and tires

ratio is calculated by dividing the tire width by the tire height.

Tire code: tire code ③ specifies the tire type. "R" represents radial tires; "D" represents diagonal tires; "B" represents diagonal radial tires.

Optionally, tires with a maximum speed of over 149mph (240km/h) may have "ZR" in the size description, depending on the manufacturer (e.g. 245/40 ZR 18).

Rim diameter: rim diameter ④ is the diameter of the bead seat, not the diameter of the rim flange. The rim diameter is specified in inches (in).

Load-bearing index: load-bearing index (5) is a numerical code that specifies the maximum load-bearing capacity of a tire.

Do not overload the tires by exceeding the specified load limit. The maximum permissible load can be found on the vehicle's Tire and Loading Information placard on the B-pillar on the driver's side (\triangleright page 304).

Example:

A load-bearing index of 91 indicates a maximum load of 1,356lb (615kg) that can be carried by the tires. For further information on the maximum tire load in kilograms and pounds, see (\triangleright page 307).

For further information on the load-bearing index, see Load index (\triangleright page 311).

Speed rating: speed rating (6) specifies the approved maximum speed of the tire.

MARNING

Exceeding the stated tire load-bearing capacity and the approved maximum speed could lead to tire damage or the tire bursting. There is a risk of accident.

Therefore, only use tire types and sizes approved for your vehicle model. Observe the tire load rating and speed rating required for your vehicle.

Regardless of the speed rating, always observe the speed limits. Drive carefully and

adapt your driving style to the traffic conditions.

Summer tires			
Index	Speed rating		
Q	up to 100mph (160 km/h)		
R	up to 106mph (170 km/h)		
S	up to 112mph (180 km/h)		
Т	up to 118mph (190 km/h)		
Н	up to 130mph (210 km/h)		
V	up to 149mph (240 km/h)		
W	up to 168mph (270 km/h)		
Y	up to 186mph (300 km/h)		
ZRY	up to 186mph (300 km/h)		
ZR(Y)	over 186mph (300 km/h)		
ZR	over 149mph (240 km/h)		

- Optionally, tires with a maximum speed of over 149 mph (240km/h) may have "ZR" in the size description, depending on the manufacturer (e.g. 245/40 ZR 18).
 The service specification is made up of load-bearing index (5) and speed rating (6).
- If the size description of your tire includes "ZR" and there are no service specifications, ask the tire manufacturer in order to find out the maximum speed.

If a service specification is available, the maximum speed is limited according to the speed rating in the service specification. Example: 245/40 ZR 18 97 Y. In this example, "97 Y" is the service specification. The letter "Y" represents the speed rating and the maximum speed of the tire is limited to 186 mph (300km/h).

 The size description for all tires with maximum speeds of over 186mph (300km/h) must include "ZR", and the service specification must be given in

Tire labeling 311

brackets. Example: 275/40 ZR 18 (99 Y). The speed rating "(Y)" indicates that the maximum speed of the tire is over 186mph (300km/h). Ask the tire manufacturer about the maximum speed.

All-weather tires and winter tires			
Index	Speed rating		
Q M+S ²⁰	up to 100mph (160 km/h)		
T M+S ²⁰	up to 118mph (190 km/h)		
H M+S ²⁰	up to 130mph (210 km/h)		
V M+S ²⁰	up to 149mph (240 km/h)		

O Not all tires with the M+S marking provide the driving characteristics of winter tires. In addition to the M+S marking, winter tires also have the ▲ snowflake symbol on the tire wall. Tires with this marking fulfill the requirements of the Rubber Manufacturers Association (RMA) and the Rubber Association of Canada (RAC) regarding snow traction, and were specially developed for driving on snow.

An electronic speed limiter prevents your vehicle from exceeding the following speeds:

- all vehicles (except AMG vehicles): 130 mph (210 km/h)
- AMG vehicles: 155 mph (250 km/h)
- AMG vehicles with Handling Package: 174 mph (280 km/h)

The speed rating of tires mounted at the factory may be higher than the maximum speed that the electronic speed limiter permits.

Make sure that your tires have the required speed rating for your vehicle as specified in the "Tires" section (\triangleright page 316), e.g. if you buy new tires.

Further information about reading tire data can be obtained from any qualified specialist workshop.

Load index



1 Tire data is vehicle-specific and may deviate from the data in the example.

In addition to the load bearing index, load index (1) may be imprinted after the letters that identify speed rating (6) (\triangleright page 309) on the sidewall of the tire.


- If no specification is given: no text (as in the example above), represents a standard load (SL) tire
- XL or Extra Load: represents a reinforced tire
- Light load: represents a light load tire
- C, D, E: represents a load range that depends on the maximum load that the tire can carry at a certain pressure

DOT, Tire Identification Number (TIN)

U.S. tire regulations prescribe that every manufacturer of new tires or retreader has to imprint a TIN in or on the sidewall of each tire produced.

²⁰ Or M+S 🛕 for winter tires.

312 Definition of terms for tires and loading



The TIN is a unique identification number. The TIN enables the tire manufacturers to inform purchasers of recalls and other safetyrelevant matters. It makes it possible for the purchaser to easily identify the affected tires. The TIN is made up of manufacturer identification code (2), tire size (3), tire type code (4) and manufacturing date (5).

1 Tire data is vehicle-specific and may deviate from the data in the example.

DOT (Department of Transportation): tire symbol (1) indicates that the tire complies with the requirements of the U.S. Department of Transportation.

Manufacturer identification code:


manufacturer identification code (2) provides details on the tire manufacturer. New tires have a code with two symbols. Retreaded tires have a code with four symbols.

Further information about retreaded tires (▷ page 294).

Tire size: identifier (3) describes the tire size.

Tire type code: tire type code ④ can be used by the manufacturer as a code to describe specific characteristics of the tire.

Date of manufacture: date of manufacture (5) provides information about the age of a tire. The first and second positions represent the week of manufacture, starting with "01" for the first calendar week. Positions three and four represent the year of manufacture. For example, a tire that is marked with "3208", was manufactured in week 32 in 2008.





1 Tire data is vehicle-specific and may deviate from the data in the example.

This information describes the tire cord and the number of layers in sidewall (1) and under the tread (2).

Definition of terms for tires and loading

Tire ply composition and material used

Describes the number of plies or the number of layers of rubber-coated fabric in the tire tread and sidewall. These are made of steel, nylon, polyester and other materials.

Bar

Metric unit for tire pressure.

14.5038 pounds per square inch (psi) and 100 kilopascals (kPa) are the equivalent of 1 bar.

DOT (Department of Transportation)

DOT marked tires fulfill the requirements of the United States Department of Transportation.

Normal occupant weight

The number of occupants the vehicle is designed to seat, multiplied by 68 kilograms (150 lb).

Uniform Tire Quality Grading Standards

A uniform standard to grade the quality of tires with regards to tread quality, tire traction and temperature characteristics. Ratings are determined by tire manufacturers using U.S. government testing procedures. The ratings are molded into the sidewall of the tire.

Recommended tire pressure

The recommended tire pressure applies to the tires mounted at the factory.

The Tire and Loading Information placard contains the recommended tire pressures for cold tires on a fully loaded vehicle and for the maximum permissible vehicle speed.

The tire pressure table contains the recommended pressures for cold tires for various operating conditions, i.e. differing load and speed conditions.

Increased vehicle weight due to optional equipment

This is the combined weight of all standard and optional equipment available for the vehicle, regardless of whether it is actually installed on the vehicle or not.

Rim

This is the part of the wheel on which the tire is mounted.

GAWR (Gross Axle Weight Rating)

The GAWR is the maximum permissible axle load. The actual load on an axle must never exceed the gross axle weight rating. The gross axle weight rating can be found on the vehicle identification plate on the B-pillar on the driver's side.

Speed rating

The speed rating is part of the tire identification. It specifies the speed range for which the tire is approved.

GVW (Gross Vehicle Weight)

The gross vehicle weight includes the weight of the vehicle including fuel, tools, the spare wheel, accessories installed, occupants, luggage and the drawbar noseweight, if applicable. The gross vehicle weight must not exceed the gross vehicle weight rating GVWR as specified on the vehicle identification plate on the B-pillar on the driver's side.

Wheels and tires

GVWR (Gross Vehicle Weight Rating)

The GVWR is the maximum permissible gross weight of a fully loaded vehicle (the weight of the vehicle including all accessories, occupants, fuel, luggage and the drawbar noseweight, if applicable). The gross vehicle weight rating is specified on the vehicle identification plate on the B-pillar on the driver's side.

Maximum loaded vehicle weight

The maximum weight is the sum of the curb weight of the vehicle, the weight of the accessories, the total load limit and the weight of the optional equipment installed at the factory.

314 Definition of terms for tires and loading

Kilopascal (kPa)

Metric unit for tire pressure. 6.9 kPa corresponds to 1 psi. Another unit for tire pressure is bar. There are 100 kilopascals (kPa) to 1 bar.

Load index

In addition to the load-bearing index, the load index may also be imprinted on the sidewall of the tire. This specifies the load-bearing capacity more precisely.

Curb weight

The weight of a vehicle with standard equipment including the maximum capacity of fuel, oil and coolant. It also includes the airconditioning system and optional equipment if these are installed in the vehicle, but does not include passengers or luggage.

Maximum load rating

The maximum load rating in kilograms or pounds is the maximum weight for which a tire is approved.

Maximum permissible tire pressure

Maximum permissible tire pressure for one tire.

Maximum load on one tire

Maximum load on one tire. This is calculated by dividing the maximum axle load of one axle by two.

PSI (pounds per square inch)

A standard unit of measure for tire pressure.

Aspect ratio

Relationship between tire height and tire width in percent.

Tire pressure

This is pressure inside the tire applying an outward force to each square inch of the tire's surface. The tire pressure is specified in pounds per square inch (psi), in kilopascal (kPa) or in bar. The tire pressure should only be corrected when the tires are cold.

Tire pressure of cold tires

The tires are cold:

- if the vehicle has been parked without direct sunlight on the tires for at least three hours and
- if the vehicle has not been driven more than 1 mile (1.6 km).

Tread

The part of the tire that comes into contact with the road.

Bead

The tire bead ensures that the tire sits securely on the wheel. There are several steel wires in the bead to prevent the tire from coming loose from the wheel rim.

Sidewall

The part of the tire between the tread and the bead.

Weight of optional extras

The combined weight of those optional extras that weigh more than the replaced standard part and more than 2.3 kg (5 lb). These optional extras, such as high-performance brakes, level control, a roof rack or a highperformance battery, are not included in the curb weight and the weight of the accessories.

TIN (Tire Identification Number)

This is a unique identifier which can be used by a tire manufacturer to identify tires, for example for a product recall, and thus identify the purchasers. The TIN is made up of the manufacturer's identification code, tire size, tire type code and the manufacturing date.

Load bearing index

The load bearing index (also load index) is a code that contains the maximum load bearing capacity of a tire.

Traction

Traction is the result of friction between the tires and the road surface.

Treadwear indicators

Narrow bars (tread wear bars) that are distributed over the tire tread. If the tire tread is level with the bars, the wear limit of $\frac{1}{16}$ in (1.6 mm) has been reached.

Occupant distribution

The distribution of occupants in a vehicle at their designated seating positions.

Total load limit

Rated cargo and luggage load plus 68 kilograms (150 lb), multiplied by the vehicle's designated seating capacity.

Changing a wheel

Flat tire

The "Breakdown assistance" section (▷ page 275) contains information and notes on how to deal with a flat tire. It also provides instructions on changing a wheel or mounting the spare wheel/emergency spare wheel.

Interchanging the wheels

Interchanging the front and rear wheels may severely impair the driving characteristics if the wheels or tires have different dimensions. The wheel brakes or suspension components may also be damaged. There is a risk of accident.

Rotate front and rear wheels only if the wheels and tires are of the same dimensions.

Always pay attention to the instructions and safety notes in the "Changing tires and mounting the spare wheel" section (> page 276).

The wear patterns on the front and rear tires differ, depending on the operating conditions. Rotate the wheels before a clear wear pattern has formed on the tires. Front tires typically wear more on the shoulders and the rear tires in the center.

If your vehicle's tire configuration allows, you can rotate the wheels according to the intervals in the tire manufacturer's warranty book in your vehicle documents. If this is not available, the tires should then be replaced every 3000 to 6000 miles (5000 to 10,000 km), or earlier if the tire wear requires this. Do not change the direction of wheel rotation.

Clean the contact surfaces of the wheel and the brake disc thoroughly every time a wheel is interchanged. Check the tire pressures. For information on changing tires and mounting the spare wheel, see (\triangleright page 276).

316 Wheel and tire combinations

On vehicles equipped with a tire pressure monitor, electronic components are located in the wheel.

Tire-mounting tools should not be used near the valve. This could damage the electronic components.

Only have tires changed at a qualified specialist workshop.

Direction of rotation

Tires with a specified direction of rotation have additional benefits, e.g. if there is a risk of hydroplaning. You will only gain these benefits if the correct direction of rotation is maintained.

An arrow on the sidewall of the tire indicates its correct direction of rotation.

You may mount a spare wheel/emergency spare wheel against the direction of rotation. Observe the time restriction on use as well as the speed limit specified on the spare wheel/ emergency spare wheel.

Storing wheels

Store wheels that are not being used in a cool, dry and preferably dark place. Protect the tires from oil, grease, gasoline and diesel.

Cleaning the wheels

▲ WARNING

Do not use power washers with circular-jet nozzles (dirt grinders) to clean your vehicle, in particular the tires. You could otherwise damage the tires and cause an accident.

Wheel and tire combinations

Please bear the following in mind

For safety reasons, Mercedes-Benz recommends that you only use tires and wheels which have been approved by Mercedes-Benz specifically for your vehicle.

These tires have been specially adapted for use with the control systems, such as ABS or ESP[®], and are marked as follows:

- MO = Mercedes-Benz Original
- MOE = Mercedes-Benz Original Extended (tires featuring run-flat characteristics)
- MO1 = Mercedes-Benz Original (only certain AMG tires)

Mercedes-Benz Original Extended tires may only be used on wheels that have been specifically approved by Mercedes-Benz.

Only use tires, wheels or accessories tested and approved by Mercedes-Benz. Certain characteristics, e.g. handling, vehicle noise emissions or fuel consumption, may otherwise be adversely affected. In addition, when driving with a load, tire dimension variations could cause the tires to come into contact with the bodywork and axle components. This could result in damage to the tires or the vehicle.

Mercedes-Benz accepts no liability for damage resulting from the use of tires, wheels or accessories other than those tested and approved.

Information on tires, wheels and approved combinations can be obtained from any qualified specialist workshop.

- The recommended pressures for various operating conditions can be found:
 - on the Tire and Loading Information placard with the recommended tire pressures on the B-pillar on the driver's side
 - in the tire pressure table on the inside of the fuel filler flap

Observe the notes on recommended tire pressures under various operating conditions (▷ page 297).

Check tire pressures regularly, and only when the tires are cold. Comply with the maintenance recommendations of the tire manufacturer in the vehicle document wallet.

 Notes on the vehicle equipment – always equip the vehicle with:

- tires of the same size on a given axle (left/right)
- the same type of tires at a given time (summer tires, winter tires, MOExtended tires)

On the following pages, you can find information on approved wheel rims and tire sizes for equipping your vehicle with winter tires. Winter tires are not available at the factory as standard equipment or optional extras.

If you would like to equip your vehicle with approved winter tires, you may also, in certain circumstances, require rims of the appropriate size. The sizes of the approved winter tires may deviate from that of the standard tires. This is dependent on the model and the equipment installed at the factory.

The tires and wheel rims, as well as further information, can be obtained at a qualified specialist workshop.

Overview of abbreviations used in the following tire tables:

- BA: both axles
- FA: front axle
- RA: rear axle

In the following table, the wheel/tire combinations are assigned to the vehicle models through variants, e.g. V1, V2 etc.:

V1	SLK 250
1/0	011/ 050

- V2 SLK 350
- V3 SLK 55 AMG

 Not all wheel and tire combinations are available at the factory for all countries.

Wheel and tire combinations 318

Tires					
	Summer tires	Alloy wheels	V1	V2	V3
FA RA	225/45 R17 91 W 245/40 R17 91 W ²¹	7.5 J x 17 H2 Wheel offset: 1.65 in (42 mm) 8.5 J x 17 H2 Wheel offset: 1.42 in (36 mm)	•	•	
FA RA	225/45 R17 91 W MOExtended ²² 245/40 R17 91 W MOExtended ^{21, 22}	7.5 J x 17 H2 Wheel offset: 1.65 in (42 mm) 8.5 J x 17 H2 Wheel offset: 1.42 in (36 mm)	•	•	—
FA RA	225/40 R18 92 Y XL 245/35 R18 92 Y XL ²¹	7.5 J x 18 H2 Wheel offset: 1.65 in (42 mm) 8.5 J x 18 H2 Wheel offset: 1.42 in (36 mm)	•	•	
FA RA	235/40 ZR 18 95 Y XL 255/35 ZR 18 94 Y XL ²¹	8.0 J x 18 H2 Wheel offset: 1.69 in (43 mm) 9.0 J x 18 H2 Wheel offset: 1.65 in (42 mm)	_	_	•
	Winter tires	Alloy wheels	V1	V2	V3

7.5 J x 17 H2

7.5 J x 17 H2

8.0 J x 18 H2

8.0 J x 18 H2

9.0 J x 18 H2

Wheel offset: 1.65 in (42 mm)

Wheel offset: 1.65 in (42 mm)

Wheel offset: 1.69 in (43 mm)

Wheel offset: 1.69 in (43 mm)

Wheel offset: 1.65 in (42 mm)

Wheels and tires

ΒA

ΒA

ΒA

FA

RA

225/45 R17 91 H M+S 🚕

M+S 🔬 MOExtended²²

235/40 R18 95 V XL M+S 🛕

235/40 R18 95 V XL M+S 🚕

255/35 R18 94 V XL M+S 🛕 21

225/45 R17 91 H

²¹ Use of snow chains is not permitted. Observe the notes in the "Snow chains" section.

²² MOExtended tires (tires featuring run-flat characteristics) only in combination with an activated tire pressure monitor.

Collapsible spare wheel ²¹				
Tires	Steel wheel	V1	V2	V3
145/70 - 17 92P Tire pressure: 350 kPa (3.5 bar/51 psi)	4.5 B x 17 H2 Wheel offset: 0.47 in (12 mm)	٠	٠	_
175/55 - 18 95P Tire pressure: 350 kPa (3.5 bar/51 psi)	6.0 B x 18 H2 Wheel offset: 0.98 in (25 mm)	-	-	٠

²¹ Use of snow chains is not permitted. Observe the notes in the "Snow chains" section.

Useful information	322
Notes on technical data	322
Genuine Mercedes-Benz parts	322
Warranty	323
Identification plates	323
Service products and filling capaci-	
ties	324
Vehicle data	329

Useful information

- This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- I Please read the information on qualified specialist workshops (▷ page 23).

Notes on technical data

The data stated here specifically refers to a vehicle with standard equipment. Consult a Mercedes-Benz Center for the data for all vehicle variants and trim levels.

Genuine Mercedes-Benz parts

All Mercedes-Benz Centers maintain a supply of genuine Mercedes-Benz parts for necessary service and repair work. In addition, strategically located parts delivery centers provide for quick and reliable parts service.

There are more than 300,000 different genuine Mercedes-Benz parts available for Mercedes-Benz models.

Genuine Mercedes-Benz parts are subject to strict quality control. Each part has been specially developed, manufactured or selected for Mercedes-Benz vehicles and fine-tuned for them.

Therefore, only genuine Mercedes-Benz parts should be used.

🕂 WARNING

Driving safety may be impaired if nonapproved parts, tires and wheels or safetyrelevant accessories are used. This could lead to malfunctions in safetyrelevant systems, e.g. the brake system. This could cause you to lose control of your vehicle and cause an accident.

For this reason, Mercedes-Benz recommends that you use genuine Mercedes-Benz parts or parts of equal quality. Only use tires, wheels and accessories that have been specifically approved for your vehicle.

Air bags and Emergency Tensioning Devices, as well as control units and sensors for these restraint systems may be installed in the following areas of your vehicle:

- doors
- door pillars
- door sills
- seats
- dashboard
- instrument cluster
- center console

Do not install accessories such as audio systems in these areas. Do not carry out repairs or welding. You could impair the operating efficiency of the restraint systems.

Have aftermarket accessories installed at a qualified specialist workshop. Mercedes-Benz recommends that you use an authorized Mercedes-Benz Center for this purpose.

Daimler AG also supplies reconditioned major assemblies and parts which are of the same quality as new parts. They are covered by the same Limited Warranty entitlements as new parts.

Always specify the vehicle identification number (VIN) (> page 323) and the engine number (> page 324) when ordering genuine Mercedes-Benz parts.

Warranty

The Service and Warranty Information booklet contains detailed information about the warranties covering your vehicle.

Your authorized Mercedes-Benz Center will exchange or repair any defective parts originally installed in the vehicle in accordance with the terms of the following warranties:


- New Vehicle Limited Warranty
- Emission System Warranty
- Emission Performance Warranty
- California, Connecticut, Maine, Massachusetts, New York, Pennsylvania, Rhode Island and Vermont Emission Control Systems Warranty
- State Warranty Enforcement Laws (Lemon Laws)

Replacement parts and accessories are covered by the Mercedes-Benz Parts and Accessories warranties. You can obtain information about this from any authorized Mercedes-Benz Center.

Should you lose your Service and Warranty Information booklet, have an authorized Mercedes-Benz Center arrange for a replacement. It will be mailed to you.

Identification plates

Vehicle identification plate with vehicle identification number (VIN) and paint code number



Open the driver's door.
 You will see vehicle identification plate (1).



Example: vehicle identification plate (USA only) (2) VIN

③ Paint code



Example: vehicle identification plate (Canada only) (2) VIN

- ③ Paint code
- The data shown on the identification plate is example data. This data is different for every vehicle and can deviate from the data shown here. You can find the data applicable to your vehicle on the vehicle's identification plate.

Vehicle identification number (VIN)

The vehicle identification number (VIN) can be found in the following locations:

- on the vehicle identification plate (> page 323)
- on the lower edge of the windshield (▷ page 324)

324 Service products and filling capacities


In addition to being stamped on the vehicle identification plate, the vehicle identification number (VIN) is also stamped onto the vehicle body.

It is located in the transmission tunnel on the front-passenger side.



- Slide the front-passenger seat to its frontmost position.
- Fold trim (1) upwards.
 You will see vehicle identification number (VIN) (2).

Engine number



- Emission control information plate, including the certification of both federal and Californian emissions standards
- Engine number (stamped into the crankcase)
- ③ VIN (on the lower edge of the windshield)

Service products and filling capacities

Important safety notes

▲ WARNING

Comply with all valid regulations with respect to handling, storing and disposing of service fluids. Otherwise, you could endanger persons or the environment.

Keep service fluids out of the reach of children.

For health reasons, you should prevent service fluids from coming into direct contact with your skin or clothing.

If a service fluid is swallowed, contact a physician immediately.

Service products include the following:

- fuels
- lubricants (e.g. engine oil, transmission oil)
- coolant
- brake fluid
- windshield washer fluid
- climate control system refrigerant

Vehicle components and their service products must match. Therefore only use products tested and approved by Mercedes-Benz.

Information about tested and approved products can be obtained from an authorized Mercedes-Benz Center or on the Internet at http://bevo.mercedes-benz.com.

You can recognize service products approved by Mercedes-Benz by the following inscription on the containers:

- MB-Freigabe (e.g. MB-Freigabe 229.51)
- MB Approval (e.g. MB Approval 229.51)

Other designations or recommendations indicate a level of quality or a specification in accordance with an MB Sheet number (e.g. MB 229.5). They have not necessarily been approved by Mercedes-Benz.

Technical data

Fuel

Important safety notes

Gasoline is highly flammable and poisonous. It burns violently and can cause serious personal injury.

Never allow sparks, flames or smoking materials near gasoline.

Turn off the engine before refueling.

Whenever you are around gasoline, avoid inhaling fumes and any skin or clothing contact.

Direct skin contact with fuels and the inhalation of fuel vapors are damaging to your health.

Tank capacity

Total capacity	18.5 US gal (70.0 l)
Of which reserve	Approx. 2.4 US gal (9.0 l)

Gasoline

Fuel grade

Do not use diesel to refuel vehicles with a gasoline engine. Even small amounts of the wrong fuel result in damage to the fuel system and engine.

You should only refuel with unleaded premium-grade gasoline as this avoids damaging the catalytic converter.

If engine running problems are apparent, have the cause checked immediately and repaired. Excess unburned fuel can otherwise enter the catalytic converter, leading to overheating and possibly causing a fire.

To ensure the longevity and full performance of the engine, only premiumgrade unleaded gasoline may be used. If there is no premium-grade unleaded gasoline available and regular unleaded gasoline must be used, please observe the following precautions:

- only fill the fuel tank to half full with regular unleaded gasoline and fill the rest with premium-grade unleaded gasoline as soon as possible.
- do not drive at the maximum speed.
- avoid sudden acceleration.
- if the vehicle is carrying a light load, e.g. two passengers without luggage, do not allow the engine to rev above 3000 rpm.
- if the vehicle is fully loaded or is being operated in mountainous terrain, do not depress the accelerator pedal further than ²/₃ of the pedal travel.

Only refuel with premium-grade unleaded gasoline with a minimum octane number of 91.

Reformulated Gasoline (RFG) and/or unleaded gasoline with additives can be used. However, the concentration of additives in the fuel must be less than 10%, e.g.

- Ethanol
- TAME
- ETBE
- IPA
- TBA

For MTBE, the concentration should not exceed 15%.

The concentration of methanol in gasoline including other additives must not exceed 3%.

Using mixtures of methanol and ethanol is not permitted. Gasohol, a mixture of 10% ethanol and 90% unleaded gasoline, can be used.

All of these mix fuels must fulfill the fuel requirements, e.g.:

- knock resistance
- boiling point
- vapor pressure

You will usually find information about the fuel grade on the pump. If you cannot find the label on the pump, ask the staff for assistance.

For further information, consult an authorized Mercedes-Benz Center or visit http://www.mbusa.com (USA only).

Information on refueling (\triangleright page 146).

Additives

Do not refuel with low-grade fuel and do not use fuel additives that are not tested and approved for Mercedes-Benz vehicles. Damage to or malfunctions of the fuel system may otherwise occur.

One of the main problems of poor fuel quality is the forming of deposits that are created during the gasoline combustion process. Mercedes-Benz recommends that you use branded fuels that have additives.

If you use fuels without these additives over a longer period of time, carbon deposits may build up. These deposits form at the inlet valves and in the combustion chamber in particular.

This could lead to engine problems, e.g.:

- longer engine warm-up phase
- uneven idle
- engine noise
- misfiring
- loss of power

Carbon deposits may form if the availability of gasoline with relevant additives is insufficient (in certain regions). In this case, Mercedes-Benz recommends additives approved for use in Mercedes-Benz vehicles; see http://bevo.mercedes-benz.com.

For a list of approved products, consult an authorized Mercedes-Benz Center. Comply with the instructions for use on the product label.

Do not mix other fuel additives with fuel. This causes unnecessary costs and could damage the engine.

Engine oil

Please bear the following in mind

Never use engine oil or an oil filter of a specification other than is necessary to fulfill the prescribed service intervals. Do not change the engine oil or oil filter in order to achieve longer replacement intervals than those prescribed. You could otherwise cause engine damage or damage to the exhaust gas aftertreatment.
Follow the instructions in the service interval display regarding the oil change. Otherwise, you may damage the engine and the exhaust gas aftertreatment.

The engine oils are matched to the performance of Mercedes-Benz engines and service intervals. You should therefore only use engine oils and oil filters that are approved for vehicles with maintenance systems.

For a list of approved engine oils and oil filters, consult an authorized Mercedes-Benz Center. Or visit the website http://bevo.mercedes-benz.com.

The table shows which engine oils have been approved for your vehicle.

Model	Engine model	MB Approval
SLK 250	271	229.5
SLK 350	276	
SLK 55 AMG ²³	152	

MB approval is indicated on the oil containers.

Filling capacities


The following values refer to an oil change including the oil filter.

Model	Capacity
SLK 250	5.8 US qt (5.5 l)
SLK 350	6.9 US qt (6.5 l)
SLK 55 AMG	10.0 US qt (9.5 l) ²⁴

Additives

Do not use any additives in the engine oil. This could damage the engine.

Engine oil viscosity



Viscosity describes the flow characteristics of a fluid. If an engine oil has a high viscosity, this means that it is thick; a low viscosity means that it is thin.

Select an engine oil with an SAE (viscosity) classification suitable for the prevailing outside temperatures. The table shows you which SAE classifications are to be used. The low-temperature characteristics of engine oils can deteriorate significantly, e.g. as a result of aging, soot and fuel deposits. It is therefore strongly recommended that you carry out regular oil changes using an approved engine oil with the appropriate SAE classification.

Brake fluid

Over a period of time, the brake fluid absorbs moisture from the air; this lowers its boiling point.

If the boiling point of the brake fluid is too low, vapor pockets may form in the brake system when the brakes are applied hard (e.g. when driving downhill). This would impair braking efficiency.

You should have the brake fluid renewed at regular intervals. The brake fluid change intervals can be found in the Maintenance Booklet.

Only use brake fluid approved by Mercedes-Benz. Information about approved brake fluid can be obtained at any qualified specialist workshop or on the Internet at http://bevo.mercedes-benz.com.

Coolant

Important safety notes

Antifreeze is highly flammable. Fire, naked flames and smoking are prohibited when handling antifreeze.

If antifreeze comes into contact with hot engine parts, it may ignite and you could burn yourself. Do not spill any antifreeze on hot engine parts.

Only add coolant that has been premixed with the desired antifreeze protection. You could otherwise damage the engine.

Further information on coolants can be found in the Mercedes-Benz Specifications for Service Products, MB Specifications for Service Products 310.1, e.g. on the Internet at

http://bevo.mercedes-benz.com. Or contact a qualified specialist workshop.

328 Service products and filling capacities

Always use a suitable coolant mixture, even in countries where high temperatures prevail.

Otherwise, the engine cooling system is not sufficiently protected from corrosion and overheating.

The coolant is a mixture of water and antifreeze/corrosion inhibitor. It performs the following tasks:

- corrosion protection
- antifreeze protection
- raising the boiling point

If the coolant has antifreeze protection down to -35 °F (-37 °C), the boiling point of the coolant under operating conditions is approximately 266 °F (130 °C).

The antifreeze/corrosion inhibitor concentration in the engine cooling system should:

- be at least 50 %. This will protect the engine cooling system against freezing down to approximately -35 °F (-37 °C).
- not exceed 55% (antifreeze protection down to -49 °F [-45 °C]). Otherwise, heat will not be dissipated as effectively.

If the vehicle has lost coolant, add equal amounts of water and antifreeze/corrosion inhibitor. Mercedes-Benz recommends an antifreeze/corrosion inhibitor concentrate in accordance with MB Specifications for Service Products 310.1.

The coolant is checked with every maintenance interval at a qualified specialist workshop.

When the vehicle is first delivered, it is filled with a coolant mixture that ensures adequate antifreeze and corrosion protection.

Capacity

Model	Capacity
SLK 250	Approx. 10.1 US qt (9.6 l)
SLK 350	Approx. 11.0 US qt (10.4 l)
SLK 55 AMG	Approx. 10.0 US qt (9.5 l)

Use MB 325.0 or MB 326.0 corrosion inhibitor/antifreeze.

Washer fluid

MARNING

Washer solvent/antifreeze is highly flammable. Do not spill washer solvent/ antifreeze on hot engine parts, because it may ignite and burn. You could be seriously burned.

- Only use washer fluid that is suitable for plastic lamp lenses, e.g. MB SummerFit or MB WinterFit. Unsuitable washer fluid could damage the plastic lenses of the headlamps.
- Do not add distilled or de-ionized water to the washer fluid container. Otherwise, the level sensor may be damaged.
- Only MB SummerFit and MB WinterFit washer fluid should be mixed together. The spray nozzles may otherwise become blocked.

At temperatures above freezing:

- Fill the washer fluid reservoir with a mixture of water and windshield washer fluid, e.g. MB SummerFit.
- Add 1 part MB SummerFit to 100 parts water.

At temperatures below freezing:

- Fill the washer fluid reservoir with a mixture of water and windshield washer fluid, e.g. MB WinterFit. Adapt the mixing ratio to the outside temperature.
- Down to 14 °F (-10 °C): mix 1 part MB WinterFit with 2 parts water.
- Down to -4 °F (-20 °C): mix 1 part MB WinterFit with 1 part water.
- Down to -20.2 °F (-29 °C): mix 2 parts MB WinterFit with 1 part water.

Model	Capacity
All models	3.7 US qt (3.5 l)

• Add windshield washer fluid, e.g. MB SummerFit or MB WinterFit, to the washer fluid all year round.

Turning radius	34.5 ft (10.52 m)
Maximum trunk load	220 lb (100 kg)

SLK 55 AMG	
Vehicle length	163.2 in (4146 mm)
Vehicle width including exterior mirrors	79.0 in (2006 mm)
Vehicle height	51.2 in (1301 mm)
Wheelbase	95.7 in (2430 mm)
Turning radius	34.6 ft (10.55 m)
Maximum trunk load	220 lb (100 kg)

Vehicle data

Please note that for the specified vehicle data:

- the heights specified may vary as a result of:
 - tires
 - load
 - condition of the suspension
 - optional equipment
- the vehicle length specified includes the front license plate adapter.

All models (except AMG vehicles)	
Vehicle length	162.9 in (4138 mm)
Vehicle width including exterior mirrors	79.0 in (2006 mm)
Vehicle height	51.3 in (1303 mm)
Wheelbase	95.7 in (2430 mm)