

# SLK Operator's Manual







Order no. 6515 3321 13 Part no. 172 584 50 81 Edition A 2014

### Symbols

Registered trademarks:

- Bluetooth<sup>®</sup> is a registered trademark of Bluetooth SIG Inc.
- DTS is a registered trademark of DTS, Inc.
- Dolby and MLP are registered trademarks of DOLBY Laboratories.
- BabySmart<sup>™</sup>, ESP<sup>®</sup> and PRE-SAFE<sup>®</sup> are registered trademarks of Daimler AG.
- $\mbox{ }$  HomeLink  $\mbox{ }^{\mbox{ }}$  is a registered trademark of Johnson Controls.
- iPod<sup>®</sup> and iTunes<sup>®</sup> are registered trademarks of Apple Inc.
- Logic7<sup>®</sup> is a registered trademark of Harman International Industries.
- Microsoft<sup>®</sup> and Windows media<sup>®</sup> are registered trademarks of Microsoft Corporation.
- SIRIUS is a registered trademark of Sirius XM Radio Inc.
- HD Radio is a registered trademark of iBiquity Digital Corporation.
- Gracenote<sup>®</sup> is a registered trademark of Gracenote, Inc.
- ZAGATSurvey<sup>®</sup> and related brands are registered trademarks of ZagatSurvey, LLC.

In this Operator's Manual you will find the following symbols:

### 

Warning notes make you aware dangers which could pose a threat to your health or life, or to the health and life of others.

### $\Psi$ Environmental note

Environmental notes provide you with information on environmentally aware actions or disposal.

Notes on material damage alert you to dangers that could lead to damage to your vehicle.

1 Practical tips or further information that could be helpful to you.

This symbol indicates an instruction that must be followed.

- Several of these symbols in succession indicate an instruction with several steps.
- (▷ page) This symbol tells you where you can find more information about a topic.
- ▷▷ This symbol indicates a warning or an instruction that is continued on the next page.
- **Display** This font indicates a display in the multifunction display/COMAND display.

Parts of the software in the vehicle are protected by copyright <sup>©</sup> 2005 The FreeType Project http://www.freetype.org. All rights reserved.

### Publication details

### Internet

Further information about Mercedes-Benz vehicles and about Daimler AG can be found on the following websites:

http://www.mbusa.com (USA only) http://www.mercedes-benz.ca (Canada only)

### Editorial office

<sup>©</sup>Daimler AG: Not to be reprinted, translated or otherwise reproduced, in whole or in part, without written permission from Daimler AG.

### Welcome to the world of Mercedes-Benz

We urge you to read this Operator's Manual carefully and familiarize yourself with the vehicle before driving. For your own safety and a longer vehicle life, follow the instructions and warning notices in this manual. Ignoring them could result in damage to the vehicle or personal injury to you or others.

Vehicle damage caused by failure to follow instructions is not covered by the Mercedes-Benz Limited Warranty.

The equipment or product designation of your vehicle may vary depending on:

- Model
- Order
- Country specification
- Availability

Mercedes-Benz therefore reserves the right to introduce changes in the following areas:

- Design
- Equipment
- Technical features

The equipment in your vehicle may therefore differ from that shown in the descriptions and illustrations.

The following are integral components of the vehicle:

- Operator's Manual
- Maintenance Booklet
- Equipment-dependent supplements

Keep printed copies of the documents in the vehicle at all times. If you sell the vehicle, always pass the documents on to the new owner.

The technical documentation team at Daimler AG wishes you safe and pleasant motoring.

Mercedes-Benz USA, LLC

Mercedes-Benz Canada, Inc.

A Daimler Company

# Contents

Index	. 4
Introduction	20

At a glance 27
Safety 37
Opening and closing 69
Seats, steering wheel and mirrors 95
Lights and windshield wipers 107
Climate control 121
Driving and parking 137
On-board computer and displays 191
Stowage and features 253
Maintenance and care 273
Breakdown assistance
Wheels and tires 305
Technical data 341

### 1. 2. 3 ...

# 12 V socket

see Sockets

### Α

### ABS (Anti-lock Braking System) Display message ..... 211 Function/notes ..... 59 Important safety notes ...... 59 Warning lamp ..... 242 Activating/deactivating cooling with air dehumidification ..... 127 Active light function ...... 112 Adaptive Highbeam Assist Display message ..... 224 Function/notes ..... 112 Switching on/off (on-board computer) ..... 203 Additional speedometer ...... 203 Air bags Display message ..... 220 Front air bag (driver, front passenger) ..... Head bag ..... Important safety notes ..... Knee bag ..... PASSENGER AIR BAG OFF indicator lamp ..... Safety guidelines ..... Side impact air bag ..... Air-conditioning system see Climate control AIRGUIDE ..... AIRSCARF Problem (malfunction) ..... Switching on/off ..... AIRSCARF vents Setting the blower output ..... Air vents Important safety notes ..... Setting ..... Setting the blower output of the AIRSCARF vents .....

Setting the center air vents ......

 	Service message	278
 42	Special service requirements	279
 	ATA (Anti-Theft Alarm system)	
	Activating/deactivating	. 67
 43	Function	. 67
	Switching off the alarm	. 67
 . 45	ATTENTION ASSIST	
 . 39	Activating/deactivating	201
 . 43	Display message	227
	Function/notes	186
	Audio menu (on-board computer)	198
 . 91	Authorized Centers	
	see Qualified specialist workshop	
 100	Authorized Mercedes-Benz Center	
 100	see Qualified specialist workshop	
	Authorized workshops	
 135	see Qualified specialist workshop	
	AUTO lights	
 134	Display message	224
 134	see Lights	
	Automatic engine start (ECO start/	
 135	stop function)	144
 134		

Setting the side air vents ..... 135

Switching AIRSCARF on/off ..... 100

computer) ..... 203

computer) ..... 204

AMG menu (on-board computer) ..... 206

see ABS (Anti-lock Braking System)

see ATA (Anti-Theft Alarm system)

computer) ..... 200

computer) ..... 200

Displaying a service message ...... 279

Hiding a service message ...... 278

display ..... 279

see ATA (Anti-Theft Alarm system)

Setting the brightness (on-board

Setting the color (on-board

Anti-lock braking system

Anti-theft alarm system

Assistance display (on-board

Assistance menu (on-board

Resetting the service interval

ASSYST PLUS

Alarm svstem

Ambient lighting

Automatic engine switch-off (ECO	
start/stop function)	144
Automatic headlamp mode	109
Automatic transmission	
Accelerator pedal position	150
Automatic drive program	152
Changing gear	150
Display message	235
Driving tips	150
Emergency running mode	156
Kickdown	151
Manual drive program	152
Manual drive program (vehicles	
with Sports package AMG)	153
Overview	149
Problem (malfunction)	156
Program selector button	151
Pulling away	142
Releasing the parking lock	
manually	156
Selector lever	149
Starting the engine	142
Steering wheel paddle shifters	152
Transmission position display	149
Transmission positions	150
Automatic transmission	
emergency mode	156

# В

Backup lamp	
Changing bulbs	117
BAS (Brake Assist System)	60
BAS PLUS (Brake Assist System	
PLUS)	60
Battery (SmartKey)	
Checking	73
Important safety notes	73
Replacing	73
Battery (vehicle)	
Charging	296
Display message	226
Important safety notes	294
Jump starting	298
Overview	294

Blind Spot Assist	
Activating/deactivating	201
	229
Notes/function	187
Bottle holder	257
Brake Assist	
see BAS (Brake Assist System)	
Brake fluid	
Display message	216
Notes	347
Brake lamps	
Display message	222
Brakes	
ABS	59
BAS	60
BAS PLUS	60
Brake fluid (notes)	347
Display message	211
Driving tips	164
High-performance brake system	165
Important safety notes	164
Maintenance	165
Parking brake	160
Warning lamp	242
Breakdown	
see Flat tire	
see Towing away	

# Bulbs

see Replacing bulbs

# С

California Important notice for retail	
customers and lessees	. 22
Calling up a malfunction	
see Display messages	
Car	
see Vehicle	
Care	
Carpets	285
Car wash	280
Display	284
Exhaust pipe	283
Exterior lights	283
Gear or selector lever	284
Interior	284
Matte finish	282

Notes	279
Paint	281
Plastic trim	284
Power washer	281
Roof lining	285
Seat belt	285
Seat cover	285
Sensors	283
Steering wheel	284
Trim pieces	284
Washing by hand	280
Wheels	282
Windows	282
Wiper blades	282
Wooden trim	284
Car keys	204
see SmartKey	
Car wash (care)	280
CD player/CD changer (on-board	200
	198
computer) Center console	190
	22
Lower section Upper section	
Central locking	32
0	
Automatic locking (on-board	205
computer)	205
Locking/unlocking (SmartKey)	. 70
Changing bulbs	
High-beam headlamps	116
Low-beam headlamps	116
Reversing lamps	117
Side marker lamps (rear)	116
Turn signals (front)	117
Children	
In the vehicle	
Restraint systems	
Special seat belt retractor	
Cigarette lighter	258
Cleaning	
Mirror turn signal	283
Climate control	
Air-conditioning system	123
Automatic climate control (dual-	
zone)	125
Controlling automatically	129
Cooling with air dehumidification	127
Defrosting the windows	131
Defrosting the windshield	131

Important safety notes	122
Indicator lamp	129
Information on using dual-zone	
automatic climate control	126
Maximum cooling	131
Notes on using the air-	
conditioning system	124
Overview of systems	122
Problems with cooling with air	
dehumidification	129
Problem with the rear window	127
defroster	133
Refrigerant	349
Refrigerant filling capacity	349
Setting the air distribution	130
Setting the airflow	130
	130
Setting the air vents	
Setting the temperature	129
Switching air-recirculation mode	100
on/off	133
Switching on/off	127
Switching residual heat on/off	133
Switching the rear window	
defroster on/off	131
Switching the ZONE function on/	
off	130
Cockpit	
Overview	. 28
see Instrument cluster	
Collapsible spare wheel	
Inflating	338
see Emergency spare wheel	
COMAND display	
Cleaning	284
Combination switch	110
Compass	
Calibrating	272
Calling up	271
Setting	271
Consumption statistics (on-board	
computer)	195
Convenience closing feature	. 84
Convenience opening feature	
see Side windows	
Coolant (engine)	
Checking the level	277
Checking the level Display message Filling capacity	225

Important safety notes	347
Temperature (on-board computer) .	206
Temperature gauge	192
Warning lamp	248
Cooling	
see Climate control	
Copyright	26
Cornering light function	
Display message	221
Function/notes	111
Crash-responsive emergency	
lighting	114
Cruise control	
Cruise control lever	168
Deactivating	169
Display message	232
Driving system	167
Function/notes	167
Important safety notes	167
Setting a speed	169
Storing and maintaining current	
speed	168
Cup holder	
Center console	257
Important safety notes	256
Customer Assistance Center (CAC)	. 25
Customer Relations Department	
·	

# D

Dashboard	
see Instrument cluster	
Dashboard lighting	
see Instrument cluster lighting	
Data	
see Technical data	
Daytime running lamps	
Display message	224
Function/notes	109
Switching on/off (on-board	
computer)	203
Dealerships	
see Qualified specialist workshop	
Declarations of conformity	. 24
Delayed switch-off	
Exterior lighting (on-board	
computer)	204
Interior lighting	204

Diagnostics connection	. 24
Digital speedometer	196
Display messages	
ASSYST PLUS	278
Calling up (on-board computer)	210
Driving systems	227
Engine	225
General notes	210
Hiding (on-board computer)	210
KEYLESS-GO	239
Lights	221
Safety systems	211
SmartKey	238
Tires	233
Vehicle	235
Distance recorder	195
see Trip odometer	
Distance warning (warning lamp)	250
DISTRONIC PLUS	
Cruise control lever	171
Deactivating	176
Display message	230
Displays in the multifunction	
display	175
Driving tips	177
Function/notes	169
Important safety notes	170
Setting the specified minimum	
distance	175
Warning lamp	250
Doors	
Automatic locking (on-board	
computer)	205
Automatic locking (switch)	. 78
Central locking/unlocking	
(SmartKey)	
Control panel	. 35
Display message	237
Emergency locking	
Emergency unlocking	
Important safety notes	
Opening (from inside)	
Overview	
Drinking and driving	162
Drinks holder	
see Cup holder	

### Drive program

Automatic	152
Display	149
Manual	152
Manual (vehicles with Sports	
package AMG)	153
	207
Driver's door	
see Doors	
Driving abroad	
Mercedes-Benz Service	279
Symmetrical low beam	108
Driving on flooded roads	166
Driving safety systems	
ABS (Anti-lock Braking System)	59
ADAPTIVE BRAKE	65
BAS (Brake Assist System)	60
BAS PLUS (Brake Assist System	
PLUS)	60
Electronic brake force distribution	65
ESP <sup>®</sup> (Electronic Stability Program) .	61
ETS (Electronic Traction System)	61
Important safety information	59
Overview	59
PRE-SAFE <sup>®</sup> Brake	65
Driving systems	
ATTENTION ASSIST	186
Blind Spot Assist	187
Cruise control	167
Display message	227
DISTRONIC PLUS	169
Driving Assistance package	187
Dynamic handling package	178
HOLD function	179
Lane Keeping Assist	188
Parking Guidance	183
PARKTRONIC	180
Driving tips	
Automatic transmission	150
Brakes	164
Break-in period	138
DISTRONIC PLUS	177
Downhill gradient	164
Drinking and driving	162
Driving abroad	108
Driving in winter	166
Driving on flooded roads	166
5	

Driving on wet roads	166
Exhaust check	163
Fuel	162
General	162
Hydroplaning	166
Icy road surfaces	167
Limited braking efficiency on	
salted roads	165
Snow chains	309
Symmetrical low beam	108
Wet road surface	165
DVD audio	
Operating (on-board computer)	198
DVD video	
Operating (on-board computer)	199
Dynamic handling package	
Function/notes	178

### Ε

EASY-ENTRY feature	
Activating/deactivating	205
Function/notes	101
EASY-EXIT feature	
Crash-responsive	102
Function/notes	101
Switching on/off	205
EBD (electronic brake force	
distribution)	
Display message	213
Function/notes	65
ECO display	
Function/notes	163
On-board computer	196
ECO start/stop function	
Automatic engine start	144
Automatic engine switch-off	144
Deactivating/activating	145
General information	143
Important safety notes	143
Introduction	143
Electronic Stability Program	
see ESP <sup>®</sup> (Electronic Stability Progra	m)
Emergency release	,
Driver's door	78
Trunk	81
Vehicle	78

Important safety notes337Points to remember337Removing337Stowing338Technical data340Emergency Tensioning DevicesFunction55Safety guidelines39Emissions controlService and warranty informationService and warranty information21EngineCheck Engine warning lampCheck Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronics346Problem (malfunction)147Engine oil275Adding276Additives346Checking the oil level using the346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic Stability207Program)AMG menu (on-board computer)207	Points to remember337Removing337Stowing338Technical data340Emergency Tensioning DevicesFunction55Safety guidelines39Emissions controlservice and warranty informationService and warranty information21EngineCheck Engine warning lampCheck Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting dhe engine with theSmartKey142Starting off160Tow-starting (vehicle)303Engine electronics76Adding276Additives346Checking the oil level using the275Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic Stability	Points to remember337Removing337Stowing338Technical data340Emergency Tensioning DevicesFunction55Safety guidelines39Emissions controlService and warranty informationService and warranty information21EngineCheck Engine warning lampCheck Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with theSmartKeySwitching off160Tow-starting (vehicle)303Engine oil276Adding276Additives346Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
Removing337Stowing338Technical data340Emergency Tensioning DevicesFunction55Safety guidelines39Emissions controlService and warranty information21EngineCheck Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting dhe engine with theSmartKeySwitching off160Tow-starting (vehicle)303Engine electronicsProblem (malfunction)Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)	Removing337Stowing338Technical data340Emergency Tensioning DevicesFunction55Safety guidelines39Emissions controlService and warranty informationService and warranty information21EngineCheck Engine warning lampCheck Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with theSmartKey142Starting off160Tow-starting (vehicle)303Engine electronicsProblem (malfunction)147Engine oil4ddingAdding275Checking the oil level using thedipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)AMG menu (on-board computer)207Deactivating/activating (AMGvehicles)63Deactivating/activating (notes;except AMG vehicles)62Display message211	Removing337Stowing338Technical data340Emergency Tensioning DevicesFunction55Safety guidelines39Emissions controlService and warranty informationService and warranty information21EngineCheck Engine warning lampCheck Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine oil276Adding276Additives346Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
Stowing338Technical data340Emergency Tensioning DevicesFunction55Safety guidelines39Emissions controlservice and warranty information21EngineCheck Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with theSmartKeySwitching off160Tow-starting (vehicle)303Engine electronicsProblem (malfunction)147Problem (malfunction)147Engine oilAdditives346Checking the oil level using the dipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic Stability346	Stowing338Technical data340Emergency Tensioning DevicesFunction55Safety guidelines39Emissions controlservice and warranty information21EngineCheck Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting problems142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronicsProblem (malfunction)Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level using the346Checking the oil level using the346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)AMG menu (on-board computer)207Deactivating/activating (AMG207Deactivating/activating (notes; except AMG vehicles)63Deactivating/activating (notes; except AMG vehicles)62Display message211	Stowing338 Technical data340Emergency Tensioning DevicesFunction55Safety guidelines39Emissions controlService and warranty information21EngineCheck Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with theSmartKeySwitching off160Tow-starting (vehicle)303Engine oil276Adding276Additives346Checking the oil level using the dipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
Technical data340Emergency Tensioning DevicesFunction55Safety guidelines39Emissions controlService and warranty information21EngineCheck Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with theSmartKeySwartKey142Starting off160Tow-starting (vehicle)303Engine electronicsProblem (malfunction)Problem (malfunction)147Engine oil275Adding276Additives346Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)	Technical data340Emergency Tensioning DevicesFunction55Safety guidelines39Emissions controlService and warranty information21EngineCheck Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with theSmartKeySmartKey142Switching off160Tow-starting (vehicle)303Engine oil276Adding276Additives346Checking the oil level using the346Checking the oil level using the346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)AMG menu (on-board computer)207Deactivating/activating (AMG207Deactivating/activating (notes; except AMG vehicles)63Deactivating/activating (notes; except AMG vehicles)62Display message211	Technical data340Emergency Tensioning DevicesFunction55Safety guidelines39Emissions controlService and warranty information21EngineCheck Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine oil276Adding276Additives346Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
Emergency Tensioning DevicesFunction55Safety guidelines39Emissions controlservice and warranty information21EngineCheck Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with theSmartKeySwitching off160Tow-starting (vehicle)303Engine electronics76Adding276Additives346Checking the oil level using the346dipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic Stability346	Emergency Tensioning DevicesFunction55Safety guidelines39Emissions controlService and warranty information21EngineCheck Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with theSmartKeySwitching off160Tow-starting (vehicle)303Engine electronicsProblem (malfunction)Problem (malfunction)147Engine oil275Additives346Checking the oil level using the346Ockeking the oil level using the346Notes about oil grades346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)AMG menu (on-board computer)207Deactivating/activating (AMG63Deactivating/activating (notes; except AMG vehicles)62Display message211	Emergency Tensioning DevicesFunction55Safety guidelines39Emissions controlService and warranty information21EngineCheck Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with theSmartKeySwitching off160Tow-starting (vehicle)303Engine oil276Adding276Additives346Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
Function55Safety guidelines39Emissions controlService and warranty information21EngineCheck Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with theSmartKeySwitching off160Tow-starting (vehicle)303Engine electronicsProblem (malfunction)147Problem (malfunction)147Engine oil346Additives346Checking the oil level using the346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic Stability346	Function55Safety guidelines39Emissions controlService and warranty information21EngineCheck Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with theSmartKeySmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronicsProblem (malfunction)Problem (malfunction)147Engine oil276Additives346Checking the oil level using thedipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)AMG menu (on-board computer)207Deactivating/activating (AMG63Deactivating/activating (notes; except AMG vehicles)62Display message211	Function55Safety guidelines39Emissions controlService and warranty information21EngineCheck Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with the303SmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine oil276Adding276Additives346Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
Safety guidelines39Emissions control21Service and warranty information21Engine248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with theSmartKeySwitching off160Tow-starting (vehicle)303Engine electronicsProblem (malfunction)147Problem (malfunction)147Engine oil346Checking the oil level using the dipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic Stability346Program)	Safety guidelines39Emissions control21Service and warranty information21Engine248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with theSmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronics766Problem (malfunction)147Engine oil276Additives346Checking the oil level using the346Checking the oil level using the346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic Stability346Program)AMG menu (on-board computer)207Deactivating/activating (notes; except AMG vehicles)63Deactivating/activating (notes; except AMG vehicles)62Display message211	Safety guidelines39Emissions controlService and warranty information21EngineCheck Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with theSmartKeySwitching off160Tow-starting (vehicle)303Engine oil4ddingAdding276Additives346Checking the oil level using the346Ghecking the oil level using the346Filling capacity346Notes about oil grades346Notes on oil level/consumption275
Emissions control Service and warranty information 21 Engine Check Engine warning lamp 248 Display message	Emissions controlService and warranty information21Engine248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with theSmartKeySmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronicsProblem (malfunction)Problem (malfunction)147Engine oil276Additives346Checking the oil level using the346dipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)207Deactivating/activating (AMG43vehicles)63Deactivating/activating (notes;62Display message211	Emissions controlService and warranty information 21Engine248Display message
Service and warranty information21Engine248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with theSmartKeySwitching off160Tow-starting (vehicle)303Engine electronicsProblem (malfunction)Problem (malfunction)147Engine oil275Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic Stability346Program)248	Service and warranty information21Engine248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with theSmartKeySmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronicsProblem (malfunction)Problem (malfunction)147Engine oil276Additives346Checking the oil level275Checking the oil level using the346dipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)207Deactivating/activating (AMG43vehicles)63Deactivating/activating (notes;62Display message211	Service and warranty information21Engine248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with the303SmartKey142Starting off160Tow-starting (vehicle)303Engine electronics76Problem (malfunction)147Engine oil275Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
EngineCheck Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with theSmartKeySmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronicsProblem (malfunction)Problem (malfunction)147Engine oil276Additives346Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)Program	EngineCheck Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with theSmartKeySmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronicsProblem (malfunction)Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic Stability970Program)AMG menu (on-board computer)207Deactivating/activating (AMG63Deactivating/activating (notes; except AMG vehicles)62Display message211	EngineCheck Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with theSmartKeySmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronicsProblem (malfunction)Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
Check Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with theSmartKeySmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronicsProblem (malfunction)Problem (malfunction)147Engine oil276Additives346Checking the oil level using thedipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)	Check Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with theSmartKeySmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronicsProblem (malfunction)Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic Stability97Program)AMG menu (on-board computer)207Deactivating/activating (AMG63Deactivating/activating (notes; except AMG vehicles)62Display message211	Check Engine warning lamp248Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with the303SmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronics766Adding276Adding the oil level275Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with theSmartKeySmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronicsProblem (malfunction)Problem (malfunction)147Engine oil346Additives346Checking the oil level using thedipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)	Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with the3martKeySmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronicsProblem (malfunction)Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level275Checking the oil level using the dipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)AMG menu (on-board computer)207Deactivating/activating (AMG vehicles)63Deactivating/activating (notes; except AMG vehicles)62Display message211	Display message225ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with the142SmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronics766Adding276Adding the oil level275Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with the303SmartKey142Switching off160Tow-starting (vehicle)303Engine electronics976Adding276Adding the oil level275Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic Stability346	ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting problems147Starting the engine with theSmartKeySmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronicsProblem (malfunction)Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level275Checking the oil level using the dipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)AMG menu (on-board computer)207Deactivating/activating (AMG vehicles)63Deactivating/activating (notes; except AMG vehicles)62Display message211	ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with theSmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronics706Problem (malfunction)147Engine oil346Adding275Checking the oil level275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with the303SmartKey142Switching off160Tow-starting (vehicle)303Engine electronics976Adding276Adding the oil level275Checking the oil level using the275Display message226Filling capacity346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic Stability346	ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with the303SmartKey142Switching off160Tow-starting (vehicle)303Engine electronics9Problem (malfunction)147Engine oil4ddingAdding276Additives346Checking the oil level275Checking the oil level using the346dipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)AMG menu (on-board computer)207Deactivating/activating (AMG63Deactivating/activating (notes;62Display message211	ECO start/stop function143Engine number343Irregular running147Jump-starting298Starting problems147Starting the engine with the142SmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronics147Problem (malfunction)147Engine oil346Adding276Additives346Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
Irregular running147Jump-starting298Starting problems147Starting the engine with the142SmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronics9Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic Stability9	Irregular running147Jump-starting298Starting problems147Starting the engine with the142SmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronics147Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level275Checking the oil level using the346dipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)AMG menu (on-board computer)207Deactivating/activating (AMG63Deactivating/activating (notes;62Display message211	Irregular running147Jump-starting298Starting problems147Starting the engine with the142SmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronics700Problem (malfunction)147Engine oil346Adding275Checking the oil level275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
Irregular running147Jump-starting298Starting problems147Starting the engine with the142SmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronics70Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic Stability346Program)346	Irregular running147Jump-starting298Starting problems147Starting the engine with the142SmartKey142Switching off160Tow-starting (vehicle)303Engine electronics147Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level275Checking the oil level using the346dipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic Stability207Deactivating/activating (AMG63Deactivating/activating (notes;62Display message211	Irregular running147Jump-starting298Starting problems147Starting the engine with the142SmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronics9Problem (malfunction)147Engine oil346Additives346Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
Jump-starting298Starting problems147Starting the engine with the142SmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronics147Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)	Jump-starting298Starting problems147Starting the engine with the142SmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronicsProblem (malfunction)Problem (malfunction)147Engine oil276Additives346Checking the oil level275Checking the oil level using thedipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)AMG menu (on-board computer)207Deactivating/activating (AMG63Deactivating/activating (notes;62Display message211	Jump-starting298Starting problems147Starting the engine with the142SmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronics9Problem (malfunction)147Engine oil276Additives346Checking the oil level275Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
Starting problems147Starting the engine with theSmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronics9Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level using the275Checking the oil level using the346Killing capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)	Starting problems147Starting the engine with the142SmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronicsProblem (malfunction)Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level275Checking the oil level using thedipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)AMG menu (on-board computer)207Deactivating/activating (AMG63Deactivating/activating (notes;62Display message211	Starting problems147Starting the engine with the142SmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronics147Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level275Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
Starting the engine with theSmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronics9Problem (malfunction)147Engine oil4ddingAdding276Additives346Checking the oil level using the275Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)	Starting the engine with theSmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronics9Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level275Checking the oil level using thedipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)AMG menu (on-board computer)207Deactivating/activating (AMG63Deactivating/activating (notes;62Display message211	Starting the engine with theSmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronics7Problem (malfunction)147Engine oil346Additives346Checking the oil level275Checking the oil level using the40dipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
SmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronics147Problem (malfunction)147Engine oil4ddingAdding276Additives346Checking the oil level275Checking the oil level using thedipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)	SmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronicsProblem (malfunction)147Engine oil276Adding276Additives346Checking the oil level275Checking the oil level using thedipstickdipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)AMG menu (on-board computer)207Deactivating/activating (AMG63Deactivating/activating (notes;62Display message211	SmartKey142Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronics9Problem (malfunction)147Engine oil276Adding346Checking the oil level275Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronics147Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level275Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)	Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronics9Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level275Checking the oil level using thedipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)AMG menu (on-board computer)207Deactivating/activating (AMG63Deactivating/activating (notes;62Display message211	Starting with KEYLESS-GO142Switching off160Tow-starting (vehicle)303Engine electronics76Problem (malfunction)147Engine oil276Adding346Checking the oil level275Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
Switching off160Tow-starting (vehicle)303Engine electronicsProblem (malfunction)147Engine oil276Adding276Additives346Checking the oil level275Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)	Switching off160Tow-starting (vehicle)303Engine electronics9Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level275Checking the oil level using thedipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)AMG menu (on-board computer)207Deactivating/activating (AMG63Deactivating/activating (notes;62Display message211	Switching off160Tow-starting (vehicle)303Engine electronics76Problem (malfunction)147Engine oil346Adding276Additives346Checking the oil level275Checking the oil level using the40dipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
Tow-starting (vehicle)303Engine electronics147Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level275Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)	Tow-starting (vehicle)303Engine electronics147Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level275Checking the oil level using the dipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)AMG menu (on-board computer)207Deactivating/activating (AMG vehicles)63Deactivating/activating (notes; except AMG vehicles)62Display message211	Tow-starting (vehicle)303Engine electronics147Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level275Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
Engine electronicsProblem (malfunction)147Engine oil276Adding346Checking the oil level275Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)	Engine electronicsProblem (malfunction)147Engine oilAddingAdditives346Checking the oil levelChecking the oil level using thedipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)AMG menu (on-board computer)207Deactivating/activating (AMGvehicles)63Deactivating/activating (notes;except AMG vehicles)62Display message211	Engine electronicsProblem (malfunction)147Engine oil276Adding276Additives346Checking the oil level275Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level275Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)	Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level275Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)AMG menu (on-board computer)207Deactivating/activating (AMG63Deactivating/activating (notes; except AMG vehicles)62Display message211	Problem (malfunction)147Engine oil276Adding276Additives346Checking the oil level275Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
Engine oil276Adding276Additives346Checking the oil level275Checking the oil level using the215dipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)	Engine oilAdding276Additives346Checking the oil level275Checking the oil level using the275dipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)AMG menu (on-board computer)207Deactivating/activating (AMGvehicles)63Deactivating/activating (notes;except AMG vehicles)62Display message211	Engine oil276Adding276Additives346Checking the oil level275Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
Adding276Additives346Checking the oil level275Checking the oil level using thedipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)	Adding       276         Additives       346         Checking the oil level       275         Checking the oil level using the       275         dipstick       275         Display message       226         Filling capacity       346         Notes about oil grades       346         Notes on oil level/consumption       275         Temperature (on-board computer)       206         Viscosity       346         ESP® (Electronic Stability       90         Program)       AMG menu (on-board computer)       207         Deactivating/activating (AMG       63         Deactivating/activating (notes;       62         Display message       211	Adding276Additives346Checking the oil level275Checking the oil level using the275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
Additives346Checking the oil level275Checking the oil level using the215dipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)	Additives       346         Checking the oil level       275         Checking the oil level using the       275         Display message       226         Filling capacity       346         Notes about oil grades       346         Notes on oil level/consumption       275         Temperature (on-board computer)       206         Viscosity       346         ESP® (Electronic Stability         Program)       AMG menu (on-board computer)       207         Deactivating/activating (AMG         vehicles)       63         Deactivating/activating (notes;       62         Display message       211	Additives346Checking the oil level275Checking the oil level using the275dipstick275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
Checking the oil level	Checking the oil level	Checking the oil level
Checking the oil level using the dipstick	Checking the oil level using the         dipstick       275         Display message       226         Filling capacity       346         Notes about oil grades       346         Notes on oil level/consumption       275         Temperature (on-board computer)       206         Viscosity       346         ESP® (Electronic Stability       Program)         AMG menu (on-board computer)       207         Deactivating/activating (AMG       63         Deactivating/activating (notes;       62         Display message       211	Checking the oil level using the dipstick275 275Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275
dipstick	dipstick	dipstick
Display message	Display message226Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)AMG menu (on-board computer)207Deactivating/activating (AMGvehicles)63Deactivating/activating (notes;62Display message211	Display message
Filling capacity346Notes about oil grades346Notes on oil level/consumption275Temperature (on-board computer)206Viscosity346ESP® (Electronic StabilityProgram)	Filling capacity       346         Notes about oil grades       346         Notes on oil level/consumption       275         Temperature (on-board computer)       206         Viscosity       346         ESP® (Electronic Stability       9         Program)       AMG menu (on-board computer)       207         Deactivating/activating (AMG       63         Deactivating/activating (notes;       62         Display message       211	Filling capacity
Notes about oil grades       346         Notes on oil level/consumption       275         Temperature (on-board computer)       206         Viscosity       346         ESP® (Electronic Stability         Program)	Notes about oil grades       346         Notes on oil level/consumption       275         Temperature (on-board computer)       206         Viscosity       346         ESP® (Electronic Stability       346         Program)       AMG menu (on-board computer)       207         Deactivating/activating (AMG       63         Deactivating/activating (notes;       62         Display message       211	Notes about oil grades
Notes on oil level/consumption 275 Temperature (on-board computer) . 206 Viscosity 346 ESP <sup>®</sup> (Electronic Stability Program)	Notes on oil level/consumption       275         Temperature (on-board computer)       206         Viscosity       346         ESP® (Electronic Stability       9         Program)       AMG menu (on-board computer)       207         Deactivating/activating (AMG       63         Deactivating/activating (notes;       62         Display message       211	Notes on oil level/consumption 275
Temperature (on-board computer) . 206 Viscosity	Temperature (on-board computer) . 206 Viscosity	
Viscosity 346 ESP® (Electronic Stability Program)	Viscosity	
ESP <sup>®</sup> (Electronic Stability Program)	ESP® (Electronic Stability Program) AMG menu (on-board computer) 207 Deactivating/activating (AMG vehicles)	
Program)	Program)       AMG menu (on-board computer) 207         Deactivating/activating (AMG         vehicles)	
	AMG menu (on-board computer) 207Deactivating/activating (AMGvehicles)	
	Deactivating/activating (AMG vehicles)	
( I )	vehicles)	
	Deactivating/activating (notes; except AMG vehicles)	
	except AMG vehicles)	
	Display message 211	
EIS		

General notes	. 61
Important safety information	. 62
Warning lamp	244
ETS (Electronic Traction System)	. 61
Exhaust check	163
Exhaust pipe (cleaning instructions)	283
Exterior lighting	
Setting options	108
see Lights	
Exterior mirrors	
Adjusting	103
Dipping (automatic)	104
Folding in/out (automatically)	104
Folding in/out (electrically)	104
Folding in when locking (on-board	
computer)	206
Out of position (troubleshooting)	104
Storing settings (memory function)	105
Storing the parking position	104
Eyeglasses compartment	255

### F

Filler cap	
see Fuel filler flap	
Filling capacities (Technical data)	344
Fire extinguisher	289
First-aid kit	288
Flat tire	
MOExtended tires	290
Preparing the vehicle	289
TIREFIT kit	291
see Emergency spare wheel	
Floormats	272
Fog lamps	
Switching on/off	109
Front fog lamps	
Display message	223
Switching on/off	109
Fuel	
Additives	345
Consumption statistics	195
Displaying the current	
consumption	196
Displaying the range	196
Driving tips	162
Fuel gauge	. 29
Grade (gasoline)	345

Important safety notes	344
Premium-grade unleaded gasoline .	345
Problem (malfunction)	159
Refueling	156
Tank content/reserve fuel	344
Fuel filler flap	
Opening/closing	157
Fuel level	
Calling up the range (on-board	
computer)	196
Fuel tank	
Capacity	344
Problem (malfunction)	159
Fuse allocation chart (vehicle tool	
kit)	289
Fuses	
Allocation chart	303
Before changing	303
Fuse box in the engine	
compartment	304
Fuse box in the trunk	304
Important safety notes	303

# G

### Garage door opener

Clearing the memory	270
Important safety notes	268
Opening/closing the garage door	270
Programming (button in the rear-	
view mirror)	268
Gear indicator (on-board computer)	206
Genuine parts	. 20
Glove box	254

### Н

### Handbrake

see Parking brake	
Hazard warning lamps	111
Display message	238
Head bags	
Display message	218
Operation	. 44
Headlamps	
Cleaning system (notes)	348
Fogging up	113
see Automatic headlamp mode	

Head level heating (AIRSCARF)	100
Head restraints	
Adjusting	. 99
see NECK-PRO head restraints	
Heating	
see Climate control	
High-beam headlamps	
Changing bulbs	116
Display message	222
Switching Adaptive Highbeam	
Assist on/off	113
Switching on/off	111
Hill start assist	143
HOLD function	
Activating	179
Deactivating	179
Display message	228
Function/notes	179
Hood	
Closing	275
Display message	236
Important safety notes	274
Opening	274
Hydroplaning	166

# I

Ignition lock	
see Key positions	
Immobilizer	. 67
Indicator lamps	
see Warning and indicator lamps	
Instrument cluster	
Overview	. 29
Warning and indicator lamps	. 30
Instrument cluster lighting	192
Interior lighting	113
Automatic control	114
Delayed switch-off (on-board	
computer)	204
Emergency lighting	114
Manual control	114
Overview	113
Reading lamp	113

Setting the brightness of the	
ambient lighting (on-board	
computer)	203
Setting the color of the ambient	
lighting (on-board computer)	204

### J

Jack	
Storage	lo

Jump starting (engine)	
Using	330
Storage location	289

# Κ

### **KEYLESS-GO**

Convenience closing feature	84
Display message 2	39
Locking	71
Start/Stop button 1	39
Starting the engine 1	42
Unlocking	71
Key positions	
KEYLESS-GO 1	39
SmartKey 1	39
Kickdown	
Driving tips 1	51
Manual drive program 1	55
Knee bag	43

### L

### Lamps

1 -	
see Warning and indicator lamps	
Lane Keeping Assist	
Activating/deactivating	201
Display message	228
Function/information	188
Lap time (RACETIMER)	207
License plate lamp (display	
message)	223
Light function, active	
Display message	224
Lighting	
Light switch	108
Lights	
Activating/deactivating the	
interior lighting delayed switch-off .	204
Active light function	112
-	

Automatic headlamp mode	109
Cornering light function	111
Driving abroad	108
Fog lamps	109
Hazard warning lamps	111
High beam flasher	111
High-beam headlamps	111
Low-beam headlamps	109
Parking lamps	110
Rear fog lamp	110
Setting the brightness of the	
ambient lighting (on-board	
computer)	203
Setting the color of the ambient	004
lighting (on-board computer)	204
Standing lamps	110
Switching Adaptive Highbeam	
Assist on/off	203
Switching the daytime running	202
lamps on/off (on-board computer)	203
Switching the exterior lighting	
delayed switch-off on/off (on-	201
board computer)	204
Switching the surround lighting	201
on/off (on-board computer)	204
Turn signals	110
see Interior lighting see Replacing bulbs	
Light sensor (display message)	224
Locking	224
see Central locking	
Locking (doors)	
Automatic	78
Emergency locking	
From inside (central locking	/0
button)	77
Locking centrally	,,
see Central locking	
Locking verification signal (on-	
board computer)	205
Low-beam headlamps	
Changing bulbs	116
Display message	221
Setting for driving abroad	
(symmetrical)	108
Switching on/off	109
Luggage cover	
see Trunk partition	

Lumbar support	. 99
М	
M+S tires	308
MAGIC SKY CONTROL	. 9
Malfunction message	
see Display messages	
Manual transmission	
Engaging reverse gear	148
Gear lever	14
Pulling away	14
Shift recommendation	14
Starting the engine	14
Matte finish (cleaning instructions)	28
mbrace	
Call priority	26
Display message	21
Downloading destinations	
(COMAND)	26
Downloading routes	26
Emergency call	26
General notes	25
Geo fencing	26
Locating a stolen vehicle	26
MB info call button	26
Remote vehicle locking	26
Roadside Assistance button	26
Search & Send	26
Self-test	26
Speed alert	26
System	26
Triggering the vehicle alarm	26
Vehicle remote malfunction	
diagnosis	26
Vehicle remote unlocking	26
Mechanical key	
Function/notes	
Locking vehicle	
Unlocking the driver's door	. 7
Memory card (audio)	19
Memory function	10
Message memory (on-board	
computer)	21

Message memory (on-board	
computer)	210
Messages	
see Display messages	

# Mirrors

see Exterior mirrors	
see Rear-view mirror	
see Vanity mirror (in the sun visor)	
Mobile phone	
Menu (on-board computer)	199
Modifying the programming	
(SmartKey)	71
MOExtended tires	
Mounting wheels	
Lowering the vehicle	332
Mounting a new wheel	332
Preparing the vehicle	329
Raising the vehicle	330
Removing a wheel	331
Securing the vehicle against	
rolling away	329
MP3	
see separate operating instructions	
Multifunction display	
Function/notes	194
Permanent display	203
Multifunction steering wheel	
Operating the on-board computer . Overview	193 31

# Ν

	•		
Na	νισ	ation	

Menu (on-board computer)	197
NECK-PRO head restraints	
Operation	50
Resetting after being triggered	51
Notes on breaking-in a new vehicle	138

# 0

Occupant Classification System (OCS)

Faults	49
Operation	45
System self-test	48
Occupant safety	
Children in the vehicle	55
Important safety notes	38
PRE-SAFE <sup>®</sup> (anticipatory	
occupant protection)	50

### ocs

Faults	49
Operation	45
System self-test	48
Odometer	195
Oil	

# see Engine oil On-board computer

AMG menu	206
Assistance menu	200
Audio menu	198
Convenience submenu	205
Displaying a service message	279
Display messages	210
DISTRONIC PLUS	175
Factory settings submenu	202
Important safety notes	192
Instrument cluster submenu	202
Lighting submenu	203
Menu overview	195
Message memory	210
Navigation menu	197
Operation	193
RACETIMER	207
Service menu	201
Settings menu	202
Standard display	195
Telephone menu	199
Trip menu	195
Vehicle submenu	205
Video DVD operation	199
Operating safety	
Declaration of conformity	. 24
Important safety notes	. 23
Operating system	
see On-board computer	
Operator's Manual	
Vehicle equipment	
Outside temperature display	
Overhead control panel	. 34

# Ρ

Paint code number	342
Paintwork (cleaning instructions)	281
Panic alarm	38
Parking	159
Important safety notes	159

Parking brake Position of exterior mirror, front-	160
passenger side see PARKTRONIC	104
Parking aid	
	100
Parking Guidance see Exterior mirrors	183
see PARKTRONIC	
Parking brake	010
Display message	213
Electric parking brake	160
Warning lamp	247
Parking Guidance	
Display message	229
Important safety notes	183
Parking lamps	
Switching on/off	110
PARKTRONIC	
Deactivating/activating	182
Driving system	180
Function/notes	180
Important safety notes	180
Problem (malfunction)	183
Range of the sensors	181
Warning display	182
PASSENGER AIR BAG OFF	
Problem (malfunction)	. 49
Problems (malfunction)	220
PASSENGER AIR BAG OFF indicator	
lamp	. 45
Pivoting draft stop	
see AIRGUIDE	
Plastic trim (cleaning instructions) .	284
Power washers	281
Power windows	
see Side windows	
PRE-SAFE <sup>®</sup> (anticipatory occupant	
protection)	
Display message	216
Operation	. 50
PRE-SAFE <sup>®</sup> Brake	
Activating/deactivating	201
Display message	217
Function/notes	
Warning lamp	250
Program selector button	151

#### Index 14

Protection of the environment	
General notes	20
Pulling away	
Automatic transmission	142
Manual transmission	142

# ۵

Qualified	specialist workshop		24
-----------	---------------------	--	----

# R

RACETIMER (on-board computer)	207
Radar sensor system	
Activating/deactivating	205
Display message	228
Radio	
Selecting a station	198
Radio-wave reception/	
transmission in the vehicle	
Declaration of conformity	. 24
Reading lamp	113
Rear fog lamp	
Display message	223
Switching on/off	110
Rear lamps	
see Lights	
Rear-view mirror	
Anti-glare (manual)	103
Dipping (automatic)	104
Rear window defroster	
Problem (malfunction)	133
Switching on/off	132
Refrigerant (air-conditioning	
system)	
Important safety notes	349
Refueling	
Fuel gauge	
Important safety notes	156
Refueling process	157
see Fuel	
Releasing the parking lock	
manually (automatic transmission)	156
Remote control	
Programming (garage door opener)	268

Replacing bulbs	
Important safety notes 11	4
Overview of bulb types 11	5
Removing/replacing the cover	
(front wheel arch) 11	5
Reporting safety defects 2	25
Reserve (fuel tank)	
see Fuel	
Reserve fuel	
Display message 22	7
Warning lamp 24	-8
see Fuel	
Residual heat (climate control) 13	3
Restraint system	
see SRS (Supplemental Restraint	
System)	
Reverse gear	
Engaging (automatic transmission) 14	.9
Engaging (manual transmission) 14	-8
Reversible floor panel (trunk) 25	6
Reversing feature	
Side windows 8	32
Trunk lid 7	9
Reversing lamps (display message) 22	3
Roadside Assistance (breakdown) 2	2
Roof	
Display message 23	7
Important safety notes 8	6
Opening/closing (with roof switch) 8	7
Opening/closing (with SmartKey) 8	8
Overview 8	6
Problem (malfunction) 9	3
Relocking 8	8
Roof carrier	6
Roof lining and carpets (cleaning	
guidelines) 28	5
Roof switch 8	37

# S

### Safety

Children in the vehicle	55
Child restraint systems	55
Occupant Classification System	
(OCS)	45
Safety system	
see Driving safety systems	

### Seat belts

Adjusting the driver's and front-	
passenger seat belt	. 53
Belt force limiters	
Cleaning	285
Correct usage	. 52
Emergency Tensioning Devices	. 55
Fastening	
Important safety guidelines	
Releasing	
Safety guidelines	
Switching belt adjustment on/off	
(on-board computer)	206
Warning lamp	240
Warning lamp (function)	
Seats	
Adjusting (electrically)	. 98
Adjusting (manually)	
Adjusting the 4-way lumbar	. /0
support	. 99
Adjusting the head restraint	
Cleaning the cover	285
Correct driver's seat position	
Important safety notes	
Overview	
Seat heating problem	100
Storing settings (memory function)	100
Switching AIRSCARF on/off	100
Switching seat heating on/off	
Selector lever	. 77
	284
Cleaning Sensors (cleaning instructions)	283
Service menu (on-board computer) .	201
Service products	047
Brake fluid	347 347
Coolant (engine)	
Engine oil	346
Fuel	344
Important safety notes	344
Refrigerant (air-conditioning	
system)	349
Washer fluid	348
Settings	
Factory (on-board computer)	202
On-board computer	202
Setting the air distribution	130
Setting the airflow	130
SETUP (on-board computer)	207

Side impact air bag	. 43
Side marker lamp	
Changing bulbs (rear)	116
Side marker lamp (display	
message)	223
Side windows	
Cleaning	282
Convenience closing feature	. 84
Important safety information	. 82
Opening/closing (all)	
Opening/closing (front)	. 82
Overview	
Problem (malfunction)	. 86
Resetting	. 84
SmartKey	
Changing the battery	. 73
Changing the programming	. 71
Checking the battery	. 73
Convenience opening feature	. 83
Display message	238
Door central locking/unlocking	. 70
Important safety notes	. 70
Loss	
Mechanical key	
Opening/closing the roof	
Overview	. 70
Positions (ignition lock)	139
Problem (malfunction)	. 75
Starting the engine	142
Snow chains	309
Sockets	
Center console	259
General notes	258
Under the armrest	259
Spare wheel	
Stowing	338
see Emergency spare wheel	
Specialist workshop	
Special seat belt retractor	. 58
Speed, controlling	
see Cruise control	
Speedometer	
Activating/deactivating the	
additional speedometer	203
Digital	196
In the Instrument cluster	. 29
Segments	193
Selecting the unit of measurement	202

# 6 Index

SPORT handling mode	
Activating/deactivating (AMG	
vehicles)	. 63
Warning lamp	
SRS	
see SRS (Supplemental Restraint	
System)	
SRS (Supplemental Restraint	
System)	
Display message	217
Introduction	. 39
Warning lamp	247
Warning lamp (function)	. 39
Standing lamps	
Display message	223
Switching on/off	110
Start/stop function	
see ECO start/stop function	
Starting (engine)	141
Steering (display message)	237
Steering wheel	
Adjusting (electrically)	101
Adjusting (manually)	101
Button overview	. 31
Buttons (on-board computer)	193
Cleaning	284
Important safety notes	100
Paddle shifters	152
Storing settings (memory function)	105
Steering wheel paddle shifters	152
Stopwatch (RACETIMER)	207
Stowage areas	254
Stowage compartments	
Armrest (under)	255
Center console	255
Cup holders	256
Door	255
Eyeglasses compartment	255
Glove box	254
Important safety information	254
Rear wall	255
Stowage net	256
Stowage net	256
Summer tires	308
Sun visor	257
Surround lighting (on-board	
computer)	204

Switching air-recirculation mode	
on/off	133
Switching off the alarm (ATA)	67

# Т

Tachometer	193
Tail lamps	
Display message	222
see Lights	
Tank content	
Fuel gauge	. 29
Technical data	
Capacities	344
Emergency spare wheel	340
Information	342
Tires/wheels	333
Vehicle data	350
TELEAID	
Call priority	263
Downloading destinations	
(COMAND)	263
Downloading routes	267
Emergency call	260
Geo fencing	267
Locating a stolen vehicle	266
MB info call button	262
Remote vehicle locking	265
Roadside Assistance button	262
Search & Send	264
Self-test	260
Speed alert	267
System	260
Triggering the vehicle alarm	268
Vehicle remote malfunction	
diagnosis	266
Vehicle remote unlocking	265
Tele Aid	
General notes	259
Telephone	
Accepting a call	199
Display message	237
Menu (on-board computer)	199
Number from the phone book	200
Redialing	200
Rejecting/ending a call	199

### Temperature

Coolant	192
Coolant (on-board computer)	206
Engine oil (on-board computer)	206
Outside temperature	193
Setting (climate control)	129
Theft deterrent systems	
ATA (Anti-Theft Alarm system)	. 67
Immobilizer	
Time	
see separate operating instructions	
Timing (RACETIMER)	207
TIREFIT kit	291
Tire pressure	
Calling up (on-board computer)	314
Checking manually	313
Display message	233
Important safety notes	314
Maximum	312
Notes	311
Not reached (TIREFIT)	293
Reached (TIREFIT)	293
Recommended	310
Tire pressure loss warning	010
system	
Important safety notes	313
Restarting	314
Tire pressure monitoring system	014
Checking the tire pressure	
electronically	316
Function/notes	314
General notes	314
Important safety notes	315
Restarting	317
Warning lamp	251
	316
Warning message	310
Aspect ratio (definition)	327
Average weight of the vehicle	327
	326
occupants (definition)	
Bar (definition)	326
Changing a wheel	328
Characteristics	325
Checking	307
Definition of terms	326
Direction of rotation	329
Display message	233

Distribution of the vehicle	
occupants (definition)	328
DOT, Tire Identification Number	020
(TIN)	325
DOT (Department of	020
Transportation) (definition)	326
GAWR (Gross Axle Weight Rating)	020
(definition)	326
GVW (Gross Vehicle Weight)	020
(definition)	326
GVWR (Gross Vehicle Weight	020
Rating) (definition)	326
Important safety notes	306
Increased vehicle weight due to	
optional equipment (definition)	326
Kilopascal (kPa) (definition)	327
Labeling (overview)	322
Load bearing index (definition)	328
Load index	324
Load index (definition)	327
M+S tires	308
Maximum loaded vehicle weight	
(definition)	327
Maximum load on a tire (definition)	327
Maximum permissible tire	
pressure (definition)	327
Maximum tire load	325
Maximum tire load (definition)	327
MOExtended tires	308
Optional equipment weight	
(definition)	327
Overview	306
PSI (pounds per square inch)	
(definition)	327
Replacing	328
Service life	308
Sidewall (definition)	327
Speed rating (definition)	326
Storing	329
Structure and characteristics	
(definition)	326
Summer tires	308
Temperature	321
TIN (Tire Identification Number)	
(definition)	327
Tire bead (definition)	327
Tire pressure (definition)	327
Tire pressures (recommended)	326

Tire size (data)	333
Tire size designation, load-bearing	
capacity, speed rating	322
Tire tread	307
Tire tread (definition)	327
Total load limit (definition)	328
Traction	321
Traction (definition)	328
Tread wear	321
Uniform Tire Quality Grading	
Standards	320
Uniform Tire Quality Grading	
Standards (definition)	326
Unladen weight (definition)	327
Wear indicator (definition)	328
Wheel rim (definition)	326
see Flat tire	020
Towing	
Important safety guidelines	300
Installing the towing eye	301
Removing the towing eye	301
With the rear axle raised	302
Towing away	002
With both axles on the ground	302
Tow-starting	002
Emergency engine starting	303
Important safety notes	300
Installing the towing eye	301
Removing the towing eye	301
Transmission	001
Selector lever	149
see Automatic transmission	177
see Manual transmission	
Transporting the vehicle	302
Trim pieces (cleaning instructions) .	284
Trip computer (on-board computer)	195
Trip odometer	170
Calling up	195
Resetting (on-board computer)	196
Trunk	.,.
Emergency release	. 81
Important safety notes	
Locking separately	
Opening/closing (manually from	
outside)	. 80
Opening (automatically from	
outside)	. 80
Overview	

### Trunk lid

Display message	236
Opening/closing	79
Opening dimensions	350
Trunk load (maximum)	350
Trunk partition	
Display message	237
General notes	88
Opening/closing	89
Turn signals	
Changing bulbs (front)	117
Display message	221
Switching on/off	110
Type identification plate	
see Vehicle identification plate	

# U

### Unlocking

Emergency unlocking	78
From inside the vehicle (central	
unlocking button)	77

### V

### Vanity mirror (in the sun visor) ...... 258 Vehicle Correct use ..... 25

	ZJ
Data acquisition	26
Display message 23	35
Equipment	21
Individual settings 20	02
	25
Loading 3	17
	78
	70
	32
	22
Parking for a long period 10	62
Pulling away 14	42
Raising 33	30
	25
Securing from rolling away 32	29
	00
	00
	02
	78

Unlocking (SmartKey)	70
Vehicle data	350
Vehicle battery	
see Battery (vehicle)	
Vehicle data	350
Vehicle dimensions	350
Vehicle emergency locking	78
Vehicle identification number	
see VIN	
Vehicle identification plate	342
Vehicle tool kit	289
Video	
Operating the DVD	199
VIN	342

### W

# Warning and indicator lamps

ABS	242
Brakes	242
Check Engine	248
Coolant	248
Distance warning	250
DISTRONIC PLUS	250
ESP <sup>®</sup>	244
ESP <sup>®</sup> OFF	245
Fuel tank	248
Overview	. 30
PASSENGER AIRBAG OFF	. 45
Reserve fuel	248
Seat belt	240
SPORT handling mode	245
SRS	247
Tire pressure monitor	251
Warning triangle	288
Warranty	342
Washer fluid	
Display message	238
Wheel bolt tightening torque	332
Wheel chock	329
Wheels	
Changing a wheel	328
Checking	307
Cleaning	282
Cleaning (warning)	329
Emergency spare wheel	337
Important safety notes	306
Interchanging/changing	328

Mounting a new wheel	332
Mounting a wheel	329
Overview	306
Removing a wheel	331
Storing	329
Tightening torque	332
Wheel size/tire size	333
Windows	
see Side windows	
Wind screen	
Inserting and removing	
Preparing for installation	89
see AIRGUIDE	
Windshield	
Defrosting	131
Windshield washer fluid	
see Windshield washer system	
Windshield washer system	
Adding washer fluid	277
Notes	348
Windshield wipers	
Display message	238
Problem (malfunction)	120
Replacing the wiper blades	118
Switching on/off	117
Winter driving	
Important safety notes	308
Slippery road surfaces	167
Snow chains	309
Winter operation	
Overview	308
Winter tires	
M+S tires	308
Wiper blades	
Cleaning	282
Important safety notes	118
Replacing	118
Wooden trim (cleaning instructions)	284
Workshops	
see Qualified specialist workshop	

# Ζ

# **ZONE** function

Switching on/off		130
------------------	--	-----

### Protection of the environment

### **General notes**

### Environmental note

Daimler's declared policy is one of comprehensive environmental protection.

The objectives are for the natural resources that form the basis of our existence on this planet to be used sparingly and in a manner that takes the requirements of both nature and humanity into account.

You too can help to protect the environment by operating your vehicle in an environmentally responsible manner.

Fuel consumption and the rate of engine, transmission, brake and tire wear are affected by these factors:

- operating conditions of your vehicle
- your personal driving style

You can influence both factors. You should bear the following in mind:

Operating conditions:

- avoid short trips as these increase fuel consumption.
- always make sure that the tire pressures are correct.
- do not carry any unnecessary weight.
- remove roof racks once you no longer need them.
- a regularly serviced vehicle will contribute to environmental protection. You should therefore adhere to the service intervals.
- always have service work carried out at a qualified specialist workshop.

Personal driving style:

- do not depress the accelerator pedal when starting the engine.
- do not warm up the engine when the vehicle is stationary.
- drive carefully and maintain a safe distance from the vehicle in front.
- avoid frequent, sudden acceleration and braking.

- change gear in good time and use each gear only up to <sup>2</sup>/<sub>3</sub> of its maximum engine speed.
- switch off the engine in stationary traffic.
- keep an eye on the vehicle's fuel consumption.

# Environmental concerns and recommendations

Wherever the operating instructions require you to dispose of materials, first try to regenerate or re-use them. Observe the relevant environmental rules and regulations when disposing of materials. In this way you will help to protect the environment.

### **Genuine Mercedes-Benz parts**

#### Environmental note

Daimler AG also supplies reconditioned major assemblies and parts which are of the same quality as new parts. They are covered by the same Limited Warranty entitlements as new parts.

- Air bags and Emergency Tensioning Devices, as well as control units and sensors for these restraint systems, may be installed in the following areas of your vehicle:
  - doors
  - door pillars
  - door sills
  - seats
  - cockpit
  - instrument cluster
  - center console

Do not install accessories such as audio systems in these areas. Do not carry out repairs or welding. You could impair the operating efficiency of the restraint systems. Have aftermarket accessories installed at a qualified specialist workshop.

You could jeopardize the operating safety of your vehicle if you use parts, tires and wheels as well as accessories relevant to safety which have not been approved by Mercedes. This could lead to malfunctions in safetyrelevant systems, e.g. the brake system. Use only genuine Mercedes-Benz parts or parts of equal quality. Only use tires, wheels and accessories that have been specifically approved for your vehicle.

Genuine Mercedes-Benz parts are subject to strict quality control. Every part has been specifically developed, manufactured or selected for and adapted to Mercedes-Benz vehicles. Only genuine Mercedes-Benz parts should therefore be used.

More than 300,000 different genuine Mercedes-Benz parts are available for Mercedes-Benz models.

All authorized Mercedes-Benz Centers maintain a supply of genuine Mercedes-Benz parts for necessary service and repair work. In addition, strategically located parts delivery centers provide quick and reliable parts service.

Always specify the vehicle identification number (VIN) (> page 342) and the engine number (> page 343) when ordering genuine Mercedes-Benz parts. The original purchase agreement lists all systems installed in your vehicle.

Should you have any questions concerning equipment and operation, please consult an authorized Mercedes-Benz Center.

The Operator's Manual and Maintenance Booklet are important documents and should be kept in the vehicle.

### Service and vehicle operation

### Service and literature

Your vehicle is covered under the terms of the warranties printed in the Service and Warranty Information booklet. Your authorized Mercedes-Benz Center will exchange or repair any defective parts originally installed in the vehicle in accordance with the terms of the following warranties:

- New Vehicle Limited Warranty
- Emission Systems Warranty
- Emission Performance Warranty
- California, Connecticut, Maine, Massachusetts, New York, Pennsylvania, Rhode Island and Vermont Emission Control Systems Warranty
- State warranty enforcement laws (lemon laws)

### **Operator's Manual**

### Vehicle equipment

This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of going to print. Country-specific differences are possible. Bear in mind that your vehicle may not feature all functions described here. This also applies to safety-relevant systems and functions. The equipment in your vehicle may therefore differ from that shown in the descriptions and illustrations.

# Information for customers in California

Under California law you may be entitled to a replacement of your vehicle or a refund of the purchase price or lease price, if after a reasonable number of repair attempts Mercedes-Benz USA, LLC and/or its authorized repair or service facilities fail to fix one or more substantial defects or malfunctions in the vehicle that are covered by its express warranty. During the period of 18 months from original delivery of the vehicle or the accumulation of 18,000 miles (approximately 29,000 km) on the odometer of the vehicle, whichever occurs first, a reasonable number of repair attempts is presumed for a retail buyer or lessee if one or more of the following occurs:

- (1) the same substantial defect or malfunction results in a condition that is likely to cause death or serious bodily injury if the vehicle is driven, that defect or malfunction has been subject to repair two or more times, and you have directly notified Mercedes-Benz USA, LLC in writing of the need for its repair,
- (2) the same substantial defect or malfunction of a less serious nature than category (1) has been subject to repair four or more times and you have directly notified us in writing of the need for its repair, or
- (3) the vehicle is out of service by reason of repair of the same or different substantial defects or malfunctions for a cumulative total of more than 30 calendar days.

Please send your written notice to: Mercedes-Benz USA, LLC Customer Assistance Center One Mercedes Drive Montvale, NJ 07645-0350

### Maintenance

The Service and Warranty Booklet describes all the necessary maintenance work which should be done at regular intervals. Always have the Service and Warranty Booklet with you when you bring the vehicle to an authorized Mercedes-Benz Center. The service advisor will record every service for you in the Service and Warranty Booklet.

### **Roadside Assistance**

The Mercedes-Benz Roadside Assistance Program offers technical help in the event of a breakdown. Calls to the toll-free Roadside Assistance Hotline are answered by our agents 24 hours a day, 365 days a year.

### 1-800-FOR-MERCedes(1-800-367-6372) (USA)

### 1-800-387-0100 (Canada)

For additional information, refer to the Mercedes-Benz Roadside Assistance Program brochure (USA) or the "Roadside Assistance" section in the Service and Warranty booklet (Canada). You will find both in your vehicle literature portfolio.

# Change of address or change of ownership

In the event of a change of address, please send us the "Notification of Address Change" in the Service and Guarantee booklet or simply call the Mercedes-Benz Customer Assistance Center (USA) at the hotline number

1-800-FOR-MERCedes(1-800-367-6372) or Customer Service Center (Canada) at 1-800-387-0100. This will assist us in contacting you in a timely manner should the need arise.

If you sell your Mercedes, please leave the entire literature in the vehicle so that it is available to the next owner. If you have purchased a used car, please send us the "Notification of Used Car Purchase" in the Service and Guarantee booklet or simply call the Mercedes-Benz Customer Assistance Center (USA) at the hotline number 1-800-FOR-MERCedes(1-800-367-6372) or Customer Service (Canada) at 1-800-387-0100.

# Vehicle operation outside the USA and Canada

If you plan to operate your vehicle in foreign countries, please be aware that:

- service facilities or replacement parts may not be readily available.
- unleaded fuel for vehicles with a catalytic converter may not be available. Leaded fuel may cause damage to the catalytic converter.
- the fuel may have a considerably lower octane rating. Unsuitable fuel can cause engine damage.

Some Mercedes-Benz models are available for delivery in Europe through our European Delivery Program. For details, consult an authorized Mercedes-Benz Center or write to one of the following addresses.

### In the USA

Mercedes-Benz USA, LLC European Delivery Department One Mercedes Drive Montvale, NJ 07645-0350

### In Canada

Mercedes-Benz Canada, Inc. European Delivery Department 98 Vanderhoof Avenue

Toronto, Ontario M4G 4C9

### **Operating safety**

### Important safety notes

### MARNING

If you do not have the prescribed service/ maintenance work or any required repairs carried out, this can result in malfunctions or system failures. There is a risk of an accident.

Always have the prescribed service/ maintenance work as well as any required repairs carried out at a qualified specialist workshop.

### 

If you switch off the ignition while driving, safety-relevant functions are only available with limitations, or not at all. This could affect, for example, the power steering and the brake boosting effect. You will require considerably more effort to steer and brake. There is a risk of an accident.

Do not switch off the ignition while driving.

### 

Modifications to electronic components, their software as well as wiring can impair their function and/or the function of other networked components. In particular, systems relevant to safety could also be affected. As a result, these may no longer function as intended and/or jeopardize the operating safety of the vehicle. There is an increased risk of an accident and injury. Never tamper with the wiring as well as electronic components or their software. You should have all work to electrical and electronic equipment carried out at a qualified specialist workshop.

- I There is a risk of damage to the vehicle if:
  - the vehicle becomes stuck, e.g. on a high curb or an unpaved road
  - you drive too fast over an obstacle, e.g. a curb or a hole in the road
  - a heavy object strikes the undercarriage or parts of the chassis.

In situations like this, the body, the undercarriage, chassis parts, wheels or tires could be damaged without the damage being visible. Components damaged in this way can unexpectedly fail or, in the case of an accident, no longer withstand the strain they are designed to. If the underbody paneling is damaged, combustible materials such as leaves. grass or twigs can gather between the underbody and the underbody paneling. If these materials come in contact with hot parts of the exhaust system for an extended period, they can catch fire. Have the vehicle checked and repaired immediately at a qualified specialist workshop. If on continuing your journey you notice that driving safety is impaired, pull over and stop the vehicle immediately, paying attention to road and traffic conditions. In such cases, visit a qualified specialist workshop.

### **Declarations of conformity**

# Vehicle components which receive and/or transmit radio waves

**USA:** "The wireless devices of this vehicle comply with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) These devices may not cause harmful interference, and 2) These devices must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."

**Canada:** "The wireless devices of this vehicle comply with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) These devices may not cause interference, and (2) These devices must accept any interference, including interference that may cause undesired operation of the device."

#### **Diagnostics connection**

The diagnostics connection is only intended for the connection of diagnostic equipment at a qualified specialist workshop.

### **MARNING №**

If you connect equipment to the diagnostics connection in the vehicle, it may affect the operation of the vehicle systems. As a result, the operating safety of the vehicle could be affected. There is a risk of an accident.

Do not connect any equipment to a diagnostics connection in the vehicle.

### 

Objects in the driver's footwell can restrict the pedal travel or obstruct a depressed pedal. The operating and road safety of the vehicle is jeopardized. There is a risk of an accident.

Make sure that all objects in the vehicle are stowed correctly, and that they cannot enter the driver's footwell. Install the floormats securely and as specified in order to ensure sufficient clearance for the pedals. Do not use loose floormats and do not place floormats on top of one another.

If the engine is switched off and equipment on the diagnostics connection is used, the starter battery may discharge.

Connecting equipment to the diagnostics connection can lead to emissions monitoring information being reset, for example. This may lead to the vehicle failing to meet the requirements of the next emissions test during the main inspection.

### **Qualified specialist workshop**

An authorized Mercedes-Benz Center is a qualified specialist workshop. It has the necessary specialist knowledge, tools and

Introduction 25

qualifications to correctly carry out the work required on your vehicle. This is especially the case for work relevant to safety.

Observe the notes in the Maintenance Booklet.

Always have the following work carried out at an authorized Mercedes-Benz Center:

- work relevant to safety
- service and maintenance work
- repair work
- alterations, installation work and modifications
- work on electronic components

### **Correct use**

If you remove any warning stickers, you or others could fail to recognize certain dangers. Leave warning stickers in position.

Observe the following information when driving your vehicle:

- the safety notes in this manual
- the Technical Data section in this manual
- traffic rules and regulations
- laws and safety standards pertaining to motor vehicles

### Problems with your vehicle

If you should experience a problem with your vehicle, particularly one that you believe may affect its safe operation, we urge you to contact an authorized Mercedes-Benz Center immediately to have the problem diagnosed and rectified. If the problem is not resolved to your satisfaction, please discuss the problem again with a Mercedes-Benz Center or contact us at one of the following addresses.

### In the USA

Customer Assistance Center Mercedes-Benz USA, LLC One Mercedes Drive Montvale, NJ 07645-0350

#### In Canada

Customer Relations Department Mercedes-Benz Canada, Inc. 98 Vanderhoof Avenue Toronto, Ontario M4G 4C9

### **Reporting safety defects**

#### USA only:

The following text is published as required of manufacturers under Title 49, Code of U.S. Federal Regulations, Part 575 pursuant to the "National Traffic and Motor Vehicle Safety Act of 1966".

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Mercedes-Benz USA, LLC.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Mercedes-Benz USA, LLC.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at

1-888-327-4236(TTY: 1-800-424-9153); go to **http://www.safercar.gov**; or write to: Administrator, NHTSA, 400 Seventh Street, SW., Washington, DC 20590.

You can also obtain other information about motor vehicle safety from

http://www.safercar.gov

### **Limited Warranty**

Follow the instructions in this manual about the proper operation of your vehicle as well as about possible vehicle damage. Damage to your vehicle that arises from culpable contraventions against these instructions is not covered either by the Mercedes-Benz Limited Warranty or by the New or Used-Vehicle Warranty.

### Data stored in the vehicle

# Information about electronic data acquisition in the vehicle

(Including notice pursuant to California Code § 9951)

Please note that your vehicle is equipped with devices that can record vehicle systems data. If your vehicle is equipped with mbrace (Canada: TELE AID), data is transmitted in the event of an accident.

This information helps, for example, to test vehicle systems after an accident and to continually improve vehicle safety.

Daimler AG can access these data and submit them:

- for safety research or vehicle diagnosis purposes
- with the consent of the vehicle owner
- on the instruction of prosecuting authorities
- for use in arbitration of disputes that involve Daimler AG, its subsidiaries or its sales and service organizations
- as otherwise required or permitted by law

Please check your mbrace (Canada: TELE AID) purchase agreement to find out more about data that can be recorded and transmitted by this system.

This vehicle is equipped with an event data recorder (EDR). The main purpose of an EDR is to record data that will assist in understanding how a vehicle's systems performed in certain crash or near crash-like situations, such as during air bag deployment or when hitting a road obstacle. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less. The EDR in this vehicle is designed to record such data as:

- how various systems in your vehicle are operating
- whether or not the driver and passenger seat belts are fastened
- how far (if at all) the driver is depressing the accelerator and/or brake pedal and
- · how fast the vehicle is traveling

This data can help provide a better understanding of the circumstances in which crashes and injuries occur. NOTE: EDR data is recorded by your vehicle only if a non-trivial crash situation occurs; no data is recorded by the EDR under normal driving conditions and no personal data (e.g., name, gender, age, and crash location) are recorded. However, other parties, such as law enforcement, can combine the EDR data with the type of personal identification data routinely acquired during a crash investigation.

To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties, such as law enforcement, who have the special equipment, can read the information if they have access to the vehicle or the EDR.

### Information on copyright

### **General information**


Information on license for free and opensource software used in your vehicle and its electronic components is available on the following website:

http://www.mercedes-benz.com/ opensource

Dashboard	28	
Instrument cluster	29	
Multifunction steering wheel	31	Ce
Center console	32	an
Overhead control panel		60
Door control panel	35	\t a

D

# Dashboard




	Function	Page
1	Steering wheel paddle shifters	152
2	Combination switch	110
3	Instrument cluster	29
4	Horn	
5	PARKTRONIC warning display	180
6	Overhead control panel	34
7	Climate control systems	122
8	Ignition lock Start/Stop button	139 139

	Function	Page
9	Adjusting the steering wheel manually	100
10	Adjusting the steering wheel electrically	100
(1)	Cruise control lever	168
(12)	Electric parking brake	160
(13)	Diagnostics connection	24
(14)	Opening the hood	274
(15)	Light switch	108

### Instrument cluster

### Displays and controls



# Warning and indicator lamps



	Function	Page
1	Iow-beam headlamps	109
2	Foot Parking lamps	110
3	ED High-beam headlamps	111
4	ESP <sup>®</sup>	244
5	<b>PARK</b> Electric parking brake (red)	242
6	(P) Electric parking brake (yellow)	242
7	<b>A</b> Distance warning	250
8	🗘 🗘 Turn signals	110
9	(!) Tire pressure monitor	314
(10)	🖈 SRS	247

	Function	Page
(11)	[ 🍇 Seat belt	240
(12)	SPORT SPORT handling mode in AMG vehicles	245
(13)	Coolant	248
(14)	0≢ Rear fog lamp	110
(15)	<b>₽</b> Front fog lamps	109
(16)	Check Engine	248
(17)	Reserve fuel	248
(18)	SFF ESP <sup>®</sup> OFF	244
(19)	(a) ABS	242
20	BRAKE Brakes	242

# Multifunction steering wheel



	Function	Page	
1	Multifunction display	194	
2	COMAND display; see the separate Operating Instructions		
3	Switches on the Voice Control System; see the separate operating instructions		
4	Rejects or ends a call Exits phone book/redial memory Makes or accepts a call Switches to the redial memory + - Adjusts the volume Mute	199	

	Function	Page
5	Selects a menu	193
	Selects a submenu or scrolls through lists	193
	Confirms your selection	193
	Hides display messages	210
6	Back Switches off the Voice Control System; see the separate operating instructions	193

# At a glance

# Center console


# Center console, upper section



	Function	Page	
1	COMAND; see the separate operating instructions		
2	₩ Seat heating	99	
3	AIRSCARF	100	
4	PW PARKTRONIC	180	
5	<b>ECO</b> ECO start/stop function (AMG vehicles)	143	


	Function	Page
6	Azard warning lamps	111
7	orr ⅔2 PASSENGER AIR BAG OFF indicator lamp	45
8	ESP <sup>®</sup>	62
9	Dynamic handling package with sports mode	178

# Center console, lower section



	Function	Page		Function	Page
(10)	Stowage compartment	254	(14)	Roof switch cover	87
	Ashtray Cigarette lighter Socket	258 258 258	(15)	COMAND controller; see the separate operating instructions	
(11)	Selector lever	149	(16)	$[{}^{s}_{{\mathbb L}_{\mathcal M}}]$ Selects the drive	
(12)	Cup holder	256		program	151
(13)	Stowage compartment	254		$\mathbf{M}^{\underline{C}}$ Selects the drive program (AMG vehicles)	151


# Overhead control panel



	Function	Page
1	盗 Switches the left- hand reading lamp on/off	113
2	Switches the interior lighting on/off	114
3	Operates MAGIC SKY CONTROL	91
4	Switches the right- hand reading lamp on/off	113
5	Switches the automatic interior lighting control on/off	114
6	Eyeglasses compartment	255

	Function	Page
7	Si MB Info call button (mbrace system)	262
8	Rear-view mirror	103
9	Buttons for the garage door opener	270
10	☑ Roadside Assistance call button (mbrace system)	262
(1)	<b><b>€</b><sup>sos</sup> SOS button (mbrace system)</b>	260

# At a glance





	Function	Page
1	Opens the door	77
2	Unlocks/locks the vehicle	77
3	Adjusts the seats electrically	98
4	M 1 2 3 Stores settings for the seat, exterior mirrors and steering wheel	105
5	Folds the exterior mirrors in/out	104

	Function	Page
6	Selects the right exterior mirror	103
7	Opens/closes the right side window	82
8	Opens/closes the left side window	82
9	Adjusts the exterior mirrors	103
10	Selects the left exterior mirror	103

Useful information	38
Panic alarm	38
Occupant safety	38
Child restraint systems	55
Driving safety systems	59
Theft deterrent locking system	67

Safety

#### **Useful information**

This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.

I Read the information on qualified specialist workshops: (▷ page 24).



► To activate: press PANIC button ① for at least one second.

An alarm sounds and the exterior lighting flashes.

► To deactivate: press PANIC button (1) again.

or

- Insert the SmartKey into the ignition lock.
   or
- Press the KEYLESS-GO Start/Stop button. The KEYLESS-GO key must be in the vehicle.

#### Occupant safety

#### Important safety notes

# 

Modifications to the restraint systems could result in them not functioning properly any more. The restraint systems could then no longer protect vehicle occupants as they are designed to do and could fail in the event of an accident or activate unexpectedly, for example. There is an increased risk of injury. Never modify parts of the restraint systems. Do not attempt to modify the wiring as well as electronic components or their software.

If it is necessary to modify an air bag system to accommodate a person with disabilities, contact an authorized Mercedes-Benz center. USA only: for further information contact our Customer Assistance Center at 1-800-FOR-MERCedes (1800-367-6372).

In this section, you will learn the most important facts about the restraint system components of the vehicle.

The restraint system consists of:

- · Seat belts
- · Child restraint systems

Additional protection is provided by:

- SRS (Supplemental Restraint System)
- NECK-PRO head restraints
- PRE-SAFE®
- Air bag system components with:
  - The PASSENGER AIR BAG ON/OFF indicator lamp<sup>1</sup>
  - Front-passenger seat with Occupant Classification System (OCS)

Although the systems are independent, their protective functions work in conjunction with each other. Not all air bags are always deployed in an accident.

• For information on infants and children traveling with you in the vehicle restraint

<sup>1</sup> The PASSENGER AIR BAG ON indicator lamp does not have a function. It lights up briefly when the ignition is switched on and then goes out again.

Safety

systems for infants and children, see "Children in the vehicle" (▷ page 55).

#### SRS (Supplemental Restraint System)

#### Introduction

SRS consists of:

- The 😰 SRS warning lamp
- Air bags
- The air bag control unit with crash sensors
- Emergency Tensioning Device (ETD) for seat belts
- · Seat belt force limiter

SRS reduces the risk of vehicle occupants coming into contact with parts of the vehicle's interior in the event of an accident. It can also reduce the forces to which vehicle occupants are subjected during an accident.

#### SRS warning lamp

#### 

If SRS is malfunctioning, child restraint system components may be triggered unintentionally or might not be triggered at all in the event of an accident with a high rate of vehicle deceleration. There is an increased risk of injury, possibly even fatal.

Have SRS checked and repaired immediately at a qualified specialist workshop.

SRS functions are checked regularly when you switch on the ignition and when the engine is running. Therefore, malfunctions can be detected in good time.

The SRS warning lamp in the instrument cluster lights up when the ignition is switched on. It goes out no later than a few seconds after the engine is started.

The SRS components are in operational readiness when the SRS warning lamp goes out while the engine is running.

There is a malfunction if:

- the SRS warning lamp does not light up when the ignition is switched on
- the engine is running and the 💽 SRS warning lamp does not go out after a few seconds
- the engine is running and the 💽 SRS warning lamp lights up again

#### Safety guidelines for seat belts, Emergency Tensioning Devices (ETDs) and air bags

#### MARNING

- Damaged seat belts or seat belts that have been subjected to stress in an accident must be replaced. Their anchoring points must also be checked. Only use seat belts installed or supplied by an authorized Mercedes-Benz Center.
- Air bags and pyrotechnic Emergency Tensioning Devices (ETDs) contain perchlorate material, which may require special handling and regard for the environment. Check your national disposal guidelines. In California, see www.dtsc.ca.gov/HazardousWaste/ Perchlorate/index.cfm.
- Air bags and ETDs are designed to function on a one-time-only basis. An air bag or ETD that has deployed must be replaced.
- Do not pass seat belts over sharp edges. They could tear.
- Do not make any modification that could change the effectiveness of the seat belts.
- Do not bleach or dye seat belts, as this may severely weaken them. In a crash, they may not be able to provide adequate protection.
- Do not make any modifications to the SRS wiring or components.
- Do not modify or remove any components or parts of the SRS.

- Do not install additional trim material, seat covers, badges, etc. to the:
  - padded steering wheel boss
  - knee bag covers
- front-passenger air bag cover
- outer side of front seat bolsters
- outer seat bolsters of the rear bench seat backrest
- roof frame trim
- Do not install additional electrical/ electronic equipment on or near SRS components and wiring.
- Keep the area between the air bags and occupants free of objects (e.g. packages, handbags, umbrellas etc.).
- Do not hang any objects such as coat hangers on the coat hooks or the grab handle above the door. These items may be thrown around in the vehicle and cause head and other injuries when the window curtain air bag is deployed.
- Air bag system components will be hot after an air bag has inflated. Do not touch them.
- Never rest your feet on the dashboard or the seat. Always keep both feet on the floor in front of the seat.
- Improper repair work on the SRS creates a risk of rendering the SRS inoperative or causing unintended air bag deployment.
   Work on the SRS must therefore only be performed by qualified technicians.
   Consult an authorized Mercedes-Benz Center.
- For your protection and the protection of others, when scrapping the air bag unit or ETD, our safety instructions must be followed. These are available from any authorized Mercedes-Benz Center.
- Given the considerable deployment speed, required inflation volume, and the material of the air bags, there is the possibility of abrasions or other, potentially more serious injuries resulting from air bag deployment.

If you sell your vehicle, Mercedes-Benz strongly recommends that you inform the subsequent owner that the vehicle is equipped with SRS. Also, refer them to the applicable section in the Operator's Manual.

#### Air bags

#### Important safety notes

#### **MARNING** ▲

Using unsuitable seat covers could restrict or even prevent deployment of the air bags integrated into the seats. Consequently, the air bags cannot protect vehicle occupants as they are designed to do. In addition, the function of the air bag deactivation system could be restricted. This poses an increased risk of injury or even fatal injury.

You should only use seat covers that have been approved for the respective seat by Mercedes-Benz.

# MARNING

The air bag parts are hot after the airbag has been deployed. There is a risk of injury.

Do not touch the air bag parts. Have the deployed air bags replaced at a qualified specialist workshop as soon as possible.

# MARNING

Air bags are designed to reduce the incidence of injuries and fatalities in certain situations:

- frontal impacts (driver's and frontpassenger front air bags and knee bags)
- side impacts (side impact air bags and head bags)
- rollover (head bags)

However, no system available today can completely eliminate injuries and fatalities.

When the air bags are deployed, a small amount of powder is released. The powder generally does not constitute a health hazard and does not indicate that there is a fire in the vehicle. In order to prevent potential breathing difficulties, you should leave the vehicle as soon as it is safe to do so. If you have any breathing difficulty but cannot get out of the vehicle after the air bag inflates, then get fresh air by opening a window or door.

# 

In order to reduce the potential danger of injuries caused during the deployment of the front air bags, the driver and front passenger must always be correctly seated and wear their seat belts.

For maximum protection in the event of a collision, you must always be in the normal seat position with your back against the backrest. Fasten your seat belt and make sure that it is correctly positioned on your body.

As the air bag inflates with considerable speed and force, a proper seating position and correct positioning of the hands on the steering wheel will help to keep you at a safe distance from the air bag. Occupants who are not wearing their seat belt, are not seated properly or are too close to the air bag can be seriously injured or killed by an air bag, as it inflates with great force instantaneously:

- sit with the seat belt fastened correctly and in a position that is as upright as possible with your back against the backrest.
- move the driver's seat as far back as possible, still permitting proper operation of vehicle controls. The distance from the center of the driver's chest to the middle of the air bag cover on the steering wheel must be at least 10 inches (25 cm). You should be able to accomplish this by adjusting the seat and steering wheel. If you have any difficulties, please contact a qualified specialist workshop.
- do not lean your head or chest close to the steering wheel or dashboard.
- only hold the steering wheel on the outside.
   Placing hands and arms inside the rim of the steering wheel can increase the risk

and potential severity of hand/arm injuries if the air bag inflates.

- adjust the front-passenger seat as far back as possible from the dashboard when the seat is occupied.
- occupants, especially children, should never place their bodies or lean their heads in the area of the door where the side impact air bag and/or head bag inflates. This could result in serious injuries or death should the side impact air bag/head bag be deployed. Always sit as upright as possible, wear the seat belt properly and use an appropriately sized infant restraint, toddler restraint or booster seat recommended for the size and weight of the child.

Failure to follow these instructions can result in severe injuries to you or other occupants. If you sell your vehicle, it is important that you make the buyer aware of this safety information. Be sure to give the buyer this Operator's Manual.

# MARNING

If the side impact air bag and/or head bag is deployed in the event of a side impact and the front passenger, especially a child, is not properly seated or restrained when next to a side impact air bag/head bag, injuries are possible due to the rapid inflation of the side impact air bag/head bag.

To help avoid the possibility of injury, please follow these guidelines:

- Always sit as upright as possible, and use the seat belts properly. Make sure that children 12 years old and under use an appropriately sized child restraint, infant restraint or booster seat recommended for the size and weight of the child.
- (2) Always wear seat belts properly.

If the air bags are deployed, you will hear a bang, and a small amount of powder may also be released. Only in rare cases will the bang affect your hearing. The powder that is released generally does not constitute a health hazard and does not indicate that there is a fire in the vehicle. The dust might cause some temporary breathing difficulty for people with asthma or other breathing trouble. To avoid this, you may wish to get out of the vehicle as soon as it is safe to do so. You can also open the window to allow fresh air to enter the vehicle interior. The rest SRS warning lamp lights up.

The air bag installation locations are identified by the AIR BAG symbol.

The air bags are deployed if the air bag control unit detects the need for deployment. Only in the event of such a situation will the air bags provide their supplemental protection.

If the driver and front passenger do not wear their seat belts, it is not possible for the air bags to provide their supplemental protection.

In the event of other types of impacts and impacts below air bag deployment thresholds, the air bags will not deploy. The driver and passenger will then be protected to the extent possible by a properly fastened seat belt. A properly fastened seat belt is also needed to provide the best possible protection in a rollover.

Air bags provide additional protection; they are not, however, a substitute for seat belts. All vehicle occupants must fasten their seat belts.

It is important for your safety and that of your passenger to have deployed air bags replaced and to have any malfunctioning air bags repaired. This will help to make sure the air bags continue to perform their protective function for the vehicle occupants in the event of a crash.

After an air bag has been deployed, have the vehicle towed to the nearest qualified specialist workshop, even if your vehicle is ready to drive.

#### Front air bags



Driver's air bag ① deploys in front of the steering wheel; front-passenger front air bag ② deploys in front of and above the glove box.

The front air bags increase protection for the driver's and front passenger's head and chest.

They are deployed:

- at the start of an accident with a high rate of vehicle acceleration or deceleration in a longitudinal direction
- if the system determines that air bag deployment can offer additional protection to that provided by the seat belt
- independently of other air bags in the vehicle

The release time of the front air bags is dependant upon the use of the seat belt.

If the vehicle rolls over, the front air bags are generally not deployed.

Your vehicle has adaptive, two-stage front air bags. In the event of a collision, the air bag control unit evaluates the vehicle deceleration. In the first deployment stage, the front air bag is filled with enough propellant gas to reduce the risk of injuries. The front air bag is fully deployed if a second deployment threshold is exceeded within a few milliseconds.

The deployment of the front-passenger front air bag is also influenced by the weight category of the front passenger, which is determined by the Occupant Classification System (OCS) (▷ page 45).

The lighter the passenger-side occupant, the higher the vehicle deceleration rate required (predicted at the start of the impact) for second-stage inflation of the front-passenger front air bag. In the second stage, the front air bags are inflated with the maximum amount of propellant gas available.

The front air bags are not deployed in situations where a low impact severity is predicted. You will then be protected by the fastened seat belt.

The front-passenger front air bag will only deploy if:

- the system, based on the OCS weight sensor readings, detects that the frontpassenger seat is occupied
- the PASSENGER AIR BAG OFF indicator lamp on the center console is not lit (▷ page 45)
- the air bag control unit predicts a high impact severity

#### Knee bags

 Observe the "Important safety notes" section (▷ page 40)



Driver's knee bag ① deploys underneath the steering column and front-passenger knee bag ② underneath the glove box. They deploy together with the front air bags. They are designed to operate together with the front air bags in frontal impacts if certain thresholds are exceeded. The knee bags

operate at best in conjunction with correctly positioned and fastened seat belts.

Knee bags provide increased protection for the driver and front passenger against the risk of:

- knee injuries
- thigh injuries
- lower leg injuries

#### Side impact air bags

## 

Using unsuitable seat covers could restrict or even prevent deployment of the air bags integrated into the seats. Consequently, the air bags cannot protect vehicle occupants as they are designed to do. In addition, the function of the air bag deactivation system could be restricted. This poses an increased risk of injury or even fatal injury.


You should only use seat covers that have been approved for the respective seat by Mercedes-Benz.

#### MARNING

Sensors to control the air bags are located in the doors. Modifications or work not performed correctly to the doors or door paneling, as well as damaged doors, can lead to the function of the sensors being impaired. The air bags might therefore not function properly any more. Consequently, the air bags cannot protect vehicle occupants as they are designed to do. There is an increased risk of injury.

Never modify the doors or parts of the doors. Always have work on the doors or door paneling carried out at a qualified specialist workshop.

You should only use seat covers that have been approved for your vehicle by Mercedes-Benz. The seat covers must have a special tear seam for side impact air bags. Otherwise, the side impact air bags cannot deploy correctly and therefore cannot provide the intended protection in the event of an accident.



Example: side impact air bag on the driver's side

Side impact air bags ① deploy next to the outer side bolsters of the seat backrest.

When deployed, the side impact air bags offer additional protection for the thorax of the vehicle occupants on the side of the vehicle on which the impact occurs. However, they do not protect the:

- head
- neck
- arms

The side impact air bags are deployed:

- on the side on which an impact occurs
- at the start of an accident with a high rate of lateral vehicle deceleration or acceleration, e.g. in a side impact
- independently of the use of the seat belt
- · independently of the front air bags
- independently of the ETDs


If the vehicle rolls over, the side impact air bags are generally not deployed. Side impact air bags are deployed if the system detects high vehicle deceleration or acceleration in a lateral direction and determines that side impact air bag deployment can offer additional protection to that provided by the seat belt.

Side impact air bags will not deploy in side impacts which do not exceed the system's preset deployment thresholds for lateral acceleration/deceleration. You will then be protected by the fastened seat belt. The side impact air bag on the frontpassenger side does not deploy under the following conditions:

- the OCS system detects that the frontpassenger seat is not occupied, and
- the front-passenger seat belt is not fastened.

The side impact air bag on the frontpassenger side will deploy if the frontpassenger seat belt is fastened, regardless of whether the front-passenger seat is occupied or not.

#### Head bags



Example: head bag on the front-passenger side

Head bags (1) deploy in the area of the side windows at the front. Head bags enhance the level of protection for the head, but not chest or arms, of the vehicle occupants on the side of the vehicle on which the impact occurs.

The head bags are deployed:

- at the start of an accident with a high rate of lateral vehicle deceleration or acceleration, e.g. in a side impact
- on the side on which an impact occurs
- on the driver's side and passenger side, in the event of a vehicle rollover and if the system determines that air bag deployment can offer the vehicle occupants additional protection to that provided by the seat belt
- independently of the use of the seat belt
- independently of the front air bags Head bags will not deploy in side impacts which do not exceed the system's preset

deployment thresholds for lateral acceleration/deceleration. You will then be protected by the fastened seat belt. The head bag on the front-passenger side is not deployed in the following situations:

- the OCS system detects that the frontpassenger seat is not occupied, and
- the front-passenger seat belt is not fastened.

The head bag on the front-passenger side will deploy if the front-passenger seat belt is fastened, regardless of whether the frontpassenger seat is occupied or not.

# Occupant Classification System (OCS)

#### Method of operation

#### MARNING

If the *PASSENGER AIR BAG OFF* indicator lamp illuminates when an adult or someone larger than a small individual is in the front-passenger seat, have the front passenger reposition himself or herself in the seat until the *PASSENGER AIR BAG OFF* indicator lamp goes out.

In the event of a collision, the air bag control unit will not allow front-passenger front air bag and front-passenger knee bag deployment when the OCS has classified the front-passenger occupant as weighing as much as or less than a typical 12 month old child in a standard child restraint or if the front-passenger seat is classified as being unoccupied.

When the OCS senses that the frontpassenger seat occupant is classified as being up to or less than the weight of a typical 12-month-old child in a standard child restraint, the 2 PASSENGER AIR BAG OFF indicator lamp will illuminate when the engine is started and remain illuminated. This indicates that the front-passenger front air bag and the front-passenger knee bag are deactivated.

When the OCS senses that the frontpassenger seat is classified as being empty, the <u>PASSENGER AIR BAG OFF</u> indicator lamp will illuminate when the engine is started and remain illuminated. This indicates that the front-passenger front air bag and the front-passenger knee bag are deactivated.

When the OCS senses that the frontpassenger seat occupant is classified as being heavier than the weight of a typical 12month-old child seated in a standard child restraint or as being a small individual (such as a young teenager or a small adult), the PASSENGER AIR BAG OFF indicator lamp will illuminate for approximately 6 seconds when the engine is started. Depending on occupant weight sensor readings from the seat, it will then remain illuminated or go out. If the Sk PASSENGER AIR BAG OFF indicator lamp is illuminated, the front-passenger front air bag and the frontpassenger knee bag are deactivated. If the PASSENGER AIR BAG OFF indicator lamp is not illuminated, the front-passenger front air bag and the front-passenger knee bag are activated.

When the OCS senses that the frontpassenger seat occupant is classified as an adult or someone larger than a small individual, the <u>PASSENGER AIR BAG</u> OFF indicator lamp will illuminate for approximately six seconds when the engine is started and then go out. This indicates that the front-passenger front air bag and the front-passenger knee bag are activated. If the <u>PASENGER AIR BAG OFF</u> indicator lamp is illuminated, the front-

passenger front air bag and the frontpassenger knee bag are deactivated and are not deployed. If the 22 PASSENGER AIR BAG OFF indicator lamp is not illuminated, the frontpassenger front air bag and the frontpassenger knee bag are activated and are deployed:

- in certain front impacts
- independently of the side impact air bag and head bag
- if the impact has exceeded a predetermined threshold value for deployment

If the front-passenger front air bag is deployed, the rate of inflation will be influenced by:

- the rate of vehicle deceleration as assessed by the air bag control unit
- the front passenger's weight category as determined by the OCS

# 

Children under 12 years must be secured correctly in a suitable infant or child restraint system or booster seat suitable for the size and weight of the child.

The infant or child restraint must be properly secured with the vehicle's seat belt fully in accordance with the child seat manufacturer's instructions.

Occupants, in particular children, must sit as upright as possible, fasten the seat belt correctly and use a suitable infant restraint system, child restraint system or booster seat suitable for the size and weight of the child.

Children can be seriously or even fatally injured by an air bag deploying.

Observe the following information:

 Your vehicle is equipped with air bag technology designed to deactivate the front-passenger front air bag and the frontpassenger knee bag in your vehicle when the system senses the weight of a typical 12-month-old child or less along with the weight of a standard appropriate child restraint on the front-passenger seat.

- A child in a rear-facing child restraint system on the front-passenger seat will be seriously injured or even killed if the frontpassenger front air bag inflates in a collision despite the air bag technology installed in your vehicle, which could occur under some circumstances.
- If you must install a rearward-facing child restraint on the front-passenger seat, make sure the Sk PASSENGER AIR BAG OFF indicator lamp is illuminated, indicating that the front-passenger front air bag and front-passenger knee bag are deactivated. If the 🐹 PASSENGER AIR BAG OFF indicator lamp does not light up or goes out when a rearward-facing child restraint system is installed, please check installation. Periodically check the PASSENGER AIR BAG OFF indicator lamp while driving to make sure the PASSENGER AIR BAG OFF indicator lamp is illuminated. If the 🔀 PASSENGER AIR BAG OFF indicator lamp goes out or remains out do not carry a child on the front-passenger seat.
- A child in a rearward-facing child restraint system on the front-passenger seat will be seriously injured or even killed if the frontpassenger air bag is deployed.
- When securing a child in a child restraint system on the front-passenger seat, you must:
  - move the front-passenger seat as far back as possible
  - use a child restraint system that is suitable for the age, size and weight of the child
  - observe the manufacturer's installation instructions in order to install and secure the child restraint system correctly.
- For children larger than the typical 12month-old child, the front-passenger front air bag may or may not be activated.

# 

If the red 💽 SRS warning lamp in the instrument cluster and the 🔀 PASSENGER AIR BAG OFF indicator lamp light up simultaneously, the OCS is malfunctioning. The front-passenger front air bag and the front-passenger knee bag will be deactivated in this case. Have the system checked as soon as possible by qualified technicians. Consult an authorized Mercedes-Benz Center.

Only have the seat repaired at an authorized Mercedes-Benz Center.

In order to ensure correct operation of the air bag system and OCS:

- sit with the seat belt fastened correctly and in a position that is as upright as possible with your back against the backrest.
- while seated, an occupant should not position themselves in such a way as to cause their weight to be lifted from the seat cushion as this may result in OCS being unable to correctly assess the occupant's weight category.
- read and observe all warnings in this section.



① PASSENGER AIR BAG OFF indicator lamp

② PASSENGER AIR BAG ON indicator lamp

If the SmartKey is removed from the ignition lock or is in position **0**, PASSENGER AIR BAG OFF indicator lamp ① does not light up.

PASSENGER AIR BAG ON indicator lamp (2) has no function. It lights up briefly when the ignition is switched on and then goes out again.

Occupant Classification System (OCS) categories the occupant on the frontpassenger seat using a weight sensor. The front-passenger front air bag and the frontpassenger knee bag are deactivated automatically for certain weight categories. PASSENGER AIR BAG OFF indicator lamp (1) shows you the current status. If PASSENGER AIR BAG OFF indicator lamp (1) lights up, the front-passenger front air bag and the frontpassenger knee bag are deactivated. The system does not deactivate:

- the side impact air bag
- the front-passenger head bag
- the Emergency Tensioning Devices

To be classified correctly, the front passenger must sit:

- with the seat belt fastened correctly
- in a position that is as upright as possible with their back against the seat backrest
- with their feet on the floor

The OCS weight sensor reading is affected if the occupant's weight is transferred, e.g. by leaning on the armrest.

If the front-passenger seat, the seat cover or the seat cushion are damaged, have the necessary repair work carried out at a qualified specialist workshop.

Mercedes-Benz recommends that you only use seat accessories which have been approved by Mercedes-Benz.

Both the driver and the front passenger should always observe PASSENGER AIR BAG OFF indicator lamp ① as an indication of whether or not the front passenger is positioned correctly. Observe also the air bag display messages that can be displayed in the instrument cluster (⊳ page 220).

If the driver's air bag deploys, this does not mean that the front-passenger front air bag will also deploy. The OCS may have detected that the seat:

- is empty or occupied by the weight of a typical child up to twelve months old, seated in a child restraint system.
- is occupied by a small individual, such as a young teenager or a small adult.
- is occupied by a child in a child restraint system whose weight is greater than that of a typical twelve month old child.

These are examples of when the OCS deactivates the front-passenger front air bag and front-passenger knee bag. Deactivation takes place although the collision fulfills the criteria for deploying the driver's air bag.

For further information, see "Air bag display messages" ( $\triangleright$  page 220).

#### System self-test

#### MARNING

If the ASSENGER AIR BAG OFF indicator lamp does not illuminate, the system is not functioning. Consult an authorized Mercedes-Benz Center before seating a child on the front-passenger seat.

# MARNING

Never place anything between seat cushion and child seat (e.g. a pillow), since it reduces the effectiveness of the OCS. The underside and rear side child restraint system must be placed entirely on the seat cushion and the backrest of the front-passenger seat backrest.

If necessary, adjust the tilt of the passenger seat backrest.

An incorrectly mounted child seat could cause injuries to the child in case of an accident, instead of increasing protection for the child.

Follow the manufacturer's instructions for installation of child restraint systems.

The PASSENGER AIR BAG OFF indicator lamp lights up:

- if you turn the SmartKey in the ignition lock to position 1 or 2
- if you press the KEYLESS-GO Start/Stop button once or twice on vehicles with KEYLESS-GO
- if an adult is seated properly on the frontpassenger seat and the OCS classifies the occupant as an adult

The PASSENGER AIR BAG OFF indicator lamp goes out again after approximately 6 seconds.

If the seat is not occupied and the OCS detects that the front-passenger seat is empty, the PASSENGER AIR BAG OFF indicator lamp will continue to light up. The PASSENGER AIR BAG OFF indicator lamp will not go out.

For more information about the OCS, see "Problems with the Occupant Classification System" (> page 49).

#### Problems with the occupant classification system

# 

If the *PASSENGER AIR BAG OFF* indicator lamp illuminates and remains illuminated when the weight of a typical adult or an individual that is the size of a typical adult has been detected on the front-passenger seat, do not allow any occupant to use the front-passenger seat until the system has been repaired.

# **▲ WARNING**

If the <u>Sec</u> PASSENGER AIR BAG OFF indicator lamp does not illuminate or remains out with the weight of a typical 12-month-old child in a standard child restraint or less, or is unoccupied, on the front-passenger seat, do not transport a child on the front-passenger seat until the system has been repaired.

Problem	Possible causes/consequences and Solutions
The PASSENGER AIR BAG OFF indicator lights up and remains on. The person on the front-passenger seat:	<ul> <li>The OCS is malfunctioning.</li> <li>Have the OCS checked as soon as possible at a qualified specialist workshop.</li> <li>Observe the additional display messages in the multifunction display (▷ page 220).</li> </ul>
<ul> <li>has the weight of a typical adult</li> <li>has been determined by the system not to be a child</li> </ul>	

Problem	Possible causes/consequences and ► Solutions
The PASSENGER AIR BAG OFF indicator lamp does not light up and/or stays on. The front-passenger seat is: • unoccupied • occupied with the weight of a child up to twelve months old in a child restraint system	<ul> <li>The OCS is malfunctioning.</li> <li>Make sure there is nothing between the seat cushion and the child seat.</li> <li>Check the installation of the child restraint system.</li> <li>Make sure that no objects are applying additional weight onto the seat.</li> <li>If the PASSENGER AIR BAG OFF indicator lamp remains off, have the OCS system checked as soon as possible at a qualified specialist workshop. Do not transport a child on the front-passenger seat until the OCS has been repaired.</li> <li>Observe the additional display messages in the multifunction display (▷ page 220).</li> </ul>

# PRE-SAFE<sup>®</sup> (anticipatory occupant protection system)

## Introduction

 AMG vehicles do not include the PRE-SAFE<sup>®</sup> system.

All vehicles (except AMG vehicles): the PRE-SAFE<sup>®</sup> system is only available in vehicles with DISTRONIC PLUS.

PRE-SAFE<sup>®</sup> takes preemptive measures to protect occupants in certain hazardous situations.

#### Important safety notes

Make sure that there are no objects in the footwell or behind the seats when resetting the seats. There is a risk that the seats and/or the objects could be damaged.

Despite your vehicle being equipped with the PRE-SAFE<sup>®</sup> system, the possibility of personal injuries occurring as a result of an accident cannot be eliminated.

Always adapt your driving style to suit the prevailing road and weather conditions and maintain a safe distance from the vehicle in front. Drive carefully.

#### Function

PRE-SAFE<sup>®</sup> intervenes:

- in emergency braking situations, e.g. when BAS is activated.
- in critical driving situations, e.g. when physical limits are exceeded and the vehicle understeers or oversteers severely.
- on vehicles with DISTRONIC PLUS: if BAS PLUS brakes hard or the radar sensor system detects an imminent danger of collision in certain situations.

PRE-SAFE<sup>®</sup> takes the following measures depending on the hazardous situation detected:

- the seat belts are pre-tensioned.
- if the vehicle skids, the side windows are closed so that only a small gap remains.
- vehicles with the memory function for the front-passenger seat: the frontpassenger seat is adjusted if it is in an unfavorable position.

If the hazardous situation passes without resulting in an accident, PRE-SAFE<sup>®</sup> slackens the belt pre-tensioning. All settings made by PRE-SAFE<sup>®</sup> can then be reversed.

If the seat belts are not released:

When the vehicle is stationary, move the backrest or seat back slightly. The seat belt pre-tensioning is reduced and the locking mechanism is released.

The seat-belt adjustment is an integral part of the PRE-SAFE<sup>®</sup> convenience function. More information about seat-belt adjustment can be found under "Seat-belt adjustment" ( $\triangleright$  page 53).

#### **NECK-PRO head restraints**

#### Important safety notes

#### MARNING

Do not secure any objects (e.g. coat hangers) on the NECK-PRO head restraints. Otherwise, the NECK-PRO head restraints may not function properly, or in the event of a rear-end collision may not be able offer the level of protection they are designed to provide.

#### MARNING

Seat or head restraint covers can cause a malfunction when the NECK-PRO head restraints are activated or when the side impact air bags are deployed, or they can prevent this completely. The NECK-PRO head restraints or side impact air bags can

Safety

therefore not provide the intended protection. Do not use any seat or head restraint covers.

# MARNING

For your protection, drive only with properly positioned head restraints.

Adjust the head restraint so that it is as close to the head as possible and the center of the head restraint supports the back of the head at eye level. This will reduce the potential for injury to the head and neck in the event of an accident or similar situation.

# MARNING

For safety reasons, have the NECK-PRO head restraints checked at a qualified specialist workshop after a rear-end collision.

The NECK-PRO head restraints reduce the likelihood of head and chest injuries. The NECK-PRO head restraints on the driver's and front-passenger seats are moved forwards and upwards in the event of a rear-end collision of a certain severity. This provides better head support.

If the NECK-PRO head restraints have been triggered in an accident, reset the NECK-PRO head restraints on the driver's and front-passenger seat (▷ page 51). Otherwise, the additional protection will not be available in the event of another rear-end collision. You can recognize when NECK-PRO head restraints have been triggered by the fact that they have moved forwards and can no longer be adjusted.

# Resetting triggered NECK-PRO head restraints

# MARNING

When pushing back the NECK-PRO head restraint cushion, make sure your fingers do not become caught between the head restraint cushion and the cover. Failure to observe this could result in injuries.



- ► Tilt the top of the NECK-PRO head restraint cushion forwards in the direction of arrow ①.
- Push the NECK-PRO head restraint cushion down in the direction of arrow (2) as far as it will go.
- Firmly push the NECK-PRO head restraint cushion back in the direction of arrow (3) until the cushion engages.
- Repeat this procedure for the second NECK-PRO head restraint.
- Resetting the NECK-PRO head restraints requires a lot of strength. If you have difficulty resetting the NECK-PRO head restraints, have this work carried out at a qualified specialist workshop.

#### Seat belts

#### Important safety notes

#### 

The seat belt does not offer the intended level of protection if the backrest is not in the upright position. When braking or in the event of an accident, you could slide underneath the seat belt and sustain abdomen or neck injuries, for example. This poses an increased risk of injury or even fatal injury.

Adjust the seat properly before beginning your journey. Always make sure that the seat is in the upright position.

# MARNING

Seat belts cannot protect as intended, if:

- they are damaged, extremely dirty, bleached or dyed
- the seat belt buckle is damaged or extremely dirty
- the Emergency Tensioning Devices or the belt anchorage has been modified.

Damage caused to seat belts in an accident may not be visible, e.g. by splinters of glass. Modified or damaged seat belts can tear or fail, for example in the event of an accident. Modified Emergency Tensioning Devices may be deployed unintentionally or fail to be deployed when required. There is an increased risk of injury, possibly even fatal.

Never modify seat belts, Emergency Tensioning Devices, seat belt anchorages and inertia reels. Ensure that seat belts are not damaged or worn and are clean.

Only use seat belts that have been approved for your vehicle by Mercedes-Benz.

The use of seat belts and infant and child restraint systems is required by law in:

- all 50 states
- the U.S. territories
- the District of Columbia
- all Canadian provinces

Even where this is not required by law, all vehicle occupants should correctly fasten their seat belts before starting the journey.

See "Children in the vehicle"
 (▷ page 55) for further information on infants and children traveling in the vehicle as well as on child restraint systems.

#### Proper use of the seat belts

#### MARNING

USE SEAT BELTS PROPERLY

• Seat belts can only work when used properly. Never wear seat belts in any other way than as described in this section, as that could result in serious injuries in the event of an accident.

- Each occupant should wear their seat belt at all times, because seat belts help reduce the likelihood of and potential severity of injuries in accidents, including rollovers. The integrated restraint system includes SRS (driver front air bag, knee bags, frontpassenger front air bag, side impact air bags, head air bags), Emergency Tensioning Devices (ETDs) and seat belt force limiters. The system is designed to enhance the protection offered to properly belted occupants in certain frontal (front air bags, knee bags and ETDs) and side (side impact air bags, head air bags and ETDs) impacts which exceed preset deployment thresholds.
- Never wear the shoulder belt under your arm, across your neck or off your shoulder. In a frontal crash, your body would move too far forward. That would increase the chance of head and neck injuries. The seat belt would also apply too much force to the ribs or abdomen, which could severely injure internal organs such as your liver or spleen.


Adjust the seat belt so that the shoulder section is located as close as possible to the middle of the shoulder (it should not touch the neck).

- Position the lap belt as low as possible on your hips and not across the abdomen. If the lap belt is positioned across your abdomen, it could cause serious injuries in a crash.
- Never wear seat belts over rigid or breakable objects in or on your clothing, such as eyeglasses, pens, keys etc., as these might cause injuries.
- Make sure the seat belt is always fitted snugly. Take special care of this when wearing loose clothing.
- Never use a seat belt for more than one person at a time. Do not fasten a seat belt

around a person and another person or other objects at the same time.

- Seat belts should not be worn twisted. In a crash, you would not have the full width of the seat belt to distribute impact forces. The twisted seat belt against your body could cause injuries.
- Pregnant women should also always use a lap-shoulder belt. The lap belt portion should be positioned as low as possible on the hips to avoid any possible pressure on the abdomen.
- Place the seat backrest in a position that is as upright as possible.
- Check your seat belt during travel to make sure it is properly positioned.
- Never place your feet on the instrument panel, dashboard, or on the seat. Always keep both feet on the floor in front of the seat.
- When using a seat belt to secure infant restraints, toddler restraints, or children in booster seats, always follow the child seat manufacturer's instructions.

#### Fastening seat belts



- ► Adjust the seat and move the backrest to an almost vertical position (▷ page 96).
- Pull the seat belt smoothly through belt loop ①.
- Without twisting it, guide the shoulder section of the seat belt across the middle of your shoulder and the lap section across your pelvis.
- ► Engage belt tongue ② in buckle ③. Seat-belt adjustment: if necessary, the driver's and front-passenger seat belts automatically adjust to the upper body (▷ page 53).
- If necessary, pull upwards on the shoulder section of the seat belt to tighten the belt across your body.

The seat belt on the front-passenger side is equipped with a special seat belt retractor to secure a child restraint system properly to the front-passenger seat. Further information on the "Special seat belt retractor" (> page 58).

Information on releasing the seat belt with release button () > page 54).

#### Seat belt adjustment

() AMG vehicles do not include the seat-belt adjustment function.

The seat-belt adjustment function adjusts the driver's and front-passenger seat belt to the upper body of the occupants.

The belt strap is tightened slightly when:

- you engage the belt tongue in the belt buckle and you then turn the SmartKey to position **2** in the ignition lock.
- the SmartKey is in position **2** in the ignition lock and you then engage the belt tongue in the buckle.


The seat-belt adjustment will apply a retraction force if any slack is detected between the occupant and the seat belt. Do not hold on to the seat belt tightly while it is adjusting. You can switch the seat-belt

adjustment on and off in the on-board computer ( $\triangleright$  page 206).

The seat belt adjustment is a convenience function integrated in PRE-SAFE<sup>®</sup> (preventative occupant protection). More information on PRE-SAFE<sup>®</sup> (▷ page 50).

# **Releasing seat belts**

Make sure that the seat belt is fully rolled up. Otherwise, the seat belt or belt tongue will be trapped in the door or in the seat mechanism. This could damage the door, the door trim panel and the seat belt. Damaged seat belts can no longer fulfill their protective function and must be replaced. Visit a qualified specialist workshop.



- ▶ Press release button ④ on belt buckle ③.
- ► Guide belt tongue ② back to seat belt loop ①.

# Belt warning for the driver and front passenger

Regardless of whether the driver's and frontpassenger seat belts have already been fastened, the A seat belt warning lamp lights up for six seconds each time the engine is started. It then goes out if the driver and the front passenger have already fastened their seat belts.

If the driver's seat belt is not fastened when the engine is started, an additional warning tone will sound. This warning tone stops after a maximum of six seconds or once the driver's seat belt is fastened.

If after six seconds, the driver or front passenger have not fastened their seat belts and the doors are closed:

• the 4 seat belt warning lamp remains lit as long as the driver's or front-passenger's seat belt is not fastened and

 if a vehicle speed of 15 mph (25 km/h) is exceeded, the seat belt warning lamp begins to flash. A warning tone also sounds with increasing intensity for a maximum of 60 seconds or until the driver or front passenger have fastened their seat belts.

If the driver/front passenger unfasten their seat belt while the vehicle is in motion, the

A seat belt warning lamp lights up and a warning tone sounds again.

The warning tone ceases even if the driver or front-passenger seat belt has still not been fastened after 60 seconds. The <u></u> seat belt warning lamp stops flashing but remains illuminated.

After the vehicle comes to a standstill, the warning tone is reactivated and the \_\_\_\_\_\_ seat belt warning lamp flashes again if the vehicle speed again exceeds 15 mph (25 km/h).

The [ and the seat belt warning lamp only goes out if:

- both the driver and the front passenger have fastened their seat belts.
   or
- the vehicle is stationary and a door is open.
- For more information on the ▲ seat belt warning lamp, see "Warning and indicator lamps in the instrument cluster, seat belts" (▷ page 240).

Safety

# Emergency Tensioning Devices, seat belt force limiters

## MARNING

Pyrotechnic Emergency Tensioning Devices that have been deployed are no longer operational and are unable to perform their intended protective function. This poses an increased risk of injury or even fatal injury. Therefore, have pyrotechnic Emergency

Tensioning Devices which have been triggered immediately replaced at a qualified specialist workshop.

If the co-driver's seat is unoccupied, do not insert the belt tongue into the buckle of the co-driver's seat. This may otherwise lead to the triggering of the Emergency Tensioning Device in the event of an accident, which will then need to be replaced.

• Vehicles with PRE-SAFE<sup>®</sup>: Emergency Tensioning Devices that are triggered by an electric motor can be deployed as often as desired and do not need to be replaced.

The seat belts are equipped with Emergency Tensioning Devices and seat belt force limiters.

The ETDs tighten the seat belts in an accident, pulling them close against the body.

The ETDs do not correct incorrect seat positions or incorrectly fastened seat belts.

The ETDs do not pull vehicle occupants back towards the backrest.

The ETDs can only be activated when:

- the ignition is switched on
- the restraint systems are operational; see "SRS warning lamp "(▷ page 39)
- the belt tongue is engaged in the buckle on each of the three-point seat belts.

The ETDs are triggered depending on the type and severity of an accident:

• in the event of a head-on or rear-end collision if the vehicle decelerates or accelerates rapidly in a longitudinal

direction during the initial stages of the impact.

- in the event of a side impact if the vehicle decelerates or accelerates rapidly in a lateral direction on the side opposite to the impact..
- in certain situations where the vehicle rolls over if the system determines that it can provide additional protection.

If the ETDs are deployed, you will hear a bang, and a small amount of powder may also be released. Only in rare cases will the bang affect your hearing. The powder that is released generally does not constitute a health hazard and does not indicate that there is a fire in the vehicle. The dust might cause some temporary breathing difficulty for people with asthma or other breathing trouble. To avoid this, you may wish to get out of the vehicle as soon as it is safe to do so. You can also open the window to allow fresh air to enter the vehicle interior. The SRS warning lamp lights up.

When triggered, seat belt force limiters help to reduce the force exerted by the seat belt on the vehicle occupant.

The seat belt force limiters are synchronized with the front air bags, which take on a part of the deceleration force. Thus, the force exerted on the occupant is distributed over a greater area.

# **Child restraint systems**

#### Important safety notes

#### **MARNING** ▲

Children 12 years old and under must be seated and properly secured in an appropriate infant restraint, toddler restraint, or booster seat recommended for the size and weight of the child.

The infant or child restraint system must be correctly secured using the vehicle's seat belt in complete accordance with the child seat manufacturer's instructions. Occupants, in particular children, must sit as upright as possible, fasten the seat belt correctly and use a suitable infant restraint system, child restraint system or booster seat suitable for the size and weight of the child.

Children can be seriously or even fatally injured by an air bag deploying. Observe the following information:

- Your vehicle is equipped with air bag technology designed to deactivate the front-passenger front air bag in your vehicle when the system senses the weight of a typical 12-month-old child or less along with the weight of a standard appropriate child restraint on the passenger seat.
- A child in a rearward-facing child restraint system on the front-passenger seat could be seriously injured or even killed if the front-passenger air bag inflates in a collision despite the air bag technology installed in your vehicle, which could occur under some circumstances.
- · If you install a rearward-facing child restraint on the front-passenger seat, make sure that the Sk PASSENGER AIR BAG OFF indicator lamp is illuminated, indicating that the front-passenger front air bag is deactivated. Should the 🔀 PASSENGER AIR BAG OFF indicator lamp not illuminate or go out while a rearwardfacing child restraint system is installed, please check installation. Periodically check the S PASSENGER AIR BAG OFF indicator lamp while driving to make sure it is illuminated. If the Sk PASSENGER AIR BAG OFF indicator lamp goes out or remains out, do not transport a child on the front-passenger seat.
- A child in a rearward-facing child restraint system on the front-passenger seat can be seriously injured or even killed if the frontpassenger air bag is deployed.

- When securing a child in a child restraint system on the front-passenger seat, you must:
  - move the front-passenger seat as far back as possible
  - use a child restraint system that is suitable for the age, size and weight of the child
  - observe the manufacturer's installation instructions in order to install and secure the child restraint system correctly.
- For children larger than the typical 12month-old child, the front-passenger front air bag may or may not be activated.

#### **MARNING** ★

If the child restraint system is installed incorrectly on a suitable seat, it cannot protect as intended. The child cannot then be restrained in the event of an accident, heavy braking or sudden changes of direction. There is an increased risk of injury, possibly even fatal.

Make sure that you observe the child restraint system manufacturer's installation instructions and the notes on use. Please ensure, that the base of the child restraint system is always resting completely on the seat cushion. Never place objects, e.g. cushions, under or behind the child restraint system. Only use child restraint systems with the original cover designed for them. Only replace damaged covers with genuine covers.

## 

If the child restraint system is installed incorrectly or is not secured, it can come loose in the event of an accident, heavy braking or a sudden change in direction. The child restraint system could be thrown about, striking vehicle occupants. There is an increased risk of injury, possibly even fatal.

Always install child restraint systems properly, even if they are not being used. Make sure that you observe the child restraint system manufacturer's installation instructions.

## MARNING

Child restraint systems or their securing systems which have been damaged or subjected to a load in an accident can no longer protect as intended. The child cannot then be restrained in the event of an accident, heavy braking or sudden changes of direction. There is an increased risk of injury, possibly even fatal.

Replace child restraint systems which have been damaged or subjected to a load in an accident as soon as possible. Have the securing systems on the child restraint system checked at a qualified specialist workshop, before you install a child restraint system again.

#### MARNING

Infants and small children should never share a seat belt with another occupant. In the event of an accident, they could be crushed between the occupant and seat belt.

A child's risk of serious or fatal injuries is significantly increased if the child restraints are not properly secured in the vehicle and/ or the child is not properly secured in the child restraint.

Children that are too large for a child restraint must travel in seats using normal seat belts. Position the shoulder belt across the chest and shoulder, not the face or neck. A booster seat may be necessary to achieve proper seat belt positioning for children over 41 lbs (18 kg) until they reach a height where a lap/ shoulder belt fits properly without a booster seat.

When the child restraint is not in use, remove it from the vehicle or secure it with the seat belt to prevent the child restraint from becoming a projectile in the event of an accident.

# MARNING

If children are left unsupervised in the vehicle, they could:

- open the doors, thus endangering other people or road users.
- get out and disrupt traffic.
- operate the vehicle's equipment.

Additionally, children could set the vehicle in motion if, for example, they:

- release the parking brake.
- shift the automatic transmission out of parking position P.
- shift the manual transmission into neutral.
- starting the engine.

There is a risk of an accident and injury. When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children or animals unattended in the vehicle. Always keep the SmartKey out of reach of children.

#### 

If persons, particularly children are subjected to prolonged exposure to extreme heat or cold, there is a risk of injury, possibly even fatal. Never leave children unattended in the vehicle.

# 

If the child restraint system is subjected to direct sunlight, parts may get very hot. Children may burn themselves on these parts, particularly on the metal parts of the child restraint system. There is a risk of injury.

If you leave the vehicle, taking the child with you, always ensure that the child restraint system is not exposed to direct sunlight. Protect it with a blanket, for example. If the child restraint system has been exposed to direct sunlight, let it cool down before securing the child in it. Never leave children unattended in the vehicle. If an infant or child is traveling in the vehicle:

- Secure the child with a child or infant seat restraint system appropriate to the age and weight of the child.
- Make sure that the infant or child is properly secured at all times while the vehicle is in motion.

Mercedes-Benz recommends that you always properly secure all infants and children with a child or infant seat restraint system for the trip.

The use of seat belts and infant and child restraint systems is required by law in:

- all 50 states
- the U.S. territories
- the District of Columbia
- all Canadian provinces

Infants and children must always be seated in an appropriate infant or child restraint system recommended for the size and weight of the child. The infant or child restraint system must be properly secured with a three-point seat belt in accordance with the manufacturer's instructions.

All infant or child restraint systems must meet the following standards:

- U.S. Federal Motor Vehicle Safety Standards 213 and 225
- Canadian Motor Vehicle Safety Standards 213 and 210.2

Confirmation that the child restraint system corresponds to the standards can be found on an instruction label on the child restraint system. This confirmation can also be found in the installation instructions that are included with the child restraint system. Always read and follow the manufacturer's instructions when using an infant or child restraint system or booster seat.

Observe the warning labels in the vehicle interior or on the infant or child restraint.

#### Special seat belt retractor

# 

If the seat belt is released while driving, the child restraint system will no longer be secured properly. The special seat belt retractor is disabled and the inertia real draws in a portion of the seat belt. The seat belt cannot be immediately refastened. There is an increased risk of injury, possibly even fatal. Stop the vehicle immediately, paying attention to road and traffic conditions. Reactivate the special seat belt retractor and secure the child restraint system properly.

The seat belt on the front-passenger side is equipped with a special seat belt retractor. When activated, the special seat belt retractor ensures that the seat belt will not slacken once the child restraint system has been secured.

Installing a child restraint system:

- Always comply with the manufacturer's installation instructions.
- Pull the seat belt smoothly from the seat belt retractor.
- Engage the seat belt tongue in the belt buckle.

Activating the special seat belt retractor:

- Pull the seat belt out fully and let the seat belt retractor retract it again.
   While the seat belt is retracting, you should hear a ratcheting sound. The special seat belt retractor is activated.
- Push down on the child restraint system to take up any slack.

Removing a child restraint system/ deactivating the special seat belt retractor:

- Always comply with the manufacturer's installation instructions.
- Press the seat belt release button and guide the belt tongue to the belt outlet. The special seat belt retractor is deactivated.

If necessary:

- Additionally move the seat backwards. The special seat belt retractor is deactivated.
- If necessary:
- Additionally, remove the seat belt from the seat belt guide on the seat backrest and guide the seat belt back to the belt outlet. The special seat belt retractor is deactivated.

#### **Driving safety systems**

#### Overview of driving safety systems

In this section, you will find information about the following driving safety systems:

- ABS (Anti-lock Braking System)
   (▷ page 59)
- BAS (Brake Assist System) (▷ page 60)
- BAS PLUS (Brake Assist System PLUS) (▷ page 60)
- ESP<sup>®</sup> (Electronic Stability Program) (▷ page 61)
- EBD (electronic brake force distribution) (▷ page 65)
- ADAPTIVE BRAKE(▷ page 65)
- PRE-SAFE<sup>®</sup> Brake (▷ page 65)

#### Important safety notes

If you fail to adapt your driving style or become distracted, the driving safety systems can neither reduce the risk of accident nor override the laws of physics. Driving safety systems are merely aids designed to assist driving. You are responsible for the distance to the vehicle in front, for vehicle speed and for braking in good time. Always adapt your driving style to suit the prevailing road and weather conditions and maintain a safe distance from the vehicle in front. Drive carefully.

The driving safety systems described only work as effectively as possible when there is adequate contact between the tires and the road surface. Please pay special attention to the notes on tires, recommended minimum tire tread depths, etc. (> page 306).

In wintry driving conditions, always use winter tires (M+S tires) and if necessary, snow chains. Only in this way will the driving safety systems described in this section work as effectively as possible.

#### **ABS (Anti-lock Braking System)**

#### General information

ABS regulates brake pressure in such a way that the wheels do not lock when you brake. This allows you to continue steering the vehicle when braking.

The yellow () ABS warning lamp in the instrument cluster lights up when the ignition is switched on. It goes out when the engine is running.

#### Important safety notes

Observe the "Important safety notes" section (▷ page 59).

#### 

If ABS is faulty, the wheels could lock when braking. The steerability and braking characteristics may be severely impaired. Additionally, further driving safety systems are deactivated. There is an increased danger of skidding and accidents.

Drive on carefully. Have ABS checked immediately at a qualified specialist workshop.

When ABS is malfunctioning, other systems, including driving safety systems, will also become inoperative. Observe the information on the ABS warning lamp ( $\triangleright$  page 242) and display messages which may be shown in the instrument cluster ( $\triangleright$  page 211).

ABS works from a speed of about 5 mph (8 km/h), regardless of road-surface

conditions. ABS works on slippery surfaces, even if you only brake gently.

## Braking

If ABS intervenes: continue to depress the brake pedal vigorously until the braking situation is over.

To make a full brake application: depress the brake pedal with full force.

If ABS intervenes when braking, you will feel a pulsing in the brake pedal.

The pulsating brake pedal can be an indication of hazardous road conditions, and functions as a reminder to take extra care while driving.

## **BAS (Brake Assist System)**

#### **General information**

BAS operates in emergency braking situations. If you depress the brake pedal quickly, BAS automatically boosts the braking force, thus shortening the stopping distance.

#### Important safety notes

 Observe the "Important safety notes" section (▷ page 59).

## MARNING

If BAS is malfunctioning, the braking distance in an emergency braking situation is increased. There is a risk of an accident.

In an emergency braking situation, depress the brake pedal with full force. ABS prevents the wheels from locking.

#### Braking

 Keep the brake pedal firmly depressed until the emergency braking situation is over.
 ABS prevents the wheels from locking.

The brakes will function as usual once you release the brake pedal. BAS is deactivated.

# BAS PLUS (Brake Assist System PLUS)

#### **General information**

Observe the "Important safety notes" section (▷ page 59).

BAS PLUS is only available in vehicles equipped with DISTRONIC PLUS.

For BAS PLUS to assist you, the radar sensor system must be operational.

With the help of the radar sensor system, BAS PLUS can detect obstacles that are in the path of your vehicle for an extended period of time.

If the radar sensor system is malfunctioning, BAS PLUS will not be available. The brake system is still available with complete brake boosting effect and BAS.

BAS PLUS can help you to minimize the risk of a collision with a vehicle or reduce the effects of such a collision. If BAS PLUS detects a danger of collision, you are assisted when braking.

#### Important safety notes

# MARNING

BAS PLUS cannot always clearly identify objects and complex traffic situations. In such cases, BAS PLUS may:

- intervene unnecessarily
- not intervene

There is a risk of an accident.

Always pay careful attention to the traffic situation and be ready to brake. Terminate the intervention in a non-critical driving situation.

# 

BAS PLUS does not react:

- to people or animals
- to oncoming vehicles
- to crossing traffic
- when cornering

As a result, BAS PLUS may not intervene in all critical situations. There is a risk of an accident.

Always pay careful attention to the traffic situation and be ready to brake.

In the event of snowfall or heavy rain, the recognition can be impaired.

Recognition by the radar sensor system is also impaired in the event of:

- dirt on the sensors or anything else covering the sensors
- interference by other radar sources
- there are strong radar reflections, for example in parking garages
- a narrow vehicle traveling in front, e.g. a motorbike
- a vehicle traveling in front on a different line relative to the center of your vehicle

Following damage to the front end of the vehicle, have the configuration and operation of the radar sensors checked at a qualified specialist workshop. This also applies to collisions at low speeds where there is no visible damage to the front of the vehicle.

#### Function

To avoid a collision, BAS PLUS calculates the brake force necessary if:

- you approach an obstacle, and
- BAS PLUS has detected a risk of collision

When driving at a speed under 20 mph (30 km/h): if you depress the brake pedal, BAS PLUS is activated. The increase in brake pressure will be carried out at the last possible moment.

When driving at a speed above 20 mph (30 km/h): if you depress the brake pedal sharply, BAS PLUS automatically raises the brake pressure to a value adapted to the traffic situation.

BAS PLUS provides braking assistance in hazardous situations with vehicles in front

within a speed range between 4 mph (7 km/h) and 155 mph (250 km/h).

At speeds of up to approximately 40 mph (70 km/h), BAS PLUS can also react to stationary objects. Examples of stationary objects are stopped or parked vehicles.

- If BAS PLUS demands particularly high braking force, preventative passenger protection measures (PRE-SAFE<sup>®</sup>) are activated simultaneously.
- Keep the brake pedal depressed until the emergency braking situation is over. ABS prevents the wheels from locking.

BAS PLUS is deactivated and the brakes function as usual again, if:

- you release the brake pedal.
- there is no longer a risk of collision.
- no obstacle is detected in front of your vehicle.
- you depress the accelerator pedal.
- you activate kickdown.

#### ESP<sup>®</sup> (Electronic Stability Program)

#### General notes

Observe the "Important safety notes" section (▷ page 59).

ESP<sup>®</sup> monitors driving stability and traction, i.e. power transmission between the tires and the road surface.

If ESP<sup>®</sup> detects that the vehicle is deviating from the direction desired by the driver, one or more wheels are braked to stabilize the vehicle. The engine output is also modified to keep the vehicle on the desired course within physical limits. ESP<sup>®</sup> assists the driver when pulling away on wet or slippery roads. ESP<sup>®</sup> can also stabilize the vehicle during braking.

# ETS (Electronic Traction System)

Observe the "Important safety notes" section (▷ page 59). ETS traction control is part of ESP®.

ETS brakes the drive wheels individually if they spin. This enables you to pull away and accelerate on slippery surfaces, for example if the road surface is slippery on one side. In addition, more drive torque is transferred to the wheel or wheels with traction.

ETS remains active when you deactivate  $\ensuremath{\mathsf{ESP}}^{\ensuremath{\texttt{\$}}}.$ 

AMG vehicles: your vehicle may be equipped with 20-inch tires on the rear axle. If replaced with a 19-inch tire, ETS may intervene noticeably sooner for the first few kilometers. After approximately 10 km ETS will function as usual again. Information on the dimensions and types of wheels and tires for your vehicle can be found in the "Wheel/tire combinations" section (▷ page 333).

#### Important safety notes

#### **▲** WARNING

If ESP<sup>®</sup> is malfunctioning, ESP<sup>®</sup> is unable to stabilize the vehicle. Additionally, further driving safety systems are deactivated. This increases the risk of skidding and an accident.

Drive on carefully. Have ESP<sup>®</sup> checked at a qualified specialist workshop.

When testing the electric parking brake on a braking dynamometer, switch off the ignition. Application of the brakes by ESP<sup>®</sup> may otherwise destroy the brake system.

When towing the vehicle with the rear axle raised, observe the notes on  $ESP^{\textcircled{R}}(\rhd page 302)$ .

ESP<sup>®</sup> is deactivated if the series warning lamp in the instrument cluster lights up continuously when the engine is running.

If the 📑 warning lamp and the 📑 warning lamp are lit continuously, ESP<sup>®</sup> is not available due to a malfunction.

Observe the information on warning lamps (> page 244) and display messages which may be shown in the instrument cluster (> page 211).

Only use wheels with the recommended tire sizes. Only then will ESP<sup>®</sup> function properly.

#### Characteristics of ESP®

#### General information

If the 📻 ESP warning lamp goes out before beginning the journey, ESP<sup>®</sup> is automatically active.

If ESP<sup>®</sup> intervenes, the ESP<sup>®</sup> warning lamp flashes in the instrument cluster.

If ESP<sup>®</sup> intervenes:

- Do not deactivate ESP<sup>®</sup> under any circumstances.
- Only depress the accelerator pedal as far as necessary when pulling away.
- Adapt your driving style to suit the prevailing road and weather conditions.

#### ECO start/stop function

The ECO start/stop function switches the engine off automatically when the vehicle stops moving. The engine starts automatically when the driver wants to pull away again. ESP<sup>®</sup> remains in its previously selected status. **Example:** if ESP<sup>®</sup> was deactivated before the engine was switched off, ESP<sup>®</sup> remains deactivated when the engine is switched on again.

# Deactivating/activating ESP<sup>®</sup> (except AMG vehicles)

#### Important safety notes

Observe the "Important safety notes" section (▷ page 59). You can select between the following states of  $\mathsf{ESP}^{\texttt{B}}$ :

- ESP<sup>®</sup> is activated.
- ESP<sup>®</sup> is deactivated.

#### MARNING

If you deactivate ESP<sup>®</sup>, ESP<sup>®</sup> no longer stabilizes the vehicle. There is an increased risk of skidding and an accident.

Only deactivate ESP<sup>®</sup> in the situations described in the following.

It may be best to deactivate  $\mathsf{ESP}^{\texttt{®}}$  in the following situations:

- when using snow chains
- in deep snow
- on sand or gravel
- Activate ESP<sup>®</sup> as soon as the situations described above no longer apply. ESP<sup>®</sup> will otherwise not be able to stabilize the vehicle if the vehicle starts to skid or a wheel starts to spin.

Avoid spinning the driven wheels for an extended period with ESP<sup>®</sup> deactivated. You could otherwise damage the drivetrain.

#### Deactivating/activating ESP<sup>®</sup>



- ► To switch off: press button ①. The SFE ESP<sup>®</sup> OFF warning lamp in the instrument cluster lights up.
- ► To switch on: press button ①. The SFP® OFF warning lamp in the instrument cluster goes out.

#### Characteristics when ESP<sup>®</sup> is deactivated

If ESP<sup>®</sup> is deactivated and one or more wheels start to spin, the ESP<sup>®</sup> warning lamp in the instrument cluster flashes. In such situations, ESP<sup>®</sup> will not stabilize the vehicle. If you deactivate ESP<sup>®</sup>:

- ESP<sup>®</sup> no longer improves driving stability.
- engine torque is no longer limited and the drive wheels are able to spin.

The spinning of the wheels results in a cutting action for better traction on loose surfaces.

- traction control is still activated.
- $\bullet$  ESP  $^{\circledast}$  still provides support when you brake.

# Deactivating/activating ESP<sup>®</sup> (AMG vehicles)

#### Important safety notes

Observe the "Important safety notes" section (▷ page 59).

You can select between the following states of ESP<sup>®</sup>:

- ESP<sup>®</sup> is activated.
- SPORT handling mode is activated.
- ESP<sup>®</sup> is deactivated.

#### 

When SPORT handling mode is activated, there is a greater risk of skidding and accidents.

Only activate SPORT handling mode in the situations described in the following.

#### MARNING

If you deactivate ESP<sup>®</sup>, ESP<sup>®</sup> no longer stabilizes the vehicle. There is an increased risk of skidding and an accident.

Only deactivate ESP<sup>®</sup> in the situations described in the following.

In the following situations, it may be better to activate SPORT handling mode or deactivate  $\text{ESP}^{\textcircled{B}}$ :

- when using snow chains
- in deep snow
- on sand or gravel
- on designated roads when the vehicle's own oversteering and understeering characteristics are desired

Driving in SPORT handling mode or without ESP<sup>®</sup> requires an extremely qualified and experienced driver.

- Activate ESP<sup>®</sup> as soon as the situations described above no longer apply. ESP<sup>®</sup> will otherwise not be able to stabilize the vehicle if the vehicle starts to skid or a wheel starts to spin.
- Avoid spinning the driven wheels for an extended period with ESP<sup>®</sup> deactivated. You could otherwise damage the drivetrain.

#### Deactivating/activating ESP®



► To activate SPORT handling mode: briefly press button ①. The SPORT SPORT handling mode warning

lamp in the instrument cluster lights up. The SPORT handling mode message appears in the multifunction display.

► To deactivate SPORT handling mode: briefly press button ①.

The **SPORT** SPORT handling mode warning lamp in the instrument cluster goes out.

- ► To deactivate ESP<sup>®</sup>: press button ① until the Section ESP<sup>®</sup> OFF warning lamp lights up in the instrument cluster. The OFF message appears in the multifunction display.
- ► To activate ESP<sup>®</sup>: briefly press button ①. The \_\_\_\_\_\_\_ ESP<sup>®</sup> OFF warning lamp in the instrument cluster goes out. The \_\_\_\_\_\_ ESP<sup>®</sup>ON message appears in the multifunction display.

#### Characteristics of activated SPORT handling mode

If SPORT handling mode is activated and one or more wheels start to spin, the ESP<sup>®</sup> warning lamp in the instrument cluster flashes. ESP<sup>®</sup> only stabilizes the vehicle to a limited degree.

When SPORT handling mode is activated:

- $\bullet$  ESP  $^{\textcircled{R}}$  only improves driving stability to a limited degree.
- the engine's torque is restricted only to a limited degree and the drive wheels can spin. The spinning of the wheels results in a cutting action, which provides better grip.
- ETS is still active.
- ESP<sup>®</sup> still provides support when you brake.

# Characteristics when ESP<sup>®</sup> is deactivated

If ESP<sup>®</sup> is deactivated and one or more wheels start to spin, the ESP<sup>®</sup> warning lamp in the instrument cluster does not flash. In such situations, ESP<sup>®</sup> will not stabilize the vehicle. If you deactivate ESP<sup>®</sup>:

- $\bullet$  ESP  $^{\ensuremath{\mathbb{R}}}$  no longer improves driving stability.
- engine torque is no longer limited and the drive wheels are able to spin.

The spinning of the wheels results in a cutting action for better traction on loose surfaces.

• traction control is still activated.

- PRE-SAFE<sup>®</sup> is no longer available, nor is it activated if you brake firmly and ESP<sup>®</sup> intervenes.
- PRE-SAFE<sup>®</sup> Brake is no longer available, it is also not activated if you brake firmly and ESP<sup>®</sup> intervenes.
- ESP<sup>®</sup> still provides support when you brake.

# EBD (electronic brake force distribution)

## General information

EBD monitors and controls the brake pressure on the rear wheels to improve driving stability while braking.

## Important safety notes

 Observe the "Important safety notes" section for driving safety systems (▷ page 59).

# 

If EBD has malfunctioned, the rear wheels can still lock, e.g. under full braking. This increases the risk of skidding and an accident. You should therefore adapt your driving style to the different handling characteristics. Have the brake system checked at a qualified specialist workshop.

Observe information regarding indicator and warning lamps ( $\triangleright$  page 242) as well as display messages ( $\triangleright$  page 213).

# ADAPTIVE BRAKE

ADAPTIVE BRAKE enhances braking safety and offers increased braking comfort. In addition to the braking function, ADAPTIVE BRAKE also has the HOLD function (▷ page 179) and hill start assist (▷ page 143).

# PRE-SAFE<sup>®</sup> Brake

## General information

Observe the "Important safety notes" section (▷ page 59).

PRE-SAFE<sup>®</sup> Brake is only available in vehicles with DISTRONIC PLUS.

For PRE-SAFE<sup>®</sup> Brake to assist you when driving, the radar sensor system must be operational.

With the help of the radar sensor system, PRE-SAFE<sup>®</sup> Brake can detect obstacles that are in front of your vehicle for an extended period of time.

PRE-SAFE<sup>®</sup> Brake can help you to minimize the risk of a collision with a vehicle ahead, and reduce the effects of such a collision. If PRE-SAFE<sup>®</sup> Brake has detected a risk of collision, you will be warned visually and acoustically as well as by automatic braking. PRE-SAFE<sup>®</sup> Brake cannot prevent a collision without your intervention.

# Important safety notes

# 

PRE-SAFE<sup>®</sup> Brake will initially brake your vehicle by a partial application of the brakes if a danger of collision is detected. There may be a collision unless you also brake. Automatic emergency braking cannot prevent a collision. There is a risk of an accident.

Always apply the brakes yourself and try to take evasive action.

# 

PRE-SAFE<sup>®</sup> Brake cannot always clearly identify objects and complex traffic conditions.

In these cases,  $\mathsf{PRE}\text{-}\mathsf{SAFE}^{\circledast}$  Brake may:

- give an unnecessary warning and then brake the vehicle
- not give a warning or intervene

There is a risk of an accident.

Always pay particular attention to the traffic situation and be ready to brake, especially if PRE-SAFE<sup>®</sup> Brake warns you. Terminate the intervention in a non-critical driving situation.

In order to maintain the appropriate distance to the vehicle in front and thus prevent a collision, you must apply the brakes yourself.

#### MARNING

PRE-SAFE<sup>®</sup> Brake does not react:

- to people or animals
- to oncoming vehicles
- to crossing traffic
- when cornering

As a result, PRE-SAFE<sup>®</sup> Brake may neither give warnings nor intervene in all critical situations. There is a risk of an accident.

Always pay careful attention to the traffic situation and be ready to brake.

In the event of snowfall or heavy rain, the recognition can be impaired.

Recognition by the radar sensor system is also impaired in the event of:

- dirt on the sensors or anything else covering the sensors
- interference by other radar sources
- there are strong radar reflections, for example in parking garages
- a narrow vehicle traveling in front, e.g. a motorbike
- a vehicle traveling in front on a different line relative to the center of your vehicle

Following damage to the front end of the vehicle, have the configuration and operation of the radar sensors checked at a qualified specialist workshop. This also applies to collisions at low speeds where there is no visible damage to the front of the vehicle.

#### Function

► To activate/deactivate: activate or deactivate PRE-SAFE<sup>®</sup> Brake in the onboard computer (▷ page 201). When PRE-SAFE<sup>®</sup> Brake is deactivated, the assistance graphic shows the prefer symbol in the multifunction display.

Starting at a speed of around 4 mph (7 km/h), this function warns you if you rapidly approach a vehicle in front. An intermittent warning tone will then sound and the A distance warning lamp will light up in the instrument cluster.

Brake immediately to defuse the situation.
 or

 Take evasive action provided it is safe to do so.

PRE-SAFE<sup>®</sup> Brake can also brake the vehicle automatically under the following conditions:

- the driver and front-passenger have their seat belts fastened and
- the vehicle speed is between approximately 4 mph (7 km/h) and 124 mph (200 km/h)

At speeds of up to approximately 40 mph (70 km/h) PRE-SAFE<sup>®</sup> Brake can also detect stationary objects. Examples of stationary objects are stopped or parked vehicles.

 If there is an increased risk of collision, preventive passenger protection measures (PRE-SAFE<sup>®</sup>) are activated.

If the risk of collision with the vehicle in front remains and you do not brake, take evasive action or accelerate significantly, the vehicle may perform automatic emergency braking, up to the point of full brake application. Automatic emergency braking is not performed until immediately prior to an imminent accident. You can prevent the intervention of the PRE-SAFE<sup>®</sup> Brake at any time by:

- depressing the accelerator pedal further.
- activating kickdown.
- releasing the brake pedal.

The braking action of PRE-SAFE<sup>®</sup> Brake is ended automatically if:

- you maneuver to avoid the obstacle.
- there is no longer any danger of a collision.
- there is no longer an obstacle detected in front of your vehicle.

#### Theft deterrent locking system

#### Immobilizer

- ► To activate with the SmartKey: remove the SmartKey from the ignition lock.
- To activate with KEYLESS-GO: switch the ignition off and open the driver's door.
- ► **To deactivate:** switch on the ignition.

The immobilizer prevents your vehicle from being started without the correct SmartKey. When leaving the vehicle, always take the SmartKey with you and lock the vehicle. The engine can be started by anyone with a valid SmartKey that is left inside the vehicle.

**1** The immobilizer is always deactivated when you start the engine.

In the event that the engine cannot be started when the starter battery is fully charged, the immobilizer may be faulty. Contact an authorized Mercedes-Benz Center or call 1-800-FOR-MERCedes (in USA) or 1-800-387-0100 (in Canada).

#### ATA (anti-theft alarm system)



Safety

- To arm: lock the vehicle with the SmartKey or KEYLESS-GO. Indicator lamp ① flashes. The alarm system is armed after approximately 15 seconds.
- ► **To disarm:** unlock the vehicle with the SmartKey or KEYLESS-GO.

A visual and audible alarm is triggered if the alarm system is armed and you open:

- a door
- the vehicle with the mechanical key
- the trunk lid
- the hood
- the glove box
- the stowage space under the armrest
- a stowage compartment in the rear
- To turn the alarm off with the SmartKey: press the or button on the SmartKey. The alarm is switched off.

or

Insert the SmartKey into the ignition lock. The alarm is switched off. ► To stop the alarm using KEYLESS-GO: grasp the outside door handle. The SmartKey must be outside the vehicle. The alarm is switched off.

or

 Press the Start/Stop button on the dashboard. The SmartKey must be inside the vehicle.
 The alarm is switched off.

The alarm is not switched off, even if you close the open door that triggered it, for

example.
If the alarm continues for more than 30 seconds, the mbrace emergency call system automatically notifies the Customer Assistance Center. This is done either by text message or data connection.

message or data provided that:you have subscribed to the mbrace service.

The emergency call system sends the

- the mbrace service has been activated properly.
- the necessary mobile phone network is available.

70
70
76
79
82
86

# **Useful information**

- This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- I Read the information on qualified specialist workshops: (▷ page 24).

#### SmartKey

#### Important safety notes

#### MARNING

If children are left unsupervised in the vehicle, they could:

- open the doors, thus endangering other people or road users.
- get out and disrupt traffic.
- operate the vehicle's equipment.

Additionally, children could set the vehicle in motion if, for example, they:

- release the parking brake.
- shift the automatic transmission out of parking position P.
- shift the manual transmission into neutral.
- starting the engine.

There is a risk of an accident and injury. When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children or animals unattended in the vehicle. Always keep the SmartKey out of reach of children.

# 

If persons, particularly children are subjected to prolonged exposure to extreme heat or cold, there is a risk of injury, possibly even fatal. Never leave children unattended in the vehicle.

#### MARNING

If you attach heavy or large objects to the SmartKey, the SmartKey could be unintentionally turned in the ignition lock. This could cause the engine to be switched off. There is a risk of an accident.

Do not attach any heavy or large objects to the SmartKey. Remove any bulky key rings before inserting the SmartKey into the ignition lock.


Keep the SmartKey away from strong magnetic fields. Otherwise, the remote control function could be affected.

Strong magnetic fields can occur in the vicinity of powerful electrical installations.

Do not keep the SmartKey:

- with electronic devices, e.g. a mobile phone or another SmartKey
- with metallic objects, e.g. coins or metal foil
- inside metallic objects, e.g. a metal case This can affect the functionality of the SmartKey.

#### **SmartKey functions**



- ① **[]** To lock the vehicle
- ② S To unlock the trunk lid
- ③ To unlock the vehicle

► To unlock centrally: press the button.

If you do not open the vehicle within approximately 40 seconds of unlocking:

- the vehicle is locked again.
- the theft deterrent locking system is armed again.
- ► To lock centrally: press the 🕞 button.

The SmartKey centrally locks/unlocks:

- the doors
- the trunk lid
- the glove box
- the stowage compartment in the center console
- the fuel filler flap

When unlocking, the turn signals flash once. When locking, they flash three times.

You can also set an audible signal to confirm that the vehicle has been locked. The audible signal can be activated and deactivated using the on-board computer ( $\triangleright$  page 205).

When it is dark, the surround lighting also comes on if it is activated in the on-board computer ( $\triangleright$  page 204).

#### **KEYLESS-GO**

#### General notes

Bear in mind that the engine can be started by any of the vehicle occupants if there is a KEYLESS-GO key in the vehicle.

#### Locking/unlocking centrally

You can start, lock or unlock the vehicle using KEYLESS-GO. To do this, you only need carry the SmartKey with you. You can combine the functions of KEYLESS-GO with those of a conventional SmartKey. Unlock the vehicle by using KEYLESS-GO, for instance, and lock it using the **•** button on the SmartKey. When locking or unlocking with KEYLESS-GO, the distance between the SmartKey and the

corresponding door handle must not be greater than 3 ft (1 m).

A check which periodically establishes a radio connection between the vehicle and the SmartKey determines whether a valid SmartKey is in the vehicle. This occurs, for example:

- when the external door handles are touched
- when starting the engine
- while the vehicle is in motion



- To unlock the vehicle: touch the inner surface of the door handle.
- To lock the vehicle: touch sensor surface ①.
- Convenience closing feature: touch recessed sensor surface (2) for an extended period.

Further information on the convenience closing feature ( $\triangleright$  page 84).

To unlock the trunk lid: pull the handle on the trunk lid.

The vehicle only unlocks the trunk lid.

# Changing the settings of the locking system

You can change the settings of the locking system. This means only the driver's door, the lockable stowage compartments in the vehicle interior and the fuel filler flap are unlocked when the vehicle is unlocked. This is useful if you frequently travel on your own.

- ► To change the setting: press and hold down the \_\_\_\_\_ and \_\_\_\_ buttons simultaneously for approximately six seconds until the battery check lamp flashes twice (▷ page 73).
- - locks or
  - unlocks the vehicle

The SmartKey now functions as follows:

- ► To unlock centrally: press the button twice.
- ▶ To lock centrally: press the 🕞 button.

The KEYLESS-GO function is changed as follows:

- ► To unlock the driver's door: touch the inner surface of the door handle on the driver's door.
- ► To unlock centrally: touch the inner surface of the front-passenger door handle.
- ► To lock centrally: touch the outer sensor surface on one of the door handles.
- ► To restore the factory settings: press and hold down the or and or buttons simultaneously for approximately six seconds until the battery check lamp flashes twice (▷ page 73).

#### Mechanical key

#### **General notes**

If the vehicle can no longer be locked or unlocked with the SmartKey, use the mechanical key.

If you use the mechanical key to unlock and open the driver's door or the trunk lid, the anti-theft alarm system will be triggered (> page 67). There are several ways to turn off the alarm:

► To turn the alarm off with the SmartKey: press the or u button on the SmartKey.

or

Insert the SmartKey into the ignition lock.

or

► To disarm the alarm with KEYLESS-GO: press the Start/Stop button in the ignition lock. The SmartKey must be in the vehicle.

or

 Lock or unlock the vehicle using KEYLESS-GO. The SmartKey must be outside the vehicle.

If you unlock the vehicle using the mechanical key, the fuel filler flap will not be unlocked automatically.

► To unlock the fuel filler flap: insert the SmartKey into the ignition lock.

## Removing the mechanical key



Push release catch ① in the direction of the arrow and at the same time remove mechanical key ② from the SmartKey.

For further information about:

- unlocking the driver's door (▷ page 78)
- unlocking the trunk (▷ page 81)
- locking the vehicle (> page 78)

#### SmartKey battery

#### Important safety notes

#### MARNING

Batteries contain toxic and corrosive substances. If batteries are swallowed, it can result in severe health problems. There is a risk of fatal injury.

Keep batteries out of the reach of children. If a battery is swallowed, seek medical attention immediately.

Mercedes-Benz recommends that you have the batteries replaced at a qualified specialist workshop.

The SmartKey batteries contain perchlorate material, which may require special handling and regard for the environment. National guidelines must be observed during disposal.

#### Checking the battery



Press the g or g button. The battery is working properly if battery check lamp (1) lights up briefly.

The battery is discharged if battery check lamp (1) does not light up briefly.

- Change the battery ( $\triangleright$  page 73).
- - locks or
  - unlocks the vehicle

• You can get a battery at any qualified specialist workshop.

#### Replacing the battery

You require a CR 2025 3 V cell battery.

► Take the mechanical key out of the SmartKey (▷ page 72).



- Press mechanical key ② into the SmartKey opening in the direction of the arrow until battery compartment cover ① opens. Do not hold battery compartment cover ① closed while doing so.
- ▶ Remove battery compartment cover ①.



- Repeatedly tap the SmartKey against your palm until battery (3) falls out.
- Insert the new battery with the positive terminal facing upwards. Use a lint-free cloth to do so.
- Make sure that the surface of the battery is free of lint, grease and other contaminants.

**Opening and closing** 

# 74 SmartKey

- Insert the front tabs of battery compartment cover ① into the housing first and then press to close it.
- Insert mechanical key (2) into the SmartKey.
- Check the function of all SmartKey buttons on the vehicle.

# Problems with the SmartKey

Problem	Possible causes/consequences and ► Solutions
You can no longer lock or unlock the vehicle using the SmartKey.	<ul> <li>The SmartKey battery is discharged or nearly discharged.</li> <li>Check the SmartKey battery (▷ page 73) and replace it if necessary (▷ page 73).</li> <li>If this does not work:</li> <li>Unlock (▷ page 78) or lock (▷ page 78) the vehicle using the mechanical key.</li> </ul>
	<ul> <li>The SmartKey is faulty.</li> <li>Unlock (▷ page 78) or lock (▷ page 78) the vehicle using the mechanical key.</li> <li>Have the SmartKey checked at a qualified specialist workshop.</li> </ul>
You can no longer lock or unlock the vehicle using KEYLESS-GO.	<ul> <li>There is interference from a powerful source of radio waves.</li> <li>Lock/unlock the vehicle using the remote control function of the SmartKey. To do this, hold the SmartKey as close as possible to the vehicle and press the</li></ul>
	<ul> <li>KEYLESS-GO is malfunctioning.</li> <li>Lock/unlock the vehicle using the remote control function of the SmartKey.</li> <li>Have KEYLESS-GO checked at a qualified specialist workshop.</li> <li>If the vehicle can also not be locked/unlocked using the remote control function:</li> <li>Unlock (▷ page 78) or lock (▷ page 78) the vehicle using the mechanical key.</li> <li>Have KEYLESS-GO checked at a qualified specialist workshop.</li> </ul>
You have lost a SmartKey.	<ul> <li>Have the SmartKey deactivated at a qualified specialist workshop.</li> <li>Report the loss immediately to the vehicle insurers.</li> <li>If necessary, have the locks changed as well.</li> </ul>
You have lost the mechanical key.	<ul> <li>Report the loss immediately to the vehicle insurers.</li> <li>If necessary, have the locks changed as well.</li> </ul>

Opening and closing

Problem	Possible causes/consequences and ► Solutions
The engine can no longer be started using the SmartKey.	The on-board voltage is too low.
	<ul> <li>Switch off non-essential consumers, e.g. seat heating or interior lighting, and try to start the engine again.</li> </ul>
	If this does not work:
	<ul> <li>Check the starter battery and charge it if necessary (&gt; page 296).</li> </ul>
	or
	► Jump-start the vehicle (▷ page 298).
	or
	<ul> <li>Consult a qualified specialist workshop.</li> </ul>
The engine can no longer be started using KEYLESS-GO. The SmartKey is in the vehicle.	The vehicle is locked.
	Unlock the vehicle and try to start the vehicle again.
	<ul><li>There is interference from a powerful source of radio waves.</li><li>Start your vehicle with the SmartKey in the ignition lock.</li></ul>

#### Doors

#### Important safety notes

#### MARNING

If children are left unsupervised in the vehicle, they could:

- open the doors, thus endangering other people or road users.
- get out and disrupt traffic.
- operate the vehicle's equipment.

Additionally, children could set the vehicle in motion if, for example, they:

- release the parking brake.
- shift the automatic transmission out of parking position P.
- shift the manual transmission into neutral.
- starting the engine.

There is a risk of an accident and injury. When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children or animals unattended in the vehicle. Always keep the SmartKey out of reach of children.

## 

If children are left unsupervised in the vehicle, they could:

- open the doors, thus endangering other people or road users.
- get out and disrupt traffic.
- operate the vehicle's equipment.

Additionally, children could set the vehicle in motion if, for example, they:

- release the parking brake.
- shifting the automatic transmission out of park position  $\ensuremath{\textbf{P}}$
- Start the engine.

There is a risk of an accident and injury. When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children or animals unattended in the vehicle. Always keep the SmartKey out of reach of children.

# Opening and closing

# 

If children are left unsupervised in the vehicle, they could:

- open the doors, thus endangering other people or road users.
- get out and disrupt traffic.
- operate the vehicle's equipment.

Additionally, children could set the vehicle in motion if, for example, they:

- release the parking brake.
- shifting the automatic transmission out of park position P
- Start the engine.

There is a risk of an accident and injury.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children or animals unattended in the vehicle. Always keep the SmartKey out of reach of children.

## 


If persons, particularly children are subjected to prolonged exposure to extreme heat or cold, there is a risk of injury, possibly even fatal. Never leave children unattended in the vehicle.

# Unlocking and opening doors from the inside

The side windows will not open/close if the battery is discharged or if the side windows have iced up. It will then not be possible to close the door. Do not attempt to force the door closed. You could otherwise damage the door or the side window.

You can open a door from inside the vehicle even if it has been locked.

If the vehicle was previously locked with the SmartKey or with KEYLESS-GO, opening the vehicle from the inside will activate the antitheft alarm system. Switch off the alarm ( $\triangleright$  page 67).




Pull door handle ②. If the door is locked, locking knob ① pops up. The door is unlocked and can be opened.

When a door is opened, the side window on that side opens slightly. When the door is closed, the side window closes again.

# Centrally locking and unlocking the vehicle from the inside

You can centrally lock or unlock the vehicle from the inside. For example, you can unlock the front-passenger door from the inside or lock the vehicle before you pull away.



- ► To unlock: press button ①.
- ► To lock: press button ②. If the front-passenger door is closed, the vehicle locks.

The central locking/unlocking button does not lock or unlock the fuel filler flap or the stowage compartments, such as the glove box. Opening and closing


You cannot unlock the vehicle centrally from the inside if the vehicle has been locked with the SmartKey or KEYLESS-GO.

You can open a door from inside the vehicle even if it has been locked.

If the vehicle has been locked using the locking button for the central locking, or has been locked automatically, and a door is opened from the inside:

- the vehicle will be fully unlocked if it had previously been fully unlocked
- only the door which has been opened form the inside is unlocked if only the driver's door had been previously unlocked

#### Automatic locking feature



- ① Disarming
- Arming
- ► **To disarm:** press and hold button ① for about five seconds until a tone sounds.
- ► **To arm:** press and hold button ② for about five seconds until a tone sounds.
- (1) If you press one of the two buttons and do not hear a tone, the relevant setting has already been selected.

The vehicle is locked automatically when the ignition is switched on and the wheels are turning.

You could therefore lock yourself out if:

- the vehicle is being pushed.
- the vehicle is being towed.
- the vehicle is on a roller dynamometer.

You can also switch the automatic locking function on and off using the on-board computer ( $\triangleright$  page 205).

# Unlocking the driver's door (mechanical key)

If the vehicle can no longer be unlocked with the SmartKey, use the mechanical key.

If you use the mechanical key to unlock and open the driver's door, the anti-theft alarm system will be triggered ( $\triangleright$  page 67).

- ► Take the mechanical key out of the SmartKey (▷ page 72).
- Insert the mechanical key into the lock of the driver's door as far as it will go.




- Turn the mechanical key counter-clockwise to position 1. The door is unlocked.
- Turn the mechanical key back and remove it.
- Insert the mechanical key into the SmartKey.

#### Locking the vehicle (mechanical key)

If the vehicle can no longer be locked with the SmartKey, use the mechanical key.

- Open the driver's door.
- Close the front-passenger door and the trunk lid.
- ▶ Press the locking button (▷ page 77).

- ► Check whether the locking knob on the front-passenger door is still visible. If necessary, press the locking knob down by hand (▷ page 77).
- Close the driver's door.
- ► Take the mechanical key out of the SmartKey (▷ page 72).
- Insert the mechanical key into the lock of the driver's door as far as it will go.



- 1 To lock
- Turn the mechanical key clockwise as far as it will go to position 1.
- Turn the mechanical key back and remove it.
- Make sure that the doors and the trunk lid are locked.
- Insert the mechanical key into the SmartKey.
- If you lock the vehicle as described above, the fuel filler flap is not locked. The antitheft alarm system is not armed.

### Trunk

#### Important safety notes

### MARNING

If objects, luggage or loads are not secured or not secured sufficiently, they could slip, tip over or be flung around and thereby hit vehicle occupants. There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction. Always store objects so that they cannot be flung around. Secure objects, luggage or loads against slipping or tipping before the journey.

# 

If persons, particularly children are subjected to prolonged exposure to extreme heat or cold, there is a risk of injury, possibly even fatal. Never leave children unattended in the vehicle.

- The trunk lid swings upwards when opened. Therefore, make sure that there is sufficient clearance above the trunk lid.
- Only close the trunk once the roof is lowered completely. Otherwise, you could damage the roof.

If you close the trunk lid before the roof is lowered completely, the loading aid switch lights up and a warning tone sounds.

Opening dimensions of the trunk lid
 (▷ page 350).

Do not leave the SmartKey in the trunk. You could otherwise lock yourself out.

The trunk lid can be:

- opened/closed from outside
- opened automatically from outside
- locked separately
- unlocked with the mechanical key
- opened with the emergency release button

#### Trunk lid reversing feature

The trunk lid is equipped with an automatic reversing feature. It reacts if a solid object obstructs or restricts the trunk lid during the closing procedure. The trunk lid opens again automatically. The automatic reversing feature is only an aid and is not a substitute for your attentiveness to the trunk lid while it is closing.

# 80 Trunk

## **∧** WARNING

The reversing feature does not react:

- to soft, light and thin objects, e.g. small fingers
- over the last 1/3 in(8 mm) of the closing movement

This means that the reversing feature cannot prevent someone being trapped in these situations. There is a risk of injury.

Make sure that no body parts are in close proximity during the closing procedure. If somebody becomes trapped:

- ii somebody becomes trapped.
- $\bullet$  press the  $\fbox$  button on the SmartKey, or
- press the remote operating switch on the driver's door, or
- press the closing or locking button on the trunk lid, or
- pull on the trunk lid handle

#### Opening/closing from outside

#### Opening



- $\blacktriangleright$  Press the  $\bigcirc$  button on the SmartKey.
- ▶ Pull handle ①.
- Raise the trunk lid.

#### Closing



- ▶ Pull the trunk lid down using recess ①.
- ► Lock the vehicle if necessary with the button on the SmartKey or with KEYLESS-GO.
- If a KEYLESS-GO key is detected in the trunk, the trunk lid cannot be locked and will open again.

#### Opening automatically from outside

#### General notes

- The trunk lid swings upwards when opened. Therefore, make sure that there is sufficient clearance above the trunk lid.
- Opening dimensions of the trunk lid (▷ page 350).

### Opening

You can automatically open the trunk lid using the handle in the trunk lid.

If the trunk lid is unlocked, pull the trunk lid handle and let it go again immediately.

Vehicles with the trunk lid remote closing feature: the trunk lid can also be opened automatically with the SmartKey.

Press and hold the button on the SmartKey until the trunk lid opens.

#### Locking the trunk separately

You can lock the trunk separately. If you then unlock the vehicle centrally, the trunk remains locked and cannot be opened.

- Close the trunk lid.
- ► Take the mechanical key out of the SmartKey (▷ page 72).



- 1 Basic position
- 2 To lock
- Insert the mechanical key into the trunk lid lock as far as it will go.
- ► Turn the mechanical key clockwise from position 1 to position 2.
- ▶ Remove the mechanical key.
- Insert the mechanical key into the SmartKey.


#### Unlocking the trunk (mechanical key)

The trunk lid swings upwards when opened. Therefore, make sure that there is sufficient clearance above the trunk lid.

If the trunk cannot be unlocked with the SmartKey or KEYLESS-GO, use the mechanical key.

If you use the mechanical key to unlock and open the trunk lid, the anti-theft alarm system will be triggered ( $\triangleright$  page 67).

- ► Take the mechanical key out of the SmartKey (▷ page 72).
- Insert the mechanical key into the trunk lid lock as far as it will go.



- 1 Basic position
- 2 To unlock
- Turn the mechanical key counter-clockwise as far as it will go from position 1 to position 2.
- Pull the trunk lid handle. The trunk is unlocked.
- Turn the mechanical key back to position
   and remove it.
- Insert the mechanical key into the SmartKey.
- When you lock the vehicle (▷ page 78), the trunk is also locked.

#### **Trunk emergency release**

You can unlock the trunk lid from the inside with the emergency release button.



 Press emergency release button ① briefly. The trunk lid unlocks and opens.

The trunk lid can be unlocked with the trunk lid emergency release when the vehicle is stationary or while driving.

The trunk lid emergency release does not unlock the trunk lid if the battery is disconnected or discharged.

Trunk lid emergency release light:

- emergency release button ① flashes for 30 minutes after the trunk lid is opened
- emergency release button ① flashes for 60 minutes after the trunk lid is closed

#### Side windows

#### Important safety notes

#### MARNING

While opening the side windows, body parts could become trapped between the side window and the door frame as the side window moves. There is a risk of injury.

Make sure that nobody touches the side window during the opening procedure. If somebody becomes trapped, release the switch or pull the switch to close the side window again.

## 

While opening the side windows, body parts in the closing area could become trapped. There is a risk of injury.

Make sure that no body parts are in close proximity during the closing procedure. If somebody becomes trapped, release the switch or press the switch to open the side window again.

## 

If children operate the side windows they could become trapped, particularly if they are left unsupervised. There is a risk of injury. When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children unsupervised in the vehicle.

#### Side window reversing feature

The side windows are equipped with an automatic reversing feature. If a solid object blocks or restricts a side window during the closing process, the side window opens again automatically. However, the automatic reversing feature is only an aid and does not relieve you of the responsibility of paying attention when closing a side window.

### 

The reversing feature does not react:

- to soft, light and thin objects, e.g. small fingers
- over the last 1/6 in(4 mm) of the closing movement
- during resetting
- when closing the side window again manually immediately after automatic reversing


This means that the reversing feature cannot prevent someone being trapped in these situations. There is a risk of injury.

Make sure that no body parts are in close proximity during the closing procedure. If someone becomes trapped, press the switch to open the side window again.

# Opening and closing the side windows in the front

The switches for the front side windows are located on the driver's door. There is also a switch for the front-passenger side window on the front-passenger door.

The switches on the driver's door take precedence.



- 1 Left
- 2 Right
- ► Turn the SmartKey to position 1 or 2 in the ignition lock.
- You can continue to operate the side windows after you switch off the engine. This function is available for up to five minutes or until the driver's or frontpassenger door is opened.
- **To open:** press the corresponding switch.
- **To close:** pull the corresponding switch.
- Automatic operation: press or pull the corresponding switch beyond the point of resistance.

The side window opens or closes fully.

To interrupt automatic operation: press or pull the corresponding switch again.

#### Opening and closing all side windows

#### Using the switch on the center console

You can use the switch on the center console to close all side windows simultaneously.

Open the cover in the lower center console. The switch for all side windows is under the cover.



- ► To open all side windows: press switch ① to the point of resistance.
- To open all side windows fully: press switch (1) beyond the point of resistance. All side windows open simultaneously.
- 1 If, after opening the windows, you then close a side window using the switch on the door control panel, the other side windows will remain open. To close the other side windows, you must pull the switch on the center console and hold it. The front side window will close first, then the rear side windows.
- To close all side windows: pull switch ①.

The rear side windows close after the front side windows.

- Make sure that all the side windows are fully closed.
- When the roof is open, only the two front side windows can be operated using the switch on the center console.

### Using the SmartKey

#### **▲ WARNING**

When using the convenience closing feature, parts of the body could be trapped in the closing area when a side window is being closed. There is a risk of injury.

Observe the complete closing procedure when the convenience closing feature is operating. Make sure that no body parts are in close proximity during the closing procedure. If someone is trapped:

- $\blacktriangleright$  Release the **\bigcirc** button immediately.
- Press and hold the button until the side windows open again.

You can use the SmartKey to open or close all side windows simultaneously.

- ► Close the roof (▷ page 87).
- ▶ Open the trunk partition (▷ page 88).
- ► Vehicles without KEYLESS-GO: point the tip of the SmartKey at the door handle on the driver's door.
- Vehicles with KEYLESS-GO: the SmartKey must be within 6 ft (2 m) of the vehicle.
- ► To interrupt the opening procedure: release the relea
- To close all side windows: press the
   button on the SmartKey until the side windows are fully closed.

#### **Convenience closing with KEYLESS-GO**

### MARNING

When using the convenience closing feature, parts of the body could be trapped in the closing area when a side window is being closed. There is a risk of injury.

Observe the complete closing procedure when the convenience closing feature is operating. Make sure that no body parts are in close proximity during the closing procedure.

If someone is trapped:

- Release the recessed sensor surface on the door handle immediately.
- Pull the door handle immediately and hold it until the side windows open again.

With KEYLESS-GO you can close all side windows simultaneously. The KEYLESS-GO key must be outside the vehicle. All the doors must be closed.



- Touch recessed sensor surface ① on the door handle until the side windows are fully closed.
- (1) Make sure you only touch recessed sensor surface (1).
- Make sure that all the side windows are closed.
- ► To interrupt convenience closing: release recessed sensor surface ① on the door handle.

#### **Resetting the side windows**

If a side window can no longer be closed fully, you must reset it.

- Close all the doors.
- ► Turn the SmartKey to position 1 or 2 in the ignition lock.
- ► Pull the corresponding switch on the door control panel until the side window is completely closed. (▷ page 82)
- ► Hold the switch for an additional second.

If the side window opens again slightly:

- Immediately pull the corresponding switch on the door control panel until the side window is completely closed (▷ page 82).
- ► Hold the switch for an additional second.
- If the corresponding side window remains closed after the button has been released,

the side window has been reset correctly. If this is not the case, repeat the steps above again.

#### Problems with the side windows

#### **∧** WARNING

If you close a side window again immediately after it has been blocked or reset, the side window closes with increased or maximum force. The reversing feature is then not active. Parts of the body could be trapped in the closing area in the process. This poses an increased risk of injury or even fatal injury.

Make sure that no parts of the body are in the closing area. To stop the closing process, release the switch or push the switch again to reopen the side window.

Problem	Possible causes/consequences and ► Solutions
A side window cannot be closed because it is blocked by objects, e.g. leaves in the window guide.	<ul><li>Remove the objects.</li><li>Close the side window.</li></ul>
A side window cannot be closed and you cannot see the cause.	<ul> <li>If a side window is obstructed during closing and reopens again slightly:</li> <li>Immediately after the window blocks, pull the corresponding switch again until the side window has closed. The side window is closed with increased force.</li> </ul>
	If a side window is obstructed again during closing and reopens again slightly:
	<ul> <li>Immediately after the window blocks, pull the corresponding switch again until the side window has closed.</li> <li>The side window is closed without the anti-entrapment feature.</li> </ul>

#### Roof

#### Important safety notes

### MARNING

If you do not fully open/close the soft top, the soft-top hydraulics depressurize after a short time. This causes the soft top to lower unexpectedly and may cause you or others to be trapped. There is a risk of injury.

Always open or close the soft top completely.

#### MARNING

Closing the roof manually is a complicated and technically demanding procedure, which

requires a lot of strength. You or others can become trapped. There is a risk of injury. Only have the soft top closed manually at a qualified specialist workshop.

- Never sit on the rear shelf or store heavy objects there. You will otherwise damage the roof and the rear shelf of your vehicle.
- Do not forget that the weather can change abruptly. Make certain that the roof is closed when you leave the vehicle. The vehicle electronics can be damaged if water enters the vehicle interior.
- When opening and closing the roof, make sure that:

- there is sufficient clearance, as the roof swings upwards.
- there is sufficient clearance behind the vehicle, as the trunk lid swings backwards beyond the bumper.
- the trunk is only loaded to below the trunk partition.
- the trunk partition is not pushed up by the load.
- the trunk partition is closed.
- the trunk lid is closed.
- the outside temperature is above 5 °F (-15 °C).

You could otherwise damage the roof, trunk and other parts of the vehicle.

① The vehicle's dimensions when opening/ closing the roof (▷ page 350).

Make sure that the roof and rear window are clean and dry before opening the roof. Otherwise, water or dirt could enter the vehicle interior or trunk.

# Opening and closing using the roof switch


#### Important safety notes

### 

When opening or closing the roof, body parts could be trapped by, for example, the roof mechanism, trunk lid or side windows. There is a risk of injury.

When raising or lowering the roof, make sure that no body parts are in the vicinity of moving components. If someone becomes trapped, release the button.

## Opening and closing



- ► Secure the vehicle against rolling away (▷ page 159).
- ► Close the trunk partition (▷ page 89).
- Close the trunk lid.
- ► Turn the SmartKey to position **2** in the ignition lock.
- ▶ Open the cover in the lower center console. Roof switch ① is located under the cover.
- ► **To open:** pull soft-top switch ① until the entire soft top is stowed away in the trunk. You see the Vario-Roof in Operation message in the multifunction display. As soon as the opening procedure has ended, the message disappears and you hear a tone.

All of the side windows open.

► To close: press and hold soft-top switch ① until the soft top is fully closed. You see the Vario-Roof in Operation message in the multifunction display. As soon as the closing procedure has ended, the message disappears and you hear a tone.

All of the side windows open.

- ► To close all side windows, pull the switch under the cover of the center console (▷ page 83).
- **1** If you operate the roof switch and the Trunk Partition Open message appears in the multifunction display, the trunk partition has not been closed correctly.

# 88 Roof

Opening and closing using the SmartKey

#### Important safety notes

#### MARNING

When opening or closing the roof, body parts could be trapped by, for example, the roof mechanism, trunk lid or side windows. There is a risk of injury.

When raising or lowering the roof, make sure that no body parts are in the vicinity of moving components. If someone becomes trapped, release the button.

#### **Opening and closing**

- ► Close the trunk partition (▷ page 88).
- ► Close the trunk lid (> page 79).
- Vehicles without KEYLESS-GO: point the tip of the SmartKey at the door handle on the driver's door.
- ► Vehicles with KEYLESS-GO: the SmartKey must be within 6 ft (2 m) of the vehicle.
- ► To open: press and hold the on the SmartKey until the roof is fully opened.

The roof and the rear side windows open. The front side windows close.

- ► To interrupt the opening procedure: release the relea
- ► **To close:** press and hold the **\_\_** button on the SmartKey until the roof is fully closed.

The roof and the side windows close.

- ► To interrupt the closing procedure: release the \_\_\_\_\_ button.
- When the roof is closed and the trunk partition is open, the roof cannot be opened using the SmartKey functions. Instead, all of the side windows open or close simultaneously (▷ page 83).

Additionally, the Trunk Partition Open message appears in the multifunction display.

#### Locking the roof again

#### Important safety notes

#### MARNING

If you do not fully open/close the soft top, the soft-top hydraulics depressurize after a short time. This causes the soft top to lower unexpectedly and may cause you or others to be trapped. There is a risk of injury.

Always open or close the soft top completely.

The roof is not locked if:

- the symbol and the Vario-Roof in Operation message appear in the multifunction display.
- the symbol and the Open/Close Vario-Roof Completely message appear and you hear a warning tone.
- you hear a warning tone for up to 10 seconds when pulling away or while driving.

### Locking

You can lock the roof again if it is not locked fully.

- Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.
- Make sure that the SmartKey is in position
   2 in the ignition lock.
- ▶ Press the roof switch (▷ page 87).

#### **Trunk partition**

#### General notes

To avoid damaging the roof or luggage when folding back the roof, you should:

- only load the trunk to below the trunk partition
- not place any objects on or in front of the trunk partition
- not place any objects on the cover behind the roll bars
- not allow the cargo to push the trunk partition upwards

The trunk partition can be used to cover luggage and loads in the trunk.

## **Opening and closing**



- ► To close: pull back trunk partition ① by the handle in the direction of the arrow until it engages on both sides in the eyelets on the cargo compartment lip.
- ► **To open:** grip the handle of trunk partition ①.
- Press the release button in the handle of trunk partition (1).
   Trunk partition (1) is unlocked.
- Pull trunk partition ① up out of the eyelets on the cargo compartment lip.
- Push trunk partition ① forwards against the direction of the arrow by handle.

#### Wind screen

### Important safety notes

#### MARNING

If you use the wind screen in darkness or in other conditions offering poor visibility, your

view to the rear is further impaired. There is a risk of an accident.

Only use the wind screen when visibility conditions are good.

# 

If the wind screen is incorrectly installed, it could detach itself during a journey and endanger other road users. There is a risk of an accident and injury.

Install the wind screen as described.

Install or remove the wind screen only when the roof is open. You could otherwise damage the wind screen or the vehicle interior.

The wind screen offers protection from the wind when driving with the roof down. The wind screen can be installed or removed

from the driver's side or passenger side.

For operations involving the wind screen, it is preferable to be positioned on the side of the vehicle facing away from the traffic, after stopping the vehicle in accordance with the traffic conditions.

# Installing and removing the wind screen

## Preparing for installation




Preparing for installation from the left side of the vehicle (example)

- Wind screen
- Locked latch
- ③ Unlocked latch

# 90 Roof

- The following conditions must be fulfilled for installation:
  - unlocking buttons **R** and **L** point in the direction of travel.
  - latch ③ facing you is unlocked.
  - latch (2) facing away from you is locked.
- ► To unlock the latch: press unlocking button **R** or **L** on the locked latch.
- ► To lock the latch: push the unlocked latch upwards by hand until it engages.


#### Installing



Installation from the left side of the vehicle (example)

- Stop the vehicle, paying attention to road and traffic conditions.
- ► Take the wind screen out of the trunk.
- ▶ Prepare for installing (▷ page 89).
- ► Hold wind screen ① at an angle and slide it with locked latch ② in the direction of arrow ④ into the bracket of the opposite roll bar.
- Press wind screen (1) on the side of the vehicle facing you downwards in the direction of arrow (5) until it engages.
   Make sure that studs (6) and latch (3) fit into the respective brackets.
- Check whether wind screen ① is fully inserted into all four brackets and is sitting securely.
- If this is not the case, remove wind screen (1) again and repeat the steps above.

#### Removing



Removing from the left side of the vehicle (example)

- Stop the vehicle, paying attention to road and traffic conditions.
- Press unlocking button L①. Meanwhile, pull wind screen ② on the side of the vehicle facing you upwards and tilt it.



Removing from the left side of the vehicle (example)

- Pull wind screen (2) out of the bracket of the opposite roll bar in the direction of the arrow.
- ► Secure wind screen ② to the trunk floor by the rubber strips (▷ page 256).

#### AIRGUIDE

#### Important safety notes

#### MARNING

You could lose control of the vehicle if you fold AIRGUIDE in/out while the vehicle is in motion. There is a risk of an accident.


Only fold AIRGUIDE in/out while the vehicle is stationary.

AIRGUIDE can only be positioned correctly by folding it in or out. AIRGUIDE cannot be dismantled. Do not try to remove AIRGUIDE from its anchorage. Otherwise, you could damage AIRGUIDE or the vehicle.

AIRGUIDE can be folded out or back in from the driver's side or passenger side.

When operating AIRGUIDE, preferably stand on the side of the vehicle away from the traffic, after you have stopped the vehicle in accordance with road and traffic conditions.

#### **Operating AIRGUIDE**



Example: folding out from the left side of the vehicle

- Stop the vehicle, paying attention to road and traffic conditions.
- To fold out AIRGUIDE: turn disc ① in the direction of the arrow towards the middle of the vehicle to the stop.
- ▶ Repeat with disc ②.
- To fold in AIRGUIDE: turn discs ① and ② back behind the roll bar to the stop.

 Discs 1 and 2 can also be used independently of each other, e.g. when you are driving without a passenger.

#### MAGIC SKY CONTROL

#### General notes

MAGIC SKY CONTROL is a glass roof, the transparency of which can be changed by applying electrical voltage.

MAGIC SKY CONTROL can be switched between darkened and transparent states.

 MAGIC SKY CONTROL darkens automatically when you turn the SmartKey to position 0 in the ignition lock or remove the SmartKey.

#### **Risk of electric shock**

#### 

MAGIC SKY CONTROL operates using high voltage. If the trim behind the overhead control panel is damaged or removed, electrical components will be exposed. If you touch these components, you could get an electric shock. There is a risk of fatal injury.

- Never remove the trim behind the overhead control panel.
- If the trim is damaged, never touch the electrical components behind it.
- Always have work on the MAGIC SKY CONTROL carried out at a qualified specialist workshop.

The electrical components of MAGIC SKY CONTROL are protected by a paneling behind the overhead control panel.

The MAGIC SKY CONTROL control unit is marked with a yellow warning sticker that warns you of high voltage. The electric cables of the high-voltage section are colored orange.

#### **Operating MAGIC SKY CONTROL**



► Turn the SmartKey to position 1 or 2 in the ignition lock.

MAGIC SKY CONTROL switches to the status it was set to before the engine was switched off.

► To change the degree of transparency: press button ①.

• At sub-zero temperatures, the change is slower and uneven. The entire process may take some time.

# Problems with the roof

Problem	Possible causes/consequences and ► Solutions
The roof will not open or close.	<ul><li>The trunk partition is not closed and not properly engaged.</li><li>▶ Close the trunk partition (▷ page 89).</li></ul>
	The trunk lid is open. ► Close the trunk lid (▷ page 80).
	The on-board voltage is too low. ► Leave the engine running.
	<ul> <li>The roof has been opened and closed several times in a row. The roof drive has been automatically deactivated.</li> <li>You can open and close the roof again after approximately ten minutes.</li> <li>Switch off the ignition and turn it back on.</li> <li>Repeat the opening or closing procedure.</li> </ul>
	The automatic roof mechanism is faulty. ► Consult a qualified specialist workshop.

Useful information	96
Correct driver's seat position	96
Seats	97
Steering wheel	100
Mirrors	103
Memory function	105

#### **Useful information**

- This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- Read the information on qualified specialist workshops: (▷ page 24).

#### Correct driver's seat position



- ► Observe the safety guidelines on seat adjustment (▷ page 97).
- Make sure that seat ③ is adjusted properly.

Manual seat adjustment ( $\triangleright$  page 98) Electrical seat adjustment ( $\triangleright$  page 98) When adjusting the seat, make sure that:

• you are as far away from the driver's air bag

- as possible.
- you are sitting in a normal upright position.
- you can fasten the seat belt properly.

- you have moved the backrest to an almost vertical position.
- you have set the seat cushion angle so that your thighs are gently supported.
- you can depress the pedals properly.
- Check whether the head restraint is adjusted properly.

When doing so, make sure that you have adjusted the head restraint so that the back of your head is supported at eye level by the center of the head restraint.

- ► Observe the safety guidelines on steering wheel adjustment (▷ page 100).
- Make sure that steering wheel (1) is adjusted properly.

Adjusting the steering wheel manually (> page 101)

Adjusting the steering wheel electrically (> page 101)

When adjusting the steering wheel, make sure that:

- you can hold the steering wheel with your arms slightly bent.
- you can move your legs freely.
- you can see all the displays in the instrument cluster clearly.
- ► Observe the safety guidelines for seat belts (▷ page 51).
- ► Check whether you have fastened seat belt ② properly (▷ page 53).

The seat belt should:

- fit snugly across your body
- be routed across the middle of your shoulder
- be routed in your pelvic area across the hip joints
- Before starting off, adjust the rear-view mirror and the exterior mirrors
   (▷ page 103) in such a way that you have a good view of road and traffic conditions.
- ► Vehicles with a memory function: save the seat, steering wheel and exterior mirror settings (▷ page 105).

#### Seats

#### Important safety notes

#### MARNING

Children could become trapped if they adjust the seats, particularly when unattended. There is a risk of injury.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children unsupervised in the vehicle.

## 

If the driver's seat is not engaged, it could move unexpectedly while the vehicle is in motion. This could cause you to lose control of the vehicle. There is a risk of an accident.

Always make sure that the driver's seat is engaged before starting the engine.

### MARNING

If you adjust the seat height carelessly, you or other vehicle occupants could be trapped and thereby injured. Children in particular could accidentally press the electrical seat adjustment buttons and become trapped. There is a risk of injury.

While moving the seats, make sure that your hands or other body parts do not get under the lever assembly of the seat adjustment system.

## 

When you adjust a seat, you or other vehicle occupants could become trapped, e.g. on the seat guide rail. There is a risk of injury.

Make sure when adjusting a seat that no one has any body parts in the sweep of the seat.

### 

If head restraints are not installed and adjusted correctly, they cannot provide protection as intended. There is an increased risk of injury in the head and neck area, e.g. in the event of an accident or when braking. Always drive with the head restraints installed. Before driving off, make sure for every vehicle occupant that the center of the head restraint supports the back of the head at about eye level.

### 

You could lose control of your vehicle if you do the following while driving:

- adjust the driver's seat, steering wheel or mirrors
- fasten the seat belt

There is a risk of an accident.

Adjust the driver's seat, steering wheel or mirrors and fasten your seat belt before starting the engine.

## 

When you adjust a seat, you or other vehicle occupants could become trapped, e.g. on the seat guide rail. There is a risk of injury.

Make sure when adjusting a seat that no one has any body parts in the sweep of the seat.

## 

If head restraints are not installed and adjusted correctly, they cannot provide protection as intended. There is an increased risk of injury in the head and neck area, e.g. in the event of an accident or when braking.


Always drive with the head restraints installed. Before driving off, make sure for every vehicle occupant that the center of the head restraint supports the back of the head at about eye level.

- To avoid damage to the seats and the seat heating, observe the following information:
  - keep liquids from spilling on the seats. If liquid is spilled on the seats, dry them as soon as possible.
  - if the seat covers are damp or wet, do not switch on the seat heating. The seat heating should also not be used to dry the seats.

- clean the seat covers as recommended; see the "Interior care" section.
- do not transport heavy loads on the seats. Do not place sharp objects on the seat cushions, e.g. knives, nails or tools. The seats should only be occupied by passengers, if possible.
- when the seat heating is in operation, do not cover the seats with insulating materials, e.g. blankets, coats, bags, seat covers, child seats or booster seats.
- Make sure that there are no objects in the footwell or behind the seats when resetting the seats. There is a risk that the seats and/or the objects could be damaged.
- The head restraints are installed with the NECK-PRO system (▷ page 50). For this reason, it is not possible to remove the head restraints from the seats.

For more information, contact a qualified specialist workshop.


#### Adjusting the seats manually



- To set seat fore-and-aft adjustment: lift lever 1 and slide the seat forwards or backwards.
- Release lever ① again.
   Make sure that you hear the seat engage in position.

- ► To adjust the backrest angle: relieve the pressure on the backrest.
- Pull handle (2) and adjust the backrest to the desired angle.
- Release handle (2) again.
   The backrest must audibly engage.
- To adjust the seat height: pull handle ③ upwards or push it down repeatedly until the seat has reached the desired height.

## Adjusts the seats electrically



- ① Backrest angle
- ② Seat fore-and-aft adjustment
- ③ Seat cushion angle
- ④ Seat height
- You can store the seat settings using the memory function (▷ page 105).


#### Adjusting the head restraints

#### Adjusting the head restraints manually



To raise/lower: push the head restraint upwards or pull it down into the desired position.

#### Adjusting the 4-way lumbar support



- To raise the backrest contour
- To soften the backrest contour
- ③ To lower the backrest contour
- ④ To harden the backrest contour

You can adjust the contour of the seat backrests individually to provide optimum support for your back.

#### Switching the seat heating on/off

#### Activating/deactivating

#### 

Repeatedly switching on the seat heating can cause the seat cushion and backrest pads to become very hot. The health of persons with limited temperature sensitivity or a limited ability to react to excessively high temperatures may be affected or they may even suffer burn-like injuries. There is a risk of injury.

Therefore, do not switch the seat heating on repeatedly.



Driver's and front-passenger seat

The three red indicator lamps in the button indicate the heating level you have selected.

The system automatically switches down from level **3** to level **2** after approximately five minutes.

The system automatically switches down from level **2** to level **1** after approximately ten minutes.

The system automatically switches off approximately 20 minutes after it is set to level **1**.

- Make sure that the SmartKey is in position
   1 or 2 in the ignition lock.
- ► To switch on: press button ① repeatedly until the desired heating level is set.
- ► To switch off: press button ① repeatedly until all the indicator lamps go out.

#### Problems with the seat heating

The seat heating has switched off prematurely or cannot be switched on. The vehicle's electrical system voltage is too low because too many electrical consumers are switched on.

- Switch off electrical consumers that you do not need, such as the rear window defroster or interior lighting.
- Once the battery is sufficiently charged, switch on the seat heating again.

#### AIRSCARF

#### Activating/deactivating

#### **∧** WARNING

When AIRSCARF is switched on, very hot air can flow from the vents in the head restraints. This could result in burns in the immediate vicinity of the air vents. There is a risk of injury. Reduce the heater output before it becomes too hot.



The AIRSCARF function warms the head and neck area of vehicle occupants with warm air. The warm air flows out of the holes in the head restraints.

The three red indicator lamps in the button indicate the heating level you have selected.

- Make sure that the SmartKey is in position
   2 in the ignition lock.
- ▶ To switch on: press button ①. Three red indicator lamps in the button light up. The blower starts up after a preheating phase of seven seconds.
- Press button ① repeatedly until the desired heating level is set.
- ► To switch off: press button ① repeatedly until all the indicator lamps go out.
- The blower continues running for seven seconds to cool down the heating elements.
- If the battery voltage is too low, AIRSCARF may switch off.

#### Problems with AIRSCARF

AIRSCARF has switched off prematurely or will not switch on. The vehicle's electrical system voltage is too low because too many electrical consumers are switched on.

- Switch off electrical consumers that you do not need, such as the rear window defroster or interior lighting.
- Switch on AIRSCARF again.

#### **Steering wheel**

#### Important safety notes

#### **▲** WARNING

You could lose control of your vehicle if you do the following while driving:

- adjust the driver's seat, head restraint, steering wheel or mirrors
- fasten the seat belt

There is a risk of an accident.


Adjust the driver's seat, head restraint, steering wheel and mirror and fasten your seat belt before starting the engine.

# 

You can no longer steer the vehicle if the steering wheel lock has been engaged. There is a risk of an accident.


Always switch off the ignition when towing the vehicle with a tow cable or a tow bar.

# Adjusting the steering wheel manually



- 1 Release lever
- To adjust the steering wheel height
- ③ To adjust the steering wheel position (fore-and-aft adjustment)
- Push release lever (1) down completely in the direction of the arrow.
   The steering column is unlocked.
- Adjust the steering wheel to the desired position.
- Push release lever ① up completely. The steering column is locked.
- Check if the steering column is locked. When doing so, try to push the steering wheel up or down or try to move it in the fore-and-aft direction.

# Adjusting the steering wheel electrically



- ① To adjust the steering wheel height
- To adjust the steering wheel position (fore-and-aft adjustment)
- () Further related subjects:
  - EASY-ENTRY/EXIT feature (▷ page 101)
  - Storing settings (▷ page 105)

# EASY-ENTRY/EXIT feature

#### Important safety notes

#### MARNING

If you drive off while the EASY-ENTRY/EXIT feature is making adjustments, you could lose control of the vehicle. There is a risk of an accident.

Always wait until the adjustment process is complete before driving off.

### 

When the EASY-ENTRY/EXIT feature adjusts the steering wheel, you and other vehicle occupants – particularly children – could become trapped. There is a risk of injury. While the EASY-ENTRY/EXIT feature is making adjustments, make sure that no one has any body parts in the sweep of the steering wheel. If somebody becomes trapped:

- press one of the memory function position buttons, or
- move the switch for steering wheel adjustment in the opposite direction to that in which the steering wheel is moving.

The adjustment process is stopped.

#### 

When the EASY-ENTRY/EXIT feature adjusts the steering wheel and the driver's seat, you and other vehicle occupants – particularly children – could become trapped. There is a risk of injury.

While the EASY-ENTRY/EXIT feature is making adjustments, make sure that no one has any body parts in the sweep of the seat and the steering wheel.

If somebody becomes trapped:

- press one of the memory function position buttons, or
- press one of the memory function memory buttons, or
- move the switch for steering wheel adjustment in the opposite direction to that in which the steering wheel is moving

The adjustment process is stopped.

## 

If you use openings in the bodywork or detachable parts as steps, you could:

- slip and/or fall
- damage the vehicle and cause yourself to fall.

There is a risk of injury.

Always use secure climbing aids, e.g. a suitable ladder.

The EASY-ENTRY/EXIT feature makes getting in and out of your vehicle easier.

You can activate and deactivate the EASY-ENTRY/EXIT feature in the on-board computer ( $\triangleright$  page 205).

# Position of the steering wheel when the EASY-ENTRY/EXIT feature is active

The steering wheel swings upwards when you:

- remove the SmartKey from the ignition lock
- open the driver's door with KEYLESS-GO in position 1
- open the driver's door and the SmartKey is in position **0** or **1** in the ignition lock
- The steering wheel only moves upwards if it has not already reached the upper end stop.

# Position of the steering wheel for driving

The steering wheel is moved to the last selected position when:

- the driver's door is closed
- you insert the SmartKey into the ignition lock

or

• you press the Start/Stop button once on vehicles with KEYLESS-GO

When you close the driver's door with the ignition switched on, the steering wheel is also automatically moved to the previously set position.

The last position of the steering wheel is stored when you switch off the ignition or when you store the setting with the memory function ( $\triangleright$  page 105).

### Crash-responsive EASY-EXIT feature

If the crash-responsive EASY-EXIT feature is triggered in an accident, the steering column will move upwards when the driver's door is opened. This occurs irrespective of the position of the SmartKey in the ignition lock. This makes it easier to exit the vehicle and rescue the occupants.

The crash-responsive EASY-EXIT feature is only operational if the EASY-EXIT/ENTRY feature is activated in the on-board computer.

#### Mirrors

#### **Rear-view mirror**



 Anti-glare mode: flick anti-glare lever (1) forwards or back.

#### **Exterior mirrors**

#### Adjusting the exterior mirrors

#### MARNING

The exterior mirrors reduce the size of the image. Visible objects are actually closer than they appear. This means that you could misjudge the distance from road users traveling behind, e.g. when changing lane. There is a risk of an accident.

For this reason, always make sure of the actual distance from the road users traveling behind by glancing over your shoulder.

### 

The exterior mirror on the front-passenger side reduces the size of the image. Visible objects are actually closer than they appear. This means that you could misjudge the distance from road users traveling behind, e.g. when changing lane. There is a risk of an accident.

For this reason, always make sure of the actual distance from the road users traveling behind by glancing over your shoulder.



- Make sure that the SmartKey is in position
   1 or 2 in the ignition lock.
- Press button ① for the left-hand exterior mirror or button ② for the right-hand exterior mirror.

The indicator lamp in the corresponding button lights up in red.

The indicator lamp goes out again after some time. You can adjust the selected mirror using adjustment button ③ as long as the indicator lamp is lit.

Press adjustment button ③ up, down, to the right or to the left.

The exterior mirror must be set to a position that provides you with a good overview of traffic conditions.

The convex exterior mirrors provide a larger field of vision.

The exterior mirrors are automatically heated after starting the vehicle if the rear window defroster is switched on and the outside temperature is low. Mirror heating lasts up to 10 minutes.

You can also heat up the exterior mirrors manually by switching on the rear window defroster.

# Folding the exterior mirrors in or out electrically



- Make sure that the SmartKey is in position
   1 or 2 in the ignition lock.
- Briefly press button ①.
   Both exterior mirrors fold in or out.
- Make sure that the exterior mirrors are always folded out fully while driving. They could otherwise vibrate.

# Folding the exterior mirrors in or out automatically

If the "Fold in mirrors when locking" function is activated in the on-board computer (> page 206):

- the exterior mirrors fold in automatically as soon as you lock the vehicle from the outside.
- the exterior mirrors fold out again automatically as soon as you unlock the vehicle and then open the driver's or frontpassenger door.
- The exterior mirrors do not fold out if they have been folded in manually.

### Exterior mirror pushed out of position

If an exterior mirror has been pushed out of position, proceed as follows:

- Vehicles without electrically folding exterior mirrors: move the exterior mirror into the correct position manually.
- Vehicles with electrically folding exterior mirrors: press and hold mirror-

folding button ① until you hear a click and then the mirrors engage in position (> page 104).

The mirror housing is engaged again and you can adjust the exterior mirrors as usual (> page 103).

#### Automatic anti-glare mirrors

The rear-view mirror and the exterior mirror on the driver's side automatically go into antiglare mode if the following conditions are met simultaneously:


- the ignition is switched on and
- incident light from headlamps strikes the sensor in the rear-view mirror.

The mirrors do not go into anti-glare mode if reverse gear is engaged or if the interior lighting is switched on.

# Parking position for the exterior mirror on the front-passenger side

#### Setting and storing the parking position


#### Using reverse gear



You can position the front-passenger side exterior mirror in such a way that you can see the rear wheel on that side as soon as you engage reverse gear. You can store this position.

- Make sure that the vehicle is stationary and that the SmartKey is in position 2 in the ignition lock.
- Press button ② for the exterior mirror on the front-passenger side.
- Engage reverse gear.
   The exterior mirror on the front-passenger side moves to the preset parking position.
- Use adjustment button ③ to adjust the exterior mirror to a position that allows you to see the rear wheel and the curb. The parking position is stored.
- If you shift the transmission to another position, the exterior mirror on the frontpassenger side returns to the driving position.

#### Using the memory button



You can position the front-passenger side exterior mirror in such a way that you can see the rear wheel on that side as soon as you engage reverse gear. This setting can be stored using memory button  $\mathbf{M}$  (4).


- Make sure that the SmartKey is in position
   2 in the ignition lock.
- With the exterior mirror on the frontpassenger side activated, use adjustment button ③ to adjust the exterior mirror. In the exterior mirror, the rear wheel and the curb should be visible.

Press memory button M ④ and one of the arrows on adjustment button ③ within three seconds.

The parking position is stored if the exterior mirror does not move.

► If the mirror moves out of position, repeat the steps.

# Calling up a stored parking position setting



- ► Turn the SmartKey to position 2 in the ignition lock.
- ► Adjust the exterior mirror on the frontpassenger side using button ②.
- Engage reverse gear. The exterior mirror on the front-passenger side moves to the stored parking position.

The exterior mirror on the front-passenger side moves back to its original position:

- as soon as you exceed a speed of 9 mph (15 km/h)
- if you press button ① for the exterior mirror on the driver's side

#### Memory function

#### Storing settings

#### MARNING

If you use the memory function on the driver's side while driving, you could lose control of the vehicle as a result of the adjustments being made. There is a risk of an accident.

Only use the memory function on the driver's side when the vehicle is stationary.

#### MARNING

When the memory function adjusts the seat or steering wheel, you and other vehicle occupants – particularly children – could become trapped. There is a risk of injury. While the memory function is making adjustments, make sure that no one has any body parts in the sweep of the seat or steering wheel. If somebody becomes trapped, immediately release the memory function position button. The adjustment process is stopped.

#### 

When the memory function adjusts the seat, you and other vehicle occupants – particularly children – could become trapped. There is a risk of injury.

While the memory function is making adjustments, make sure that no one has any body parts in the sweep of the seat. If somebody becomes trapped, immediately release the memory function position button. The adjustment process is stopped.

#### MARNING

Children could become trapped if they activate the memory function, particularly when unattended. There is a risk of injury.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children unsupervised in the vehicle.



- ► Adjust the seat electrically (▷ page 98).
- On the driver's side, adjust the steering wheel (▷ page 101) and the exterior mirrors (▷ page 103).
- Press memory button M and one of the storage position buttons 1, 2 or 3 within three seconds.

The settings are stored in the selected preset position. A tone sounds when the settings have been completed.

#### Calling up a stored setting

- Press and hold the relevant storage position button 1, 2 or 3 until the seat, steering wheel and exterior mirrors are in the stored position.
- The setting procedure is interrupted as soon as you release the storage position button.

Useful information	108
Exterior lighting	108
Interior lighting	113
Replacing bulbs	114
Windshield wipers	117

### **Useful information**

- This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- Read the information on qualified specialist workshops: (▷ page 24).

## **Exterior lighting**

### General notes

For reasons of safety, Mercedes-Benz recommends that you drive with the lights switched on even during the daytime. In some countries, operation of the headlamps varies due to legal requirements and self-imposed obligations.

### **Driving abroad**

### Symmetrical low-beam headlamps

Switch the headlamps to symmetrical low beam in countries in which traffic drives on the opposite side of the road from the country where the vehicle is registered. This prevents glare to oncoming traffic. When using symmetrical lights, the edge of the road is not lit as widely and as far ahead as normal.

Have the headlamps converted at a qualified specialist workshop as close to the border as possible before driving in these countries.

### Asymmetrical low beam

Have the headlamps converted back to asymmetrical low-beam headlamps at a qualified specialist workshop as soon as possible after crossing the border again.

### Setting the exterior lighting


### Setting options

Exterior lighting can be set using:

- the light switch
- the combination switch (▷ page 110)
- the on-board computer (▷ page 203)

### Light switch

### Operation



- **1 ►P** ≤ Left-hand standing lamps
- 2 **P**≤→ Right-hand standing lamps
- Image: Second stress
   Parking lamps, license plate and instrument cluster lighting
- 4 Automatic headlamp mode, controlled by the light sensor
- **5 D** Low-beam/high-beam headlamps
- ⑥ 0 Rear fog lamp
- ⑦ 10 Fog lamp (only vehicles with front fog lamps)

If you hear a warning tone when you leave the vehicle, the lights may still be switched on.

Turn the light switch to AUTO.

The exterior lighting (except the parking/ standing lamps) switches off automatically if you:

- remove the SmartKey from the ignition lock
- open the driver's door with the SmartKey in position **0**.

### Automatic headlamp mode

### MARNING

When the light switch is set to **AUTO**, the lowbeam headlamps may not be switched on automatically if there is fog, snow or other causes of poor visibility due to the weather conditions such as spray. There is a risk of an accident.

In such situations, turn the light switch to  $\square$ .

The automatic headlamp feature is only an aid. The driver is responsible for the vehicle's lighting at all times.

**Auro** is the favored light switch setting. The light setting is automatically selected according to the brightness of the ambient light (exception: poor visibility due to weather conditions such as fog, snow or spray):

- SmartKey in position 1 in the ignition lock: the parking lamps are switched on or off automatically depending on the brightness of the ambient light.
- With the engine running: if you have activated the daytime running lamps function via the on-board computer, the daytime running lamps or the low-beam headlamps and parking lamps are switched on or off automatically depending on the brightness of the ambient light.
- To switch on automatic headlamp mode: turn the light switch to AUTO.

### Only for Canada:

The daytime running lamps improve the visibility of your vehicle during the day. The daytime running lamps function is required by law in Canada. It cannot therefore be deactivated.

When the engine is running and the vehicle is stationary: if you move the selector lever from a drive position to **P**, the daytime running lamps/low-beam headlamps go out after three minutes.

When the engine is running, the vehicle is stationary and in bright ambient light: if you

turn the light switch to  $[\bigcirc 0 \subset ]$ , the daytime running lamps and parking lamps switch on. If the engine is running and you turn the light switch to  $[\bigcirc ]$ , the manual settings take precedence over the daytime running lamps.

### USA only:

The daytime running lamps improve the visibility of your vehicle during the day. To do this, the daytime running lamps function must be switched on using the on-board computer ( $\triangleright$  page 203).

If the engine is running and you turn the light switch to  $\boxed{>00c}$  or  $\boxed{\blacksquare0}$ , the manual settings take precedence over the daytime running lamps.

### Low-beam headlamps

## 

When the light switch is set to **Auro**, the lowbeam headlamps may not be switched on automatically if there is fog, snow or other causes of poor visibility due to the weather conditions such as spray. There is a risk of an accident.

In such situations, turn the light switch to  $\square$ .

Even if the light sensor does not detect that it is dark, the parking lamps and low-beam headlamps switch on when the ignition is switched on and the light switch is set to the D position. This is a particularly useful function in the event of rain and fog.

- ► To switch on the low-beam headlamps: turn the SmartKey in the ignition lock to position 2 or start the engine.

### Front fog lamps

In conditions where visibility is poor due to fog, snow or rain, the fog lamps improve visibility as well as making it easier for other road users to see you. They can be operated together with the parking lamps or together with the parking lamps and low-beam headlamps.

- To switch on the front fog lamps: turn the SmartKey in the ignition lock to position
   2 or start the engine.
- ► Turn the light switch to 🗊 or **AUTO**.
- Press the 10 button.
   The green 10 indicator lamp in the instrument cluster lights up.
- ► To switch off the front fog lamps: press the ≇D button. The green ≇D indicator lamp in the

instrument cluster goes out.

Only vehicles with front fog lamps have the fog lamps function.

## Rear fog lamp

The rear fog lamp improves visibility of your vehicle for the traffic behind in the event of thick fog. Please take note of the countryspecific regulations for the use of rear fog lamps.

- ► To switch on the rear fog lamps: turn the SmartKey in the ignition lock to position 2 or start the engine.
- ► Turn the light switch to **ID** or **AUTO**.
- Press the <u>0</u><sup>‡</sup> button.
   The yellow <u>0</u><sup>‡</sup> indicator lamp in the instrument cluster lights up.

The yellow <u>I</u> indicator lamp in the instrument cluster goes out.

## Parking lamps

If the battery has been excessively discharged, the parking lamps or standing lamps are automatically switched off to enable the next engine start. Always park your vehicle safely and sufficiently lit according to legal standards. Avoid the continuous use of the <u>→00</u> parking lamps for several hours. If possible, switch on the **P** = + right or the **+P** = left standing lamp. ► **To switch on:** turn the light switch to <u>SOCE</u>.

The green  $\exists x \in T$  indicator lamp in the instrument cluster lights up.


### Standing lamps

Switching on the standing lamps ensures the corresponding side of the vehicle is illuminated.

- ► To switch on the standing lamps: the SmartKey is not in the ignition lock or it is in position **0**.
- ► Turn the light switch to +P≤ (left-hand side of the vehicle) or P≤+ (right-hand side of the vehicle).

### **Combination switch**

### Turn signal



- High-beam headlamps
- Turn signal, right
- ③ High-beam flasher
- ④ Turn signal, left
- To indicate briefly: press the combination switch briefly to the pressure point in the direction of arrow ② or ④. The corresponding turn signal flashes three times.
- ► To indicate: press the combination switch beyond the pressure point in the direction of arrow ② or ④.

## High-beam headlamps

- ► To switch on the high-beam headlamps: turn the SmartKey in the ignition lock to position 2 or start the engine.
- ► Turn the light switch to 🗊 or **AUTO**.
- Press the combination switch beyond the pressure point in the direction of arrow (1).

In the **Auro** position, the high-beam headlamps are only switched on when it is dark and the engine is running.

The *indicator* lamp in the instrument cluster lights up when the high-beam headlamps are switched on.

 To switch off the high-beam headlamps: move the combination switch back to its normal position.

The **D** indicator lamp in the instrument cluster goes out.

## High-beam flasher

- ► To switch on: turn the SmartKey in the ignition lock to position 1 or 2 or start the engine.
- ▶ Pull the combination switch in the direction of arrow ③.

## Hazard warning lamps



► To switch on the hazard warning lamps: press button ①.

All turn signals flash. If you now switch on a turn signal using the combination switch,

only the turn signal lamp on the corresponding side of the vehicle will flash.

► To switch off the hazard warning lamps: press button ①.

The hazard warning lamps automatically switch on if:

- an air bag is deployed
- the vehicle decelerates rapidly from a speed of more than 45mph (70 km/h) and comes to a standstill.

The hazard warning lamps switch off automatically if the vehicle reaches a speed of over 6mph (10km/h) again after a full brake application.

 The hazard warning lamps still operate if the ignition is switched off.

## **Cornering light function**



The cornering light function improves the illumination of the road over a wide angle in the direction you are turning, enabling better visibility in tight bends, for example. The cornering light function can only be activated when the low-beam headlamps are switched on.

### Active:

- if you are driving at speeds below
   25mph (40 km/h) and switch on the turn signal or turn the steering wheel.
- if you are driving at speeds between 25mph (40 km/h) and45mph (70 km/h) and turn the steering wheel

**Not active:** if you are driving at speeds above 25 mph (40 km/h) or switch off the turn signals or turn the steering wheel to the straight-ahead position.

The cornering light function may remain lit for a short time, but is automatically switched off after no more than three minutes.

## **Active light function**





The active light function is a system that moves the headlamps according to the steering movements of the front wheels. In this way, relevant areas remain illuminated while driving. This allows you to recognize pedestrians, cyclists and animals.

Active: when the lights are switched on.

### Adaptive Highbeam Assist

### Important safety notes

### MARNING

Adaptive Highbeam Assist does not recognize road users:

- who have no lights, e.g. pedestrians
- who have poor lighting, e.g. cyclists
- whose lighting is blocked, e.g. by a barrier

In very rare cases, Adaptive Highbeam Assist may fail to recognize other road users that have lights, or may recognize them too late. In this or similar situations, the automatic high-beam headlamps will not be deactivated or activated regardless. There is a risk of an accident.

Always carefully observe the traffic conditions and switch off the high-beam headlamps in good time.

Adaptive Highbeam Assist cannot take into account road, weather or traffic conditions. Adaptive Highbeam Assist is only an aid. You are responsible for adjusting the vehicle's lighting to the prevailing light, visibility and traffic conditions.

In particular, the detection of obstacles can be restricted if there is:

- poor visibility, e.g. due to fog, heavy rain or snow
- dirt on the sensors or the sensors are obscured

### **General notes**



You can use this function to set the headlamps to change between low beam and high beam automatically. The system recognizes vehicles with their lights on, either approaching from the opposite direction or traveling in front of your vehicle, and consequently switches the headlamps from high beam to low beam.

The system automatically adapts the lowbeam headlamp range depending on the distance to the other vehicle. Once the system no longer detects any other vehicles, it reactivates the high-beam headlamps.

The system's optical sensor is located behind the windshield near the overhead control panel.

# Switching Adaptive Highbeam Assist on/off

- ► To activate: activate the Adaptive Highbeam Assist function using the onboard computer (> page 203).
- ► Turn the light switch to **AUTO**.
- ► Press the combination switch beyond the pressure point in the direction of arrow ① (▷ page 110).

The indicator lamp in the multifunction display lights up if it is dark and the light sensor activates the low-beam headlamps.

If you are driving at speeds above approximately 28 mph (45 km/h):

The headlamp range is set automatically depending on the distance between the vehicle and other road users.

If you are driving at speeds above approximately 35 mph (55 km/h) and no other road users have been detected:

The high-beam headlamps are switched on automatically. The <u>ID</u> indicator lamp in the instrument cluster also lights up.

If you are driving at speeds below approximately 30 mph (45 km/h) or other road users have been detected or the roads are adequately lit:

The high-beam headlamps are switched off automatically. The <u>ID</u> indicator lamp in the instrument cluster goes out. The <u>ID</u> indicator lamp in the multifunction display remains lit.

 To deactivate: move the combination switch back to its normal position.
 The indicator lamp in the instrument cluster goes out.

### Headlamps fogged up on the inside

The headlamps may fog up on the inside if there is high atmospheric humidity.

- Switch on the lights and drive off. The level of fogging diminishes, depending on the length of the journey and the weather conditions (humidity and temperature).
- If the level of fogging does not diminish:
- Have the headlamps checked at a qualified specialist workshop.

### **Interior lighting**



Overhead control panel

- ① [ 査] Switches the left-hand reading lamp on/off
- ② Switches the automatic interior lighting control on/off
- ③ A Switches the right-hand reading lamp on/off
- ④ 💮 Switches the interior lighting on/off

### Interior lighting control

### General notes

In order to prevent the vehicle's battery from discharging, the interior lighting functions are automatically deactivated after some time unless the SmartKey is in position **2** in the ignition lock.

The color and brightness of the ambient lighting may be set using the on-board computer ( $\triangleright$  page 203).

### Automatic interior lighting control

To activate/deactivate: press the button.

When the automatic interior lighting control is activated, the button is flush with the overhead control panel.

The interior lighting automatically switches on if you:

- unlock the vehicle
- open a door
- remove the SmartKey from the ignition lock

The interior light is activated for a short while when the SmartKey is removed from the ignition lock. You can activate this delayed switch-off using the on-board computer ( $\triangleright$  page 204).

### Manual interior lighting control

- ► To switch the interior lighting on/off: press the real button.
- ► To switch the reading lamps on/off: press the X button.

### Crash-responsive emergency lighting

The interior lighting is activated automatically if the vehicle is involved in an accident.

 To switch off the crash-responsive emergency lighting: press the hazard warning lamp button.

or

 Lock and then unlock the vehicle using the SmartKey.

### **Replacing bulbs**

### Important safety notes

### Xenon bulbs

## 

Xenon bulbs carry a high voltage. You can get an electric shock if you remove the cover of the Xenon bulb and touch the electrical contacts. There is a risk of fatal injury.

Never touch the parts or the electrical contacts of the Xenon bulb. Always have work on the Xenon bulbs carried out at a qualified specialist workshop.

If your vehicle is equipped with Xenon bulbs, you can recognize this by the following: the cone of light from the Xenon bulbs moves from the top to the bottom and back again when you start the engine. For this to be observed, the lights must be switched on before starting the engine.

Bulbs and lamps are an important aspect of vehicle safety. You must therefore make sure that these function correctly at all times. Have the headlamp setting checked regularly.

### Other bulbs

### MARNING

Bulbs, lamps and connectors can get very hot when operating. If you change a bulb, you could burn yourself on these components. There is a risk of injury.

Allow these components to cool down before changing a bulb.

Do not use a bulb that has been dropped or if its glass tube has been scratched.

The bulb may explode if:

- you touch it
- it is hot
- you drop it
- you scratch it

Only operate bulbs in enclosed lamps designed for that purpose. Only install spare

bulbs of the same type and the specified voltage.

Marks on the glass tube reduce the service life of the bulbs. Do not touch the glass tube with your bare hands. If necessary, clean the glass tube when cold with alcohol or spirit and rub it off with a lint-free cloth.


Protect bulbs from moisture during operation. Do not allow bulbs to come into contact with liquids.

There are bulbs other than the Xenon bulbs that you cannot replace. Replace only the bulbs listed ( $\triangleright$  page 115). Have the bulbs that you cannot replace yourself changed at a qualified specialist workshop.

If you require assistance changing bulbs, consult a qualified specialist workshop.

If the new bulb still does not light up, consult a qualified specialist workshop.

Bulbs and lamps are an important aspect of vehicle safety. You must therefore make sure that these function correctly at all times. Have the headlamp setting checked regularly.




Halogen headlamps

- ① Low-beam headlamp: H7 55 W
- ② High-beam headlamp: H7 55 W
- ③ Turn signal lamp: PY 21 W



Bi-Xenon headlamps
(1) Cornering lamp: H7 55 W



Tail lamp ① Backup lamp: W 16 W

### Changing the front bulbs

## Removing/mounting the cover in the front wheel housing




- ► To remove: switch off the lights.
- ► Turn the front wheels inwards.

## 116 Replacing bulbs

- ▶ Slide cover ① up and remove it.
- ► To install: insert cover ① again and slide down until it engages.

# Low-beam headlamps (halogen headlamps)




- ▶ Remove the cover in the front wheel housing (▷ page 115).
- Turn housing cover ① counter-clockwise and pull it out.
- ▶ Press retainer ② up.
- ▶ Remove connector ③ with the bulb.
- ▶ Pull the bulb out of connector ③.
- Insert the new bulb into connector ③ and into bracket for retainer ②.

Make sure the bulb is positioned correctly.

- Press retainer ② down.
- Attach housing cover ① and turn it clockwise until it engages.
- ▶ Replace the cover in the front wheel housing (▷ page 115).

### High-beam headlamps (halogen headlamps)/cornering lamps (Bi-Xenon headlamps)



- Switch off the lights.
- Open the hood.
- ► Turn housing cover ① counter-clockwise and pull it out.
- At the bulb holder, push the bulb upwards, disconnect it and pull it out of bulb holder (2).
- Insert the new bulb into bulb holder ②, push it down and secure it in place.
- Attach housing cover ① and turn it clockwise until it engages.

## Side marker lamps (halogen headlamps)

Due to their location, have the bulbs in the side marker lamp changed at a qualified specialist workshop.


Turn signals (halogen headlamps)




- Switch off the lights.
- ▶ Open the hood.
- Turn bulb holder ① counter-clockwise and pull it out.
- ► Take the bulb out of bulb holder ①.
- Insert the new bulb into bulb holder ①.
- Insert bulb holder (1) and turn it clockwise until it engages.

## Changing the rear bulbs

### Backup Light



- Switch off the lights.
- Make sure that the roof is closed.
- Open the trunk.
- ▶ Turn and pull out buffer stop ②.
- ▶ Unclip catch ① for side paneling ③.



- Reach upwards into side paneling ③, loosen and pull downwards until holder ④ of the backup lamp is easily accessible.
- ▶ Pull out bulb holder ④.
- ▶ Pull out the bulb.
- ▶ Insert the new bulb into bulb holder ④.
- ▶ Insert holder ④ until it engages.
- ▶ re-install side paneling ③ precisely.
- ▶ Clip in catch ① for side paneling ③.
- ▶ Push in and tighten buffer stop ②.

## Windshield wipers


Switching the windshield wipers on/ off

Do not operate the windshield wipers when the windshield is dry, as this could damage the wiper blades. Moreover, dust that has collected on the windshield can scratch the glass if wiping takes place when the windshield is dry.

If it is necessary to switch on the windshield wipers in dry weather conditions, always use washer fluid when operating the windshield wipers.

If the windshield wipers leave smears on the windshield after the vehicle has been washed in an automatic car wash, wax or other residues may be the reason for this. Clean the windshield using washer fluid after washing the vehicle in an automatic car wash. Intermittent wiping with rain sensor: due to optical influences and the windshield becoming dirty in dry weather conditions, the windshield wipers may be activated inadvertently. This could then damage the windshield wiper blades or scratch the windshield.

For this reason, you should always switch off the windshield wipers in dry weather.



Combination switch

- 1 0 Windshield wiper off
- 2 ••• Intermittent wipe, low (rain sensor set to low sensitivity)
- 3 ••••• Intermittent wipe, high (rain sensor set to high sensitivity)
- 4 Continuous wipe, slow
- 5 Continuous wipe, fast
- Single wipe/ To wipe the windshield using washer fluid
- Switch on the ignition.
- Turn the combination switch to the corresponding position.

In the ••• or ••• position, the appropriate wiping frequency is set automatically according to the intensity of the rain. In the •••• position, the rain sensor is more sensitive than in the ••• position, causing the windshield wipers to wipe more frequently.

If the wiper blades are worn, the windshield will no longer be wiped properly. This could prevent you from observing the traffic conditions, thereby causing an accident. Replace the wiper blades twice a year, ideally in spring and fall.

### Replacing the wiper blades

### Important safety notes

#### 

If the windshield wipers begin to move while you are changing the wiper blades, you could be trapped by the wiper arm. There is a risk of injury.

Always switch off the windshield wipers and ignition before changing the wiper blades.

- To avoid damaging the wiper blades, make sure that you touch only the wiper arm of the wiper.
- Never open the hood if a windshield wiper arm has been folded away from the windshield.

Never fold a windshield wiper arm without a wiper blade back onto the windshield.

Hold the windshield wiper arm firmly when you change the wiper blade. If you release the windshield wiper arm without a wiper blade and it falls onto the windshield, the windshield may be damaged by the force of the impact.

Mercedes-Benz recommends that you have the wiper blades changed at a qualified specialist workshop.


Always position the windshield wiper arms vertically before folding them away from the windshield. By doing so, you will avoid damage to the hood.

### Replacing the wiper blades

### Removing the wiper blades


- ► Turn the SmartKey to position 1 or 2 in the ignition lock.
- Set the windshield wipers to position \_\_\_\_.

- When the wiper arms have reached a vertical position, turn the SmartKey to position **0** and remove it from the ignition lock.
- Fold the windshield wiper arms away from the windshield.



- ▶ Press both release clips ②.
- ► Fold wiper blade ① in the direction of arrow ③ away from wiper arm ④.
- Remove wiper blade (1) in the direction of arrow (5).

### Installing the wiper blades



- Position new wiper blade 1 with recess 6 on lug 5.
- Fold wiper blade ① in the direction of arrow ③ onto the wiper arm, until retaining clips ② engage in bracket ④.
- Make sure that wiper blade 1 is seated correctly.
- Fold the wiper arm back onto the windshield.

Problem	Possible causes/consequences and Solutions
The windshield wipers are jammed.	<ul> <li>Leaves or snow, for example, may be obstructing the windshield wiper movement. The wiper motor has been deactivated.</li> <li>For safety reasons, you should remove the SmartKey from the ignition lock.</li> <li>or</li> <li>Switch off the engine using the Start/Stop button and open the driver's door.</li> <li>Remove the cause of the obstruction.</li> <li>Switch the windshield wipers back on.</li> </ul>
The windshield wipers fail completely.	<ul> <li>The windshield wiper drive is malfunctioning.</li> <li>Select another wiper speed on the combination switch.</li> <li>Have the windshield wipers checked at a qualified specialist workshop.</li> </ul>
The windshield washer fluid from the spray nozzles no longer hits the center of the windshield.	<ul> <li>The spray nozzles are misaligned.</li> <li>► Have the spray nozzles adjusted at a qualified specialist workshop.</li> </ul>

Useful information	122
Overview of climate control sys-	
tems	122
Operating the climate control sys-	
tems	127
Setting the air vents	134

### **Useful information**

- This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- I Read the information on qualified specialist workshops: (▷ page 24).

### **Overview of climate control systems**

#### Important safety notes

Observe the settings recommended on the following pages. The windows could otherwise fog up.

To prevent the windows from fogging up:

- switch off climate control only briefly
- switch on air-recirculation mode only briefly
- switch on the cooling with air dehumidification function
- switch on the defrost windshield function briefly, if required


Climate control regulates the temperature and the humidity in the vehicle interior and filters undesirable substances out of the air.

Climate control can only be operated when the engine is running. Optimum operation is only achieved with the side windows and roof closed.

The residual heat function can only be activated or deactivated with the ignition switched off ( $\triangleright$  page 133).


When the weather is warm, ventilate the vehicle for a brief period. This will speed up the cooling process and the desired vehicle interior temperature will be reached more quickly.  The integrated filter can filter out most particles of dust, and completely filters out pollen. A clogged filter reduces the amount of air supplied to the vehicle interior. For this reason, you should always observe the interval for replacing the filter, which is specified in the Maintenance Booklet. As it depends on environmental conditions, e.g. heavy air pollution, the interval may be shorter than stated in the Maintenance Booklet.

## Air-conditioning system control panel



### Canada only

- ① Sets the temperature ( $\triangleright$  page 129)
- ② Activates/deactivates the residual heat function (▷ page 133)
- ③ Sets the air distribution ( $\triangleright$  page 130)
- (4) Defrosts the windshield ( $\triangleright$  page 131)
- ⑤ Activates/deactivates cooling with air dehumidification (▷ page 127)
- ⑥ Activates/deactivates air-recirculation mode (▷ page 133)
- $\bigcirc$  Sets the airflow ( $\triangleright$  page 130)
- ⑧ Switches the rear window defroster on/off (▷ page 131)



### USA only

- ① Sets the temperature ( $\triangleright$  page 129)
- ② Switches maximum cooling MAX COOL on/off (▷ page 131)

## 124 Overview of climate control systems

- ③ Sets the air distribution ( $\triangleright$  page 130)
- (4) Defrosts the windshield ( $\triangleright$  page 131)
- ⑤ Activates/deactivates cooling with air dehumidification (▷ page 127)
- ⑥ Activates/deactivates air-recirculation mode (▷ page 133)
- ⑦ Sets the airflow ( $\triangleright$  page 130)
- ⑧ Switches the rear window defroster on/off (▷ page 131)

## Notes on using the air-conditioning system


### Air-conditioning system

Below, you can find a number of notes and recommendations to help you use the airconditioning system optimally.

- Switch on climate control using the <u>A/c</u> button. The indicator lamp in the <u>A/c</u> button lights up.
- Set the temperature to 72 °F (22 °C).
- Recommendation for air distribution in winter: set the *r,i* and *r,i* settings.
   Recommendation for air distribution in summer: set the *r,i* setting.
- Only use the "Windshield defrosting" function briefly until the windshield is clear again.
- Only use air-recirculation mode briefly, e.g. if there are unpleasant outside odors or when in a tunnel. The windows could otherwise fog up, since no fresh air is drawn into the vehicle in air-recirculation mode.

## ECO start/stop function


During automatic engine switch-off, the ECO start/stop function only operates at a reduced capacity. If you require full climate control capacity, the ECO start/stop function can be deactivated by pressing the ECO button ( $\triangleright$  page 145).



## Control panel for dual-zone automatic climate control

### Canada only

- ① To set the temperature, left ( $\triangleright$  page 129)
- ② To defrost the windshield ( $\triangleright$  page 131)
- ③ To switch the ZONE function on/off
- ④ To switch cooling with air dehumidification on/off (▷ page 127) To switch the residual heat function on/off (▷ page 133)
- (5) To switch the rear window defroster on/off ( $\triangleright$  page 131)
- (6) To set the temperature, right ( $\triangleright$  page 129)
- ⑦ To activate/deactivate air-recirculation mode (▷ page 133)
- (a) To set the air distribution ( $\triangleright$  page 130)
- ( ) To increase the airflow ( $\triangleright$  page 130)
- (1) To reduce the airflow ( $\triangleright$  page 130)
- (1) To switch climate control on/off ( $\triangleright$  page 127)
- ② To set climate control to automatic (▷ page 129)



### USA only

- (1) To set the temperature, left ( $\triangleright$  page 129)
- (2) To defrost the windshield ( $\triangleright$  page 131)
- ③ To switch maximum cooling on/off (▷ page 131)
- ④ To switch cooling with air dehumidification on/off ( $\triangleright$  page 127)
- (5) To switch the rear window defroster on/off ( $\triangleright$  page 131)
- (6) To set the temperature, right ( $\triangleright$  page 129)
- ⑦ To activate/deactivate air-recirculation mode (▷ page 133)
- ⑧ To set the air distribution (▷ page 130)
- ( ) To increase the airflow ( $\triangleright$  page 130)
- (1) To reduce the airflow ( $\triangleright$  page 130)
- (1) To switch climate control on/off ( $\triangleright$  page 127)
- ⑦ To set climate control to automatic (▷ page 129)

## Information about using dual-zone automatic climate control

### Automatic climate control

The following contains instructions and recommendations to enable you to get the most out of your automatic climate control.

- Activate climate control using the Auro and  $\boxed{A/C}$  buttons or the  $\boxed{A/C}$  button on the control panel of the climate control. The indicator lamps in the Auro and  $\boxed{A/C}$ buttons or the  $\boxed{A/C}$  button light up.
- Set the temperature to 72 °F (22 °C).

- Only use the "Windshield defrosting" function briefly until the windshield is clear again.
- Only use air-recirculation mode briefly, e.g. if there are unpleasant outside odors or when in a tunnel. The windows could otherwise fog up, since no fresh air is drawn into the vehicle in air-recirculation mode.
- Use the ZONE function to adopt the temperature settings on the driver's side for the front-passenger side as well. The indicator lamp in the ZONE button goes out.
- Use the residual heat function if you want to heat or ventilate the vehicle interior

when the ignition is switched off. The residual heat function can only be activated or deactivated with the ignition switched off.

### ECO start/stop function

During automatic engine switch-off, the ECO start/stop function only operates at a reduced capacity. If you require full climate control capacity, the ECO start/stop function can be deactivated by pressing the ECO button ( $\triangleright$  page 145).

## Operating the climate control systems

Switching climate control on/off

### General notes

When the climate control is switched off, the air supply and air circulation are also switched off. The windows could fog up. Therefore, switch off climate control only briefly

 Activate climate control primarily using the **▲uto** button (▷ page 129).

### Air-conditioning system

- ► Turn the SmartKey to position **2** in the ignition lock (▷ page 139).
- ► To activate: turn airflow control ⑦ clockwise to the desired position (except position 0) (> page 123).
- ► To deactivate: turn airflow control ⑦ counter-clockwise to position
   O(▷ page 123).

### Dual-zone automatic climate control

- ► Turn the SmartKey to position **2** in the ignition lock (▷ page 139).
- To switch on: press the Auro button. The indicator lamp in the Auro button lights up. Airflow and air distribution are set to automatic mode.

or

- ▶ Press the **OFF** button.
  - The indicator lamp in the **OFF** button goes out. The previously selected settings are restored.
- ► To switch off: press the OFF button. The indicator lamp in the OFF button lights up.

## Activating/deactivating cooling with air dehumidification

### General notes

If you deactivate the "Cooling with airdehumidification" function, the air inside the vehicle will not be cooled. The air inside the vehicle will also not be dehumidified. The windows can fog up more quickly. Therefore, deactivate the cooling with airdehumidification function only briefly.

The "Cooling with air dehumidification" function is only available when the engine is running. The air inside the vehicle is cooled and dehumidified according to the temperature selected.

Condensation may drip from the underside of the vehicle when it is in cooling mode. This is normal and not a sign that there is a malfunction. ► To activate: press the A/C or A/C button. The indicator lamp in the A/C or A/C REAT

button lights up.
 ► To deactivate: press the A/C or A/C NET

button.

The indicator lamp in the A/C or A/C button goes out. The "Cooling with air dehumidification" function has a delayed switch-off feature.

Problems with the "Cooling with	air dehumidification" function
---------------------------------	--------------------------------

Problem	Possible causes/consequences and Solutions
The indicator lamp in the $\boxed{A/C} / \boxed{A/C}$ button flashes three times or remains off. The "Cooling with air dehumidification" function cannot be switched on.	<ul> <li>Cooling with air dehumidification has been deactivated due to a malfunction.</li> <li>Visit a qualified specialist workshop.</li> </ul>

### Setting climate control to automatic

### General notes

In automatic mode, the set temperature is maintained automatically at a constant level. The system automatically regulates the temperature of the dispensed air, the airflow and the air distribution.

The automatic mode functions optimally when the "Cooling with air dehumidification" function is activated. If necessary, cooling with air dehumidification can be deactivated.

If you deactivate the "Cooling with airdehumidification" function, the air inside the vehicle will not be cooled. The air inside the vehicle will also not be dehumidified. The windows can fog up more quickly. Therefore, deactivate the cooling with airdehumidification function only briefly.

## Activating/switching

- ► Turn the SmartKey to position **2** in the ignition lock (▷ page 139).
- ► Set the desired temperature.
- ► To activate: press the <u>Auro</u> button. The indicator lamp in the <u>Auro</u> button lights up. Automatic air distribution and airflow are activated.

► To switch to manual mode: press the

or

Press the solution or solution. The indicator lamp in the Auro button goes out.

### Setting the temperature

### Air-conditioning system

- ► Turn the SmartKey to position **2** in the ignition lock (▷ page 139).
- ► To increase/reduce: turn control ① clockwise or counter-clockwise (▷ page 123).

Only change the temperature setting in small increments. Start at 72 °F (22 °C).

### Dual-zone automatic climate control

Different temperatures can be set for the driver's and front-passenger sides.

- ► Turn the SmartKey to position **2** in the ignition lock (▷ page 139).
- ► To increase/reduce: turn control ① or
   ⑥ clockwise or counter-clockwise
   (▷ page 125).

Only change the temperature setting in small increments. Start at 72 °F (22 °C).

### Air-conditioning system

- ► Turn the SmartKey to position 2 in the ignition lock (▷ page 139).
- Press one or more of the بنا, بنا,
   الله buttons.

The corresponding indicator lamp lights up briefly.

The following air distribution settings can be selected:

- Directs air through the defroster vents
- Directs air through the footwell air vents
- Directs air through the center and side air vents
- You can also activate several air distribution settings simultaneously. To do this, press multiple air distribution buttons. The air is then directed through various vents.

### Dual-zone automatic climate control

- ► Turn the SmartKey to position 2 in the ignition lock (▷ page 139).
- Press the just button repeatedly until the desired symbol appears in the display.

The following air distribution settings can be selected:

- Directs air through the center and side air vents
- Directs air through the footwell air vents
- rip → Directs air through the center, side and footwell vents
- Directs air through the defroster vents
- Directs the airflow through the defroster, center and side air vents<sup>2</sup>

- Directs air through the defroster and footwell vents
- Directs the airflow through the defroster, center, side and footwell air vents<sup>3</sup>
- Regardless of the air distribution setting, airflow is always directed through the side air vents. You can only close the side air vents, by fully closing the adjuster on the side air vents (▷ page 135).

### Setting the airflow

### Air-conditioning system

- ► Turn the SmartKey to position 2 in the ignition lock (▷ page 139).
- ► To increase/reduce: turn control ⑦ clockwise or counter-clockwise (▷ page 123).

### Dual-zone automatic climate control

- ► Turn the SmartKey to position **2** in the ignition lock (▷ page 139).

### Switching the ZONE function on/off

This function is only available with dual-zone automatic climate control on vehicles for Canada.

- ► To switch on: press the ZONE button. The indicator lamp in the ZONE button lights up. The temperature setting for the driver's side is not adopted for the front-passenger side.
- ► To switch off: press button ZONE. The indicator lamp in the ZONE button goes out. The temperature setting for the

**Climate control** 

- <sup>2</sup> Canada only.
- <sup>3</sup> Canada only.

driver's side is adopted for the frontpassenger side.

### Defrosting the windshield

You can use this function to defrost the windshield or to defrost the inside of the windshield and the side windows.

Switch off the "Windshield defrosting" function as soon as the windshield is clear again.

- ► Turn the SmartKey to position **2** in the ignition lock (▷ page 139).
- ► To activate: press the max button. The indicator lamp in the max button lights up.

The climate control system switches to the following functions:

- high airflow
- high temperature
- air distribution to the windshield and front side windows
- air-recirculation mode off
- ► To deactivate: press the max button. The indicator lamp in the max button goes out. The previously selected settings are restored. Air-recirculation mode remains deactivated.

or

▶ Press the **AUTO** button.

The indicator lamp in the www button goes out. Airflow and air distribution are set to automatic mode.

### MAX COOL maximum cooling

The MAX COOL function is only available in vehicles for the USA.

MAX COOL is only operational when the engine is running.

- ► **To activate:** press the M button. The indicator lamp in the button lights up.
- ► **To activate:** press off-road button 🗱 again.

The indicator lamp goes out. The previously selected settings are restored.

When you activate MAX COOL, climate control switches to the following functions:

- maximum cooling
- maximum airflow
- · air-recirculation mode on

### Defrosting the windows

### Windows fogged up on the inside

- Activate the A/C / A/C cooling with air dehumidification function.
- ► Activate automatic mode **AUTO**.
- ► If the windows continue to fog up, activate the max "Windshield defrosting" function.
- You should only select this setting until the windshield is clear again.

### Windows fogged up on the outside

- Activate the windshield wipers.
- Press the just button repeatedly until the just or just symbol appears in the display.
- You should only select this setting until the windshield is clear again.

### **Rear window defroster**

#### General notes

The rear window defroster has a high current draw. You should therefore switch it off as soon as the rear window is clear. Otherwise, the rear window defroster switches off automatically after several minutes.

If the battery voltage is too low, the rear window defroster may switch off.

### Activating/deactivating

- ► Turn the SmartKey to position **2** in the ignition lock (> page 139).
- Press the press the press the press button.
   The indicator lamp in the press button lights up or goes out.

### Problems with the rear window defroster

Problem	Possible causes/consequences and ► Solutions
The indicator lamp on the Imperial button	The on-board voltage is too low because too many electrical consumers are switched on.
flashes. The rear window defroster has deactivated prematurely or cannot be activated.	<ul> <li>Switch off any consumers that are not required, e.g. reading lamps, interior lighting or the seat heating.</li> <li>When the battery is sufficiently charged, the rear window defroster can be activated again.</li> </ul>
be activated.	<ul> <li>The roof is open.</li> <li>Close the roof.</li> <li>When the roof is closed, the rear window defroster can be activated again.</li> </ul>

### Activating/deactivating airrecirculation mode

### General notes

If you switch on air-recirculation mode, the windows can fog up more quickly, in particular at low temperatures. Only use airrecirculation mode briefly to prevent the windows from fogging up.

### Activating/deactivating

- ► Turn the SmartKey to position 2 in the ignition lock (▷ page 139).
- ▶ To activate: press the button. The indicator lamp in the button lights up.
- Air-recirculation mode is automatically activated at high levels of pollution or at high outside temperatures. When airrecirculation mode is activated automatically, the indicator lamp in the button is not lit.

Outside air is added after about 30 minutes.

► To deactivate: press the S button. The indicator lamp in the S button goes out.  Air-recirculation mode deactivates automatically:

- after approximately five minutes at outside temperatures below approximately 41 °F (5 °C)
- after approximately five minutes if cooling with air dehumidification is deactivated
- after approximately 30 minutes at outside temperatures above approximately 41 °F (5 °C) if the "Cooling with air dehumidification" function is activated

## Activating/deactivating the residual heat function

#### General notes

The residual heat function is only available on vehicles for Canada.

It is possible to make use of the residual heat of the engine to continue heating the stationary vehicle for up to 30 minutes after the engine has been switched off. The heating time depends on the temperature that has been set. Depending on the equipment level, the control panel has either the **REST** button or the  $\left[\frac{A/C}{\text{HEGT}}\right]$  button.

### Activating/deactivating

- ► Turn the SmartKey to position **0** in the ignition lock or remove it (▷ page 139).
- ► To activate: press the REST or A/C BEST button.

The indicator lamp in the **REST** or  $\begin{bmatrix} A/C \\ REST \end{bmatrix}$  button lights up.

- **1** The blower will run at a low speed regardless of the airflow setting.
- If you activate the residual heat function at high temperatures, only the ventilation will be activated. The blower runs at medium speed.
- ► To deactivate: press the REST or A/C REST button.

The indicator lamp in the **REST** or  $\begin{bmatrix} A/C \\ KGT \end{bmatrix}$  button goes out.

Residual heat is deactivated automatically:

- after approximately 30 minutes
- when the ignition is switched on
- · if the battery voltage drops

### Setting the air vents

### Important safety notes

### MARNING

Very hot or very cold air can flow from the air vents. This could result in burns or frostbite in the immediate vicinity of the air vents. There is a risk of injury.

Make sure that all vehicle occupants always maintain a sufficient distance to the air outlets. If necessary, redirect the airflow to another area of the vehicle interior.

## MARNING


When AIRSCARF is switched on, very hot air can flow from the vents in the head restraints.

This could result in burns in the immediate vicinity of the air vents. There is a risk of injury. Reduce the heater output before it becomes too hot.

In order to ensure the direct flow of fresh air through the air vents into the vehicle interior, please observe the following notes:

- keep the air inlet grille on the hood and in the engine compartment on the frontpassenger side free of blockages, such as ice, snow or leaves.
- never cover the air vents or air intake grilles in the vehicle interior.
- You can move the adjusters for the air vents vertically or horizontally to set the direction of the airflow.
- For optimal climate control in the vehicle, open the air vents completely and set the adjusters to the central position.

### Setting the center air vents



- ► To open the center air vent: turn the adjuster in one of center air vents ① counter-clockwise.
- ► To close the center air vent: turn the adjuster in one of center air vents ① clockwise until it engages.

## Setting the side air vents



- ① Side window defroster vent
- Side air vent
- To open a side air vent: turn the adjuster in side air vent ② counter-clockwise.
- ► To close a side air vent: turn the adjuster in side air vent ② clockwise until it engages.

## Setting the blower output of the AIRSCARF vents

## 


Very hot or very cold air can flow from the air vents. This could result in burns or frostbite in the immediate vicinity of the air vents. There is a risk of injury.

Make sure that all vehicle occupants always maintain a sufficient distance to the air outlets. If necessary, redirect the airflow to another area of the vehicle interior.

## 

When AIRSCARF is switched on, very hot air can flow from the vents in the head restraints. This could result in burns in the immediate vicinity of the air vents. There is a risk of injury.

Reduce the heater output before it becomes too hot.



You can adjust the blower output of AIRSCARF vents (1) using the AIRSCARF button ( $\triangleright$  page 100).

Useful information	138
Notes on breaking-in a new vehicle	138
Driving	138
Manual transmission	148
Automatic transmission	149
Refueling	156
Parking	159
Driving tips	162
Driving systems	167

### **Useful information**

This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.

**1** Read the information on qualified specialist workshops: ( $\triangleright$  page 24).

### Notes on breaking-in a new vehicle

#### Important safety notes

New and replaced brake pads and discs only reach their optimum braking effect after several hundred kilometers of driving. Compensate for this by applying greater force to the brake pedal.

### The first 1000 miles (1500 km)

The more you look after the engine when it is new, the more satisfied you will be with its performance in the future.

- You should therefore drive at varving vehicle and engine speeds for the first 1,000 miles (1,500 km).
- Avoid heavy loads, e.g. driving at full throttle, during this period.
- Change gear in good time, before the tachometer needle is  $\frac{2}{3}$  of the way to the red area of the tachometer.
- Do not manually shift to a lower gear to brake the vehicle.

Vehicles with automatic transmission:

- Ideally, for the first 1,000 miles (1,500 km), drive in program **C**.
- If possible, do not depress the accelerator pedal past the point of resistance (kickdown).

After 1,000 miles (1,500 km), you can increase the engine speed gradually and bring the vehicle to full speed.

Additional breaking-in notes for AMG vehicles:

- Do not drive faster than 85 mph (140 km/h) for the first 1,000 miles (1,500 km).
- Only allow the engine to reach a maximum engine speed of 4,500 rpm briefly.
- Change gear in good time.
- 1 You should also observe these notes on breaking in if the engine or parts of the drive train on your vehicle have been replaced.
- Always observe the respective speed limits.

### AMG vehicles with self-locking rear axle differential

Your vehicle is equipped with a self-locking differential on the rear axle. To protect the differential on the rear axle, carry out an oil change after a breaking-in phase of 2,000 miles (3,000 km). This oil change prolongs the service life of the differential. Have the oil change carried out at a qualified specialist workshop. Mercedes-Benz recommends that you use an authorized Mercedes-Benz Center for this purpose.

### Driving

#### Important safety notes

### **WARNING**

Objects in the driver's footwell can restrict the pedal travel or obstruct a depressed pedal. The operating and road safety of the vehicle is jeopardized. There is a risk of an accident. Make sure that all objects in the vehicle are stowed correctly, and that they cannot enter the driver's footwell. Install the floormats securely and as specified in order to ensure sufficient clearance for the pedals. Do not use loose floormats and do not place floormats on top of one another.

### 

Unsuitable footwear can hinder correct usage of the pedals, e.g.:

- shoes with thick soles
- shoes with high heels
- slippers

There is a risk of an accident.

Wear suitable footwear to ensure correct usage of the pedals.

## 

If you switch off the ignition while driving, safety-relevant functions are only available with limitations, or not at all. This could affect, for example, the power steering and the brake boosting effect. You will require considerably more effort to steer and brake. There is a risk of an accident.

Do not switch off the ignition while driving.

## 

If the parking brake has not been fully released when driving, the parking brake can:

- overheat and cause a fire
- lose its hold function.

There is a risk of fire and an accident. Release the parking brake fully before driving off.

Warm up the engine quickly. Do not use the engine's full performance until it has reached operating temperature.


Only shift the automatic transmission to the desired drive position when the vehicle is stationary.

Where possible, avoid spinning the drive wheels when pulling away on slippery roads. You could otherwise damage the drive train.

AMG vehicles: at low engine oil temperatures below 68 °F (+20 °C), the maximum engine speed is restricted in order to protect the engine. To protect the engine and maintain smooth engine operation, avoid driving at full throttle when the engine is cold.

## **Key positions**

### SmartKey



- To remove the SmartKey
   Vehicles with automatic transmission: shift the transmission to position P
- 1 Power supply for some consumers, such as the windshield wipers
- 2 Ignition (power supply for all consumers) and drive position
- 3 To start the engine
- The SmartKey can be turned in the ignition lock even if it is not the correct SmartKey for the vehicle. The ignition is not switched on. The engine cannot be started.

## **KEYLESS-GO**

### General notes

Vehicles with KEYLESS-GO are equipped with a SmartKey featuring an integrated KEYLESS-GO start function and a detachable Start/ Stop button.

You can switch the engine on and off with the Start/Stop button. The Start/Stop button must be inserted in the ignition lock and the SmartKey must be in the vehicle.

Pressing the Start/Stop button several times in succession corresponds to the different

SmartKey positions in the ignition lock. This is only the case if you are not depressing the brake pedal.

If you depress the brake pedal and press the Start/Stop button, the engine starts immediately.

The Start/Stop button can be removed from the ignition lock. Then, you can insert the SmartKey into the ignition lock.

• You do not have to remove the Start/Stop button from the ignition lock when you leave the vehicle. You should, however, always take the SmartKey with you when leaving the vehicle. As long as the SmartKey is in the vehicle:

- the vehicle can be started using the Start/Stop button and
- electrically powered equipment can be operated.
- The engine can be turned off while the vehicle is in motion by pressing and holding the Start/Stop button for approximately three seconds. This function operates independently of the ECO start/stop automatic engine switch-off function.

## Key positions with KEYLESS-GO



- ① Start/Stop button
- Ignition lock
- Insert Start/Stop button (1) into ignition lock (2).
- When you insert Start/Stop button (1) into ignition lock (2), the system needs approximately two seconds recognition

time. You can then use Start/Stop button ①.



Start/Stop button

- ③ USA only
- ④ Canada only

If Start/Stop button ① has not yet been pressed, this corresponds to the SmartKey being removed from the ignition.

- To switch on the power supply: press Start/Stop button ① once. The power supply is switched on. You can now activate the windshield wipers, for example.
- If you then open the driver's door when in this position, the power supply is deactivated.
- To switch on the ignition: press Start/ Stop button ① twice. The ignition is switched on.
- The power supply is switched off if you press Start/Stop button (1) twice when in this position and the driver's door is open.

As soon as the ignition is switched on, all the indicator lamps in the instrument cluster light up. If an indicator lamp does not go out after starting the engine or lights up while driving, there may be a technical problem ( $\triangleright$  page 242).

### Removing the Start/Stop button



You can remove the Start/Stop button from the ignition lock and start the vehicle as normal using the SmartKey.

- Remove Start/Stop button ① from ignition lock ②.
- You do not have to remove the Start/Stop button from the ignition lock when you leave the vehicle.

### Starting the engine

#### Important safety notes

### MARNING

If children are left unsupervised in the vehicle, they could:

- open the doors, thus endangering other people or road users.
- get out and disrupt traffic.
- operate the vehicle's equipment.

Additionally, children could set the vehicle in motion if, for example, they:

- release the parking brake.
- shift the automatic transmission out of parking position P.
- shift the manual transmission into neutral.
- starting the engine.

There is a risk of an accident and injury.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children or animals unattended in the vehicle. Always keep the SmartKey out of reach of children.

## 

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Inhaling these exhaust gases leads to poisoning. There is a risk of fatal injury. Therefore never leave the engine running in enclosed spaces without sufficient ventilation.

## 

Flammable materials introduced through environmental influence or by animals can ignite if in contact with the exhaust system or parts of the engine that heat up. There is a risk of fire.

Carry out regular checks to make sure that there are no flammable foreign materials in the engine compartment or in the exhaust system.

- Do not depress the accelerator pedal when starting the engine.
- **1** AMG vehicles: the exhaust flap of the exhaust system will be checked after every cold start. A resulting noise can be heard during this process.
- During a cold start, the engine runs at higher speeds to enable the catalytic converter to reach its operating temperature. The sound of the engine may change during this time.

### Manual transmission

- Depress the brake pedal and keep it depressed.
- ► Fully depress the clutch pedal.
- ► Shift to neutral N.
- You can only start the engine when the clutch pedal is fully depressed.

## Automatic transmission

 Shift the transmission to position P. The transmission position display in the multifunction display shows P.

**1** You can also start the engine when the transmission is in position **N**.

## Starting procedure with the SmartKey

- ► Turn the SmartKey to position **3** in the ignition lock (▷ page 139) and release it as soon as the engine is running.
- To start the engine using the SmartKey instead of KEYLESS-GO, pull the Start/ Stop button out of the ignition lock.

## Using KEYLESS-GO to start the engine

- The Start/Stop button can be used to start the vehicle manually without inserting the SmartKey into the ignition lock. The Start/Stop button must be inserted in the ignition lock and the SmartKey must be in the vehicle. This mode for starting the engine operates independently of the ECO start/stop automatic engine start function.
- Depress the brake pedal and keep it depressed.
- Press the Start/Stop button once (> page 139).
   The engine starts.

## Pulling away

## Manual transmission

- Change gear in good time and avoid spinning the wheels. You could otherwise damage the vehicle.
- Depress the brake pedal and keep it depressed.
- ► Fully depress the clutch pedal.
- ► Shift to either first gear or reverse gear **R**.

- Release the electric parking brake (> page 160).
- Release the brake pedal.
- Slowly release the clutch pedal and gently depress the accelerator pedal.
- 1 The vehicle locks centrally once you have pulled away. The locking knobs in the doors drop down.

You can open the doors from the inside at any time.

You can also deactivate the automatic locking feature ( $\triangleright$  page 205).

## Automatic transmission

## 

If the engine speed is above the idling speed and you engage transmission position  ${\bf D}$  or  ${\bf R}$ , the vehicle could pull away suddenly. There is a risk of an accident.

When engaging transmission position **D** or **R**, always firmly depress the brake pedal and do not simultaneously accelerate.

- 1 It is only possible to shift the transmission from position **P** to the desired position if you depress the brake pedal. Only then is the shift lock released.
- Depress the brake pedal and keep it depressed.
- ► Shift the transmission to position **D** or **R**.
- Release the brake pedal.
- ► Carefully depress the accelerator pedal. The electric parking brake (▷ page 160) is automatically released.

The red **PARK** (USA only) or (**(D)** (Canada only) indicator lamp in the instrument cluster goes out.

The vehicle locks centrally once you have pulled away. The locking knobs in the doors drop down.

You can open the doors from the inside at any time.

You can also deactivate the automatic locking feature ( $\triangleright$  page 205).

Upshifts take place at higher engine speeds after a cold start. This helps the catalytic converter to reach its operating temperature more quickly.

## Hill start assist

Hill start assist helps you when pulling away forwards or in reverse on an uphill gradient. It holds the vehicle for a short time after you have removed your foot from the brake pedal. This gives you enough time to move your foot from the brake pedal to the accelerator pedal and to depress it before the vehicle begins to roll.

## MARNING

After a short time, hill start assist will no longer brake your vehicle and it could roll away. There is a risk of an accident and injury.

Therefore, quickly move your foot from the brake pedal to the accelerator pedal. Never leave the vehicle when it is held by hill start assist.

- Remove your foot from the brake pedal. The vehicle is then held for about a second.
- Pull away.

Hill start assist is not active if:

- you are pulling away on a level road or on a downhill gradient.
- $\bullet$  on vehicles with automatic transmission, the transmission is in  $\ensuremath{\text{N}}.$
- the electric parking brake is applied.
- ESP<sup>®</sup> is malfunctioning.

## ECO start/stop function

#### Introduction

The ECO start/stop function switches the engine off automatically if the vehicle is stopped under certain conditions.

The engine starts automatically when the driver wants to pull away again. The ECO start/stop function thereby helps you to reduce the fuel consumption and emissions of your vehicle.

## Important safety notes

## 

If the engine is switched off automatically and you exit the vehicle, the engine is restarted automatically. The vehicle may begin moving. There is a risk of accident and injury.

If you wish to exit the vehicle, always turn off the ignition and secure the vehicle against rolling away.

#### General notes



① ECO start/stop display

If the **ECO** symbol is shown in green in the multifunction display, the ECO start/stop function switches the engine off automatically if the vehicle stops moving.

Every time you switch on the engine using the SmartKey or the Start/Stop button, the ECO start/stop function is activated.

If the ECO start/stop function has been manually deactivated ( $\triangleright$  page 145) or a malfunction has caused the system to be deactivated, the **ECO** symbol is not displayed.

**AMG vehicles:** the ECO start/stop function is only available in drive program **C**.

**()** AMG vehicles: if automatic cylinder shutoff is active in drive program **C**, the number of active cylinders **4** is also shown in the **ECO** symbol. This means that the engine is operating with four cylinders.

# 144 Driving

If cylinder shut-off is not active, the engine will operate with all eight cylinders. In this case, the number of active cylinders  $\mathbf{8}$  is shown in the **ECO** symbol.

# Automatic engine switch-off

## Method of operation

The ECO start/stop function is operational and the  $\boxed{\text{ECO}}$  symbol is displayed in green in the multifunction display, if:

- the indicator lamp in the ECO button is lit green.
- the outside temperature is within the comfort range.
- the engine is at normal operating temperature.
- the set temperature for the vehicle interior has been reached.
- the battery is sufficiently charged.
- the system detects that the windshield is not fogged up when the air-conditioning system is switched on.
- the hood is closed.
- the driver's door is closed and the driver's seat belt is fastened.

If not all conditions for automatic engine switch-off are fulfilled, the **ECO** symbol is shown in yellow.

 All of the vehicle's systems remain active when the engine has been stopped automatically.

# All vehicles (apart from AMG)

**vehicles):** automatic engine switch-off can take place a maximum of four times consecutively (initial stop then repeated three times). The  $\boxed{\text{ECO}}$  symbol is shown in yellow in the multifunction display after the engine has been started automatically for the fourth time. When the  $\boxed{\text{ECO}}$  symbol is shown in green in the multifunction display, automatic engine switch-off is again possible.

- **1** AMG vehicles: times which the engine can be automatically switched off.
- The HOLD function can be activated if the engine has been switched off automatically. It is then not necessary to continue applying the brakes during the automatic stop phase. When you depress the accelerator pedal, the engine starts automatically and the braking effect of the HOLD function is deactivated.

## Vehicles with manual transmission



The ECO start/stop function switches off the engine automatically at low speeds.

- Brake the vehicle.
- Engage neutral N (follow gearshift instruction ① to engage neutral N, if necessary).
- Release the clutch pedal.
   The engine is switched off automatically.

## Vehicles with automatic transmission

If the vehicle is braked to a standstill in **D** or **N**, the ECO start/stop function switches off the engine automatically.

# Automatic engine start

## Method of operation

The engine starts automatically if:

- you switch off the ECO start/stop function by pressing the ECO button.
- you engage reverse gear R.
- $\bullet$  you switch to drive program  ${\bf S}$  or  ${\bf M}$  (AMG vehicles).
- you unfasten your seat belt or open the driver's door.
- the vehicle starts to roll.

**Driving and parking** 

- the brake system requires this.
- the temperature in the vehicle interior deviates from the set range.
- the system detects moisture on the windshield when the air-conditioning system is switched on.
- the charge level of the battery is too low.

### Vehicles with manual transmission

Only engage gear when the clutch pedal is depressed.

The engine is started automatically if you:

- fully depress the clutch pedal.
- depress the accelerator pedal.

#### Vehicles with automatic transmission

The engine is started automatically if you:

- release the brake pedal when HOLD is not activated and the transmission is in position D or N.
- depress the accelerator pedal.
- $\bullet$  move the transmission out of position  ${\bf P}.$
- **1** Shifting the transmission to position **P** does not start the engine.
- If you shift the transmission from R to D, the ECO start/stop function is available again once the ECO symbol reappears in green in the multifunction display.

## Deactivating/activating the ECO start/ stop function



ECO button

#### Deactivating (except for AMG vehicles)

 Press button ①.
 Indicator lamp ② and the ECO symbol in the multifunction display go out.

## Activating (except for AMG vehicles)

Press button ①.
 Indicator lamp ② lights up.

If all conditions for automatic engine switch-off ( $\triangleright$  page 144) are fulfilled, the **ECO** symbol is shown in green in the multifunction display.

If not all conditions for automatic engine switch-off ( $\triangleright$  page 144) are fulfilled, the **ECO** symbol is shown in yellow in the multifunction display. If this is the case, the ECO start/stop function is not available.

#### Deactivating (AMG vehicles)

▶ Press button ① in drive program **C**.

or

Switch to drive program S or M
 (> page 151).
 Indicator lamp (2) and the ECO symbol in the multifunction display go out.

### Activating (AMG vehicles)

Press button ①.

Indicator lamp ② lights up. If drive program **S** or **M** is active, the automatic transmission switches to drive program **C**.

If all conditions for automatic engine switch-off ( $\triangleright$  page 144) are fulfilled, the **ECO** symbol is shown in green in the multifunction display.

If not all conditions for automatic engine switch-off ( $\triangleright$  page 144) are fulfilled, the **ECO** symbol is shown in yellow in the multifunction display. If this is the case, the ECO start/stop function is not available.

If indicator lamp ② is off, the ECO start/ stop function has been deactivated manually or as the result of a malfunction. The engine will then not be switched off automatically when the vehicle stops. **1** All vehicles (except AMG vehicles): the ECO start/stop function is activated each time the engine is switched on.

(1) AMG vehicles: each time the engine is started, the ECO start/stop function switches to the status (on or off) that was selected before switching off the engine.

**Driving and parking** 

# Problems with the engine

Problem	Possible causes/consequences and Solutions
The engine does not start.	► Try to start the engine again.
The engine does not start. The starter motor can be heard.	<ul> <li>There is a malfunction in the engine electronics.</li> <li>There is a malfunction in the fuel supply.</li> <li>Turn the SmartKey back to position <b>0</b> in the ignition lock before attempting to start the engine again.</li> <li>or</li> <li>Press the Start/Stop button repeatedly until all indicator lamps in the instrument cluster go out.</li> <li>Try to start the engine again (▷ page 141). Avoid excessively long and frequent attempts to start the engine, as this will drain the battery.</li> <li>If the engine does not start after several attempts:</li> <li>Consult a qualified specialist workshop.</li> </ul>
The engine does not start. You cannot hear the starter motor.	<ul> <li>The on-board voltage is too low because the battery is too weak or discharged.</li> <li>Jump-start the vehicle (▷ page 298).</li> <li>If the engine does not start despite attempts to jump-start it:</li> <li>Consult a qualified specialist workshop.</li> </ul>
	<ul> <li>The starter motor was exposed to a thermal load that was too high.</li> <li>Allow the starter motor to cool down for approximately two minutes.</li> <li>Try to start the engine again.</li> <li>If the engine still does not start:</li> <li>Consult a qualified specialist workshop.</li> </ul>
The engine is not running smoothly and is misfiring.	<ul> <li>There is a malfunction in the engine electronics or in a mechanical component of the engine management system.</li> <li>Only depress the accelerator pedal slightly. Otherwise, non-combusted fuel may get into the catalytic converter and damage it.</li> <li>Have the cause rectified immediately at a qualified specialist workshop.</li> </ul>

# Problem

The coolant temperature display is showing more than 248 °F (120 °C). The coolant warning lamp may also be lit and a warning tone may sound.

#### Possible causes/consequences and Solutions

The coolant level is too low. The coolant is too hot and the engine is no longer being cooled sufficiently.

- Stop as soon as possible and allow the engine and the coolant to cool down.
- ► Check the coolant level (▷ page 277). Observe the warning notes as you do so and add coolant if necessary.

If the coolant level is correct, the engine radiator fan may be faulty. The coolant is too hot and the engine is no longer being cooled sufficiently.

- ► At coolant temperatures below 248 °F (120 °C), drive to the next qualified specialist workshop.
- Avoid heavy loads on the engine as you do so, e.g. driving in mountainous terrain and stop-and-go traffic.

### Manual transmission

#### Gear lever

- Only engage gear when the clutch pedal is depressed.
- When shifting between **5th** and **6th** gear, you should always push the gear lever all the way to the right. You could otherwise shift unintentionally into **3rd** or **4th** gear and damage the transmission.

If you shift down at too high a speed (transmission braking), this can cause the engine to overrev, leading to engine damage.

Never hold the vehicle stopped on a hill by using the clutch pedal. There is otherwise a risk of damaging the clutch.



Gear lever

R Reverse gear

1 to 6 Forward gears

#### Engaging reverse gear

- Only shift into reverse gear **R** when the vehicle is stationary. Otherwise, you could damage the transmission.
- Stop the vehicle.
- Depress the clutch pedal fully.
- Shift to neutral N.
- Move the gear lever firmly to the left beyond the point of resistance and then forwards.

The ECO start/stop function is not available when reverse gear is engaged. Further information on the ECO start/stop function (▷ page 143).



 Shift gear according to gearshift recommendation (1) when shown in the multifunction display of the instrument cluster.

The gearshift recommendations assist you in adopting an economical driving style. The recommended gear is shown in the multifunction display.

# Automatic transmission

Important safety notes

## MARNING

If the engine speed is above the idling speed and you engage transmission position  ${\bf D}$  or  ${\bf R}$ , the vehicle could pull away suddenly. There is a risk of an accident.

When engaging transmission position **D** or **R**, always firmly depress the brake pedal and do not simultaneously accelerate.

# MARNING

The automatic transmission switches to neutral position  ${\bf N}$  when you switch off the engine. The vehicle may roll away. There is a risk of an accident.

After switching off the engine, always switch to parking position **P**. Prevent the parked vehicle from rolling away by applying the parking brake.

#### **Selector lever**

#### **Overview of transmission positions**



Selector lever

- P Park position with selector lever lock
- R Reverse gear
- Neutral
- D Drive

# Transmission position and drive program display



- Transmission position display
- Drive program display

The current position of the selector lever is shown by the indicators next to the selector lever.

The indicators light up when the SmartKey is inserted into the ignition lock. The indicators go out when the SmartKey is removed from the ignition lock.

#### Transmission positions

#### P Park position

Do not shift the transmission into position  $P(\triangleright$  page 149) unless the vehicle is stationary. The parking lock should not be used as a brake when parking. Always apply the electronic parking brake in addition to the parking lock in order to secure the vehicle.

The SmartKey can only be removed if the transmission is in position **P**. If the SmartKey is removed from the ignition lock, the selector lever is locked.

If the vehicle electronics are malfunctioning, the selector lever may be locked in position **P**. To release a locked selector lever, see "Manual override of parking lock" (> page 156).

#### Reverse gear

R

Only shift the transmission to **R** when the vehicle is stationary.

#### N Neutral

Do not shift the transmission to **N** while driving. Otherwise, the automatic transmission could be damaged.

No power is transmitted from the engine to the drive wheels.

Releasing the brakes will allow you to move the vehicle freely, e.g. to push it or tow it.

If  $ESP^{\circledast}$  is deactivated or faulty: only shift the transmission to position **N** if the vehicle is in danger of skidding, e.g. on icy roads.

Rolling in neutral **N** can damage the drive train.

# D Drive

The automatic transmission changes gear automatically. All forward gears are available.

## **Changing gear**

The automatic transmission shifts to the individual gears automatically when it is in transmission position **D**. This automatic gearshifting behavior is determined by:

- the selected drive program (▷ page 151)
- the position of the accelerator pedal
- the road speed

#### **Driving tips**

#### Accelerator pedal position

Your style of driving influences how the automatic transmission shifts gear:

- · little throttle: early upshifts
- more throttle: late upshifts

## **Double-clutch function**

When shifting down, the double-clutch function is active regardless of the currently selected drive program. The double-clutch function reduces load change reactions and is conducive to a sporty driving style. The sound generated by the double-clutch function depends on the drive program selected.

## Kickdown

Use kickdown for maximum acceleration.

 Depress the accelerator pedal beyond the pressure point.
 The transmission shifts to a lower gear

depending on the engine speed.

 Ease off the accelerator pedal once the desired speed is reached.
 The automatic transmission shifts back up.

## **Program selector button**

#### **General notes**



Example: program selector button

Press program selector button ① repeatedly until the letter for the desired gearshift program appears in the multifunction display.

The program selector button allows you to choose between different driving characteristics.

 Further information about permanent drive program M (▷ page 153). As well as this permanent drive program  $\mathbf{M}$ , you can also activate temporary drive program  $\mathbf{M}$  (> page 152).

In AMG vehicles, drive program **E** is called drive program **C**.

<b>E</b> Economy <b>C</b> Controlled Efficiency	Comfortable, economical driving
<b>S</b> Sport	Sporty driving style
M Manual	Manual gear shifting

Only change from automatic drive program  ${\bf E}$  or  ${\bf S}$  to manual drive program  ${\bf M}$  when the vehicle is stationary.

- **()** When the engine is started, the automatic transmission always switches to automatic drive program **E** (drive program **C** in AMG vehicles).
- **1** AMG vehicles: when in drive program C and with a small load demand, the engine will automatically only operate with four cylinders. This is the case in city traffic or on a country road, for example. This reduces fuel consumption. Cylinder shutoff is inactive in drive programs S and M, so that the engine will operate with all eight cylinders.
- For further information on the automatic drive program, see (▷ page 152).

### Steering wheel paddle shifters



① Left-hand steering wheel paddle shifter

Right-hand steering wheel paddle shifter

In the manual drive program, you can change gear using the steering wheel paddle shifters or the selector lever ( $\triangleright$  page 152).

Further information about permanent drive program  $\mathbf{M}$  ( $\triangleright$  page 153).

Further information about temporary drive program **M** ( $\triangleright$  page 152).

- The full range of functions for the steering wheel paddle shifters is available only once operating temperature has been reached.
- You can only change gear with the steering wheel paddle shifters when the transmission is in position **D**.

#### Automatic drive program

#### Automatic drive programs E and S

Drive program **E** (drive program **C** on MAG vehicles) is characterized by the following:

- comfort-oriented engine and transmission settings
- optimal fuel consumption resulting from the automatic transmission shifting up sooner
- the vehicle pulling away more gently in forward and reverse gears, unless the accelerator pedal is depressed fully

- increased sensitivity. This improves driving stability on slippery road surfaces, for example
- the automatic transmission shifting up sooner. This results in the vehicle being driven at lower engine speeds and the wheels being less likely to spin

Drive program **S** is characterized by the following:

- · sporty engine and transmission settings
- the vehicle pulling away in first gear
- the automatic transmission shifting up later
- the fuel consumption possibly being higher as a result of the later automatic transmission shift points

#### Manual drive program M

#### General notes

In this drive program, you can briefly change gear yourself by using the steering wheel paddle shifters. The transmission must be in position **D**.

You can activate manual drive program **M** in the **E** and **S** automatic drive programs.

As well as temporary drive program M, you can also activate permanent drive program M(⊳ page 151).

Further information about permanent drive program  $\mathbf{M}(\triangleright$  page 153).

### Activating

- ▶ Shift the transmission to position **D**.
- Pull the left or right steering wheel paddle shifter (> page 152).
   Manual drive program M is temporarily activated. The selected gear and M appear in the multifunction display.

# Upshifting

 Briefly press the selector lever to the right towards D+.

or

- Pull the right-hand steering wheel paddle shifter (> page 152).
   In cases where it is permissible, the automatic transmission shifts up to the next gear.
- If the maximum engine speed on the currently engaged gear is reached and you continue to accelerate, the automatic transmission automatically shifts up in order to prevent engine damage.

## Shift recommendation



The gearshift recommendations assist you in adopting an economical driving style. The recommended gear is shown in the multifunction display.

Shift to recommended gear ② according to gearshift recommendation ① when shown in the multifunction display of the instrument cluster.

# Downshifting

► Briefly press the selector lever to the left towards D-.

or

- Pull the left-hand steering wheel paddle shifter (> page 152).
   In cases where it is permissible, the automatic transmission shifts down to the next gear.
- For maximum acceleration, push the selector lever to the left or pull and hold the left-hand steering wheel paddle shifter until

the transmission shifts to the optimal gear for the current speed.

• If the engine exceeds the maximum engine speed when shifting down, the automatic transmission protects against engine damage by not shifting down.

• Automatic down shifting occurs when coasting.

# Disarming

If you have activated manual drive program **M**, it will remain active for a certain amount of time. Under certain conditions the minimum amount of time is extended, e.g. in the case of lateral acceleration, during an overrun phase or when driving on steep terrain.

If manual drive program **M** has been deactivated, the automatic transmission shifts into the automatic drive program that was last selected, i.e. **E** or **S**.

You can also deactivate manual drive program **M** yourself:

Pull on the right-hand steering wheel paddle shifter and hold it in place (▷ page 152).

or

► Use the lever to switch the transmission position.

or

► Use the program selector button to change the drive program (▷ page 151). Manual drive program M is deactivated. The automatic transmission switches into the automatic drive program that was last selected, i.e. E or S.

# Manual drive program

# **General information**

In this drive program, you can permanently change gear yourself by using the steering wheel paddle shifters. The transmission must be in position **D**. As well as this permanent drive program
 M, you can also activate temporary drive program M(⊳ page 152).

# Switching on the manual drive program

Manual drive program **M** is different from drive program **S** with regard to spontaneity, responsiveness and smoothness of gear changes.

Manual drive program  $\mathbf{M}$  can be selected using the program selector button. You can change gear using the steering wheel paddle shifters or the selector lever in manual drive program  $\mathbf{M}$  if the transmission is in position  $\mathbf{D}$ . The selected gear appears in the multifunction display.

▶ Press the program selector button (▷ page 151) repeatedly until M appears in the multifunction display.

# Upshifting

Briefly press the selector lever to the right towards D+.

or

► Pull the right-hand steering wheel paddle shifter (▷ page 152).

The automatic transmission shifts up to the next gear.

# Shift recommendation



The gearshift recommendations assist you in adopting an economical driving style. The recommended gear is shown in the multifunction display.

 Shift to recommended gear ② according to gearshift recommendation ① when shown in the multifunction display of the instrument cluster.

# AMG vehicles

In manual drive program **M**, the automatic transmission does not shift up automatically even when the engine limiting speed for the current gear is reached. When the engine limiting speed is reached, the fuel supply is cut to prevent the engine from overrevving. Always make sure that the engine speed does not reach the red area of the tachometer. There is otherwise a risk of engine damage.



- ① Gear indicator
- Upshift indicator

Before the engine speed reaches the red area, an upshift indicator will be shown in the multifunction display.

If the color in the speedometer multifunction display changes to red and the UP display message is shown, shift up a gear.

# Downshifting

► Briefly press the selector lever to the left towards D-.

or

▶ Pull the left-hand steering wheel paddle shifter (▷ page 152).

The automatic transmission shifts down to the next gear.

If you brake the vehicle or stop without shifting down, the automatic transmission will shift down to a gear that will allow the vehicle to accelerate or pull away again. • For maximum acceleration, push the selector lever to the left or pull and hold the left-hand steering wheel paddle shifter until the transmission shifts to the optimal gear for the current speed.

## Kickdown

You can also use kickdown for maximum acceleration in manual drive program **M**.

- Depress the accelerator pedal beyond the pressure point. The automatic transmission shifts to a lower gear depending on the engine speed.
- **1** AMG vehicles: it is not possible to use kickdown in manual drive program **M**.

## Switching off the manual drive program

Press the program selector button (> page 151) repeatedly until E (C in AMG vehicles) or S appears in the multifunction display.

# Problems with the transmission

Problem	Possible causes/consequences and Solutions
The transmission has problems shifting gear.	<ul> <li>The transmission is losing oil.</li> <li>Have the transmission checked at a qualified specialist workshop immediately.</li> </ul>
The acceleration ability is deteriorating. The transmission no longer changes gear.	<ul> <li>The transmission is in emergency mode.</li> <li>It is only possible to shift into second gear and reverse gear.</li> <li>Stop the vehicle.</li> <li>Shift the transmission to position P.</li> <li>Switch off the engine.</li> <li>Wait at least ten seconds before restarting the engine.</li> <li>Shift the transmission to position D or R.</li> <li>If D is selected, the transmission shifts into second gear; if R is selected, the transmission shifts into reverse gear.</li> <li>Have the transmission checked at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center, immediately.</li> </ul>

## Releasing the parking lock manually

Do not use any sharp-edged objects to remove the selector lever gaiter from the center console. This could damage the selector lever gaiter.



- ► Apply the electric parking brake.
- Press the frame of selector level gaiter ① together somewhat on the side edge at the back and hold with one hand ②.
- With the other hand, pry off the frame of selector level gaiter (1) with a flat, blunt object (e.g. a screwdriver wrapped in cloth)

at rear edge ③, pulling it up and out at the same time.

Press release button ④ down and simultaneously move the selector lever out of position P.

The selector lever can now be moved freely until it is returned to position **P**.

In the event of an electrical malfunction, it is possible to release the selector lever lock manually to move it out of position **P**. This is the case, for example, if you wish to tow the vehicle away.

# Refueling

#### Important safety notes

# MARNING

Fuel is highly flammable. If you handle fuel incorrectly, there is a risk of fire and explosion.

You must avoid fire, open flames, creating sparks and smoking. Switch off the engine

and, if applicable, the auxiliary heating before refueling.

# MARNING

Fuel is poisonous and hazardous to health. There is a risk of injury.

You must make sure that fuel does not come into contact with your skin, eyes or clothing and that it is not swallowed. Do not inhale fuel vapors. Keep fuel away from children.

If you or others come into contact with fuel, observe the following:

- Wash away fuel from skin immediately using soap and water.
- If fuel comes into contact with your eyes, immediately rinse them thoroughly with clean water. Seek medical assistance without delay.
- If fuel is swallowed, seek medical assistance without delay. Do not induce vomiting.
- Immediately change out of clothing which has come into contact with fuel.

# 

Electrostatic buildup can create sparks and ignite fuel vapors. There is a risk of fire and explosion.

Always touch the vehicle body before opening the fuel filler flap or touching the fuel pump nozzle. Any existing electrostatic buildup is thereby discharged.

Do not use diesel to refuel vehicles with a gasoline engine. Do not switch on the ignition if you accidentally refuel with the wrong fuel. Otherwise, the fuel will enter the fuel system. Even small amounts of the wrong fuel could result in damage to the fuel system and the engine. Notify a qualified specialist workshop and have the fuel tank and fuel lines drained completely.

• Overfilling the fuel tank could damage the fuel system.


- Take care not to spill any fuel on painted surfaces. You could otherwise damage the paintwork.
- Use a filter when refueling from a fuel can. Otherwise, the fuel lines and/or injection system could be blocked by particles from the fuel can.

Do not get into the vehicle again during the refueling process. Otherwise, electrostatic charge could build up again.

If you overfill the fuel tank, fuel could spray out when the fuel pump nozzle is removed. For further information on fuel and fuel quality (> page 344).

## Refueling

## Opening/closing the fuel filler flap



- 1 Fuel filler flap
- ② To insert the fuel filler cap
- ③ Tire pressure table
- ④ Fuel type to be used

The fuel filler flap is unlocked or locked automatically when you open or close the vehicle with the SmartKey or with KEYLESS-GO.

The position of the fuel filler cap is displayed in the instrument cluster. The arrow next to the filling pump indicates the side of the vehicle.

# Opening the fuel filler flap

- ► Switch the engine off.
- ► Remove the SmartKey from the ignition lock.
- KEYLESS-GO: open the driver's door. This corresponds to key position 0: "key removed".
  - The driver's door can be closed again.
- Press the fuel filler flap in marked area (1).
   Fuel filler flap (1) swings up.
- ► Turn the fuel filler flap counter-clockwise and remove it.
- Insert the fuel filler cap into the holder bracket on the inside of filler flap (2).
- Completely insert the filler neck of the fuel pump nozzle into the tank and refuel.
- Only fill the tank until the pump nozzle switches off.
- **1** Do not add any more fuel after the pump stops filling for the first time. Otherwise, fuel could leak out.

# Closing the fuel filler flap

- Place fuel filler cap on the fuel filler neck and turn clockwise until it engages.
- ► Close fuel filler flap ①.
- Close the fuel filler flap before locking the vehicle.
- If you are driving with the fuel filler cap open, the reserve fuel warning lamp flashes. The Check Engine warning lamp may also light up. A message appears in the multifunction display (▷ page 227). For further information on warning and indicator lamps in the instrument cluster, see (▷ page 248).

## Problems with fuel and the fuel tank

Problem	Possible causes/consequences and ► Solutions
Fuel is leaking from the vehicle.	<ul> <li>The fuel line or the fuel tank is faulty.</li> <li>MARNING</li> <li>Risk of explosion or fire.</li> <li>Turn the SmartKey to position <b>0</b> in the ignition lock and remove it immediately (▷ page 139).</li> <li>Do not restart the engine under any circumstances.</li> <li>Consult a qualified specialist workshop.</li> </ul>
The fuel filler flap cannot be opened.	The fuel filler flap is not unlocked. or The SmartKey battery is discharged. ▶ Unlock the vehicle (▷ page 70). or ▶ Unlock the vehicle using the mechanical key (▷ page 72). The fuel filler flap is unlocked, but the opening mechanism is jammed. ▶ Consult a qualified specialist workshop.

## Parking

Important safety notes

# 

Flammable material such as leaves, grass or twigs may ignite if they come into contact with hot parts of the exhaust system or exhaust gas flow. There is a risk of fire.

Park the vehicle so that no flammable materials come into contact with parts of the vehicle which are hot. Take particular care not to park on dry grassland or harvested grain fields.

# 

If you switch off the ignition while driving, safety-relevant functions are only available with limitations, or not at all. This could affect, for example, the power steering and the brake boosting effect. You will require considerably more effort to steer and brake. There is a risk of an accident.

Do not switch off the ignition while driving.

# 

If you leave children unsupervised in the vehicle, they could set it in motion by, for example:

- release the parking brake.
- shift the automatic transmission out of park position **P** or shift manual transmission into neutral.
- start the engine.

In addition, they may operate vehicle equipment and become trapped. There is a risk of an accident and injury.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children unsupervised in the vehicle. Always secure the vehicle correctly against rolling away. Otherwise, the vehicle or its drivetrain could be damaged.

To ensure that the vehicle is secured against rolling away unintentionally:

- the electric parking brake must be applied.
- on vehicles with manual transmission, engage first gear or reverse gear.
- on vehicles with automatic transmission, the transmission must be in position **P** and the SmartKey must be removed from the ignition lock.
- on steep uphill or downhill gradients, turn the front wheels towards the curb.

#### Switching off the engine

#### Important safety notes

## 

The automatic transmission switches to neutral position  $\mathbf{N}$  when you switch off the engine. The vehicle may roll away. There is a risk of an accident.

After switching off the engine, always switch to parking position **P**. Prevent the parked vehicle from rolling away by applying the parking brake.

## Vehicles with manual transmission

- ▶ Shift to either first gear or reverse gear **R**.
- Turn the SmartKey to position 0 in the ignition lock and remove it. The immobilizer is activated.
- ► Apply the electric parking brake.

# Vehicles with automatic transmission

- Apply the electric parking brake.
- ► Shift the transmission to position **P**.

## Using the SmartKey

- Turn the SmartKey to position 0 in the ignition lock and remove it. The immobilizer is activated.
- **1** The SmartKey can only be removed if the transmission is in position **P**.

## Using KEYLESS-GO

- ▶ Press the Start/Stop button (▷ page 139). The engine stops and all the indicator lamps in the instrument cluster go out.
- When the driver's door is closed, this corresponds to key position **1**. When the driver's door is open, this corresponds to key position **0**: "Key removed".

If you try to switch off the engine when the transmission is not in position **P**, a message appears in the multifunction display. A signal sounds.

## **Electric parking brake**

#### General notes

# MARNING

If you leave children unsupervised in the vehicle, they could set it in motion by, for example:

- release the parking brake.
- shift an automatic transmission out of park position **P**.
- shift the manual transmission into neutral.
- start the engine.

They could also operate the vehicle's equipment. There is a risk of an accident and injury.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children unsupervised in the vehicle.

The electric parking brake performs a function test at regular intervals while the engine is switched off. The sounds that can be heard while this is occurring are normal.

## Engaging and releasing manually



► To engage: push handle ①. When the electric parking brake is engaged, the PARK (USA only) or () (Canada only) red indicator lamp lights up in the instrument cluster.

• The electric parking brake can also be applied when the SmartKey is removed.

- **To release:** switch on the ignition.
- Pull handle ①. The red PARK (USA only) or ② (Canada only) indicator lamp in the instrument cluster goes out.
- The electric parking brake can only be released:
  - if the SmartKey is in position 1 in the ignition lock or
  - if the ignition was switched on using the Start/Stop button.

# Applying automatically

The electric parking brake is applied automatically:

- if DISTRONIC PLUS brings the vehicle to a standstill or
- if the HOLD function is keeping the vehicle stationary

In addition, at least one of the following conditions must be fulfilled:

- the engine is switched off.
- the driver's seat belt is not inserted in the belt buckle and the driver's door is open.
- the vehicle is stationary for a lengthy period.

The red **PARK** (USA only) or **()** (Canada only) indicator lamp in the instrument cluster lights up.

## **Releasing automatically**

The electric parking brake is released automatically when all of the following conditions are fulfilled:

- the engine is running.
- the transmission is in position **D** or **R**.
- the driver's seat belt is fastened.
- you depress the accelerator pedal.

If the transmission is in position **R**, the trunk lid must be closed.

If your seat belt is not fastened, the following conditions must be fulfilled to automatically release the electric parking brake:

- the driver's door is closed.
- you have shifted out of P or you have previously driven faster than 2 mph (3 km/h).
- The electric parking brake can only be released automatically on vehicles with automatic transmission.

#### Emergency braking

The vehicle can also be braked during an emergency by using the electric parking brake.

- While driving, push handle ① of the electric parking brake.
- The vehicle is braked for as long as the handle of the electric parking brake is pressed. The longer the electric parking brake handle is depressed, the greater the braking force.

During braking:

- a warning tone sounds
- the Release Parking Brake message appears
- the red **PARK** (USA only) or (Canada only) indicator lamp in the instrument cluster flashes.

When the vehicle has been braked to a standstill, the electric parking brake is engaged.

## Parking the vehicle for a long period

If you leave the vehicle parked for longer than four weeks, the battery may be damaged by exhaustive discharging.

- ► Connecting a trickle charger.
- You can obtain information about trickle chargers from a qualified specialist workshop.

If you leave the vehicle parked for longer than six weeks, the vehicle may suffer damage as a result of lack of use.

 Visit a qualified specialist workshop and seek advice.

# **Driving tips**

## **General notes**

## Important safety notes

# 

If you switch off the ignition while driving, safety-relevant functions are only available with limitations, or not at all. This could affect, for example, the power steering and the brake boosting effect. You will require considerably more effort to steer and brake. There is a risk of an accident.

Do not switch off the ignition while driving.

# 

If you operate mobile communication equipment while driving, you will be distracted from traffic conditions. You could also lose control of the vehicle. There is a risk of an accident.

Only operate this equipment when the vehicle is stationary.

Observe the legal requirements for the country in which you are driving. Some jurisdictions prohibit the driver from using a mobile phone while driving a vehicle.

If you make a call while driving, always use hands-free mode. Only operate the telephone when the traffic situation permits. If you are unsure, pull over to a safe location and stop before operating the telephone.

Bear in mind that at a speed of only 30 mph (approximately 50 km/h), the vehicle covers a distance of 44 ft (approximately 14 m) per second.

# Drive sensibly - save fuel

Observe the following tips to save fuel:

- The tires should always be inflated to the recommended tire pressure.
- Remove unnecessary loads.
- Warm up the engine at low engine speeds.
- Avoid frequent acceleration or braking.
- Observe the service intervals in the Maintenance Booklet or in the service interval display. Have all the maintenance work carried in accordance with Daimler AG regulations.

Fuel consumption also increases when driving in cold weather, in stop-start traffic and in hilly terrain.

# Drinking and driving

# MARNING

Drinking and driving and/or taking drugs and driving are very dangerous combinations. Even a small amount of alcohol or drugs can affect your reflexes, perceptions and judgment.

The possibility of a serious or even fatal accident is greatly increased when you drink or take drugs and drive.

Do not drink or take drugs and drive or allow anyone to drive who has been drinking or taking drugs.

## **Emission control**

# 

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Inhaling these exhaust gases leads to poisoning. There is a risk of fatal injury. Therefore never leave the engine running in enclosed spaces without sufficient ventilation.

Certain engine systems are designed to keep the level of poisonous components in exhaust fumes within legal limits.

These systems only work at peak efficiency if they are serviced exactly in accordance with the manufacturer's specifications. All work on the engine must be carried out only by qualified and authorized Mercedes-Benz technicians.

The engine settings must not be changed under any circumstances. Furthermore, all specific service work must be carried out at regular intervals and in accordance with the Mercedes-Benz service requirements. Details can be found in the Maintenance Booklet. The ECO display gives you information on how economical your driving style is. The ECO display assists you in achieving the optimum driving style in terms of consumption, taking the actual and selected conditions into consideration. Your driving style can significantly influence the vehicle's consumption.

The ECO display consists of three bars:

- Acceleration
- Constant
- Coasting

The percent value is the average value of the three bars. The three bars and the mean value begin at the value of 50 %. A higher percentage indicates a more economical driving style.

The ECO display does not indicate the actual fuel consumption and a fixed percentage count in the ECO display does not indicate a fixed consumption figure.

Apart from driving style, consumption is dependent on many factors such as, e.g.:

- load
- tire pressure
- cold start
- choice of route
- electrical consumers switched on

These factors are not taken into consideration by the ECO display. The evaluation of your driving style is carried

out using the following three categories:

## **ECO display**



Example: ECO display

# 164 Driving tips

- Acceleration (evaluation of all acceleration processes):
  - The bar fills up: moderate acceleration, especially at higher speeds
  - The bar empties: sporty acceleration
- Constant (assessment of driving behavior at all times):
  - The bar fills up: constant speed and avoidance of unnecessary acceleration and deceleration
  - The bar empties: fluctuations in speed
- Coasting (assessment of all deceleration processes):
  - The bar fills up: anticipatory driving, keeping your distance and early release of the accelerator. The vehicle can coast without use of the brakes.
  - The bar empties: frequent braking
- An economical driving style specially requires driving at moderate engine speeds.

To achieve a higher value in the categories Acceleration and Constant:

- observe the gearshift recommendations.
- drive in drive program **E** (vehicles with an automatic transmission).

On long journeys at a constant speed, e.g. on the highway, only the bar for Constant will change.

 The ECO display summaries the driving characteristics from the start of the journey to its completion. For this reason, the bars change dynamically at the beginning of the journey. On longer journeys, there are fewer changes. For more dynamic changes, carry out a manual reset.

Further information on the ECO display (▷ page 196).

## Braking

# Important safety notes

# 

If you shift down on a slippery road surface in an attempt to increase the engine's braking effect, the drive wheels could lose their grip. There is an increased danger of skidding and accidents.

Do not shift down for additional engine braking on a slippery road surface.

# Downhill gradients

On long, steep gradients, you must reduce the load on the brakes. To use engine braking, shift to a lower gear in good time. This helps you to avoid overheating the brakes and wearing them out excessively.

When making use of the engine braking effect, it is possible that a drive wheel may not turn for some time, e.g. in the case of suddenly changing or slippery road surface conditions. This could cause damage to the drive train. This type of damage is not covered by the Mercedes-Benz warranty.

Change into a lower gear in good time on long and steep downhill gradients. This is especially important if the vehicle is laden.

# Heavy and light loads

# MARNING

If you rest your foot on the brake pedal while driving, the braking system can overheat. This increases the stopping distance and can even cause the braking system to fail. There is a risk of an accident.

Never use the brake pedal as a footrest. Never depress the brake pedal and the accelerator pedal at the same time.

Depressing the brake pedal constantly results in excessive and premature wear to the brake pads.

If the brakes have been subjected to a heavy load, do not stop the vehicle immediately, but drive on for a short while. This allows the airflow to cool the brakes more quickly.

# Wet roads

If you have driven for a long time in heavy rain without braking, there may be a delayed reaction from the brakes when braking for the first time.

This may also occur after driving through water deep enough to wet brake components.

You have to depress the brake pedal more firmly. Maintain a greater distance from the vehicle in front.

After driving on a wet road or having the vehicle washed, brake firmly while paying attention to the traffic conditions. This will warm up the brake discs, thereby drying them more quickly and protecting them against corrosion.

## Limited braking performance on salttreated roads

If you drive on salted roads, a layer of salt residue may form on the brake discs and brake pads. This can result in a significantly longer braking distance.

- Brake occasionally to remove any possible salt residue. Make sure that you do not endanger other road users when doing so.
- Carefully depress the brake pedal and the beginning and end of a journey.
- Maintain a greater distance to the vehicle ahead.

# High performance and ceramic brake system for AMG vehicles

The high-performance brake system is installed only on the SLK 55 AMG.

The AMG brake systems are designed for heavy loads. This may lead to noise when braking. This will depend on:

- speed
- braking force
- ambient conditions, e.g. temperature and humidity

The wear of individual components of the brake system, such as the brake pads/linings or brake discs, depends on the individual driving style and operating conditions.

For this reason, it is impossible to state a mileage that will be valid under all circumstances. An aggressive driving style will lead to high wear. You can obtain more information on this from a qualified specialist workshop.

New and replaced brake pads and discs only reach their optimum braking effect after several hundred kilometers of driving. Compensate for this by applying greater force to the brake pedal. Keep this in mind, and adapt your driving and braking accordingly during this break-in period.

Excessive heavy braking results in correspondingly high brake wear. Observe the brake system warning lamp in the instrument cluster and note any brake status messages in the multifunction display. For high-performance driving in particular, it is important to maintain and have the brake system checked regularly.

# Servicing the brakes

If the red brake warning lamp lights up in the instrument cluster and you hear a warning tone while the engine is running, the brake fluid level may be too low. Observe additional warning messages in the multifunction display.

The brake fluid level may be too low due to brake pad wear or leaking brake lines.

Have the brake system checked immediately. This work should be carried out at a qualified specialist workshop. As the ESP<sup>®</sup> system operates automatically, the engine and the ignition must be switched off (SmartKey in position **0** or **1** in the ignition lock) if the electric parking brake is being tested on a brake dynamometer (maximum 10 seconds).

Braking triggered automatically by ESP<sup>®</sup> may seriously damage the brake system.

All checks and maintenance work on the brake system must be carried out at a qualified specialist workshop. Have this work carried out at an authorized Mercedes-Benz Center.

Have the brake pads replaced and the brake fluid renewed at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.

If the brake system has only been subject to moderate loads, you should test the functionality of your brakes at regular intervals. To do so, press firmly on the brake pedal when driving at a high speed. This improves the grip of the brake pads.

A description of Brake Assist (BAS): (▷ page 60)

Mercedes-Benz recommends that you only have brake pads/linings installed on your vehicle which have been approved for Mercedes-Benz vehicles or which correspond to an equivalent quality standard. Brake pads/linings which have not been approved for Mercedes-Benz vehicles or which are not of an equivalent quality could affect your vehicle's operating safety.

Mercedes-Benz recommends that you only use brake fluid that has been specially approved for your vehicle by Mercedes-Benz, or which corresponds to an equivalent quality standard. Brake fluid which has not been approved for Mercedes-Benz vehicles or which is not of an equivalent quality could affect your vehicle's operating safety.

## Driving on wet roads

## Hydroplaning

If water has accumulated to a certain depth on the road surface, there is a danger of hydroplaning occurring, even if:

- you drive at low speeds.
- the tires have adequate tread depth.

For this reason, in the event of heavy rain or in conditions in which hydroplaning may occur, you must drive in the following manner:

- lower your speed.
- avoid ruts.
- brake carefully.

# Driving on flooded roads

Do not drive through flooded areas. Check the depth of any water before driving through it. Drive slowly through standing water. Otherwise, water may enter the vehicle interior or the engine compartment. This can damage the electronic components in the engine or the automatic transmission. Water can also be drawn in by the engine's air suction nozzles and this can cause engine damage.

# Winter driving

# Important safety notes

# 

If you shift down on a slippery road surface in an attempt to increase the engine's braking effect, the drive wheels could lose their grip. There is an increased danger of skidding and accidents.

Do not shift down for additional engine braking on a slippery road surface.

# 

If the exhaust pipe is blocked or adequate ventilation is not possible, poisonous gases

such as carbon monoxide (CO) may enter the vehicle. This is the case, e.g. if the vehicle becomes trapped in snow. There is a risk of fatal injury.

If you leave the engine or the auxiliary heating running, make sure the exhaust pipe and area around the vehicle are clear of snow. To ensure an adequate supply of fresh air, open a window on the side of the vehicle that is not facing into the wind.

Have your vehicle winterproofed at a qualified specialist workshop at the onset of winter.

Observe the notes in the "Winter operation" section (▷ page 308).

## Driving with summer tires

Observe the notes in the "Winter operation" section (▷ page 308).

## Slippery road surfaces

# MARNING

If you shift down on a slippery road surface in an attempt to increase the engine's braking effect, the drive wheels could lose their grip. There is an increased danger of skidding and accidents.

Do not shift down for additional engine braking on a slippery road surface.

If the vehicle threatens to skid or cannot be stopped when moving at low speed:

- Vehicles with manual transmission: shift to neutral.
- ► Vehicles with automatic transmission: shift the transmission to position N.

Drive particularly carefully on slippery road surfaces. Avoid sudden acceleration, steering and braking maneuvers. Do not use cruise control.

The outside temperature indicator is not designed to serve as an ice-warning device and is therefore unsuitable for that purpose. Changes in the outside temperature are displayed after a short delay. Indicated temperatures just above the freezing point do not guarantee that the road surface is free of ice. The road may still be icy, especially in wooded areas or on bridges. You should pay special attention to road conditions when temperatures are around the freezing point.

● For more information on driving with snow chains, see (▷ page 309).

#### **Driving systems**

# Cruise control

#### General notes

Cruise control maintains a constant road speed for you. It brakes automatically in order to avoid exceeding the set speed. On long and steep downhill gradients, especially if the vehicle is laden, you must select a lower gear in good time. By doing so, you will make use of the braking effect of the engine. This relieves the load on the brake system and prevents the brakes from overheating and wearing too quickly.

Use cruise control only if road and traffic conditions make it appropriate to maintain a steady speed for a prolonged period. You can store any road speed above 20 mph (30 km/h).


## Important safety notes

If you fail to adapt your driving style, cruise control can neither reduce the risk of an accident nor override the laws of physics. Cruise control cannot take into account the road, traffic and weather conditions. Cruise control is only an aid. You are responsible for the distance to the vehicle in front, for vehicle speed, for braking in good time and for staying in lane. Do not use cruise control:

- in road and traffic conditions which do not allow you to maintain a constant speed e.g. in heavy traffic or on winding roads
- on slippery road surfaces. Braking or accelerating could cause the drive wheels to lose traction and the vehicle could then skid
- when there is poor visibility, e.g. due to fog, heavy rain or snow

If there is a change of drivers, advise the new driver of the speed stored.

# **Cruise control lever**



Cruise control lever

- To store the current speed or a higher speed
- ② To store the current speed or calling up the last stored speed
- ③ To store the current speed or a lower speed
- ④ To deactivate cruise control

When you activate cruise control, the stored speed is shown in the status indicator of the multifunction display:

- USA only: e.g. CRUISE 55 Miles
- Canada only: e.g. 🚱 90 Km/h

# Storing, maintaining and calling up a speed

## Storing and maintaining a speed

- Accelerate the vehicle to the desired speed.
- ▶ Briefly press the cruise control lever up (1) or down (4).
- Remove your foot from the accelerator pedal.

Cruise control is activated. The vehicle automatically maintains the stored speed.

You can store the current speed if you are driving faster than 20 mph (30 km/h).

- Cruise control may be unable to maintain the stored speed on uphill gradients. The stored speed is resumed when the gradient evens out. Cruise control maintains the stored speed on downhill gradients by automatically applying the brakes.
- () Vehicles with manual transmission:
  - Always drive at adequate, but not excessive, engine speeds.
  - Change gear in good time.
  - If possible, do not shift down several gears at a time.

# Storing or calling up a speed

# MARNING

If you call up the stored speed and it differs from the current speed, the vehicle accelerates or decelerates. If you do not know the stored speed, the vehicle could accelerate or brake unexpectedly. There is a risk of an accident.

Pay attention to the road and traffic conditions before calling up the stored speed. If you do not know the stored speed, store the desired speed again.

- Briefly pull the cruise control lever toward you ③.
- Remove your foot from the accelerator pedal.

The first time cruise control is activated, it stores the current speed or regulates the speed of the vehicle to the previously stored speed.

# Setting a speed

# **▲ WARNING**


Keep in mind that it may take a brief moment until the vehicle has made the necessary adjustments.

Increase or decrease the set vehicle speed to a value that the prevailing road conditions and legal speed limits permit. Otherwise, sudden and unexpected acceleration or deceleration of the vehicle could cause an accident and/ or serious injury to you and others.

- To adjust the set speed in 1 mph increments (1 km/h increments): briefly press the cruise control lever up ① to the pressure point for a higher speed or down ④ for a lower speed. Every time the cruise control lever is pressed up or down, the last speed stored is increased or reduced.
- To adjust the set speed in 5 mph increments (10 km/h increments): briefly press the cruise control lever up ① past the pressure point for a higher speed or down ④ for a lower speed. Every time the cruise control lever is pressed up or down, the last speed stored is increased or reduced.

Cruise control is not deactivated if you depress the accelerator pedal. For example, if you accelerate briefly to overtake, cruise control adjusts the vehicle's speed to the last speed stored after you have finished overtaking.

# Deactivating cruise control



Cruise control lever

There are several ways to deactivate cruise control:

 Briefly press the cruise control lever forwards ①.

or

Brake.

Cruise control is automatically deactivated if:

- you engage the electric parking brake
- you are driving at less than 20 mph (30 km/h)
- ESP<sup>®</sup> intervenes or you deactivate ESP<sup>®</sup>
- on vehicles with manual transmission, you shift to a gear that is too high, and as a result the engine speed is too low
- you shift the transmission to position N while driving

If cruise control is deactivated, you will hear a warning tone. You will see the Cruise Control Off message in the multifunction display for approximately five seconds.

**1** When you switch off the engine, the last speed stored is cleared.

# **DISTRONIC PLUS**

# General notes

DISTRONIC PLUS regulates the speed and automatically helps you maintain the distance to the vehicle detected in front.

DISTRONIC PLUS brakes automatically so that the set speed is not exceeded.

On long and steep downhill gradients, especially if the vehicle is laden, you must select a lower gear in good time. By doing so, you will make use of the braking effect of the engine. This relieves the load on the brake system and prevents the brakes from overheating and wearing too quickly.

If a slower-moving vehicle is detected in front, DISTRONIC PLUS brakes your vehicle. It maintains the preset distance to the vehicle in front.

If DISTRONIC PLUS detects that there is a risk of a collision, you will be warned visually and acoustically. DISTRONIC PLUS cannot prevent a collision without your intervention. An intermittent warning tone will then sound and the distance warning lamp will light up in the instrument cluster. Brake immediately in order to increase the distance to the vehicle in front or take evasive action provided it is safe to do so.

For DISTRONIC PLUS to assist you, the radar sensor system must be operational.

If there is no vehicle in front, DISTRONIC PLUS operates in the same way as cruise control in the speed range between 20 mph (Canada: 30 km/h) and 120 mph (Canada: 200 km/h). If a vehicle is driving in front of you, it operates in the speed range between 0 mph (0 km/h) and 120 mph (Canada: 200 km/h).

Do not use DISTRONIC PLUS while driving on roads with steep gradients.

As DISTRONIC PLUS transmits radar waves, it can resemble the radar detectors of the responsible authorities. You can refer to the relevant chapter in the Operator's Manual if questions are asked about this.

USA only: This device has been approved by the FCC as a "Vehicular Radar System". The radar sensor is intended for use in an automotive radar system only. Removal, tampering, or altering of the device will void any warranties, and is not permitted by the FCC. Do not tamper with, alter, or use in any non-approved way.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

Canada only: This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and

2. this device must accept any interference received, including interference that may cause undesired operation of the device.

Removal, tampering, or altering of the device will void any warranties, and is not permitted. Do not tamper with, alter, or use in any non-approved way.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

## Important safety notes

## **∧** WARNING

DISTRONIC PLUS does not react to:

- people or animals
- stationary obstacles on the road, e.g. stopped or parked vehicles
- oncoming and crossing traffic

As a result, DISTRONIC PLUS may neither give warnings nor intervene in such situations. There is a risk of an accident.

Always pay careful attention to the traffic situation and be ready to brake.

# 

DISTRONIC PLUS cannot always clearly identify other road users and complex traffic situations.

In such cases, DISTRONIC PLUS may:

- give an unnecessary warning and then brake the vehicle
- neither give a warning nor intervene
- accelerate unexpectedly

There is a risk of an accident.

Continue to drive carefully and be ready to brake, in particular when warned to do so by DISTRONIC PLUS.

# 

DISTRONIC PLUS brakes your vehicle with up to 40% of the maximum braking force. If this braking force is insufficient, DISTRONIC PLUS warns you visually and audibly. There is a risk of an accident.

In such cases, apply the brakes yourself and try to take evasive action.

If DISTRONIC PLUS or the HOLD function is activated, the vehicle brakes automatically in certain situations. To prevent damage to the vehicle, deactivate DISTRONIC PLUS and the HOLD function in the following or other similar situations:

- when towing the vehicle
- in the car wash

If you fail to adapt your driving style, DISTRONIC PLUS can neither reduce the risk of accident nor override the laws of physics. DISTRONIC PLUS cannot take into account the road, traffic and weather conditions. DISTRONIC PLUS is only an aid. You are responsible for the distance to the vehicle in front, for vehicle speed, for braking in good time and for staying in lane.

Do not use DISTRONIC PLUS:

- in road and traffic conditions which do not allow you to maintain a constant speed e.g. in heavy traffic or on winding roads
- on slippery road surfaces. Braking or accelerating could cause the drive wheels to lose traction and the vehicle could then skid
- when there is poor visibility, e.g. due to fog, heavy rain or snow

DISTRONIC PLUS may not detect narrow vehicles driving in front, e.g. motorcycles, or vehicles driving on a different line.

In particular, the detection of obstacles can be impaired if:

- there is dirt on the sensors or anything else covering the sensors
- snow or heavy rain
- interference by other radar sources
- strong radar reflections, for example, in parking garages


If DISTRONIC PLUS no longer detects a vehicle in front, DISTRONIC PLUS may unexpectedly accelerate the vehicle to the stored speed.

This speed may:

- be too high if you are driving in a filter lane or an exit lane
- be so high when driving in the right-hand lane that you overtake vehicles in the lefthand lane
- be so high when driving in the left-hand lane that you overtake vehicles in the right-hand lane

If there is a change of drivers, advise the new driver of the speed stored.

# **Cruise control lever**



Cruise control lever

- To store the current speed or a higher speed
- ② To set the specified minimum distance
- ③ To store the current speed or calling up the last stored speed

- ④ To store the current speed or a lower speed
- 5 To deactivate DISTRONIC PLUS

# Activating DISTRONIC PLUS; storing, maintaining and calling up a speed

## Important safety notes

If DISTRONIC PLUS or the HOLD function is activated, the vehicle brakes automatically in certain situations. To prevent damage to the vehicle, deactivate DISTRONIC PLUS and the HOLD function in the following or other similar situations:

- when towing the vehicle
- in the car wash

In order to activate DISTRONIC PLUS, the following conditions must be fulfilled:

- the engine must be started. It may take up to two minutes after pulling away before DISTRONIC PLUS is operational.
- your vehicle must not be secured by the electric parking brake.
- ESP<sup>®</sup> must be activated.
- the transmission must be in position **D**.
- the hood must be closed.
- the driver's door must be closed when you shift from **P** to **D** or your seat belt must be fastened.
- the front-passenger door must be closed.
- the vehicle must not skid.

## Arming

- Briefly pull the cruise control lever toward you (3), up (1) or down (4).
   DISTRONIC PLUS is selected.
- To adjust the set speed in 1 mph increments (1 km/h increments): briefly press the cruise control lever up (1) to the

pressure point for a higher speed or down ④ for a lower speed. Every time the cruise control lever is pressed up or down, the last speed stored is increased or reduced.

or

- ► To adjust the set speed in 5 mph increments (10 km/h increments): briefly press the cruise control lever up ① past the pressure point for a higher speed or down ④ for a lower speed. Every time the cruise control lever is pressed up or down, the last speed stored is increased or reduced.
- Remove your foot from the accelerator pedal.

Your vehicle adapts its speed to that of the vehicle in front, but only up to the desired stored speed.

When driving at speeds below 20 mph (30 km/h), you can only activate DISTRONIC PLUS if the vehicle in front has been detected and is shown in the multifunction display. If the vehicle in front is no longer detected and displayed, for example because it has changed lanes, DISTRONIC PLUS is deactivated. You will hear a warning tone if this is the case.

If you do not fully release the accelerator pedal, the DISTRONIC PLUS Inactive message appears in the multifunction display. The set distance to a slowermoving vehicle in front will then not be maintained. You will be driving at the speed you determine by the position of the accelerator pedal.

## Pulling away and driving

If you depress the brake, DISTRONIC PLUS is deactivated unless your vehicle is stationary.

- If the vehicle in front pulls away: remove your foot from the brake pedal.
- ▶ Briefly pull the cruise control lever toward you ③.

or

 Accelerate briefly. Your vehicle pulls away and adapts its speed to that of the vehicle in front.

If there is no vehicle in front, DISTRONIC PLUS operates in the same way as cruise control.

If DISTRONIC PLUS detects that the vehicle in front has slowed down, it brakes your vehicle. It maintains the preset distance to the vehicle in front.

If DISTRONIC PLUS detects that there is a risk of a collision, you will be warned visually and acoustically. DISTRONIC PLUS cannot prevent a collision without your intervention. An intermittent warning tone will then sound and the distance warning lamp will light up in the instrument cluster. Brake immediately in order to increase the distance from the vehicle in front, or take evasive action, provided it is safe to do so.

If DISTRONIC PLUS detects a faster-moving vehicle in front, it increases the driving speed. However, the vehicle is only accelerated up to the speed you have stored.

# **Changing lanes**

If you wish to change to the passing lane (in countries where traffic drives on the right, the passing lane is the left-hand lane), DISTRONIC PLUS supports you if:

- you are driving faster than 40 mph (60 km/h)
- DISTRONIC PLUS is maintaining the distance to a vehicle in front
- you have switched on the corresponding turn signal
- DISTRONIC PLUS does not detect a danger of collision

If these conditions are fulfilled, your vehicle is accelerated. Acceleration will be

interrupted if changing lanes takes too long or if the distance between your vehicle and the vehicle in front becomes too small.

# Stopping

# MARNING

When leaving the vehicle, even if it is braked only by DISTRONIC PLUS, it could roll away if:

- there is a malfunction in the system or in the voltage supply.
- DISTRONIC PLUS has been deactivated with the cruise control lever, e.g. by a vehicle occupant or from outside the vehicle.
- the electrical system in the engine compartment, the battery or the fuses have been tampered with.
- the battery is disconnected.
- the accelerator pedal has been depressed, e.g. by a vehicle occupant.

There is a risk of an accident.

If you wish to exit the vehicle, always turn off DISTRONIC PLUS and secure the vehicle against rolling away.

# Deactivating DISTRONIC PLUS (⊳ page 176).

If DISTRONIC PLUS detects that the vehicle in front is stopping, it brakes your vehicle until it is stationary.

Once your vehicle is stationary, it remains stationary and you do not need to depress the brake. After a time, the electric parking brake secures the vehicle and relieves the service brake.

Depending on the specified minimum distance, your vehicle will come to a standstill at a sufficient distance behind the vehicle in front. The specified minimum distance is set using the control on the cruise control lever. The electric parking brake automatically secures the vehicle if DISTRONIC PLUS is activated and:

- the driver's door is open and the driver's seat belt is unfastened.
- the engine is switched off, unless it is automatically switched off by the ECO start/stop function.
- the hood is opened.
- a system malfunction occurs.
- the power supply is not sufficient.

If there is a malfunction in the vehicle electronics, a warning message may also appear in the multifunction display.

# Brake Immediately

Immediately depress the brake firmly until the warning message in the multifunction display goes out. DISTRONIC PLUS is deactivated.

# Shift to 'P'

Shift the transmission to position P to prevent the vehicle from rolling away. DISTRONIC PLUS is deactivated. The warning message in the multifunction display disappears.

The horn will also sound at regular intervals if DISTRONIC PLUS is activated and you:

- switch the engine off, open the driver's door and remove your seat belt.
- open the hood.

The sounding of the horn alerts you to the fact that the vehicle has been parked while DISTRONIC PLUS is still activated. The sound becomes louder if you attempt to lock the vehicle. The vehicle is not locked until DISTRONIC PLUS is deactivated.

 If the engine has been switched off, it cannot be started again until DISTRONIC PLUS has been deactivated.

# Storing the current speed or calling up the last stored speed

# 

If you call up the stored speed and it differs from the current speed, the vehicle accelerates or decelerates. If you do not know the stored speed, the vehicle could accelerate or brake unexpectedly. There is a risk of an accident.

Pay attention to the road and traffic conditions before calling up the stored speed. If you do not know the stored speed, store the desired speed again.

- ▶ Briefly pull the cruise control lever toward you ③.
- Remove your foot from the accelerator pedal.

DISTRONIC PLUS is activated. The first time it is activated, the current speed is stored. Otherwise, it sets the vehicle cruise speed to the previously stored value.

# Setting a speed

Keep in mind that it may take a brief moment until the vehicle has accelerated or braked to the speed set.

- To adjust the set speed in 1 mph increments (1 km/h increments): briefly press the cruise control lever up 1 to the pressure point for a higher speed or down 4 for a lower speed. Every time the cruise control lever is pressed up or down, the last speed stored is increased or reduced.
- To adjust the set speed in 5 mph increments (10 km/h increments): briefly press the cruise control lever up ① past the pressure point for a higher speed or down ④ for a lower speed. Every time the cruise control lever is pressed up or down, the last speed stored is increased or reduced.

## Setting the specified minimum distance

You can set the specified minimum distance for DISTRONIC PLUS by varying the time span between one and two seconds. With this function, you can set the minimum distance that DISTRONIC PLUS keeps to the vehicle in front, dependent on vehicle speed. You can see this distance in the multifunction display ( $\triangleright$  page 175).

Make sure that you maintain a sufficiently safe distance from the vehicle in front. Adjust the distance to the vehicle in front if necessary.



Cruise control lever

- ► To increase: turn control ③ toward ②. DISTRONIC PLUS then maintains a greater distance between your vehicle and the vehicle in front.
- ► To decrease: turn control ③ toward ①. DISTRONIC PLUS then maintains a shorter distance between your vehicle and the vehicle in front.

## DISTRONIC PLUS displays in the instrument cluster

## Displays in the speedometer



**Driving and parking** 

When DISTRONIC PLUS is activated, one or two segments ② in the set speed range light up.

If DISTRONIC PLUS detects a vehicle in front, segments ② between speed of the vehicle in front ① and stored speed ③ light up.

• For design reasons, the speed displayed in the speedometer may differ slightly from the speed set for DISTRONIC PLUS.

# Display when DISTRONIC PLUS is deactivated



- ① Vehicle in front, if detected
- ② Distance indicator, current distance to the vehicle in front
- ③ Specified minimum distance to the vehicle in front; adjustable
- ④ Own vehicle

# 176 Driving systems

 Select the Assistance Graphic function using the on-board computer (> page 200).

In the Assistance menu of the on-board computer, you can also activate or deactivate PRE-SAFE<sup>®</sup> Brake (> page 201).

# Display when DISTRONIC PLUS is activated




- ① Vehicle in front, if detected
- ② Specified minimum distance to the vehicle in front; adjustable
- ③ Own vehicle
- ④ DISTRONIC PLUS activated
- Select the Assistance Graphic function using the on-board computer (> page 200).

You will initially see the stored speed for about five seconds when you activate DISTRONIC PLUS.

## **Deactivating DISTRONIC PLUS**

# 

DISTRONIC PLUS is deactivated and releases the brakes if the vehicle is slowed down to a speed below 20 mph (30km/h) by the system, provided that DISTRONIC PLUS does not detect a vehicle directly in front. At this point, the driver must apply the brakes in order to slow down further and bring the vehicle to a standstill.



#### Cruise control lever

There are several ways to deactivate DISTRONIC PLUS:

 Briefly press the cruise control lever forwards (1).

or

▶ Brake, unless the vehicle is stationary.

When you deactivate DISTRONIC PLUS, you will see the **DISTRONIC** PLUS Off message in the multifunction display for approximately five seconds.

- The last speed stored remains stored until you switch off the engine.
- DISTRONIC PLUS is not deactivated if you depress the accelerator pedal. If you accelerate to overtake, DISTRONIC PLUS adjusts the vehicle's speed to the last speed stored after you have finished overtaking.

DISTRONIC PLUS is automatically deactivated if:

- you engage the electric parking brake or if the vehicle is automatically secured with the electric parking brake
- you are driving slower than 15 mph (25 km/h) and there is no vehicle in front, or if the vehicle in front is no longer detected
- ESP<sup>®</sup> intervenes or you deactivate ESP<sup>®</sup>
- the transmission is in the P, R or N position

the vehicle has skidded


If DISTRONIC PLUS is deactivated, you will hear a warning tone. You will see the DISTRONIC PLUS Off message in the multifunction display for approximately five seconds.

# Tips for driving with DISTRONIC PLUS

# General notes


The following contains descriptions of certain road and traffic conditions in which you must be particularly attentive. In such situations, brake if necessary. DISTRONIC PLUS is then deactivated.

# Cornering, going into and coming out of a bend




The ability of DISTRONIC PLUS to detect vehicles when cornering is limited. Your vehicle may brake unexpectedly or late.

# Vehicles traveling on a different line




DISTRONIC PLUS may not detect vehicles traveling on a different line. The distance to the vehicle in front will be too short.

# Other vehicles changing lanes




DISTRONIC PLUS has not detected the vehicle cutting in yet. The distance to this vehicle will be too short.

## Narrow vehicles




DISTRONIC PLUS has not yet detected the vehicle in front on the edge of the road, because of its narrow width. The distance to the vehicle in front will be too short.

#### **Obstructions and stationary vehicles**



DISTRONIC PLUS does not brake for obstacles or stationary vehicles. If, for example, the detected vehicle turns a corner and reveals an obstacle or stationary vehicle, DISTRONIC PLUS will not brake for these.

#### **Crossing vehicles**



DISTRONIC PLUS may mistakenly detect vehicles that are crossing your lane. Activating DISTRONIC PLUS at traffic lights with crossing traffic, for example, could cause your vehicle to pull away unintentionally.

#### Dynamic handling package

#### General notes



The adjustable damping system adapts to the current driving conditions. The adjustment depends on whether you have selected sport or comfort mode. Your selection remains stored even if you remove the SmartKey from the ignition lock.

# Sports tuning

The firmer setting of the suspension tuning in sports mode ensures even better contact with the road. Select this mode if you want more direct contact with the road when employing a sporty driving style, e.g. on winding country roads.

If indicator lamp (1) is not lit: press button (2).

Indicator lamp ① lights up. You have selected the suspension for a sporty driving style.

## Comfort tuning

Select comfort mode if you prefer a more comfortable driving style.

If indicator lamp (1) is lit: press button (2).

Indicator lamp ① goes out. You have selected the suspension for a comfortable driving style.

# **HOLD** function

### General notes

The HOLD function can assist the driver in the following situations:

- when pulling away, especially on steep slopes
- when maneuvering on steep slopes
- when waiting in traffic

The vehicle is kept stationary without the driver having to depress the brake pedal.

The braking effect is canceled and the HOLD function deactivated when you depress the accelerator pedal to pull away.

### Important safety notes

### MARNING

When leaving the vehicle, it can still roll away despite being braked by the HOLD function if:

- there is a malfunction in the system or in the voltage supply.
- the HOLD function has been deactivated by pressing the accelerator pedal or the brake pedal, e.g. by a vehicle occupant.
- the electrical system in the engine compartment, the battery or the fuses have been tampered with.
- the battery is disconnected

There is a risk of an accident.

If you wish to exit the vehicle, always turn off the HOLD function and secure the vehicle against rolling away.

If DISTRONIC PLUS or the HOLD function is activated, the vehicle brakes automatically in certain situations. To prevent damage to the vehicle, deactivate DISTRONIC PLUS and the HOLD function in the following or other similar situations:

- when towing the vehicle
- in the car wash

Deactivating the HOLD function (> page 179).

### Activation conditions

You can activate the HOLD function if:

- the vehicle is stationary
- the engine is running or if it has been automatically switched off by the ECO start/stop function
- the driver's door is closed or your seat belt is fastened
- the hood is closed.
- the electric parking brake is released
- the selector lever is in position **D**, **R** or **N** on vehicles with automatic transmission
- DISTRONIC PLUS is deactivated

# Activating the HOLD function



- Make sure that the activation conditions are met.
- Depress the brake pedal.
- Quickly depress the brake pedal further until 1HOLD appears in the multifunction display.

The HOLD function is activated. You can release the brake pedal.

**1** If depressing the brake pedal the first time does not activate the HOLD function, wait briefly and then try again.

# Deactivating the HOLD function

The HOLD function is deactivated automatically if:

- you accelerate. On vehicles with automatic transmission: only when the transmission is in position **D** or **R**.
- you shift the transmission to position **P** on vehicles with automatic transmission.

- you apply the brakes again with a certain amount of pressure until HOLD disappears from the multifunction display.
- you secure the vehicle using the electric parking brake.
- you activate DISTRONIC PLUS.
- After a time, the electric parking brake secures the vehicle and relieves the service brake.

The electric parking brake automatically secures the vehicle if the HOLD function is activated and:

- the driver's door is open and the driver's seat belt is unfastened.
- the engine is switched off, unless it is automatically switched off by the ECO start/stop function.
- the hood is opened.
- a system malfunction occurs.
- the power supply is not sufficient.

If there is a malfunction in the vehicle electronics, a warning message may also appear in the multifunction display.

# Brake Immediately

Immediately depress the brake firmly until the warning message in the multifunction display goes out.

The HOLD function is deactivated.

In vehicles with automatic transmission: Shift to 'P'.

Shift the transmission to position P to prevent the vehicle from rolling away. The HOLD function is deactivated. The warning message in the multifunction display disappears.

The horn will also sound at regular intervals if the HOLD function is activated and you:

- switch the engine off, open the driver's door and remove your seat belt.
- open the hood.

The sounding of the horn alerts you to the fact that the vehicle has been parked while the HOLD function is still activated. If you attempt

to lock the vehicle, the tone becomes louder. The vehicle is not locked until the HOLD function is deactivated.

**1** If the engine has been switched off, it cannot be started again until the HOLD function has been deactivated.

### PARKTRONIC

### Important safety notes

PARKTRONIC is an electronic parking aid with ultrasonic sensors. It indicates visually and audibly the distance between your vehicle and an object.

PARKTRONIC is only an aid. It is not a replacement for your attention to your immediate surroundings. You are always responsible for safe maneuvering, parking and exiting a parking space. When maneuvering, parking or pulling out of a parking space, make sure that there are no persons, animals or objects in the area in which you are maneuvering.

When parking, pay particular attention to objects above or below the sensors, such as flower pots or trailer drawbars. PARKTRONIC does not detect such objects when they are in the immediate vicinity of the vehicle. You could damage the vehicle or the objects.

The sensors may not detect snow and other objects that absorb ultrasonic waves.

Ultrasonic sources such as an automatic car wash, the compressed-air brakes on a truck or a pneumatic drill could cause PARKTRONIC to malfunction.

PARKTRONIC may not function correctly on uneven terrain.

PARKTRONIC is activated automatically when you:

- switch on the ignition.
- move the selector lever to position  ${\bf D},\,{\bf R}$  or  ${\bf N}$  on vehicles with automatic transmission.
- release the electric parking brake.

Driving and parking

PARKTRONIC is deactivated at speeds above 11 mph (18km/h). It is reactivated at lower speeds.


PARKTRONIC monitors the area around your vehicle using six sensors in the front bumper and four sensors in the rear bumper.

### Range of the sensors


### **General notes**

PARKTRONIC does not take objects into consideration that are:

- below the detection range, e.g. people, animals or objects
- above the detection range, e.g. overhanging loads, truck overhangs or loading ramps.



(1) Sensors in the front bumper, left-hand side (example)



100 50 0 (cm) 40 20 0 (in) 0 54.65.4266-31

### Top view

The sensors must be free from dirt, ice or slush. They can otherwise not function correctly. Clean the sensors regularly, taking care not to scratch or damage them (> page 283).

### **Front sensors**

Center	Approx. 40in (approx. 100cm)
Corners	Approx. 24in (approx. 60cm)

### Rear sensors

Center	Approx. 48in (approx. 120cm)
Corners	Approx. 32in (approx. 80cm)


### Minimum distance

Center	Approx. 8in (approx. 20cm)
Corners	Approx. 6in (approx. 15cm)

If there is an obstacle within this range, the relevant warning displays light up and a warning tone sounds. If the distance falls below the minimum, the distance may no longer be shown.

Side view

### Warning displays



Warning display for the front area

- Segments on the left-hand side of the vehicle
- ② Segments on the right-hand side of the vehicle
- ③ Segments showing operational readiness

The warning displays show the distance between the sensors and the obstacle. The warning display for the front area is located on the dashboard above the center air vents. The warning display for the rear area is located between the roll bars.

The warning display for each side of the vehicle is divided into five yellow and two red segments. PARKTRONIC is operational if yellow segments showing operational readiness ③ light up.

Manual transmission:

Gear lever position	Warning display
<b>Forwards gear</b> or <b>Neutral</b>	Front area activated
<b>Reverse gear</b> , or the vehicle is rolling backwards	Rear and front areas activated

Automatic transmission:

Transmission position	Warning display
D	Front area activated
<b>R</b> , <b>N</b> or the vehicle is rolling backwards	Rear and front areas activated
Р	No areas activated

One or more segments light up as the vehicle approaches an obstacle, depending on the vehicle's distance from the obstacle. From the:

- sixth segment onwards, you will hear an intermittent warning tone for approximately two seconds.
- seventh segment onwards, you will hear a warning tone for approximately two seconds. This indicates that you have now reached the minimum distance.

# Deactivating/activating PARKTRONIC



- Indicator lamp
- ② To deactivate/activate PARKTRONIC

If indicator lamp ① is on then PARKTRONIC is deactivated. Parking Guidance is also deactivated.

 PARKTRONIC is automatically activated when you turn the SmartKey to position 2 in the ignition lock.

### Problems with PARKTRONIC

Problem	Possible causes/consequences and Solutions
Only the red segments in the PARKTRONIC warning displays are lit. You also hear a warning tone for approximately two seconds. PARKTRONIC is deactivated after approximately 20 seconds, and the indicator lamp in the PARKTRONIC button lights up.	<ul> <li>PARKTRONIC has malfunctioned and has switched off.</li> <li>If problems persist, have PARKTRONIC checked at a qualified specialist workshop.</li> </ul>
Only the red segments in the PARKTRONIC warning displays are lit. PARKTRONIC is deactivated after approximately five seconds.	<ul> <li>The PARKTRONIC sensors are dirty or there is interference.</li> <li>Clean the PARKTRONIC sensors (▷ page 283).</li> <li>Switch the ignition back on.</li> </ul>
	<ul><li>The problem may be caused by an external source of radio or ultrasound waves.</li><li>See if PARKTRONIC functions in a different location.</li></ul>

### **Parking Guidance**

### Important safety notes

Parking Guidance is an electronic parking aid with ultrasound. Ultrasound is used to measure the road on both sides of the vehicle. A suitable parking space is indicated by the parking symbol. You receive steering instructions when parking. You may also use PARKTRONIC (> page 180).

Parking Guidance is only an aid. It is not a replacement for your attention to your immediate surroundings. You are always responsible for safe maneuvering, parking and exiting a parking space. When maneuvering, parking or pulling out of a parking space, make sure that there are no persons, animals or objects in the area in which you are maneuvering.

# MARNING

If objects are located above the detection range, Parking Guidance may provide steering instructions too soon. You may cause a collision as a result. There is a risk of an accident.

If objects are located above the detection range, stop and switch off Parking Assist.

If unavoidable, you should drive over obstacles such as curbs slowly and not at a sharp angle. Otherwise, you may damage the wheels or tires.

When PARKTRONIC is deactivated, Parking Guidance is also unavailable.

Parking Guidance may also display spaces not suitable for parking, e.g.:

- where parking or stopping is prohibited
- in front of driveways or entrances and exits
- on unsuitable surfaces

Use Parking Guidance for parking spaces:


- that are parallel to the direction of travel
- that are on straight roads, not bends
- that are on the same level as the road, i.e. not on the pavement, for example. Parking Guidance may not detect flat curbs

Parking tips:

- On narrow roads, drive as close to the parking space as possible.
- Parking spaces that are littered or overgrown might be identified or measured incorrectly.
- Parking spaces that are partially occupied by trailer drawbars might not be identified as such or be measured incorrectly.
- Snowfall or heavy rain may lead to a parking space being measured inaccurately.
- Pay attention to the PARKTRONIC (▷ page 182) warning messages during the parking procedure.
- When transporting a load which protrudes from your vehicle, you must not use Parking Guidance.
- Never use Parking Guidance with snow chains or an emergency spare wheel mounted.
- Make sure that the tire pressures are always correct. This has a direct effect on the steering instructions.
- The way your vehicle is positioned in the parking space after parking is dependent on various factors. These include the position and shape of the vehicles parked in front and behind it and the conditions of the location. In some cases, Parking Guidance may guide you too far or not far enough into a parking space. In some cases, it may also lead you across or onto

the curb. If necessary, cancel the parking procedure with Parking Guidance.

### **Detecting parking spaces**



- ① Detected parking space on the left
- Parking symbol
- ③ Detected parking space on the right

Parking Guidance is automatically activated when you drive forwards. The system is operational at speeds of up to approximately 22 mph (35 km/h). While in operation, the system independently locates and measures parking spaces on both sides of the vehicle. When driving at speeds below 19 mph (30 km/h), you will see parking symbol (2) as a status indicator in the instrument cluster.

When a parking space has been detected, an arrow towards the right ③ or the left ① also appears. Parking Guidance only displays parking spaces on the front-passenger side as standard. Parking spaces on the driver's side are displayed as soon as the turn signal on the driver's side is activated. To park on the driver's side, you must leave the driver's side turn signal switched on until you have engaged reverse gear.

Parking Guidance will only detect parking spaces:

- that are parallel to the direction of travel
- that are at least 5 ft (1.5 m) wide
- that are at least 4.3 ft (1.3 m) longer than your vehicle

A parking space is displayed while you are driving past it, and until you are approximately 50 ft (15 m) away from it.

### Parking

### Moving the vehicle into the stop position

- Stop the vehicle when the parking space symbol shows the desired parking space in the instrument cluster.
- Vehicles with manual transmission: shift to reverse gear.

Vehicles with automatic transmission: shift into position **R**.

The multifunction display shows the Check Vehicle Surroundings Press 'OK' to Confirm message.



 Press the OK button on the multifunction steering wheel to confirm. The multifunction display switches to Parking Guidance.

Depending on your distance from the parking space, the Please Drive Backward message will appear in the multifunction display.

 If necessary, reverse towards the parking space. This is indicated by an arrow pointing backwards.

Continue backing up until you hear a tone. Stop – the stop position has been reached. The arrow is white.

The Please Steer Wheel to the Right or Please Steer Wheel to the Left message appears in the multifunction display.

#### Backing up into the parking space



- Driving and parking
- While the vehicle is stationary, turn the steering wheel in the specified direction until the arrow is white and a warning tone sounds.
- ► To reverse into the parking space: maintain the steering wheel angle and reverse carefully.
- Stop as soon as you hear a warning tone, The vehicle has reached the position in which you need to countersteer.

The Please Steer Wheel to the Right or Please Steer Wheel to the Left message appears in the multifunction display.

- ► To countersteer: while the vehicle is stationary, turn the steering wheel in the specified direction until the arrow is white and a warning tone sounds.
- ► To reverse into the parking space: maintain the steering wheel angle and reverse carefully.
- Stop as soon as you hear a warning tone, at the latest when PARKTRONIC sounds the continuous warning tone. The Parking Guidance Finished message appears in the multifunction display and a tone sounds. You may be asked to steer in a different direction and then change gear. In this case, further displays in the multifunction display will direct you to the final position.

- ► Maneuver if necessary.
- ► Always observe the warning messages displayed by PARKTRONIC (▷ page 182).

# **Canceling Parking Guidance**

 Press the PARKTRONIC button on the center console (> page 182).
 Parking Guidance is canceled immediately and PARKTRONIC is deactivated.

Parking Guidance is canceled automatically if it is no longer possible to guide you into the parking space, or if a malfunction occurs.

The parking space symbol goes out and a warning tone sounds. The Parking

Guidance Canceled message appears in the multifunction display.

# **ATTENTION ASSIST**

### Important safety notes

ATTENTION ASSIST helps you during long, monotonous journeys, such as on highways. It is active in the range between 50 mph (80 km/h) and 112 mph (180 km/h). If ATTENTION ASSIST detects typical indicators of fatigue or increasing lapses in concentration on the part of the driver, it suggests you take a break.

ATTENTION ASSIST assesses your level of fatigue or lapses in concentration by taking the following criteria into account:

- your personal driving style, e.g. steering characteristics
- journey details, e.g. time of day and length of journey

The functionality of ATTENTION ASSIST is restricted and warnings may be delayed or not occur at all:

- if the road condition is poor, e.g. if the surface is uneven or if there are potholes
- if there is a strong side wind

- if you have adopted a sporty driving style with high cornering speeds or high rates of acceleration
- if you are predominantly driving slower than 50 mph (80 km/h) or faster than 112 mph (180 km/h)
- if you are currently using COMAND or making a telephone call with it
- if the time has been set incorrectly
- in active driving situations, such as when you change lanes or change your speed

ATTENTION ASSIST is only an aid to the driver. It might not always recognize fatigue or increasing inattentiveness in time or fail to recognize them at all. The system is not a substitute for a well-rested and attentive driver.

# Warning and display messages in the multifunction display

- ► Activate ATTENTION ASSIST using the onboard computer (▷ page 201). If ATTENTION ASSIST is active, you will be warned no sooner than 20 minutes after your journey has begun. You then hear an intermittent warning tone twice and the Attention Assist: Take a Break! message appears in the multifunction display.
- ▶ If necessary, take a break.
- ▶ Press the OK or 🛨 button to confirm the message.

On long journeys, take regular breaks in good time to allow yourself to rest properly. If you do not take a break and ATTENTION ASSIST still detects increasing lapses in concentration, you will be warned again after 15 minutes at the earliest. ATTENTION ASSIST is reset when you continue your journey and starts assessing your tiredness again if:

- you switch off the engine.
- you take off your seat belt and open the driver's door, e.g. for a change of drivers or to take a break.

When ATTENTION ASSIST is deactivated, the **e** orf symbol appears in the multifunction display in the assistance graphics display.

### **Driving Assistance package**

### General notes

The Driving Assistance package consists of DISTRONIC PLUS ( $\triangleright$  page 169), Blind Spot Assist ( $\triangleright$  page 187) and Lane Keeping Assist ( $\triangleright$  page 188).

### **Blind Spot Assist**

### **General notes**

Blind Spot Assist uses a radar sensor system to monitor the areas on both sides of your vehicle. It supports you from a speed of approximately 20 mph (30 km/h). A warning display in the exterior mirrors draws your attention to vehicles detected in the monitored area. If you then switch on the corresponding turn signal to change lanes, you will also receive a visual and audible collision warning. Blind Spot Assist uses sensors in the rear bumper for monitoring purposes.

For Blind Spot Assist to assist you, the radar sensor system must be operational.

#### Important safety notes

### **▲ WARNING**

Blind Spot Assist does not react to:

- vehicles overtaken too closely on the side, placing them in the blind spot area
- vehicles which approach with a large speed differential and overtake your vehicle

As a result, Blind Spot Assist may not give warnings in such situations. There is a risk of an accident.


Always observe the traffic conditions carefully, and maintain a safe lateral distance.

# **1** USA only:

This device has been approved by the FCC as a "Vehicular Radar System". The radar sensor is intended for use in an automotive radar system only. Removing, tampering with, or altering the device will void any warranties, and is not permitted by the FCC. Do not tamper with, alter, or use in any non-approved way.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

### Monitoring range of the sensors




Blind Spot Assist monitors the area up to 10 ft (3.0 m) behind your vehicle and directly next to your vehicle, as shown in the diagram. For this purpose, Blind Spot Assist uses radar sensors in the rear bumper.

If the lanes are narrow, vehicles driving in the lane beyond the lane next to your vehicle may be indicated, especially if the vehicles are not driving in the middle of their lane. This may be the case if there are vehicles driving at the inner edge of their lanes. Due to the nature of the system:

- warnings may be issued in error when driving close to crash barriers or similar solid lane borders.
- the warning is canceled when driving for an extended period next to long vehicles, such as trucks.

The two radar sensors for Blind Spot Assist are integrated into the sides of the rear bumper. Make sure that the bumper is free of dirt, ice or slush in the vicinity of the sensors. The sensors must not be covered, for example by cycle racks or overhanging loads. Following a severe impact or in the event of damage to the bumpers, have the function of the sensors checked at a qualified specialist workshop. Blind Spot Assist may otherwise not work properly.

### Indicator and warning display



① Yellow indicator lamp/red warning lamp

When Blind Spot Assist is activated, indicator lamp ① in the exterior mirrors lights up yellow at speeds of up to 20 mph (30 km/h). At speeds above 20 mph (30 km/h), the indicator lamp goes out and Blind Spot Assist is operational.

If a vehicle is detected within the blind spot monitoring range at speeds above 20 mph (30 km/h), warning lamp ① on the corresponding side lights up red. This warning is always emitted when a vehicle enters the blind spot monitoring range from behind or from the side. When you overtake a vehicle, the warning only occurs if the difference in speed is less than 7 mph (12 km/h).

The yellow indicator lamp goes out if reverse gear is engaged. In this event, Blind Spot Assist is no longer active.

The brightness of the indicator/warning lamps is adjusted automatically according to the ambient light.

### Collision warning

If a vehicle is detected in the monitoring range of Blind Spot Assist and you switch on the corresponding turn signal, a double warning tone sounds. Red warning lamp (1) flashes. If the turn signal remains on, vehicles detected are indicated by the flashing of red warning lamp (1). There are no further warning tones.


### Switching on Blind Spot Assist

- Make sure that the radar sensor system (> page 205) and Blind Spot Assist
   (> page 201) are activated in the on-board computer.
- ► Turn the SmartKey to position **2** in the ignition lock.

Warning lamps ① in the exterior mirrors light up red for approximately 1.5 seconds and then turn yellow.

# Lane Keeping Assist

### General notes



Lane Keeping Assist monitors the area in front of your vehicle with camera (), which is mounted at the top of the windshield. Lane Keeping Assist detects lane markings on the road and warns you before you leave your lane unintentionally.

If you select km on the on-board computer in the Display Unit Speed-/Odometer function (▷ page 202), Lane Keeping Assist is active starting at a speed of 60 km/h. If the miles display unit is selected, the assistance range begins at 40 mph.

A warning may be given if a front wheel passes over a lane marking. It will warn you by means of intermittent vibration in the steering wheel for up to 1.5 seconds.

#### Important safety notes

### **MARNING №**

Lane Keeping Assist may not always clearly recognize lane markings.

In this case, Lane Keeping Assist may:

- give an unnecessary warning
- not give a warning

There is a risk of an accident.

Always pay particular attention to the traffic situation and stay in lane, in particular if warned by Lane Keeping Assist.

# 

The Lane Keeping Assist warning does not return the vehicle to the original lane. There is a risk of an accident.

You should always steer, brake or accelerate yourself, in particular if warned by Lane Keeping Assist.

If you fail to adapt your driving style, Lane Keeping Assist can neither reduce the risk of an accident nor override the laws of physics. Lane Keeping Assist cannot take into account the road, traffic and weather conditions. Lane Keeping Assist is merely an aid. You are responsible for the distance to the vehicle in front, for vehicle speed, for braking in good time and for staying in your lane.

The Lane Keeping Assist does not keep the vehicle in the lane.

The system may be impaired or may not function if:

- there is poor visibility, e.g. due to insufficient illumination of the road, or due to snow, rain, fog or spray
- there is glare, e.g. from oncoming traffic, the sun or reflections (e.g. when the road surface is wet)
- the windshield is dirty, fogged up, damaged or covered, for instance by a sticker, in the vicinity of the camera
- there are no, several or unclear lane markings for a lane, e.g. in areas with road construction work
- the lane markings are worn away, dark or covered up, e.g. by dirt or snow
- the distance to the vehicle in front is too small and the lane markings thus cannot be detected
- the lane markings change quickly, e.g. lanes branch off, cross one another or merge
- the road is narrow and winding
- there are strong shadows cast on the lane

### Switching on Lane Keeping Assist

Switch on Active Lane Keeping Assist using the on-board computer; to do so, select Standard or Adaptive(▷ page 201). If you drive at speeds above 40 mph (60 km/h) and lane markings are detected, the lines in the assistance graphics display (▷ page 200) are shown in green. Lane Keeping Assist is ready for use.

### Standard

If **Standard** is selected, no warning vibration occurs if:

- you switch on the turn signals. In this event, the warnings are suppressed for a certain period of time.
- a driving safety system intervenes, such as ABS, BAS or ESP<sup>®</sup>.

### Adaptive

When Adaptive is selected, no warning vibration occurs if:

- you switch on the turn signals. In this event, the warnings are suppressed for a certain period of time.
- a driving safety system intervenes, e.g. ABS, BAS or ESP<sup>®</sup>.
- you accelerate hard, e.g. kickdown.
- you brake hard.
- you steer actively, e.g. swerve to avoid an obstacle or change lanes quickly.
- you cut the corner on a sharp bend.

In order that you are warned only when necessary and in good time if you cross the lane marking, the system recognizes certain conditions and warns you accordingly.

The warning vibration occurs earlier if:

- you approach the outer lane marking on a bend.
- the road has very wide lanes, e.g. a highway.

• the system recognizes solid lane markings.

The warning vibration occurs later if:

- the road has narrow lanes.
- you cut the corner on a bend.

Useful information	192
Important safety notes	192
Displays and operation	192
Menus and submenus	195
Display messages	210
Warning and indicator lamps	240

### **Useful information**

1 This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.

 Read the information on qualified specialist workshops: (▷ page 24).

### Important safety notes

### MARNING

If you operate information systems and communication equipment integrated in the vehicle while driving, you will be distracted from traffic conditions. You could also lose control of the vehicle. There is a risk of an accident.

Only operate the equipment when the traffic situation permits. If you are not sure that this is possible, park the vehicle paying attention to traffic conditions and operate the equipment when the vehicle is stationary.

### MARNING

If the instrument cluster has failed or malfunctioned, you may not recognize function restrictions in systems relevant to safety. The operating safety of your vehicle may be impaired. There is a risk of an accident.

Drive on carefully. Have the vehicle checked at a qualified specialist workshop immediately.

You must observe the legal requirements for the country in which you are currently driving when operating the on-board computer.

The on-board computer only shows messages or warnings from certain systems in the

multifunction display. You should therefore make sure your vehicle is operating safely at all times. Otherwise, a vehicle that is not operating safely may cause an accident. For an overview, see the instrument panel illustration (> page 29).

### Displays and operation

### Instrument cluster lighting

The lighting in the instrument cluster, in the displays and the controls in the vehicle interior can be adjusted using the brightness control knob.

The brightness control knob is on the bottom left of the instrument cluster ( $\triangleright$  page 29).

- ► Turn the brightness control knob counterclockwise or clockwise. If the light switch is set to Auro, ⊇00€ or ID, the brightness is dependent upon the brightness of the ambient light.
- The light sensor in the instrument cluster automatically controls the brightness of the multifunction display.

In daylight, the displays in the instrument cluster are not lit.

#### **Coolant temperature display**

### MARNING

Opening the hood when the engine is overheated or when there is a fire in the engine compartment could expose you to hot gases or other service products. There is a risk of injury.

Let an overheated engine cool down before opening the hood. If there is a fire in the engine compartment, keep the hood closed and contact the fire department.

A display message is shown if the coolant temperature is too high.

If the coolant temperature is over 248 °F(120 °C), do not continue driving. The engine will otherwise be damaged.

The coolant temperature gauge is in the instrument cluster on the right-hand side ( $\triangleright$  page 29).

Under normal operating conditions and with the specified coolant level, the coolant temperature may rise to 248 °F (120 °C).

### Tachometer

Do not drive in the overrevving range, as this could damage the engine.

The red band in the tachometer indicates the engine's overrevving range.

The fuel supply is interrupted to protect the engine when the red band is reached.

### **Outside temperature display**

You should pay special attention to road conditions when temperatures are around freezing point.

The outside temperature display is in the multifunction display ( $\triangleright$  page 194).

Changes in the outside temperature are displayed after a short delay.


#### **Speedometer with segments**

The segments in the speedometer indicate which speed range is available.

- Cruise control activated (> page 167): The segments light up from the stored speed to the maximum speed.
- DISTRONIC PLUS activated (▷ page 169): One or two segments in the set speed range light up.
- DISTRONIC PLUS detects a vehicle in front: The segments between the speed of the vehicle in front and the stored speed light up.

### Operating the on-board computer

#### Overview



- Multifunction display
- Right control panel
- ③ Left control panel
- To activate the on-board computer: turn the SmartKey to position 1 in the ignition lock.

You can control the multifunction display and the settings in the on-board computer using the buttons on the multifunction steering wheel.

### Left control panel

Calls up the menu and menu bar

### A Press briefly:

- Scrolls in lists
- Selects a submenu or function
- In the Audio menu: selects a stored station, an audio track or a video scene
- In the Tel (telephone) menu: switches to the phone book and selects a name or telephone number



OK

# Press and hold:

- In the Audio menu: selects the previous/next station or selects an audio track or a video scene using rapid scrolling
- In the Tel (Telephone) menu: starts rapid scrolling if the phone book is open
- Confirms a selection/display message
  - In the Tel (telephone) menu: switches to the telephone book and starts dialing the selected number
  - In the Audio menu: stops the station search function at the desired station

### **Right control panel**

	<ul> <li>Rejects or ends a call</li> <li>Exits phone book/redial memory</li> </ul>
P	<ul><li>Makes or accepts a call</li><li>Switches to the redial memory</li></ul>
+	• Adjusts the volume
¥J	• Mute

### **Back button**


### Press briefly:

- Back
- Switches off the Voice Control System; see the separate operating instructions
- Hides display messages/calls up the last Trip menu function used
- Exits the telephone book/redial memory

#### Press and hold:

• Calls up the standard display in the Trip menu

### **Multifunction display**



Example: vehicles with automatic transmission

- (1) Transmission position ( $\triangleright$  page 149)
- ② Drive program (▷ page 149)
- ③ Text field
- ④ Menu bar
- 5 Time
- Outside temperature or speed (▷ page 203)

Text field ③ shows the selected menu or submenu as well as display messages.

► To show menu bar ④: press the or ▶ button on the steering wheel. Menu bar ④ disappears after a few seconds.

• You can set the time using COMAND; see the separate operating instructions.

**Vehicles with manual transmission:** instead of transmission position ① and drive program ②, the time and the outside temperature or speed are shown.

The following messages may appear in the multifunction display:

- Gearshift recommendation, for manual transmission (▷ page 149) or automatic transmission (▷ page 152)
- ← P → Parking Guidance (▷ page 183)
- CRUISE Cruise control (▷ page 167)
- Adaptive Highbeam Assist (▷ page 113)
- ECO ECO start/stop function (▷ page 143)
- HOLD HOLD function (▷ page 179)

### Menus and submenus

### Menu overview

Press the  $\checkmark$  or  $\blacktriangleright$  button on the steering wheel to call up the menu bar and select a menu.

Operating the on-board computer ( $\triangleright$  page 193).


Depending on the equipment installed in the vehicle, you can call up the following menus:

- Trip menu (⊳ page 195)
- Navi menu (navigation instructions) (▷ page 197)
- Audio menu (⊳ page 198)
- Tel menu (telephone) (> page 199)
- DriveAssist menu (assistance) (▷ page 200)
- Service menu (⊳ page 201)

- Settings menu (settings) (▷ page 202)
- AMG menu in AMG vehicles (> page 206)

### Trip menu

### Standard display



Press and hold the <u>steering</u> button on the steering wheel until the Trip menu with trip odometer (1) and odometer (2) is shown.

# Trip computer "From Start" or "From Reset"



Example: trip computer "From Start"

- ① Distance
- Time
- ③ Average speed
- ④ Average fuel consumption
- Press the or button on the steering wheel to select the Trip menu.
- ► Press the ▲ or ▼ button to select From Start or From Reset.

The values in the From Start submenu are calculated from the start of a journey whilst the values in the From Reset submenu are calculated from the last time the submenu was reset ( $\triangleright$  page 196).

The From Start trip computer is automatically reset when:

- the ignition has been switched off for more than four hours.
- 999 hours have been exceeded.
- 9,999 miles have been exceeded.

The From Reset trip computer is automatically reset if the value exceeds 9,999 hours or 99,999 miles.

# ECO display



### Example: ECO display

- Press the or button on the steering wheel to select the Trip menu.
- ► Press the ▲ or ▼ button to select ECO DISPLAY.

If the ignition remains switched off for longer than four hours, the ECO display will be automatically reset.

Further information on the ECO display ( $\triangleright$  page 163).


# Displaying the range and current fuel consumption



- Press the or button on the steering wheel to select the Trip menu.
- Press the or button to select the current fuel consumption (not for AMG vehicles) and the approximate range.

The approximate range that can be covered depends on the fuel level and your current driving style. If there is only a small amount of fuel left in the fuel tank, the display shows a vehicle being refueled  $\boxed{m}$  instead of the range.

### **Digital speedometer**



- ① Gearshift recommendation, manual transmission (▷ page 149) or automatic transmission (▷ page 152)
- Digital speedometer

Gearshift recommendation ① is not given on AMG vehicles.

- Press the or button on the steering wheel to select the Trip menu.
- Press the or button to select the digital speedometer.

### **Resetting values**



Example: resetting the trip computer "From start"

- Press the or button on the steering wheel to select the Trip menu.
- Press the or button to select the function that you wish to reset.
- ▶ Press the OK button.
- Press the vert button to select Yes and press the OK button to confirm.

You can reset the values of the following functions:

- Trip odometer
- "From Start" trip computer

- "From Reset" trip computer
- ECO display
- When you reset the values in the "ECO display", the values in the trip computer "From Start" are likewise reset. When you reset the values in the trip computer "From Start", the values in the "ECO display" are likewise reset.

### Navigation system menu

### **Displaying navigation instructions**

In the Navi menu, the multifunction display shows navigation instructions. For more information on navigation, see the separate operating instructions.

- Switch on COMAND (see the separate operating instructions).
- Press the or button on the steering wheel to select the Navi menu.

### Route guidance not active



- Direction of travel
- Current road

# Route guidance active

### No change of direction announced



- ① Distance to the destination
- ② Distance to the next change of direction

- ③ Current road
- ④ "Follow the road's course" symbol


# Change of direction announced without a lane recommendation



- Road into which the change of direction leads
- ② Distance to change of direction and visual distance display
- ③ Change-of-direction symbol

When a change of direction is announced, you will see symbol ③ for the change of direction and distance graphic ②. The distance indicator shortens towards the top of the display as you approach the point of the announced change of direction.

# Change of direction announced with a lane recommendation



- Road into which the change of direction leads
- ② Distance to change of direction and visual distance display
- ③ New lane during a change of direction
- ④ Uninterrupted lane
- 5 Lane recommendation
- 6 Change-of-direction symbol

On multilane roads, the system can display lane recommendation (3) for the next change of direction. During the change of direction, additional lanes may be displayed. Lane recommendations are only displayed if the relevant data is available on the digital map.

# Other status indicators of the navigation system

- New Route... or Calculating Route: calculating a new route
- Off Map or Off Mapped Road: the vehicle position is outside the area of the digital map (off-map position).
- No Route: no route could be calculated to the selected destination.

### Audio menu

### Selecting a radio station



- ① Waveband
- Station frequency with memory position
- Station (2) is displayed with the station frequency or station name. The memory position is only displayed along with station (2) if this has been stored.
- Switch on the audio system or COMAND and select Radio; see the separate operating instructions.
- Press the or button on the steering wheel to select the Audio menu.
- ► To select a stored station: briefly press the ▲ or ▼ button.

► To select a station from the station list: press and briefly hold the or button.

If no station list is received:

- ► To select a station using the station search: press and briefly hold the or ▼ button.
- For information on changing waveband and storing stations, see the separate operating instructions.
- SIRIUS XM satellite radio functions like a normal radio.

For more information on satellite radio operation, see the separate operating instructions.

# Operating an audio player or audio media



Example: CD/DVD changer display ① Current title

Audio data from various audio devices or media can be played, depending on the equipment installed in the vehicle.

- Switch on COMAND and activate audio CD/DVD mode or MP3 mode; see the separate operating instructions.
- Press the or button on the steering wheel to select the Audio menu.
- ► To select the next/previous track: briefly press the ▲ or ▼ button.
- To select a track from the track list (rapid scrolling): press and hold the
   or v button until desired track (2) has been reached.

If you press and hold or , the rapid scrolling speed is increased. Not all

audio drives or data carriers support this function.

If track information is stored on the audio device or medium, the multifunction display will show the number and title of the track. The current track does not appear in audio AUX mode (**Aux**iliary audio mode: external audio source connected).

### Video DVD operation



Example: CD/DVD changer display

Current scene

- Switch on COMAND and select video DVD; see the separate operating instructions.
- Press the or button on the steering wheel to select the Audio menu.
- ► To select the next/previous scene: briefly press the or button.
- To select a scene from the scene list (rapid scrolling): press and hold the
   or v button until desired scene (1) has been reached.

### **Telephone menu**

### Introduction

### MARNING

If you operate information systems and communication equipment integrated in the vehicle while driving, you will be distracted from traffic conditions. You could also lose control of the vehicle. There is a risk of an accident.

Only operate the equipment when the traffic situation permits. If you are not sure that this is possible, park the vehicle paying attention to traffic conditions and operate the equipment when the vehicle is stationary.

When telephoning, you must observe the legal requirements for the country in which you are currently driving.

- Switch on your mobile phone and COMAND, see the separate operating instructions.
- Establish a Bluetooth<sup>®</sup> connection to COMAND; see the separate operating instructions.
- Press the or button on the steering wheel to select the Tel menu.

You will see one of the following display messages in the multifunction display:

- Phone READY or the name of the network provider: the mobile phone has found a network and is ready to receive.
- Phone No Service: there is no network available or the mobile phone is searching for a network.

### Accepting a call



Example: incoming call

Press the button on the steering wheel to accept an incoming call.

If someone calls you when you are in the Tel menu, a display message appears in the multifunction display.

You can accept a call even if you are not in the Tel menu.

### Rejecting or ending a call

 Press the button on the steering wheel. You can end or reject a call even if you are not in the Tel menu.

### Dialing a number from the phone book

- Press the or button on the steering wheel to select the Tel menu.
- ► Press the ▲, ▼ or OK button to switch to the phone book.
- Press the or button to select the desired name.

or

► To begin rapid scrolling: press and hold the ▲ or ▼ button for longer than one second.

Rapid scrolling stops when you release the button or reach the end of the list.

► If only one telephone number is stored for a name: press the or OK button to start dialing.

or

- ► If there is more than one number for a particular name: press the or OK or OK button to display the numbers.
- Press the or button to select the number you want to dial.
- ▶ Press the row or OK button to start dialing.

or

► To exit the phone book: press the or button.

### Redialing

The on-board computer saves the last names or numbers dialed in the redial memory.

- Press the or button on the steering wheel to select the Tel menu.
- Press the button to switch to the redial memory.
- Press the or button to select the desired name or number.

▶ Press the *P* or *N* button to start dialing.

or

► To exit the redial memory: press the or → button.

### Assistance menu

### Introduction



In the **DriveAssist** menu, you have the following options:

- Displaying the assistance graphic (> page 200)
- Activating/deactivating PRE-SAFE<sup>®</sup> Brake (▷ page 201)
- Activating/deactivating ATTENTION ASSIST (▷ page 201)
- Activating/deactivating Blind Spot Assist (▷ page 201)
- Activating/deactivating Lane Keeping Assist (⊳ page 201)

# Displaying the assistance graphic

- Press the or button on the steering wheel to select the DriveAssist menu.
- ► Press ▲ or ▼ to select Assistance Graphic.
- ► Press the OK button. The multifunction display shows the DISTRONIC PLUS distance display in the assistance graphic (▷ page 175).

The assistance graphic can display the status of and information from other driving systems or driving safety systems. The assistance graphic shows:

- the **■**orf symbol when ATTENTION ASSIST (▷ page 186) is deactivated.
- the lane markings as bright lines when Lane Keeping Assist (▷ page 188) is activated.
- the ể symbol when PRE-SAFE<sup>®</sup> Brake (▷ page 65) is deactivated.

### Activating/deactivating PRE-SAFE<sup>®</sup> Brake

PRE-SAFE<sup>®</sup> Brake is only available in vehicles with DISTRONIC PLUS.

- Press or on the steering wheel to select the DriveAssist menu.
- ► Press the ▲ or ▼ button to select PRE-SAFE Brake.
- Press the OK button.
   The current selection is displayed.
- ► To activate/deactivate: press the OK button again.

When PRE-SAFE<sup>®</sup> Brake is deactivated, the symbol appears in the assistance graphic in the multifunction display.

For more information on PRE-SAFE<sup>®</sup> Brake, see ( $\triangleright$  page 65).

# Activating/deactivating ATTENTION ASSIST

- Press or on the steering wheel to select the DriveAssist menu.
- ► Press the ▲ or ▼ button to select ATTENTION ASSIST.
- Press the OK button.
   The current selection is displayed.
- ► To activate/deactivate: press the OK button again. When ATTENTION ASSIST is deactivated, the error symbol appears in the multifunction display in the assistance graphics display.

For further information about ATTENTION ASSIST, see (▷ page 186).

### Activating/deactivating Blind Spot Assist

- Press the or button on the steering wheel to select the DriveAssist menu.
- ► Press the ▲ or ▼ button to select Blind Spot Assist.
- Press the OK button. The current selection is displayed.
- ► To activate/deactivate: press the OK button again.

Further information about Blind Spot Assist (▷ page 187)

### Activating/deactivating Lane Keeping Assist

- Press the or button on the steering wheel to select the DriveAssist menu.
- Press or v to select Lane Keeping Assist.
- Press the OK button.
   The current selection is displayed.
- ▶ Press OK to confirm.
- Press v or to set Off, Standard or Adaptive.
- Press the OK button to save the setting. When Lane Keeping Assist is activated, the multifunction display shows the lane markings as bright lines in the assistance graphic.

For further information about Lane Keeping Assist, see (▷ page 188).



In the Service menu, you have the following options:

- Calling up display messages
   (▷ page 210)
- Restarting the tire pressure loss warning system (▷ page 314)
- Checking the tire pressure electronically (▷ page 314)
- Calling up the service due date (▷ page 279)

### Settings menu

### Introduction



In the Settings menu, you have the following options:

- Changing the instrument cluster settings (▷ page 202)
- Changing the light settings (▷ page 203)
- Changing the vehicle settings (▷ page 205)
- Changing the convenience settings (▷ page 205)
- Restoring the factory settings (> page 202)

### **Restoring the factory settings**

- Press the or button on the steering wheel to select the Settings menu.
- ► Press the ▼ or ▲ button to select the Factory Setting submenu.
- Press OK to confirm.
   The Reset All Settings? message appears.

- ► Press the ▼ or ▲ button to select No or Yes.
- ► Press the OK button to confirm the selection.

If you have selected Yes, the multifunction display shows a confirmation message.

For safety reasons, the Daytime Running Lights function in the Lights submenu is only reset if the vehicle is stationary.

#### Instrument cluster

#### Selecting the unit of measurement for distance

You can determine whether the multifunction display shows some messages in miles or kilometers.

- Press the or button on the steering wheel to select the Settings menu.
- ► Press the ▼ or ▲ button to select the Instrument Cluster submenu.
- ▶ Press OK to confirm.
- Press the v or button to select the Display Unit Speed-/Odometer function.

You will see the selected setting: km or miles.

▶ Press the OK button to save the setting.

The selected unit of measurement for distance applies to:

- Digital speedometer in the Trip menu
- Odometer and the trip odometer
- Trip computer
- Current consumption and the range
- Navigation instructions in the Navi menu
- Cruise control
- DISTRONIC PLUS
- ASSYST PLUS service interval display

# Switching the additional speedometer on/off

Only vehicles with manual transmission have this function.

- Press the or button on the steering wheel to select the Settings menu.
- ► Press the ▼ or ▲ button to select the Instrument Cluster submenu.
- ▶ Press OK to confirm.
- ► Press the ▼ or ▲ button to select the Additional Speedometer [mph] function.

You will see the selected setting: On or Off.

▶ Press the OK button to save the setting.

Speed is displayed in mph.

### The Additional Speedometer [mph] function allows you to choose whether the status area in the multifunction display always shows the speed in mph instead of the outside temperature.

# Selecting the permanent display function

You can determine whether the multifunction display permanently shows your speed or the outside temperature.

- Press the or button on the steering wheel to select the Settings menu.
- ► Press the ▼ or ▲ button to select the Instrument Cluster submenu.
- ▶ Press OK to confirm.
- Press the ▼ or ▲ button to select the Permanent Display function. You will see the selected setting Outside Temperature or Additional Speedometer [km/h]/Additional Speedometer [mph].
- ▶ Press the OK button to save the setting.
- 1 The speed is displayed in km/h/mph.

# Lights

# Setting the daytime running lamps

1 This function is not available in Canada.

- Press the or button on the steering wheel to select the Sett menu.
- Press the v or button to select the Lights submenu.
- ▶ Press OK to confirm.
- ► Press the ▼ or ▲ button to select the Daytime Running Lights function. If the Daytime Running Lights function has been switched on, the cone of light and the ※ symbol in the multifunction display are shown in orange.
- Press the OK button to save the setting.

Further information on daytime running lamps (▷ page 109).

# Switching Adaptive Highbeam Assist on/ off

- Press the or button on the steering wheel to select the Sett menu.
- Press the v or button to select the Lights submenu.
- ▶ Press OK to confirm.
- Press the v or button to select the Adaptive Highbeam function.
   If the Adaptive Highbeam function has been switched on, the cone of light and the symbol in the multifunction display are shown in orange.
- ► Press the OK button to save the setting.

For further information about Adaptive Highbeam Assist, see (▷ page 113).

# Setting the brightness of the ambient lighting

- Press the or button on the steering wheel to select the Settings menu.
- ► Press the ▼ or ▲ button to select the Lights submenu.
- ▶ Press OK to confirm.

- Press the v or button to select the Amb. Light +/- function. You will see the selected setting.
- Press OK to confirm.
- Press the v or button to adjust the brightness to any level from Off to Level 5 (bright).
- Press the OK or button to save the setting.

### Setting the ambient lighting color

- Press the or button on the steering wheel to select the Settings menu.
- Press the v or button to select the Lights submenu.
- ▶ Press OK to confirm.
- ► Press the ▼ or ▲ button to select the Ambient Light Color function.
- ▶ Press OK to confirm.
- Press the v or button to set the color to SOLAR, SOLAR orange or SOLAR red.
- Press the OK or button to save the setting.

### Activating/deactivating surround lighting and exterior lighting delayed switch-off

- Press the or button on the steering wheel to select the Sett menu.
- Press the v or button to select the Lights submenu.
- ▶ Press OK to confirm.
- ▶ Press the ▼ or ▲ button to select the Surround Lighting function. When the Surround Lighting function is activated, the light cone and the area around the vehicle are displayed in orange in the multifunction display.
- ▶ Press the OK button to save the setting.

Deactivating delayed switch-off of the exterior lighting temporarily:

- Before leaving the vehicle, turn the SmartKey to position 0 in the ignition lock.
- Turn the SmartKey to position 2 in the ignition lock. The exterior lighting delayed switch-off is deactivated.

Delayed switch-off of the exterior lighting is reactivated the next time you start the engine.

If you have activated the Surround

Lighting function and the light switch is set to **Auro**, the following functions are activated when it is dark:

- **surround lighting:** the exterior lighting remains lit for 40 seconds after unlocking with the SmartKey. If you start the engine, the surround lighting is switched off and automatic headlamp mode is activated (▷ page 109).
- exterior lighting delayed switch-off: the exterior lighting remains lit for 60 seconds after the engine is switched off. If you close all the doors and the trunk lid, the exterior lighting goes off after 15 seconds.
- Depending on your vehicle's equipment, when the surround lighting and delayed switch-off exterior lighting are on, the following light up:
  - Parking lamps
  - Front fog lamps
  - Low-beam headlamps
  - Daytime running lamps
  - Side marker lamps
  - Surround lighting in the exterior mirrors

# Activating/deactivating the interior lighting delayed switch-off

If you activate the Interior Lighting Delay function, the interior lighting remains on for 20 seconds after you remove the SmartKey from the ignition lock.

- Press the or button on the steering wheel to select the Sett menu.
- ► Press the ▼ or ▲ button to select the Lights submenu.
- ▶ Press OK to confirm.
- ► Press the ▼ or ▲ button to select the Interior Lighting Delay function. If the Interior Lighting Delay function has been switched on, the vehicle interior is displayed in orange in the multifunction display.
- ▶ Press the OK button to save the setting.

# Vehicle

# Activating/deactivating the automatic door locking mechanism

- Press the or button on the steering wheel to select the Sett menu.
- ► Press the ▼ or ▲ button to select the Vehicle submenu.
- ▶ Press OK to confirm.
- ▶ Press the ▼ or ▲ button to select the Automatic Door Lock function. When the Automatic Door Lock function is activated, the left-hand vehicle door is displayed in orange in the multifunction display.
- ▶ Press the OK button to save the setting.

If you activate the Automatic Door Lock function, the vehicle is centrally locked above a speed of around 9 mph (15 km/h). For further information on the automatic locking feature, see ( $\triangleright$  page 78).

# Activating/deactivating the acoustic locking verification signal

If you switch on the Acoustic Lock function, an acoustic signal sounds when you lock the vehicle.

- Press the or button on the steering wheel to select the Sett menu.
- ► Press the ▼ or ▲ button to select the Vehicle submenu.

- ▶ Press OK to confirm.
- ► Press the ▼ or ▲ button to select the Acoustic Lock function. If the Acoustic Lock function is activated, the ⊕ symbol in the multifunction display lights up orange.
- ▶ Press the OK button to save the setting.

# Activating/deactivating the radar sensor system

- Press the or button on the steering wheel to select the Settings menu.
- Press the v or button to select the Vehicle submenu.
- ▶ Press OK to confirm.
- Press the or button to select Radar Sensor (See Oper. Manual):. You will see the selected setting: Enabled or Disabled.
- ► Press the OK button to save the setting.

The following systems are switched off when the radar sensor system is deactivated:

- DISTRONIC PLUS (▷ page 169)
- BAS PLUS (▷ page 60)
- PRE-SAFE<sup>®</sup> Brake (▷ page 65)

# Convenience

# Activating/deactivating the EASY-ENTRY/EXIT feature

# 

When the EASY-ENTRY/EXIT feature adjusts the steering wheel, you and other vehicle occupants – particularly children – could become trapped. There is a risk of injury. While the EASY-ENTRY/EXIT feature is making adjustments, make sure that no one has any body parts in the sweep of the steering wheel. **On-board computer and displays** 

If somebody becomes trapped:

- press one of the memory function position buttons, or
- move the switch for steering wheel adjustment in the opposite direction to that in which the steering wheel is moving.
- The adjustment process is stopped.
- Press the or button on the steering wheel to select the Sett menu.
- Press the v or button to select the Convenience submenu.
- ▶ Press OK to confirm.
- Press the void of the control of
- ▶ Press the OK button to save the setting.

Further information on the EASY-ENTRY/EXIT feature ( $\triangleright$  page 101).

### Switching the belt adjustment on/off

- Press the or button on the steering wheel to select the Sett menu.
- ► Press the ▼ or ▲ button to select the Convenience submenu.
- ▶ Press OK to confirm.
- ► Press the ▼ or ▲ button to select the Belt Adjustment function. When the Belt Adjustment function is activated, the vehicle seat belt is displayed in orange in the multifunction display.
- ▶ Press the OK button to save the setting.

For further information on belt adjustment, see ( $\triangleright$  page 53).

# Switching the fold-in mirrors with the locking feature on/off

This function is only available on vehicles with the memory function ( $\triangleright$  page 105).

When you activate the Auto. Mirror Folding function, the exterior mirrors are folded in when the vehicle is locked.


If you unlock the vehicle and then open a door, the exterior mirrors fold out again.

If you have switched on the Auto. Mirror Folding function and you fold in the exterior mirrors using the button on the door (> page 104), they will not fold out automatically. The exterior mirrors can then only be folded out using the button on the door.

- Press the or button on the steering wheel to select the Sett menu.
- ► Press the ▼ or ▲ button to select the Convenience submenu.
- ▶ Press OK to confirm.
- Press or to select the Auto. Mirror Folding function. If the Auto. Mirror Folding function is activated, the vehicle's exterior mirror is displayed in orange in the multifunction display.
- ▶ Press the OK button to save the setting.

### AMG menu in AMG vehicles

### AMG displays



- Digital speedometer
- Gear indicator
- ③ Upshift indicator
- ④ Engine oil temperature
- ⑤ Coolant temperature
- Transmission fluid temperature

Press or on the steering wheel to select the AMG menu.

Upshift indicator UP (3) indicates that the engine has reached the overrevving range when in the manual gearshift program. Upshift indicator UP (3) fades out other messages until you have shifted up. If the engine oil temperature is below 176 °F (80 °C), oil temperature (4) is shown in blue. Avoid driving at full engine output during this time.

If the transmission fluid temperature is below 122 °F (50 °C), oil temperature is shown in blue. Avoid driving at full engine output during this time.

### SETUP



- ① Drive program (C/S/M)
- ESP<sup>®</sup> mode (ON/OFF) or SPORT handling mode (SPORT)

SETUP shows the drive program, the ESP<sup>®</sup> (Electronic Stability Program) mode and the SPORT handling mode.

- Press the or button on the steering wheel to select the AMG menu.
- Press the button repeatedly until SETUP is displayed.

# RACETIMER

### **Displaying and starting RACETIMER**

The RACETIMER is only intended for use on a closed race circuit. Do not use the function on public roads.



① Lap

② RACETIMER

You can start the RACETIMER when the engine is running or if the SmartKey is in position **2** in the ignition lock.

- Press or or on the steering wheel to select the AMG menu.
- Press the button repeatedly until the RACETIMER is shown.
- ► **To start:** press the OK button to start the RACETIMER.

# Displaying the intermediate time



- ▶ Press the or button to select Interm. Time.
- Press OK to confirm.
   The intermediate time is displayed for five seconds.

# Starting a new lap



- RACETIMER
- ② Fastest lap time (best lap)
- ③ Lap

### ▶ Press OK to confirm New Lap.

It is possible to store a maximum of sixteen laps. The 16th lap can only be completed with Finish Lap.

### Stopping the RACETIMER



- Press the button on the steering wheel.
- ▶ Press OK to confirm Yes.

The RACETIMER interrupts timing when you stop the vehicle and turn the SmartKey to position 1 in the ignition lock. If you turn the SmartKey to position 2 or 3 and then press OK to confirm Start, timing is continued.

### Resetting the current lap

- ► Stop the RACETIMER.
- ► Press the or button to select Reset Lap.
- ▶ Press OK to reset the lap time to "0".

### Deleting all laps




If you switch off the engine, the RACETIMER is reset to "0" after 30 seconds. All laps are deleted.

You cannot delete individual stored laps. If you have stopped 16 laps, the current lap does not have to be reset.

- Reset the current lap.
- Press OK to confirm Reset.
   Reset Race Timer? appears in the multifunction display.
- Press the velocity button to select Yes and press the OK button to confirm.
   All laps are deleted.

### **Overall statistics**




- ① RACETIMER overall evaluation
- Total time driven
- ③ Average speed
- ④ Distance covered
- 5 Maximum speed

This function is shown if you have stored at least one lap and stopped the RACETIMER.

- Press or or on the steering wheel to select the AMG menu.
- Press the button repeatedly until the overall evaluation is shown.

### Lap statistics



- 1 Lap
- Lap time
- ③ Average lap speed
- ④ Lap length
- 5 Top speed during lap

This function is only available if you have stored at least two laps and have stopped the RACETIMER.

- Press or on the steering wheel to select the AMG menu.
- Press the button repeatedly until the lap evaluation is shown.
   Each lap is shown in a separate submenu.
   The fastest lap is indicated by flashing symbol ①.
- ► Press the ▲ or ▼ button to select a different lap evaluation.

### **Display messages**

### Introduction

# General notes

Display messages appear in the multifunction display.

Display messages with graphic displays may be shown in simplified form in the Operator's Manual and may differ from the messages shown in the multifunction display.

Please respond in accordance with the display messages and follow the additional notes in this Operator's Manual.

Certain display messages are accompanied by an audible warning tone or a continuous tone. When you stop and park the vehicle, please observe the notes on:

- HOLD function (▷ page 179)
- Parking (▷ page 159)

# Hiding display messages

Press the OK or button on the steering wheel to hide the display message. The display message is cleared.

The multifunction display shows high-priority display messages in red. Some high-priority display messages cannot be hidden.

The multifunction display shows these messages continuously until the causes for the messages have been remedied.

### Message memory

The on-board computer saves certain display messages in the **message memory**. You can call up the display messages:

- Press the or button on the steering wheel to select the Serv. menu. If there are display messages, the multifunction display shows 2 Messages, for example.
- ▶ Press the ▲ or ▼ button to select the entry, e.g. 2 Messages.
- ▶ Press OK to confirm.
- ▶ Press the ▲ or ▼ button to scroll through the display messages.

When the ignition is switched off, all display messages are deleted, apart from some highpriority display messages. Once the causes of the high-priority display messages have been rectified, the corresponding display messages are also deleted.

### Safety systems

### **Display messages**



Currently Unavailable See Operator's Manual

### Possible causes/consequences and ► Solutions

ABS (Anti-lock Braking System), ESP<sup>®</sup> (Electronic Stability Program), BAS (Brake Assist), PRE-SAFE<sup>®</sup>, the HOLD function and hill start assist are temporarily unavailable.

BAS PLUS and PRE-SAFE<sup>®</sup> Brake may also have failed.

In addition, the 🛒, 👫 and 🝘 warning lamps light up in the instrument cluster.

ATTENTION ASSIST is deactivated.

Possible causes are:

- self-diagnosis is not yet complete.
- the on-board voltage may be insufficient.

# 

The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example.

The steerability and braking characteristics may be severely affected. The braking distance in an emergency braking situation can increase.

If ESP<sup>®</sup> is not operational, ESP<sup>®</sup> is unable to stabilize the vehicle.

There is an increased risk of skidding and an accident.

Carefully drive on a suitable stretch of road, making slight steering movements at a speed above 12 mph (20 km/h). If the display message disappears, the functions mentioned above are available again.

If the display message continues to be displayed:

- ► Drive on carefully.
- ► Visit a qualified specialist workshop.



Inoperative See Operator's Manual ABS, ESP<sup>®</sup>, BAS, PRE-SAFE<sup>®</sup>, the HOLD function and hill start assist are unavailable due to a malfunction.

BAS PLUS and PRE-SAFE<sup>®</sup> Brake may also have failed.

The BRAKE (USA only)/ ((1)) (Canada only), (2), (3), and (3) warning lamps in the instrument cluster also light up. ATTENTION ASSIST is deactivated.

# 

The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example.

s/	Display messages
On-board computer and displays	
On-board comp	Currently Unavailable See Operator's Manual

# Possible causes/consequences and Solutions

The steerability and braking characteristics may be severely affected. The braking distance in an emergency braking situation can increase.

If ESP<sup>®</sup> is not operational, ESP<sup>®</sup> is unable to stabilize the vehicle. There is an increased risk of skidding and an accident.

- ► Drive on carefully.
- ▶ Visit a qualified specialist workshop immediately.

ESP®, BAS, PRE-SAFE®, the HOLD function and hill start assist are temporarily unavailable.

BAS PLUS and PRE-SAFE<sup>®</sup> Brake may also have failed.

In addition, the 📻 and \sum warning lamps light up in the instrument cluster.

ATTENTION ASSIST is deactivated

The self-diagnosis function might not be complete, for example.

# **WARNING**

The brake system continues to function normally, but without the functions listed above.

The braking distance in an emergency braking situation can thus increase.

If ESP<sup>®</sup> is not operational, ESP<sup>®</sup> is unable to stabilize the vehicle. There is an increased risk of skidding and an accident.

• Carefully drive on a suitable stretch of road, making slight steering movements at a speed above 12 mph (20 km/h). If the display message disappears, the functions mentioned above are available again.

If the display message continues to be displayed:

- ▶ Drive on carefully.
- Visit a gualified specialist workshop.

#### Possible causes/consequences and Solutions **Display messages** ESP<sup>®</sup>, BAS, PRE-SAFE<sup>®</sup>, the HOLD function and hill start assist are unavailable due to a malfunction. Inoperative See BAS PLUS and PRE-SAFE<sup>®</sup> Brake may also have failed. **Operator's Manual** In addition, the 👔 and 👫 warning lamps light up in the instrument cluster. ATTENTION ASSIST is deactivated. **∧** WARNING The brake system continues to function normally, but without the functions listed above. The braking distance in an emergency braking situation can thus increase. If ESP<sup>®</sup> is not operational, ESP<sup>®</sup> is unable to stabilize the vehicle. There is an increased risk of skidding and an accident. Drive on carefully. Visit a gualified specialist workshop. EBD (electronic brake force distribution), ABS, ESP<sup>®</sup>, BAS, PRE-EBD (ABS) SAFE<sup>®</sup>, the HOLD function and hill start assist are unavailable due to a malfunction. **Inoperative See** BAS PLUS and PRE-SAFE<sup>®</sup> Brake may also have failed. **Operator's Manual** In addition, the 👰 , 🐉 and 🞯 warning lamps light up in the instrument cluster and a warning tone sounds. **WARNING** The brake system continues to function normally, but without the functions listed above. The front and rear wheels could therefore lock if you brake hard, for example. The steerability and braking characteristics may be severely affected. The braking distance in an emergency braking situation can increase. If ESP<sup>®</sup> is not operational, ESP<sup>®</sup> is unable to stabilize the vehicle. There is an increased risk of skidding and an accident. Drive on carefully. Visit a gualified specialist workshop immediately. The red PARK (USA only)/ (D) (Canada only) indicator lamp PARK USA flashes and a warning tone sounds. A condition for automatic only) (Canada release of the electric parking brake is not fulfilled ( $\triangleright$ page 160). only) You are driving with the electric parking brake applied. Please Release Release the electric parking brake manually. Parking Brake

<b>D</b> ' 1	
Display messages	Possible causes/consequences and ► Solutions
	The red PARK (USA only)/ () (Canada only) indicator lamp flashes and a warning tone sounds. You are making an emergency stop using the electric parking brake (▷ page 160).
PARK (USA only) (P) (Canada only) Parking Brake See Operator's Manual	<ul> <li>The yellow () warning lamp lights up.</li> <li>The electric parking brake is malfunctioning.</li> <li>To apply:</li> <li>Switch the ignition off.</li> <li>Press the electric parking brake handle for at least ten seconds.</li> <li>Vehicles with manual transmission: engage first gear.</li> <li>Vehicles with automatic transmission: shift the transmission to P.</li> <li>Consult a qualified specialist workshop.</li> </ul>
	The yellow () warning lamp and the red PARK (USA only)/ () (Canada only) indicator lamp light up. The electric parking brake is malfunctioning. <b>To release:</b>
	<ul> <li>Switch off the ignition and turn it back on.</li> <li>Release the electric parking brake manually.</li> <li>or</li> <li>Vehicles with manual transmission (automatic emergency release): insert the seat belt in the belt buckle and accelerate slightly more when pulling away.</li> <li>Vehicles with automatic transmission: release the electric parking brake automatically (▷ page 160).</li> <li>If the yellow () warning lamp remains lit or continues to flash:</li> </ul>
	<ul><li>Do not drive on.</li><li>Consult a qualified specialist workshop.</li></ul>

Display messages	Possible causes/consequences and ► Solutions
PARK (USA only) (Canada only)	The yellow () warning lamp lights up. The red PARK (USA only)/() (Canada only) indicator lamp flashes for about ten seconds after the electric parking brake has been applied or released. It then goes out or remains lit.
Parking Brake Inoperative	The electric parking brake is malfunctioning, e.g. because of overvoltage or undervoltage.
	Remove the cause for the overvoltage or undervoltage, e.g. by charging the battery or restarting the engine.
	Engage or release the electric parking brake.
	If it remains impossible to apply or release the electric parking brake:
	Switch off the ignition and turn it back on.
	Engage or release the electric parking brake.
	If the electric parking brake still cannot be released:
	<ul> <li>Consult a qualified specialist workshop.</li> </ul>
	The display message is only shown while the vehicle is in motion. The yellow () warning lamp lights up and the red PARK (USA only)/ () (Canada only) indicator lamp flashes.
	It is not possible to apply the electric parking brake manually.
	<ul> <li>Vehicles with manual transmission: engage first gear.</li> <li>Vehicles with automatic transmission: shift the transmission to P.</li> </ul>
	<ul> <li>Visit a qualified specialist workshop.</li> </ul>
PARK (USA	The red PARK (USA only)/ (P) (Canada only) indicator lamp lights up.
only) (Canada only)	You attempted to release the electric parking brake while the ignition was switched off.
Turn On the Ignition to Release the Parking Brake	<ul> <li>SmartKey: turn the SmartKey to position 1 in the ignition lock.</li> <li>KEYLESS-GO: switch on the ignition.</li> </ul>

Display messages	Possible causes/consequences and Solutions
BRAKE (USA only) (Canada only) Check Brake Fluid Level	<ul> <li>There is not enough brake fluid in the brake fluid reservoir.</li> <li>In addition, the ■RAKE (USA only)/(①) (Canada only) warning lamp lights up in the instrument cluster and a warning tone sounds.</li> <li>MARNING</li> <li>The braking effect may be impaired.</li> <li>There is a risk of an accident.</li> <li>Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.</li> <li>Secure the vehicle against rolling away (▷ page 159).</li> <li>Consult a qualified specialist workshop.</li> <li>Do not add brake fluid. This does not correct the malfunction.</li> </ul>
BRAKE (USA only) ((Canada only) Brake Immediately	<ul> <li>A malfunction has occurred while the HOLD function or DISTRONIC PLUS is active.</li> <li>A tone may also sound at regular intervals. If you attempt to lock the vehicle, the tone becomes louder.</li> <li>You cannot start the engine.</li> <li>Paying attention to the traffic situation, immediately depress the brake pedal firmly and hold until the display message disappears.</li> <li>Prevent the vehicle from rolling away before you leave it (▷ page 159). You can restart the engine.</li> </ul>
Check Brake Pad Wear	<ul><li>The brake pads/linings have reached their wear limit.</li><li>Visit a qualified specialist workshop.</li></ul>
<b>©SOS</b> mbrace Inoperative	<ul> <li>One or more main features of the mbrace system are malfunctioning.</li> <li>Have the mbrace system checked immediately at a qualified specialist workshop.</li> </ul>
PRE-SAFE Inoperative See Operator's Manual	<ul> <li>Important functions of PRE-SAFE<sup>®</sup> have failed. All other occupant safety systems, e.g. air bags, remain available.</li> <li>Visit a qualified specialist workshop immediately.</li> </ul>

Display messages	Possible causes/consequences and ► Solutions
PRE-SAFE Functions Currently Limited See Operator's Manual	<ul> <li>Possible causes/consequences and ▶ Solutions</li> <li>PRE-SAFE<sup>®</sup> Brake is deactivated or temporarily inoperative. Possible causes are: <ul> <li>function is impaired due to heavy rain or snow.</li> <li>the sensors in the radiator grill and the bumper are dirty.</li> <li>the radar sensor system is temporarily inoperative, e.g. due to electromagnetic radiation emitted by nearby TV or radio stations or other sources of electromagnetic radiation.</li> <li>AMG vehicles: ESP<sup>®</sup> is deactivated.</li> <li>the system is outside the operating temperature range.</li> <li>the on-board voltage is too low.</li> </ul> </li> <li>When the causes stated above no longer apply, the display message disappears.</li> <li>PRE-SAFE<sup>®</sup> Brake is operational again.</li> <li>Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.</li> <li>Secure the vehicle against rolling away (▷ page 159).</li> <li>Clean the sensors in the radiator grill and the bumper (▷ page 283).</li> <li>Restart the engine.</li> <li>AMG vehicles: reactivate ESP<sup>®</sup>(▷ page 63).</li> </ul>
PRE-SAFE Functions Limited See Operator's Manual	<ul> <li>PRE-SAFE<sup>®</sup> Brake is inoperative due to a malfunction. BAS PLUS or the distance warning signal may also have failed.</li> <li>Visit a qualified specialist workshop.</li> </ul>
SRS Malfunction Service Required	<ul> <li>There is a malfunction in the SRS (Supplemental Restraint System). The  <i>y</i> warning lamp also lights up in the instrument cluster.</li> <li><i>WARNING</i></li> <li>The air bags or Emergency Tensioning Devices may either be triggered unintentionally or, in the event of an accident, may not be triggered.</li> <li>There is an increased risk of injury.</li> <li>Visit a qualified specialist workshop.</li> <li>For further information about SRS, see (▷ page 39).</li> </ul>

Display messages	Possible causes/consequences and Solutions
Front Left Malfunction Service Required or Front Right Malfunction Service Required	<ul> <li>SRS has malfunctioned at the front on the left or right. The x warning lamp also lights up in the instrument cluster.</li> <li>▲ WARNING</li> <li>The air bags or Emergency Tensioning Devices may either be triggered unintentionally or, in the event of an accident, may not be triggered.</li> <li>There is an increased risk of injury.</li> <li>▶ Visit a qualified specialist workshop.</li> </ul>
Left Side Curtain Airbag Malfunction Service Required or Right Side Curtain Airbag Malfunction Service Required	<ul> <li>There is a malfunction in the left-hand and/or right-hand head bag. The right warning lamp also lights up in the instrument cluster.</li> <li>▲ WARNING</li> <li>The left or right head bag may either be triggered unintentionally or, in the event of an accident, may not be triggered.</li> <li>There is an increased risk of injury.</li> <li>▶ Visit a qualified specialist workshop.</li> </ul>

#### Display messages

Front Passenger Airbag Disabled See Operator's Manual

#### Possible causes/consequences and Solutions

The front-passenger air bag and front-passenger knee bag are deactivated during the journey, although:

an adult

or

• a person larger than a certain size is occupying the frontpassenger seat

If additional forces are applied to the seat, the system may interpret the occupant's weight as lower than it actually is.

#### MARNING

The front-passenger front air bag and front passenger knee bag may not be triggered in the event of an accident.

There is an increased risk of injury.

- Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.
- ► Secure the vehicle against rolling away (▷ page 159).
- ► Switch the ignition off.
- ► Have the occupant get out of the vehicle.
- Keep the seat unoccupied, close the front-passenger door and switch on the ignition.
- Observe the PASSENGER AIR BAG OFF indicator lamp in the center console and the multifunction display and check the following:

Seat unoccupied and ignition switched on:

- the PASSENGER AIR BAG OFF indicator lamp must light up and remain lit. If the indicator lamp is on, OCS has disabled the frontpassenger air bag and front-passenger knee bag (▷ page 45).
- the Front Passenger Airbag Enabled See Operator's Manual or Front Passenger Airbag Disabled See Operator's Manual display messages must not be shown in the multifunction display.
- Wait for a period of at least 60 seconds until the necessary system checks have been completed.
- Make sure that the display messages do not appear in the multifunction display.

If these conditions are fulfilled, the front-passenger seat can be occupied again. Whether the PASSENGER AIR BAG OFF indicator lamp remains lit or goes out depends on how OCS classifies the occupant.

If the conditions are not fulfilled, the system is not operating correctly.

Display messages	Possible causes/consequences and ► Solutions
	Visit a qualified specialist workshop immediately.
	For further information about the Occupant Classification System, see ( $\triangleright$ page 45).
Front Passenger Airbag Enabled	The front-passenger air bag and front-passenger knee bag are enabled during the journey, even though:
See Operator's Manual	<ul> <li>a child, a small adult or an object weighing less than the system's weight threshold is located on the front-passenger seat</li> </ul>
	Or
	the front-passenger seat is unoccupied The system may detect objects or forees applying additional
	The system may detect objects or forces applying additional weight on the seat.
	The front-passenger front air bag and front passenger knee bag may be triggered unintentionally.
	There is an increased risk of injury.
	Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.
	► Secure the vehicle against rolling away (▷ page 159).
	► Switch the ignition off.
	Open the front-passenger door.
	Remove the child and the child restraint system from the front- passenger seat.
	Make sure that there are no objects on the seat adding to the weight.
	The system may otherwise detect the additional weight and interpret the seat occupant's weight as greater than it actually is.
	Keep the seat unoccupied, close the front-passenger door and switch on the ignition.
	<ul> <li>Observe the PASSENGER AIR BAG OFF indicator lamp in the center console and the multifunction display and check the following:</li> </ul>
	Seat unoccupied and ignition switched on:
	• the PASSENGER AIR BAG OFF indicator lamp must light up and remain lit. If the indicator lamp is on, OCS (Occupant Classification System) has disabled the front-passenger air bag and front-passenger knee bag (> page 45).
	• the Front Passenger Airbag Enabled See Operator's

• the Front Passenger Airbag Enabled See Operator's Manual or Front Passenger Airbag Disabled See

Display messages	Possible causes/consequences and ► Solutions
	<b>Operator's Manual</b> display messages must not be shown in the multifunction display.
	Wait for a period of at least 60 seconds until the necessary system checks have been completed.
	Make sure that the display messages do not appear in the multifunction display.
	If these conditions are fulfilled, the front-passenger seat can be occupied again. Whether the PASSENGER AIR BAG OFF indicator lamp remains lit or goes out depends on how OCS classifies the occupant.
	If the conditions are not fulfilled, the system is not operating correctly.
	<ul> <li>Visit a qualified specialist workshop immediately.</li> </ul>
	For further information about the Occupant Classification System, see ( $\triangleright$ page 45).

# Lights

**1** Display messages about LEDs:

This display message will only appear if all LEDs have failed.

Display messages	Possible causes/consequences and Solutions
Check Left Cornering Light or Check Right Cornering Light	<ul> <li>The left or right-hand cornering light is defective.</li> <li>► Check whether you are permitted to replace the bulb yourself (▷ page 115).</li> <li>or</li> <li>► Visit a qualified specialist workshop.</li> </ul>
Check Left Low Beam or Check Right Low Beam	<ul> <li>The left or right-hand low-beam headlamp is defective.</li> <li>► Check whether you are permitted to replace the bulb yourself (▷ page 115).</li> <li>or</li> <li>► Visit a qualified specialist workshop.</li> </ul>
Check Rear Left Turn Signal or Check Rear Right Turn Signal	<ul> <li>The rear left-hand or rear right-hand turn signal is defective.</li> <li>Check whether you are permitted to replace the bulb yourself (▷ page 115).</li> <li>or</li> <li>Visit a qualified specialist workshop.</li> </ul>

# 222 Display messages

Display messages	Possible causes/consequences and Solutions
Check Front Left Turn Signal or Check Front Right Turn Signal	<ul> <li>The front left-hand or front right-hand turn signal is defective.</li> <li>Check whether you are permitted to replace the bulb yourself (▷ page 115).</li> <li>or</li> <li>Visit a qualified specialist workshop.</li> </ul>
Check Left Mirror Turn Signal or Check Right Mirror Turn Signal	<ul> <li>The turn signal in the left-hand or right-hand exterior mirror is defective.</li> <li>Check whether you are permitted to replace the bulb yourself (▷ page 115).</li> <li>or</li> <li>Visit a qualified specialist workshop.</li> </ul>
Check Center Brake Lamp	<ul> <li>The high-mounted brake lamp is faulty.</li> <li>► Check whether you are permitted to replace the bulb yourself (▷ page 115).</li> <li>or</li> <li>► Visit a qualified specialist workshop.</li> </ul>
Check Left Brake Lamp or Check Right Brake Lamp	<ul> <li>The left or right-hand brake lamp is defective.</li> <li>Check whether you are permitted to replace the bulb yourself (▷ page 115).</li> <li>or</li> <li>Visit a qualified specialist workshop.</li> </ul>
Check Left Tail and Brake Lamps or Check Right Tail and Brake Lamps	<ul> <li>The left or right-hand tail lamp/brake lamp is defective.</li> <li>Check whether you are permitted to replace the bulb yourself (▷ page 115).</li> <li>or</li> <li>Visit a qualified specialist workshop.</li> </ul>
Check Left High Beam or Check Right High Beam	<ul> <li>The left or right-hand high beam is defective.</li> <li>► Check whether you are permitted to replace the bulb yourself (▷ page 115).</li> <li>or</li> <li>► Visit a qualified specialist workshop.</li> </ul>

Display messages	Possible causes/consequences and Solutions
License Plate Lamp	<ul> <li>The left or right-hand license plate lamp is defective.</li> <li>Check whether you are permitted to replace the bulb yourself (▷ page 115).</li> <li>or</li> <li>Visit a qualified specialist workshop.</li> </ul>
Check Left Fog LamporCheck Right Fog Lamp	<ul> <li>The left-hand or right-hand front fog lamp is defective.</li> <li>Check whether you are permitted to replace the bulb yourself (▷ page 115).</li> <li>or</li> <li>Visit a qualified specialist workshop.</li> </ul>
िक्रे Rear Fog Lamp	<ul> <li>The rear fog lamp is defective.</li> <li>Check whether you are permitted to replace the bulb yourself (▷ page 115).</li> <li>or</li> <li>Visit a qualified specialist workshop.</li> </ul>
Check Front Left Parking Lamp or Check Front Right Parking Lamp	<ul> <li>The front left or front right parking or standing lamp is defective.</li> <li>Check whether you are permitted to replace the bulb yourself (▷ page 115).</li> <li>or</li> <li>Visit a qualified specialist workshop.</li> </ul>
改 Backup Light	<ul> <li>The backup lamp is defective.</li> <li>Check whether you are permitted to replace the bulb yourself (▷ page 115).</li> <li>or</li> <li>Visit a qualified specialist workshop.</li> </ul>
Check Front Left Sidemarker Lamp or Check Front Right Sidemarker Lamp	<ul> <li>The left or right front side marker lamp is defective.</li> <li>Check whether you are permitted to replace the bulb yourself (▷ page 115).</li> <li>or</li> <li>Visit a qualified specialist workshop.</li> </ul>
Check Rear Left Sidemarker Lamp or Check Rear Right Sidemarker Lamp	<ul> <li>The rear left or right side marker lamp is defective.</li> <li>Check whether you are permitted to replace the bulb yourself (▷ page 115).</li> <li>or</li> <li>Visit a qualified specialist workshop.</li> </ul>

# 224 Display messages

Display messages	Possible causes/consequences and Solutions
Check Left Daytime Running Light or Check Right Daytime Running Light	<ul> <li>The left-hand or right-hand daytime running lamp is faulty.</li> <li>Check whether you are permitted to replace the bulb yourself (▷ page 115).</li> <li>or</li> <li>Visit a qualified specialist workshop.</li> </ul>
·핫 Active Headlamps Inoperative	<ul><li>The active light function is defective.</li><li>▶ Visit a qualified specialist workshop.</li></ul>
· . Malfunction See Operator's Manual	<ul><li>The exterior lighting is defective.</li><li>▶ Visit a qualified specialist workshop.</li></ul>
· . Auto Lamp Function Inoperative	<ul><li>The light sensor is defective.</li><li>▶ Visit a qualified specialist workshop.</li></ul>
्र्क् Switch Off Lights	The lights are still switched on when you leave the vehicle. A warning tone also sounds. ► Turn the light switch to <b>AUTO</b> .
Adaptive Highbeam Assist Inoperative	<ul><li>Adaptive Highbeam Assist is faulty.</li><li>► Visit a qualified specialist workshop.</li></ul>
Adaptive Highbeam Assist Currently Unavailable See Operator's Manual	<ul> <li>Adaptive Highbeam Assist is deactivated and temporarily inoperative. Possible causes are:</li> <li>the windshield in the camera's field of vision is dirty.</li> <li>visibility is impaired due to heavy rain, snow or fog.</li> <li>Clean the windshield.</li> <li>If the system detects that the camera is fully operational again, the Adaptive Highbeam Assist Now Available message is displayed.</li> <li>Adaptive Highbeam Assist is operational again.</li> </ul>

Engine	
Display messages	Possible causes/consequences and Solutions
Check Coolant Level See	The coolant level is too low.
	Avoid making long journeys with too little coolant in the engine cooling system. The engine will otherwise be damaged.
Operator's Manual	► Add coolant, observing the warning notes before doing so (▷ page 277).
	If coolant needs to be added more often than usual, have the engine coolant system checked at a qualified specialist workshop.
	The fan motor is faulty.
	► At coolant temperatures below 248 °F (120 °C), drive to the
	<ul> <li>nearest qualified specialist workshop.</li> <li>Avoid subjecting the engine to heavy loads, e.g. driving in</li> </ul>
	mountainous terrain, and stop-and-go traffic.
~	The coolant is too hot.
Coolant Too Hot	A warning tone also sounds.
Stop Vehicle Turn	
Engine Off	Do not drive when your engine is overheated. This can cause some fluids which may have leaked into the engine compartment to catch fire.
	Steam from the overheated engine can also cause serious burns which can occur just by opening the hood. There is a risk of injury.
	<ul> <li>Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions.</li> </ul>
	▶ Secure the vehicle against rolling away (▷ page 159).
	• Leave the vehicle and keep a safe distance from the vehicle until the engine has cooled down.
	Make sure that the air supply to the engine radiator is not blocked, e.g. by snow, slush or ice.
	<ul> <li>Do not start the engine again until the display message goes out and the coolant temperature is below 248 °F (120 °C).</li> <li>Otherwise, the engine could be damaged.</li> </ul>
	Pay attention to the coolant temperature display.
	If the temperature increases again, visit a qualified specialist workshop immediately.
	Under normal operating conditions and with the specified coolant level, the coolant temperature may rise to 248 $^{\circ}$ F (120 $^{\circ}$ C).

Display messages	Possible causes/consequences and Solutions
	<ul> <li>The battery is not being charged.</li> <li>A warning tone also sounds.</li> <li>Possible causes are: <ul> <li>a defective alternator</li> <li>a torn poly-V-belt</li> <li>a malfunction in the electronics</li> </ul> </li> <li>Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions.</li> <li>Secure the vehicle against rolling away (▷ page 159).</li> <li>Open the hood.</li> <li>Check whether the poly-V-belt is torn.</li> </ul> <li>If the poly-V-belt is torn: <ul> <li>Do not continue driving. The engine could otherwise overheat.</li> <li>Consult a qualified specialist workshop.</li> </ul> </li> <li>If the poly-V-belt is not damaged: <ul> <li>Visit a qualified specialist workshop.</li> </ul> </li>
Check Engine Oil At Next Refueling	<ul> <li>The engine oil level has dropped to the minimum level.</li> <li>A warning tone also sounds.</li> <li>Check the oil level when next refueling, at the latest (▷ page 275).</li> <li>If necessary, add engine oil (▷ page 276).</li> <li>Have the engine checked at a qualified specialist workshop if engine oil needs to be added more often than usual.</li> <li>Avoid long journeys with too little engine oil. The engine will otherwise be damaged.</li> <li>Information on approved engine oils can be obtained from any qualified specialist workshop or on the Internet at http://bevo.mercedes-benz.com.</li> </ul>

Display messages	Possible causes/consequences and Solutions
Check Engine Oil Level (Add 1 quart)	<ul> <li>AMG vehicles: the engine oil level is too low.</li> <li>Check the oil level when next refueling, at the latest (▷ page 275).</li> <li>If necessary, add engine oil (▷ page 276).</li> <li>Have the engine checked at a qualified specialist workshop if engine oil needs to be added more often than usual.</li> </ul>
	<ul> <li>Avoid long journeys with too little engine oil. The engine will otherwise be damaged.</li> <li>Information on approved engine oils can be obtained from any qualified specialist workshop or on the Internet at http://bevo.mercedes-benz.com.</li> </ul>
Fuel Level Low	<ul><li>The fuel level has dropped into the reserve range.</li><li>▶ Refuel at the nearest gas station.</li></ul>
	<ul><li>There is only a very small amount of fuel in the fuel tank.</li><li>▶ Refuel at the nearest gas station without fail.</li></ul>
Gas Cap Loose	<ul> <li>The fuel system pressure is too low. The fuel filler cap is not closed correctly or the fuel system is leaking.</li> <li>Check that the fuel filler cap is correctly closed.</li> <li>If the fuel filler cap is not correctly closed:</li> <li>Close the fuel filler cap.</li> <li>If the fuel filler cap is correctly closed:</li> <li>Visit a qualified specialist workshop.</li> </ul>

Driving systems	
Display messages	Possible causes/consequences and Solutions
Attention Assist: Take a Break!	<ul> <li>Based on certain criteria, ATTENTION ASSIST has detected fatigue or a lack of concentration on the part of the driver. A warning tone also sounds.</li> <li>If necessary, take a break.</li> </ul>
	During long journeys, take regular breaks in good time so you get enough rest.
Attention Assist Inoperative	<ul><li>ATTENTION ASSIST is inoperative.</li><li>Visit a qualified specialist workshop.</li></ul>

Display messages	Possible causes/consequences and Solutions
HOLD Off	<ul> <li>The HOLD function is deactivated. the vehicle is skidding.</li> <li>A warning tone also sounds.</li> <li>▶ Reactivate the HOLD function later (▷ page 179).</li> </ul>
Radar Sensors Deactivated See Operator's Manual	<ul> <li>The radar sensor system is deactivated.</li> <li>▶ Switch on the radar sensor system (▷ page 205).</li> </ul>
Lane Keeping Assist Currently Unavailable See Operator's Manual	<ul> <li>Lane Keeping Assist is deactivated and temporarily inoperative. Possible causes are:</li> <li>the windshield in the camera's field of vision is dirty.</li> <li>visibility is impaired due to heavy rain, snow or fog.</li> <li>there are no lane markings for a longer period.</li> <li>the lane markings are worn, dark or covered, e.g. by dirt or snow.</li> <li>When the causes stated above no longer apply, the display message disappears.</li> <li>Lane Keeping Assist is operational again.</li> <li>If the display message does not disappear:</li> <li>Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.</li> <li>Secure the vehicle against rolling away (▷ page 159).</li> <li>Clean the windshield.</li> </ul>
Lane Keeping Assist Inoperative	Lane Keeping Assist is faulty. ▶ Visit a qualified specialist workshop.

Display messages	Possible causes/consequences and Solutions
Blind Spot Assist Currently Unavailable See Operator's Manual	<ul> <li>Blind Spot Assist is temporarily inoperative. Possible causes are:</li> <li>the sensors are dirty.</li> <li>function is impaired due to heavy rain or snow.</li> <li>the radar sensor system is outside the operating temperature range.</li> <li>the radar sensor system is temporarily inoperative, e.g. due to electromagnetic radiation emitted by nearby TV or radio stations or other sources of electromagnetic radiation.</li> <li>The yellow  indicator lamps also light up in the exterior mirrors.</li> <li>When the causes stated above no longer apply, the display message disappears.</li> <li>Blind Spot Assist is operational again.</li> <li>If the display message does not disappear:</li> <li>Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.</li> <li>Secure the vehicle against rolling away (▷ page 159).</li> <li>Clean the sensors (▷ page 283).</li> <li>Restart the engine.</li> </ul>
Blind Spot Assist Inoperative	<ul> <li>Blind Spot Assist is defective.</li> <li>The yellow ▲ indicator lamps also light up in the exterior mirrors.</li> <li>Visit a qualified specialist workshop.</li> </ul>
Parking Guidance Inoperative	<ul> <li>Parking Guidance is malfunctioning (▷ page 183).</li> <li>▶ Restart the engine.</li> <li>If the display message continues to be displayed:</li> <li>▶ Visit a qualified specialist workshop.</li> </ul>

Display messages	Possible causes/consequences and ► Solutions
Parking Guidance Canceled	<ul> <li>Parking Guidance is deactivated. Possible causes are:</li> <li>the vehicle is skidding.</li> <li>the sensors are dirty.</li> <li>a malfunction has occurred.</li> <li>A warning tone also sounds.</li> <li>Reactivate Parking Guidance later (▷ page 183).</li> <li>If the parking space symbol does not appear in the multifunction display at speeds below 19 mph (30 km/h):</li> <li>Clean the sensors (▷ page 283).</li> <li>Restart the engine.</li> <li>If the parking space symbol still does not appear in the multifunction display at speeds below 19 mph (30 km/h):</li> <li>Visit a qualified specialist workshop.</li> </ul>
	<ul> <li>Parking Guidance has been deactivated because you are no longer following the recommended path.</li> <li>Park again and, while doing so, observe the display messages in the multifunction display.</li> </ul>
Parking Guidance Finished	The vehicle is parked. A warning tone also sounds. The display message disappears automatically.
DISTRONIC PLUS Off	DISTRONIC PLUS has been deactivated (> page 169). If it was deactivated automatically, a warning tone also sounds.
DISTRONIC PLUS available again	DISTRONIC PLUS is operational again after having been temporarily unavailable. You can now reactivate DISTRONIC PLUS (▷ page 169).

Display messages	Possible causes/consequences and Solutions
DISTRONIC PLUS Currently Unavailable See Operator's Manual	<ul> <li>DISTRONIC PLUS is temporarily inoperative. Possible causes are:</li> <li>function is impaired due to heavy rain or snow.</li> <li>the sensors in the radiator grill and the bumper are dirty.</li> <li>the radar sensor system is temporarily inoperative, e.g. due to electromagnetic radiation emitted by nearby TV or radio stations or other sources of electromagnetic radiation.</li> <li>the system is outside the operating temperature range.</li> <li>the on-board voltage is too low.</li> <li>A warning tone also sounds.</li> <li>When the causes stated above no longer apply, the display message disappears.</li> <li>DISTRONIC is operational again.</li> <li>If the display message does not disappear:</li> <li>Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.</li> <li>Secure the vehicle against rolling away (▷ page 159).</li> <li>Clean the sensors in the radiator grill and the bumper (▷ page 283).</li> <li>Restart the engine.</li> </ul>
DISTRONIC PLUS Inoperative	<ul> <li>DISTRONIC PLUS is defective.</li> <li>BAS PLUS (Brake Assist PLUS) and PRE-SAFE<sup>®</sup> Brake may be inoperative as well.</li> <li>A warning tone also sounds.</li> <li>Visit a qualified specialist workshop.</li> </ul>
DISTRONIC PLUS Passive	You have depressed the accelerator pedal. DISTRONIC PLUS is no longer controlling the speed of the vehicle. ► Remove your foot from the accelerator pedal.
DISTRONIC PLUS mph	<ul> <li>An activation condition for DISTRONIC PLUS is not fulfilled.</li> <li>► Check the activation conditions for DISTRONIC PLUS (▷ page 169).</li> </ul>

Display messages	Possible causes/consequences and Solutions
Cruise Control Inoperative	<ul><li>Cruise control is defective.</li><li>A warning tone also sounds.</li><li>▶ Visit a qualified specialist workshop.</li></ul>
Cruise Control mph	<ul> <li>A condition for activating cruise control has not been fulfilled.</li> <li>You have tried to store a speed below 20 mph (30 km/h), for example.</li> <li>▶ If conditions permit, drive faster than 20 mph (30 km/h) and store the speed.</li> <li>▶ Check the activation conditions for cruise control (▷ page 167).</li> </ul>

Tires		
Display messages	Possible causes/consequences and Solutions	
Check Tire Pressure Soon	Canada only: The tire pressure loss warning system has detected a significant loss in pressure. A warning tone also sounds.	
	MARNING	
	With tire pressures which are too low, there is a risk of the following hazards:	
	<ul> <li>they may burst, especially as the load and vehicle speed increase.</li> </ul>	
	• they may wear excessively and/or unevenly, which may greatly impair tire traction.	
	• the driving characteristics, as well as steering and braking, may be greatly impaired.	
	There is a risk of an accident.	
	<ul> <li>Stop the vehicle without making any sudden steering or braking maneuvers. Pay attention to the traffic conditions as you do so.</li> <li>Secure the vehicle against rolling away (▷ page 159).</li> <li>Check the tires and, if necessary, follow the instructions for a flat tire (▷ page 289).</li> <li>Check the tire pressures and, if necessary, correct the tire pressure.</li> <li>Restart the tire pressure loss warning system when the tire pressure is correct (▷ page 214).</li> </ul>	
	pressure is correct (⊳ page 314).	
Check Tire Pressure Then Restart Run Flat Indicator	<ul> <li>Canada only:</li> <li>The tire pressure loss warning system generated a display message and has not been restarted since.</li> <li>▶ Set the correct tire pressure in all four tires.</li> <li>▶ Restart the tire pressure loss warning system (&gt; page 314).</li> </ul>	
Run Flat Indicator Inoperative	<ul><li>Canada only:</li><li>The tire pressure loss warning system is faulty.</li><li>► Visit a qualified specialist workshop.</li></ul>	
Please Correct Tire Pressure	<ul> <li>The tire pressure is too low in at least one of the tires, or the tire pressure difference between the wheels is too great.</li> <li>Check the tire pressures at the next opportunity (▷ page 314).</li> <li>If necessary, correct the tire pressure.</li> <li>Restart the tire pressure monitor (▷ page 317).</li> </ul>	

Display messages	Possible causes/consequences and ► Solutions
Check Tires	The tire pressure in one or more tires has dropped significantly. The wheel position is displayed in the multifunction display. A warning tone also sounds.
	With tire pressures which are too low, there is a risk of the following hazards:
	<ul> <li>they may burst, especially as the load and vehicle speed increase.</li> </ul>
	• they may wear excessively and/or unevenly, which may greatly impair tire traction.
	• the driving characteristics, as well as steering and braking, may be greatly impaired.
	There is a risk of an accident.
	Stop the vehicle without making any sudden steering or braking maneuvers. Pay attention to the traffic conditions as you do so.
	<ul> <li>Secure the vehicle against rolling away (▷ page 159).</li> <li>Check the tires and, if necessary, follow the instructions for a flat tire (▷ page 289).</li> </ul>
	► Check the tire pressure (▷ page 314).
	► If necessary, correct the tire pressure.
Warning Tire Malfunction	The tire pressure in one or more tires has dropped suddenly. The wheel position is shown in the multifunction display.
	If you drive with a flat tire, there is a risk of the following hazards:
	<ul> <li>a flat tire affects the ability to steer or brake the vehicle.</li> <li>you could lose control of the vehicle.</li> </ul>
	<ul> <li>continued driving with a flat tire will cause excessive heat build- up and possibly a fire.</li> </ul>
	There is a risk of an accident.
	<ul> <li>Stop the vehicle without making any sudden steering or braking maneuvers. Pay attention to the traffic conditions as you do so.</li> <li>Secure the vehicle against rolling away (▷ page 159).</li> <li>Check the tires and, if necessary, follow the instructions for a flat tire (▷ page 289).</li> </ul>
	nat the (> page 207).

Display messages	Possible causes/consequences and ► Solutions
Tire Pressure Monitor Currently	Due to a source of radio interference, no signals can be received from the wheel sensors. The tire pressure monitor is temporarily malfunctioning.
Unavailable	Drive on. The tire pressure monitor restarts automatically as soon as the problem has been solved.
TirePress. Sensor(s) Missing	<ul> <li>There is no signal from the tire pressure sensor of one or several wheels. The pressure of the affected tire is not displayed in the multifunction display.</li> <li>► Have the faulty tire pressure sensor replaced at a qualified specialist workshop.</li> </ul>
Tire Pressure Monitor Inoperative No Wheel Sensors	<ul> <li>The wheels mounted do not have a suitable tire pressure sensor.</li> <li>The tire pressure monitor is deactivated.</li> <li>▶ Mount wheels with suitable tire pressure sensors.</li> <li>The tire pressure monitor is activated automatically after driving for a few minutes.</li> </ul>
Tire Pressure Monitor Inoperative	<ul><li>The tire pressure monitor is faulty.</li><li>▶ Visit a qualified specialist workshop.</li></ul>

Vehicle	
Display messages	Possible causes/consequences and Solutions
Shift to 'P' or 'N'	You have attempted to start the engine with the transmission in position <b>R</b> or <b>D</b> .
to Start Engine	► Shift the transmission to position <b>P</b> or <b>N</b> .
Apply Brake	You have attempted to move the transmission selector lever to position <b>D</b> , <b>R</b> or <b>N</b> without depressing the brake pedal.
to Shift from 'P'	▶ Depress the brake pedal.

Display messages	Possible causes/consequences and ► Solutions
Risk of Rolling Transmission Not in P	You have switched off the engine with the Start/Stop button and opened the driver's door. You wanted to lock the vehicle. A warning tone also sounds. or You have turned off the engine with the Start/Stop button and opened the driver's door while the transmission was in position <b>N</b> . ► Shift the transmission to position <b>P</b> .
	<ul> <li>While the HOLD function or DISTRONIC PLUS is active, you have:</li> <li>opened the driver's door and released the seat belt or</li> <li>switched off the engine or</li> <li>opened the hood</li> <li>A tone may also sound at regular intervals. If you attempt to lock the vehicle, the tone becomes louder.</li> <li>You cannot start the engine.</li> <li>Shift the transmission to position P. You can restart the engine.</li> </ul>
Service Required, Do Not Shift Gears Visit Dealer	<ul> <li>You cannot change the transmission position due to a malfunction.</li> <li>A warning tone also sounds.</li> <li>If transmission position D is selected:</li> <li>Drive to a qualified specialist workshop without shifting the transmission from position D.</li> <li>If transmission position R, N or P is selected:</li> <li>Notify a qualified specialist workshop or breakdown service.</li> </ul>
~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	The trunk lid is open. ► Close the trunk lid.
	<ul> <li>The hood is open.</li> <li>▲ WARNING</li> <li>The open hood may block your view when the vehicle is in motion.</li> <li>There is a risk of an accident.</li> <li>Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.</li> <li>▶ Secure the vehicle against rolling away (▷ page 159).</li> <li>▶ Close the hood.</li> </ul>

Display messages	Possible causes/consequences and ► Solutions
	<ul><li>At least one door is open. A warning tone also sounds.</li><li>▶ Close all the doors.</li></ul>
Power Steering Malfunction See Operator's Manual	<ul> <li>The power steering is malfunctioning.</li> <li>A warning tone also sounds.</li> <li>WARNING</li> <li>You will need to use more force to steer.</li> <li>There is a risk of an accident.</li> <li>Check whether you are able to apply the extra force required.</li> <li>If you are able to steer safely: carefully drive on to a qualified specialist workshop.</li> <li>If you are unable to steer safely: do not drive on. Contact the nearest qualified specialist workshop.</li> </ul>
تیں Trunk Partition Open	<ul><li>The trunk partition is open.</li><li>▶ Close the trunk partition (▷ page 89).</li></ul>
Phone No Service	<ul> <li>Your vehicle is outside the network provider's transmitter/ receiver range.</li> <li>▶ Wait until the mobile phone operational readiness symbol appears in the multifunction display.</li> </ul>
Decrease Speed	<ul> <li>You wanted to open the roof while the vehicle was in motion.</li> <li>Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.</li> <li>Open the roof (▷ page 87).</li> </ul>
Vario-Roof Lowering	<ul> <li>The roof is not fully opened or closed. The hydraulics are depressurized.</li> <li>Fully open or close the roof (▷ page 87).</li> </ul>
Open/Close Vario- Roof Completely	<ul> <li>The roof is not locked.</li> <li>Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.</li> <li>Push or pull the roof switch until the roof is fully open or closed (▷ page 87).</li> </ul>

Display messages	Possible causes/consequences and Solutions
Start Engine See Operator's Manual	<ul> <li>The on-board voltage is too low.</li> <li>Start the engine.</li> <li>Repeat the opening/closing process after approximately ten seconds (▷ page 87).</li> </ul>
	<ul> <li>The roof has been opened and closed several times in a row. The roof drive has been switched off automatically for safety reasons.</li> <li>You can open and close the roof again after approximately ten minutes.</li> <li>▶ Switch off the ignition and turn it back on.</li> <li>▶ Repeat the opening or closing procedure (▷ page 87).</li> </ul>
Close Rear Side Windows	<ul> <li>You wish to leave the vehicle and at least one of the rear side windows is open.</li> <li>▶ Close the rear side windows (▷ page 83).</li> </ul>
Check Washer Fluid	<ul> <li>The washer fluid level in the washer fluid reservoir has dropped below the minimum.</li> <li>► Add washer fluid (▷ page 277).</li> </ul>
Wiper Malfunctioning	<ul><li>The windshield wipers are malfunctioning.</li><li>▶ Visit a qualified specialist workshop.</li></ul>
Hazard Warning Flashers Malfunctioning	<ul><li>The hazard warning lamps are faulty.</li><li>▶ Visit a qualified specialist workshop.</li></ul>

# SmartKey

Display messages	Possible causes/consequences and Solutions
Key Does Not Belong to Vehicle	You have put the wrong SmartKey in the ignition lock. ► Use the correct SmartKey.
Take Your Key from Ignition	<ul><li>The SmartKey is in the ignition lock.</li><li>▶ Remove the SmartKey.</li></ul>
Obtain a New Key	<ul><li>The SmartKey needs to be replaced.</li><li>▶ Visit a qualified specialist workshop.</li></ul>

Display messages	Possible causes/consequences and ► Solutions
Replace Key Battery	<ul> <li>The batteries of the KEYLESS-GO key are discharged.</li> <li>▶ Change the batteries (▷ page 73).</li> </ul>
Don't Forget Your Key	<ul> <li>The display message is shown for a maximum of 60 seconds and is only a reminder.</li> <li>You have opened the driver's door with the engine switched off. The KEYLESS-GO key is not in the ignition lock.</li> <li>Remember to take the KEYLESS-GO key with you when you leave the vehicle.</li> </ul>
Key not detected (red display message)	<ul> <li>The KEYLESS-GO key is not in the vehicle.</li> <li>A warning tone also sounds.</li> <li>If the engine is switched off, you can no longer lock the vehicle centrally or start the engine.</li> <li>▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.</li> <li>▶ Secure the vehicle against rolling away (▷ page 159).</li> <li>▶ Locate the KEYLESS-GO key.</li> </ul>
	<ul> <li>The KEYLESS-GO key is not detected while the engine is running because there is interference from a strong source of radio waves.</li> <li>A warning tone also sounds.</li> <li>Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.</li> <li>Secure the vehicle against rolling away (&gt; page 159).</li> <li>Operate the vehicle with the SmartKey in the ignition lock.</li> </ul>
Key Not Detected (white display message)	<ul> <li>The KEYLESS-GO key cannot be detected at present.</li> <li>Change the location of the SmartKey with the KEYLESS-GO functions in the vehicle.</li> <li>If the KEYLESS-GO key is still not detected:</li> <li>Operate the vehicle with the SmartKey in the ignition lock.</li> </ul>
Key Detected in Vehicle	<ul><li>The KEYLESS-GO key has been detected inside the vehicle during locking.</li><li>▶ Remove the KEYLESS-GO key from the vehicle.</li></ul>

	Display messages	Possible causes/consequences and ► Solutions
	Remove 'Start' Button and Insert Key	The KEYLESS-GO key can continuously not be detected. KEYLESS-GO is temporarily malfunctioning or is defective. A warning tone also sounds.
		<ul> <li>Insert the SmartKey into the ignition lock and turn it to the desired position.</li> <li>Visit a qualified specialist workshop.</li> </ul>
	Close Doors to Lock Vehicle	<ul><li>At least one door is open. A warning tone also sounds.</li><li>▶ Close all doors and lock the vehicle again.</li></ul>

# Warning and indicator lamps

# Safety

## Seat belts

Problem	Possible causes/consequences and Solutions
After starting the engine, the red seat belt warning lamp lights up for 6 seconds.	<ul> <li>The seat belt warning lamp reminds the driver and front passenger to fasten their seat belts.</li> <li>▶ Fasten your seat belt (▷ page 53).</li> </ul>
After starting the engine, the red seat belt warning lamp lights up. In addition, a warning tone sounds for up to six seconds.	<ul> <li>The driver's seat belt is not fastened.</li> <li>▶ Fasten your seat belt (▷ page 53). The warning tone ceases.</li> </ul>
The red seat belt warning lamp lights up after the engine starts, as soon as the driver's or the front-passenger door is closed.	<ul> <li>The driver or front passenger has not fastened their seat belt.</li> <li>▶ Fasten your seat belt (▷ page 53). The warning lamp goes out.</li> </ul>
	<ul> <li>There are objects on the front-passenger seat.</li> <li>Remove the objects from the front-passenger seat and stow them in a secure place.</li> <li>The warning lamp goes out.</li> </ul>

#### Problem



The red seat belt warning lamp flashes and an intermittent audible warning sounds.

#### Possible causes/consequences and ► Solutions

The driver or front passenger has not fastened their seat belt. The car is being driven faster than 15 mph (25 km/h) or has briefly been driven faster than 15 mph (25 km/h).

► Fasten your seat belt (▷ page 53). The warning lamp goes out and the intermittent warning tone ceases.

There are objects on the front-passenger seat. The car is being driven faster than 15 mph (25 km/h) or has briefly been driven faster than 15 mph (25 km/h).

▶ Remove the objects from the front-passenger seat and stow them in a secure place.

The warning lamp goes out and the intermittent warning tone ceases.

# Safety systems

Problem	Possible causes/consequences and Solutions
(USA only) (D) (Canada only) The red brake system warning lamp comes on while the engine is running. A warning tone also sounds.	<ul> <li>There is not enough brake fluid in the brake fluid reservoir.</li> <li>MARNING</li> <li>The braking effect may be impaired.</li> <li>There is a risk of an accident.</li> <li>Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.</li> <li>Secure the vehicle against rolling away (▷ page 159).</li> <li>Do not add brake fluid. Adding more will not remedy the malfunction.</li> <li>Consult a qualified specialist workshop.</li> <li>Observe the additional display messages in the multifunction display.</li> </ul>
(G) The yellow ABS warning lamp is lit while the engine is running.	<ul> <li>ABS (Anti-lock Braking System) is deactivated due to a malfunction. BAS (Brake Assist), BAS PLUS, ESP® (Electronic Stability Program), PRE-SAFE®, PRE-SAFE® Brake, the HOLD function and hill start assist are therefore also deactivated, for example.</li> <li>ATTENTION ASSIST is deactivated.</li> <li>MARNING</li> <li>The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example.</li> <li>The steerability and braking characteristics may be severely affected. The braking distance in an emergency braking situation can increase.</li> <li>If ESP® is not operational, ESP® is unable to stabilize the vehicle.</li> <li>There is an increased risk of skidding and an accident.</li> <li>Observe the additional display messages in the multifunction display.</li> <li>Drive on carefully.</li> <li>Visit a qualified specialist workshop.</li> <li>If the ABS control unit is faulty, there is also a possibility that other systems, such as the navigation system or the automatic</li> </ul>

#### Problem

#### (485)

The yellow ABS warning lamp is lit while the engine is running.

#### Possible causes/consequences and Solutions

ABS is temporarily unavailable. BAS, BAS PLUS, ESP<sup>®</sup>, EBD (electronic brake force distribution), PRE-SAFE<sup>®</sup>, PRE-SAFE<sup>®</sup> Brake, the HOLD function, hill start assist are therefore also deactivated, for example.

Possible causes are:

- self-diagnosis is not yet complete.
- the on-board voltage may be insufficient.

ATTENTION ASSIST is deactivated.

### MARNING

The brake system continues to function normally, but without the functions listed above. The front and rear wheels could therefore lock if you brake hard, for example.

The steerability and braking characteristics may be severely affected. The braking distance in an emergency braking situation can increase.

If ESP<sup>®</sup> is not operational, ESP<sup>®</sup> is unable to stabilize the vehicle.

There is a risk of an accident.

 Carefully drive a suitable distance, making slight steering movements at a speed above 12 mph (20 km/h). The functions mentioned above are available again when the warning lamp goes out.

If the warning lamp is still on:

- Observe the additional display messages in the multifunction display.
- ► Drive on carefully.
- ► Visit a qualified specialist workshop.

displays
and
computer
comp
oard
Qn-b

Problem

# (ABS)

The yellow ABS warning lamp is lit while the engine is running. A warning tone also sounds.

# BRAKE (USA only)

(Canada only)

# 

The red brake warning lamp, the yellow ESP® and ESP<sup>®</sup> OFF warning lamps and the yellow ABS warning lamp are lit while the engine is running.

#### Possible causes/consequences and Solutions

EBD is not available due to a malfunction. Therefore, ABS, BAS, BAS PLUS, ESP<sup>®</sup>, PRE-SAFE<sup>®</sup>, PRE-SAFE<sup>®</sup> Brake, the HOLD function and hill start assist are also unavailable, for example. ATTENTION ASSIST is deactivated.

#### **WARNING**

The brake system continues to function normally, but without the functions listed above. The front and rear wheels could therefore lock if you brake hard, for example.

The steerability and braking characteristics may be severely affected. The braking distance in an emergency braking situation can increase.

If ESP<sup>®</sup> is not operational, ESP<sup>®</sup> is unable to stabilize the vehicle. There is an increased risk of skidding and an accident.

- ▶ Observe the additional display messages in the multifunction display.
- ▶ Drive on carefully.
- ► Visit a qualified specialist workshop.

ABS and ESP<sup>®</sup> are not available due to a malfunction. Therefore, BAS, BAS PLUS, EBD, PRE-SAFE<sup>®</sup>, PRE-SAFE<sup>®</sup> Brake, the HOLD function and hill start assist, for example, are not available either. ATTENTION ASSIST is deactivated.

### **WARNING**

The brake system continues to function normally, but without the functions listed above. The front and rear wheels could therefore lock if you brake hard, for example.

The steerability and braking characteristics may be severely affected. The braking distance in an emergency braking situation can increase.

If ESP<sup>®</sup> is not operational, ESP<sup>®</sup> is unable to stabilize the vehicle. There is an increased risk of skidding and an accident.

- Observe the additional display messages in the multifunction display.
- ► Drive on carefully.
- Visit a gualified specialist workshop.

Problem	Possible causes/consequences and Solutions
The yellow ESP <sup>®</sup> warning lamp flashes while the vehicle is in motion.	<ul> <li>ESP<sup>®</sup> or traction control has intervened because there is a risk of skidding or at least one wheel has started to spin.</li> <li>Cruise control or DISTRONIC PLUS is deactivated.</li> <li>When pulling away, only depress the accelerator pedal as far as necessary.</li> <li>Ease off the accelerator pedal while the vehicle is in motion.</li> <li>Adapt your driving style to suit the road and weather conditions.</li> <li>Do not deactivate ESP<sup>®</sup>. For exceptions, see: (&gt; page 62).</li> </ul>
The yellow ESP <sup>®</sup> OFF warning lamp is lit while the engine is running.	<ul> <li>ESP<sup>®</sup> is deactivated.</li> <li>MARNING</li> <li>If ESP<sup>®</sup> is switched off, ESP<sup>®</sup> is unable to stabilize the vehicle. There is an increased risk of skidding and an accident.</li> <li>Reactivate ESP<sup>®</sup>. For exceptions, see: (▷ page 62).</li> <li>Adapt your driving style to suit the road and weather conditions.</li> <li>If ESP<sup>®</sup> cannot be activated:</li> <li>Drive on carefully.</li> <li>Have ESP<sup>®</sup> checked at a qualified specialist workshop.</li> </ul>
SPORT AMG vehicles only: The yellow SPORT handling mode warning lamp is lit while the engine is running.	<ul> <li>SPORT handling mode is activated.</li> <li>▲ WARNING</li> <li>When SPORT handling mode is switched on, ESP<sup>®</sup> is unable to stabilize the vehicle.</li> <li>There is an increased risk of skidding and an accident.</li> <li>♦ Only switch on SPORT handling mode in certain situations (▷ page 63).</li> </ul>

#### Problem

# 

The yellow ESP<sup>®</sup> and ESP<sup>®</sup> OFF warning lamps are lit while the engine is running.

#### Possible causes/consequences and Solutions

ESP<sup>®</sup>, BAS, BAS PLUS, PRE-SAFE<sup>®</sup>, PRE-SAFE<sup>®</sup> Brake, the HOLD function and hill start assist are not available due to a malfunction. ATTENTION ASSIST is deactivated.

#### MARNING

The brake system continues to function normally, but without the functions listed above.

The braking distance in an emergency braking situation can thus increase.

If ESP<sup>®</sup> is not operational, ESP<sup>®</sup> is unable to stabilize the vehicle. There is an increased risk of skidding and an accident.

- Observe the additional display messages in the multifunction display.
- ► Drive on carefully.
- ► Visit a qualified specialist workshop.

# R Coff

The yellow ESP<sup>®</sup> and ESP<sup>®</sup> OFF warning lamps are lit while the engine is running.  $\mathsf{ESP}^{\circledast},\mathsf{BAS},\mathsf{PRE}\text{-}\mathsf{SAFE}^{\circledast},\mathsf{the}\,\mathsf{HOLD}\,\mathsf{function}\,\mathsf{and}\,\mathsf{hill}\,\mathsf{start}\,\mathsf{assist}\,\mathsf{are}\,\mathsf{temporarily}\,\mathsf{unavailable}.$ 

BAS PLUS and PRE-SAFE<sup>®</sup> Brake may also have failed.

ATTENTION ASSIST is deactivated.

Self-diagnosis is not yet complete.

#### **▲** WARNING

The brake system continues to function normally, but without the functions listed above.

The braking distance in an emergency braking situation can thus increase.

If ESP<sup>®</sup> is not operational, ESP<sup>®</sup> is unable to stabilize the vehicle. There is an increased risk of skidding and an accident.

 Carefully drive a suitable distance, making slight steering movements at a speed above 12 mph (20 km/h). The functions mentioned above are available again when the warning lamp goes out.

If the warning lamp is still on:

- Observe the additional display messages in the multifunction display.
- ► Drive on carefully.
- ► Visit a qualified specialist workshop.

Problem	Possible causes/consequences and Solutions
PARK (USA only) (@) (Canada only) The red electric parking brake indicator lamp flashes or lights up and/or (@) warning lamp for the electric parking brake lights up.	Observe the additional display messages in the multifunction display.
The red SRS warning lamp is lit while the engine is running.	<ul> <li>There is a malfunction in the SRS (Supplemental Restraint System).</li> <li> MARNING </li> <li>The air bags or Emergency Tensioning Devices may either be triggered unintentionally or, in the event of an accident, may not be triggered.</li> <li>There is an increased risk of injury.</li> <li>Drive on carefully.</li> <li>Have SRS checked at a qualified specialist workshop immediately.</li> <li>For further information about the Supplemental Restraint System, see (▷ page 39).</li> </ul>

Engine	
Problem	Possible causes/consequences and ► Solutions
The yellow Check Engine warning lamp lights up while the engine is running.	<ul> <li>There may be a malfunction, for example:</li> <li>in the engine management</li> <li>in the fuel injection system</li> <li>in the exhaust system</li> <li>in the ignition system</li> <li>in the fuel system</li> <li>The emission limit values may be exceeded and the engine may be running in emergency mode.</li> <li>Have the vehicle checked as soon as possible at a qualified specialist workshop.</li> <li>In some states, you must immediately visit a qualified specialist workshop as soon as the yellow Check Engine warning lamp lights up. This depends on the locally applicable legal requirements. If in doubt, check whether such legal regulations apply in the state in which you are currently driving.</li> </ul>
The yellow reserve fuel warning lamp lights up while the engine is running.	<ul><li>The fuel level has dropped into the reserve range.</li><li>▶ Refuel at the nearest gas station.</li></ul>
The yellow reserve fuel warning lamp flashes while the vehicle is in motion. In addition, the Car Check Engine warning lamp may light up.	<ul> <li>The fuel system pressure is too low. The fuel filler cap is not closed correctly or the fuel system is leaking.</li> <li>Check that the fuel filler cap is correctly closed.</li> <li>If the fuel filler cap is not correctly closed: close the fuel filler cap.</li> <li>If the fuel filler cap is closed: visit a qualified specialist workshop.</li> </ul>
The red coolant warning lamp lights up while the engine is running and the coolant temperature gauge is at the start of the scale.	<ul> <li>The temperature sensor for the coolant temperature gauge is defective.</li> <li>The coolant temperature is no longer being monitored. There is a risk of engine damage if the coolant temperature is too high.</li> <li>Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions. Do not continue driving under any circumstances.</li> <li>Secure the vehicle against rolling away (▷ page 159).</li> <li>Consult a qualified specialist workshop.</li> </ul>

Problem	Possible causes/consequences and ► Solutions
	· ·
The red coolerat	The coolant level is too low.
The red coolant warning lamp comes on while the engine is	If the coolant level is correct, the airflow to the engine radiator may be blocked or the electric engine radiator fan may be malfunctioning.
running.	The coolant is too hot and the engine is no longer being cooled sufficiently.
	<ul> <li>Observe the additional display messages in the multifunction display.</li> </ul>
	Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions.
	► Secure the vehicle against rolling away (▷ page 159).
	Leave the vehicle and keep a safe distance from the vehicle until the engine has cooled down.
	► Check the coolant level and add coolant, observing the warning notes (▷ page 277).
	If you need to add coolant more often than usual, have the engine coolant system checked.
	Make sure that the air supply to the engine radiator is not blocked, e.g. by snow, slush or ice.
	<ul> <li>Do not start the engine again until the coolant temperature is below 248 °F (120 °C). Otherwise, the engine could be damaged.</li> <li>Drive to the nearest qualified specialist workshop.</li> </ul>
	<ul> <li>Avoid subjecting the engine to heavy loads, e.g. driving in mountainous terrain, and stop-and-go traffic.</li> </ul>
تعلیہ) The red coolant warning lamp comes on	The coolant temperature has exceeded 248 °F (120 °C). The airflow to the engine radiator may be blocked or the coolant level may be too low.
while the engine is	MARNING
running. A warning tone also sounds.	The engine is not being cooled sufficiently and may be damaged.
	Do not drive when your engine is overheated. This can cause some fluids which may have leaked into the engine compartment to

catch fire.

Steam from the overheated engine can also cause serious burns which can occur just by opening the hood.

There is a risk of injury.

- Observe the additional display messages in the multifunction display.
- ▶ Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions.
- ► Secure the vehicle against rolling away (▷ page 159).

Problem	Possible causes/consequences and ► Solutions
	• Leave the vehicle and keep a safe distance from the vehicle until the engine has cooled down.
	► Check the coolant level and add coolant, observing the warning notes (▷ page 277).
	If you need to add coolant more often than usual, have the engine coolant system checked.
	Make sure that the air supply to the engine radiator is not blocked, e.g. by snow, slush or ice.
	► At coolant temperatures below 248 °F (120 °C), drive to the next qualified specialist workshop.
	Avoid subjecting the engine to heavy loads, e.g. driving in mountainous terrain, and stop-and-go traffic.
Driving systems	
Problem	Possible causes/consequences and Solutions
A The red distance	You are approaching a vehicle or a stationary obstacle in your line of travel at too high a speed.
warning lamp lights up	Be prepared to brake immediately.
while the vehicle is in motion. A warning tone	Pay careful attention to the traffic situation. You may have to brake or take evasive action.
also sounds.	Eurther information on DISTRONIC PLUS (Nanage 160)

Further information on DISTRONIC PLUS ( $\triangleright$  page 169). Further information on PRE-SAFE<sup>®</sup> Brake ( $\triangleright$  page 65).

Tires	
Problem	Possible causes/consequences and ► Solutions
(1) The yellow tire pressure monitor warning lamp (pressure loss/ malfunction) is lit.	The tire pressure monitor has detected a loss of pressure in at least one of the tires.
	With tire pressures which are too low, there is a risk of the following hazards:
	<ul> <li>they may burst, especially as the load and vehicle speed increase.</li> </ul>
	• they may wear excessively and/or unevenly, which may greatly impair tire traction.
	<ul> <li>the driving characteristics, as well as steering and braking, may be greatly impaired.</li> </ul>
	There is a risk of an accident.
	<ul> <li>Stop the vehicle without making any sudden steering or braking maneuvers. Pay attention to the traffic conditions as you do so.</li> <li>Secure the vehicle against rolling away (&gt; page 159).</li> </ul>
	<ul> <li>Observe the additional display messages in the multifunction display.</li> </ul>
	► Check the tires and, if necessary, follow the instructions for a flat tire (▷ page 289).
	► Check the tire pressure (▷ page 314).
	► If necessary, correct the tire pressure.
⟨!⟩         The yellow tire pressure monitor warning lamp (pressure loss/ malfunction) flashes for approximately one minute and then remains lit.	The tire pressure monitor is faulty.
	The system is possibly unable to recognize or register low tire pressure.
	There is a risk of an accident.
	<ul> <li>Observe the additional display messages in the multifunction display.</li> </ul>
	Visit a qualified specialist workshop.

253

#### **Useful information**

- This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- Read the information on qualified specialist workshops: (▷ page 24).

#### Stowage areas

Stowage space


#### Important safety notes

#### 

If you do not correctly store objects in the vehicle interior, they can slip or be flung around, thus striking vehicle occupants. There is a risk of injury, especially when braking or abruptly changing directions.


- Always store objects so that they cannot be flung around in these or in similar situations.
- Always make sure that objects do not protrude from stowage compartments, parcel nets or stowage nets.
- Close lockable stowage compartments while driving.
- Stow and secure objects that are heavy, hard, pointy, sharp-edged, fragile or too large in the trunk.

#### Glove box



- ► **To open:** pull handle ① and open glove box flap ②.
- ► To close: fold glove box flap ② upwards until it engages.

The glove box flap contains brackets for coins, pens, and credit and service cards.



The glove box can be locked and unlocked using the mechanical key.

- ► **To lock:** insert the mechanical key into the lock and turn it to position **2**.
- ► **To unlock:** insert the mechanical key into the lock and turn it to position 1.

# Stowage compartment/telephone compartment under the armrest



► **To open:** push button ① up and raise armrest ②.

The stowage compartment can be locked and unlocked centrally using the SmartKey (> page 70).

Depending on the vehicle's equipment, a 12 V socket, a USB socket, and an AUX IN connection or Media Interface are installed in the stowage compartment. A Media Interface is a universal interface for mobile audio equipment, e.g. for an iPod<sup>®</sup> or MP3 player (see the separate COMAND Operating Instructions).

# **Eyeglasses compartment**



▶ To open: press marking ①.

Make sure that the eyeglasses compartment is always closed while the vehicle is in motion.


# Stowage compartment in the center console



- To open: briefly press the lower section of cover ①.
- ► To remove the insert: pull the left-hand side of the insert up and out.
- ► To install the insert: press the insert into the housing.

Depending on the vehicle equipment, there may be an ashtray in the center console instead of a storage compartment.


# Stowage compartment in the doors



In the door trim, there is a ruffled pocket ② with storage slot ①.

# Stowage box in the rear wall between the seats

A ruffled pocket is located on the rear wall between the seats.




Ruffled pocket

#### Stowage net


Stowage nets are located in the frontpassenger footwell and on the rear wall behind the driver's seat.

#### Reversible floor panel in the trunk

Using the flat side of the reversible floor panel will give you a level trunk. If you turn the reversible floor panel over, you can transport objects, for example a drinks crate, on it.



- ► To turn over: pull up reversible floor panel ② using strap ①.
- Turn over reversible floor panel (2) and reinsert it.



Attached to the reversible floor panel are two flexible straps ② that you can use to secure objects, for example wind screen ③, when reversible floor panel ① has been turned over.

# **Roof carrier**

This vehicle is not designed to transport items on the roof. Roof carriers and other devices which are mounted on the roof that have not been specifically approved for this model by Mercedes-Benz must not be used as they could damage the vehicle and the retractable hardtop (vario-roof).

At the time of going to print, Mercedes-Benz does not offer any roof carrier or other roof-installed devices for this model.

This vehicle is not designed to transport any items on the trunk lid or to allow luggage carriers or equipment of any kind to be installed to the trunk lid. Otherwise the vehicle and the retractable hardtop could be damaged.

## Features

#### Cup holder

#### Important safety notes

Only use the cup holders for containers of the right size and which have lids. The drinks could otherwise spill.

Cup holder in the center console



- ► To open: slide cover ② back.
- ► To remove the insert: slide catch ① inwards on both sides in the direction of the arrow.
- ▶ Remove the cup holder insert upwards.
- ► To re-install the insert: place the insert in the stowage space.
- Slide catch ① outwards in the direction of the arrow until it engages.

You can remove the cup holder insert for cleaning. Clean with clear, lukewarm water only.

## **Bottle holder**

Observe the "Important safety notes" in the "Stowage compartments" section (> page 254).

Make sure that any bottles weighing more than 1.1 lb(0.5 kg) that are stored in the bottle holder, rest on the vehicle floor. The bottle holder could otherwise be damaged.



- Press the outer edge of button ① and slide in the direction of the arrow until the bottle fits into the opening.
- Insert the bottle into the bottle holder.

The bottle holder is suitable for bottles with a capacity of 25 fl. oz. (0.7 l) to 54 fl. oz. (1.5 l).

The bottle holder does not secure the bottles; it merely prevents them from tipping over.


## Sun visors

#### Overview

#### MARNING

If the mirror cover of the vanity mirror is folded up when the vehicle is in motion, you could be blinded by incident light. There is a risk of an accident.

Always keep the mirror cover folded down while driving.



- Mirror light
- Bracket
- ③ Retaining strip, e.g. for a parking lot ticket
- ④ Vanity mirror
- 5 Mirror cover
- When driving at high speeds with the side window or roof open:

If you have inserted a car park ticket into retaining strip ③, make sure that it is not blown away by the wind.

# Vanity mirror in the sun visor

Mirror light ① only functions if the sun visor is clipped into bracket ② and mirror cover ⑤ has been folded up.

## Glare from the side

- ► Fold down the sun visor.
- Pull the sun visor out of retainer 2.
- Swing the sun visor to the side.
- ► Slide the sun visor horizontally as desired.

#### Ashtray



► To open: push the lower section of cover ①.

The cover opens.

- ► To remove the insert: lift insert ③ up ② and out.
- To re-install the insert: press insert ③ into the holder until it engages.

#### **Cigarette lighter**

# MARNING

You can burn yourself if you touch the hot heating element or the socket of the cigarette lighter.

In addition, flammable materials can ignite if:

- the hot cigarette lighter falls
- a child holds the hot cigarette lighter to objects, for example

There is a risk of fire and injury.

Always hold the cigarette lighter by the knob. Always make sure that the cigarette lighter is out of reach of children. Never leave children unsupervised in the vehicle.



Your attention must always be focused on the traffic conditions. Only use the cigarette lighter when road and traffic conditions permit.

- ► Turn the SmartKey to position 2 in the ignition lock (▷ page 139).
- ► **To open:** push the lower section of cover ①.

The ashtray opens.

 Press in cigarette lighter (2).
 Cigarette lighter (2) will pop out automatically when the heating element is red-hot.

#### 12 V sockets

#### General notes

- If you are using all sockets in the vehicle, make sure that you do not exceed the maximum current draw of 55 A. Otherwise, you will overload the fuses.
- ► Turn the SmartKey to position 1 in the ignition lock (▷ page 139).

The sockets can be used for accessories with a maximum draw of 180 W (15 A). Accessories include such items as lamps or chargers for mobile phones. If you use the sockets for long periods when the engine is switched off, the battery may discharge.

• An emergency cut-out ensures that the on-board voltage does not drop too low. If the on-board voltage is too low, the power to the sockets is automatically cut. This ensures that there is sufficient power to start the engine.

#### Socket under the armrest



- ► Open the stowage compartment under the armrest (▷ page 255).
- ▶ Lift up the cover of socket ①.

On vehicles without ashtrays or lighters, there is an additional socket in the center console.

# Socket in the front-compartment center console



► To open: push the lower section of cover ①.

The stowage compartment opens.

▶ Lift up the cover of socket ②.

#### mbrace

## General notes

You must have a license agreement to activate the mbrace service. Make sure that your system is activated and operational. To log in, press the **S** MB Info call button. If any of the steps mentioned are not carried out, the system may not be activated.

If you have questions about the activation, contact one of the following telephone hotlines:

 USA: Mercedes-Benz Customer Assistance Center at 1-800-FOR-MERCedes (1-800-367-6372)

1-800-FOR-MERCedes (1-800-367-6372) or 1-866-990-9007

• Canada: Customer Service at 1-888-923-8367

Shortly after successfully registering with the service, a user ID and password will be sent to you by post.

USA only: you can use this password to log onto the mbrace area under "Owners Online" at **http://www.mbusa.com**.

The system is available if:

- it has been activated and is operational
- the corresponding mobile phone network is available for transmitting data to the Customer Center
- a service subscription is available
- the starter battery is sufficiently charged
- Determining the location of the vehicle on a map is only possible if:
  - GPS reception is available.
  - the vehicle position can be forwarded to the Customer Assistance Center.

#### The mbrace system

To adjust the volume during a call, proceed as follows:

Press the + or - button on the multifunction steering wheel.

or

 Use the volume controller of the audio system/COMAND.

The system offers various services, e.g:

- Automatic and manual emergency call
- Roadside Assistance call
- MB Info call

USA only: you can find information and a description of all available features under "Owners Online" at http://www.mbusa.com.

# System self-test

After you have switched on the ignition, the system carries out a self-diagnosis.

A malfunction in the system has been detected if one of the following occurs:

- The indicator lamp in the SOS button does not come on during the system self-test.
- The indicator lamp in the Set Roadside Assistance button does not light up during self-diagnosis of the system.
- The indicator lamp in the <u>S</u> MB Info call button does not light up during selfdiagnosis of the system.
- The indicator lamp in one or more of the following buttons continues to light up red after the system self-diagnosis:
  - SOS button
  - 🚱 Roadside Assistance call button
  - 🕓 👔 MB Info call button
- After the system self-diagnosis, the Inoperative or Service Not Activated message appears in the multifunction display.

If a malfunction is indicated as outlined above, the system may not operate as

expected. In the event of an emergency, help will have to be summoned by other means.

Have the system checked at the nearest authorized Mercedes-Benz Center or contact the following service hotlines:

- USA: Mercedes-Benz Customer Assistance Center at 1-800-FOR-MERCedes (1-800-367-6372) or 1-866-990-9007
- Canada: Customer Service at 1-888-923-8367

## Emergency call

#### Important safety notes

# MARNING

It can be dangerous to remain in the vehicle, even if you have pressed the SOS button in an emergency if:

- you see smoke inside or outside of the vehicle, e.g. if there is a fire after an accident
- the vehicle is on a dangerous section of road
- the vehicle is not visible or cannot easily be seen by other road users, particularly when dark or in poor visibility conditions

There is a risk of an accident and injury.

Leave the vehicle immediately in this or similar situations as soon as it is safe to do so. Move to a safe location along with other vehicle occupants. In such situations, secure the vehicle in accordance with national regulations, e.g. with a warning triangle.

You must have a license agreement to activate the mbrace service. Make sure that your system is activated and operational. To register, press the  $\fbox{blue}$  MB Info call button. If any of the steps mentioned are not carried out, the system may not be activated. If you have questions about the activation, contact one of the following telephone hotlines:

- USA: Mercedes-Benz Customer Assistance Center at 1-800-FOR-MERCedes (1-800-367-6372) or 1-866-990-9007
- Canada: Customer Service at 1-888-923-8367

#### **General notes**

An emergency call is dialed automatically if an air bag or Emergency Tensioning Device is triggered.

• You cannot end an automatically triggered emergency call yourself.

An emergency call can also be initiated manually.

As soon as the emergency call has been initiated, the indicator lamp in the SOS button flashes. The multifunction display shows the **Connecting Call** message.

The audio output is muted.

Once the connection has been made, the Call Connected message appears in the multifunction display.

All important information on the emergency is transmitted, for example:

- Current location of the vehicle (as determined by the GPS system)
- Vehicle identification number
- · Information on the severity of the accident

Shortly after the emergency call has been initiated, a voice connection is automatically established between the Customer Assistance Center and the vehicle occupants.

- If the vehicle occupants respond, the Mercedes-Benz Customer Assistance Center attempts to get more information on the emergency.
- If there is no response from the vehicle occupants, an ambulance is immediately sent to the vehicle.


If no voice connection can be established to the Mercedes-Benz Customer Assistance Center, the system has been unable to initiate an emergency call.

This can occur, for example, if the relevant mobile phone network is not available. The indicator lamp in the SOS button flashes continuously.

The Call Failed message appears in the multifunction display and must be confirmed.

In this case, summon assistance by other means.

#### Making an emergency call



- To initiate an emergency call manually: press cover ① briefly to open.
- Press SOS button (2) briefly. The indicator lamp in SOS button (2) flashes until the emergency call is concluded.
- Wait for a voice connection to the Mercedes-Benz Customer Assistance Center.
- ► After the emergency call, close cover ①.
- If the mobile phone network is unavailable, mbrace will not be able to make the emergency call. If you leave the vehicle immediately after pressing the SOS button, you will not know whether mbrace placed the emergency call. In this case, always summon assistance by other means.

#### **Roadside Assistance button**



 Press Roadside Assistance button ①.
 This initiates a call to the Mercedes-Benz Customer Assistance Center.

The indicator lamp in Roadside Assistance button ① flashes while the call is active. The multifunction display shows the **Connecting Call** message. The audio output is muted.

If a connection can be made, the Call Connected message appears in the multifunction display.

If a mobile phone network and GPS reception are available, the system transfers data to the Mercedes-Benz Customer Assistance Center, for example:

- Current location of the vehicle
- Vehicle identification number
- The audio system or COMAND display indicates that a call is active. During the call, you can change to the navigation menu by pressing the NAVI button on COMAND, for example.

Voice output is not available.

A voice connection is established between the Mercedes-Benz Customer Assistance Center and the vehicle occupants.

From the vehicle remote malfunction diagnosis, the Mercedes-Benz Customer Assistance Center can ascertain the nature of the problem (▷ page 266).

The Mercedes-Benz Customer Assistance Center either sends a qualified MercedesBenz technician or makes arrangements for your vehicle to be transported to the nearest authorized Mercedes-Benz Center.

You may be charged for services such as repair work and/or towing.

Further details are available in your mbrace manual.

- 1 The system has not been able to initiate a roadside assistance call, if:
  - the indicator lamp for Roadside Assistance call button (1) is flashing continuously.
  - no voice connection to the Mercedes-Benz Customer Assistance Center was established.

This can occur if the relevant mobile phone network is not available, for example.

The Call Failed message appears in the multifunction display.

► To end a call: press the 
button on the 
multifunction steering wheel.

#### or

Press the corresponding button for ending a phone call on the audio system or on COMAND.

#### MB Info call button



▶ Press MB Info call button ①.

This initiates a call to the Mercedes-Benz Customer Assistance Center.

The indicator lamp in MB Info call button ① flashes while the connection is being made. The multifunction display shows the Connecting Call message. The audio system is muted.

If a connection can be made, the Call Connected message appears in the multifunction display.

If a mobile phone network and GPS reception are available, the system transfers data to the Mercedes-Benz Customer Assistance Center, for example:

- Current location of the vehicle
- Vehicle identification number
- The audio system or COMAND display indicates that a call is active. During the call, you can change to the navigation menu by pressing the NAVI button on COMAND, for example.

Voice output is not available.

A voice connection is established between the Mercedes-Benz Customer Assistance Center and the vehicle occupants.

You receive information about operating your vehicle, about the nearest authorized Mercedes-Benz Center and about other products and services from Mercedes-Benz.

USA only: you can find further information on the mbrace system under "Owners Online" at http://www.mbusa.com.

1 The system has not been able to initiate an MB Info call, if:

- the indicator lamp in MB Info call button (1) is flashing continuously.
- no voice connection to the Mercedes-Benz Customer Assistance Center was established.

This can occur if the relevant mobile phone network is not available, for example.

The Call Failed message appears in the multifunction display.

► To end a call: press the button on the multifunction steering wheel.

or

 Press the corresponding button for ending a phone call on the audio system or on COMAND.

# Call priority

When service calls are active, e.g. Roadside Assistance or MB Info calls, an emergency call can still be initiated. In this case, an emergency call will take priority and override all other active calls.

The indicator lamp of the respective button flashes until the call is ended.

An emergency call can only be terminated by the Mercedes-Benz Customer Assistance Center.

All other calls can be ended by pressing:

- the 🙆 button on the multifunction steering wheel
- the corresponding button on the audio system or on COMAND for ending a telephone call
- When a call is initiated, the audio system is muted. The mobile phone is no longer connected to COMAND. However, if you want to use your mobile phone, do so only when the vehicle is stationary and in a safe location.

# Downloading destinations in COMAND

## Downloading destinations

Destination Download gives you access to a data bank with over 15 million Points of Interest (POIs). These can be downloaded on the navigation system in your vehicle. If you know the destination, the address can be downloaded. Alternatively, you can obtain the location of Points of Interest (POIs)/ important destinations in the vicinity. Furthermore, you can download routes with up to 20 way points.

# 264 Features

You are prompted to confirm route guidance to the address entered.

- Select Yes with the or buttons on the COMAND system.
- Confirm with the button on the COMAND system.

The system calculates the route and subsequently starts the route guidance with the address entered.

- If you select No, the address can be saved in the address book.
- The destination download function is available if the relevant mobile phone network is available and data transfer is possible.
- The destination download function can only be used if the vehicle is equipped with a navigation system.

#### **Route Assistance**

This service is part of the mbrace PLUS Package and cannot be purchased separately.

• You can also use the Route Assistance function if your vehicle is not equipped with a navigation system.

Within the framework of this service, you receive a professional and reliable form of navigation support without having to leave your vehicle.

The customer service representative finds a suitable route depending on your vehicle's current position and the desired destination. You will then be guided live through the current route section.

## Search and Send

#### **General notes**

To use "Search & Send", your vehicle must be equipped with mbrace and a navigation system. Additionally, an mbrace service subscription must be completed. "Search & Send" is a destination entry service. A destination address which is found on Google Maps<sup>®</sup> can be transferred via mbrace directly to your vehicle's navigation system.

# Specifying and sending the destination address

- ➤ Go to the website http:// www.maps.google.com and enter a destination address into the entry field.
- To send the destination address to the e-mail address of your mbrace account: click on the corresponding button on the website.
- **1** Example:

If you select 'Send to vehicle' and then 'Mercedes-Benz', the destination address will be sent to your vehicle.

- When the "Send" dialog window appears: Enter the e-mail address you specified when setting up your mbrace account into the corresponding field.
- Click "Send".
- Information on specific commands such as "Address entry" or "Send" can be found on the website.

#### Calling up destination addresses

Switch on the ignition.
 The destination address is loaded into the vehicle's navigation system.

A display message appears, asking whether navigation should be started.

Select Yes by turning () or sliding
 ← → the COMAND controller and press
 to confirm.

The system calculates the route and subsequently starts the route guidance with the address entered.

 If you select No, the address can be saved in the address book. If you have sent more than one destination address, each individual destination must be confirmed separately.

1 Destination addresses are loaded in the same order as the order in which they were sent.

If you own multiple Mercedes-Benz vehicles with mbrace and activated mbrace accounts:

If multiple vehicles are registered under the same e-mail address, the destination will be sent to all the vehicles.

# Vehicle remote opening

You can use the vehicle remote opening if you have unintentionally locked your vehicle and a replacement SmartKey is not available.

The vehicle can be opened by the Mercedes-Benz Customer Assistance Center.

The vehicle can be immediately opened remotely within four days of the ignition being turned off. After this time, the remote unlocking may be delayed by 15 to 60 minutes. After 30 days, the vehicle can no longer be opened remotely.

- Contact the following service hotlines:
  - USA: Mercedes-Benz Customer Assistance Center at 1-800-FOR-MFRCedes (1-800-367-6372) or 1-866-990-9007
  - Canada: Customer Service at 1-888-923-8367
  - You will be asked for your password.
- Return to your vehicle at the time agreed upon with the Mercedes-Benz Customer Assistance Center.

USA only: alternatively, the vehicle can be opened via:

- the Internet, under the "Owners Online" section
- the telephone application (e.g. iPhone<sup>®</sup>, Blackberry)

To do this, you will need your identification number and password.

1 Vehicle remote opening is only possible if the corresponding mobile phone network is accessible

# Vehicle remote closing

The remote closing feature can be used when you have forgotten to lock the vehicle and you are no longer nearby.

The vehicle can then be locked by the Mercedes-Benz Customer Assistance Center. The vehicle can be immediately remotely locked within four days of the ignition being turned off. After this time, the remote closing may be delayed by 15 to 60 minutes. After 30 days the vehicle can no longer be closed remotely.

- Contact the following service hotlines:
  - USA: Mercedes-Benz Customer Assistance Center at 1-800-FOR-MFRCedes (1-800-367-6372) or 1-866-990-9007
  - Canada: Customer Service at 1-888-923-8367

You will be asked for your password.

The next time you are inside the vehicle and you switch on the ignition, the Doors Locked Remotely message appears in the multifunction display.

USA only: alternatively, the vehicle can be locked via:

- the Internet, under the "Owners Online" section
- the telephone application (e.g. iPhone<sup>®</sup>, Blackberry)

To do this, you will need your identification number and password.

1 The vehicle remote closing feature is available when the relevant mobile phone network is available and data connection is possible.

#### Stolen vehicle recovery service

If your vehicle has been stolen:

- Notify the police. The police will issue a numbered incident report.
- This number will be forwarded to the Mercedes-Benz Customer Assistance Center together with your PIN.

The Mercedes-Benz Customer Assistance Center then tries to locate the system. The Mercedes-Benz Customer Assistance Center contacts you and the local law enforcement agency if the vehicle is located.

However, only the law enforcement agency is informed of the location of the vehicle.

If the anti-theft alarm system is activated for longer than 30 seconds, the Mercedes-Benz Customer Assistance Center is automatically informed.

### Vehicle remote malfunction diagnosis

With the vehicle remote malfunction diagnosis (Vehicle Health Check), the Customer Assistance center can provide improved support for problems with your vehicle. During an existing call, vehicle data is transferred to the Customer Assistance center. The customer service representative can use the received data to decide what kind of assistance is required. You are then, for example, guided to the nearest authorized Mercedes-Benz Center or a recovery vehicle is called.

If vehicle data needs to be transferred during an MB Info call or a Roadside Assistance call, this is initiated by the Customer Assistance center. You will see the Roadside Assistance Connected message in the COMAND display. If the vehicle remote malfunction diagnosis can be started, the Request for vehicle diagnosis received. Start vehicle diagnosis? message appears in the display.

- Confirm the message with Yes.
- When the Vehicle Diagnosis Please start ignition message appears, turn the SmartKey to position 2 in the ignition lock (▷ page 139).
- When the Please follow the instructions received by phone and move your vehicle to a safe position. message appears, follow the customer service representative's instructions.

The message in the display disappears. If you select Cance1, the vehicle remote malfunction diagnosis is canceled completely.

The vehicle operating state check begins. You will see the Vehicle diagnosis activated. message.

When the diagnosis is completed, the Send vehicle diagnostics data//(Voice connection may be//interrupted during data transfer) message appears. The vehicle data can now be sent to the Customer Assistance center.

Press OK to confirm the message. The voice connection with the Customer Assistance center is terminated.

You will see the Vehicle Diagnosis: Transferring data... message.

The vehicle data is sent to the Customer Assistance center.

Depending on what the customer service representative agreed with you, the voice connection is re-established after the transfer is complete. If necessary, you will be contacted at a later time by another means, e.g. by e-mail or phone.

Further functions of the vehicle remote malfunction diagnosis include, for example:

• transfer of service data to the Customer Assistance center. If a service is overdue, the COMAND display shows a message about various special offers at your workshop.

 monthly status information e-mail on oil level, air pressure, maintenance, brakes, etc. If applicable, you will receive information on special offers in the e-mail. USA only: this information can also be called up under "Owners Online" at http:// www.mbusa.com.

Information on the data stored in the vehicle ( $\triangleright$  page 26).

Information on Roadside Assistance (▷ page 22).

# **Downloading routes**

Downloading routes allows you to transfer and save predefined routes in the navigation system. To do this, an SD memory card must be inserted into the COMAND system. If no SD memory card is inserted, you must insert the card into the card slot on the COMAND system before saving.

A route can be prepared and sent either by a customer service representative or via the mbrace portal on the Internet.

Each route can include up to 20 way points. Once a route has been received by the navigation system, you will see the <route name> has been saved to memory card. Do you want to start route

guidance? message in the COMAND display. The route is saved to the SD memory card.

- To start route guidance: select Yes. An overview of the route is shown in the display.
- 1 If you select No, the saved route can be called up later via the navigation menu.
- Select Start.
   Route guidance is started.
- Downloaded and saved data can be called up again in COMAND.

You can find further information in the separate COMAND Operating Instructions.

# Speed alert

You can define the upper speed limit, which must not be exceeded by the vehicle.

If this selected speed is exceeded by the vehicle, a message will be sent to the Customer Assistance center. The Customer Assistance center then forwards this information to you.

You can select the way in which you receive this information beforehand. Possible options include text message, e-mail or an automated call.

The data you receive contains the following information:

- the location where the speed limit was exceeded
- the time at which the speed limit was exceeded
- the selected speed limit which was exceeded

# Geo fencing

Geo fencing allows you to select areas which the vehicle should not enter or leave. You will be informed if the vehicle crosses the boundaries of the selected areas. You can select the way in which you receive this information beforehand. Possible options include text message, e-mail or an automated call.

The area can be determined as either a circle or a polygon with a maximum of ten corners. You can specify up to ten areas simultaneously. Different settings are possible for each area.

USA only: these settings can be called up under "Owners Online" at http:// www.mbusa.com.

Alternatively, you can trigger an MB Info call and inform the customer service

representative that you wish to activate geo fencing.

Currently inactive areas can be activated by text message.

## Triggering the vehicle alarm

With this function, you can trigger the vehicle's panic alarm via text message. An alarm sounds and the exterior lighting flashes. Depending on the setting, the panic alarm lasts five or ten seconds. Afterwards, the alarm switches off.

#### Garage door opener

#### Important safety notes

#### MARNING

When you operate or program the garage door with the integrated garage door opener, persons in the range of movement of the garage door can become trapped or struck by the garage door. There is a risk of injury. When using the integrated garage door opener, always make sure that nobody is within the range of movement of the garage door.

## MARNING

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Inhaling these exhaust gases leads to poisoning. There is a risk of fatal injury. Therefore never leave the engine running in enclosed spaces without sufficient ventilation.

The HomeLink<sup>®</sup> garage door opener integrated in the rear-view mirror allows you to operate up to three different door and gate systems.

Use the integrated garage door opener only on garage doors that:

- have safety stop and reverse features and
- meet current U.S. federal safety standards

When programming a garage door opener, park the vehicle outside the garage.

Certain garage door drives are incompatible with the integrated garage door opener. If you have difficulty programming the integrated garage door opener, contact an authorized Mercedes-Benz Center.

Alternatively, you can call the following telephone assistance services:

- USA: Mercedes-Benz Customer Assistance Center at 1-800-FOR-MERCedes
- Canada: Customer Service at 1-800-387-0100
- HomeLink<sup>®</sup> hotline 1-800-355-3515 (free of charge)


More information on HomeLink<sup>®</sup> and/or compatible products is also available online at http://www.homelink.com.

 Only Notes on the declaration of conformity (▷ page 24).
 USA: FCC ID: CB2HMIHL4
 Canada: IC: 279B-HMIHL4

#### Programming

#### Programming buttons

Observe the "Important safety notes" (> page 268).



Integrated garage door opener in the rear-view mirror

Garage door remote control (5) is not part of the integrated garage door opener.

- ► The first time before programming, clear the integrated garage door opener memory (▷ page 270).
- Turn the SmartKey to position 2 in the ignition lock.

- Press and hold one of buttons (2) to (4) on the integrated garage door opener.
   After a short time, indicator lamp (1) lights up yellow.
- Indicator lamp (1) lights up yellow as soon as button (2), (3) or (4) is programmed for the first time. If the selected button has already been programmed, indicator lamp (1) will only light up yellow after ten seconds have elapsed.
- ▶ Release button ②, ③ or ④. Indicator lamp ① flashes yellow.
- Point garage door remote control (5) towards buttons (2) to (4) on the rear-view mirror at a distance of 2 to 8 inches (5 to 20 cm).
- (1) The required distance between remote control (5) and the integrated garage door opener depends on the garage door drive system. Several attempts might be necessary. You should test every position for at least 25 seconds before trying another position.
- Press and hold button (6) on remote control
   (5) until indicator lamp (1) lights up green.
   If indicator lamp (1) lights up green or
   flashes, then programming has been successful.
- Release button (6) on remote control (5) for the garage door drive system.
- If indicator lamp (1) lights up red: repeat the programming procedure for the corresponding button on the rear-view mirror. When doing so, vary the distance between remote control (5) and the rearview mirror.

If the indicator lamp flashes green after successful programming, the garage door system is using a rolling code. After programming, you must synchronize the garage door opener integrated in the rearview mirror with the receiver of the garage door system.

# Synchronizing the rolling code

Observe the "Important safety notes" (> page 268).

Your vehicle must be within reach of the garage door or exterior gate drive. Make sure that neither your vehicle nor any persons/ objects are present within the sweep of the door or gate.

- ► Turn the SmartKey to position **2** in the ignition lock.
- Press the program button of the door or gate drive (see the door or gate drive operating instructions, e.g. under "programming of additional remote controls").
- Usually, you now have 30seconds to initiate the next step.
- Press previously programmed button ②,
   ③ or ④ of the integrated garage door opener until the door closes.
   The rolling code synchronization is then complete.

# Notes on programming the remote control

Canadian radio frequency laws require a "break" (or interruption) of the transmission signals after broadcasting for a few seconds. Therefore, these signals may not last long enough for the integrated garage door opener. The signal is not recognized during programming. Comparable with Canadian law, some U.S. garage door openers also feature a "break".

Proceed as follows:

- if you live in Canada
- if you have difficulties programming the garage door opener (regardless of where you live) when using the programming steps

- Press and hold one of buttons (2) to (4) on the integrated garage door opener.
   After a short time, indicator lamp (1) lights up yellow.
- Release the button.
   Indicator lamp ① flashes yellow.
- Press button (6) of garage door remote control (5) for two seconds, then release it for two seconds.
- ▶ Press button ⑥ again for two seconds.
- Repeat this sequence on button (6) of remote control (5) until indicator lamp (1) lights up green.
  - If indicator lamp (1) turns red, repeat the process.
- Continue with the other programming steps (see above).

## Problems when programming

If you are experiencing problems programming the integrated garage door opener on the rear-view mirror, take note of the following instructions:

• Check the transmitter frequency of garage door drive remote control (5). This can usually be found on the back of the remote control.

The integrated garage door opener is compatible with devices that have units which operate in the frequency range of 280to 433MHz.

- Replace the batteries in garage door remote control (5). This increases the likelihood that garage door remote control (5) will transmit a strong and precise signal to the integrated garage door opener in the rear-view mirror.
- When programming, hold remote control
   (5) at varying distances and angles from the button that you are programming. Try various angles at a distance between 2and 12 inches (5to 30 cm) or at the same angle but at varying distances.
- If another remote control for the same garage door drive is available, repeat the

same programming steps with this remote control. Before performing these steps, make sure that new batteries have been installed in garage door drive remote control (5).

- Note that some remote controls only transmit for a limited amount of time (the indicator lamp on the remote control goes out). Press button (a) on remote control
   (5) again before transmission ends.
- Align the antenna cable of the garage door opener unit. This can improve signal reception/transmission.

# Opening/closing the garage door

After it has been programmed, the integrated garage door opener performs the function of the garage door system remote control. Please also read the operating instructions for the garage door system.

- ► Turn the SmartKey to position **2** in the ignition lock.
- Press button (2), (3) or (4) which you have programmed to operate the garage door. Garage door system with a fixed code: indicator lamp (1) lights up green.

Garage door system with a rolling code: indicator lamp ① flashes green.

The transmitter will transmit a signal as long as the button is pressed. The transmission is halted after a maximum of ten seconds and indicator lamp (1) lights up yellow. Press button (2), (3) or (4) again if necessary.

#### **Clearing the memory**

- ► Turn the SmartKey to position **2** in the ignition lock.
- Press buttons ② and ④.
   The indicator lamp lights up yellow.
- Press and hold buttons (2) and (4) until the indicator lamp turns green.

Make sure that you clear the memory of the integrated garage door opener before selling the vehicle.

## Compass


## Calling up the compass




Compass (2) displays the compass direction in which the vehicle is currently traveling: N, NE, E, SE, S, SW, W or NW.

To receive a correct display in rear-view mirror (1), the compass must be calibrated and the magnetic field zone set.

## Setting the compass



North America zone map



South America zone map

▶ Set your location using the zone maps.

Push a round pen into opening
 () page 271) for approximately three seconds.

The zone currently selected appears in compass display ②(▷ page 271).

► To select the zone: push a round pen into opening ③(▷ page 271) until the desired zone is selected.

If, after a few seconds, the display in compass display (2)(▷ page 271) changes direction, the zone has been selected.

# Calibrating the compass

Make sure that there is sufficient space for you to drive in a circle without impeding traffic.

In order to calibrate the compass correctly, do the following:

- calibrate the compass in the open and not in the vicinity of steel structures or highvoltage transmission lines.
- switch off electrical consumers such as the climate control, windshield wipers or rear window defroster.
- close all doors and the trunk lid.
- Switch on the ignition.
- Push a round pen into opening ③(▷ page 271) for approximately six seconds, until symbol C is shown in compass display ②(▷ page 271).
- Drive your vehicle in a full circle at approximately 3 mph (5 km/h) to 6 mph (10 km/h).

When the calibration has successfully been completed, the current direction is shown in compass display  $\textcircled{O}(\vartriangleright page 271)$ .


## Floormats

# 

Objects in the driver's footwell can restrict the pedal travel or obstruct a depressed pedal.

The operating and road safety of the vehicle is jeopardized. There is a risk of an accident.

Make sure that all objects in the vehicle are stowed correctly, and that they cannot enter the driver's footwell. Install the floormats securely and as specified in order to ensure sufficient clearance for the pedals. Do not use loose floormats and do not place floormats on top of one another.



- Slide the seat backwards.
- ► To install: place the floormat in the footwell.
- ▶ Press studs ① onto retainers ②.
- ► To remove: pull the floormat off retainers ②.
- Remove the floormat.

#### **Useful information**

This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.

 Read the information on qualified specialist workshops: (▷ page 24).

#### **Engine compartment**

#### Hood

#### Important safety notes

#### MARNING

If the hood is unlatched, it may open up when the vehicle is in motion and block your view. There is a risk of an accident.

Never unlatch the hood while driving.

# 

When opening and closing the hood, it may suddenly fall into the closed position. There is a risk of injury to persons within range of movement of the hood.

Open and close the hood only when no one is within its range of movement.

## 

Opening the hood when the engine is overheated or when there is a fire in the engine compartment could expose you to hot gases or other service products. There is a risk of injury.

Let an overheated engine cool down before opening the hood. If there is a fire in the engine compartment, keep the hood closed and contact the fire department.

# 

The engine compartment contains moving components. Certain components, such as the radiator fan, may continue to run or start again suddenly when the ignition is off. There is a risk of injury.

If you need to do any work inside the engine compartment,

- switch off the ignition
- never reach into the area where there is a risk of danger from moving components, such as the fan rotation area
- keep clothing away from moving parts

#### Opening the hood

#### **MARNING** ★

Certain components in the engine compartment, such as the engine, radiator and parts of the exhaust system, can become very hot. Working in the engine compartment poses a risk of injury.

Where possible, let the engine cool down and touch only the components described in the following.

# MARNING

When the hood is open and the windshield wipers are set in motion, you can be injured by the wiper linkage. There is a risk of injury. Always switch off the windshield wipers and the ignition before opening the hood.

Make sure that the windshield wipers are not folded away from the windshield. You could otherwise damage the windshield wipers or the hood.



- Make sure that the windshield wipers are turned off.
- ► Pull release lever ① on the hood. The hood is released.



 Reach into the gap, pull hood catch handle ② up and lift the hood.

If you lift the hood by approximately 15 in (40 cm), the hood is opened and held open automatically by the gas-filled strut.

# Closing the hood

- Lower the hood and let it fall from a height of approximately 8 in (20 cm).
- Check that the hood has engaged properly. If the hood can be raised slightly, it is not properly engaged. Open it again and close it with a little more force.

# Engine oil

# Notes on the oil level

Depending on the driving style, the vehicle consumes up to 0.9 US qt (0.8I) of oil over a distance of 600 miles (1000km). The oil consumption may be higher than this when the vehicle is new or if you frequently drive at high engine speeds.

**AMG vehicles:** before operation on race tracks, check the oil level and (▷ page 275) add oil if necessary (▷ page 276). Race track operation is only permitted with a maximum engine oil level.

Depending on the engine, the oil dipstick may be in a different location.

When checking the oil level:


- park the vehicle on a level surface.
- the engine should be switched off for approximately five minutes if the engine is at normal operating temperature.
- if the engine is not at normal operating temperature, e.g. if the engine was only started briefly: wait about 30 minutes before carrying out the measurement.

# Checking the oil level using the oil dipstick

# 

Certain components in the engine compartment, such as the engine, radiator and parts of the exhaust system, can become very hot. Working in the engine compartment poses a risk of injury.

Where possible, let the engine cool down and touch only the components described in the following.



Example

- Pull oil dipstick ① out of the dipstick guide tube.
- ▶ Wipe off oil dipstick ①.
- Slowly slide oil dipstick ① into the guide tube to the stop, and take it out again.
   If the level is between MIN mark ③ and MAX mark ②, the oil level is correct.
- If the oil level has dropped to MIN mark
   (3) or below, add 1.1 US qt (1.0 liter) of engine oil.

# Adding engine oil

# MARNING

Certain components in the engine compartment, such as the engine, radiator and parts of the exhaust system, can become very hot. Working in the engine compartment poses a risk of injury.

Where possible, let the engine cool down and touch only the components described in the following.

# 

If engine oil comes into contact with hot components in the engine compartment, it may ignite. There is a risk of fire and injury.

Make sure that engine oil is not spilled next to the filler neck. Let the engine cool down and thoroughly clean the engine oil off the components before starting the engine.

# $\Psi$ Environmental note

When adding oil, take care not to spill any. If oil enters the soil or waterways, it is harmful to the environment.

Only use engine oils and oil filters that have been approved for vehicles with a service system. You can obtain a list of the engine oils and oil filters tested and approved in accordance with the Mercedes-Benz Specifications for Service Products at any Mercedes-Benz Service center.

Damage to the engine or exhaust system is caused by the following:

- using engine oils and oil filters that have not been specifically approved for the service system
- replacing engine oil and oil filters after the interval for replacement specified by the service system has been exceeded
- using engine oil additives.
- Do not add too much oil. If the oil level is above the "max" mark on the dipstick, too much oil has been added. This can lead to damage to the engine or the catalytic converter. Have excess oil siphoned off.



Example: engine oil cap

- ► Turn cap ① counter-clockwise and remove it.
- Add engine oil.

If the oil level is at or below the MIN mark on the oil dipstick, add 1.1 US qt (1.0 l) of engine oil.

 Replace cap (1) on the filler neck and turn clockwise.

Ensure that the cap locks into place securely.

► Check the oil level again with the oil dipstick (▷ page 275).

Further information on engine oil  $(\triangleright$  page 346).

# Checking and adding other service products

## Checking coolant level


## **MARNING** ★

Certain components in the engine compartment, such as the engine, radiator and parts of the exhaust system, can become very hot. Working in the engine compartment poses a risk of injury.

Where possible, let the engine cool down and touch only the components described in the following.

# 

The engine cooling system is pressurized, particularly when the engine is warm. When opening the cap, you could be scalded by hot coolant spraying out. There is a risk of injury. Let the engine cool down before opening the cap. Wear eye and hand protection when opening the cap. Open the cap slowly half a turn to allow pressure to escape.



Example

- Park the vehicle on a level surface. Only check the coolant level when the vehicle is on a level surface and the engine has cooled down.
- ► Turn the SmartKey to position 2 in the ignition lock (▷ page 139). On vehicles with KEYLESS-GO, press the Start/Stop button twice (▷ page 139).
- Check the coolant temperature gauge in the multifunction display.
   The coolant temperature must be below 158 °F (70 °C).
- ► Turn the SmartKey to position
   0 (▷ page 139) in the ignition lock.
- Slowly turn cap (2) half a turn counterclockwise to allow excess pressure to escape.
- Turn cap (2) further counter-clockwise and remove it.

If the coolant is at the level of marker bar ③ in the filler neck when cold, there is enough coolant in coolant expansion tank ①.

If the coolant level is approximately 0.6 in (1.5 cm) above marker bar ③ in the fuel filler neck when warm, there is enough coolant in expansion tank ①.

- If necessary, add coolant that has been tested and approved by Mercedes-Benz.
- Replace cap (2) and turn it clockwise as far as it will go.

For further information on coolant, see  $(\triangleright \text{ page 347})$ .

## Windshield washer system

## MARNING

Certain components in the engine compartment, such as the engine, radiator and parts of the exhaust system, can become very hot. Working in the engine compartment poses a risk of injury.

Where possible, let the engine cool down and touch only the components described in the following.

# 

Windshield washer concentrate is highly flammable. If it comes into contact with hot engine components or the exhaust system it could ignite. There is a risk of fire and injury. Make sure that no windshield washer concentrate is spilled next to the filler neck.



Example

- ► **To open:** pull cap ① upwards by the tab.
- ► Add the premixed washer fluid.
- To close: press cap ① onto the filler neck until it engages.

If the washer fluid level drops below the recommended minimum of 1 liter, a message appears in the multifunction display prompting you to add washer fluid (> page 238).

Further information on windshield washer fluid/antifreeze (▷ page 348).

## **ASSYST PLUS**

#### Service messages

The ASSYST PLUS service interval display informs you of the next service due date.

Information on the type of service and service intervals (see the separate Maintenance Booklet).

You can obtain further information from an authorized Mercedes-Benz Center or at http://www.mbusa.com (USA only).

(1) The ASSYST PLUS service interval display does not show any information on the engine oil level. Observe the notes on the engine oil level (▷ page 275).

The multifunction display shows a service message for several seconds, e.g.:

- Service A in .. Days
- Service A Due
- Service A Exceeded by .. Days

Depending on the operating conditions of the vehicle, the remaining time or distance until the next service due date is displayed.

The letter A or B, possibly in connection with a number or another letter, shows the type of service. A stands for a minor service and B for a major service.

You can obtain further information from an authorized Mercedes-Benz Center.

The ASSYST PLUS service interval display does not take into account any periods of time during which the battery is disconnected.

Maintaining the time-dependent service schedule:

Note down the service due date displayed in the multifunction display before disconnecting the battery.

or

After reconnecting the battery, subtract the battery disconnection periods from the service date shown on the display.

#### Hiding a service message

Press the or OK button on the steering wheel.

#### **Displaying service messages**

- Switch on the ignition.
- Press the or button on the steering wheel to select the Service menu.
- Press the or button to select the ASSYST PLUS submenu and confirm by pressing the OK button. The service due date appears in the multifunction display.

## Information about Service

# Resetting the ASSYST PLUS service interval display

If the ASSYST PLUS service interval display has been inadvertently reset, this setting can be corrected at a qualified specialist workshop.

Have service work carried out as described in the Maintenance Booklet. This may otherwise lead to increased wear and damage to the major assemblies or the vehicle.

A qualified specialist workshop, e.g. an authorized Mercedes-Benz Center, will reset the ASSYST PLUS service interval display after the service work has been carried out. You can also obtain further information on maintenance work, for example.

# **Special service requirements**

The specified maintenance interval takes only the normal operation of the vehicle into account. Under arduous operating conditions or increased load on the vehicle, maintenance work must be carried out more frequently, for example:

- regular city driving with frequent intermediate stops
- if the vehicle is primarily used to travel short distances

- use in mountainous terrain or on poor road surfaces
- if the engine is often left idling for long periods

Under these or similar conditions, have, for example, the air filter, engine oil and oil filter replaced or changed more frequently. Under arduous operating conditions, the tires must be checked more often. Further information can be obtained at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.

#### Driving abroad

An extensive Mercedes-Benz Service network is also available in other countries. You can obtain further information from any authorized Mercedes-Benz Center.

#### Care

### Notes on care

## Environmental note

Dispose of empty packaging and cleaning cloths in an environmentally responsible manner.

For cleaning your vehicle, do not use any of the following:

- dry, rough or hard cloths
- abrasive cleaning agents
- solvents
- cleaning agents containing solvents

Do not scrub.

Do not touch the surfaces or protective films with hard objects, e.g. a ring or ice scraper. You could otherwise scratch or damage the surfaces and protective film.

Do not park the vehicle for an extended period straight after cleaning it, particularly after having cleaned the wheels with wheel cleaner. Wheel cleaners could cause increased corrosion of the brake discs and brake pads/linings. For this reason, you should drive for a few minutes after cleaning. Braking heats the brake discs and the brake pads/linings, thus drying them. The vehicle can then be parked.

Regular care of your vehicle is a condition for retaining the quality in the long term.

Use care products and cleaning agents recommended and approved by Mercedes-Benz.

# Washing the vehicle and cleaning the paintwork

#### Automatic car wash

## MARNING

Braking efficiency is reduced after washing the vehicle. There is a risk of an accident.

After the vehicle has been washed, brake carefully while paying attention to the traffic conditions until full braking power is restored.

If DISTRONIC PLUS or the HOLD function is activated, the vehicle brakes automatically in certain situations. To prevent damage to the vehicle, deactivate DISTRONIC PLUS and the HOLD function in the following or other similar situations:

- when towing the vehicle
- in the car wash

It is preferable to use car washes with adjustable high-pressure pre-cleaning that corresponds to the specification for the Cabriolet program. In car washes that use high water pressures, there is a risk that a small amount of water may leak into the vehicle.

Lock the car if you wash it in an automatic car wash. Otherwise, the vehicle might be damaged.

Never clean your vehicle in a Touchless Automatic Car Wash as these use special cleaning agents. These cleaning agents can damage the paintwork or plastic parts.

- Make sure that the automatic transmission is in position **N** when washing your vehicle in a tow-through car wash. The vehicle could be damaged if the transmission is in another position.
- I Make sure that:
  - the side windows and the roof are completely closed
  - the climate control blower is switched off
  - the windshield wiper switch is at position
     0

The vehicle could otherwise be damaged.

You can wash the vehicle in an automatic car wash from the very start.

If the vehicle is very dirty, pre-wash it before cleaning it in an automatic car wash.

After using an automatic car wash, wipe off wax from the windshield and the wiper blades. This will prevent smears and reduce wiping noises caused by residue on the windshield.

## Washing by hand

In some countries, washing by hand is only allowed at specially equipped washing bays. Observe the legal requirements in all countries concerned.

- Do not use hot water and do not wash the vehicle in direct sunlight.
- ▶ Use a soft sponge to clean.
- Use a mild cleaning agent, such as a car shampoo approved by Mercedes-Benz.
- Thoroughly hose down the vehicle with a gentle jet of water.
- Do not point the water jet directly towards the air inlet.
- Use plenty of water and rinse out the sponge frequently.
- ► Rinse the vehicle with clean water and dry thoroughly with a chamois.
- Do not let the cleaning agent dry on the paintwork.

When using the vehicle in winter, remove all traces of road salt deposits carefully and as soon as possible.

## Power washers

# MARNING

The water jet from a circular jet nozzle (dirt blasters) can cause invisible exterior damage to the tires or chassis components. Components damaged in this way may fail unexpectedly. There is a risk of an accident.

Do not use power washers with circular jet nozzles to clean the vehicle. Have damaged tires or chassis components replaced immediately.

Always maintain a distance of at least 11.8 in (30 cm) between the vehicle and the power washer nozzle. Information about the correct distance is available from the equipment manufacturer.

Move the power washer nozzle around when cleaning your vehicle.

Do not aim directly at any of the following:

- tires
- door gaps, roof gaps, joints, etc.
- · electrical components
- battery
- connectors
- lights
- seals
- trim
- ventilation slots

Damaged seals or electrical components can lead to leaks or failures.

Do not use high-pressure cleaners if the tank recess is open while you clean it. This can cause damage to the seals or other components.

# **Cleaning the paintwork**

- Do not affix:
  - stickers
  - films
  - magnetic plates or similar items

to painted surfaces. You could otherwise damage the paintwork.

Scratches, corrosive deposits, areas affected by corrosion and damage caused by inadequate care cannot always be completely repaired. In such cases, visit a qualified specialist workshop.

- Remove dirt immediately, where possible, while avoiding rubbing too hard.
- Soak insect remains with insect remover and rinse off the treated areas afterwards.
- Soak bird droppings with water and rinse off the treated areas afterwards.
- Remove coolant, brake fluid, tree resin, oils, fuels and greases by rubbing gently with a cloth soaked in petroleum ether or lighter fluid.
- ► Use tar remover to remove tar stains.
- ► Use silicone remover to remove wax.

If water no longer forms "beads" on the paint surface, use the paint care products recommended and approved by Mercedes-Benz. This is the case approximately every three to five months, depending on the climate conditions and the care product used.

If dirt has penetrated the paint surface or if the paint has become dull, the paint cleaner recommended and approved by Mercedes-Benz should be used.

Do not use these care products in the sun or on the hood while the hood is hot.

Use a suitable touch-up stick, e.g. MB Touch-Up Stick, to repair slight damage to the paintwork quickly and provisionally.

### Matte finish care

- Never polish the vehicle or the light alloy wheels. Polishing causes the finish to shine.
- The following may cause the paint to become shiny and thus reduce the matte effect:
  - Vigorous rubbing with unsuitable materials.
  - Frequent use of car washes.
  - Washing the vehicle in direct sunlight.

Never use paint cleaner, buffing or polishing products, or gloss preserver, e.g. wax. These products are only suitable for high-gloss surfaces. Their use on vehicles with matte finish leads to considerable surface damage (shiny, spotted areas). Always have paintwork repairs carried out at a qualified specialist workshop.

Do not use wash programs with a hot wax treatment under any circumstances.

Observe these notes if your vehicle has a clear matte finish. This will help you to avoid damage to the paintwork due to incorrect treatment.

These notes also apply to light alloy wheels with a clear matte finish.

- The vehicle should preferably be washed by hand using a soft sponge, car shampoo and plenty of water.
- Use only insect remover and car shampoo from the range of recommended and approved Mercedes-Benz care products.

#### **Cleaning the vehicle parts**

#### **Cleaning the wheels**

Do not use acidic wheel cleaning products to remove brake dust. This could damage wheel bolts and brake components. Do not park the vehicle for an extended period straight after cleaning it, particularly after having cleaned the wheels with wheel cleaner. Wheel cleaners could cause increased corrosion of the brake discs and brake pads/linings. For this reason, you should drive for a few minutes after cleaning. Braking heats the brake discs and the brake pads/linings, thus drying them. The vehicle can then be parked.

#### **Cleaning the windows**

#### MARNING

You could become trapped by the windshield wipers if they start moving while cleaning the windshield or wiper blades. There is a risk of injury.

Always switch off the windshield wipers and the ignition before cleaning the windshield or wiper blades.

- Do not use dry cloths, abrasive products, solvents or cleaning agents containing solvents to clean the inside of the windows. Do not touch the insides of the windows with hard objects, e.g. an ice scraper or ring. There is otherwise a risk of damaging the windows.
- Clean the water drainage channels of the windshield and the rear window at regular intervals. Deposits such as leaves, petals and pollen may under certain circumstances prevent water from draining away. This can lead to corrosion damage and damage to electronic components.
- Clean the inside and outside of the windows with a damp cloth and a cleaning agent that is recommended and approved by Mercedes-Benz.

#### Cleaning wiper blades

## MARNING

You could become trapped by the windshield wipers if they start moving while cleaning the

windshield or wiper blades. There is a risk of injury.

Always switch off the windshield wipers and the ignition before cleaning the windshield or wiper blades.

Do not pull the wiper blade. Otherwise, the wiper blade could be damaged.

Do not clean wiper blades too often and do not rub them too hard. Otherwise, the graphite coating could be damaged. This could cause wiper noise.

Hold the wiper arm securely when folding back. The windshield could be damaged if the wiper arm smacks against it suddenly.

 Fold the windshield wiper arms away from the windshield.

- Carefully clean the wiper blades with a damp cloth.
- ► Fold the windshield wiper arms back again before switching on the ignition.

## **Cleaning the exterior lighting**

- Only use cleaning agents or cleaning cloths which are suitable for plastic light lenses. Unsuitable cleaning agents or cleaning cloths could scratch or damage the plastic light lenses.
- Clean the plastic lenses of the exterior lighting using a wet sponge and a mild cleaning agent, e.g. Mercedes-Benz car shampoo or cleaning cloths.

#### Mirror turn signals

- Only use cleaning agents or cleaning cloths that are suitable for plastic lenses. Unsuitable cleaning agents or cleaning cloths could scratch or damage the plastic lenses of the mirror turn signals.
- Clean the plastic lenses of the mirror turn signals in the exterior mirror housing using a wet sponge and mild cleaning agent, e.g.

Mercedes-Benz car shampoo or cleaning cloths.

#### Cleaning the sensors

If you clean the sensors with a power washer, make sure that you keep a distance of at least 11.8 in (30 cm) between the vehicle and the power washer nozzle. Information about the correct distance is available from the equipment manufacturer.



► Clean sensors ① of the driving systems with water, car shampoo and a soft cloth.

## Cleaning the exhaust pipe

- Do not clean the exhaust pipe with acidbased cleaning agents such as sanitary cleansers or wheel cleaners.
- Clean the exhaust pipe with a chrome care product tested and approved by Mercedes-Benz.

Impurities combined with the effects of road grit and corrosive environmental factors may cause flash rust to form on the surface. You can restore the original shine of the exhaust pipe by cleaning it regularly, especially in winter and after washing.

# Interior care

### **Cleaning the display**

For cleaning, do not use any of the following:

- alcohol-based thinner or gasoline
- abrasive cleaning agents
- commercially-available household cleaning agents

These may damage the display surface. Do not put pressure on the display surface when cleaning. This could lead to irreparable damage to the display.

- Before cleaning the display, make sure that it is switched off and has cooled down.
- Clean the display surface using a commercially available microfiber cloth and TFT/LCD display cleaner.
- Dry the display surface using a dry microfiber cloth.

#### Cleaning the plastic trim

## MARNING

Care products and cleaning agents containing solvents cause surfaces in the cockpit to become porous. As a result, plastic parts may come loose in the event of air bag deployment. There is a risk of injury.

Do not use any care products and cleaning agents to clean the cockpit.

Do not affix the following to plastic surfaces:

- stickers
- films
- scented oil bottles or similar items

You can otherwise damage the plastic.

Do not allow cosmetics, insect repellent or sunscreen to come into contact with the plastic trim. This maintains the high-quality look of the surfaces.

- ▶ Wipe the plastic trim with a damp, lint-free cloth, e.g. a microfiber cloth.
- Heavy soiling: use car care and cleaning products recommended and approved by Mercedes-Benz.

The surface may change color temporarily. Wait until the surface is dry again.

# Cleaning the steering wheel and gear or selector lever

Thoroughly wipe with a damp cloth or use leather care agents that have been recommended and approved by Mercedes-Benz.

# Cleaning genuine wood and trim elements

- Do not use solvent-based cleaning agents such as tar remover, wheel cleaners, polishes or waxes. There is otherwise a risk of damaging the surface.
- Do not use chrome polish on trim pieces. The trim pieces have a chrome look but are mostly made of anodized aluminum and can lose their shine if chrome polish is used. Use a damp, lint-free cloth instead when cleaning the trim pieces.

If the chrome-plated trim pieces are very dirty, you can use a chrome polish. If you are unsure as to whether the trim pieces are chrome-plated or not, consult an authorized Mercedes-Benz Center.

- Wipe the wooden trim and trim pieces with a damp, lint-free cloth, e.g. a microfiber cloth.
- Heavy soiling: use car care and cleaning products recommended and approved by Mercedes-Benz.

## Cleaning the seat covers

# General notes

- Do not use microfiber cloths to clean genuine leather, artificial leather or Alcantara® covers. If used often, these can damage the cover.
- Note that regular care is essential to ensure that the appearance and comfort of the covers is retained over time.

## Genuine leather seat covers

- To retain the natural appearance of the leather, observe the following cleaning instructions:
  - Clean genuine leather covers carefully with a damp cloth and then wipe the covers down with a dry cloth.
  - Make sure that the leather does not become soaked. It may otherwise become rough and cracked.
  - Only use leather care agents that have been tested and approved by Mercedes-Benz. You can obtain these from a qualified specialist workshop.

Leather is a natural product.

It exhibits natural surface characteristics, for example:

- Differences in the texture
- Signs of stretching and marking
- Slight nuances of color

These are characteristics of leather and not material defects.

## Seat covers of other materials

Observe the following when cleaning:

- Clean artificial leather covers with a cloth moistened with a solution containing 1% detergent (e.g. dish washing liquid).
- Clean cloth covers with a microfiber cloth moistened with a solution containing 1% detergent (e.g. dish washing liquid). Rub carefully and always wipe entire seat sections to avoid leaving visible lines. Leave the seat to dry

afterwards. Cleaning results depend on the type of dirt and how long it has been there.

 Clean Alcantara® covers with a damp cloth. Make sure that you wipe entire seat sections to avoid leaving visible lines.

# Cleaning the seat belts

# MARNING

Seat belts can become severely weakened if bleached or dyed. This could cause the seat belts to tear or fail, for instance, in the event of an accident. This poses an increased risk of injury or fatal injury.

Never bleach or dye the seat belts.

- Do not clean the seat belts using chemical cleaning agents. Do not dry the seat belts by heating at temperatures above 176 °F (80 °C) or in direct sunlight.
- ► Use clean, lukewarm water and soap solution.

# Cleaning the headliner and carpets

- Headliner: if it is very dirty, use a soft brush or dry shampoo.
- Carpets: use the carpet and textile cleaning agents recommended and approved by Mercedes-Benz.

Useful information	288
Where will I find?	288
Flat tire	289
Battery (vehicle)	294
Jump-starting	298
Towing and tow-starting	300
Fuses	303


# **Useful information**

- This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- Read the information on qualified specialist workshops: (▷ page 24).

# Where will I find ...?

Warning triangle

# Removing the warning triangle



Warning triangle 2 is secured on the inside of the trunk lid.


- ▶ Open the trunk lid.
- ► Turn catch ① in the direction of the arrow.
- ▶ Remove warning triangle ②.

# Setting up the warning triangle



- ▶ Fold feet ③ down and out to the side.
- Pull side reflectors (2) upwards to form a triangle and lock them at the top using upper press-stud (1).


# First-aid kit



First-aid kit (1) is located in the trunk under the trunk floor.

- Open the trunk lid.
- ► Lift the trunk floor upwards (▷ page 256).
- ▶ Remove first-aid kit ①.
- Check the expiration date on the first-aid kit at least once a year. Replace the contents if necessary, and replace missing items.

# **Fire extinguisher**



The fire extinguisher is located underneath the front of the driver's seat.

- Pull tab ② upwards.
- ▶ Remove fire extinguisher ①.
- Have fire extinguisher (1) refilled after each use and checked every one to two years. It may otherwise fail in an emergency.

Observe the legal requirements in all countries concerned.

# Vehicle tool kit

#### General notes


The vehicle tool kit can be found in the stowage well under the trunk floor.

Apart from certain country-specific variations, vehicles are not equipped with a tire-change tool kit. Some tools for changing a wheel are specific to the vehicle. For more information on which tools are required to perform a wheel change on your vehicle, consult a qualified specialist workshop.

Necessary wheel-changing tools can include, for example:

- Jack
- Wheel chock
- Lug wrench
- Ratchet wrench
- Alignment bolt

# Vehicles with a collapsible spare wheel



- Folding wheel chock
- Fuse allocation chart
- ③ Jack
- ④ Sheet for faulty wheel
- ⑤ Alignment bolt
- 6 Lug wrench
- ⑦ Towing eye
- ⑧ Valve extractor
- Tire inflation compressor
- ► Lift the trunk floor up.
- ▶ Remove the collapsible spare wheel (▷ page 337).
- AMG vehicles: loosen the central screw of the bracket counter-clockwise and remove it together with the bracket.

# Flat tire

#### Preparing the vehicle

Your vehicle may be equipped with:

- MOExtended tires (tires with run-flat properties) (▷ page 290)
   Vehicle preparation is not necessary on vehicles with MOExtended tires.
- an emergency spare wheel (▷ page 337)
   Information on changing/mounting a wheel
   (▷ page 328).

- Stop the vehicle on solid, non-slippery and level ground, as far away as possible from traffic.
- Switch on the hazard warning lamps.
- ► Secure the vehicle against rolling away (▷ page 159).
- If possible, bring the front wheels into the straight-ahead position.
- ▶ Switch off the engine.
- Vehicles without KEYLESS-GO: remove the SmartKey from the ignition lock.
- Vehicles with KEYLESS-GO: open the driver's door. The on-board electronics now have status.

**0**. This is the same as the SmartKey having been removed.

- ► Vehicles with KEYLESS-GO: remove the Start/Stop button from the ignition lock (▷ page 139).
- All occupants must get out of the vehicle. Make sure that they are not endangered as they do so.
- Make sure that no one is near the danger area while a wheel is being changed. Anyone who is not directly assisting in the wheel change should, for example, stand behind the barrier.
- Get out of the vehicle. Pay attention to traffic conditions when doing so.
- Close the driver's door.

# MOExtended tires (tires with run-flat properties)

#### **General notes**

With MOExtended tires (tires with run flat characteristics), you can continue to drive your vehicle even if there is a total loss of pressure in one or more tires. The affected tire must not show any clearly visible damage.

You can recognize MOExtended tires by the MOExtended marking which appears on the sidewall of the tire. You will find this marking next to the tire size designation, the load-

bearing capacity and the speed index (> page 322).

MOExtended tires may only be used in conjunction with an active tire pressure loss warning system or with an active tire pressure monitor.

# If the pressure loss warning message appears in the multifunction display:

- Observe the instructions in the display messages (▷ page 233).
- Check the tire for damage.
- If driving on, observe the following notes.

The maximum driving distance is approximately 50 miles (80 km) when the vehicle is partially laden and approximately 18 miles (30 km) when the vehicle is fully laden.

In addition to the vehicle load, the driving distance possible depends upon:

- Speed
- Road condition
- Outside temperature

The driving distance possible in run-flat mode may be reduced by extreme driving conditions/maneuvers, or it can be increased through a moderate style of driving.

The maximum permissible distance which can be driven in run-flat mode is counted from the moment the tire pressure loss warning appears in the multifunction display. You must not exceed a maximum speed of

50 mph (80 km/h).

- When replacing one or all tires, make sure that you use only tires:
  - of the size specified for the vehicle and
  - marked "MOExtended"

If a tire has gone flat and cannot be replaced with a MOExtended tire, a standard tire may be used as a temporary measure. Make sure that you use the proper size and type (summer or winter tire). Vehicles equipped with MOExtended tires are not equipped with a TIREFIT kit at the factory. It is therefore recommended that you additionally equip your vehicle with a TIREFIT kit if you mount tires that do not feature run-flat properties, e.g. winter tires. A TIREFIT kit is available, for example, from a qualified specialist workshop.

#### Important safety notes

## **MARNING**

When driving in emergency mode, the driving characteristics deteriorate, e.g. when cornering, accelerating quickly and when braking. There is a risk of an accident.

Do not exceed the stated maximum speed. Avoid abrupt steering and driving maneuvers, and driving over obstacles (curbs, potholes, off-road). This applies in particular to a laden vehicle.

Stop driving in emergency mode if:

- you hear banging noises.
- the vehicle starts to shake.
- you see smoke and smell rubber.
- ESP<sup>®</sup> is intervening constantly.

• there are tears in the sidewalls of the tire. After driving in emergency mode, have the wheel rims checked at a qualified specialist workshop with regard to their further use. The defective tire must be replaced in every case.

#### **TIREFIT** kit

#### Important safety notes

TIREFIT is a tire sealant.

You can use TIREFIT to seal punctures of up to 0.16 in (4 mm), particularly those in the tire tread. You can use TIREFIT at outside temperatures down to  $-4 \, ^{\circ}$ F (-20  $^{\circ}$ C).

# MARNING

In the following situations, the tire sealant is unable to provide sufficient breakdown assistance, as it is unable to seal the tire properly:

- there are cuts or punctures in the tire larger than those mentioned above.
- the wheel rim is damaged.
- you have driven at very low tire pressures or on a flat tire.

There is a risk of an accident.

Do not drive any further. Contact a qualified specialist workshop.

# 


The tire sealant is harmful and causes irritation. It must not come into contact with your skin, eyes or clothing or be swallowed. Do not inhale TIREFIT fumes. Keep tire sealant away from children. There is a risk of injury.

If you come into contact with the tire sealant, observe the following:

- Rinse off the tire sealant from your skin immediately with water.
- If the tire sealant comes into contact with your eyes, immediately rinse them thoroughly with clean water.
- If tire sealant is swallowed, immediately rinse your mouth out thoroughly and drink plenty of water. Do not induce vomiting, and seek medical attention immediately.
- Immediately change out of clothing which has come into contact with tire sealant.
- If an allergic reaction occurs, seek medical attention immediately.
- Do not operate the tire inflation compressor for longer than eight minutes at a time without a break. It may otherwise overheat.


The tire inflation compressor can be operated again once it has cooled down.

# Using the TIREFIT kit




TIREFIT sticker, 2-part

- Do not remove any foreign objects which have penetrated the tire, e.g. screws or nails.
- ▶ Remove the tire sealant bottle, the accompanying TIREFIT sticker and the tire inflation compressor from the stowage well underneath the trunk floor (> page 289).
- ► Affix part ① of the TIREFIT sticker within the driver's field of vision.
- ► Affix part ② of the TIREFIT sticker near the valve on the wheel with the defective tire.



- Remove filler hose (6) and plug (3) from the bottom section of the tire inflation compressor housing.
- Slide the yellow filler hose connector into the mounting on yellow cap (5) of tire sealant bottle (1) until the plug engages.
- With the sealing rings in front, slide yellow cap (5) of tire sealant bottle (1) into the mounting of tire inflation compressor (2).

The cap must engage in both hooks.



- Remove the cap from valve ⑦ on the faulty tire.
- ▶ Screw filler hose ⑧ onto valve.
- ► Insert plug ③ into the socket of the cigarette lighter (▷ page 258) or into a 12 V power socket in your vehicle (▷ page 258).
- ► Turn the SmartKey to position 1 in the ignition lock (▷ page 139).
- Press on/off switch ④ on the tire inflation compressor to ON.
   The tire inflation compressor is switched on. The tire is inflated.
- **1** First, tire sealant is pumped into the tire. The pressure can briefly rise to approximately 500 kPa (5 bar/73 psi).

# Do not switch off the tire inflation compressor during this phase.

Let the tire inflation compressor run for a maximum of ten minutes. The tire should then have attained a pressure of at least 200 kPa (2.0 bar/29 psi).

If a tire pressure of 200 kPa (2.0 bar/29 psi) is achieved after a maximum of ten minutes, see (▷ page 293).

If a tire pressure of 200 kPa (2.0 bar/29 psi) is not achieved after a maximum of ten minutes, see (⊳ page 293).

If tire sealant leaks out, allow it to dry. It can then be removed like a layer of film.
 If your clothes are soiled with tire sealant, have them cleaned with perchloroethylene at a dry cleaner as soon as possible.

## Tire pressure not reached

If a maximum pressure 200 kPa (2.0 bar/ 29 psi) has not been attained after a maximum of ten minutes:

- Switch off the tire inflation compressor.
- Unscrew the filler hose from the valve of the faulty tire.
- Very slowly drive forwards or reverse approximately 30 ft (10 m).
- ▶ Pump up the tire again.

After a maximum of ten minutes, the tire pressure must be at least 200 kPa (2.0 bar/29 psi).

# 

If the required tire pressure is not reached after the specified time, the tire is too badly damaged. The tire sealant cannot repair the tire in this instance. Damaged tires and a tire pressure that is too low can significantly impair the vehicle's braking and driving characteristics. There is a risk of accident.

Do not continue driving. Contact a qualified specialist workshop.

#### Tire pressure reached

# MARNING

A tire temporarily sealed with tire sealant impairs the driving characteristics and is not suitable for higher speeds. There is a risk of accident.

You should therefore adapt your driving style accordingly and drive carefully. Do not exceed the specified maximum speed with a tire that has been repaired using tire sealant.

Residue from the tire sealant may come out of the filler hose after use. This could cause stains.

Therefore, place the filler hose in the plastic bag which contained the TIREFIT kit.

# Environmental note

Have the used tire sealant bottle disposed of professionally, e.g. at a qualified specialist workshop.

If tire pressure of 200 kPa (2.0 bar/29 psi) has been achieved after a maximum period of ten minutes:

- Switch off the tire inflation compressor.
- Unscrew the filler hose from the valve of the faulty tire.
- Stow the tire sealant bottle and the tire inflation compressor.

#### ▶ Pull away immediately.

The maximum speed for a tire sealed with tire sealant is 50 mph (80 km/h). The upper part of the TIREFIT sticker must be affixed to the instrument cluster in the driver's field of vision.

Stop after driving for approximately ten minutes and check the tire pressure with the tire inflation compressor. The tire pressure must now be at least 130 kPa (1.3 bar/19 psi).

# MARNING


If the required tire pressure is not reached after driving for a short period, the tire is too badly damaged. The tire sealant cannot repair the tire in this instance. Damaged tires and a tire pressure that is too low can significantly impair the vehicle's braking and driving characteristics. There is a risk of accident.

Do not continue driving. Contact a qualified specialist workshop.

- Correct the tire pressure if it is still at least 130 kPa (1.3 bar/19 psi) (for the values, see the Tire and Loading Information placard on the driver's side B-pillar or tire pressure table on the fuel filler flap).
- ► To increase the tire pressure: switch on the tire inflation compressor.



- ► To reduce the tire pressure: depress pressure release button ① next to pressure gauge ②.
- When the tire pressure is correct, unscrew the filler hose from the valve of the sealed tire.
- Screw the valve cap onto the tire valve of the sealed tire.



- ► To remove the tire sealant bottle from the tire inflation compressor, press together the locking tabs on the yellow cap.
- ▶ Pull the tire sealant bottle out of the tire inflation compressor.

The filler hose remains attached to the tire sealant bottle.

- ► Stow the tire sealant bottle and the tire inflation compressor.
- Drive to the nearest qualified specialist workshop and have the tire changed there.

- Have the tire sealant bottle and the filler hose replaced as soon as possible at a qualified specialist workshop.
- Have the tire sealant bottle replaced every four years at a qualified specialist workshop.

# Battery (vehicle)

#### Important safety notes

Special tools and expert knowledge are required when working on the battery, e.g. removal and installing. You should therefore have all work involving the battery carried out at a qualified specialist workshop.

# 

Work carried out incorrectly on the battery can lead, for example, to a short circuit and thus damage the vehicle electronics. This can lead to function restrictions applying to safety-relevant systems, e.g. the lighting system, ABS (anti-lock braking system) or ESP<sup>®</sup> (Electronic Stability Program). The operating safety of your vehicle may be restricted. You could lose control of the vehicle, for example:

- braking
- in the event of abrupt steering maneuver and/or when the vehicle's speed is not adapted to the road conditions

There is a risk of an accident.

In the event of a short circuit or a similar incident, contact a qualified specialist workshop immediately. Do not drive any further. You should have all work involving the battery carried out at a qualified specialist workshop.

For more information on ABS ( $\triangleright$  page 59) and ESP ( $\triangleright$  page 61).

# 

Electrostatic build-up can lead to the creation of sparks, which could ignite the highly

explosive gases of a battery. There is a risk of an explosion.

Before handling the battery, touch the vehicle body to remove any existing electrostatic build-up.

The highly flammable gas mixture forms when charging the battery as well as when jump-starting.

Always make sure that neither you nor the battery is electrostatically charged. A buildup of electrostatic charge can be caused, for example:

- by wearing clothing made from synthetic fibers
- due to friction between clothing and seats
- if you push or pull the battery across the carpet or other synthetic materials
- if you wipe the battery with a cloth

# 

During the charging process, a battery produces hydrogen gas. If a short circuit occurs or sparks are created, the hydrogen gas can ignite. There is a risk of an explosion.

- Make sure that the positive terminal of a connected battery does not come into contact with vehicle parts.
- Never place metal objects or tools on a battery.
- It is important that you observe the described order of the battery terminals when connecting and disconnecting a battery.
- When jump-starting, make sure that the battery poles with identical polarity are connected.
- It is particularly important to observe the described order when connecting and disconnecting the jumper cables.
- Never connect or disconnect the battery terminals while the engine is running.

# 

Battery acid is caustic. There is a risk of injury.

Avoid contact with the skin, eyes or clothing. Do not inhale any battery gases. Do not lean over the battery. Keep children away from batteries. Wash battery acid immediately with water and seek medical attention.

#### 



Batteries contain dangerous substances. It is against the law to dispose of them with the household rubbish. They must be collected separately and recycled to protect the environment.



Dispose of batteries in an environmentally friendly manner. Take discharged batteries to a qualified specialist workshop or a special collection point for used batteries.

Have the battery checked regularly at a qualified specialist workshop.

Observe the service intervals in the Maintenance Booklet or contact a qualified specialist workshop for more information.

- You should have all work involving the battery carried out at a qualified specialist workshop. In the exceptional case that it is necessary for you to disconnect the battery yourself, make sure that:
  - you switch off the engine and remove the key. On vehicles with KEYLESS-GO, ensure that the ignition is switched off. Check that all the indicator lamps in the instrument cluster are off. Otherwise, electronic components, such as the alternator, may be damaged.
  - you first remove the negative terminal clamp and then the positive terminal clamp. Never swap the terminal clamps. Otherwise, the vehicle's electronic system may be damaged.
  - in vehicles with automatic transmission, the transmission is locked in position **P**

after disconnecting the battery. The vehicle is secured against rolling away. You can then no longer move the vehicle.

The battery and the cover of the positive terminal clamp must be installed securely during operation.

In order for the battery to achieve the maximum possible service life, it must always be sufficiently charged.

Comply with safety precautions and take protective measures when handling batteries.



Risk of explosion.

Fire, open flames and smoking are prohibited when handling the battery. Avoid creating sparks.



Battery acid is caustic. Avoid contact with skin, eyes or clothing. Wear suitable protective clothing, especially gloves, apron and faceguard.

Rinse any acid spills immediately with clear water. Contact a physician if necessary.



Wear eye protection.



Keep children away.



Observe this Operator's Manual.

The vehicle battery, like other batteries, can discharge over time if you do not use the vehicle. In this case, have the battery disconnected at a qualified specialist workshop. You can also charge the battery with a charger recommended by Mercedes-Benz. Contact a qualified specialist workshop for further information. Have the battery condition of charge checked more frequently if you use the vehicle mainly for short trips or if you leave it standing idle for a lengthy period. Consult a qualified specialist workshop if you wish to leave your vehicle parked for a long period of time.

- Remove the SmartKey if you park the vehicle and do not require any electrical consumers. The vehicle will then use very little energy, thus conserving battery power.
- If the power supply has been interrupted, e.g. if you reconnect the battery, you will have to:
  - set the clock; see the separate operating instructions.

On vehicles with COMAND and a navigation system, the clock is set automatically.

 reset the function for folding the exterior mirrors in/out automatically, by folding the mirrors out once (▷ page 104).

# Charging the battery

# MARNING

During charging and jump-starting, explosive gases can escape from the battery. There is a risk of an explosion.

Particularly avoid fire, open flames, creating sparks and smoking. Ensure there is sufficient ventilation while charging and jump-starting. Do not lean over a battery.

#### 

Battery acid is caustic. There is a risk of injury. Avoid contact with the skin, eyes or clothing. Do not inhale any battery gases. Do not lean over the battery. Keep children away from batteries. Wash battery acid immediately with water and seek medical attention.

# 

A discharged battery can freeze at temperatures below freezing point. When jump-starting the vehicle or charging the battery, gases can escape from the battery. There is a risk of an explosion.

Allow the frozen battery to thaw out before charging it or jump-starting.

Only use battery chargers with a maximum charging voltage of 14.8 V.

Only charge the battery using the jumpstarting connection point.

The jump-starting connection point is in the engine compartment.

If, at low temperatures, the indicator lamps/ warning lamps in the instrument cluster do not light up, it is highly likely that the discharged battery has frozen. In this case, you may neither charge the battery nor jumpstart the vehicle. The service life of a thawedout battery may be shorter. The starting characteristics can be impaired, particularly at low temperatures. Have the thawed-out battery checked at a qualified specialist workshop.

Read the battery charger's operating instructions before charging the battery.

- Open the hood.
- Connect the battery charger to the positive terminal and ground point in the same order as when connecting the donor battery in the jump-starting procedure (> page 298).

#### Jump-starting

For the jump-starting procedure, use only the jump-starting connection point, consisting of a positive terminal and a ground point, in the engine compartment.

# 

Battery acid is caustic. There is a risk of injury.

Avoid contact with the skin, eyes or clothing. Do not inhale any battery gases. Do not lean over the battery. Keep children away from batteries. Wash battery acid immediately with water and seek medical attention.

# 

During charging and jump-starting, explosive gases can escape from the battery. There is a risk of an explosion.

Particularly avoid fire, open flames, creating sparks and smoking. Ensure there is sufficient ventilation while charging and jump-starting. Do not lean over a battery.

# MARNING

During the charging process, a battery produces hydrogen gas. If a short circuit occurs or sparks are created, the hydrogen gas can ignite. There is a risk of an explosion.

- Make sure that the positive terminal of a connected battery does not come into contact with vehicle parts.
- Never place metal objects or tools on a battery.
- It is important that you observe the described order of the battery terminals when connecting and disconnecting a battery.
- When jump-starting, make sure that the battery poles with identical polarity are connected.
- It is particularly important to observe the described order when connecting and disconnecting the jumper cables.
- Never connect or disconnect the battery terminals while the engine is running.

# 

A discharged battery can freeze at temperatures below freezing point. When jump-starting the vehicle or charging the battery, gases can escape from the battery. There is a risk of an explosion. Allow the frozen battery to thaw out before charging it or jump-starting.

Avoid repeated and lengthy starting attempts. Otherwise, the catalytic converter could be damaged by the non-combusted fuel.


If, at low temperatures, the indicator lamps/warning lamps in the instrument cluster do not light up, it is highly likely that the discharged battery has frozen. In this case, you may neither charge the battery nor jump-start the vehicle. The service life of a thawed-out battery may be shorter. The starting characteristics can be impaired, particularly at low temperatures. Have the thawed-out battery checked at a qualified specialist workshop.

Do not start the vehicle using a rapid charging device. If your vehicle's battery is discharged, the engine can be jump-started from another vehicle or from a second battery using jumper cables. Observe the following points:

- The battery is not accessible in all vehicles. If the other vehicle's battery is not accessible, jump-start the vehicle using a second battery or a jump-starting device.
- You may only jump-start the vehicle when the engine and exhaust system are cold.
- Do not start the engine if the battery is frozen. Let the battery thaw first.
- Only jump-start from batteries with a 12 V voltage rating.
- Only use jumper cables which have a sufficient cross-section and insulated terminal clamps.
- If the battery is fully discharged, leave the battery that is being used to jump-start connected for a few minutes before attempting to start. This charges the battery slightly.
- Make sure that the two vehicles do not touch.

Make sure that:

- the jumper cables are not damaged.
- when the jumper cables are connected to the battery, uninsulated sections of the terminal clamp do not come into contact with other metal sections.
- the jumper cables cannot come into contact with parts which can move when the engine is running, such as the V-belt pulley or the fan.
- Secure the vehicle by applying the electric parking brake.
- ► Manual transmission: depress the clutch pedal fully and shift to neutral.
- ► Automatic transmission: move the selector lever to position P.
- Switch off all electrical consumers, e.g. rear window defroster, lighting, etc.
- Open the hood.



Position number (6) identifies the charged battery of the other vehicle or an equivalent jumpstarting device.

- ▶ Slide cover ① of positive terminal ② in the direction of the arrow.
- ► Connect positive terminal ② on your vehicle to positive terminal ③ of donor battery ⑥ using the jumper cable, always begin with positive terminal ② on your own vehicle first.
- ► Start the engine of the donor vehicle and run it at idling speed.
- ► Connect negative terminal ④ of donor battery ⑥ to ground point ⑤ of your vehicle using the jumper cable, connecting the jumper cable to battery of other vehicle ⑥ first.
- ► Start the engine.
- ▶ Before disconnecting the jumper cables, let the engine run for several minutes.
- ▶ First, remove the jumper cables from ground point (5) and negative terminal (4), then from positive clamp (2) and positive terminal (3). Begin each time at the contacts on your own vehicle first.
- ► Close cover (1) of positive terminal (2) after removing the jumper cables.
- ► Have the battery checked at a qualified specialist workshop.
- **1** Jump-starting is not considered to be a normal operating condition.
- Jumper cables and further information regarding jump-starting can be obtained at any qualified specialist workshop.

# Towing and tow-starting

#### Important safety notes

# MARNING

If the weight of the vehicle to be towed or towstarted is greater than the permissible gross weight of your vehicle:

- the towing eye could detach itself
- the vehicle/trailer combination could rollover.

There is a risk of an accident.

When towing or tow-starting another vehicle, its weight should not be greater than the permissible gross weight of your vehicle.

- If DISTRONIC PLUS or the HOLD function is activated, the vehicle brakes automatically in certain situations. To prevent damage to the vehicle, deactivate DISTRONIC PLUS and the HOLD function in the following or other similar situations:
  - when towing the vehicle
  - in the car wash
- Only secure the tow rope or tow bar at the towing eyes. Otherwise, the vehicle could be damaged.
- Do not use the towing eye for recovery, this could damage the vehicle. If in doubt, recover the vehicle with a crane.
- When towing, pull away slowly and smoothly. If the tractive power is too high, the vehicles could be damaged.
- Do not tow with sling-type equipment. This could damage the vehicle.
- On vehicles with KEYLESS-GO, use the SmartKey instead of the Start/Stop

button. Turn the SmartKey to position 2 in the ignition lock and shift the automatic transmission to **N**. Then, turn the SmartKey back to **0** and leave it in the ignition lock.

- Make sure that the electric parking brake is released. If the electric parking brake is faulty, visit a qualified specialist workshop.
- The vehicle can be towed a maximum of 30 miles (50km). The towing speed of 30 mph (50 km/h) must not be exceeded. If the vehicle has to be towed more than 30 miles (50km), the entire vehicle must be raised and transported.

If you tow or tow-start another vehicle, its weight must not exceed the maximum permissible gross vehicle weight of your vehicle.

Information on your vehicle's gross vehicle weight rating can be found on the vehicle identification plate (▷ page 342).

It is better to have the vehicle transported than to have it towed.

Vehicles with automatic transmission: when towing a vehicle, the automatic transmission must be in position **N**.

The battery must be connected and charged. Otherwise, you:

- cannot turn the SmartKey to position **2** in the ignition lock
- $\bullet$  cannot shift the transmission to position  ${\bf N}$  on vehicles with automatic transmission

Vehicles with automatic transmission: release the selector lever lock manually to move it out of position  $P(\triangleright$  page 156).

Disarm the automatic locking feature before the vehicle is towed (▷ page 205). You could otherwise be locked out when pushing or towing the vehicle.

# Installing/removing the towing eye

# Installing the towing eye

# MARNING

The exhaust tail pipe may be very hot. There is a risk of burns when removing the rear cover.

Do not touch the exhaust pipe. Take particular care when removing the rear cover.



The mountings for the removable towing eyes are located in the bumpers. They are at the front and at the rear, behind the covers.

- Press the mark on cover ① inwards in the direction of the arrow.
- ► Take cover ① off the opening.
- ▶ Remove the towing eye from the vehicle tool kit (▷ page 289).
- Screw in and tighten the towing eye clockwise to the stop.

# Removing the towing eye

- Unscrew and remove the towing eye.
- Attach cover ① to the bumper and press until it engages.
- ► Place the towing eye in the vehicle tool kit (▷ page 289).

# Towing the vehicle with the rear axle raised

- The ignition must be switched off if you are towing the vehicle with the rear axle raised. Intervention by ESP<sup>®</sup> could otherwise damage the brake system.
- Switch on the hazard warning lamps (▷ page 111).
- ► Turn the SmartKey to position **0** in the ignition lock and remove the SmartKey from the ignition lock.
- When leaving the vehicle, take the SmartKey or the KEYLESS-GO key with you.

When towing your vehicle with the rear axle raised, it is important that you observe the safety instructions ( $\triangleright$  page 300).

# Towing a vehicle with both axles on the ground

# MARNING

You can no longer steer the vehicle if the steering wheel lock has been engaged. There is a risk of an accident.

Always switch off the ignition when towing the vehicle with a tow cable or a tow bar.

- ► Switch on the hazard warning lamps (▷ page 111).
- When towing with the hazard warning lamps switched on, use the combination switch as usual to signal a change of direction. In this case, only the indicator lamps for the direction of travel flash. When you reset the combination switch, the hazard warning flashers start flashing again.
- ► Turn the SmartKey to position 2 in the ignition lock.
- When the vehicle is stationary, depress the brake pedal and keep it depressed.

 Vehicles with manual transmission: depress the clutch pedal fully and shift to neutral.

or

- Vehicles with automatic transmission: shift the automatic transmission to position N.
- Release the brake pedal.
- ► Release the electric parking brake.

It is important that you observe the safety instructions when towing away your vehicle (> page 300).

# Transporting the vehicle

You may only secure the vehicle by the wheels, not by parts of the vehicle such as axle or steering components. Otherwise, the vehicle could be damaged.

The towing eye can be used to pull the vehicle onto a trailer or transporter for transporting purposes.

- Vehicles with manual transmission: depress the clutch pedal fully and shift to neutral.
- ► Vehicles with automatic transmission: turn the SmartKey to position 2 in the ignition lock.
- ► Move the selector lever to **N**.

#### As soon as the vehicle has been loaded:

- Prevent the vehicle from rolling away by applying the electric parking brake.
- Vehicles with manual transmission: fully depress the clutch pedal and engage first or reverse gear.
- ► Vehicles with automatic transmission: move the selector lever to P.
- ► Turn the SmartKey to position **0** in the ignition lock and remove the SmartKey from the ignition lock.
- Secure the vehicle.

# Tow-starting (emergency engine starting)

Vehicles with automatic transmission must not be tow-started. You could otherwise damage the automatic transmission.

You can find information on "Jump-starting" at (▷ page 298).

Before tow-starting:

- the battery must be connected
- the engine must be cold
- the exhaust system must have cooled down.

When tow-starting, it is important that you observe the safety instructions ( $\triangleright$  page 300).

- Switch on the hazard warning lamps (▷ page 111).
- ▶ Install the towing eye (▷ page 301).
- Secure the rigid towing bar or the towing rope.
- Depress and hold the brake pedal.
- Turn the SmartKey to position 2 in the ignition lock.
- Depress the clutch pedal fully, engage second gear and keep the clutch pedal depressed.
- ▶ Release the brake pedal.
- Tow-start the vehicle.
- Release the clutch pedal slowly; do not depress the accelerator pedal while doing so.
- As soon as the engine starts, depress the clutch pedal immediately and shift to neutral.
- Stop at a suitable place, in accordance with the traffic conditions.
- Depress the parking brake.
- Remove the rigid towing bar or towing rope.
- ▶ Remove the towing eye (▷ page 301).
- Switch off the hazard warning lamps.

#### Fuses

# Important safety notes

# 

If you manipulate or bridge a faulty fuse or if you replace it with a fuse with a higher amperage, the electric cables could be overloaded. This could result in a fire. There is a risk of an accident and injury.

Always replace faulty fuses with the specified new fuses having the correct amperage.

Only use fuses that have been approved for Mercedes-Benz vehicles and which have the correct fuse rating for the system concerned. Otherwise, components or systems could be damaged.

The fuses in your vehicle serve to close down faulty circuits. If a fuse blows, all the components on the circuit and their functions stop operating.

Blown fuses must be replaced with fuses of the same rating, which you can recognize by the color and value. The fuse ratings are listed in the fuse allocation chart.

If a newly inserted fuse also blows, have the cause traced and rectified at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.

#### Before changing a fuse

- Secure the vehicle against rolling away (> page 159).
- Switch off all electrical consumers.
- ► Turn the SmartKey to position 0 in the ignition lock and remove it (▷ page 139).

or

► On vehicles with KEYLESS-GO, make sure the ignition is switched off (▷ page 139).

All indicator lamps in the instrument cluster must be off.

The fuses are located in various fuse boxes:

- Fuse box in the engine compartment on the left-hand side of the vehicle, when viewed in the direction of travel
- Fuse box in the trunk

The fuse allocation chart is located in the vehicle tool kit in the stowage compartment under the trunk floor ( $\triangleright$  page 289).

#### Fuse box in the engine compartment

#### MARNING

When the hood is open and the windshield wipers are set in motion, you can be injured by the wiper linkage. There is a risk of injury. Always switch off the windshield wipers and the ignition before opening the hood.

- Make sure that no moisture can enter the fuse box when the cover is open.
- When closing the cover, make sure that it is lying correctly on the fuse box. Moisture seeping in or dirt could otherwise impair the operation of the fuses.
- Make sure that the windshield wipers are turned off.
- ▶ Open the hood.



- Use a dry cloth to remove any moisture from the fuse box.
- ▶ To open: open clamp ①.
- Remove fuse box cover ② forwards.


- ► **To close:** check whether the seal is seated correctly in cover ②.
- Insert cover ② at the rear of the fuse box into the retainer.
- ► Fold down cover ② and close clamps ①.
- Close the hood.

#### Fuse box in the trunk

Make sure that no moisture can enter the fuse box when the cover is open.

The fuse box is located in the trunk behind the partition covering.

Open the trunk lid.



- ► **To open:** release cover ① on the right and left-hand sides with a flat object.
- Open cover ① downwards in the direction of the arrow.

Useful information	306
Important safety notes	306
Operation	306
Winter operation	308
Tire pressure	310
Loading the vehicle	317
All about wheels and tires	320
Changing a wheel	328
Wheel and tire combinations	333
Emergency spare wheel	337

#### **Useful information**

- This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- I Read the information on qualified specialist workshops: (▷ page 24).

#### Important safety notes

#### MARNING

If wheels and tires of the wrong size are used, the wheel brakes or suspension components may be damaged. There is a risk of an accident.

Always replace wheels and tires with those that fulfill the specifications of the original part.

When replacing wheels, make sure to use the correct:

- designation
- model

When replacing tires, make sure to use the correct:

- designation
- manufacturer
- model

#### MARNING

A flat tire severely impairs the driving, steering and braking characteristics of the vehicle. There is a risk of accident.

Tires without run-flat characteristics:

- do not drive with a flat tire.
- immediately replace the flat tire with your emergency spare wheel or spare wheel, or consult a qualified specialist workshop.

Tires with run-flat characteristics:

 pay attention to the information and warning notices on MOExtended tires (tires with run-flat characteristics).

Accessories that are not approved for your vehicle by Mercedes-Benz or are not being used correctly can impair operating safety. Before purchasing and using non-approved accessories, visit a qualified specialist workshop and inquire about:

- suitability
- · legal stipulations
- factory recommendations

Information on dimensions and types of wheels and tires for your vehicle can be found (> page 333).

Information on air pressure for the tires on your vehicle can be found:

- on the vehicle's Tire and Loading Information placard on the B-pillar
- on the tire pressure label on the fuel filler flap
- under "Tire pressure"

# Operation

#### Information on driving

If the vehicle is heavily loaded, check the tire pressures and correct them if necessary.

While driving, pay attention to vibrations, noises and unusual handling characteristics, e.g. pulling to one side. This may indicate that the wheels or tires are damaged. If you suspect that a tire is defective, reduce your speed immediately. Stop the vehicle as soon as possible to check the wheels and tires for damage. Hidden tire damage could also be causing the unusual handling characteristics. If you find no signs of damage, have the tires and wheels checked at a qualified specialist workshop.

When parking your vehicle, make sure that the tires do not get deformed by the curb or

other obstacles. If it is necessary to drive over curbs, speed humps or similar elevations, try to do so slowly and at an obtuse angle. Otherwise, the tires, particularly the sidewalls, may be damaged.

## Regular checking of wheels and tires

# MARNING

Damaged tires can cause tire inflation pressure loss. As a result, you could lose control of your vehicle. There is a risk of accident.

Check the tires regularly for signs of damage and replace any damaged tires immediately.

Regularly check the wheels and tires of your vehicle for damage at least once a month, as well as after driving off-road or on rough roads. Damaged wheels can cause a loss of tire pressure. Pay particular attention to damage such as:

- cuts in the tires
- punctures
- tears in the tires
- bulges on tires
- deformation or severe corrosion on wheels

Regularly check the tire tread depth and the condition of the tread across the whole width of the tire ( $\triangleright$  page 307). If necessary, turn the front wheels to full lock in order to inspect the inner side of the tire surface.

All wheels must have a valve cap to protect the valve against dirt and moisture. Do not mount anything onto the valve other than the standard valve cap or other valve caps approved by Mercedes-Benz for your vehicle. Do not use any other valve caps or systems, e.g. tire pressure monitoring systems. Regularly check the pressure of all the tires

particularly prior to long trips. Adjust the tire pressure as necessary ( $\triangleright$  page 310).

Observe the notes on the emergency spare wheel ( $\triangleright$  page 337)

The service life of tires depends on the following factors amongst other things:

- Driving style
- Tire pressure
- Distance covered

# Important safety notes on the tire tread

# 


Insufficient tire tread will reduce tire traction. The tire is no longer able to dissipate water. This means that on wet road surfaces, the risk of hydroplaning increases, in particular where speed is not adapted to suit the driving conditions. There is a risk of accident.

If the tire pressure is too high or too low, tires may exhibit different levels of wear at different locations on the tire tread. Thus, you should regularly check the tread depth and the condition of the tread across the entire width of all tires.

Minimum tire tread depth for:

- Summer tires: <sup>1</sup>/<sub>8</sub> in (3 mm)
- M+S tires: 1/6 in (4 mm)

For safety reasons, replace the tires before the legally prescribed limit for the minimum tire tread depth is reached.



Bar indicator ① for tread wear is integrated into the tire tread.

Treadwear indicators (TWI) are required by law. Six indicators are positioned on the tire tread. They are visible once the tread depth is approximately  $\frac{1}{16}$  in (1.6 mm). If this is the case, the tire is so worn that it must be replaced.

# Selecting, mounting and replacing tires

• Only mount tires and wheels of the same type and make.

Exception: it is permissible to install a different type or make in the event of a flat tire. Observe the "MOExtended tires (tires with run-flat characteristics" section (> page 290).

- Only mount tires of the correct size onto the wheels.
- Break in new tires at moderate speeds for the first 60 miles (100 km). They only reach their full performance after this distance.
- Do not drive with tires which have too little tread depth, as this significantly reduces the traction on wet roads (hydroplaning).
- Replace the tires after six years at the latest, regardless of wear.

# MOExtended tires (tires with run-flat properties)

With MOExtended tires (tires with run flat characteristics), you can continue to drive your vehicle even if there is a total loss of pressure in one or more tires.

MOExtended tires may only be used in conjunction with an active tire pressure loss warning system or with an active tire pressure monitor and on wheels specifically tested by Mercedes-Benz.

Notes on driving with MOExtended tires with a flat tire ( $\triangleright$  page 290).

• Vehicles equipped with MOExtended tires are not equipped with a TIREFIT kit at the factory. It is therefore recommended that you additionally equip your vehicle with a TIREFIT kit if you mount tires that do not feature run-flat properties, e.g. winter tires. A TIREFIT kit can be obtained from a qualified specialist workshop.

#### Winter operation

#### **General notes**

Have your vehicle winterproofed at a qualified specialist workshop at the onset of winter. Observe the notes in the "Changing a wheel" section (▷ page 328).

#### Driving with summer tires

At temperatures below 45 °F (+7 °C), summer tires lose elasticity and therefore traction and braking power. Change the tires on your vehicle to M+S tires. Using summer tires at very cold temperatures could cause cracks to form, thereby damaging the tires permanently. Mercedes-Benz cannot accept responsibility for this type of damage.

#### M+S tires

# MARNING

M+S tires with a tire tread depth of less than <sup>1</sup>/<sub>6</sub> in (4 mm) are not suitable for use in winter and do not provide sufficient traction. There is a risk of an accident.

M+S tires with a tread depth of less than  $\frac{1}{6}$  in (4 mm) must be replaced immediately.

At temperatures below 45 °F (+7 °C), use winter tires or all-season tires. Both types of tire are identified by the M+S marking.

Only winter tires bearing the A snowflake symbol in addition to the M+S marking provide the best possible grip in wintry road conditions.

Only these tires will allow driving safety systems such as ABS and ESP<sup>®</sup> to function optimally in winter. These tires have been developed specifically for driving in snow.

Use M+S tires of the same make and tread on all wheels to maintain safe handling characteristics.

Always observe the maximum permissible speed specified for the M+S tires you have mounted.

When you have mounted M+S tires:

- Check the tire pressures ( $\triangleright$  page 313).
- ► Vehicles for USA: restart the tire pressure monitor (▷ page 314).
- ► Vehicles for Canada: restart the tire pressure loss warning system (▷ page 314).

For more information on driving with the emergency spare wheel, see ( $\triangleright$  page 337).

# **Snow chains**

# 

If snow chains are installed to the front wheels, they may drag against the vehicle body or chassis components. This could cause damage to the vehicle or the tires. There is a risk of an accident.

To avoid hazardous situations:

- never install snow chains to the front wheels
- always install snow chains in pairs to the rear wheels.

You must drive at raised vehicle level (level 1) if snow chains have been mounted. The vehicle may otherwise be damaged.

• On some tire sizes there is not enough space for snow chains. To avoid damage to the vehicle or tires, observe the "Wheel and tire combinations" section under "Tires and wheels".

Vehicles with steel wheels: if you wish to mount snow chains on steel wheels, make sure that you remove the respective wheels' hubcaps first. The hubcaps may otherwise be damaged. For safety reasons, Mercedes-Benz recommends that you only use snow chains that have been specially approved for your vehicle by Mercedes-Benz, or are of a corresponding standard of quality. If you intend to mount snow chains, please bear the following points in mind:

- Snow chains may not be mounted on all wheel/tire combinations. Permissible wheel-tire combinations (▷ page 333).
- Only use snow chains when driving on roads completely covered by snow.
   Remove the snow chains as soon as possible when you come to a road that is not snow-covered.
- Local regulations may restrict the use of snow chains. Observe the appropriate regulations if you wish to install snow chains.
- Do not exceed the maximum permissible speed of 30 mph (50 km/h).
- You may wish to deactivate ESP<sup>®</sup> when pulling away with snow chains installed (▷ page 62). You can thereby allow the wheels to spin in a controlled manner, achieving an increased driving force (cutting action).

For more information on driving with the emergency spare wheel, see ( $\triangleright$  page 337).

#### **Tire pressure**

Tire pressure specifications

#### Important safety notes

# MARNING

Tires with tire pressures that are too low or too high are associated with the following hazards:

- they can burst, in particular if the vehicle is heavily laden or when driven at high speeds.
- the tires can wear excessively and/or unevenly, which can severely impair tire traction.
- the driving, steering and braking characteristics may be severely impaired.

There is a risk of accident.

Follow recommended tire inflation pressures and check the pressure of all the tires including the spare wheel:

- monthly, at least
- if the load changes
- · before beginning a long journey
- under different operating conditions, e.g. off-road driving

If necessary, correct the tire pressure.

 The specifications on the sample Tire and Loading Information placard and tire pressure tables are examples. Tire pressure specifications are vehicle-specific and may deviate from the data shown here. The tire pressure specifications that are valid for your vehicle can be found on the Tire and Loading Information placard and tire pressure table on the vehicle.

#### **General notes**

The recommended tire pressures for the tires mounted at the factory can be found on the labels described here.

**Operation with the emergency spare wheel**(▷ page 337). Further information on tire pressures can be obtained at a qualified specialist workshop.

## Tire and Loading Information placard

691	RENSEIGNEMENT	SUR LES PNEUS	T LE CHARGEMENT
The command of	SEATING CASHOTY NOMERE OF PLACES. 10 weight of bompanth and o	105 aboutd honer nanned	ADDELE (1) ADDELE (1) ADDELE (1) ADDELE (1) ADDELE (1) ADDELE (1) ADDELE (1)
TINE	SZZE DIMENSIONS	COLD TIRE PRESSURE PRESSION DES PNEUS À FROID	SPE OWNER'S MANUAL FOR
FRONT	255/40 ZR 18 99Y XL	200 KPA, 29 PSI	ADDITIONAL INFORMATION
REAR ARRIÊRE	285/35 ZR 18 1019 XL	200 KPA, 29 PSI	VOIR LE MANUEL DE L'USAGER
SHARE DE SECOURS	175/55-1895P	420 KPA, 60 PSI	POUR PLUS DE RENSIGNEMENTS,


① Recommended tire pressures

The Tire and Loading Information placard is on the B-pillar on the driver's side (> page 317).

The Tire and Loading Information placard contains the recommended tire pressures for cold tires. The recommended tire pressures are valid for the maximum permissible load and up to the maximum permissible vehicle speed.


#### Tire pressure table

The tire pressure table is on the inside of the fuel filler flap.




Example: tire pressure table for all tires permitted for this vehicle by the factory

The tire pressure table contains the recommended pressures for cold tires for various operating conditions, i.e. differing load and speed conditions.



Example: tire pressure table with tire dimensions

If a tire size precedes a tire pressure, the tire pressure information following is only valid for that tire size. The load conditions "partially laden" and "fully laden" are defined in the table for different numbers of occupants and amounts of luggage. The actual number of seats may differ.



Some tire pressure tables show only the rim diameters instead of the full tire size, e.g. **R18**. The rim diameter is part of the tire size and can be found on the tire sidewall ( $\triangleright$  page 322).

If the tire pressures have been set to the lower values for lighter loads and/or lower road speeds, the pressures should be reset to the higher values:

- if you want to drive with an increased load and/or
- if you want to drive at higher road speeds.
- The tire pressures for increased loads and/or higher road speeds, shown in the tire pressure table, may have a negative effect on driving comfort.

If the tire pressure is not set correctly, this can lead to an excessive build up of heat and a sudden loss of pressure.

For more information, contact a qualified specialist workshop.

#### Important notes on tire pressure

#### MARNING

If the tire pressure drops repeatedly, the wheel, valve or tire may be damaged. Tire pressure that is too low may result in a tire blow-out. There is a risk of an accident.

- Check the tire for foreign objects.
- Check whether the wheel is losing air or the valve is leaking.

If you are unable to rectify the damage, contact a qualified specialist workshop.

## MARNING

If you fit unsuitable accessories onto tire valves, the tire valves may be overloaded and malfunction, which can cause tire pressure loss. Due to their design, retrofitted tire pressure monitors keep the tire valve open. This can also result in tire pressure loss. There is a risk of an accident.

Only screw the standard valve cap or other valve caps approved by Mercedes-Benz for your vehicle onto the tire valve.

Use a suitable pressure gauge to check the tire pressure. The outer appearance of a tire does not permit any reliable conclusion about the tire pressure. On vehicles equipped with the electronic tire pressure monitoring system, the tire pressure can be checked using the on-board computer.

The tire temperature and pressure increase when the vehicle is in motion. This is dependent on the driving speed and the load. Therefore, you should only correct tire pressures when the tires are cold. The tires are cold:

- if the vehicle has been parked without direct sunlight on the tires for at least three hours and
- if the vehicle has been driven for less than 1 mile (1.6 km).

The tire temperature changes depending on the outside temperature, the vehicle speed and the tire load. If the tire temperature changes by 18 °F (10 °C), the tire pressure changes by approximately 10 kPa (0.1 bar/ 1.5 psi). Take this into account when checking the pressure of warm tires. Only correct the tire pressure if it is too low for the current operating conditions. If you check the tire pressure when the tires are warm, the resulting value will be higher than if the tires were cold. This is normal. Do not reduce the tire pressure to the value specified for cold tires. The tire pressure would otherwise be too low.

Observe the recommended tire pressures for cold tires:

- on the Tire and Loading Information placard on the B-pillar on the driver's side
- in the tire pressure table on the inside of the fuel filler flap
- printed in yellow on the rim of the emergency/collapsible spare wheel (depending on vehicle equipment)

# Underinflated or overinflated tires

# Underinflation

# 

Tires with pressure that is too low can overheat and burst as a consequence. In addition, they also suffer from excessive and/ or irregular wear, which can severely impair the braking properties and the driving characteristics. There is a risk of an accident.

Avoid tire pressures that are too low in all the tires, including the spare wheel.

Underinflated tires may:

- overheat, leading to tire defects
- have an adverse effect on handling characteristics
- · wear quickly and unevenly
- have an adverse effect on fuel consumption

# Overinflation

# MARNING

Tires with excessively high pressure can burst because they are damaged more easily by road debris, potholes etc. In addition, they also suffer from irregular wear, which can severely impair the braking properties and the driving characteristics. There is a risk of an accident.

Avoid tire pressures that are too high in all the tires, including the spare wheel.

Overinflated tires may:

- increase the braking distance
- have an adverse effect on handling characteristics
- · wear quickly and unevenly
- have an adverse effect on ride comfort
- be more susceptible to damage

# Maximum tire pressures



 Example: maximum permissible tire pressure

Never exceed the maximum permissible tire inflation pressure. Always observe the recommended tire pressure for your vehicle

when adjusting the tire pressure  $(\triangleright \text{ page 310}).$ 

The actual values for tires are vehiclespecific and may deviate from the values in the illustration.

#### Checking the tire pressures

#### Important safety notes

Observe the notes on tire pressure  $(\triangleright \text{ page 310}).$ 

Information on air pressure for the tires on your vehicle can be found:

- on the vehicle's Tire and Loading Information placard on the B-pillar (▷ page 317)
- on the tire pressure label on the fuel filler flap (▷ page 157)
- in the "Tire pressure" section

#### Checking tire pressures manually

To determine and set the correct tire pressure, proceed as follows:

- Remove the valve cap of the tire that is to be checked.
- Press the tire pressure gauge securely onto the valve.
- ► Read the tire pressure and compare it with the recommended value on the Tire and Loading Information placard (▷ page 310).
- ► If the tire pressure is too low, increase it to the recommended value.
- If the tire pressure is too high, release air by pressing down the metal pin in the valve. Use the tip of a pen, for example. Then, check the tire pressure again using the tire pressure gauge.
- Screw the valve cap onto the valve.
- Repeat these steps for the other tires.

#### Tire pressure loss warning system (Canada only)

#### General notes

While the vehicle is in motion, the tire pressure loss warning system monitors the set tire pressure using the rotational speed of the wheels. This enables the system to detect significant pressure loss in a tire. If the speed of rotation of a wheel changes as a result of a loss of pressure, a corresponding warning message will appear in the multifunction display.

You can recognize the tire pressure loss warning by the Run Flat Indicator Active Press 'OK' to Restart message which appears in the Service menu of the multifunction display. Information on the message display can be found in the "Restarting the tire pressure loss warning system" section ( $\triangleright$  page 314).

#### Important safety notes

The tire pressure warning system does not warn you of an incorrectly set tire pressure. Observe the notes on the recommended tire pressure ( $\triangleright$  page 310).

The tire pressure loss warning does not replace the need to regularly check the tire pressure. An even loss of pressure on several tires at the same time cannot be detected by the tire pressure loss warning system.

The tire pressure monitor is not able to warn you of a sudden loss of pressure, e.g. if the tire is penetrated by a foreign object. In the event of a sudden loss of pressure, bring the vehicle to a halt by braking carefully. Avoid abrupt steering maneuvers.

The function of the tire pressure loss warning system is limited or delayed if:

- snow chains are mounted on your vehicle's tires.
- road conditions are wintry.
- you are driving on sand or gravel.

- you adopt a very sporty driving style (cornering at high speeds or driving with high rates of acceleration).
- you drive with a heavy load.

# Restarting the tire pressure loss warning system

Restart the tire pressure loss warning system if you have:

- changed the tire pressure
- changed the wheels or tires
- mounted new wheels or tires
- Before restarting, make sure that the tire pressures are set properly on all four tires for the respective operating conditions. The recommended tire pressures can be found on the Tire and Loading Information placard on the B-pillar on the driver's side or the tire pressure table on the fuel filler flap.

The tire pressure loss warning system can only give reliable warnings if you have set the correct tire pressure. If an incorrect tire pressure is set, these incorrect values will be monitored.

- ► Also observe the notes in the section on tire pressures (▷ page 310).
- Make sure that the SmartKey is in position 2 in the ignition lock (▷ page 139).
- Press the or button on the steering wheel to select the Service menu.
- Press the or button to select Tire Pressure.
- Press the OK button.
   The Run Flat Indicator Active Press 'OK' to Restart message appears in the multifunction display.

#### If you wish to confirm the restart:

- Press the OK button. The Tire Pressure Now OK? message appears in the multifunction display.
- ► Press the ▲ or ▼ button to select Yes.
- Press the OK button.
   The Run Flat Indicator Restarted message appears in the multifunction

display. After a teach-in period, the tire pressure loss warning system will monitor the set tire pressures of all four tires.

#### If you wish to cancel the restart:

Press the button.

or

- ► If the Tire Pressure Now OK? message appears, use the ▲ or ▼ button to select Cance1.
- ▶ Press the OK button.
  - The tire pressure values stored at the last restart will continue to be monitored.

#### Tire pressure monitor

#### General notes

If a tire pressure monitor is installed, the vehicle's wheels have sensors that monitor the tire pressures in all four tires. The tire pressure monitor warns you if the pressure drops in one or more of the tires. The tire pressure monitor only functions if the correct sensors are installed on all wheels.

Information on tire pressures is displayed in the multifunction display. After a few minutes of driving, the current tire pressure of each tire is shown in the **Service** menu of the multifunction display.



Example: current tire pressure display

For information on the message display, refer to the "Checking the tire pressure electronically" section ( $\triangleright$  page 316).

#### Important safety notes

# **MARNING** ★

Each tire, including the spare (if provided), should be checked at least once a month when cold and inflated to the pressure recommended by the vehicle manufacturer on the Tire and Loading Information placard on the driver's door B-pillar or the tire pressure label on the inside of the fuel filler flap. If your vehicle has tires of a different size than the size indicated on the Tire and Loading Information placard or the tire pressure label, you should determine the proper tire pressure for those tires.

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale when one or more of your tires are significantly underinflated. Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly underinflated tire causes the tire to overheat and can lead to tire failure. Underinflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability.

Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if underinflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale. Your vehicle has also been equipped with a TPMS malfunction indicator to indicate if the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the warning lamp will flash for approximately a minute and then remain continuously illuminated. This sequence will be repeated every time the vehicle is started as long as the malfunction exists.

When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of incompatible replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly. Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

It is the driver's responsibility to set the tire pressure to that recommended for cold tires which is suitable for the operating situation ( $\triangleright$  page 310). Note that the correct tire pressure for the current operating situation must first be taught-in to the tire pressure monitor. If there is a substantial loss of pressure, the warning threshold for the warning message is aligned to the reference values taught-in. Restart the tire pressure monitor after adjusting the pressure of the cold tires ( $\triangleright$  page 317). The current pressures are saved as new reference values. As a result, a warning message will appear if the tire pressure drops significantly.

The tire pressure monitor does not warn you of an incorrectly set tire pressure. Observe the notes on the recommended tire pressure ( $\triangleright$  page 310).

The tire pressure monitor is not able to warn you of a sudden loss of pressure, e.g. if the tire is penetrated by a foreign object. In the event of a sudden loss of pressure, bring the vehicle to a halt by braking carefully. Avoid abrupt steering maneuvers.

The tire pressure monitor has a yellow warning lamp in the instrument cluster for indicating a pressure loss or malfunction. Whether the warning lamp flashes or lights up indicates whether a tire pressure is too low or the tire pressure monitor is malfunctioning:

- if the warning lamp is lit continuously, the tire pressure on one or more tires is significantly too low. The tire pressure monitor is not malfunctioning.
- if the warning lamp flashes for around a minute and then remains lit constantly, the tire pressure monitor is malfunctioning.
- In addition to the warning lamp, a message appears in the multifunction display.

Further information can be found on  $(\triangleright$  page 233).

If the tire pressure monitor is malfunctioning, it may take more than ten minutes for the tire pressure warning lamp to inform you of the malfunction by flashing for approximately one minute and then remaining lit. When the malfunction has been rectified, the tire pressure warning lamp goes out after a few minutes of driving.

The tire pressure values indicated by the onboard computer may differ from those measured at a gas station with a pressure gauge. The tire pressures shown by the onboard computer refer to those measured at sea level. At high altitudes, the tire pressure values indicated by a pressure gauge are higher than those shown by the on-board computer. In this case, do not reduce the tire pressures.

The operation of the tire pressure monitor can be affected by interference from radio transmitting equipment (e.g. radio headphones, two-way radios) that may be being operated in or near the vehicle.

## Checking the tire pressure electronically

- ► Make sure that the SmartKey is in position 2 in the ignition lock (▷ page 139).
- Press the or button on the steering wheel to select the Service menu.
- Press the or button to select Tire Pressure.
- Press the OK button. The current tire pressure of each tire is shown in the multifunction display.

#### If the vehicle has been parked for over 20 minutes, the Tire pressure will be displayed after driving a few minutes message appears.

After a teach-in process, the tire pressure monitor automatically detects new wheels or new sensors. As long as a clear allocation of the tire pressure value to the individual wheels is not possible, the **Tire Pressure Monitor Active** display message is shown instead of the tire pressure display. The tire pressures are already being monitored.

If an emergency spare wheel is mounted, the system may continue to show the tire pressure of the wheel that has been removed for a few minutes. If this occurs, note that the value displayed for the position where the spare wheel is mounted is not the same as the current tire pressure of the emergency spare wheel.

## Tire pressure monitor warning messages

If the tire pressure monitor detects a pressure loss in one or more tires, a warning message is shown in the multifunction display and the yellow tire pressure monitor warning lamp comes on.

• If the Please Correct Tire Pressure message appears in the multifunction display, the tire pressure in at least one tire is too low and must be corrected at the next opportunity.

- If the Check Tires message appears in the multifunction display, the tire pressure in one or more tires has dropped significantly and the tires must be checked.
- If the Warning Tire Malfunction appears in the multifunction display, the tire pressure in one or more tires has dropped suddenly and the tires must be checked.

Observe the instructions and safety notes in the display messages in the "Tires" section (> page 233).

(1) If the wheel positions on the vehicle are rotated, the tire pressures may be displayed for the wrong positions for a short time. This is rectified after a few minutes of driving, and the tire pressures are displayed for the correct positions.

# Restarting the tire pressure monitor

When you restart the tire pressure monitor, all existing warning messages are deleted and the warning lamps go out. The monitor uses the currently set tire pressures as the reference values for monitoring. In most cases, the tire pressure monitor will automatically detect the new reference values after you have changed the tire pressure. However, you can also define reference values manually as described here. The tire pressure monitor then monitors the new tire pressure values.

Set the tire pressure to the value recommended for the corresponding driving situation on the Tire and Loading Information placard on the driver's side B-pillar (▷ page 310).

Additional tire pressure values for different loads can also be found on the tire pressure table on the inside of the fuel filler flap (> page 310).

Make sure that the tire pressure is correct on all four wheels.

- Make sure that the SmartKey is in position
   2 in the ignition lock.
- Press the or button on the steering wheel to select the Service menu.
- ► Press the ▲ or ▼ button to select Tire Pressure.
- Press the OK button. The multifunction display shows the current tire pressure for the individual tires or the Tire pressure will be displayed after driving a few minutes message.
- Press the vertex button.
   The Use Current Pressures as New Reference Values message appears in the multifunction display.

# If you wish to confirm the restart:

Press the OK button.
 The Tire Pressure Monitor
 Restarted message appears in the multifunction display.

After driving for a few minutes, the system checks whether the current tire pressures are within the specified range. The new tire pressures are then accepted as reference values and monitored.

# If you wish to cancel the restart:

▶ Press the 📩 button.

The tire pressure values stored at the last restart will continue to be monitored.

# Loading the vehicle

# Instruction labels for tires and loads


# MARNING

Overloaded tires can overheat, causing a blowout. Overloaded tires can also impair the steering and driving characteristics and lead to brake failure. There is a risk of accident. Observe the load rating of the tires. The load rating must be at least half of the GAWR of your vehicle. Never overload the tires by exceeding the maximum load.

Two instruction labels on your vehicle show the maximum possible load.


- (1) The Tire and Loading Information placard is on the B-pillar on the driver's side. The Tire and Loading Information placard shows the maximum permissible number of occupants and the maximum permissible vehicle load. It also contains details of the tire sizes and corresponding pressures for tires installed at the factory.
- (2) The vehicle identification plate is on the B-pillar on the driver's side. The vehicle identification plate informs you of the gross vehicle weight rating. It is made up of the vehicle weight, all vehicle occupants, the fuel and the cargo. You can also find information about the maximum gross axle weight rating on the front and rear axle.

The maximum gross axle weight rating is the maximum weight that can be carried by one axle (front or rear axle). Never exceed the maximum load or the maximum gross axle weight rating for the front or rear axle.



B-pillar, driver's side

#### Maximum permissible gross vehicle weight rating



P40.00-2206-31

Specification for maximum gross vehicle weight ① is listed in the Tire and Loading Information placard: "The combined weight of occupants and cargo should never exceed XXX kilograms or XXX lbs."

The gross weight of all vehicle occupants, load and luggage must not exceed the specified value.

1 The specifications shown on the Tire and Loading Information placard in the illustration are examples. The maximum permissible gross vehicle weight rating is vehicle-specific and may differ from that in the illustration. You can find the valid maximum permissible gross vehicle weight rating for your vehicle on the Tire and Loading Information placard.

#### Number of seats

2.6	A DECEMBER OF A DECEMBER OF	the second second second second	ET LE CHARGEMENT
-	WINDRE DE LEMPED-1	3 (194941 3	MIDDLE 3 REAR MILIEU 3 ARRIERE Z
	weight of occupants and e to incounts to do charge		XXX ag ou XXX inc."
TIDE GNRL	siti massiolis	PALENTINE PALENTINE PALENTINA DES. PALENTSA FROID	SEE OWNER'S MANUAL FOR
FILDHO /WMAT	255/46 ZR 10 999 KL	200 KPA, 29 PS1	ADDITIONAL INFORMATION
REAR ARHIERE	205/05 ZR18 (019 XL	200 (BA, 29 FSI	VOIR LE MANUEL DE L'USAGER
SFARE De àecours	175/55-1879534	-120 KWL 50 PSI	POUR PLUS DE RENSIGNEMENTS

Maximum number of seats ① indicates the maximum number of occupants allowed to

travel in the vehicle. This information can be found on the Tire and Loading Information placard.

 The specifications shown on the Tire and Loading Information placard in the illustration are examples. The number of seats is vehicle-specific and can differ from the details shown. The number of seats in your vehicle can be found on the Tire and Loading Information placard.

#### Determining the correct load limit

#### Step-by-step instructions

The following steps have been developed as required of all manufacturers under Title 49, Code of U.S. Federal Regulations, Part 575 pursuant to the "National Traffic and Motor Vehicle Safety Act of 1966".

- Step 1: Locate the statement "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs." on your vehicle's Tire and Loading Information placard.
- Step 2: Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- Step 3: Subtract the combined weight of the driver and passengers from XXX kilograms or XXX lbs.
- Step 4: The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the "XXX" amount equals 1,400 lbs and there will be five 150 lbs passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs (1,400 - 750 (5 x 150) = 650 lbs).
- Step 5: Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in step 4.

#### Example: steps 1 to 3

The following table shows examples on how to calculate total and cargo load capacities with varying seating configurations and number and size of occupants. The following examples use a maximum load of 1,500 lbs (680 kg). **This is for illustration purposes only.** Make sure you are using the actual load limit for your vehicle stated on your vehicle's Tire and Loading Information placard (> page 317).

The higher the weight of all the occupants, the smaller the maximum load for luggage.

#### Step 1

	Example 1	Example 2
Combined maximum weight of occupants and cargo (data from the Tire and Loading Information placard)	1500 lbs (680 kg)	1500 lbs (680 kg)

# Step 2

	Example 1	Example 2
Number of people in the vehicle (driver and occupants)	1	2
Weight of the occupants	Occupant 1: 175 lbs (80 kg)	Occupant 1: 175 lbs (80 kg) Occupant 2: 195 lbs (88 kg)
Gross weight of all occupants	175 lbs (80 kg)	370 lbs (168 kg)

# Wheels and tires

	Example 1	Example 2
Permissible load (maximum gross vehicle weight rating from the Tire and Loading Information placard minus the gross weight of all occupants)	1500 lbs (680 kg) -175 lbs (80 kg) = 1325 lbs (600 kg)	1500 lbs (680 kg) -370 lbs (168 kg) = 1130 lbs (512 kg)

#### Step 3

#### Vehicle identification plate

Even if you have calculated the total load carefully, you should still make sure that the gross vehicle weight rating and the gross axle weight rating are not exceeded. Details can be found on the vehicle identification plate on the B-pillar on the driver's side of the vehicle ( $\triangleright$  page 317).

**Permissible gross vehicle weight:** the gross weight of the vehicle, all passengers and the load must not exceed the permissible gross vehicle weight.


**Gross axle weight rating:** the maximum permissible weight that can be carried by one axle (front or rear axle).

To ensure that your vehicle does not exceed the maximum permissible values (gross vehicle weight and maximum gross axle weight rating), have your loaded vehicle (including driver, occupants and the load) weighed on a suitable vehicle weighbridge.

#### All about wheels and tires

Uniform Tire Quality Grading Standards

Overview of Tire Quality Grading Standards



Uniform Tire Quality Grading Standards are U.S. government specifications. Their purpose is to provide drivers with uniform reliable information on tire performance data. Tire manufacturers have to grade tires using three performance factors: treadwear grade (1), traction grade (2) and temperature grade (3). These regulations do not apply to Canada. Nevertheless, all tires sold in North America are provided with the corresponding quality grading markings on the sidewall of the tire.

Where applicable, the tire grading information can be found on the tire sidewall between the tread shoulder and maximum tire width.

Example:

- Treadwear grade: 200
- Traction grade: AA
- Temperature grade: A

All passenger car tires must conform to the statutory safety requirements in addition to these grades.

• The actual values for tires are vehiclespecific and may deviate from the values in the illustration.

#### Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified U.S. government course. For example, a tire graded 150 would wear one and one-half times as well on the government course as a tire graded 100.

The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm, due to variations in driving habits, service practices and differences in road characteristics and climate conditions.

#### Traction

#### **MARNING ∕**

The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

Avoid wheelspin. This can lead to damage to the drive train.

The traction grades, from highest to lowest, are AA, A, B, and C. Those grades represent the tire's ability to stop on a wet surface as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.

The safe speed on a wet, snow covered or icy road is always lower than on dry road surfaces.

You should pay special attention to road conditions when temperatures are around freezing point.

Mercedes-Benz recommends a minimum tread depth of 1/6 in (4 mm) on all four winter tires. Observe the legally required minimum tire tread depth (> page 307). Winter tires can reduce the braking distance on snow-covered surfaces in comparison with summer tires. The braking distance is still much further than

on surfaces that are not icy or covered with snow. Take appropriate care when driving. Further information on winter tires (M+S tires) (> page 308).

#### Temperature


# MARNING

The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause excessive heat build-up and possible tire failure.

The temperature grades are A (the highest). B, and C. These represent the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

#### **Tire labeling**

#### Overview



- Uniform Tire Quality Grading Standard (▷ page 326)
- ② DOT, Tire Identification Number (▷ page 325)
- ③ Maximum tire load (▷ page 325)
- ④ Maximum tire pressure (▷ page 312)
- ⑤ Manufacturer
- ⑥ Tire material (▷ page 325)
- ⑦ Tire size designation, load-bearing capacity and speed index (▷ page 322)
- ⑧ Load index (▷ page 324)
- ⑦ Tire name


The markings described above are on the tire in addition to the tire name (sales designation) and the manufacturer's name.

 Tire data is vehicle-specific and may deviate from the data in the example.

# Tire size designation, load-bearing capacity and speed rating

## MARNING

Exceeding the stated tire load-bearing capacity and the approved maximum speed could lead to tire damage or the tire bursting. There is a risk of accident. Therefore, only use tire types and sizes approved for your vehicle model. Observe the tire load rating and speed rating required for your vehicle.



- Tire width
- ② Nominal aspect ratio in %
- ③ Tire code
- ④ Rim diameter
- 5 Load bearing index
- 6 Speed rating

**General:** depending on the manufacturer's standards, the size imprinted in the tire wall may not contain any letters or may contain one letter that precedes the size description.

If there is no letter preceding the size description (as shown above): these are passenger vehicle tires according to European manufacturing standards.

If "P" precedes the size description: these are passenger vehicle tires according to U.S. manufacturing standards.

If "LT" precedes the size description: these are light truck tires according to U.S. manufacturing standards.

If "T" precedes the size description: these are compact emergency spare wheels at high tire pressure, to be used only temporarily in an emergency.

**Tire width:** tire width ① shows the nominal tire width in millimeters.

**Height-width ratio:** aspect ratio ② is the size ratio between the tire height and tire width and is shown in percent. The aspect

ratio is calculated by dividing the tire width by the tire height.

**Tire code:** tire code ③ specifies the tire type. "R" represents radial tires; "D" represents diagonal tires; "B" represents diagonal radial tires.

Optionally, tires with a maximum speed of over 149 mph (240 km/h) may have "ZR" in the size description, depending on the manufacturer (e.g. 245/40 ZR 18).

**Rim diameter:** rim diameter ④ is the diameter of the bead seat, not the diameter of the rim flange. The rim diameter is specified in inches (in).

**Load-bearing index:** load-bearing index (5) is a numerical code that specifies the maximum load-bearing capacity of a tire. Do not overload the tires by exceeding the specified load limit. The maximum permissible load can be found on the vehicle's Tire and Loading Information placard on the B-pillar on the driver's side ( $\triangleright$  page 317).

Example:

Load-bearing index 91 indicates a maximum load of 1,356 lb (615 kg) that the tires can bear. For further information on the maximum tire load in kilograms and lbs, see (> page 325).

For further information on the load bearing index, see "Load index" ( $\triangleright$  page 324).

**Speed rating:** speed rating (6) specifies the approved maximum speed of the tire.

**1** Tire data is vehicle-specific and may deviate from the data in the example.

Regardless of the speed rating, always observe the speed limits. Drive carefully and adapt your driving style to the traffic conditions.

Summe r tires	
Index	Speed rating
Q	up to 100 mph (160 km/h)
R	up to 106 mph (170 km/h)
S	up to 112 mph (180 km/h)
Т	up to 118 mph (190 km/h)
Н	up to 130 mph (210 km/h)
V	up to 149 mph (240 km/h)
W	up to 168 mph (270 km/h)
Y	up to 186 mph (300 km/h)
ZRY	up to 186 mph (300 km/h)
ZR(Y)	over 186 mph (300 km/h)
ZR	over 149 mph (240 km/h)

- Optionally, tires with a maximum speed of over 149 mph (240 km/h) may have "ZR" in the size description, depending on the manufacturer (e.g. 245/40 ZR 18). The service specification is made up of load-bearing index (5) and speed rating (6).
- If the size description of your tire includes "ZR" and there are no service specifications, ask the tire manufacturer in order to find out the maximum speed.

If a service specification is available, the maximum speed is limited according to the speed rating in the service specification. Example: 245/40 ZR18 97 Y. In this example, "97 Y" is the service specification. The letter "Y" represents the speed rating. The maximum speed of the tire is limited to 186 mph (300 km/h).

• The size description for all tires with maximum speeds of over 186 mph (300 km/h) must include "ZR", **and** the service specification must be given in parentheses. Example: 275/40 ZR 18 (99 Y). Speed rating "(Y)" indicates that the maximum speed of the tire is over 186 mph (300 km/h). Ask the tire manufacturer about the maximum speed.

All- weather tires and winter tires	
Index	Speed rating
Q M+S <sup>4</sup>	up to 100 mph (160 km/h)
T M+S <sup>4</sup>	up to 118 mph (190 km/h)
H M+S <sup>4</sup>	up to 130 mph (210 km/h)
V M+S <sup>4</sup>	up to 149 mph (240 km/h)

Not all tires with the M+S marking provide the driving characteristics of winter tires. In addition to the M+S marking, winter tires also have the A snowflake symbol on the tire wall. Tires with this marking fulfill the requirements of the Rubber Manufacturers Association (RMA) and the Rubber Association of Canada (RAC) regarding the tire traction on snow. They have been especially developed for driving on snow.

An electronic speed limiter prevents your vehicle from exceeding the following speeds:

- all vehicles (except AMG vehicles): 130 mph (210 km/h)
- AMG vehicles: 155 mph (250 km/h)
- AMG vehicles with Handling Package: 174 mph (280 km/h)

The speed rating of tires mounted at the factory may be higher than the maximum speed that the electronic speed limiter permits.

Make sure that your tires have the required speed rating, e.g. when buying new tires. The

required speed rating for your vehicle can be found in the "tires" section (▷ page 333). Further information about reading tire data can be obtained from any qualified specialist workshop.

### Load index



In addition to the load bearing index, load rating (1) may be imprinted after the letters that identify speed rating on the sidewall of the tire ( $\triangleright$  page 322).

- If no specification is given: no text (as in the example above), represents a standard load (SL) tire
- XL or Extra Load: represents a reinforced tire
- Light Load: represents a light load tire
- C, D, E: represents a load range that depends on the maximum load that the tire can carry at a certain pressure
- Tire data is vehicle-specific and may deviate from the data in the example.

4 Or M+S 🔬 for winter tires.

### Maximum load rating




Maximum load rating ① is the maximum permissible weight for which the tire is approved.

Do not overload the tires by exceeding the specified load limit. The maximum permissible load can be found on the vehicle's Tire and Loading Information placard on the B-pillar on the driver's side ( $\triangleright$  page 317).

The actual values for tires are vehiclespecific and may deviate from the values in the illustration.

### DOT, Tire Identification Number (TIN)

U.S. tire regulations prescribe that every tire manufacturer or retreader must imprint a TIN in or on the sidewall of every tire produced.



The TIN is a unique identification number. The TIN makes it easier for tire manufacturers or retreaders to notify customers of recalls or other safety-related matters. It makes it

possible for the purchaser to easily identify the affected tires.

The TIN consists of the manufacturer identification code ②, tire size ③, tire type code ④ and manufacturing date ⑤.

**DOT (Department of Transportation):** tire symbol ① indicates that the tire complies with the requirements of the U.S. Department of Transportation.

### Manufacturer identification code:

manufacturer identification code (2) provides details on the tire manufacturer. New tires have a code with two symbols. Retreaded tires have a code with four symbols.

For further information about retreaded tires, see ( $\triangleright$  page 306).

Tire size: identifier ③ describes the tire size.

**Tire type code:** tire type code ④ can be used by the manufacturer as a code to describe specific characteristics of the tire.

**Date of manufacture:** date of manufacture (5) provides information about the age of a tire. The first and second positions represent the week of manufacture, starting with "01" for the first calendar week. Positions three and four represent the year of manufacture. For example, a tire that is marked with "3208", was manufactured in week 32 in 2008.

**1** Tire data is vehicle-specific and may deviate from the data in the example.

### Tire characteristics



This information describes the type of tire cord and the number of layers in sidewall (1) and under tire tread (2).

**1** Tire data is vehicle-specific and may deviate from the data in the example.

### Definition of terms for tires and loading

### Tire ply composition and material used

Describes the number of plies or the number of layers of rubber-coated fabric in the tire tread and sidewall. These are made of steel, nylon, polyester and other materials.

### Bar

Metric unit for tire pressure. 14.5038 pounds per square inch (psi) and 100 kilopascals (kPa) are the equivalent of 1 bar.

### **DOT (Department of Transportation)**

DOT marked tires fulfill the requirements of the United States Department of Transportation.

### Normal occupant weight

The number of occupants which the vehicle is designed for, multiplied by 68 kilograms (150 lb).

### Uniform Tire Quality Grading Standards

A uniform standard to grade the quality of tires with regards to tread quality, tire traction and temperature characteristics. Ratings are determined by tire manufacturers using U.S. government testing procedures. The ratings are molded into the sidewall of the tire.

### **Recommended tire pressure**

The recommended tire pressure applies to the tires mounted at the factory.

The Tire and Loading Information placard contains the recommended tire pressures for cold tires on a fully loaded vehicle and for the maximum permissible vehicle speed.

The tire pressure table contains the recommended pressures for cold tires for

various operating conditions, i.e. differing load and speed conditions.

### Increased vehicle weight due to optional equipment

This is the combined weight of all standard and optional equipment available for the vehicle, regardless of whether it is actually installed on the vehicle or not.

### Rim

This is the part of the wheel on which the tire is mounted.

### GAWR (Gross Axle Weight Rating)

The GAWR is the maximum permissible axle weight. The actual load on an axle must never exceed the gross axle weight rating. The gross axle weight rating can be found on the vehicle identification plate on the B-pillar on the driver's side.

### Speed rating

The speed rating is part of the tire identification. It specifies the speed range for which the tire is approved.

### GVW (Gross Vehicle Weight)

The gross vehicle weight includes the weight of the vehicle including fuel, tools, the spare wheel, accessories installed, occupants, luggage and the drawbar noseweight, if applicable. The gross vehicle weight must not exceed the gross vehicle weight rating GVWR as specified on the vehicle identification plate on the B pillar on the driver's side.

### GVWR (Gross Vehicle Weight Rating)

The GVWR is the maximum permissible gross weight of a fully loaded vehicle (the weight of the vehicle including all accessories, occupants, fuel, luggage and the drawbar noseweight, if applicable). The gross vehicle weight rating is specified on the vehicle identification plate on the B-pillar on the driver's side.

### Maximum loaded vehicle weight

The maximum weight is the sum of:

- the curb weight of the vehicle
- the weight of the accessories
- the load limit
- the weight of the factory installed optional equipment

### Kilopascal (kPa)

Metric unit for tire pressure. 6.9 kPa corresponds to 1 psi. Another unit for tire pressure is bar. There are 100 kilopascals (kPa) to 1 bar.

### Load index

In addition to the load-bearing index, the load index may also be imprinted on the sidewall of the tire. This specifies the load-bearing capacity more precisely.

### **Curb weight**

The weight of a vehicle with standard equipment including the maximum capacity of fuel, oil and coolant. It also includes the airconditioning system and optional equipment if these are installed in the vehicle, but does not include passengers or luggage.

### Maximum load rating

The maximum tire load is the maximum permissible weight in kilograms or lbs for which a tire is approved.

### Maximum permissible tire pressure

Maximum permissible tire pressure for one tire.

### Maximum load on one tire

Maximum load on one tire. This is calculated by dividing the maximum axle load of one axle by two.

### PSI (pounds per square inch)

A standard unit of measure for tire pressure.

### Aspect ratio

Relationship between tire height and tire width in percent.

### Tire pressure

This is pressure inside the tire applying an outward force to each square inch of the tire's surface. The tire pressure is specified in pounds per square inch (psi), in kilopascal (kPa) or in bar. The tire pressure should only be corrected when the tires are cold.

### Cold tire pressure

The tires are cold:

- if the vehicle has been parked without direct sunlight on the tires for at least three hours and
- if the vehicle has been driven for less than 1 mile (1.6 km).

### Tread

The part of the tire that comes into contact with the road.

### Bead

The tire bead ensures that the tire sits securely on the wheel. There are several steel wires in the bead to prevent the tire from coming loose from the wheel rim.

### Sidewall

The part of the tire between the tread and the bead.

### Weight of optional extras

The combined weight of those optional extras that weigh more than the replaced standard parts and more than 2.3 kilograms (5 lbs). These optional extras, such as highperformance brakes, level control, a roof rack or a high-performance battery, are not included in the curb weight and the weight of the accessories.

### TIN (Tire Identification Number)

This is a unique identifier which can be used by a tire manufacturer to identify tires, for example for a product recall, and thus identify the purchasers. The TIN is made up of the manufacturer's identity code, tire size, tire type code and the manufacturing date.

### Load bearing index

The load bearing index (also load index) is a code that contains the maximum load bearing capacity of a tire.

### Traction

Traction is the result of friction between the tires and the road surface.

### **Treadwear indicators**

Narrow bars (tread wear bars) that are distributed over the tire tread. If the tire tread is level with the bars, the wear limit of  $\frac{1}{16}$  in (1.6 mm) has been reached.

### **Occupant distribution**

The distribution of occupants in a vehicle at their designated seating positions.

### Total load limit

Rated cargo and luggage load plus 68 kilograms (150 lb) multiplied by the number of seats in the vehicle.

### Changing a wheel

### Flat tire

You can find information on what to do in the event of a flat tire in the "Breakdown assistance" section (▷ page 289). Information on driving with MOExtended tires in the event of a flat tire can be found under "MOExtended tires (tires with run-flat characteristics" (▷ page 290).

The "Breakdown assistance" section (▷ page 289) contains information and notes on how to deal with a flat tire. Information on driving with MOExtended tires in the event of a flat tire can be found under "MOExtended tires (tires with run-flat characteristics" (▷ page 290).

### **Rotating the wheels**

### 

Interchanging the front and rear wheels may severely impair the driving characteristics if the wheels or tires have different dimensions. The wheel brakes or suspension components may also be damaged. There is a risk of accident.

Rotate front and rear wheels only if the wheels and tires are of the same dimensions.

On vehicles equipped with a tire pressure monitor, electronic components are located in the wheel.

Tire-mounting tools should not be used near the valve. This could damage the electronic components.

Only have tires changed at a qualified specialist workshop.

Always pay attention to the instructions and safety notes when changing a wheel (> page 329).

The wear patterns on the front and rear tires differ, depending on the operating conditions. Rotate the wheels before a clear wear pattern has formed on the tires. Front tires typically wear more on the shoulders and the rear tires in the center.

If your vehicle's tire configuration allows, you can rotate the wheels according to the intervals in the tire manufacturer's warranty book in your vehicle documents. If no warranty book is available, the tires should be rotated every 3,000 to 6,000 miles (5,000 to 10,000 km), or earlier if tire wear requires. Do not change the direction of wheel rotation. Clean the contact surfaces of the wheel and the brake disc thoroughly every time a wheel is rotated. Check the tire pressure and, if

necessary, restart the tire pressure loss warning system or the tire pressure monitor.

### **Direction of rotation**

Tires with a specified direction of rotation have additional benefits, e.g. if there is a risk of hydroplaning. You will only gain these benefits if the correct direction of rotation is maintained.

An arrow on the sidewall of the tire indicates its correct direction of rotation.

### **Storing wheels**

Store wheels that are not being used in a cool, dry and preferably dark place. Protect the tires from oil, grease, gasoline and diesel.

### **Cleaning the wheels**

### MARNING

The water jet from a circular jet nozzle (dirt blasters) can cause invisible exterior damage to the tires or chassis components.

Components damaged in this way may fail unexpectedly. There is a risk of an accident.

Do not use power washers with circular jet nozzles to clean the vehicle. Have damaged tires or chassis components replaced immediately.

### Mounting a wheel

### Preparing the vehicle


- Stop the vehicle on solid, non-slippery and level ground.
- ► Apply the electric parking brake manually.
- Bring the front wheels into the straightahead position.
- Vehicles with manual transmission: fully depress the clutch pedal and engage first or reverse gear.
- ► Vehicles with automatic transmission: move the selector lever to P.
- ▶ Switch off the engine.

- Vehicles without KEYLESS-GO: remove the SmartKey from the ignition lock.
- Vehicles with KEYLESS-GO: open the driver's door.
   The on-board electronics now have status
   This is the same as the SmartKey baying

**0**. This is the same as the SmartKey having been removed.

- ► Vehicles with KEYLESS-GO: remove the Start/Stop button from the ignition lock (▷ page 139).
- If included in the vehicle equipment, remove the tire-change tool kit from the vehicle.
- Secure the vehicle to prevent it from rolling away.
- Due to differences in vehicle equipment, not all vehicles are equipped with a tirechange tool kit. For information on which tools are required to perform a wheel change on your vehicle, consult an authorized Mercedes-Benz Center. Necessary wheel-changing tools can include, for example:
  - Jack
  - Wheel chock
  - Lug wrench

# Securing the vehicle to prevent it from rolling away



If your vehicle is equipped with a wheel chock, it can be found in the tire-change tool kit (> page 289).

The folding wheel chock is an additional securing measure to prevent the vehicle from

rolling away, for example when changing a wheel.

- ▶ Fold both plates upwards ①.
- ▶ Fold out lower plate ②.
- Guide the lugs on the lower plate fully into the openings in base plate 3.



Securing the vehicle on level ground

► On level ground: place chocks or other suitable items under the front and rear of the wheel that is diagonally opposite the wheel you wish to change.



Securing the vehicle on slight downhill gradients

On light downhill gradients: place chocks or other suitable items in front of the wheels of the front and rear axle.

### **Raising the vehicle**

### MARNING


If you do not position the jack correctly at the appropriate jacking point of the vehicle, the jack could tip over with the vehicle raised. There is a risk of injury. Only position the jack at the appropriate jacking point of the vehicle. The base of the jack must be positioned vertically, directly under the jacking point of the vehicle.

The jack is designed exclusively for jacking up the vehicle at the jacking points. Otherwise, your vehicle could be damaged.

The following must be observed when raising the vehicle:


- to raise the vehicle, only use the vehiclespecific jack that has been tested and approved by Mercedes-Benz. If used incorrectly, the jack could tip over with the vehicle raised.
- the jack is designed only to raise and hold the vehicle for a short time while a wheel is being changed. It is not suited for performing maintenance work under the vehicle.
- avoid changing the wheel on uphill and downhill slopes.
- before raising the vehicle, secure it from rolling away by applying the parking brake and inserting wheel chocks. Never disengage the parking brake while the vehicle is raised.
- the jack must be placed on a firm, flat and non-slip surface. On a loose surface, a large, load-bearing underlay must be used. On a slippery surface, a non-slip underlay must be used, e.g. rubber mats.
- do not use wooden blocks or similar objects as a jack underlay. Otherwise, the jack will not be able to achieve its loadbearing capacity due to the restricted height.
- make sure that the distance between the underside of the tires and the ground does not exceed 1.2 in (3 cm).
- never place your hands and feet under the raised vehicle.
- never lie under the raised vehicle.
- never start the engine when the vehicle is raised.

- never open or close a door or the trunk lid when the vehicle is raised.
- make sure that no persons are present in the vehicle when the vehicle is raised.




 Using lug wrench ①, loosen the bolts on the wheel you wish to change by about one full turn. Do not unscrew the bolts completely. AMG vehicles and vehicles with AMG equipment: to protect the vehicle body, the vehicle has covers next to the jacking points on the outer sills.


AMG vehicles and vehicles with AMG equipment: fold cover ② upwards.



▶ Position jack ④ at jacking point ③.



The jacking points are located just behind the front wheel housings and just in front of the rear wheel housings (arrows).



Covers, front (example: vehicles with AMG equipment)



P40.10-5216-31

Wheels and tires

Example

- ► Make sure the foot of the jack is directly beneath the jacking point.
- ► Turn crank ⑤ clockwise until jack ④ sits completely on jacking point ③ and the base of the jack lies evenly on the ground.
- ► Turn crank (5) until the tire is raised a maximum of 1.2 in (3 cm) off the ground.

### Removing a wheel

Do not place wheel bolts in sand or on a dirty surface. The bolt and wheel hub threads could otherwise be damaged when you screw them in.



- Unscrew the uppermost wheel bolt completely.
- Screw alignment bolt ① into the thread instead of the wheel bolt.
- ▶ Unscrew the remaining wheel bolts fully.
- ▶ Remove the wheel.

### Mounting a new wheel

### **∧** WARNING

Oiled or greased wheel bolts or damaged wheel bolts/hub threads can cause the wheel bolts to come loose. As a result, you could lose a wheel while driving. There is a risk of accident.

Never oil or grease wheel bolts. In the event of damage to the threads, contact a qualified specialist workshop immediately. Have the damaged wheel bolts or hub threads replaced/renewed. Do not continue driving.

### MARNING

If you tighten the wheel bolts or wheel nuts when the vehicle is raised, the jack could tip over. There is a risk of injury.

Only tighten the wheel bolts or wheel nuts when the vehicle is on the ground.

Always pay attention to the instructions and safety notes in the "Changing a wheel" section (▷ page 328).

Only use wheel bolts that have been designed for the wheel and the vehicle. For safety reasons, Mercedes-Benz recommends that you only use wheel bolts which have been approved for Mercedes-Benz vehicles and the respective wheel.

To prevent damage to the paintwork, hold the wheel securely against the wheel hub while screwing in the first wheel bolt.




- Clean the wheel and wheel hub contact surfaces.
- Slide the wheel to be mounted onto the alignment bolt and push it on.
- Tighten the wheel bolts until they are finger-tight.
- Unscrew the alignment bolt.
- Tighten the last wheel bolt until it is fingertight.
- Vehicles with a collapsible spare wheel: inflate the collapsible spare wheel (> page 338). Only then lower the vehicle.

### Lowering the vehicle

### 

The wheels could work loose if the wheel nuts and bolts are not tightened to the specified tightening torque. There is a risk of accident. Have the tightening torque immediately checked at a qualified specialist workshop

after a wheel is changed.



- Turn the crank of the jack counterclockwise until the vehicle is once again standing firmly on the ground.
- Place the jack to one side.
- Tighten the wheel bolts evenly in a crosswise pattern in the sequence indicated (1 to 5). The specified tightening torque is 96 lb-ft (130 Nm).
- ▶ Turn the jack back to its initial position.
- Stow the jack and the rest of the vehicle tools in the trunk again.
- AMG vehicles and vehicles with AMG equipment: insert the cover into the outer sill.
- Check the tire pressure of the newly installed wheel and adjust it if necessary.
   Observe the recommended tire pressure (> page 310).
- Vehicles with tire pressure loss warning system: as long as you are driving with an emergency spare wheel, the tire pressure loss warning system cannot function reliably. Only restart the tire pressure loss warning system when the defective wheel has been replaced with a new wheel.
- Vehicles with tire pressure monitor: all wheels mounted must be equipped with functioning sensors.

### Wheel and tire combinations

### **General notes**

For safety reasons, Mercedes-Benz recommends that you only use tires and wheels which have been approved by Mercedes-Benz specifically for your vehicle.

These tires have been specially adapted for use with the control systems, such as ABS or ESP<sup>®</sup>, and are marked as follows:

- MO = Mercedes-Benz Original
- MOE = Mercedes-Benz Original Extended (tires featuring run-flat characteristics)
- MO1 = Mercedes-Benz Original (only certain AMG tires)

Mercedes-Benz Original Extended tires may only be used on wheels that have been specifically approved by Mercedes-Benz. Only use tires, wheels or accessories tested and approved by Mercedes-Benz. Certain characteristics, e.g. handling, vehicle noise emissions or fuel consumption, may otherwise be adversely affected. In addition, when driving with a load, tire dimension variations could cause the tires to come into contact with the bodywork and axle components. This could result in damage to the tires or the vehicle.

Mercedes-Benz accepts no liability for damage resulting from the use of tires, wheels or accessories other than those tested and approved.

Information on tires, wheels and approved combinations can be obtained from any qualified specialist workshop.

Retreaded tires are neither tested nor recommended by Mercedes-Benz, since previous damage cannot always be detected on retreaded tires. As a result, Mercedes-Benz cannot guarantee vehicle safety if retreaded tires are mounted. Do not mount used tires if you have no information about their previous usage. Overview of abbreviations used in the following tire tables:

- BA: both axles
- FA: front axle
- RA: rear axle

The recommended pressures for various operating conditions can be found:

- on the Tire and Loading Information placard with the recommended tire pressures on the B-pillar on the driver's side
- in the tire pressure table on the inside of the fuel filler flap

Observe the notes on recommended tire pressures under various operating conditions (> page 310).

Check tire pressures regularly, and only when the tires are cold. Comply with the

maintenance recommendations of the tire manufacturer in the vehicle document wallet.

Notes on the vehicle equipment – always equip the vehicle with:

- tires of the same size on a given axle (left/ right)
- the same type of tires at a given time (summer tires, winter tires, MOExtended tires)

Exception: it is permissible to install a different type or make in the event of a flat tire. Observe the "MOExtended tires (tires with run-flat characteristics" section (> page 290).

Vehicles equipped with MOExtended tires are not equipped with a TIREFIT kit at the factory. It is therefore recommended that you additionally equip your vehicle with a TIREFIT kit if you mount tires that do not feature runflat properties, e.g. winter tires. A TIREFIT kit may be obtained from a qualified specialist workshop.

- Not all wheel and tire combinations are available at the factory for all countries.
- The following pages contain information on approved wheel rims and tire sizes for equipping your vehicle with winter tires.

Winter tires are not available at the factory as standard equipment or optional extras.

If you want to equip your vehicle with approved winter tires, it may be necessary to obtain wheel rims in the corresponding size. The size of the approved winter tires may differ from the standard tires. This is dependent on the model and the equipment installed at the factory.

The tires and wheel rims, as well as further information, can be obtained at a qualified specialist workshop.

### Tires

### **SLK 250**

### Summer tires

### R17

Tires	Alloy wheels
FA: 225/45 R17 91 W <sup>5</sup>	FA: 7.5 J x 17 H2
	Wheel offset: 1.65 in (42 mm)
RA: 245/40 R17 91 W <sup>5, 6</sup>	RA: 8.5 J x 17 H2
	Wheel offset: 1.42 in (36 mm)

### R18

### Tires

FA: 225/40 R18 92 Y XL

RA: 245/35 R18 92 Y XL<sup>6</sup>

### Winter tires

### R17

### Tires

BA: 225/45 R17 91 H M+S 🚕 5

### **SLK 350**

### Summer tires

### R17

### Tires

FA: 225/45 R17 91 W<sup>5</sup>

RA: 245/40 R17 91 W<sup>5, 6</sup>

### Alloy wheels

FA: 7.5 | x 18 H2 Wheel offset: 1.65 in (42 mm) RA: 8.5 J x 18 H2 Wheel offset: 1.42 in (36 mm)

### Alloy wheels

BA: 7.5 J x 17 H2 Wheel offset: 1.65 in (42 mm)

# Alloy wheels FA: 7.5 J x 17 H2

Wheel offset: 1.65 in (42 mm) RA: 8.5 J x 17 H2 Wheel offset: 1.42 in (36 mm)

<sup>5</sup> Also available as MOExtended tires.

<sup>6</sup> Use of snow chains is not permitted. Observe the notes in the "Snow chains" section.

### R18

Tires	Alloy wheels
FA: 225/40 R18 92 Y XL	FA: 7.5 J x 18 H2
RA: 245/35 R18 92 Y XL <sup>6</sup>	Wheel offset: 1.65 in (42 mm) RA: 8.5 J x 18 H2 Wheel offset: 1.42 in (36 mm)
Winter tires R17	
Tires	Alloy wheels
BA: 225/45 R17 91 H M+S 🔏 5	BA: 7.5 J x 17 H2 Wheel offset: 1.65 in (42 mm)
SLK 55 AMG	

### Summer tires R18

Tires	Alloy wheels
FA: 235/40 ZR18 95 Y XL	FA: 8.0 J x 18 H2
	Wheel offset: 1.69 in (43 mm)
RA: 255/35 ZR18 94 Y XL <sup>6</sup>	RA: 9.0 J x 18 H2
	Wheel offset: 1.65 in (42 mm)
Winter tires	

### Winter tires R18

Tires	Alloy wheels
BA: 235/40 R18 95 V XL M+S 🛕	BA: 8.0 J x 18 H2 Wheel offset: 1.69 in (43 mm)
FA: 235/40 R18 95 V XL M+S 🛕	FA: 8.0 J x 18 H2 Wheel offset: 1.69 in (43 mm)
RA: 255/35 R18 94 V XL M+S 🛕 6	RA: 9.0 J x 18 H2 Wheel offset: 1.65 in (42 mm)

<sup>6</sup> Use of snow chains is not permitted. Observe the notes in the "Snow chains" section.

<sup>5</sup> Also available as MOExtended tires.

# Wheels and tires

### **Emergency spare wheel**

### Important safety notes

### MARNING

The wheel or tire size as well as the tire type of the spare wheel or emergency spare wheel and the wheel to be replaced may differ. Mounting an emergency spare wheel may severely impair the driving characteristics. There is a risk of an accident.

To avoid hazardous situations:

- adapt your driving style accordingly and drive carefully.
- never mount more than one spare wheel or emergency spare wheel that differs in size.
- only use a spare wheel or emergency spare wheel of a different size briefly.
- do not switch ESP<sup>®</sup> off.
- have a spare wheel or emergency spare wheel of a different size replaced at the nearest qualified specialist workshop.
   Observe that the wheel and tire dimensions as well as the tire type must be correct.

When using an emergency spare wheel or spare wheel of a different size, you must not exceed the maximum speed of 50 mph (80 km/h).

Snow chains must not be mounted on emergency spare wheels.

### **General notes**


You should regularly check the pressure of the emergency spare wheel, particularly prior to long trips, and correct the pressure as necessary ( $\triangleright$  page 310). The applicable value is found on the wheel or under "Technical data" ( $\triangleright$  page 340).

An emergency spare wheel may also be mounted against the direction of rotation. Observe the time restriction on use as well as the speed limitation specified on the emergency spare wheel. Replace the tires after six years at the latest, regardless of wear. This also applies to the emergency spare wheel.

• When you are driving with the collapsible spare wheel mounted, the tire pressure loss warning system or the tire pressure monitor cannot function reliably. Only restart the tire pressure loss warning system/the tire pressure monitor when the damaged wheel has been replaced with a new wheel.

Vehicles with tire pressure monitor: after mounting an emergency spare wheel, the system may still display the tire pressure of the removed wheel for a few minutes. The value displayed for the mounted emergency spare wheel is not the same as the current tire pressure of the emergency spare wheel.


### Removing the emergency spare wheel



### (Example)

The collapsible spare wheel can be found in the stowage well under the trunk floor.

- ► Lift and remove the reversible floor panel in the trunk (▷ page 256).
- Turn retaining screw (2) counter-clockwise and remove it.
- ▶ Remove collapsible spare wheel ①.



### AMG vehicles

**AMG vehicles:** the collapsible spare wheel is packed in a bag and attached to a bracket in the trunk.

- ► Loosen tensioning straps ① on both sides.
- Unhook spring hooks (2) and (3) tensioning strap (1) from the bracket.
- Remove the emergency spare wheel bag with the emergency collapsible spare wheel.
- Open the bag and remove the emergency collapsible spare wheel.

Always observe the instructions and safety notes in the "Mounting a wheel" section (> page 329).

### Stowing the emergency spare wheel

• Only place the collapsible spare wheel in the vehicle when it is dry. Otherwise, moisture may get into the vehicle.

Take the following steps to stow a used collapsible spare wheel. Otherwise, the collapsible spare wheel will not install in the trunk in the intended manner. Mercedes-Benz recommends that you have this work carried out at a qualified specialist workshop.


- ► Unscrew the valve cap from the valve.
- ► If possible, unscrew the valve insert from the valve and release the air.
- Fully deflating the tires can take a few minutes.
- Screw the valve insert back into the valve.

- Screw the valve cap back on.
- Pull the protective sheet provided with the spare wheel over the collapsible spare wheel.
- Stow the collapsible spare wheel in the emergency spare wheel well under the trunk.
- Use the retaining screw to pierce the protective sheet and fasten the collapsible spare wheel in place.
- ► AMG vehicles: pull the bag over the collapsible spare wheel and close it.
- Place the bag with the collapsible spare wheel in the trunk.
- Hook in the retaining strap carabiners and lash the collapsible spare wheel to the bracket.

### Inflating the collapsible spare wheel

- Inflate the collapsible spare wheel using the tire inflation compressor before lowering the vehicle. The wheel rim could otherwise be damaged.
- Do not operate the tire inflation compressor for longer than ten minutes at a time without a break. It may otherwise overheat.

The tire inflation compressor can be operated again once it has cooled down.



Mount the collapsible spare wheel as described (▷ page 329).

The collapsible spare wheel must be mounted before it is inflated.

- ▶ Pull plug ④ out of the housing.
- ► Take the air hose out of the housing.
- Insert the yellow hose connector of the air hose into the guide in the housing and push it into the fixture until the hose connector engages.
- Remove the cap from the valve on the collapsible spare wheel.
- Screw union nut ① on the air hose onto the valve.
- ► Make sure the tire inflation compressor's on/off switch (5) is set to OFF.
- Insert plug ④ into the socket of the cigarette lighter or into a 12 V power socket in your vehicle.

Observe the notes on the cigarette lighter (▷ page 258). Observe the notes on sockets (▷ page 258).

- ► Turn the SmartKey to position **1** in the ignition lock (▷ page 139).
- ▶ Press on/off switch ⑤ on the tire inflation compressor to **ON**.

The tire inflation compressor is switched on. The tire is inflated. The tire pressure is shown on pressure gauge ③.

Inflate the tire to the specified tire pressure.

The specified tire pressure is printed on the yellow label of the emergency spare wheel.

- When the specified tire pressure has been reached, press on/off switch (5) to OFF, on the tire inflation compressor. The tire inflation compressor is switched off.
- ► Turn the SmartKey to position **0** in the ignition lock.
- If the tire pressure is higher than the specified pressure, press pressure release button (2) until the correct tire pressure has been reached.

- ► Unscrew union nut ① on the air hose from the valve.
- Screw the cap onto the valve of the collapsible spare wheel again.



Removing an air hose

- To remove the hose from the tire inflation compressor, push down the rocker switch on the hose connector and pull out the hose.
- Stow plug ④ and the air hose in the lower section of the blower housing.
- Stow the tire inflation compressor in the vehicle.

### Technical data

### All models (except for AMG vehicles)

### Collapsible emergency spare wheel<sup>7</sup>

**Tires** 145/70-17 92 P Tire pressure: 350 kPa (3.5 bar/51 psi)

### AMG vehicles

### Collapsible spare wheel

Tires	Alloy wheels
175/55 - 18 95P	6.0 B x 18 H2
Tire pressure: 350 kPa (3.5 bar/51 psi)	Wheel offset: 0.98 in (25 mm)

Alloy wheels

4.5 B x 17 H2

Wheel offset: 0.47 in (12 mm)

Depending on the country, the engine and the wheels mounted, your vehicle may be equipped with TIREFIT or a collapsible spare wheel.

1 The specified tire pressure is printed in yellow on the emergency spare wheel.

<sup>7</sup> Use of snow chains is not permitted. Observe the notes in the section on snow chains.

Useful information	342
Information regarding technical	
data	342
Warranty	342
Identification plates	342
Service products and filling capaci-	
ties	344
Vehicle data	350

### **Useful information**

- This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- Read the information on qualified specialist workshops: (▷ page 24).

### Information regarding technical data

### **General information**

The data stated here specifically refers to a vehicle with standard equipment. Consult an authorized Mercedes-Benz Center for the data for all vehicle variants and trim levels.

## Information in the printed Operator's Manual

In the printed Operator's Manual you can find information about:

- Vehicle data
- · Opening dimensions of the trunk lid
- · Tank capacity
- Coolant (engine)
- · Engine oil approval and capacity
- Refrigerant filling capacity and PAG oil

### Warranty

Your vehicle is covered under the terms of the warranties printed in the Service and Warranty Information booklet.

Your authorized Mercedes-Benz Center replaces and repairs all factory-fitted parts in accordance with the following warranty terms and conditions:


- New Vehicle Limited Warranty
- Emission Systems Warranty
- Emission Performance Warranty
- California, Connecticut, Maine, Massachusetts, New York, Pennsylvania, Rhode Island and Vermont Emission Control System Warranty
- State warranty enforcement laws (Lemon Laws)

Replacement parts and accessories are covered by the Mercedes-Benz Parts and Accessories warranties. These are available at any authorized Mercedes-Benz Center.

If you lose the Service and Warranty Information booklet, contact an authorized Mercedes-Benz Center to arrange a replacement. The new Service and Warranty Information booklet will be mailed to you.

### Identification plates

Vehicle identification plate with vehicle identification number (VIN)



Open the driver's door.
 You will see vehicle identification plate 1.



Example: vehicle identification plate (USA only)
(2) VIN

③ Paint code



Example: vehicle identification plate (Canada only)
(2) VIN

- ③ Paint code
- The data shown on the vehicle identification plate is used only as an example. This data is different for every vehicle and can deviate from the data shown here. You can find the data applicable to your vehicle on the vehicle identification plate.

VIN




- Slide the front-passenger seat to its frontmost position.
- Fold trim 1 upwards.
   VIN 2 can be seen.

The VIN can also be found in the following locations:

- on the vehicle identification plate (▷ page 342)
- on the lower edge of the windshield (▷ page 343)

### Engine number



- Emission control information plate, including the certification of both federal and Californian emissions standards
- Engine number (stamped into the crankcase)
- ③ VIN (on the lower edge of the windshield)

### Service products and filling capacities

### Important safety notes

### MARNING

Service products may be poisonous and hazardous to health. There is a risk of injury.

Comply with instructions on the use, storage and disposal of service products on the labels of the respective original containers. Always store service products sealed in their original containers. Always keep service products out of the reach of children.

### Environmental note

Dispose of service products in an environmentally responsible manner.

Service products include the following:

- Fuels
- Lubricants (e.g. engine oil, transmission oil)
- Coolant
- Brake fluid
- Windshield washer fluid
- · Climate control system refrigerant

Comply with all valid regulations with respect to handling, storing, and disposing of service fluids.

Components and service products must be matched. You should therefore only use products that have been tested and approved by Mercedes-Benz.

Information about tested and approved products can be obtained from an authorized Mercedes-Benz Center or on the Internet at http://bevo.mercedes-benz.com.

You can recognize service products approved by Mercedes-Benz by the following inscription on the containers:

- MB-Freigabe (e.g. MB-Freigabe 229.51)
- MB Approval (e.g. MB Approval 229.51)

Other designations or recommendations indicate a level of quality or a specification in accordance with an MB Sheet number (e.g. MB 229.5). They have not necessarily been approved by Mercedes-Benz.

### Fuel

### Important safety notes

### 

Fuel is highly flammable. If you handle fuel incorrectly, there is a risk of fire and explosion.

You must avoid fire, open flames, creating sparks and smoking. Switch off the engine and, if applicable, the auxiliary heating before refueling.

### 

Fuel is poisonous and hazardous to health. There is a risk of injury.

You must make sure that fuel does not come into contact with your skin, eyes or clothing and that it is not swallowed. Do not inhale fuel vapors. Keep fuel away from children.

If you or others come into contact with fuel, observe the following:

- Wash away fuel from skin immediately using soap and water.
- If fuel comes into contact with your eyes, immediately rinse them thoroughly with clean water. Seek medical assistance without delay.
- If fuel is swallowed, seek medical assistance without delay. Do not induce vomiting.
- Immediately change out of clothing which has come into contact with fuel.

### Tank capacity

Model	Total capacity
All models	18.5 US gal (70.0 l)

Model	Of which reserve
All models	Approx. 2.4 US gal (9.0 l)

### Gasoline

### Fuel grade

Do not use diesel to refuel vehicles with a gasoline engine. Do not switch on the ignition if you accidentally refuel with the wrong fuel. Otherwise, the fuel will enter the fuel system. Even small amounts of the wrong fuel could result in damage to the fuel system and the engine. Notify a qualified specialist workshop and have the fuel tank and fuel lines drained completely.

Only refuel using unleaded gasoline with a minimum octane rating of 91.

Only use the fuel recommended. Operating the vehicle with other fuels can lead to engine failure.

Do not use the following:

- E85 (gasoline with 85% ethanol)
- E100 (100% ethanol)
- M15 (gasoline with 15% methanol)
- M30 (gasoline with 30% methanol)
- M85 (gasoline with 85% methanol)
- M100 (100% methanol)
- Gasoline with metalliferous additives
- Diesel

Do not mix such fuels with the fuel recommended for your vehicle. Do not use additives. This can otherwise lead to engine damage. This does not include cleaning additives for the removal and prevention of residue build-up. gasoline may only be mixed with cleaning additives recommended by Mercedes-Benz; see "Additives". You can obtain further information from any authorized Mercedes-Benz Center. To ensure the longevity and full performance of the engine, only premiumgrade unleaded gasoline must be used.

If standard premium-grade unleaded gasoline is unavailable and unleaded gasoline of a lower grade is used for refueling, observe the following precautions:

- only fill the fuel tank to half full with regular unleaded gasoline and fill the rest with premium-grade unleaded gasoline as soon as possible.
- do not drive at the maximum speed.
- avoid sudden acceleration and engine speeds above 3000 rpm.
- never refuel using fuel with an octane number lower than 87. Otherwise, engine failure could occur.

Using mixtures of methanol and ethanol is not permitted. E10 fuel or E15 fuel (unleaded gasoline with 10% or 15% ethanol) can be used.

You will usually find information about the fuel grade on the pump. If you cannot find the label on the pump, ask the staff for assistance.

### For further information, consult a qualified specialist workshop or on the Internet at http://www.mbusa.com (USA only).

Information on refueling ( $\triangleright$  page 156).

### Additives in gasoline

• Operating the engine with fuel additives added later can lead to engine failure. Do not mix fuel additives with fuel. This does not include additives for the removal and prevention of residue buildup. gasoline must only be mixed with additives recommended by Mercedes-Benz. Comply with the instructions for use on the product label. More information about recommended additives can be obtained from any authorized Mercedes-Benz Center. Mercedes-Benz recommends that you use fuel brands that have the additives.

The quality of the fuel available in some countries may not be sufficient. Residue could build up as a result. In such cases, and in consultation with an authorized Mercedes-Benz Center, the gasoline may be mixed with the cleaning additive recommended by Mercedes-Benz (part no. A000989254512). You must observe the notes and mixing ratios specified on the container.

### **Engine oil**

### **General notes**

• Never use engine oil or an oil filter of a specification other than is necessary to fulfill the prescribed service intervals. Do not change the engine oil or oil filter in order to achieve longer replacement intervals than those prescribed. You could otherwise cause engine damage or damage to the exhaust gas aftertreatment.

Follow the instructions in the service interval display regarding the oil change. Otherwise, you may damage the engine and the exhaust gas aftertreatment.

Comply with the important safety notes for service products when handling engine oil (> page 344).

The engine oils are matched to the performance of Mercedes-Benz engines and service intervals. You should therefore only use engine oils and oil filters that are approved for vehicles with maintenance systems.

For a list of approved engine oils and oil filters, consult an authorized Mercedes-Benz Center. Or visit the website

http://bevo.mercedes-benz.com.

The table shows which engine oils have been approved for your vehicle.

Model	Engine model	MB Approval
SLK 250	271	229.5
SLK 350	276	229.5
SLK 55 AMG	152	229.5

Use only SAE 0W-40 or SAE 5W-40 engine oils for AMG vehicles.

MB approval is indicated on the oil containers.

### **Filling capacities**


The following values refer to an oil change including the oil filter.

Model	Capacity
SLK 250	5.8 US qt (5.5 l)
SLK 350	6.9 US qt (6.5 l)
SLK 55 AMG	With external oil cooler: 10.0 US qt (9.5 l)

### Additives

Do not use any additives in the engine oil. This could damage the engine.

### **Engine oil viscosity**



Viscosity describes the flow characteristics of a fluid. If an engine oil has a high viscosity,

this means that it is thick; a low viscosity means that it is thin.

Select an engine oil with an SAE classification (viscosity) suitable for the prevailing outside temperatures. The table shows you which SAE classifications are to be used. The lowtemperature characteristics of engine oils can deteriorate significantly, e.g. as a result of aging, soot and fuel deposits. It is therefore strongly recommended that you carry out regular oil changes using an approved engine oil with the appropriate SAE classification.

### **Brake fluid**

### 

The brake fluid constantly absorbs moisture from the air. This lowers the boiling point of the brake fluid. If the boiling point of the brake fluid is too low, vapor pockets may form in the brake system when the brakes are applied hard. This would impair braking efficiency. There is a risk of an accident.

You should have the brake fluid renewed at the specified intervals.

When handling brake fluid, observe the important safety notes on service products (> page 344).

The brake fluid change intervals can be found in the Maintenance Booklet.

Only use brake fluid approved by Mercedes-Benz according to MB Approval 331.0.

Information about approved brake fluid can be obtained at any qualified specialist workshop or on the Internet at http://bevo.mercedes-benz.com.

**1** Have the brake fluid regularly replaced at a qualified specialist workshop and the replacement confirmed in the Maintenance Booklet.

### Coolant

### Important safety notes

### MARNING

If antifreeze comes into contact with hot components in the engine compartment, it may ignite. There is a risk of fire and injury. Let the engine cool down before you add antifreeze. Make sure that antifreeze is not spilled next to the filler neck. Thoroughly

clean the antifreeze from components before starting the engine.

• Only add coolant that has been premixed with the desired antifreeze protection. You could otherwise damage the engine.

Further information on coolants can be found in the Mercedes-Benz Specifications for Service Products, MB Specifications for Service Products 310.1, e.g. on the Internet at

http://bevo.mercedes-benz.com. Or contact a qualified specialist workshop.

Always use a suitable coolant mixture, even in countries where high temperatures prevail.

Otherwise, the engine cooling system is not sufficiently protected from corrosion and overheating.

• Have the coolant regularly replaced at a qualified specialist workshop and the replacement confirmed in the Maintenance Booklet.

Comply with the important safety precautions for service products when handling coolant (> page 344).

The coolant is a mixture of water and antifreeze/corrosion inhibitor. It performs the following tasks:

- corrosion protection
- antifreeze protection
- raising the boiling point

If the coolant has antifreeze protection down to -35  $^{\circ}$ F (-37  $^{\circ}$ C), the boiling point of the

coolant during operation is approximately 266 °F (130 °C).

The antifreeze/corrosion inhibitor concentration in the engine cooling system should:

- be at least 50%. This will protect the engine cooling system against freezing down to approximately -35 °F (-37 °C).
- not exceed 55% (antifreeze protection down to -49 °F [-45 °C]). Otherwise, heat will not be dissipated as effectively.

If the vehicle has lost coolant, add equal amounts of water and antifreeze/corrosion inhibitor.

Mercedes-Benz recommends an antifreeze/ corrosion inhibitor concentrate in accordance with MB Specifications for Service Products 310.1.

- When the vehicle is first delivered, it is filled with a coolant mixture that ensures adequate antifreeze and corrosion protection.
- The coolant is checked with every maintenance interval at a qualified specialist workshop.

### **Filling capacities**

Missing values were not available at time of going to print.

Model	Capacity
SLK 250	Approx. 10.1 US qt (9.6 l)
SLK 350	Approx. 11.0 US qt (10.4 l)
SLK 55 AMG	

Use antifreeze/corrosion inhibitor according to MB approval 325.0 or 326.0.

### Windshield washer system

### Important safety notes

### 

Windshield washer concentrate is highly flammable. If it comes into contact with hot engine components or the exhaust system it could ignite. There is a risk of fire and injury.

Make sure that no windshield washer concentrate is spilled next to the filler neck.

- Only use washer fluid that is suitable for plastic lamp lenses, e.g. MB SummerFit or MB WinterFit. Unsuitable washer fluid could damage the plastic lenses of the headlamps.
- Do not add distilled or de-ionized water to the washer fluid container. Otherwise, the level sensor may be damaged.
- Only MB SummerFit and MB WinterFit washer fluid should be mixed together. The spray nozzles may otherwise become blocked.

When handling washer fluid, observe the important safety notes on service products (> page 344).

At temperatures above freezing:

- Fill the washer fluid reservoir with a mixture of water and windshield washer fluid, e.g. MB SummerFit.
- Add 1 part MB SummerFit to 100 parts water.

At temperatures below freezing:

 Fill the washer fluid reservoir with a mixture of water and washer fluid, e.g. MB WinterFit. Adapt the mixing ratio to the outside temperature.

- Down to 14 °F (-10 °C): mix 1 part MB WinterFit to 2 parts water.
- Down to -4 °F (-20 °C): mix 1 part MB WinterFit to 1 part water.
- Down to -20.2 °F (-29 °C): mix 2 parts MB WinterFit to 1 part water.
- Add windshield washer fluid, e.g. MB SummerFit or MB WinterFit, to the washer fluid all year round.

### **Climate control system refrigerant**

### Important safety notes

The climate control system of your vehicle is filled with refrigerant R-134a.

The instruction label regarding the refrigerant type used can be found on the radiator cross member.

Only the refrigerant R-134a and the PAG oil approved by Mercedes-Benz may be used. The approved PAG oil may not be mixed with any other PAG oil that is not approved for R-134a refrigerant. Otherwise, the climate control system may be damaged.

Service work, such as topping-up refrigerant or replacing components, may only be carried out by a qualified specialist workshop. All applicable regulations must be adhered to, SAE standard J639 included.

Always have work on the climate control system carried out at a qualified specialist workshop.

### Refrigerant instruction label



Example: refrigerant instruction label

- ① Warning symbol
- Refrigerant filling capacity
- ③ Applicable SAE standards
- ④ PAG oil part number
- 5 Type of refrigerant

Warning symbols (1) indicate:

- possible dangers
- having service work carried out at a qualified specialist workshop

### Filling capacities

Missing values were not available at time of going to print.

All models	Capacity
Refrigerant	550 ± 10 g (19.4 ± 0.4 oz)
PAG oil	

### Vehicle data

### **General notes**

Please note that for the specified vehicle data:

- the heights specified may vary as a result of:
  - tires
  - load
  - condition of the suspension
  - optional equipment

**Dimensions and weights** 

• optional equipment reduces the maximum payload.

Turning radius	34.5 ft (10.52 m)	
Maximum trunk load	220 lb (100 kg)	
SLK 55 AMG		
Vehicle length	163.2 in (4146 mm)	
Vehicle width including exterior mirrors	79.0 in (2006 mm)	
Vehicle height	51.2 in (1301 mm)	
Wheelbase	95.7 in (2430 mm)	

All models (except for AMG vehicles)

Wheelbase	95.7 in (2430 mm)
Turning radius	34.6 ft (10.55 m)
Maximum trunk load	220 lb (100 kg)

Model	①Opening height
All models	(70.7 in)
	(1796 mm)

All models (except for AMG vehicles)	
Vehicle length	162.8 in (4134 mm)
Vehicle width including exterior mirrors	79.0 in (2006 mm)
Vehicle height	51.3 in (1303 mm)
Wheelbase	95.7 in (2430 mm)