

Owner's Manual
for Vehicle



The Ultimate
Driving Machine



Z4 sDrive30i
Z4 sDrive35i

Owner's Manual for Vehicle

Congratulations, and thank you for choosing a BMW.

Thorough familiarity with your vehicle will provide you with enhanced control and security when you drive it. We therefore have this request:

Please take the time to read this Owner's Manual and familiarize yourself with the information that we have compiled for you before starting off in your new vehicle. It contains important data and instructions intended to assist you in gaining maximum use and satisfaction from your BMW's unique range of technical features. The manual also contains information on maintenance designed to enhance operating safety and contribute to maintaining the value of your BMW throughout an extended service life.

This manual is supplemented by a Service and Warranty Information Booklet for US models or a Warranty and Service Guide Booklet for Canadian models.

We wish you an enjoyable driving experience.

BMW AG

© 2009 Bayerische Motoren Werke
Aktiengesellschaft
Munich, Germany
Reprinting, including excerpts, only with the
written consent of BMW AG, Munich.
US English VIII/09, 09 09 500
Printed on environmentally friendly paper,
bleached without chlorine, suitable for recycling.

Contents

The fastest way to find information on a particular topic or item is by using the index, refer to page 236.

Using this Owner's Manual

- 4 Notes
- 6 Reporting safety defects

At a glance

- 10 Cockpit
- 16 iDrive
- 22 Letters and numbers
- 23 Voice activation system

Controls

- 28 Opening and closing
- 41 Adjustments
- 48 Transporting children safely
- 50 Driving
- 64 Controls overview
- 77 Technology for driving comfort and safety
- 88 Lamps
- 93 Climate
- 100 Practical interior accessories

Driving tips

- 112 Things to remember when driving

Navigation

- 120 Navigation system
- 121 Destination entry
- 130 Destination guidance
- 137 What to do if...

Entertainment

- 140 On/off and tone
- 143 Radio
- 146 Satellite radio
- 151 CD/DVD player and CD/DVD changer
- 158 Music collection
- 163 External devices

Communications

- 170 Telephone
- 182 Contacts
- 184 BMW Assist

Mobility

- 192 Refueling
- 194 Wheels and tires
- 201 Under the hood
- 206 Maintenance
- 208 Care
- 212 Replacing components
- 218 Giving and receiving assistance

Reference

- 226 Technical data
- 229 Short commands for the voice activation system
- 236 Everything from A to Z

Notes

Using this Owner's Manual

We have tried to make all the information in this Owner's Manual easy to find. The fastest way to find specific topics is to refer to the detailed index at the back of the manual. If you wish to gain an initial overview of your vehicle, you will find this in the first chapter.

Should you sell your BMW some day, please remember to hand over the Owner's Manual as well; it is an important component of your vehicle.

Additional sources of information

Should you have any other questions, your BMW center will be glad to advise you at any time.

Information on BMW, e.g., on technical aspects, can also be found on the Internet at www.bmwusa.com.

Symbols used



Indicates precautions that must be followed precisely in order to avoid the possibility of personal injury and serious damage to the vehicle. ◀



Indicates information that will assist you in gaining the optimum benefit from your vehicle and enable you to care more effectively for your vehicle. ◀



Refers to measures that can be taken to help protect the environment. ◀

◀ Marks the end of a specific item of information.

* Indicates special equipment, country-specific equipment and optional accessories, as well as equipment and functions not yet available at the time of printing.

"..." Identifies Control Display texts used to select individual functions.

›...‹ Verbal instructions to use with the voice activation system.

››...‹‹ Identifies the answers generated by the voice activation system.

Symbols on vehicle components



Indicates that you should consult the relevant section of this Owner's Manual for information on a particular part or assembly.

The individual vehicle

When you ordered your BMW, you chose various items of equipment. This Owner's Manual describes the entire array of options and equipment available with a specific BMW model.

Please bear in mind that the manual may contain information on accessories and equipment that you have not specified for your own vehicle. Sections describing options and special equipment are marked by asterisks * to assist you in identifying possible differences between the descriptions in this manual and your own vehicle's equipment.

If equipment in your BMW is not described in this Owner's Manual, please refer to the accompanying Supplementary Owner's Manuals.

Editorial notice

BMW pursues a policy of continuous, ongoing development that is conceived to ensure that our vehicles continue to embody the highest quality and safety standards combined with advanced, state-of-the-art technology. For this reason, it is possible in exceptional cases that features described in this Owner's Manual could differ from those on your vehicle.

For your own safety

Maintenance and repair



Advanced technology, e.g., the use of modern materials and powerful electronics, requires specially adapted maintenance and repair methods. You should therefore have the corresponding work on your vehicle performed only by your BMW center or at a workshop that works according to BMW repair procedures with correspondingly trained personnel. If this work is not carried out properly, there is a danger of subsequent damage and related safety hazards. ◀

Parts and accessories



For your own safety, use genuine parts and accessories approved by BMW.

When you purchase accessories tested and approved by BMW and Original BMW Parts, you simultaneously acquire the assurance that they have been thoroughly tested by BMW to ensure optimum performance when installed on your vehicle.


BMW warrants these parts to be free from defects in material and workmanship.

BMW will not accept any liability for damage resulting from installation of parts and accessories not approved by BMW.

BMW cannot test every product made by other manufacturers to verify if it can be used on a BMW safely and without risk to either the vehicle, its operation, or its occupants.


Original BMW Parts, BMW Accessories and other products approved by BMW, together with professional advice on using these items, are available from all BMW centers.

Installation and operation of accessories not approved by BMW, such as alarms, radios, amplifiers, radar detectors, wheels, suspension components, brake dust shields, telephones, including operation of any mobile phone from within the vehicle without using an externally mounted antenna, or transceiver equipment, for instance, CBs, walkie-talkies, ham radio or similar accessories, may cause extensive damage to the vehicle, compromise its safety, interfere with the vehicle's electrical system or affect the validity of the BMW Limited Warranty. See your BMW center for additional information. ◀

 Maintenance, replacement, or repair of the emission control devices and systems may be performed by any automotive repair establishment or individual using any certified automotive part. ◀

California Proposition 65 warning

California law requires us to issue the following warning:

 Engine exhaust and a wide variety of automobile components and parts, including components found in the interior furnishings in a vehicle, contain or emit chemicals known to the State of California to cause cancer and birth defects and reproductive harm. In addition, certain fluids contained in vehicles and certain products of component wear contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

Battery posts, terminals and related accessories contain lead and lead compounds. Wash your hands after handling.

Used engine oil contains chemicals that have caused cancer in laboratory animals. Always protect your skin by washing thoroughly with soap and water. ◀

Service and warranty

We recommend that you read this publication thoroughly.

Your BMW is covered by the following warranties:

- ▷ New Vehicle Limited Warranty
- ▷ Rust Perforation Limited Warranty
- ▷ Federal Emissions System Defect Warranty
- ▷ Federal Emissions Performance Warranty
- ▷ California Emission Control System Limited Warranty

Detailed information about these warranties is listed in the Service and Warranty Information Booklet for US models or in the Warranty and Service Guide Booklet for Canadian models.

Your vehicle has been specifically adapted and designed to meet the particular operating conditions and homologation requirements in your country and continental region in order to deliver the full BMW driving pleasure while the vehicle is operated under those conditions. If you wish to operate your vehicle in another country or region, you may be required to adapt your vehicle to meet different prevailing operating conditions and homologation requirements. You should also be aware of any applicable warranty limitations or exclusions for such country or region. In such case, please contact Customer Relations for further information.

Reporting safety defects

For US customers

The following only applies to vehicles owned and operated in the US.

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration, NHTSA, in addition to notifying BMW of North America, LLC, P.O. Box 1227, Westwood, New Jersey 07675-1227, Telephone 1-800-831-1117.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your center, or BMW of North America, LLC.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to <http://www.safercar.gov>; or write to: Administrator, NHTSA, 400 Seventh Street, SW., Washington, DC 20590. You can also obtain other information about motor vehicle safety from <http://www.safercar.gov>

For Canadian customers

Canadian customers who wish to report a safety-related defect to Transport Canada, Defect Investigations and Recalls, may call 1-800-333-0510 toll-free from anywhere in Canada or 1-613-993-9851 from the Ottawa region and from other countries, or contact Transport Canada by mail at: Transport Canada, ASFAD, Place de Ville, Tower C, 330 Sparks Street, Ottawa, ON, K1A 0N5.

You can also obtain other information about motor vehicle safety from <http://www.tc.gc.ca>














At a glance

















This overview of buttons, switches and displays is intended to familiarize you with your vehicle's operating environment. The section will also assist you in becoming acquainted with the control concepts and options available for operating the various systems.

Cockpit

Around the steering wheel: controls and displays



- | | |
|---|--|
| <p>1  Opening and closing windows jointly 37</p> <p>2  Opening and closing rear windows 37</p> <p>3  Opening and closing front windows 37</p> <p>4  Folding exterior mirrors in and out* 45</p> <p>5  Adjusting exterior mirrors, automatic curb monitor* 45</p> | <p>6  Parking lamps 88</p> <p> Low beams 88</p> <p> Automatic headlamp control* 88</p> <p> Adaptive light control* 89</p> <p> High-beam assistant* 90</p> |
|---|--|

- 7  Turn signals [59](#)
-  High beams, headlamp flasher [90](#)
-  High-Beam Assistant* [90](#)
-  Roadside parking lamps* [90](#)
-  Computer [65](#)
-  Settings and information about the vehicle [68](#)
- 8 Instrument cluster [12](#)
- 9 Buttons* on the steering wheel
-  Changing radio station
 -  Selecting music track
 -  Scrolling through phone book and lists with stored phone numbers
 -  Next entertainment source
 -  Recirculated-air mode [98](#)
- 10  Windshield wipers [60](#)
-  Rain sensor* [60](#)
- 11  Switching the ignition on/off and starting/stopping the engine [50](#)
- 12 Ignition lock [50](#)
- 13  Steering wheel heating* [47](#)
- 14 Horn, the entire surface
- 15 Adjusting the steering wheel [46](#)
- 16  Cruise control* [61](#)

17 Buttons* on the steering wheel



Telephone*:

- ▷ Press: accepting and ending a call, starting to dial* selected phone number. Redialing if no phone number is selected
- ▷ Press longer: redialing




Volume




Activating/deactivating voice activation system* [23](#)

18 Releasing the hood [201](#)

- 19  Opening the luggage compartment lid [32](#)

Instrument cluster



- 1 Speedometer
- 2 Indicator lamps for turn signals
- 3 Indicator and warning lamps [13](#)
- 4 Tachometer [64](#)
- 5 Engine oil temperature [65](#)
- 6 Display for
 - ▷ Clock [64](#)
 - ▷ Outside temperature [64](#)
 - ▷ Indicator and warning lamps [13](#)
- 7 Display for
 - ▷ Position of automatic transmission* [54](#)
 - ▷ Gear display for 7-gear sport automatic transmission with dual clutch* [56](#)
 - ▷ Computer [65](#)
 - ▷ Date of next scheduled service, and remaining distance to be driven [69](#)
 - ▷ Odometer and trip odometer [64](#)
 - ▷ Programs for Dynamic Driving Control [79](#)
 - ▷ High-Beam Assistant* [90](#)
 - ▷ Checking the engine oil level [202](#)
 - ▷ Settings and information [68](#)
 - ▷ ▲ There is a Check Control message [73](#)
- 8 Fuel gauge [65](#)
- 9 Resetting the trip odometer [64](#)

Indicator and warning lamps


The concept




Indicator and warning lamps can light up in a variety of combinations and colors.

Some lamps are checked for proper functioning and thus come on briefly when the engine is started or the ignition is switched on.

Explanatory text messages



Text messages at the upper edge of the Control Display explain the meaning of the displayed indicator and warning lamps.



You can call up more information, e.g., on the cause of a malfunction and on how to respond, via Check Control, refer to page 73.

In urgent cases, this information will be shown as soon as the corresponding lamp comes on.

Indicator lamps without text messages

The following indicator lamps notify you that certain functions are active:



High beams/headlamp flasher 90



Lamp flashes:
DSC or DTC is regulating the propulsive forces in order to maintain driving stability 78



Parking brake set 52



Canada: Parking brake set 52




Engine malfunction with adverse effect on exhaust emissions 207



Canada: Engine malfunction with adverse effect on exhaust emissions 207

Around the center console: controls and displays



- 1 SOS: initiating an Emergency Request call* 218
- 2 Reading lamp 92
- 3 Interior lamps 92
- 4 Reading lamp 92
- 5 Passenger airbag status lamp* 86
- 6 Control Display 16
- 7 Hazard warning flashers
- 8 Central locking system 32
- 9 Automatic climate control



Air distribution 96

AUTO

Automatic air distribution and flow rate 97



Cooling function 97



Recirculated-air mode, automatic recirculated-air control 98



Maximum cooling 97



Air flow, residual heat utilization 97



Defrosting windows 98



Rear window defroster 98

- 10 Hard drive for
 - ▷ Audio CD 140
 - ▷ Navigation DVD* 120
- 11 Programmable memory keys 21
- 12 Changing
 - ▷ Radio station 143
 - ▷ Track 151

- 13  Heated seats* 43



Park Distance Control PDC* 77



Close the retractable hardtop 38



Open the retractable hardtop 38

- 14 Parking brake 52
- 15 Buttons on the controller 16
 - For selecting the menus directly
- 16 Controller 16
 - Can be turned, pressed, or moved horizontally in four directions
- 17 Buttons for the Dynamic Driving Control 79
- 18 Switching audio sources on/off and adjusting volume 140
- 19 Ejecting of
 - ▷ Audio CD 140
 - ▷ Navigation DVD* 120

iDrive integrates the functions of a large number of switches. This allows these functions to be operated from a single central position. The following section provides an introduction to

basic menu navigation. The control of the individual functions is described in connection with the relevant equipment.

Controls



1 Control Display

2 Controller with button

You can use the buttons to open the menus directly. The controller can be used to select the menu items and create settings.

- ▷ Move in four directions, arrows **3**
- ▷ Turn, arrow **4**
- ▷ Push, arrow **5**




Operate the controller only when traffic and road conditions allow this, to avoid endangering the car's occupants and other road users by being distracted. ◀

Buttons on the controller

Button	Function
MENU	Open the main menu
RADIO	Open the Radio menu
CD	Open the CD/Entertainment Server menu
NAV	Open the Navigation menu
TEL	Open the Telephone menu
BACK	Display the previous menu
OPTION	Open the Options menu

Operating principle


With the ignition at radio readiness or beyond, refer to page 50, the following message is displayed on the Control Display:



To hide the message:
 Press the controller.
 The main menu is displayed.
 The message is automatically hidden after approx. 10 seconds.

Opening the main menu

MENU Press the button.
 The main menu is displayed.




All iDrive functions can be called up via five menu items.

Selecting menu items

The menu items shown in white can be selected.

1. Turn the controller until the desired menu item is highlighted.



2. Press the controller.

A new menu is displayed or the function is executed.


Menu items in the Owner's Manual

In the Owner's Manual, menu items that can be selected are set in quotation marks, e.g., "Settings".

Changing between panels

After selecting a menu item, e.g., "Radio", a new menu is displayed on a panel. The panels can overlap.

Move the controller to the left or right to change between the panels.



White arrows pointing to the left or right indicate that additional panels can be opened.

Open the Options menu

OPTION Press the button.
The "Options" menu is displayed.




Additional options: move the controller to the right repeatedly until the "Options" menu appears.

The "Options" menu contains the following:


- ▷ Screen settings, refer to page 20.
- ▷ Control options for the selected menu.

Adjusting settings

1. Select a field.
2. Turn the controller until the desired setting is displayed.




3. Press the controller to confirm the setting.


 The scroll bar on the right side indicates whether additional menu items or settings can be selected that are currently not visible. ◀

Example: setting the clock


1. **MENU** Press the button.
The main menu is displayed.
2. Turn the controller until "Settings" is highlighted, and then press the controller.



3. Turn the controller until "Time/Date" is highlighted, and then press the controller.



4. Turn the controller until "Time:" is highlighted, and then press the controller.



5. Turn the controller to set the hours and press the controller.
6. Turn the controller to set the minutes and press the controller.

Status information




- 1 Time
- 2 Display for:
 - ▷ Reception strength of the wireless network, depends on the mobile phone
 - ▷ Incoming, outgoing or missed call
 - ▷ SMS* received
- 3 Display for:
 - ▷ Entertainment: Radio, CD/DVD, external devices, TV*
 - ▷ Telephone*: Name of the mobile phone paired with the vehicle
- 4 Sound output is switched off or display for traffic bulletins*:
 - ▷ "TI": Traffic bulletins are switched on.
 - ▷ No display: Traffic bulletins are switched off.

Other displays:

Status information is temporarily hidden during Check Control message displays or entries via the voice activation system*.

Switching the control display on/off

1. **OPTION** Press the button.
2. "Close Control display"



Press the controller to switch on.

Split screen

Additional information can be displayed on the right side of the split screen, e.g., information from the computer.

In the divided screen view, the so-called split screen, this information remains visible even when you change to another menu.

The setting is stored for the remote control currently in use.

Switching the split screen on and off

1. **OPTION** Press the button.
2. "Split screen"

The split screen is activated.

Selecting the display for the split screen content

When the split screen is switched on, you can select the content displayed on the screen.



1. Move the controller to the right repeatedly until the split screen content is selected.
2. Select the display.



Programmable memory keys




Certain iDrive functions can be stored on the programmable memory keys and called up directly, e.g., radio stations, navigation destinations, phone numbers and entry points into the menu.

Storing functions

1. Select the function via the iDrive.
2.  ...  Press the desired button for longer than 2 seconds.

Example for programmable memory keys

Switch the voice instructions for the navigation on/off.

1. "Navigation"
2. "Map"
3. Select the  symbol using the controller.
4.  ...  Press the desired button for longer than 2 seconds.

Executing a function

 ...  Press the button.

The function is executed immediately. This means, for example, that the number is dialed when a phone number is selected.

Displaying memory key assignments

Touch the button with a finger. Do not wear gloves or use objects.



Displaying brief information

 ...  Touch the button.

The key assignment is displayed at the top edge of the screen.






Displaying detailed information

 ...  Touch the button and hold.

Letters and numbers



Entering letters and numbers

1. Turn the controller: select the letters or numbers.
2. Select additional letters or numbers if needed.
3. "OK": confirm the entry.

Symbol	Function
	Press the controller: delete one letter or number
	Press the controller for an extended period: delete all letters or numbers
	Enter a blank space

Switching between letters and numbers

Depending on the menu, you can switch between entering letters and numbers:

Symbol	Function
	Entering letters
	Entering numbers

Wordmatch concept during navigation

Entry of names and addresses: the selection is narrowed down every time a letter is entered and letters may be added automatically.

Destination search: the entries are continuously compared to the data stored in the vehicle.

- ▷ The only letters offered for entering addresses are those for which data are available.
- ▷ Town/city names can be entered with the spelling used in any of the languages available on the Control Display.

Voice activation system

The concept

The voice activation system allows you to control operation of various vehicle systems without removing your hands from the steering wheel.

Individual menu items on the Control Display can be spoken as commands. It is not necessary to use the controller.


The voice activation system transforms your oral commands into control signals for the selected systems and provides support in the form of instructions or questions.

The voice activation system uses a special microphone located in the area of the steering column.

Precondition

Via iDrive, select the language in which the voice activation system is operating, so that the spoken commands can be identified. Selecting the language for iDrive, refer to page 75.

Symbols in the Owner's Manual


-  ›...‹ Say the specified commands word for word.
- ››...‹‹ Indicates responses of the voice activation system.


Saying commands

Activating voice activation system


1. Press the  button on the steering wheel.




 This symbol on the Control Display and an acoustic signal indicate that the voice activation system is ready to receive spoken commands.



2. Say the command.
The command appears on the Control Display.

 This symbol appears on the Control Display when you can enter additional commands. If no further commands are possible, continue by operating the item of equipment via iDrive.

Terminating or canceling voice activation system

Press the  button on the steering wheel or


 ›Cancel‹

In dialogs that call for a text of your choice, the procedure can only be canceled using the button on the steering wheel.

Possible commands

The commands available in each case depend on the menu item selected on the Control Display.

Having the possible commands read aloud


 ›Voice commands‹


For example, if "CD/DVD" is selected, the commands for operating CD/Multimedia are read aloud.

Calling up functions immediately via short commands

Short commands enable you to perform certain functions immediately, irrespective of which menu item is selected, refer to page 229.

Example: selecting the track of a CD

1. If necessary, switch on entertainment audio output.
2. Press the  button on the steering wheel.


 3. Select the music track, e.g.:
›CD track 4‹
System says:
››Track 4‹‹

Setting the voice dialog

You can set whether the system should use the standard dialog or a shorter variant. In the shorter variant of the voice dialog, the prompts and responses from the system are abbreviated.

1. "Settings"
2. "Language/Units"


3. "Speech mode:"



4. Select a setting:

- ▷ "Default"
- ▷ "Short"

Notes

 For information on voice commands for the telephone, refer also to the separate Owner's Manual. ◀

For voice commands, bear in mind the following:

- ▷ Do not use the voice activation system to initiate an Emergency Request. In stressful situations, the voice and vocal pitch can change. This can unnecessarily delay the establishment of a telephone connection. Use the emergency button near the interior rearview mirror.
- ▷ Pronounce the commands and digits smoothly and at normal volume, avoiding excessive emphases and pauses. This also applies when spelling out destinations during destination entry.
- ▷ When selecting a radio station, use the standard pronunciation of the station name.
- ▷ For entries in the voice-activated phone book, only use names in the language of the voice activation system and no abbreviations.
- ▷ Keep the doors, windows and retractable hardtop closed to prevent interference from outside noise.
- ▷ Avoid ambient noise in the vehicle while speaking.



A close-up, blue-tinted photograph of a car's interior controls. The image shows a circular dial on the left, a vertical slider or button in the center, and a rectangular control panel on the right. The background is blurred, focusing attention on the controls.

Controls

This chapter is intended to provide you with information for complete control of your vehicle. All features and accessories that are useful for driving and your safety, comfort and convenience, are described here.

Opening and closing

Remote control



Each remote control contains a rechargeable battery that is automatically recharged when it is in the ignition lock while the car is being driven. Use each remote control at least twice a year for longer road trips in order to maintain the batteries' charge status. In cars with Comfort Access*, the remote control contains a replaceable battery, refer to page 36.

The settings called up and implemented when the car is unlocked depend on which remote control is used to unlock the car, refer to Personal Profile, next column.

In addition, information about service requirements is stored in the remote control, refer to Service data in the remote control, page 206.

Integrated key



Press button 1 to release the key.

The integrated key fits the following locks:

- ▷ Glove compartment, refer to page 103
- ▷ Driver's door, refer to page 31

New remote controls

Your BMW center can supply new remote controls with integrated keys as additional units or as replacements in the event of loss.

Personal Profile

The concept

You can set many of your BMW's functions to suit your personal needs and preferences. Without any action on your part, Personal Profile ensures that most of these settings are stored for the remote control currently in use. When you unlock the car, the remote control used for the purpose is recognized and the settings stored for it are called up and implemented.

This means that your personal settings will be activated for you, even if in the meantime your car was used by someone else with another remote control and the corresponding settings. The individual settings are stored for a maximum of four remote controls. They are stored for two remote controls if Comfort Access* is in use.

Personal Profile settings

For more information on specific settings, refer to the specified pages.

- ▷ Assignment of programmable memory keys, refer to page 21
- ▷ Response of the central locking system when the car is unlocked, refer to page 29
- ▷ Automatic locking of the vehicle, refer to page 32
- ▷ Automatic call-up* of the driver's seat position, refer to page 43
- ▷ Triple turn signal activation, refer to page 60

- ▷ Settings for the display on the Control Display and in the instrument cluster:
 - ▷ 12h/24h format of the clock, refer to page 71
 - ▷ Date format, refer to page 72
 - ▷ Brightness of Control Display, refer to page 76
 - ▷ Language on the Control Display, refer to page 75
 - ▷ Split screen, refer to page 20
 - ▷ Units of measure for fuel consumption, distance covered/remaining distances, and temperature, refer to page 68
- ▷ Show visual warning for Park Distance Control PDC*, refer to page 77
- ▷ Light settings:
 - ▷ Welcome lamps, refer to page 88
 - ▷ Pathway lighting, refer to page 89
 - ▷ Daytime running lights, refer to page 89
 - ▷ High-beam assistant*, refer to page 90
- ▷ Automatic climate control: activating/deactivating AUTO program, cooling function and automatic recirculated-air control, setting temperature, air flow rate and distribution, refer to page 96 ff
- ▷ Entertainment:
 - ▷ Tone control, refer to page 140
 - ▷ Volume, refer to page 142

Central locking system

The concept

The central locking system functions when the driver's door is closed.

The system simultaneously engages and releases the locks on the following:

- ▷ Doors
- ▷ Luggage compartment lid
- ▷ Fuel filler flap
- ▷ Center armrest*

Operating from outside

- ▷ Via the remote control
- ▷ Using the door lock
- ▷ In cars with Comfort Access*, via the handles on the driver's and passenger doors


In addition, if the remote control is used, the welcome lamps, interior lamps and the door's courtesy lamps* are switched on or off. The alarm system* is also armed or disarmed. For further details of the alarm system, refer to page 33.


Operating from inside

By means of the button for central locking, refer to page 32.

In the event of a sufficiently severe accident, the central locking system unlocks automatically. In addition, the hazard warning flashers and interior lamps come on.

Opening and closing: Using the remote control

 Persons or animals in a parked vehicle could lock the doors from the inside. You should therefore take the remote control with you when you leave the vehicle so that the latter can be opened from outside. ◀

 To operate the retractable hardtop with the remote control, the doors and luggage compartment lid must be closed and the cargo area partition must be folded down and engaged on both sides. Refer also to page 38. ◀

Unlocking

Press the  button.



The interior lamps, the courtesy lamps* and the welcome lamps come on.

Setting unlocking characteristics

You can set whether only the driver's door or the entire vehicle is to be unlocked when the button is pressed for the first time.

1. "Settings"
2. "Door locks"
3. "Unlock button"




4. Select a menu item:
 - ▷ "All doors" Press the  button once to unlock the entire vehicle.
 - ▷ "Driver's door only" Press the  button once to unlock the driver's door and fuel filler flap. Press the button twice to unlock the entire vehicle.
5. Press the controller.


Convenient opening*: Windows and hardtop

When you are close to the vehicle, the remote control for Comfort Access can be used to open the retractable hardtop.

Hold the  button down.

The windows and the retractable hardtop are opened if the doors are closed.

When you are close to the vehicle, the windows move up if you continue to press the  button after opening the hardtop.

 Watch during the opening process to ensure that no one is injured. Releasing the button interrupts the opening process. ◀

Locking


Press the  LOCK button.

Convenient closing*

When you are close to the vehicle, the remote control for Comfort Access can be used to close the retractable hardtop and the windows.

Hold the  LOCK button down.

The retractable hardtop and the windows are closed.

 Watch during the closing process to ensure that no one is injured. Releasing the button interrupts the closing process. ◀


Switching on interior lamps


While the car is locked:

Press the  LOCK button.

You can also use this function to locate your vehicle in parking garages etc.

Unlocking the luggage compartment lid



Press the  button for approx. 1 second.

 The luggage compartment lid swings back and up when opened. Ensure that there is sufficient clearance. To avoid locking yourself out by accident, do not place the remote control in the cargo area. A previously locked luggage compartment lid is locked again after closing.

Before and after each trip, check that the luggage compartment lid has not been inadvertently unlocked. ◀

Convenient loading*

When you are close to the vehicle, the remote control for Comfort Access can be used to partially raise the open hardtop for more convenient loading of the cargo area.

1. Briefly press the  button and, within one second, press again until the retractable hardtop stops in an intermediate position. The luggage compartment lid opens slightly.
2. Open the luggage compartment lid, press the cargo area partition upward and stow the cargo in the cargo area.
3. Press down the cargo area partition until it engages on both sides and close the luggage compartment lid.
4. Press the  button for a longer period to fold the retractable hardtop back in.


Confirmation signals

You can activate or deactivate the confirmation signals.

1. "Settings"
2. "Door locks"
3. "Flash when lock/unlock"



4. Press the controller.

 Flashing when locking/unlocking the vehicle is switched on.

Malfunctions

The remote control may malfunction due to local radio waves. If this occurs, unlock and lock the car at the door lock with the integrated key.

If the car can no longer be locked with a remote control, the battery in the remote control is discharged. Use the remote control on an extended trip to recharge the battery, refer to page 28. The remote control for Comfort Access* contains a battery that may have to be changed, refer to page 36.

For US owners only


The transmitter and receiver units comply with part 15 of the FCC/Federal Communications Commission regulations. Operation is governed by the following:

FCC ID:
LX8766S
LX8766E
LX8CAS


Compliance statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- ▷ This device must not cause harmful interference, and
- ▷ This device must accept any interference received, including interference that may cause undesired operation.

 Any unauthorized modifications or changes to these devices could void the user's authority to operate this equipment. ◀

Opening and closing: Using the door lock




You can set the way in which the car is unlocked, refer to page 29.

Convenient operation*

You can operate the windows and the retractable hardtop via the door lock.

Hold the key in the position for unlocking or locking.

 During each closing procedure, and when opening the retractable hardtop, watch the process and ensure that no one becomes trapped. Releasing the key stops the operation. ◀

Manual operation

In the event of an electrical malfunction, you can lock and unlock the driver's door by turning the integrated key to the corresponding limit positions in the door lock.

Opening and closing: From the inside*



This button* serves to unlock or lock doors and the luggage compartment lid, but does not activate the anti-theft system. The fuel filler flap remains unlocked.

Automatic locking

You can also set the situations in which the car locks:

1. "Settings"
2. "Door locks"
3. Select the desired function:
 - ▷ "Lock if no door is opened"
The central locking system locks the vehicle after a short time, unless a door has been opened.
 - ▷ "Lock after start. to drive"
The central locking system locks the vehicle when you drive away.




The setting is stored for the remote control currently in use.

Unlocking and opening doors


- ▷ Either unlock the doors together using the button for the central locking system and then pull the door handle above the armrest or
- ▷ pull on the door handle of each door twice: the first time unlocks the door, the second time opens it.

Locking


- ▷ Use the central locking button to lock all of the doors simultaneously, or
- ▷ press down the safety lock button of a door. To prevent you from being locked out, the open driver's door cannot be locked using the lock button.

 Persons or animals in a parked vehicle could lock the doors from the inside. You should therefore take the remote control with you when you leave the vehicle so that the latter can be opened from outside. ◀

Luggage compartment lid

 In order to avoid damage, make sure there is sufficient clearance before opening the luggage compartment lid. ◀


Opening from inside



Press the button: the luggage compartment lid opens unless it has been locked.

Opening from outside



Press on the top half of the BMW emblem or, for approx. 1 second, on the  button of the remote control:
The luggage compartment can be opened.

Emergency release*





Pull the lever in the cargo area. The luggage compartment lid is unlocked.

Closing



The handle recesses on the interior trim of the luggage compartment lid make it easier to pull down.

 Make sure that the closing path of the luggage compartment lid is clear; otherwise, injuries may result. ◀

 To close the luggage compartment lid, press it down lightly. The lid is closed automatically. ◀

Alarm system*

The concept

The vehicle alarm system responds:


- ▶ When a door, the hood or the luggage compartment lid is opened
- ▶ To movements inside the vehicle: Interior motion sensor, refer to page 34
- ▶ When the car's inclination changes, for instance if an attempt is made to jack it up and steal the wheels or to raise it prior to towing away
- ▶ When there is an interruption in the power supply from the battery

The alarm system signals unauthorized entry attempts for a short time by means of:

- ▶ An acoustic alarm
- ▶ Switching on the hazard warning flashers
- ▶ Flashing the high beams


Arming and disarming

When you lock or unlock the vehicle, either with the remote control or at the door lock, the alarm system is armed or disarmed at the same time.

You can open the luggage compartment lid using the  button of the remote control even if the alarm system is armed, refer to page 30. The lid is locked and monitored again as soon as it is closed.

Panic mode*

You can trigger the alarm system if you find yourself in a dangerous situation:

Press the  button for at least three seconds.

To switch off the alarm: press any button.

Switching off an alarm

- ▷ Unlock the car with the remote control, refer to page 29.
- ▷ Insert the remote control all the way into the ignition lock.

Indicator lamp displays



- ▷ The indicator lamp under the inside rearview mirror flashes continuously: the system is armed.
- ▷ The indicator lamp flashes after locking: doors, hood or luggage compartment lid are not properly closed. Even if you do not close the alerted area, the system begins to monitor the remaining areas, and the indicator lamp flashes continuously after approx. 10 seconds. The interior motion sensor and the tilt alarm sensor are not activated.
- ▷ The indicator lamp goes out after unlocking: your vehicle has not been disturbed while you were away.
- ▷ If the indicator lamp flashes after unlocking until the remote control is inserted in the ignition, but for no longer than approx. 5 minutes: your vehicle has been disturbed while you were away.

Tilt alarm sensor

The tilt of the vehicle is monitored. The alarm system reacts, e.g., to attempts to steal a wheel or tow the vehicle.

Interior motion sensor

The interior of the car is monitored up to the height of the seat cushions. Thus the alarm system is activated together with the interior motion sensor even if the hardtop is open. An

alarm can be triggered unintentionally by falling objects such as leaves, refer to Avoiding unintentional alarms.

Avoiding unintentional alarms

The tilt alarm sensor and interior motion sensor may be switched off at the same time. This prevents unintentional alarms, e.g., in the following situations:

- ▷ In duplex garages
- ▷ During transport on car-carrying trains, boats/ships or on a trailer
- ▷ When animals are to remain in the vehicle

Switching off tilt alarm sensor and interior motion sensor

Press the **LOCK** button on the remote control again as soon as the vehicle is locked.

The indicator lamp lights up briefly and then flashes continuously. The tilt alarm sensor and the interior motion sensor are switched off until the next time the vehicle is unlocked and subsequently locked again.

Comfort Access*

Comfort Access enables you to enter your vehicle without needing to hold the remote control in your hand. All you need to do is wear the remote control close to your body, e.g., in your jacket pocket. The vehicle detects the corresponding remote control within the immediate vicinity or in the passenger compartment.

Comfort Access supports the following functions:

- ▷ Unlocking/locking the vehicle
- ▷ Unlocking the luggage compartment lid separately
- ▷ Starting the engine
- ▷ Convenient opening
- ▷ Convenient closing

Functional requirement

- ▷ The vehicle or the luggage compartment lid can only be locked when the vehicle detects that the remote control currently in use is outside of the vehicle.
- ▷ The vehicle cannot be locked or unlocked again until after approx. 2 seconds.
- ▷ The engine can only be started when the vehicle detects that the remote control currently in use is inside the vehicle.


Comparison to the standard remote control


In general, there is no difference between using Comfort Access or pressing the buttons on the remote control to carry out the functions mentioned above. You should therefore first familiarize yourself with the instructions on opening and closing starting on page 28.

Special features regarding the use of Comfort Access are described below.


- ▷ If you notice a brief delay while opening or closing the windows or retractable hard-top, the system is checking whether a remote control is inside the vehicle. Please repeat the opening or closing procedure, if necessary. ◀

Releasing



Pull the handle up, arrow 1. This corresponds to pressing the  button.

Locking


Press on the surface, arrow 2. This corresponds to pressing the  LOCK button.

- ▷ To preserve the battery, please make sure that the ignition and all electrical consumers are switched off before locking the vehicle. ◀

Window and convertible top operation

With the ignition at radio readiness or beyond, you can open and close the windows and the convertible top when a remote control is located inside the vehicle.

Unlocking the luggage compartment lid separately

Press on the top half of the BMW emblem. This corresponds to pressing the  button.

- ▷ If the vehicle detects that a remote control has been accidentally left inside the locked vehicle's cargo area after the luggage compartment lid is closed, the lid will reopen. The hazard warning flashers flash and an acoustic signal* sounds. ◀

Switching on radio readiness

Radio readiness is switched on by pressing the start/stop button, refer to page 50.

- ▷ Do not depress the brake or the clutch; otherwise, the engine will start. ◀

Starting the engine

You can start the engine or switch on the ignition when a remote control is inside the vehicle. It is not necessary to insert a remote control into the ignition switch, refer to page 50.

Switching off the engine in cars with automatic transmission

The engine can only be switched off when the selector lever is in position P, refer to page 52. To switch the engine off when the selector lever is in position N, the remote control must be in the ignition switch.

Before driving a vehicle with automatic transmission into a car wash

1. Insert the remote control into the ignition switch.
2. Depress the brake.
3. Move the selector lever to position N.
4. Switch off the engine.

The vehicle can roll.

Malfunction

Comfort Access may malfunction due to local radio waves. If this happens, open or close the vehicle via the buttons on the remote control or using the integrated key. To start the engine afterward, insert the remote control into the ignition switch.

Warning lamps



The warning lamp in the instrument cluster lights up when you attempt to start the engine: the engine cannot be started. The remote control is not inside the vehicle or is malfunctioning. Take the remote control with you inside the vehicle or have it checked. If necessary, insert another remote control into the ignition switch.



The warning lamp in the instrument cluster lights up while the engine is running: the remote control is no longer inside the vehicle. After the engine is switched off, the engine can only be restarted within approx. 10 seconds.



The indicator lamp in the instrument cluster comes on and a message appears on the Control Display: replace the battery in the remote control.

Replacing the battery

The remote control for Comfort Access contains a battery that will need to be replaced from time to time.

1. Take the integrated key out of the remote control, refer to page 28.



2. Remove the cover.
3. Insert the new battery with the plus side facing up.
4. Press the cover on to close.



Take the old battery to a battery collection point or to your BMW center. ◀

Windows



To prevent injuries, watch the windows while closing them.

Take the remote control with you when you leave the car; otherwise, children could operate the electric windows and possibly injure themselves. ◀

Opening, closing

Individually



- ▶ Press the switch to the resistance point: The window opens as long as you press the switch.
- ▶ You can close all windows in the same manner by pulling the switch. Press the switch beyond the resistance point: The window opens automatically. Press the switch again to stop the opening movement.

You can close the windows in the same manner by pulling the switch.

Jointly



- ▶ Press the switch to the resistance point: All windows open as long as you press the switch.
- ▶ You can close all windows in the same manner by pulling the switch. Press the switch beyond the resistance point: All windows open automatically. Press the switch again to stop the opening movement.

After switching off the ignition


When the remote control is removed or the ignition is switched off, you can still operate the windows for approx. 1 minute as long as no door is opened.

Convenient operation

For information on convenient operation via the remote control or the door lock, refer to page 29 or 31. For information on Convenient closing with Comfort Access, refer to Locking on page 30.

Pinch protection system

If the closing force exceeds a specific value as one of the front side windows closes, the window stops closing and reopens slightly.

 Despite the pinch protection system check and clear the window's travel path prior to closing it; otherwise, the safety system might fail to detect certain kinds of obstructions, such as thin objects, and the window would continue closing.

Do not install any accessories that might interfere with window movement. Otherwise, the pinch protection system could be impaired. ◀

Closing without pinch protection

If there is an external danger, or if ice on the windows, etc., prevents you from closing the windows normally, proceed as follows:


1. Pull the switch past the resistance point and hold it there. Pinch protection is limited and the window reopens slightly if the closing force exceeds a certain value.
2. Pull the switch again past the resistance point within approx. 4 seconds and hold it there. The window closes without pinch protection.

Retractable hardtop


The retractable hardtop combines reliable weather protection with simple and convenient operation.


Please note:

- ▷ It is advisable that you close the retractable hardtop when you park the vehicle. Not only does the closed hardtop protect the vehicle interior against unanticipated weather damage, it also offers theft protection. However, even when the hardtop is closed, valuables should only be stored in the locked cargo area.
- ▷ Do not attach roof rack systems to the retractable hardtop, and in particular do not attach magnetic racks.
- ▷ Do not attach rack systems to the luggage compartment lid, and in particular do not attach magnetic racks.
- ▷ When the retractable hardtop is operated, the luggage compartment lid swings back and up. Before operating the retractable hardtop, ensure that there is enough clearance, e.g., in tight parking spaces.
- ▷ If you open the hardtop while it is wet, e.g., after driving in the rain, water may drip into the cargo area. If necessary, remove items from the cargo area beforehand to avoid water stains or soiling.


 Do not place any objects on the retractable hardtop or on the luggage compartment lid; otherwise, they could fall during movements of the retractable hardtop and cause damage or injury.

Driving when the hardtop is not fully opened or not fully closed may result in damage or injury. Do not reach into the mechanism while the hardtop is opening or closing. Keep children away from the swiveling area of the retractable hardtop. ◀

 The retractable hardtop cannot be moved at temperatures below +14 °F / -10 °C. A message appears on the Control Display. ◀

 The retractable hardtop can only be opened and closed when the vehicle is stationary. To avoid causing damage, do not drive off until the hardtop has stopped moving. ◀

Before opening and closing

 Do not let the hardtop stop in an intermediate position when opening or closing. Otherwise, there is the danger of personal injury since the hardtop will be lowered automatically after a few minutes. ◀

- ▷ Comply with the safety precautions described above.
- ▷ Ensure that the luggage compartment lid is closed.
- ▷ The vehicle should be parked on fairly level ground. Excessive angle is indicated by a lamp.
- ▷ Fold down the cargo area partition and make sure it engages, refer to the instructions below.
- ▷ Do not place any objects next to or on the cargo area partition and close the storage compartment on the left side of the cargo area.
- ▷ Do not exceed the maximum loading height under the cargo area partition; refer to the label in the cargo area showing a line indicating the maximum height.

Folding down the cargo area partition




Before opening the hardtop, close the cargo area partition, arrow, and make sure it engages on both sides.

Opening and closing

When the vehicle is stationary and at radio readiness or beyond, refer to page 50:

- ▶ If possible, conserve the battery by only operating the retractable hardtop when the engine is running.

Before closing the retractable hardtop, remove all foreign objects from the windshield frame as these could prevent the hardtop from closing properly. ◀



- 1 Press and hold button 1:
The retractable hardtop closes.
- 2 Press and hold button 2:
The retractable hardtop opens.
- 3 LEDs

- ▶ The side windows move down when the hardtop is opened or closed. Convenient closing* If you continue pressing the buttons after the LED 3 goes out, the windows move back up. ◀

If the windows pause briefly as they move, this is for technical reasons and is not a malfunction.

LEDs

In the following situations, a message appears on the Control Display or an acoustic signal sounds in addition to the LED lighting up:

- ▶ While the hardtop is being operated, the green LED lights up. It goes out as soon as the top is fully opened or closed.
- ▶ If the red LED flashes when you release the switch, the opening or closing action has not yet finished.

- ▶ If the red LED lights up when the switch is pressed, the cargo area partition is folded up, the luggage compartment lid is not closed, the vehicle is standing on a strong incline or there is a malfunction. The retractable hardtop cannot be moved.

Interruption

The automatic sequence of movements is interrupted if the switch for hardtop operation is released. The sequence can be continued in the desired direction by pushing or pulling the switch.

- ▶ **!** Open or close the hardtop fully; otherwise, there is a risk of injury or damage when driving.

Do not interrupt and resume the closing procedure several times in close succession as this could damage the mechanism. ◀

- ▶ If the hardtop is not fully opened or closed, the luggage compartment lid cannot be opened and the windows cannot be moved. ◀

Convenient operation with remote control or via door lock


Refer to pages 30 and 31.

Wind deflector*


The wind deflector keeps air movements in the passenger compartment to a minimum when the hardtop is open and provides an even more comfortable ride, particularly at high speeds.

Installation

1. Insert the wind deflector **1** into the holders **2** on the rollover bars; the arrow should point in the direction of travel.




2. Push the wind deflector down, arrow **1**, and then push down and forward simultaneously, arrow **2**, until it engages.



⚠ The wind deflector must engage firmly; otherwise, it could become detached at higher vehicle speeds. ◀

Removing the wind deflector

1. Push the wind deflector down and back simultaneously, arrow **1**, to disengage it from the catch mechanism.



2. Pull the wind deflector upward out of the holders, arrow **2**.

Coat hooks




Coat hooks **1** are located on the wind deflector panels in the rollover bars.

⚠ Do not hang heavy objects on the hooks. If you do, they could endanger the passengers, for example during braking or evasive maneuvers. ◀

Storage

1. Fold the wind deflector **1** and slide it into the storage pouch **2**.



2. You can store the wind deflector on the lateral storage shelf behind the seats.


Adjustments

Sitting safely

The ideal sitting position can make a vital contribution to relaxed, fatigue-free driving. In conjunction with the safety belts, the head restraints and the airbags, the seated position has a major influence on your safety in the event of an accident. To ensure that the safety systems operate with optimal efficiency, we strongly urge you to observe the instructions contained in the following section.

For additional information on transporting children safely, refer to page 48.

Airbags

 Always maintain an adequate distance between yourself and the airbags. Always grip the steering wheel on the rim, with your hands in the 3 o'clock and 9 o'clock positions, to minimize the risk of injury to the hands or arms in the event of the airbag being triggered off. No one and nothing should come between the airbags and the seat occupant.

Do not use the cover of the front airbag on the passenger side as a storage area. Make sure that the passenger is sitting correctly, e.g., keeping his or her feet or legs in the footwell and not on the dashboard; otherwise, leg injuries can occur if the front airbag deploys.

Make sure that passengers do not lean their heads against the side airbag; otherwise, serious injuries could result if the airbag suddenly deployed. ◀


Even if you follow all the instructions, injuries resulting from contact with airbags cannot be fully excluded, depending on the circumstances. The ignition and inflation noise may provoke a mild hearing loss in extremely sensitive individuals. This effect is usually only temporary.

For airbag locations and additional information on airbags, refer to page 85.

Safety belt

Before every drive, make sure that all occupants wear their safety belts. Airbags complement the safety belt as an additional safety device, but they do not represent a substitute.

Your vehicle has two seats, each of which is equipped with a safety belt.

 Never allow more than one person to wear a single safety belt. Never allow infants or small children to ride in a passenger's lap. Make sure that the belt in the lap area sits low across the hips and does not press against the abdomen.


The safety belt must not rest against the throat, run across sharp edges, pass over hard or fragile objects or be pinched. Fasten the safety belt so that it sits as snugly as possible against the lap and shoulder without being twisted. Otherwise, the belt could slide over your hips and injure your abdomen in the event of a frontal collision.

Avoid wearing bulky clothing and regularly pull the belt in the upper-body area taut; otherwise, its restraining effect could be impaired. ◀

Safety belts, refer to page 44.

Seats

Note before adjusting


 Never attempt to adjust your seat while the vehicle is moving. The seat could respond with unexpected movement, and the ensuing loss of vehicle control could lead to an accident.

On the passenger seat as well, do not incline the backrest too far to the rear while the vehicle is being driven; otherwise, there is a danger in the event of an accident of sliding under the safety belt, eliminating the protection normally provided by the belt. ◀

Note the information on safety belt damage on page 45.

Manual adjustment

! Observe the adjustment instructions on page 41 to ensure the best possible personal protection. ◀




Longitudinal direction

Pull lever 1 and slide the seat to the desired position. After releasing the lever, move the seat gently forward or back to make sure it engages properly.

Height

Pull lever 2 and apply your weight to the seat or lift it off, as necessary.

Backrest



Pull lever 3 and apply your weight to the backrest or lift it off, as necessary.

Distance:


Adjust the backrest so that the head restraint is as close as possible to the back of the head.

Tilt*



Pull the lever and apply your weight to the seat or lift it off, as necessary.

Thigh support*



Pull the lever and move the thigh support forward or back.

Electrical adjustment

! Observe the adjustment instructions on page 41 to ensure the best possible personal protection. ◀



- 1 Longitudinal direction
- 2 Height
- 3 Angle



4 Backrest

Lumbar support*



You can also adjust the contour of the backrest to obtain additional support in the lumbar region.

The upper hips and spinal column receive supplementary support to help you maintain a relaxed, upright sitting position.

- ▷ Increase or decrease curvature: press the switch at the front or rear, respectively.
- ▷ Shift curvature up or down: press the switch at the top or bottom, respectively.


Backrest width*



You can change the width of the backrest to suit your individual preferences by adjusting the lateral-support pads.

Press the front or rear end of the switch. Backrest width decreases or increases accordingly.

Heated seats*



Press once for each temperature level. Three LEDs indicate the highest temperature.

To switch off:
Press button longer.

If you continue driving within approx. the next 15 minutes, the seat heating is automatically activated at the previously set temperature.


The temperature is lowered or the heating is switched off entirely to save on battery power. The LEDs stay lit.

Seat and mirror memory*

You can store and call up two different combinations of driver's-seat and exterior-mirror positions.

Settings for the backrest width and lumbar support are not stored in memory.

Storing



1. Switch on radio readiness or the ignition, refer to page 50.
2. Adjust the seat and exterior mirrors to the desired positions.
3. Press the **M** button.
The LED in the button lights up.
4. Press the desired memory button **1** or **2**: the LED goes out.

The driver's seat and exterior mirror positions are stored for the remote control currently in use.

Call-up

! Do not call up memory while you are driving; otherwise, unexpected seat movement could result in an accident. ◀

Convenience mode

1. Unlock and open the driver's door or switch on radio readiness, refer to page 50.
2. Briefly press the desired memory button **1** or **2**.

The adjusting procedure is halted immediately when you touch a seat adjustment switch or one of the memory buttons.

Safety feature

1. Close the driver's door and switch the ignition on or off, refer to page 50.
2. Press the desired memory button **1** or **2** and keep it pressed until the adjustment process has been completed.

If the **M** button was pressed accidentally: Press the button again; the LED goes out.

Call-up with the remote control


The driver's seat position last stored is stored for the remote control currently in use.

You can select whether the seat should be reset to that position.

! When this Personal Profile function is used, first make sure that the footwell behind the driver's seat is free of obstacles. Failure to do so could result in damage to the objects if the seat were to move rearward. ◀

The adjusting procedure is halted immediately when you touch a seat adjustment switch or one of the memory buttons.

1. "Settings"
2. "Door locks"
3. "Last seat position automatic"



Safety belts

! Observe the adjustment instructions on page 41 to ensure the best possible personal protection. ◀

Before every drive, make sure that all occupants wear their safety belts. Airbags complement the safety belt as an additional safety device, but they do not represent a substitute.



Closing

Make sure you hear the latch plate engage in the belt buckle.

The upper belt anchor is suitable for adults of any stature as long as the seat is adjusted properly, refer to page 41.

Opening

1. Grasp the belt firmly.
2. Press the red button in the buckle.
3. Guide the belt into its reel.


'Fasten safety belts' reminder for driver and passenger*



The indicator lamp comes on and an acoustic signal sounds. In addition, a message appears on the Control Display. Check whether the safety belt has been fastened correctly.


The 'Fasten safety belts' reminder is issued as long as the driver's safety belt has not been fastened. In some country-specific versions, the 'Fasten safety belts' reminder is also activated at road speeds above approx. 5 mph or 8 km/h if the passenger safety belt is not fastened, if objects are placed on the passenger seat, or if driver or passenger unfasten their safety belts.


Damage to safety belts

 If the safety belts are damaged or stressed in an accident: have the belt system, including any belt tensioners or child restraint systems, replaced and the belt anchors checked. Have this work done only by your BMW center or at a workshop that works according to BMW repair procedures with correspondingly trained personnel. Otherwise, it is not guaranteed that the safety devices will function properly. ◀

Mirrors

Exterior mirrors

 The passenger's mirror is more convex than the driver's mirror. The objects seen in the mirror are closer than they appear. Do not gauge your distance from traffic behind you on the basis of what you see in the mirror; otherwise, there is an increased risk of an accident. ◀



- 1 Adjustments
- 2 Folding mirrors in and out*
- 3 Switching to the other mirror or automatic curb monitor*


The setting for the exterior mirrors is stored for the remote control currently in use*. The stored position is called up automatically when the vehicle is unlocked.

Manual adjustment

The mirrors can also be adjusted manually: press the edge of the glass.

Folding mirrors in and out*

At driving speeds up to approx. 12 mph/20 km/h, you can fold the mirrors in and out by pressing button 2. This can be beneficial in narrow streets, for example, or for moving mirrors that were folded in by hand back out into their correct positions. Mirrors that were folded in are folded out automatically at a speed of approx. 25 mph/40 km/h.

 Before entering an automatic car wash, fold in the exterior mirrors by hand or with button 2 to prevent them from being damaged due to the width of the vehicle. ◀

Automatic heating

Depending on the outside temperature, both exterior mirrors are heated automatically when the engine is running or the ignition is switched on.

Passenger-side mirror tilt function – automatic curb monitor*

Activating

1. Push the switch to the position for the driver's side mirror, arrow 1.



2. Engage reverse gear or move the selector lever to position R.
The glass of the mirror on the passenger side tilts slightly down. This allows the driver to see the area immediately adjacent to the vehicle, e.g., a curb, when backing into a parking space.

Deactivating

Push the switch to the position for the passenger-side mirror, arrow 2.

Interior rearview mirror



Turn the knob to reduce glare from the headlights of cars behind you when driving at night.

Interior and exterior mirrors, automatic dimming feature*





The automatic dimming feature of the interior and exterior mirrors* is controlled by two photo cells in the interior rearview mirror. One photo cell is in the mirror frame, see arrow; the other is on the back of the mirror.

In order to ensure that the system functions correctly, keep the photo cells clean, do not cover the area between the interior rearview mirror and windshield, and do not affix adhesive labels or stickers of any kind to the windshield directly in front of the mirror.

Steering wheel

Adjustments

 Do not adjust the steering wheel position while the car is in motion; otherwise, there is a risk of accident due to an unexpected movement. ◀



1. Fold the lever down.
2. Move the steering wheel to the preferred height and angle to suit your seated position.

3. Swing the lever back up.



Do not use force to swing the lever back up; otherwise, the mechanism will be damaged. ◀

Steering wheel heating*



To switch on or off, press the button.
The LED lights up: the steering wheel heating is switched on.

Transporting children safely

The right place for children

⚠ Do not leave children unattended in the vehicle; otherwise, they could endanger themselves and/or other persons by opening the doors, for example. ◀

Children on the passenger seat

⚠ Always transport children under the age of 13 or smaller than 5 ft/150 cm in a child restraint system suitable for their age, weight and size, and with the passenger airbag deactivated. Otherwise, there is an increased risk of injury in the event of an accident or if the airbags deploy. ◀

Children 13 years of age or older must be buckled in with a safety belt as soon as there no longer is any child restraint system that is appropriate for their age, size and weight.

For more information on automatic deactivation of the passenger airbags refer to page 86.

Installing child restraint systems

⚠ After installing a child restraint system on the passenger seat, make sure that the front and side airbags for the passenger are deactivated; otherwise, there is an increased risk of injury if the airbags deploy.

Observe the child restraint system manufacturer's instructions when selecting, installing and using child restraint systems. Otherwise, the protective effect may be diminished. ◀

Standard child restraint systems are designed to be secured with a lap belt or with the lap-belt section of a lap-and-shoulder belt. Incorrectly or improperly installed child restraint systems can increase the risk of injury to children.

Always follow the installation instructions for the system with the greatest care.

On the passenger seat

⚠ After installing a child restraint system on the passenger seat, make sure that the front and side airbags for the passenger are deactivated; otherwise, there is an increased risk of injury if the airbags deploy. ◀

Seat position

Before installing a child restraint system, move the passenger seat as far back and up* as possible to obtain the best possible position for the belt.

Backrest width*

⚠ The backrest width of the passenger seat must be at its widest possible setting. Do not change the setting after installing the child seat. Otherwise, the child seat's stability on the passenger seat is limited. ◀

1. Adjust the backrest width to its widest setting, refer to page 43.
2. Install the child seat.

Child seat security



The safety belt for the passenger can be locked to prevent it from being pulled out when it is used to secure child restraint systems.

To lock the safety belt

1. Secure the child restraint system with the belt.
2. Pull the belt strap all the way out.
3. Allow the belt strap to retract and pull it taut against the child restraint system.

The safety belt is locked.

To unlock the safety belt

1. Open the belt buckle.
2. Remove the child restraint system.
3. Allow the safety belt strap to retract all the way.

Upper LATCH retaining strap

For Canadian Customers only


The following statement is required by Transport Canada

This vehicle is not equipped with user-ready tether anchorages. As such neither a child restraint system, nor a booster cushion, requiring the use of a tether strap can be properly secured in the vehicle.

Driving

Ignition lock

Insert the remote control into the ignition lock




Insert the remote control all the way into the ignition lock.

- ▷ Radio readiness is switched on. Individual electrical consumers can operate.

Comfort Access*

If the car is equipped with Comfort Access, only insert the remote control into the ignition lock under special circumstances, refer to page 34.

Removing the remote control from the ignition lock

 Do not forcibly pull the remote control out of the ignition lock as this may cause damage. ◀

Before removing the remote control, push it all the way in to release the locking mechanism.

- ▷ The ignition is switched off if it was on.

Automatic transmission

You can only take out the remote control if transmission position P is engaged: Interlock

Start/stop button



Pressing the start/stop button switches radio readiness or the ignition on or off.

- ▷ The engine is started when you press the start/stop button and depress the clutch if the car has manual transmission, or the brake if the car has automatic transmission. ◀

Radio readiness

Individual electrical consumers can operate. The time and the outside temperature are displayed in the instrument cluster.

Radio readiness is switched off automatically:

- ▷ When the remote control is removed from the ignition lock
- ▷ In cars with Comfort Access*, by touching the surface above the door lock, refer to Locking on page 35

Ignition on

All electrical consumers can operate. The odometer and trip odometer are displayed in the instrument cluster.

- ▷ When the engine is off, please switch off the ignition and any unnecessary electrical consumers in order to preserve the battery. ◀

Radio readiness and ignition off


All indicator and warning lamps as well as displays in the instrument cluster go out.

Starting the engine

⚠ Do not run the engine in enclosed areas; otherwise, the inhalation of toxic exhaust gases can cause loss of consciousness and death. The exhaust gases contain carbon monoxide, an odorless and colorless, but highly toxic gas. Never leave an unattended vehicle with the engine running; otherwise, such a vehicle represents a potential safety hazard. Before leaving the car with the engine running, place the transmission in neutral or move the selector lever to position P and set the parking brake to prevent the car from moving. ◀

⚠ Avoid frequent starting in quick succession as well as repeated start attempts in which the engine does not start. Otherwise, the fuel is not burned or incompletely burned and there is a danger of overheating and damaging the catalytic converter. ◀

Do not wait for the engine to warm up while the vehicle remains stationary. Start driving right away, but at moderate engine speeds.



Manual transmission

Remote control in the ignition lock or, with Comfort Access, inside the vehicle, refer to page 34.

1. Depress the brake.
2. Depress the clutch and shift to neutral position.
3. Press the start/stop button.

The starter operates automatically for a certain time, and stops automatically as soon as the engine has started.

Automatic transmission

Remote control in the ignition lock or, with Comfort Access, inside the vehicle, refer to page 34.

1. Depress the brake.
2. Move the selector lever to position P.
3. Press the start/stop button.

The starter operates automatically for a certain time, and stops automatically as soon as the engine has started.


7-gear sport automatic transmission with dual clutch

Remote control in the ignition lock or, with Comfort Access, inside the vehicle, refer to page 34.

1. Depress the brake.
2. Press the start/stop button.

The engine starts, regardless of the current selector lever position.

Switching off the engine

 Always take the remote control with you when you leave the vehicle. Set the parking brake firmly when parking; otherwise, the vehicle could roll. ◀

Manual transmission

1. With the car at a standstill, press the start/stop button.
2. Shift into first gear or reverse.
3. Set the parking brake.
4. Removing the remote control from the ignition lock, refer to page 50.

Automatic transmission

1. With the car at a standstill, move the selector lever to position P.
2. Press the start/stop button.
3. Set the parking brake.
4. Removing the remote control from the ignition lock, refer to page 50.

7-gear sport automatic transmission with dual clutch

1. With the car at a standstill, engage transmission position P.
2. Press the start/stop button.
3. Set the parking brake.
4. Removing the remote control from the ignition lock, refer to page 50.

Parking brake

The concept


Your BMW is equipped with an electromechanical parking brake that can be set and released by using a button. The parking brake is primarily used to prevent the vehicle from rolling when it is parked.


When the vehicle is stationary, the parking brake acts on the rear wheels via an electromechanical mechanism. When the vehicle is rolling or being driven, the parking brake acts on the disc brakes of the front and rear wheels via the hydraulic brake system.

Setting the brake



Pull the button. The parking brake is set.

 The indicator lamp in the instrument cluster and the LED on the button light up red. The parking brake is set.


 Indicator lamp in Canadian models.


To set the parking brake, the remote control does not need to be in the ignition lock.

While driving

In the rare case that the parking brake needs to be used while driving, pull the button for a lengthy period:


The vehicle brakes hard while the button is being pulled.

 The indicator lamp in the instrument cluster lights up red, a sound is issued and the brake lamps light up.

 Indicator lamp in Canadian models.

As soon as you brake the vehicle almost to a standstill, approx. 2 mph/3 km/h, the parking brake remains set.

Releasing

 Take the remote control with you when leaving the vehicle so that children, for example, cannot release the parking brake. ◀

The parking brake can only be released while the ignition is switched on or the engine is running.




With manual transmission


Press the button of the parking brake. Depress the brake and clutch pedals while doing so.

With automatic transmission or 7-gear sport automatic transmission with dual clutch

Press the parking brake button while the brake is depressed or transmission position P is engaged.

Indicator lamps

 The indicator lamp in the instrument cluster goes out.


 Indicator lamp in Canadian models.

Malfunction

In the event of a failure or malfunction of the parking brake, secure the vehicle against rolling using a wheel chock, for example, if you leave the vehicle.

Manual transmission



 When shifting into 5th or 6th gear, press the gearshift lever to the right. Otherwise, the engine could be damaged if you inadvertently shift into 3rd or 4th gear. ◀


Reverse gear

Select this only when the vehicle is stationary. When the gearshift lever is pressed to the left, a slight resistance has to be overcome.

Automatic transmission with Steptronic*

In addition to fully automatic operation, you can also manually shift with the Steptronic, refer to page 54.

Vehicle parking

 To prevent the vehicle from rolling, always select position P and set the parking brake before leaving the vehicle with the engine running. ◀

Disengaging the remote control

In order to remove the remote control from the ignition lock, you must first move the selector lever to position P and switch off the engine: interlock. Removing the remote control from the ignition lock, refer to page 50.

Selector lever positions

P R N D M/S + -

Displays in the instrument cluster



P R N D S M1 to M6

The selector lever position is displayed, or the current gear in the manual mode.

Changing selector lever positions

- ▷ With the ignition switched on or the engine running, the selector lever can be moved out of position P.
- ▷ Before moving the lever away from P or N with the vehicle stationary, first depress the brake; otherwise, the selector lever will refuse to move: shiftlock.



To prevent the vehicle from creeping after you select a driving position, depress the brake until you are ready to start. ◀



A lock prevents you from inadvertently engaging selector lever positions R and P. To cancel the lock, press the button on the front of the selector lever, see arrow.

P Park

Select this only when the vehicle is stationary. The rear wheels are locked.

R Reverse

Select this only when the vehicle is stationary.

N Neutral

You can select this in a car wash, for example. The vehicle can roll.

D Drive, automatic position

Position for normal vehicle operation. All forward gears are selected automatically.


Under normal operating conditions, fuel consumption is lowest when you are driving in position D.

Kickdown

Kickdown enables you to achieve maximum performance.

Press the accelerator pedal beyond the full-throttle resistance point.

Sport program and manual operation M/S



Move selector lever from position D toward the left into the M/S shifting slot:

The sport program is activated and DS is displayed in the instrument cluster. This position is recommended for a performance-oriented driving style.

To deactivate the sport program or manual mode M/S, move the selector lever to the right into position D.

Shifting gears via the selector lever

When you press the selector lever forwards or backwards, the manual mode is activated and Steptronic changes gear. M1 through M6 are displayed in the instrument cluster.

Upshifts and downshifts are executed only when they will result in a plausible combination of engine and vehicle speed; thus, for example,


a downshift that would cause the engine to overrev will not be executed by the system. The gear selected is briefly displayed in the instrument cluster, followed by the gear actually in use.

Shifting gears via shift paddles* on the steering wheel

The shift paddles allow you to shift gears without taking your hands off the steering wheel.

- ▶ When you use the shift paddles on the steering wheel to shift gears in automatic mode, the transmission switches to manual mode.
- ▶ If you do not accelerate or shift gears using the shift paddles for a certain amount of time, the transmission switches back to automatic mode.

▶ If the selector lever is in the M/S gear plane, manual mode remains active. ◀




- ▶ To shift up: press one of the shift paddles back, arrow 1.
- ▶ To shift down: press one of the shift paddles forward, arrow 2.

Upshifts and downshifts are executed only when they will result in a plausible combination of engine and vehicle speed; thus, for example, a downshift that would cause the engine to overrev will not be executed by the system. The gear selected is briefly displayed in the instrument cluster, followed by the gear actually in use.

Overriding selector lever lock

Should the selector lever refuse to move out of position P although the button on the selector lever is pressed, the selector lever lock can be overridden:

1. Unclip the sleeve of the selector lever.
2. Pull the sleeve up over the selector lever until the sleeve is inside out.



3. Using the screwdriver from the onboard vehicle tool kit, refer to page 212, press the red lever while moving the selector lever to the desired position.

7-gear sport automatic transmission with dual clutch*

The concept

This transmission is an automated manual transmission with two clutches and two gearbox components in which the gears are changed without loss of torque.

You operate the transmission using the selector lever and two shift paddles on the steering wheel.

It offers the following functions:

- ▶ Selection between manual and automatic operation: manual mode or drive mode
- ▶ Automatic downshifting and protection against selecting the wrong gear, even in manual mode
- ▶ Launch Control acceleration assistant, refer to page 58
- ▶ Automatic double declutch

System limitations

This transmission is equipped with an overheating protection system that protects the clutches against extremely high loads.



The indicator lamp lights up yellow if the transmission becomes too warm.

Avoid high engine loads and driving off frequently.

If the transmission overheats, the indicator lamp lights up red and power flow to the engine is interrupted. You can only continue driving after the transmission has cooled down.

Avoid driving off frequently with high acceleration and do not hold the vehicle on inclines by depressing the accelerator lightly; otherwise, the transmission may overheat.

Transmission positions

P R N D M/S + -

Displays in the instrument cluster



P, R, N, D1 to D7, S1 to S7, M1 to M7

The transmission position and the gear currently engaged are displayed.

Engaging transmission positions N, D, R

- ▷ Transmission position P can only be disengaged if the engine is running.
- ▷ Before moving the lever away from P or N with the vehicle stationary, depress the brake; otherwise, the transmission will not shift.



Briefly push the selector lever in the desired direction, beyond a resistance point if necessary.

When shifting out of P or into R, press button 1 at the same time.

The engaged transmission position is also displayed on the selector lever.

When you release the selector lever, it returns to its center position.

N Neutral

The vehicle can roll.

- ▷ N remains engaged after the engine is switched off if the remote control remains in the ignition lock. This function can be used in an automatic car wash, for example. P is automatically engaged after approx. 30 minutes. ◀

D drive mode

In drive mode, all forward gears are shifted automatically.

R Reverse

Select this only when the vehicle is stationary.

Engaging transmission position P

Select this only when the vehicle is stationary.



Press button P.

P Park

The rear wheels are locked.

P is engaged automatically when the following conditions are met:

- ▶ The driver's door is opened while the engine is running, your safety belt is not fastened and neither the brake pedal nor the accelerator are activated.
- ▶ The engine is switched off unless N is engaged and the remote control is in the ignition lock.
- ▶ The remote control is removed from the ignition lock.

Kickdown

To accelerate rapidly, e.g., when passing, press the accelerator down past the resistance point. This provides maximum acceleration.

Activating the Sport program and manual mode M/S



Move the selector lever from position D toward the left:

The Sport program is activated.

Sport program

S1 through S7 is displayed in the instrument cluster. This position is recommended for a performance-oriented driving style.

Manual mode:

When you press the selector lever forward or backward, or when you press the shift paddles, manual mode is activated and the gear is changed.

M1 through M7 are displayed in the instrument cluster.

The transmission provides assistance in the following situations:

- ▶ Upshifts and downshifts are executed only when they will result in a plausible combination of engine and vehicle speed; thus, for example, a downshift that would cause the engine to overrev will not be executed by the system.
- ▶ When the vehicle stops, the transmission automatically shifts down to first gear.
- ▶ Shortly before the vehicle slows down to below the minimum speed of the gear currently engaged, the transmission automatically shifts down without requiring your intervention.

Rapid downshifting: in manual mode, you can skip several gears to achieve optimal acceleration. Do so by pressing the accelerator past the resistance point.

Changing to drive mode

Push the selector lever to the right.


Shifting gears via the selector lever

In manual mode:

- ▶ To shift up, pull back the selector lever.
- ▶ To shift down, push it forward.

Shifting gears via the shift paddles on the steering wheel

The shift paddles allow you to shift gears without taking your hands off the steering wheel. You do not need to raise your foot from the accelerator when doing so.



- ▶ To shift up: press one of the shift paddles back, arrow 1.

- ▶ To shift down: press one of the shift paddles forward, arrow 2.

Gears can be shifted using the shift paddles in drive mode or in manual mode.

Gear change in manual mode:

When manual mode is active, refer to page 57, gears can be changed using the shift paddles or the selector lever.

Gear change in drive mode

The shift paddles can be used to change gears in drive mode as well.

Afterwards, if the shift paddles are not used for some time and vehicle acceleration is insufficient, the forward gears are changed again automatically.

Launch Control

Launch Control enables you to drive off with an optimal vehicle acceleration on a high grip road surface.

- ⚠ Do not use Launch Control too often, as the higher loads on the vehicle lead to premature component wear. ◀

Launch Control is available when the engine is at operating temperature, i.e., after driving continuously for at least 6 miles/10 km.

1. With the engine running, depress the brake pedal with your left foot.
2. Activate the SPORT+ program of the Dynamic Driving Control, refer to page 79.
3. With the vehicle stationary, activate manual mode and select first gear.
4. Press the accelerator all the way down. The engine speed when driving off is controlled. A flag symbol appears in the instrument cluster.
5. The vehicle accelerates when you release the brake pedal. Keep the accelerator pressed all the way down.
6. The transmission shifts up automatically as long as the accelerator is pressed all the way down.

Launch Control only becomes available again after a certain distance has been driven.

Launch Control can only be used after the break-in phase, refer to page 112.

- ▶ To maintain driving stability, activate DSC whenever possible. ◀

Manually releasing and engaging the transmission lock

- ▶ If a power failure occurs, e.g., if the battery is discharged or disconnected or if there is an electrical malfunction, the transmission lock must be released manually; otherwise, the rear wheels are blocked and the vehicle cannot be towed. ◀

Release the transmission lock manually for towing only and set the parking brake beforehand to prevent the vehicle from rolling. After parking the vehicle, lock the transmission lock again manually, refer to page 59.

Manual release

1. Unclip the sleeve of the selector lever.
2. Pull the sleeve up over the selector lever until the sleeve is inside out.



3. Insert the Allen wrench from the onboard vehicle tool kit, refer to page 212, into the cap.

- Turn the cap with the Allen wrench, arrow 1, and remove it, arrow 2.



- Insert the Allen wrench into the opening, arrow 1.



- Turn the Allen wrench as far as it will go, arrow 2. The transmission lock is released.


⚠ Do not turn the Allen wrench in the opposite direction as this may damage the mechanism. ◀

- Draw the Allen wrench out of the opening.

⚠ After parking the vehicle, lock the transmission lock again, refer to Locking manually. Otherwise, there is a danger of the vehicle rolling. ◀

Locking manually

- Press the button, see arrow.
The transmission lock is locked again.



- Clip the sleeve of the selector lever back in place.
- Set the parking brake.
Jump-starting and towing, refer to page 219.

Turn signals/ headlamp flasher



- High beams
- Headlamp flasher
- Turn signals

Using turn signals

Press the lever beyond the resistance point.

To turn off manually, press the lever to the resistance point.

▷ Unusually rapid flashing of the indicator lamp indicates that a turn signal indicator has failed. ◀

Indicating a turn briefly

Press the lever as far as the resistance point for as long as you wish to indicate a turn.

Triple turn signal activation

Press the lever as far as the resistance point. The turn signals flash once.


You can set whether it should flash once or three times when activated.

1. **MENU** Press the button.
2. "Settings"
3. "Lighting"
4. "Triple turn signal"



The setting is stored for the remote control currently in use.

Wiper system



- 1 Switching on wipers
- 2 Switching off wipers or brief wipe
- 3 Activating/deactivating intermittent wipe or rain sensor*
- 4 Cleaning windshield and headlamps
- 5 Setting speed for intermittent wipe, or sensitivity of the rain sensor

Switching on wipers

Press the lever upward, arrow 1.

The lever automatically returns to its initial position when released.

Normal wiper speed

Press once.

The system switches to operation in the intermittent mode when the vehicle is stationary.

Fast wiper speed

Press twice or press beyond the resistance point.


The system switches to normal speed when the vehicle is stationary.

Intermittent wipe or rain sensor*

If the car is not equipped with a rain sensor, the intermittent-wipe time is a preset.

If the car is equipped with a rain sensor, the time between wipes is controlled automatically and depends on the intensity of the rainfall. The rain sensor is mounted on the windshield, directly in front of the interior rearview mirror.

Activating intermittent wipe or rain sensor




Press the button, arrow 3. The LED in the button lights up.

Setting speed for intermittent wipe or sensitivity of the rain sensor

Turn knurled wheel 5 up or down.

Deactivating intermittent wipe or rain sensor

Press the button again, arrow 3.
The LED goes out.


 Deactivate the rain sensor before entering an automatic car wash. Failure to do so could result in damage caused by undesired wiper activation. ◀

Cleaning windshield and headlamps*

Pull the lever, arrow 4.

Washer fluid is sprayed onto the windshield and the wipers are operated for a short time.


When the vehicle lighting system is switched on, the headlamps are cleaned at regular and appropriate intervals.

 Do not use the washers if there is any danger that the fluid will freeze on the windshield. If you do, your vision could be obscured. Antifreeze should therefore be added to the fluid, refer to Washer fluid. Do not use the washers when the washer fluid reservoir is empty; otherwise, you will damage the washer pump. ◀


Windshield washer nozzles


The windshield washer nozzles are heated automatically while the engine is running or the ignition is switched on.

Washer fluid

 Washer fluid antifreeze is flammable. Therefore, keep it away from ignition sources and only store it in the closed original container that is kept out of reach of children; otherwise, there is a risk of personal injury. Comply with the instructions on the container. ◀


Washer fluid filler neck

 Only refill washer fluid when the engine is cool to avoid contact with hot engine parts. Otherwise, fluid spills constitute a fire hazard and a risk to personal safety. ◀



All washer nozzles are supplied with washer fluid by the same reservoir.

Fill with water and, if required, with a washer antifreeze, according to manufacturer's recommendations.

 Mix the water and antifreeze before filling the washer fluid reservoir to make sure the correct concentration is maintained. ◀


Capacity

Approx. 6.3 US quarts/6 liters.

Cruise control*

The concept


Cruise control is available for use at speeds of approx. 20 mph or 30 km/h. The car then stores and maintains the speed that you specify using the lever on the steering column. In order to maintain the specified speed, the system brakes the vehicle when the engine braking effect is insufficient on downhill gradients.

 Do not use cruise control when driving at constant speed is prevented by adverse conditions, e.g., winding roads, dense traffic, poor visibility or unfavorable road conditions due to, e.g., snow, rain, ice or loose surfaces. Otherwise, you could lose control of the vehicle and cause an accident as a result. ◀

Manual transmission

You can shift gears while cruise control is activated. An indicator lamp notifies you that you should shift gears when you drive for an extended period at very high or very low engine speeds, or the system is deactivated.

One lever for all functions



- 1 Storing and maintaining speed or accelerating
- 2 Storing and maintaining speed or decelerating
- 3 Deactivating cruise control
- 4 Resuming a speed stored beforehand

Maintaining current speed

Tap the lever, arrow **1**, or pull it briefly, arrow **2**. The car's current speed is stored and maintained. It is displayed on the speedometer and briefly in the instrument cluster.

On uphill gradients, it may prove impossible to maintain the set speed if current engine power output is insufficient. If the engine braking effect is insufficient on downhill slopes, the system will brake the vehicle slightly.

Increasing desired speed

Repeatedly press the lever to the resistance point or beyond, arrow **1**, until the desired speed is reached.

- ▷ Each time the lever is pressed to the resistance point, the desired speed is increased by approx. 1 mph or 1 km/h.
- ▷ Each time the lever is pressed beyond the resistance point, the desired speed is increased by up to 5 mph or 10 km/h.

The system stores and maintains the speed.

Accelerating using the lever

Accelerating slightly:

Press the lever to the resistance point, arrow **1**, and hold until the desired speed is reached.

Accelerating significantly:

Press the lever beyond the resistance point, arrow **1**, and hold until the desired speed is reached.

The vehicle accelerates without pressure on the accelerator pedal. The system stores and maintains the speed.

Decreasing speed

Repeatedly pull the lever to the resistance point or beyond, arrow **2**, until the desired speed is displayed.

- ▷ Each time the lever is pulled to the resistance point, the desired speed is decreased by approx. 1 mph or 1 km/h.
- ▷ Each time the lever is pulled beyond the resistance point, the desired speed is reduced by up to 5 mph or 10 km/h until the minimum speed of 20 mph or 30 km/h is achieved.

The system stores and maintains the speed.

Interrupting the system

Tap the lever upwards or downwards, arrow **3**. The displays in the speedometer change color. In addition, the system is automatically deactivated:

- ▷ When you brake the vehicle
- ▷ When you switch gears very slowly or shift to neutral in cars with a manual transmission
- ▷ When you engage selector lever position N in cars with an automatic transmission
- ▷ When you engage transmission position N in 7-gear sport automatic transmissions with a dual clutch
- ▷ When you activate the DTC Dynamic Traction Control or deactivate DSC
- ▷ When DSC or ABS is intervening

Cruise control is not deactivated by depressing the accelerator pedal. Once the accelerator pedal is released, the stored speed is achieved again and maintained.

Warning lamp



The warning lamp comes on, for example, when cruise control has been deactivated as a result of DSC intervention. A message appears on the Control Display.

Deactivating the system

- ▷ Press the lever upward or downward twice, arrow **3**.
- ▷ Switch off the ignition.

The stored speed is cleared.

Resuming a speed stored beforehand

Press the button, arrow **4**. The last stored speed is resumed and maintained.

Displays in the instrument cluster



- 1** Stored speed
- 2** Selected speed is displayed briefly

▷ If --- mph or --- km/h temporarily appears in the instrument cluster display, it is possible that the system prerequisites for operation are currently not met.

Calling up Check Control messages, refer to page [74](#). ◀

Malfunction



The warning lamp comes on when the system has failed. A message appears on the Control Display. More information can be found beginning on page [73](#).

Controls overview

Odometer, outside temperature display, clock



- 1 Knob in the instrument cluster
- 2 Outside temperature display and clock
- 3 Odometer and trip odometer

Knob in the instrument cluster

- ▷ To reset the trip odometer while the ignition is switched on
- ▷ To display the time, outside temperature and odometer briefly while the ignition is switched off

Units of measure

To select the respective units of measure, miles or km for the odometer as well as °F or °C for the outside temperature, refer to page 68.


The setting is stored for the remote control currently in use.

Time, outside temperature display

Setting the time, refer to page 71.

Outside temperature warning

When the displayed temperature sinks to approx. +37 °F / +3 °C, a signal sounds and a warning lamp lights up. There is an increased risk of black ice.

 Black ice can also form at temperatures above +37 °F / +3 °C. You should therefore drive carefully on bridges and shaded roads, for example; otherwise, there is an increased risk of an accident. ◀

Odometer and trip odometer

Resetting trip odometer:
With the ignition switched on, press button 1 in the instrument cluster.

When the vehicle is parked

If you still want to view the time, outside temperature and odometer reading briefly after the remote control has been taken out of the ignition lock:

Press button 1 in the instrument cluster.

Tachometer



Never force the engine speed up into the red warning field, see arrow. In this range, the fuel supply is interrupted to protect the engine.

Coolant temperature

A warning lamp will come on if the coolant, and therefore the engine, becomes too hot. In addition, a message will appear on the Control Display.

Check coolant level, refer to page 204.

Engine oil temperature*



When the engine is at normal operating temperature, the engine oil temperature is between approx. 210 °F/100 °C and approx. 300 °F/150 °C.

If the engine oil temperature is too high, a message appears on the Control Display.

Fuel gauge




Fuel tank capacity: approx. 14.5 US gallons/ 55 liters.

You can find information on refueling on page 192.

If the tilt of the vehicle varies for a longer period, when you are driving in mountainous areas, for example, the indicator may fluctuate slightly.

Reserve

Once the fuel level has fallen to the reserve zone, a message briefly appears on the Control Display and the cruising range for the remaining amount of fuel is displayed on the computer. Under a cruising range of approx. 30 miles/ 50 km, the message remains in the Control Display.

 Refuel as soon as possible once your cruising range falls below 30 miles/ 50 km; otherwise, engine functions are not ensured and damage can occur. ◀

Computer

Displays in the instrument cluster

Calling up information



Press the button in the turn indicator lever.


The following items of information are displayed in the order listed:

- ▷ Cruising range
- ▷ Average speed
- ▷ Average fuel consumption
- ▷ Current fuel consumption*
- ▷ No information

To set the corresponding units of measure, refer to Units of measure on page 68.

Cruising range

Displays the estimated cruising range available with the remaining fuel. The range is calculated on the basis of the way the car has been driven over the last 18 miles/30 km and the amount of fuel currently in the tank.

 Refuel as soon as possible once your cruising range falls below 30 miles/ 50 km; otherwise, engine functions are not ensured and damage can occur. ◀

Average speed

Periods with the vehicle parked and the engine switched off are not included in the calculations of average speed.

With the trip computer, refer to page 67, you can have the average speed for another trip displayed.

To reset average speed: press the button in the turn indicator lever for approx. 2 seconds.

Average fuel consumption

The average fuel consumption is calculated for the time during which the engine is running.

With the trip computer, refer to page 67, you can have the average consumption for another trip displayed.

To reset average fuel consumption: press the button in the turn indicator lever for approx. 2 seconds.

Current fuel consumption

Displays the current fuel consumption. This allows you to see whether your current driving style is conducive to fuel economy with minimum exhaust emissions.

Displays on the Control Display

The computer can also be opened via iDrive.

1. "Vehicle Info"
2. "Onboard info" or "Trip computer"




Displays on the "Onboard info":



- ▷ Cruising range
- ▷ Distance from destination
- ▷ Estimated time of arrival if:
 - ▷ A distance was manually entered into the computer, refer to information below.
 - ▷ A destination was entered in the navigation system*, refer to page 121.

Displays on the "Trip computer":



- ▷ Departure time
- ▷ Trip duration
- ▷ Trip distance

Both displays show:

- ▷ The average speed and
- ▷ the average fuel consumption.

Resetting the fuel consumption and speed

You can reset the values for average speed and average consumption:

1. Select the respective menu item and press the controller.
2. Press the controller again to confirm your selection.

Resetting the Trip computer

1. "Vehicle Info"
2. "Trip computer"
3. "Reset"
4. "Yes"

Entering a distance manually

1. "Vehicle Info"
2. "Onboard info"
3. "To dest."




4. Turn the controller until the desired distance is displayed.
5. Press the controller.

The distance is automatically entered during destination guidance using the navigation system*.

Settings and information


Operating principle



- 1 Button for:
 - ▷ Selecting display
 - ▷ Setting values
- 2 Button for:
 - ▷ Confirming selected display or set values
 - ▷ Calling up computer information [65](#)
- 3 When the lights are on: instrument lighting brightness [91](#)
- 4 Calling up Check Control [73](#)
- 5 Checking engine oil level [202](#)
- 6 Setting the time [71](#)
- 7 Setting the date [72](#)
- 8 Viewing service requirement display [69](#)

Units of measure

1. "Settings"
2. "Language/Units"



3. Select the desired menu item.
4. Select the desired unit.

The settings are stored for the remote control currently in use.


Exiting displays

The outside temperature reading and the time reappear when you press button **2** or if you make no entries within approx. 15 seconds. If required, complete the current setting first.


Service requirements



The remaining driving distance and the date of the next scheduled service are displayed briefly immediately after you start the engine or switch on the ignition.


 The extent of service work required can be read out from the remote control by your BMW Service Advisor. ◀

For certain maintenance operations, you can view the respective distance remaining or due date individually in the instrument cluster.



1. Switch on the ignition, refer to page 50.
2. Push button **1** in the turn indicator lever up or down repeatedly until the appropriate symbol appears in the display, accompanied by the words "SERVICE-INFO".
3. Press button **2**.
4. Use button **1** to scroll through the individual service items.

Possible displays



- 1 Button for selecting functions
- 2 Service requirements
- 3 Engine oil
- 4 Roadworthiness test*
- 5 Front brake pads

- 6 Rear brake pads
- 7 Brake fluid

The sequence of displayed service items may vary. The data for the next service appointment is shown first.

More information

Detailed information on service requirements

More information on the scope of service required can be displayed on the Control Display.

1. "Vehicle Info"
2. "Vehicle status"



3. "Service required"

Required maintenance procedures and legally mandated inspections are displayed.




You can request more detailed information on every entry:

Select the entry and press the controller.

To exit from the menu:

Move the controller to the left.

Symbols

-  No service is currently required.
-  The deadline for service or a legally mandated inspection is approaching. Please schedule a service appointment.
-  The service deadline has already passed.


Entering deadlines for legally required inspections*

Make sure the date on the Control Display is set correctly, refer to page 72; otherwise, the effectiveness of CBS Condition Based Service is not ensured.

1. "Vehicle Info"
2. "Vehicle status"
3. "Service required"



4. "§ Vehicle inspection"



5. Open the menu for entering the deadline.
6. "Date:"
7. Create the settings.
8. Press the controller to apply the setting. The year is highlighted.
9. Turn the controller to make the adjustment.
10. Press the controller to apply the setting. The date entry is stored.

To exit from the menu:

Move the controller to the left.

More information on the BMW Maintenance System can be found on page 206.

Clock

Setting the time

In the instrument cluster


To set the 12h/24h mode, refer to Setting the time format below.




1. Push button **1** in the turn indicator lever up or down repeatedly until the appropriate symbol appears in the display, accompanied by the time and the word "SET".
2. Press button **2**.
3. Use button **1** to set the hours.
4. Press button **2** to confirm the entry.
5. Use button **1** to set the minutes.
6. Press button **2** to confirm the entry.
7. Press button **2**.
The system accepts the new time.

Via iDrive

1. **MENU** Press the button.
The main menu is displayed.




2. "Settings"



Setting the time

1. "Settings"
2. "Time/Date"



3. "Time:"
4. Turn the controller until the desired hours are displayed, and then press the controller.
5. Turn the controller until the desired minutes are displayed, and then press the controller.

The time is stored.

Setting the time format

1. "Settings"
2. "Time/Date"
3. "Format:"
4. Select the desired format and press the controller.

The time format is stored.

The setting is stored for the remote control currently in use, refer also to Personal Profile on page 28.

Date

The settings are stored for the remote control currently in use, refer also to Personal Profile on page 28.

Setting the date

In the instrument cluster

To set the dd/mm or mm/dd date format, refer to Setting the date format below.



1. Push button 1 in the turn indicator lever up or down repeatedly until the appropriate symbol appears in the display, accompanied by the date and the word "SET".
2. Press button 2.
3. Use button 1 to set the day of the month.
4. Press button 2 to confirm the entry.
5. Set the month and the year in the same way.
6. Press button 2. The system stores the new date.

Via iDrive

1. "Settings"
2. "Time/Date"
3. "Date:"
4. Turn the controller until the desired day is displayed, and then press the controller.
5. Create the necessary settings for the month and year.

The date is stored.

Setting the date format

1. "Settings"
2. "Time/Date"
3. "Format:"



4. Select the desired format.
The date format is stored.

Check Control

The concept

The Check Control monitors vehicle functions and alerts you to any malfunctions in the systems monitored. A Check Control message encompasses indicator and warning lamps in the instrument cluster and may include an acoustic signal and text messages on the Control Display.

Indicator and warning lamps



Indicator and warning lamps can light up in a variety of combinations and colors.




⚠ indicates that Check Control messages have been stored. You can view the Check Control messages whenever it is convenient for you.

Explanatory text messages

Text messages at the upper edge of the Control Display explain the meaning of the displayed indicator and warning lamps.

For most Check Control messages, you can view more information later, e.g., regarding the cause of a malfunction and how to respond; refer to the information provided below.



In urgent cases, this information will be shown as soon as the corresponding lamp comes on.


To exit the displayed information:
Move the controller to the left.

Hiding Check Control messages




Press the button in the turn indicator lever.

Some Check Control messages are displayed until the malfunctions have been rectified. They cannot be hidden. If several malfunctions occur at the same time, they are displayed in succession.

 They are marked with the symbol shown here.

Other messages are automatically hidden after approx. 20 seconds, but are kept in memory.

 They are marked with the symbol shown here.

Viewing stored Check Control messages



1. Push button **1** in the turn indicator lever up or down repeatedly until the appropriate symbol appears in the display, accompanied by the words "CHECK CONTROL".
2. Press button **2**. "CHECK OK" appears if there are no Check Control messages. If a Check Control message has been stored, the corresponding lamp comes on. It is accompanied by a text message on the Control Display.

3. Push button **1** to check for other messages.
4. Press button **2**. The display again shows the outside temperature and the time.

Displaying stored Check Control messages

1. **MENU** Press the button.
2. "Vehicle Info"
3. "Vehicle status"
4. "Check Control"



5. Select the text message.

Speed limit

You can enter a speed, and a Check Control message will indicate when you reach this speed. This enables you, for example, to receive warnings if you exceed a speed limit in an urban area.

You are not alerted to having reached this speed again until after your vehicle speed drops below it by at least 3 mph or 5 km/h.

1. "Settings"
2. "Speed"
3. "Warning"



- Turn the controller until the desired limit is displayed.
 - Press the controller.
- The speed limit is stored.

Applying your current speed as the limit


- "Settings"
- "Speed"
- "Select current speed"




- Press the controller.
- The system adopts your current speed as the limit.

Activating/deactivating the limit

- "Settings"
- "Speed"
- "Warning"



- Press the controller.
-  The limit warning is switched on.

Settings on the Control Display

Language on the Control Display

Setting the language

- "Settings"
- "Language/Units"
- "Language:"




- Select the desired language.
- The setting is stored for the remote control currently in use.

Setting the voice dialog

Switch between a standard dialog and a short dialog.

- "Settings"
- "Language/Units"
- "Speech mode:"
- Select the desired dialog.




The setting is stored for the remote control currently in use.

Volume of the warning signals*

You can raise or lower the volume of the warning signals, e.g., the 'Fasten safety belts' reminder, relative to the entertainment sound output. The warning signals have a fixed minimum and maximum volume that cannot be dropped below or exceeded.

1. "Settings"
2. "Tone"
3. "Volume settings"



- ▷ "Speed volume": speed-dependent volume control
- ▷ "PDC": volume of the PDC signal tone relative to the entertainment sound output
- ▷ "Gong": volume of the signal tone, e.g., for the "Fasten safety belts" reminder, relative to the entertainment sound output

Brightness of Control Display

The brightness is automatically adapted to the ambient lighting conditions. However, you can change the basic setting while the low beams are switched on.

1. "Settings"
2. "Control display"
3. "Brightness"



4. Turn the controller until the desired setting is selected.
5. Press the controller.

The setting is stored for the remote control currently in use. In bright conditions, for example, the brightness control may not be clearly visible.


Technology for driving comfort and safety

Park Distance Control PDC*

The concept

The PDC assists you with maneuvering in tight parking spaces. Acoustic signals and a visual indicator warn you of the presence of an object in front of* or behind your vehicle. To measure the distance, there are four ultrasonic sensors in either bumper.

These sensors have a range of approx. 6.5 ft/ 2 m. However, an acoustic warning does not sound until an object is approx. 24 in/60 cm from the corner sensors, or approx. 5 ft/1.50 m from the center sensors.

 PDC is a parking aid that can indicate objects when they are approached slowly, as is usually the case when parking. Avoid approaching an object at high speed; otherwise, physical circumstances may lead to the system warning being issued too late. ◀

Switching on automatically

With the engine running or the ignition switched on, the system is activated after approx. 1 second when you engage reverse gear or move the automatic transmission selector lever to position R. Wait this short period before driving.

Switching off automatically

After approx. 165 ft/50 m of driving or above approx. 20 mph or 30 km/h, the system switches off and the LED goes out.

Signal tones

When nearing an object, its position is indicated correspondingly by an interval tone. As the distance between vehicle and object decreases, the intervals between the tones become shorter. If the distance to the nearest object falls to below roughly 1 ft/30 cm, then a continuous tone sounds.

An interval tone is interrupted after approx. 3 seconds

- ▷ If you remain in front of an object that has been detected by only one of the corner sensors
- ▷ If you are driving parallel to a wall.

Malfunction




The indicator lamp in the instrument cluster comes on. PDC is malfunctioning. A message appears on the Control Display. Have the system checked.

To avoid this problem, keep the sensors clean and free of ice or snow in order to ensure that they will continue to operate effectively. When using a high-pressure cleaner, do not spray the sensors for extended periods of time and only from a distance of at least 12 in/30 cm.

PDC with visual warning

The approach of the vehicle to an object is shown on the Control Display. Objects that are farther away are displayed on the Control Display before a signal tone sounds. The display appears on the Control Display as soon as PDC is activated.

System limitations

 Even with PDC, final responsibility for estimating the distance between the vehicle and any obstructions always remains with the driver. Even when sensors are provided, there is a blind spot in which objects can no longer be detected. The system is also subject to the physical limits that apply to all forms of ultrasonic measurement, such as those encountered with trailer towbars and hitches, thin or wedge-shaped objects, etc. Low objects that have already been displayed, e.g., curbs, can disappear again from the detection area of the sensors before or after a continuous tone sounds. Higher, protruding objects, e.g., ledges, cannot be detected. Therefore, always drive cautiously; otherwise, there is a risk of personal injury or property damage.

Loud sound sources outside or inside the car can drown out the PDC signal. Therefore, always drive cautiously; otherwise, there is a risk of personal injury or property damage. ◀

Driving stability control systems

Your BMW has a number of systems that help to maintain the vehicle's stability even in adverse driving conditions.

Antilock Brake System ABS

ABS prevents locking of the wheels during braking. Safe steering response is maintained even during full braking. Active safety is thus increased.

The ABS is operational every time you start the engine. Braking safely, refer to page 114.

Electronic brake-force distribution

The system controls the brake pressure in the rear wheels to ensure stable braking behavior.

Dynamic Brake Control DBC

When you apply the brakes rapidly, this system automatically produces the maximum braking force boost and thus helps to achieve the shortest possible braking distance during full braking. This system exploits all of the benefits provided by ABS.

Do not reduce the pressure on the brake for the duration of the full braking application.

Dynamic Stability Control DSC

DSC prevents the driving wheels from losing traction when you pull away from rest or accelerate. The system also recognizes unstable driving conditions, for example if the rear of the car is about to swerve or if momentum is acting at an angle past the front wheels. In these cases, DSC helps the vehicle maintain a safe course within physical limits by reducing engine output and through braking actions at the individual wheels.



The laws of physics cannot be repealed, even with DSC. An appropriate driving style always remains the responsibility of the driver. Therefore, do not reduce the additional safety margin again by taking risks, as this could result in an accident. ◀

Deactivating/activating the DSC OFF program

The program can be deactivated via Dynamic Driving Control, refer to DSC OFF.

For better control



The indicator lamp flashes: DSC controls the drive forces and brake forces.

The indicator lamp lights up: DSC has failed.

DTC Dynamic Traction Control

The concept

The DTC system and the TRACTION program are a variant of the DSC in which forward momentum is optimized.

The system ensures maximum forward momentum on special road conditions, e.g., unplowed snowy roads, but driving stability is limited.

It is therefore necessary to drive with appropriate caution.

You may find it useful to briefly activate DTC under the following special circumstances:

- ▷ When driving in slush or on uncleared, snow-covered roads.
- ▷ When rocking the vehicle or driving off in deep snow or on loose surfaces.
- ▷ When driving with snow chains.

Deactivating/activating DTC Dynamic Traction Control

The system and program can be deactivated/activated via Dynamic Driving Control.

Dynamic Driving Control

The concept

Dynamic Driving Control can be used to adjust the driving dynamics of the vehicle. Several programs are available for this purpose; they can be activated using the two Dynamic Driving Control buttons.

The following characteristics are adapted, depending on which program was selected:

- ▷ Engine response.
- ▷ Shift times of the automatic transmission*.
- ▷ Power steering support*.
- ▷ Changes in the suspension characteristics through damping control*.
- ▷ Vehicle stabilization through DSC Dynamic Stability Control.

Operating the programs



- 1 You can activate or deactivate the following programs using this button:
 - ▷ DSC OFF
 - ▷ TRACTION
- 2 You can activate or deactivate the following programs using this rocker switch:
 - ▷ SPORT+
 - ▷ SPORT
 - ▷ NORMAL

DSC OFF



Driving stability is limited during acceleration and when driving in bends.

To increase vehicle stability, activate DSC again as soon as possible.

Activating DSC OFF



Press and hold the button, but not longer than approx. 10 seconds, until the indicator lamp for the DSC lights up in the instrument cluster and DSC OFF is displayed in the instrument cluster.

The DSC system is switched off.

Deactivating DSC OFF



Press the button.

DSC OFF and the DSC indicator lamp go out.

For better control

When DSC is switched off, DSC OFF is displayed in the instrument cluster.



The indicator lamp lights up: DSC is deactivated.

TRACTION

Maximum traction on loose road surfaces. DTC Dynamic Traction Control is switched on. Driving stability is limited during acceleration and when driving in bends.

Activating TRACTION



Press the button.

TRACTION is displayed in the instrument cluster.

The DSC indicator lamp in the instrument cluster lights up.

Deactivating TRACTION



Press the button again.

TRACTION and the DSC indicator lamp go out.

For better control

When DTC is switched on, TRACTION is displayed in the instrument cluster.



The indicator lamp lights up: DTC Dynamic Traction Control is activated.

SPORT+



Sporty driving with a tight suspension and limited driving stabilization.

Dynamic Traction Control is switched on.

The driver handles several of the stabilization tasks.

Activating SPORT+



Press the button repeatedly until SPORT+ appears in the instrument cluster and the DSC indicator lamp lights up.

For better control

SPORT+ is displayed in the instrument cluster.



The indicator lamp lights up: DTC Dynamic Traction Control is activated.

SPORT

Consistently sporty tuning of the suspension for greater driving agility with maximum driving stabilization.

Activating SPORT



Press the button repeatedly until SPORT+ appears in the instrument cluster.

NORMAL

For a balanced tuning with maximum driving stabilization.

Activating NORMAL



Press the button repeatedly until the program display disappears in the instrument cluster.

Displays in the instrument cluster



The selected program is displayed in the instrument cluster.

Drive-off assistant

The drive-off assistant enables you to drive off smoothly on uphill gradients. The parking brake is not required.

1. Hold the car in place by depressing the brake.
2. Release the brake and drive off without delay.



The drive-off assistant holds the car in place for approx. 2 seconds after the brake is released. Drive off without delay after releasing the brake. Because the drive-off

assistant will not hold the car in place after approx. 2 seconds, the car would otherwise start to roll backwards. ◀

Flat Tire Monitor FTM*

The concept

The Flat Tire Monitor detects pressure loss in a tire by comparing the rotating speeds of the individual tires while moving.

In the event of pressure loss, the rolling circumference changes and, thus, the rotating speed of the affected wheel. This change is detected and is reported as a flat tire.

Functional requirement

In order to assure the reliable reporting of a flat tire, the system must be initialized for the correct tire inflation pressure.

▶ The system must be reinitialized each time a tire inflation pressure has been corrected or a wheel or tire has been changed. ◀

System limitations

⚠ The Flat Tire Monitor is unable to warn the driver of sudden, severe tire damage caused by external factors, nor can it identify the gradual loss of pressure that will inevitably occur in all four tires over a lengthy period of time. ◀

In the following situations, the system could be delayed or malfunction:

- ▶ System has not been initialized
- ▶ Driving on snowy or slippery road surface
- ▶ Performance-oriented style of driving: slip in the drive wheels, high lateral acceleration
- ▶ Snow chains are attached

Initializing the system

▶ The initialization is completed during driving, which can be interrupted at any time. When driving resumes, the initialization is continued automatically.

Do not initialize the system while snow chains are attached. ◀

1. "Vehicle Info"
2. "Vehicle status"
3. "Reset"



4. Start the engine - do not drive away.
5. Start the initialization using "Reset".
6. Start to drive.

The initialization is completed during the trip.

The initialization is completed during driving, which can be interrupted at any time.

When driving resumes, the initialization is continued automatically.

Indication of a flat tire

⚠ The warning lamps come on in yellow and red. A message appears on the Control Display. In addition, an acoustic signal sounds. There is a flat tire or substantial loss of tire pressure.

1. Cautiously reduce speed to below 50 mph or 80 km/h. Avoid sudden braking and steering maneuvers. Do not exceed a speed of 50 mph or 80 km/h.


⚠ If the car is not equipped with run-flat tires, refer to page 199, the standard equipment by design, do not continue driving. Otherwise, a severe accident could result if you continue driving. ◀

2. At the next opportunity, check the air pressure in all four tires.

▶ If all four tires are inflated to the correct pressures, the Flat Tire Monitor might not have been initialized. The system must then be initialized. ◀

3. In the event of complete tire pressure loss, 0 psi/0 kPa, you can estimate the possible distance for continued driving on the basis of the following guidelines:

- ▷ With a light load:
 - 1 person without luggage:
approx. 155 miles/250 km
- ▷ With a medium load:
 - 1 person, cargo area full, or 2 people without luggage:
approx. 90 miles/150 km
- ▷ With a full load:
 - 2 people, cargo area full:
approx. 30 miles/50 km

 Drive cautiously and do not exceed a speed of 50 mph or 80 km/h; otherwise, there is a risk of an accident. In the event of pressure loss, vehicle handling changes. This includes reduced tracking stability in braking, extended braking distance and altered natural steering characteristics. If unusual vibration or loud noises occur during the journey, this may be an indication that the damaged tire has finally failed. Reduce your speed and pull over as soon as possible at a suitable location. Otherwise, parts of the tire could come loose, resulting in an accident. Do not continue driving. Instead, contact your BMW center. ◀

Status display

1. "Vehicle Info"
2. "Vehicle status"
3. "Flat Tire Monitor"



The status is displayed.

Tire Pressure Monitor TPM*


The concept

TPM checks the inflation pressures of the four mounted tires. The system notifies you if there is a significant loss of pressure in one or more tires.


Functional requirement

In order to assure the reliable reporting of a flat tire, the system must be reset while all tire inflation pressures are correct.

Always use wheels with TPM electronics. Otherwise, the system may malfunction.

 Each time a tire inflation pressure has been corrected or a wheel or tire has been changed, reset the system. ◀

System limitations

 TPM cannot warn you in advance of sudden severe tire damage caused by outside influences. ◀

The system does not work correctly if it has not been reset; for example, a flat tire may be indicated even though the tire inflation pressures are correct.

The system is inactive and cannot indicate a flat tire if a wheel without TPM electronics, such as a compact spare wheel, has been mounted, or if TPM is temporarily malfunctioning due to other systems or devices using the same radio frequency.

Status indicator on the Control Display

The color of the tires represents the status of the tires and the system.

TPM takes into account that tire pressures change while the vehicle is being driven. The tire pressures do not need to be corrected unless the TPM instructs you to do so by means of color indicators.

Green

The tire inflation pressure corresponds to the established target value.

"TPM active" appears on the Control Display.

One wheel yellow

There is a flat tire or substantial loss of tire pressure in the indicated tire. A message appears on the Control Display.

All wheels yellow

There is a flat tire or substantial loss of tire pressure in several tires. A message appears on the Control Display.

Gray

The system cannot detect a puncture.

Possible reasons for this:

- ▷ TPM is being reset
- ▷ Temporary malfunction caused by systems or devices using the same radio frequency
- ▷ Malfunction

Resetting the system

▷ Each time a tire inflation pressure has been corrected or a wheel or tire has been changed, reset the system. ◀

1. **MENU** Press the button
The start menu is opened.
2. "Vehicle Info"
3. "Vehicle status"
4. "Reset TPM"



5. Start the engine, but do not start driving.
6. Start the initialization using "Reset TPM".
7. Start to drive.
The tires are shown in gray and "Resetting TPM..." is displayed.

After driving a few minutes, the set inflation pressures in the tires are accepted as the target values to be monitored. The system reset is completed during your drive, and can be interrupted at any time. When driving resumes, the reset is continued automatically. On the Control Display, the tires are shown in green and "TPM active" is displayed again.

▷ If a flat tire is detected while the system is resetting and determining the inflation pressures, all tires on the Control Display are displayed in yellow. The message "Low tire!" is shown. ◀

Message for low tire inflation pressure



The warning lamps come on in yellow and red. A message appears on the Control Display. In addition, a signal sounds. There is a flat tire or substantial loss of tire pressure.

1. Cautiously reduce speed to below 50 mph/ 80 km/h. Avoid sudden braking and steering maneuvers. Do not exceed a speed of 50 mph/80 km/h.
▷ If the car is not equipped with run-flat tires, refer to page 199, the standard equipment by design, do not continue driving. Otherwise, a severe accident could result after a tire puncture if you continue driving. ◀
2. In the event of complete pressure loss, 0 psi/0 kPa, you can estimate the possible distance for continued driving on the basis of the following guidelines:
 - ▷ With a light load:
1 person without luggage:
approx. 155 miles/250 km

- ▷ With a medium load:
1 person, cargo area full, or 2 people without luggage:
approx. 95 miles/150 km
- ▷ With a full load:
2 people, cargo area full:
approx. 30 miles/50 km



Drive cautiously and do not exceed a speed of 50 mph/80 km/h. In the event of pressure loss, vehicle handling changes. This includes reduced tracking stability in braking, extended braking distance and altered natural steering characteristics.

If unusual vibration or loud noises occur during the journey, this may be an indication that the damaged tire has finally failed. Reduce your speed and pull over as soon as possible at a suitable location. Otherwise, parts of the tire could come loose, resulting in an accident. Do not continue driving. Instead, contact your BMW center. ◀

Message for unsuccessful system reset



The warning lamp lights up yellow. A message will appear on the Control Display. The system was not reset after a tire was changed, for example.

Check the tire inflation pressure and reset the system, refer to page 83.

Status display

1. **MENU** Press the button
The start menu is opened.
2. "Vehicle Info"
3. "Vehicle status"
4. "TPM"
5. The status is displayed.

Malfunction



The small warning lamp flashes in yellow and then lights up continuously; the larger warning lamp comes on in yellow. On the Control Display,

the tires are shown in gray and a message appears. No punctures can be detected.

This type of message is shown in the following situations:

- ▷ If there is a malfunction
Have the system checked.
- ▷ If a wheel without TPM electronics has been mounted
- ▷ If TPM is temporarily malfunctioning due to other systems or devices using the same radio frequency.

Declaration according to NHTSA/ FMVSS 138 Tire Pressure Monitoring Systems

Each tire should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label. If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label, you should determine the proper tire inflation pressure for those tires. As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system, TPMS, that illuminates a low tire pressure telltale when one or more of your tires are significantly under-inflated. Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly underinflated tire causes the tire to overheat and can lead to tire failure.

Underinflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability. Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if underinflation has not reached the level at which the TPMS low tire pressure telltale illuminates.

The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously lit. This sequence will continue upon subsequent vehicle startups as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be

able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly. Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

Servotronic*

The concept


The Servotronic varies the steering force required to turn the wheels depending on the speed at which you are driving. When you are driving at low speeds, power steering provides more support, i.e. little effort is needed to turn the wheels. Power steering support lessens as your speed increases.

The system works automatically.

Malfunction

Malfunctions are displayed via Check Control.

Dynamic brake lamps*



On the left: normal braking.

On the right: sharp braking.

During sharp braking, the brake lamps and the dynamic brake lamps of your BMW light up.

The dynamic brake lamps are automatically activated if the turn signal is not flashing.


Airbags



The following airbags are located under the marked covers:


- 1 Front airbags
- 2 Side airbags in the seat backrests
- 3 Knee airbag

Protective action

 Observe the adjustment instructions on page 41 to ensure the best possible personal protection. ◀

The front airbags help protect the driver and passenger by responding to frontal impacts in which safety belts alone cannot provide adequate restraint. When needed, the side airbags help provide protection in the event of a side impact. The relevant side airbag supports the head and the side upper body area.

The airbags have been designed to not be triggered in every collision situation, e.g., not in minor accidents or rear-end collisions.

 Do not apply adhesive materials to the cover panels of the airbags, cover them or modify them in any other way.

Keep the dashboard and window on the passenger side clear, i.e., do not cover with adhesive labels or coverings, and do not attach holders such as for navigation instruments and mobile phones.

Do not attach seat covers, cushions or other objects to the front seats that are not specifically approved for seats with integral side airbags. Do not hang items of clothing such as coats or jackets over the backrests.

Do not attempt to remove the airbag retention system from the vehicle. Do not modify the indi-

vidual components of the system or its wiring in any way. This includes the upholstered covers of the steering wheel, the dashboard and the seats. Do not attempt to remove or dismantle the steering wheel.

Do not touch the individual components immediately after the system has been triggered, because there is a danger of burns.

In the event of malfunctions, deactivation or triggering of the airbag restraint system, have the testing, repair, removal and disposal of airbag generators executed only by a BMW center or a workshop that works according to repair procedures of BMW with correspondingly trained personnel and that has the required explosives licenses. Unprofessional attempts to work on the system could lead to failure in an emergency or to undesired airbag activation, either of which could result in personal injury. ◀

Warning notices and information about the airbags can also be found on the sun visors.

Automatic deactivation of the passenger airbags

The system determines whether the passenger seat is occupied by measuring the resistance of the human body. Front, knee and side airbags on the passenger side are activated or deactivated accordingly.

⚠ Make sure that the passenger keeps his or her feet in the footwell; otherwise, the passenger airbags may not function properly. ◀

The indicator lamp above the interior rearview mirror shows the current status of the passenger airbags, deactivated or activated, refer to Status of passenger airbags below.

⚠ Before transporting a child on the front passenger seat, read the safety precautions and handling instructions under Transporting children safely, see page 48.

Malfunction of the automatic deactivation system

The front, knee and side airbags can also be deactivated by adolescents and adults sitting in certain positions; the indicator lamp for the passenger airbags comes on. In such cases, the passenger should change his or her sitting position so that the passenger airbags are activated and the indicator lamp goes out. If the desired airbag status cannot be achieved by changing the sitting position, do not transport the passenger in the vehicle.

To make sure that occupation of the seat cushion can be detected correctly:

- ▷ Do not attach seat covers, seat cushion padding, ball mats or other items to the passenger seat unless they are specifically recommended by BMW.
- ▷ Do not place any items under the seat which could press against the seat from below. ◀

Status of passenger airbags



The indicator lamp for the passenger airbags shows the functional status of the passenger's front, knee and side airbags in accordance with whether and how the passenger seat is occupied. The indicator lamp shows whether the passenger airbags are activated or deactivated.

- ▷ The indicator lamp lights up when a child who is properly seated in a child restraint system intended for that purpose is detected on the seat or the seat is empty. The front, knee and side airbags for the passenger are not activated.

Most child seats are detected by the system, especially child seats required by the NHTSA at the time of vehicle production. After mounting a child seat, ensure that the indicator lamp for the passenger airbag is lit. It indicates that the child seat has been detected and that the passenger airbags are deactivated.

- ▷ The indicator lamp does not come on when, for example, a person of sufficient size and in a correct sitting position is detected on the seat.
The front, knee and passenger airbags for the passenger are activated.


Operational readiness of airbag system



As of radio readiness, refer to page 50, the warning lamp comes on briefly to indicate that the entire airbag system and the belt tensioners are operational.


Airbag system malfunction

- ▷ Warning lamp does not light up at radio readiness or beyond.
- ▷ Warning lamp remains permanently on.

 In the event of a fault in the airbag system, have it checked without delay; otherwise, there is the risk that the system will not function as intended even if a sufficiently severe accident occurs. ◀

Lamps

Parking lamps/low beams




- 0** Lamps off, daytime running lights
- 1** Parking lamps and daytime running lights
- 2** Low-beam headlamps and welcome lamps
- 3** Automatic headlamp control*, daytime running lights, welcome lamps, high-beam assistant* and adaptive light control*

When you open the driver's door with the ignition switched off, the exterior lighting is automatically switched off if the light switch is in position **0**, **2** or **3**.

Switch on the parking lamps if necessary, switch position **1**.

Parking lamps

In switch position **1**, the front, rear and side vehicle lighting is switched on. You can use the parking lamps for parking.

 The parking lamps will discharge the battery. Therefore, do not leave them on for unduly long periods of time; otherwise, the battery might not have enough power to start the engine. It is preferable to switch on the left-hand or right-hand roadside parking lamps, refer to page [90](#). ◀


Low beams

The low beams light up when the light switch is in position **2** and the ignition is on.

Automatic headlamp control*

When the switch is in position **3**, the low beams are switched on and off automatically depending on ambient light conditions, e.g., in a tunnel, in twilight, or if there is precipitation. The adaptive light control* is active. The LED next to the symbol is illuminated when the low beams are on. You can also activate the daytime running lights, refer to page [89](#). In the situations described above, the lamps then automatically switch from daytime running lights to low beams.

The headlamps may also come on when the sun is sitting low on a blue sky.


 The automatic headlamp control cannot serve as a substitute for your personal judgment in determining when the lamps should be switched on in response to ambient lighting conditions. For example, the system cannot detect fog or hazy weather. To avoid safety risks, you should always switch on the low-beam headlamps manually under these conditions. ◀


Welcome lamps

If you leave the light switch in position **2** or **3** when you park the car, the parking lamps and the interior lamps light up briefly when you unlock the vehicle.

Activating/deactivating welcome lamps

1. "Settings"
2. "Lighting"
3. "Welcome light"



 Welcome lamps are activated and are stored for the remote control currently in use.

Pathway lighting

If you activate the headlamp flasher after parking the car, with the lights switched off, the low beams come on and remain on for a certain time.

You can adjust the operating period or deactivate the function.

1. "Settings"
2. "Lighting"
3. "Pathway light.:"
4. Set or deactivate the duration.




The setting is stored for the remote control currently in use.


Daytime running lights

The daytime running lights light up in switch position **0**, **1** and **3**. They are less powerful than the low beams.

Activating/deactivating the daytime running lights

1. "Settings"
2. "Lighting"
3. "Daytime running lamps"



 Daytime running lights are activated and are stored for the remote control currently in use.

Adaptive light control*

The concept

Adaptive light control is a variable headlamp control system that enables better illumination of the road surface. Depending on the steering angle and other parameters, the light from the headlamp follows the course of the road.

Activating adaptive light control

With the ignition switched on, turn the light switch to position **3**, refer to page **88**.

Standstill function*: To avoid blinding oncoming traffic, adaptive light control directs light towards the passenger side when the vehicle is at a standstill.

Malfunction

A message appears on the Control Display. Adaptive light control is malfunctioning or has failed. Have the system checked as soon as possible.

High beams/roadside parking lamps




- 1 High beams
- 2 Headlamp flasher
- 3 Roadside parking lamps*

Roadside parking lamps, left or right*

There is an additional option of switching on the lamps on the side of the car facing the road when parked.

Switching on

After parking the vehicle, press the lever up or down beyond the pressure point for a longer period, arrow 3.

 The roadside parking lamps drain the battery. Therefore, do not leave them on for unduly long periods of time; otherwise, the battery might not have enough power to start the engine. ◀

Switching off

Press the lever in the opposite direction to the pressure point, arrow 3.

High-Beam Assistant*

The concept

This system automatically switches the high beams on and off. The procedure is controlled by a sensor on the front of the interior rearview mirror. The assistant ensures that the high beams are switched on whenever the traffic sit-

uation allows. It handles this task for you and gives you the benefit of the best possible view. You can intervene at any time and switch the high beams on and off as usual.

Activating the system

1. Turn the light switch to position 3, refer to page 88.
2. With the low beams switched on, briefly push the turn indicator lever in the direction of the high beam.




The indicator lamp in the instrument cluster lights up when the high beams are activated. The system automatically switches from high beams to low beams and vice versa in response to oncoming traffic, traffic ahead of you, and adequate ambient lighting, e.g., on city streets.

Switching the high beams on and off manually

Whenever you wish, or when the situation requires, you can intervene:

- ▷ If the high-beam assistant switches on the high beams, but you would like to drive with the low beams, simply switch off the high beams using the turn indicator lever. This deactivates the high-beam assistant. To reactivate the system, briefly push the turn indicator lever toward the high beams again.
- ▷ If the high-beam assistant switches on the low beams, but you would like to drive with the high beams, switch on the high beams as usual. This deactivates the system and the high beams need to be switched off manually, if necessary. To reactivate the system, briefly push the turn indicator lever toward the high beams again.
- ▷ Use the headlamp flasher as usual with the low beams switched on.

System limitations


 The high-beam assistant cannot serve as a substitute for the driver's personal judgment of when to use the high beams. Therefore, manually switch off the high beams in situations where this is required to avoid a safety risk. ◀


The system is not fully functional in situations such as the following, and driver intervention may be necessary:

- ▶ In very unfavorable weather conditions, such as fog or heavy precipitation
- ▶ In detecting poorly-lit road users, such as pedestrians, cyclists, horseback riders and wagons; when driving close to train or ship traffic; and at animal crossings
- ▶ In tight curves, on hilltops or in depressions, in cross traffic or half-observed oncoming traffic on highways
- ▶ In poorly lit towns and cities and in the presence of highly reflective signs
- ▶ At low speeds
- ▶ When the windshield in front of the interior rearview mirror is fogged over, dirty or covered with stickers, etc.
- ▶ If the sensor is dirty. Clean the sensor on the front of the interior rearview mirror using a cloth moistened with a small amount of glass cleaner.

Switching off via iDrive

1. "Settings"
2. "Lighting"
3. "High beam assistant"



 The high-beam assistant is activated and is stored for the remote control currently in use.

Instrument lighting

You can adjust the brightness of the instrument lighting only when the parking lamps or the low beams are switched on.



1. Push button **1** up or down repeatedly until the appropriate symbol appears in the display, accompanied by the brightness setting and scale the word "SET".
2. Press button **2**.




3. Push button **1** up or down to select the desired brightness level.
4. Press button **2**.
The display again shows the outside temperature and the time.

Interior lamps

The interior lamps, footwell lamps*, entry lamps*, cargo area lamp and courtesy lamps* are controlled automatically.

The LEDs for the courtesy lamps are set in the door handles and illuminate the ground in front of the doors.

 To avoid draining the battery, all lamps inside the car are switched off about 8 minutes after the ignition is switched off, refer to Start/stop button on page 50. ◀

Switching interior lamps on/off manually




Interior lighting*:


To switch on and off, press the button.

To switch off the interior lamps, footwell lamps*, entry lamps* and courtesy lamps* permanently, press the button for the front interior lamps for about 3 seconds.

Reading lamps



The reading lamps are located next to the interior lamps. To switch on and off, press the button.



Equipment versions


Depending on the equipment version, your car has an air conditioner or an automatic climate control system.

- 1 Air conditioner [94](#)
- 2 Automatic climate control* [96](#)

Air vents

- 3 Air flow directed toward the windshield and side windows
- 4 Air to the upper body area.
The thumbwheels open and close the air supply continuously. The levers alter the direction of the air flow. For further details on draft-free ventilation refer to page [98](#).
- 5 Air in the knee area, footwell




Air conditioning system



- 1 Air distribution
- 2 Recirculated-air mode
- 3 Cooling function
- 4 Temperature
- 5 Air flow rate
- 6 Rear window defroster

Air distribution



Direct the flow of air to the windows , to the upper body area  or to the knee area and footwell . Intermediate settings are possible. In the 6 o'clock position, a small amount of air is also directed towards the windows in order to keep them from fogging over.

Recirculated-air mode



If the air outside the car has an unpleasant odor or contains pollutants, shut off the supply to the interior of the car temporarily. The system then recirculates the air currently within the vehicle.

You can also activate/deactivate the recirculated-air mode by means of a button* on the steering wheel, refer to page 11.



If condensation starts to form on the inside window surfaces during operation in the recirculated-air mode, you should switch it off while also increasing the air flow rate as required.

The recirculated-air mode should not be used continuously for lengthy periods; otherwise, the quality of the air inside the car will gradually deteriorate. ◀

Air flow rate



Press the corresponding button. The higher the rate, the more effective the heating or cooling will be.

The air flow rate may be reduced or the blower may be switched off entirely to save on battery power.

Switching the system on/off



With the blower at its lowest setting, press the left side of the button. The blower and air conditioner are completely switched off and the air supply is cut off.

To switch on the air conditioner, set the desired air flow rate.

Switching cooling function on/off



The cooling function cools and dehumidifies the incoming air before reheating it as required, according to the temperature setting. This function is only available while the engine is running.

The cooling function helps prevent condensation on the windows or removes it quickly.

Depending on the weather, the windshield may fog over briefly when the engine is started.

Rear window defroster



The defroster switches off automatically after a certain time or when the hardtop is opened.


Temperature



To increase the temperature, turn the rotary switch clockwise towards red.

For a lower temperature, turn the rotary switch counterclockwise towards blue.

Defrosting windows and removing condensation



1. Air distribution **1** in position
2. Deactivate recirculated-air mode **2**.
3. Switch on cooling function **3**.
4. Temperature **4** to the right, red.
5. Set the air flow rate **5** to the maximum level.
6. Switch on rear window defroster **6** to defrost the rear window .

Ventilation



- 1 Use the lever to change the direction of the air flow
- 2 Use the thumbwheels to smoothly open and close the air vents

Ventilation for cooling

Adjust the vent outlets to direct the flow of cool air in your direction, for instance if it has become too hot in the car.


Draft-free ventilation

Set the vent outlets so that the air flows past you and not straight at you.

Microfilter

The microfilter removes dust and pollen from the incoming air. The microfilter is changed by your BMW center during routine maintenance work.

Automatic climate control*



- 1 Temperature, left side of passenger compartment
- 2 Maximum cooling
- 3 Rear window defroster
- 4 Defrosting windows and removing condensation
- 5 Automatic recirculated-air control AUC/ recirculated-air mode
- 6 Air distribution, manual
- 7 AUTO program
- 8 Air flow rate, manual, climate level
- 9 Temperature, right side of passenger compartment
- 10 Switching cooling function on/off manually

Comfortable interior climate

AUTO program **7** offers the ideal air distribution and air flow rate for almost all conditions, refer to AUTO program below. All you need to do is select an interior temperature which is comfortable for you.

The following sections inform you in detail about how to adjust the settings.

Most settings are stored for the remote control currently in use, refer also to Personal Profile settings on page [28](#).

Air distribution, manual

Depending on the selected setting, the air is directed to the windshield, to the upper body area, to the knee area and into the footwell.

Adjusting air distribution manually



Press the button repeatedly until the air distribution is set as required. The corresponding LED lights up.


The manual air distribution is also switched on when the AUTO program is deactivated.

Temperature



Set the desired temperatures individually for the driver's and passenger sides.

The automatic climate control achieves this temperature as quickly as possible regardless of the season, using maximum cooling or heating power if necessary, and then maintains it.

 To give the automatic climate control enough time to achieve the set temperature, do not switch between different temperature settings in quick succession. ◀

You can achieve maximum heating power with the highest setting, regardless of the outside temperature.

The lowest setting effects continuous cooling.

Switching the cooling function on and off



The cooling function cools and dehumidifies the incoming air before reheating it as required, according to the temperature setting. This function is only available while the engine is running.

The cooling function helps prevent condensation on the windows or removes it quickly.

Depending on the weather, the windshield may fog over briefly when the engine is started.

The cooling function is automatically switched on along with the AUTO program.

Maximum cooling



Maximum cooling is achieved most quickly at outside temperatures above 32 °F / 0 °C and when the engine is running.

The automatic climate control goes into recirculated-air mode at the lowest temperature. Air flows at maximum rate from the vents for the upper body area. You should therefore open the vents for maximum cooling.

AUTO program

The AUTO program automatically adjusts the air distribution to the windshield and side windows, towards the upper body area, and into the footwell and knee area.

The air flow rate and air distribution, in addition to your temperature specifications, will be adapted to outside influences as a result of seasonal changes, e.g., sunlight or window condensation.

The cooling is switched on automatically with the AUTO program.

Switching on/off



Press the button.

Manual air distribution and air flow rate are activated when the AUTO program is deactivated.

AUTO program climate level

The climate levels can be used to vary the intensity when the AUTO program is switched on. For example, air flow is adjusted automatically to optimize climate control.



When the AUTO program is switched on, you can select the climate level of the AUTO program using the buttons for controlling the manual air flow rate.

The selected climate level is displayed by an LED.

Convertible program

When the hardtop is open, the convertible program is activated as well. In the convertible program, the automatic climate control is optimized for driving with the hardtop open. In addition, the air flow rate is increased as vehicle speed increases.



The effectiveness of the convertible program can be enhanced considerably by installing the wind deflector. ◀

Adjusting air flow rate manually



Press the left side of the button to reduce air flow. Press the right side of the button to increase it.

The air flow rate may be reduced to save battery power. The display remains the same.

Switching the system on/off

With the blower at its lowest setting, press the left side of the button to switch off the automatic climate control. All displays are cleared except for the rear window defroster if it is switched on.

Press any button except the rear window defroster to reactivate the automatic climate control.

Residual heat

The heat stored in the engine is used to heat the interior.



This function can be switched on using the right button under the following conditions:

- ▷ Up to 15 minutes after the engine has been switched off
- ▷ While the engine is at operating temperature
- ▷ As long as battery voltage is sufficient
- ▷ At an outside temperature below 77 °F / 25 °C


The middle LED is lit when the function is on.

Automatic recirculated-air control AUC/recirculated-air mode



Switch on the desired operating mode by pressing this button repeatedly:

- ▷ LED off: outside air flows in continuously.
- ▷ Left-hand LED on, AUC mode: a sensor detects pollutants in the outside air. If necessary, the system blocks the supply of outside air and recirculates the inside air. As soon as the concentration of pollutants in the outside air has decreased sufficiently, the system automatically switches back to outside air supply.
- ▷ Right-hand LED on, recirculated-air mode: the supply of outside air is permanently shut off. The system then recirculates the air currently within the vehicle.

 If condensation starts to form on the inside window surfaces during operation in the recirculated-air mode, you should switch it off while also increasing the air flow rate as required.

The recirculated-air mode should not be used over an extended period of time; otherwise, the air quality inside the car will deteriorate continuously. ◀

Defrosting windows and removing condensation



Quickly removes ice and condensation from the windshield and front side windows.


Switch on the cooling function as well.

Rear window defroster



The defroster switches off automatically after a certain time or when the hardtop is opened.

Ventilation



- 1 Lever for changing the direction of the air flow.
- 2 Thumbwheels for opening and closing the air vents.
- 3 Thumbwheel for adjusting the amount of cool air from the vents to the upper body area. In this way you can optimize the air temperature for the upper body area.

Ventilation for cooling

Adjust the vent outlets to direct the flow of cool air in your direction, for instance if it has become too hot in the car.

Draft-free ventilation

Set the vent outlets so that the air flows past you and not straight at you.

Microfilter/activated-charcoal filter

The microfilter traps dust and pollen in the incoming air. The activated-charcoal filter provides additional protection by filtering gaseous pollutants from the outside air. Your BMW center replaces this combined filter during routine maintenance.

Practical interior accessories


Integrated universal remote control*

The concept


The integrated universal remote control can replace as many as three hand-held transmitters for various remote-controlled devices, such as garage doors and gates or lighting systems. The integrated universal remote control registers and stores signals from the original hand-held transmitters.

The signal of an original hand-held transmitter can be programmed on one of the three memory buttons **1**. After this, the programmed memory button **1** will operate the system in question. The LED **2** flashes to confirm transmission of the signal.

Should you sell your vehicle one day, be sure to delete the stored programs beforehand for your safety, refer to page [101](#).

 To prevent possible damage or injury, before programming or using the integrated universal remote control, always inspect the immediate area to make certain that no people, animals or objects are within the pivoting or travel range of the device being operated. Comply also with the safety instructions supplied with the original hand-held transmitter. ◀

Checking compatibility

 If this symbol appears on the package or in the instructions supplied with the original hand-held transmitter, you can assume that the radio remote control device will be compatible with the integrated universal remote control.

For additional information, please contact your BMW center or call: 1-800-355-3515.

You can also obtain information on the Internet at:

www.bmwusa.com or

www.homelink.com.

HomeLink is a registered trademark of Johnson Controls, Inc. ◀

Programming




1 Memory buttons

2 LED

Fixed-code hand-held transmitters


1. Switch on the ignition, refer to page [50](#).
2. When starting operation for the first time: press the left and right memory buttons **1** for approx. 20 seconds until the LED **2** flashes rapidly. The three memory buttons are cleared.
3. Hold the original hand-held transmitter at a distance of approx. 4 to 12 in/10 to 30 cm from the memory buttons **1**.

 The required distance between the hand-held transmitter and the memory buttons **1** depends on the system of the respective original hand-held transmitter used. ◀

4. Simultaneously press the transmit key on the original hand-held transmitter and the desired memory button **1** on the integrated universal remote control. The LED **2** flashes slowly at first. As soon as the LED **2** flashes rapidly, release both buttons. If the LED **2** does not flash rapidly after approx. 15 seconds, alter the distance and repeat this step.
5. To program other original hand-held transmitters, repeat steps 3 and 4.


The corresponding memory button **1** is now programmed with the signal of the original hand-held transmitter.

You can operate the device while the ignition is switched on.

 If the device fails to function even after repeated programming, check whether the original hand-held transmitter uses an alternating-code system. To do so, either read the instructions for the original hand-held transmitter or hold down the programmed memory button **1** of the integrated universal remote control. If the LED **2** on the integrated universal remote control flashes rapidly and then remains lit for about two seconds, the original hand-held transmitter uses an alternating-code system. If it uses an alternating-code system, program the memory buttons **1** as described under Alternating-code hand-held transmitters. ◀


Alternating-code hand-held transmitters

To program the integrated universal remote control, consult the operating instructions for the device to be set. You will find information there on the possibilities for synchronization. When programming hand-held transmitters that employ an alternating code, please observe the following supplementary instructions:

 Programming will be easier with the aid of a second person. ◀

1. Park your vehicle within the range of the remote-controlled device.
2. Program the integrated universal remote control as described above in the section Fixed-code hand-held transmitters.
3. Locate the button on the receiver of the device to be set, e.g., on the drive unit.
4. Press the button on the receiver of the device to be set. After step 4, you have approx. 30 seconds for step 5.
5. Press the programmed memory button **1** of the integrated universal remote control three times.

The corresponding memory button **1** is now programmed with the signal of the original hand-held transmitter.


 If you have any questions, please contact your BMW center. ◀

Deleting all stored programs

Press the left and right memory buttons **1** for approx. 20 seconds until the LED **2** flashes rapidly: all stored programs are deleted.

Reassigning individual programs

1. Hold the original hand-held transmitter at a distance of approx. 4 to 12 in/10 to 30 cm from the memory buttons **1**.

 The required distance between the hand-held transmitter and the memory buttons **1** depends on the system of the respective original hand-held transmitter used. ◀
2. Press the desired memory button **1** of the integrated universal remote control.
3. If the LED **2** flashes slowly after approx. 20 seconds, press the transmit key of the original hand-held transmitter. Release both buttons as soon as the LED **2** flashes rapidly. If the LED **2** does not flash rapidly after approx. 15 seconds, alter the distance and repeat this step.

Digital compass*



1 Adjustment button

2 Display

The display shows you the main or secondary compass direction in which you are driving.

Operating principle


You can call up various functions by pressing the adjustment button with a pointed object

such as a pen or similar item. The following adjustment options are displayed one after the other, depending on how long you keep the adjustment button pressed:

- ▷ Press briefly: switch display on/off
- ▷ 3 to 6 seconds: set the compass zone
- ▷ 6 to 9 seconds: calibrate the compass
- ▷ 9 to 12 seconds: set left-hand/right-hand steering
- ▷ 12 to 15 seconds: Setting the language

Setting compass zones

Set the compass zone corresponding to your vehicle's geographic location so that the compass can function correctly; refer to the world map with compass zones.



To set the compass zone, press the adjustment button for approx. 3-4 seconds. The number of the compass zone set is shown in the display.

To change the zone setting, briefly press the adjustment button repeatedly until the display shows the number of the compass zone corresponding to your current location.

The compass is operational again after approx. 10 seconds.

Calibrating the digital compass

The digital compass must be calibrated in the following situations:

- ▷ An incorrect compass direction is shown.
- ▷ The compass direction shown does not change although the direction of travel does.
- ▷ Not all compass directions are shown.

Procedure

1. Make sure that no large metal objects or overhead power lines are in the vicinity of your vehicle and that you have enough space to drive in a circle.
2. Set the currently valid compass zone.
3. Ensure that the retractable hardtop is fully closed.
4. Press the adjustment button for approx. 6-7 seconds to call up C. Drive at least one full circle at a maximum speed of 7 km/h. After the system is calibrated correctly, display C is replaced by the compass directions.
5. Open the retractable hardtop fully and repeat step 4.

Setting right-hand/left-hand steering

Your digital compass is factory-set to right-hand or left-hand steering, in accordance with your vehicle.


Setting the language

You can set the language of the display:

Press the adjustment button for approx. 12-13 seconds. Briefly press the adjustment button again to switch between English, "E", and German, "O".

The setting is automatically saved after approx. 10 seconds.

Glove compartment



Opening

Pull the handle, arrow 2.

The light in the glove compartment comes on.



To prevent injury in the event of an accident while the vehicle is being driven, close the glove compartment immediately after use. ◀

Closing

Fold cover up.


Locking

Lock with a key, arrow 1.



If you hand out the remote control without the integrated key, such as at a hotel, refer to page 28, the glove compartment cannot be unlocked.

USB interface for data transmission



Port for importing and exporting data on a USB device, e.g., music collections, refer to page 158.

Observe the following when connecting:

- ▷ Do not use force when plugging the connector into the USB audio interface.
- ▷ Do not connect devices such as fans or lamps to the USB audio interface.
- ▷ Do not connect a USB hard drive.
- ▷ Do not use the USB interface to recharge external devices.

Center armrest

Storage compartment

The center armrest contains either two cupholders, a compartment or the cover for the snap-in adapter*, depending on the equipment version.

Locking the storage compartment*

When you lock the vehicle from the outside, the storage compartment in the center armrest is locked as well.

Opening



Fold the center armrest up, see arrow.

Connection for external audio device

You can connect an external audio device such as a CD or MP3 player and play audio tracks over the car's loudspeaker system:

- ▷ AUX-IN port, refer to page 163
- ▷ USB audio interface*, refer to page 163

Storage compartments inside the vehicle

The following compartments are available, depending on how your vehicle is equipped:

Compartments* in the doors



To open: fold open the cover.

Compartment* in the center console

There is an open storage compartment in the center console.

Storage compartment* in the partition



To open: pull the handle.




The inserts in the storage compartment can be removed individually.

Removing the storage compartment

The storage compartment can be removed completely to be able to use other inserts, for example.




In the cargo area: Press the handle up and fold the storage compartment completely down.

 For more information on the various inserts available, contact your BMW center. ◀

Lateral storage shelf behind the seats


This space can be used to store briefcases, for example.



 When loading the lateral storage shelf, do not move both seats all the way forward while moving them to their uppermost position and leaning the backrests forward. Otherwise, the seats could hit and damage the seal on the windshield and the sun visor.

Only transport light and small objects on the lateral storage shelf; otherwise, braking maneuvers and swerving may lead to a safety hazard due to objects flying about the passenger compartment. Only transport heavy luggage in the cargo area if it has been appropriately secured. ◀

Cupholders*

 Use lightweight and shatterproof containers and do not transport hot beverages; otherwise, there is an increased risk of injury in the event of the accident. Do not force containers that are too large into the cupholders; otherwise, damage could result. ◀

In the center armrest



The cupholders are located in the center console.

Attachable cupholder*

Attaching to the center console



Mount the cupholder onto the center console so that it snaps into place.

Storing in the glove compartment

Insert the cupholder into the holder in the glove compartment.

Connecting electrical appliances

Sockets

In your BMW, when the engine is running or the ignition is switched on, you can use electrical devices such as a flashlight, car vacuum cleaner, etc., up to approx. 200 watts at 12 volts, as long as one of the following sockets is available. Avoid damaging the sockets by attempting to insert plugs of unsuitable shape or size.

Cigarette lighter socket*

To access the socket: take the cigarette lighter out of the socket.

Under the center armrest

External audio device, refer to page 104.

In the passenger footwell*

A socket is located on the left below the glove compartment.


Cargo area

Depending on your vehicle's equipment, the following storage spaces can be found in the cargo area:

- ▷ Rubber band* for securing light objects
- ▷ Storage compartment

To open: turn the lock to the left, see arrow, and fold the cover up.


Enlarging the cargo area




When the hardtop is closed you can enlarge the cargo area:


To do so, press the cargo area partition **1** upward.

Before opening the hardtop, pull the cargo area partition **1** down until it engages in both guides **2**.

 Before moving the hardtop, ensure that there are no objects on or next to the cargo area partition; otherwise, parts of the hardtop may be damaged. Do not exceed the maximum loading height; refer to the sticker in the cargo area showing a line indicating the maximum height. Do not use force to push down the cargo area partition. ◀

 The retractable hardtop can only be opened if the cargo area partition is in its lowermost position and engaged on both sides. ◀

Through-loading opening with integrated transport bag*

 Always secure transported skis or similar objects with the ski support*; otherwise, they could endanger occupants during braking maneuvers and swerving. ◀

The transport bag lets you transport up to two pairs of standard skis safely and cleanly.

The transport bag can hold skis up to a length of 5.4 ft/1.70 m. When transporting skis that are 5.4 ft/1.70 m in length, the overall capacity of the ski bag is reduced as the bag narrows.

Loading

1. Fold the cover down.



2. In the cargo area: press the tab up and fold the cover down.



3. Undo the fastener and spread out the transport bag between the seats.
4. Insert the latch plate of the retaining strap into the belt buckle under the transport bag.




5. Load the transport bag. The zipper eases access to the stored items.

Only place clean skis in the transport bag. Wrap sharp edges to prevent damage.

Securing cargo




After loading, secure the transport bag and its contents. Tighten the retaining strap on the tensioning buckle for this purpose.


 Secure the transport bag in the manner described; otherwise, it could endanger the car's occupants, e.g., in case of heavy braking or sudden swerving. ◀

To store the transport bag, perform the steps described for loading in reverse order.

Ski support*

 Always secure transported skis or similar objects with the ski support* as they could otherwise endanger occupants during braking maneuvers and swerving. ◀


1. Remove both covers **1** with the screwdriver.



2. Attach the ski support **2** and fold it down, see arrow.

3. Pull the fastener up and attach the rear of the ski.




 Before closing the cargo area, ensure that the luggage compartment lid cannot be damaged by the skis. ◀

Removing the transport bag

The transport bag can be completely removed, e.g., for faster drying or to allow you to use other inserts.



In the cargo area: Press the handle up and fold the transport bag completely down.

 For more information on the various inserts available, contact your BMW center. ◀



Driving tips

This section provides you with information useful in dealing with specific driving and operating conditions.

Things to remember when driving

Break-in period

Moving parts need breaking-in time to adjust to each other. Please follow the instructions below in order to achieve the optimal service life and economy of operation for your vehicle.

Engine and differential

Always obey all official speed limits.

Up to 1,200 miles/2,000 km

Drive at varying engine and road speeds, but do not exceed an engine speed of 4,500 rpm or a road speed of 100 mph/160 km/h.

Do not drive with full-throttle operation, and do not use the transmission's kickdown mode or Launch Control.

After driving 1,200 miles/2,000 km

Engine and vehicle speeds can be gradually increased.

Tires

Due to technical factors associated with their manufacture, tires do not achieve their full traction potential until after an initial break-in period. Therefore, drive cautiously during the first 200 miles/300 km.

Brake system

Brakes require an initial break-in period of approx. 300 miles/500 km to achieve optimized contact and wear patterns between brake pads and rotors. Drive cautiously during this break-in period.

Clutch

The function of the clutch reaches its optimal level only after a distance driven of approx. 300 miles/500 km. During this break-in period, engage the clutch gently.

Following part replacement

The same break-in procedures should be observed if any of the components mentioned above have to be renewed in the course of the vehicle's operating life.

Saving fuel

The fuel consumption of your vehicle depends on several factors. You can lower fuel consumption and the environmental impact by taking certain measures, adjusting your driving style and having the vehicle serviced regularly.

Remove any unneeded cargo

Additional weight increases fuel consumption.

Remove any mounted parts after you have finished using them

Remove additional mirrors and the luggage rack when they are no longer in use. Mounted parts affect the vehicle's aerodynamics and increase fuel consumption.

Close both windows

An open window causes higher air resistance and thus increases fuel consumption.

Check tire inflation pressure regularly

Check the tire inflation pressure at least twice a month and before embarking on a long journey, and correct it if necessary.

Low tire inflation pressure causes higher rolling resistance and thus increases fuel consumption and tire wear.

Set off immediately

Do not let the engine warm up while the car is still standing, but set off immediately at moderate engine speed. This is the fastest way for the cold engine to reach its operating temperature.

Drive defensively

Avoid unnecessary acceleration and braking maneuvers. To do so, keep an adequate distance to the forward vehicle. A defensive and smooth driving style keeps fuel consumption down.

Avoid high engine speeds

Only use first gear when setting off. In second and higher gears, accelerate without hesitation or pauses. When accelerating, shift up before reaching high engine speeds.

When you reach the desired speed, shift into the highest applicable gear and drive with the engine speed as low as possible and at a constant speed.

As a rule: driving at low engine speeds lowers fuel consumption and reduces wear.

Coasting

When approaching a red light, take your foot off the accelerator and coast to a stop in the highest applicable gear.

On a downhill slope, take your foot off the accelerator and coast in a suitable gear.

The fuel supply is interrupted when coasting.

Switch off the engine during lengthy stops

Switch off the engine when stopping for lengthy periods, e.g., at traffic lights, railroad crossings or in traffic congestion. You achieve fuel savings even if standing time is as short as approx. 4 seconds.

Switch off functions you do not need at the moment


Functions such as the air conditioner and the seat or rear window heating draw large amounts of power and consume additional fuel. Especially in city traffic and in stop-and-go driving they have a considerable impact. Therefore, switch these functions off when they are not really needed.

Have the vehicle serviced

Have the vehicle serviced regularly to achieve good economy and a long vehicle life. BMW recommends having the vehicle serviced at a BMW center. Also note the BMW service system, refer to page 206.

General driving notes


Close the luggage compartment lid

 Operate the vehicle only when the luggage compartment lid is closed. Otherwise, exhaust fumes could enter the interior of the vehicle. ◀


If the vehicle must be driven with the luggage compartment lid open:

1. Close all windows.
2. Greatly increase the air volume of the automatic climate control system, refer to page 97.

Hot exhaust system


 In all vehicles, extremely high temperatures are generated in the exhaust system. Do not remove the heat shields installed adjacent to various sections of the exhaust system, and never apply undercoating to them. When driving, standing at idle and while parking, take care to avoid possible contact between the hot exhaust system and any highly flammable materials such as hay, leaves, grass, etc. Such contact could lead to a fire, with the risk of serious personal injuries and property damage. Do not touch hot exhaust tail pipes. Otherwise, there is a risk of burns. ◀

Hydroplaning


 When driving on wet or slushy roads, reduce road speed. If you do not, a wedge of water can form between tires and road surface. This situation, known as hydroplaning, means that the tire can completely lose contact with the road surface, so that neither the car can be steered nor the brake be properly applied. ◀

The risk of hydroplaning increases with declining tread depth on the tires, refer also to Minimum tread depth on page 198.

Driving through water

 Drive through calm water only if it is not deeper than 1 ft/25 cm and at this height no faster than walking speed, up to 6 mph/10 km/h. Otherwise, the vehicle's engine, the electrical systems and the transmission may be damaged. ◀

Use the parking brake on inclines

 On inclines, do not hold the vehicle for a lengthy period using the clutch; use the parking brake instead. Otherwise, greater clutch wear will result. ◀

For more information about the drive-off assistant, refer to page 80.

Braking safely


Your BMW is equipped with ABS as a standard feature. Applying the brakes fully is the most effective way of braking in situations in which this is necessary. Since the vehicle maintains steering responsiveness, you can still avoid possible obstacles with a minimum of steering effort.

Pulsation of the brake pedal, combined with sounds from the hydraulic circuits, indicate that ABS is in its active mode.

Driving in wet conditions


When roads are wet or there is heavy rain, briefly exert gentle pressure on the brake pedal every few miles. Monitor traffic conditions to ensure that this maneuver does not endanger other road users. The heat generated in this process helps dry the pads and rotors. Full braking efficiency will then be available when you need it.

Hills

 To prevent overheating and the resulting reduced efficiency of the brake system, drive long or steep downhill gradients in the gear in which the least braking is required. Even

light but consistent brake pressure can lead to high temperatures, brake wear and possibly even brake failure. ◀

You can increase the engine's braking effect by shifting down, all the way to first gear if necessary. This strategy helps you avoid placing excessive loads on the brake system. Downshifting in manual mode of the automatic transmission, refer to page 54.

 7-gear sport automatic transmission with dual clutch: Never drive with the transmission in neutral or with the engine switched off; otherwise, engine braking action will not be present or there will be no power assistance to the brakes or steering.

Manual transmission: Never drive with the clutch held down, with the transmission in neutral or with the engine switched off; otherwise, engine braking action will not be present or there will be no power assistance to the brakes or steering.

Never allow floor mats, carpets or any other objects to protrude into the area around the pedals; otherwise, pedal function could be impaired. ◀

Corrosion on brake rotors

When the vehicle is driven only occasionally, during extended periods when the vehicle is not used at all, and in operating conditions where brake applications are less frequent, there is an increased tendency for corrosion to form on rotors, while contaminants accumulate on the brake pads. This occurs because the minimum pressure which must be exerted by the pads during brake applications to clean the rotors is not reached.

Should corrosion form on the brake rotors, the brakes will tend to respond with a pulsating effect that even extended application will fail to cure.

When the vehicle is parked

Condensation forms while the automatic climate control is in operation, and then exits under the vehicle. Traces of condensed water under the vehicle are therefore normal.

Before driving into a car wash

General information on caring for your BMW can be found on page 208.

With Comfort Access and automatic transmission

Insert the remote control into the ignition switch.


The engine can be switched off when the selector lever is in position N. Refer also to page 208.


With Comfort Access and 7-gear sport automatic transmission with dual clutch


Insert the remote control into the ignition switch.

The engine can be switched off when the transmission is in position N. Refer also to page 209.

Cargo loading

 To avoid loading the tires beyond their approved carrying capacity, never overload the vehicle. Overloading can lead to overheating and increases the rate at which damage develops inside the tires. This can ultimately result in a sudden blowout. ◀

 Make sure that no liquids are spilled or leak from their containers in the cargo area, as this could result in damage to the vehicle. ◀


 Always position and secure the cargo as described so that it cannot endanger the car's occupants, for example if sudden braking or swerving is necessary.

Never exceed either the approved gross vehicle weight or either of the approved axle loads, refer to page 228, as excessive loads can pose a safety hazard, and may also place you in violation of traffic safety laws.


Heavy or hard objects should not be carried loose inside the car, since they could be thrown around, for example as a result of heavy braking, sudden swerves, etc., and endanger the occupants. ◀

Determining loading limit



1. Locate the following statement on your vehicle's placard*:
 The combined weight of occupants and cargo should never exceed XXX kg or YYY lbs. Otherwise, overloading can result in damage to the vehicle and unstable driving conditions. ◀
2. Determine the combined weight of the driver and passengers that will be riding in your vehicle.
3. Subtract the combined weight of the driver and passengers from XXX kilograms or YYY pounds.
4. The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the YYY amount equals 1,400 lbs and there will be five 150 lbs passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs:
$$1,400 \text{ lbs} \text{ minus } 750 \text{ lbs} = 650 \text{ lbs}$$
5. Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in step 4.
6. If your vehicle will be towing a trailer, part of the load from your trailer will be transferred to your vehicle. Consult the manual for transporting a trailer to determine how this may reduce the available cargo and luggage load capacity of your vehicle.

Load




The permissible load is the sum of the occupants' weights and the weight of the cargo. The greater the weight of the occupants, the less cargo/luggage can be transported.

Stowing cargo

Cargo area

- ▶ Load heavier cargo as far forward as possible, directly behind the cargo area partition, and as low as possible.



- ▶ Cover sharp edges and corners.

⚠ Before opening the hardtop, fold down the cargo area partition. Make sure the cargo area is loaded correctly; otherwise, parts of the hardtop can be damaged, refer to page 38. ◀

Lateral storage shelf

⚠ When storing objects on the lateral storage shelf, do not move both seats all the way forward while moving them to their uppermost position and leaning the backrests forward. Otherwise, the seats could hit and damage the seal on the windshield, the sun visor and the headliner. ◀



Light and small objects can be stored on the lateral storage shelf.

Securing cargo

Cargo area

Secure smaller and lighter items using retaining straps, a cargo area net* or draw straps*.

Lateral storage shelf

You can obtain cargo straps* from your BMW center. Four lashing eyes are provided behind the seats for attaching the cargo straps. Adhere to the information included with the cargo straps.

Lashing eyes on the lateral storage shelf

Top:



Bottom:





Navigation

This chapter describes how you can enter destinations and specify your route so that your navigation system guides you reliably to your destination.

Navigation system*

General information

With the help of satellites, the navigation system is able to ascertain the precise position of the vehicle and guide you reliably to any destination you enter.

⚠ Enter data only when the vehicle is stationary, and always give priority to the applicable traffic regulations in the event of any contradiction between traffic and road conditions and the instructions issued by the navigation system. Failure to take to this precaution can place you in violation of the law and put vehicle occupants and other road users in danger. ◀

Navigation data

General information

Navigation data are stored in the vehicle and can be updated.

Navigation data and authorization codes are available from your BMW center.

Depending on the data volume, a data update may take several hours.


- ▷ The data are updated while you are driving.
- ▷ The update is resumed automatically when a trip is continued after an interruption.
- ▷ All functions are available during the trip.
- ▷ The data are stored in the vehicle.
- ▷ After the update, the system restarts.
- ▷ The medium that holds the navigation data can be removed after the update is completed.

Updating the navigation data

Inserting the navigation DVD

1. Insert the navigation DVD into the DVD player with the labeled side facing up.
2. Follow the instructions on the Control Display.
3. Enter the authorization code of the navigation DVD and change the DVD if needed.

Removing navigation DVD



1. **⏏** Press button 1. The DVD emerges slightly from the drive.
2. Remove the DVD.

Displaying information on the version


1. "Navigation"
2. Open "Options".
3. "Navigation system version": Information on the data version is displayed.

Destination entry

In entering your destination you can select from the following options:

- ▷ Entering a destination manually, see below
- ▷ Selecting destination from the address book, refer to page 123
- ▷ Last destinations, refer to page 124
- ▷ Special destinations, refer to page 124
- ▷ Entering a destination on the map, refer to page 126
- ▷ Selecting a home address, refer to page 124
- ▷ Entering a destination by voice commands*, refer to page 127
- ▷ Destination entry via BMW Assist*, refer to page 125

You can also store a navigation destination on the programmable memory keys, refer to page 21.

 Enter data only when the vehicle is stationary, and always give priority to the applicable traffic regulations in the event of any contradiction between traffic and road conditions and the instructions issued by the navigation system. Otherwise, vehicle occupants and other road users may be endangered. ◀

Entering a destination manually

The system's word-matching principle makes it easier for you to enter the names of streets or towns, refer to page 129. This allows you to enter different spellings and completes your entry automatically, so that stored names can be called up quickly.

1. Press the **MENU** button.
2. "Navigation"

3. "Enter address"



The system also supports you with the following features:


- ▷ If you do not enter a street, the system will guide you to the downtown area of a town or city.
- ▷ You can skip the entry of state/province and locality if the current entries should be retained for your new destination.

Entering a state/province

1. "Navigation"
2. "Enter address"
3. Select "State/Province" or the displayed state/province.

Entering a town/city

1. Select "Town/City/Postal Code" or the displayed town/city.



2. Select letters, if necessary.

To delete letters:

- ▷ To delete individual letters:
Turn the controller to select **⬅**, and then press the controller.
- ▷ To delete all letters:
Turn the controller to select **⬅**, and then press the controller for an extended period.

To enter spaces:

- ▷ Select the **□** symbol.

The list gradually grows smaller each time you enter a new letter.

3. Move the controller to the right.
4. Select the name of the town/city from the list.

If there are several towns/cities with the same name:

1. Change to the list of town/city names.
2. Highlight the town/city: a preview map is displayed.
3. Select the town/city.

Entering the postal code

1. Select "Town/City/Postal Code" or the displayed town/city.
2. Select the **1@+** symbol.
3. Select the digits.
4. Change to the list of postal codes and towns/cities.
5. Highlight the postal code: a preview map is displayed.
6. Select the postal code.

Entering street and intersection

1. Select "Street" or the displayed street.
2. Enter a street and intersection as you would the town/city.

After the street you can also enter the intersection or the house number.

If there are several streets with the same name:


1. Change to the list of street names.
2. Highlight the street: a preview map is displayed.
3. Select the street.

Entering a street without a destination town/city

You can also enter a street without specifying a town/city. In this case, all streets of the same name in the designated state/province are offered. The corresponding town/city is displayed after the street name.

If a town/city has already been entered, you can negate this entry. This could be helpful in instances where the desired street does not exist in the entered town/city because it belongs to another suburb, for example.

1. "Navigation"
2. "Enter address"
3. Select "Street" or the displayed street.
4. Change to the list of street names.
5. Select "In" with the state/province currently displayed.



6. Select the letters.
7. Change to the list of street names.
8. Highlight the street: a preview map is displayed.
9. Select the street.

Entering a house number

You can enter any house number stored in the navigation data for the street.

1. "House number"
2. Select the digits.
3. Change to the list of house numbers.
4. Select a house number or range of house numbers.

Starting destination guidance after entering the destination

1. "Accept destination"
 2. "Start guidance" or "Add as another dest."
- ▷ Set your "Route preference", refer to page 130.
 - ▷ Search for "Points of Interest at loc.", refer to page 124.

Address book


To create contacts, refer to page 182.

Selecting a destination from the address book

1. "Navigation"
2. "Address book"

Contacts with addresses are displayed if these have been checked as destinations.

If the contacts with addresses from the mobile phone are not displayed, they first need to be checked as destinations, refer to page 183.




3. Select a contact from the list or, if necessary, using "A-Z search".
4. If necessary, select "Business address" or "Home address".

Storing a destination in the address book

Store the destination in the address book after entering the destination.

1. Open "Options".
2. "Store as new contact" or "Add to existing contact".



3. Select an existing contact, if available.
4. Select "Business address" or "Home address".
5. Enter "Last name" and, if necessary, "First name".
6. "Store in vehicle"

Storing the position

Your current position can be stored in the address book.

1. "Navigation"
2. Open "Options".
3. "Store position as contact" or "Add position to contact".



- Depending on the selection, select an existing contact from the list or the type of address and enter the last and first name.
- "Store in vehicle"


Editing or deleting an address

- "Navigation"
- "Address book"
- Highlight the entry.
- Open "Options".
- "Edit in Contacts" or "Delete entry".

Using home address as destination

The home address must be stored as a destination. Refer to Specifying a contact as the home address, page 182.

- "Navigation"
- "Address book"
- "Home"



- "Start guidance"

Last destinations

The last destinations are stored automatically. These destinations can be called up and used as a destination for destination guidance.

Opening the last destinations

- "Navigation"
- "Last destinations"



- Select the destination.
- "Start guidance"

Editing a destination

Destinations can be edited, for example, to change the house number of an existing entry.

- "Navigation"
- "Last destinations"
- Highlight the destination.
- Open "Options".
- "Edit destination"


Deleting the last destinations

- "Navigation"
- "Last destinations"
- Highlight the destination.
- Open "Options".
- "Delete entry" or "Delete all last destinations".

Special destinations

You can search for special destinations, e.g., hotels and places of interest, and start destination guidance to this location.

The search can be narrowed by entering the location and type of special destination.

 The scope of information provided depends on the particular set of navigation data you are using. ◀

Opening the search for special destinations

1. "Navigation"
2. "Points of Interest"

Special destination location

Search for a special destination according to its location relative to a locality or route.

1. "Search area"



2. Select the location where the system is to search for the special destination:
 - ▷ "At current location"
 - ▷ "At destination"
 - ▷ "At a different destination"
 - ▷ "Along route"


Special destination category

1. "Category"
2. Select "All" or a specific category, e.g., hotels or restaurants.


Category details

For some special destinations, additional details can be displayed that are available in the navigation data, e.g., Italian-style restaurant.

"Category details"



Starting the search for special destinations


1. "Start search"
2. A list of the special destinations is displayed.
 - ▷ "At current location"
Special destinations are listed according to their distance from the current location and are displayed with a directional arrow pointing to the destination.
 - ▷ "At destination", "At a different destination", "Along route"
Special destinations are listed according to their distance from the location where the search is being performed.
 - ▷ Destinations of the selected category are displayed in the map display as symbols. The display depends on the map scale and the category.
3. Highlight a special destination: The destination is displayed in the preview map.
4. Select the special destination.
5. Select the  symbol.
6. "Start guidance" or "Add as another dest.". If a phone number is available, a connection can be established, if desired.

Destination entry via BMW Assist*

A connection is established to the BMW Concierge service, refer to page 185.

1. "Navigation"
2. "Enter address"
3. Open "Options".
4. "BMW Assist dest. entry"

Entering special destinations by name

1. "Navigation"
2. "Points of Interest"
3. "Name, A-Z search"
4. Enter the letters.
Depending on the distance, the search may take some time. The list can contain a maximum of 100 entries.
5. Change to the list of special destinations.
6. Highlight a special destination: The destination is displayed in the preview map.
7. Select the special destination.
8. Select the  symbol.
9. "Start guidance" or "Add as another dest."

Displaying special destinations in the map

To display symbols of the special destinations in the map:

1. "Navigation"
2. "Map"
3. Open "Options".
4. "Display Points of Interest"



5. Select the settings.

Entering the destination via the map


If you only know the location of the town or street, you can enter the destination using the map.

Opening the map


1. "Navigation"
2. "Map"

A map section is displayed on the Control Display. The map shows the current position of the vehicle.

Selecting the destination

1. Select the  symbol. The interactive map is started.



2. Select the destination with the cross-hairs.
 - ▷ To change the scale: Turn the controller.
 - ▷ To shift the map: move the controller in the required direction.
 - ▷ To shift the map diagonally: move the controller in the required direction and turn it.
3. Press the controller to display additional menu items.
 - ▷ Select the  symbol: "Start guidance" or "Add as another dest."
 - ▷ "Return": return to the map view.
 - ▷ "Find points of interest": the search for special destinations is started.

Specifying the street

If the system cannot recognize a street, it displays a street name in the vicinity or the coordinates of the destination.

Interactive map

In the interactive map, the scale can be adjusted and the visible map section can be shifted. In addition, pressing the controller makes further functions available:



- ▷ Select a symbol and "Start guidance", if necessary.
- ▷ "Exit interactive map"
- ▷ Map display
- ▷ "Display destination"
The map section around the destination is displayed.
- ▷ "Display current location"
The map section around your current location is displayed.
- ▷ "Find points of interest", refer to page 124.

Entering a destination by voice commands*

General information

You can enter a desired destination via the voice activation system. During the destination input, you can switch between voice entry and entry via iDrive at any time. To do so, reactivate the voice activation system if necessary.

You can have the possible commands read aloud via **›Voice commands‹**. ◀

Saying the entries

- ▷ Countries, towns and cities, streets and intersections can be said as whole words or spelled in the system language, refer to page 23.

Example: to enter a destination in a US state as a complete word, the system language must be English.

- ▷ The town/city, street and house number can be said as a single sentence.*
- ▷ Spell the entry if the language region and the system language differ.
- ▷ Say the letters smoothly, and avoid exaggerating the pronunciation and inserting lengthy pauses between the letters.

Entering an address*

1. Press the button on the steering wheel.
2. **›Enter address‹**
3. Wait for a request from the system.
4. Say the town or city, street and house number in a single sentence.
5. Continue making the entry as prompted by the system.
6. If necessary, individually name the separate components of the address, e.g., the town/city.

Entering a town/city


The town/city can be spelled or entered as a complete word*.

The methods of entry depend on the navigation data in use and the country and language settings. ◀

1. **›City‹** or **›Spell city‹**.
2. Wait for the system to prompt you for the town/city.
3. Say the name of the town/city, or name at least the first three letters.

Depending on the entry, up to 20 towns/cities may be suggested.

4. Select a location:
 - ▷ To select a recommended town/city: **›Yes‹**
 - ▷ To select another town/city: **›New entry‹**
 - ▷ To select an entry: e.g., **›Entry 2‹**
 - ▷ To spell an entry: **›Spell city‹**

 Identical-sounding towns/cities that cannot be distinguished by the system are compiled in a separate list and shown as a town/city followed by three dots.

If necessary, select this entry with ›Yes‹. Then select the desired town/city from that list. ◀


The town/city can also be selected from the list via iDrive: Turn the controller until the town/city is selected and press the controller.

Entering a street or intersection


The street or intersection is entered in the same manner as the town/city.

Entering a house number

You can enter house numbers up to 999:


-  1. ›House number‹
2. Say the house number.
3. ›Yes‹ to confirm the house number.
4. "Accept destination"

Starting destination guidance

 ›Start guidance‹

Destination guidance starts immediately.

Adding further intermediate destinations

 ›Add as another destination‹

Further intermediate destinations can be added.

Storing destinations


The destination is automatically added to the list of last destinations.


Planning a trip

New trip

Various intermediate destinations can be entered for a trip.

1. "Navigation"
2. "Map"
3. Move the controller to the left, if necessary.


4. Select the  symbol.
5. "Enter new destination"
6. Select the type of destination entry and enter the intermediate destination.



Entering further intermediate destinations

A maximum of 30 intermediate destinations can be entered for one trip.

1. "Enter new destination"
2. Select the type of destination entry and enter the intermediate destination.



3. Select "Add as another dest.".
4. Select the location where the intermediate destination is to be inserted.

Starting the trip

After all intermediate destinations have been entered:

"Start guidance"

Storing a trip

Up to 30 created trips can be stored in the trip list.

1. Open "Options".
2. "Store trip"

3. Enter the letters.
4. "OK"

The trip is stored in the trip list under the entered name.

Starting a stored trip

1. "Navigation"
2. "Stored trips"
3. Select the desired trip.
4. "Start guidance"

Changing trips

Changing the trip direction

Intermediate destinations can be displayed in reverse order after destination guidance is started.

1. "Map"
2. "Guidance"
3. Open "Options".
4. "Reverse order of trip dest."

Rearranging the intermediate destinations

1. "Map"
2. "Guidance"
3. "Display all trip dest."
4. Select an intermediate destination.
5. "Reposition dest. in the trip"

Deleting an intermediate destination

1. "Map"
2. "Guidance"
3. "Display all trip dest."
4. Select an intermediate destination.
5. "Delete dest. in the trip"

Deleting a trip

1. "Navigation"
2. "Stored trips"
3. Select the desired trip.
4. Open "Options".
5. "Delete all trips" or "Delete trip".

Word-matching principle

The system's word-matching principle makes it easier for you to enter the names of towns or streets. The system runs ongoing checks, comparing your destination entries with the data stored in the vehicle as the basis for instant response. The benefits for you include:

- ▷ Names of towns entered may differ from the official versions if you are using a spelling that is customary in another country.

Example:

Instead of the German spelling "München" you can also enter the English spelling "Munich" or the Italian spelling "Monaco".

- ▷ When you are entering the names of towns and streets the system will complete them automatically as soon as enough letters are available to ensure unambiguous identification.
- ▷ The system offers only those letters for selection of name entries that are stored in the vehicle. Thus, entry of erroneous or unregistered names is impossible.


Destination guidance

Starting destination guidance

1. "Navigation"
2. "Enter address"
3. Select the destination.
4. "Accept destination"
5. "Start guidance"

The route is displayed on the Control Display after it is calculated.

Terminating destination guidance

1. "Navigation"
2. "Map"
3. Select the  symbol.
4. "Stop guidance"

Continuing destination guidance

If the destination was not reached during the last trip, destination guidance can be resumed.

"Resume guidance"

Route criteria

General information


You can influence the calculated route by choosing certain route criteria. You can change the route criteria as often as you like during destination entry or during destination guidance.

The route is planned according to fixed rules. The type of road is taken into account, e.g., whether it is a highway or a winding road. As a result, the routes recommended by the navigation system may not always be the same ones that you would choose based on personal experience.

The settings are stored for the remote control currently in use.

Changing route criteria

1. "Navigation"
2. "Map"
3. "Route preference"
4. Selecting a criterion:
 - ▷ "Fast route": time-optimized route, which is a combination of the shortest possible route and the fastest roads
 - ▷ "Efficient route": optimized combination of the fastest and shortest roads
 - ▷ "Short route": short distance, irrespective of how fast or slow progress will be
 - ▷ "Alternative routes": other suggested alternative routes while destination guidance is active



5. Select additional route criteria, if desired. Where possible, the selected criteria will be avoided on the route.
 - ▷ Avoid highways where possible: "Avoid highways"
 - ▷ Avoid toll roads where possible: "Avoid toll roads"
 - ▷ Avoid ferries where possible: "Avoid ferries"

The setting applies to the current route and to the planning of future routes.


Dynamic destination guidance

"Dynamic guidance" is switched on:

The route is automatically changed in the event of traffic obstructions. The system does not point out traffic obstructions along the original route.

Depending on the type of road and the nature and length of the traffic obstruction, the route can also be calculated so that you travel through the traffic obstruction.

1. "Navigation"
2. Open "Options".
3. "Dynamic guidance"

 If the "Avoid highways", "Avoid toll roads" or "Avoid ferries" route criteria are selected, route calculation may take longer. ◀

Route

General information

Depending on the equipment in your vehicle, various views of the route are available during destination guidance.

- ▷ List of streets and towns/cities
- ▷ Map view, refer to page 132

Displaying a list of the streets or towns/cities on the route

When destination guidance is started, a list of the streets and towns/cities on the route is displayed. The driving distances and traffic bulletins are displayed for each route section.

1. "Navigation"
2. "Route information"
3. Highlight a section.

The section is displayed in the preview map.

Bypassing a section of the route

During destination guidance, you can revise the navigation system's route recommendations to avoid particular stretches of road. Enter the number of miles/kilometers that you want to travel before returning to the original route.

1. "Navigation"
2. "Route information"
3. "New route for:"



4. Turn the controller: enter the desired number of miles.
5. Press the controller.


Resuming the original route

If the route section should no longer be bypassed:

1. "Navigation"
2. "Route information"
3. "Remove blocking"

Gas station recommendations


The remaining range is calculated and gas stations along the route are recommended.



1. "Navigation"
2. "Route information"
3. "Recommended refuel"
A list of gas stations is displayed.
4. Select a gas station.
5. Select the  symbol.
6. "Start guidance" or "Add as another dest."

Destination guidance through voice instructions

Switching voice instructions on/off


Voice instructions can be switched on or off during destination guidance.

1. "Navigation"
2. "Map"
3. Select the  symbol.

Symbol	Meaning
	Voice instructions are switched on
	Voice instructions are switched off

For rapid access, the feature can be stored on a programmable memory key, refer to page 21.


Repeating a voice instruction

1. "Navigation"
2. "Map"
3. Highlight the  symbol.
4. Press the controller twice.

Adjusting the volume of voice instructions*

The volume can be adjusted only while a voice instruction is being issued.

1. Have the last voice instruction repeated, if necessary.
2. Turn the button during the voice instruction to select the desired volume.



The setting is stored for the remote control currently in use.









Map display

Map display

You can have your current position displayed on a map. After starting the destination guidance, the planned route is shown on the map.

1. "Navigation"
2. "Map"

The following functions are directly available in the map display:




Symbol	Function
	Starting/stopping destination guidance
	Switching voice instructions on/off
	Changing route criteria or selecting route alternatives
	Special destinations
	Display traffic bulletins
	Interactive map
	Map view settings
	Changing scale

Information in the map display:

- ▷ Time, entertainment source, sound output, map orientation.
- ▷ Distance from destination, estimated time of arrival, if destination guidance is active.
- ▷ Any traffic obstructions are highlighted in color.

To show/hide the information on the map: Press the controller.


Viewing the map

1. Select the    symbol.
2. Select a setting:
 - ▷ "View facing north"
 - ▷ "View in dir. of travel"
 - ▷ "Perspective view"
 - ▷ "Arrow display"
3. Press the controller.

Changing the map section

- ⊕ Select the interactive map.
 - ▷ To shift the map: move the controller in the required direction.
 - ▷ To shift the map diagonally: move the controller in the required direction and turn it.

Changing scale

1. Select the  symbol.
2. Turn the controller to adjust the scale.

Automatic scaling of the map

In the map view facing north, turn the controller in any direction until AUTO is displayed as the map scale.

The map shows the entire range from your location to the destination.

Settings for the map display


The map is shown on the Control Display.

1. Open "Options".
2. "Settings"
3. Set the optimized map view.
 - ▷ "Day/night mode"
Select and create the necessary settings depending on the light conditions. When the traffic bulletin map is activated, this setting is disregarded.
 - ▷ "Satellite images"
Satellite images* are displayed depending on availability and resolution.
 - ▷ "Perspective view in 3D"
Displays a spatial view. Prominent areas that are contained in the navigation data are displayed on the map in 3D.

- ▷ "Traffic Info map"
The map is optimized for displaying traffic bulletins. Symbols for the special destinations are no longer displayed.

Map view for the split screen display

The map view for the split screen can be selected separately from the main screen.

1. Open "Options".
2. "Split screen"
 The split screen is switched on.
3. Move the controller to the right repeatedly until the split screen content is selected.
4. Select the map view:
 - ▷ "Arrow display"
 - ▷ "Map facing north"
 - ▷ "Map direction of travel"
 - ▷ "Map view with perspective"
 - ▷ "Exit ramp view"

Changing scale

1. Move the controller to the right until the split screen is selected.
2. Turn the controller.

Traffic bulletins*

You can display the traffic bulletins from radio stations that broadcast the TMC (Traffic Message Channel) of a traffic information service. This information from the traffic information service is continuously updated on the basis of measurement data from traffic control centers and information on traffic congestion. During destination guidance, traffic bulletins that are relevant to areas along the route are automatically displayed and taken into account in the route planning. You can open all traffic bulletins manually via iDrive.

The traffic bulletins are shown in the map display.

Real Time Traffic Information End-User Provisions

Certain BMW models equipped with navigation have the capability to display real-time traffic information. If your system has this capability the following additional terms and conditions apply:

An End-User shall no longer have the right to use the Traffic Data in the event that the End-User is in material breach of the terms and conditions contained herein.

A. Total Traffic Network, a division of Clear Channel Broadcasting, Inc. ("Total Traffic Network") holds the rights to the traffic incident data and RDS-TMC network through which it is delivered. You may not modify, copy, scan or use any other method to reproduce, duplicate, republish, transmit or distribute in any way any portion of traffic incident data. You agree to indemnify, defend and hold harmless BMW of North America, LLC. ("BMW NA") and Total Traffic Network, Inrix, Inc (and their affiliates) against any and all claims, damages, costs or other expenses that arise directly or indirectly out of (a) your unauthorized use of the traffic incident data or the RDS-TMC network, (b) your violation of this directive and/or (c) any unauthorized or unlawful activities by you in connection herewith.

B. Total Traffic Network traffic data is informational only. User assumes all risk of use. Total Traffic Network, BMW NA, and their suppliers make no representations about content, traffic and road conditions, route usability, or speed.

C. The licensed material is provided to license "as is," and "where is". Total Traffic Network, including, but not limited to, any and all third party providers of any of the licensed material, expressly disclaims, to the fullest extent permitted by law, all warranties or representations with respect to the licensed material (including, without limitation, that the licensed material will be error-free, will operate without interruption or that the traffic data will be accurate), express,

implied or statutory, including, without limitation, the implied warranties of merchantability, non-infringement fitness for a particular purpose, or those arising from a course of dealing or usage of trade.

D. Neither Total Traffic Network, Inrix, Inc. nor BMW NA will be liable to you for any indirect, special, consequential, exemplary, or incidental damages (including, without limitation, lost revenues, anticipated revenues, or profits relating to the same) arising from any claim relating directly or indirectly to use of the traffic data, and even if Total Traffic Network, Inrix, Inc., or BMW NA are aware of the possibility of such damages. These limitations apply to all claims, including, without limitation, claims in contract and tort (such as negligence, product liability and strict liability). Some states do not allow the exclusion or limitation of incidental or consequential damages, so those particular limitations may not apply to you.

Activating/deactivating reception

1. "Navigation"
2. Open "Options".
3. Activate/deactivate "Receive Traffic Info".


In many metropolitan areas you can receive traffic information broadcast by radio stations. The traffic conditions are monitored by traffic control centers and the traffic information is updated periodically.

During destination guidance, the traffic bulletins relevant to your planned route are automatically shown. Whether destination guidance is active or not, you can have the traffic bulletins displayed in the map view or in the traffic bulletin list.


Traffic bulletins in a list

A list of the traffic bulletins can be opened via the menu or map display.

Opening the traffic bulletins

1. "Navigation"
2. "Map"
3. Move the controller to the left, if necessary.
4. Select the  symbol: "Traffic Info"
First, the traffic bulletins on the planned route are displayed. The traffic bulletins are sorted in the order of their distance from the current vehicle position.
5. Select a traffic bulletin.

Additional information can be displayed for some traffic bulletins:

1. Select the  symbol.
2. Additional information is displayed.
3. Exit the menu:
Move the controller to the left.

Traffic bulletins in the map

When the traffic bulletin map is activated, the Control Display changes to a black and white display. This enables a better view of the traffic bulletins. The day/night mode is disregarded in this setting. The symbols for the special destinations are no longer displayed.

1. "Navigation"
2. "Map"
3. Open "Options".
4. "Settings"
5. "Traffic Info map"

Symbols in the map display

Depending on the scale of the map and the location of the traffic obstruction along the route, the symbols for the traffic obstructions are displayed.


Additional information in the map view

Depending on the map scale, a traffic obstruction's length, direction and impact are displayed on the map using triangles or gray bars along the calculated route.

Filtering of traffic bulletins

You can filter which traffic bulletins are to be displayed by the system:

1. "Navigation"
2. "Map"
3. Open "Options".
4. "Traffic Info categories"
5. Select the desired category.



Traffic bulletins of the selected category are displayed.

- ▷ Traffic bulletins on incidents along the route are always displayed.
- ▷ For your own safety, traffic bulletins that notify you of potentially dangerous situations, such as wrong-way drivers, cannot be hidden.

Traffic bulletins during destination guidance

System response will vary depending on whether or not "Dynamic guidance" is selected, refer to page 131.

During destination guidance, traffic obstructions on the route are taken into consideration. Information on sources of great danger, such as wrong-way drivers, is displayed regardless of the setting.


Displaying traffic obstructions

When the navigation system receives a traffic obstruction message and "Dynamic guidance" is not selected, you will be shown certain information, such as the length of the traffic congestion, when you are approx. 30 miles/50 km away from the traffic obstruction.

The last possible detour exit is indicated just before you reach it.

This information is displayed even if you have called up another application on the Control Display.

Selecting a detour

Select the  symbol: "Detour".

"Dynamic guidance" is activated for the current destination guidance.

Dynamic route planning

When "Dynamic guidance" is selected, the route will be changed automatically in the event of a traffic obstruction. The system will not point out traffic obstructions on the original route.

Depending on the road type and the kind and extent of the traffic obstruction, the newly calculated route may lead through the traffic obstruction.

What to do if...

What to do if...

- ▷ The current position cannot be displayed?
The position is in an unrecognized region, in a poor reception area, or the system is in the process of determining the position. Reception is generally available when you are in the open.
- ▷ Destination guidance does not accept an address without the street name?
A downtown area cannot be determined for the town or city that has been entered. Input any street in the selected town/city and start destination guidance.
- ▷ The destination guidance does not accept a destination?
The destination data are not contained in the navigation data. Choose a destination as close as possible to the original one.
- ▷ The letters for a destination cannot be selected during destination entry?
The stored data do not contain the data of the destination. Select a destination that is as close as possible to the original.
- ▷ The map view is displayed in black and white?
When the traffic bulletin map is activated, the Control Display changes to a black and white display. This enables a better view of the traffic bulletins.
- ▷ Voice instructions are no longer issued before intersections during destination guidance?
The area has not yet been fully recorded, or you have left the recommended route and the system requires a few seconds to calculate a new route suggestion.





Entertainment

Operation of the radio, CD equipment and external audio devices as well as their tone settings are described in this chapter.

On/off and tone

The following audio and video sources share the same control elements and adjustments:


- ▷ Radio
- ▷ CD/DVD player
- ▷ CD/DVD changer*
- ▷ Video*
- ▷ External devices, e.g., MP3 player

Controls

The audio and video sources can be controlled using the:

- ▷ Buttons near the CD/DVD player
- ▷ iDrive
- ▷ Buttons on the steering wheel, refer to page 10
- ▷ Programmable memory keys, refer to page 21
- ▷ Voice activation system

Buttons near the CD/DVD player



- 1** Sound output for entertainment on/off, volume
 - ▷ Press: switch on/off
When the system is switched on, the most recently selected radio station or track is played.
 - ▷ Turn: Adjusting volume
- 2** Ejecting a CD/DVD
- 3** CD/DVD drive

- 4** **FM/AM:** change the radio station waveband
- 5** **MODE:** change the audio and video sources
- 6** Station scan/track search
 - ▷ Change the radio station
 - ▷ Select the track for the CD/DVD player, CD/DVD changer and certain multimedia devices

Switching on/off

In order to switch the entertainment sound output on and off:

Press button **1** next to the CD/DVD player.

This symbol on the Control Display indicates that sound output is switched off.

The sound output is available for approx. 20 minutes after the ignition is switched off. For sound output, switch the unit back on.

Adjusting volume

Turn button **1** next to the CD/DVD player until the desired volume is obtained.

You can also adjust the volume with buttons on the steering wheel, refer to page 10.

Tone control

You can alter various tone settings, e.g., treble and bass or the speed-dependent volume increase.

The tone settings are applied to all audio sources.

The settings are stored for the remote control currently in use.

Treble, bass, balance, fader

- ▷ "Balance": left/right volume distribution
- ▷ "Fader": front/rear volume distribution

Adjustments

1. "CD/Multimedia", "Radio" or "Settings".
2. "Tone"



3. Select the desired tone setting.




4. To adjust: Turn the controller.
5. To store: Press the controller.

Equalizer*

You can set individual sound frequency ranges.

1. "CD/Multimedia", "Radio" or "Settings".
2. "Tone"
3. "Equalizer"
4. Select the desired setting.




5. To adjust: Turn the controller.
6. To store: Press the controller.

Multi-channel playback, surround*

You can choose between stereo and multi-channel playback, surround.

1. "CD/Multimedia", "Radio" or "Settings".
2. "Tone"
3. "Surround"



Multi-channel playback, surround, is simulated when playing back an audio track in stereo.


Surround is automatically activated or deactivated, depending on the audio track selected.

Volume

- ▷ "Speed volume": speed-dependent volume control
- ▷ "PDC"*: volume of the PDC signal tone relative to the entertainment sound output
- ▷ "Gong": volume of the signal tone, e.g., for the "Fasten safety belt" reminder, relative to the entertainment sound output

Adjustments

1. "CD/Multimedia", "Radio" or "Settings".
2. "Tone"
3. "Volume settings"
4. Select the desired volume setting.



5. To adjust: Turn the controller.
6. To store: Press the controller.

Resetting tone settings

You can reset all tone settings to the default setting.


1. "CD/Multimedia", "Radio" or "Settings".
2. "Tone"
3. "Reset"

Radio

Your radio is designed for reception of the following stations:


- ▷ FM and AM
- ▷ HD Radio*
- ▷ Satellite radio*

Selecting a station




Press the button if the sound output is switched off.

1. "Radio"



2. "FM" or "AM"

3. Select the desired station.



The selected station is stored for the remote control currently in use.

Changing stations

Turn the controller and press it

or

◀ ▶ Press the button for the corresponding direction

or

Press the buttons on the steering wheel, refer to page 10.

Selecting a station manually

Station selection using the frequency.

1. "Radio"
2. "FM" or "AM"
3. "Manual"
4. Select the frequency: turn the controller.



To store the station: press the controller for an extended period.

Storing a station

Via iDrive

1. "Radio"
2. "FM" or "AM"
3. Select the desired station.




4. Press the controller for an extended period.
5. Select the desired memory location.

The stations are stored for the remote control currently in use.

Via programmable memory keys

You can also store a station on the programmable memory keys, refer to page 21.

1. Select a station.
2.  Press the desired button for a longer period.


Radio Data System RDS*

In the FM waveband, additional information is transmitted via RDS. If the reception conditions are good, the station names are shown on the Control Display. Where reception is poor or in the event of interference, it may take some time before the station names will appear in the display.

Switching the RDS on/off

1. "Radio"
2. "FM"
3. Open "Options".

4. "RDS"



The setting is stored for the remote control currently in use.

HD Radio*

Many stations broadcast both analog and digital signals. If a digital radio network is available, these stations can be received digitally and thus with better sound quality.

License conditions

HD Radio™ technology is manufactured under license from iBiquity Digital Corp. U.S. and Foreign Patents. HD Radio™ and the HD and HD Radio logos are proprietary trademarks of iBiquity Digital Corp.

Switching digital radio reception on/off

1. "Radio"
2. "FM" or "AM"
3. Open "Options".
4. "HD Radio"

The setting is stored for the remote control currently in use.

 This symbol is displayed when a station is received digitally.

In areas in which the station is not continuously received in digital mode, the playback switches between analog and digital reception. Due to time delayed broadcasting, there may be repetitions or interruptions. In this case, switch off digital radio reception.

Displaying additional information

Some stations broadcast additional information on the current track, such as the name of the artist.

1. Select the desired station.
2. Open "Options".
3. "Station info"

Selecting a substation

1. Select the desired station.
2. Press the controller.
3. Select the substation.

Presets

It is possible to store up to 40 stations.

Calling up a station

1. "Radio"
2. "Presets"
3. Select the desired station.

Storing a station

The station currently selected is stored.

1. "Radio"
2. "Presets"
3. "Store station"



4. Select the desired memory location.

The list of stored stations is stored for the remote control currently in use.

You can also store the stations on the programmable memory keys, refer to page 21.

Deleting a station








1. "Radio"
2. "Presets"
3. Select the desired station.
4. Open "Options".
5. "Delete entry"

Satellite radio*

General information

The channels are offered in predefined packages. The packages must be enabled by telephone.

Navigation bar overview

Symbol	Function
	Changing the list view
	Selecting a category
	Direct channel entry
	Timeshift
	Opening the favorites, opening the My Favorites category
	Managing the favorites
	Traffic Jump

The functions of the navigation bar symbols can also be stored on the programmable memory buttons, refer to page 21.

Managing a subscription

To be able to enable or unsubscribe from the channels, you must have reception. It is usually at its best when you have an unobstructed view of the sky. The channel name is displayed in the status line.

Enabling the channels


The Unsubscribed Channels category contains all disabled channels.

1. "Radio"
2. "Satellite radio"

3.  "Categories"



4. Select the Unsubscribed Channels category.
5. Select the desired channel.
The phone number and an electronic serial number, ESN, are displayed.
6. Select the phone number to have the channel enabled.



You can unsubscribe from the channels again via this phone number.

Unsubscribing from channels

1. "Radio"
2. "Satellite radio"
3. Open "Options"
4. "Manage subscription"



The phone number and an electronic serial number, ESN, are displayed.

5. Call Sirius to unsubscribe from the channels.

Selecting a channel

You can only listen to enabled channels. The selected channel is stored for the remote control currently in use.

Via iDrive

1. "Radio"
2. "Satellite radio"
3. Select "All Channels" or the desired category.
4. Select the desired channel.



Via the button in the area of the CD/DVD player

Press the button for the corresponding direction.

The next channel is selected.

Via direct channel entry

1. "Radio"
2. "Satellite radio"
3. "Select channel"
4. Turn the controller until the desired channel is reached and press the controller.

Storing a channel

1. "Radio"
2. "Satellite radio"
3. If necessary, open "All Channels" or the desired category.
4. Select the desired channel.
5. Press the controller again.
6. Press the controller again to confirm the highlighted channel.



7. Select the desired memory location.

The channels are stored for the remote control currently in use.

You can also store the channels on the programmable memory keys, refer to page 21.


Changing the list view

The list view changes every time the first symbol on the navigation bar is pressed.

Information on the channel is displayed.

Symbol	Function
	Channel name
	Artist
	Track


Selecting a category


1. "Radio"
2. "Satellite radio"
3.  "Categories"
4. Select the desired category.

Timeshift

Approx. one hour of the program being broadcast on the channel currently being listened to is stored in a buffer. The signal must be available. The stored audio track can be played with a delay following the live broadcast. When the buffer is full, the older tracks are overwritten. The buffer is cleared when a new channel is selected.







Opening the timeshift function

1. "Radio"
2. "Satellite radio"
3. Open "Options".
4.  "Replay - Time Shift"
A new panel opens.



- ▶ The red arrow shows the current playback position.
- ▶ The time difference to the live broadcast is displayed next to the buffer bar.
- ▶ If playback is live, "live" is displayed next to the buffer bar.

Timeshift menu

Symbol	Function
	Go to the live broadcast
	Playback/pause
	Next track
	Previous track
	Fast forward
	Reverse

Storing favorites

Up to 30 favorites can be stored in the favorites list. Available favorites are artist, track, game, league and team.


Storing the artist, track or game

It is only possible to store favorites that are currently being broadcast. The channel information must be available.

1. "Radio"
2. "Satellite radio"
3. If necessary, select "All Channels" or the desired category.
4. Select the desired channel.
5. Press the controller again.
6. Select the artist, track or game.

Storing the league or team

Leagues or teams can be added to the favorites from a selection list.

1. "Radio"
2. "Satellite radio"
3.  "Manage favorites"
4. "Add sports information"



5. Select the desired league.
6. Select "Add all teams" or the desired team.

Opening the favorites

When an activated favorite is playing, the following message appears for approx. 20 seconds: "Playing favorite!".

☆☆ Select "Favorites" while the message is being displayed.



The displayed favorite is played.

If there is no message, the system changes to the My Favorites category. All favorites currently being broadcast can be selected from a list.

Managing the favorites

Activating/deactivating the favorites

Favorites can be activated and deactivated globally and individually.

1. "Satellite radio"
2. ☆ "Manage favorites"

3. Select "Activate alert" or the desired favorite.

The setting is stored for the remote control currently in use.

Deleting favorites

1. "Satellite radio"
2. ☆ "Manage favorites"
3. Highlight the desired favorite.
4. Open "Options".
5. "Delete entry"

Traffic Jump

Traffic and weather information for a selected region is broadcast every few minutes.

Selecting a region

1. "Radio"
2. "Satellite radio"
3. Open "Options".
4. "Set Jump"
5. Select the desired region.

The region is stored for the remote control currently in use.

Activating/deactivating the jump

1. "Radio"
2. "Satellite radio"
3. ↻ "Jump to:"

Information for the selected region is broadcast as soon as it is available.

A new panel opens.

Canceling the Traffic Jump: "Cancel".

Symbol	Meaning
↻	Information will be broadcast shortly.
↻	Information is currently being broadcast.

Select one of the symbols to deactivate Traffic Jump.

Automatic update

About twice a year, Sirius performs an update of the channel names and positions. The update takes place automatically and may take several minutes.

Notes

- ▷ Reception may not be available in some situations, such as under certain environmental or topographic conditions. The satellite radio cannot influence this.
- ▷ The signal may not be available in tunnels or underground garages; next to tall buildings; or near trees, mountains or other powerful sources of radio interference.

CD/DVD player and CD/DVD changer*

CD/DVD playback



Inserting a CD/DVD

Insert the CD/DVD into the drive with the printed side up. The CD/DVD is drawn in automatically.

Playback starts automatically if the sound output is on. When playing CDs/DVDs with compressed audio files, it may take several minutes to read in the data, depending on the directory structure.

Playable formats

CD/DVD player

- ▶ DVD: DVD-ROM, DVD-R, DVD+R, DVD-RW, DVD+RW, DVD-R DL, DVD+R DL, DVD audio (video part only), DVD video
- ▶ CD: CD-ROM, CD-R, CD-RW, CD-DA, VCD, SVCD
- ▶ Compressed audio files: MP3, WMA, AAC

CD changer*

- ▶ CD: CD-ROM, CD-R, CD-RW, CD-DA

DVD changer*

- ▶ DVD: DVD-ROM, DVD-R, DVD+R, DVD-RW, DVD+RW, DVD-R DL, DVD+R DL, DVD audio (video part only), DVD video, CD: CD-ROM, CD-R, CD-RW, CD-DA, VCD, SVCD


Starting playback

Via iDrive


Fill the CD/DVD magazine and insert it, refer to page 155.

To start playback if a CD is already located in the player or changer:

1. "CD/Multimedia"





2. "CD/DVD"
3. Select the desired CD or DVD:



Ejecting a CD/DVD

▶ Press the button next to the CD/DVD player. The CD/DVD emerges slightly from the drive.

Symbol	Function
	CD/DVD player
	CD/DVD changer

Audio playback

Selecting a track using the button

◀ ▶ Press the button for the appropriate direction as often as necessary until the desired track is reached.

Selecting a track using iDrive

Audio CDs

1. "CD/Multimedia"
2. "CD/DVD"
3. Select the desired CD or DVD.
4. Select the desired track to begin playback.



CDs/CDs/DVDs with compressed audio files*

Depending on the data, some letters and numbers of the CD/DVD may not be displayed correctly.

1. "CD/Multimedia"
2. "CD/DVD"
3. Select the desired CD or DVD.
4. Select the directory, if necessary.
To change to a higher level directory: Move the controller to the left.



5. Select a track and press the controller.



Displaying information about the track*

If information about a track has been stored, it is displayed automatically:




- ▷ Artist
- ▷ Album title
- ▷ Number of tracks on the CD/DVD
- ▷ Track file name

Random play sequence

The tracks on the current CD/DVD are played once each in random order.

1. "CD/Multimedia"
2. "CD/DVD"
3. Select the desired CD or DVD.
4. Open "Options".


5. "Random"



CDs/DVDs with compressed audio files: the directories and the tracks contained therein are played back in random sequence.

Random mode is switched off if the audio source is changed or the ignition is switched off.

Fast forward/reverse

 Press and hold the button for the corresponding direction.

Automatic repeat*

Selected tracks, directories or CDs/DVDs are repeated automatically.

Video playback*

Country codes


Only DVDs with the code of the home region can be played back; also refer to the information on your DVD.

Code	Region
1	USA, Canada
2	Japan, Europe, Middle East, South Africa
3	Southeast Asia
4	Australia, Central and South America, New Zealand
5	Northwest Asia, North Africa
6	China
0	All regions

Start playback

For your own safety, the video image is only displayed up to approx. 2 mph/3 km/h, and in some market-specific versions only with the parking brake applied.


DVD video

1. "CD/Multimedia"
2. "CD/DVD"
3. Select a DVD with video content.
4.  "DVD menu"



5. Start the DVD via the DVD menu.

VCD/SVCD

1. "CD/Multimedia"
2. "CD/DVD"
3. Select a CD/DVD with video content.
4.  "Select track"











5. Select the desired track.
The CD/DVD is started.

Video menu

To open the Video menu:


1. Turn the controller during playback.
2. Press the controller when "Back" is displayed.

The Video menu is displayed:

Symbol	Function
	Open the DVD menu*
	Start playback
	Pause
	Stop
	Next chapter/next track
	Previous chapter/previous track
	Fast forward
	Reverse

In fast forward/reverse: the speed increases every time the controller is pressed. To stop, start playback.

DVD menu

1. If necessary, turn the controller to open the video menu.
2.  "DVD menu"
The DVD menu is displayed. The display depends on the contents of the DVD.
 - ▶ To select menu items: move and press the controller.
 - ▶ To change to the Video menu: turn the controller and select "Back".

DVD/VCD settings

For some DVDs, settings can only be made via the DVD menu; refer also to the information on your DVD.

Language*

1. Turn the controller during playback.
2. Open "Options".
3. "Audio/language"




4. Select the desired language.

The languages that are available depend on the DVD.

Subtitles*

Subtitles can be selected if they are contained on the DVD.

1. Turn the controller during playback.
2. Open "Options".
3. "Subtitles"
4. Select the desired language or "Do not display subtitles".



Brightness, contrast, color

1. Turn the controller during playback.
2. Open "Options".
3. "Display settings"

4. "Brightness", "Contrast" or "Color"




5. Turn the controller until the desired setting is displayed, and then press the controller.

Zoom

Display the video image on the full screen.

1. Turn the controller during playback.
2. Open "Options".
3. "Additional options"
4. "Zoom mode"



Selecting track

DVD video:

1. Turn the controller during playback.
2. Open "Options".
3. "Additional options"
4. "Select title"
5. Select the desired track.

VCD/SVCD:

1. "Select track"
2. Select the desired track.

Camera angle*


The camera angle depends on the DVD.

1. Turn the controller during playback.
2. Open "Options".
3. "Additional options"
4. "Viewing angle"
5. Select the desired camera angle.

Opening the main menu, back

These functions are not contained on every DVD. Therefore, they may not be available for use.

CD/DVD changer*




The BMW CD/DVD changer for six CDs/DVDs is located in the glove compartment.

Press the lever.

The CD/DVD changer drops down.

To close the CD/DVD changer, fold it back up.


Controls and displays



- 1 Empty CD/DVD compartments
- 2 LEDs on the CD/DVD slot flash when a CD/DVD can be inserted.
- 3 Buttons for the CD/DVD compartments LED lights up when the CD/DVD compartment is filled.
- 4 CD/DVD slot
- 5 Load CD/DVD compartments

Filling the CD/DVD changer


1. **LOAD** Press the button.
The LED on the first empty compartment flashes.
2. Select a different CD/DVD compartment, if needed:
1 ... **6** Press the button.
3. When the LEDs **2** on the CD/DVD slot **4** flash, insert a single CD/DVD in the middle. The CD/DVD is drawn in automatically and placed into the selected CD/DVD compartment.

 Do not insert a CD/DVD until the LEDs **2** on the CD/DVD slot **4** flash, as otherwise the CD/DVD or the CD/DVD changer could be damaged. Do not continue to push on the CD/DVD; this may cause it to jam and prevent it from being able to eject again. ◀

4. To fill additional CD/DVD compartments: Repeat steps 1 to 3.

Filling empty CD/DVD compartments


1. **LOAD** Press the button for a longer period. The LEDs on the empty CD/DVD compartments flash.
2. When the LEDs **2** on the CD/DVD slot **4** flash, insert a single CD/DVD in the middle. The CD/DVD is drawn in automatically and placed into the first empty CD/DVD compartment.


 Do not insert a CD/DVD until the LEDs **2** on the CD/DVD slot **4** flash, as otherwise the CD/DVD or the CD/DVD changer could be damaged. Do not continue to push on the CD/DVD; this may cause it to jam and prevent it from being able to eject again. ◀

3. Wait until the CD/DVD is drawn in.
4. To fill additional CD/DVD compartments: Repeat steps 2 and 3.


After they are inserted, it may take several minutes for the CDs/DVDs to be read in.

Removing the CDs/DVDs individually

1.  Press the button.
2. **1** ... **6** Press a button to select a CD/DVD compartment. The CD/DVD is partially ejected from the CD/DVD changer.
3. Remove the CD/DVD.

 If the CD/DVD is not removed, it is drawn in again after approx. 10 seconds. ◀

Removing all CDs/DVDs

1.  Press the button for a longer period. One after the other, the CDs/DVDs are partially ejected out of the CD/DVD changer.
2. Remove the CDs/DVDs.

Malfunctions


If all LEDs on the CD/DVD changer flash rapidly, the system is malfunctioning.

To correct the malfunction:

1. Press the **LOAD** or **▶** button.
The CD/DVD inserted last is ejected.
2. Remove the CD/DVD.

If the LEDs stop flashing rapidly, the CD/DVD changer is functional again.

Notes

 BMW CD/DVD players and changers are officially designated Class 1 laser products. Do not operate if the cover is damaged; otherwise, severe eye damage can result. Do not use self-recorded CDs/DVDs with labels applied as these can become detached during playback due to heat build-up and can cause irreparable damage to the device.

Only use round CDs/DVDs with a standard diameter of 4.7 in/12 cm and do not play CDs/DVDs with an adapter, e.g., Single-CDs; otherwise, the CDs or the adapter can jam and will no longer eject.

Do not use a combined CD/DVD, e.g., DVD^{Plus}; otherwise, the CD/DVD can jam and will no longer eject. ◀

General malfunctions

BMW CD/DVD changers and players have been optimized for performance in vehicles. In some instances they may be more sensitive to faulty CDs/DVDs than stationary devices would be.

If a CD/DVD cannot be played, first check if it has been inserted correctly.

Humidity

High levels of humidity can lead to condensation on the CD/DVD or the laser's scan lens and temporarily prevent playback.

Malfunctions with individual CDs/DVDs

If malfunctions occur only with particular CDs/DVDs, this may be due to one of the following reasons.

Self-recorded CDs/DVDs

Possible reasons for malfunctions with self-recorded CDs/DVDs are inconsistent data-creation or recording processes, or poor quality or old age of the CD/DVD blank.

Only label CDs/DVDs on the top, with a pen designed for this purpose.

Damage

Avoid leaving fingerprints, as well as dust, scratches or moisture on the CDs/DVDs. Keep CDs/DVDs in protective sleeves or cases. Do not subject CDs/DVDs to temperatures over 122 °F /50 °C, high levels of humidity or direct sunlight.

CDs/DVDs with copy protection

CDs/DVDs are often copy-protected by the manufacturer. This can mean that some CDs/DVDs cannot be played or can only be played to a limited extent.

MACROVISION

This product contains copyrighted technology that is based on multiple registered US patents and the intellectual property of the Macrovision Corporation and other manufacturers. The use of this copy protection must be approved by Macrovision. Media protected by this product - unless otherwise agreed with Macrovision - may only be used for private purposes. Copying of this technology is prohibited.


Music collection


Storing music

The music tracks from CDs, DVDs and USB devices can be stored in the music collection in the vehicle and played from there.

- ▷ Audio CD: tracks are converted into a compressed audio format when they are stored. If available, information on the album, such as the artist, is stored as well.
- ▷ CD/DVD or USB device with compressed audio files: The entire content of the CD/DVD or the USB device is stored in the vehicle as an album. After storing, the tracks and directories can be deleted individually. Files are only stored in the WMA, MP3, and AAC formats.

Tracks with DRM copy protection can be stored in the vehicle but cannot be played back.

 Regularly back up the music data; otherwise, it could be lost if there is a fault on the hard drive. ◀

 Music recognition technology and related data are provided by Gracenote®. Gracenote® is the industry standard in music recognition technology and related content delivery. For more information, please visit www.gracenote.com.


CD and music-related data from Gracenote, Inc., copyright

© 2000-2009 Gracenote. Gracenote Software, copyright 2000-2009 Gracenote. This product and service may practice one or more of the following U.S. Patents: #5,987,525; #6,061,680; #6,154,773, #6,161,132, #6,230,192, #6,230,207, #6,240,459, #6,330,593, and other patents issued or pending. Some services supplied under license from Open Globe, Inc. for U.S. Patent: 6.304.523.

Gracenote and CDDb are registered trade marks of Gracenote. The Gracenote logo, the logo typeface and the "powered by Gracenote" logo are trade marks of Gracenote.

Storing from CDs/DVDs

CDs/DVDs can only be stored from the CD/DVD player.

1. Insert a CD/DVD into the CD/DVD player.
2. "CD/Multimedia"
3. "CD/DVD"
4.  Select the symbol for the CD/DVD player.
5. "Store in vehicle"



The music collection is displayed. The tracks are stored and played back in sequence out of the music collection.

Observe the following during the storage process:

Do not switch back to the CD/DVD player and do not remove the CD/DVD from the CD/DVD player as this will interrupt the storage process. You can switch to the other audio sources without interrupting the storage process. Tracks from the current CD/DVD that have already been stored can be called up.

Interrupting storage


1. "CD/Multimedia"
2. "CD/DVD"
3. "Storing..."



4. "Cancel storing"

The storage process is interrupted and can be continued at any time.

Continuing the storage process

1. "CD/Multimedia"
2. "CD/DVD"
3.  Select the symbol for the CD/DVD player.
4. "Continue storing"

Storage of the CD continues at the beginning of the track at which storage was interrupted.

Album information


During storage, information such as the name of the artist is stored with the track, if this information is available in the vehicle database or on the CD.

To update the database, contact your service center.

Storing from a USB device

To store music, a suitable device must be connected to the USB interface in the glove compartment.

- ▷ Suitable devices: USB mass storage devices, such as USB flash drives or MP3 players with a USB interface.
- ▷ Unsuitable media: USB hard drives, USB hubs, USB memory card readers with multiple inserts, Apple iPod/iPhone.

 It is only possible to store music from a USB device via the USB interface in the glove compartment. ◀

1. Connect the USB device to the USB interface in the glove compartment.
2. "CD/Multimedia"
3. "Music collection"
4. Open "Options".
5. "Music data import/export"
6. "Import music (USB)"



Music, playing

Music search

All tracks for which additional information has been stored can be accessed by the music search. Tracks without additional information can be called up via the corresponding album.

1. "CD/Multimedia"
2. "Music collection"
3. "Music search"



- Select the desired category.



- To select the desired entry:
 - ▶ Open "A-Z search" and enter the desired entry.
 - or
 - ▶ Select the desired entry from the list.
- Select additional categories if desired. The tracks found are listed in alphabetical order. Not all categories need to be selected. For example, to search for all tracks by a certain artist, call up that artist only. All of the tracks by that artist are then displayed.
- "Start play"

Restarting the music search

"New search"

Music search by voice*

For instructions on the voice activation system, refer to page 23.

- Press the button on the steering wheel.
- ›Music search‹
- Open the desired category, e.g., ›Select artist‹.
- Say the desired entry in the list.
- Select additional categories if desired.

To select a track directly:

›Title ...‹

Say the voice command and the name of the desired track in one sentence.

Current playback

The list of tracks that was generated last by the music search or the album selected last.

- "Current playback"



- Select the desired track, if necessary.

Top 50

List of the 50 most frequently played tracks.

- "CD/Multimedia"
- "Music collection"
- "Top 50"
- Select the desired track, if necessary.

Albums

All stored albums, listed in order of their storage dates. Symbols indicate the format.

Symbol	Format
	Audio CD
	Compressed audio files

- "CD/Multimedia"
- "Music collection"
- Select the desired album.




Depending on the album, the tracks or the subdirectories of the album are displayed. The first track is played automatically, if possible.

4. To select tracks, change directories if needed. To go up one level in the directory, move the controller to the left.

Random play sequence

All tracks of the selection are played back in random order.

1. "CD/Multimedia"
2. "Music collection"
3. Open "Options".
4. "Random"



Managing music

Albums

Renaming an album

The name of the album, if available, is automatically entered when the album is stored. If the name is unknown, it can be changed later.

An album cannot be renamed while a track from that album is being played.

1. "CD/Multimedia"
2. "Music collection"
3. Highlight the album.
4. Open "Options".

5. "Rename album"



6. Select the letters individually.

Deleting an album

An album cannot be deleted while a track from that album is being played.

1. "CD/Multimedia"
2. "Music collection"
3. Highlight the album.
4. Open "Options".
5. "Delete album"

Deleting a track and directory

A track cannot be deleted while it is being played back.

A directory cannot be deleted while a track from that directory is being played back.

1. "CD/Multimedia"
2. "Music collection"
3. Highlight the directory or track.
4. Open "Options".
5. "Delete folder" or "Delete track".

Free memory capacity

Display the free memory capacity in the music collection.

1. "CD/Multimedia"
2. "Music collection"
3. Open "Options".
4. "Free memory"


Music collection

Backing up the music collection

The entire music collection can be stored on a USB medium. Make sure there is enough free memory capacity on the USB device.

Depending on the number of tracks, backing up the music collection may take several hours. Therefore, it is best to perform the backup during a long trip.


1. Start the engine.
2. Connect the USB device to the USB interface in the glove compartment.
3. "CD/Multimedia"
4. "Music collection"
5. Open "Options".
6. "Music data import/export"



7. "Backup music on USB"



Restoring the music collection in the vehicle

 When storing from the USB device, the music collection existing in the vehicle is replaced. ◀

1. "CD/Multimedia"
2. "Music collection"
3. Open "Options".
4. "Music data import/export"
5. "Restore music from USB"

Deleting the music collection

1. "CD/Multimedia"
2. "Music collection"
3. Open "Options".
4. "Delete music collection"

External devices

AUX-IN port

You can connect an external audio device, for instance an MP3 player, and play audio tracks over the car's loudspeaker system. You can adjust the tone using iDrive.

Connecting

Lift up the center armrest.



Connection for audio playback:
TRS connector 1/8 in/3.5 mm

To play audio tracks over the car's loudspeaker system, connect the headset or line-out port of the external device to the AUX-IN port.

Starting audio playback

Connect the audio device, switch it on and select a track. Operate the system on the audio device.

Via iDrive


1. "CD/Multimedia"
2. If applicable, "External devices"
3. "AUX front"

Adjusting volume

The volume of the sound output depends on the audio device. If this volume differs markedly from the volume of the other audio sources, it is advisable to adjust the volumes.

1. "CD/Multimedia"
2. If applicable, "External devices"

3. "AUX front"
4. "Volume"



5. To adjust: Turn the controller.
6. To store: Press the controller.

USB audio interface*/ additional connection of the music player in the mobile phone*

It is possible to connect external audio devices/mobile phones. They can be operated via iDrive. Sound is output on the vehicle loudspeakers.

Connection options for external devices

- ▷ Connection via USB audio interface: Apple iPod/iPhone, USB devices, e.g., MP3 player, USB flash drive, or mobile phones that are supported by the USB audio interface.
- ▷ Connection via snap-in adapter*, refer to page 180, when equipped with additional connection of music player in the mobile phone: Apple iPhone/mobile phones. Playback is possible only if no audio device/mobile phone is connected to the USB audio interface.

Due to the large number of different audio devices/mobile phones available on the market, it cannot be ensured that every audio device/mobile phone is operable on the vehicle. Ask about suitable audio devices/mobile phones at your BMW center.

Audio files

Standard audio formats, e.g., MP3, WMA, WAV (PCM) and AAC, and playlists in the M3U format can be played.

Connecting via USB audio interface

Lift up the center armrest.



- 1 AUX-IN port for audio playback:
TRS connector 1/8 in/3.5 mm
- 2 USB interface


Apple iPod/iPhone

To connect the device, use the special cable adapter for the Apple iPod/iPhone, available from your BMW center. The cable adapter is required for a flawless connection.

Connect the Apple iPod/iPhone with the AUX-IN port and USB interface **1** using the cable adapter for the Apple iPod/iPhone.

The Apple iPod/iPhone menu structure is supported by the USB audio interface.

USB device

 To connect the device, use a flexible adapter cable to protect the USB interface and your USB device against physical damage. ◀


Connect the USB device with connector **2** using the flexible adapter cable.

After the device is connected for the first time, the information on all tracks (e.g., artist, type of music) and the playlists are transferred from the USB device to the vehicle. This procedure may take some time. The duration depends on the USB device and the number of tracks.

During transmission, the tracks can be called up via the file directory.


Information from up to four USB devices can be stored in the vehicle, or a total of about 16,000 tracks.

If a fifth USB device is connected or if more than 16,000 tracks are stored, information on existing tracks may be deleted.

 Music tracks with integrated Digital Rights Management (DRM) cannot be played. ◀

Starting audio playback

If the audio device has a device name, the name is displayed.

1. "CD/Multimedia"
2. "External devices"
3. Select the  symbol.
The name of the audio device may appear.



Playback begins with the first track. When an Apple iPhone is connected via the snap-in adapter and an audio device is connected to the AUX-IN port at the same time, the audio signal of the AUX-IN port is played.

Information about the track

If information about a track has been stored, it is displayed automatically:

- ▷ Artist
- ▷ Album title
- ▷ Number of tracks
- ▷ Track file name

Track search


You can call up the tracks using the playlists and information. With USB devices you can also call up tracks using the file directory.

Selection is possible via:

- ▷ Playback lists
- ▷ Information: type of music, artist, album, track
- ▷ Additionally for USB devices: file directory, composer

Tracks are displayed if they have been saved in the Latin alphabet.

Starting the track search

1. "CD/Multimedia"
2. "External devices"
3. Select the  symbol.
The name of the audio device may appear.
4. Select the desired category, "Genre", "Artist".



All entries are displayed in a list. The "A-Z search" can be used to find specific entries.

- ▷ Open "A-Z search" and enter the desired entry.
- ▷ Select the desired entry from the list.

5. Select additional categories if desired.

The tracks found are listed. Not all categories need to be selected. For example, to search for all tracks by a certain artist, call up that artist only. All of the tracks by that artist are then displayed.


6. "Start play"

Restarting a track search

"New search"


Playback lists

To open playback lists.

1. "CD/Multimedia"
2. "External devices"
3. Select the  symbol.
4. "Playlists"

Current playback

List of tracks currently being played.


1. "CD/Multimedia"
2. "External devices"
3. Select the  symbol.
4. "Current playback"

Random play sequence


You can play the tracks in the selected list in random order, e.g., all tracks of a single artist.

1. "CD/Multimedia"
2. "External devices"
3. Open "Options".
4. "Random"

Fast forward/reverse

 Press and hold the button for the corresponding direction.

Notes

 Do not expose the audio device to extreme environmental conditions, e.g., very high temperatures, refer to the operating instructions of the audio device. Otherwise, the audio device may become damaged, which could compromise safety while driving. ◀

Depending on the configuration of the audio files, e.g., bit rates greater than 256 Kbit/s, the files may not play back correctly in every case.

Notes on connecting

- ▷ The connected audio device is supplied with a maximum current of 500 mA, if the device supports this. Therefore, do not connect the device to the power socket in the vehicle.
- ▷ Do not forcibly connect the plug to the USB interface.
- ▷ Do not connect devices such as fans or lamps to the USB audio interface.
- ▷ Do not connect USB hard drives.
- ▷ Do not use the USB audio interface to charge external devices.



Communications

This chapter describes how to use the telephone, BMW Assist and TeleService.

Telephone*

The concept

Your BMW is equipped with a full preparation package mobile phone. After pairing a suitable mobile phone with the vehicle once, you can operate the mobile phone via the iDrive, the buttons on the steering wheel or using voice commands*.

Once a mobile phone has been paired with your vehicle, it is automatically recognized as soon as it is inside the vehicle while the engine is running or the ignition is switched on. You can store the pairing data for up to four mobile phones simultaneously. If several mobile phones are detected at the same time, the mobile phone last paired can be operated via the vehicle.


Using the telephone inside the vehicle

Using the snap-in adapter*

The so-called snap-in adapter, a holder for mobile phones, allows you to charge the mobile phone's battery and connect the mobile phone to your vehicle's outside antenna. This ensures better network reception and consistent reproduction quality. Please contact your BMW center to find out for which mobile phones there are snap-in adapters available.

For your safety

A car phone makes life more convenient in many ways, and can even save lives in an emergency. While you should consult your mobile phone's separate operating instructions for a detailed description of safety precautions and information, we request that you direct your particular attention to the following:

 Only make entries when the traffic situation allows you to do so. Do not hold the mobile phone in your hand while you are driving; use the hands-free system instead. If you do

not observe this precaution, your being distracted can endanger vehicle occupants and other road users. ◀

Suitable mobile phones

Please ask your BMW center which mobile phones with Bluetooth interface are supported by the mobile phone preparation package and which mobile phones are compatible with the snap-in adapter. By virtue of their particular software versions, these mobile phones support the functions described in this Owner's Manual. Malfunctions may occur with other mobile phones.

Operating options

You can operate the mobile phone using:

- ▷ Buttons on the steering wheel, refer to page 10
- ▷ iDrive, refer to page 16
- ▷ Voice commands*, refer to page 178
- ▷ Programmable memory keys, refer to page 21

Avoid operating a mobile phone recognized by the vehicle via the mobile phone's keypad; otherwise, malfunctions may result.


Start-up

Pairing the mobile phone with the vehicle

The following prerequisites must be met:

- ▷ Compatible mobile phone: The mobile phone is supported by the full preparation package mobile phone. You can obtain information on the Internet at: www.bmw.com/bluetooth

- ▷ The mobile phone is ready to operate.
- ▷ Bluetooth is activated in the vehicle, refer to page 173, and on the mobile phone.
- ▷ Depending on the mobile phone, certain settings may be necessary on the mobile phone, e.g., via the following menu items:
 - ▷ Bluetooth switched on
 - ▷ Connection must be allowed without requiring further confirmation
 - ▷ Reconnection
- ▷ Depending on the mobile phone type, the power-saving mode setting, for example, may result in a paired mobile phone not being detected by the vehicle.
- ▷ For pairing purposes, define any 4 to 16-digit number as a Bluetooth passkey, e.g. 25081107. A long and complex number offers the best protection against unauthorized access. This Bluetooth passkey is no longer required after pairing has been successful.
- ▷ The ignition is switched on.

 Pair the mobile phone with the vehicle only when the car is stationary, to avoid endangering the car's occupants and other road users by being distracted. ◀

Switch on ignition

1. Insert remote control all the way into the ignition lock.
2. Switch on ignition without operating the brake or clutch or pressing the start/stop button.

Preparation via iDrive

3. "Telephone"
4. "Bluetooth"
5. "Add new phone"



The Bluetooth name of the vehicle is displayed.

Preparation via the mobile phone

6. Further steps must be carried out with the mobile phone and vary depending on the model. Please refer to your mobile phone's operating instructions, e.g., under the topics of Searching for a Bluetooth device, Linking or Pairing.


The Bluetooth name of the vehicle appears on the mobile phone display.
7. Select the Bluetooth name of the vehicle on the mobile phone display.

Logging in

Depending on your mobile phone, you will see messages, first on the mobile phone display or on the iDrive, requesting you to enter the same Bluetooth passkey previously determined by you.

8. Enter the Bluetooth passkey.

Depending on the mobile phone, you will have approx. 30 seconds to enter your Bluetooth passkey on the mobile phone and the Control Display.



If the pairing was successful, the mobile phone appears at the top of the list of mobile phones.

Following the initial pairing

- ▷ The mobile phone is detected/connected in the vehicle within 2 minutes if the engine is running or the ignition is switched on.
- ▷ As soon as a mobile phone is detected by the vehicle, the phone book entries stored on the SIM card or on your mobile phone are transmitted to the vehicle. This transmission is dependent on your mobile phone, refer to the operating instructions of the mobile phone if necessary, and can take several minutes.
- ▷ Four mobile phones can be paired.
- ▷ Specific settings may be necessary in some mobile phones, e.g., authorization or a secure connection, refer to the mobile phone operating instructions.

If not all phone book entries are displayed:

- ▷ Transfer all phone book entries from the SIM card to the mobile phone, if necessary.
- ▷ Phone book entries with special characters may not be displayed.

Checks to perform if pairing is unsuccessful

- ▷ Is the mobile phone supported by the mobile phone preparation package? You can obtain information on the Internet at: www.bmw.com/bluetooth.
- ▷ Do the Bluetooth passkeys on the mobile phone and vehicle match? The same Bluetooth passkey must be entered on the mobile phone's display and via iDrive.
- ▷ Did it take you more than 30 seconds to enter the Bluetooth passkey? Then repeat the pairing procedure.
- ▷ Are too many Bluetooth devices connected to the mobile phone? If so, delete the connections with other devices on the mobile phone.
- ▷ Is the mobile phone no longer responding? Switch the mobile phone off and on or briefly disconnect the power supply.

- ▷ Repeat the pairing procedure.
- ▷ If all items on the list have been checked and the mobile phone still cannot be paired, please contact Customer Relations.

Connecting a particular mobile phone


If more than one mobile phone is detected by the vehicle, the mobile phone at the top of the list is connected. A different mobile phone can be connected by selecting it.

1. "Telephone"
2. "Bluetooth"
3. Select the desired mobile phone.



Unpairing the mobile phone from the vehicle


1. "Telephone"
2. "Bluetooth"
3. Highlight the mobile phone that is to be unpaired.
4. Open "Options".
5. "Remove phone from list"



The unpaired mobile phone is deleted from the list.


The phone book entries and the lists of stored phone numbers are deleted as well.

Activating/deactivating the Bluetooth link


 The use of Bluetooth technology is not permitted in all countries. Observe all applicable local regulations. Temporarily deactivate the Bluetooth link between the vehicle and the mobile phone, if necessary. If the Bluetooth link is deactivated, you can no longer operate the mobile phone via the vehicle, and other devices with a Bluetooth interface can be used in combination with the mobile phone, e.g., a laptop. ◀

To temporarily deactivate the Bluetooth link between the vehicle and your mobile phone:

1. "Telephone"
2. Open "Options".
3. "Bluetooth"



Adjusting volume



Turn the knob during a call to select the desired volume.

This volume for the hands-free system is maintained, even if the other audio sources are set to minimum volume.

The setting is stored for the remote control currently in use.

Operation via iDrive

You can operate the following functions using iDrive:

- ▷ Accepting/rejecting calls
- ▷ Dialing phone numbers
- ▷ Selecting phone numbers from the phone book
- ▷ Selecting stored phone numbers, e.g., from the list of received calls
- ▷ Ending calls

When the ignition is switched off or in radio readiness, e.g., after taking the remote control out of the ignition switch, you can continue an ongoing call via the hands-free system for several minutes.

Voice quality

If the person you are talking to is having difficulties understanding you, this may be due to excessive background noise. The full preparation package mobile phone can compensate for these noises to a certain extent. To optimize voice quality during a call, we recommend that you:

- ▷ Reduce background noise, e.g., by closing the windows, reducing air flow from the automatic climate control or pointing the open front air vents downward
- ▷ Reduce the volume of the hands-free system.


Requirements

- ▷ The mobile phone's pairing data are stored by the vehicle and the mobile phone is operational.
- ▷ The engine is running or the ignition is switched on.
- ▷ The mobile phone is recognized by the vehicle.

Receiving calls


If you have the phone number of the caller stored in the phone book and the phone number has been transmitted, the name of the entry is displayed.

Accepting a call

Press the  button on the steering wheel

or

"Accept"




Rejecting a call

"Reject"


The caller is diverted to your mailbox if the mailbox was activated.

Ending calls


Press the  button on the steering wheel

or

1. "Telephone"
2. "Active calls"
3. Select an active call.




Dialing phone numbers

1. "Telephone"
2. "Dial number"
3. Select the digits individually.
4.  Select this symbol to establish the connection



or

Press the  button on the steering wheel.

The phone number can also be entered using voice commands*, refer to page 178.

For your phone number to be displayed to the person you are talking to, the display of phone numbers must be enabled by your provider.

Calls with multiple parties

You can switch between calls and connect two calls to a single conference call. This function must be supported by the mobile phone and service provider.

Accepting a call while speaking to another party

This function may need to be enabled by the service provider, and the mobile phone may have to be set up accordingly.

If a second call comes in during an active call, you will hear a call waiting signal.


"Accept"

The call is accepted and the existing call is put on hold.

Establishing a second call

Establish another call during an active call.

1. "Telephone"
2. "Active calls"
3. "Hold"



The existing call is put on hold.

4. Dial the new phone number or select it from a list.

Switching between two calls, toggling


- ▷ Active call: indicated by a red handset
- ▷ Call on hold: indicated by a green handset

To switch to the call on hold, select this handset.

Establishing a conference call

Two calls can be connected to a single telephone conference call.

1. Establish two calls.
2. "Conference call"



When terminating a conference call, both calls are ended.



Phone book

The phone book accesses the contacts* and shows all contacts for which a phone number has been stored. The entries can be selected to make a call.

1. "Telephone"
2. "Phone book"

All contacts with a phone number are displayed. A symbol indicates the storage location of the contacts.



Symbol	Storage location
No symbol	In the vehicle; the address has not been checked as a destination.
	In the vehicle; the address has been checked as a destination.
	Mobile phone

Calling a contact

1. Select the desired contact.
A connection is established immediately if calling contacts with one phone number.
For contacts with several phone numbers:
2. Select the desired phone number.
The connection is established.

Editing a contact

The entries in the contacts can be changed. When a contact from the mobile phone is changed, the changes are not stored on the mobile phone. A copy of the entry is stored in the vehicle.

1. Highlight the contact.
2. Open "Options".
3. "Edit entry"

The contact can be edited.

Redialing

The eight phone numbers dialed last are stored.

Dialing the number via iDrive

1. "Telephone"
2. "Redial"



3. Select the desired entry.
The connection is established.

Deleting entries

1. Highlight an entry.
2. Open "Options".
3. "Delete entry" or "Delete list".

Saving an entry in the contacts

1. Highlight an entry.
2. Open "Options".
3. "Store as new contact" or "Add to existing contact".
4. Select the type of number: "Home", "Business", "Mobile" or "Other".
5. Complete the entries if necessary.
6. "Store in vehicle"

Received calls

The 20 calls that were last received are displayed.

1. "Telephone"
2. "Received calls"



Dialing a number

Select an entry.

The connection is established.

Deleting entries

1. Highlight an entry.
2. Open "Options".
3. "Delete entry" or "Delete list".

Saving an entry in the contacts

1. Highlight an entry.
2. Open "Options".
3. "Store as new contact" or "Add to existing contact".
4. Select the type of number: "Home", "Business", "Mobile" or "Other".
5. Complete the entries if necessary.
6. "Store contact"

Messages

Different types of messages can be displayed:


- ▷ My Info messages from the BMW Assist portal.
- ▷ Messages from BMW Concierge

Displaying messages


1. "Telephone"
2. "Messages"
3. Select the desired message.

My Info

Starting destination guidance:


1. Select the message that contains the desired destination.
2.  "Start guidance" or "Add as another dest."

Dialing the number in the message:

1. Select the message that contains the desired number.
2.  "Call"

Messages from the concierge service


Using the address in destination guidance*:

1. Select the message.
2.  "Start guidance" or "Add as another dest."



3. Start destination guidance, if necessary.

Dialing a phone number:

1. Select the message.
2.  "Call"

Saving an address:

1. Select the message.
2. Open "Options".
3. "Store contact in vehicle"

Deleting messages

1. Select the message to be deleted.
2. Open "Options".
3. "Delete message"

Switching between mobile phone and hands-free system

From mobile phone to hands-free system*

You can continue ongoing calls outside of the vehicle's Bluetooth range via the hands-free system as long as the engine is running or the ignition is switched on. Depending on your mobile phone, the system automatically switches to hands-free mode.

With mobile phones that do not automatically switch to hands-free mode:

Depending on the type of mobile phone you are using, it may be possible to continue the conversation via the hands-free system. Refer to the display on your mobile phone and/or your mobile phone's operating instructions.

From hands-free system to mobile phone

If you are making a call via the hands-free system, it may be possible to continue the call via the mobile phone, depending on your mobile phone model. Refer to the display on your mobile phone and/or your mobile phone's operating instructions.

Alternatively, you can deactivate the Bluetooth link, refer to page 173.

Depending on the type of mobile phone you are using, it may occur that calls are switched from the hands-free system to the mobile phone if reception of the wireless network is poor.

Operation by voice commands*

The concept


- ▷ You can operate your mobile phone without having to take a hand off the steering wheel.
- ▷ Most menu items on the Control Display can be voiced as commands. The voice activation system supports you by making announcements and asking questions.
- ▷ ›...‹ Verbal instructions to use with the voice activation system.

Requirements

The same prerequisites apply as for operation via iDrive, refer to page 173.


Saying commands

Activating voice activation system

1. Briefly press the  button on the steering wheel.
A sound signal indicates that you can say commands.
2. Say the command.


Example: dialing phone numbers


Start the dialog:

 Press the button on the steering wheel.

You say	Voice command response
›Dial number‹	››Please say the number‹‹
For instance, ›123 456 7890‹	Depending on your equipment version: ››123 456 7890. Continue ?‹‹
›Dialing‹	››Dialing number‹‹

Ending/canceling operation by voice commands


Briefly press the  button on the steering wheel
or

 ›Cancel‹.

In dialogs not involving voice commands, i.e., when you are speaking only text, e.g., a name, canceling is possible only via the button on the steering wheel.

Having the possible commands read aloud

The system recognizes specific commands that must be pronounced exactly word for word. You can have the possible commands for any function read aloud to you:


 ›Help‹.

Digits from zero to nine are recognized.

You can say each digit individually or group them into a sequence to accelerate the input.


Using alternative commands

Often there is more than a single command to run a function, e.g.:

 ›Dial name‹ or ›Name‹.

Adjusting the volume of the instructions

You can adjust the volume for the instructions from the system:



Turn the button during an instruction.

This volume for the instructions is maintained, even if the other audio sources are set to minimum volume.

The setting is stored for the remote control currently in use.

Calling

Dialing phone numbers

1. ›Dial number‹.
2. Say the phone number.
For telephone calls abroad, say ›Plus‹ and then the country code.
3. ›Dialing‹.

The connection to the desired subscriber is established.

Correcting phone numbers

After the last spoken sequence of digits has been repeated by the system, you can delete this sequence of digits.

1. ›Correct number‹.
The digits are deleted.

The command ›Correct number‹ can be repeated as often as you like.

Deleting phone numbers

1. ›Delete‹.

All digits entered up to this point are deleted.

Redialing

To redial the phone number dialed last:

1. ›Redial‹.

Voice phone book

A separate voice phone book is needed for operation using voice commands.

The entries must be entered using voice commands and are separate from the memory in the mobile phone. In this case, phone numbers stored on the mobile phone cannot be called up or saved there using voice commands. Up to 50 entries can be set up. An entry always consists of a name and a phone number.

Creating and editing a voice phone book

To store an entry:

An entry always consists of a name and a phone number.

1. ›Save name‹.
2. Say the name.
Saying the name for the voice phone book should not take longer than approx. 2 seconds.
3. Say the phone number after being prompted to do so by the system.
4. To save the phone number:
›Save‹.

To delete an entry:

You can delete any entry from the voice phone book.

1. ›Delete name‹.
The dialog for deleting an entry opens.
2. Say the name when prompted.
3. Confirm the query with ›Yes‹.

To delete all entries:

›Delete phone book‹ deletes all entries in the phone book.

1. ›Delete phone book‹.
The dialog for deleting the phone book opens.
2. Confirm the query with ›Yes‹.
3. Confirm the query again with ›Yes‹.

To read and dial entries:

You can have all entries in your voice phone book read aloud in the order in which they were entered and select a specific entry to establish a connection:

1. ›Read phone book‹.
The dialog for reading the phone book opens.
2. Say ›Dial number‹ when the desired entry is read.

Selecting an entry

The connection to the phone number of the selected entry is established.

1. ›Dial name‹.
The dialog for dialing an entry is opened.
2. Say the name when prompted.
3. Confirm the query with ›Yes‹.

Notes

Notes on Emergency Requests

Do not use the voice activation system to initiate an Emergency Request. In stressful situations, the voice and vocal pitch can change. This can unnecessarily delay the establishment of a telephone connection. Use the SOS button* instead, refer to page 218.

Important for voice commands


For voice commands, bear in mind the following:

- ▶ Say the commands, numbers and letters smoothly and with normal volume, emphasis and speed.

- ▶ Always say commands in the language of the voice activation system.
- ▶ Keep the doors, windows and retractable hardtop closed to prevent interference from outside noise.
- ▶ Avoid ambient noise in the vehicle while speaking.

Inserting/removing the snap-in adapter*


1. Press button 1 and remove the cover.



2. Insert the snap-in adapter at the front and press it downward until it engages.




To remove the snap-in adapter:
Press button 1.




Inserting mobile phone


1. If applicable, remove the protective cap from the mobile phone's antenna connector so that the mobile phone can engage in the snap-in adapter.
2. With its buttons facing upward, slide the mobile phone up towards the electrical contact points and press it downward until it engages.



The mobile phone's battery is charged as soon as the vehicle is in radio readiness or the steering is unlocked.

 To conserve vehicle battery power, you should avoid using the mobile phone when the ignition is switched off. ◀

Removing mobile phone



Press the button.

Contacts*

You can create and edit contacts. The contacts from the mobile phone* are displayed as well if this function is supported by the mobile phone. The addresses can be used as destinations for navigation and the phone numbers can be dialed.

New contact

1. "Contacts"
2. "New contact"



3. If the entry fields are still filled with the previous entries, select "Delete input fields", if necessary.
4. To fill in the entry fields: Select the symbol next to the entry field.



5. Enter the text.




If the vehicle is equipped with a navigation system, it is only possible to enter addresses that are contained in the navigation data in the vehicle. This ensures that destination guidance is possible for all addresses. ◀

6. "Store contact in vehicle"

Specifying a contact as the home address

A contact can be stored as a home address. It is placed at the top of the "My contacts" list.

1. Create a new contact.
2. Open "Options".
3. "Store as home address"



When the home address is deleted, only the content of the home address entry is deleted and not the entry itself.

My contacts



A list of all contacts in the vehicle and on the mobile phone*.

Displaying contacts

"My contacts"



All contacts are listed in alphabetical order. Depending on the number of contacts, an A-Z search is offered. A symbol indicates the storage location of the contacts:

Symbol	Storage location
No symbol	In the vehicle; the address has not been checked as a destination.
	In the vehicle; the address has been checked as a destination.
	Mobile phone*

Displaying the detailed view*

Select the desired contact.
All fields that have been filled in for that contact are displayed.

Selecting a contact as the navigation destination

1. "My contacts"
2. Select the desired contact.
3. Select the desired address.

Contacts from the mobile phone* may contain addresses that do not match the navigation data contained in the vehicle and thus cannot be used for destination guidance. In this case: Manually correct the address.

Checking the address as a destination*

An address that is to be used for destination guidance must match the navigation data contained in the vehicle. An address that is stored on the mobile phone can be matched to the navigation data.

1. Select the desired contact and highlight the address.
2. Open "Options".
3. "Check as destination"
4. Correct and store the address, if necessary.

After an address has been corrected, the contact can be stored in the vehicle. The address is not changed on the mobile phone.


Dialing a phone number*

1. "My contacts"
2. Select the desired contact.
3. Select the desired phone number.

The connection is established.

Editing a contact

1. "My contacts"
2. Select the desired contact.
3. "Edit contact"



4. Change the entries.
5. Move the controller to the left.
6. "Yes"

If a contact from the mobile phone* is edited, the changes are not stored on the mobile phone. A copy of the entry is stored in the vehicle, and only this copy is displayed.

Deleting contacts

Only contacts that are stored in the vehicle are deleted. The contacts on the mobile phone* cannot be deleted.

1. "My contacts"
2. Highlight the contact.
3. Open "Options".
4. "Delete contact" or "Delete all contacts".

BMW Assist*

BMW Assist*

BMW Assist provides a number of different services. For example, the position data of the vehicle can be transmitted to the BMW Assist Response Center when an Emergency Request* is sent.

Many BMW Assist services depend on the contract individually agreed upon.

After your contract has expired, the BMW Assist system will be deactivated by the BMW Assist Response Center without your having to visit a BMW center. After the BMW Assist system has been deactivated, no BMW Assist services will be available. The BMW Assist system can be reactivated by a BMW center after a new contract has been signed.

Requirements

- ▷ The installed BMW Assist system is logged in to a wireless communications network. This network must be capable of transmitting the services.
- ▷ To transmit position data, the vehicle must be able to determine the current position.
- ▷ To activate and update BMW Assist, a GPS signal must be available.
- ▷ The BMW Assist service contract was signed with your BMW center or with the BMW Assist Response Center. The service must have been fully enabled.
- ▷ BMW Assist is activated.

Services offered

- ▷ **Emergency Request:** when you press the SOS button, a connection is established to the BMW Assist Response Center. The BMW Assist Response Center then speaks with you and takes further steps to help you.

- ▷ **Automatic Collision Notification:** under certain conditions, a connection is established to the BMW Assist Response Center after a serious accident. If possible, the BMW Assist Response Center then speaks with you and takes further steps to help you.
- ▷ **Enhanced Roadside Assistance:** BMW Roadside Assistance* can be contacted if assistance is needed in the event of a breakdown. If possible, the vehicle data and position data are transmitted during this call.
- ▷ **Customer Relations:** connection with Customer Relations for information on all aspects of your vehicle.
- ▷ **TeleService:** data on your vehicle's service status or required inspections are transmitted to your BMW center, either automatically before a service due date or when you request a BMW service appointment.
- ▷ **Remote Door Unlock:** the BMW Assist Response Center provides assistance if, for example, the remote control is not available and the vehicle needs to be opened.
- ▷ **Stolen Vehicle Recovery:** after you report that your vehicle was stolen to the police, the BMW Assist Response Center can determine its position.
- ▷ In addition to these services, the optional Convenience Plan offers concierge service and information for route planning, traffic and weather. A limited number of calls can be made via the BMW Assist Response Center with Critical Calling, for example, if the mobile phone is not available or discharged.
Press the SOS button to contact the BMW Assist Response Center.

TeleService*

TeleService supports communication with your BMW center.

- ▷ Data on the vehicle's service requirements can be sent directly to the BMW center. In this way, the BMW center can plan its work in advance. This shortens the duration of the service appointment.
- ▷ In the event of a breakdown, data on the vehicle's condition can be sent directly to Roadside Assistance*.
- ▷ The service varies by country.
- ▷ Connection costs may ensue.
- ▷ Services may be restricted abroad.

Requirements

- ▷ BMW Assist is activated.
- ▷ Wireless reception is available.
- ▷ The engine is running.

Concierge service*

When you call the BMW Assist Concierge, you can obtain information about, for example, restaurants, emergency pharmacy services, gas stations or hotels, as well as receive the corresponding telephone numbers and addresses.

You can then dial a phone number directly or use an address for destination guidance*.

Starting the concierge service

1. "BMW Assist"
2. "Concierge"



3. "Start service"

A voice connection is established to the BMW Concierge.

You are connected to the BMW Concierge service to obtain the required information. You can then have the phone number and address sent to you and, for example, use it for destination guidance in the navigation system. Many hotels can be booked directly through the BMW Concierge. When an information message is received, a list of the received messages is displayed automatically. Open the message via the message list, refer to page 176.

Roadside Assistance

You can call BMW Roadside Assistance* should you require help in the event of a breakdown.

Starting Roadside Assistance

Vehicle not equipped with BMW Assist or TeleService

1. "BMW Assist"
2. "Roadside Assistance"



The Roadside Assistance number is displayed.

3. Select the number. If a mobile phone* is paired, a connection is established to BMW Roadside Assistance.

Vehicle equipped with BMW Assist or TeleService

1. "BMW Assist"
2. "Roadside Assistance"
3. "Start service"



TeleService Diagnosis*

TeleService Diagnosis enables the wireless transmission of detailed vehicle data that are important for vehicle diagnosis. TeleService Diagnosis can be started after a prompt by Roadside Assistance and termination of the voice connection.

TeleService Help*

TeleService Help enables an in-depth diagnosis of the vehicle by Roadside Assistance via wireless transmission. TeleService Help can be started after a prompt by Roadside Assistance and termination of the voice connection.

Starting TeleService Help

1. Park the vehicle in a safe place.
2. Set the parking brake.
3. The engine is running.
4. "TeleService Help"

After completion of TeleService Help, a voice connection is established to Roadside Assistance.

Activating BMW Assist*

If the services included in a valid BMW Assist subscription are not displayed, they may need to be activated.

1. Make sure that the vehicle can determine its current position. Reception is usually best when you have an unobstructed view to the sky.
2. Switch on the ignition.
3. "Activate BMW Assist"

Activation may take several minutes. If another menu is opened, activation continues running in the background.

BMW Search*

BMW Search is an online portal that makes certain services available for use in your vehicle, e.g., information on restaurants along your route.

License conditions:

This product contains NetFront Browser Software of ACCESS Co., Ltd. Copyright © 2007 ACCESS Co., Ltd. All rights reserved. NetFront is a trademark or registered trademark of ACCESS CO., LTD., in Japan and other countries.

This software is based in part on the work of the Independent JPEG Group.

Requirements

- ▷ Subscription to the optional Convenience Plan.
- ▷ The vehicle is located within wireless network coverage.
- ▷ The date setting on the Control Display is current.

Starting BMW Search

1. "BMW Assist"
2. "BMW Search"



3. Select "OK", if necessary.
The BMW Search start page is displayed.


Using BMW Search

To select and display content:

- ▷ Turn the controller to highlight an element.
- ▷ Press the controller to display an element.

Opening the start page

1. Open "Options".
2. "Home"



Loading a new page

1. Open "Options".
2. "Reload"

Canceling

1. Open "Options".
2. "Cancel loading"

Customer Relations

At a glance

Contact Customer Relations for information on all aspects of your vehicle.

Calling Customer Relations

Vehicle equipped with BMW Assist or TeleService


1. "BMW Assist"
2. "Customer Relations"
3. "Start service"

A voice connection is established to Customer Relations.

Vehicle not equipped with BMW Assist or TeleService

1. "BMW Assist"
2. "Customer Relations"

The Customer Relations phone number is displayed. If the vehicle is equipped with the mobile phone preparation package, a voice connection is established.



TeleService Call*

At a glance

You can send a request to your BMW center to arrange a service appointment. The TeleService data is transmitted during a Service Request. If possible, your BMW center will establish contact with you.

Starting a Service Request

1. "BMW Assist"
2. "Service Request"
3. "Start service"



Automatic TeleService Call*

The TeleService data necessary for servicing the vehicle are automatically sent to your BMW center prior to the service deadline. If possible, the center will contact you and a service appointment can be arranged.

You can check when the BMW center was notified.

1. "Vehicle Info"
2. "Vehicle status"



3. Open "Options".
4. "Last Service Request"

Data transfer*

The status of the data transfer is displayed.

1. "BMW Assist"
2. Open "Options".
3. "Data transfer"

Service status*

Displaying available services

Display of all services available in the vehicle. This function can be called up via "Options".

1. "BMW Assist"
2. Open any menu.
3. Open "Options".
4. "Service status"
5. "Available services"

Activating BMW Assist

If the services included in a BMW Assist subscription are not displayed, they may need to be activated.

"Activate BMW Assist"





Mobility

This section helps you maintain your car's mobility by supplying important information on vital topics including fuels and lubricants, wheels and tires, service, maintenance and breakdown assistance.


Refueling

⚠ Always switch off the engine before refueling; otherwise, fuel cannot be added to the tank and a message will be displayed. ◀

⚠ Take all precautionary measures and observe all applicable regulations when handling fuel. Do not carry any spare fuel containers in your vehicle. They can develop a leak and cause an explosion or cause a fire in the event of an accident. ◀

Fuel filler flap

Opening



1. Open fuel filler flap. To do so, lightly press the rear edge.
2. Turn the gas cap counterclockwise.
3. Place the gas cap in the bracket attached to the fuel filler flap.

Closing

Fit the cap and turn it clockwise until you clearly hear a click.

⚠ Do not pinch the band attached to the cap; otherwise, the cap cannot be closed properly and fuel vapors can escape. A message will be displayed if the gas cap is loose or missing. ◀

Manually releasing the fuel filler flap

In the event of a malfunction, you can release the fuel filler flap manually:



Pull the button in the cargo area with the fuel pump symbol down. The fuel filler flap is released.

Observe the following when refueling

⚠ When handling fuels, follow the safety instructions provided at filling stations; otherwise, there is a risk of personal injury or property damage. ◀

When refueling, insert the filler nozzle completely into the filler pipe. Avoid lifting the filler nozzle while filling the tank, as that would lead to:

- ▷ premature pump shutoff
- ▷ reduced efficiency of the fuel-vapor recovery system.


The fuel tank is full when the filler nozzle clicks off the first time.

Fuel tank capacity

Approx. 15.5 US gallons/55 liters, including the reserve capacity of 2.1 US gallons/8 liters.

⚠ Refuel as soon as possible once your cruising range falls below 30 miles/50 km; otherwise, engine functions are not ensured and damage can occur. ◀

Fuel specifications

 Do not fill the tank with leaded fuel as this would cause permanent damage to the catalytic converter.

Do not fill the tank with E85, i.e., fuel containing 85% ethanol, nor with FlexFuel. Otherwise, the engine and fuel supply system will be damaged. ◀

Required fuel


Super Premium Gasoline/AKI 91

This gasoline is highly recommended.

However, you may also use gasoline with less AKI. The minimum AKI Rating is:


- ▷ Z4 sDrive30i: 87
- ▷ Z4 sDrive35i: 89

If you use gasoline with this minimum AKI Rating, the engine may produce knocking sounds when starting at high outside temperatures. This has no effect on the engine life.

 Do not use any gasoline below the specified minimum fuel grade. Otherwise, the engine could be damaged. ◀

Use high-quality brands

Field experience has indicated significant differences in fuel quality: volatility, composition, additives, etc., among gasolines offered for sale in the United States and Canada. Fuels containing up to and including 10% ethanol or other oxygenates with up to 2.8% oxygen by weight, that is, 15% MTBE or 3% methanol plus an equivalent amount of co-solvent, will not void the applicable warranties with respect to defects in materials or workmanship.

 The use of poor-quality fuels may result in driveability, starting and stalling problems especially under certain environmental conditions such as high ambient temperature and high altitude.

Should you encounter driveability problems which you suspect could be related to the fuel you are using, we recommend that you respond by switching to a recognized high-quality brand such as gasoline that is advertised as Top Tier Detergent Gasoline.

Failure to comply with these recommendations may also result in unscheduled maintenance. ◀

BMW recommends BP fuels 

Wheels and tires

Tire inflation pressures

Information for your safety

It is not merely the tires' service life, but also driving comfort and, to a great extent, driving safety that depend on the condition of the tires and the maintenance of the specified tire pressure.

⚠ Check the tire inflation pressure regularly and correct it, if necessary: at least twice a month and before starting long trips. If you fail to observe this precaution you may be driving on tires with incorrect tire pressures, a condition that can not only compromise your vehicle's driving stability, but also lead to tire damage and the risk of an accident. Do not drive with deflated, i.e., flat tires, except when using run-flat tires. A flat tire will seriously impair your vehicle's handling and braking response. Attempts to drive on a flat tire can lead to loss of control over the vehicle. ◀

Checking pressure

Only check tire inflation pressure when the tires are cold. This means after a maximum of 1.25 miles/2 km driving or when the vehicle has been parked for at least 2 hours. When tires are warm, the tire inflation pressure is higher.

▶ After correcting the tire inflation pressure, reinitialize the Tire Pressure Monitor, refer to page 83, or the Flat Tire Monitor, refer to page 81. ◀

Inflation pressure specifications

The tables below provide all the correct inflation pressures for the specified tire sizes at ambient temperature.

▶ The inflation pressures apply to the tire sizes approved and tire brands recommended by BMW; a list of these is available from your BMW center. ◀

For correct identification of the right tire inflation pressures, observe the following:

- ▶ Tire sizes for your vehicle
- ▶ Load conditions
- ▶ Maximum allowable driving speed

Tire inflation pressures for driving up to 100 mph or 160 km/h

For normal driving up to 100 mph or 160 km/h and to achieve optimum driving comfort, adjust pressures to the respective tire inflation pressures listed on the following pages in the columns for traveling speeds up to a maximum of 100 mph or 160 km/h.

These tire inflation pressures can also be found on the driver's side door post when the driver's door is open.





⚠ The maximum permissible speed for these tire pressures is 100 mph or 160 km/h. Do not exceed this speed; otherwise, tire damage and accidents could occur. ◀

Tire inflation pressures for driving above 100 mph or 160 km/h

⚠ In order to drive at maximum speeds in excess of 100 mph or 160 km/h, adjust pressures to the respective tire inflation pressures listed on the following pages in the columns for traveling speeds including those exceeding 100 mph or 160 km/h. Otherwise, tire damage and accidents could occur. ◀

Observe all national and local maximum speed limits; otherwise, violations of the laws could occur.

Tire inflation pressures Z4 sDrive30i

Tire size	Pressure specifications in psi/kPa			
	Traveling speeds up to a max. of 100 mph/160 km/h		Traveling speeds including those exceeding 100 mph/160 km/h	
All pressure specifications in the table are indicated in psi/kilopascal with cold tires. Cold = ambient temperature				

without Sport Package:



225/45 R 17 91 V				
225/45 R 17 91 H M+S	36/250	44/300	36/250	44/300
225/45 R 17 94 V M+S XL				
Front: 225/45 R 17 91 V	36/250	-	36/250	-
Rear: 255/40 R 17 94 V	-	39/270	-	39/270
Front: 225/40 R 18 88 W	36/250	-	36/250	-
Rear: 255/35 R 18 90 W	-	42/290	-	42/290
Front: 225/35 R 19 88 Y XL	36/250	-	36/250	-
Rear: 255/30 R 19 91 Y XL	-	42/290	-	42/290

with Sport Package:

225/45 R 17 91 W				
225/45 R 17 91 H M+S	36/250	44/300	36/250	44/300
225/45 R 17 94 V M+S XL				
Front: 225/45 R 17 91 W	36/250	-	36/250	-
Rear: 255/40 R 17 94 W	-	39/270	-	39/270
Front: 225/40 R 18 88 W	36/250	-	38/260	-
Rear: 255/35 R 18 90 W	-	42/290	-	45/310
Front: 225/35 R 19 88 Y XL	36/250	-	36/250	-
Rear: 255/30 R 19 91 Y XL	-	42/290	-	44/300

More details on the permissible load and weights can be found on page [228](#).

Tire inflation pressures Z4 sDrive35i

Tire size	Pressure specifications in psi/kPa	
	Traveling speeds up to a max. of 100 mph/160 km/h	Traveling speeds including those exceeding 100 mph/160 km/h
All pressure specifications in the table are indicated in psi/kilopascal with cold tires. Cold = ambient temperature		

without Sport Package:

225/45 R 17 91 H M+S				
225/45 R 17 94 V M+S XL	36/250	44/300	36/250	44/300
Front: 225/45 R 17 91 V	36/250	-	36/250	-
Rear: 255/40 R 17 94 V	-	39/270	-	39/270
Front: 225/40 R 18 88 W	36/250	-	36/250	-
Rear: 255/35 R 18 90 W	-	42/290	-	42/290
Front: 225/35 R 19 88 Y XL	36/250	-	36/250	-
Rear: 255/30 R 19 91 Y XL	-	42/290	-	42/290

with Sport Package:

225/45 R 17 91 H M+S				
225/45 R 17 94 V M+S XL	36/250	44/300	36/250	44/300
Front: 225/45 R 17 91W	36/250	-	36/250	-
Rear: 255/40 R 17 94 W	-	39/270	-	39/270
Front: 225/40 R 18 88 W	36/250	-	38/260	-
Rear: 255/35 R 18 90 W	-	42/290	-	45/310
Front: 225/35 R 19 88 Y XL	36/250	-	36/250	-
Rear: 255/30 R 19 91 Y XL	-	42/290	-	44/300

More details on the permissible load and weights can be found on page [228](#).

Tire identification marks

Knowledge of the labeling on the side of the tire makes it easier to identify and choose the right tires.

Tire size

For example: 225/45 R 17 91 V

Nominal width in mm ————

Aspect ratio in % ————

Radial belt construction ————

Rim diameter in inches ————

Load rating, not on ZR tires ————

Speed code letter, in front of the R on ZR tires ————

Speed code letter

Q = up to 100 mph or 160 km/h

T = up to 118 mph or 190 km/h

H = up to 131 mph or 210 km/h

V = up to 150 mph or 240 km/h

W = up to 167 mph or 270 km/h

Y = up to 186 mph or 300 km/h

Tire Identification Number

Tires with DOT codes meet the guidelines of the US Department of Transportation.

DOT code:

For example: DOT xxxx xxx 3709

Manufacturer's code for tire make ————

Tire size and tire design ————

Tire age ————

Tire age

The manufacturing date of tires is contained in the tire coding: DOT ... 3709 means that the tire was manufactured in week 37 of 2009.

BMW recommends that you replace all tires after 6 years at most, even if some tires may last for 10 years.

Uniform Tire Quality Grading

Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width. For example:

Tread wear 200 Traction AA

Temperature A

DOT Quality Grades

Tread wear

Traction AA A B C

Temperature A B C



All passenger car tires must conform to Federal Safety Requirements in addition to these grades. ◀

Tread wear

The tread wear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course. For example, a tire graded 150 would wear one and one-half (1 ½) times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

Traction

The traction grades, from highest to lowest, are AA, A, B, and C.


Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.



The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics. ◀

Temperature

The temperature grades are A, the highest, B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

 The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure. ◀

RSC – run-flat tires

You will recognize run-flat tires by a circular symbol containing the letters RSC on the side of the tire, refer to page 199.

M+S

Winter and all-season tires. These have better winter properties than summer tires.

XL

Designation for specially reinforced tires.


Tire condition

Inspect your tires frequently for tread wear, signs of damage and for foreign objects lodged in the tread. Check the tread depth.

Minimum tread depth

The tread depth should not drop below 1/8 in/ 3 mm, although, for example, European legislation only specifies a minimum tread depth of

1/16 in/1.6 mm. At tread depths below 1/8 in/ 3 mm there is an increased risk of high-speed hydroplaning, even when only small amounts of water are present on the road surface. When winter tires wear down past a tread depth of 1/6 in/4 mm, they become perceptibly less suitable for winter conditions. In the interest of safety, new tires should be installed.




Wear indicators in the base of the tread groove are distributed around the tire's circumference; the letters TWI, for Tread Wear Indicator, on the tire's sidewalls identify tires that incorporate these wear indicators. Once the tire tread has worn down to the wear indicators, the tire has worn to a depth of 1/16 in/1.6 mm.

Wheel/tire damage

Please note that low-profile tires cause wheels, tires and suspension parts to be more susceptible to road hazard and consequential damages.

Unusual vibrations encountered during normal vehicle operation can indicate tire failure or some other vehicle defect. This can, for example, be caused by driving over curbs. The same applies to any other abnormal road behavior, such as pulling severely to the right or left.

 In these cases, reduce speed immediately and have wheels and tires thoroughly checked. To do so, drive carefully to the nearest BMW center or tire shop that works according to BMW repair procedures with correspondingly trained personnel. If necessary, have the vehicle towed there.

Otherwise, tire damage can be extremely dangerous for vehicle occupants and other road users. ◀

Tire age

For various reasons, such as the development of brittleness, BMW recommends tire replacement after no more than 6 years, regardless of the actual wear of the tires.

The manufacturing date of tires is contained in the tire coding:

DOT ... 3709 means that the tire was manufactured in week 37 of 2009.


Run-flat tires




The symbol identifying run-flat tires is a circle with the letters RSC on the sidewall. Run-flat tires comprise a conditionally self-supporting tire and a special rim. The reinforcement in the sidewalls ensures that the tire can continue to be used subject to certain restrictions, even if depressurized.

For information on continuing to drive with a flat tire, refer to Indication of a flat tire, page 81.

New wheels and tires


 Have new wheels and tires installed only by your BMW center or tire shop that works according to BMW repair procedures with correspondingly trained personnel. If this work is not carried out properly, there is a danger of subsequent damage and related safety hazards. Make sure that the new wheels are balanced. ◀

Retreaded tires

 BMW recommends that you do not use retreaded tires, since driving safety may be impaired. The causes for this include potentially different tire casing structures and often wide variations in tire age, which can result in a limited service life. ◀

Correct wheels and tires

When mounting new tires or changing over from summer to winter tires and vice versa, mount run-flat tires for your own safety. In the event of a flat, no spare wheel is available. Your BMW center will be glad to advise you.

 BMW recommends that you use only wheel and tire combinations that BMW has tested and approved for your particular vehicle. Variations in factors such as manufacturing tolerances mean that even wheels and tires with identical official size ratings could actually have different dimensions, which could lead to body contact and thus to severe accidents. If non-approved wheels and tires are used, BMW cannot evaluate their suitability, and therefore cannot guarantee their driving safety. ◀

You can inquire about the right wheel/tire combination at your BMW center.


The correct combination of wheels and tires is also necessary to ensure reliable operation of various vehicle systems such as ABS, DSC or TPM.

To maintain good handling and vehicle response, use only tires of a single brand and tread configuration. After a tire has been damaged, mount the previous wheel and tire combination again as soon as possible.

Wheels with Tire Pressure Monitor TPM electronics

When mounting new tires or changing over from summer to winter tires, or vice versa, only use wheels with TPM electronics; otherwise, the Tire Pressure Monitor may not be able to detect a puncture, refer to page 82. Your BMW center will be glad to advise you.

Recommended tire brands




Certain makes of tire are recommended by BMW for each tire size. They are marked with a clearly visible BMW designation on the sidewall of the tire.

When properly used, these tires meet the highest standards in terms of safety and handling characteristics.

Special characteristics of winter tires

BMW recommends winter tires for winter roads or at temperatures below +45 °F /+7 °C. Although all-season M+S tires provide better winter traction than summer tires, they generally fail to provide the same levels of cold-weather performance as winter tires.

Pay attention to speed

 Always comply with the speed limit for the winter tires mounted on your car; failure to do so could result in tire damage and accidents. ◀

If the car is capable of speeds higher than that permitted for the winter tires, a label stating the maximum permitted speed for the mounted tires must be displayed in your field of view. Specialist tire dealers and your BMW center can supply these labels.

Storage

Always store wheels and tires in a cool, dry place with as little exposure to light as possible. Always protect tires against all contact with oil, grease and fuels. Do not exceed the maximum tire inflation pressure indicated on the sidewall of the tire.


Swapping wheels between axles

BMW advises against swapping wheels between the front and rear axles, even if all tires have the same size, as this could impair driving characteristics. If the tires are of mixed sizes, swapping wheels between the axles is not permissible.

Snow chains*

Only certain fine-link snow chains have been tested by BMW, classified as safe for use and recommended. Consult your BMW center for more information.

Snow chains must be mounted in pairs and on the rear wheels only. Observe the manufacturer's instructions when mounting snow chains. Do not exceed a speed of 30 mph or 50 km/h.

 Do not initialize the Flat Tire Monitor if snow chains are mounted; otherwise, the instrument might issue an incorrect reading. When driving with snow chains, you may find it helpful to activate DTC temporarily, refer to page 78. ◀

Under the hood

! Do not work on the car unless you possess the necessary technical knowledge. If you are unfamiliar with the statutory guidelines, have any work on the vehicle performed only by a BMW center or by a workshop that works according to BMW repair procedures with correspondingly trained personnel. If this work is not carried out properly, there is a danger of subsequent damage and related safety hazards. ◀

Hood

Releasing




Pull the lever.

Opening



! To avoid damage, make sure that the wiper arms are against the windshield before you open the engine compartment. Do not open the engine hood before the engine has cooled down; otherwise, injuries may result. ◀
Push the release lever to the right and open the hood.

Closing




Close the hood from a height of approx. 16 in/ 40 cm with momentum. It must be clearly heard to engage.

! Make sure that the closing path of the hood is clear; otherwise, injuries may result.

If you see any signs while driving your vehicle that the hood is not completely closed, stop at once and close it securely. ◀

Important parts of the engine compartment



- 1 Expansion tank for coolant, refer to page 204
- 2 Jump-starting connection, negative terminal, refer to page 219
- 3 Vehicle identification number
- 4 Washer fluid filler neck for headlamp cleaning system and window washer system, refer to page 61
- 5 Fluid filler neck for engine oil, refer to page 204
- 6 Jump-starting connection, positive terminal, refer to page 219

Engine oil

The engine oil consumption is dependent on driving style and driving conditions.

Checking engine oil level

Your car is equipped with an electronic oil-level monitor.

For the oil level to be measured and displayed correctly, it is necessary that the engine be at operating temperature, i.e., after uninterrupted driving for at least approx. 6.2 miles/10 km. You can have the oil level displayed while you are driving, or while the vehicle is at a standstill on a level surface and the engine is running.

Display in the instrument cluster




1. Push button 1 in the turn indicator lever up or down repeatedly until the appropriate symbol is shown in the display, accompanied by the word "OIL".

- Press button **2** in the turn indicator lever. The oil level is checked and the reading displayed.

Possible displays



- Oil level OK
- Oil level is being checked.
This can take about 3 minutes if the car is at a standstill on a level surface, or about 5 minutes while the car is on the move.
- Oil level down to minimum:
Add engine oil as soon as possible, but no more than 1 US quart/1 liter, refer also to Adding engine oil on page 204.
- Oil level is too high.
 Too much oil will harm the engine. Have the vehicle checked without delay. ◀
- The oil level sensor is defective.
Do not add engine oil. You can continue your journey. Note the newly calculated distance remaining to the next oil service, refer to page 69. Have the system checked as soon as possible.

Display via iDrive


- "Vehicle Info"
- "Vehicle status"



- "Engine oil level"




Possible messages

- ▷ "Engine oil level OK"
- ▷ "Measurement not possible at this time."
- ▷ "Measuring engine oil level...":
This can take about 3 minutes if the car is at a standstill on a level surface and the engine is running, and about 5 minutes while the car is moving.
If engine oil was added, it may take up to 30 minutes to obtain an oil level reading.
- ▷ "Engine oil level below minimum. Add 1 quart!"
Add engine oil as soon as possible, but no more than 1 US quart/1 liter, refer also to Adding engine oil below.
- ▷ "Engine oil level too high! Have this checked."
 Too much oil will harm the engine. Have the vehicle checked without delay. ◀

- ▷ "Measurement inactive. Have this checked."
Do not add engine oil. You can continue your journey. Note the newly calculated distance remaining to the next oil service, refer to page 69. Have the system checked as soon as possible.

Adding engine oil



Do not add 1 US quart/1 liter of engine oil until a corresponding message is shown on the Control Display.

- ⚠ Add oil within the next 125 miles/200 km; otherwise, the engine damage could occur. ◀
- ⚠ Keep oils, greases, etc. out of the reach of children and comply with the relevant warnings on the containers. Otherwise, health hazards may result. ◀

Oil change

Have oil changed only at your BMW center or at a workshop that works according to BMW repair procedures with correspondingly trained personnel.

Oil types

- ⚠ Do not use oil additives as these may cause engine damage. ◀

Specified engine oils

Your service center can advise you on which engine oils have been approved by the manufacturer of your vehicle.

The engine oil quality is critical for the life of the engine.

Approved oils can be identified by the following specification:

Preferred:	BMW Longlife-01 BMW Longlife-01 FE
Alternative:	BMW Longlife-98

Approved oils belong to the following viscosity classes: SAE 0W-40, SAE 0W-30, SAE 5W-40 and SAE 5W-30.

Alternative oil types

If the approved engine oils are not available, up to 1 US quart/1 liter of another oil with the following specification may be used:

API SM or higher


BMW recommends 

Coolant

- ⚠ Do not add coolant to the cooling system when the engine is hot. Escaping coolant can cause burns. ◀

Coolant consists of half water and half additive. Not all commercially available additives are suitable for your BMW. Ask your BMW center for suitable additives.

- ⚠ Only use suitable additives; otherwise, engine damage may result. Because additives are harmful to your health, it is important to follow the instructions on the containers. ◀

 Comply with the appropriate environmental protection regulations when disposing of coolant additives. ◀

Checking coolant level

1. Do not open the engine hood before the engine has cooled down.
2. Turn the expansion tank cap counterclockwise slightly to allow any accumulated pressure to escape, then continue turning to open.

- The coolant level is correct if it is between the maximum and minimum marks in the filler neck, refer also to the diagram next to the filler neck.



- If the coolant is low, slowly add coolant up to the specified level; do not overfill.
- Turn the cap until there is an audible click.
- Have the reason for the coolant loss eliminated as soon as possible.

Maintenance

BMW Maintenance System



The BMW Maintenance System supports the preservation of the traffic and operating safety of your BMW. The objective is to optimize efforts with respect to minimal vehicle maintenance costs.

If and when you come to sell your BMW, a comprehensive record of servicing will prove a significant benefit.

Condition Based Service CBS


Sensors and special algorithms take the different driving conditions of your BMW into account. Condition Based Service uses this to determine the current and future service requirements. By letting you define a service and maintenance regimen that reflects your own individual requirements, the system builds the basis for trouble-free driving.

On the Control Display, you can have the remaining times or distances for selected maintenance tasks and any legally prescribed dates displayed, refer to page 69:

- ▷ Engine oil
- ▷ Brake pads, separately for the front and back
- ▷ Brake fluid
- ▷ Vehicle check
- ▷ Legally mandated inspections depending on local regulations


Service data in the remote control

Your vehicle continuously stores service-requirement information in the remote control while you are driving. Your BMW Service Advisor can read out this data from the remote control unit, and propose an optimized maintenance approach. Whenever you take your car in for servicing you should therefore hand your BMW Service Advisor the remote control unit that you last used.

 Make sure that the date is always set correctly, refer to page 72; otherwise, the effectiveness of Condition Based Service CBS is not assured. ◀

Service and Warranty Information Booklet for US models and Warranty and Service Guide Booklet for Canadian models

Please consult your Service and Warranty Information Booklet for US models and Warranty and Service Guide Booklet for Canadian models for additional information on service requirements.

 BMW recommends that you have service and repair operations performed at your BMW center.

Take the time to ensure that these service procedures are confirmed by entries in your vehicle's Service and Warranty Information Booklet for US models and Warranty and Service Guide Booklet for Canadian models. These entries verify that your vehicle has received the specified regular maintenance. ◀

Socket for Onboard Diagnosis OBD



Primary components that make up exhaust emissions can be checked by a device via the OBD socket.

This socket is located under a cover on the left on the driver's side.

Exhaust emission values

SERVICE ENGINE SOON The warning lamp lights up: The vehicle emissions are raised. The trip can be continued. Have the car checked as soon as possible.



Canadian models display this warning lamp.

The lamp flashes under certain conditions. This indicates excessive misfiring in the engine. If this happens, you should reduce your speed and visit your nearest BMW center as soon as possible. Severe engine misfiring can quickly lead to serious damage of emissions-related components, especially the catalytic converter.



The warning lamp comes on if the gas cap is not properly tightened and the OBD system assumes that fuel vapor is escaping. If the gas cap is then tightened, the warning lamp should go out within a few days.

Data recorders

Your vehicle may be equipped with one or several measuring or diagnostic modules or a device for recording or sending certain vehicle data or information. In addition, if you have signed a service contract for BMW Assist, certain vehicle data may be transmitted or recorded in order to facilitate the corresponding services.


Care


Care products


Regular cleaning and care contributes significantly to the value retention of your BMW.

BMW recommends cleaning and caring for your vehicle with products that are approved by BMW for this purpose.

Your BMW center will be happy to advise you on the products and services available for cleaning and caring for your BMW.


 Original BMW CareProducts have been material-tested, laboratory-checked and proven in the field, and offer optimal care and protection for your vehicle. ◀


 Do not use cleaners that contain alcohol or solvents as these may result in damage. ◀

 Cleaning agents can contain substances that are dangerous or hazardous to your health. Therefore, follow the warning and safety instructions on the packaging. When cleaning inside the vehicle, always open the doors or windows of the vehicle. In enclosed areas, provide for sufficient ventilation. Only use products designed for cleaning vehicles. ◀

Exterior care


Washing the vehicle

 Especially during the winter months, ensure that the vehicle is washed more frequently. Heavy soiling and road salt can lead to vehicle damage. ◀

 After washing the vehicle, apply the brakes briefly to dry them; otherwise, water can reduce braking efficiency over the short term and brake discs can corrode. ◀


Automatic car washes

Preference should be given to cloth car washes.

 Do not use high-pressure car washes; otherwise, water may drip into the vehicle around the windows. ◀

Before driving into a car wash, ensure that it is suitable for your BMW. Check the following:

- ▷ Dimensions of your vehicle, refer to page 227.
- ▷ If necessary: fold in the exterior mirrors, refer to page 45.
- ▷ Maximum permissible tire width.

 Avoid car washes with guide rail heights over 4 in/10 cm; otherwise, there is danger of damaging chassis parts. ◀

Preparations before driving into an automatic car wash:

- ▷ Unscrew the rod antenna*.
- ▷ Deactivate the rain sensor* to avoid unintentional activation of the wipers.
- ▷ Remove additional attachments, e.g., spoilers or telephone antennas, if there is a possibility that they could be damaged.

Automatic transmission

Before driving into an automatic car wash, perform the following steps to ensure that the vehicle can roll:

1. Insert the remote control, even with Comfort Access, into the ignition lock.
2. Move the selector lever to position N.
3. Release the parking brake.
4. Switch off the engine.
5. Leave the remote control in the ignition lock so that the vehicle can roll.

7-gear sport automatic transmission with dual clutch


Before driving into an automatic car wash, perform the following steps to ensure that the vehicle can roll:

1. Insert the remote control, even with Comfort Access, into the ignition lock.
2. Engage transmission position N.
3. Release the parking brake.
4. Switch off the engine.
5. Leave the remote control in the ignition lock so that the vehicle can roll.


Transmission position P is engaged:

- ▷ Automatically after approx. 30 minutes
- ▷ When you take the remote control out of the ignition lock

Steam jets / high-pressure washers


 When using steam jets or high-pressure washers, ensure that you maintain sufficient clearance to the vehicle and do not exceed a temperature of 140 °F /60 °C.


Insufficient clearance or excessive pressure or temperature can lead to component damage or water penetration. Follow the operating instructions of the high-pressure washer. ◀

 When using high-pressure washers, do not spray against the seals of the retractable hardtop, the sensors and the cameras, e.g., of the Park Distance Control or Rear View Camera, for an extended period and maintain a distance of at least 12 in/30 cm. ◀

Manual car wash

When washing the vehicle by hand, use large quantities of water and car shampoo if necessary. Clean the vehicle with a sponge or washing brush, applying light pressure only.

 Before cleaning the windshield, deactivate the rain sensor or switch off the ignition to prevent unintentional activation of the wipers. ◀

 Observe local regulations pertaining to washing vehicles by hand. ◀

Headlamps


Do not rub them dry and do not use abrasive or corrosive cleaning agents.

Loosen dirt, e.g., insects, with shampoo or insect remover and wash away with copious quantities of water.

Thaw ice with a windshield deicer and do not use an ice scraper.


Windows

Clean the inside and outside surfaces of the windows and the mirrors with window cleaner.

 Do not clean the mirrors with cleaners containing quartz. ◀

Retractable hardtop

Proceed as you would in a normal car wash.

 When you open a wet hardtop, water drops may run into the cargo area. If necessary, remove items from the cargo area beforehand to avoid water stains or soiling. ◀


Paintwork care

Regular care contributes to value retention and protects the paintwork against the long-term effects of damaging substances.

Region-specific environmental influences can damage the vehicle paintwork. Therefore, it is important to adapt the frequency and scope of car care accordingly.

Immediately remove aggressive materials such as spilled fuel, oil, grease, brake fluid, tree sap or bird droppings to prevent damage to the paintwork.

Repairing paintwork damage

 Immediately repair scratches or similar damage, such as that caused by stones hitting the vehicle, where necessary to prevent rusting. ◀


BMW recommends having paintwork damage repaired by a professional paint repair workshop according to BMW specifications using original BMW paint materials.

Preservation

A preservation treatment is necessary when water no longer beads off the clean paintwork surface. Only use products for paintwork preservation that contain carnauba or synthetic waxes.

Rubber seals

Treat only with water or rubber care products.


 Do not use silicon-containing care products on rubber seals; otherwise, noise and damage could occur. ◀

Chrome parts


Carefully clean vehicle parts, such as the radiator grill, door handles or window frames, with copious quantities of water and a shampoo additive. For additional treatment, use a chrome polish.

Light-alloy wheels

For technical reasons, dust is generated during braking that is deposited on the light-alloy wheels. Remove the dust regularly using acid-free rim cleaner.

 Do not use aggressive, acidic, strongly alkaline and abrasive cleaning agents or steam jets over 140 °F /60 °C; otherwise, damage may occur. ◀

Outside sensors / cameras


 Keep the sensors and cameras on the outside of the vehicle, e.g., those of Park Distance Control, clean and free of ice to ensure that they remain fully functional. ◀


Interior care

Upholstery fabrics/cloth trims/ Alcantara fabrics


Vacuum regularly with a vacuum cleaner to remove superficial dirt.

To remove severe spots such as stains from beverages, use a soft sponge or lint-free microfiber cloth and suitable interior cleaners. Follow the instructions on the packaging.

 Clean the upholstery down to the seams using a sweeping motion. Avoid strong rubbing. ◀

 Opened Velcro fasteners, etc., on pants or other articles of clothing can damage the seat covers. Ensure that Velcro fasteners are closed. ◀


Leather/leather trim

 The leather used by BMW is a high quality natural product. Slight irregularities in the leather are a typical characteristic of natural leather. ◀

Dust and road grit in the pores and folds of the leather have an abrasive effect, leading to increased wear and causing the leather surface to become brittle prematurely. Therefore, regularly dust the leather with a cloth, for example.

Clean light-colored leather more frequently as dust and dirt are more noticeable.

Treat the leather at least once every two months using a leather lotion as dirt and grease will gradually attack the leather's protective layer.


 Rivets, etc., on pants or other articles of clothing can damage the seat covers. ◀

Carpets / cargo area

You can vacuum the carpets and floor mats or clean them with interior cleaner if heavily soiled.

The floor mats can be removed for cleaning. When replacing the mats, ensure that the seat rails do not extend over the floor mats, as this may damage the mats.

Lint on the floor mats occurs for technical reasons and can be removed by vacuuming repeatedly.

 When cleaning the interior, do not move both seats all the way forward while moving them to their uppermost position and leaning the backrests forward. Otherwise, the seats could hit and damage the seal on the windshield, the sun visor or the headliner. ◀

Interior plastic parts

- ▷ Imitation leather surfaces
- ▷ Lamp glasses
- ▷ Display pane of instrument cluster
- ▷ Matte parts


Clean with water and solvent-free plastic cleaner if necessary.

Fine wood parts

Clean fine wood trim and fine wood parts with a damp cloth. Wipe dry with a soft cloth.

Safety belts

Dirty belt straps impede the reeling action and thus have a negative impact on safety.

 Do not clean with cleaning agents as these may destroy the fabric. ◀


Use only a mild soapy solution, with the safety belts clipped into their buckles. Do not allow the reels to retract the safety belts until they are dry.


Interior sensors / cameras

To clean interior sensors and cameras, e.g., of the high-beam assistant, use a lint-free cloth moistened with glass cleaner.


Displays

To clean the displays, e.g., of the radio or instrument cluster, use a display cleaning cloth or a soft, non-abrasive, lint-free cloth.

 Avoid applying excessive pressure when cleaning the displays; otherwise, damage may occur. ◀

 Do not use chemical or abrasive household cleaning agents. Keep all types of fluid away from the device. Otherwise, surfaces or electrical components may be corroded or damaged. ◀

CD/DVD drives


 Do not use a cleaning CD, as it may damage parts of the drive. ◀

Vehicle storage

If your vehicle is to be decommissioned for longer than three months, your BMW center or a workshop that operates according to BMW specifications will be glad to advise you.


Replacing components

Onboard vehicle tool kit



The onboard vehicle tool kit is stored in a pouch under the cargo area floor panel.

Wiper blades



1. Fold up the wiper arm.
2. Fold the wiper blade upwards.
3. Press the hook.
4. Pull the wiper blade downward out of the holder and remove it toward the top left, see arrow.

! To avoid damage, make sure that the wiper arms are resting against the windshield before you open the engine compartment. ◀

Lamps and bulbs

Lamps and bulbs make an essential contribution to vehicle safety. They should, therefore, be handled carefully. BMW recommends hav-

ing your BMW center perform any work that you do not feel competent to perform yourself or that is not described here.

▷ Never touch the glass of new bulbs with your bare fingers, as even minute amounts of contamination will burn into the bulb's surface and reduce its service life. Use a clean tissue, cloth or something similar, or hold the bulb by its base. ◀

You can obtain a selection of replacement bulbs at your BMW center.

! Only change bulbs while they are cool to the touch; otherwise, you could suffer burns. ◀

! When working on electrical systems, always begin by switching off the consumer in question; otherwise, short-circuits could result. To avoid possible injury or equipment damage when replacing bulbs, observe any instructions provided by the bulb manufacturer. ◀

For care of the headlamps, please follow the instructions in the chapter entitled "Care".

▷ If the routine for changing a particular bulb is not described here, please contact your BMW center or a workshop that works according to BMW repair procedures with correspondingly trained personnel. ◀

Light-emitting diodes LED

Light-emitting diodes installed behind translucent lenses serve as the light source for many of the controls and displays in your vehicle. These light-emitting diodes, which operate using a concept similar to that applied in conventional lasers, are officially designated as Class 1 light-emitting diodes.

! Do not remove the covers or expose the eyes directly to the unfiltered light source for several hours; otherwise, this could cause irritation to the retina. ◀

Xenon lamps

! Have any work on the xenon lamp system, including bulb replacements, performed only by a BMW center or a workshop that works according to BMW repair procedures with correspondingly trained personnel. Otherwise, if such work is carried out improperly, the high voltage in the system presents the danger of fatal injuries. ◀

Parking lamps and roadside parking lamps, daytime running lights

H8 bulb, 35 watts

1. Switch off the lamps and take the remote control out of the ignition lock.
2. Turn the upper access cover to the left and remove it, see arrow.



3. Turn the lamp by approx. 90°, see arrow 1, and pull it out, see arrow 2.



4. Disconnect the plug, change the bulb and reconnect the plug.
5. Insert the bulb and turn it until it stops.
6. Screw on the access cover tightly by turning it to the right.

! Be careful when attaching the access cover; otherwise, it may leak, causing damage to the headlamp system. ◀


Turn signals, front

P24W bulb, 24 watt


1. Turn the wheel outwards.



2. Turn both locks in the wheel house to the left and remove the cover.




3. Turn the bulb holder to the left and remove it.
4. Turn the bulb to the right, see arrow, and remove it.



5. Change the bulb and screw it into the bulb holder toward the left.
6. Insert the bulb holder and turn it to the right.
7. Reattach the cover.

Tail lamps

- ▷ Brake lamp, backup lamp:
W16W bulb, 16 watts




- 1 Brake lamp
- 2 Tail lamp, LED
- 3 Brake lamp
- 4 Backup lamp
- 5 Turn signal/dynamic brake lamp*, LED


If bulb **2** or **5** malfunctions, please contact your BMW center or a workshop that works according to BMW repair procedures with correspondingly trained personnel.

Changing the backup lamp and inner brake lamp


- 1. Press the locking mechanism in the cargo area, see arrow, and remove the cover.



- 2. Pull out the bulb holder and replace the bulb.
 - ▷ Inner brake lamp:



- ▷ Backup lamp:




- 3. Attach the bulb holder.
- 4. Reattach the cover.

Changing the outer brake lamp

- 1. Remove the cover in the cargo area.



2. Pull out the bulb holder, see arrow, and change the bulb.



3. Attach the bulb holder.
4. Reattach the cover.

License plate lamp, rear lamp, center brake lamp and turn signal

These lamps use LED technology for operation. In the event of a malfunction, please contact your BMW center or a workshop that works according to BMW repair procedures with correspondingly trained personnel.


Changing wheels

Your BMW is equipped with run-flat tires as standard. This removes the need to change a wheel immediately in the event of a puncture.


For information on continuing to drive with a damaged tire, refer to Indication of a flat tire on page 81.

The symbol identifying run-flat tires is a circle with the letters RSC on the sidewall, refer to Run-flat tires, page 199.

When mounting new tires or changing over from summer to winter tires and vice versa, mount run-flat tires for your own safety. In the event of a flat, no spare wheel is available. Your BMW center will be glad to advise you. Refer also to New wheels and tires, page 199.

 The tools for changing wheels are available as optional accessories from your BMW center. ◀

Jack mounting points



The jacking points are at the positions shown in the illustration.

Lug bolt lock*



- 1 Lug bolt for adapter
- 2 Adapter, in onboard vehicle tool kit

Removing the wind deflector

1. Remove the adapter **2** from the onboard vehicle tool kit and insert it in the lug bolt.
2. Unscrew the lug bolt **1**.

Remove the adapter after screwing the lug bolt back on.


The code number is stamped on the front of the adapter. Please note down this number and keep it in a safe place in case the adapter should get lost.

Vehicle battery

Battery care

The battery is 100% maintenance-free, the electrolyte will last for the life of the battery when the vehicle is operated in a temperate climate. Your BMW center will be glad to advise in all matters concerning the battery.

Battery replacement


 Only use approved batteries. Only use vehicle batteries that have been approved for your vehicle by the manufacturer; otherwise, the vehicle could be damaged and systems or functions may not be fully available. ◀

After a battery replacement, have the battery registered on the vehicle by your service center to ensure that all comfort functions are fully available.

Charging the battery

Only charge the battery in the vehicle via the terminals in the engine compartment with the engine off. Connections, refer to Jump-starting on page 219.

Disposal


 Have old batteries disposed of by your BMW center or bring them to a recycling center. Maintain the battery in an upright position for transport and storage. Always secure the battery against tipping over during transport. ◀

Power failure

After a temporary power loss, the functioning of some equipment may be limited and require reinitialization. Individual settings may likewise have been lost and will have to be programmed:

- ▷ Time and date
These values must be updated, refer to page 71.
- ▷ Radio
In some cases, stations may have to be stored again, refer to page 144.
- ▷ Navigation system
Operability must be waited for, refer to page 120.
- ▷ Seat and mirror memory
The positions must be stored again, refer to page 43.
- ▷ Inside rearview mirror with digital compass
The system must be calibrated, refer to page 103.

Fuses

 Never attempt to repair a blown fuse and do not replace a defective fuse with a substitute of another color or amperage rating; otherwise, this could lead to a circuit overload, ultimately resulting in a fire in the vehicle. ◀

1. Remove the screws **1** using the screwdriver from the onboard vehicle tool kit.
2. Remove the cover **2**, unwinding the cable to the footwell lamp*, if necessary.



3. Release the shiny fastener **3**.



4. Fold the current distributor **4** downward and pull forward.

A pair of plastic tweezers is found on the current distributor.

See the inside of the cover for information on fuse assignment.

The cover is reinstalled in reverse order.

Giving and receiving assistance

Emergency Request*

Requirements

- ▷ BMW Assist is activated. Activating BMW Assist, refer to page 186.
- ▷ Radio readiness is on.
- ▷ The BMW Assist system is logged on to a wireless network.
- ▷ The Emergency Request system is operable.
- ▷ Equipment version with full preparation package mobile phone. This equipment makes it possible to send an Emergency Request even if no mobile phone is paired with the vehicle.

Once your service contract for BMW Assist expires, the BMW Assist system can be deactivated by a BMW center without you having to visit a workshop. Once the BMW Assist system has been deactivated, Emergency Requests are not possible. The BMW Assist system can be reactivated by a BMW center after a new contract has been signed.

Sending an Emergency Request

1. Briefly press the cover flap to open.



2. Press the SOS button until the LED in the button lights up.

As soon as the voice connection to the BMW Assist Response Center has been established, the LED flashes.


Once the BMW Assist Response Center has received your Emergency Request, the BMW Assist Response Center contacts you and takes further steps to help you. Even if you are unable to respond, the BMW Assist Response Center will be able to initiate further steps to assist you under certain conditions.

If the circumstances allow this, remain in the vehicle until the connection has been established. You will then be able to provide a detailed description of the situation.

In a BMW Assist Emergency Request, data for determining the necessary rescue measures are transmitted to the BMW Assist Response Center, e.g., the current position of your vehicle, if it can be determined.

If the LED is flashing but the BMW Assist Response Center cannot be heard over the hands-free system, it is possible that the hands-free system is malfunctioning. You may still be heard by the BMW Assist Response Center, however.

Under certain conditions, an Emergency Request is sent automatically immediately after a severe accident. This Automatic Collision Notification is not affected by the button being pressed.

 For technical reasons, the Emergency Request service cannot be guaranteed for the most unfavorable conditions. ◀

Roadside Assistance

BMW Roadside Assistance is there to assist you around the clock in the event of a breakdown, including on weekends and public holidays.

The phone numbers of Roadside Assistance in your home country can be found in the Contact brochure.

In vehicles equipped with BMW Assist or TeleService, you can establish contact with BMW Roadside Assistance for breakdown assistance directly via iDrive, refer to page 185.

First aid pouch*

Some of the articles contained in the first aid pouch have a limited service life. Therefore, check the expiration dates of the contents regularly and replace any items in good time, if necessary.



The first aid pouch is located on the lateral storage shelf behind the seats.

Warning triangle*




The warning triangle is located in a holder in the luggage compartment lid. Press the tabs to take it out.

Jump-starting


If the car's own battery is flat, your BMW's engine can be started by connecting two jumper cables to another vehicle's battery. You

can also use the same method to help start another vehicle. Only use jumper cables with fully-insulated clamp handles.


 Do not touch any electrically live parts when the engine is running, or a fatal accident may occur. Carefully adhere to the following sequence, both to prevent damage to one or both vehicles, and to guard against possible personal injuries. ◀

Preparation

1. Check whether the battery of the other vehicle has a voltage of 12 volts and approximately the same capacitance in Ah. This information can be found on the battery.
2. Switch off the engine of the assisting vehicle.
3. Switch off any consumers in both vehicles.

 There must not be any contact between the bodies of the two vehicles; otherwise, there is a danger of shorting. ◀

Connecting jumper cables


 Connect the jumper cables in the correct order, so that no sparks which could cause injury occur. ◀

Your BMW has a jump-starting connection in the engine compartment which acts as the battery's positive terminal, refer also to the Engine compartment overview on page 202. The cap is marked with +.

1. Pull the cap of the BMW jump-starting connection up to remove.



2. Attach one terminal clamp of the plus/+ jumper cable to the positive terminal of the battery or a starting-aid terminal of the vehicle providing assistance.
3. Attach the second terminal clamp of the plus/+ jumper cable to the positive terminal of the battery or a starting-aid terminal of the vehicle to be started.
4. Attach one terminal clamp of the minus/- jumper cable to the negative terminal of the battery or to an engine or body ground of the assisting vehicle.
Your BMW has a special nut as body ground or negative pole.




5. Attach the second terminal clamp of the minus/- jumper cable to the negative terminal of the battery or to the engine or body ground of the vehicle to be started.



Starting the engine

1. Start the engine of the donor vehicle and allow it to run for a few minutes at slightly increased idle speed.
2. Start the engine on the other vehicle in the usual way.
If the first start attempt is not successful, wait a few minutes before another attempt in order to allow the discharged battery to recharge.
3. Let the engines run for a few minutes.
4. Disconnect the jumper cables by reversing the above connecting sequence.

If necessary, have the battery checked and recharged.

-  Never use spray fluids to start the engine. ◀


Tow-starting, towing away

-  Observe the applicable laws and regulations for tow-starting and towing vehicles. ◀
-  Do not transport any passengers other than the driver in a vehicle that is being towed. ◀

Using a tow fitting


The screw-in tow fitting must always be carried in the car. It can be screwed in at the front or rear of the BMW.

It is stored in the onboard vehicle tool kit underneath the floor panel in the cargo area, refer to page 212.

-  Use only the towing eyelet supplied with the vehicle and screw it in firmly until it stops. Use the tow fitting for towing on paved roads only. Avoid lateral loading of the tow fitting, e.g., do not lift the vehicle by the tow fitting. Otherwise, the tow fitting and the vehicle could be damaged. ◀


Access to screw thread

Front




Release the cover panel in the bumper:
Press on the recess at the bottom left in the cover panel.

Rear



Release the cover panel in the bumper: Press on the recess at the bottom center in the cover panel.

Being towed

 Make sure that the ignition is switched on, refer to page 50; otherwise, the low-beam headlamps, tail lamps, turn signal indicators and windshield wipers may be unavailable.

If the electrical system fails, do not tow-start or tow the vehicle. The electrical steering wheel lock cannot be released and the vehicle cannot be steered. Jump-starting, refer to page 219.

Power steering assistance is not available when the engine is not running. Thus, braking and steering will require increased effort. ◀


Manual transmission

Gearshift lever in neutral position.


Automatic transmission

Selector lever in position N.

Changing selector lever positions, refer to page 54.


 Do not exceed a towing speed of 31 mph or 50 km/h and a towing distance of 31 miles/50 km; otherwise, the automatic transmission may be damaged. ◀

7-gear sport automatic transmission with dual clutch


 Ensure that transmission lock P is not engaged as the rear wheels will otherwise be blocked.

When using the car wash function, refer to page 209, note that the parking lock P is engaged automatically after approx. 30 minutes, blocking the rear wheels.


If an electrical malfunction occurs or if towing takes longer than approx. 20 minutes, manually release the parking lock, refer to page 58. ◀

 Do not exceed a towing speed of 31 mph or 50 km/h and a towing distance of 31 miles/50 km; otherwise, the 7-gear sport automatic transmission may be damaged. ◀

Towing methods


 Do not lift the vehicle by a tow fitting or body and chassis parts; otherwise, damage may result. ◀

With a tow bar

 The towing vehicle must not be lighter than the towed vehicle; otherwise, it may be impossible to maintain control. ◀

The tow fittings used should be on the same side on both vehicles. Should it prove impossible to avoid mounting the tow bar at an angle, please observe the following:

- ▷ Clearance and maneuvering capability will be sharply limited during cornering.
- ▷ The tow bar will generate lateral forces if it is attached offset.

 Attach the tow bar to the tow fittings only, as attaching it to other parts of the vehicle could result in damage. ◀


With a tow rope

When starting off in the towing vehicle, make sure that the tow rope is taut.


⚠ To avoid jerking and the associated stresses on vehicle components when towing, always use nylon ropes or nylon straps. Attach the tow rope to the tow fittings only, as attaching it to other parts of the vehicle could result in damage. ◀

With a tow truck

Manual and automatic transmission:



7-gear sport automatic transmission with dual clutch:



Have the BMW transported with a tow truck with a so-called lift bar or on a flat bed.

Tow-starting

Avoid tow-starting the vehicle whenever possible; instead, jump-start the engine, refer to page 219. Vehicles with a catalytic converter should only be tow-started when the engine is cold.

Vehicles with an automatic transmission or 7-gear sport automatic transmission with dual clutch cannot be tow-started at all.

1. Switch on hazard warning flashers, comply with local regulations.
2. Switch on the ignition, refer to page 50.
3. Shift into 3rd gear.
4. Have the vehicle tow-started with the clutch depressed and slowly release the clutch. After the engine starts, immediately depress the clutch completely again.
5. Stop at a suitable location, remove the tow bar or rope and switch off the hazard warning flashers.
6. Have the vehicle checked.



Reference


This chapter contains technical data, short commands for the voice activation system and an index that will help you find information most quickly.

Technical data

Engine data

		Z4 sDrive30i	Z4 sDrive35i
Displacement	cu in/cm ³	182.8/2,996	181.8/2,979
Number of cylinders		6	6
Maximum power output	hp	255	300
at engine speed	rpm	6,600	5,800
Maximum torque	lb ft/Nm	220/298	300/407
at engine speed	rpm	2,600	1,400 - 5,000

Dimensions



All dimensions given in inches/mm.
Smallest turning circle diam.: 36 ft 1 in/11.0 m.

BMW

At a glance

Controls

Driving tips

Navigation

Entertainment

Communications

Mobility

Reference

Weights

		Z4 sDrive30i	Z4 sDrive35i
Approved gross weight			
▷ with manual transmission	lbs/kg	3,924/1,780	4,134/1,875
▷ with automatic transmission	lbs/kg	3,990/1,810	4,178/1,895
Load	lbs/kg	562/255	562/255
Approved front axle load	lbs/kg	1,808/820	1,918/870
Approved rear axle load	lbs/kg	2,227/1,010	2,271/1,030
Cargo area capacity	cu ft/l	6.4 - 10.9/180 - 310	6.4 - 10.9/180 - 310

Capacities

			Notes
Fuel tank	US gal/liters	Approx. 15.5/55	Fuel grade: page 193
Including reserve of	US gal/liters	Approx. 2.1/8.0	
Window washer system			For more details: page 61
Including headlamp washers	US qt/liters	Approx. 6.3/6.0	

Short commands for the voice activation system*

With short commands you can carry out certain functions directly, regardless of which menu

item is selected. Here are the important short commands for the voice activation system.

Useful short commands

Function	Command
Opening the music collection	›Music collection‹
Opening the tone control	›Tone‹
Selecting the settings	›Settings‹
Opening the computer	›Onboard info‹
Opening the contacts*	›Contacts‹
Displaying the phone book*	›Phonebook‹
Opening BMW Assist*	›B M W Assist‹
Opening the home address*	›Home address‹
Opening destination entry*	›Enter address‹

CD/Multimedia

CD/DVD drive

Function	Command
Playing back a CD	›C D on‹
Selecting a CD	›Select C D‹
Selecting a CD and track	›C D ... track ...‹ e.g., CD 3 track 5
Selecting a track	›C D track ...‹ e.g., track 5
Opening the CD and Multimedia menu	›C D and multimedia‹
CD and DVD	›C D and D V D‹
Selecting a DVD	›D V D ...‹ e.g., DVD 3
Displaying entertainment details on the split screen	›Entertainment details‹

Music collection

Function	Command
Calling up the current playback	›Current playback‹
Opening the music collection	›Music collection‹
Playing back a music collection	›Music collection on‹
Searching for music; opening the menu	›Music search‹
Playing back the most frequently played tracks	›Top fifty‹

External devices

Function	Command
Opening external devices	›External devices‹

Tone control

Function	Command
Opening the tone control	›Tone‹

Radio

FM

Function	Command
Calling up the radio	›Radio‹
Calling up an FM station	›F M‹
Opening manual search	›Manual search‹
Calling up a frequency	›Frequency ... megahertz‹ e.g., 93.5 megahertz or frequency 93.5
Selecting the frequency range	›Select frequency‹
Calling up a station	›Select station‹
Calling up a station directly	›Station ...‹ e.g., W-PLJ

AM

Function	Command
Calling up an AM station	›A M‹
Opening manual search	›Manual search‹
Calling up a frequency	›Frequency ... Kilohertz‹ e.g., frequency 753 or 753 kilohertz

Satellite radio

Function	Command
Calling up the satellite radio	›Satellite radio‹
Switching on the satellite radio	›Satellite radio on‹
Selecting a satellite radio channel	›Satellite radio channel ...‹ e.g., satellite radio channel 2

Presets

Function	Command
Calling up the stored stations	›Presets‹
Choosing a stored station	›Select preset‹
Selecting a stored station	›Preset ...‹ e.g., stored station 2

Telephone

Function	Command
Opening the Telephone menu	›Telephone‹
Displaying the phone book	›Phonebook‹
Redialing	›Redial‹
Displaying accepted calls	›Received calls‹
Dialing a phone number	›Dial number‹
List of messages	›Messages‹
Bluetooth devices	›Bluetooth‹

Navigation

General information

Function	Command
Navigation menu	›Navigation‹
Opening destination entry	›Enter address‹
Entering an address	›Enter address‹
Opening destination guidance	›Guidance‹
Starting destination guidance	›Start guidance‹
Ending destination guidance	›Stop guidance‹
Opening the home address	›Home address‹
Opening the route criteria	›Route preference‹
Opening the route	›Route information‹

Function	Command
Switching on the voice instructions	›Switch on voice instructions‹
Repeating a voice instruction	›Repeat voice instructions‹
Switching off the voice instructions	›Switch off voice instructions‹
Displaying the address book	›Address book‹
Displaying the last destinations	›Last destinations‹
Opening the traffic bulletins	›Traffic Info‹
Special destinations	›Points of interest‹

Map

Function	Command
Displaying the map	›Map‹
Map facing north	›Map facing north‹
Map in the direction of travel	›Map in direction of travel‹
Perspective map	›Map perspective view‹
Automatic scaling of the map*	›Map with automatic scaling‹
Scale...feet*	›Map scale ... feet‹ e.g., map scale of 100 feet
Scale...meters*	›Map scale ... meters‹ e.g., map scale of 100 meters
Scale...kilometers*	›Map scale ... kilometers‹ e.g., map scale of 5 kilometers
Scale...miles*	›Map scale ... miles‹ e.g., map scale of 5 miles
Scale...yards*	›Map scale ... yards‹ e.g., map scale of 100 yards

Split screen settings

Function	Command
Split screen	›Switch on splitscreen‹
Switching off the split screen	›Turn off split screen‹
Adapting the split screen	›Split screen content‹
Split screen map facing north	›Split screen map facing north‹
Split screen current position	›Split screen current position‹
Split screen direction of travel	›Split screen map in direction of travel‹
Split screen perspective	›Split screen perspective‹
Expanded intersection zoom on the split screen	›Splitscreen Exit ramp view‹
Split screen scale...feet*	›Split screen scale ... feet‹ e.g., split screen scale of 100 feet

Function	Command
Split screen scale...meters*	›Split screen scale ... meters‹ e.g., split screen scale of 100 meters
Split screen scale...kilometers*	›Split screen scale ... kilometers‹ e.g., split screen scale of 5 kilometers
Split screen scale...miles*	›Split screen scale ... miles‹ e.g., split screen scale of 5 miles
Split screen scale...yards*	›Split screen scale ... yards‹ e.g., split screen scale of 100 yards
Split screen, highlighting traffic bulletins	›Split screen, Traffic Info map‹
Split screen, computer	›Split screen on board info‹
Split screen, trip computer	›Splitscreen trip computer‹
Automatically scaling the split screen	›Split screen automatic scaling‹

Destination guidance with intermediate destination

Function	Command
Entering a new destination	›Enter address‹
Trip list	›Stored trips‹

Contacts

Function	Command
My contacts	›My contacts‹
Opening the contacts	›Contacts‹
New contact	›New contact‹

BMW Assist

Function	Command
Opening BMW Assist*	›B M W Assist‹
Opening BMW Search*	›B M W Search‹

Vehicle information

Function	Command
Opening the computer	›Onboard info‹
Opening the trip computer	›Trip computer‹
Opening the vehicle information	›Vehicle info‹
Opening the vehicle status	›Vehicle status‹

Settings

Vehicle

Function	Command
Opening the main menu	›Main menu‹
Selecting the settings	›Settings‹
Opening the options	›Options‹
Settings on the Control Display	›Control display‹
Opening the time and date settings	›Time and date‹
Opening the language and unit settings	›Language and units‹
Opening the speed limit settings	›Speed‹
Opening the light settings	›Lighting‹
Selecting the door lock	›Door locks‹

Everything from A to Z

Index

A

- ABS Antilock Brake System **78**
- Acceleration assistant, refer to Launch Control **58**
- Accident, refer to Sending an Emergency Request **218**
- Activated-charcoal filter for automatic climate control **98**
- Adaptive light control **89**
- Additional connection of the music player in the mobile phone **163**
- Additives
 - coolant **204**
 - engine oil **204**
- Address for navigation
 - entering **121**
- Adjusting temperature inside the car, refer to Air conditioner **94**
- Adjusting temperature inside the car, refer to Automatic climate control **96**
- Adjusting the thigh support **42**
- Adjusting the tone during audio operation, refer to Tone control **140**
- Airbags **85**
 - indicator/warning lamp **87**
 - sitting safely **41**
- Air conditioner **93**
- Air conditioning mode
 - air conditioner **94**
 - automatic climate control **96**
 - ventilation **95, 98**
- Air distribution
 - automatic **97**
 - individual **94**
 - manual **94**
- Air flow rate **94, 97**
- Airing, refer to Ventilation **95, 98**
- Air outlets, refer to Air vents **93**
- Air pressure, refer to Tire inflation pressure **194**
- Air recirculation, refer to Recirculated-air mode **94, 98**
- Air supply
 - air conditioner **94**
 - automatic climate control **96**
 - ventilation **95, 98**
- Air vents **93**
- AKI, refer to Fuel specifications **193**
- Alarm system **33**
 - avoiding unintentional alarms **34**
 - interior motion sensor **34**
 - switching off an alarm **34**
 - tilt alarm sensor **34**
- Albums of music collection **160**
- All-season tires, refer to Winter tires **200**
- AM, waveband **143**
- Ambient air, refer to Recirculated-air mode **94, 98**
- Antenna for mobile phone **170**
- Antifreeze
 - coolant **204**
 - washer fluid **61**
- Antilock Brake System ABS **78**
- Anti-theft alarm system, refer to Alarm system **33**
- Anti-theft system **29**
 - for lug bolts, refer to Lug bolt lock **215**
- Approved axle loads, refer to Weights **228**
- Approved engine oils, refer to Specified engine oils **204**
- Approved gross vehicle weight, refer to Weights **228**
- Armrest, refer to Center armrest **104**
- Arrival time, refer to Computer **66**
- Assistance systems, refer to Driving stability control systems **78**
- AUC automatic recirculated-air control **98**
- Audio **140**
 - controls **140**
 - switching on/off **140**
 - tone control **140**
 - volume **140**
- Audio device, external **104**
- Automatic
 - air distribution **97**
 - air flow rate **97**
 - cruise control **61**
 - headlamp control **88**
- Automatic car washes **208**
- Automatic climate control **93**
 - automatic air distribution **97**
- Automatic curb monitor **46**

Automatic high beams and low beams, refer to High-beam assistant [90](#)

Automatic recirculated-air control AUC [98](#)

Automatic Service Request [188](#)

Automatic transmission with Steptronic [53](#)

- interlock [53, 54](#)
- overriding selector lever lock [55](#)
- shiftlock, refer to Changing selector lever position [54](#)
- sport program [54](#)
- towing [220](#)
- tow-starting [220](#)

AUTO program for automatic climate control [97](#)

AUX-IN port [104, 163](#)

Available services [188](#)

Average fuel consumption [66](#)

- setting the units [68](#)

Average speed [66](#)

Avoid highways in navigation [130](#)

Avoiding unintentional alarms [34](#)

Axle loads, refer to Weights [228](#)

B

Backrest contour, refer to Lumbar support [43](#)

Backrests, refer to Seat adjustment [42](#)

Backrest width adjustment [43](#)

Backup lamps

- replacing bulb [214](#)

Backup lamps, refer to Tail lamps [214](#)

Band-aids, refer to First-aid pouch [219](#)

Bar, refer to Towing methods [221](#)

Base plate for telephone or mobile phone

- refer to Snap-in adapter [180](#)
- refer to Snap-in adapter in the center armrest storage compartment [104](#)

Bass, tone setting [140](#)

Battery [216](#)

- charging [216](#)
- disposal [36, 216](#)
- jump-starting [219](#)
- remote control [28](#)
- temporary power failure [216](#)

Battery for mobile phone [181](#)

Battery renewal

- remote control [36](#)
- remote control for vehicle [36](#)

Being towed [221](#)

Belts, refer to Safety belts [44](#)

Belt tensioner, refer to Safety belts [44](#)

Beverage holders, refer to Cupholders [105](#)

Blower, refer to Air flow rate [94, 97](#)

Bluetooth, activating/deactivating [173](#)

Bluetooth, refer to separate Owner's Manual

BMW

- car shampoo [211](#)

BMW Assist, activating [186, 188](#)

BMW Assist [184](#)

BMW Homepage [4](#)

BMW Maintenance System [206](#)

BMW Search [186](#)

BMW webpage [4](#)

Bottle holders, refer to Cupholders [105](#)

Brake

- parking brake [52](#)

Brake Assist, refer to Dynamic Brake Control DBC [78](#)

Brake fluid, refer to Service requirements [69](#)

Brake Force Display [85](#)

Brake lamps

- Brake Force Display [85](#)
- replacing bulb [214](#)

Brake pads [112](#)

- breaking in [112](#)

Brake rotors [114](#)

- brakes [112](#)
- breaking in [112](#)

Brakes

- ABS [78](#)
- BMW Maintenance System [206](#)
- breaking in [112](#)
- service requirements [69](#)

Brakes, refer to Braking safely [114](#)

Brake system [112](#)

- BMW Maintenance System [206](#)
- breaking in [112](#)
- disc brakes [114](#)

Breakdown services, refer to Roadside Assistance [218](#)

Breaking in the clutch [112](#)

Breaking in the differential, refer to Engine and differential [112](#)

Break-in period [112](#)

Brightness of Control Display [76](#)

Bulb changing, refer to Lamps and bulbs [212](#)

Button for starting the engine, refer to Start/stop button [50](#)

Buttons on the steering wheel [11](#)

C

California Proposition 65 warning [6](#)

- Call
 - accepting 174
 - ending 174
 - rejecting 174
- Calling, refer to Phone numbers, dialing 174
- Can holders, refer to Cupholders 105
- Capacities 228
- Capacity of the cargo area 228
- Car battery, refer to Vehicle battery 216
- Car care, refer to Care 208
- Care 208
 - automatic car washes 208
 - care products 208
 - carpets 210
 - CD/DVD drives 211
 - chrome parts 210
 - displays 211
 - exterior 208
 - fine wood parts 211
 - headlamps 209
 - high-pressure washer 209
 - interior 210
 - leather 210
 - light-alloy wheels 210
 - paintwork 209
 - plastic parts 211
 - retractable hardtop 209
 - rubber seals 210
 - safety belts 211
 - sensors and cameras 211
 - upholstery and cloth trim 210
 - washing the car manually 209
 - windows 209
- Cargo, securing 116
- Cargo area
 - capacity 228
 - Comfort Access 35
 - lamp, refer to Interior lamps 92
 - opening from inside 32
 - opening from outside 33
- Cargo loading
 - securing cargo 116
 - stowing cargo 116
 - vehicle 115
- Car jack
 - jacking points 215
- Car key, refer to Integrated key/remote control 28
- Car phone
 - installation location, refer to Center armrest 104
 - refer to separate Owner's Manual
- Car phone, refer to Telephone 170
- Car radio, refer to Radio 143
- Car shampoo 211
- Car wash 115
 - with Comfort Access 36
- Car wash, refer to the Caring for your vehicle brochure
- Catalytic converter, refer to Hot exhaust system 113
- CBS Condition Based Service 206
- CD, audio playback 152
- CD/DVD changer
 - filling or emptying the magazine 156
- CD changer 151, 155
 - controls 140
 - fast forward/reverse 153
 - random play sequence 152
 - selecting a track 152
 - switching on/off 140
 - tone control 140
 - volume 140
- CD player 151
 - controls 140
 - fast forward/reverse 153
 - random play sequence 152
 - selecting a track 152
 - switching on/off 140
 - tone control 140
 - volume 140
- Center armrest 104
- Center brake lamp
 - replacing bulb 215
- Center console, refer to
 - Around the center console 14
- Central locking
 - from inside 32
 - from outside 29
- Central locking system 29
 - Comfort Access 34
 - setting unlocking characteristics 29
- Changes, technical, refer to For your own safety 5
- Changing bulbs, refer to Lamps and bulbs 212
- Changing the measurement units on the Control Display 68
- Changing wheels 215
- Chassis number, refer to Engine compartment 202
- Check Control 73
- Child restraint systems 48
- Child seats, refer to Transporting children safely 48
- Chrome parts 211
- Chrome polish 211
- Cleaning headlamps 61
 - washer fluid 61
- Cleaning your BMW, refer to Care 208
- Clock 64
 - 12h/24h mode 72
 - setting the time and date 72
 - setting time 71
- Closing
 - from inside 32
 - from outside 29
- Cockpit 10
- Cold start, refer to Starting the engine 51
- Combined instrument, refer to Instrument cluster 12
- Comfort Access 34
 - replacing the battery 36
 - what to observe before entering a car wash 36
- Comfort access, refer to Comfort Access 34

Comfort area, refer to Around the center console [14](#)
Compartment for remote control, refer to Ignition lock [50](#)
Compass [102](#)
Computer [65](#)
– displays on Control Display [66](#)
Computer, refer to iDrive [16](#)
Concierge service [185](#)
Condensation, refer to When the vehicle is parked [114](#)
Condition Based Service CBS [206](#)
Configuring settings, refer to Personal Profile [28](#)
Confirmation signals for locking/unlocking the vehicle [31](#)
Congestion
– refer to Route, bypassing sections [131](#)
Connecting vacuum cleaner, refer to Connecting electrical appliances [106](#)
Consumption, refer to Average consumption [66](#)
Consumption display
– average consumption [66](#)
Contacts
– creating [182](#)
Control Center, refer to iDrive [16](#)
Control Display, refer to iDrive [16](#)
– adjusting brightness [76](#)
Controller, refer to iDrive [16](#)
controls and displays [10](#)
Control unit, refer to iDrive [16](#)
Convenient loading [30](#)
Convenient operation [31](#)
– retractable hardtop [30](#)
– windows [30](#)
Convertible
– enlarging cargo area [38](#), [106](#)
Coolant [204](#)
– checking level [204](#)
Coolant temperature [65](#)

Cooling, maximum [97](#)
Cooling fluid, refer to Coolant [204](#)
Cooling system, refer to Coolant [204](#)
Copyright [2](#)
Corner-illuminating lamps, refer to Adaptive light control [89](#)
Cornering lamps, refer to Adaptive light control [89](#)
Correct tires [199](#)
Country codes DVD [153](#)
Courtesy lamps, refer to Interior lamps [92](#)
Criteria for route [130](#)
Cross-hairs in navigation [126](#)
Cruise control [61](#)
– malfunction [63](#)
Cruising range [66](#)
Cupholders [105](#)
Curb weight, refer to Weights [228](#)
Current playback
– external devices [165](#)
– of music collection [160](#)
Customer Relations [187](#)

D

Dashboard, refer to Cockpit [10](#)
Dashboard, refer to Instrument cluster [12](#)
Dashboard lighting, refer to Instrument lighting [91](#)
Data, technical [226](#)
– dimensions [227](#)
– engine [226](#)
– weights [228](#)
Data recorders [207](#)
Data transfer [188](#)
Date
– date format [73](#)
– setting [72](#)
Daytime running lights [89](#)
DBC Dynamic Brake Control [78](#)
DCC, refer to Cruise control [61](#)
Deactivating passenger airbags [86](#)
Deadlocking, refer to Locking [30](#)
Defect
– door lock [31](#)
– fuel filler flap [192](#)
Defogging windows [95](#)
Defrosting windows [95](#)
Defrost position, refer to Defrosting windows [95](#)
Destination, entering by town/city name [121](#)
Destination address
– entering [121](#), [127](#)
Destination entry via BMW Assist [125](#)
Destination for navigation
– entering by voice [127](#)
– entering via map [126](#)
– entry [121](#)
– home address [124](#)
– manual entry [121](#)
Destination guidance [130](#)
– bypassing a route section [131](#)
– changing specified route [130](#)
– continuing [130](#)
– starting [130](#)
– voice instructions [132](#)
– volume of voice instructions [132](#)
Detour, selecting [136](#)
Digital clock [64](#)
Digital compass [102](#)
Digital radio, refer to HD Radio [144](#)
Dimensions [227](#)
Directional indicators, refer to Turn signals [59](#)
Direction instructions, refer to Voice instructions [132](#)
Directory for navigation, refer to Address book [123](#)
Displacement, refer to Engine data [226](#)

- Display, refer to iDrive controls [16](#)
 - Display lighting, refer to Instrument lighting [91](#)
 - Displays
 - on the Control Display [16](#)
 - Displays, refer to Instrument cluster [12](#)
 - Displays and controls [10](#)
 - Disposal
 - coolant [204](#)
 - remote control battery [36](#)
 - vehicle battery [216](#)
 - Distance remaining to service, refer to Service requirements [69](#)
 - Distance warning, refer to Park Distance Control PDC [77](#)
 - Door key, refer to Remote control with integrated key [28](#)
 - Door lock [31](#)
 - Doors, emergency operation [31](#)
 - DOT Quality Grades [197](#)
 - Draft-free ventilation [95, 98](#)
 - Drinks holders, refer to Cupholders [105](#)
 - Drive mode [56](#)
 - Drive-off assistance, refer to Dynamic Stability Control DSC [78](#)
 - Drive-off assistant [80](#)
 - Driving lamps, refer to Parking lamps/low beams [88](#)
 - Driving notes [112](#)
 - Driving off on hills, refer to Drive-off assistant [80](#)
 - Driving position, engaging, refer to Transmission positions [56](#)
 - Driving stability control systems [78, 79](#)
 - Driving through water [114](#)
 - Driving tips, refer to Driving notes [112](#)
 - DSC Dynamic Stability Control [78](#)
 - Dual clutch transmission [55](#)
 - kickdown [56](#)
 - DVD
 - country codes [153](#)
 - settings [154](#)
 - video playback [153](#)
 - DVD changer [155](#)
 - malfunctions [157](#)
 - DVD changer, refer to CD changer [151](#)
 - DVD menu [154](#)
 - DVD player, refer to CD player [151](#)
 - DVD video [153](#)
 - Dynamic Brake Control DBC [78](#)
 - Dynamic destination guidance [131](#)
 - Dynamic Driving Control [79](#)
- ## E
- Eject button, refer to Buttons on the CD/DVD player [140](#)
 - Electrical malfunction
 - door lock [31](#)
 - driver's door [31](#)
 - fuel filler flap [192](#)
 - M dual clutch transmission with Drivelogic [58](#)
 - Electric seat adjustment [42](#)
 - Electric steering wheel lock
 - with Comfort Access [35](#)
 - Electronic brake-force distribution EBV [78](#)
 - Electronic oil level check [202](#)
 - Electronic Stability Program ESP, refer to Dynamic Stability Control DSC [78](#)
 - Emergency actuation, automatic transmission, refer to Overriding selector lever lock [55](#)
 - Emergency operation
 - fuel filler flap, manual release [192](#)
 - Emergency operation, refer to Manual operation
 - door lock [31](#)
 - Emergency release
 - luggage compartment lid from inside [33](#)
 - Emergency Request [218](#)
 - Emergency services, refer to Roadside Assistance [218](#)
 - Energy, saving
 - saving fuel [112](#)
 - Engine
 - breaking in [112](#)
 - data [226](#)
 - overheated, refer to Coolant temperature [65](#)
 - speed [226](#)
 - starting [51](#)
 - starting, Comfort Access [34](#)
 - switching off [52](#)
 - Engine compartment [202](#)
 - Engine coolant, refer to Coolant [204](#)
 - Engine oil
 - adding [204](#)
 - additives, refer to Specified engine oils [204](#)
 - alternative oil types [204](#)
 - BMW Maintenance System [206](#)
 - capacity [228](#)
 - checking level [202](#)
 - intervals between changes, refer to Service requirements [69](#)
 - specified engine oils [204](#)
 - Engine output, refer to Engine data [226](#)
 - Engine speed, refer to Engine data [226](#)
 - Engine starting, refer to Starting the engine [51](#)
 - Entering special destinations by name [126](#)
 - Entering the address [121, 127](#)
 - Entry lamps, refer to Interior lamps [92](#)
 - Entry map for destination [126](#)
 - Equalizer, tone setting [141](#)
 - Error messages, refer to Check Control [73](#)

Exhaust system, refer to Hot exhaust system [113](#)
Exterior mirrors [45](#)
– adjusting [45](#)
– automatic dimming feature [46](#)
– automatic heating [46](#)
– folding in and out [45](#)
External audio device [104](#)
Eyes
– for tow-starting and towing away [220](#)
– for tying down loads [116](#)

F

Failure messages, refer to Check Control [73](#)
Failure of an electrical consumer [216](#)
False alarm
– avoiding unintentional alarm [34](#)
– switching off an alarm [34](#)
Fastening safety belts, refer to Safety belts [44](#)
Fastest route for navigation [130](#)
Fast forward
– CD changer [153](#)
– CD player [153](#)
Fault
– parking brake [53](#)
Filter
– refer to Microfilter/activated-charcoal filter for automatic climate control [98](#)
– refer to Microfilter for air conditioner [95](#)
First aid pouch [219](#)
Fixture for remote control, refer to Ignition lock [50](#)
Flash when locking/unlocking [31](#)
Flat tire
– run-flat tires [199](#)
– Tire Pressure Monitor TPM [82](#)

Flat Tire Monitor FTM [81](#)
– indicating a flat tire [81](#)
– indicator/warning lamp [81](#)
– initializing the system [81](#)
– snow chains [81](#), [200](#)
– system limits [81](#)
Flat tires, refer to Tire condition [198](#)
Fluid reservoir, refer to Washer fluid reservoir [61](#)
FM, waveband [143](#)
Folding in the mirrors, before driving into a car wash [45](#)
Footbrake, refer to Braking safely [114](#)
Footwell lamps, refer to Interior lamps [92](#)
Forward gear, engaging, refer to Transmission positions [56](#)
For your own safety [5](#)
Free memory capacity, music collection [161](#)
Front airbags [85](#)
FTM, refer to Flat Tire Monitor [81](#)
Fuel [193](#)
– average consumption [66](#)
– gauge [65](#)
– high-quality brands [193](#)
– quality [193](#)
– specifications [193](#)
– tank contents, refer to Capacities [228](#)
Fuel clock, refer to Fuel gauge [65](#)
Fuel display, refer to Fuel gauge [65](#)
Fuel filler flap [192](#)
– releasing in the event of electrical malfunction [192](#)
Fuses [216](#)

G

Garage door opener, refer to Integrated universal remote control [100](#)

Gasoline
– refer to Average consumption [66](#)
Gasoline, refer to Required fuel [193](#)
Gasoline display, refer to Fuel gauge [65](#)
Gas station recommendations [131](#)
Gear display, refer to Displays in the instrument cluster [56](#)
Gear indicator, automatic transmission with Steptronic [53](#)
Gears, changing [57](#)
Gearshift lever
– automatic transmission with Steptronic [54](#)
– manual transmission [53](#)
Gearshifts
– automatic transmission with Steptronic [54](#)
– manual transmission [53](#)
General driving notes [113](#)
Glove compartment [103](#)
GPS navigation, refer to Navigation system [120](#)
Grills, refer to Air vents [93](#)
Gross vehicle weight, refer to Weights [228](#)

H

Handbrake, refer to Parking brake [52](#)
Hands-free system [14](#)
Hazard warning flashers [14](#)
HD Radio [144](#)
Head airbags [85](#)
Headlamp control, automatic [88](#)
Headlamp flasher [59](#)
– indicator lamp [11](#), [13](#)
Heated
– mirrors [46](#)
– rear window [95](#), [98](#)
– seats [43](#)

- Heating [93](#)
 - mirrors [46](#)
 - rear window [95, 98](#)
 - seats [43](#)
 - Heating and ventilation, refer to Climate [93](#)
 - Heavy loads, refer to Stowing cargo [116](#)
 - Height, refer to Dimensions [227](#)
 - Height adjustment
 - seats [42](#)
 - steering wheel [46](#)
 - High-beam assistant [90](#)
 - High beams [90](#)
 - headlamp flasher [90](#)
 - indicator lamp [13](#)
 - High beams and low beams, automatic, refer to High-beam assistant [90](#)
 - High-pressure washer [208, 209](#)
 - High water, refer to Driving through water [114](#)
 - Highways, refer to Route criteria [130](#)
 - Hills [114](#)
 - Holders for cups [105](#)
 - Homepage BMW [4](#)
 - Hood [201](#)
 - Horn [10, 11](#)
 - Hot exhaust system [113](#)
 - Hydraulic brake assist, refer to Dynamic Brake Control DBC [78](#)
 - Hydroplaning [113](#)
- I**
- IBOC, refer to HD Radio [144](#)
 - Ice warning, refer to Outside temperature warning [64](#)
 - Identification marks
 - run-flat tires [199](#)
 - tire coding [197](#)
 - iDrive [16](#)
 - adjusting brightness [76](#)
 - changing language [75](#)
 - changing settings [75](#)
 - changing units of measure and display format [68](#)
 - controls [16](#)
 - menu guidance [17](#)
 - operating principle [16](#)
 - overview [16](#)
 - setting the date and time [71, 72](#)
 - status information [20](#)
 - iDrive operating principle [16](#)
 - Ignition [50](#)
 - switched off [50](#)
 - switched on [50](#)
 - Ignition key, refer to Remote control with integrated key [28](#)
 - Ignition key position 1, refer to Radio readiness [50](#)
 - Ignition key position 2, refer to Ignition on [50](#)
 - Ignition lock [50](#)
 - Imprint [2](#)
 - Indicator and warning lamps [13](#)
 - Tire Pressure Monitor TPM [83](#)
 - Individual air distribution [94](#)
 - Inflation pressure, refer to Tire inflation pressure [194](#)
 - Inflation pressure monitoring, refer to Tire Pressure Monitor TPM [82](#)
 - Initializing
 - after power failure [216](#)
 - compass, refer to Calibrating [103](#)
 - Flat Tire Monitor FTM [81](#)
 - radio, refer to Station, storing [144](#)
 - refer to Setting the time and date [72](#)
 - Installation location
 - telephone [104](#)
 - Instructions for navigation system, refer to Voice instructions [132](#)
 - Instrument cluster [12](#)
 - Instrument lighting [91](#)
 - Instrument panel, refer to Cockpit [10](#)
 - Integrated key [28](#)
 - Integrated universal remote control [100](#)
 - Interactive map [127](#)
 - Interior lamps [92](#)
 - remote control [30](#)
 - Interior motion sensor [34](#)
 - Interior rearview mirror [46](#)
 - automatic dimming feature [46](#)
 - compass [102](#)
 - Interlock, refer to Disengaging the remote control [53](#)
 - Intermittent mode of the wipers [60](#)
 - Intersection, entering, navigation [122](#)
 - iPod, connecting, refer to AUX-IN port [163](#)
 - iPod, connecting, refer to USB audio interface [163](#)
- J**
- Jacking points [215](#)
 - Joystick, refer to iDrive [16](#)
 - Jumpering, refer to Jump-starting [219](#)
 - Jump-starting [219](#)
- K**
- Key, refer to Integrated key/remote control [28](#)
 - Keyless go, refer to Comfort Access [34](#)

Keyless opening and closing, refer to Comfort Access [34](#)
Key Memory, refer to Personal Profile [28](#)
Kickdown [54](#)
– automatic transmission with Steptronic [54](#)
Knock control [193](#)

L

Lamps
– automatic headlamp control [88](#)
– parking lamps/low beams [88](#)
Lamps and bulbs, replacing bulbs [212](#)
Language, changing on Control Display [75](#)
Lap-and-shoulder belt, refer to Safety belts [44](#)
Lashing eyes, refer to Securing cargo [116](#)
Last destinations [124](#)
Launch Control [58](#)
Leather care [210](#)
LED Light-emitting diodes [212](#)
Length, refer to Dimensions [227](#)
License plate lamp, replacing bulb [215](#)
Light
– high-beam assistant [90](#)
– refer to High-beam assistant [90](#)
Light-alloy wheels [210](#)
Light-emitting diodes LED [212](#)
Lighter
– connecting electrical appliances [106](#)
Lighting
– instruments [91](#)
– lamps and bulbs [212](#)
– vehicle, refer to Lamps [88](#)

Light switch [88](#)
Limit, refer to Speed limit [74](#)
Load securing equipment, refer to Securing cargo [116](#)
Lockable lug bolts, refer to Lug bolt lock [215](#)
Lock buttons, doors, refer to Locking [32](#)
Locking
– adjusting confirmation signal [31](#)
– from inside [32](#)
– from outside [30](#)
– without remote control, refer to Comfort Access [34](#)
Locking and unlocking doors
– confirmation signals [31](#)
– from inside [32](#)
– from outside [29](#)
Low beam control, refer to High-beam assistant [90](#)
Low-beam headlamps [88](#)
– automatic [88](#)
Lower back support, refer to Lumbar support [43](#)
Lug bolt lock [215](#)
Luggage compartment lid [32](#)
– Comfort Access [35](#)
– emergency release [33](#)
– opening from inside [32](#)
– opening from outside [33](#)
– remote control [30](#)
Lumbar support [43](#)

M

M+S tires, refer to Winter tires [200](#)
Maintenance, refer to Service Booklet
Maintenance system [206](#)
Malfunction
– automatic transmission with Steptronic [55](#)
– tires [81](#)

Malfunction warnings, refer to Check Control [73](#)
Managing music [161](#)
Manual air distribution [94](#)
Manual car wash [209](#)
Manual mode, automatic transmission with Steptronic [54](#)
Manual operation
– door lock [31](#)
– driver's door [31](#)
– fuel filler flap [192](#)
– transmission lock [58](#)
– transmission lock, automatic transmission [55](#)
Manual transmission [53](#)
Map display [132](#)
Map for navigation
– changing scale [133](#)
– entering destination [126](#)
Master key, refer to Remote control with integrated key [28](#)
Maximum cooling [97](#)
Maximum speed
– with winter tires [200](#)
M dual clutch transmission with Drivelogic
– Launch Control [58](#)
– manually releasing transmission lock [58](#)
– neutral [56](#)
– reverse gear [56](#)
Measurements, refer to Dimensions [227](#)
Memory, refer to Seat and mirror memory [43](#)
MENU button [16](#)
Menus, refer to iDrive [16](#)
Messages [176](#)
Messages from the concierge service [177](#)

- Microfilter
 - BMW Maintenance System [206](#)
 - for air conditioner [95](#)
 - for automatic climate control [98](#)
 - Microfilter/activated-charcoal filter
 - BMW Maintenance System [206](#)
 - Mirror dimming feature [46](#)
 - Mirrors [45](#)
 - automatic curb monitor [46](#)
 - exterior mirrors [45](#)
 - heating [46](#)
 - interior rearview mirror [46](#)
 - memory, refer to Seat and mirror memory [43](#)
 - Mobile phone
 - adjusting volume [173](#)
 - connecting, refer to Mobile phone, pairing [170](#)
 - installation location, refer to Center armrest [104](#)
 - operation via iDrive [173](#)
 - pairing [170](#)
 - refer to separate Owner's Manual
 - Mobile phone, installation location, refer to Center armrest [104](#)
 - Mobile phone, refer to Telephone [170](#)
 - Mobile phone, refer to the separate Owner's Manual
 - Modifications, technical, refer to For your own safety [5](#)
 - Monitor, refer to iDrive controls [16](#)
 - Monitoring system for tire pressures, refer to Flat Tire Monitor [81](#)
 - MP3 player, connecting, refer to AUX-IN port [163](#)
 - MP3 player, connecting, refer to USB audio interface [163](#)
 - Multi-channel playback [141](#)
 - Multifunctional steering wheel, refer to Buttons on the steering wheel [11](#)
 - Multifunction switch
 - refer to Turn signals/headlamp flasher [59](#)
 - refer to Wiper system [60](#)
 - Multimedia screen, refer to iDrive [16](#)
 - Music, playing [159](#)
 - Music collection [158](#)
 - backup [162](#)
 - deleting [162](#)
 - random sequence [161](#)
 - restoring [162](#)
 - Music player, connecting, refer to AUX-IN port [163](#)
 - Music player, connecting, refer to USB audio interface [163](#)
 - Music search [159](#)
 - My Info [177](#)
- ## N
- Navigation
 - starting destination guidance after entering a destination [123](#)
 - storing current position [123](#)
 - voice activation [127](#)
 - Navigation announcements, refer to Switching voice instructions on/off [132](#)
 - Navigation data [120](#)
 - Navigation system [120](#)
 - address book [123](#)
 - bypassing a route section [131](#)
 - continuing destination guidance [130](#)
 - destination entry [121](#)
 - dynamic destination guidance [131](#)
 - entering a destination by voice [127](#)
 - entering a destination manually [121](#)
 - frequently asked questions [137](#)
 - gas station recommendations [131](#)
 - planning a trip [128](#)
 - route list [131](#)
 - selecting destination via map [126](#)
 - selecting route criteria [130](#)
 - special destinations [124](#)
 - starting destination guidance [130](#)
 - terminating destination guidance [130](#)
 - traffic bulletins [133](#)
 - voice instructions [132](#)
 - volume adjustment [132](#)
 - Nets, refer to Storage compartments [104](#)
 - Neutral [56](#)
 - New tires [199](#)
 - NORMAL program, Dynamic Driving Control [79](#), [80](#)
 - North-facing map [132](#)
 - Number of cylinders, refer to Engine data [226](#)
 - Nylon rope, refer to Tow rope [222](#)

O

- OBD socket, refer to Socket for Onboard Diagnosis 207
- Octane ratings, refer to Fuel specifications 193
- Odometer 64
- Oil, refer to Engine oil 202
- Oil consumption 202
- Oil level 202
- Old batteries, refer to Disposal 216
- Onboard vehicle tool kit 212
- Opening and closing
 - Comfort Access 34
 - from inside 32
 - from outside 29
 - using the door lock 31
 - via the remote control 29
- Options, selecting for navigation 130
- Outlets
 - refer to Ventilation 95, 98
- Outlets, refer to Air vents 93
- Output, refer to Engine data 226
- Outside-air mode
 - automatic climate control 98
- Outside temperature display 64
- changing units of measure 68
- in computer 68
- Outside temperature warning 64
- Overheated engine, refer to Coolant temperature 65
- Overriding selector lever lock 55
- Overview
 - radio control 140

P

- Paintwork care 209

- Park assistant, refer to Park Distance Control 77
- Park Distance Control PDC 77
- Parking
 - vehicle 52
- Parking aid, refer to Park Distance Control PDC 77
- Parking brake 52
- Parking lamps 88
- Parking lamps/low beams 88
- Passenger-side mirror tilt function 46
- Pathway lighting 89
- Personal Profile 28
- Phone book 173
- Phone numbers
 - dialing 174
- Pinch protection system
 - windows 37
- Placing a call, refer to telephone owner's manual
- Polish 211
- Pollen
 - refer to Microfilter/activated-charcoal filter for automatic climate control 98
 - refer to Microfilter for air conditioner 95
- Postal code, entering for navigation 122
- Power failure 216
- Power windows 37
- Power windows, refer to Windows 36
- Pressure, tires 194
- Pressure monitoring, tires 81
 - Flat Tire Monitor 81
- Pressure monitoring of tires, refer to Tire Pressure Monitor TPM 82
- Programmable buttons on the steering wheel 11
- Protection function, refer to Pinch protection system
 - windows 37

- Providing medical assistance, refer to First aid pouch 219
- Puncture
 - Flat Tire Monitor 81

R

- Radio
 - controls 140
 - HD Radio 144
 - satellite radio 146
 - selecting a waveband 143
 - storing stations 144
 - switching on/off 140
 - tone control 140
 - volume 140
- Radio position, refer to Radio readiness 50
- Radio readiness 50
 - switched off 50
 - switched on 50
- Radio-remote key, refer to Remote control with integrated key 28
- Rain sensor 60
- Random sequence
 - CD changer 152
 - CD player 152
 - external devices 165
 - music collection 161
- Reading lamps 92
- Rear fog lamps
 - indicator lamp 13
- Rear lamp, refer to Tail lamps
 - replacing bulb 214
- Rear lamps, refer to Tail lamps 214
- Rear turn signals
 - replacing bulb 214
- Rearview mirror, refer to Mirrors 45
- Rear window defroster 95, 98
- Receiving level of mobile phone, refer to Status information 20

Reception
 – quality 144
 – radio station 144
 Recirculated-air mode 94, 98
 Recirculation of air, refer to
 Recirculated-air
 mode 94, 98
 Reclining seat, refer to
 Backrest 42
 Refueling 192
 Releasing
 – hood 201
 Remaining distance, refer to
 Cruising range 66
 Remote control 28
 – battery renewal 36
 – Comfort Access 34
 – garage door opener 100
 – luggage compartment lid 30
 – malfunction 31, 36
 – removing from the ignition
 lock 50
 – service data 206
 Replacement remote
 control 28
 Replacing bulbs, refer to
 Lamps and bulbs 212
 Replacing tires 199
 Replacing tires, refer to New
 wheels and tires 199
 Reporting safety defects 6
 Reserve warning, refer to Fuel
 gauge 65
 Reset, refer to Resetting tone
 settings 142
 Restraint systems
 – for children 48
 – refer to Safety belts 44
 Retractable hardtop
 – care, refer to Caring for your
 vehicle brochure
 – convenient operation 30
 – opening and closing 39
 – remote control 30
 retractable hardtop 38
 Reverse
 – CD changer 153
 – CD player 153

Reverse gear 56
 – automatic transmission with
 Steptronic 54
 – manual transmission 53
 Road map 132
 Roadside
 Assistance 185, 218
 Roadside parking lamps 90
 Roadworthiness test, refer to
 Service requirements 69
 Roof load capacity 228
 Rope, refer to Tow-starting,
 towing away 222
 Rotary/pushbutton, refer to
 iDrive 16
 Route 130, 131
 – bypassing sections 131
 – changing 130, 131
 – changing criteria 130
 – displaying streets or towns/
 cities 131
 – map display 132
 – selecting 130
 Route instructions, refer to
 Destination guidance
 through voice
 instructions 132
 Route map, refer to Map
 display 132
 Route section, changing 131
 Route selection 130
 RSC Runflat System
 Component, refer to Run-
 flat tires 199
 Runflat System Component
 RSC, refer to Run-flat
 tires 199
 Run-flat tires 199
 – continuing driving with a
 damaged tire 82
 – flat tire 81
 – Flat Tire Monitor 81
 – new tires 199
 – replacing 199
 – tire inflation pressure 194
 – winter tires 200

S

Safety-belt height
 adjustment 45
 Safety belts 44
 – damage 45
 – indicator/warning lamp 45
 – reminder 45
 – sitting safely 41
 Safety systems
 – airbags 85
 – Antilock Brake System
 ABS 78
 – brake system 78
 – driving stability control
 systems 78
 – Dynamic Stability Control
 DSC 78
 – safety belts 44
 Safety tires, refer to Run-flat
 tires 199
 Satellite radio 146
 – enabling or unsubscribing
 from a channel 146
 – favorites 148
 – selecting channel 147
 – storing channel 147
 – timeshift 148
 – Traffic Jump 149
 Saving fuel 112
 Screen, refer to iDrive
 controls 16
 Screw thread for tow
 fitting 220
 SDARS, refer to Satellite
 radio 146
 Seat adjustment
 – electric 42
 – mechanical 42
 Seat and mirror memory 43
 Seat belt reminder, refer to
 "Fasten safety belts"
 reminder 45
 Seat heating 43

- Seats [41](#)
 - adjusting electrically [42](#)
 - adjusting the seats [42](#)
 - heating [43](#)
 - memory, refer to Seat and mirror memory [43](#)
 - saving a setting, refer to Seat and mirror memory [43](#)
 - sitting safely [41](#)
- Securing cargo [107](#)
- Securing the vehicle
 - from inside [32](#)
 - from outside [29](#)
- Selecting new scale for navigation [133](#)
- Selector lever [56](#)
 - automatic transmission with Steptronic [54](#)
- Selector lever lock, refer to Changing selector lever positions, shiftlock [54](#)
- Selector lever positions
 - automatic transmission with Steptronic [54](#)
- Service, refer to Roadside Assistance [218](#)
- Service car, refer to Roadside Assistance [218](#)
- Service data in the remote control [206](#)
- Service Interval Display, refer to Condition Based Service CBS [206](#)
- Service Request [187](#)
- Service requirement display, refer to Condition Based Service CBS [206](#)
- Service requirements [69](#)
- Services status [188](#)
- Servotronic [85](#)
- Settings
 - changing on Control Display [75](#)
 - clock, 12h/24h mode [72](#)
 - DVD [154](#)
 - language [75](#)
- Settings and information [68](#)
- Settings for the map display [133](#)
- Shifting [57](#)
- Shifting, sport automatic transmission [57](#)
- Shifting gears
 - automatic transmission with Steptronic [54](#)
 - manual transmission [53](#)
- Shiftlock
 - automatic transmission, refer to Changing selector lever positions [54](#)
- Shift paddles on steering wheel [57](#)
- Short commands for the voice activation system [229](#)
- Short route in navigation, refer to Selecting route [130](#)
- Side airbags [85](#)
- Side windows, refer to Windows [36](#)
- Signal horn, refer to Horn [10](#), [11](#)
- Sitting safely [41](#)
 - with airbags [41](#)
 - with safety belts [41](#)
- Ski bag for convertible, refer to Through-loading opening with integrated transport bag [106](#)
- Slot for remote control [50](#)
- Snap-in adapter
 - inserting/removing [180](#)
 - use [170](#)
- Snap-in adapter, refer to Center armrest storage compartment [104](#)
- Socket, Onboard Diagnosis OBD [207](#)
- Socket, refer to Connecting electrical appliances [106](#)
- SOS, refer to Sending an Emergency Request [218](#)
- Sound output for entertainment on/off [140](#)
- Spare fuses, [216](#)
- Spare fuses, refer to Fuses [216](#)
- Special destinations [124](#)
- Special destinations, displaying [126](#)
- Special oils, refer to Specified engine oils [204](#)
- Specified engine oils [204](#)
- Speed
 - run-flat tires [82](#)
 - with winter tires [200](#)
- Speed limit [74](#)
- Speed limit warning, refer to Speed limit [74](#)
- Speedometer [12](#)
- Speed Volume [142](#)
- SPORT+ program, Dynamic Driving Control [79](#), [80](#)
- SPORT program, Dynamic Driving Control [79](#), [80](#)
- Sport program with sport automatic transmission [57](#)
- Spray nozzles, refer to Cleaning windshield and headlamps [61](#)
- Stability control, refer to Driving stability control systems [78](#), [79](#)
- Start/stop button [50](#)
 - starting the engine [51](#)
 - switching off the engine [52](#)
- Starting, refer to Starting the engine [51](#)
- Starting assistance, refer to Jump-starting [219](#)
- Starting difficulties
 - jump-starting [219](#)
- Starting the engine
 - start/stop button [50](#)
- State/province, for navigation [121](#)
- Station, refer to Radio [143](#)
- Station, selecting
 - radio [143](#)
- Status of this Owner's Manual at time of printing [5](#)
- Steam jet [208](#), [209](#)

- Steering wheel [46](#)
 - adjustment [46](#)
 - buttons on steering wheel [11](#)
 - lock [50](#)
 - locking with Comfort Access [35](#)
 - shift paddles [57](#)
- Steering wheel buttons, refer to Shift paddles [57](#)
- Steptronic, refer to Automatic transmission with Steptronic [53](#)
- Storage [211](#)
- Storage compartments [104](#)
- Storage nets [106](#)
- Stored trip, calling up [129](#)
- Storing a destination in the address book [123](#)
- Storing music [158](#)
- Storing seat positions, refer to Seat and mirror memory [43](#)
- Storing tires [200](#)
- Stowage, refer to Storage compartments [104](#)
- Stowing cargo [116](#)
- Street, entering, navigation [122](#)
- Summer tires, refer to Wheels and tires [194](#)
- Surface ice, refer to Outside temperature warning [64](#)
- Surround [141](#)
- SVCD [153](#)
- SW, waveband [143](#)
- Switches, refer to Cockpit [10](#)
- Switching off
 - engine [52](#)
- Switching off the engine
 - start/stop button [50](#)
- Switching on
 - audio [140](#)
 - CD changer [140](#)
 - CD player [140](#)
 - radio [140](#)
- Symbols [4](#)
 - status information [20](#)
- T**
- Tachometer [64](#)
- Tailgate
 - opening from inside [32](#)
- Tailgate, refer to Luggage compartment lid [32](#)
- Tail lamps [214](#)
 - replacing bulb [214](#)
- Tank contents, refer to Capacities [228](#)
- Technical data [226](#)
 - capacities [228](#)
 - dimensions [227](#)
- Technical modifications, refer to For your own safety [5](#)
- Telephone [170](#)
 - installation location, refer to Center armrest [104](#)
 - refer to separate Owner's Manual
 - voice commands [178](#)
- TeleService [185](#)
- TeleService Diagnosis [186](#)
- TeleService Help [186](#)
- Temperature
 - air conditioner [95](#)
 - automatic climate control [96](#)
 - changing unit of measure [68](#)
 - coolant, refer to Coolant temperature [65](#)
- Temperature display
 - outside temperature [64](#)
 - outside temperature warning [64](#)
 - setting the units [68](#)
- Tempomat, refer to Cruise control [61](#)
- Tensioning straps, refer to Securing cargo [116](#)
- The individual vehicle [5](#)
- Third brake lamp, refer to Center brake lamp [215](#)
- Through-loading opening with integrated transport bag [106](#)
- Tilt alarm sensor [34](#)
- Tilt function, passenger-side mirror [46](#)
- Tire inflation pressure [194](#)
 - loss [81](#), [83](#)
- Tire pressure monitoring, refer to Flat Tire Monitor [81](#)
- Tire Pressure Monitor TPM [82](#)
 - resetting the system [83](#)
 - system limitations [82](#)
 - warning lamp [83](#)
- Tire puncture, refer to Flat Tire Monitor [81](#)
- Tire Quality Grading [197](#)
- Tires
 - age [197](#), [199](#)
 - air loss [83](#)
 - breaking in [112](#)
 - changing, refer to Changing wheels [215](#)
 - condition [198](#)
 - damage [198](#)
 - inflation pressure [194](#)
 - labels [197](#)
 - minimum tread depth [198](#)
 - new wheels and tires [199](#)
 - pressure monitoring, refer to Flat Tire Monitor [81](#)
 - pressure monitoring, refer to Tire Pressure Monitor TPM [82](#)
 - puncture [81](#)
 - replacing [199](#)
 - run-flat [199](#)
 - size [197](#)
 - storage [200](#)
 - tread depth [198](#)
 - wear indicators, refer to Minimum tread depth [198](#)
 - wheel/tire combination, refer to Correct wheels and tires [199](#)
 - winter tires [200](#)
- TMC station, refer to Traffic bulletins [133](#)
- Tone
 - control [140](#)
 - middle setting [142](#)
- Tools, refer to Onboard vehicle tool kit [212](#)

Top, refer to Retractable hardtop [38](#)
Top 50 of music collection [160](#)
Torque, refer to Engine data [226](#)
Tow bar [221](#)
Tow fitting [220](#)
– screw thread [220](#)
Tow fittings for tow-starting and towing away [220](#)
Towing [220](#)
– car with automatic transmission [220](#)
– methods [221](#)
Towing and tow-starting [220](#)
Town/city, for navigation [121](#)
Tow rope [222](#)
Tow-starting [220](#), [222](#)
TPM, refer to Tire Pressure Monitor [82](#)
Track
– selecting on CD [152](#)
Traction control, refer to Dynamic Stability Control DSC [78](#)
TRACTION program, Dynamic Driving Control [79](#)
Traffic bulletins
– categories [135](#)
Traffic bulletins, filtering [135](#)
Traffic bulletins for navigation [133](#)
– during destination guidance [135](#)
– in map view [135](#)
Traffic jam
– displaying traffic bulletins [133](#)

Transmission
– automatic transmission with Steptronic [53](#)
– dual clutch transmission [55](#)
– Launch Control [58](#)
– manual transmission [53](#)
– neutral [56](#)
– overriding selector lever lock for automatic transmission with Steptronic [55](#)
– reverse gear [56](#)
– transmission lock, releasing manually [58](#)
Transmission interlock
– refer to Changing selector lever position [54](#)
– refer to P Park [54](#)
Transmission lock, releasing manually [58](#)
Transmission positions [56](#)
Transporting children safely [48](#)
Transport securing devices, refer to Securing cargo [116](#)
Travel instructions, refer to Voice instructions [132](#)
Tread depth, refer to Minimum tire tread [198](#)
Trip, deleting [129](#)
Trip, storing [128](#)
Trip-distance counter, refer to Trip odometer [64](#)
Triple turn signal activation [60](#)
Trip odometer [64](#)
Trips, changing [129](#)
Turning circle, refer to Dimensions [227](#)
Turn signal indicators
– indicator/warning lamp [12](#)
– triple turn signal [60](#)
Turn signals [59](#)
Tying down loads, refer to Cargo loading [116](#)

U

Uniform Tire Quality Grading/UTQR [197](#)

Units
– average consumption [68](#)
– temperature [68](#)
Universal garage door opener, refer to Integrated universal remote control [100](#)
Universal mobile phone preparation package, refer to separate Owner's Manual
Universal remote control [100](#)
Unlatching, refer to Unlocking [34](#)
Unlocking
– from inside [32](#)
– from outside [29](#)
– luggage compartment lid [35](#)
– setting unlocking characteristics [29](#)
– without remote control, refer to Comfort Access [34](#)
Updating the navigation data [120](#)
USB audio interface [163](#)
USB interface [103](#)

V

VCD [153](#)
Vehicle
– battery [216](#)
– breaking in [112](#)
– cargo loading [115](#)
– Identification Number, refer to Engine compartment [202](#)
– measurements, refer to Dimensions [227](#)
– parking [52](#)
– weight [228](#)
Vehicle jack [215](#)
Vehicle storage [211](#)
Ventilation [98](#)
– air conditioner [95](#)
– draft-free [95](#), [98](#)
Ventilation, refer to Climate [93](#)
Vents, refer to Air vents [93](#)
Vents, refer to Ventilation [95](#), [98](#)
Video menu [154](#)
Video playback [153](#)

Voice, refer to Destination guidance through voice instructions [132](#)
 Voice commands
 – short commands [229](#)
 – telephone [178](#)
 Voice instructions from navigation system [132](#)
 – repeating [132](#)
 – switching on/off [132](#)
 – volume [132](#)
 Voice phone book* [179](#)
 Volume [140](#)
 – audio sources [140](#)
 – fuel tank, refer to Capacities [228](#)
 – mobile phone [173](#)
 – voice instructions [132](#)
 Volume balance, tone setting [142](#)

W

Warning and indicator lamps [13](#)

Warning messages, refer to
 Check Control [73](#)
 Warning triangle [219](#)
 Washer fluid [61](#)
 – content of the reservoir [61](#)
 Washer fluid reservoir [61](#)
 Water on roads, refer to
 Driving through water [114](#)
 Water penetration [208](#), [209](#)
 Waveband on the radio [143](#)
 Wear indicators in tires, refer to Minimum tread depth [198](#)
 Weights [228](#)
 Welcome lamps [88](#)
 Wheel/tire combination, refer to Correct wheels and tires [199](#)
 Wheelbase, refer to
 Dimensions [227](#)
 Wheels, new [199](#)
 Wheels and tires [194](#)
 Width, refer to
 Dimensions [227](#)
 Wind deflector [39](#)
 Windows [36](#)
 – convenient operation [30](#)
 – opening, closing [37](#)
 – pinch protection system [37](#)
 Windows, defrosting, refer to
 Defrosting windows [95](#)
 Windows, defrosting and defogging
 – air conditioner [95](#)
 Windows, indicator on Control
 Display [16](#)
 Windshield
 – cleaning [61](#)
 – defrosting and defogging [95](#)
 Windshield, defrosting, refer to
 Defrosting windows [95](#)
 Windshield wash [60](#)
 – filling capacity, reservoir [228](#)
 – nozzles [61](#)
 – reservoir for washer fluid [61](#)
 – washer fluid [61](#)
 Windshield wiper blades, changing [212](#)
 Windshield wipers, refer to
 Wiper system [60](#)

Winter tires [200](#)
 – storage [200](#)
 Wiper blade replacement [212](#)
 Wiper system [60](#)
 Word-matching principle for navigation [129](#)
 Work in the engine compartment [201](#)
 Wrench/screwdriver, refer to
 Onboard vehicle tool kit [212](#)

X

Xenon lamps
 – replacing bulbs [213](#)

Y

Your individual vehicle
 – settings, refer to Personal Profile [28](#)

More about BMW

bmwusa.com



The Ultimate
Driving Machine



01 41 2 602 883 Ue iDrive